

ACTION / DESCRIPTION

1. Press the Timebase menu key.
2. Select the time/div parameter with the top softkey, if it is not already selected.

You can always tell when a numeric parameter is selected because its background is brighter than other parameters on the same display. (Compare the brightness of the time/div background to Delay, third from the top.)

3. Rotate the knob to set the time/div to 50 μ s or use the Entry keypad to enter 50 μ s.

You can more easily see that in making the change to the new frequency, the VCO signal goes above the target frequency before it settles at the new frequency; the overshoot is plainly visible.

