



Agilent 75000 Series B

Agilent E1326B 5 1/2-Digit Multimeter

Service Manual

Enclosed is the Service Manual for the Agilent E1326B 5 1/2-Digit Multimeter. Insert this manual, along with any other VXIbus manuals that you have, into the binder that came with your Agilent Technologies mainframe.



Agilent Technologies



Manual Part Number: E1326-90017
Printed in Malaysia E0306

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (formerly National Bureau of Standards), to the extent allowed by that organization's calibration facility, and to the calibration facilities of other International Standards Organization members.

Warranty

This Agilent Technologies product is warranted against defects in materials and workmanship for a period of one year from date of shipment. Duration and conditions of warranty for this product may be superseded when the product is integrated into (becomes a part of) other Agilent products. During the warranty period, Agilent Technologies will, at its option, either repair or replace products which prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent and Agilent shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent from another country.

Agilent warrants that its software and firmware designated by Agilent for use with a product will execute its programming instructions when properly installed on that product. Agilent does not warrant that the operation of the product, or software, or firmware will be uninterrupted or error free.

Limitation Of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied products or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

The design and implementation of any circuit on this product is the sole responsibility of the Buyer. Agilent does not warrant the Buyer's circuitry or malfunctions of Agilent products that result from the Buyer's circuitry. In addition, Agilent does not warrant any damage that occurs as a result of the Buyer's circuit or any defects that result from Buyer-supplied products.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. Agilent SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Exclusive Remedies

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. Agilent SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Notice

The information contained in this document is subject to change without notice. Agilent Technologies MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Agilent shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material. This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Agilent Technologies, Inc. Agilent assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Agilent.

U.S. Government Restricted Rights

The Software and Documentation have been developed entirely at private expense. They are delivered and licensed as "commercial computer software" as defined in DFARS 252.227- 7013 (Oct 1988), DFARS 252.211-7015 (May 1991) or DFARS 252.227-7014 (Jun 1995), as a "commercial item" as defined in FAR 2.101(a), or as "Restricted computer software" as defined in FAR 52.227-19 (Jun 1987)(or any equivalent agency regulation or contract clause), whichever is applicable. You have only those rights provided for such Software and Documentation by the applicable FAR or DFARS clause or the Agilent standard software agreement for the product involved.

Agilent E1326B 5 1/2-Digit Multimeter Service Manual
Edition 3 Rev 2

Copyright © 1996-2006 Agilent Technologies, Inc. All Rights Reserved.

Printing History


The Printing History shown below lists all Editions and Updates of this manual and the printing date(s). The first printing of the manual is Edition 1. The Edition number increments by 1 whenever the manual is revised. Updates, which are issued between Editions, contain replacement pages to correct the current Edition of the manual. Updates are numbered sequentially starting with Update 1. When a new Edition is created, it contains all the Update information for the previous Edition. Each new Edition or Update also includes a revised copy of this printing history page. Many product updates or revisions do not require manual changes and, conversely, manual corrections may be done without accompanying product changes. Therefore, do not expect a one-to-one correspondence between product updates and manual updates.

Edition 1 (Part Number E1326-90015)..... March 1991
Update 1 (Part Number E1326-90092)..... August 1991
Edition 2 (Part Number E1326-90016)..... January 1993
Edition 3 (Part Number E1326-90017)..... April 1996
Edition 3 Rev 2 (Part Number E1326-90017) March 2006

Safety Symbols



Instruction manual symbol affixed to product. Indicates that the user must refer to the manual for specific WARNING or CAUTION information to avoid personal injury or damage to the product.



Alternating current (AC).



Direct current (DC).




Indicates hazardous voltages.



Indicates the field wiring terminal that must be connected to earth ground before operating the equipment—protects against electrical shock in case of fault.

WARNING

Calls attention to a procedure, practice, or condition that could cause bodily injury or death.



Frame or chassis ground terminal—typically connects to the equipment's metal frame.

CAUTION

Calls attention to a procedure, practice, or condition that could possibly cause damage to equipment or permanent loss of data.

WARNINGS

The following general safety precautions must be observed during all phases of operation, service, and repair of this product. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the product. Agilent Technologies assumes no liability for the customer's failure to comply with these requirements.

Ground the equipment: For Safety Class 1 equipment (equipment having a protective earth terminal), an uninterruptible safety earth ground must be provided from the mains power source to the product input wiring terminals or supplied power cable.

DO NOT operate the product in an explosive atmosphere or in the presence of flammable gases or fumes.

For continued protection against fire, replace the line fuse(s) only with fuse(s) of the same voltage and current rating and type. DO NOT use repaired fuses or short-circuited fuse holders.

Keep away from live circuits: Operating personnel must not remove equipment covers or shields. Procedures involving the removal of covers or shields are for use by service-trained personnel only. Under certain conditions, dangerous voltages may exist even with the equipment switched off. To avoid dangerous electrical shock, DO NOT perform procedures involving cover or shield removal unless you are qualified to do so.

DO NOT operate damaged equipment: Whenever it is possible that the safety protection features built into this product have been impaired, either through physical damage, excessive moisture, or any other reason, REMOVE POWER and do not use the product until safe operation can be verified by service-trained personnel. If necessary, return the product to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

DO NOT service or adjust alone: Do not attempt internal service or adjustment unless another person, capable of rendering first aid and resuscitation, is present.

DO NOT substitute parts or modify equipment: Because of the danger of introducing additional hazards, do not install substitute parts or perform any unauthorized modification to the product. Return the product to an Agilent Technologies Sales and Service Office for service and repair to ensure that safety features are maintained.

Declaration of Conformity
according to ISO/IEC Guide 22 and CEN/CE NELEC EN 45014

Manufacturer's Name: Agilent Technologies, Inc.
Loveland Manufacturing Center

Manufacturer's Address: 815 14th Street S.W.
Loveland, Colorado 80537

declares, that the product:

Product Name: B-Size VXI 5 1/2 Digit Multimeter

Model Number: E1326B

Product Options: All

conforms to the following Product Standards:

Safety: IEC 61010-1:1990+A1:1992+A2:1995/EN61010-1:1993+A2 1995
Canada: CSA C22.2 No. 1010.1:1992
UL 3111-1:1994

EMC: IEC 61326-1:1997+A1:1998/EN 61326-1:1997+A1:1998
CISPR 11:1997+A1:1997/EN55011:1998: Group 1, Class A ^[1]
IEC 61000-4-2:1995+A1:1998 / EN 61000-4-2:1995: 4kV CD, 8kV AD
IEC 61000-4-3:1995 / EN 61000-4-3:1995: 3 V/m, 80-1000 MHz
IEC 61000-4-4:1995 / EN 61000-4-4:1995: 0.5kV signal lines, 1kV power lines
IEC 61000-4-5:1995 / EN 61000-4-5:1995: 0.5 kV line-line, 1 kV line-ground
IEC 61000-4-6:1996 / EN 61000-4-6:1996: 3V, 0.15-80 MHz
IEC 61000-4-11:1994 / EN 61000-4-11:1994: I cycle, 100%

Canada: ICES-001:1998
Australia/New Zealand: AS/NZS 2064.1

Supplemental Information:

[1] The product was tested in a typical configuration with Agilent Technologies test systems.



Date: September 5, 2000


Jim White, QA Manager

For further information, please contact your local Agilent Technologies sales office, agent or distributor.

European contact: Your local Agilent Technologies Sales and Service Office or Agilent Technologies GmbH, Department HQ-TRE, Herrenberger Straße 130, D-71034 Böblingen, Germany (FAX +49-7031-14-3143).

Agilent 75000 Series B Service Documentation

Suggested Sequence to Use Manuals



Manual Descriptions

Installation and Getting Started Guide. Contains step-by-step instructions for all aspects of plug-in module and mainframe installation. This guide also contains introductory programming information and examples.

Agilent Mainframe User's Manual. Contains programming information for the mainframe, front panel operation information (for the Agilent E1301B mainframe), and general programming information for instruments installed in the mainframe.

Plug-In Module User's Manuals. Contains plug-in module programming and configuration information. These manuals contain examples for the most-used module functions, and a complete SCPI command reference for the plug-in module.

Agilent Mainframe Service Manual. Contains service information for the mainframe. This manual contains information for ordering replaceable parts and exchanging assemblies. Also contains information and procedures for performance verification, adjustment, preventive maintenance, troubleshooting, and repair.

Plug-In Module Service Manuals. Contains plug-in module service information. These manuals contain information for exchanging the module or ordering replaceable parts. Depending on the module, information and procedures for functional verification, operation verification, performance verification, adjustment, preventive maintenance, troubleshooting, and repair is also provided.

What's in this Manual

Manual Overview

This manual shows how to service the Agilent E1326B 5 1/2-Digit Multimeter. Additional manuals which may be required for servicing the multimeter include the *Agilent E1326B/E1411B User's Manual* which contains multimeter operation, installation, and configuration information, and the appropriate mainframe user's manual(s) for mainframe operation, installation and configuration information.

Manual Content

Chapter	Title	Content
1	General Information	Provides a basic description, and lists available options and accessories. Also lists the tools and test equipment required for service.
2	Installation	Procedures to install the multimeter, perform initial inspection, prepare for use, and store and ship the multimeter.
3	Operating Instructions	Procedures to operate the multimeter, perform scheduled preventive maintenance, and perform operator's check.
4	Verification Tests	Functional verification, operation verification, and performance verification tests to test the multimeter.
5	Adjustments	Procedures to adjust the multimeter to within its rated specifications.
6	Replaceable Parts	Lists part numbers for user replaceable parts in the multimeter. Provides information on ordering spare parts and module/assembly exchange.
7	Manual Changes	Information to adapt this manual to instruments whose serial numbers are lower than those listed on the title page.
8	Service	Procedures to aid in fault isolation and repair of the multimeter.
A	Calculating Multimeter Accuracy	Shows how multimeter accuracy, measurement uncertainty, and test accuracy ratios (TARs) are calculated.

Contents

Chapter 1 - General Information

Introduction	1-1
Safety Considerations	1-1
Multimeter Description	1-3
Recommended Test Equipment	1-5

Chapter 2 - Installation

Introduction	2-1
Initial Inspection	2-1
Preparation for Use	2-1
Shipping the Multimeter	2-2

Chapter 3 - Operating Instructions

Introduction	3-1
Multimeter Operation	3-1
Operator's Check	3-1

Chapter 4 - Verification Tests

Introduction	4-1
Test Conditions/Procedures	4-1
Performance Test Record	4-1
Verification Test Examples	4-2
Functional Verification Test	4-2
Self-Test Procedure	4-2
Example: Self-Test	4-3
Operation Verification Tests	4-3
Performance Verification Tests	4-3
Test 4-1: DC Voltage Test (Zero Volt Input)	4-4
Test 4-2: DC Voltage Test (DCV Input)	4-6
Test 4-3: AC Voltage Test	4-8
Test 4-4: Resistance Test (4-Wire Ohms)	4-11
Performance Test Record	4-14

Chapter 5 - Adjustments

Introduction	5-1
DC Voltage Adjustments	5-2
AC Voltage Adjustments	5-5
Resistance Adjustments	5-7
Calibration Errors	5-10

Chapter 6 - Replaceable Parts

Introduction	6-1
Exchange Assemblies	6-1
Ordering Information	6-1
Replaceable Parts List	6-1
Reference Designators	6-2
Code List of Manufacturers	6-3

Chapter 7 - Manual Changes

Introduction	7-1
------------------------	-----

Chapter 8 - Service

Introduction	8-1
Equipment Required	8-1
Service Aids	8-1
Recommended Repair Strategy	8-2
Troubleshooting Techniques	8-2
Identifying the Problem	8-2
Testing Assemblies	8-3
Repair/Maintenance Guidelines	8-5
ESD Precautions	8-5
Removing A2 Inguard PCA	8-6
Removing Binding Posts	8-7
Soldering Printed Circuit Boards	8-7
Post-Repair Safety Checks	8-8

Appendix A - Calculating Multimeter Accuracy

Introduction	A-1
Calculating Multimeter Accuracy	A-2
DC Voltage Accuracy Equations	A-2
AC Voltage Accuracy Equations	A-3
4-Wire Ohms Accuracy Equations	A-3
Calculating Measurement Uncertainty	A-4
Calculate DCV Measurement Uncertainty	A-4
Calculate ACV Measurement Uncertainty	A-5
Calculate Resistance Measurement Uncertainty	A-5
Calculating Test Accuracy Ratios (TARs)	A-6

Appendix B - Verification Tests - C Programs

Functional Verification Test	B-1
Performance Verification Tests	B-2
Adjustments	B-6

General Information

Introduction

This Agilent E1326B Service Manual contains information required to test, adjust, troubleshoot, and repair the Agilent E1326B B-Size VXI 5 1/2-Digit Multimeter (multimeter). See the *Agilent E1326B/E1411B User's Manual* for additional information on the Agilent E1326B multimeter. Figure 1-1 shows the Agilent E1326B multimeter and accessories supplied.




Figure 1-1. Agilent E1326B Multimeter and Accessories

Safety Considerations

This product is a Safety Class I instrument that is provided with a protective earth terminal when installed in the mainframe. The mainframe, multimeter, and all related documentation should be reviewed for familiarization with safety markings and instructions before operation or service.

Refer to the WARNINGS page (page iii) in this manual for a summary of safety information. Safety information for preventive maintenance, testing, adjusting, and service follows and is also found throughout this manual.

Warnings and Cautions

This section contains WARNINGS which must be followed for your protection and CAUTIONS which must be followed to avoid damage to the equipment when performing instrument maintenance or repair.

WARNING

SERVICE-TRAINED PERSONNEL ONLY. The information in this manual is for service-trained personnel who are familiar with electronic circuitry and are aware of the hazards involved. To avoid personal injury or damage to the instrument, do not perform procedures in this manual or do any servicing unless you are qualified to do so.

CHECK MAINFRAME POWER SETTINGS. Before applying power, verify that the mainframe setting matches the line voltage and the correct fuse is installed. An uninterruptible safety earth ground must be provided from the main power source to the mainframe input wiring terminals, power cord, or supplied power cord set.

GROUNDING REQUIREMENTS. Interruption of the protective (grounding) conductor (inside or outside the mainframe) or disconnecting the protective earth terminal will cause a potential shock hazard that could result in personal injury. (Grounding one conductor of a two-conductor outlet is not sufficient protection.)

COMMON GROUND. Verify that a common ground exists between the unit under test and the multimeter (via the mainframe) prior to energizing either unit.

IMPAIRED PROTECTION. Whenever it is likely that instrument protection has been impaired, the mainframe must be made inoperative and be secured against any unintended operation.

REMOVE POWER IF POSSIBLE. Some procedures in this manual may be performed with power supplied to the mainframe while protective covers are removed. Energy available at many points may, if contacted, result in personal injury. (If maintenance can be performed without power applied, the power should be removed.)

USING AUTOTRANSFORMERS. If the mainframe is to be energized via an autotransformer (for voltage reduction) make sure the common terminal is connected to neutral (that is, the grounded side of the main's supply).

WARNING

CAPACITOR VOLTAGES. Capacitors inside the mainframe may remain charged even when the mainframe has been disconnected from its source of supply.

USE PROPER FUSES. For continued protection against fire hazard, replace the line fuse(s) only with fuses of the same current rating and type (such as normal blow, time delay, etc.). Do not use repaired fuses or short-circuited fuseholders.

CAUTION

Static electricity is a major cause of component failure. To prevent damage to the electrical components in the multimeter, observe anti-static techniques whenever working on the multimeter.

Multimeter Description

The Agilent E1326B multimeter is an "instrument" in the slots of a VXIbus mainframe. As such, it is assigned an error queue, input and output buffers, status registers, and is allocated a portion of mainframe memory for reading storage.

NOTE

Instruments are based on the logical addresses of the plug-in modules. See the Agilent 75000 Series B Installation and Getting Started Guide to set the addresses to create an instrument.

The instrument may consist of the multimeter only (stand-alone operation), or can include relay or FET multiplexers (scanning multimeter operation). The instrument can be operated from the mainframe front panel or from a computer using Standard Commands for Programmable Instruments (SCPI).

In stand-alone operation, input signals are connected to the multimeter's external (faceplate) terminals. In scanning multimeter operation, input signals are connected to the multiplexer channels. The multimeter is linked to relay multiplexers via an analog bus cable. The multimeter is linked to FET multiplexers via an analog bus cable and a digital bus cable.

Multimeter Specifications

Multimeter specifications are listed in *Appendix A* of the *Agilent E1326B/E1411B User's Manual*. These specifications are the performance standards or limits against which the instrument may be tested.

Multimeter Serial Numbers

Multimeters covered by this manual are identified by a serial number prefix listed on the title page. Agilent uses a two part serial number in the form XXXXAYYYYY, where XXXX is the serial prefix, A is the country of origin (A= USA) and YYYYY is the serial suffix. The serial number prefix identifies a series of identical instruments. The serial number suffix is assigned sequentially to each instrument.

If the serial number prefix of your instrument is greater than the one listed on the title page, a Manual Update (as required) will explain how to adapt this manual to your instrument. If the serial number prefix of your instrument is lower than the one listed on the title page, information contained in Chapter 7 (Manual Changes) will explain how to adapt this manual to your instrument.

Multimeter Options

There are no electrical or mechanical options available for the Agilent E1326B multimeter. However, you can order Option 1BN which provides a MIL-STD-45662A Calibration Certificate, or Option 1BP which provides the Calibration Certificate and measurement data. Contact your nearest Agilent Technologies Sales and Service Office for information on Options 1BN and 1BP.

Field Installation Kits

An Agilent E1326B multimeter can be installed inside the Agilent E1300B/E1301B mainframe (using one or two A-size slots). If you have an Agilent E1326B multimeter, order installation kit E1326-80004 and (optionally) installation kit E1326-80005.

As shown in Figure 1-2, the E1326-80004 kit provides the multimeter front panel without binding posts. The E1326-80004 kit also contains required hardware and installation instructions. The E1326-80005 installation kit adds another front panel with binding posts. (If you use the E1326-80005 kit, a second A-size slot is required.)




Figure 1-2. Agilent E1326B Field Installation Kits

Recommended Test Equipment

Table 1-1 lists the test equipment recommended for testing, adjusting and servicing the multimeter. Essential requirements for each piece of test equipment are described in the Requirements column.

Table 1-1. Recommended Test Equipment

Instrument	Requirements	Recommended Model	Use*
Controller, GPIB	GPIB compatibility as defined by IEEE Standard 488-1978 and the identical ANSI Standard MC1.1: SH1, AH1, T2, TE0, L2, LE0, SR0, RL0, PP0, DC0, DT0, and Cl, 2, 3, 4, 5	HP Series 300 or IBM compatible PC with BASIC	A,O,F, P,T
Mainframe	Compatible with multimeter	Agilent E1300B, E1301B, E1302A, or E1401B/T, E1421A (requires E1405A/B or E1406A)	A,O,F, P,T
AC Standard	Voltage Range 0.1 V to 300 V	Datron 4708 with Option 20	A,P
DC Standard	Voltage Range 0.07 V to 300 V	Datron 4708 with Option 10	A,P
Resistance Standard	Values 1 k Ω to 1 M Ω	Datron 4708 with Option 30	A,P
Digital Multimeter	General Purpose Voltage and Resistance	Agilent 3458	T

* A = Adjustments, F = Functional Verification, M = Preventive Maintenance, O = Operation Verification Tests, P = Performance Verification Tests, T = Troubleshooting

NOTES:

Introduction

This chapter provides information to install the Agilent E1326B multimeter, including initial inspection, preparation for use, environment, storage and shipment.

Initial Inspection

Inspect the shipping container for damage. If the shipping container or cushioning material is damaged, keep the container until the shipment contents have been checked and the instrument has been checked mechanically and electrically. See Chapter 1 (Figure 1-1) for shipment contents. See Chapter 4 for procedures to check electrical performance.

WARNING

To avoid possible hazardous electrical shock, do not perform electrical tests if there are signs of shipping damage to any portion of the outer enclosure (covers, panels, etc.).

If the contents are incomplete, if there is mechanical damage or defect, or if the instrument does not pass the electrical performance tests, notify your nearest Agilent Technologies Sales and Service Office. If the shipping container is damaged or the cushioning material shows signs of stress, notify the carrier as well as Agilent, and keep the shipping materials for the carrier's inspection.

Preparation for Use

See Chapter 2 of the *Agilent E1326B/E1411B User's Manual* to prepare the Agilent E1326B multimeter for use. See the appropriate mainframe user's manual(s) to prepare your mainframe. If your mainframe is not manufactured by Agilent, consult the manufacturer for a list of available manual(s).

Recommended operating environment for the Agilent E1326B multimeter is 0°C to + 55°C with humidity < 65% relative (0 °C to + 40°C). The instrument should be stored in a clean, dry environment. For storage and shipment, the temperature range is -40°C to + 75°C with humidity < 65% relative (0°C to + 40°C).

Shipping the Multimeter

If you need to return the Agilent E1326B multimeter to Agilent Technologies, first remove any adapters or connectors before packaging the instrument for shipment. When you return the instrument to Agilent, attach a tag to the instrument identifying the owner and indicating service or repair required. In any correspondence, refer to the instrument by model number and full serial number.

When shipping the instrument, we recommend using containers and materials identical to those used in factory packaging, which are available through Agilent Sales and Service Offices. Mark the shipping container "FRAGILE" to assure careful handling.

If you use other (commercially available) shipping materials, wrap the instrument in heavy paper or plastic. Use a strong shipping container. A double-wall carton of 2.4 MPa (350 psi) test material is adequate.

Use enough shock-absorbing material (75 to 100 mm layer; 3 to 4 inches) around all sides of the instrument to provide firm cushion and prevent movement in the container. Protect the front panel with cardboard. Seal the shipping container securely and mark the container "FRAGILE" to assure careful handling.

Operating Instructions

Introduction

This chapter lists operating information for the Agilent E1326B multimeter, including:

- Multimeter operation
- Operator's check (self-test)

Multimeter Operation

See the *Agilent E1326B/E1411B 5 1/2-Digit Multimeter User's Manual* for multimeter operation, including:

- Getting started
- Configuring the multimeter
- Using the multimeter
- Understanding the multimeter

- Multimeter command reference
- Multimeter specifications
- Multimeter error messages
- Register-based programming

Operator's Check

The Operator's Check for the Agilent E1326B multimeter consists of sending the self-test (*TST?) command and checking the return. The operator's check can be used at any time to verify the multimeter is connected properly and is responding to the self-test command.

As required, see the mainframe user's manual for information on address selection. See the *Agilent E1326B/E1411B User's Manual* for information on multimeter SCPI commands.

Self-Test Procedure

1. Verify the multimeter is properly installed in the mainframe and the mainframe has passed its power-on sequence test.

2. Execute the multimeter functional test using the *TST? command (see example following).

3. A "0" returned means no self-test failure, while "1", "2", "3", or "4" returned means a failure was detected. See *Chapter 8 - Service* for troubleshooting information (see NOTE following).

NOTE

Test failures can be caused by improper cabling, improper selection of the interface select code, primary, and/or secondary address setting. Verify proper connection and address selection before troubleshooting.

**Example:
Multimeter
Self-Test**

An example follows which uses an HP 9000 Series 300 computer with BASIC and a multimeter address of 70903.

10 OUTPUT 70903;"*TST?"

*Send the self-test
command*

20 ENTER 70903;A

Enter self-test result

30 PRINT A

40 END

Verification Tests

Introduction

The three levels of test procedures described in this chapter are used to verify that the Agilent E1326B multimeter:

- is fully functional (Functional Verification)
- meets selected testable specifications (Operation Verification)
- meets all testable specifications (Performance Verification)

WARNING

Do not perform any of the following verification tests unless you are a qualified, service-trained person and have read the WARNINGS and CAUTIONS in Chapter 1.

Test Conditions/ Procedures

For valid tests, all test equipment and the multimeter must have a one hour warmup, the line voltage must be $115/230 \text{ Vac} \pm 10\%$, and multimeter Auto Zero must be set. See Table 1-1, *Recommended Test Equipment* for test equipment requirements.

For best test accuracy, the ambient temperature of the test area should be between 18°C and 28°C and stable to within $\pm 1^{\circ}\text{C}$. You should perform the Performance Verification tests at least once a year. For heavy use or severe operating environments, perform the tests more often.

The verification tests assume the person performing the tests understands how to operate the mainframe, multimeter and specified test equipment. The test procedures do not specify equipment settings for test equipment, except in general terms. It is assumed a qualified, service-trained person will select and connect the cables, adapters, and probes required for the test.

Performance Test Record

Table 4-1, *Agilent E1326B Performance Test Record*, at the end of this chapter provides space to enter the results of each Performance Verification test and to compare the results with the upper and lower limits for the test. You can make a copy of this form, if desired.

NOTE

The upper and lower limits in the Performance Test Record assume the test equipment used is calibrated and operating at peak performance. If this is not the case, problems can occur. For example, an uncalibrated source may cause what seems to be an inaccurate measurement. This condition must be considered when observed measurements do not agree with the performance test limits.

The value in the "Measurement Uncertainty" column of Table 4-1 is derived from the specifications for the source used for the test, and represents the expected accuracy of the source. The value in the "Test Accuracy Ratio (TAR)" column of Table 4-1 is the ratio of multimeter accuracy to measurement uncertainty, rounded to the nearest integer.

Verification Test Examples

Each Performance Verification Test includes an example program to perform the test. Each example uses address 70903 for the multimeter, and an HP 9000 Series 200/300 computer running BASIC commands. You may need to change the multimeter address and/or command syntax to perform the examples for your setup.

As required, see the mainframe user's manual for information on address selection and cabling guidelines. See the *Agilent E1326B/E1411B User's Manual* for information on multimeter Standard Commands for Programmable Instruments (SCPI) commands.

Functional Verification Test

The functional verification test for the Agilent E1326B multimeter consists of the multimeter self-test. You can perform this test any time to verify the multimeter is functional and is communicating with the mainframe, external computer and/or external terminal.

Self-Test Procedure

This test verifies the multimeter is communicating with the mainframe, external controller, and/or external terminal by performing a multimeter self-test. Do the following steps to perform the self-test:

1. Verify the multimeter is correctly installed in the mainframe.
2. Connect a power cable to the mainframe and set mainframe power ON. Verify proper mainframe power-up sequence. (See the mainframe user's manual for additional information.) If correct, proceed with step 3. If incorrect, troubleshoot the problem before proceeding.

3. Execute the multimeter functional verification test using the *TST? command. See the following example which uses an HP 9000 Series 300 computer with BASIC and a multimeter address of 70903.

4. A "0" returned means no failure, while "1", "2", "3" or "4" returned means a failure was detected. See *Chapter 8 - Service* for troubleshooting information.

NOTE

Test failures can be caused by improper selection of the interface select code, primary address setting, and/or secondary address setting. Verify proper address selection before troubleshooting.

Example: Self-Test

10 OUTPUT 70903;"* TST?"	<i>Send the self-test command</i>
20 ENTER 70903;A	<i>Enter the test result</i>
30 PRINT A	<i>Display the result</i>
40 END	

Operation Verification Tests

There are no operation verification tests for the Agilent E1326B multimeter. Use the Performance Verification tests for post-repair checkout.

Performance Verification Tests

Performance verification tests are used to check the multimeter's electrical performance against the specifications in *Appendix A - Specifications* of the *Agilent E1326B/E1411B User's Manual* as the performance standards. These tests are suitable for incoming inspection, troubleshooting, and preventive maintenance.

NOTE

When an Agilent E1326B is installed internal to the Agilent E1300B/E1301B mainframe, the (optional) Agilent E1326-80005 panel with binding posts is recommended to do the performance verification tests and adjustments. The binding posts provide a way to connect an external standard source directly to the internally-installed multimeter.

Test 4-1: DC Voltage Test (Zero Volt Input)

This test verifies DC Voltage accuracy on all five ranges with a zero volt input.

- Equipment Setup** 1. Connect the equipment as shown in Figure 4-1.




Figure 4-1. DC Voltage (Zero Volt Input) Setup

2. Set the Agilent E1326B multimeter as follows:

- Reset Multimeter * RST
- Auto Zero ON
- Power Line Cycles (PLC) 1
- Line Freq Reference (CAL:LFR) 50Hz or 60Hz

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

Test Procedure

1. Set the Agilent E1326B range to 0.113 V (0.125 V with 10% overrange) with MEAS:VOLT:DC? 0.1
2. Measure the input and verify the results are within specified limits (at the range selected for 1 PLC).

3. Repeat steps 1 and 2 for the following ranges:

E1326B Range	10% Overrange	Input
0.91 V	1 V	0 V
7.27 V	8 V	0 V
58.1 V	64 V	0 V
300 V	N/A	0 V

4. Remove power and disconnect test equipment.

Example: Zero Volt DCV Test

This example performs a DCV test for zero volts input and a power line reference frequency of 60 Hz. Change line 20 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

```

10  OUTPUT 70903;"* RST"           Resets and sets autozero
                                       ON and PLC to 1
20  OUTPUT 70903;"CAL:LFR 60"      Sets line reference to 60 Hz
30  OUTPUT 70903;"MEAS:VOLT:DC? .1" Measure 0.113 V range
40  ENTER 70903;A
50  PRINT A
60  OUTPUT 70903;"MEAS:VOLT:DC? .9" Measure 0.91 V range
70  ENTER 70903;B
80  PRINT B
90  OUTPUT 70903;"MEAS:VOLT:DC? 7" Measure 7.27 V range
100 ENTER 70903;C
110 PRINT C
120 OUTPUT 70903;"MEAS:VOLT:DC? 58" Measure 58.1 V range
130 ENTER 70903;D
140 PRINT D
150 OUTPUT 70903;"MEAS:VOLT:DC? 300" Measure 300 V range
160 ENTER 70903;E
170 PRINT E
180 END

```


Test 4-2: DC Voltage Test (DCV Input)

This test verifies DC Voltage accuracy on all five ranges with DC voltage inputs.

Equipment Setup

1. Connect the equipment as shown in Figure 4-2. You can connect to the E1326B OR the E1326-80005 terminals, but not to both.

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages which are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.

2. Set the Agilent E1326B multimeter as follows:




Figure 4-2. DC Voltage (DCV Input) Setup

- Reset Multimeter* RST
- Auto ZeroON
- Power Line Cycles (PLC)1
- Line Freq Reference (CAL:LFR)50Hz or 60Hz

NOTE

*RST sets Auto Zero to ON and Power Line Cycles to 1.

Test Procedure

1. Set the DC Standard (Datron 4708, Option 10) Output to 0.1 DCV.
2. Set the Agilent E1326B range to 0.113 V (0.125 V with 10% overrange) with CONF:VOLT:DC 0.1.
3. Measure the input with READ? and verify the results are within specified limits (at the range selected for 1 PLC).
4. Repeat steps 1 through 3 for the following DC Standard voltage settings and Agilent E1326B ranges:

E1326B Range	10% overrange	DC Std Output
0.91 V	1 V	0.9 V
7.27 V	8 V	7.0 V
58.1 V	64 V	58.0 V
300 V	N/A	300.0 V

5. Remove power and disconnect test equipment.

Example: DC Voltage Test (DCV Input)

This example performs a DCV test for DC volts input and a power line reference frequency of 60 Hz. Change line 80 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

NOTE

When connected to the Agilent E1326B multimeter, some DC Standards may exhibit voltage variations at the start of a measurement. The WAIT 1 statement (line 150) provides a one second wait before measurement to allow settling of the DC Standard output.

```
1  ! DC Voltage Performance Verification
2  !
10 OPTION BASE 1
20 DIM Range(5), Volts(5), Read_meas(5)
30 DATA 0.113, 0.91, 7.27, 58.1, 300.0
40 READ Range(*)
50 DATA 0.1, 0.9, 7.0, 58.0, 300.0
60 READ Volts(*)
70 OUTPUT 70903;"* RST"           Set autozero on and PLC 1
80 OUTPUT 70903;"CAL:LFR 60"    Set 60 Hz line frequency
90 FOR I= 1 TO 5
```

```

100 PRINT "Set DC Standard to ";Volts(I);" VDC"
110 PRINT "Press Continue when ready"
120 PAUSE
130 CLEAR SCREEN
140 OUTPUT 70903;"CONF:VOLT:DC ";Range(I) Set DCV, range
150 WAIT 1                               Wait for settling
160 OUTPUT 70903;"READ?"
170 ENTER 70903;Read_meas(I)             Enter DC voltage
180 NEXT I
190 FOR I= 1 TO 5
200 PRINT "Voltage on";Range(I);"V range = ";Read_meas(I); "VDC"
210 NEXT I
220 END

```

Test 4-3: AC Voltage Test

This test verifies AC voltage accuracy on the 87.5 mV and 300 V ranges using sine wave input at $\geq 50\%$ of full scale. The input frequency varies from 60 Hz to 10 kHz. The DC component must be $< 10\%$ of the AC component.

NOTE

The DC Voltage Performance test must be performed prior to the AC Voltage test to check the A/D accuracy on all ranges. If the DC Voltage test has not been performed, the AC voltage must be checked on all ranges.

Equipment Setup

1. Connect the equipment as shown in Figure 4-3. You can connect to the E1326B OR the E1326-80005 terminals, but not to both.




Figure 4-3. AC Voltage Setup

WARNING

The AC Standard (Datron 4708, Option 20) can produce dangerous voltages which are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.

2. Set the Agilent E1326B multimeter as follows:

- Reset Multimeter *RST
 - Auto Zero ON
 - Power Line Cycles (PLC) 1
 - Line Freq Reference (CAL:LFR) 50Hz or 60Hz
-

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

Test Procedure

1. Set the AC Standard (Datron 4708, Option 20) Output to 0.07 Vac at 60 Hz sine wave.
2. Set the Agilent E1326B range to 79.5 mV (87.5 mV with 10% overrange) using CONF:VOLT:AC .07.
3. Measure the AC input voltage with READ? and verify the results are within specified limits (at the range selected for 1 PLC).
4. Repeat steps 1 through 3 using the following AC Standard voltage and frequency settings, and Agilent E1326B ranges:

E1326B Range	10% overrange	AC Standard Output	
		Voltage (Vac)	Frequency (Hz)
79.5 mV	87.5 mV	0.07 V	5 kHz
79.5 mV	87.5 mV	0.07 V	10 kHz
300 V	N/A	300 V	5 kHz

5. Remove power and disconnect test equipment.

**Example:
AC Voltage
Test**

This example performs an ACV test for a power line reference frequency of 60 Hz. Change line 80 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

NOTE

When connected to the Agilent E1326B multimeter, some AC Standards may exhibit voltage variations at the start of a measurement. The WAIT 1 statement (line 160) allows settling time for the AC Standard output.

```
1  ! AC Voltage Performance Verification
2  !
10 OPTION BASE 1
20 DIM Read_meas(4),Source_volts(4),Source_freq(4)
30 DATA 0.07, 0.07, 0.07, 300.0
40 READ Source_volts(*)
50 DATA 60, 5000, 10000, 5000
60 READ Source_freq(*)
70 OUTPUT 70903;"* RST"           Set autozero on, PLC 1
80 OUTPUT 70903;"CAL:LFR 60"     Set 60 Hz line ref freq
90 FOR I= 1 TO 4
100 PRINT " 1. Set AC Standard output to";Source_volts(I);"Vac"
110 PRINT " 2. Set AC Standard frequency to";Source_freq(I);"Hz"
120 PRINT " 3. Press Continue when ready"
130 PAUSE
140 CLEAR SCREEN
150 OUTPUT 70903;"CONF:VOLT:AC ";Source_volts(I)
160 WAIT 1                       One second settling time
170 OUTPUT 70903;"READ?"
180 ENTER 70903;Read_meas(I)
190 NEXT I
200 FOR I= 1 TO 4
210 PRINT "Voltage for";Source_volts(I);" Vac range @";
Source_freq(I);"Hz = ";Read_meas(I);"Vac"
220 NEXT I
230 END
```

Test 4-4: Resistance Test (4-Wire Ohms)

This test verifies the 4-wire resistance accuracy of the 2k Ω , 131k Ω , and 1M Ω ranges.

NOTE

The DC Voltage performance test must be performed prior to the Resistance Test to check the A/D accuracy on all ranges. If the DC Voltage test has not been performed, resistance must be checked on all ranges at 0 and at 50% of full scale.

Equipment Setup

1. Connect the equipment as shown in Figure 4-4. You can connect to the E1326B OR to the E1326-80005, but not to both.




Figure 4-4. Resistance Test Setup

2. Set the Agilent E1326B multimeter as follows:

- Reset Multimeter *RST
- Auto Zero ON
- Power Line Cycles (PLC) 1
- Line Freq Reference (CAL:LFR) 50 Hz or 60 Hz

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

Test Procedure

1. Set the Resistance Standard (Datron 4708, Option 30) to 1 k Ω setting.
 2. Set the Agilent E1326B range to 1861 Ω (2048 Ω with 10% overrange) with CONF:FRES 1861.
 3. Measure the input resistance and verify the results are within specified limits (at the range selected for 1 PLC).
-

NOTE

For best measurement accuracy, you may want to measure the ACTUAL Resistance Standard value. You can do this by recording the front panel display of the resistance value, or measure the resistance with an Agilent 3458A multimeter or equivalent.

*For example, suppose the ACTUAL resistance value for the 1 k Ω setting is 1001.3 Ω . Then, the Lower Limit for this value = 1000.9 Ω and the Upper Limit = 1001.7 Ω . These limits would replace the existing limits of 999.6 Ω and 1000.4 Ω shown in Table 4-1. If the measured value falls within the **revised** limits, the test passes.*

4. Repeat steps 1 through 3 using the following Resistance Standard settings.

E1326B Range	10% overrange	Resistance Std Setting
119,156 Ω 1,048,576 Ω	131,052 Ω N/A	100 k Ω 1 M Ω

5. Remove power and disconnect test equipment.

Example: 4-Wire Ohms Test

This example performs a 4-wire ohms resistance test for a power line reference frequency of 60 Hz. Change line 80 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

The program also calculates the Upper Limit and Lower Limit values for the ACTUAL Resistance Standard resistance value (lines 170 -190). If the actual Resistance Standard value is different than 1 k Ω , 100 k Ω , or 1 M Ω , replace the Lower Limit and Upper Limit values shown in Table 4-1, *Performance Test Record*, with the values computed by the program.

```

1  ! 4-Wire Ohms Performance Verification
2  !
10 OPTION BASE 1
20 DIM Range(3),Source(3),Read_meas(3),Limit(3),Ohms(3)
30 DATA 1861, 119156, 1048576
40 READ Range(*)
50 DATA 1000, 100000, 1000000
60 READ Source(*)
70 OUTPUT 70903;"* RST" Sets autozero on and PLC
I
80 OUTPUT 70903;"CAL:LFR 60" Set 60 Hz line ref freq
90 FOR I= 1 TO 3
100 PRINT "1. Set Resistance Standard to";Source(I);"Ohms"
110 PRINT "2. Measure ACTUAL Resistance Standard value (in
Ohms)"
120 INPUT " Enter ACTUAL Resistance Standard value (in Ohms)
";Ohms(I)
130 CLEAR SCREEN
140 OUTPUT 70903;"CONF:FRES ";Range(I) Set 4-wire ohms,
range
150 OUTPUT 70903;"READ?"
160 ENTER 70903;Read_meas(I)
170 IF I= 1 THEN Limit(I)= .0004* Ohms(I)+ 2.0E-2 2 kOhm
limits
180 IF I= 2 THEN Limit(I)= .0004* Ohms(I)+ 1. 131 kOhm
limits
190 IF I= 3 THEN Limit(I)= .0004* Ohms(I)+ 10. 1 MOhm
limits
200 NEXT I
210 PRINT " Measured Source Low Limit High Limit"
220 PRINT " Resistance Resistance (Ohms) (Ohms)"
230 PRINT
240 Format:IMAGE 7D.3D,6X,7D.3D,6X,7D.3D,6X,7D.3D
250 FOR I= 1 TO 3
260 PRINT USING Format;Read_meas(I),Ohms(I),
Ohms(I)-Limit(I),Ohms(I)+ Limit(I)
270 NEXT I
280 END

```

Performance Test Record

Table 4-1, *Performance Test Record for the Agilent E1326B Multimeter*, is a form you can copy and use to record performance verification test results for the multimeter. Page 3 of Table 4-1 shows multimeter accuracy, measurement uncertainty and test accuracy ratio (TAR) values. See *Appendix A - Calculating Multimeter Accuracy* for example calculations of Table 4-1 entries.

NOTE

The accuracy, measurement uncertainty, and TAR values shown in Table 4-1 are valid ONLY for the specific test conditions, test equipment, and assumptions described. If you use different test equipment and/or change the test conditions, you will need to compute the specific values for your test setup.

Multimeter Accuracy

Accuracy is defined for DC Voltage, AC Voltage, and 4-Wire Resistance measurements using the 1-year specifications in *Appendix A - Specifications* in the *Agilent E1326B/E1411B User's Manual*. In Table 4-1, the "High Limit" and "Low Limit" columns represent the multimeter accuracy for the specified test conditions.

Measurement Uncertainty

For the performance verification tests in this manual, measurement uncertainties are calculated assuming a Datron 4708 source for inputs to the multimeter. Measurement uncertainties in Table 4-1 are calculated for the 90-day accuracy specifications in the *Datron 4708 User's Handbook*.

Test Accuracy Ratio (TAR)

In Table 4-1, the "Test Accuracy Ratio (TAR)" is calculated from (high limit - expected measurement)/measurement uncertainty. (To meet MIL-STD-45662A requirements, the TAR must be 4:1 or greater.) "N/A" means measurement uncertainty and TAR do not apply to the measurement. Although all TAR values are > 10:1, the entry for each value is > 10:1.

Table 4-1. Performance Test Record for the Agilent E1326B Multimeter (Page 1 of 3)

Test Facility:	
Name _____	Report No. _____
Address _____	Date _____
City/State _____	Customer _____
Phone _____	Tested by _____
Model _____	Ambient temperature _____ °C
Serial No. _____	Relative humidity _____ %
Options _____	Line frequency _____ Hz (nominal)
Firmware Rev. _____	
Special Notes:	

Table 4-1. Performance Test Record for the Agilent E1326B Multimeter (Page 2 of 3)

Model _____	Report No. _____	Date _____
-------------	------------------	------------

Test Equipment Used: Description	Model No.	Trace No.	Cal Due Date
1. DATRON 4708	_____	_____	_____
2. _____	_____	_____	_____
3. _____	_____	_____	_____
4. _____	_____	_____	_____
5. _____	_____	_____	_____
6. _____	_____	_____	_____
7. _____	_____	_____	_____
8. _____	_____	_____	_____
9. _____	_____	_____	_____
10. _____	_____	_____	_____
11. _____	_____	_____	_____
12. _____	_____	_____	_____
13. _____	_____	_____	_____
14. _____	_____	_____	_____
15. _____	_____	_____	_____
16. _____	_____	_____	_____
17. _____	_____	_____	_____
18. _____	_____	_____	_____
19. _____	_____	_____	_____
20. _____	_____	_____	_____

Table 4-1. Performance Test Record for the Agilent E1326B Multimeter (Page 3 of 3)

Model _____	Report No. _____	Date _____
-------------	------------------	------------

1-Year Specifications							
Test No.	Test Input	DMM Range	Low Limit	Measured Reading	High Limit	Meas Uncert*	Test Acc Ratio (TAR)**
DC Voltage (Zero Volts Input) (Values in Vdc)							
4-1	0	0.113	-.000005	_____	+.000005	N/A	N/A
	0	0.91	-.000015	_____		N/A	N/A
	0	7.27	-.00005	_____	+.000015	N/A	N/A
	0	58.1	-.001	_____		N/A	N/A
	0	300	-.005	_____	+.00005 +.001 +.005	N/A	N/A
DC Voltage (DCV Input) (Values in Vdc)							
4-2	0.1	0.113	0.09996	_____	0.10004	.0000030	> 10:1
	0.9	0.91	0.89978	_____	0.90022	.0000046	> 10:1
	7.0	7.27	6.9986	_____	7.0014	.0000115	> 10:1
	58.0	58.1	57.98	_____	58.02	.0001680	> 10:1
	300.0	300	299.9	_____	300.1	.0011770	> 10:1
AC Voltage (60 Hz, 5 kHz, 10 kHz, 5 kHz) (Values in Vac)							
4-3	0.07	0.0875	.0693	_____	.0707	.000044	> 10:1
	0.07	0.0875	.0676	_____	.0724	.000044	> 10:1
	0.07	0.0875	.0676	_____	.0724	.000044	> 10:1
	300.00	300	269.1	_____	330.9	.038030	> 10:1
4-Wire Resistance (Values in Ohms)							
4-4	1000	2000	999.6	_____	1000.4	0.003	> 10:1
	100000	131000	99959	_____	100041	0.3	> 10:1
	1000000	1000000	999590	_____	1000410	10.0	> 10:1

* Measurement Uncertainty of Datron 4708 source for 90 days since calibration and 23°C ± 1°C.

** TAR = multimeter accuracy/measurement uncertainty, shown as > 10:1.

NOTES:

Introduction

This chapter contains procedures to adjust the Agilent E1326B multimeter for peak performance. For best performance, the instrument should be adjusted after repair. All adjustments are performed electrically, so manual adjustment of the multimeter is not necessary.

WARNING

Do not perform any of the following adjustments unless you are a qualified, service-trained person, and have read the WARNINGS and CAUTIONS in Chapter 1.

NOTE

ALL adjustment procedures MUST be performed in the order shown in this manual (DC Voltage, then AC Voltage, and then Resistance).

Adjustment Conditions/ Procedures

For valid adjustments, the Agilent E1326B multimeter and test equipment used must have at least a 60 minute warm-up, and the line voltage must be 115/230 Vac $\pm 10\%$. For best accuracy, the temperature of the area where adjustments are made should be between 18°C and 28°C and stable to within $\pm 1^\circ\text{C}$. See Table 1-1, *Recommended Test Equipment*, for test equipment requirements.

The adjustment procedures assume the person performing the adjustments understands how to operate the mainframe, multimeter and specified test equipment. The adjustment procedures do not specify test equipment settings, except in general terms. It is assumed a qualified, service-trained person will select and connect the cables and jumpers required for the adjustments.

DC Voltage Adjustments

This procedure adjusts Agilent E1326B DC voltage measurement accuracy.

Equipment Setup

1. Connect the equipment as shown in Figure 5-1. You can connect to the E1326B OR the E1326-80005 terminals, but not to both.

WARNING

The DC Standard (Datron 4708, Option 10) can produce dangerous voltages which are present on the terminals. Do not touch the front (or rear) panel terminals unless you are sure no dangerous voltage is present.




Figure 5-1. DC Voltage Adjustment Setup

2. Set the Agilent E1326B as follows:

- Reset Multimeter * RST
- Auto Zero ON
- Power Line Cycles (PLC) 1
- Line Freq Reference (CAL:LFR) 50 Hz or 60 Hz

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

**Adjustment
Procedure**

1. Set the DC Standard output to 7.7 V.
2. Set the Agilent E1326B range to 8 V, and adjust the multimeter at + 7.7 V using:

```
FUNC:VOLT:DC
VOLT:DC:RANGE 8
CAL:VAL 7.7
CAL?
```

3. Verify that the returned calibration error code is 0 (no error).
If not 0, see Table 5-1 for a list of calibration errors and codes.
The calibration error is displayed on the Agilent E1301B front panel, or can be returned to an external computer using ENTER.
4. Repeat steps 1 through 3 using the following Agilent E1326B (and VOLT:DC:RANG) voltage ranges, and DC Standard (and CAL:VAL) settings:

Agilent E1326B range/ VOLT:DC:RANG <>	DC Standard Output/ CAL:VAL <>
8 V	- 7.7 V
0.125 V	+ 0.121 V
0.125 V	- 0.121 V
1 V	+ 0.97 V
1 V	- 0.97 V
64 V	+ 62.0 V
64 V	-62.0 V
300 V	+ 300 V
300 V	-300 V

5. Remove power and disconnect test equipment.

**Example: DC
Voltage
Adjustments**

This example performs DC voltage adjustments for a power line reference frequency of 60 Hz. Change line 80 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

If no calibration error occurs (Cal_code = 0 in line 210), the program

displays an "adjustment complete" message. If a calibration error occurs, the program displays the calibration error and prompts you to repeat the adjustment (see Table 5-1 for a list of calibration errors).

When connected to the Agilent E1326B multimeter, some DC Standards may exhibit voltage variations at the start of a measurement. TRIG:DEL .05 (line 190) adds a 0.8 second wait before calibration begins to allow settling time for the DC Standard output. TRIG:DEL .05 is used since the input is sampled 16 times before the calibration is performed. Thus, total added delay = 0.05 seconds x 16 = 0.8 second.

```
1  ! DC Voltage Adjustments
2  !
10 OPTION BASE 1
20 DIM Range(10),Volts(10)
30 DATA 8.0, 8.0, 0.125, 0.125, 1.0, 1.0, 64.0, 64.0, 300.0, 300.0
40 READ Range(*)
50 DATA 7.7, -7.7, .121, -.121, .97, -.97, 62.0, -62.0, 300.0, -300.0
60 READ Volts(*)
70 OUTPUT 70903;"* RST"           Set autozero on and PLC 1
80 OUTPUT 70903;"CAL:LFR 60"     Set 60 Hz line ref frequency
90 FOR I= 1 TO 10
100 Re_try: !
110 CLEAR SCREEN
120 PRINT "Set DC Standard to ";Volts(I);" VDC"
130 PRINT "Press Continue when ready"
140 PAUSE
150 CLEAR SCREEN
160 OUTPUT 70903;"FUNC:VOLT:DC"   Set DCV function
170 OUTPUT 70903;"VOLT:RANG ";Range(I) Set E1326B range
180 OUTPUT 70903;"CAL:VAL ";Volts(I) Set CAL:VAL value
190 OUTPUT 70903;"TRIG:DEL .05"   Wait for settling
200 OUTPUT 70903;"CAL?"           Perform calibration
210 ENTER 70903 USING "K";Cal_code Return cal error code
220 IF Cal_code< > 0 THEN
230 PRINT "Calibration Error";Cal_code;"for ";Volts(I);"VDC input."
240 PRINT "Check source value/connections, then"
250 PRINT "press Continue to retry this adjustment"
260 PAUSE
270 GOTO Re_try
280 ELSE
290 PRINT "Adjustment complete for ";Volts(I);"VDC input"
300 END IF
```

- 310 PRINT "Press Continue for the next adjustment"
- 320 PAUSE
- 330 CLEAR SCREEN
- 340 NEXT I
- 350 END

AC Voltage Adjustments

This procedure adjusts the Agilent E1326B AC voltage measurement accuracy.

NOTE

The DC Voltage adjustment MUST be performed before the AC Voltage adjustment.




Figure 5-2. AC Voltage Adjustment Setup

Equipment Setup

1. Connect the equipment as shown in Figure 5-2. You can connect to the E1326B OR the E1326-80005 terminals, but not to both.
2. Set the Agilent E1326B as follows:

- Reset Multimeter * RST
- Auto Zero ON

- Power Line Cycles (PLC) 1
- Line Freq Reference (CAL:LFR) 50 Hz or 60 Hz

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

Adjustment Procedure

1. Set the AC Standard output to 5.6 Vac at 1 kHz.
2. Set the Agilent E1326B range to 5.6 V, and adjust the multimeter at 5.6 V using:

```

FUNC:VOLT:AC
VOLT:AC:RANG 5.6
CAL:VAL 5.6
CAL?

```

3. Verify that the returned calibration error code is 0 (no error).
If not 0, see Table 5-1 for a list of calibration errors and codes.
4. Remove power and disconnect test equipment.

Example: AC Voltage Adjustments

This example performs an AC voltage adjustment for a power line reference frequency of 60 Hz and an input of 5.6 Vac @ 1 kHz. Change line 20 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation.

If no calibration error occurs (Cal_code = 0 in line 130), the program displays an "adjustment complete" message. If a calibration error occurs, the program displays the calibration error (see Table 5-1 for a list of calibration errors).

When connected to the Agilent E1326B multimeter, some AC Standards may exhibit voltage variations at the start of a measurement. TRIG:DEL .05 (line 110) adds a 0.8 second wait before calibration begins to allow settling time for the AC Standard output. TRIG:DEL .05 is used since the input is sampled 16 times before the calibration is performed. Thus, total added delay = 0.05 seconds x 16 = 0.8 second.

```

1  ! AC Voltage Adjustments
2  !
10 OUTPUT 70903;"* RST"           Set autozero on and PLC 1
20 OUTPUT 70903;"CAL:LFR 60"     Set 60 Hz line ref frequency

```

```

30 Re_try: !
40 PRINT "Set AC Standard to 5.6 Vac at 1.0 kHz"
50 PRINT "Press Continue when ready"
60 PAUSE
70 CLEAR SCREEN
80 OUTPUT 70903;"FUNC:VOLT:AC"      Set ACV function
90 OUTPUT 70903;"VOLT:RANG 5.6"    Set 5.6 Vac range
100 OUTPUT 70903;"CAL:VAL 5.6"     Set 5.6 Vac cal value
110 OUTPUT 70903;"TRIG:DEL .05"    Wait for settling
120 OUTPUT 70903;"CAL?"            Perform calibration
130 ENTER 70903 USING "K";Cal_code
140 IF Cal_code< > 0 THEN
150 PRINT "Calibration Error";Cal_code;"on 5.6 Vac range"
160 PRINT "Check source value/connections, then"
170 PRINT "press Continue to retry this adjustment"
180 PAUSE
190 CLEAR SCREEN
200 GOTO Re_try
210 ELSE
220 PRINT "AC Voltage adjustment complete"
230 END IF
240 END

```

Resistance Adjustments

This procedure adjusts 4-wire resistance measurement accuracy.




Figure 5-3. Resistance Adjustments Setup

NOTE

The DC Voltage adjustment and the AC Voltage adjustment MUST be performed before the Resistance adjustment.

Equipment Setup

1. Connect the equipment as shown in Figure 5-3. You can connect to the E1326B OR the E1326-80005 terminals, but not to both.

2. Set the Agilent E1326B as follows:

- Reset Multimeter *RST
 - Auto Zero ON
 - Power Line Cycles (PLC) 1
 - Line Freq Reference (CAL:LFR) 50 Hz or 60 Hz
-

NOTE

**RST sets Auto Zero to ON and Power Line Cycles to 1.*

Adjustment Procedure

1. Set the Resistance Standard to 1 k Ω .

2. Set the Agilent E1326B range to 2 k Ω , and adjust the multimeter at 1 k Ω using:

```
FUNC:FRES
FRES:RANG 2000
CAL:VAL 1000
CAL?
```

NOTE

For best adjustment accuracy, you may want to measure the ACTUAL resistance value of the Resistance Standard and use this value in the CAL:VAL command. You can read the actual resistance value from the Datron front panel or you can measure the value with an Agilent 3458A multimeter or equivalent.

3. Verify that the returned calibration error code is 0 (no error).

If not 0, see Table 5-1 for a list of calibration errors and codes. The calibration error is displayed on the Agilent E1301B front panel,

or can be returned to the computer using an ENTER statement.

- Repeat steps 1 through 3 using the following Agilent E1326B (and FRES:RANG) ranges, and Resistance Standard (and CAL:VAL) values.

Agilent E1326B Range/ FRES:RANG < >	Resistance Standard/ CAL:VAL < >
16000Ω 1048576Ω	10000Ω 1000000Ω

- Remove power and disconnect test equipment.

Example: 4-Wire Resistance Adjustments

This example performs a 4-wire ohms resistance adjustment for a power line reference frequency of 60 Hz. Change line 80 to OUTPUT 70903;"CAL:LFR 50" for 50 Hz operation. If a calibration error occurs, the program displays the calibration error and prompts you to repeat the adjustment (see Table 5-1 for a list of calibration errors).

```

10  OPTION BASE 1
20  DIM Range(3),Source(3)
30  DATA 2000, 16000, 1048576
40  READ Range(*)
50  DATA 1000, 10000, 1000000
60  READ Source(*)
70  OUTPUT 70903;"* RST"           Set autozero on and PLC I
80  OUTPUT 70903;"CAL:LFR 60"    Set 60 Hz line ref freq
90  FOR I= 1 TO 3
100 Re_try: !
110  PRINT "1. Set Resistance Standard to";Source(I);"Ohms"
120  PRINT "2. Measure ACTUAL Resistance Standard value (in
Ohms)"
130  INPUT " Enter ACTUAL Resistance Standard value (in Ohms)
",Ohms_actual
140  CLEAR SCREEN
150  OUTPUT 70903;"FUNC:FRES"     Set 4-wire ohms
160  OUTPUT 70903;"FRES:RANG ";Range(I) Set resistance range
170  OUTPUT 70903;"CAL:VAL ";Ohms_actual Set cal value
180  OUTPUT 70903;"CAL?"         Perform calibration
190  ENTER 70903 USING "K";Cal_code
200  IF Cal_code< > 0 THEN
210  PRINT "Calibration Error";Cal_code;"with";Source(I);"Ohms
input"
220  PRINT "Check source value/connections, then"
230  PRINT "Press Continue to repeat this adjustment"
240  PAUSE

```

```

250 CLEAR SCREEN
260 GOTO Re_try
270 ELSE
280 PRINT "Adjustment complete with";Source(I);"Ohms source"
290 PRINT "Press Continue for the next adjustment"
300 PAUSE
310 CLEAR SCREEN
320 END IF
330 NEXT I
340 PRINT "Resistance adjustments completed"
350 END

```

Calibration Errors

Table 5-1 summarizes calibration error numbers, titles and descriptions for the Agilent E1326B multimeter. Note that an error is returned if the adjustment (calibration) standard used is outside the calibration range of the multimeter (between \pm (0.5 full scale and full scale)).

Table 5-1. Agilent E1326B Multimeter Calibration Errors

Error	Title	Description	Code*
0	No Error	No error has occurred since last time the error code was read.	
4	Reading Overrun	The FIFO memory was still full at the time the new reading was ready, or a new command was received while in the middle of outputting a reading. TRIGGER ARM is disabled and the multimeter waits for a new command.	U
6	Calibration Error	An error occurred when computing a calibration constant, probably due to an improper input or a defective Unit Under Test (UUT). Calibration cycle aborted.	U/H
7	Checksum Error	The non-volatile RAM contains a checksum error. The data is assumed to be corrupted.	H
8	Invalid CAL Request	Calibration requested for an invalid combination of multimeter range and function.	U
9	Bad CAL Target	The target value for the calibration was outside the range of \pm (0.5 full scale to full scale).	U
11	No Inguard Response	No response from inguard (expected data and got nothing). Timed out instead.	H
13	Linearity CAL Error	An error has occurred during a linearity calibration sequence. Probably a hardware failure of the A/D inguard section.	H

14	Pacer Overrun Error	The pacer is in use and the pacer rate is faster than the maximum A/D conversion rate based on integration time, autorange setting, autozero setting, and interrupts enabled.	U
15	Input Overload	<p>A potentially damaging overload has been applied to the multimeter terminals and the multimeter has disconnected from the input. A new SET RANGE command is necessary to restore normal operation. A damaging overload is defined as:</p> <ol style="list-style-type: none"> 1. Applying $> \pm 40$ volts HI to LO or HI to COMMON while in manual range with RANGE ≤ 8 volts. 2. Applying $> \pm 40$ volts between LO and COMMON under any circumstances. 	U

* U = improper operation, H = hardware failure

Replaceable Parts

Introduction

This chapter contains information to order replaceable parts for the Agilent E1326B multimeter.

Exchange Assemblies

Table 6-1 lists assemblies that may be replaced on an exchange basis (EXCHANGE ASSEMBLIES). Exchange, factory-repaired, and tested assemblies are available only on a trade-in basis. Defective assemblies must be returned for credit. Assemblies required for spare parts stock must be ordered by the new assembly part number. Contact your nearest Agilent Technologies Sales and Service Office for details.

Ordering Information

To order a part listed in Table 6-1, specify the Agilent part number and the quantity required. Send the order to your nearest Agilent Sales and Service Office.

Replaceable Parts List

Table 6-1, *Agilent E1326B Replaceable Parts*, lists the replaceable parts for the Agilent E1326B multimeter. See Figure 6-1 (page 6-3) for locations of parts listed in Table 6-1.

Table 6-1. Agilent E1326B Replaceable Parts

Reference* Designator	Agilent Part Number	Qty	Description	Mfr** Code	Mfr Part Number
	E1326-66202	1	EXCHANGE ASSEMBLIES Multimeter Module (New)	28480	E1326-66202
	E1326-69202	1	Multimeter Module (Exchange)	28480	E1326-69202
A1	E1326-66511	1	OUTGUARD PRINTED CIRCUIT ASSY [a]	28480	E1326-66511
A1F1-F2	2110-0712	2	Fuse - Sub Miniature 4A 125V	75915	R251004T1
A1J1	1252-3416	1	Connector - 4 Pin Right Angle	27264	705-53-0108
A1J2	1250-1846	1	Connector - Right Angle BNC	24931	28JR342-1
A1J3	1251-5222	1	Connector - Post 2X5 10 Pin	18873	65863-265
A1JM1	1251-4927	2	Connector - Header 16 Pin	18873	67997-616
A1JM3	1251-4927	1	Connector - Header 16 Pin	18873	67997-616
A1P1	1252-1596	1	Connector - Right Angle 96 Pin	06776	DIN-96CPC-SRI-TR
A1P3	1258-0247	1	4-Position Jumper	18873	69146-204
A1SW1	3101-3066	1	Switch - Rocker 8 Position 5 V 0.1 A	81073	76YY22968S
A1XU23	1200-0817	1	Socket - 40 Pin Integrated Circuit	00779	2-640379-1

(Continued on next page)

Reference* Designator	Agilent Part Number	Qty	Description	Mfr** Code	Mfr Part Number
A2 A2J101 A2J102 A2J103 A2K104-K105 A2K106 A2XU104	E1326-66502 44702-61603 1252-3712 1252-3416 0490-1556 0490-1555 1200-0817	1 1 1 1 2 1 1	INGUARD PRINTED CIRCUIT ASSY [a] Cable Assembly - Ribbon 10 Conductor Connector - Right Angle 2X6 12 Pin Connector - Right Angle 4 Pin Relay - Reed 2A 250MA 400VDC 5VDC-Coil Relay - Reed 2A 250MA 400VDC 5VDC-Coil Socket - 40 Pin Integrated Circuit	28480 28480 18873 27264 71707 71707 00779	E1326-66502 44702-61603 68668-004 705-53-0108 3500-0050 3500-0051 2-640379-1
CBL1 CBL2 CBL3	E1326-61605 E1326-61601 E1326-61606	1 1 1	CABLE ASSEMBLIES Cable Assembly - 4 Conductor Cable Assembly - 6 Conductor Cable Assembly - 4 Conductor Ribbon	28480 28480 28480	E1326-61605 E1326-61601 E1326-61606
LBL1 MP1 MP2 MP3-MP6 MP9-MP10 PNL1 SHD1	E1326-84302 E1300-45101† E1300-45102† 1510-0091 1400-1567 E1326-00208† E1300-80601	1 2 4 2 1 1 1	MECHANICAL PARTS Label - Serial Number HNDL-KIT TOP, Agilent† HNDL-KIT BTM, VXI † Binding Post - Red Wire Saddle - Nylon PNL-EXTERNAL VM† Shield - Safety	28480 28480 28480 28480 28480 28480 28480	E1326-84302 E1300-45101† E1300-45102† 1510-0091 1400-1567 E1326-00208† E1300-80601
SCR1-SCR2 SCR3-SCR4 SCR9-SCR10	0515-0372 0515-2140 0515-1968 0515-2743 2950-0001 3050-0593	1 2 2 2 4 4	COMMON HARDWARE SCR Pan-Head M3.0 X .5 Torx T10 SCR-THD-RLG M2.5 X0.45 14mm SCR Pan-Head M2.5 X 11 Pozidriv SCR-FH M2.5 X 8 THREAD ROLLING Nut-Hex-DBL Chamfer 3/8-32 THD Washer-Spring NO. 3/8	28480 28480 28480 28480 28480 28480	0515-0372 0515-2140 0515-1968 0515-2743 2950-0001 3050-0593

* See Table 6-2 for Reference Designator definitions

** See Table 6-3 for Code List of Manufacturers

[a] Repair limited to replacement of parts listed - see Introduction for ordering information

† These parts are not compatible with older version fixed handles or their corresponding front panels. To replace one or more of these old parts, you must order all three new parts (Top and Bottom Handle Kits AND External Panel).

Table 6-2. Agilent E1326B Reference Designators

Agilent E1326B Reference Designators	
A assembly	MP misc. mechanical part
CBL cable	P electrical connector (plug)
F fuse	PNL panel
J electrical connector (jack)	SCR screw
JM electrical connector (header)	SHD shield
K relay	SW switch
LBL label	XU socket, integrated circuit




Figure 6-1. Agilent E1326B Replaceable Parts

Table 6-3. Agilent E1326B Code List of Manufacturers

Mfr Code	Manufacturer Name	Address
00000	Any satisfactory supplier	
00779	AMP Inc	Harrisburg, PA US 17111
06776	Robinson Nugent Inc	New Albany, IN US 47150
18873	Dupont E I De Nemours & Co	Wilmington, DE US 19801
24931	Specialty Connector Co	Franklin, IN US 46131
27264	Molex Inc	Lisle, IL US 60532
28480	Agilent Technologies	Palo Alto, CA US 94304
71707	Coto Wabash	Providence, RI US 02907
75915	Littelfuse Inc	Des Plaines, IL US 60016
81073	Grayhill Inc	La Grange, IL US 60525

Manual Changes

Introduction

This chapter contains information to adapt this manual to instruments for which the content does not directly apply. Since this manual applies directly to instruments with serial numbers listed on the title page, change information is not required. See *Multimeter Serial Numbers* in Chapter 1 for Agilent E1326B multimeter serial number information.

Introduction

This chapter contains information to service the Agilent E1326B multimeter, including:

- recommended repair strategy
- troubleshooting techniques
- repair/maintenance guidelines

WARNING

Do not perform any of the service procedures shown unless you are a qualified, service-trained person, and have read the WARNINGS and CAUTIONS in Chapter 1.

Equipment Required

See Table 1-1, *Recommended Test Equipment* for equipment required for multimeter troubleshooting and repair. To avoid damage to screw head slots, use Pozidriv or TORX drivers as specified. See Table 8-1 for driver numbers.

Table 8-1. Pozidriv/Torx Drivers

Description	Agilent Part Number
No. 1 Pozidriv No. 2 Pozidriv	8710-0899 8710-0900
Size T-8 Torx Size T-10 Torx Size T-15 Torx	8710-1673 8710-1284 8710-1816

Service Aids

There are no test points or manual adjustment locations for the Agilent E1326B multimeter. Service aids on printed circuit boards may include pin numbers, some reference designations, and assembly part numbers. See *Chapter 6 - Replaceable Parts* for descriptions and locations of Agilent E1326B multimeter replaceable parts.

Service notes and other service literature for the Agilent E1326B multimeter may be available through Agilent. For information, contact your nearest Agilent Sales and Service Office.

Recommended Repair Strategy

The recommended repair strategy for the Agilent E1326B multimeter is assembly-level repair. User repairs to the Agilent E1326B multimeter are limited to replacement of the parts shown in Table 6-1 *Agilent E1326B Replaceable Parts*.

If the fault cannot be traced to a user-replaceable part in Table 6-1, return the entire Agilent E1326B multimeter to Agilent for exchange or replacement (see *Chapter 6 - Replaceable Parts* for details.) Individual A1 or A2 printed circuit assemblies (PCAs) cannot be returned for exchange or replacement.

Troubleshooting Techniques

There are two main steps to troubleshoot an Agilent E1326B multimeter problem: (1) identify the problem, and (2) test assemblies to isolate the cause to a user-replaceable component.

Identifying the Problem

Multimeter problems can be divided into four general categories:

- Self-test errors
- Operator errors
- Catastrophic failures
- Performance out of specification

Self-Test Errors

An error number (1, 2, 3, or 4) is returned when the multimeter self-test fails. If a self-test error occurs, recycle power and repeat the self-test. If the error repeats, see "Testing Assemblies" to troubleshoot the multimeter. Table 8-2 shows some typical causes of self-test errors.

Table 8-2. Self-Test Errors

Error	Description	Typical Causes
1	Multimeter does not respond to self-test	. Bad connections/settings . Incorrect operation . Hardware failure (exchange)
2	Invalid communication between A1 and A2 processors	. Bad A1/A2 connection . Hardware failure (exchange)
3	Data line test between multimeter and mainframe failed	. Bad connections/settings . Incorrect operation . Hardware failure (exchange)
4	Invalid communication between multimeter and mainframe	. Bad connections/settings . Incorrect operation . Hardware failure (exchange)

Operator Errors

Apparent failures may result from operator errors. See *Appendix B - Error Messages* in the *Agilent E1326B/E1411B User's Manual* for information on operator errors.

Catastrophic Failure

If a catastrophic failure occurs, see "Testing Assemblies" to troubleshoot the multimeter.

Performance Out of Specification

If the multimeter performance is out of specification limits, use the adjustment procedures in *Chapter 5 - Adjustments* to correct the problem.

If the condition repeats, see "Testing Assemblies" to troubleshoot the multimeter.

Testing Assemblies

You can use the tests and checks in Table 8-3 to isolate the problem to a user-replaceable part on the multimeter frame, to the A1 Outguard PCA, or to the A2 Inguard PCA. See Figure 6-1 in *Chapter 6 - Replaceable Parts* for locations of user-replaceable parts.

NOTE

If the problem cannot be traced to a user-replaceable part listed in Table 6-1, return the multimeter to Agilent for exchange. See Chapter 6 - Replaceable Parts for procedures.

Table 8-3. Agilent E1326B Tests/Checks

Test/Check	Reference Designator	Check:
Heat Damage	-----	Discolored PC boards Damaged insulation Evidence of arcing
Switch/Jumper Settings	JM1, JM3 SW1	IRQ Level setting LADDR setting
Frame	CBL1, CBL2, CBL3 MP3, MP4, MP5, MP6	Cable contact damage Panel binding posts
A1 Outguard PCA	F1, F2 J1, J2, J3 P1, P3 XU23	Fuse continuity Mating connector contacts Connector contacts IC contact/connections
A2 Inguard PCA	J101, J102, J103 K104, K105, K106 XU104	Cable connector contacts Relay opening/closure IC contact/connections

Checking Heat Damage

Inspect the multimeter for signs of abnormal internally generated heat such as discolored printed circuit boards or components, damaged insulation, or evidence of arcing. If there is damage, do not operate the multimeter until you correct the problem.

Checking Switches/Jumpers

Verify the logical address setting is set correctly (factory set at 24). Verify the interrupt priority jumpers are set correctly (factory set at level 1). See the *Agilent E1326B/E1411B User's Manual* for information.

Testing Multimeter Frame

To test the multimeter frame, see Table 8-3 for guidelines to check binding posts MP3, MP4, MP5, and MP6, and cables CBL1, CBL2, and CBL3. If you need to remove and/or replace the binding posts, see "Removing Binding Posts" in this chapter.

Testing A1/A2 PCAs

To test the A1 Outguard PCA and the A2 Inguard PCAs, remove mainframe power and remove the multimeter from the mainframe. Then, remove the A2 Inguard PCA (see "Removing A2 Inguard PCA" for instructions). Then, see Table 8-3 for guidelines to isolate the problem to a user-replaceable part.

Repair/ Maintenance Guidelines

This section gives guidelines to repair and maintain the Agilent E1326B multimeter, including:

- ESD precautions
- Removing A2 inguard PCA
- Removing binding posts
- Soldering printed circuit boards
- Post-repair safety checks

ESD Precautions

Electrostatic discharge (ESD) may damage MOS, CMOS and other static sensitive devices in the Agilent E1326B multimeter. This damage can range from slight parameter degradation to catastrophic failure. When handling multimeter assemblies, follow these guidelines to avoid damaging multimeter components:

- Always use a static-free work station with a pad of conductive rubber or similar material when handling multimeter




Figure 8-1. Removing A2 Inguard PCA

components.

- After you remove an assembly from the multimeter, place the assembly on a conductive surface to guard against ESD damage. Do not stack assemblies.
- Do not use pliers to remove a MOS or CMOS device from a high-grip socket. Instead, use a small screwdriver to pry the device up from one end. Slowly lift the device up, one pair of pins at a time.
- After you remove a MOS or CMOS device from an assembly, place the device onto a pad of conductive foam or other suitable holding material.
- If a device requires soldering, be sure the assembly is placed on a pad of conductive material. Also, be sure you, the pad, and the




Figure 8-2. Removing Binding Posts

soldering iron tip are grounded to the assembly. Apply as little heat as possible when soldering.

- When you replace a MOS or CMOS device, ground the foam to the multimeter before removing the device from the foam.

Removing A2 Inguard PCA

Use the following steps to remove the A2 A/D Inguard printed circuit assembly (PCA) from the A1 Outguard PCA. See Figure 8-1 for component locations.

1. Disconnect the four-conductor cable (CBL1) from A2J103.
2. Remove CBL1 from the two plastic retainers (MP9 and MP10) on the A2 Inguard PCA.
3. Disconnect the 10-pin ribbon cable (A2J101) from A1J3.
4. Remove the Torx T10 screw, using a T10 Torx driver.
5. Slide the A2 Inguard PCA to align with the large holes on the retaining pins.
6. Lift and remove the A2 Inguard PCA from the A1 Outguard PCA.
7. Reverse Steps 1 through 6 to reinstall the A2 Inguard PCA onto the A1 Outguard PCA.

NOTE

When reinstalling the A2 Inguard PCA, verify that the holes are aligned with the retainers. Then, slide the PCA into place.

Removing Binding Posts

Use the following steps to remove the Agilent E1326B faceplate binding posts (MP3, MP4, MP5, and MP6) (see Figure 8-2).

1. Unsolder wire.
2. Remove the 3/8-32 nut and spring washer.
3. Remove the binding post.
4. Reverse the order to reinstall the binding post.

Soldering Printed Circuit Boards

The etched circuit boards in the multimeter have plated-through holes that allow a solder path to both sides of the insulating material. Soldering can be done from either side of the board with equally good results. When soldering to any circuit board, keep in mind the following guidelines.

CAUTION

Do not use a sharp metal object such as an awl or twist drill, since sharp objects may damage the plated-through conductor.

- Avoid unnecessary component unsoldering and soldering. Excessive replacement can result in damage to the circuit board and/or adjacent components.
- Do not use a high power soldering iron on etched circuit boards (a 38-watt soldering iron is recommended), as excessive heat may lift a conductor or damage the board.
- Use a suction device or wooden toothpick to remove solder from component mounting holes. When using a suction device, be sure the equipment is properly grounded to prevent electrostatic discharge from damaging CMOS devices.

Post-Repair Safety Checks

After making repairs to the Agilent E1326B multimeter, inspect the multimeter for any signs of abnormal internally generated heat, such as discolored printed circuit boards or components, damaged insulation, or evidence of arcing. Determine and correct the cause of the condition. Then run the self-test (*TST? command) to verify that the multimeter is functional.

NOTES:

Calculating Multimeter Accuracy

Introduction

This appendix shows how multimeter accuracy, measurement uncertainty, and test accuracy ratio (TAR) values are defined and calculated for the performance verification tests for the Agilent E1326B multimeter.

See Table 4-1, "Performance Test Record for the Agilent E1326B Multimeter" for 1-year specification values of multimeter accuracy, measurement uncertainty, and test accuracy ratios (TARs).

NOTE

Multimeter accuracy, measurement uncertainty, and test accuracy ratios in Table 4-1 are valid ONLY for the specified test conditions and assumptions described in this manual. For the test conditions described, all TARs exceed the 4:1 requirements of MIL-STD-45662A.

Multimeter Accuracy Definition

Multimeter accuracy is the expected accuracy of the measurement due ONLY to the multimeter. The "Low Limit" entry in Table 4-1 is the lower (-) value of multimeter accuracy, while the "High Limit" entry is the upper (+) value of multimeter accuracy.

Measurement Uncertainty Definition

Measurement Uncertainty is the expected accuracy of the source used to input signals to the multimeter. Since the Datron 4708 Autocal Multifunction Standard is the source used for measurements in this manual, the measurement uncertainty of the source is that of the Datron 4708.

This value is shown in the "Measurement Uncertainty" column of Table 4-1. See the *Datron 4708 User's Handbook* for additional information on calculating measurement uncertainty for the Datron 4708 source.

NOTE

Measurement Uncertainty does not apply to the DC Voltage (Zero Volts Input) test, since no input is applied.

Test Accuracy Ratio (TAR) Definition

Test Accuracy Ratio (TAR) is the ratio of multimeter accuracy to measurement uncertainty. For the Agilent E1326B multimeter performance tests, test accuracy ratio = (High Limit value - Test Input value)/ Measurement Uncertainty value. This value is shown in the "Test Accuracy Ratio (TAR)" column of Table 4-1.

NOTE

Test accuracy ratio does not apply to the DC Voltage (Zero Volts Input) test, since no measurement uncertainty value applies.

Multimeter Accuracy Calculations

For the Agilent E1326B multimeter performance verification tests, multimeter accuracy is defined for DC Voltage, AC Voltage, and 4-Wire Resistance measurements using the 90-day specifications in *Appendix A - Specifications of the Agilent E1326B/E1411B User's Manual*. The **assumed** test conditions are:

- One year since the last calibration
- Temperature within $\pm 5^{\circ}\text{C}$ of calibration temperature
- Module calibration temperature 18°C to 28°C
- One hour warmup
- 4-wire ohms resistance measurements
- Aperture = 16.7 msec (60 Hz) or 20 msec (50 Hz)
- Autozero ON

DC Voltage Accuracy Equations

From *Appendix A* of the *Agilent E1326B /E1411B User's Manual*, DC voltage 1-year accuracy = \pm (% of reading + volts). The accuracy equations for the ranges and apertures used in the performance verification tests are:

Range	Accuracy [\pm (% of reading + Volts)]
125 mV	0.023 + 5.0 μV
1 V	0.013 + 15.0 μV
8 V	0.010 + 50.0 μV
64 V	0.015 + 1.0 mV
300 V	0.015 + 5.0 mV

Example: Calculate DC Voltage Accuracy

For a 7.0 DCV input to the multimeter, using the 8 V range and 16.7/20 msec aperture, multimeter accuracy (1-year) = \pm (.020% reading + 50.0 μV) = \pm (.0002 x 7.0 + 50 x 10^{-6}) = \pm 0.0014 Volts. Thus, for a 7.0 DCV

input the Low Limit in Table 4-1 = 6.9986 Volts and the High Limit = 7.0014 Volts.

AC Voltage Accuracy Equations

From *Appendix A* of the *Agilent E1326B/E1411B User's Manual*, AC voltage 1-year accuracy = \pm (% of reading + volts). The accuracy equations for the ranges, frequencies and apertures used in the performance verification tests are:

Range	Frequency	Accuracy [\pm (% of reading + Volts)]
87.5 mV	60 Hz	0.695 + 200 μ V
87.5 mV	5 kHz	3.195 + 200 μ V
87.5 mV	10 kHz	3.195 + 200 μ V
300 V	5 kHz	10.14 + 500 mV

Example: Calculate AC Voltage Accuracy

For a 0.07 ACV input to the multimeter, using the 87.5 mV range, 60 Hz frequency, and 16.7/20 msec aperture, multimeter accuracy (1-year) = \pm (0.695% reading + 200 μ V) = \pm (.00695 x 0.07 + 200 x 10⁻⁶) = \pm 0.0007 Volts. Thus, for a 0.07 ACV input the Low Limit in Table 4-1 = 0.0693 Volts and the High Limit = 0.0707 Volts.

4-Wire Ohms Accuracy Equations

From *Appendix A* of the *Agilent E1326B/E1411B User's Manual*, 4-Wire resistance 90-day accuracy = \pm (% of reading + Ohms). The accuracy equations for the ranges and apertures used in the performance verification tests are:

Range	Accuracy [\pm (% of reading + Ohms)]
2 k Ω	0.04 + 20 m Ω
131 k Ω	0.04 + 1 Ω
1 M Ω	0.04 + 10 Ω

Example: Calculate 4-Wire Resistance Accuracy

For a 1 k Ω input to the multimeter, using the 2 k Ω range and 16.7/20 msec aperture, multimeter accuracy (1-year) = \pm (.04% reading + 20 m Ω) = \pm (.0004 x 1000 + 20 x 10⁻³) = \pm 0.4 Ω . Thus, for a 1 k Ω input the Low Limit in Table 4-1 = 999.6 Ω and the High Limit = 1000.4 Ω .

Measurement Uncertainty Calculations

Measurement uncertainties for the Datron 4708 source are calculated using the 90-day accuracy specifications in the *Datron 4708 User's Handbook*:

Measurement Uncertainty = Datron Accuracy + Calibration Uncertainty, where Datron Accuracy (ppm) = Accuracy Relative to Calibration Standards = $\pm(\text{ppm OUTPUT} + \text{ppm FS})$

and FS = 2 x range for all ranges except 1000V
 FS = 1100 for the 1000V range

The **assumed** test conditions are:

- Temperature of $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$
- 90 days since last calibration
- 4-wire sense function for ohms measurements

Calculate DCV Measurement Uncertainty

From *Section 6 - Specifications* of the *Datron 4708 User's Handbook*, DC Voltage (Option 10) Accuracy (90 days since calibration and $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$) follows, where Datron Accuracy = $\pm(\text{ppm OUTPUT} + \text{ppm FS})$.

Datron OUTPUT (DCV)	Datron Range (Volts)	Datron Accuracy (ppm)	Calibration Uncertainty (ppm)
0.1	1.0000000V	2 + 0.4	2
0.9	1.0000000V	2 + 0.4	2
7.0	10.000000V	1 + 0.15	1.5
58.0	100.00000V	2 + 0.25	2
300.0	1000.0000V	3 + 0.25	2

Example: Calculate DC Voltage Measurement Uncertainty

Since Measurement Uncertainty = Datron Accuracy + Calibration Uncertainty, for a 7.0 DCV OUTPUT and the Datron 4708 range set to 10.000000 V, Measurement Uncertainty (μV) = $\pm[(1.0 \times 7.0) + (2 \times 0.15 \times 10)] + 1.5 = \pm 11.5 \mu\text{V} = \pm 0.0000115 \text{ V}$.

Or, with a 300 DCV OUTPUT and the 1000.0000V range, Measurement Uncertainty (μV) = $\pm[(3.0 \times 300) + (0.25 \times 1100)] + 2.0 = \pm 1177 \mu\text{V} = \pm 0.001177 \text{ V}$.

Calculate ACV Measurement Uncertainty

From *Section 6 - Specifications* of the *Datron 4708 User's Handbook*, AC Voltage (Option 20) Accuracy (90 days since last calibration and $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$) where Datron Accuracy = $\pm(\text{ppm OUTPUT} + \text{ppm FS})$.

Datron Output (ACV)	Datron Range	Datron Freq	Datron Accuracy (ppm)	Calibration Uncertainty (ppm)
0.07	100 mV	20 Hz	110 + 20 + 5 μV	30 + 1 μV
0.07	100 mV	60 Hz	60 + 20 + 5 μV	30 + 1 μV
0.07	100 mV	5 kHz	50 + 20 + 5 μV	30 + 1 μV
0.07	100 mV	10 kHz	50 + 20 + 5 μV	30 + 1 μV
300.0	1000 V	5 kHz	90 + 10	30

Example: Calculate AC Voltage Measurement Uncertainty

Since Measurement Uncertainty = Datron Accuracy + Calibration Uncertainty, for a 0.07 ACV OUTPUT to the multimeter and the Datron 4708 range set to 100 mV at 60 Hz, Measurement Uncertainty (μV) = $\pm [(60.0 \times 0.07) + (2 \times 20 \times .1) + 5] + [(30 + 1)] = \pm 44.2 \mu\text{V} = \pm 0.000044 \text{ V}$.

Or, for a 300 ACV OUTPUT to the multimeter and the Datron 4708 range set to 1000 V at 5 kHz, Measurement Uncertainty (μV) = $\pm [(90.0 \times 300.0) + (10 \times 1100)] + 30 = \pm 38030 \mu\text{V} = \pm 0.038030 \text{ V}$.

Calculate Resistance Measurement Uncertainty

From *Section 6 - Specifications* of the *Datron 4708 User's Handbook*, 4-Wire Resistance (Option 30) Accuracy (90 days since last calibration and $23^{\circ}\text{C} \pm 1^{\circ}\text{C}$) follows, where Datron Accuracy = $\pm(\text{ppm OUTPUT} + \text{ppm FS})$.

Datron Range (Ohms)	Datron Accuracy (ppm)	Calibration Uncertainty (ppm)
1.0000000k	3	5
100.00000k	3	6
1.0000000M	10	12

Example: Calculate 4-Wire Ohms Measurement Uncertainty

For the 100k Ω range, measurement uncertainty = $[(3 \times 10^{-6} \times 10^5) + (6 \times 10^{-6})] \Omega = (0.3 + 0.000006) \Omega = 0.300 \Omega$.

Test Accuracy Ratio (TAR) Calculations

For the Agilent E1326B multimeter **Test Accuracy Ratio (TAR)** = $[\text{High Limit} - \text{Input Value}] / \text{Measurement Uncertainty}$ where the source input value is in DCV, ACV, or Ohms.

Example: Calculate DCV Test Accuracy Ratio

For a 7.0 DCV measurement if the High Limit value = 7.000750 DCV and the Measurement Uncertainty = .0000115 DCV, Test Accuracy Ratio (TAR) = $(7.000750 \text{ V} - 7.0000000 \text{ V}) / .0000115 \text{ V} = 65:1$ (rounded to the nearest integer value). Since this value is >10:1, the entry in Table 4-1 is ">10:1".

Verification Tests - C Programs

Functional Verification Test

This program is designed to do the Functional Verification Test found in *Chapter 4 - Verification Tests*.

Example: Self Test

This example performs a multimeter self-test to ensure that the multimeter is communicating with the mainframe, external controller, and/or external terminal.

```
#include <stdio.h>
#include <siicl.h>

#define ADDR "hpib7,9,03"          /* Address of device */

void main ()
{
    INST id;                       /* Define id as an instrument */
    char a[256] = {0};             /* Result variable */

    id = iopen (ADDR);             /* Open instrument session */

    ipromptf(id, "**TST?\n", "%t", a); /* Self test command */

    printf("\n %s", a);            /* Print result */

    getchar();                     /* Pause */

    iclose (id);                   /* Close instrument session */
}
```

Performance Verification Tests

These programs are designed to do the Performance Verification Tests found in *Chapter 4 - Verification Tests*.

Example: Zero Volt DCV Test

This example performs a DCV test for zero volts input and a power line reference frequency of 60 Hz.

```
/* Zero Volt DCV Test   E1326B */

#include <stdio.h>
#include <scil.h>

#define ADDR "hpib7,9,03"      /* Address of Agilent E1326B */

void main (void)
{
    INST id;                  /* Define id as an instrument */
    char volt[256] = {0};     /* Result variable */

    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _InitEasyWin();
    #endif

    ionerror(I_ERROR_EXIT);

    id = iopen (ADDR);       /* Open instrument session */

    iprintf (id, "**RST\n");  /* Resets and set autozero
                               ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    ipromptf (id, "MEAS:VOLT:DC? .1\n", "%t", volt);
    /* Measure 0.113 V range */
    printf ("Voltage for 0.113 V range = %s\n", volt);

    ipromptf (id, "MEAS:VOLT:DC? .9\n", "%t", volt);
    /* Measure 0.91 V range */
    printf ("Voltage for 0.91 V range = %s\n", volt);

    ipromptf (id, "MEAS:VOLT:DC? 7\n", "%t", volt);
    /* Measure 7.27 V range */
    printf ("Voltage for 7.27 V range = %s\n", volt);

    ipromptf (id, "MEAS:VOLT:DC? 58\n", "%t", volt);
    /* Measure 58.1 V range */
    printf ("Voltage for 58.1 V range = %s\n", volt);

    ipromptf (id, "MEAS:VOLT:DC? 300\n", "%t", volt);
    /* Measure 300 V range */
    printf ("Voltage for 300 V range = %s\n", volt);

    iclose (id);             /* Close instrument session */
}
```

Example: DC Voltage Test

This test performs a DC Voltage test for positive input DC volts and a power line reference frequency of 60 Hz.

```
/* DC Voltage Test (DCV Input) E1326B */

#include <stdio.h>
#include <siicl.h>

#define ADDR "hpib7,9,03" /* Address of Agilent E1326B */

void main ()
{
    INST id; /* Define id as an instrument */
    float range[5] = {0.113, 0.910, 7.270, 58.10, 300.0};
    float volts[5] = {0.1, 0.9, 7.0, 58.0, 300.0};
    char measurement[5][256], complete[256]; /* Result variable */
    int i;

    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _InitEasyWin();
    #endif

    ionerror(L_ERROR_EXIT); /* Exit on error */

    id = iopen (ADDR); /* Open instrument session */

    iprintf (id, "RST\n"); /* Resets and set autozero
                           ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    for(i = 0; i < 5; i++) /* Take voltage measurements */
    {
        printf("\n Set DC Standard to %.1f VDC", volts[i]);
        printf("\n press ENTER when ready\n");
        getchar ();
        iprintf(id, "CONF:VOLT:DC %f\n", range[i]); /* Voltage range */
        ipromptf(id, "**OPC?\n", "%s", complete); /* Wait for settling */
        ipromptf(id, "READ?\n", "%t", measurement[i]); /* Read voltage */
    }

    for (i=0; i < 5; i++) /* Print voltage measurements */
        printf("\n Voltage on %4f V range = %s ", range[i], measurement[i]);

    iclose (id); /* Close instrument session */
}
```

Example: AC Voltage Test

This example performs an AC voltage test for a power line reference frequency of 60 Hz.

```
/* AC Voltage Test      E1326B */

#include <stdio.h>
#include <sicl.h>

#define ADDR "hpib7,9,03"      /* Address of Agilent E1326B */

void main ()
{
    INST id;                    /* Define id as an instrument */
    float source_volts[4] = {0.07, 0.07, 0.07, 300.0};
    float source_freq[4] = {60, 5000, 10000, 5000};
    char measurement[4][256], complete[256]; /* Result variable */
    int i;

    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _initEasyWin();
    #endif

    ionerror(I_ERROR_EXIT); /* Exit on error */

    id = iopen (ADDR);        /* Open instrument session */

    iprintf (id, "RST\n");    /* Resets and set autozero
                               ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    for(i = 0; i < 4; i++)    /* Take voltage measurements */
    {
        printf("\n 1. Set AC Standard output to %.2f VAC",
               source_volts[i]);
        printf("\n 2. Set AC Standard frequency to %.1f
               Hz", source_freq[i]);
        printf("\n 3. Press ENTER when ready\n");
        getchar ();

        iprintf(id, "CONF:VOLT:AC %f\n", source_volts[i]);
        /* Set voltage range */
        ipromptf(id, "OPC?\n", "%s", complete);
        ipromptf(id, "READ?\n", "%t", measurement[i]);
        /* Read voltage */
    }

    for (i=0; i < 4; i++)    /* Print voltage measurements */
        printf("\n Voltage for %4f V range at %.1f Hz = %s ", source_volts[i],
               source_freq[i], measurement[i]);

    iclose (id);            /* Close instrument session */
}
```

Example: Resistance Test

This example performs a 4-wire ohms resistance test. The program also calculates the Upper and Lower Limit values for the ACTUAL resistance values. Use these values in Table 4-1 if they differ from the given values.

```
/* Resistance Test (4-wire Ohms) E1326B */

#include <stdio.h>
#include <siicl.h>

#define ADDR "hpb7,9,03" /* Address of Agilent E1326B */

void main ()
{
    INST id; /* Define id as an instrument */
    float range[3] = {1861, 119156, 1048576};
    float source[3] = {1000, 100000, 1000000};
    char measurement[3][256], complete[256];
    float limit[3], actual[3];
    int i;

    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _initEasyWin();
    #endif

    ionerror(L_ERROR_EXIT); /* Exit on error */

    id = iopen (ADDR); /* Open instrument session */

    iprintf (id, "RST\n"); /* Resets and set autozero
                           ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    for(i = 0; i < 3; i++) /* Take measurements */
    {
        printf("\n 1. Set Resistance Standard to %.1f Ohms", source[i]);
        printf("\n 2. Measure ACTUAL resistance standard value (in
               Ohms)");
        printf("\n 3. Enter ACTUAL resistance standard (in Ohms): ");
        scanf("%f", &actual[i]);

        iprintf(id, "CONF:FRES %f\n", range[i]);
        /* Set resistance range */
        ipromptf(id, "OPC?\n", "%s", complete); /* Wait for settling */
        ipromptf(id, "READ?\n", "%t", measurement[i]);
        /* Read resistance */

        if (i == 0)
            limit[i] = .0004*actual[i] + 0.02; /* 2kOhm limits */
        if (i == 1)
            limit[i] = .0004*actual[i] + 1.0; /* 131 kOhm limits */
        if (i == 2)
            limit[i] = .0004*actual[i] + 10; /* 1 MOhm limits */
    }

    printf("\nMeasured Source Low Limit High Limit");
    printf("\nResistance Resistance (Ohms) (Ohms)\n");

    for (i=0; i < 3; i++) /* Print measurements and limits */
        printf("\n%s %10.2f %10.2f %10.2f",
               measurement[i], actual[i], actual[i]-limit[i], actual[i]+limit[i]);

    iclose (id); /* Close instrument session */
}
```

Adjustments

These programs are designed to do the adjustments found in *Chapter 5 - Adjustments*.

DC Voltage Adjustments

This example performs DC Voltage adjustments for a power line reference frequency of 60 Hz. If no calibration error occurs, the program displays an "adjustment complete" message. If a calibration error occurs, the program displays the calibration error and prompts you to repeat the adjustment (see Table 5-1 for a list of calibration errors).

```
/* DC Voltage Adjustments   E1326B */

#include <stdio.h>
#include <siicl.h>

#define ADDR "hpib7,9,03"      /* Address of device */

void main ()
{
    INST id;                  /* Define id as an instrument */
    float range[10] = {8.0, 8.0, 0.125, 0.125, 1.0, 1.0, 64.0, 64.0,
                      300.0, 300.0};
    float volts[10] = {7.7, -7.7, .121, -.121, .97, -.97, 62.0, -62.0,
                      300.0, -300.0};
    char cal_code[5][256];
    int i;
    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _InitEasyWin();
    #endif
    ionerror(L_ERROR_EXIT);   /* Exit on error */
    id = iopen (ADDR);        /* Open instrument session */
    iprintf (id, "RST\n");     /* Resets and set autozero
                               ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */
    for(i = 0; i < 10; i++)   /* Take voltage measurements */
    {
        retry:
        printf("\n Set DC Standard to %.1f VDC", volts[i]);
        printf("\n press ENTER when ready\n");
        getchar ();
        iprintf(id, "FUNC:VOLT:DC\n"); /* Set DCV function */
        iprintf(id, "VOLT:RANG %f\n", range[i]); /* Set E1326B range */
        iprintf(id, "CAL:VAL %f\n", volts[i]); /* Set CAL:VAL value */
        iprintf(id, "TRIG:DEL .05\n"); /* Wait for settling */
        ipromptf(id, "CAL?\n", "%t", cal_code[i]); /* Read voltage */

        if (cal_code != 0)
        {
            printf ("\nCalibration Error %s for %f Vdc input", cal_code,
                    volts[i]);
            printf ("\nCheck source value/connections, then");
            printf ("\npress ENTER to retry this adjustment");
            getchar ();
            goto retry;
        }
        else
            printf ("\nAdjustment complete for %f Vdc input", volts[i]);
    }
    iclose (id);              /* Close instrument session */
}
```

AC Voltage Adjustments

This example performs an AC Voltage adjustment for a power line reference frequency of 60 Hz and an input of 5.6 Vac at 1 kHz. If no calibration error occurs, the program displays an "adjustment complete" message. If a calibration error occurs, the program displays the calibration error and prompts you to repeat the adjustment (see Table 5-1 for a list of calibration errors).

```
/* AC Voltage Adjustments   E1326B */

#include <stdio.h>
#include <fcntl.h>

#define ADDR "hpib7,9,03"      /* Address of device */

void main ()
{
    INST id;                    /* Define id as an instrument */
    char cal_code[256];

    #if defined(__BORLANDC__) && !defined(__WIN32__)
        _initEasyWin();
    #endif

    ionerror(L_ERROR_EXIT);     /* Exit on error */

    id = iopen (ADDR);          /* Open instrument session */

    iprintf (id, "RST\n");      /* Resets and set autozero
                                ON and PLC to 1 */
    printf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    retry:
    printf("\n Set AC Standard to 5.6 Vac at 1.0 kHz");
    printf("\n press ENTER when ready\n");
    getchar (); iprintf(id, "FUNC:VOLT:AC\n"); /* Set DCV function */
    iprintf(id, "VOLT:RANG 5.6\n");          /* Set E1326B range */
    iprintf(id, "CAL:VAL 5.6\n");           /* Set CAL:VAL value */
    iprintf(id, "TRIG:DEL .05\n");         /* Wait for settling */
    ipromptf(id, "CAL?\n", "%t", cal_code[i]); /* Read voltage */

    if (cal_code != 0)
    {
        printf ("\nCalibration Error %s on 5.6 Vac range", cal_code);
        printf ("\nCheck source value/connections, then");
        printf ("\npress ENTER to retry this adjustment");
        getchar ();
        goto retry;
    }
    else
        printf ("\nAdjustment complete for %f Vdc input", volts[i]);

    iclose (id);                /* Close instrument session */
}
```

Resistance Adjustments

This example performs a 4-wire ohms resistance adjustment for a power line reference frequency of 60 Hz. If a calibration error occurs, the program displays the calibration error and prompts you to repeat the adjustment (see Table 5-1 for a list of calibration errors).

```
/* 4-wire Resistance Adjustments E1326B */

#include <stdio.h>
#include <siicl.h>

#define ADDR "hpib7,9,03" /* Address of device */

void main ()
{
    INST id; /* Define id as an instrument */
    float range[3] = {2000, 16000, 1048576};
    float source[3] = {1000, 10000, 1000000};
    char cal_code[5][256];
    float actual[3];
    int i;

    #if defined(__BORLANDC__) && !defined(__WIN32__)
    _InitEasyWin();
    #endif

    ionerror(I_ERROR_EXIT); /* Exit on error */

    id = iopen (ADDR); /* Open instrument session */

    iprintf (id, "RST\n"); /* Resets and set autozero
                           ON and PLC to 1 */
    iprintf (id, "CAL:LFR 60\n"); /* Sets line reference to 60 Hz */

    for(i = 0; i < 3; i++) /* Take voltage measurements */
    {
        retry:
        printf("\n Set Resistance Standard to %.1f Ohms", source[i]);
        printf("\n Measure ACTUAL Resistance Standard value (in
               Ohms:");
        scanf ("%f", &actual[i]);

        iprintf(id, "FUNC:FRES\n"); /* Set DCV function */
        iprintf(id, "FRES:RANG %f\n", range[i]); /* Set E1326B range */
        iprintf(id, "CAL:VAL %f\n", actual[i]); /* Set CAL:VAL value */
        ipromptf(id, "CAL?\n", "%t", cal_code[i]); /* Read voltage */

        if (cal_code[i] != 0)
        {
            printf ("\nCalibration Error %s for %f Ohms", cal_code[i],
                    source[i]);
            printf ("\nCheck source value/connections, then");
            printf ("\npress ENTER to retry this adjustment");
            getchar ();
            goto retry;
        }
        else
            printf ("\nAdjustment complete with %f Ohms source\n",
                    source[i]);
    }

    iclose (id); /* Close instrument session */
}
```