



**E8042A Analysis Probe
for the Intel® Xeon™ Processor
in the 603-Pin Package**

Interposer Installation Quick Start



The interposer is a precision instrument. To avoid damaging the interposer, carefully follow the instructions in this Quick Start and in the “Probing the Target System” chapter of the User’s Guide.



Manual Part Number E8034-92002 Printed in USA January 2002



Agilent Technologies



Check to see if the interposer socket is open.



The square openings in the middle of the socket and base should be flush at the keyed end when the socket is in the open position.

When the socket is open, no clips should be visible when looking down into the socket.

If clips are still visible when the socket is in the open position, the socket clips may be damaged.

DO NOT attempt to insert the processor into a damaged socket. This will damage the pins.

If the socket is open, go to page 4. If the socket is closed, proceed to page 2.





Open the interposer socket.

Line up the groove slot on the actuation tool arm with the interposer socket cover.

Make sure the tool arm is being attached to the keyed end of the interposer socket marked ***open***.

Drop the legs of the actuation tool into the matching holes on the interposer.

Do not attempt to insert the legs until the slot on the arm has been attached to the cover.





Open the interposer socket (Cont'd)

Insert a 1/8 inch wide flathead screwdriver into the actuation tool in the slot between the two shoulder screws.

Move the screw driver handle in the direction shown in the above pictures. As the socket is actuated, the cover will move about 1mm into the open position. Actuation should not require excessive force. If the cover does not move immediately, remove the actuation tool and check to see if it was attached to the correct end of the socket.

When the cover has actuated, remove the actuation tool by lifting it up and out of the interposer holes. Verify that the square opening is aligned flush with the opening in the socket base at the keyed end of the socket. If the cover is over-or under-actuated, use your hands to move the cover into the correct open position.




Insert the processor into the interposer.

Insert the processor into the interposer socket by lining up the keyed end of the socket with the keyed end of the processor.

The processor should drop into the socket with little or no force required. If there is resistance, check again to insure the socket is open or that the clips in the socket are not damaged.

Do not force the processor into the socket. This could result in damaged pins.


If the processor is correctly inserted into the interposer socket, it will be seated flat against the socket.



Close the interposer socket


Follow the same instructions for opening the socket, (pages 2-3) except this time attach the tool to the non keyed end instead of the keyed end. The end is marked by the **closed** label on the flex. As the socket is actuated, you will feel the socket move and the pins lock into place. Actuation should not require excessive force.

If the cover does not move, remove the actuation tool and check to see that the processor is seated properly and that the tool is attached to the correct end of the socket. Verify that the processor is locked into the interposer by removing the actuation tool and attempting to remove the processor with your hands. If the processor is correctly locked in, removing it with your hands will not be possible.



Remove the actuation tool


Remove the actuation tool by doing the reverse of the installation instructions. Remove the legs then remove the slot from the cover. Removal is easiest if the tool is lifted up and out of the interposer in a counter clockwise fashion.



Remove the pin protector

The interposer should have been shipped with the pin protector in the **open** and unlocked position.

If the interposer is not easily removed from the pin protector, unlock it by inserting a 1/8 inch wide screw driver into the pin protector socket actuator at the non-keyed end marked **closed**. The actuator can be seen through the openings in the flex circuit. Move the handle of the screw driver toward the processor. Be careful not to damage the flex circuit with the screw driver.





Insert the interposer into the mother board socket.

Check to see that the mother board socket is in the open position.

The easiest way to insert the interposer is to hold both wings of the interposer with one hand. Line up the opening in the flex circuit with the actuator on the mother board socket.

Make sure the keyed end of the interposer is lined up with the keyed end of the mother board socket.



Lock the interposer into the mother board socket.

Insert the 1/8" wide screwdriver into the mother board socket through the opening in the flex at the end marked "closed".

Press down on the interposer slightly while actuating the mother board socket to make sure the interposer does not push itself out of the socket during actuation.

Move the screwdriver in the same fashion as before to actuate the mother board socket.

Once the mother board socket has been actuated, the interposer should be sitting flat against the mother board socket.

Summary - Removal Instructions

See User's Guide for more details.

1. Unlock the mother board socket.
2. Remove the interposer from the mother board socket.
3. Place the interposer into the pin protector.
4. Attach the actuation tool to the end marked "open" on the interposer.
5. Actuate the socket open.
6. Remove the processor.

© Copyright
Agilent Technologies Inc. 2001,
2002
All Rights Reserved.

Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

Restricted Rights Legend.

Use, duplication or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Agilent Technologies Inc.
395 Page Mill Rd.
Palo Alto, California 94303
U.S.A.

Rights for no- DOD U.S. Government Departments and Agencies are set forth in FAR 52.227-19(c) (1,2).

Document Warranty

The information contained in this document is subject to change without notice.

Agilent Technologies Inc. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose.

Agilent Technologies Inc. shall not be liable for errors contained herein or for damages in connection with the furnishing, performance, or use of this material.

Agilent Technologies
P.O. Box 2197
1900 Garden of the Gods Road
Colorado Springs, CO. 80901

Product Warranty

This Agilent Technologies Inc. product has a warranty against defects in material and workmanship for a period of one year from date of shipment. Some newly manufactured Agilent Technologies Inc. products may contain remanufactured parts which are equivalent to new in performance. During the warranty period, Agilent Technologies Inc. will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies Inc.

For products returned to Agilent Technologies Inc. for warranty service, the Buyer shall prepay shipping charges to Agilent Technologies Inc. and Agilent Technologies Inc. shall pay shipping charges to return the product to the Buyer. However, the Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument software, or firmware will be uninterrupted or error free.

Limitation of Warranty

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by the Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

No other warranty is expressed or implied. Agilent Technologies Inc. specifically disclaims the implied warranties of merchantability or fitness for a particular purpose.

Exclusive Remedies

The remedies provided herein are the buyer's sole and exclusive remedies. Agilent Technologies Inc. shall not be liable for any direct, indirect, special, incidental, or consequential damages, whether based on contract, tort, or any other legal theory.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies Inc. products. For any assistance, contact your nearest Agilent Technologies Sales Office.

Certification

Agilent Technologies Inc. certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies Inc. further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology, to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.