

## **PSA-Series Spectrum Analyzers**

This manual provides documentation for the following analyzers:

E4440A

E4443A

E4445A

E4446A

E4447A

E4448A

**Security Features and  
Document of Volatility**

## Table of Contents

---

Contacting Agilent Sales and Service Offices .....	3
Products Covered by this Document .....	4
Security Terms and Definitions .....	5
Instrument Memory .....	6
Summary of Memory Declassification Procedures.....	11
Memory Sanitization Procedures .....	14
Recording Critical Information.....	14
Backing up the Option and License Key Information to a PC .....	14
Secure Erase All.....	15
Secure Erase User.....	16
User and Remote Interface Security Measures .....	17
Remote Access Interfaces .....	17
Procedure for Declassifying a Faulty Instrument.....	18
References.....	19

## Contacting Agilent Sales and Service Offices

---

Assistance with test and measurements needs, and information on finding a local Agilent office, is available on the Internet at:

<http://www.agilent.com/find/assist>

If you do not have access to the Internet, please contact your field engineer.

**Note:** In any correspondence or telephone conversation, refer to the instrument by its model number and full serial number. With this information, the Agilent representative can determine whether your unit is still within its warranty period.

## Products Covered by this Document

---

Product Family Name	Product Names	Model Numbers
High-Performance Spectrum Analyzers	PSA-Series Spectrum Analyzers	E4440A, E4443A, E4445A, E4446A, E4447A, E4448A

This document describes instrument security features and the steps to declassify an instrument through memory clearing, sanitization or removal.

For additional information, go to:

<http://www.agilent.com/find/security>

**Note:** Be sure that all information stored by the user in the instrument that needs to be saved is properly backed up before attempting to clear any of the instrument memory. Agilent Technologies cannot be held responsible for any lost files or data resulting from the clearing of memory. Be sure to read this document entirely before proceeding with any file deletion or memory clearing.

## Security Terms and Definitions

---

Term	Definition
<b>Clearing</b>	As defined in Section 8-301a of <b>DoD 5220.22-M</b> , clearing is the process of eradicating the data on media before reusing the media so that the data can no longer be retrieved using the standard interfaces on the instrument. Clearing is typically used when the instrument is to remain in an environment with an acceptable level of protection.
<b>Instrument Declassification</b>	A term that refers to procedures that must be undertaken before an instrument can be removed from a secure environment, such as is the case when the instrument is returned for calibration. Declassification procedures include memory sanitization or memory removal, or both. Agilent declassification procedures are designed to meet the requirements specified in <b>DoD 5220.22-M</b> , Chapter 8.
<b>Sanitization</b>	As defined in Section 8-301b of <b>DoD 5220.22-M</b> , sanitization is the process of removing or eradicating stored data so that the data cannot be recovered using any known technology. Instrument sanitization is typically required when an instrument is moved from a secure to a non-secure environment, such as when it is returned to the factory for calibration.  Agilent memory sanitization procedures are designed for customers who need to meet the requirements specified by the US Defense Security Service (DSS). These requirements are specified in the "Clearing and Sanitization Matrix" in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b> .
<b>Secure Erase</b>	Secure Erase is a term that is used to refer to either the clearing or sanitization features of Agilent instruments.

## Instrument Memory

This section contains information on the types of memory available in your instrument. It explains the size of memory, how it is used, its location, volatility, and the sanitization procedure.

Table 1: Summary of instrument memory - base instrument

Memory Type and Size	Writable During Normal Operation?	Data Retained When Powered Off?	Purpose/ Contents	Data Input Method	Location in Instrument and Remarks	Sanitization Procedure
Main Memory (Flash) 48 MByte or 64 MByte See Note 2 below	Yes See Note 1 below	Yes	Used to store firmware, operating system, and other system files.  If Option 115 or 117 is not installed, user-saved state files are also stored here.  If Option 115 or 117 is installed, these files are stored in the Compact Flash memory (see Table 2 for details).  To determine installed options, see Note 3 below.	Programmed before installed, by firmware operations, and by user input	A26A2 Flash Memory Board	See Table 4
Boot Memory (NVRAM) 96 kByte	Yes	Yes	Stores instrument boot information, instrument state (parameter settings) information, and the like.	Programmed before installed and by Firmware operations	A26 CPU Assembly	See Table 7
Firmware Memory (DRAM) 256 MByte	Yes	No	Temporarily stores the firmware "running program"	Firmware operations	A26 CPU Assembly (128 MByte)  A26A1 DRAM Card (128 MByte)  Volatile memory	Cycle power

Memory Type and Size	Writable During Normal Operation?	Data Retained When Powered Off?	Purpose/ Contents	Data Input Method	Location in Instrument and Remarks	Sanitization Procedure
Config & Cal Memory (EEPROM) 1 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A7 Digital IF Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 1 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A8 Analog IF Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 1 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A9 2 <sup>nd</sup> LO Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 16 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A10 3 <sup>rd</sup> Converter Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 1 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A11 Reference Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 16 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A12A1 LO Synthesizer Assembly  Contains no user data	See Table 8
Config & Cal Memory (EEPROM) 96 kByte	No	Yes	Used to identify the assembly and store factory calibration data and option configuration data.	Programmed before installed and by Firmware operations (cal routines)	A13 Front End Driver Assembly  Contains no user data	See Table 8

Memory Type and Size	Writable During Normal Operation?	Data Retained When Powered Off?	Purpose/ Contents	Data Input Method	Location in Instrument and Remarks	Sanitization Procedure
Option 107 Config & Cal Memory (EEPROM) 32 kByte	No	Yes	Used for the A37 Audio Digitizer calibration data.	Programmed before installed and by Firmware operations (cal routines)	A37 Audio Digitizer Assembly Contains no user data	See Table 8
Option 110/123 Config & Cal Memory (EEPROM) 128 kByte	No	Yes	Used to store flatness data for the Option 110 preamp, and Option 123 amplitude flatness calibration data.	Programmed before installed and by Firmware operations (cal routines)	A38 Option Driver Assembly Contains no user data	See Table 8

*Notes*

1. This memory is *not* writable when Option 117 is installed and enabled.
2. To determine the installed memory size, press **[System] > More (1 of 3) > Show Hdw.**
3. To determine which options are installed, press **[System] > More (1 of 3) > More (2 of 3) > Personality.** The instrument displays a list of installed options.



Table 2: Summary of instrument memory - Option 117

Memory Type and Size	Writable During Normal Operation?	Data Retained When Powered Off?	Purpose/Contents	Data Input Method	Location in Instrument and Remarks	Sanitization Procedure
User Memory (Flash) 512 MByte <b>(Option 117)</b>	Yes	Yes	<p>When Option 117 is installed and enabled, Main Memory is mounted Read Only and any user-alterable memory is relocated to the A39A1 flash card.</p> <p>The flash card stores: User state, Trace, Screen dumps, Result files, Power on last state, Limit Lines, and Amplitude Corrections.</p> <p>See Table 3 below for a comparative summary.</p>	User input	A39A1 flash card, located on A39 Memory Board.	See Table 6

Table 3 below summarizes the memory locations for all file types, with and without Options 115 or 117 installed.

Option 115 uses the same Compact Flash memory card as Option 117, but uses the additional memory to store Downloadable Personalities, User State, Trace, and Power On Last State files. Option 115 and Option 117 are mutually exclusive: an instrument may have at most one of these options installed.

*Table 3: Summary of File Locations by Type*

<b>File Type</b>	<b>Location without Options 115 or 117</b>	<b>Location with Option 115</b>	<b>Location with Option 117</b>
Amplitude Corrections	Main Flash	Main Flash	Compact Flash
Core User Preset Files	Main Flash	Main Flash	Compact Flash
LAN Configuration	Main Flash	Main Flash	Main Flash
License Keys	Main Flash	Main Flash	Main Flash
Limit Line	Main Flash	Main Flash	Compact Flash
Mode Cache Files	Main Flash	Compact Flash	Compact Flash
Network Settings	Main Flash	Main Flash	Main Flash
Personalities	Main Flash	Compact Flash	Main Flash
Personality Data Files	Main Flash	Compact Flash	Main Flash
Personality Package Files	Main Flash	Compact Flash	Main Flash
Personality Power On Last State	Main Flash	Compact Flash	Compact Flash
Personality User Preset Files	Main Flash	Compact Flash	Compact Flash
User State, Trace, Screen dumps and result files	Main Flash	Compact Flash	Compact Flash

## Summary of Memory Declassification Procedures

---

This section explains how to clear, sanitize, and remove memory from your instrument, for all classes of memory that are writeable during normal operation.

**Important:** Before beginning clearing or sanitization, be sure to write down and save the instrument's Option and License Key information. The "Secure Erase All" procedure erases the option and license key information and this information is essential for successful restoration of the instrument's operating system.

**Note:** Read this entire document before using any sanitization procedure. Failure to do so may necessitate returning the instrument to an Authorized Agilent Service Center for firmware downloads and recalibration.

*Table 4: Main Flash*

<b>Description and purpose</b>	<p>This memory is used to store firmware, operating system, and other system files.</p> <p>If Option 117 is not installed, this memory also stores all user-saved files, including: User State, Trace, Screen Dumps, Results, Power On Last State, Limit Lines and Amplitude Corrections.</p> <p>If Option 117 is installed, all user-saved files are instead stored in the additional Compact Flash memory, as described in Table 6.</p>
<b>Size</b>	<p>Either 48 Mbytes or 64 Mbytes. To determine how much Flash is installed, press <b>[System] &gt; More (1 of 3) &gt; Show Hdw.</b></p>
<b>Memory clearing</b>	<p>This memory can be cleared by carefully following the instructions in "Secure Erase All" presented later in this document.</p> <p>This procedure complies with the clearing requirements specified for Flash EPROM in the "Clearing and Sanitization Matrix" in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b>.</p>
<b>Memory sanitization</b>	<p>This memory can be sanitized by carefully following the instructions in "Secure Erase All" presented later in this document.</p> <p>This procedure complies with the sanitization requirements specified for Flash EPROM in the "Clearing and Sanitization Matrix" in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b>.</p>
<b>Memory removal</b>	N/A
<b>Memory validation</b>	<p>When this memory is cleared, the instrument will not load the operating system or the firmware and is effectively rendered inoperative.</p>
<b>Remarks</b>	<p>Be sure to write down and save the instrument's option and license key information before performing a "Secure Erase All" procedure. This procedure erases the option and license key information, which is essential for successful restoration of the instrument's hardware and software options.</p>

Table 5: Compact Flash (Option 115)

<b>Description and purpose</b>	If Option 115 is installed, this memory is used to store: Measurement Personalities, User State, Trace, Screen Dumps, Results, Power On Last State, Limit Lines, and Amplitude Corrections.
<b>Size</b>	512 Mbytes
<b>Memory clearing</b>	This memory can be cleared by carefully following the instructions in “Secure Erase User” presented later in this document. This feature requires firmware revision A.09.00 or higher.  This procedure complies with the clearing requirements specified for Flash EPROM in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b> .
<b>Memory sanitization</b>	This memory can be sanitized by carefully following the instructions in “Secure Erase User” presented later in this document.  This procedure complies with the sanitization requirements specified for Flash EPROM in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b> .
<b>Memory removal</b>	You can physically remove the A39 Memory Board, which contains this memory, from the instrument.
<b>Write protecting</b>	This memory cannot be write-protected.
<b>Memory validation</b>	N/A

Table 6: Compact Flash (Option 117)

<b>Description and purpose</b>	If Option 117 is installed, this memory is used to store: User State, Trace, Screen Dumps, Results, Power On Last State, Limit Lines, and Amplitude Corrections.
<b>Size</b>	512 Mbytes
<b>Memory clearing</b>	This memory can be cleared by carefully following the instructions in “Secure Erase User” presented later in this document.  This procedure complies with the clearing requirements specified for Flash EPROM in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b> .
<b>Memory sanitization</b>	This memory can be sanitized by carefully following the instructions in “Secure Erase User” presented later in this document.  This procedure complies with the sanitization requirements specified for Flash EPROM in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b> .
<b>Memory removal</b>	You can physically remove the A39 Memory Board, which contains this memory, from the instrument.
<b>Write protecting</b>	This memory cannot be write-protected.
<b>Memory validation</b>	N/A

Table 7: NVRAM

<b>Description and purpose</b>	Memory used to store instrument boot information, instrument state (parameter settings) information, and the like.
<b>Size</b>	96 kBytes (about 32 kBytes are dedicated to storing boot information)
<b>Memory clearing</b>	<p>Press [<b>System</b>] &gt; <b>Power On/Preset</b>. If “Factory” is not shown under Preset Type, press <b>Preset Type</b> and select <b>Factory</b>. Pressing <b>Power On</b> toggles between “Last” and “Preset.” Make sure Preset is selected, then press the green <b>Preset</b> key. This clears the NVRAM of any measurement data and restores factory default settings.</p> <p>This procedure complies with the clearing requirements specified for NVRAM in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the <b>ISFO Process Manual</b>.</p>
<b>Memory sanitization</b>	This memory can be sanitized by carefully following the instructions in “Secure Erase All” presented later in this document. This procedure complies with the sanitization requirements specified for Flash in the “Clearing and Sanitization Matrix” in Section 5.2.5.5.5 of the ISFO Process Manual.
<b>Memory removal</b>	N/A
<b>Memory validation</b>	N/A

Table 8: EEPROM

<b>Description and purpose</b>	This memory is used to identify the assembly and store factory calibration data and option configuration data.
<b>Size</b>	1 kByte, 16 kBytes, or 96 kBytes (refer to Table 1)
<b>Memory clearing</b>	Since this memory contains no user information, it need not be cleared.
<b>Memory sanitization</b>	This memory contains no user-accessible information, therefore sanitization is not applicable, and there is no provision for sanitizing this memory.
<b>Memory removal</b>	EEPROM is not accessible to the instrument user and therefore need not be cleared or sanitized.
<b>Memory validation</b>	N/A

## Memory Sanitization Procedures

---

### Recording Critical Information

1. Record the Ethernet Number of the instrument. Press [**System**] > **More** > **Show System**. The Ethernet Number is a 12-digit alphanumeric string with a hyphen between the first set of six characters and the last set of six characters; for example, 001083-b80c55. Having this number recorded will save time when you re-install the firmware.
2. Record the IP address of the instrument. Press [**System**] > **Config I/O**.
3. Save the Application License Keys by either saving a screen capture of the license keys or writing down the options and license key information:
4. Obtain a list of the License Keys by saving a screen capture of the instrument's Licensing Screen. To do this, press [**System**] > **More (1 of 3)** > **More (2 of 3)** > **Licensing** > **Show License**. Next, use the PSA file manager to save an image of the PSA screen to a formatted floppy disk. Insert a formatted disk in the front panel disk drive, then press [**File**] > **Save**, press **Type** and select **Screen**, press **Format** and select **Bitmap**, press **Dir Select** and select "A." Press **Save Now**. The file can be displayed or printed from any application capable of reading Windows bitmap (.bmp) files.
5. Verify the screen capture of the license keys has been properly saved to the floppy disk, prior to proceeding, by opening the file using a computer. If you are *unable* to save the license key information using this procedure, write down the "Option" and "License Key" numbers.
6. Properly store this Application License Key data in a safe place (or attach this information to the top cover of the instrument).

### Backing up the Option and License Key Information to a PC

1. Load the PSA Series Firmware Update Program from the following Agilent Web site:  
[http://www.agilent.com/find/psa\\_firmware](http://www.agilent.com/find/psa_firmware). Click the download link for the firmware update EXE file:  
PSA\_Axx.xx.exe.
2. Begin the PSA firmware upgrade procedure. Accept the licensing agreement. When prompted for an instrument IP address, enter the instrument's IP address.
3. Allow the configuration files to be saved to the default location on the PC.
4. The analyzer's user data, options, and license keys are saved in a file named `Config` under a directory that begins with the model number, followed by the serial number, then a date and time stamp on the C: drive of the PC; for example, "C:\E4448A\US42070187\15-Oct-02-11-29-AM\Config." Make a note of the path name. This file will be used to restore the analyzer's configuration and License Keys after Secure Erase All has been used to erase its memory.

- When the screen regarding loading the operating system and options appears, exit the firmware upgrade process. At this point, you have saved the configuration files (including the License Keys). You do *not* need to continue with the instrument firmware download.


## Secure Erase All

**Note:** Before starting this procedure, make a record of the instrument's license key and other critical information by following either of the procedures "Recording Critical Information" or "Backing up the Option and License Key Information to a PC", as described above.

The following procedure erases all persistent storage in the instrument; that is, the operating system, firmware, and all user files. This procedure should be performed *only* when the instrument is to be removed from a secure area.


The procedure requires firmware revision A.09.00 or higher.

- Press **[System] > More (1 of 3) > More (2 of 3) > Security > Secure Erase All**.
- The instrument displays a message warning you that, if you proceed with the erasure operation, the instrument will be rendered unusable until you reinstall the instrument firmware. If you definitely want to proceed, press **Secure Erase All** again.




This key will delete all data and firmware in the instrument.  
You will need to reinstall firmware after executing this operation.  
Press the key again if you wish to proceed

- The instrument displays a further message, asking you to confirm that you wish to proceed. Press **Yes** to continue, or press **No** to exit without altering any part of the memory.



Please Confirm Erase Operation  
Press Yes to erase all data and firmware from the instrument.  
Press No to cancel the operation

- If you press **Yes**, the erase operation starts, and cannot be aborted. The instrument displays a progress bar during the operation.




Erasing System Flash  
Percent Complete  
4%

## Secure Erase User

**Note:** This function is available *only* if Option 117 is installed.


Use this function to erase all user-saved files from the instrument, while retaining the instrument's operating system, firmware, license keys and network settings.

1. Press **[System] > More (1 of 3) > More (2 of 3) > Security > Secure Erase User**.
2. The instrument displays a message warning you that, if you proceed, you will erase all user data. If you definitely want to proceed, press **Secure Erase User** again.




This key will reformat the C: drive and erase all user data from the instrument. You will lose all save states and traces. Press the key again if you wish to proceed

3. The instrument displays a further message, asking you to confirm that you wish to proceed. Press **Yes** to continue, or press **No** to exit without altering any part of the memory.



Please Confirm Erase Operation  
Press Yes to reformat C: and erase all saved states and traces.  
Press No to cancel the operation

4. If you press **Yes**, the erase operation starts, and *cannot* be aborted. The instrument displays a progress bar during the operation.



Erasing User Flash  
Percent Complete  
15%



## User and Remote Interface Security Measures

---

### Remote Access Interfaces

The GPIB command LLO (local lockout) can be sent by the controller to prevent front-panel keyboard access.

The user is responsible for providing security for the I/O ports for remote access by controlling physical access to the I/O ports. The I/O ports must be controlled because they provide access to most user settings, user states, and the display memory.

## **Procedure for Declassifying a Faulty Instrument**

---

If the instrument is not able to power on, the user information cannot be cleared using the front panel or the remote interface. The only choice in this situation is to take manual steps to remove any user information that may be present. This includes removing the A26 CPU assembly. Refer to the Service Guide for your instrument for removal procedures.

## References

---

1. **DoD 5220.22-M, “National Industrial Security Program Operating Manual (NISPOM)”**  
United States Department of Defense. Revised February 28, 2006.  
May be downloaded in Acrobat (PDF) format from:  
[http://www.dss.mil/isp/fac\\_clear/download\\_nispom.html](http://www.dss.mil/isp/fac_clear/download_nispom.html)
2. **ISFO Process Manual for the Certification and Accreditation of Classified Systems under the NISPOM**  
Defense Security Service.  
DSS-cleared industries may request a copy of this document via email, by following the instructions at:  
<http://www.dss.mil/isp/odaa/request.html>

This information is subject to change without notice.

© Agilent Technologies, Inc. 2005-2011

Published in USA, December 2011

Supersedes: June 2009

E4440-90631