3560A-01

S	Е	R	V	I	С	Е		Ν	0	Т	E
							SUPE	RSEDE	S: None)	
356	0A Por	table I	Dynar	nic Sig	gnal Ai	nalyze	r				
Seria	al Numbe	ers: 0000	A0000	0 / 3319	A00846						
Firn	nware U	Ipgrade	e: Rev	vision	A.00.00) to A.0	0.02				
	s Require	ed:									
Part No.				Description							
03560-84402			F	Firmware Upgrade kit							
Kit (Contents:										
Part	No.	Qty.	D	escript	ion						
0356	0-60321	1		GM EP							
0356	0-60322	1	Р	GM EP	ROM						
0356	0-90016	1	Ν	lanl- Op	o. & Serv	vice					
0356	0-90017	1	N	lote-Inst	allation						
5001	-7615	1	I	C-Extra	ctor						
Situa	ation:										
	3560A fir						y software	e defects	. Most of	these	
defec	ets are con	rected ir	the ne	w revisi	on A.00.	02.					
									(Continued	
							DATE·	18 Oct	ober 199	33	

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:										
MODIFICATION RECOMMENDED										
ACTION CATEGORY:	 IMMEDIATELY ON SPECIFIED FAILURE AGREEABLE TIME 	ON SPECIFIED FAILURE Labor 0.5 Hour								
LOCATION CATEGORY:	CUSTOMER INSTALLABLE	SERVICE □ RETURN USED □ RETURN INVENTORY: ■ SCRAP PARTS: ■ SCRAP □ SEE TEXT □ SEE TEXT								
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: 18 October 1995								
AUTHOR: DAA	ENTITY: A100	ADDITIONAL INFORMATION:								

© 1993 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



Solution/Action:

Check the current firmware revision from the 3560A front panel:

- 1. Turn instrument on.
- 2. Read the Revision number on the screen; press PRESET if you missed it (first display only lasts 2 to 3 seconds at power up).

If revision is A.00.00, then order the firmware update kit (p/n 03560-84402) and install two new EPROMs, as per kit installation note instructions.



The EPROM installation must be performed at a static protected workstation to prevent static discharge to the PC assembly.

Copy all stored 3560A files to a PC, as they will be lost due to the EPROM change.

Firmware upgrade Rev A.00.02 provides the following corrections:

- 1. Transfers map files saved in the upper 50% of memory.
- 2. Full octave span won't change when you save/recall.
- 3. Corrects Coherence measurements with no input signal.
- 4. Corrects LOG and ZOOM ON intermittent operation.
- 5. LOGMAG Y-axis does not start at zero.
- 6. Saves trace scaling along with the data.

Added Enhancements:

- 1. Easier units conversion when integrating.
- 2. Y-axis pan up/down.
- 3. Xon/Xoff RS232 handshake.
- 4. Trace type labels added.
- 5. Key beeper added.
- 6. Laser printer plot added.
- 7. Integration of transfer functions added.
- 8. Special preset state added.