

1680A/AD-Series and 1690A/AD-Series Logic Analyzers

The Following manual is a copy of the 1680/90 logic analyzer online help system. Information covering the operation of any "Add-in" tools listed in the Tools Menu of the product is covered in separate documentation for those tools.

1680A/AD-Series



1690A/AD-Series



Table of Contents

TUTORIAL - GETTING TO KNOW YOUR LOGIC ANALYZER 17

Logic analyzer basics	19
When should I use an oscilloscope	19
When should I use a logic analyzer	20
What is a Logic Analyzer	21
What is a Logic Analyzer	21
What is a timing analyzer	21
What is a state analyzer	21
Clocking data in the timing analyzer	22
Sampling in the timing analyzer	23
Sampling accuracy	23
Triggering the timing analyzer.....	25
Pattern Trigger.....	25
Edge Trigger	25
Clocking data in the state analyzer	27
Sampling in the state analyzer	28
Triggering the state analyzer	29
Probing options.....	31
General Purpose Probing	31
Adaptor to board connectors	33
Analysis Probes	33
Measurement overview	34
Turning on the logic analyzer.....	34
Connecting to the target system	35
Credit card demo board	36
Setting up bus/signal names	37
Delete bus/signal names	37
Add new bus/signal name.....	37
Map signals into the analyzer	38
Setting the acquisition mode	39
Setting up a simple trigger	40
Open the tutorial configuration file	41
Load the configuration file	41
View the data.....	41
Using markers	42
To create a marker	42
To place a marker in data	42
Go To a marker in data	42
Zooming in on the data	43
Expand a bus	43

Change the scale	43
Time saving tasks	44
Loading and saving configuration files	44
Saving and recalling trigger setups.....	45
To recall a trigger setup	45
Quick marker measurements.....	46
Searching data	47
Toolbars, tooltips and mouse shortcuts.....	48
Toolbars.....	48
Mouse shortcuts	48
Tooltips.....	48
MEASUREMENT EXAMPLES.....	49
Making a timing analyzer measurement	50
Bus and signal setup.....	50
Acquisition mode setup	50
Trigger setup	50
Run the measurement.....	50
Making a state analyzer measurement.....	51
Bus and signal setup.....	51
Acquisition mode setup	51
Trigger setup	51
Run the measurement.....	51
External Triggering	52
Trigger signal characteristics.....	52
To trigger other instruments - Trigger Out	52
To trigger analyzer from another instrument - Trigger In	52
Making marker measurements.....	54
To create a new interval measurement.....	55
To create a new value at measurement	56
TRIGGER FUNCTIONS	57
Timing mode trigger functions	57
Edge	60
"N" number of edges	61
Edge followed by edge.....	62
Edge followed by pattern	63
Edges too far apart	64
Pattern	65

Edge and Pattern	66
Pattern present for > "T" time	67
Pattern present for < "T" time	68
Pattern absent for > "T" time	69
Pattern absent for < "T" time	70
Pattern too late after edge	71
Pattern "AND" Pattern (timing)	72
Pattern "OR" Pattern (timing)	73
Find anything "N" times (timing).....	74
Width violation on pattern or pulse.....	75
Wait "T" seconds.....	76
Wait for external arm (timing).....	77
Run until user stop (timing)	78
Reset and start timer (timing)	79
Advanced If/Then (timing)	80
Advanced 2-Way Branch (timing).....	81
Advanced 3-Way Branch (timing).....	82
Advanced 4-Way Branch (timing).....	83
State mode trigger functions	84
Pattern "N" times	85
"N" consecutive samples with Pattern1	86
Pattern1 followed by Pattern2.....	87
Pattern1 immediately followed by Pattern2	88
Pattern1 followed by Pattern2 before Pattern3.....	89
Too few states between Pattern1 and Pattern2	90
Too many states between Pattern1 and Pattern2	91
Pattern2 occurring too soon after Pattern1	92
Pattern2 occurring too late after Pattern1	93
Find anything "N" times (state).....	94
Run until user stop (state)	95
Reset and start timer (state)	96
Wait for external arm (state).....	97
Wait "N" external clock states.....	98
Pattern "AND" Pattern (state)	99
Pattern "OR" Pattern (state).....	100
Advanced If/Then (state)	101
Advanced 2-Way Branch (state)	102
Advanced 3-Way Branch (state)	103
Advanced 4-Way Branch (state)	104

TASK GUIDE..... 105

Waveform Window Tasks	106
Bus/Signal configuration	106
To reposition bus/signal names	107
Simple Trigger	107
Marker display bar	107
Waveform display area	107
Working with Markers	109
To set waveform window properties	110
To set window properties.....	110
To set row properties	110
To set background color	110
To set font size	110
To set an overlay color.....	111
To show activity indicators.....	111
To show tool tip - values	111
To show tool tip - transition width	111
To set markers - snap to edge	111
To set markers - move edge on screen	111
To set markers - place on edge	112
To select the Bus/Signal.....	112
To set data color	112
To set row height	112
To set numeric base	112
To show data values	113
To show soft glitch	113
To set bus options	113
To set waveform style - Bus	113
To set waveform style - Magnitude	113
To expand into signals	114
Change delay	115
Change scale (time/division)	116
Change the scale.....	116
Draw a rectangle in the data	116
To overlay bus/signals.....	118
To group signals into a bus	119
To add or delete display windows.....	120
To add a new display windows	120
To delete display windows	120
Turning window tabs on/off.....	121
Set quick trigger with rectangle	122
General guidelines:	122
Specific guidelines to the listing display:	122
Specific guidelines to the waveform display:	122

To draw the rectangle	122
Tool Tips.....	124
To add user comments	125
To edit symbols for a bus/signal	126
To add a symbol.....	126
To edit a symbol.....	126
To delete a symbol	126
To save symbols.....	126
Listing Display Window	128
Column configuration	128
To reposition bus/signal names	129
Simple Trigger	129
Marker display bar	129
Listing display area	129
Column configuration	130
Insert Column Before.....	130
Insert Column After	130
Delete Column	130
Assign Channels	130
Rename	130
Symbols.....	130
Display.....	130
Properties.....	130
To set listing window properties.....	131
To set window properties.....	131
To set column properties	131
To set background color	131
To set font size	131
Column display options	131
Display activity indicators.....	131
Display column base.....	132
Display simple trigger	132
To show center rectangle	132
To select the Bus/Signal name	132
To set data color	132
To set column width	133
To set column alignment	133
To set numeric base	133
To set marker relative.....	133
To display symbols.....	134
Example.....	135

Buses/Signals Setup	136
Read only options	136
To add a new bus or signal.....	138
To delete a bus or signal.....	139
To delete an individual bus or signal	139
To delete all buses and signals	139
To rename a bus or signal.....	140
To assign channels.....	141
To set thresholds	142
To set numeric base	143
To set polarity	145
To set setup/hold.....	146
To add a folder	148
To alias a bus/signal name.....	149
Sampling Setup Tasks	150
State - Synchronous Sampling mode.....	150
Timing - Asynchronous Sampling mode	150
To set the acquisition mode.....	152
To select the timing analyzer	152
To select the state analyzer	152
To set acquisition depth.....	153
To set the trigger position	154
To select the state clock type	155
Master	155
Master/Slave	155
Demultiplex	156
To set the state clock qualifier	157
To set up advanced clocking.....	158
To set the sampling period.....	159
To set sampling options	160
Transitional timing	161
More on storing transitions	161
Minimum transitions stored	161
Maximum transitions stored.....	161
Transitional timing considerations.....	161
Data storage.....	161
Sequence level branching.....	162
Global counters.....	162
Storing Time Tags	162
Increasing Duration of Storage.....	162
Invalid Data.....	162
Trigger Position	162

Triggering	163
Simple Trigger Tasks	164
Simple Trigger	164
To set bus pattern triggers	166
Operators	166
To set signal trigger options	167
Options	167
To triggering on a glitch	167
Advanced Trigger Tasks	168
Advanced Trigger Dialog	168
To build a trigger sequence	169
Trigger steps	169
To set store qualification	170
Default storage	170
Sequence step storage	170
Storage interaction	171
How to read event and action statements	173
To insert events and actions	174
To negate a function statement	176
To modify trigger step display	177
ANDing and ORing Event statements	179
To store a trigger	180
Most recently used trigger list	180
Stored favorite triggers list	180
Recall Trigger Dialog	181
To recall a trigger	181
To configure a counter	182
To insert a counter event	182
To insert a counter action	182
See Also	183
To configure a timer	184
Model	184
Timing Acquisition Mode	184
State Acquisition Mode	184
To insert a timer check event	184
To insert a timer start action	185

Marker Tasks	187
To create new markers	187
Using abbreviated names	187
To place markers in data	188
Place marker at center screen	188
Place marker at mouse cursor	188
Go To Markers	189
To center the display about a marker	190
To delete a marker.....	191
To rename a marker.....	192
To send a marker to the back.....	193
To set marker properties.....	194
To rename the marker	194
Using abbreviated names	194
To change the marker color	194
To hide the marker	194
To lock marker in viewer	194
To change the marker type.....	195
To drag and drop markers in data	196
Reading off-screen markers.....	197
File Management Tasks.....	198
File management	198
To open a configuration file	199
To save a configuration file	201
To recall a recently used configuration file.....	203
To import files	204
To import a file	204
Information not imported from XML file.....	205
To export files	206
To export a file.....	206
Information not imported from XML file.....	207
Searching.....	209
To search for a value.....	210
To perform complex pattern searches.....	211
To Go To a specific position in the acquisition	213
Favorite Find Pattern	214
To store a favorite pattern.....	214
To recall a favorite pattern	214
To delete a favorite pattern	215
Find Options.....	216

To use the Place function.....	216
To use the Place new marker on each occurrence function.....	216
Capturing Data	217
To start/stop measurements	218
To run the analyzer in single mode	218
To run the analyzer in repetitive run mode	218
To stop the analyzer	218
To print data and screens.....	219
To print data	219
To copy and print text	219
To copy and print a screen	219
To install a printer.....	221
To connect a LAN.....	222
REFERENCE.....	223
Product Overview	224
Supplied Accessories	224
1680A/AD-series.....	224
1690A/AD-series.....	224
Optional Accessories.....	224
Documentation	224
Quick Start/Installation Guide.....	224
Online Help System.....	224
Agilent Technologies Web Sites	225
Corporation/Contact.....	225
Product Information	225
Documentation	225
Intrinsic Support	225
Table of 1680-series channel, memory, and speed	226
Model	226
Channel Count and Memory Depth.....	226
Table of 1690-series channel, memory, and speed	227
Model	227
Channel Width and Memory Depth.....	227

Front Panel Operation	228
Run/Stop	228
Item	228
Description	228
Save/Open Setup.....	228
Item	228
Description	228
General purpose knob	228
Alphanumeric Keypad	228
Item	229
Description	229
Shortcuts	229
Item	229
Description	229
Vertical	229
Item	230
Description	230
Horizontal	230
Item	230
Description	230
Marker.....	231
Item	231
Description	231
Probing	232
General Purpose Probing.....	233
Adaptor to board connectors	234
Analysis Probes.....	234
Self Tests	235
To access self test menu	235
Self test descriptions	235
Register Test	235
Memory Test.....	235
Comparator Test	235
Trigger Bus Test.....	236
Trigger Arm Test	236
Clock Paths Test.....	236
Memory Modes Test.....	236
Calibration Test.....	236

Menus.....	237
File Menu	238
Edit Menu	239
View Menu	241
Setup Menu.....	242
Tools Menu	243
Markers Menu.....	244
Run/Stop Menu.....	245
Window Menu.....	246
Help Menu.....	247
Toolbars.....	248
Standard Toolbar	249
Setup Toolbar.....	251
Markers Toolbar.....	252
Run/Stop Toolbar.....	253
Viewers Toolbar	254
To create a custom toolbar.....	255
To add tool icons.....	255
To remove tool icons.....	255
Windows	256
Dialogs	257
Analyzer Setup Dialog	258
Analyzer Setup Dialog	258
System Options Dialog	259
To change how many triggers are saved.....	259
To change the length of the file history	259
To create data when offline.....	259
To set Trigger In and Trigger Out	259
To set message level	260
Properties Dialog	261
Properties Dialog	261
Symbol Selection	262

Specifications and Characteristics	263
1680/1690-Series Logic Analyzer Characteristics	264
General Information	264
Probes	264
State Analysis	264
Timing Analysis	264
Triggering	265
Operating Environment Characteristics	265
1680/90A-Series Logic Analyzer Specifications	266
About the Probe Cable	267
Signal Requirements	268
Minimum Signal Amplitude	268
Signal Loading	268
Maximum Probe Input Voltage	268
Overdrive	268
What is a Specification?	270
What is a Calibration Procedure?	270
What is a Characteristic?.....	271
What is a Function Test?	271
Markers Display Bar.....	272
Marker Measurement Display Bar	273
Config Translator Application	274
To convert a configuration file	274
Information not converted from file	275
Error Messages	276
Error messages.....	276
Acquisition errors	276
Bus/Signal errors.....	276
File errors.....	278
Hardware errors	278
Help file errors	279
Import/Export and Translator errors	279
Naming errors.....	281
Tool errors.....	281
Trigger Errors	282
Warning Messages	284

Informational messages.....	285
Keyboard Commands.....	287
Access Menus.....	287
File Operations.....	287
Edit Operations.....	287
Search Operations.....	288
View Operations.....	288
Run/Stop Operations.....	288
Window Operations.....	288
Help Operations.....	288
Miscellaneous.....	288
Data Formats.....	290
ALA Format.....	290
General.....	290
Trigger specifications.....	290
Analyzer characteristics.....	291
Bus/Signal folders.....	291
Bus/Signal information (per bus/signal).....	291
Marker information.....	291
Find value.....	292
Search event parameters.....	292
Symbols.....	292
Tools (e.g., inverse assemblers).....	292
Filters.....	292
Listing display attributes.....	292
Waveform display attributes.....	292
CSV Format.....	294
XML Format.....	295
<Setup> section.....	295
<Module> subsection.....	295
<Tool> subsection.....	295
<Data> section.....	296
<Module> subsection.....	296
<TimeData> subsection.....	296
<DigitalData> subsection.....	296
<Tool> subsection.....	297
<IntegralData> and <StringData> subsections.....	297

Tutorial

Getting to know your logic analyzer

The following tutorial is intended to give new users a quick overview of logic analyzer basics. In addition to learning the concepts of logic analysis, you will see some of the logic analyzer's more common features by going through a measurement overview. Finally, you are shown some easy time saving tasks that can quickly make you as productive as the more experienced user.

Logic analysis basics

- When should I use an oscilloscope
- When should I use a logic analyzer
- What is a logic analyzer

Timing analyzer

- Clocking
- Sampling
- Triggering

State analyzer

- Clocking
- Sampling
- Triggering
- Probing options

Measurement overview

The following overview does not require an active target system. However, in order to show features that work on data, you are asked to load a configuration file between steps 5 and 6 that contains data to finish the exercise.

- Turning on the logic analyzer
- Connecting to the target system
- Setting up bus/signal names
- Setting the acquisition mode
- Setting up a simple trigger
- Open the tutorial configuration file
- Using markers
- Zooming in on the data

Time saving tasks

- Loading and saving configuration files
- Saving and recalling trigger setups
- Quick marker measurements
- Searching data
- Toolbars and mouse shortcuts

See Also

Product overview

Logic analyzer basics

When should I use an oscilloscope

[Tutorial Home](#)


[Next Topic](#)

[Previous Topic](#)


Generally, an oscilloscope is used when you need precise parametric information such as time intervals and voltage readings.

More specifically:

- When you need to measure small voltage excursions on your signals such as undershoot or overshoot.



- When you need high time-interval accuracy. Oscilloscopes can capture precise parametric information such as the time between two points on a rising edge of a pulse with very high accuracy.



When should I use a logic analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

Generally, a logic analyzer is used to view timing relationships among many signals, or if you need to trigger on patterns of logic highs and lows. A logic analyzer reacts the same way as the logic circuits do when a voltage threshold is crossed by a signal in the device under test. It will recognize the signal to be either low or high.

More specifically:

- When you need to see many signals at once. Logic analyzers are very good at organizing and displaying multiple signals. A common task is to group multiple signals into a bus and assign a custom name. Good examples are address, data, and control buses.
- When you need to look at signals in your system the same way your hardware does. Signals are displayed on a time axis so you can see when transitions occur relative to other bus signals or clock signals.
- When you need to trigger on a unique bus pattern or signal edge. Logic analyzers can be configured to store data when the high or low values of a group (bus) of signals match a predefined pattern. Logic analyzers can be configured to store data when a specific edge or level is detected on a single signal.

What is a Logic Analyzer

What is a Logic Analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

Now that we've talked a little about when to use a logic analyzer, let's look in more detail at what a logic analyzer is. Up to now, we've used the term "logic analyzer" rather loosely. In fact, most logic analyzers are really two analyzers in one.

What is a timing analyzer

A timing analyzer is the part of a logic analyzer that is analogous to an oscilloscope. As a matter of fact, they can be thought of as close cousins.

The timing analyzer displays information in the same general form as a scope, with the horizontal axis representing time and the vertical axis as voltage amplitude. Because the waveforms on both instruments are time-dependent, the displays are said to be in the "time domain".

The basic areas of functionality in a timing analyzer are as follows:

Clocking data in the timing analyzer

Sampling in the timing analyzer

Triggering the timing analyzer

What is a state analyzer

A state analyzer is very good at tracking down bugs in software or defective components in hardware. It can help eliminate the question whether a problem is in the software code or some hardware device.

Most often, state analyzers are used to find out what logic levels are present on a bus when a particular clock signal occurs. In other words, you want to know what "state of activity" is present when the clock occurs and data is suppose to be valid. Data captured in memory is displayed in a listing format with a time tag attached to every state.

The basic areas of functionality in a state analyzer are as follows:

Clocking data in the state analyzer

Sampling in the state analyzer

Triggering the state analyzer

Clocking data in the timing analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

The timing analyzer uses its own internal clock to control the sampling of data. This type of clocking makes the sampling of data in the logic analyzer **asynchronous** to the clocking in the device under test.

More specifically:

- A timing analyzer is good at showing you "When" signal activity occurs "Relative to other signals".
- A timing analyzer is more interested in viewing the timing relationships between individual signals, than the timing relationships to the signals that are controlling execution in the device under test.
- This is why a timing analyzer can sample data "out of sync", or asynchronous to the target system clock signals.

Sampling in the timing analyzer


[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

The timing analyzer works by sampling the input waveforms to determine whether they are high or low. It determines a high or low by comparing the voltage level of the incoming signal to a user-defined voltage threshold. If the signal is above that threshold when it samples, it will be displayed as a 1 or high by the analyzer. By the same criterion, any signal sampled that is below threshold is displayed as a 0 or low.

The figure below illustrates how a logic analyzer samples a sine wave as it crosses the threshold level.




The sample points are then stored in memory and used to reconstruct a more squared-off digital waveform.

This tendency to square everything up would seem to limit the usefulness of a timing analyzer. However, a timing analyzer is not intended as a parametric instrument. If you want to check rise time of a signal with an analyzer, you should use a scope. But if you need to verify timing relationships among several or hundreds of signals by seeing them all together, a timing analyzer is the right choice.

Sampling accuracy

When the timing analyzer samples an input channel, it is either high or low. If the channel is at one state (high or low) on one sample, and the opposite state on the next sample, the analyzer "knows" that the input signal has transitioned sometime between the two samples. It doesn't know when, so it places the transition point at the next sample, as shown in the figure below.



This presents some ambiguity as to when the transition actually occurred and when it is displayed by the analyzer.

Worst case for this ambiguity is one sample period, assuming that the transition occurred immediately after the previous sample point.

With this technique however, there is a trade-off between resolution and total acquisition time. Remember that every sampling point uses one memory location. Thus, the higher the resolution (faster sampling rate), the shorter the acquisition window.

Triggering the timing analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)


At some point in a measurement, the logic analyzer has to know when to capture (store) the data that is flowing through it's memory. This is know as the trigger point.

One way to get the analyzer to trigger is to configure the analyzer to look for either a pattern of highs and lows from a group of signals (bus), or a rising or falling edge from a single signal. When the analyzer sees the specified patterns or edges in data, it triggers.

Pattern Trigger

Pattern triggers are used to find specific patterns of highs and lows across a bus. You can specify different kinds of criteria such as equal, not equal, in or out of a range, or greater than/less than.

Example: You have a bus containing 8 signal lines. You configure the Simple Trigger to specify that the analyzer triggers when the incoming data is equal to a pattern of "AA".




To make things easier for some users, the trigger point on most analyzers can be set not only in Hex, but in binary (1's and 0's), octal, ASCII, or decimal. For instance, the Hex trigger value of AA could also be set to an equivalent binary trigger value of 0101 0101. However, using hex for the trigger point is particularly helpful when looking at buses that are 16, 24, 32, or 64 bits wide.

Edge Trigger

Edge triggering is a familiar concept to those accustomed to using an oscilloscope. When adjusting the "trigger level" knob on a scope, you could think of it as setting the level of a voltage comparator that tells the scope to trigger when the input voltage crosses that level. A timing analyzer works essentially the same on edge triggering except that the trigger level is preset to a logic threshold.

While many logic devices are level dependent, clock and control signals of these devices are often edge-sensitive. Edge triggering allows you to start capturing data as the device is clocked.

Example: Take the case of an edge-triggered shift register that is not shifting data correctly. Is the problem with the data or the clock edge? In order to check the device, we need to verify the data when it is clocked – on the clock edge. The analyzer can be told to capture data when the clock edge occurs (rising or falling) and catch all of the outputs of the shift register.



Clocking data in the state analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

The state analyzer requires a clock signal from the target system. This type of clocking makes the sampling of data in the logic analyzer **synchronous** to the clocked events on the device under test.

More specifically:

- A state analyzer is good at showing you "What" the signal activity is during a "Valid clock or control signal".
- A state analyzer is more interested in viewing signal activity during specified times of target system execution, than signal activity unrelated to the target system timing.
- This is why a state analyzer wants to sample data that is "synchronized" or synchronous to the target system clock signals.

Sampling in the state analyzer

[Tutorial Home](#)


[Next Topic](#)

[Previous Topic](#)

In the world of microprocessors, you can have both data and address appearing on the same signal lines. To capture the correct data, the state analyzer has to restrict the sampling of data to times when only the desired data is valid and appears on the signal lines. It does this by sampling data from the same signal lines but with different clocks.

Example: The following timing diagram shows that to capture addresses, we want the analyzer to sample when MREQ line goes low.


To capture data, we want the analyzer to sample when the WR line goes low (write cycle) or when RD goes low (read cycle).




Triggering the state analyzer

Similar to a timing analyzer, a state analyzer has the capability to qualify the data we want to store. If we are looking for a specific pattern of highs and lows on the address bus, we can tell the analyzer to start storing when it finds that pattern and to continue storing until the analyzer's memory is full.

Simple Trigger Example: Looking at the "D" flip-flop shown below, data on the "D" input is not valid until after a positive-going clock edge occurs. Thus, a valid state for the flip-flop is when the clock input is high.



Now imagine that we have eight of these flip-flops in parallel. All eight are connected to the same clock signal as shown below.



When a high level occurs on the clock line, all eight capture data at their "D" inputs. Again, a valid state occurs each time there is a positive level on the clock line.

The following simple trigger tells the analyzer to collect data on lines D0 - D7 when a high level is on the clock line.

Sample Number	D0 - D7	Clock
	<input type="text" value="= X [grid icon]"/>	<input type="text" value="1"/>
-10	7FF6	1
-9	7FF7	0
-8	7FF8	1
-7	7FF9	0

Advanced Trigger Example: You want to see what data is stored in memory at the address value 406F6. You configure the advanced trigger to look for the pattern 406F6 (hexadecimal) on the address bus and a high level on the RD (memory read) clock line.

Step 1 Pattern n times

Find 1 occurrence of

Bus/Signal ADDR All bits Equals 4 06F6 Hex And

Bus/Signal RD High

Then Trigger and fill memory

with Anything

As you configure the Edge And Pattern trigger dialog, try to think of it as constructing a sentence that reads left-to-right.

"Find the first occurrence of a **Bus** named **ADDR**, and on **All bits** a pattern that **Equals 406F6 Hex**, And a **Signal** named **RD** with a **High** level. Then **Trigger and fill memory** with **Anything**.

Probing options

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

- General Purpose Probing (Standard)
- Adapter to board connectors (Optional)
- Analysis probes (Optional)

So far we've talked about some of the differences between scopes, timing and state analyzers. Before we're ready to apply these new tools, we should talk about one more subject – the probing system.

A scope probe is designed to gain easy access to the target system while minimizing the signal distortion. Since we want to look at parametric information like voltage levels and rise times, it is important that the probe doesn't load the circuit under test significantly. A typical scope probe has 1 M ohm impedance shunted by 10 pF, depending on the bandwidth required.


Logic analyzer probes are designed to allow connection of a high number of channels to the target system easily by trading off amplitude accuracy of the signal under test. Remember that a logic analyzer only distinguishes between two voltage levels!

Traditionally, logic analyzers used active probe pods, which had an integrated signal detection circuitry for eight channels integrated. From these pods, we could connect with leads to the circuit under test.

The typical impedance of a logic analyzer probe is in the area of 100 k ohm shunted by 8 pF at the input of the active pod. The connecting wires, however, add another 8 pF stray capacitance, giving a total of 16 pF per channel.


General Purpose Probing

Physical connections to digital systems must be reliable and convenient to deliver accurate data to the logic analyzer with minimum intrusion to the target system. The standard general purpose probing solution shown below is shipped with the logic analyzer. Each channel is terminated at both ends with 100k ohm and 8 pF.



The standard set plugs directly into any .1-inch grid with 0.026 to 0.033-inch diameter round pins or 0.025-inch square pins. All probe tips work with the Agilent Technologies 5059-4356 surface mount grabbers and the Agilent Technologies 5959-0288 through-hole grabbers.

Adaptor to board connectors



Both the 01650-63203 and the E5346A adapters include termination for the logic analyzer. The 01650-63203 termination adapter plugs into a 2 x 10 pin header with 0.1 inch spacing. The E5346A high-density adapter connects to an AMP "Mictor 38" connector.

Analysis Probes

Connecting a state analyzer to a microprocessor system requires some effort in terms of mechanical connection and clock selection. Remember, we have to clock the state analyzer whenever data or addresses on the bus are valid. With some microprocessors it might be necessary to use external circuitry to decode several signals to derive the clock for the state analyzer.

Analysis probes (formerly called preprocessors) are microprocessor-specific interfaces that make it easier to probe buses. Generally, analysis probes consist of a circuit board that attaches to the microprocessor (possibly through an adapter) and a configuration file. The configuration file sets up the logic analyzer's clocks, buses, and signals correctly, and may include an inverse assembler. The circuit board provides access to logical groups of pins through headers designed to connect directly to the logic analyzer.

Measurement overview


Turning on the logic analyzer

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

1. Plug in the power cable and press the front-panel On/Off button.
2. From the Windows Start bar, click **Start>Programs>Agilent Logic Analyzer>Agilent Logic Analyzer**.



Optional: If you have a logic analyzer shortcut icon on screen, double-click the icon.

Connecting to the target system


[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

The standard probing that comes with the logic analyzer is the passive general purpose probe with sixteen channels per cable. Each channel is terminated at both ends with 100k ohm and 8 pF. With this type of probing, you can also disconnect the leads and plug the cable connector directly into a connector on the device under test.

Note: In this tutorial, no probe connections are required. Later on in this tutorial, you are asked to load a configuration file containing data to simulate the results of a probed device under test. However, at this time, if you have the credit card demo board available, you can connect it and capture real data for this tutorial.



As the number of channel connections increase, other probing options may be more convenient.


Credit card demo board

[Tutorial Home](#)

[Previous Topic](#)

If you have a credit card demo board available, you can connect it as shown below and capture the same data used in this measurement overview. Other benefits are that you will see real activity indicators in the bus/signal setup dialog.

1. Connect the probe cable of **Pod 1** into connector **J1** of the demo board.



Setting up bus/signal names

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

By default, the analyzer has two buses (My Bus 1 & 2) and two signals (My Signal 1 & 2) configured in the interface. The following exercise cleans up the display defaults and re-configures the analyzer bus/signal setup for a new measurement.

Delete bus/signal names

1. In the menu bar click **Setup>Buses/Signals**.
2. In the Analyzer Setup dialog that appears, right-click on **My Bus 1**, then select **Delete**. Repeat until all bus signal names are deleted. After the last bus/signal is deleted, "My Bus 1" appears again as a default name.




Tip: You can delete all bus/signal configurations at once with the **Delete All** button.

Bus/Signal Name	Channels Assigned	Width
My Bus 1		
My Bus 2		
My Signal 1		
My Signal 2		

Pod 1															
Threshold: TTL (1.50 V)															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
								✓	✓	✓	✓	✓	✓	✓	✓
✓	✓	✓	✓	✓	✓	✓	✓								

Add new bus/signal name

1. In the Analyzer Setup dialog, right-click on **My Bus 1**, then select **Rename**.
2. From the keypad that appears, type in the new name "counter".
3. Select **Ok**.




Map signals into the analyzer

The analyzer must be told which probed signals from the device under test are to be included in the measurement, and how you want them grouped in the analyzer. In this exercise, you assign channels 0 - 7 on Pod 1 under the name "counter". Notice that when more than one channel is assigned to "counter" it becomes a bus.

1. Check the activity indicators for verification of proper connection to the target system. You should see a transition arrow on all 8 channels.

Note: If you have the credit card demo board connected for this tutorial, you will see activity indicators as shown below. If you will be loading the demo configuration file (later in this tutorial) you will not see activity.

1. Click each **channel assignment box** under channels 0 - 7 on Pod 1. Notice that as you assign channels, the configuration information is updated for the bus/signal.
2. Click **Ok**.



Setting the acquisition mode

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)


Under the Sampling tab of the Analyzer Setup dialog is where you set the analyzer to be either a timing or state analyzer. You also set either the timing options, such as memory depth or sampling period, or the state clocking options.

1. From the menu bar, click **Setup>Timing/State (Sampling)...** , or click the



icon in the toolbar.

2. Select **Timing - Asynchronous Sampling**.
3. Click **Ok**.





Setting up a simple trigger


[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

The Simple Trigger is a quick way to configure the analyzer to trigger on either a data pattern on a bus, or an attribute of a single signal such as a rising edge or a low logic level.

1. In the Simple Trigger, click on the **pattern qualifier**  and set it to **Equal**.
2. Click in the **text entry field**  and enter the data pattern "E5".



Open the tutorial configuration file

[Tutorial Home](#)


[Next Topic](#)

[Previous Topic](#)

At this point in a measurement, you would normally run the logic analyzer. However, because you are not connected to a device under test, you cannot capture real data. You will have to load a configuration file that contains this data.


Load the configuration file

1. Select **File>Open**.
2. From the file manager dialog, select the file named **DemoConfig.ala** from the following directory: **C:\Documents and Settings\All Users\Documents\Agilent Technologies\Logic Analyzer\Provided Configs\Agilent\Help Demo**
3. Select **Open**.



View the data

Notice how the logic analyzer triggered on data pattern E5 and placed it in the center of the display. The red line shows that the trigger point is at the start of the data pattern E5.



Using markers

[Tutorial Home](#)


[Next Topic](#)

[Previous Topic](#)

Markers are used for creating reference points in data. Once markers are placed in data, you can use them to quickly see what time, sample, or data value the marker is set on.

To create a marker

1. From the menu bar, click **Markers>New**.
2. From the New Marker dialog that appears, configure the new marker and if desired, specifically a position it in data. When you do not position the marker, by default it is placed at the trigger point.
3. Select **Ok**.



To place a marker in data

When you first create a new marker, you have the option to place it in data at a specific point in time or a specific sample number. The following exercise shows you other ways to position markers in data.

1. In the display, click on marker M3 (your new marker) and while holding the mouse button down, drag marker M3 to -100ns before trigger, then release. Notice that the marker position value changes as you move it.
2. From the menu bar, click **Markers>Place On Screen**, then select M1 and click **Ok**. Notice how M1 is placed at center screen at the red trigger line.
3. Point the mouse cursor at any desired point in data, then right-click and select **Place Marker**. From the Place Marker dialog that appears, choose the M2 marker. Notice that the marker is placed where the mouse was pointing.

Go To a marker in data

Once you have markers set in data, you can quickly find any of them as follows.

1. From the menu bar, click **Markers>GoTo**.
2. Select the marker you want to find, and click **Ok**.

Zooming in on the data


[Tutorial Home](#) | [Next Topic](#) | [Previous Topic](#)

Data from a timing analyzer is displayed similarly to oscilloscope data. Both an analyzer and scope display waveforms on a horizontal time axis. Therefore to zoom in or out on a waveform, change the Scale (time/division) of the time axis of the waveform.

Both state and timing analyzers can have multiple signals grouped together in a bus. To get a view of all signals, you can expand a bus into individual signals.


Expand a bus

Click the "+" symbol just to the left of the bus named "counter". The collection of signals under "counter" breaks out into individual signals named counter[0] - counter[7].



Change the scale

Click the zoom out icon to expand the signals to where you want them.



Time saving tasks

Loading and saving configuration files


[Tutorial Home](#)[Next Topic](#)[Previous Topic](#)

Many times it is quicker to open an existing configuration file with a similar setup than to create a new configuration from scratch. You simply open a similar file, make the appropriate changes to the setup, then save the file as a new filename.

Note: When you rename an existing configuration file, you retain the saved trigger setups and "Find" search favorites from the first configuration file.

You already have learned how to open a configuration file. In the following exercise, you will save the "democonfig" file to a new name.

1. From the menu bar, click **File>Save As...**
2. From the file manager dialog that appears, type in the new name "myconfig", then click **Save**.



Saving and recalling trigger setups

[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

Each time you setup a new trigger and run the measurement, the trigger setup is stored in the analyzer. It is quicker to recall a trigger setup rather than re-configure the trigger setup each time.


Note: The analyzer must be run before the trigger setup is stored. Also, trigger setups are stored as part of the configuration file. If you load a new configuration file, the trigger setups will be overwritten by trigger setups stored with the new file.

To recall a trigger setup

1. From the menu bar, click **Setup>Recall Trigger**.
2. From the lower list, select the desired trigger setup, then click **Ok**.



Tip: When the list of most recently used triggers get long, you can store the most often used triggers in the upper favorites list.



Quick marker measurements


[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)


You can quickly read the time or number of samples between markers.

1. Click **Markers>New Interval Measurement**.
2. Configure the Interval dialog to display the **Time** from **M1** to **M2** as shown below, then click **Ok**.



The result of the interval measurement `M1 to M2 = 150 ns` is displayed in the marker measurements display bar.

3. Click **Markers>New Value At Measurement**.
4. Configure the Value At dialog to display the **Hex** value of **counter** at **M1** as shown below, then click **Ok**.



The result of the value at measurement `counter@M1 = E1` is displayed in the marker measurement display bar.

Searching data


[Tutorial Home](#)

[Next Topic](#)

[Previous Topic](#)

You can search for a data pattern on a bus, or a single signal. You can also choose when the search begins and ends. Finally, you can save the search criterion in a favorites list.

1. From the menu bar, click **Edit>Find**.
2. From the Find dialog that appears, configure the search criterion as shown below to find "AA".
3. Select **Ok**.



As you configure the Find dialog, try to think of it as constructing a sentence that reads left-to-right.

"**Find** the **1st** occurrence from **Display Center**, on a Bus named **counter**, including **All bits**, a pattern that **Equals AA**".

Toolbars, tooltips and mouse shortcuts

[Tutorial Home](#)

[Previous Topic](#)

Throughout this tutorial, the menu bar has been used to access features. There are two other ways to access features as well as other useful tips that can save you time.

Toolbars

Below the menu bar are groups of icons that represent shortcuts to many dialogs and features. For more information refer to Toolbars in the main help.




Mouse shortcuts

There are many mouse shortcuts available. To access them simply point the mouse over a screen element such as a marker, or screen area, then right-click the mouse. Mouse shortcuts are especially useful within the waveform and listing data display areas.

Tooltips

Tooltips are small information displays that appear during operations such as moving markers, setting a trigger with the mouse, or hovering the mouse over a bus/signal name. Use them as comments, or to monitor your progress or current positions.



Measurement Examples

The following measurement examples show you the typical order of steps to setup and run a measurement. As you go through the examples, you will encounter steps such as probing or triggering where alternative choices are available. In these steps, select the probing or trigger example that best fits your measurement.

Making a timing analyzer measurement

Making a state analyzer measurement

To trigger other instruments - Trigger out

To trigger the analyzer from another instrument - Trigger in

See Also

Tutorial - Getting to know your logic analyzer

Timing mode trigger functions

State mode trigger functions

Making marker measurements

Making a timing analyzer measurement

The following measurement example shows you the steps necessary to configure and run the logic analyzer for a typical timing analyzer measurement. As you go through the example, make the appropriate choices from the selection lists that best match the kind of configuration you need.



Tip: If you are new to logic analysis, refer to "Getting to know your logic analyzer" for a quick tutorial on logic analysis concepts and measurements.

1. Connect the **Probing** to the device under test.
2. Turn on the logic analyzer.

Bus and signal setup

3. In the menu bar, select **Setup>Bus/Signal...**
4. From the Buses/Signals tab, assign bus/signal names to the probed signals on the target system. You do this by either renaming existing names, or deleting and creating new names.
5. From the Buses/Signals tab, assign channels under the appropriate pods for all probed buses/signals on the device under test.

Acquisition mode setup

6. In the Analyzer Setup dialog, select the **Sampling** tab.
7. From the Sampling tab, set the acquisition mode to Timing - Asynchronous Sampling.
8. Set the Sampling Options.
9. Set the Sampling Period.

Trigger setup

10. The trigger required to capture specific data depends on the measurement. However, the trigger is generally set in two ways.
 - From within the data display, setup a **Simple Trigger**.
 - From the Advanced Trigger dialog, setup a timing mode **Advanced Trigger** function.

Run the measurement

11. Run the measurement.

See Also

To set the trigger position

To set acquisition depth

Making a state analyzer measurement

The following measurement example shows you the steps necessary to configure and run the logic analyzer for a typical state analyzer measurement. As you go through the example, make the appropriate choices from the selection lists that best match the kind of configuration you need.



Tip: If you are new to logic analysis, refer to "Getting to know your logic analyzer" for a quick tutorial on logic analysis concepts and measurements.

1. Connect the **Probing** to the device under test.

Note: Be sure that the clock signals of your device under test are connected to clock channels on the pods. Any unused clock channels can be used for additional data channels and will not feed into the state clock setup.

2. Turn on the logic analyzer.

Bus and signal setup

3. In the menu bar, select **Setup>Bus/Signal...**
4. From the Buses/Signals tab, assign bus/signal names to the probed signals on the target system. You do this by either renaming existing names, or deleting and creating new names.
5. From the Buses/Signals tab, assign channels under the appropriate pods for all probed buses/signals on the device under test.

Acquisition mode setup

6. In the Analyzer Setup dialog, click the Sampling tab.
7. From the Sampling tab, set the acquisition mode to State - Synchronous Sampling.
8. Set the state clock type.
9. Set the state clock qualifiers.
10. If necessary, set the advanced state clocking.

Trigger setup

11. The trigger required to capture specific data depends on the measurement. However, the trigger is generally set in two ways.
 - From within the data display, set up a **Simple Trigger**.
 - From the Advanced Trigger dialog, set up an **Advanced Trigger** function.

Run the measurement

12. Run the measurement.

See Also

To set the trigger position
To set acquisition depth

External Triggering

There are **Trigger In** and **Trigger Out** BNC connectors located on the logic analyzer (rear panel of 1680-series and front panel of 1690-series). Use them to connect the analyzer to an external instrument and either send or receive a trigger signal.

Trigger signal characteristics

Trigger out signal:

The trigger out signal is designed to drive a 50 Ohm load. It is recommended that for good signal quality, the trigger out signal be terminated in 50 Ohms to ground.

VOH (output high level) = >2.0 V.

VOL (output low level) = <0.5 V.

Pulse width = Approximately 60 ns to 140 ns.

Signal type is set in the System Options dialog. System Options is reached by **Edit>Options**.

Trigger in signal:

TTL, ECL, or user defined 5.5 V Max.

Edge type is set in the System Options dialog. System Options is reached by **Edit>Options**.

The following tasks show you how to configure the analyzer for external triggering. For an example of a complete analyzer measurement, refer to the measurement examples listed below under See Also.

To trigger other instruments - trigger out


To trigger analyzer from another instrument - trigger in

To trigger other instruments - Trigger Out

1. Connect a BNC cable from the **Trigger Out** BNC to the external instrument you want to trigger.
2. Configure the logic analyzer as you would normally for any other measurement. Refer to See Also below.
3. When the analyzer's trigger sequence becomes true and the analyzer triggers, a trigger signal is sent out through the **Trigger Out** BNC to the external instrument.

To trigger analyzer from another instrument - Trigger In

1. Connect a BNC cable from the **Trigger In** BNC to the external instrument that will send the trigger signal.
2. Configure the logic analyzer as you would normally for any other measurement. Refer to See Also.
3. From the menu bar select **Setup>Advanced Trigger**.
4. From the Trigger dialog, select the **Other** tab, then select the **Wait for external arm** trigger function.



5. When the logic analyzer receives the external arm signal (trigger signal), it arms and begins to evaluate its trigger sequence. When the trigger sequence becomes true, the analyzer triggers.

See Also

- Making a state analyzer measurement
- Making a timing analyzer measurement
- Wait for external arm - (state)
- Wait for external arm - (timing)

Making marker measurements

Making marker measurements

Once a marker is created, you can use it as a reference point in the data when measuring intervals or viewing the data value at the marker.

To create a new interval measurement

To create a new value at measurement

See Also

[Working with markers](#)

To create a new interval measurement

Use the new interval measurement feature to measure a time interval, or the number of samples between two specified points in data. Measurement results are displayed in the marker measurement display bar.


Note: Marker measurements use either the default M1 and M2 markers, or any other user-defined markers.

1. From the menu bar select **Markers>New Interval Measurement**, or click the




icon in the markers toolbar.

2. Select either time or sample, then select the markers you want to measure between.



3. Click **OK**.

The result of the interval measurement  is displayed in the marker measurements display bar.

See Also

To create a new value at measurement

To create a new value at measurement

Use the new value at measurement feature to measure the value of a bus or a single signal at a specified marker location in data. Measurement results are displayed in the marker measurement display bar.


Note: Marker measurements use either the default M1 and M2 markers, or any other user-defined markers.

1. From the menu bar select **Markers>New Value At Measurement**, or click the



icon in the markers toolbar.

2. Select the numeric base of the data, the bus or signal source, then the marker.



3. Click **OK**.

The result of the value at measurement

counter@M1 = E1

is displayed in the marker measurement display bar.

See Also

To create a new interval measurement

Trigger Functions

Timing mode trigger functions

State mode trigger functions

Timing mode trigger functions

The following trigger setup examples are available as Trigger Functions in the Advanced Trigger dialog when in the timing acquisition mode. To see these trigger setups in the context of an example measurement refer to "Making a timing analyzer measurement".

Edge

- Edge
- "N" number of edges
- Edge and Pattern
- Edge followed by edge
- Edges too far apart
- Edge followed by pattern
- Pattern too late after edge

Bus Pattern

- Pattern
- Edge And Pattern
- Pattern present for > "T" time
- Pattern present for < "T" time
- Pattern absent for > "T" time
- Pattern absent for < "T" time
- Edge followed by pattern
- Pattern too late after edge

Other

- Find anything "N" times
- Reset and start timer
- Width violation on pattern or pulse
- Wait "T" seconds
- Run until user stop
- Wait for external arm

Advanced

- Advanced If/Then
- Advanced 2-Way Branch
- Advanced 3-Way Branch
- Advanced 4-Way Branch
- Pattern "AND" Pattern
- Pattern "OR" Pattern

State mode trigger functions

The following trigger setup examples are available as Trigger Functions in the Advanced Trigger dialog when in the state acquisition mode. To see these trigger setups in the context of an example measurement refer to "Making a state analyzer measurement".

Patterns

- Pattern "N" times
- "N" consecutive samples with Pattern1
- Pattern1 followed by Pattern2
- Pattern1 immediately followed by Pattern2
- Pattern1 followed by Pattern2 before Pattern3
- Too few states between Pattern1 and Pattern2
- Too many states between Pattern1 and Pattern2
- Pattern2 occurring too soon after Pattern1
- Pattern2 occurring too late after Pattern1

Other

- Reset and start timer
- Find anything "N" times
- Run until user stop
- Wait for external arm
- Wait "N" external clock states

Advanced

- Advanced If/Then
- Advanced 2-Way Branch
- Advanced 3-Way Branch
- Advanced 4-Way Branch
- Pattern AND Pattern
- Pattern OR Pattern

See Also

External Triggering

Timing Mode

Timing mode trigger functions

Edge

- Edge
- "N" number of edges
- Edge and Pattern
- Edge followed by edge
- Edges too far apart
- Edge followed by pattern
- Pattern too late after edge

Bus Pattern

- Pattern
- Edge and Pattern
- Pattern present for > "T" time
- Pattern present for < "T" time
- Pattern absent for > "T" time
- Pattern absent for < "T" time
- Edge followed by pattern
- Pattern too late after edge

Other

- Find anything "N" times
- Reset and start timer
- Width violation on pattern or pulse
- Wait "T" seconds
- Run until user stop
- Wait for external arm

Advanced

- Advanced If/Then
- Advanced 2-Way Branch
- Advanced 3-Way Branch
- Advanced 4-Way Branch
- Pattern "AND" Pattern
- Pattern "OR" Pattern

See Also

State mode trigger functions

To build a trigger sequence

To store a trigger

To recall a trigger


Simple Trigger

Edge



The screenshot shows a configuration window for an 'Edge' trigger. It features a 'Step 1' dropdown menu. Below it, there are three input fields: 'Find' with a dropdown arrow, 'Bus/Signal' with a dropdown arrow, 'My Signal 1' with a dropdown arrow, and 'Rising Edge' with a dropdown arrow. At the bottom, there is a 'Then' dropdown menu with the option 'Trigger and fill memory' selected.


This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a user-defined edge occurs.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

"N" number of edges




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when the "Nth" occurrence of a user-defined edge occurs.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Edge followed by edge




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when edge 2 occurs within a specified time period after edge 1.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Edge followed by pattern



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a bus pattern occurs within a specified time period after an edge.





To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Edges too far apart

Step 1 ▾ Edges Too Far Apart

Find a time period of  


after ▾ Bus/Signal ▾ My Signal 1 ▾ Rising Edge ▾

in which ▾ Bus/Signal ▾ My Signal 1 ▾ Rising Edge ▾

does not occur

Then ▾ Trigger and fill memory ▾

This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when edge 2 does not occur within a specified time period after edge 1.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a designated bus pattern occurs.



To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Edge and Pattern


Step 1 ▾ Edge And Pattern

Find ▾ Bus/Signal ▾ My Signal 1 ▾ Rising Edge ▾

And ▾ Bus/Signal ▾ My Bus 1 ▾ All bits ▾ Equals ▾ Hex ▾

Then ▾ Trigger and fill memory ▾

This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when both a user-defined edge and bus pattern occur at the same time.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern present for > "T" time



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a user-defined bus pattern is present greater than a specified time period.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern present for < "T" time




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a user-defined bus pattern is present less than a specified time period.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern absent for > "T" time




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a user-defined bus pattern is absent greater than a specified time period.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern absent for < "T" time




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a user-defined bus pattern is absent less than a specified time period.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern too late after edge




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a specified bus pattern does not occur within a specified time period after an edge.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern "AND" Pattern (timing)




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when both pattern1 "AND" pattern2 occur at the same time, and for the specified numbers of samples (occurs).




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern "OR" Pattern (timing)



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when either pattern1 "OR" pattern2 occurs for the specified numbers of samples (occurs).




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Find anything "N" times (timing)




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when it sees any data (Anything) for the Nth time.




To edit this function

- To insert events and actions
- To modify trigger setup display
- To negate a function statement

Width violation on pattern or pulse



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when a pulse or bus pattern is found that is either too narrow or too wide.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Wait "T" seconds




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers after the specified time period expires.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Wait for external arm (timing)



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when an external arming signal appears through the external trigger in port. The external trigger port is located on the rear panel of the 168X models and the front panel of the 169X models.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Run until user stop (timing)



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. This trigger function sets up to never trigger. You must select the stop button to view the captured data.



To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Reset and start timer (timing)

Step 1 ▼ Reset and start timer


Find ▼ Anything ▼

Then ▼ Timer ▼ 1 ▼ Start from reset ▼

▼ Trigger and fill memory ▼

Note: This trigger function is not available in the 1683A/93A models because they do not have timers available.


This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. This trigger function resets a timer, then starts the timer for a specified period of time. This trigger function requires that the timer value be set in either the same trigger step, or another trigger step that follows. When the timer stops, the analyzer triggers. For more information refer to "To configure a timer".




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced If/Then (timing)



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The analyzer triggers when the "If" clause becomes true.



To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 2-Way Branch (timing)

Step 1 ▾ Advanced If/Then

▾ If ▾ Bus/Signal ▾ My Bus 1 ▾ All bits ▾ Equals ▾ ✕ 🧮 Hex ▾


occurs ▾ 1 🧮 - +

Then ▾ Goto ▾ Next ▾

▾ Else if ▾ Bus/Signal ▾ My Bus 1 ▾ All bits ▾ Equals ▾ ✕ 🧮 Hex ▾

Then ▾ Goto ▾ 1 ▾


This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The two-way branch is evaluated true when either of two patterns (if or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 3-Way Branch (timing)




This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The three-way branch is evaluated true when either of three patterns (If or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.




To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 4-Way Branch (timing)



This trigger function is available when the acquisition mode is set to **Timing - Asynchronous**. The four-way branch is evaluated true when either of four patterns (If or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.



To edit this function

- To insert events and actions
- To modify trigger step display
- To negate a function statement

State Mode

State mode trigger functions

Patterns

- Pattern "N" times
- "N" consecutive samples with Pattern1
- Pattern1 followed by Pattern2
- Pattern1 immediately followed by Pattern2
- Pattern1 followed by Pattern2 before Pattern3
- Too few states between Pattern1 and Pattern2
- Too many states between Pattern1 and Pattern2
- Pattern2 occurring too soon after Pattern1
- Pattern2 occurring too late after Pattern1

Other

- Reset and start timer
- Find anything "N" times
- Run until user stop
- Wait for external arm
- Wait "N" external clock states

Advanced

- Advanced If/Then
- Advanced 2-Way Branch
- Advanced 3-Way Branch
- Advanced 4-Way Branch
- Pattern "AND" Pattern
- Pattern "OR" Pattern

See Also

Timing mode trigger functions

To build a trigger sequence


To set store qualification

To store a trigger


To recall a trigger

Simple Trigger

Pattern "N" times




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when it finds the nth occurrence of a bus pattern as shown below.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

"N" consecutive samples with Pattern1




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when a bus pattern occurs a specified number times.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern1 followed by Pattern2




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern2 occurs eventually after pattern 1.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern1 immediately followed by Pattern2




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern 2 is found immediately after exiting pattern 1.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern1 followed by Pattern2 before Pattern3




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern2 occurs eventually after pattern1, for a specified number of times, without pattern3 occurring in between.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Too few states between Pattern1 and Pattern2




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern1 is followed by pattern2 with fewer than "N" specified states in between.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Too many states between Pattern1 and Pattern2




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern1 is followed by pattern2 with more than "N" specified states in between.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern2 occurring too soon after Pattern1




This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern2 occurs within a specified time period after pattern1.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern2 occurring too late after Pattern1



This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when pattern2 does not occur within a specified time period after pattern1.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Find anything "N" times (state)



This trigger function is available when the acquisition mode is set to **State - Synchronous**. It will trigger the logic analyzer when any data (Anything) is seen for the Nth time. It is commonly used to create an immediate trigger, or a trigger after a user-defined delay.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Run until user stop (state)




This trigger function is available when the acquisition mode is set to **State - Synchronous**. This trigger function sets up to never trigger. You must select the stop button to view the captured data.



To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Reset and start timer (state)



Note: This trigger function is not available in the 1683A/93A models because they do not have timers available.

This trigger function is available when the acquisition mode is set to **State - Synchronous**. This trigger function resets a timer, then starts the timer for a specified period of time. This trigger function requires that the timer value be set in either the same trigger step, or another trigger step that follows. When the timer stops, the analyzer triggers. For more information refer to "To configure a timer".




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Wait for external arm (state)




This trigger function is available when the acquisition mode is set to **State - Synchronous**. The analyzer triggers when an external arming signal appears through the external trigger in port. The external trigger port is located on the rear panel of the 168X models and the front panel of the 169X models.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Wait "N" external clock states




This trigger function is available when the acquisition mode is set to **State - Synchronous**. The analyzer triggers on the "Nth" occurrence of the external clock signal (plus any user-defined clock qualification) from the device under test.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern "AND" Pattern (state)




This trigger function is available when the acquisition mode is set to **State - Synchronous**. The analyzer triggers when both pattern1 "AND" pattern2 occur at the same time, and for the specified numbers of samples (occurs).




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Pattern "OR" Pattern (state)




This trigger function is available when the acquisition mode is set to **State - Synchronous**. The analyzer triggers when either pattern1 "OR" pattern2 occurs for the specified numbers of samples (occurs).




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced If/Then (state)



This trigger function is available when the acquisition mode is set to **State - Synchronous**. The analyzer triggers when the "If" clause becomes true.



To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 2-Way Branch (state)

Default Storage (overridden by sequence level store actions):

Store Bus/Signal My Bus 1 All bits Equals Hex

Step 1 Advanced If/Then

If Bus/Signal My Bus 1 All bits Equals Hex


occurs 1

Then Goto Next

Else if Bus/Signal My Bus 1 All bits Equals Hex

Then Goto 1

This trigger function is available when the acquisition mode is set to **State - Synchronous**. The two-way branch is evaluated true when either of two patterns (if or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.



To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 3-Way Branch (state)

Default Storage (overridden by sequence level store actions):

Store Bus/Signal My Bus 1 All bits Equals

Step 1 Advanced If/Then

If Bus/Signal My Bus 1 All bits Equals

occurs

Then Goto Next


Else if Bus/Signal My Bus 1 All bits Equals

Then Goto 1

Else if Bus/Signal My Bus 1 All bits Equals

Then Goto 1


This trigger function is available when the acquisition mode is set to **State - Synchronous**. The three-way branch is evaluated true when either of three patterns (If or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.




To edit this function

- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Advanced 4-Way Branch (state)



This trigger function is available when the acquisition mode is set to **State - Synchronous**. The four-way branch is evaluated true when either of four patterns (If or Else if) are found. Depending on which pattern is found true, the appropriate "Then" action is executed.



To edit this function


- To set store qualification
- To insert events and actions
- To modify trigger step display
- To negate a function statement

Task Guide

- Listing display window
- Waveform display window
- Bus/Signal setup tab
- Sampling setup tab
- Triggering
- Working with markers
- File management
- Symbols
- Capturing Data
- Searching
- Printing
- Importing
- Exporting

Waveform Window Tasks

Waveform Display Window



The Waveform window is accessed through the menu bar's **Window>Waveform**. If you have Tabbed Windows turned on, you can also select a tab at the bottom of the window.

The Waveform window displays captured data as a digital waveform. You can configure the window to display selected buses and signals with time or pattern markers in the data. You can also set up bus pattern triggers and signal trigger options.

The Waveform window consists of the following four areas:

- Bus/Signal configuration
- Simple Trigger
- Marker display bar
- Waveform display area

Bus/Signal configuration

To access the following Bus/Signal configuration options, right-click on any bus or signal name in the Bus/Signal column.

Undo - Undo the last action performed.

Insert Row Before - Inserts a predefined bus/signal before the highlighted row.

Insert Row After - Inserts a predefined bus/signal after the highlighted row.

Delete Row - Deletes the bus/signal in the highlighted row.

Expand - Expands the highlighted bus into separate displayed channels.

Collapse - Collapses displayed channels to a single displayed bus.

Assign Channels - Access to the Buses/Signals tab of the Analyzer Setup dialog for mapping (assigning) the highlighted bus/signal to the desired pod and channel connection of the probes.

Rename - Access a keypad to rename the highlighted bus/signal.

Group into Bus - Groups highlighted signals into a bus.

Overlay - Overlays the highlighted bus or signal with another selected bus or signal.

Overlay Remove - Separates overlaid bus/signals.

Symbols - Access to edit symbols dialog for selected bus/signal.

Properties - Access to properties dialog for waveform window, waveform data, and markers.

To reposition bus/signal names

To reposition bus/signal names in the display window, click and hold the mouse cursor over the name to move, then drag and drop the name to the new position. The name is placed above the red position indicator that appears.

Simple Trigger

To set bus pattern triggers

To set signal trigger options

Marker display bar

To access the Marker bar options, right-click anywhere in the marker display bar.

New - To create new markers.

Place - To place markers in data.

Go To - Go To a predefined marker.

Center About - To center the display about a marker.

Delete - To delete a marker.

Rename - To rename a marker.

Send to back - To send a marker to the back.

Properties - To set marker properties.

Drag and drop markers - To move markers in the marker display bar.

Waveform display area

To access waveform display options, right-click anywhere in the display area.

Undo - Undo the last action performed.

Zoom Out

Zoom In

Go To

Place Markers

Center About Markers

Find

Find Next

Find Previous

Properties

Drawing Rectangle in data

Zoom In

Set Quick Trigger - Alternative way to set a Simple Trigger.

Find Next - Data value on left edge of rectangle becomes Find search criteria and next occurrence of that data value is placed at center screen.

Find Previous - Data value on left edge of rectangle becomes Find search criteria and previous occurrence of that data value is placed at center screen.

[Change Delay](#)

[Change Scale](#)

See Also

[Working with Markers](#)

[Advanced trigger dialog](#)

[To edit symbols](#)

[To add or delete display windows](#)

[Turning window tabs on/off](#)

[Tooltips](#)

Working with Markers

- To create new markers
- To place markers in data
- Go To marker
- To center the display about a marker
- To delete a marker
- To rename a marker
- To send a marker to the back
- To set marker properties
- To drag and drop markers in data
- Marker snap to edge
- To create a new interval measurement
- To create a new value at measurement

See Also

- Markers display bar
- Reading off-screen markers
- Marker measurement display bar
- Marker menu
- Marker toolbar

To set waveform window properties

Use the Waveform Properties dialog to modify the attributes of the waveform window or the data that appears in each row of the display. To access the Waveform Properties dialog click **Edit>Window Properties** in the menu bar.



Tip: You can also access the Properties dialog by a **right-click** in the display area, then select **Properties**.

To set window properties

The following properties effect the entire waveform window, including displayed data, bus/signal text, and simple trigger text.

To set background color

To set font size

To set an overlay color

To show activity indicators

To show tool tip - values

To show tool tip - transition width

To set markers - snap to edge

To set markers - move edge on screen

To set markers - place on edge

To set row properties

The following properties effect only the row data of the selected bus/signal unless **<all>** is selected.

To select the Bus/Signal

To set data color

To set row height

To set numeric base

To show data values

To show soft glitch

To set bus options

To set background color

The background color property sets the background color of the data display area of the waveform window.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the background **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set font size

The font size property adjusts the size of font used in the data display, bus/signal text, and simple trigger text. Fonts can range from size 6 through 72. As the font size is changed, the row height is automatically adjusted to a minimum height to fit the new font size.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the font size **up/down** arrows to adjust the font to the desired size.

3. Click **Ok**.

To set an overlay color

Multiple bus/signals can be inserted (Overlay) within a single row. All overlaid bus/signals are displayed in a different color than the primary bus or signal.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the overlay **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To show activity indicators

Activity indicators are displayed to the left of the bus or signal name. The Show Activity Indicators property controls whether the indicators are shown or hidden. The indicators show either a low bar (low level), high bar (high level), or a transition arrow (transitioning signal).

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Show Activity Indicators** box to display the indicators.
3. Click **Ok**.

To show tool tip - values

When the mouse is moved within the display area, and is positioned directly over a waveform, a tool tip (text readout) appears that displays the data value of that waveform at its current position. The Show Values property controls whether the tool tip is shown or hidden.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Show Values** box under Tool Tips.
3. Click **Ok**.

To show tool tip - transition width

When the mouse is positioned directly over a waveform, a tool tip (text readout) appears that displays both the data value and the transition width of that waveform at its current position. The Transition Width property controls whether the tool tip includes the transition width. Transition width is displayed in parenthesis.

Note: The Transition Width property is only available when Show Values is on.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Transition Width** box under Tool Tips.
3. Click **Ok**.

To set markers - snap to edge

The Markers - Snap to Edge property enables easy placement of markers on waveform edges by using graphical guidance. When a marker is grabbed and dragged in the data display area, the cursor changes to a green "direction arrow" indicating the direction of the next valid edge. A red "valid edge" bar is placed on the next edge that the marker will be placed on if you decide to release the mouse button. In other words, the green arrow points to the red bar where the marker will be placed.

If the mouse cursor is not positioned over any waveforms when you begin the drag and drop operation, the marker can be dropped anywhere between edges with no snap-to-edge action.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Snap to Edge** box under Markers.
3. Click **Ok**.

To set markers - move edge on screen

When a marker is snapped to an edge that is off-screen, the data display is shifted so the marker and the new edge it is snapped to, appear at center screen. The waveform delay is adjusted to the time of the new edge.

Note: The Move Edge on Screen property is only available when Snap to Edge is on.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Move Edge on Screen box** under Markers.
3. Click **Ok**.

To set markers - place on edge

With the Place on Edge property set, when a marker is placed using the **right-click>Place Marker** shortcut, the marker will be placed on the closest edge from where the mouse right-click occurred. When the Place on Edge property is disabled, the marker is set where the mouse right-click occurred.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Place on Edge box** under Markers.
3. Click **Ok**.

To select the Bus/Signal

The Bus/Signal field lists all signals that have been inserted into the display in the Buses/Signals tab. Use the Bus/Signal property to select the bus or signal that you want the property changes applied to. In addition to the individual signals listed, you also have the selections of "all" and "selected". The "all" selection will apply property changes to all bus/signals. The "selected" option is only available when multiple bus/signals are selected (highlighted), and will apply property changes only to the bus/signals highlighted, and only to the common properties to each of the selected bus/signals. If a property change is not valid to all selected bus/signals, the fields will be greyed out.

Property changes to a bus effects all signals within the bus. For example, if the color of a bus is changed, then if you were to expand the bus, all individual signals would have their color changed.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click in the **Bus/Signal** name field, then select the desired bus/signal name.
3. Click **Ok**.

To set data color

The waveform Color property sets the color of the waveform in the data display.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set row height

The Height property controls the height of the row measured in pixels. The minimum row height is set by the font size. The maximum height is 1000 pixels.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the **Height box**, then enter the desired height value.
3. Click **Ok**.



Tip: You can also set row height by hovering mouse over separator line, when cursor changes to a resizing cursor, click and drag row border to new width.

To set numeric base

The Base property sets the numeric base used to display the data. If you change to a base

that creates a longer number format (example; Hex to Binary), all fields are automatically adjusted. Also, if you have data values displayed within the waveform, and you switch from Hex to Binary or Symbols, ">>" may appear to indicate that more text will be displayed if you expand the scale.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Click the **Base field**, then select the desired numeric base.
3. Click **Ok**.

To show data values

The Show Value property enables an integrated display of both the waveform and the data value of the waveform at that point. You also can set a color for the waveform data value text.

Note: If the waveform time scale is small, ">>" may appear in the data value to indicate that more text will be displayed if you expand the scale.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Show Value box**, then click in the color box and select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To show soft glitch

The Show Soft Glitch property enables you to be visually cued when multiple transitions are occurring at the same point in time. It does this by displaying screen pixels that are common to multiple transitions being drawn on screen. These common pixels are drawn in a different color to create an eye pattern to compare against an expected visual pattern. Soft glitches are seen when you zoom out the time scale.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Show Soft Glitch box**, then click in the color box and select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set bus options

The Bus Options button is only available when a bus is selected for property changes. The options listed below are applied only to the selected bus.

1. From the Waveform Properties dialog, click the **Windows Properties** tab.
2. Check the **Show Value box**, then click in the color box and select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set waveform style - Bus

The Bus property sets the waveform appearance to a conventional bus shape. When Bus is selected, and MSB ordering is checked, the ordering of the signals in the bus are changed from least significant bit first to most significant bit first.

To set waveform style - Magnitude

The Magnitude property sets the waveform appearance to a samples versus time (chart mode) display. When Magnitude is selected, and Show Axis is checked, a small axis is drawn in the center of the waveform which represents the center of the range of values being displayed. When Show Axis is checked, you can also set an axis color.

When the Magnitude property is selected, you can also set the following Waveform Limits:

- Max/Min - sets the range limits of the displayed axis.
- Lock to Setup - sets the range limits based on the width of the bus. For example, an 8-bit bus is set to a range of 0-255.
- Show Clipped - enables out-of-range data values to be displayed in a user defined color.

To expand into signals

The Expand into Signals property expands the bus into individual signals. This function is the same as if you selected the Expand (+) field to the left of the bus name.







See Also

To set marker properties

Change delay



The delay adjusts the display window relative to the waveform data. The display window's relative position in time is dependant on the trigger point, and the beginning and end of data. Use the following delay controls to position the display window over the desired data.

	Use the keypad to enter a numeric value. If the value you enter is greater than or less than the time of the data range, the window will be moved to the beginning or end limit.
	Moves the window over the beginning of data.
	Scrolls the window towards the beginning of data.
	Moves the window over the trigger point.
	Scrolls the window towards the end of data.
	Moves the window over the end of data.


Change scale (time/division)

Data from a timing analyzer is displayed similar to oscilloscope data. That is, they both display waveforms on a horizontal time axis. Therefore, to zoom in or out on a waveform, you simply change the Scale (time/division) of the time axis that the waveform is viewed with.

- Change the scale
- Draw a rectangle in the data


Change the scale

1. Click the zoom out icon to expand the signals to where you want them. The scale ranges from 1 ps/div to 1ks/div. You can also change the scale by clicking the keypad icon and entering a numeric value.




Draw a rectangle in the data

1. Point the mouse to the upper-left corner of the desired view area, then click and hold while moving the mouse to the lower-right corner, then release the mouse button.
2. Select **Zoom In**. The new display scale is adjusted to the width of the box drawn.



To overlay bus/signals


Use the Overlay feature to place multiple bus or signals into one row of displayed data. When multiple signals are overlaid, you can see the relationships visually between all signals. The overlaid bus or signal is drawn first, then the main bus/signal is drawn last as to overwrite the overlaid bus/signals for clarity.



1. Right-click on the bus or signal you want to overlay another bus or signal onto, then select **Overlay...** .
2. From the Overlay selection dialog that appears, select the bus or signal you want to overlay onto the highlighted bus or signal.
3. If you want to change the color of the overlaid bus or signal, go to Window Properties and change Overlay color.

To group signals into a bus

1. While holding the shift key down, click on all desired signals.
2. With the mouse pointer over any one of the highlighted signals, right-click and select **Group into Bus**.



To add or delete display windows

You can add new listing and waveform display windows to the interface. As new windows are added, they appear in the list under **Window** in the menu bar. The active window will have a check mark. All available windows can be accessed either through the menu bar or through the use of tabs.

To add a new display windows

1. In the menu bar, click **Window>New Listing or New Waveform**. If the windows are tabbed, you can also right-click on the tab, then select New Listing or New Waveform.

To delete display windows

1. From the menu bar, click **Window>Close**. If windows are tabbed, you can also right-click on the tap, then select Close.


See Also

Turning window tabs on/off
Viewer toolbar

Turning window tabs on/off

By default, the Listing and Waveform display windows are tabbed for ease of switching between displays.

To turn on or off window tabs, select **View>Tabbed Windows**.



To switch display windows when tabs are turned off, you must select **Window>"display window name"**.

See Also

To add or delete display windows

Set quick trigger with rectangle

Within the waveform and listing displays, you can quickly setup a simple trigger by drawing a rectangle with the mouse. After a simple trigger has been defined, and the analyzer is run, the trigger is stored and can be recalled at any time.

The following guidelines explain how each display interprets the drawn rectangle in regards to the data and how the trigger is set.

General guidelines:

- Any bus/signals with overlapping bits are not included within the trigger specification.

Example: Bus_1 has channels 0 through 7 of pod 1 assigned and Bus_2 has channels 3 through 6 of pod 1 assigned. At this point, you have the same probed signals (channels 3 through 6 of pod 1) assigned in both Bus_1 and Bus_2. Now you draw the rectangle over both bus_1 and bus_2. Since Bus_1 channels 3 through 6 are repeated (overlapped) on Bus_2, they will not be included in the trigger specification.

- Only a single sequence level can be defined by a drawn rectangle.
- As you draw the rectangle, a tooltip is displayed showing the current trigger specification that would be set.

Specific guidelines to the listing display:


- As you move the mouse left-to-right and top-to-bottom, the signal level or bus value in contact with the **top of the rectangle** becomes the trigger.

Specific guidelines to the waveform display:

- As you move the mouse left-to-right and top-to-bottom, the signal edge/level or bus value in contact with the **left of the rectangle** becomes the trigger.
- Only one edge can be set.
- If a bus is expanded into its separate signals, three condition apply: 1. If drawing starts on a bus, none of its expanded signals can be included. 2. If drawing starts on a signal, the bus cannot be included. 3. Edges and levels are mutually exclusive. That is, either one edge can be set, or all levels can be set, but not both at the same time.


To draw the rectangle

1. Using the mouse, point to the upper-left corner of your desired trigger rectangle.
2. While holding down the mouse button, drag the mouse pointer to the lower-right corner of your desired rectangle, then release the mouse button. As you draw the rectangle, you can monitor the trigger as it is set with the tooltip readout that appears.





Note: In the waveform display, it may be necessary to redraw the rectangle if you do not get your desired trigger points dictated by the left-side line of the rectangle. You could also try drawing the rectangle backwards leaving the left-side rectangle line set last.

3. Select **Set Trigger**.




Tool Tips

Tool tips are small information displays (text readout) that appear during mouse operations such as hovering over a waveform or bus/signal name, moving markers, or drawing a rectangle in data. Use them as comments or to read current positions, waveform transition widths, or trigger specifications (when setting trigger with mouse).



To add user comments



You can attach comments to buses and signals. The comments show up in the tool tip when you hover the mouse over a bus or signal name in both the waveform and listing windows.

1. From the menu bar, select **Setup>Bus/Signal**.
2. In the Buses/Signals setup tab that appears, select **Display**.
3. Select **Comment**. A new column labelled Comment appears.
4. In the Comment column, type your comment for the bus or signal.
5. Click **OK** to close the Analyzer Setup dialog.


Note: Comments are intended as a descriptor to embellish a bus/signal name and not as a notepad. Comments can be up to 64 character in length.

To edit symbols for a bus/signal


You can edit symbols whenever the Edit symbols dialog is displayed.

To add a symbol

1. Select **Setup>Symbols...**



2. Select the bus or signal for which the new symbol should be displayed. Each symbol is defined for a particular bus/signal.
3. Click **Add**.
4. Define a value or range of values.



There are no restrictions on the characters you can use in the name of a symbol. The symbols on a particular bus or signal must have unique names.

5. Click **Apply**.

To see the symbols in the listing or waveform display, click OK in the Symbols dialog and change the base for the bus/signal to Symbols.

To edit a symbol

1. Select **Setup>Symbols...**
2. Select the symbol you want to edit.
3. Click **Edit**.

To delete a symbol

1. Select **Setup>Symbols...**
2. Select the symbol you want to delete.
3. Click **Delete**.

To save symbols

Save symbols as part of a configuration file. Symbols are saved in the configuration whether or not you select **Setup only** in the Save As dialog.

See Also

To display symbols

Listing Window Tasks

Listing Display Window

	Sample Number	Bus 1	Bus 2	Signal 1	Signal 2	Time
		= XX	= XXXX	☒	☒	
	-7	F9	3FF9	1	1	-350
	-6	FA	3FFA	1	1	-300
M1 →	-5	FB	3FFB	1	1	-250
	-4	FC	3FFC	1	1	-200
	-3	FD	3FFD	1	1	-150
	-2	FE	3FFE	1	1	-100
	-1	FF	3FFF	1	1	-50
I →	0	00	0000	0	0	0
	1	01	0001	0	0	50
	2	02	0002	0	0	100
	3	03	0003	0	0	150
	4	04	0004	0	0	200
M2 →	5	05	0005	0	0	250
	6	06	0006	0	0	300
	7	07	0007	0	0	350

The Listing window is accessed through the menu bar's **Window>Listing**. If you have Tabbed Windows turned on, you can also select a tab at the bottom of the window.

The Listing window displays your captured data as a state listing. You configure the window to display selected buses and signals in columns. Within the listed data, you can insert time or pattern markers. You can also configure the bus pattern triggers and signal trigger options.

The Listing window consists of the following four areas:

- Column configuration
- Simple Trigger
- Marker display bar
- Listing display area

Column configuration

To access the following column configuration options, right-click on any bus or signal name in the column head.

Insert Column Before

Insert Column After

Delete Column

Assign Channels

Rename

Symbols

Display

Properties

To reposition bus/signal names

To reposition bus/signal names in the display window, click and hold the mouse cursor over the name to move, then drag and drop the name to the new position. The name is placed to the left of the red position indicator that appears.

Simple Trigger

To set bus pattern triggers

To set signal trigger options

Marker display bar

To access the marker display options, right-click anywhere in the marker display bar.

New - To create new markers.

Place - To place markers in data.

Go To - Go To a marker.

Center About - To center the display about a marker.

Delete - To delete a marker.

Rename - To rename a marker.

Send to back - To send a marker to the back.

Properties - To set marker properties.

Drag and drop markers - To move markers in the marker display bar.

Listing display area

To access the Listing display options, right-click anywhere in the display area.

Undo - Same as Edit>Undo.

Go To

Place Marker

Find

Find Next

Find Previous

Properties

Draw Rectangle in data

Set Quick Trigger - Alternative way to set a simple trigger.

Find Next - Data value on top edge of rectangle becomes Find search criteria and next occurrence of that data value is placed at center screen.

Find Previous - Data value on top edge of rectangle becomes Find search criteria and previous occurrence of that data value is placed at center screen.

Copy Text - Copies data as text into the system clipboard.

See Also

To display symbols

Working with Markers

To add or delete display windows

Turning window tabs on/off

Tool Tips

Column configuration

To access the tasks in this area, right-click on any bus or signal name in the column head of the listing window.

Insert Column Before

Insert Column After

Delete Column

Assign Channels

Rename

Symbols

Display

Properties

Insert Column Before

Accesses a list of predefined bus and signal names. The selected name is inserted to the left of the highlighted column. To create new bus and signal names go to To add a new bus or signal.

Insert Column After

Accesses a list of predefined bus and signal names. The selected name is inserted to the right of the highlighted column. To create new bus and signal names go to To add a new bus or signal.

Delete Column

Deletes the highlighted column.

Assign Channels

To assign channels to pods go to Buses/Signal Setup.

Rename

Accesses a keypad to rename the highlighted bus or signal name.

Symbols

For information on editing symbols, go to Symbols.

Display

Turns on or off the activity indicators, default base, and the simple trigger. When turned on, they are visible in the column head of the listing window.

Properties

For information on setting listing window properties, refer to To set listing window properties.

To set listing window properties

Use the Listing Properties dialog to modify the attributes of the listing window or the data that appears in each column of the display. To access the Listing Properties dialog click **Edit>Window Properties** from the menu bar.



Tip: You can also access the Properties dialog by a **right-click** in the display area, then select **Properties**.

To set window properties

The following properties effect the window as well as all displayed row data.

To set background color

To set font size

To show column display options - activity indicators

To show column display options - column base

To show column display options - simple trigger

To show center rectangle

To set column properties

The following properties effect the displayed column data.

To select the Bus/Signal name

To set data color

To set column width

To set column alignment

To set numeric base

To set marker relative

To set background color

The Background Color property sets the background color of the data display area of the Listing window.

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Click the background **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set font size

The font size property adjusts the size of font used in the data display, bus/signal text, and simple trigger text. Fonts can range from size 6 through 72. As the font size is changed, the column width is automatically adjusted to a minimum width to fit the new font size.

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Click the font size **up/down** arrows to adjust the font to the desired size.
3. Click **Ok**.

Column display options

The Column Display Options properties enable viewing of the activity indicators, the column base, and the simple trigger configuration.

Display activity indicators

Activity indicators are displayed to the left of the bus or signal name. The indicators show signal activity as either a low bar (low level), high bar (high level), or a transition arrow (transitioning signal).

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Check the **Display Activity Indicators** box to display the indicators.
3. Click **Ok**.

Display column base

The base field displays the numeric base for which the data is displayed in. The numeric base is set in the Buses/Signals tab of the Analyzer.

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Check the **Display Column Base** box to display the indicators.
3. Click **Ok**.

Display simple trigger

The Display Simple Trigger property enables configuration and viewing of the simple trigger. For more information on configuring the simple trigger refer to Simple Trigger.

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Check the **Display Simple Trigger** box to display the indicators.
3. Click **Ok**.

To show center rectangle

The center rectangle is the box that is drawn around the one state displayed at center screen. The Display Rectangle property enables the rectangle to be displayed or hidden.

1. From the Listing Properties dialog, click the **Windows Properties** tab.
2. Under Center Rectangle, check the **Display Rectangle** box to display the center rectangle.
3. Click the rectangle **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
4. Click **Ok**.

To select the Bus/Signal name

The Bus/Signal field lists all signals inserted into the display. The names are listed in the same order as they appear in the display. Use the Bus/Signal property to select the bus or signal that you want the property changes applied to. In addition to the individual signals listed, you also have the selections of "all" and "selected". The "all" selection will apply property changes to all bus/signals. The "selected" option is only available when multiple bus/signals are selected (highlighted in display), and will apply property changes only to the bus/signals highlighted, and only to the common properties to each of the selected bus/signals. If a property change is not valid to all selected bus/signals, the fields will be greyed out.

Property changes to a bus effects all signals within the bus. For example, if the color of a bus is changed, then if you were to expand the bus, all individual signals would have their color changed.

1. From the Listing Properties dialog, click the **Column Properties** tab.
2. Click in the **Bus/Signal** name field, then select the desired bus/signal name.
3. Click **Ok**.

To set data color

The Color property sets the color of the data in the listing display.

1. From the Listing Properties dialog, click the **Column Properties** tab.

2. Click the **color box**, then select the desired color from the palette. If you want to create a custom color, click **Other...** to access the custom color dialog.
3. Click **Ok**.

To set column width

The Width property controls the width of the column (specified in pixels). The minimum column width is 1 pixel, while the maximum width is 1000 pixels.

1. From the Listing Properties dialog, click the **Column Properties** tab.
2. Click the **width box**, then type in the desired pixel width value.
3. Click **Ok**.



Tip: You can also set column width by hovering mouse over separator line, when cursor changes to a resizing cursor, click and drag column border to new width.

To set column alignment

The Alignment property sets the display of data to be left-justified, right-justified, or centered within the column.

1. From the Listing Properties dialog, click the **Column Properties** tab.
2. Click the **Alignment box**, then select the desired alignment choice.
3. Click **Ok**.

To set numeric base

The Base property sets the numeric base used to display the data. If you change to a base that creates a longer number format (example; Hex to Binary), all fields are automatically adjusted.

1. From the Listing Properties dialog, click the **Column Properties** tab.
2. Click the **Base box**, then select the desired numeric base choice.

Note: If the **Time** column has been selected instead of a data column, your choices change from a numeric format to Absolute, Relative Previous, or Relative Marker.

3. Click **Ok**.

To set marker relative

The Marker property only applies when a Time column is selected and the base of the Time column is set to Relative Marker. This field allows the selection of a marker to act as the location where time should be relative from.

1. From the Listing Properties dialog, click the **Column Properties** tab.
2. Click the **Marker box**, then select the desired marker.
3. Click **Ok**.

See Also



To set marker properties

To display symbols

You can display a bus or signal using meaningful names rather than numeric values. Symbols can be displayed in both the Listing and Waveform displays.

To display symbols:

1. Change the numeric base of the bus or signal to Symbols.



2. Define the symbols.

If the symbol is defined as a range, values in the range will be displayed with an offset

from the lowest end of the range.


If the definitions of several symbols overlap, the first one listed in the Symbols dialog has precedence over the others.

In the Waveform display, ">>" will be shown when the full name of the symbol will not fit into the space available.


Once you have set up symbols, it's usually a good idea to save the logic analyzer configuration. The symbol definitions will be stored as part of the configuration.

Example


Here is what "My Bus 1" looks like before defining any symbols:



When the symbols have been defined, they are shown in the Symbols dialog:




Here is what the bus looks like after the symbols are defined:



Buses/Signals Setup Tasks

Buses/Signals Setup



The Buses/Signals tab is accessed through the menu bar's **Setup>Bus/Signal**. The Buses/Signals tab is used to map (assign) bus and signal names in the interface to the pod and channel connections of the probes. You also use the Buses/Signal tab to setup thresholds, polarity, numeric base, and enter user comments. Through the **Display...** field, you can select what bus/signal setup information is displayed.

The following tasks are performed in the Buses/Signals setup tab.

- To add a new bus or signal
- To delete a bus or signal
- To rename a bus or signal
- To assign channels
- To set thresholds
 - To set numeric base
 - To set setup/hold
- To set polarity
 - To add user comments
 - To add a folder
 - To alias a bus/signal name
- To edit symbols

Read only options

The following fields are read only and cannot be edited. The display of these items can be turned on/off under the **Display...** field.

Channels Assigned	The Channels Assigned column displays the channel assignments in textual form.
Width	The Width column displays the number of


	assigned channels on each bus.
Activity	<p>The Activity row displays the type of signal activity on each channel.</p> <ul style="list-style-type: none">• Low bar = A stable low level.• High bar = A stable high level.• Transition arrows = An active signal transition between low and high
Channel Numbers	The Channel Numbers row displays pod channel numbers

To add a new bus or signal

The add bus/signal feature allows you to add new buses and signals to the configuration. Once added to the configuration, the new bus/signal is automatically inserted into the data displays and also becomes available in any bus/signal insert function.

1. From the menu bar, select **Setup>Bus/Signal**.
2. Select **Add Bus/Signal** to add a new bus or signal.
3. The new bus/signal will appear with a system generated default name. Rename the new bus/signal if desired.

Note: Before a new bus/signal can be added to the configuration, at least one channel must be assigned to the bus/signal.



See Also

- To delete a bus or signal
- To rename a bus or signal
- To assign channels
- Buses/Signals Setup

To delete a bus or signal


The delete bus or signal feature allows you to remove buses and signals individually or all at once. The delete bus or signal feature is accessed through the setup menu or the setup toolbar.

To delete an individual bus or signal

To delete all buses and signals

To delete an individual bus or signal

1. From the menu bar, select **Setup>Bus/Signal**.
2. Highlight the bus or signal you want to delete.
3. Click **Delete**.



To delete all buses and signals

1. From the menu bar, select **Setup>Bus/Signal**.
2. Click **Delete All**.


Note: Some tools "lock" buses and signals because they use the bus or signal to produce their own output. Delete and Delete All will not delete these locked buses and signals. A locked bus or signal has a grey icon to the left of the name instead of a red icon.


See Also

Buses/Signals Setup

To rename a bus or signal

The rename bus/signal feature allows you to change bus and signal names. All channel, pod, and clock assignments for the renamed bus/signal remain unchanged.

1. From the menu bar, select **Setup>Bus/Signal**, or click the  icon in the setup toolbar.
2. Right-click the bus or signal name and choose **Rename...**



3. Enter the new bus or signal name.
4. Select **OK**.


See Also

To add a new bus or signal
To delete a bus or signal
Buses/Signals Setup

To assign channels

To make the logic analyzer display match your system's design, assign the physical channels of the logic analyzer to bus and signal names.

1. From the menu bar, select **Setup>Bus/Signal**.
2. In the Buses/Signals tab, select squares in the grid to assign channels to bus and signal names. For each signal probed in your device under test, you should have a black check mark mapping the channel to a pod and to a signal name in the interface. Example: In the picture below, channels 0-7 (pod 1) are mapped to My Bus 1, channels 8-15 (pod 1) are mapped to My Bus 2, and channels 8 and 9 (pod 2) are mapped to My Signal 1 & 2 respectively.




Tip: If clock channels are not connected to clock signals, they can be used as extra data channels. Clock channels are grouped together after the last pod in the channel assignment area.

To set thresholds

It is very important that you specify a threshold voltage that matches what your target system is using. Incorrect threshold voltages result in incorrect data.

1. From the menu bar, select **Setup>Bus/Signal**.
2. Click any **Threshold** field. The Threshold fields are located under the Pod label. The Threshold Settings window appears.




- a. Select **All Pods** or just a single pod.
- b. Specify the threshold level. Choices are

AGP (1.32 V)	CCT (1.50 V)	CMOS 5V (2.50 V)
ECL (-1.30 V)	GTL (0.80 V)	GTLPlus (1.00 V)
HSTL (0.75 V)	LVC MOS 1.5V (0.75V)	LVC MOS 1.8V (0.90 V)
LVC MOS 2.5 V (1.25 V)	LVC MOS 3.3 V (1.65 V)	LVPECL (2.00 V)
LV TTL (1.40 V)	PECL (3.70 V)	SSTL2 (1.25 V)
SSTL3 (1.50 V)	TTL (1.50 V)	User (-6.00 to 6.00 V)

To set numeric base

You can set the default numeric base for a bus when you create the bus. The default base is used to display bus and signal values in the listing and waveform views. Default base only affects new buses and signals; if you change default base for an existing bus or signal you will not see a change unless you add a new copy of the bus or signal to a listing or waveform view.

1. From the menu bar, select **Setup>Bus/Signal**.
2. In the bus/signal setup dialog, select **Display**.
3. Select **Default Base**.



4. To change the default base for a bus or signal, click the default base value.

Buses/Signals | Sampling

Enter buses and signals and the channels they correspond to:

Bus/Signal Name	Channels Assigned	Width	Default Base
My Bus 1	Pod 1[7:0]	8	Hex
My Bus 2	Pod 1[15:8]	8	Hex
My Signal 1	Pod 2[0]	1	Hex
My Signal 2	Pod 2[1]	1	Hex

Pod
Threshold: T

0 15 14 13 12 11 10 9 8

- Binary
- Hex
- Octal
- Decimal
- Signed Decimal
- Ascii
- Symbol


5. Select a new value.
6. Click **OK** to close the bus/signal dialog.

To set polarity

You can define buses and signals to display with negative or positive polarity. This affects the display of values and waveforms. When a bus or signal is set to negative polarity, an incoming high voltage will be shown with a low waveform and a logical value of 0. The polarity is reflected in all places that use values, such as trigger and symbols.

The default polarity is positive (high = 1).

1. From the menu bar, select **Setup>Bus/Signal**.
2. In the bus/signal setup dialog, select **Display**.
3. Select **Polarity**.



4. In the polarity column that appears, toggle between + (positive) and (negative).

To set setup/hold


Setup and hold is available in State mode only.

Setup/Hold specifies where the logic analyzer's window should be relative to the clock signal it receives from the target system. The target system needs a window in which the data is valid that is at least as long as the logic analyzer's setup/hold window plus any clock offset. Use the setup/hold setting to move the logic analyzer's setup/hold window relative to the target system's data valid window.

1. Select **Setup>Timing/State (Sampling)...**
2. Change Acquisition to **State - Synchronous Sampling**.
3. Set up the clock description.

Note: Single-edge clocks have a smaller setup/hold window than other clocks. Changing to a different setup/hold window changes the setup value. (Hold remains constant.)

4. Select **Buses/Signals** tab.



5. If the Setup/Hold column is not already displayed, select **Display>Setup/Hold**.
6. If you are using a slave or demultiplexed clock, change the pod clock type for appropriate buses and signals. You change the pod clock type by selecting Master Clock in the pod column of the assigned channels.
7. Click the bus or signal's Setup/Hold value to adjust it. You can also adjust individual bits, in which case the field shows **Individual**.

If the data valid window on the target system does not include the time when the clock signal transition, use negative values for the setup or hold. For a single-edge clock, the valid setup/hold window is adjustable from 4.5 ns setup/-2.0 ns hold to -2.0 ns setup/4.5 ns hold in 100 ps increments. For multiple-edge clocks, the valid setup/hold window is adjustable from 5.0 ns setup/-2.0 ns hold to -1.5 ns setup/4.5 ns hold in 100 ps

increments.

Note: Setup time cannot be changed independently of hold time. The total setup/hold window is a constant, but can be adjusted relative to your data valid window.

See Also

To select the state clock type

To set the state clock qualifier

To add a folder

The **Add Folder...** feature adds a windows style folder to the bus/signal list. Use folders to help organize bus and signal names when using many bus/signal names with inverse assemblers.

1. From the menu bar, select **Setup>Bus/Signal**.
2. Right-click on a bus/signal name, then select **Add Folder**.
3. The new folder appears directly below the highlighted name. By default, the new folder has a system generated default name. If desired, rename the new folder in the same way you would a bus/signal name.

See Also

To alias a bus/signal name

To alias a bus/signal name

The **Add Alias...** feature adds an exact duplicate bus or signal name (same channel, polarity, etc. assignments). Use alias names along with folders to help organize the many bus and signal names with inverse assembly.


1. From the menu bar, select **Setup>Bus/Signal**.
2. Right-click on the desired bus/signal name, then select **Add Alias**.
3. The new alias name appears directly below the highlighted name. The new alias name can be renamed, however, the new name will also be applied to the original name.

See Also

To add a folder

Sampling Setup Tasks

Sampling Setup



The Sampling tab is access through the menu bar's **Setup>Timing/State (Sampling)**. The Sampling setup tab is used to select and configure the acquisition mode.

In the Timing - Asynchronous Sampling mode, you set the sampling period and channel width. You also set the acquisition (memory) depth and the trigger position. Timing mode samples the target system at regular intervals (the sampling period).

In the State - Synchronous Sampling mode, you configure the clocking type and any desired clock qualifier. You also set the acquisition (memory) depth and the trigger position. State mode samples the target system when a signal matching the defined clock occurs.

The following tasks are performed in the Sampling setup tab.

- To set the acquisition mode
- To set acquisition depth
- To set the trigger position

State - Synchronous Sampling mode

- To select the state clock type
- To set the state clock qualifier
- To setup advanced clocking

Timing - Asynchronous Sampling mode

- To set the sampling period

To set the sampling options

To set the acquisition mode

To select the timing analyzer

1. From the menu bar select **Setup>Timing/State (Sampling)**, or click the icon from the setup toolbar.
2. In the Sampling setup dialog, select the **Timing - Asynchronous Sampling** option.



To select the state analyzer


1. From the menu bar select **Setup>Timing/State (Sampling)**, or click the icon from the setup toolbar.
2. In the Sampling setup dialog, select the **State - Synchronous Sampling** option.



To set acquisition depth

The acquisition depth control allows the user to set the amount of memory that is filled with data on an acquisition. The choices available depend on the maximum memory depth available in the analyzer that is being used.

1. From the menu bar select **Setup>Timing/State (Sampling)**.
2. Set the acquisition mode and any state or timing options. These will affect the available memory choices.
3. In the Options box to the right, set Acquisition Depth.



See Also

To set the trigger position


To set the trigger position

The trigger position specifies the amount of trace memory used for samples captured before the trigger. For example when 10% is selected, 90% of trace memory is used for samples captured after the trigger. When 90% is selected, 10 % of trace memory is used for samples captured before the trigger.

In timing mode, the amount of pre-trigger and post-trigger memory will always be what you expect based on your settings, even if your trigger condition occurs before pre-trigger memory is filled. This happens because in timing mode, the trigger sequencer does not start until pre-trigger memory is full.

However, this is not true for state mode. In state mode, the sequencer starts immediately, in other words, it doesn't wait for prestore memory to be filled. Thus, in state mode, your trigger position may not be where you expect. For example, if you set the trigger position to 50%, but you find the trigger right away, the amount of pre-trigger memory will be less than what you expect.


1. From the menu bar select **Setup>Timing/State (Sampling)**, or click the  icon from the setup toolbar.
2. Select the trigger position.



See Also

To set the acquisition depth

To select the state clock type



By default the clock mode is set to Master. If you want to set the clock mode to Master/Slave or Demultiplex, follow the procedure below.

Note: To probe demultiplexed data, use only one pod of a pod pair.


1. From the menu bar, select **Setup>State/Timing (Sampling)**.
2. Select **State**.
3. In the State Options, change Clock Mode to **Master/Slave/Demux**.
4. Set up your master and slave clocks.
5. Select the **Buses/Signals** tab.
6. Select the Clock field under the pod heading.
7. **For Demultiplex mode:** Set the clock to **Demultiplex**. The display of the pod and its neighbor changes. For example, if you set Pod 1 to demultiplex, Pod 2 goes away and you see two Pod 1 columns. The first Pod 1 column is labelled Pod 1 (Master Clock) and the second column is Pod 1 (Slave Clock). **For Master/Slave mode:** Change pod clock fields to Slave as necessary.
8. Assign channels to buses.

Master

In the Master only sampling clock mode, there is one sampling clock signal. When a clock edge occurs, data is captured and saved into one sample of logic analyzer memory. Two additional sampling clock modes let you capture data differently:

Master/Slave


In the Master/Slave mode, you can save data captured on different clock edges into the same sample of logic analyzer memory.



When the slave clock occurs, data captured on the pods that use the slave clock is saved in a slave latch. Then, when the master clock occurs, data captured on the pods that use the master clock, as well as the slave latch data, are saved into logic analyzer memory. If multiple slave clocks occur before the next master clock, only the most recently acquired slave data is saved into logic analyzer memory.

Demultiplex

In the Demultiplex mode, you can demultiplex data being probed by one pod into the logic analyzer memory that is normally used for two pods. Demultiplex mode uses the master and slave clocks to demultiplex the data.



When the slave clock occurs, data captured on the pod is saved into the slave latch for the other pod in the pod pair. Then, when the master clock occurs, data captured on the pod, as well as the slave latch data, are saved in logic analyzer memory. As with master/slave mode, if multiple slave clocks occur before the next master clock, only the most recently acquired slave data is saved into logic analyzer memory.

See Also

- To set the state clock qualifier
- To setup advanced clocking

To set the state clock qualifier

The state clock should be set to match the clock signal on your target system. The logic analyzer can handle clock signals comprised of up to four lines. Clocks can be as simple as a single rising edge, or a complicated combination of edges and highs or lows.

Pod:	4	3	2	1	
Clock:	Clk4	Clk3	Clk2	Clk1	
Activity:	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Master:	X	X	X	f	Clk1↑

In the picture above, the clocks refer to the clock signal lines on pods 1 through 4. Depending on model, your logic analyzer may have more pods. However, only the clock lines on the first 4 pods can be used to generate the state clock signal. Clock lines on extra pods can be used like normal data lines.

1. Attach logic analyzer pods to your target system. Clock signals must be connected to the clock lines on pods 1 through 4.
2. From the menu bar, select **Setup>Timing/State (Sampling)**.
3. Select **State - Synchronous Sampling**. The State Options area becomes active.
4. Select the state clock type. Most measurements use only the master clock.
5. Set up a clock description to match the clock(s) on your target system.

<input type="checkbox"/> X	Don't care. Clock line not used in this clock.
<input type="checkbox"/> f	Rising edge.
<input type="checkbox"/> F	Falling edge.
<input type="checkbox"/> fF	Either edge.
<input type="checkbox"/> 1	Qualifier - high.
<input type="checkbox"/> 0	Qualifier - low.

A clock description must have at least one edge.

See Also

- To select the state clock type
- To set setup/hold
- To setup advanced clocking

To set up advanced clocking


The Advanced Clocking dialog lets you specify more complex clock setups than you can with the normal Master or Slave selections. If you want to use a specific clock channel both as an edge and a qualifier in the same clock description, you need to use advanced clocking.

1. From the menu bar, select **Setup>State/Timing (Sampling)**.
2. Select **State** mode. The state options become selectable.
3. Next to the clock mode, select **Advanced Clocking**. The clock controls are replaced by a button.
4. Select **Master Clock...** or **Slave Clock...** as appropriate. The Advanced Clocking Setup dialog appears.
5. Choose settings as appropriate. Clock channels can be used both as primary clocking and as clock qualifiers.
6. Click **OK** to close the dialog. The clock description in the Analyzer Setup window updates.

Note: If you un-check advanced clocking, the clock settings are preserved except that all qualifiers are erased.

To set the sampling period

In timing mode, a logic analyzer takes a sample of the target system's activity once per sample period. You can set this sample period in the Sampling Setup tab. When running in 800 MHz mode, the sample period is not changeable.


1. From the menu bar select **Setup>Timing/State (Sampling)**, or click the  icon from the setup toolbar.
2. Select **Timing - Asynchronous Sampling**.
3. In the Timing Mode area of the Sampling setup dialog, increase or decrease the Sample Period.

Note: To capture signal level changes reliably, the sample period should be less than half of the period of the fastest signal you want to measure. Time interval measurements are made by counting the number of samples in the desired waveform area. These measurements are made to a +/- one sample error, so measurement accuracy is improved if the number of samples is maximized.

To set sampling options

In Timing (asynchronous) mode, you can trade off channel width for increased sample time. That is, if you want a faster sampling period, you can choose the option of using only half of the maximum channels available for your analyzer model. The channel count will vary according to the analyzer model you have.

- 1680A/90A - 136 channels
- 1681A/91A - 102 channels
- 1682A/92A - 68 channels
- 1683A/93A - 34 channels



1. From the menu bar, select **Setup>State/Timing (Sampling)**.
2. Select **Timing** acquisition mode. Timing Options becomes selectable.
3. Select the sampling option you prefer. Your channel count may be different depending on the logic analyzer model.

Note: Changing the sampling option will affect the sampling period and may affect bus assignments.

136 channels, 400 MHz	Default. All channels are available; the sampling period can be set from 2.5 ns to 1 ms.
68 channels, 800 MHz	Uses one pod from each pod pair. The sampling period is always 1.25 ns.
Store transitions only, 136 channels, 200 MHz	Provides maximum duration of acquisition because data is only stored when a change from the last value is detected. Sampling period ranges from 5.0 ns to 1 ms. See transitional timing.

See Also

Transitional timing

Transitional timing

In the **Store transitions only** mode, the timing analyzer samples data at regular intervals, but only stores data when there is a threshold level transition. Each time a level transition occurs on any of the bits, data on all channels is stored. A time tag is stored with each stored data sample so the measurement can be reconstructed and displayed later.


More on storing transitions

Minimum transitions stored

Normally, transitions do not occur at each sample point. This is illustrated below with time-tags 2, 5, 7, and 14. When transitions do occur, two samples are stored for every transition. Therefore, with 2 K samples of memory, 1 K of transitions are stored. You must subtract one, which is necessary for a starting point, for a minimum of 1023 stored transitions.

Maximum transitions stored

If transitions occur at a fast rate, such that there is a transition at each sample point, only one sample is stored for each transition as shown by time tags 17 through 21 below. If this continues for the entire trace, the number of transitions stored is 2 K samples. Again, you must subtract the starting point sample, which then yields a maximum of 2047 stored transitions.



In most cases a transitional timing trace is stored by a mixture of the minimum and maximum cases. Therefore, in this example the actual number of transitions stored will be between 1023 and 2047.

Transitional timing considerations

Data storage

When an edge is detected, two samples are stored across all channels assigned to the timing analyzer. The need of two samples is to avoid loss of data if a second edge were to occur too soon after the first edge for the edge detectors to reset.

Sequence level branching

In transitional timing, only 2 branches are available per sequence level.

Global counters

In transitional timing, only one global counter is available.

Storing Time Tags

Transitional timing requires time tags to recreate the data. Time tags are stored by interleaving them with measurement data in memory.

Increasing Duration of Storage

The analyzer looks for transitions on all bits assigned to a bus. Therefore, to increase usable memory depth and acquisition time, remove bits with transitions on signals like clock or strobe that add little useful information to the measurement when no other signals transition.

Invalid Data

The analyzer only looks for transitions on data lines on buses that are turned on. Data lines on buses that are turned off store data, but only when one of the lines that is turned on transitions. If the data line on a bus is turned on after a run, or the data line is assigned to a new bus, you would see data, but it is unlikely that every transition that occurred

Trigger Position

In transitional timing, no data prestore (samples acquired before trigger) is required. Therefore, much like state mode, the trigger position (start/center/end) will indicate the percentage of memory filled with samples after the trigger. The number of samples acquired/ displayed before trigger will vary between measurements.

Triggering

Triggering

Triggering the logic analyzer at the correct time is important because it allows you to store only the data you want to see and analyze. The more accurate the trigger point, the more precise the captured data set will be surrounding the malfunction in the target system.

In many measurements the trigger point can be as simple as an occurrence of a data pattern on a bus, or a rising edge on a clock line. In more advanced measurements, the trigger point would occur only after a series of bus patterns, edges, and qualifying time periods.

Depending on the measurement, the logic analyzer can be triggered in the following ways:

- Simple trigger

- Advanced trigger dialog


- External trigger

See Also

- Trigger Functions

Simple Trigger Tasks


Simple Trigger



The **Simple Trigger** allows you to quickly create simple triggers like edges and bus patterns within the waveform or listing window. Bus data is compared to a relational operator (example; equal to, not equal to) and a user-defined value. Single signals are compared to options such as a rising or falling edge, or a low or high level. In the state acquisition mode, edges are not available. When a bus pattern and/or signal match the user defined expression, the analyzer triggers.

When both a bus and signal are used in an expression, they are ANDed together with the restriction that only one edge can be set. In cases where multiple edges are set, the last edge set has priority, while all others are changed to don't cares (X).

When a trigger condition requires more than a simple AND/OR expression, such as using multiple sequence steps, or the use of timers and counters, you can choose to use the advance trigger dialog. When the advanced trigger dialog is used, and a trigger expression is configured that surpassed the functional limits of the simple trigger, the simple trigger fields go away. To restore the operation of the simple trigger, you must either change the existing advanced trigger configuration to use bus patterns and edges within the scope of the simple trigger, or, click in the simple trigger field, then choose **Simple Trigger** to reset the trigger.



Up to the point where the advanced trigger surpasses the functionality limits of the simple trigger, both the simple trigger fields and the advanced trigger dialog will show the current trigger configuration and are available for trigger modification. However, as mentioned above, as soon as changes in the advanced trigger dialog surpass the simple trigger functional limits, the simple trigger fields go away.

In the case where a signal and bus overlap, that is, any signal that is actually part of the group of signals making up the bus, the last change has highest priority. For example, a bus pattern has been set to trigger the analyzer, you then set an overlapping signal (channel 1 of same bus) to trigger on a rising edge. By changing the signal, the bus pattern trigger is now discarded.

To set bus pattern triggers
To set signal trigger options

See Also



Set quick trigger with rectangle
To store a trigger
To recall a trigger
Advanced trigger dialog
Trigger Functions

To set bus pattern triggers

Bus pattern triggers are part of the Simple Trigger and are used to quickly select a qualifier to compare the incoming bus to. Bus data is compared to an operator (example; equal to, not equal to) and a user-defined value. When a bus pattern matches the defined bus pattern trigger, the analyzer triggers. A complete list of operators is listed below.

The Simple Trigger is located in both listing and waveform display windows.



1. In the Simple Trigger field, click on the pattern qualifier  field and set it to the desired operator.
2. Click in the text entry field  and enter the desired data pattern.

Operators

- Equal To
- Not Equal To
- In Range
- Not In Range
- Greater Than
- Greater Than Or Equal To
- Less Than
- Less Than Or Equal To

See Also


To set signal trigger options
Advanced Trigger Dialog

To set signal trigger options

Signal trigger options are part of the Simple Trigger and are used to quickly select a qualifier to compare the incoming signal to. Signals are compared to options such as a rising edge or falling edge. When the analyzer detects a match with the defined option, the analyzer triggers. A complete list of available options is shown below.

The Simple Trigger is located in both listing and waveform display windows.



1. In the Simple Trigger field, click on the signal option  field and set it to the desired option.

Options

- Rising Edge
- Falling Edge
- Either Edge
- Glitch
- High
- Low
- Don't Care

Note: In State acquisition mode, edge options are not available.

To triggering on a glitch


When Glitch is selected as the signal's trigger option, the analyzer will trigger when a glitch with a minimum width of 1.5 ns appears on the signal line. Because the glitch is not drawn on screen, the use of an oscilloscope is required to further troubleshoot when the glitch occurs.

See Also

To set bus pattern triggers
Advanced Trigger Dialog

Advanced Trigger Tasks

Advanced Trigger Dialog



The Advanced Trigger dialog is used to configure the advanced triggers that require multiple conditions to be true before a trigger occurs. Each acquisition mode (state or timing) has its own set of trigger functions. Trigger functions are represented by blue boxes, and are drag-and-dropped onto the trigger sequence display area in the order in which you want them executed.

The Advanced Trigger dialog is accessed through the menu bar **Setup>Advanced Trigger...**. The following tasks are performed in the dialog:

To build a trigger sequence

- To set store qualification - (State mode only)
- To insert events and actions
- To negate a function statement
- To modify trigger step display
- ANDing and ORing event statements

To store a trigger

To recall a trigger

See Also

State mode trigger functions


Timing mode trigger functions

Simple Trigger

To build a trigger sequence

The trigger functions included in the advanced trigger dialog give you pre-configured trigger sequences that will work for most measurements. In the case where you have to build a custom trigger sequence for your particular measurements, the following overview shows you how to build a trigger sequence.

1. From the menu bar, click **Setup>Advanced Trigger...**
2. From the Advanced Trigger dialog, **drag and drop** the desired Trigger Function into the Trigger Sequence display area.



Replace - To replace an existing function, drag and drop the new function on top of the old one. A red box around the old function indicates the replace operation.

Add above/below - To add multiple functions, drag and drop the new functions above or below the existing function. When the mouse is positioned above or below an existing function, a red insert bar appears to indicate relative insert location of the new function.

Trigger steps

Each trigger function added to the trigger sequence displays a trigger **Step**. Trigger steps illustrate in sentence form how the function evaluates data to find the trigger point. The evaluation process continues within the trigger step until either the trigger is found, or an instruction is encountered that sends evaluation to another trigger step. Each trigger function added to the sequence adds another trigger step.

For custom trigger sequences, each trigger step can be modified in the following ways:

To set store qualification - (State mode only)

To insert events and actions

To negate a function statement

To modify trigger step display

See Also

To store a trigger

To recall a trigger

State mode trigger functions


Timing mode trigger functions

To set store qualification

Storage qualification is used to determine if an acquired sample should be stored (that is, placed in memory) or thrown away. This keeps the logic analyzer memory from being filled with samples that are not needed.

Default storage

The simplest method to set up storage qualification is by setting up the **Default Storage**. This is specified separate from the trigger sequence as shown below.



Default storage means "unless sequence step storage specifies otherwise, this is what should be stored". Sequence step storage always overrides default storage.

Example: Before the analyzer triggers, you only want to store samples if ADDR is greater than E5. Set the Default Storage as follows:




By default, the default storage is set to store all samples acquired. You can also set the default storage to store nothing, which means that no samples will be stored unless the sequence step storage overrides the default storage.

Sequence step storage

Sequence step storage means that within a particular sequence step only certain samples are stored. This also means that until a "Go To" or "Trigger" action is used to leave the sequence step, the sequence step storage applies. This is useful when you want different sequence step storage qualification for each sequence step.


Example: You want default storage to store nothing before trigger, then you want sequence step storage to store samples when ADDR is greater than E5, starting when E5 has occurred for the 3rd time.



Storage interaction

Remember, sequence step storage always overrides default storage, but only for the conditions specifically configured in the sequence step storage. You must be very careful that you account for the interaction between default storage and sequence step storage.

For example, if you want to store only samples with ADDR in the range 5000 to 6FFF while looking for DATA = 005E, the following sequence level could be used in some situations:



Notice the use of the **Store sample** action. This means "store the most recently acquired sample in memory now". It does not mean, "From now on, start storing". Since the store sample action is never executed unless ADDR is in the range 5000 to 6FFF, this branch essentially means "While in this sequence step, store only samples with ADDR between 5000 and 6FFF".

The above example seems to imply that only samples with ADDR between 5000 and 6FFF will be stored. However, this depends upon how the default storage has been set up. Using the previous example, if the default storage is set to "Store Everything", and a sample is outside of the range 5000 to 6FFF, then the Else If branch is not executed and the Default Storage is applied. In essence, the sequence step has said what to do when a sample has a value in a particular range, but it doesn't say what to do for samples outside the range. Therefore, if you want to specify the sequence step storage unambiguously, use the following:

Prior to doing a "Trigger and fill memory with" action:
Store Nothing

Step 1	Advanced If/Then/Else Step
If	Bus/Signal DATA all bits Equals 005E occurs 1
Then	Trigger and fill memory with Anything
Else if	Bus/Signal ADDR all bits In Range 5000 to 6FFF
Then	Store sample Goto 1
Else if	Bus/Signal ADDR all bits Not In Range 5000 to 6FFF
Then	Don't store sample Goto 1

Alternatively, if the default storage is set to "Store Anything", use the following:

Prior to doing a "Trigger and fill memory with" action:
Store Anything

Step 1	Advanced If/Then/Else Step
If	Bus/Signal DATA all bits Equals 005E occurs 1
Then	Trigger and fill memory with Anything
Else if	Bus/Signal ADDR all bits Not In Range 5000 to 6FFF
Then	Don't store sample Goto 1

How to read event and action statements

Your measurement goal is to see what data is stored in memory at the address value 406F6. To do this, you configure the trigger function to look for the pattern 406F6 (hexadecimal) on the address bus, and a rising edge on the RD (memory read) clock line.

The screenshot shows a configuration window titled "Step 1" with a sub-header "Pattern n times". It contains the following fields and controls:


- "Find" field with the value "1" and increment/decrement buttons.
- "occurrence of" label.
- Two rows of dropdown menus for signal selection and comparison:
 - Row 1: "Bus/Signal" (dropdown), "ADDR" (dropdown), "All bits" (dropdown), "Equals" (dropdown), "4 06F6" (text field), "Hex" (dropdown), "And" (dropdown).
 - Row 2: "Bus/Signal" (dropdown), "RD" (dropdown), "High" (dropdown).
- "Then" dropdown menu with the selected option "Trigger and fill memory".
- "with" dropdown menu with the selected option "Anything".

As you configure the trigger function, try to think of it as constructing a sentence that reads left-to-right.

For example:

"Find a **Bus** named **address**, and on **All bits**, a pattern that **Equals 406F6 Hex**, And a **Signal** named **RD** with a **Rising Edge**. When found, then **Trigger and fill memory**".

To insert events and actions





Events and Actions are statements, in sentence format, inserted into the trigger step to expand its functionality.


Events are used to qualify what data is being evaluated, and what data or process is being acted upon. When multiple event statements are used, you have the choice to combine them with either the AND or OR logic operators. The following Event options are available:

- Bus/Signal
- Anything
- Nothing
- Timer
- Counter
- Arm in from Ext. trigger

Actions are used to start processes such as timers or counters, or to start filling memory. When multiple action statements are used, they are combined using the AND logic operators. The following Action options are available:

- Timer
- Counter
- Store sample
- Don't store sample


1. Within the trigger step, click the  Event and  Action buttons, then select insert statements **Before** and **After** as desired. If a choice is inappropriate, it is greyed out.
2. Configure the new Action or Event fields that appear. The figure below illustrates the type of selections available. Make choices according to the specific needs of your measurement. See "Example of how to read event and action statements".



See Also

- To set store qualification
- ANDing and ORing Event statements
- To configure a timer
- To configure a counter
- To store a trigger
- To recall a trigger


To negate a function statement



When you negate a statement in a trigger function, you are asking the analyzer to evaluate the statement as an opposite.




To modify trigger step display



All trigger functions by default are displayed in a short form that allows you to modify them when necessary. However, the trigger step can also be displayed in two optional ways that enable you to see them without the graphical buttons and fields, or in an expanded form with graphical buttons and fields.

Note: The Advanced (If/Then, or Branch) trigger functions do not allow alternative display types. By default, they are in the expanded graphical form that cannot be changed. See the **If/then (can't undo)** choice below.

1. In the Trigger Sequence display area, click the  button in the trigger step.
2. Select the desired display choice.
 - **Default** - In most cases, the default form of the trigger function has all the necessary elements for a trigger. It appears in a short form which can hide such elements as internal occurrence counter and timer functions.
 - **If/then (read-only)** - This choice converts the trigger step into read only text. This choice can be switched back to the default form of configurable fields.
 - **If/then (can't undo)** - This choice converts the trigger step into an Advanced IF/Then form similar to the IF/Then trigger functions under the Advanced tab. This choice cannot be switched back to the default form. However, since this choice is just an expanded form of the default with configurable fields, editing the trigger step in this form is viable.

An advantage of this form is that you have access to elements such as internal occurrence counter and timer functions. The disadvantage is that you cannot convert back to the short form of the trigger function.

The following figure shows the same Edge trigger function in all three forms.

Step 1 = Default


Step 2 = If/then (read only)

Step 3 = If/then (can't undo)

Step 1		Edge		
Find	Bus/Signal	My Signal 1	Rising Edge	
Then	Trigger and fill memory			
Step 2		Edge		
2.1	If	Bus/Signal	My Signal 1	Rising Edge
		occurs 1		
	Then	Goto 3		
Step 3		Advanced If/Then		
	If	Bus/Signal	My Signal 1	Rising Edge
		occurs	1	[-] [+]
	Then	Goto	Next	

ANDing and ORing Event statements

When you add multiple event statements to form a complex trigger step, the statements are combined using the logical operators AND and OR. Parentheses are also automatically added to help show how the statement is partitioned during evaluation.



See Also

To insert event statements

To store a trigger

Depending on how you want to recall stored triggers, the logic analyzer enables you to store your trigger specification in two ways.

Most recently used trigger list

Each time you setup a new trigger and run the measurement, the trigger setup is stored automatically in a "Most recently used trigger" list in the analyzer.

Note: The analyzer must be run before the trigger setup is stored. Also, trigger setups are stored as part of the configuration file. If you load a new configuration file, the trigger setups will be overwritten by trigger setups stored with the new file.

To view triggers stored automatically, click **Setup>Recall Trigger**, then look in the "Most recently used trigger" list. If the list gets to long, you can move them to the "Stored favorite triggers" list. The number of items allowed in the list is set by **Edit>Options>Trigger History Depth**.

Stored favorite triggers list

When you force a save trigger operation before the measurement is run, the trigger is placed in the "Stored favorite triggers" list. The number of items allowed in the list is set by **Edit>Options>Recent File List Size**.

1. From the menu bar, click **Setup>Advanced Trigger**.
2. From the Advanced Trigger dialog, configure the trigger specification, then click **Store**.
3. Click **Ok**.

Optional: You can also store a trigger through the menu bar. Click **Setup>Store Trigger**.


See Also

To recall a trigger

Recall Trigger Dialog

After a trigger is stored, it is placed in a recall list for use at a later time. Use the Recall Trigger dialog to recall a previously used trigger, save a trigger in a favorites list, view trigger details, or rename the trigger to a custom name.

Note: Saved triggers are part of a the current configuration. If you load a new configuration file, saved triggers in the current recall list are lost.



Rename	Allow you to edit the name of the highlighted trigger.
Clear	Clears the highlighted trigger from the list.
Clear All	Clears all triggers from recall lists.
Details	Shows complete definition of the highlighted trigger.

To recall a trigger

1. From the menu bar click **Setup>Recall Trigger...**
2. Select the desired trigger, then click **Ok**.

See Also

To store a trigger

To configure a counter

Counters are available in both Event and Action statements, and like other events, they evaluate to either true or false. Use counters to create a user-defined delay, or to create a standard against which valid data duration is evaluated. Once configured, a counter persists throughout all the steps of the trigger sequence.

Counter considerations:

- Maximum counters available is 2.
- When using counters in the transitional timing mode, one counter is used internally so only one counter is available in a sequence step.
- Once a counter is configured, you can reuse the counter by selecting its identification number. Each use of the counter must check it for the same value.

Note: The logic analyzer also has occurrence counters, and a **reset occurrence counter** action. Occurrence counters only exist within steps that contain the "occurs" phrase and are not affected by the other counter actions described on this page.

To insert a counter event


A counter must be started with a counter action before it can be evaluated with a counter event.



1. From within the trigger Step, select the **event type button**, and from the selection list that appears, select **Counter**.
2. Select the **counter number button** and choose the number of the counter you want to test.
3. Select the **operator button** and choose either >= or <.
4. Enter the count value.

To insert a counter action

1. From within the trigger Step, select the **insert action button**, then select **Insert Action Before**.



2. Select the **action type button**, and from the selection list that appears, select **Counter**.



3. Select the **counter number button** and choose the number of the counter you want to test.
4. Select the **operator button** and choose either Increment, or Reset.

See Also

- To configure a timer
- To build a trigger sequence
- To modify trigger step display
- To negate a function statement

To configure a timer


Timers are like stopwatches. Use timers to create either a user-defined delay or a time standard which valid data duration is evaluated against. The timer can **Start** from reset, **Stop** and reset, **Pause**, or **Resume**.

Timer considerations:

- Depending on the analyzer model and acquisition mode, available timers are as follows:

Model	Timing Acquisition Mode	State Acquisition Mode
1680/90	3 timers available	4 timers available
1681/91	2 timers available	3 timers available
1682/92	1 timer available	2 timers available
1683/93	0 timers available	1 timer available


- Timers are checked in event statements, and started in action statements.
- Timers must be started before they can be checked. This is done by either including the timer start action with the timer check event within the same trigger step or starting the timer in a preceding trigger step. The following example shows the timer start action and check event within the same trigger step.




- Once a timer event is configured, you can reuse the timer by selecting its identification number. The same timer must always be checked against the same value. To check for different durations, use different timers.

To insert a timer check event

- From within the trigger step, select the **insert event button**, then select **Insert Event Before**.




- Select the **event type button**, and from the selection list that appears, select **Timer**.




3. Select the **timer identification** button and choose the number of the timer you want to use.
4. Select the **operator button** and choose either \geq or $<$.
5. Enter the time value.

To insert a timer start action


1. From within the trigger step, select the **insert action button**, then select **Insert Action Before**.



2. Select the **action type button**, and from the selection list that appears, select **Timer**.



3. Select the **timer number button** and choose the number of the timer you want to check.
4. Select the **operator button** and choose either Start from reset, Stop and reset, Pause, or Resume.



Note: As stated above in timer considerations, the timer start action can be placed in either the same trigger step as the timer check event, or it can be placed in a preceding trigger step. Checking a timer without starting it will generate an error.

See Also

- To configure a counter
- To build a trigger sequence
- To modify trigger step display
- To negate a function statement

Marker Tasks

To create new markers

When you create a new marker, you have the option of customizing it with a user-defined name and color. You can also position it precisely in data by either a time value or sample number, or by a data value. Up to 1024 markers can be created.

1. From the menu bar, select **Markers>New**.
2. From the New Marker dialog, either accept the new default marker name and color, or assign a custom name and color.
3. Configure the position of the new marker in the data by one of the following methods:
 - **Time** - Position the marker by a time value from a reference point. Reference points are the Trigger, Beginning of Data, End of Data, or another Marker.
 - **Sample** - Position the marker by a number of samples from a reference point. Reference points are the Trigger, Beginning of Data, End of Data, or another Marker.
 - **Value** - Position the marker at a user defined value. Click the **Occurs** field and configure the find data options.

Using abbreviated names

Marker names can be very descriptive. The problem with descriptive marker names is that they are long and take up room on the display. To keep a descriptive marker name and also minimize the amount of display real estate used, an abbreviated name can be defined. The abbreviated name is defined by including “[]” within the descriptive name.

Example:

The name for the trigger marker is defined as: **Trigger[T]**. The word “Trigger” is the descriptive name that appears within the marker tool tip. The “[T]” is the abbreviated name that appears within the marker display bar. If an abbreviated name is not defined within a descriptive name, the descriptive name will be displayed within the marker display bar.

See Also

- To place markers in data
- Go To markers
- Reading off-screen markers
- To center the display about a marker
- To delete a marker
- To rename a marker
- To send a marker to the back
- To set marker properties
- To drag and drop markers in data
- Marker snap to edge

To place markers in data

Use Place Markers to quickly position a pre-defined marker in the data. Depending on how you access the Place Markers feature, the marker is placed in the data a little differently.

You can also move markers by dragging with the mouse or using the front-panel knobs.

Place marker at center screen

1. From the menu bar click **Markers>Place On Screen**.
2. Select the desired marker, then select **OK**. The marker will be placed at mid-screen.

Place marker at mouse cursor

1. Point the mouse to the desired data point in the display.
2. Right-click the mouse, and select **Place Markers**.
3. Select the desired marker, then select **OK**. The marker is placed in the data at the point where the mouse cursor was pointing.

See Also

To create new markers

Go To markers

Reading off-screen markers

To center the display about a marker

To delete a marker

To rename a marker

To send a marker to the back


To set marker properties

To drag and drop markers in data

Marker snap to edge

Go To Markers

Use the Go To markers feature to quickly find a previously set marker in the data, or the beginning of data, end of data, or the trigger point. The selected marker appears at the center of the display.

1. From the menu bar, select **Markers>Go To...** or select the  icon in the markers toolbar.
2. Select the marker you wish to find from the list provided.
3. Click **OK**.

See Also

- To create new markers
- To place markers in data
- To center the display about a marker
- To delete a marker
- To rename a marker
- To sent a marker to the back
- To set marker properties
- To drag and drop markers in data
- Marker snap to edge

To center the display about a marker

Use the center about feature to center the display around a selected marker pair. If the marker pair is separated by a large time or sample amount, the scale of the display is automatically changed so both markers appear on screen.

Since the center about feature centers the display around a pair (two) markers, if you have three or more markers defined, you will have available choices for all possible combinations of two.

1. From the menu bar, select **Markers>Center About**.
2. Select the desired marker combination, then select **OK**. The center of data between the selected markers is set at mid-screen.

See Also

To create new markers

To place markers in data

Go To markers

To delete a marker

To rename a marker

To sent a marker to the back

To set marker properties

To drag and drop markers in data

Marker snap to edge

To delete a marker

1. In the Marker Display Bar, point the mouse cursor over the marker you want to delete.
2. Right-click the mouse, then select **Delete**. The marker under the mouse cursor is deleted. To delete all markers, select **Delete All**.


See Also

To create new markers
To place markers in data
Go To markers
To center the display about a marker
To rename a marker
To sent a marker to the back
To set marker properties
To drag and drop markers in data
Marker snap to edge

To rename a marker

The rename marker feature allows you to change the marker name.

1. Click in the **Marker** box, then select the marker you wish to rename.
2. Select **Rename...**, then from the pop-up keypad that appears, type in the new name.
3. Select **Ok**.




See Also

- To create new markers
- To place markers in data
- Go To markers
- To center the display about a marker
- To delete a marker
- To send a marker to the back
- To set marker properties
- To drag and drop markers in data
- Marker snap to edge

To send a marker to the back

This feature is used to toggle between markers that are located in the same position. This feature can be accessed by right clicking on the marker you want move.

1. Right click on the marker you wish to send to the back.
2. Select **Send to Back** from the pop-up menu.



See Also

- To create new markers
- To place markers in data
- Go To markers
- To center the display about a marker
- To delete a marker
- To rename a marker
- To set marker properties
- To drag and drop markers in data
- Marker snap to edge

To set marker properties

Once a marker is created, you can modify any of its attributes from the Marker Properties tab. To access marker properties, click **Markers>Properties** from the menu bar, then click the **Markers Properties tab**.



Tip: You can also access the Properties dialog by a **right-click** in the display area, then select **Properties**.

- To rename the marker
- To change the marker color
- To lock marker in viewer
- To change the marker type
- Marker snap to edge

To rename the marker

1. From the Marker properties tab, select the **Marker** to rename.
2. Select the **Rename** button, and from the Rename keypad that appears, type the new name, then select **Ok**.

Using abbreviated names

Marker names can be very descriptive. The problem with descriptive marker names is that they are long and take up room on the display. To keep a descriptive marker name and also minimize the amount of display real estate used, an abbreviated name can be defined. The abbreviated name is defined by including “[]” within the descriptive name.

Example:

The name for the trigger marker is defined as: **Trigger[T]**. The word “Trigger” is the descriptive name that appears within the marker tool tip. The “[T]” is the abbreviated name that appears within the marker display bar. If an abbreviated name is not defined within a descriptive name, the descriptive name will be displayed within the marker display bar.

To change the marker color

1. From the Marker properties tab, select the **Marker** you want to change.
2. Select the marker **Color** button, and from the color palette that appears, select the new color. For custom colors, select the **Other...** button and create the desired color from the color dialog that appears.

To hide the marker

1. From the Marker properties tab, select the **Marker** you want to hide.
2. Check the **Hide** box. When a marker is hidden, all assigned marker properties are retained, it is just hidden from view in the display.

To lock marker in viewer

When viewing data in multiple display viewers, you can make a marker in one display move and remain viewable in another display. In other words, when a marker is locked in the viewer, it will follow the movement of the same marker as it is moved in another viewer.

This applies only when a marker is dragged within the immediate data viewing area. If a marker is moved by defining a new location using the markers properties dialog, it is not guaranteed to stay in view within any of the viewers.

1. From the Marker properties tab, select the **Marker** you want to lock in the

display.

2. Check the **Lock in Viewer** box, then click **Ok**.

To change the marker type

1. From the Marker properties tab, select the **Marker** you want to change.
2. In the "Position" area of the properties dialog, select the marker type name (Example; Time) and from the selection list that appears, select the new type. When the marker type is changed between Time and Sample, the marker position in the data does not change, just the unit of measure.

See Also

To create new markers

To place markers in data

Go To markers

To center the display about a marker

To delete a marker

To rename a marker

To sent a marker to the back

To drag and drop markers in data

Reading off-screen markers

To drag and drop markers in data

Using the drag and drop feature you can move markers to new positions in the data.

1. Click and hold down the mouse button on the marker you wish to move.
2. Move the mouse cursor to the new position.
3. Release the mouse button to reposition the marker.

See Also

To create new markers

To place markers in data

Go To markers

To center the display about a marker

To delete a marker


To rename a marker

To send a marker to the back

To set marker properties

Marker snap to edge

Reading off-screen markers



In the upper marker display bar, markers are color coded and displayed with arrows that point to the marker's relative location to the locally (current window) displayed data. In the lower marker display bar, markers are displayed as color coded bars showing relative location within the data record (global).

In the waveform display as shown above, the marker display bars appear on the top/bottom of the display window. In the listing display, the marker display bars appear on the left/right sides of the display window in a similar way.



Tip: You can quickly display a different region of data from the data set by double-clicking on the global marker display bar at the bottom (waveform) or right side (listing).

File Management Tasks

File management

To open a configuration file

To save a configuration file

To recall a recently used configuration file

To export files

To import files


See Also


The XML Format

The CSV Format

The ALA Format

To open a configuration file

1. From the menu bar, select **File>Open** or select the  icon in the standard toolbar.



2. Select the file configuration you wish to open.
3. Select **Open**.

Note: Configuration files that include trace data will be much larger than files that do not contain trace data.

The **Owner**, **Project**, and **Description** dialogs are used to help identify configuration files. The configuration file was created with the software version shown in the **Version** dialog. The **Date** dialog displays the date the configuration file was created. The **Setup only** checkbox is checked if the configuration file contains only the instrument settings. If the **Setup only** box is not checked then the configuration files contains the instrument

settings and the trace data.

Note: If you are using the logic analyzer without a keyboard, you can access an on-screen keyboard by selecting **Start>Programs>Accessories>Accessibility>On-Screen Keyboard**.

See Also

The ALA Format


To import files

To export files

To save a configuration file

The save feature allows you to save a configuration file for later use. The first time a file is saved the logic analyzer configuration file dialog box will appear. The **Save As...** feature allows an existing configuration file to be saved under a different name.

1. From the menu bar, select **File>Save** or select the  icon in the standard toolbar.



2. Enter the name of the configuration you wish to save.
3. If desired, complete the **Owner**, **Project**, and **Description** dialogs. These dialogs help to identify the configuration files when they are reopened.
4. Select the **Setup only** checkbox if you wish to save only the instrument settings and not the trace data.

Note: Configuration files that include trace data will be much larger than files that do not contain trace data.

5. Select **Save**.

The **Version** and **Date** dialogs are automatically generated and cannot be edited. The configuration file was created with the software version shown in the **Version** dialog. The

Date dialog displays the date in which the configuration file was created.

Note: If you are using the logic analyzer without a keyboard, you can access an on-screen keyboard by selecting **Start>Programs>Accessories>Accessibility>On-Screen Keyboard**.

See Also


The ALA Format

To import files

To export files

To recall a recently used configuration file

1. From the menu bar, select **File**.
2. Select the configuration file you wish to open from the list provided.



To import files

The Import dialog allows you to import XML based text files previously exported using the Export dialog or created using the Config Translator Application. The imported file may contain data or just the configuration setup information.


Import/Export considerations:

- Neither XML or CSV files can re-create a complete logic analyzer configuration. Use configuration files (.ala) if you want to reload complete data and tool configurations.
- CSV files cannot be imported back into the logic analyzer.
- XML files can be imported, but some tool configuration information is lost. See below for a complete list.
- Generally, exported files should be imported into similar analyzers (same hardware configuration).
- Bus/signal folders are not imported. All bus/signals names are imported back to the root level of the bus/signal name.
- Clock channel mapping is not imported.

Note: If it is important to keep clock channel mapping, use configuration files (.ala).


To import a file

1. From the menu bar, select **File>Import**.
2. In the **File name:** field, type in the desired file name.
3. In the **Files of type:** field, select the **.txt** file format type.
4. Click **Open**.



While running an import, all other operations are disabled until either the user cancels the



import via the cancel  toolbar button, or the import operation completes. The status bar at the bottom of the display will show the progress of the import process.

Information not imported from XML file

- Clock channel mapping.
- In state acquisition mode, the clock mode and clock description.
- Bus and signal order. (Names and channel assignments are exported.)
- Filter information. (Other tool types are exported.)
- Interface layout.
- Changes in column or row properties.
- Marker information.
- Trigger history.

Note: If any of the above items are important to your post-processing, please save data in a configuration (*.ala) file.

See Also

The XML Format
To export files
Config Translator Application

To export files

The Export dialog allows you to export most configuration setup information, measurement data, and generated tool data such as Inverse Assemblers to a file on a disk. Data is exported in either in XML text format (.txt) or Comma Separated Value format (.csv).


Import/Export considerations:

- Neither XML or CSV files can re-create a complete logic analyzer configuration. Use configuration files (.ala) if you want to reload complete data and tool configurations.
- CSV files cannot be imported back into the logic analyzer.
- XML files can be imported, but some tool configuration information is lost. See below for a complete list.
- Generally, exported files should be imported into similar analyzers (same hardware configuration).
- Bus/signal folders are not imported. All bus/signals names are imported back to the root level of the bus/signal name.
- Clock channel mapping is not imported.

Note: If it is important to keep clock channel mapping, use configuration files (.ala) .


To export a file

1. From the menu bar, select **File>Export**.
2. In the **File name:** field, type in the desired file name.
3. In the **Save as type:** field, select the desired file format type.
4. In the Data Range section, select the data range you want to export.
 - **All** - Exports all data in memory.
 - **Time** - Exports data between the specified time values.
 - **Sample** - Exports data between the specified sample numbers.
 - **Marker** - Exports data between the specified markers.
 - **Setup Only** - Exports only measurement configuration, no data.
5. Click **Save**.



Note: When selecting a range of samples, be sure to include the ending transition to ensure a complete display of the selected range. The last sample specified is **not** included in the output.

While running an export, all other analyzer operations are disabled until either you cancel

the export operation using the cancel button  in the toolbar, or the export operation completes. The status bar at the bottom of the display window shows the progress of the export process.

Information not imported from XML file

- Clock channel mapping.
- In state acquisition mode, the clock mode and clock description.
- Bus and signal order. (Names and channel assignments are exported.)
- Filter information. (Other tool types are exported.)
- Interface layout.
- Changes in column or row properties.
- Marker information.

- [Trigger history.](#)

See Also

[The XML Format](#)
[The CSV Format](#)
[To import data](#)

Searching

Searching

The logic analyzer allows you to search for data patterns, time values, or sample numbers.


To search for a value - This search option locates a specified data pattern or value. You can qualify your search by specific bits, data patterns, equality, and range operators. The search result is placed at the center of the display.

To perform complex pattern searches - This search option locates specified data patterns or values by expanding the search criteria to include more than one event. You can qualify your search by specific bits, data patterns, equality, and range operators. The search result is placed at the center of the display.

To Go To a specific position in the acquisition - This search option locates an individual time value, sample number, or a marker. The search result is placed at the center of the display.


To search for a value

This search option locates a specified data pattern. You can qualify your search by specific bits, data patterns, equality, and range operators. The search result is placed at the center of the display.

1. From the menu bar select, **Edit>Find** or click the  icon in the standard toolbar.
2. In the **Find** dialog, select the number of the occurrences you wish to find, then choose the start location.

Note: Positive numbers indicate that the search operation should proceed towards the end of the data. Negative numbers indicate that the search operation should proceed towards the beginning of the data.

3. Configure the event you wish to locate.
4. Click **OK**.



5. Click the Previous  or Next  icons to see more occurrences.



Tip: As you configure the find function, try to think of it as constructing a sentence that reads left-to-right.
For example:

"Find **1** occurrence from the **Display Center** of a bus named **My Bus 1**, and on **All bits** a pattern that **Equals XX Hex**, display the event When all criteria is **Present**."


Note: The find qualifiers with an operator (Present>, Present>=, Present<=, Present>) and the "Present for Range" and "Not Present for Range" allow the user to specify a time duration. This means that the find event specified in the expression area will be found based upon the given time and operator. The other qualifiers (Present, Not Present, and Entering) do not allow a time duration.

See Also

To perform complex pattern searches
Store Favorite
Recall Favorite
Options


To perform complex pattern searches



This search option locates specified data patterns by expanding the search criteria to include more than one event. You can qualify your search by specific bits, data patterns, equality, and range operators. The search result is placed at the center of the display.

1. From the menu bar select, **Edit>Find** or click the  icon in the standard toolbar.
2. In the **Find** dialog, select the number of the occurrences you wish to find, then choose the start location.

Note: Positive numbers indicate that the search operation should proceed towards the end of the data. Negative numbers indicate that the search operation should proceed towards the beginning of the data.

3. Configure the event you wish to locate.
4. Select the drop down menu to choose the type of event you wish to add. Select **Insert Event After** to insert a new find event after the current event, or select **Insert Event Before** to insert a new find event before the current event. The **Delete Event** option will delete the current event only if there is more than one event present.



5. Select either **AND** or **OR** from the box that appears after you add a search option. AND'ed searches find occurrences of both events, while OR'ed searches find occurrences of either event.
6. Select the bus or signal name and enter the value you want to locate.
7. Click **OK**.
8. Click the Previous  or Next  icons to see more occurrences.



Tip: As you configure the find function, try to think of it as constructing a sentence that reads left-to-right.
For example:

"Find **1** occurrence from the **Display Center** of a bus named **My Bus 1**, and on **All bits** a pattern that **Equals XX Hex**, display the event When all criteria is **Present**."

Note: The find qualifiers with an operator (Present>, Present>=, Present<=, Present>) and the "Present for Range" and "Not Present for Range" allow the user to specify a time duration. This means that the find event specified in the expression area will be found based upon the given time and operator. The other qualifiers (Present, Not Present, and Entering) do not allow a time duration.

See Also

To search for a value

Store Favorite


Recall Favorite

Options

To Go To a specific position in the acquisition

This search option locates a specified time value, sample number, or a marker. The search result is placed at the center of the display.

1. From the menu bar, select **Edit>Go To**.
2. From the Go To dialog, choose either **Time**, **Sample**, or **Markers**.



3. Enter the value you want to locate or select the marker you want to locate.
4. Click **OK**.





Tip: You can also access the Go To dialog by right-clicking in the display area.

Favorite Find Pattern

- To store a favorite a pattern
- To recall a favorite pattern
- To delete a favorite pattern


To store a favorite pattern


1. From the menu bar select, **Edit>Find**, or click the  icon.
2. Set up the pattern you want to find.
3. Click **Save Favorite**.



4. Enter the name of the pattern.
5. Click **OK** to save the pattern.


To recall a favorite pattern

1. From the menu bar select, **Edit>Find**, or click the  icon.
2. Select **Recall Favorite**, then select the pattern you want to use from the drop down menu.



3. Click **OK**.

To delete a favorite pattern

1. From the menu bar select, **Edit>Find**, or click the  icon.
2. Select **Recall Favorite**, then select **Clear**.

Note: To clear all of the patterns, select **Clear All**.


3. Select the pattern you wish to delete from the list provided.
4. Select **Clear**.


See Also

Searching
Find Options

Find Options

When searching for a pattern you can place a marker at the occurrence.

1. From the menu bar select, **Edit>Find**, or click the  icon in the standard toolbar.
2. Setup the pattern you want to find.
3. Click **Options**.



To use the Place function

1. Select **Place**, then choose the marker you want to place from the drop down menu.
 - a. For **<new marker>**, enter the name of the new marker.
 - b. Select **Create new marker...** if you want a new marker at each occurrence of the pattern.
2. Select **OK**.

To use the Place new marker on each occurrence function

1. Select **Place new marker on each occurrence**.
2. Enter the name of the new marker.
3. Select **OK**.

See Also

Searching

Favorite Find Pattern

Capturing Data

Capturing Data

A logic analyzer is used to view timing relationships among many signals, or if you need to trigger on patterns of logic highs and lows. A logic analyzer is actually two analyzers in one: a timing analyzer and a state analyzer. A timing analyzer is a logic analyzer that samples based on an internal clock signal. This kind of sampling is also known as asynchronous sampling. A state analyzer is a logic analyzer that samples based on a clock signal (or signals) from the device under test. Typically, the signal used to set up sampling is a state machine or microprocessor clock signal. This type of sampling is also known as synchronous sampling.

How to set up logic analyzer measurements.

- To set the acquisition mode - Before viewing a signal, you must select either a timing analyzer or a state analyzer. A timing analyzer samples based on an internal clock, and a state analyzer samples based on a clock signal from the device under test.
- To set the sampling period - The timing analyzer works by sampling the input waveforms to determine whether they are high or low. The state analyzer has to restrict the sampling of data to times when only the desired data is valid and appears on the signal lines.
- To start/stop measurements - There are two types of run modes; the single run measurement will save captured data to trace memory one time. The run repetitive measurement will save the captured data to trace memory repetitively. Stopping a run determines how much data is captured and placed in trace memory.
- Trigger position - The trigger position specifies the amount of trace memory used for samples captured before the trigger.
- Triggering
 - Simple Trigger - The Simple Trigger allows you to quickly select a qualifier to compare the incoming bus or signal with.
 - Advanced Trigger - The Advanced Trigger is used to configure triggers that require multiple conditions to be true before a trigger occurs.

To start/stop measurements

To run the analyzer in single mode - The single run measurement will save captured data to trace memory one time. The amount of data stored during a single run is equal to the amount of trace memory allotted. For example, if trace memory is equal to 2M then the amount of data stored after one run is equal to 2M.

To run the analyzer in repetitive run mode - The run repetitive measurement will save the captured data to trace memory repetitively. The amount of data stored in a repetitive run is the same as a single run. During a repetitive run once the trace memory is full the system clears the trace memory and begins to refill with new data. This cycle will continue until the run is stopped.

To stop the analyzer - When a measurement is stopped the amount of data gathered is equal to the amount of trace memory used up until the stop occurred. For example, if trace memory is equal to 2M and the measurement is stopped exactly half way through the run then the amount of data in trace memory would equal 1M.

To run the analyzer in single mode

1. From the menu bar select **Run/Stop>Run**, or click the  icon from the run/stop toolbar.

To run the analyzer in repetitive run mode

1. From the menu bar select **Run/Stop>Run Repetitive**, or click the  icon from the run/stop toolbar.

To stop the analyzer

1. From the menu bar select **Run/Stop>Stop**, or click the  icon from the run/stop toolbar.

To print data and screens

To print data and screens

There are three ways to create printed documentation of your measurement.

- Print data

From the logic analyzer's **File>Print** dialog, print the current measurement data in memory from either the listing or waveform display viewer windows. You can print All data, or print just a defined range of Time (waveform) or Samples (listing). Data is printed from smallest time/sample to largest.

- Copy text to clip board

When in the listing display window, you can draw a rectangle in the listing display area, then copy the region. Text is copied to the system clip board. To print the text, you must paste the text into a word processor or excel spreadsheet and print from that application.

- Copy screen to clip board

Use the **Edit>Copy Screen** function to copy a bitmap of the active screen into the system clip board. To print the screen, you must paste the bitmap into a graphics editing program and print from that application.

Note: The first time you access the print dialog, you are asked to install a printer. Follow the directions in the printer install dialogs that appear.

To print data

1. From the menu bar, select **File>Print...**
2. In the "Print What" section, select the desired display viewer window.
3. Click **Options...**, then select the desired bus/signals to print. To select a bus or signal, click on the name in the left pane, then click the right-arrow button to move the selection to the right pane. Click **Ok**.
4. In the "Print range" section, set the desired range using the "from" and "to" values.
5. Click **OK** to print the specified data.

To copy and print text

1. From the listing display area, position the mouse cursor over the upper-left corner of the desired display region.
2. Click and hold the left mouse button, then drag the mouse cursor to the lower-right corner. Release the mouse button. A rectangle is drawn around the defined region (snaps to state lines and bus/signal columns).
3. From the shortcut list that appears, click **Copy Text**.
4. Open a word processor or excel spreadsheet program, paste the text into the program, then print the screen.

To copy and print a screen

1. Click **Edit>Copy Screen**. The currently displayed window is copied into the windows clip board buffer.
2. Paste the contents of the clip board buffer into a graphics editing program of your choice.
3. Print the screen from the graphics program.

See Also

To Install a printer
To connect a LAN

To install a printer

Local and network printers are installed outside of the logic analyzer environment using the Windows printer install wizard.

1. Click **Start>Settings>Printers**.
2. Click on an **existing printer**, or click **Add Printer**.
3. Follow the Windows printer install wizard instructions.

To connect a LAN

Local area networks (LAN) are install outside of the logic analyzer environment using the Windows network configuration wizard.

1. Click **Start>Settings>Network and Dial-up Connections**.
2. Click on an **existing connection**, or click **Make New Connection**.
3. Follow the Windows network install wizard instructions.

Reference

- Product overview
- Front panel operation
- Probing
- Menus
- Toolbars
- Windows and Tabs
- Dialogs
- Marker Display Bar
- Marker Measurement Display Bar
- Config Translator Application
- Specifications and Characteristics
- Error Messages
- Keyboard Commands

Product Overview

Product Overview

The Agilent Technologies 1680/90-series logic analyzers provide a variety of channel widths, memory depths, and state and timing acquisition speeds (see tables below). The 1680A/AD-series comes with a large integrated 12.1-inch color flat panel display which can show up to 22 waveforms on screen simultaneously. The 1690A/AD-series is a PC-hosted model which allows you to carry out your measurement and debug work in your PC environment.

Both model series have the familiar Windows-based user interface which takes the complexity out of making logic analyzer measurements. You can perform all operations directly from one window. See "Intrinsic Support" below.

Agilent's Simple, Quick and Advanced Trigger functions take the complexity out of triggering. Use Simple Trigger's pull down menus to define events in terms of edges and patterns. With Quick Trigger you can see if a suspect event ever reoccurs by just drawing a box around the event in the display. Quick trigger will do the rest! Use Advanced Trigger's drag and drop graphical icons with sentence-like structures to customize complex trigger scenarios.

Table of 1680A/AD-series channel, memory, and speed

Table of 1690A/AD-series channel, memory, and speed

Front Panel Operation

Characteristics

Specifications

Keyboard Commands

Supplied Accessories

1680A/AD-series	1690A/AD-series
PS2 mouse	IEEE 1394 PCI card and cable
Mini keyboard	Laptop IEEE 1394 cable
Front panel cover	Accessory pouch
Accessory pouch	

Optional Accessories

- Rack Mount Kit - Option 1CM
- Additional IEEE 1394 PCI card and cable

Documentation

Quick Start/Installation Guide

The Quick Start/Installation Guide gives you information on how to connect system peripherals and probing. Also included is an overview of the interface and information on installing software upgrades. Use this guide to quickly get familiar with the analyzer and also as a future reference for keeping your analyzer up-to-date and running properly.

Online Help System

The Online Help gives you product reference and feature information. Also included is a tutorial showing you how to make a basic measurement and links to time-saving features and concepts.

Agilent Technologies Web Sites

Corporation/Contact

Corporation - <http://www.agilent.com>

Contact Us - <http://www.agilent.com/find/contactus/>

Notify Me - <http://www.agilent.com/find/notifyme>

Product Information

Logic Analysis - <http://www.agilent.com/find/logicanalyzer/>

1680/90 Analyzer - <http://www.agilent.com/find/digitaldesign/>

Software Updates - <http://www.software.cos.agilent.com/1680-1690>

Documentation

Web-based documentation - <http://www.cos.agilent.com/manuals/>

Intrinsic Support

Because the Agilent 1680A/AD-series products operate in a Microsoft Windows 2000 Professional environment, intrinsic support shall only cover the Agilent Logic Analyzer application. Intrinsic support shall also cover any Windows 2000 Professional operating system services utilized by the Agilent Logic Analyzer application:

- Print from the Agilent Logic Analyzer application.
- Networking.
- File management from the Agilent Logic Analyzer application.

Because the Agilent 1690A/AD-series products operate on a hosted desktop PC, support shall only cover the Agilent Logic Analyzer application and the IEEE 1394 interface to the host PC. Intrinsic support shall not cover any other Windows 2000 Professional operating system issues other than those listed above. Other Windows 2000 Professional issues shall be considered Microsoft issues.

Note: Any customer-installed applications on an Agilent 1680A,AD-series product shall not be supported by Agilent. Customers must contact the software vendor for support.

See Also

Tutorial - Getting to know your logic analyzer

Table of 1680-series channel, memory, and speed

Model	Channel Count and Memory Depth
1680A	136-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1680A/D	136-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1681A	102-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1681A/D	102-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1682A	68-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1682A/D	68-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1683A	34-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1683A/D	34-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep

Table of 1690-series channel, memory, and speed

Model	Channel Width and Memory Depth
1690A	136-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1690A/D	136-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1691A	102-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1691A/D	102-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1692A	68-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1692A/D	68-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep
1693A	34-channel State: 200 MHz, 256 K deep Timing: 400 MHz/800 MHz (full/half channel), 512 K/1 M deep (full/half channel) Transitional timing: 200 MHz, 256K deep
1693A/D	34-channel State: 200 MHz, 1 M deep Timing: 400 MHz/800 MHz (full/half channel), 2 M/4 M deep (full/half channel) Transitional timing: 200 MHz, 1 M deep

Front Panel Operation

The front panel interface consist of knobs and buttons that you use to setup and run measurements. There are also shortcut buttons that quickly access commonly used dialogs in the interface.

All functions available with the front panel knobs and buttons can also be performed in the graphical user interface (GUI). Unlike in the GUI, where you can block access by disabling menus and toolbars, the front panel buttons/knobs cannot be blocked. However, when a front panel action is not valid, an audible "beep" will sound.

Run/Stop



Item	Description
Run Single	Runs a single acquisition. The Run Single button turns green indicating when a Run action is valid. While the analyzer is running, the light goes out.
Run Rep. (Repetitive)	Runs a repetitive acquisition. The Run Repetitive button turns green indicating when a Run Repetitive action is valid. While the analyzer is running, the light goes out.
Stop	Stops the current acquisition. The Stop button turns red during a Run cycle indicating when the Stop action is valid.

Save/Open Setup




Item	Description
Open Setup	Accesses the Open Configuration dialog.
Save Setup	Accesses the Save Configuration dialog.
Default Setup	Resets setup to the default power up configuration.

General purpose knob



The general purpose knob acts on the field that has the current focus. Fields that have the current focus have the blue background. The general purpose knob is typically used to increase/decrease numeric values such as waveform scale and delay.

Alphanumeric Keypad




Item	Description
Enter	Accepts value or configuration change and exits dialog.
Tab	Scrolls configuration fields left-to-right and top-to-bottom.
Backspace (left arrow)	Backspaces cursor in an alphanumeric assignment field.
Esc	In Ok/Cancel dialogs, the escape key acts as a cancel operation and exits the dialog.
Keypad	Used for alphanumeric entry.
Units	Sets unit of measure.

Shortcuts




Item	Description
Setup	Accesses Buses/Signals tab in the Analyzer Setup dialog.
Waveform	Accesses Waveform display window. When the Waveform display is active, the button turns green.
Listing	Accesses Listing display window. When the Listing display is active, the button turns green.
Find	Accesses advanced search dialog.
Trigger	Accesses advanced trigger dialog.
File Mgr	Accesses the Explore file manager dialog.
Print	Accesses the Print dialog.
Help	Accesses the online help system's main window. Same as F1 key.

Vertical



Item	Description
Size	Adjusts height of all waveform rows. The selection lights up green indicating it's part of the waveform group, and that the waveform group is currently active.
Page	Scrolls a page at a time of Listing data. The selection lights up green indicating it's part of the listing group, and that the listing group is currently active.
Scroll	Scrolls row at a time of Waveform data. The selection lights up green indicating it's part of the waveform group, and that the waveform group is currently active.
Line	Scrolls a line at a time of Listing data. The selection lights up green indicating it's part of the listing group, and that the listing group is currently active.

Horizontal



Item	Description
Time/Div	Changes time/division scale of Waveform display. The selection lights up green indicating it's part of the waveform group, and that the waveform group is currently active.
Bus/Sig	Scrolls first column to last column in Listing Display. The selection lights up green indicating it's part of the listing group, and that the listing group is currently active.
Delay	Changes delay of Waveform display. The selection lights up green indicating it's part of the waveform group, and that the waveform group is currently active.

Column	Scrolls a column at a time of Listing data. The selection lights up green indicating it's part of the listing group, and that the listing group is currently active.
--------	--

Marker



Item	Description
Move marker knob	Moves selected marker in the display.
Choose marker button	Selects marker for "Move" operation. Press button to scroll through available markers. If no markers are defined, operating the knob and Choose button will create an M1 marker for you.

For more marker information, refer to "Working with markers".

Probing

The following probing options are available:

- General Purpose Probing (Standard)
- Adapter to board connectors (Optional)
- Analysis probes (Optional)

So far we've talked about some of the differences between scopes, timing and state analyzers. Before we're ready to apply these new tools, we should talk about one more subject – the probing system.

A scope probe is designed to gain easy access to the target system while minimizing the signal distortion. Since we want to look at parametric information like voltage levels and rise times, it is important that the probe doesn't load the circuit under test significantly. A typical scope probe has 1 M ohm impedance shunted by 10 pF, depending on the bandwidth required.


Logic analyzer probes are designed to allow connection of a high number of channels to the target system easily by trading off amplitude accuracy of the signal under test. Remember that a logic analyzer only distinguishes between two voltage levels!

Traditionally, logic analyzers used active probe pods, which had an integrated signal detection circuitry for eight channels integrated. From these pods, we could connect with leads to the circuit under test.

The typical impedance of a logic analyzer probe is in the area of 100 k ohm shunted by 8 pF at the input of the active pod. The connecting wires, however, add another 8 pF stray capacitance, giving a total of 16 pF per channel.


General Purpose Probing

Physical connections to digital systems must be reliable and convenient to deliver accurate data to the logic analyzer with minimum intrusion to the target system. The standard general purpose probing solution shown below is shipped with the logic analyzer. Each channel is terminated at both ends with 100k ohm and 8 pF.



The standard set plugs directly into any .1-inch grid with 0.026 to 0.033-inch diameter round pins or 0.025-inch square pins. All probe tips work with the Agilent Technologies 5059-4356 surface mount grabbers and the Agilent Technologies 5959-0288 through-hole grabbers.

Adaptor to board connectors



Both the 01650-63203 and the E5346A adapters include termination for the logic analyzer. The 01650-63203 termination adapter plugs into a 2 x 10 pin header with 0.1 inch spacing. The E5346A high-density adapter connects to an AMP "Mictor 38" connector.

Analysis Probes

Connecting a state analyzer to a microprocessor system requires some effort in terms of mechanical connection and clock selection. Remember, we have to clock the state analyzer whenever data or addresses on the bus are valid. With some microprocessors it might be necessary to use external circuitry to decode several signals to derive the clock for the state analyzer.

Analysis probes (formerly called preprocessors) are microprocessor-specific interfaces that make it easier to probe buses. Generally, analysis probes consist of a circuit board that attaches to the microprocessor (possibly through an adapter) and a configuration file. The configuration file sets up the logic analyzer's clocks, buses, and signals correctly, and may include an inverse assembler. The circuit board provides access to logical groups of pins through headers designed to connect directly to the logic analyzer.

Self Tests

The Self Test menu checks the major hardware functions of the analyzer to verify that the analyzer is working correctly. A description of each test is found below.

If after completing the self tests you have failures, or you have questions about the performance of the logic analyzer, contact Agilent Technologies sales or support at <http://www.agilent.com/find/contactus>.

For more contact information, refer to Product overview.

To access self test menu

1. From the menu bar select **Help>Self Test>Analyzer Self Test**.
2. The first time the self test menu is accessed, a warning message comes up, "Running self tests will invalidate acquired data." Select **OK** to bring up the menu.
3. Select either a single test or to run all tests. As the test is running, test progress is reported in the lower part of the dialog.

Self test descriptions

Register Test

Memory Test

Comparator Test

Trigger Bus Test

Trigger Arm Test

Clock Paths Test

Memory Modes Test

Calibration Test

Register Test

The Register Test verifies that the registers of each acquisition IC are operating properly. Test patterns are written to each register on each acquisition IC, read, and compared with known values. The registers are reset, and verified that each register has been initialized. Test patterns are then written to ensure the chip address lines are not shorted or opened. Finally test data is written to registers of individual acquisition ICs to ensure each acquisition IC can be selected independently.

Passing the Register Test implies that the acquisition IC registers can store acquisition control data to properly manage the operating of each IC.

Memory Test

The Memory Test verifies that each bit in the acquisition memory IC can be written with a logic "0" and logic "1" through the Serial Access Memory port. Test data is generated using a shifting test register in the acquisition ICs. The serialized test patterns are then sent to the memory port of each acquisition memory IC and stored. The data in the acquisition memory ICs are then downloaded and compared with known values.

Passing the Memory Test implies the acquisition memory can store data written through the memory port. This test along with the Memory Modes Test provides complete testing of the memory ICs.

Comparator Test

The Comparator Test ensures the data signal comparators in the module front end can be set to their maximum and minimum thresholds and that they recognize activity at the signal inputs. A clock signal is routed to a test port on each comparator. The threshold is

then set to the minimum value. The comparator output is then read and compared with a known value. The threshold is then set to a maximum value. The comparator output is again read and compared with a known value.

Passing the Comparators Test implies that the front-end comparators are operating properly, can recognize both a logic "0" and logic "1", and can properly send the acquisition data downstream to the acquisition ICs.

Trigger Bus Test

The Trigger Bus Test verifies the trigger resource lines that run between each acquisition IC. The test ensures that the trigger resource lines can be both driven as outputs and read as inputs. The resource registers are written with test patterns, read back, then compared with known values. The resource registers are then written with test patterns, read back from a different acquisition IC, then compared with known values.

Trigger Arm Test

The Trigger Arm Test verifies that the local arm signal can be received by the master acquisition IC on the acquisition board. The test also verifies the global arm signal can be driven by each acquisition IC on a master board and received by all acquisition ICs on the card. The arm lines are asserted and read at the acquisition ICs to ensure each acquisition IC recognizes the signal.

Passing the Trigger Arm Test implies any acquisition IC can arm the card and that all acquisition ICs can recognize the arm signal.

Clock Paths Test

The Clock Paths Test verifies that the system Master, Slave, and Psync clocks are functional between the acquisition ICs. The module is configured to take a simple measurement. Test data is then created at the comparators and an acquisition taken. The resulting data is then downloaded and compared with known values.

Passing the Clock Paths Test implies that all acquisition IC clock lines can be driven by each acquisition IC and can be received by each acquisition IC in the module. Consequently each acquisition IC can reliably acquire data in response to the acquisition clock signal

Memory Modes Test

The Memory Modes Test verifies the CPU interface can properly manage the acquisition memory unload in full-channel, half-channel, count only, and interleaved modes. Test data is written to acquisition memory. Different unload modes are selected, then the data is read and compared with known values.

Passing the Memory Modes Test implies that the data can be reliably read from acquisition memory in full-channel, half-channel, count only, and interleaved mode. This test along with the Memory Test provides complete testing of acquisition memory downloading through the 1394 interface.

Calibration Test

The Calibration Test ensures that each acquisition IC in the module can perform an operational accuracy self-calibration. Various self-calibration routines are initiated. The results of each self-calibration routine are then checked to see if the self-calibration was successful or not.

Passing the Calibration Test implies that the module can reliably perform an operational accuracy self-calibration. Consequently the incoming data path is optimized to reduce channel-to-channel skew so the acquisition ICs can reliably capture the incoming data.

Menus

Menus

File Menu

Edit Menu

View Menu

Setup Menu

Tools Menu


Markers Menu

Run/Stop Menu

Window Menu


Help Menu

File Menu



New	Creates a new logic analyzer configuration file.
Open	Opens a previously saved logic analyzer configuration file. Secondary display windows are not restored.
Close	Closes the active window after asking whether to save its data.
Save	Saves changes to the currently open configuration file.
Save As	Saves the currently open configuration file to a new name.
Print	Prints displayed data within a defined range.
Export	Exports data in a defined range.
Import	Imports a defined file.
Recent Configuration Files	Lists recently opened files for quick reference or access.
Exit	Closes the logic analyzer user interface window.


Edit Menu



Undo	Undo the last user action. This includes any properties that have changed such as column color, column width, column move, column insert, column delete, etc. Items that cannot be undone include scrolling, acquisition runs and simple trigger modifications.
Cut	Cuts the selection from alphanumeric fields in listing and waveform windows. Alphanumeric fields in lower level modal dialogs are cut using keyboard commands (accelerator keys). Cut selections are pasted to the clipboard.
Copy	Copies the selection from alphanumeric fields in listing and waveform windows. Alphanumeric fields in lower level modal dialogs are copied using keyboard commands (accelerator keys). Copied selections are pasted to the clipboard.
Copy Screen	Copies the current screen to a bitmap and places it on the system clip board.
Paste	Pastes the cut or copied data that is stored in the clipboard into the alphanumeric field. Alphanumeric data is pasted into fields in lower level modal dialogs using keyboard commands (accelerator keys).
Insert Bus/Signal Into Window	Inserts a predefined bus or signal into the display.
Remove Bus/Signal	Deletes the highlighted bus or signal from the display window.

From Window	
Window Properties	Accesses the window properties dialog.
Symbols	Accesses the Symbols dialog.
Find	Locates specific data in the acquisition.
Find Previous	Locates the previous occurrence of the specified data.
Find Next	Locates the next occurrence of the specified data.
Go To beginning	Places the beginning of the captured data trace at center screen.
Go To Trigger	Places the trigger point at center screen.
Go To End	Places the end of the captured data trace at center screen.
Go To	Accesses the Go To selection list.
Options	Accesses the System Options dialog.

View Menu



Zoom Out

Zoom In

Toolbars

Full Screen

Tabbed Windows

Status Bar

Zooms out on an active window.

Zooms in on an active window.


Access the Toolbar dialog window.

Enables or disables full screen display.

Enables or disables Listing and Waveform tabs.

Enables or disables the status bar.

Setup Menu



Bus/Signal

Timing/State (Sampling)

Simple Trigger

Advanced Trigger

Store Trigger

Recall Trigger

Symbols

Accesses the Bus/Signal setup dialog.

Accesses the Sampling setup dialog.

See "Simple Trigger".


Accesses the Advanced Trigger dialog.

Stores current trigger.

Accesses a list of most recently used triggers.

Accesses the Symbols dialog.

Tools Menu



All add-in tools are grouped under the tools menu. Your Agilent Logic Analyzer comes with a filter/colorize tool built in. If you are using inverse assemblers, bus analysis tools, or other third-party tools, the tools will show up in the Tools menu under New.

As tools are created, they are added to the top of the Tools menu. The menu above shows one active tool.

1 *tool name*

New

Overview

Find

Edit an existing tool.

Creates a new analysis tool.

Lets you manage the active tools.

Locates specific data in the acquisition.

See Also


To add a new tool

To change a tool

To delete a tool

To filter or colorize data

Markers Menu



New

Place on Screen

Go To

Center About

Delete

New Interval Measurement

New Value At Measurement

Hide Measurements List

Properties

Creates a new marker.

Places a selected marker on screen over the trigger point.

Goes to a selected marker.

Centers the display around a selected marker.

Deletes selected markers.


Creates a new interval measurement.

Creates a new value at measurement.

Hides the marker measurement display bar.

Accesses the markers properties dialog

Run/Stop Menu



Run

Starts sampling, fills logic analyzer memory with samples around the trigger, and stops.

Run Repetitive

Starts sampling, fills logic analyzer memory with samples around the trigger, and repeats.

Stop

Stops a logic analyzer measurement that is in progress.


Cancel

Cancels the current Run.

Resume

Resumes the current Run after a Cancel.

Window Menu



New Listing

New Waveform

Rename

Properties

Close

Next

Previous

Cascade

Tile Horizontally

Tile Vertically

Arrange Icons

1.

2.

Creates an additional listing window.

Creates an additional waveform window.

Allows the user to change the active window name.

Accesses the display properties dialog.

Closes the active window.

Displays the next window.

Displays the previous window.

Displays all opened windows in an overlaid and offset format.


Displays all opened windows so the horizontal display space is equally divided.

Displays all opened windows so the vertical display space is equally divided.

All minimized listing and waveform windows are arranged at the bottom of the analyzer window.

Lists all open display windows for reference or access.

Help Menu



Help Topics

Help On Viewers

Help On AddIns

Self Test

Status Log

About

Accesses the online help.

Opens online help for either the Listing or Waveform window.

Opens online help for AddIns.

Accesses the Logic Analyzer Self-Tests dialog.

Accesses the Info Manager dialog.

Displays product version and copyright information.

Toolbars

Toolbars

Toolbars are located under the menu bar, and are used to quickly access a function or perform a task. By default, not all toolbars, or individual tools within a given toolbar are displayed. For a complete list of all available toolbars, click **View>Toolbars>**. For a complete list of all tools within a given toolbar, click **View>Toolbars>Customize>Commands.**

Standard

Setup

Markers














Run/Stop

Viewers







Customize

Standard Toolbar



-  New - Creates a new logic analyzer configuration file.
-  Open - Opens a previously saved logic analyzer configuration file. Secondary display windows are not restored.
-  Save - Saves changes to the currently open configuration file.
-  Print - Prints displayed data within a defined range.
-  Find - Locates specific data in the acquisition.
-  Find Previous - Locates the previous occurrence of the specified data.
-  Find Next - Locates the next occurrence of the specified data.
-  Go to Beginning - Centers the beginning of the acquisition data.
-  Go to Trigger - Centers the trigger point of the acquisition.
-  Go to End - Centers the end of the acquisition data.
-  Zoom Out - Zooms in on an active window.
-  Zoom In - Zooms out on an active window.
-  Tools Overview - Shows an overview of the current Tools.

Note: The following are optional standard toolbar icons.

-  Cuts the selection and places it on the clipboard.
-  Copies the selection and places it on the clipboard.
-  Pastes the data that is stored on the clipboard.
-  Provides information about the Agilent 16xx Product.
-  Undo last user action.
-  Enables or disables full screen display.



Activate the next window.



Activates the previous window.



Arranges windows as overlapping tiles.



Arranges windows as non-overlapping horizontal tiles.




Arranges windows as non-overlapping vertical tiles.

See Also

To create a custom toolbar

Setup Toolbar



Bus/Signal - Accesses the Bus/Signal setup dialog.



Timing/State (Sampling) - Accesses the Sampling setup dialog.



Advanced Trigger - Accesses the Advanced Trigger dialog.

See Also

To create a custom toolbar

Markers Toolbar



New - Creates a new marker.



Go To - Centers the display around the selected marker.



Creates a new interval measurement.



Creates a new value at a measurement.

Note: The following are optional markers toolbar icons.



Place Maker - Places the selected marker on the screen.



Center About - Centers the display around two selected markers.



Turns the marker measurement list on and off.



Accesses the markers properties dialog.

See Also

To create a custom toolbar

Run/Stop Toolbar



Starts sampling, fills logic analyzer memory with samples.



Starts Sampling, fills logic analyzer memory with samples around the trigger, and repeats.



Stops a logic analyzer measurement in progress, for example, when the trigger condition is not found.



Stops the current action.




Resumes the cancelled action.

See Also

To create a custom toolbar

Viewers Toolbar



Creates a new listing viewer.



Creates a new waveform viewer.

See Also

To create a custom toolbar

To create a custom toolbar

To add tool icons

1. From the menu bar, select **View>Toolbars**.
2. Click **Customize**, then select the **Commands** tab.
3. Select the toolbar you wish to customize.
4. Drag the desired icon to the correct position on the selected toolbar. Release the mouse button to insert the tool icon.
5. Repeat for any other icons you wish to add.
6. Select **OK**.

To remove tool icons

1. From the menu bar, select **View>Toolbars**.
2. Click **Customize**, then select the **Commands** tab.
3. Select the toolbar you wish to customize.
4. Drag the icon from the toolbar and drop it onto the **Customize** dialog box.
5. Repeat for any other icons you wish to remove.
6. Select **OK**.

Windows

Windows

Listing Display Window
Waveform Display Window

See Also
Viewers Toolbar


Dialogs

Dialogs

- Buses/Signals Setup
- Sampling Setup
- Printing Data
- Advanced Trigger
- Exporting Files
- Importing Files
- System Options
- Recall Trigger
- Waveform Window Properties
- Listing Window Properties
- Markers Properties
- Symbol Selection
- Symbols
- Filter/Colorize
- Tool Overview

Analyzer Setup Dialog

Analyzer Setup Dialog



The Analyzer Setup dialog is accessed through the menu bar's **Setup>Bus/Signal**.

The dialog consists of the following two tabs.


Buses/Signal

The Buses/Signals tab is used to map bus and signal names in the interface to the pod and channel connections of the probes. Also, you can set a pod threshold, and assign a numeric base and polarity to the bus or signal.

Sampling

The Sampling tab is used to name the analyzer, and select and configure the acquisition mode. In the Timing Acquisition Mode, you set the channel width and sampling rate. In the State Acquisition Mode you configure the state clocks and qualifiers.

System Options Dialog



To change your system options, select **Edit>Options** from the menu bar. System options are written in the Windows registry file and persist across sessions.

To change how many triggers are saved

Set the **Trigger History Depth**. You can keep as many as 50 of the most recently used triggers. See [To store a trigger for more information on re-using triggers](#). Trigger history is saved in the configuration files. The default is 10.

To change the length of the file history

Set the **Recent File List Size**. This sets how many recently-loaded configuration files are shown in the **File** menu. The default is 4.

To create data when offline

Check the **Create Data When Offline** box. When you run the analyzer, fake data will be created. This mode is useful when learning how to use the logic analyzer software.

Note: The logic analyzer does not trigger with fake data. You can set the triggers, but will not get the same results you would with a real acquisition.

To set Trigger In and Trigger Out

Trigger In allows you to trigger the logic analyzer from another source. It expects to see a TTL signal, not to exceed 5.5 volts, with a minimum signal amplitude of 500 mV.

Trigger Out sends a signal to another device when the logic analyzer triggers. Low is 0 volts, high is 3.3 volts.


To set message level

As with any other program, the Agilent Logic Analyzer generates messages about events. You can choose which messages are displayed. Check the appropriate box to indicate you wish the dialogs displayed.

Show Information Dialogs	Information dialogs offer tips such as the location of Simple Trigger, and do not indicate a failure.
Show Warning Dialogs	Warning dialogs occur when some setting may affect your data, such as being offline.
Show Error Dialogs	Error dialogs occur when an operation cannot be completed as specified.
Event Logging	You can choose to have all events recorded in a log file. Event logging will slow down your logic analyzer. Event logs can be viewed through Help>Status Log . Set the event logging level according to the directions of your Agilent Technologies support person. Be sure to turn off event logging when resuming normal use.

Properties Dialog

Properties Dialog



The Properties dialog is accessed through the menu bar's **Window>Properties**. Use it to setup how the window and the displayed data appear.

To set waveform window properties

To set waveform display properties


To set listing window properties

To set listing column properties

To set marker properties

Symbol Selection

Use the Select Symbol dialog to choose a symbol to use when the numeric base is set to Symbols.



To choose a symbol:

1. Look for the bus for which the symbol is defined.
2. Select the symbol.

If the symbol you want is not listed, you can:

- Check that you are looking at the right bus, or
- Load a configuration file in which the symbol is defined. or
- Add the symbol.

The Select Symbol dialog is used whenever you need to choose a symbol. For example, the Select Symbol dialog will be displayed when you use the Symbols numeric base in the following dialogs:

- Find
- Filter/Colorize
- Simple Trigger
- Advanced Trigger Dialog

Specifications and Characteristics

Specifications and Characteristics

Describes the specifications, characteristics, and requirements of the 1680A/AD-series and 1690A/AD-series logic analyzers.

- 1680A-Series Logic Analyzer Specifications
- 1680A-Series Logic Analyzer Characteristics
- 1690A-Series Logic Analyzer Specifications
- 1690A-Series Logic Analyzer Characteristics
- About the Probe Cable
- Signal Requirements

See Also

- What is a Specification
- What is a Characteristic

1680/1690-Series Logic Analyzer Characteristics

- General Information
- Probes
- State Analysis
- Timing Analysis
- Triggering
- Operating Environment Characteristics

General Information

State/timing channels:	34, 68, 102, and 136
Memory depth:	200 MHz State: A model = 256K; AD model = 1M 400 MHz Timing (full channel): A model = 512K; AD model = 2M 800 MHz Timing (half channel): A model = 1M; AD model = 4M 200 MHz Transitional Timing: A model = 256K; AD model = 1M
User interface:	Windows® 2000 Professional
Printers:	Can print to any local or network printer supported by Windows® 2000 Professional.
Dimensions:	1680 - 257 mm height (10.14 in), 443 mm width (17.45 in), 385 mm depth (15.15 in) 1690 - 153 mm height (6.05 in), 438 mm width (17.23 in), 335 mm depth (13.16 in)
Weight:	1680 - 13.2 kg (29.1 lbs) 1690 - 7.5 kg (16.5 lbs)

Probes

Input resistance:	100 kohm \pm 2%
Resistive tip capacitance:	1.5 pF
Minimum input voltage swing:	500 mV peak-to-peak
Maximum input voltage:	\pm 40 V peak

State Analysis

Maximum State Speed	200 MHz
Minimum state clock pulse width:	1.2 ns
Time tag resolution:	4ns or \pm 0.1% (whichever is greater)
Maximum time count between states:	17 seconds
State clock/qualifiers	4 (2 on 34 channel models)

Timing Analysis

Maximum timing sample rate:	400 MHz/800 MHz
Sample period accuracy:	\pm 0.01% of sample period \pm 100 ps
Channel-to-channel skew:	<1.5 ns typical
Timing interval accuracy:	\pm (sample period accuracy + channel-to-channel skew)

	+ 0.01% of time interval reading)
--	-----------------------------------

Triggering

Sequencer speed:	200 MHz
Occurrence counters:	1 per sequence level
Trigger sequence levels:	16

Operating Environment Characteristics

Temperature:	Instrument: 5°C to 50°C Disk media: 10°C to 40°C Probe lead sets and cables: 0°C to 65°C
Humidity:	Instrument: Up to 95% relative humidity at 40°C Disc media and hard drive: 8% to 85% relative humidity
Altitude:	4,572 m (15,000 ft) operating 15,300 m (50,000 ft) non-operating

1680/90A-Series Logic Analyzer Specifications

Threshold Accuracy	$\pm(65 \text{ mV} + 1.5 \% \text{ of setting})$
Minimum Master-to-Master Clock Time	5.0 ns
Setup/Hold Time (Single Clock, Single Edge)	2.5 ns window adjustable from 4.5/-2.0 ns to -2.0/4.5 ns in 100 ps increments per channel
Setup/Hold Time (Multiple Clock, Multiple Edge)	3.0 ns window adjustable from 5.0/-2.0 ns to -1.5/4.5 ns in 100 ps increments per channel

About the Probe Cable

The probe cable contains 16 signal lines, 1 clock line, 20 ground lines, 1 serial line for communication with analysis probes, and 2 lines that carry minimal power for demo "device under test" systems.

The cable ground lines are chassis (earth) grounds and not "floating" grounds. All the lines are woven into a flat ribbon that is 4.5 feet long. See Probing in the *Quick Start/Installation Guide* for the cable pinout and equivalent load.

Caution: Do not exceed 0.33 amps per cable, or the cable will be damaged.

Signal Requirements


- Minimum Signal Amplitude
- Signal Loading
- Maximum Probe Input Voltage
- Overdrive

Minimum Signal Amplitude

Any signal line you intend to probe with the logic analyzer probes must supply a minimum voltage swing of 500 mV to the probe tip. If you measure signal lines with a smaller voltage swing, you may not get reliable results. The minimum input overdrive is the greater of 250 mV or 30% of signal amplitude.

Signal Loading

Any probed signal line must be able to handle the following load:



If the signal cannot handle this load, the target system may malfunction.


Maximum Probe Input Voltage

The maximum probe input voltage of each logic analyzer probe is 40 volts peak.

Overdrive

Overdrive is the amount a signal must exceed the threshold voltage for the logic analyzer to detect a change in logic level. For the 1680-series logic analyzer, overdrive is 250 mV or 30% of signal peak-to-peak amplitude, whichever is greater.

For example, given a 3.3 volt CMOS signal (low = 0V, high = 3.3 V) the optimal threshold is 1.65 V (50%). If the threshold is set less than 1.0 V or greater than 2.3 V, then a timing acquisition might show excessive channel-to-channel skew. For a state acquisition, the analyzer's setup and hold requirements might not be met.



The overdrive amount is specified as the greater of 250 mV or 30% of the signal

amplitude because it has two purposes. The 250 mV ensures reliable switching or state detection. The 30% of amplitude ensures the threshold is reasonably centered within the waveform in order to minimize channel-to-channel skew (t_{PHL} vs t_{PLH}).

What is a Specification?

A specification is a numeric value, or range of values, that bounds the performance of a product parameter. The product warranty covers the performance of parameters described by specifications. Products shipped from the factory meet all specifications. Additionally, products sent to Agilent Customer Service Centers for calibration, and returned, meet all specifications. Specifications are verified by calibration procedures.

What is a Calibration Procedure?

Calibration procedures verify that products or systems operate within the specifications. Parameters covered by specifications have a corresponding calibration procedure. Calibration procedures include both performance tests and system verification procedure. Calibration procedures are traceable and must specify adequate calibration standards. Calibration procedures verify products meet the specifications by comparing measured parameters against a pass-fail limit. The pass-fail limit is the specification less any required guardband.

The term "calibration" refers to the process of measuring parameters and referencing the measurement to a calibration standard rather than the process of adjusting products for optimal performance.

Note: Self-tests are not a substitute for calibration.

See Also

What is a Characteristic

What is a Characteristic?

Characteristics describe product performance that is useful in the application of the product, but that is not covered by the product warranty. Characteristics describe performance that is typical of the majority of a given product, but not subject to the same rigor associated with specifications. Characteristics are verified by *function tests*.


What is a Function Test?

Function tests are quick tests designed to verify basic operation of a product. Function tests include operator's checks and operation verification procedures. An operator's check is normally a fast test used to verify basic operation of a product. An operation verification procedure verifies some, but not all, specifications, and often at a lower confidence level than a calibration procedure.

See Also

What is a Specification

Markers Display Bar



To access these tasks, right-click anywhere in the marker display bar.

New - To create new markers.

Place - To place markers in data.

Go To - Go To a marker.

Center About - To center the display about a marker.

Delete - To delete a marker.

Delete All - To delete all markers.

Rename - To rename a marker

Send to back - To send a marker to the back

Properties - To set marker properties.

See Also


Reading off-screen markers

Markers menu

Markers toolbar

Marker Measurement Display Bar

Marker "interval" and "value at" measurements are displayed below the menu bar with the other toolbars.



- To create a new interval measurement
- To create a new value at measurement
- To hide/show measurement display bar


Config Translator Application



Config Translator is a helper application for the Agilent Logic Analyzer. In the first release, shipped with your logic analyzer, it only translates 1670G-series Logic Analyzer configuration files. You can download updates along with updated logic analyzer software at our website, http://software.cos.agilent.com/1680_1690/.

To run Config Translator, select the Agilent Logic Analyzer menu from the Windows2000 Start bar. Config Translator can be run without any logic analyzer hardware.

To convert a configuration file



1. Open Config Translator by selecting **Start>Programs>Agilent Logic Analyzer>Agilent 167xG Config Translator**.
2. Type in the name of the configuration file you want to convert. Use the ... button to browse if you are unsure of the name.

Note: 167xG configuration files end in `._A`, but this suffix is also used by other models. If possible, confirm that it has a file type of `167xdn_config` when viewed on a 1670-series logic analyzer.

Only setup information is translated, not saved data.

3. Type in the name you want to save the new configuration files under.
 1. Because the 1670-series logic analyzers split resources between two measurement engines by default, two output files are created. The default filename is the same as the 167xG configuration file, but has `1.txt` or `2.txt` appended. Both files are created even if the configuration only used one of the measurement engines.
 2. Files are saved in the same directory as the input file unless otherwise specified.
 3. The output files are in XML format, and can be imported like other XML files.
 4. Select **Convert**.

Information not converted from file

- In timing acquisition mode, the sampling period and sampling option.
- In state acquisition mode, the clock mode and clock description.
- All data.
- Any tool information.
- Interface layout.
- Marker information.

See Also

XML Format
To import files

Error Messages

To locate the error you received, use ctrl+F and search for a key word.

Error messages

Warning messages

Informational messages

Error messages

Acquisition errors

An acquisition error has occurred due to state clock edges occurring too close together. This could be the result of:

- **Poor state clock quality (signal integrity).**
- **Inadequate probe grounding (try multiple grounds around clock signals).**
- **State clock edges spaced closer than specifications allow.**
- **Multiple clocks selected and spaced closer than specifications allow.**

When in the state acquisition mode, the logic analyzer requires a clear clock signal no faster than 200 MHz (edges at least 2.5 ns apart). Poor state clock quality may be caused by loading on the target system. It may also be caused by a clock setup in the Sampling Menu that is a combination of several signals which combined together violate the clock specification. When your clock setup uses multiple edges, the analyzer cannot sample faster than 3.0 ns. When you are using a clock speed near the specification, grounding every second or third probe connection is recommended.

Bus/Signal errors

Maximum of 128 channels per Bus.

The logic analyzer cannot handle buses that contain more than 128 channels (signals). If you require wider buses, try breaking the bus into two or more buses, for example Data_HI and Data_LO.

Cannot group into Bus. Maximum of 128 channels per Bus.

The logic analyzer cannot handle buses that contain more than 128 channels (signals). If you require wider buses, try breaking the bus into two or more buses, for example Data_HI and Data_LO.

The following Bus/Signals are required to have a specific number of assigned channels because they are locked.

Please correct the following Bus/Signals: *name* (has *num1* channels, requires *num2* channels)

Some tools may "lock" buses and signals that are necessary to produce their output. The locked buses and signals may have their specific channel assignments changed, but the total number of channels on each bus or signal must stay the same. Please change the channel assignment for each indicated bus or signal so that the width is *num2*. This message sometimes appears in combination with the next one. In these cases, you may have changed a configuration to use half the pods for sampling. Check the sampling tab.

Every Bus/Signal requires at least one assigned channel.

Please assign channels to the following Bus/Signals:

Every bus or signal requires at least one channel. If you do not see the Bus/Signal

named in the error dialog, try scrolling the Bus/Signal listing. Certain tools may also have created buses or signals within folders. If you are trying to avoid showing extra information on the viewer, delete the row or column the bus or signal is in. This removes the information from the viewer without losing the bus/signal setup information. This message sometimes appears in combination with the previous one. In these cases, you may have changed a configuration to use half the pods for sampling. Check the sampling tab.

Minimum of one Bus/Signal with assigned channels required. Please add a Bus/Signal.

The bus/signal setup cannot be closed because you have deleted all buses and signals. Folders only contain buses and signals, but do not represent data mappings of themselves. In order to close the dialog, select **Add Bus/Signal**. Assign at least one channel to the new bus or signal. Alternatively, you can select **Cancel** and revert to the previous bus and signal assignments.

name* is locked and cannot be deleted because it is required by another tool in the application. In order to unlock it, the following tools must be deleted: *tool

Some tools may "lock" buses and signals that are necessary to produce their output. Until the tool is deleted via **Tools>Overview**, you cannot delete or rename the bus or signal.

name* is locked and cannot be renamed because it is required by another tool in the application. In order to unlock it, the following tools must be deleted: *tool

Some tools may "lock" buses and signals that are necessary to produce their output. Until the tool is deleted via **Tools>Overview**, you cannot delete or rename the bus or signal.

Cannot change pod selection while there are locked Bus/Signals.

Some tools may "lock" buses and signals that are necessary to produce their output. Until the tool is deleted via **Tools>Overview**, you cannot modify the bus or signal by changing the pod in use.

Cannot delete *folder* because it contains one or more locked children.

Some tools may "lock" buses and signals that are necessary to produce their output. The folder you have tried to delete contains a unique copy of at least one locked bus or signal. You can move the locked buses or signals outside the folder, and then delete the folder. Alternatively, you can delete the tool locking the buses or signals via **Tools>Overview**, and then delete the folder.

Unable to set setup and hold times for this Bus/Signal since no channels have been assigned. Please assign channels before using setup and hold.

The possible valid range of setup and hold values depends on the clock setup used by the pods that the channels are attached to. Without knowing which pods' channels are part of the bus or signal, it is impossible for the logic analyzer to set appropriate ranges. Please assign channels to the bus or signal, and then set setup and hold.

Please enter a user threshold value.

All pods will be set to the same threshold value. If you select OK without setting a value, the current threshold values (at least one of which is different from the rest) are retained.

Please check the dialog and be sure all fields are filled in.

Please enter a threshold value.

All pods will be set to the same threshold value. If you select OK without setting a value, the current threshold values (at least one of which is different from the rest) are retained. Please check the dialog and be sure all fields are filled in.

File errors

Error trying to remove file: "*directory/hardware_log.txt*".

When the logic analyzer is started up, it replaces the old hardware_log.txt file. For some reason, this time the old hardware log was not able to be deleted. This could indicate a problem with the disk that the file is stored on.

File "*filename*" could not be opened.

When the logic analyzer is started up, it creates a new hardware_log.txt file. For some reason, this time the log was not able to be opened after creation. This could indicate a file system or disk problem.

Hardware errors

Analyzer Calibration Failed [*time*] - Instrument may need service

The logic analyzer's pre-measurement calibration failed. Any data collected after receiving this error message is possibly incorrect. If the failure is transient, cycling power may fix the problem. If the failure is persistent, run **Help>Self-test>Analyzer self-test** or call your Agilent Sales Office to arrange for service.

High speed system clock failure - Instrument may need service. Sleep Duration and Count: *duration, counted*

The internal 100 MHz clock did not pass initialization tests. Any measurements are likely to be faulty. Please contact Agilent Technologies sales or support at <http://www.agilent.com/find/contactus> for information on getting the instrument repaired.

Contact with the analyzer hardware has been lost. This application will be terminated. You will have an opportunity to save your configuration.

[1690A-series analyzers only] Something has interrupted the IEEE-1394 connection between the computer and the logic analyzer. Save your current work in a configuration (*.ala) file, then check the power to the logic analyzer hardware and the connections. A lost connection cannot be resumed; you will need to re-start the logic analyzer application.

I/O Channel Error: Invalid Request Argument.

[1690A-series analyzers only] There is a problem with the data being sent via the IEEE-1394 connection.

I/O Channel Error: Offset Out of Bounds.

[1690A-series analyzers only] There is a problem with the data being sent via the IEEE-1394 connection.

I/O Channel Error: Timeout.

[1690A-series analyzers only] There is a problem with the data being sent via the IEEE-1394 connection.

I/O Channel Error: System I/O Error.

[1690A-series analyzers only] There is a problem with the data being sent via the IEEE-1394 connection.

I/O Channel Error.

[1690A-series analyzers only] There is an unspecified problem with the data being sent via the IEEE-1394 connection.

Help file errors

Help file information was not found in the registry. You may need to reinstall the tool.

The logic analyzer could not find a registry entry for the help file associated with the tool. If you have done a custom installation of the tool, you must also install the help file to access help. If the problem persists after re-installing, please contact Agilent Technologies sales or support at <http://www.agilent.com/find/contactus> for assistance.

Help file information not found in registry. Cannot display help.

The logic analyzer could not find a registry entry for the help file associated with the tool. If you have done a custom installation of the tool, you must also install the help file to access help. If the problem persists after re-installing, please contact Agilent Technologies sales or support at <http://www.agilent.com/find/contactus> for assistance.

Help file not found. Cannot display help.

The help file was not found where specified by the registry. It may have been deleted or moved. You can search the drive where the logic analyzer software is installed for .chm files, or re-install the tool.

The HTML Help file "*filename*" was not found. You may need to re-install the product.

The help file was not found where specified by the registry. It may have been deleted or moved. You can search the drive where the logic analyzer software is installed for the file, or re-install. To re-install, close the logic analyzer application and run the setup program on the logic analyzer CD.

The HTML Help file "*filename*" was not found. You may need to re-install the tool.

The help file for the tool was not found where specified by the registry. It may have been deleted or moved. You can search the drive where the logic analyzer software is installed for .chm files, or re-install the tool.

Import/Export and Translator errors

Refer to the import files: *file1* and *file2* for more details.

The configuration translator could not complete the translation. An explanation will be listed in *file1* or *file2* between "<!--" and ">" delimiters.

The specified file is NOT a 167xG Analyzer configuration file: *filename*

The configuration translator was not able to translate the specified file because it was not in an understood format. The configuration translator only translates configuration files generated by 1670G, 1671G, 1672G, and 1673G logic analyzers.

Cannot read configuration file *filename*

The configuration translator was unable to read the configuration file indicated due to an internal error in the configuration file.

Cannot import an empty file. Import terminated.

The file you tried to import has no content.

Invalid non-ascii character read. Import terminated.

The logic analyzer only imports ASCII files. The file you tried to import contains a non-ascii character. You can edit the file in any text editing program, such as Notepad, to remove the character. Be careful to not change header data or the number of samples.

There are one or more locked bus/signals required by tool(s) currently loaded in the application. In order to unlock any of these bus/signals, you must unload every tool listed for that bus/signal. ... Import terminated.

Some tools may "lock" buses and signals that are necessary to produce their output. Until the tool is deleted via **Tools>Overview**, you cannot delete, rename, or modify the bus or signal. A side effect of this is that you cannot import a file that uses different buses and signals, or analyzer channel count.

There were fewer time data samples than indicated by the NumberOfSamples attribute of Module tag. Import terminated.

When you import a saved data file, the logic analyzer verifies that the data is consistent. To fix this error, you can edit the file in any text editing program, such as Notepad.

Syntax error in import file: *error*. Import terminated.

The error description indicates the syntax problem. Most often, it results from mismatched tags. Check the import file for any accidental deletions.

No bus/signals were valid for importing. Import terminated.

The import file was created on a logic analyzer model with more pod pairs than this one, and all the buses and signals were defined on pod pairs this model does not possess. You can attempt to modify the file by changing the assigned channels for the buses and signals. You can use any text editing program (such as Notepad) to edit import files. For more information on the format of import files, see XML Format .

Could not create file for export

The logic analyzer was unable to create the file. Possible reasons include not enough disk space or insufficient permissions to create the file where indicated.

Could not find required *tag1* section contained within *tag2* section

The import file is required to have a section with the heading *tag1* completely contained within the section delimited by *<tag2>* and *</tag2>*. You can repair the import file by adding *<tag1></tag1>* at the beginning of the *tag2* section. You can use any text editing program (such as Notepad) to edit import files. For more information on the format of import files, see XML Format .

Invalid or missing *attribute* attribute in *tag* XML tag

The import file requires the XML tag *tag* to include the keyword *attribute* and a value. For example, if *attribute* is Acquisition and *tag* is Sampling, the file has an XML tag of the form **<Sampling></Sampling>** but requires **<Sampling Acquisition="State"></Sampling>**. You can repair the import file by adding *attribute* to the specified tag and giving it a value. (Try exporting a similar configuration to see standard values.) You can use any text editing program (such as Notepad) to edit import files. For more information on the format of import files, see XML Format .

Invalid attribute value for attribute *attribute* in *tag* XML tag

The import file requires the XML tag *tag* to include the keyword *attribute* and a value. For example, if *attribute* is Acquisition and *tag* is Sampling, the file might have an XML tag of the form **<Sampling Acquisition="Time"></Sampling>** but requires **<Sampling Acquisition="Timing"></Sampling>**. You can repair the import file by editing the value. (Try exporting a similar configuration to see standard values.) You can use any text editing program (such as Notepad) to edit import files. For more information on the format of import files, see XML Format .

Naming errors

To edit channel assignment, click on the pod cells to the right.

This error occurs when you select the Channels Assigned column in Bus/Signal setup. This column is for reference only. To assign channels to a bus or signal, use the grid to the right. For more detail on channel assignment, see To assign channels . To hide the Channels Assigned column, select **Display> Channels Assigned** in the Buses/Signals setup tab.

The object name cannot be an empty string.

When you rename a viewer, tool, or bus, you must give it a name at least one character in length. The blank or empty name you tried was not accepted by the logic analyzer.

Object name must be unique.

You have tried to rename a viewer, tool, or bus, but the name you entered is already being used and so was not accepted by the logic analyzer. You may appear to have identical names on some buses or signals, but these either are truncated or refer to the same bus (aliases).

The name "*toolname*" is already in use. Please choose a different name.

You have tried to rename a tool, but the name you selected is already in use. If you do not rename the tool, it will revert back to its previous name when you close the Tool Overview dialog.

Tool errors

For errors generated by specific inverse assemblers or bus analysis tools, go to the appropriate tool help.

Could not load the component - you may need to reinstall

This error occurs when there is a problem with the tool file. Possible reasons are the tool file was renamed, or permissions changed so that the logic analyzer cannot open it. To reinstall the tool file, close the logic analyzer and run the setup program on the logic analyzer CD.

Could not get license information for component

The logic analyzer attempted to determine if the tool was licensed or freely available, but could not find the information. Try re-installing the tool.

Could not obtain license information for component

This error means the logic analyzer is missing some information it needs in order to check the license. Licenses are created by the lmtools.exe program. You can run this to see what information is missing, and to check licenses.

Could not obtain a license for component

This error occurs when the license is not in the expected directory. When the tool is installed, the license is written into a predefined directory. Moving or deleting the file prevents you from using the component. If you do not believe the license was deleted, check your hard drive for *.lic files.

License for component is invalid

This error means that a license file exists, but that the information in it does not match. Licenses are specific to equipment; you cannot transfer a license for a tool or a logic analyzer between tools or logic analyzers.

Could not create licensed component

There was a valid license for the tool earlier in the install process, but something has gone wrong. Start the tool installation process over again. If this error persists, please contact Agilent Technologies sales or support at <http://www.agilent.com/find/contactus> for assistance.

Could not create component - unknown error

A license for the tool exists in the proper directory, but the internal information is inconsistent. Licenses are specific to equipment; you cannot transfer a license between tools or between logic analyzers. If this is a corrupt license, try reinstalling the tool again.

The stored tool could not be restored from file. The tool may have been uninstalled.

The configuration file you are trying to load includes a licensed tool. The logic analyzer was not able to find this tool, so some information will be missing. All buses and signals that were based on physical data will be loaded; buses and signals created by the tool will not.

The selected tool: *Name* could not be loaded.

The configuration file you are trying to load includes a licensed tool. The logic analyzer was not able to find this tool, so some information will be missing. All buses and signals that were based on physical data will be loaded; buses and signals created by the tool will not.

The selected tool could not be loaded.

The configuration file you are trying to load includes a licensed tool. The logic analyzer was not able to find this tool, so some information will be missing. All buses and signals that were based on physical data will be loaded; buses and signals created by the tool will not.

The tool could not be created - you may need to reinstall the tool.

The configuration file you are trying to load includes a licensed tool. The logic analyzer was not able to find this tool, so some information will be missing. All buses and signals that were based on physical data will be loaded; buses and signals created by the tool will not.

The analysis tool (*toolname*) could not be restored from the configuration file.

The configuration file you are trying to load includes a licensed tool. The logic analyzer was not able to find this tool, so some information will be missing. All buses and signals that were based on physical data will be loaded; buses and signals created by the tool will not.

Trigger Errors

Only one action per timer per branch is allowed.

A branch is the collection of actions after a "Then" in an Advanced Trigger step. Some steps, such as Advanced 2-Way Branch, may have multiple branches. Within a branch, only one of Start from reset, Stop and reset, Pause, or Resume is allowed per timer. For more on timers, see To configure a timer.

Only one action per counter per branch is allowed.

A branch is the collection of actions after a "Then" in an Advanced Trigger step. Some steps, such as Advanced 2-Way Branch, may have multiple branches. Within a branch, you can not both Increment and Reset the same counter. You can increment one and reset the other. For more on counters, see To configure a counter.

Only one store action per branch is allowed.

A branch is the collection of actions after a "Then" in an Advanced Trigger step. Some steps, such as Advanced 2-Way Branch, may have multiple branches. Within a branch, you can set Store sample or Don't store sample but not both in the same branch. If you do not specify any store actions, default storage is used.

Only one reset occurrence counter action per branch is allowed.

A branch is the collection of actions after a "Then" in an Advanced Trigger step. Some steps, such as Advanced 2-Way Branch, may have multiple branches. Within a branch, you can only specify Reset occurrence counter once.

No more edge resources available for this pod pair

The logic analyzer hardware can only handle two edge statements per pod pair in 400 MHz or 800 MHz timing mode, or one edge statement per pod pair in transitions only timing mode. The pod pairs are pod 1 & pod 2, pod 3 & pod 4, pod 5 & pod 6, and pod 7 & pod 8 (some models have fewer pods). If the edges are on different signals, try probing one of the signals with another channel on another pod pair. If all the edges are being used on the same signal, replace the "either edge" terms with "rising edge OR falling edge". See To insert events for how to replace "either edge".

No more pattern resources available for this pod pair

The logic analyzer hardware has a limited number of pattern (bus value) variables per pod pair. The pod pairs are pod 1 & pod 2, pod 3 & pod 4, pod 5 & pod 6, and pod 7 & pod 8 (some models have fewer pods). If the values you are checking for are on different buses, try probing one of the buses with another pod pair.

Branch expression is too complex

The expression in one of the branches of the trigger specification is too complicated for the logic analyzer. The logic analyzer first combines all AND terms and then ORs the expressions together. AND terms that have more than 4 events use twice the resources. Try rewriting the branch expression to use more OR terms, or delete some events.

Trigger Specification is too complex

Although no single branch expression is too complex, the total number of ANDs and ORs has exceeded the logic analyzer's resources. Try simplifying some expressions in some steps, or removing steps altogether.

Replacement failed. Maximum number of sequence levels exceeded.

The logic analyzer translates the trigger you specified into internal sequence levels. Different trigger functions use different numbers of internal sequence levels. Also, the "trigger and fill memory" action requires an additional internal sequence level each time it is used in state acquisition mode. One possible way to simplify the trigger specification is to replace all other "trigger and fill memory" actions with a "goto N" action that points to a "Find anything then trigger and fill memory" step.

Unable to insert level. The maximum number of sequence levels are already allocated.

The logic analyzer translates the trigger you specified into internal sequence levels. Different trigger functions use different numbers of internal sequence levels. Also, the

"trigger and fill memory" action requires an additional internal sequence level each time it is used in state acquisition mode. One possible way to simplify the trigger specification is to replace all other "trigger and fill memory" actions with a "goto N" action that points to a "Find anything then trigger and fill memory" step.

Too many sequence levels.

The logic analyzer translates the trigger you specified into internal sequence levels. Different trigger functions use different numbers of internal sequence levels. Also, the "trigger and fill memory" action requires an additional internal sequence level each time it is used in state acquisition mode. One possible way to simplify the trigger specification is to replace all other "trigger and fill memory" actions with a "goto N" action that points to a "Find anything then trigger and fill memory" step.

Goto action specifies an undefined level.

The last step in the trigger sequence includes the action "Goto next". Because there is no next level, the logic analyzer cannot run and look for a trigger. Select **Setup>Advanced Trigger**, and change the action for the last trigger step.

Counter event specified both true and false in the same product term

In the trigger specification, at least one branch ANDs together "bus equals X" and "bus not equal X". Because this condition can never be true, the logic analyzer will not trigger and does not start the acquisition. If you intend to have it run until you press stop, use the trigger function Run Until User Stop, found under the "Other" tab in advanced trigger.

Cannot use <, <=, >, >= for a bus with clock bits that spans pod pairs

You have defined a bus that both spans pod pairs, and includes a clock bit. The pod pairs are pod 1 & pod 2, pod 3 & pod 4, pod 5 & pod 6, and pod 7 & pod 8. (Some models have fewer pod pairs.) The clock bits are numbered the same as the pod they are located on, and it is possible for them to be the channel that is not on the same pod pair as the others. Check the channel assignment in the bus/signal setup window. The logic analyzer will not run until this problem is corrected.

Cannot specify a range on a bus with clocks bits that spans pod pairs

You have defined a bus that both spans pod pairs, and includes a clock bit. The pod pairs are pod 1 & pod 2, pod 3 & pod 4, pod 5 & pod 6, and pod 7 & pod 8. (Some models have fewer pod pairs.) The clock bits are numbered the same as the pod they are located on, and it is possible for them to be the channel that is not on the same pod pair as the others. Check the channel assignment in the bus/signal setup window. The logic analyzer will not run until this problem is corrected.

Warning Messages

You are currently running "Offline," so running the analyzer is not possible. If you wish to create "fake" data while offline, go to "Edit -> Options" and select "Create Data When Offline". Note: This setting is persistent from session to session.

The logic analyzer is running in offline mode. Offline mode means that the logic analyzer software does not have access to the 1680 or 1690-series hardware. All logic analyzer software loaded onto PCs without a 1690-series logic analyzer is in offline mode. If you have a logic analyzer attached, please check the connection. For more on running with fake data, see System Options Dialog. Fake data is useful when learning how to use the

logic analyzer software.

This module is already being used by another instance of the application. You are now working Offline.

The logic analyzer hardware is attached to an open instance of the logic analyzer software. If you need to acquire data, locate that instance from the Windows taskbar. The online/offline indicator is at the bottom of the application window. In offline mode, the software can still work with saved data.

Event specified both true and false in the same product term

In the Advanced Trigger dialog, one of the branches for one of the steps checks that an event is both true and not true. An event may be a bus or signal equal to a value, a timer expiring, or a count exceeding some value. Because of the AND combination, the branch cannot be true. You may want to modify the trigger to use either an OR combination of the events, or separate them into different branches or steps. For more on constructing complex triggers, see [To build a trigger sequence](#). For more on how to interpret the trigger sequence, see [How to read event and action statements](#).

Timer n value checked as an event, but no start action specified.

In the Advanced Trigger dialog, the trigger sequence checks the value of a timer that was never started. Timers need to be explicitly started in a previous trigger step. See [To configure a timer for more information](#).

Counter n value checked as an event, but no increment action specified.

In the Advanced Trigger dialog, the trigger sequence checks the value of a counter that is never incremented. Counters need to be incremented in the action statements of a trigger step. See [To configure a counter for more information](#).

The Bus/Signals listed below could not be loaded from the configuration file. Please recheck your Trigger since it may have changed.

The configuration file you just loaded was created on a logic analyzer with more pods than this model. Because of this, some buses and signals which rely on the additional pods could not be loaded. If these buses or signals were used in the trigger sequence, the trigger sequence will have changed. You may be able to work around this by assigning different channels to the affected buses and signals, and re-creating the trigger sequence.

Slow or missing clock in Trigger Step n ...

The logic analyzer is not able to detect the state clock, and is therefore unable to take samples and evaluate the trigger sequence. If your target system's clock is bursty, this may be expected behavior. If it is not, please check all probing connections. To verify the clock signal is being received, you can assign the clock channels to a bus in timing acquisition mode and acquire data.

Informational messages

Filling memory after trigger...

The logic analyzer has triggered and is filling memory. Due to either a slow clock or storage qualification in state acquisition mode, or infrequent transitions in transitions-only timing acquisition mode, the logic analyzer is taking enough time to fill memory that this message is showing.

Trigger inhibited during prestore...

The logic analyzer is in timing acquisition mode. In timing acquisition mode, the logic analyzer fills the designated amount of memory before searching for the trigger. If this message is showing, the logic analyzer is filling memory and has not yet begun to compare data to the trigger sequence. To capture triggers that happen during the beginning of a target system's boot sequence, be sure to set the trigger position in the Sampling tab to 100% poststore.

Waiting in Trigger Step n

The logic analyzer is waiting for a sample that matches the events defined in step n of the trigger sequence. Sometimes the event is rare, causing long waits. If you feel that the logic analyzer should have triggered already, check the trigger sequence in Advanced Trigger. For more on triggering, see Advanced Trigger Dialog.

Keyboard Commands

- Access Menus
- File Operations
- Edit Operations
- Search Operations
- View operations
- Run/Stop Operations
- Window Operations
- Help Operations
- Miscellaneous

Access Menus

Alt+F	Access to File menu
Alt+E	Access to Edit menu
Alt+V	Access to View menu
Alt+S	Access to Setup menu
Alt+T	Access to Tools menu
Alt+M	Access to Markers menu
Alt+R	Access to Run/Stop menu
Alt+W	Access to Window menu
Alt+H	Access to Help menu

File Operations

The following operations are located under **File** in the menu bar.

Ctrl+N	File - New
Ctrl+O	File - Open
Ctrl+F4	File - Close
Ctrl+S	File - Save
Ctrl+P	File - Print

Edit Operations

The following operations are located under **Edit** in the menu bar.

Ctrl+Z	Edit - Undo
Ctrl+X	Edit - Cut
Ctrl+C	Edit - Copy
Ctrl+V	Edit - Paste
Alt+I	Edit - Insert Bus/Signal into Window
Alt+P	Edit - Current Window Properties

Search Operations

The following operations are located under **Edit** in the menu bar.

Ctrl+F	Edit - Find
Shift+F3	Edit - Find Previous
F3	Edit - Find Next
Ctrl+B	Edit - Go To Beginning
Ctrl+T	Edit - Go To Trigger
Ctrl+E	Edit - Go To End
Ctrl+G	Edit - Go To

View Operations

The following operations are located under **View** in the menu bar.

Shift+O	View - Zoom Out
Shift+I	View - Zoom In
F9	View - Full Screen
F11	View - Toggle Tabbed Windows
F12	View - Toggle Status Bar

Run/Stop Operations

The following operations are located under **Run/Stop** in the menu bar.

F5	Run/Stop - Run
Ctrl+F5	Run/Stop - Run Repetitive
F8	Run/Stop - Stop
Shift+F8	Run/Stop - Cancel
Shift+Ctrl+F8	Run/Stop - Resume

Window Operations

The following operations are located under **Window** in the menu bar.

Alt+P	Window - Properties
F6	Window - Toggle to Next
Shift+F6	Window - Toggle to Previous

Help Operations

The following operations are located under **Help** in the menu bar.

F1	Help - Help Topics
----	--------------------

Miscellaneous

The following operations are located throughout the interface.

Ctrl+esc	Shows Windows Start bar
----------	-------------------------

Data Formats

ALA Format

The default file format for saving configuration files is ALA. The Agilent Logic Analyzer (ALA) file format is used only in the Agilent 1680 and 1690-series logic analyzers. The ALA format is proprietary; the configuration file is not intended to be read by programs other than the 1680 or 1690 software. The ALA configuration file contains the information necessary to reconstruct the display appearance, instrument settings, and trace data (optional) that were present when the configuration file was created. The configuration file is saved through the file menu. The configuration file is also opened through the file menu.

The following is a general overview of what gets saved in the ALA configuration file.

General

Trigger specifications

Analyzer characteristics

Bus/Signal folders

Bus/Signal information (per bus/signal)

Marker information

Find value

Search event parameters

Symbols

Tools (e.g. inverse assemblers)

Filters

Listing display attributes

Waveform display attributes

General

- configuration File Owner, Project and Description (information as specified in the **File>Save** dialog edit boxes)
- date and time the configuration file was saved
- 16xx software version that saved the configuration file
- size and screen position of the active viewer in the main window
- main window toolbar and menu items
- tools (i.e., measurement, filter and viewer subsystems) that are active
- connection graph of plug-in connectivity

Trigger specifications

- history
- occurrence counter
- storage qualifiers
- timer values
- functions and function libraries and current function state
- external arming events
- named trigger events and event lists

- setup comments

Analyzer characteristics

- analyzer name
- number of pods
- acquisition depth
- state
 - setup and hold specifications
 - clock setup model
 - clock settings (qualifiers and mode)
 - sampling mode
- timing
 - sample period
 - sampling mode
- trigger position
- per-channel threshold settings
- threshold voltages
- setup dialog
 - column widths, column order, column on/off
 - horizontal scroll position
 - vertical scroll position
 - zoom factor
 - selected item
- poststore specification

Bus/Signal folders

- folder name
- expanded or collapsed
- contents

Bus/Signal information (per bus/signal)

- name
- locks
- channel assignments
- number base
- polarity

Marker information

- name
- position
- measurements
- comments
- locked or not
- sample offset
- color
- hidden or not

Find value

- marker name
- from marker ID

Search event parameters

- begin time
- end time
- event label
- event list
- occurrence count

Symbols

- symbol name
- symbol operator
- symbol context
- patterns or range values
- symbol base

Tools (e.g., inverse assemblers)

- name
- menus
- test mode
- internal labels

Note: If the configuration file is loaded into a logic analyzer that does not have a licensed copy of the tool, the tool information is not displayed.

Filters

- filter name
- enabled or disabled
- filter events
- show filter name or not

Listing display attributes

- data area background color
- signal color
- tracker color
- show markers
- show activity indicators
- font size (bus/signal and data)
- column width (minimum and user set widths)

Waveform display attributes

- data begin position
- data end position
- row height

- time per division
- time delay
- color
 - overlay and axis
 - show values
 - waveform magnitude axis
 - soft glitch
- show values
- waveform style (bus or magnitude)
- show soft glitch
- bus order
- expanded
- snap marker to edge
- move marker on screen
- place marker on edge
- show value tool tip
- show transition width tool tip
- show waveform magnitude axis

XML Format

File>Export creates an ASCII text file that stores information using standard XML format (<Tag> body </Tag>). You can edit and create XML files using any text editor, such as Notepad. Each exported file begins with a comment indicating when the file was created, and the keyword <Configuration>. The file is terminated with the keyword </Configuration>.

Example:

```
<!--Exported 03:16PM Jun12,2001-->
<Configuration>
  other sections
</Configuration>
```

The XML tag format allows as many nested sections as required. For logic analyzer data files, the two main sections are <Setup> and <Data>. In the XML file, comments are nested within the <!-- and --> tags, as with HTML. In the examples, explanatory comments are indicated *like this*.

<Setup> section

The <Setup> section contains all configuration information for the logic analyzer and any tools, such as inverse assemblers. Logic analyzer information is contained within the <Module> and </Module> tags. Tool subsections are indicated with <Tool> and </Tool>. Each tool has its own subsection, differentiated by name. The <Setup> section is terminated by the </Setup> keyword.

<Module> subsection

The <Module> subsection is further divided into <Sampling> and one or more <BusSignal> sections. The <Sampling> section denotes how digital data was acquired. <BusSignal> sections list the channels assigned to the particular bus or signal. The words appearing after the keywords are *attributes* (such as Name, or Acquisition) and *values* (such as "Address" and "Timing"). Values always need to be contained in quotes.

Example:

```
comment and <Configuration> up here
<Setup>

<Module Name="200MHz State/800MHz Timing Analyzer 1">

<Sampling Acquisition="Timing" Period="0.000000001250000000000000">
</Sampling>

<BusSignal Name="Address">
<Channels>0,1,2,3,4,5,6,7,8,9,10,11,12,13,14,15</Channels>
</BusSignal>
```

more BusSignal sections

```
</Module>
```

<Tool> subsection

Tool sections give a tool name, and one or more <Label> sections. A label will always have a name and type. Valid types are StringLabel and Integral Label. Filters are not exported.

Example:

<Setup> and <Module></Module> up here

```
<Tool Name="Arm Inverse Assembler 1">
```

```
<Label Name="Arm Cycle information" Type="StringLabel">
</Label>
```

```
<Label Name="Arm Address" Type="IntegralLabel" Width="32">
</Label>
```

more Label sections

```
</Tool>
```

```
</Setup>
```

<Data> section

The <Data> section contains all data for both logic analyzer and any saved tools. It also has <Module> and <Tool> subsections. Each nested section is terminated with a </keyword>.

<Module> subsection

<Module> has the attributes Name, NumberOfSamples, and TriggerIndex. The TriggerIndex indicates which sample was the trigger point; the first sample is counted as 0.

<TimeData> subsection

The <Module> subsection may contain a <TimeData> subsection. The <TimeData> section exists only for non-periodic sampling (i.e. transitional timing mode or state mode). Any other method of sampling is periodic and as such the <Sampling> section will simply contain a "Period" attribute and no <TimeData> section will be generated.

<DigitalData> subsection

Logic analyzer data consists of a single <DigitalData> subsection containing only digital data samples. There is one sample per line. Each sample is contained between a pair of curly braces and is formatted to appear (left to right) in the same order that the corresponding <BusSignal> sections appear in <Setup>, delimited by commas. For example, "{ Bus1, Bus2, Signal1 }" where Bus1 was the first <BusSignal> section in <Setup>, Bus2 was second, and Signal1 was third.

Example:

```
<Module Name="200MHz State/800MHz Timing Analyzer 1" NumberOfSamples="60"
TriggerIndex="30">
```

Notice there is no <TimeData> section because the running example is periodic

```
<DigitalData>
```

```
{7FE2,0,0},
```

```
{7FE3,0,0},
```

```
{7FE4,0,0},
```

54 more samples here

```
{1B,0,0},
```

```
{1C,0,0},
```

```
{1D,0,0}
```

```
</DigitalData>
```



```
</Module>
```

<Tool> subsection

<Tool>'s only attribute is Name. Each tool must have a unique name. Tool data consists of two subsections, <IntegralData> and <StringData>.

<IntegralData> and <StringData> subsections

The <IntegralData> section contains only generated data for labels in the <Label> section of <Setup> that are Integral type. The <StringData> section contains only generated data for labels of String type. As in <DigitalData>, there is one sample per line and each sample is contained within curly braces. The one difference between the format of digital data and generated data is that generated data must account for subrows. This is accomplished through the use of square brackets that denote all subrows for a label. For example, {[label1_0,label1_1],[label2_0],[label3_0,label3_1,label3_2]} where label1 has one subrow, label2 has no subrows and label3 has three subrows. The first value is always the state value and the other remaining values are subrows.

Example:

```
<Tool Name="Arm Inverse Assembler 1">
```

```
<IntegralData>
{[0000 7FE2],[0000],[F001 0023]},
{[0000 7FE2],[0000],[F001 0023]},
{[0000 7FE4],[0000],[F001 0023]},
    54 more Integral Data samples
{[0000 001A],[0000],[F001 0023]},
{[0000 001C],[0000],[F001 0023]},
{[0000 001C],[0000],[F001 0023]}
</IntegralData>
```

```
<StringData>
{[* LSL R0,R0,#0x0 T-[31:16]]},
{[* LSL R0,R0,#0x0 T-[31:16]]},
{[* LSL R0,R0,#0x0 T-[15:00]]},
    54 more StringData samples
{[* LSL R0,R0,#0x0 T-[31:16]]},
{[* LSL R0,R0,#0x0 T-[15:00]]},
{[* LSL R0,R0,#0x0 T-[15:00]]}
</StringData>
```

```
</Tool>
```

```
</Data>
```

```
</Configuration>
<!-- end of file -->
```


Index

A

accessories	224
acquiring data	217
acquisition depth	153
acquisition speed	226, 227
actions	179
activity indicators	110, 131
adding a bus or signal	138
advanced clocking	158
advanced trigger	168
ala.....	290
alias	149
AND.....	179
asynchronous sampling See timing mode	23, 50, 59, 150, 217

B

background	110, 131
bus width	136
bus/signal setup.....	136
buttons	228

C

cable.....	267
capturing data	217
center about	190
change display scale	116
change time/division.....	116
channel width	160, 226, 227
characteristics.....	264, 271
clock.....	22, 23, 27, 28, 157
collapse a bus	116
color	110, 301
column properties.....	130, 131
commands.....	287
comments	125
config screen See sampling	150
configuration	130, 199, 201, 203, 290
configuration translator	274
configure.....	182, 184
connect	222
connecting to target See probing	232, 264
connectivity	222
contact information.....	224
convert	274
counter	182
create marker	187

csv	206, 294
cursors	
see markers.....	54, 109, 189, 194, 244, 252, 272, 273

D

data valid	146
default base.....	143
default storage.....	170
delay	115
delete	139, 191
demultiplex.....	155
dialogs.....	257, 258, 261
display.....	106, 128, 256
draw rectangle in data	116
duration	67, 68, 69, 70

E

edge trigger.....	164
edit.....	239
edit menu.....	239
error messages	276
events.....	179
expand a bus	116
export.....	206, 294, 295
external triggering.....	52

F

favorite	180, 181, 214
file.....	198, 199, 201, 203, 204, 238
file format	290, 294, 295
file menu	238
filter	243, 257
filtering	243, 257
find.....	209, 210, 211, 213, 216
folder.....	148
font size	110, 131
format screen	
see bus/signal setup	136
front panel.....	228

G

getting started	17
go to.....	213
group signals	119

H

help	17, 247
help menu	247
hide data.....	301
hold.....	146

I	
import.....	204
install	221, 222
K	
keyboard commands.....	287
keypad.....	228
knobs.....	228
L	
label	
See bus/signal setup.....	136
LAN	222
listing window	128, 131
local area network	222
locate	
See search.....	209
logic analyzer basics	17
M	
macro	
See trigger function.....	59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 168
marker menu	244
markers	54, 109, 189, 194, 244, 252, 272, 273
master clock	155, 158
master/slave clock.....	155, 158
maximum input.....	268
measure time	
See markers	54, 109, 189, 194, 244, 252, 272, 273
measurement examples	49, 50, 51, 52, 54
memory depth	226, 227
menus	237
minimum amplitude.....	268
moving markers	193, 196
N	
negate	176
negative logic	145
network.....	222
numeric base	110, 131, 143
O	
occurrence.....	182
offline	259, 276
open	199
operating environment.....	264
OR.....	179
overlay.....	118
overview	17

P

place on edge markers	110
polarity	145
poststore	154
prestore	154
printer	221
printing	219
probe cable.....	267
probing	232, 264
probing options	31
product overview.....	224
properties.....	110, 131, 194
properties dialog	261
pv tests.....	235

Q

qualifier.....	28, 157
quick trigger	122

R

read marker.....	197
recall trigger	181
reference.....	237, 248, 256, 257, 263
rename	140, 192
row height.....	110
run/stop menu	245
running the analyzer	218

S

sampling options	160
sampling period	23, 28, 150, 159, 264
sampling setup.....	150
save	201
scale	
See change time/division	116
search.....	209
self tests	235
sequence level storage.....	170
setup menu	242
setup time	146
show data.....	301
signal.....	119, 136
signal loading.....	268
signal requirements	268
simple trigger	110, 131, 164
slave clock.....	155, 158
snap to edge markers	110
specifications	266, 270
state clocking.....	155
state mode	28, 51, 84, 150, 217
stopping the analyzer.....	218
store qualification	170

store trigger	180
symbols	126, 134, 262
synchronous sampling	
See state mode	28, 51, 84, 150, 217
system options.....	259

T

tabbed windows	121
task guide	105, 106, 109, 128, 130, 136, 150, 198
testing the logic analyzer.....	235
time/division.....	116
timer	184
timing mode	23, 50, 59, 150, 217
tool tips.....	110, 124, 125
toolbars.....	248, 249, 251, 252, 253, 254, 255
tools	243
tools menu	243
training	17
transitional timing	161
trigger	163, 164, 168, 180, 181
trigger function.....	59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100, 101, 102, 103, 104, 168
trigger in	52, 259
trigger out.....	52, 259
trigger position.....	154
triggering	163, 164, 168, 180, 181
tutorial.....	17

U

user interface.....	228
---------------------	-----

V

view menu.....	241
----------------	-----

W

waveform window.....	106, 110
web sites.....	224
window menu	246
windows.....	120, 121, 246, 256
working with markers	109

X

xml.....	206, 295
----------	----------

Z

zoom in on data	43, 116
-----------------------	---------