

Operating and Service Guide

Agilent Technologies 85902A Burst Carrier Trigger and RF Preamplifier



Agilent Technologies

Manufacturing Part Number: 85902-90002 Supersedes: 85902-90001

Printed in USA

January 2000

© Copyright 1993 - 2000 Agilent Technologies, Inc.

The information contained in this document is subject to change without notice.

Agilent Technologies, Inc. makes no warranty of any kind with regard to this material, including but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Warranty

This Agilent Technologies, Inc. instrument product is warranted against defects in material and workmanship for a period of three years from date of shipment. During the warranty period, Agilent Technologies, Inc. will, at its option, either repair or replace products that prove to be defective.

For warranty service or repair, this product must be returned to a service facility designated by Agilent Technologies. Buyer shall prepay shipping charges to Agilent Technologies and Agilent Technologies shall pay shipping charges to return the product to Buyer. However, Buyer shall pay all shipping charges, duties, and taxes for products returned to Agilent Technologies from another country.

Agilent Technologies warrants that its software and firmware designated by Agilent Technologies for use with an instrument will execute its programming instructions when properly installed on that instrument. Agilent Technologies does not warrant that the operation of the instrument, or software, or firmware will be uninterrupted or error-free.

LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from improper or inadequate maintenance by Buyer, Buyer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product, or improper site preparation or maintenance.

NO OTHER WARRANTY IS EXPRESSED OR IMPLIED. AGILENT TECHNOLOGIES SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

EXCLUSIVE REMEDIES

THE REMEDIES PROVIDED HEREIN ARE BUYER'S SOLE AND EXCLUSIVE REMEDIES. AGILENT TECHNOLOGIES SHALL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

Contents

1. Quick Start Guide	
What You'll Learn in this Chapter	8
What is the Burst Carrier Trigger?	9
To Verify Receipt of All Equipment	10
Front and Rear Panel Features	11
Front Panel Features	11
Rear Panel Features	12
To Make a Measurement	13
Equipment Required:	13
Procedure	13
Typical Configurations Using the 85902A	15
2. Specifications and Characteristics	
General Specifications	23
Frequency and Amplitude Characteristics	24
Envelope Trigger Characteristics*	24
Pre-Amplifier Characteristics	24
Physical Characteristics	26
Front Panel Inputs and Outputs	26
Rear Panel Features	26
Weight	27
To Perform a Functional Test	28
Burst Carrier Trigger Functional Test Procedure	29
RF Preampifier Functional Test #1	31
RF Preampifier Functional Test #2	33
3. Theory of Operation	
Theory of Operation - Burst Carrier Trigger	37
Theory of Operation - RF Preampifier	38
4. Chapter Troubleshooting	
Before Troubleshooting	40
No TTL Trigger Output	41
Bad RF Preampifier Output	43
5. Replaceable Parts	
How to Order Replaceable Parts	46
USA Direct Mail-Order System	46
USA Direct Phone-Order System	46
Regular Orders.	46
Hotline Orders.	47
6. Replacement Procedures	
Before You Start	50
Safety Notes	51
General Safety Considerations.	51
Reliability Considerations	52
Protection from Excessive Input Signals.	52

Contents

Protection from Electrostatic Discharge	52
Handling of Electronic Components and ESD	53
Test Equipment Usage and ESD	53
For Additional Information about ESD	54
Replacement Procedures	55
Tools Required	55
Available Options for the 85902A	55
End and Bottom Covers Removal	56
PC Board Replacement	57
BNC Connector Replacement	59
DC Power Cable Replacement	61
Main Housing End Cover Replacement, DC Supply End	63
Main Housing End Cover Replacement, Input/Output End	64

1 Quick Start Guide

What You'll Learn in this Chapter

This chapter consists of the following:

- A summarized description of the 85902A Burst Carrier Trigger and RF Preamplifier.
- A description of all the items shipped with your 85902A.
- A description of the front and rear panel features of your 85902A.
- Instructions on making a simple measurement using your 85902A.
- An illustrated set of typical test configurations using the 85902A.

What is the Burst Carrier Trigger?

The 85902A detects the burst RF carrier of a digital communication system and provides a TTL output trigger to synchronize a spectrum analyzer. The 8590 and 8560 - series spectrum analyzers are well suited to use the 85902A. The triggering function is especially useful when performing time dependent measurements such as power versus time and adjacent channel power gated measurements. Typical dynamic range is 60 dB without need for adjustment. The 85902A is compatible with most digital communication formats, including NADC-TDMA, E-TDMA, JDC, GSM, DCS-1800, CT2-CAI, DECT, PHP, and CDMA.

The triggering circuit is an RF envelope detector, consisting of biased Schottky diodes that can respond to -30 dBm signal levels and frequencies well into the microwave region. Typical frequency response is 10 Mhz to 2 GHz.

The following 8560 and 8590 - series spectrum analyzers are compatible with the burst carrier trigger function of the 85902A:


- 856XE,EC
- 8591E
- 8593E
- 8594E
- 8595E
- 8596E

Separate from the triggering circuitry but included inside the 85902A is a 10 MHz to 2 GHz preamplifier. It provides a typical 12 to 18 dB gain for added triggering sensitivity, *if required*. DC power for the unit is supplied through the probe power connector located on the front panel of the spectrum analyzer.

To Verify Receipt of All Equipment

Unpack the contents and confirm that all items have been received. Figure 1-1 shows the 85902A and all items included with the product.

Figure 1-1 **Items Included with the 85902A**




- 1 85902A Operating and Service Guide
- 2 85902A Burst Carrier Trigger and RF Preamplifier
- 3 BNC Cable - 23 cm (9 inches) long
- 4 BNC Cable - 122 cm (48 inches) long
- 5 Mounting bracket (installed on unit as option 001 only).

Front and Rear Panel Features

The following section provides a brief description of front and rear panel features. The explanations to the numbered callouts in Figure 1-2 are provided below.

Figure 1-2 Front and Rear Panel Features



Front Panel Features

- 1 RF preamplifier input BNC female connector. Connect an RF input signal here for pre-amplification. The preamplifier may be used before the burst carrier trigger, or it may be used alone.
- 2 RF preamplifier output BNC female connector. Connect this to the input of a device or instrument. For example, it may be connected to the burst carrier trigger RF Input connector, or to a spectrum analyzer RF input connector.
- 3 Burst carrier trigger TTL output BNC female connector. Connect this output to the spectrum analyzer EXTERNAL GATE TRIGGER INPUT connector. The TTL output signal at this connector triggers the analyzer on the rising edge of the RF pulse applied to the RF input of the burst carrier trigger.

Rear Panel Features

- 4 Input trigger threshold screwdriver adjustment. Use a small flat blade screwdriver or electronic adjustment tool here to vary the trigger sensitivity on the leading edge of the RF burst. This is a normal operating adjustment, but should seldom need changing because it is adjusted at the factory for the best overall operating range.
- 5 Trigger indicator LED. This LED illuminates for each rising edge of the output pulse. The LED remains off if the trigger threshold is set either too low or too high, or if a burst signal is not present at the RF Input.
- 6 Burst carrier trigger TTL output BNC female connector. Connect this output to the spectrum analyzer EXTERNAL GATE TRIGGER INPUT connector. The TTL output signal at this connector triggers the analyzer on the rising edge of the RF pulse applied to the RF input of the burst carrier trigger.
- 7 DC power cord and connector. DC power is supplied to the 85902A through this 50 cm (20 inch) cord and female probe power connector. Power may be conveniently supplied using analyzers with front panel probe power connectors, or with the 11899A probe power supply. Alternately, the end connector may be removed and the cable connected directly to a suitable dc supply.

To Make a Measurement

Let's begin using the burst carrier trigger/RF preamplifier to trigger the spectrum analyzer and make a power versus time measurement. We will use a mobile station with an NADC-TDMA format, but any applicable format may be used.

This procedure takes approximately five minutes to perform.


Equipment Required:

- 85902A burst carrier trigger/RF preamplifier
- 859X-series spectrum analyzer with option 105
- 85718A NADC-TDMA measurements personality
- Five BNC cables
- Type N male to BNC female adapter
- An attenuator to reduce the mobile station RF power output to avoid exceeding the analyzer RF input limitations.

Procedure

This configuration uses the spectrum analyzer IF output signal as the burst carrier trigger RF input signal. This configuration takes advantage of the built-in RF preamplifier to increase the IF output signal level before it is connected to the triggering circuitry. This is only one of several typical configurations possible. Other configurations will be explained later.

Figure 1-3 Making a Power Versus Time Measurement



se75a

1. Connect the equipment as shown in Figure 1-3.

CAUTION

Adjust the external attenuator for sufficient attenuation to avoid damage to the spectrum analyzer.

2. Load the measurement personality in the spectrum analyzer and select the NADC mode. Press **MODE**, **NADC ANALYZER**, **Power vs Time**. Make sure that the channel number selection agrees with the transmitter RF output.
3. Press **P vs T BURST** to display the transmission burst. The signal should be triggered on the display, indicating the burst carrier trigger is operational.

If the signal is not triggered, make sure the burst carrier trigger unit supply cable is plugged into the probe power connector on the analyzer. Then check all other cables and connections to the 85902A and the analyzer, especially the rear panel connections.

4. If the burst is not symmetrical with respect to the limit lines, press **TRIG DELAY**, then use the large knob on the spectrum analyzer's front panel to adjust the trigger delay until the burst is symmetrical with respect to the limit lines. Also, if you know the actual trigger time delay, you can enter the time delay by pressing **TRIG DELAY**, enter the number with the data keys, and then press the appropriate units key **sec**, **ms**, or **μs**.
5. Press **Previous Menu** when you are done with the P vs T BURST measurement, or use one of the post-measurement functions.


Typical Configurations Using the 85902A

The burst carrier trigger unit may be configured to trigger 8560 or 8590 - series spectrum analyzers by either using the transmitted RF signal, or the IF output signal from the analyzer. Examples of both configuration methods are shown in Figure 1-4 through Figure 1-9.

Use the analyzer IF output method for the following zero span measurements on a base or mobile station:

- power versus time
- carrier power
- carrier off power
- frequency deviation, cordless telephone 2 (CT2)

Figure 1-4 Using Analyzer IF Output Triggering (off-air trigger)



se725a

* Cable used with 8590-series analyzers only.


CAUTION

Adjust the external attenuator for sufficient attenuation to avoid damage to the spectrum analyzer.

Use the direct RF triggering method with a base or mobile station for both time domain (zero span) and frequency domain non-zero span measurements (Figure 1-5 through Figure 1-9):

- power versus time
- carrier power
- carrier off power
- frequency deviation, cordless telephone 2 (CT2)
- gated adjacent channel power (ACP)

Figure 1-5 Using Direct RF Triggering with a Directional Coupler




se76a

* Cable used with 8590-series analyzers only.

CAUTION Adjust the external attenuator for sufficient attenuation to avoid damage to the spectrum analyzer.

NOTE You may connect the preamplifier for added sensitivity, indicated by the dashed lines.

Figure 1-6 Using Direct RF Triggering with a Power Splitter



se77a

* Cable used with 8590-series analyzers only.

CAUTION


Adjust the external attenuator for sufficient attenuation to avoid damage to the spectrum analyzer.

NOTE

You may connect the preamplifier for added sensitivity, indicated by the dashed lines.

Use the configuration in Figure 1-7 for mobile station testing using JDC or NADC formats.

Figure 1-7 Using Direct RF Triggering with a Mobile Station Under Test and a Base Station Simulator (Method 1)



se78a


* Cable used with 8590-series analyzers only.

NOTE You may connect the preamplifier for added sensitivity, indicated by the dashed lines.

Use the configuration shown in Figure 1-8 for mobile station testing using JDC or NADC formats. This setup has the following advantages:

- Timing of the trigger signal is completely independent of the station under test carrier level
- The trigger signal is still present even if the station under test has a serious malfunction. This makes the setup good for troubleshooting.

Figure 1-8 Using Direct RF Triggering with a Mobile Station Under Test and a Base Station Simulator (Method 2)




se724a

* Cable used with 8590-series analyzers only.

NOTE

You may connect the preamplifier for added sensitivity, indicated by the dashed lines.

Figure 1-9 Using Direct RF Triggering with a Base Station Under Test and a Mobile Station Simulator



se79a

* Cable used with 8590-series analyzers only.

NOTE

You may connect the preamplifier for added sensitivity, indicated by the dashed lines.

Use the configuration shown in Figure 1-9 for mobile station testing using JDC or NADC formats. This setup has the following advantages:

- Timing of the trigger signal is completely independent of the station under test carrier level
- The trigger signal is still present even if the station under test has a serious malfunction. This makes the setup good for troubleshooting.

General	General specifications
Frequency	Frequency-related characteristics
Amplitude	Amplitude-related characteristics
Physical	Input, output and physical characteristics

This distinction between specifications and characteristics is described as follows.

- Specifications describe warranted performance over the temperature range 0 °C to +55 °C, unless otherwise noted. The unit will meet its specifications after two hours of storage at a constant temperature within the operating temperature range, and 30 minutes after DC power has been applied.
- Characteristics provide useful, but non-warranted information about the functions and performance of the burst carrier trigger/RF preamplifier unit. Characteristics are specifically identified.
- Typical Performance, where listed, is not warranted, but indicates performance that at least 80% of all units will exhibit.
- Nominal Value indicates the expected, but not warranted, value of the parameter.

General Specifications

All specifications apply over the temperature range 0 °C to +55 °C, unless otherwise noted. The unit will meet its specifications after two hours of storage at a constant temperature within the operating temperature range, and 30 minutes after DC power has been applied.

Temperature Range	
Operating	0 °C to +55 °C
Storage	-40 °C to +75 °C

Operating Humidity	Type tested to 95% relative humidity at 40°C for 5 days.
---------------------------	--

EMI Compatibility	See the Declaration of Conformity located at the front of this guide.
--------------------------	---

Power Requirements*	+15 Vdc at 100 mA -12.6 Vdc at 40 mA
----------------------------	---

* The probe power connector on the front panel of any HP/Agilent spectrum analyzer meets the power requirements.

Maximum Safe Input Level	
Average Continuous:	
RF Input	+30 dBm (1 Watt)
Preamp In/Out	+30 dBm (1 Watt)
DC:	
RF Input	25 Vdc
Preamp In/Out	25 Vdc

Frequency and Amplitude Characteristics

These are not specifications. Characteristics provide useful but non warranted information about instrument performance.

Envelope Trigger Characteristics*


Frequency Range	10 MHz to 2000 MHz
Amplitude Range	-30 dBm to +30 dBm
Burst	
Burst RF Rate	25 Hz to 2.0 kHz
Minimum Burst Width	100 μ s
Minimum Recovery Time Between RF Bursts	300 μ s
Trigger Output	
Delay	< 20 μ s for RF input >- 25 dBm
Jitter	< 2 μ s for a consistent burst signal
Level	TTL/CMOS logic level
Compatible Formats	
Formats	GSM, DCS-1800, NADC-TDMA, E-TDMA, JDC, CT2-CAI, DECT, PHP, CDMA

*At the RF Input BNC of the Burst Carrier Trigger unit.

Pre-Amplifier Characteristics

Overall Frequency Range	10 MHz to 2000 MHz
Frequency Range	Minimum Gain
10 to 350 MHz	18 dB
350 to 1000 MHz	16 dB
1000 to 2000 MHz	12 dB

Figure 2-1 **Nominal Gain versus Frequency**



se719a

Noise Figure	<10 dB
1 dB (output) Gain Compression	> +10 dBm

Physical Characteristics

Front Panel Inputs and Outputs

PREAMP IN	
Connector	BNC female
Impedance	50 Ω

PREAMP OUT	
Connector	BNC female
Impedance	50 Ω

RF INPUT	
Connector	BNC female
Impedance	50 Ω

Rear Panel Features

Threshold Level	
INPUT TRIG LVL ADJ	Screwdriver adjustable potentiometer


Trigger Indicator	
TRIG OUT	LED

TRIG OUT	
Connector	BNC female TTL/CMOS

Weight

Weight*	
Net (standard product)	341 grams (12 ounces)
Shipping (standard product)	909 grams (32 ounces)
Net (with Option 001)	426 grams (15 ounces)
Shipping (with Option 001)	995 grams (35 ounces)
* Approximate values.	

Figure 2-2 85902A Physical Dimensions



* Dimension with option 001 not installed.

† Dimension with option 001 installed.

se72a

Dimensions in the figure are shown in millimeters first and in inches (in parenthesis) second.

To Perform a Functional Test

The following functional test confirms that the burst carrier trigger and RF preamplifier are both operational. The burst carrier trigger is tested for trigger delay and the RF preamplifier is tested for swept flatness gain over its operating frequency.

This check is NOT to verify any specifications or supplemental characteristics; its purpose is to determine whether or not the unit is basically operational. This test can be used during the troubleshooting procedure, or as an operational check during incoming inspection. It takes approximately 90 minutes to perform both the burst carrier trigger and either of the RF preamplifier functional tests.

Equipment Required

The following equipment is required for the burst carrier trigger functional tests:

- 54501A oscilloscope
- 8116A pulse generator
- 11899A probe power supply
- 8642B or 8663A RF source with pulse modulation
- Four BNC cables
- BNC tee
- 3.5 mm female to BNC female adapter

The following equipment is required for the RF preamplifier functional test:

- 8560E/EC spectrum analyzer with option 002 (tracking generator)
- Three BNC cables
- Type N male to BNC female adapter


OR

- 8753ES network analyzer
- 11667A option 001 power splitter
- 8491B 20 dB attenuator
- Three BNC cables
- Four Type N male to BNC female adapters
- BNC female barrel adapter

Burst Carrier Trigger Functional Test Procedure

Procedure

Figure 2-3 Equipment Setup for the Burst Carrier Trigger Functional Test



se710a

1. Connect the equipment as shown in Figure 2-3.
2. Set the test equipment controls as follows:
 - **Signal Generator:**

CW frequency	1 GHz
Power level	5 dBm
MENU SELECT	MOD
Pulse On/Off	Extrnl

- Pulse/Function Generator

Mode	NORM
Frequency (FRQ)	500 Hz
Waveform	Pulse
Width (WID)	100 μ s
Amplitude (AMP)	4.5V
Offset (OFS)	0 mV
Disable	Off

3. On the oscilloscope, press the following keys to set the sensitivity of active channels 1 and 4. Press **MENUS, CHAN, CHANNEL 1, on, V/div, 1 V dc**. Next press **CHANNEL 2 off, CHANNEL 3 off, CHANNEL 4 on, V/div, 1 V dc, offset, 2.5 V**.
4. Press **MENUS, TIME BASE, delay, 0 s**, then **TIMEBASE, 5 μ s, reference cntr** to center the time base reference on the screen at 5 microseconds per division. Press **window off** to show one window only.
5. Press **MENUS, TRIG, source 1**. Then press the symbol that shows a leading edge trigger to trigger the signal on channel 1.
6. Press **SYSTEM CONTROL, RUN/STOP** if there are no pulses displayed. Press **MENUS, DISPLAY, connect dots on**, to show a solid line for the rising edges for both pulses.
7. Press **MENUS, Δt ΔV , ΔV markers off, Δt markers on, start marker** and use the rotary pulse generator (RPG) knob to align the start limit line (vertically-dashed) over the rising edge signal trace on the left pulse. Press **stop marker** and, in a similar manner, align the dashed stop limit line over the signal trace rising edge on the right pulse. Align the stop limit line in the approximate center of the rising edge.
8. Read the Δt value given on the screen. It should read less than 20 μ s.

RF Preamplifier Functional Test #1

NOTE Verify operation of the RF preamplifier by performing either RF preamplifier functional test #1 or test #2. It is not necessary to perform both tests together. Each test confirms operation using different test equipment; both methods are provided for your convenience.

Functional test #2 uses an 8753ES network analyzer and 11667A power splitter. Functional test #1 uses an 8593E spectrum analyzer with Option 010, or an 8560-series spectrum analyzer with option 002.


Procedure

NOTE This procedure was written for an 8560E/EC spectrum analyzer with Option 002. The procedure may vary when using an 8593E spectrum analyzer.

1. Turn the spectrum analyzer on. On the spectrum analyzer, press **PRESET**, **FREQUENCY**, **START FREQ**, 10 MHz, **STOP FREQ**, 350 MHz to set the frequency range of interest.
2. Press **AMPLITUDE**, **LOG dB/DIV**, 5 dB to set the vertical sensitivity to 5 dB per division.
3. Connect the tracking generator output to the RF input of the analyzer using a BNC cable. Press **AUX CTRL**, **TRACKING GENERATOR RANGE LVL**, 30 dB to set the dynamic range of the analyzer.
4. Press **SRC PWR ON**, **SRC PWR ON**, **SOURCE CAL MENU**, **CAL THRU**, **STORE THRU** to turn the tracking generator on and to perform a thorough calibration.
5. Press **NORMLIZE ON**, **NORM REF POSN**, 2 dB to normalize the tracking generator frequency response and position the trace near the bottom of the graticule.
6. Connect the equipment as shown in Figure 2-4.
7. Press **MKR** and turn the rotary pulse generator (RPG) knob to read the minimum power level on the trace. This amplitude should be greater than 18 dB.
8. Connect the tracking generator output to the RF input of the analyzer using a BNC cable. Press **FREQUENCY**, **START FREQ**, 350 MHz, **STOP FREQ**, 1 GHz to set the new frequency range of interest.
9. Press **AUX CTRL**, **TRACKING GENERATOR**, **SOURCE CAL MENU**, **CAL THRU**, **STORE THRU** to perform a thorough calibration. Press **NORMLIZE ON** to normalize the tracking generator frequency response.

10. Connect the equipment as shown in Figure 2-4.

Figure 2-4 **Equipment Setup #1 for the RF Preamplifier Functional Test**



se711a

11. Press **MKR** and turn the rotary pulse generator (RPG) knob to read the minimum power level on the trace. The amplitude should be greater than 16 dB.
12. Connect the tracking generator output to the RF input of the analyzer using a BNC cable. Press **FREQUENCY, START FREQ, 1 GHz, STOP FREQ, 2 GHz** to set the new frequency range of interest. Repeat [step 9](#) through [step 11](#), except the amplitude should be greater than 12 dB in [step 11](#).


RF Preamplifier Functional Test #2

NOTE

Verify operation of the RF preamplifier by performing either RF preamplifier functional test #1 or test #2. It is not necessary to perform both tests together. Each test confirms the operation using different test equipment; both methods are provided for your convenience.

Functional test #1 uses an 8560-series spectrum analyzer with option 002. This functional test uses an 8753ES network analyzer and 11667A power splitter.

Figure 2-5 Equipment Setup #2 for the RF Preamplifier Functional Test




se722a

Procedure

1. Connect the equipment as shown in Figure 2-5. Use a female BNC adapter to connect the two BNC cables together. Connect one cable end to network analyzer PORT B, and the other end to the power splitter. The attenuator connects directly to the network analyzer RF OUTPUT port and to the power splitter.
2. On the network analyzer, press **PRESET**.
3. Press **STIMULUS START, 10 MHz, STOP, 350 MHz** to set the frequency of interest.
4. Press **RESPONSE MEAS, S PARAMETERS, Trans: FWD S21 (B/R)** to set the analyzer to make a forward transmission measurement.
5. Press **RESPONSE SCALE REF, SCALE/DIV, 5 x1, REFERENCE POSITION, 2 x1** to set the scale to 5 dB per division and move the reference position lower on the graticule.

6. Press **RESPONSE CAL, CALIBRATE MENU, RESPONSE THRU** to perform a transmission response calibration. Wait until the message **WAIT--MEASURING CAL STANDARD** disappears from the display. Then press **DONE: RESPONSE** to temporarily store the calibration.
7. Remove the BNC female barrel adapter connecting the two BNC cables together. Connect the free end of the cable attached to the power splitter to the 85902A **PREAMP IN** connector. Connect the cable from the analyzer port B to the 85902A **PREAMP OUT** connector.
8. Press **RESPONSE MKR FCTN, MKR SEARCH, SEARCH: MIN** to activate the marker minimum search function.
9. Read the minimum gain in the upper right hand corner of the screen above the graticule. It should be greater than 18 dB.
10. Press **STIMULUS START, 350 MHz, STOP, 1 GHz** to change the frequency of interest. Use a BNC female barrel adapter to connect the BNC cables together that are attached to the 85902A **PREAMP IN** and **PREAMP OUT** connectors. Repeat [step 6](#) through [step 9](#), except the gain should be greater than 16 dB in [step 9](#).
11. Press **STIMULUS START, 1 GHz, STOP, 2 GHz** to change the frequency of interest. Use a BNC female barrel adapter to connect the BNC cables together that are attached to the 85902A **PREAMP IN** and **PREAMP OUT** connectors. Repeat [step 6](#) through [step 9](#), except the gain should be greater than 12 dB in [step 9](#).

Figure 3-1 Overall Block Diagram



se718a

Theory of Operation - Burst Carrier Trigger

Refer to Figure 3-1 when reading the following theory of operation.

For a typical time division multiple access (TDMA) or time division duplex (TDD) measurement, the burst carrier is split into two paths with a power splitter. One path goes to the RF input of the spectrum analyzer, while the other path goes to the RF INPUT of the burst carrier trigger (BCT). In the BCT, the RF signal is detected by an RF detector and then amplified by a 70 dB AGC amplifier. The amplified detected carrier signal is then sent to the trigger comparator. When the amplified signal exceeds the threshold trigger level, the trigger comparator switches states. The switching action is enhanced with positive feedback which also provides a small amount of hysteresis to reduce triggering jitters for slow rising/falling and/or noisy envelope signals.

The narrow pulse discriminator then receives the triggered outputs and rejects those narrow pulses which may be the result of noise or amplitude modulation. Finally, a transistor buffer is used to convert the bipolar output of the narrow pulse discriminator into TTL/CMOS logic levels.

The trigger threshold is varied by adjusting a potentiometer with a small screwdriver. The trigger indicator is an RC differentiator that lights an LED on the rising edge of each output pulse. If the trigger threshold is set too low or too high, the trigger output is always high or low. If this occurs, the LED does not light, indicating that no trigger is occurring.

The RF detector uses a pair of biased Schottky diodes that can respond to signal levels below -30 dBm and frequencies up to 2 GHz. The maximum input level without clipping is approximately +5 dBm. The input damage level is determined by the input termination resistor(s), internal to the unit. These allow +30 dBm (1 watt) of continuous power handling capability.

Theory of Operation - RF Preamplifier

The RF preamplifier includes a monolithic microwave integrated circuit (MMIC) that provides a nominal 15 dB of gain. The purpose of the preamplifier is to improve sensitivity of the RF burst detector, when required. This amplifier is a stand-alone unit with its own input and output BNC connectors. For this reason, it can be used as a general purpose amplifier as well as a preamplifier for the burst carrier trigger.

Before Troubleshooting

Before troubleshooting, make sure that the dc supply cable is plugged in, all cables in the equipment setup used are attached to the correct ports, and that the cables are in good electrical condition. These are the most likely causes of failure.

CAUTION

Static Sensitive Parts. The 85902A contains static-sensitive components that must be properly protected. Read the section entitled "Protection from Electrostatic Discharge" in Chapter 1 of this guide before troubleshooting this product.

Perform the functional tests in Chapter 2 of this guide whenever these troubleshooting procedures confirm that the suspected part of the 85902A is working properly. These functional tests more completely confirm the functionality of the 85902A.


No TTL Trigger Output

1. First, make sure that the dc supply cable is plugged in, all cables in the equipment setup used are attached to the correct ports, and that the cables are in good electrical condition. These are the most likely causes of failure.

Choose an equipment configuration that does not use the RF preamplifier portion of the 85902A. If you think that the preamplifier is not working, refer to the procedure entitled "Bad RF Preamplifier Output" in this chapter.

2. Verify with a spectrum analyzer that there is a pulsed RF signal at the end of the cable attached to the "RF INPUT" port of the 85902A. Make sure that the amplitude and frequency of this signal is within the range of the characteristics given in Chapter 2 of this guide.
3. Use a voltmeter to check the dc voltages at the probe power output connector of the spectrum analyzer or power supply. The burst trigger circuitry uses both the -12.4 V and +15 V supplies. Figure 4-1 shows the nominal voltages on each of the probe power connector pins.

Figure 4-1 Probe Power Connector Pin Voltages




se721a

4. If the proper voltages are present at the spectrum analyzer probe power connector, check the "RF INPUT" and "TRIG OUT (TTL)" BNC connectors for damage. Replace any bad connectors found.
5. If the connectors look good, connect the dc supply cable to the probe power output port of an analyzer or a suitable power supply. Attach the cable supplying the RF burst to the "RF INPUT" port of the 85902A. Then connect an oscilloscope to the "TRIG OUT (TTL)" connector and observe the output.
6. If a TTL pulse is observed, the 85902A trigger circuitry is working. If

a TTL pulse is not observed, then there may be an open wire in the dc supply cable.

7. Remove the bottom cover of the 85902A. Refer to the "**End and Bottom Covers Removal**" procedure in Chapter 6 of this guide. Connect the dc supply cable to the probe power output port of an analyzer and use a voltmeter to carefully check the voltages on the printed circuit board, as indicated in Figure 4-2.

Figure 4-2 DC Supply Voltages on the PC Board Assembly



se720a

8. If either voltage is missing, replace the dc supply cable. If the voltages are correct, visually check the "RF INPUT" and "TRIG OUT (TTL)" BNC connectors, especially where they are soldered to the PC board assembly. Make sure they are making good electrical connection.
9. If the BNC connectors are good, then the burst carrier trigger circuitry is not working; replace the PC board assembly.

Bad RF Preamplifier Output

1. First, make sure that the dc supply cable is plugged in, all cables in the equipment setup used are attached to the correct ports, and that the cables are in good electrical condition. These are the most likely causes of failure.
2. Use a voltmeter to check the dc voltages at the probe power output connector of the spectrum analyzer or power supply. The RF preamplifier circuitry uses only the +15 V supply, although the burst trigger circuitry uses both supplies. Figure 4-1 shows the nominal voltages on each of the probe power connector pins.
3. If the proper voltages are present at the spectrum analyzer probe power connector, check the "PREAMP IN" and "PREAMP OUT" BNC connectors for damage. Replace any bad connectors found.
4. If the connectors look good, then perform one of the preamplifier functional tests in Chapter 2 of this guide. Each test confirms operation using different test equipment.
5. If the functional test fails, there may be an open wire in the dc supply cable. Remove the bottom cover of the 85902A. Refer to the **"End and Bottom Covers Removal"** procedure in Chapter 6 of this guide. Connect the dc supply cable to the probe power output port of an analyzer and use a voltmeter to carefully check the voltages on the printed circuit board, as indicated in Figure 4-2.
6. If either voltage is missing, replace the dc supply cable. If the voltages are correct, visually check the "PREAMP IN" and "PREAMP OUT" BNC connectors, especially where they are soldered to the PC board assembly. Make sure they are making good electrical connection.
7. If the BNC connectors are good, then the RF preamplifier circuitry is not working; replace the PC board assembly.

How to Order Replaceable Parts

To order replacement parts listed in this chapter, contact your nearest Agilent Technologies Sales and Service Office and quote the part number and quantity desired. Customers within the USA can also use either the direct mail-order system, or the direct phone-order system, which has a toll-free phone number available. Each of these systems is described below.

USA Direct Mail-Order System

Within the USA, Agilent Technologies can supply parts through a direct mail-order system. Advantages of using the system are:

- Direct ordering and shipment from Agilent Technologies.
- No maximum or minimum on any mail order. Parts ordered through a local Agilent Technologies office that require billing and invoicing include a minimum order amount for parts.
- Transportation is prepaid, although each order includes a small handling charge.
- No invoices

To provide these advantages, a check or money order must accompany each order. Mail-order forms and specific ordering information are available through your local Agilent Technologies office.

USA Direct Phone-Order System

Within the USA, a phone order system is available for regular and hotline replacement parts service. A toll-free phone number is available, and Mastercard and Visa are accepted.


Regular Orders.

The toll-free phone number, (800) 227-8164, is available Monday through Friday, 6 AM to 5 PM, Pacific Standard time. Regular orders have a four-day delivery time.

Hotline Orders.

Hotline service is available 24 hours a day, 365 days per year, for emergency parts ordering. The toll-free phone number, (800) 227-8164 is available Monday through Friday, 6 AM to 5 PM, Pacific Standard time. After-hours and on holidays, call (916) 795-8468. To cover the cost of freight and special handling, there is an additional hotline charge on each order. Hotline orders are normally delivered the next business day after they are ordered.

Figure 5-1 85902A Replaceable Parts



se74a

Replaceable Parts
 How to Order Replaceable Parts

Item	Agilent Technologies Part Number	Description
1	0535-0031	M3 nut with lockwasher
2	85902-80001	Identification label
3	1400-0082	DC supply cable holder
4	85902-60001	Burst carrier PC board assembly (includes item number 12, quantity 4)
5	85902-20003	End cover, power cable end
6	85902-60002	DC supply cable assembly
7	0400-0019	DC supply cable grommet
8	0515-0372	M3-8 torx screw with lockwasher
9	3050-0893	M4.0 ID flat washer
10	85902-00001	Bottom cover
11	83006-20007	Bottom cover/mounting bracket (option 001)
12	1250-0524	RF BNC connector
13	not replaceable	Main housing
14	85902-20002	End cover, RF input/output end
15	0590-1251	15/32-32 hex nut
16	0515-0665	M3-14 torx screw with lockwasher
17	8120-2682	BNC cable assembly, 23 cm (9 in.)
18	8120-2582	BNC cable assembly, 122 cm (48 in.)
not shown	85902-90001	Operating and Service Guide

6 **Replacement Procedures**

This chapter contains step-by-step procedures that explain how to replace certain parts and assemblies of the 85902A.

Before You Start

There are two things you must do before you perform any of the replacement procedures in this chapter:

1. Familiarize yourself with the safety notes given below.
2. Read the section entitled “Protection from Electrostatic Discharge” in this chapter.

Safety Notes

The following safety notes are used throughout this manual.
Familiarize yourself with these notes before operating this instrument.

WARNING

Warning denotes a hazard. It calls attention to a procedure which, if not correctly performed or adhered to, could result in injury or loss of life. Do not proceed beyond a warning note until the indicated conditions are fully understood and met.

CAUTION

Caution denotes a hazard. It calls attention to a procedure that, if not correctly performed or adhered to, could result in damage to or destruction of the instrument. Do not proceed beyond a caution sign until the indicated conditions are fully understood and met.

General Safety Considerations

Before servicing the 85902A Burst Carrier Trigger and RF Preamplifier, familiarize yourself with the safety markings on the instrument and the safety instructions in this operating and service guide. This accessory has been manufactured and tested according to international safety standards. To ensure safe operation of the unit and the personal safety of the user and service personnel, the cautions and warnings in this operating and service guide must be heeded.

Reliability Considerations

Protection from Excessive Input Signals

The 85902A input circuitry can be damaged by power levels that exceed the maximum safe input level. See General Specifications [Table on page 23](#) for maximum safe input levels. To prevent input damage, these levels must not be exceeded.

Protection from Electrostatic Discharge

Electrostatic discharge can damage or destroy electronic components. All work on electronic assemblies should be performed at a static-safe work station. Figure 6-1 illustrates an example of a static-safe work station using two types of ESD protection:


- Conductive table-mat and wrist-strap combination.
- Conductive floor-mat and heel-strap combination.

Both types, when used together, provide a significant level of ESD protection. Of the two, only the table-mat and wrist-strap combination provides adequate ESD protection when used alone.

WARNING

These techniques for a static-safe work station should not be used when working on circuitry with a voltage potential greater than 500 volts.

Figure 6-1 Example of a Static-Safe Workstation



Handling of Electronic Components and ESD

The possibility of unseen damage caused by ESD is present whenever components are transported, stored, or used. The risk of ESD damage can be greatly reduced by close attention to how all components are handled.

- Perform work on all components at a static-safe workstation.
- Keep static-generating materials at least one meter away from all components.
- Store or transport components in static-shielding containers.

CAUTION

Always handle printed circuit board assemblies by the edges. This will reduce the possibility of ESD damage to components and prevent contamination of exposed plating.

Table 6-1 Static Safe Accessories

Agilent Technologies Part Number	Description
9300-0797	Set includes: 3M static control mat 0.6 m × 1.2 m (2 ft. × 4 ft.) and 4.6 cm (15 ft.) ground wire. (The wrist-strap and wrist-strap cord are not included. They must be ordered separately.)
9300-0980	Wrist-strap cord 1.5 m (5 ft.)
9300-1383	Wrist-strap, color black, stainless steel, without cord, has four adjustable links and a 7 mm post-type connection.
9300-1169	ESD heel-strap (reusable 6 to 12 months)

Test Equipment Usage and ESD

- Before connecting any coaxial cable to an instrument connector for the first time each day, momentarily short the center and outer conductors of the cable together.
- Personnel should be grounded with a 1 MΩ resistor-isolated wrist-strap before touching the center pin of any connector and before removing any assembly from the instrument.
- Be sure that all instruments are properly earth-grounded to prevent build-up of static charge.

For Additional Information about ESD

For more information about preventing ESD damage, contact the Electrical Over Stress/Electrostatic Discharge (EOS/ESD) Association, Inc. The ESD standards developed by this agency are sanctioned by the American National Standards Institute (ANSI).

CAUTION

Important assembly processes are explained in these procedures which are otherwise not apparent. Follow the replacement procedures in this chapter to avoid damage to the unit.

CAUTION

Static Sensitive Parts. The 85902A contains static-sensitive components that must be properly protected. Always handle printed circuit board assemblies by the edges. This will reduce the possibility of ESD damage to components and prevent contamination of exposed plating.

Replacement Procedures

Tools Required

These tools are required to perform all the replacement procedures:

- static-safe work station
- socket wrench and 9/16-inch deep socket
- T-10 TORX screwdriver
- pliers
- needle-nose pliers
- wire cutters
- soldering iron
- rosin-core solder
- masking tape

Available Options for the 85902A

Instrument Options:

Option 001: Adds a flat mounting bracket attached to the bottom of the unit. The bracket contains four flanges that extend outward from the bottom cover. Each flange has an oblong hole drilled through it for easy mounting to a flat surface.


Documentation Options:

Option 0BN: Provides an additional copy of the operating and service guide when ordered at the time the instrument is ordered. To order extra operating and service guides after the product has been delivered, order the Agilent Technologies part number on the title page of this operating and service guide. You can place the order through your local Agilent Technologies Sales and Service Office.

End and Bottom Covers Removal

Perform this general procedure when directed to do so from any other replacement procedure in this chapter. This procedure is required as part of most other procedures.

Figure 6-2 Removing End and Bottom Covers



se713a


Procedure

This procedure takes approximately 10 minutes to complete. Refer to Figure 6-2.

1. Put masking tape on the leading edge of a 9/16-inch socket. This will prevent the tool from scratching the end cover in the next step.
2. Use the socket wrench in step 1 to remove the hex nut holding the BNC connector to the DC supply cable end cover.
3. Use a T-10 TORX screwdriver to remove the four M3-14 screws holding the two end covers to the main housing.
4. Carefully remove the DC supply cable end cover. Turn the 85902A upside-down and slide the bottom cover off the unit.

PC Board Replacement

Figure 6-3 Removing the PC Board Assembly



se723a


Procedure

This procedure takes approximately two hours to perform. Refer to Figure 6-3.

1. Put masking tape on the front edge of a 9/16-inch deep socket. This will prevent the tool from scratching the end cover in the next step.
2. Use the socket wrench in step 1 to remove the four hex nuts holding the BNC connectors onto both end covers.
3. Use a T-10 TORX screwdriver to remove the four M3-14 screws from both end covers.
4. Carefully remove the input/output end cover. Turn the 85902A upside-down and slide the bottom cover off the unit.
5. Carefully slide the PC board assembly out of the main housing toward the DC supply end cover.
6. Turn the PC board assembly over, trace-side up. Use a pencil soldering iron to desolder and remove the four wires soldered to the PC board assembly at J5.

7. Use a T-10 TORX screwdriver to loosen the M3-8 screw holding the DC supply cable holder to the board. Remove the cable holder.
8. Carefully remove the DC supply cable end cover and position it over the BNC connector on the new PC board assembly.
9. Attach the DC supply cable holder to the board using a T-10 TORX screwdriver and an M3-8 screw.
10. Solder the four DC supply cable wires onto the new PC board assembly as shown in Figure 6-3.
11. Refer to Figure 6-4 and carefully slide the PC board assembly back into the main housing toward the input/output end cover.

Figure 6-4 Installing the New PC Board Assembly




se714a

12. Turn the 85902A upside-down and slide the bottom cover onto the unit.
13. Use a T-10 TORX screwdriver and four M3-14 screws to attach both end covers to the main housing.
14. Use the socket wrench to attach the four hex nuts to secure the BNC connectors onto both end covers.
15. To confirm electrical operation, perform the functional tests in Chapter 2 .

BNC Connector Replacement

Figure 6-5 Replacing a BNC Connector



se715a

Procedure


This procedure takes approximately two hours to complete, and applies when replacing any of the BNC connectors. Refer to Figure 6-5.

1. If only the TRIG OUT (TTL) BNC connector is being replaced, perform the “End and Bottom Covers Removal” procedure described earlier in this chapter and continue with [step 6](#). If any other BNC connectors are to be replaced, continue with [step 2](#).
2. Put masking tape on the front edge of a 9/16-inch deep socket. This will prevent the tool from scratching the end cover in the next step.
3. Use the socket wrench in [step 2](#) to remove the three hex nuts holding the BNC connectors onto the input/output end cover.
4. Use a T-10 TORX screwdriver to remove the four M3-14 screws from both end covers.
5. Carefully remove the input/output end cover. Turn the 85902A upside-down and slide the bottom cover off the unit.
6. Carefully slide the PC board assembly out of the main housing.
7. Use a T-10 TORX screwdriver to remove the two M3-14 screws and M3 nuts with lockwashers that hold the bad BNC connector to the PC board assembly.

8. Use a small pencil soldering iron to desolder and remove the bad BNC center pin from the PC board assembly. Be careful NOT to heat any surface mount components with the iron.
9. Heat the center pin of the replacement BNC connector and fill it with solder. Make sure the center pin of the replacement BNC connector is oriented so that the closed edge of the center pin is touching the PC board assembly when installed on the PC board assembly.
10. Loosely attach the replacement BNC connector onto the PC board assembly. Assemble two M3-14 screws and M3 nuts with lockwashers finger-tight through the BNC connector and PC board. Do NOT solder the connector center conductor yet.
11. Slide the PC board assembly into the main housing and attach both end covers by tightening four M3-14 screws using a T-10 TORX screwdriver. The bottom cover should be OFF at this time.
12. Secure all BNC connectors to the end cap using a 9/16-inch deep socket and 15x32-32 hex nuts. Tighten the nut or nuts to approximately 20 in.-lbs.
13. Use a T-10 TORX screwdriver to tighten the two M3-14 screws holding the new BNC connector to the PC board assembly. Tighten these screws to approximately 6 in.-lbs.
14. Use a small pencil soldering iron to solder the new BNC center pin to the PC board assembly. Be careful NOT to heat any surface mount components with the iron.
15. Use a 9/16-inch deep socket to remove the hex nut holding the BNC connector to the DC supply cable end cover.
16. Use a T-10 TORX screwdriver to remove the two M3-14 screws from the DC supply cable end cover and carefully remove the end cover.
17. Slide the bottom cover onto the main housing and replace the DC supply cable end cover.
18. Use a T-10 TORX screwdriver to tighten the two M3-14 screws holding the end cover to the main housing.
19. Use a 9/16-inch deep socket to tighten the hex nut holding the BNC connector onto the DC supply cable end cover.
20. To confirm electrical operation, perform the functional tests in Chapter 2 .

DC Power Cable Replacement

Figure 6-6 Replacing the DC Power Cable



se716a

Procedure

This procedure takes approximately two hours to complete. Refer to Figure 6-6.

1. Perform the “End and Bottom Covers Removal” procedure described earlier in this chapter.
2. Carefully slide the PC board assembly out of the main housing toward the input/output end cover.
3. Turn the PC board assembly over, trace side up. Use a pencil soldering iron to desolder and remove the four wires soldered to the PC board at J5.
4. Use a T-10 TORX screwdriver to loosen the M3-8 screw holding the DC supply cable holder to the board. Remove the cable holder.
5. Use pliers or needle-nose pliers to squeeze the DC supply cable grommet and push it out of the hole toward the outside surface of the side cover.

6. Pull the DC supply cable through its hole in the side cover. Insert the replacement cable through the side cover hole and re-install the grommet approximately 10 centimeters (4 inches) from the pigtail end of the DC supply cable. Squeeze the grommet and re-install it in the side cover hole from the outside surface of the side cover.
7. See Figure 6-5 inset. Solder the four wires of the DC supply cable into the three holes of J5 on the PC board. Take note of the wire colors.
8. Use a T-10 TORX screwdriver and an M3-8 screw to re-install the DC supply cable holder, securing the cable to the PC board. Allow approximately 7 centimeters (8.75 inches) of cable between the cable holder and the DC supply cable side cover.
9. Carefully slide the PC board assembly into the main housing.
10. Slide the bottom cover onto the main housing towards the input/output end cover. Attach both end covers to the main housing with four M3-14 screws and a T-10 TORX screwdriver.
11. Use a 9/16-inch deep socket to tighten the hex nut holding the BNC connector onto the DC supply cable end cover.
12. To confirm electrical operation, perform the functional tests in Chapter 2 .

Main Housing End Cover Replacement, DC Supply End

Procedure


This procedure takes approximately two hours to complete.

Perform the "DC Power Cable Replacement" procedure in this chapter, except replace step 6 with the following:

1. Perform the "End and Bottom Covers Removal" procedure described earlier in this chapter.
2. Carefully slide the PC board assembly out of the main housing toward the input/output end cover.
3. Turn the PC board assembly over, trace side up. Use a pencil soldering iron to desolder and remove the four wires soldered to the PC board at J5.
4. Use a T-10 TORX screwdriver to loosen the M3-8 screw holding the DC supply cable holder to the board. Remove the cable holder.
5. Use pliers or needle-nose pliers to squeeze the DC supply cable grommet and push it out of the hole toward the outside surface of the side cover.
6. Pull the DC supply cable through its hole in the side cover. Insert the cable through the replacement side cover hole and re-install the grommet at the location it was removed from the cable. Look for the bend impressions made in the cable for this location. Squeeze the grommet and re-install it in the side cover hole from the outside surface of the side cover.
7. See Figure 6-5 inset. Solder the four wires of the DC supply cable into the three holes of J5 on the PC board. Take note of the wire colors.
8. Use a T-10 TORX screwdriver and an M3-8 screw to re-install the DC supply cable holder, securing the cable to the PC board. Allow approximately 7 centimeters (8.75 inches) of cable between the cable holder and the DC supply cable side cover.
9. Carefully slide the PC board assembly into the main housing.
10. Slide the bottom cover onto the main housing towards the input/output end cover. Attach both end covers to the main housing with four M3-14 screws and a T-10 TORX screwdriver.
11. Use a 9/16-inch deep socket to tighten the hex nut holding the BNC connector onto the DC supply cable end cover.
12. To confirm electrical operation, perform the functional tests in Chapter 2 .

Main Housing End Cover Replacement, Input/Output End

Figure 6-7 Replacing the Main Housing End Cover, Input/Output End



se717a

Procedure

This procedure takes approximately 90 minutes to complete. Refer to Figure 6-7.

1. Put masking tape on the leading edge of a 9/16-inch deep socket. This will prevent the tool from scratching the end cover in the next step.
2. Use the socket wrench in step 1 to remove the three hex nuts holding the BNC connectors onto the input/output end cover.
3. Use a T-10 TORX screwdriver to remove the two M3-14 screws from the input/output end cover.
4. Carefully remove the input/output end cover and put the new end cover over the three BNC connectors.
5. Use the 9/16-inch deep socket to attach the three hex nuts holding the BNC connectors onto the input/output end cover.
6. Attach the new end cover to the main housing using two M3-14 screws and a T-10 TORX screwdriver.
7. To confirm electrical operation, perform the functional tests in Chapter 2.

Table 6-2 Agilent Technologies Sales and Service Offices

UNITED STATES		
Instrument Support Center Hewlett-Packard Company (800) 403-0801		
EUROPEAN FIELD OPERATIONS		
Headquarters Hewlett-Packard S.A. 150, Route du Nant-d'Avril 1217 Meyrin 2/ Geneva Switzerland (41 22) 780.8111	France Hewlett-Packard France 1 Avenue Du Canada Zone D'Activite De Courtaboeuf F-91947 Les Ulis Cedex France (33 1) 69 82 60 60	Germany Hewlett-Packard GmbH Hewlett-Packard Strasse 61352 Bad Homburg v.d.H Germany (49 6172) 16-0
Great Britain Hewlett-Packard Ltd. Eskdale Road, Winnersh Triangle Wokingham, Berkshire RG41 5DZ England (44 118) 9696622		
INTERCON FIELD OPERATIONS		
Headquarters Hewlett-Packard Company 3495 Deer Creek Rd. Palo Alto, CA 94304-1316 USA (415) 857-5027	Australia Hewlett-Packard Australia Ltd. 31-41 Joseph Street Blackburn, Victoria 3130 (61 3) 895-2895	Canada Hewlett-Packard (Canada) Ltd. 17500 South Service Road Trans-Canada Highway Kirkland, Quebec H9J 2X8 Canada (514) 697-4232
Japan Hewlett-Packard Japan, Ltd. Measurement Assistance Center 9-1, Takakura-Cho, Hachioji-Shi, Tokyo 192-8510, Japan TEL (81) -426-56-7832 FAX (81) -426-56-7840	Singapore Hewlett-Packard Singapore (Pte.) Ltd. 150 Beach Road #29-00 Gateway West Singapore 0718 (65) 291-9088	Taiwan Hewlett-Packard Taiwan 8th Floor, H-P Building 337 Fu Hsing North Road Taipei, Taiwan (886 2) 712-0404
China China Hewlett-Packard Co. 38 Bei San Huan X1 Road Shuang Yu Shu Hai Dian District Beijing, China (86 1) 256-6888		