
Agilent Technologies 423B and 8470B Detectors

Operating and Service
Manual



Part number: 00423-90103
Printed in USA
October 2002

Supersedes March 2001

Notice

The information contained in this document is subject to change without notice.

Agilent Technologies makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Agilent Technologies shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Agilent Technologies assumes no responsibility for the use or reliability of its software on equipment that is not furnished by Agilent Technologies.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without prior written consent of Agilent Technologies.

Restricted Rights Legend

Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013 for DOD agencies, and subparagraphs (c)(1) and (c)(2) of the Commercial Computer Software Restricted Rights clause at FAR 52.227-19 for other agencies.

Agilent Technologies
1400 Fountaingrove Parkway
Santa Rosa, CA 95403-1799, U.S.A.

© Copyright 1975, 1977, 1979, 2001, 2002 Agilent Technologies, Inc.

Warranty

Certification

Agilent Technologies certifies that this product met its published specifications at the time of shipment from the factory. Agilent Technologies further certifies that its calibration measurements are traceable to the United States National Institute of Standards and Technology (NIST, formerly NBS), to the extent allowed by the Institute's calibration facility, and to the calibration facilities of other International Standards Organization members.

Documentation Warranty

THE MATERIAL CONTAINED IN THIS DOCUMENT IS PROVIDED "AS IS," AND IS SUBJECT TO BEING CHANGED, WITHOUT NOTICE, IN FUTURE EDITIONS. FURTHER, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, AGILENT DISCLAIMS ALL WARRANTIES, EITHER EXPRESS OR IMPLIED WITH REGARD TO THIS MANUAL AND ANY INFORMATION CONTAINED HEREIN, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. AGILENT SHALL NOT BE LIABLE FOR ERRORS OR FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE FURNISHING, USE, OR PERFORMANCE OF THIS DOCUMENT OR ANY INFORMATION CONTAINED HEREIN. SHOULD AGILENT AND THE USER HAVE A SEPARATE WRITTEN AGREEMENT WITH WARRANTY TERMS COVERING THE MATERIAL IN THIS DOCUMENT THAT CONFLICT WITH THESE TERMS, THE WARRANTY TERMS IN THE SEPARATE AGREEMENT WILL CONTROL.

Assistance

Product maintenance agreements and other customer assistance agreements are available for Agilent Technologies products.

For assistance, call your local Agilent Technologies Sales and Service Office.

Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Sales and Service Center.

By internet, phone, or fax, get assistance with all your test & measurement needs.

Online assistance: www.agilent.com/find/assist

United States

(tel) 1 800 452 4844

Canada

(tel) 1 877 894 4414

(fax) (905) 206 4120

Europe

(tel) (31 20) 547 2323

(fax) (31 20) 547 2390

Japan

(tel) (81) 426 56 7832

(fax) (81) 426 56 7840

Latin America

(tel) (305) 269 7500

(fax) (305) 269 7599

Australia

(tel) 1 800 629 485

(fax) (61 3) 9210 5947

New Zealand

(tel) 0 800 738 378

(fax) 64 4 495 8950

Asia Pacific

(tel) (852) 3197 7777

(fax) (852) 2506 9284

Safety and Regulatory Information

Review this product and related documentation to familiarize yourself with safety markings and instructions before you operate the instrument. This product has been designed and tested in accordance with international standards.

WARNING

The **WARNING** notice denotes a hazard. It calls attention to a procedure, practice, or the like, that, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

CAUTION

The **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

Instrument Markings



When you see this symbol on your instrument, you should refer to the instrument's instruction manual for important information.



This symbol indicates hazardous voltages.



The laser radiation symbol is marked on products that have a laser output.



This symbol indicates that the instrument requires alternating current (ac) input.



The CE mark is a registered trademark of the European Community. If it is accompanied by a year, it indicates the year the design was proven.



The CSA mark is a registered trademark of the Canadian Standards Association.

ISM1-A

This text indicates that the instrument is an Industrial Scientific and Medical Group 1 Class A product (CISPER 11, Clause 4).

ICES/NMB-001

This ISM device complies with Canadian ICES-001. Cet appareil ISM est conforme a la norme NMB-001 du Canada.



This symbol indicates that the power line switch is ON.



This symbol indicates that the power line switch is OFF or in STANDBY position.

Notice	ii
Warranty	iii
Certification	iii
Documentation Warranty	iii
Assistance	iii
Safety and Regulatory Information	v
Description	1
Installation	2
Initial Inspection	2
Storage and Shipment	2
Operating Information	4
Operator's Check	5
Performance Tests	6
Frequency Response Test	6
Higher Level Sensitivity Test	6
Low Level Sensitivity Test	6
Match Test (SWR)	6
Service Instructions	7
Replaceable Parts	7
Detector Element Replacement	7
Load Resistor Parts Replacement	8
7-mm Connectors	13

Description

The Agilent Technologies 423B and 8470B detectors are 50 Ω (nominal) Schottky diode devices designed for measurement use in coaxial systems.

Features

- The instruments convert the RF power levels applied to the 50 Ω input connector into proportional values of dc voltage.
- The instruments measure relative power up to 200 mW and have a BNC female connector for the output jack which allows the detected output to be connected to a SWR meter.
- The output voltage polarity is negative, unless Option 003 is selected.
- The frequency range of the 423B is 10 MHz to 12.4 GHz.
- The frequency range of the 8470B is 10 MHz to 18 GHz.
- AM modulation can be detected up to about 1 MHz.

Options

The 423B and 8470B detectors are available with the following non-exclusive options.

Option 001:	Matched pair of detectors
Option 002:	Furnished with matched load resistor for optimum square law characteristics
Option 003:	Positive polarity output
Option 012:	Furnished with stainless steel type-N male connectors (8470B only)

Connectors

- The mating RF input connectors used with the 423B and 8470B Option 012 must be type-N female connectors which comply with U.S. military standard MIL-C-39012.
- The 8470B (standard) RF input connector must be an 7-mm connector.
- The mating output connector for the 423B and 8470B must be a BNC male.

Installation

Initial Inspection

1. Inspect the shipping container for damage. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the instrument has been checked mechanically and electrically. Procedures for checking electrical performance are given under [“Performance Tests” on page 6](#).
2. If the contents are incomplete, if there is mechanical damage or defect, or if the instrument does not pass the electrical performance test, contact the nearest Agilent Technologies office. Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Sales and Service Center. Refer to [“Assistance” on page iii](#). Agilent Technologies will arrange for repair or replacement of the damaged or defective equipment. Keep the shipping materials for the carrier’s inspection.
3. If you are returning the instrument for service, repackaging the instrument requires original shipping containers and materials or their equivalents. Agilent can provide packaging materials identical to the original materials. Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Sales and Service Center. Refer to [“Assistance” on page iii](#). Attach a tag indicating the type of service required, return address, model number and serial number. Mark the container **FRAGILE** to insure careful handling. In any correspondence, refer to the instrument by model number and serial number.

Storage and Shipment

The instrument should be stored in a clean, dry environment. The following environmental limitations apply to both storage and shipment:

- | | |
|-----------------|-----------------------------|
| a. Temperature: | –54 to +85 °C |
| b. Altitude | < 7620 meters (25,000 feet) |
| c. Humidity | < 95% relative |
| d. Shock | 100 G for 11 ms |
| e. Vibration | 20 G from 80 to 2000 Hz |

Specifications

<p>Frequency Range:</p> <p>423B: 10 MHz to 12.4 GHz 8470B: 10 MHz to 18 GHz</p> <p>Note: RF may leak through the output connector below 1 GHz. It can be reduced, if objectionable, with a suitable low pass filter.</p> <p>Frequency Response:^{4, 5}</p> <p>423B and 8470B: Octave flatness: ± 0.2 dB over any octave 10 MHz to 8 GHz Broadband flatness: ± 0.3 dB 10 MHz to 12.4 GHz</p> <p>8470B only: Broadband flatness: ± 0.5 dB 10 MHz to 15 GHz ± 0.6 dB 10 MHz to 18 GHz</p> <p>SWR^{1,2} (Max):</p> <p>423B and 8470B: 10 MHz to 4 GHz, 1.15 4 GHz to 12.4 GHz, 1.3</p> <p>8470B only: 12.4 GHz to 15 GHz, 1.3 15.0 GHz to 18 GHz, 1.7</p> <p>Maximum Operating Input Power:</p> <p>200 mW, peak or average</p> <p>Maximum Short Term Input Power:</p> <p>1 watt (typical) peak or average for < 1 minute</p> <p>Sensitivity:^{1, 3, 5}</p> <p>High level: < 0.35 mW produces 100 mV output Low level: > 0.5 mVdc/μW CW</p> <p>Input Impedance: 50 Ω (nominal)</p> <p>Output Impedance: 1 to 2 k Ω (typically 1.3 k Ω) shunted by 35 to 65 pF (typically 50 pF).</p> <p>Output Polarity: Negative (refer to options for positive polarity units)</p> <p>Detector Element: Supplied (refer to "Replacement Parts Table" on page 12 for replacement elements)</p> <p>Bias: Not required</p> <p>Noise: < 50 μVpp with CW applied to produce 100 mV output</p>	<p>Options:</p> <p>423B and 8470B: Option 002: Furnished with matched load resistor for optimum square law characteristics of 25 °C, within ± 0.5 dB from square law over a range of at least 30 dB up to 10 mV peak output, working into an external load > 8 k Ω. Sensitivity typically is greater than 0.1 mV/μW when load resistor is used. Option 003: Positive polarity output</p> <p>423B: Option 001: Matched detector pair. Frequency response characteristics (exclusive of basic sensitivity) track within ± 0.2 dB from 10 MHz to 12.4 GHz at -30 dBm.</p> <p>8470B: Option 001: Matched detector pair. Frequency response characteristics (exclusive of basic sensitivity) track within ± 0.2 dB from 10 MHz to 12.5 GHz; ± 0.3 dB from 12.4 GHz to 18 GHz at -30 dBm. Option 012: Furnished with stainless steel type-N male connector.</p> <p>Environmental:</p> <p>423B: Operating temperature: 0 C to +55 °C Humidity: < 95% relative Vibration: 20 G from 80 to 2000 Hz Shock: 100 G for 11 ms Altitude: < 4570 meters (15,000 feet)</p> <p>8470B: Operating temperature: -20 to +85 °C Humidity: < 95% relative Vibration: 20 G from 80 to 2000 Hz Shock: 100 G for 11 ms Altitude: < 4570 meters (15,000 feet)</p> <p>General: Weight: 423B and 8470B: Net 114 g (4 oz.) Dimensions: 423B: 63 mm long, 20 mm diameter (2.47 in. long, 0.78 in. diameter) 8470B: 64 mm long, 19mm diameter (2.50 in. long, 0.75 in. diameter)</p>
<p>1. Specifications given for +25 °C unless otherwise noted. 2. Measurement made at -20 dBm. 3. Sensitivity decreases with increasing temperature, typically: 0.5 dB from -20 to +25 °C; 0.5 dB from +25 to +40 °C; 1 dB from +40 to +55 °C; 1.25 dB from +55 to +75 °C; 1 dB from +75 to +85 °C; 4. Measured at -30 dBm. Flatness is the peak-to-valley range of the response. 5. External load resistance > 50 k Ω</p>	

Operating Information

The detector can be used as a demodulator to obtain a pulse envelope which can then be observed on an oscilloscope. It can also be used as a general purpose detector.

CAUTION

Static discharge can damage the detector element. A 100 pF capacitor (1.2 m [4 ft] of coax cable) charged to 14 volts stores .1 erg, the maximum pulse rating of the detector element.

- Connect cables to test equipment and discharge the center conductor before connecting to the detector.
- **DO NOT NEEDLESSLY HANDLE THE DETECTOR ELEMENT USED IN CRYSTAL DETECTOR.** Static electricity which builds up on a person, especially on a cold dry day, must never be allowed to discharge through the detector.
- Avoid exposed leads to or from the detector, since these are often touched accidentally.

The power applied to the detector can be either modulated or continuous wave (CW). If modulated at a 1000 Hz rate, an SWR meter can be used as an indicator. For CW detection, a dc milliammeter or millivoltmeter can be used as the indicator.

NOTE

When using the detector with an oscilloscope, and the waveshapes to be observed have rise times of less than 5 μ s, the coaxial cable connecting oscilloscope and detector should be as short as possible and shunted with a resistor.

Ideally, this resistor should be 50 Ω to terminate the coaxial cable properly. However, with 50 Ω resistance, the output video pulse may be too small to drive some oscilloscopes. Therefore, the cable should be shunted with the smallest value of resistance that will obtain suitable deflection on the oscilloscope; typically the value will lie between 50 Ω and 2k Ω . The larger the resistance the more degradation of rise time.

Operator's Check

Peak Power Measurement

The procedure for peak power measurement involves calibration of an oscilloscope which, in turn, is used to calibrate a CW generator. The output of the calibrated CW generator is measured with a power meter; the peak power of a pulse is thereby measured. The procedure is as follows:

1. Connect equipment as shown in Figure 1, step A. Observe the pulse on a de-coupled oscilloscope. Using a marking pencil, mark on the graticule the base-to-peak amplitude of the pulse envelope.
2. Replace the pulse source with a CW generator. While observing the oscilloscope trace, adjust the amplitude of CW generator output to make detector's output equal to that of pulse generator, as indicated by markings on the graticule (step A).
3. Leave the CW generator at setting obtained in step B. Disconnect the detector from CW generator.
4. Connect the output of CW generator to the power meter (step C). Measure the adjusted levels (set in step B) of the CW generator output. The peak power of the pulse envelope observed in step A is equal to the output power of the CW generator.




Figure 1 Peak Power Measurement

Reflectometer Application

For information about reflectometer systems and measurements refer to Agilent Technologies Application Note Index. Copies are available upon request.

Harmony Frequency Comparison Measurement Application

The detector can be used as a mixer in harmonic-frequency comparison measurements. Refer to Agilent Technologies Application Note Index for further information.

Performance Tests

Methods for testing detector specifications are given below. Refer to the manuals of the equipment involved for operating instructions.

NOTE

Multiple mismatch errors caused by attenuator SWR, power meter SWR, and detector SWR should be taken into account, as well as the accuracy of the indicator used to measure the detector's output.

Frequency Response Test

1. Using signal sources covering 10 MHz to 18 GHz with a 10 dB isolating attenuator and a power meter, connect the power sensor to the attenuator. Adjust the RF power level to -20 dBm input to the power sensor.
2. Without changing the RF power level of signal source, disconnect the power sensor.
3. Connect the detector to the attenuator. Measure the dc voltage output and record the measurement.
4. Change the frequency of the signal source and repeat steps 1 through 3.
5. Since the detector follows a square-law response at this power level, its output is proportional to power ($P_{dB} = 10 \log V_o$). Total variation of detector readings should meet specifications for all frequencies of interest across the band.

Higher Level Sensitivity Test

1. Using signal sources covering 10 MHz to 18 GHz and a dc voltmeter or oscilloscope as the indicator, connect the detector to the signal source. Adjust the RF power level for a 100 mV detected output from the detector, using a CW signal.
2. Disconnect the detector from the signal source and measure the RF output level. The RF output level should be ≤ 0.35 mW.
3. Repeat steps 1 and 2 for all frequencies of interest across the band.

Low Level Sensitivity Test

1. Using a signal source (covering 10 MHz to 18 GHz), a 10 dB attenuator, and a power meter, connect the attenuator to the signal source and power sensor to the attenuator. Adjust the RF power level for -20 dBm output from the attenuator. Verify the ambient temperature.
2. Disconnect the power sensor from the attenuator and connect the detector. Measure the dc voltage output from the detector. The output should be > 5.0 mV at 25 °C. Between 20 °C and 30 °C, the sensitivity slope is typically -0.04 dB/°C.

Match Test (SWR)

1. To verify the detector's SWR specifications, use any system whose measurement accuracies for SWR (residual SWR) are known.

Service Instructions

Repair and replacement information for the 423B and 8470B detectors and Option 002 load resistor are given below. Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Sales and Service Center. You can find a list of Agilent Sales and Service Centers on page v. The detectors have no internal adjustments.

Replaceable Parts

Part numbers for replaceable parts are given in [“Replacement Parts Table” on page 12](#). To order a replacement part, address your order or inquiry to the nearest Agilent Technologies office. Any adjustment, maintenance, or repair of this product must be performed by qualified personnel. Contact your customer engineer through your local Agilent Sales and Service Center. Refer to [“Assistance” on page iii](#). Include the model number, Agilent Technologies part number, and a description.

Detector Element Replacement

The detector element assembly includes only a detector element. However, Option 002 does include a resistor for the load resistor which is used to load the diode for square-law operation.

CAUTION

Read the following precautions carefully before performance of any operation with the detector element when it is out of either the housing or the detector element shipping container.

- Before installing the diode into the mount, touch the exposed metal on the mount with your hand to discharge static electricity.
- When handing the diode to another person, first touch hands to ensure that there is no difference in static electricity potential between you.
- Ohmmeters should not be used to measure forward- and back-resistance since it is easy to damage these diodes. The ohmmeter’s open-circuit voltages and short-circuit currents may cause problems.

-
1. Remove the female BNC connector and compression spring from inside of the connector cap.
 2. Remove the connector cap from the body. Use a pair of pliers with plastic jaws or protect the body with heavy paper or tape.

Service Instructions

CAUTION

- Do not rotate the detector element while inserting or removing as damage may result.
 - When inserting the detector element, do not force the large pin end into the center conductor.
 - The detector element might be damaged if the detector element is not centered.
3. Remove the old detector element, axial spacer, and RF washer and discard the detector element.
 4. Install the RF washer, axial spacer, and new detector element. Refer to the illustrations on [page 11](#) for proper orientation for the internal components.
 - a. Insert the RF washer first.
 - b. Then carefully insert the large pin end of the detector element into the center contact inside the detector body.
 - c. Place the axial spacer over the small pin end of the detector element.
 5. Carefully place the connector cap over the body and assembled components and tighten firmly in place.
 6. Place the compression spring into the center conductor of the female BNC connector. Carefully start the spring over the small pin of the detector element through the hole in the connector cap. Keep the spring in the BNC connector and screw the female BNC connector firmly into place.

Load Resistor Parts Replacement

To replace the male BNC connector

Parts referred to in the following procedures are identified in [Figure 2 on page 9](#) and [Figure 3 on page 10](#).

1. Remove the male BNC connector and lock washer from the housing.

Use a 3/8-inch open-end wrench and hold the housing either in a vise or with pliers. Be sure to protect the housing of the load resistor with material such as heavy paper or tape or use plastic jaws on the vise or pliers.
2. Unsolder the resistor.
3. Solder the resistor to the new BNC connector.
4. Let the resistor cool and then check the resistance from male BNC pin through the resistor. The resistance measurement should be $\pm 10\%$ than indicated by the color coding.
5. Replace the lockwasher and male BNC connector.

To replace the female BNC connector

1. Remove the female BNC connector. Refer to [Figure 3](#) for parts identification.

To remove or install the BNC connector, use a BNC wrench or use a male BNC connector as a wrench to prevent damage to the connector.

2. Unsolder the contact spring.
3. Prepare the replacement female BNC connector:
 - a. Cut the center conductor lead to approximately 0.79 mm (1/32 in.)
 - b. With a flat file, smooth the end of the lead; remove burr with tweezers of similar metal instrument.
4. Slip the contact spring over the center conductor lead, and solder.

CAUTION

Use solder sparingly or it will creep back on the spring. Solder on the spring will destroy its usefulness and it is difficult to remove.

5. Let the contact spring cool and then screw the connector into the mount.

To replace the 7-mm connector center contact

1. Refer to [“7-mm Connectors”](#) on page 13 for assembly and disassembly instructions.
2. Refer to [“Replacing the 7-mm Center Contact”](#) on page 14 for the center contact replacement procedure.




Figure 2 *Cutting Center Conductor Lead to Accommodate Contact Spring*

Service Instructions




Figure 3 Load Resistor, Cutaway View




Figure 4 423B Detector




Figure 5 8470B and 8470B Option 012 Detector Assemblies

Service Instructions

Replacement Parts Table

Description	Part Number	Description	Part Number
423B Assembly		Connector, RF 7 mm	1250-0909
Contact, RF connector	1250-0014	Spring, compression	1460-2606
Gasket, RF connector	1250-0015	Washer, lock internal	2190-0016
Ring, RF connector	1250-0016	Cap, connector	5020-0210
Connector, female BNC	1250-0212	Washer, cap	5021-0127
Nut, RF connector	1250-0918	Insulator	5040-0306
Spring, compression	1460-2606	Conductor, center	08470-20002
Washer, lock internal	2190-0016	Ring, RF connector (Opt 012)	1250-0016
Bead, connector	5020-0207	Connector, RF APC (Opt 012)	1250-0916
Cap, connector	5020-0210	Contact, RF connector (Opt 012)	1250-0917
Washer, cap	5021-0127	Nut, RF connector (Opt 012)	1250-0918
Conductor, center	00423-201		
Body, crystal mount	00423-202	Replacement Diode Assemblies¹	
Replacement Diode Assemblies¹		Single diode negative polarity	08470-60012
Single diode negative polarity	00423-60003	Single diode positive polarity (Opt 003)	08470-60013
Single diode positive polarity (Opt 003)	00423-60004	Single diode negative polarity with matching load resistor (Opt 002)	08470-60014
Single diode negative polarity with matching load resistor (Opt 002)	00423-60005	Single diode positive polarity with matching load resistor (Opt 002)	08470-60015
Matched pair diodes negative polarity (Opt 001)	00423-60007		
Load Resistor Assembly		8470B 7-mm Connector Assembly	
Connector, male BNC	1250-0045	Inner conductor contact mechanism (assembled contact and outer body)	1250-0816
Connector, female BNC	1250-0251	Coupling nut	1250-0918
Spring, contact	5000-0234	Coupling sleeve	1250-0820
Housing	5020-3215	Inner conductor contact	1250-0907
8470B and 8470B-012 Assemblies¹		Support bead	5040-0306
Connector, female BNC		Tools	
	1250-0212	7-mm contact extractor	5060-0370
Contact, RF connector	1250-0816	7-mm spanner wrench	5060-0237
		Open-end wrench	8710-0877

1. Refer to page 1 for a description of options.

7-mm Connectors





Figure 6 Use and Care of 7-mm Connectors

To Connect

1. On one connector, retract the coupling sleeve by turning the coupling nut counterclockwise until the sleeve and nut disengage.
2. On the other connector, fully extend the coupling sleeve by turning the coupling nut clockwise. To engage coupling sleeve and coupling nut when the sleeve is fully retracted, press back lightly on the nut while turning it clockwise.
3. Push the connectors firmly together, and thread the coupling nut of the connector with retracted sleeve over the extended sleeve.
4. Close the gap between coupling nuts with the nut on the extended-sleeve connector.

To Disconnect


1. Loosen the coupling nut of the connector showing the wider gold band.



2. **IMPORTANT:** Part the connectors carefully to prevent striking the inner conductor contact.

Service Instructions

- Care**
1. Keep contacting surfaces smooth and clean. Irregularities and foreign particles can degrade electrical performance.



2. Protect the contacting surfaces when the connector is not in use by leaving the coupling sleeve extended.
3. Use lintless material and/or firm-bristled brush such as a tooth brush for cleaning. If a cleaning fluid is needed, use isopropyl alcohol.

NOTE


Do not use aromatic or chlorinated hydrocarbons, esters, ethers, terpenes, higher alcohols, ketones, or ether-alcohols such as benzene, toluene, turpentine, dioxane, gasoline, cellosolve acetate, or carbon tetrachloride. Keep exposure of the connector parts to both the cleaning fluid and its vapors as brief as possible.

Replacing the 7-mm Center Contact

Through wear or damage the contact in the center conductor may need replacing. This contact is a small four-pronged collet which snaps into a recess in the center conductor. This contact is normally held in by the spring-action of the four prongs. With a magnifying glass, examine this contact to determine if it needs replacement.

CAUTION

DO NOT REMOVE THIS CONTACT FOR INSPECTION AS IT MAY BE DAMAGED BY REMOVAL.



The contact should be free of burrs or wear and the prongs should be equally spaced. If the contact is removed, do *NOT* re-use it (it may be damaged by removal).

If the contact needs replacement and a new contact is available, proceed as follows:

1. Place the instrument so the connector faces down, if possible.
2. Tap the connector lightly and the contact should now protrude slightly. Insert the centering pin of the collet remover (5060-0236) with the jaws open.
3. Allow the jaws on the tool used to close and pull straight back from the connector without twisting. The contact should come out with the tool. If not, repeat the process. Do *NOT* re-use the contact.
4. Snap in a new contact by pushing a new contact in place. Test the action of the new contact by pushing in on it. It should spring out again when released.