About this Manual

We've added this manual to the Agilent website in an effort to help you support your product. This manual is the best copy we could find; it may be incomplete or contain dated information. If we find a more recent copy in the future, we will add it to the Agilent website.

Support for Your Product

Agilent no longer sells or supports this product. Our service centers may be able to perform calibration if no repair parts are needed, but no other support from Agilent is available. You will find any other available product information on the Agilent Test & Measurement website, www.tm.agilent.com.

HP References in this Manual

This manual may contain references to HP or Hewlett-Packard. Please note that Hewlett-Packard's former test and measurement, semiconductor products and chemical analysis businesses are now part of Agilent Technologies. We have made no changes to this manual copy. In other documentation, to reduce potential confusion, the only change to product numbers and names has been in the company name prefix: where a product number/name was HP XXXX the current name/number is now Agilent XXXX. For example, model number HP8648A is now model number Agilent 8648A.

AMPS/EAMPS/NAMPS Cellular Tests HP 11807A,E Option 004 Software User's Guide for the HP 8920A,B,D

HP Part No. 11807-90119 Printed in U. S. A. May 1996

Rev C

Copyright © Hewlett-Packard Company 1995

RESTRICTED RIGHTS LEGEND

Use, duplication or disclosure by the U. S. Government is subject to restrictions as set forth in subparagraph (c) (1) (ii) of the Rights in Technical Data and Computer Software Clause in DFARS 252.227-7013.

Hewlett-Packard Company 3000 Hanover Street Palo Alto, CA 94304 U.S.A

Rights for non-DOD U. S. Government Departments and Agencies are as set forth in FAR 52.227-19 (c) (1, 2).

1 Product Description

HP 11807A,E Software 18

Materials Included in This Package 19

Finding the Information You Need 22

Additional Services Available 23

A.14.00

2 Using the Software/HP 8920B, or HP 8920A FW Above rev

Testing Overview 28

Customizing Testing 34

3 Using the Software/HP 8920A FW Rev Below A.14.00

Testing Overview 62

Customizing Testing 69

4 Test, Parameter, and Pass/Fail Limit Descriptions

```
Introduction 94
TEST_01. CP Registration 95
TEST_02. CP Page 97
TEST_03. TX Frequency Error 99
TEST_04. TX RF Power Output 100
TEST_05. TX Modulation Deviation Limiting 101
TEST_06. TX Audio Frequency Response 102
TEST_07. TX Audio Distortion 103
TEST_08. TX Signaling Tone/DST 104
TEST_09. TX FM Hum and Noise 106
TEST_10. TX SAT/DSAT 107
TEST_11. TX RVC Data Deviation 109
TEST_12. TX Compressor Response 112
TEST_13. TX Current Drain 114
TEST_14. RX Expandor 117
TEST_15. RX Audio Frequency Response 119
TEST_16. RX Audio Distortion 120
TEST_17. RX Hum and Noise 121
```

TEST_18. RX SINAD 122

```
TEST_19. RX FVC Order Message Error Rate 124
TEST_20. CP Release 125
TEST_21. CP Origination 126
TEST_22. OT No Audio Functional 127
TEST_23. TX Quick General 128
TEST_24. RX Quick General 129
TEST_25. CP Flow Chart 130
TEST_26. TX Switch Channels 132
TEST_27. CP Hook Flash 133
TEST_28. TX DTMF Frequency Error 134
TEST_29. RX MRI 135
Test Parameter Descriptions 136
Parameter 1. AA Enter Ph#? [0=If Needed, 1=Always, Here] 137
Parameter 2. AB MIN From? [0=RECC, 1=All 0's, 2=Phone
#] 138
Parameter 3. CP Control Channel [1:799] or [991:1023] 139
Parameter 4. CP DSAT Vector [0 thru 6] 140
Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail] 141
Parameter 6. CP SAT Tone 142
Parameter 7. CP SID Number 143
Parameter 8. RC Compandor is Always On 144
```

Parameter 9. RT External Path Loss 145
Parameter 10. RT High Supply Voltage 146
Parameter 11. RT Low Supply Voltage 147
Parameter 12. RT Nominal Supply Voltage 148
Parameter 13. RT Test at Extreme Settings [0=no 1=yes] 149
Parameter 14. RT use DUPLEX OUT & ANT IN 150
Parameters 15-17. RX Audio Response Start, Step, and Stop Frequencies 151
Parameters 18-20. RX Expandor Start, Step, and Stop Levels 152
Parameter 21. RX FVC Message Error Rate RF Level 153
Parameters 22-24. RX MRI Start, Step, and Stop Levels 154
Parameter 25. RX NAMPS RF Level for SINAD 155
Parameter 26. RX NAMPS RF Level for SINAD at Extremes 156
Parameter 27. RX RF Level for Signaling 157
Parameter 28. RX RF Level for SINAD 158
Parameter 29. RX RF Level for SINAD at Extremes 159
Parameter 30. RX Set Audio Level 160
Parameter 31. RX Tolerance for Setting Audio Level 161
Parameters 32-34. TX Audio Response Start, Step, and Stop Frequencies 162
Parameters 35-37. TX Compressor Start, Step, and Stop Levels 163

Farameter 56. 1A Current Dram Levels Tested 104	
Parameter 39. TX Frequency Deviation Step Frequency 165	
Parameter 40. TX Mod Dev Limit 50 Hz HPF [0=off 1=on] 166	
Parameter 41. TX Output Power Levels Tested 167	
Parameters 42-44. TX Switch Channels Start, Step, and Stop Channel 168	
Parameter 45. TX TS Atten for Signaling 169	
Parameter 46. TX Units for Power Meas [0=dBW 1=Watts] 170	
Parameter 47. TX Voltage for Compressor Zero Crossing 171	
Parameter 48. TXT Trnsient/SS Data 172	
Pass/Fail Limit Descriptions (Specifications) 173	
Pass/Fail Limit 1. RX Audio Distortion 174	
Pass/Fail Limit 2. RX Audio Response Dev from -6 dB/oct R1 175	
Pass/Fail Limit 3. RX Audio Response Dev from -6 dB/oct R2 176	
Pass/Fail Limit 4. RX Expandor Track Error < 0 177	
Pass/Fail Limit 5. RX Expandor Track Error > 0 178	
Pass/Fail Limit 6. RX Expandor Zero Reference Level 179	
Pass/Fail Limit 7. RX Hum and Noise 180	
Pass/Fail Limit 8. RX NAMPS Expandor Zero Reference Level 181	
Pass/Fail Limit 9. RX Order Message Error Rate (OMER) 182	

Pass/Fail Limit 10. RX SINAD 183
Pass/Fail Limit 11. TX Audio Distortion 184
Pass/Fail Limit 12. TX Audio Response Dev From 6 dB/oct 185
Pass/Fail Limit 13. TX Audio Response Roll >2.5 kHz 186
Pass/Fail Limit 14. TX Compressor Min Out @ >17.6 dB In 187
Pass/Fail Limit 15. TX Compressor Track Error < 0 188
Pass/Fail Limit 16. TX Compressor Track Error >0 189
Pass/Fail Limit 17. TX Compressor Zero Reference Deviation 190
Pass/Fail Limit 18. TX Current Drain @ Levels 0-3 191
Pass/Fail Limit 19. TX Current Drain @ Levels 4-7 192
Pass/Fail Limit 20. TX DTMF Frequency Error 193
Pass/Fail Limit 21. TX FM Hum and Noise 194
Pass/Fail Limit 22. TX Frequency Error 195
Pass/Fail Limit 23. TX Modulation Limiting 196
Pass/Fail Limit 24. TX NAMPS Compressor Zero Reference Deviation 197
Pass/Fail Limit 25. TX NAMPS DSAT Closure 198
Pass/Fail Limit 26. TX NAMPS DSAT Deviation 199
Pass/Fail Limit 27. TX NAMPS DSAT Phase Jitter 200
Pass/Fail Limit 28. TX NAMPS Modulation Limiting 201
Pass/Fail Limits 29–36. TX Output Power @ Levels 0–7 202

Pass/Fail Limit 37. TX SAT Deviation 204	
Pass/Fail Limit 38. TX SAT Frequency Error 205	
Pass/Fail Limit 39. TX Signaling Tone Deviation 206	
Pass/Fail Limit 40. TX Signaling Tone Frequency 207	
Pass/Fail Limit 41. TX Wideband Data Deviation 208	
Pass/Fail Limit 42. TXT Wideband Data Deviation Transient	209

5 Reference (Alphabetical) Conventions Used 212 Copying Files 213 Data Collection (Saving and Retrieving Test Results) 215 Disks 225 Exiting a Program 227 HP-IB Control Annunciators 228 Memory Cards 229 Parameters 237 Pass/Fail Limits (specifications) 238 Pausing or Stopping a TEST 240 Printing 241 Procedures 255 RAM Disk 261 Saving Tests Results 264 Serial Port 265 Test Execution Conditions 267

USER Keys 269

6 Problem Solving

If You Have a Problem Testing Your Radio 272
If the test procedure doesn't run on an test set 273
If the HP 11807A,E program was incorrectly loaded 274
If the printer does not print the test results 275
If you can't get the data-collection function to work 277
If the cellular phone fails to obtain service 279
If the cellular phone registers, but won't page 280
If the cellular phone fails the audio tests 281
If a cellular phone links up with a system, not the test set 282

Glossary 283

Index 287

Product Description

HP 11807A,E Software

The HP 11807A,E Option 004, Radio Test Software is used for automated testing of cellular phones. Software is written on One-Time Programmable (OTP) memory cards shown below. The test set's built-in computer (operating with HP Instrument BASIC programming language) allows automated measurements for manual, quick-functional, or full-parametric testing.

- Manual, quick-functional and full-parametric testing of cellular phones is done using pre-written test procedures on each OTP memory card.
- Also, user-defined test procedures may be created to meet your radio-specific testing needs. The user-defined test procedures are saved onto the Static Random-Access Memory (SRAM) memory card which is provided with each HP 11807A, E option.

Materials Included in This Package

This package contains the following materials. Verify that all the materials are present and inspect them for damage. If a part is missing or appears to be damaged, contact your nearest Hewlett-Packard sales or service office.

- HP 11807A Option 004 Test Software (part number 11807-10004) OR HP 11807E Option 004 Test Software (part number 11807-10023).
- SRAM memory card (uninitialized), for saving your own test procedures and results.
 - For HP 11807A, 32 Kbyte SRAM (part number HP 85700A).
 - For HP 11807E, 64 Kbyte SRAM (part number HP 83230A).
- HP 11807A,E Option 004 Software Reference Guide (part number 11807-90119).
- HP software product license agreement.

Additional Equipment Required

- HP 8920A,B,D RF Communications Test Set. The HP 11807A,E Option 004 software requires the test set to be configured with the following hardware:
 - HP 8920A Option 005: 512 Kbyte RAM Memory extension
 - HP 8920 Option 004: Tone/Digital Signaling
- The Test Set firmware revision must be A.06.11 or higher (A.06.12 will not work). Firmware revision A.07.03 or higher is recommended.

Recommended Equipment

Other hardware configurations for your HP 8920A,B are recommended, but not required:

- HP 8920 Option 001: High-Stability Timebase
- HP 8920 Option 013: C-Message Weighting Filter (HP 8920 Option 011 may also be used in place of C-Message)
- HP 8920 Option 014: 6 kHz Bandpass Filter

External Power Supplies

An external dc power supply for the cellular phone can be configured to the

HP 8920A,B in one of three ways:

- 1. A power supply or battery can be connected directly to the cellular phone.
- **2.** A power supply can be connected to the rear-panel DC CURRENT MEASUREMENT banana-plug connectors. (This requires the HP 8920A Option R03, HP-IB/RS-232/Current Measurement.)
- **3.** A power supply can be controlled by the test set when it is connected to the HP-IB connector. (This requires the HP 8920A,D Option R03, HP-IB/RS-232/Current Measurement.)

HP-IB programmable power supply from the following series are supported for external control:

HP 664xA HP 665xA HP 667xA HP 668xA

NOTE:

The HP 662xA and HP 663xA series dc power supplies do not use SCPI commands and are not supported.

Available Tests

The following tests can be performed with this software:

- CP Registration
- CP Page
- TX Frequency Error
- TX RF Power Output
- TX Modulation Deviation Limiting
- TX Audio Frequency Response
- TX Audio Distortion
- TX Signaling Tone/DST
- TX FM Hum and Noise
- TX SAT/DSAT
- TX RVC Data Deviation
- TX Compressor Response
- TX Current Drain
- RX Expandor
- RX Audio Frequency Response
- RX Audio Distortion
- · RX Hum and Noise
- RX SINAD
- RX FVC Order Message Error Rate
- CP Release
- CP Origination
- OT No Audio Functional
- TX Quick General
- RX Quick General
- CP Flow Chart
- TX Switch Channels
- CP Hook Flash
- TX DTMF Frequency Error
- RX MRI

Finding the Information You Need

This manual describes the setup and use of the HP 11807A,E Software with the HP 8920A,B,D Test Set. The book is arranged in self-contained chapters to provide the following information:



PRODUCT DESCRIPTION CHAPTER 1



USING THE SOFTWARE-CHAPTER 2

- Instructions for cabling test set.
- How to load
- How to run
- How to customize



TEST DESCRIPTIONS-CHAPTER 4

Definitions, special conditions and restrictions for:

- Tests
- Pass/fail limits
- $\bullet \, \mathsf{Parameters}$



REFERENCE-CHAPTER 5


- Alphabetically listed
- Detailed descriptions of all the features and functions of the software.
- For the advanced level user.



PROBLEM SOLVING-CHAPTER 6

- Alphabetically listed
- Symptoms and possible corrections to frequent user problems.

Additional Services Available





Consult the HP~8920A, B~User's~Guide~ or call the HP 8920A, B, D Hotline 1-800-922-8920 (in the USA and Canada only) and give your software model number.

Chapter 1, Product Description Additional Services Available

Using the Software/HP 8920B, or HP 8920A FW Above rev A.14.00

NOTE:

The firmware revision A.14.00 in the HP 8920A,D had several enhancements, which are standard in the HP 8920B. This chapter applies to users with:

- HP 8920A test sets with firmware revision above A.14.00
- All HP 8920B test sets.

The test set's firmware revision is displayed on the top right corner of the configuration screen.

 Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8920A with firmware revision below A.14.00, refer to **Chapter 3, "Using the Software/HP 8920A FW Rev Below A.14.00"**. Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

The software can be run on the factory default settings or customized to your individual needs and specific requirements. This chapter provides detailed information on how to load, run, and customize the software.

The test set has two methods of accessing on-line help. In each of the screens in the test environment, k4 (Help) accesses specific information about how to set up/use the current screen. SHIFTHELP accesses the master help file, with an alphabetical listing of help topics.

Testing Overview

Pressing TESTS will display what is called the **TESTS** (Main Menu) screen. To begin testing, you must first load the software and make connections. From this screen you have the option to:

Begin running tests:


- · The factory default settings are acceptable for your application or
- The software has already been customized and saved to a memory card

Customize the software:

- Decide which tests you desire to run (Order of Tests)
 - you may want to run all, some, or just one of the tests.
- Specify which channels to test (Channel Information)
 - you may want to test one, some, or all of the channels on your radio.
- Change the pass/fail limits for specific measurements (Pass/Fail Limits)
 - you may want the pass/fail limits to have tighter or looser specifications than the default settings.
- Change the test environment and conditions (Test Parameters)
 - decide output format.
 - enter specific information about radio equipment and/or environment.
- Save any or all of the above customized changes to a memory card (Save/Delete Procedure)

Set Up Test Set:


- Print test results or certain screens.
- Decide when and where test results are displayed (Execution Conditions/ Printer Setup)




29

Setting Up the Test Set and Making Connections

Before you begin testing, you must set up the test set and make the appropriate hardware connections.



Making a Connection



Selecting a Test Procedure


To load the software, you must first select the location to load from (in this case, it will be Card) and a procedure filename. Your card comes pre-programmed with at least one procedure. The actual software program does not get loaded into the test set's memory until k1 (Run Test) is selected. It will take approximately 15 seconds to load the software in an HP 8920B, and approximately two minutes in an HP 8920A,D.

The software memory card can be removed after the program is loaded into the test set's memory. The program will remain in memory after a power-down/power-up cycle, unless it is manually deleted or a new program is loaded.

When tests begin to run, they are executed in the order in which they were entered into the Test Procedure.

Pressing CANCEL will pause the current test (press k2 to continue the test.)

Selecting A Test Procedure



Customizing Testing

Because of the diversity of individual testing needs, the software has been designed so that changes may be easily made from the test set's front panel. You may store these changes on a memory card so that you may skip these steps in the future. See "Saving a Test Procedure" on page 52.

Because your needs change, the software allows changes to its default settings whenever you need to make them. For example, tests may be inserted or deleted, and later after running the tests you can change the pass/fail limits or decide to test different channels.


Most testing customization is accomplished through the customization screens. These customization screens are accessed from the main **TESTS** (Main Menu) screen as shown in the following figure. Customizing procedures is explained later in this chapter.

NOTE:

External Devices, Printer Setup, and IBASIC will not be explained in this customizing section.

- External Devices and Printer Setup are used when setting up printers and external disk drives which is explained in *Disks* and *Printing* in chapter 4.
- IBASIC is used when writing your own programs and is not explained in this manual.
 If you need to write your own IBASIC programs you may acquire the following manuals:
 - HP 8920A.D
 - *HP Instrument Basic User's Handbook* HP part number E2083-90000.
 - HP 8920A Programming Manual HP part number 08920-90220.
 - HP 8920B
 - HP Instrument Basic User's Handbook Version 2.0 HP part number E2083-90005.
 - HP 8920B Programming Manual HP part number 08920-90222.

How to Customize Testing



35

Changing the Order of Tests


You may define the order of tests to include all, some, or just one of the tests available. When the first test is finished, the next will run. The test sequence will remain in the test set's battery backed-up memory until another test sequence is loaded or set up. For information on saving a customized test sequence, see "Saving a Test Procedure" on page 52.


Defining the order of tests is accomplished by inserting or deleting tests from the list of tests that come with the software package. See "Test, Parameter, and Pass/Fail Limit Descriptions" in chapter 4, for descriptions of tests included in this package.


The All Chans? field allows the user to decide to run the test on all channels entered in the Channel Information table, or just the channels which are selected as Prime in the Channel Information screen. This feature allows the user the flexibility to use channels that are selected as Prime in all the tests in the sequence, and those indicated as non-prime in a subset of tests (those tests with a Yes response in All Chans). For more information, see "Specifying Channel Information" on page 40.

The following describes how to create a new test sequence and enter a response to the All Chans? field.

How to Change the Order of Tests







Specifying Channel Information

For each channel that you wish to specify, you must enter the following information into the **Channel Information** screen:

- Cell Channel
 - Enter the cell channel number.
 - For narrow channels (NAMPS only), specify lower, middle, or upper channel by appending an "L", "M", or "U" after the channel number. Example: For narrow lower channel 156 enter 156L in the channel information screen.
- Options
 - For the last channel that you want tested in the **Channel Information** table, select **Options** and using the characters in the **Choices** menu enter **END**. This will speed up the testing time (so the software will not scan through the entries that are blank in the **Channel Information** screen).
- Test? (yes/no) specifies whether you want to test the UUT at this channel. If set to "No" then the UUT will not be tested at that channel, but you may retain the channel information in the table for later use. If set to "Yes" then the channel will be used as defined by settings of Prime? and All Chans? fields.
- Prime? (yes/no) specifies which channels are "prime". Select "Yes" if you want to test the UUT at this channel on all the tests in the procedure. Select No if you want to test the UUT at this channel on just a subset of tests, which are designated by selecting Yes in the All Chans field of the Order of Tests screen. See All Chans? in "How to Change the Order of Tests" on page 37 for more information.

For information on saving the channel information table, see "How to Save a Test Procedure" on page 53.

The All Chans field in the Order of Tests screen interacts closely with the Prime? field on the Channel Information screen. When the software runs, it begins by retrieving the first channel entered into the Channel Information screen. It then checks the response in the Test? field to determine if the UUT should be tested at that channel at this time. If there is a No response in the Test? field, the software will go to the next channel in the table. If there is a Yes response in the Test? field, the software will check if the channel is Prime.

A Yes response in the Prime? field indicates to test the UUT at that channel on the entire sequence of tests in the procedure. A No response in the Prime? field indicates to test the UUT at that channel on a subset of tests in the procedure. The subset of tests is determined by a Yes response in the All Chans? field. Therefore, tests with a No response in the All Chans? field will be run on prime channels only.

Below is an example of how the software would run if you had a procedure set up as follows

Chan #	Test?	Prime?
Chan 01	Yes	Yes
Chan 02	Yes	No
Chan 03	No	No

Test Number	All Chan? Setting
Test 01	No
Test 02	Yes
Test 03	Yes
Test 04	No


The result would be:


- Chan 01 is used in Test 01, Test 02, Test 03, and Test 04.
- Chan 02 is used in Test 02, and Test 03 only.
- Chan 03 is not used.


The following table shows how to properly configure these settings according to your testing needs.


Togting Nood	Necessary Field Settings			
Testing Need	Test?	Prime?	All Chan?	
Test channel on all tests in sequence	Yes	Yes	Don't Care	
Test channel on a subset of tests in sequence	Yes	No	Yes on tests you want included in the testing subset	
Do not test this channel now, but retain information for later use	No	Don't Care	Don't Care	

How to Specify Channel Information












Repeat steps 3-8 for each Cell Channel you are entering. When you have completed entering all channels, go to step 9.









Changing Pass/Fail Limits

Pass/Fail limits define the values a measurement's result is compared against to determine if the UUT meets its specified standards. Default values are set in the test software. These default values may be changed to suit your particular requirements.


The following describes how to change the pass/fail (upper and lower) limits. See "Pass/Fail Limit Descriptions (Specifications)" on page 173 for descriptions of each pass/fail limit. For information on saving customized pass/fail limits, see "Saving a Test Procedure" on page 52.

How to Change Pass/Fail Limits








The Pass Fail Limits screen is now present on your CRT.



Continue on next page









Changing the Test Parameters

The software uses parameters to optimize the test environment and conditions for your testing situation. Many of the test parameters are determined by examining your test needs. The software comes with default settings for test parameters. Review the defaults for your particular needs. See "Test Parameter Descriptions" on page 136 for descriptions of each test parameter. For information on saving customized test parameters, see "Saving a Test Procedure" on page 52.


The following describes how you can change test parameters through the Test Parameter screen to optimize your testing conditions.


How to Change the Test Environment and Conditions








Continue on next page











Saving a Test Procedure


A Test Procedure is a collection of channel information, test parameters, testing order, and pass/fail limits saved in a file that customizes the test software to a specific application. You may save the file to a memory card or disk.

When you save a procedure you will be saving channel information, test parameters, pass/fail limits, and testing order, plus a library that contains the names of all test parameters, pass/fail limits, and tests that are resident in the software. The library file comes from the software and cannot be modified. The library file will be automatically saved on the card or disk that is being used to store the new test procedure.

The following example shows how to save a new procedure to a memory card. For more information concerning procedures, see"Procedures" on page 255.

How to Save a Test Procedure

Select





RAM Disk


(You can also save procedures


to an internal RAM disk or external


disk drive. See chapter 4-Disks.)











15

To run the saved procedure, follow the instructions below.

- 1) Insert the RAM card with your saved procedure.
- 2) On the TESTS (Main Menu) screen, a) position cursor and select Select Procedure Location:, then select Card, b) position cursor and select Select Procedure Filename:, then select your saved file name.
- 3) Remove your RAM card and insert the original HP 11807B ROM memory card.
- 4) Press Run Test.

The original card contains the full program needed to run your procedure.

PROCMA3

Changing Test Execution Conditions

Test Execution Conditions define where and when test output occurs. You may decide to:

• Display output on CRT only, or display on CRT and print hardcopy (Output Results To).

NOTE:


If printing test results is desired, after selecting **Printer**, additional steps are necessary to connect and configure the printer. See "**Printing**" on page 241.


- Display (or print) only measurements that fail, or display (or print) all measurements that pass or fail (Output Results For).
- Enter a title for an output heading for the displayed or printed results (Output Heading).
- Stop testing when a measurement fails or continue through all of the tests without stopping (If Unit-Under-Test-Fails).
- Pause between each measurement, or run through entire test (Test Procedure Run Mode).
- Start the program automatically when the Test System is powered on. (Autostart Test Procedure on Power-up)

Test Execution Conditions is accessed from the **SETUP TEST SET:** list. To change a default setting, position the cursor to the desired field. Pressing the knob ("selecting") will toggle the underlined selection.

Test Execution Conditions settings are not retained after a power-down/power-up cycle, and will return to their default settings.

How to Change Test Execution Conditions





Printing and Saving Test Results

Printing and saving test results are features of the software which require additional equipment and configuration. See "Printing" on page 241 for detailed descriptions and instructions for these features.

Chapter 2, Using the Software/HP 8920B, or HP 8920A FW Above rev A.14.00 Customizing Testing			

Using the Software with F Below Rev. A.14.00

Using the Software/HP 8920A FW Rev Below A.14.00

NOTE:

The firmware revision A.14.00 in the HP 8920A,D had several enhancements, which are standard in the HP 8920B. This chapter applies to users with:

• HP 8920A test sets with firmware revision below A.14.00

The test set's firmware revision is displayed on the top right corner of the configuration screen.

 Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8920B or an HP 8920A with firmware revision above A.14.00, refer to **chapter 2**, "**Using the Software/HP 8920B**, **or HP 8920A FW Above rev A.14.00," on page 25**. Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

The HP 11807A software can be run on the factory default settings or customized to your individual needs and the specific requirements. This chapter provides detailed information on how to load, run, and customize the software.

Testing Overview

Pressing TESTS will display what is called the **TESTS** screen. To begin testing, you must first load the software and make connections. From this screen you have the option to:

Begin running tests:

- The factory default settings are acceptable for your application or
- · The software has already been customized and saved to a memory card


Customize the software:

- Decide which tests you desire to run (Edit Seqn)
 - you may want to run all, some, or just one of the tests.
- Specify which channels to test (Edit Freq)
 - you may want to test one, some, or all of the channels on your radio.
- Change the pass/fail limits for specific measurements (Edit Spec)
 - you may want the pass/fail limits to have tighter or looser specifications than the default settings.
- Change the test environment and conditions (Edit Parm)
 - decide output format.
 - enter specific information about radio equipment and/or environment.
- Save any or all of the above customized changes to a memory card (Proc Mngr)

Set Up Test Set:


- · Print test results or certain screens.
- Decide when and where test results are displayed (Edit Cnfg)

To Run Tests




Setting Up the Test Set and Making Connections

Before you begin testing, you must set up the test set and make the appropriate hardware connections.



Making a Connection



Selecting a Test Procedure

To load the software, you must first select the location to load from (in this case, it will be Card) and a procedure filename. Your card comes pre-programmed with at least one procedure. The actual software program does not get loaded into the test set's memory until k1 (Run Test) is selected. It will take approximately 2 minutes to load the software in an HP 8920A,D.

The software memory card can be removed after the program is loaded into the test set's memory. The program will remain in memory after a power-down/power-up cycle, unless it is manually deleted or a new program is loaded.

When tests begin to run, they are executed in the order in which they were entered into the Test Procedure.

Pressing CANCEL will pause the current test (press k2 to continue the test.)

Loading a Software Upgrade, FW below rev A.12.04 only

If you have purchased a software upgrade from the factory and are loading it for the first time, you must clear the old revision software from the test set memory before running the new revision software. If you do not, the new revision will not be loaded, and the old revision will be used. This is for FW below revision A.12.04 only. For firmware revision A.12.04 and above, the test set will check for differences in the code, and automatically load the most updated version.


The easiest way to clear the old revision software is to load a different software program. The LIST_OPTS program that is stored in internal ROM can be used for this purpose.

To Load the

- 1. Press TESTS.
- LIST_OPTS Program: 2. Position the cursor to Select Procedure Location and select it.
 - 3. From the Choices menu, select ROM.
 - 4. Position the cursor to Select Procedure Filename and select it.
 - 5. From the **Choices** menu, select **LIST_OPS**.
 - 6. Press k1 (Run Test.)

The new revision software can now be loaded.

Selecting A Test Procedure



Chapter 3 Using the Software with FN Relow Rev. A 14 00

Customizing Testing

Because of the diversity of individual testing needs, the software has been designed so that changes may be easily made from the test set's front panel. You may store these changes on an SRAM card so that you may skip these steps in the future. See "Saving a Test Procedure Using the Procedure Manager" on page 86.

You may customize your software at any time. Because your needs change, the software allows changes to its default settings when you need to make them and in any order that you choose. For example, tests may be inserted or deleted, and later after running the tests you can change the pass/fail limits or decide to test different channels.


Most testing customization is accomplished through the test set's Test Function screens. These Test Function screens are accessed from the main **TESTS** screen as shown in the following figure. All Test Functions are explained in this chapter by function.

NOTE: Edit Cnfg and IBASIC will not be explained in this customizing section.

- Edit Cnfg is used when setting up printers and external disk drives which is explained in "Disks" on page 225 and "Printing" on page 241.
- IBASIC is used when writing your own programs and is not explained in this manual. If you need to write your own IBASIC programs you may acquire the following manuals:
 - HP 8920A,D
 - HP Instrument BASIC User's Handbook HP part number E2083- 90000.
 - HP 8920A Programming Manual HP part number 08920-90220.
 - HP 8920B
 - *HP Instrument BASIC User's Handbook Version 2.0* HP part number E2083-90005.
 - HP 8920B Programming Manual HP part number 08920-90222.

Beginning Software Customization

All software customization begins by accessing the **TESTS** screen first and then selecting the **Test Function** which will open the **Choices** menu. To access the **TESTS** screen, press TESTS on the front panel of the test set.



Using the Software with FM Below Rev. A.14.00

Changing the Order of Tests (Edit Sequence)


You may define a test sequence to include all, some, or just one of the tests available. When the first test is finished, the next will run. The test sequence will remain in the Test System's battery backed-up memory until another test sequence is loaded or set up. For information on saving a customized test sequence, see "Printing and Saving Test Results" on page 91.

Creation of a test sequence is accomplished by inserting or deleting tests from the list of tests that come with the HP 11807A software package. See chapter 4, "Test, Parameter, and Pass/Fail Limit Descriptions," on page 93 for test descriptions.


The All Chans? field allows the user to decide to run the test on all channels entered in the frequency table, or just the channels which are selected as Prime in the Edit Freq screen. This feature allows the user the flexibility to use channels that are selected as Prime in all the tests in the sequence, and those selected as non-prime in a subset of tests (those with a Yes response in All Chans). For more information, see "Specifying Channel Information (Edit Frequency)" on page 75.


The following describes how to create a new test sequence and enter a response to **All Chans**.

How to Change a Sequence of Tests









Specifying Channel Information (Edit Frequency)

For each channel that you wish to specify, you must enter the following information into the **Edit Frequency** screen:

- RX Chan Info
 - Enter the channel number of the voice channel to be tested.
 - For narrow channels (NAMPS only), specify lower, middle, or upper channel by appending an "L", "M", or "U" after the channel number. Example: for narrow lower channel 156 enter 156L in the edit frequency screen

NOTE:

The RX Freq and TX Freq fields are not used for entering cellular channel frequencies.

- **Test?** (yes/no) specifies whether you want to test the UUT at this channel. If set to "No" then the UUT will not be tested at that channel, but you may retain the channel information in the table for later use. If set to "Yes" then the channel will be used as defined by settings of **Prime?** and **All Chans?** fields.
- Prime? (yes/no) specifies which channels are "prime". Select "Yes" if you want to test the UUT at this channel on all the tests in the procedure. Select No if you want to test the UUT at this channel on just a subset of tests, which are designated by selecting Yes in the All Chans field of the Edit Seqn screen. See All Chans? in "Changing the Order of Tests (Edit Sequence)" on page 71 for more information.

For information on saving the frequency table, see "Saving a Test Procedure Using the Procedure Manager" on page 86.

Using the Software with FI
Below Rev. A.14.00

The All Chans field in the Edit Seqn screen interacts closely with the Prime? field on the Edit Freq screen. When the software runs, it begins by retrieving the first channel entered into the Edit Freq screen. It then checks the response in the Test? field to determine if the UUT should be tested at that channel at this time. If there is a No response in the Test? field, the software will go to the next channel in the table. If there is a Yes response in the Test? field, the software will check if the channel is Prime.

A Yes response in the Prime? field indicates to test the UUT at that channel on the entire sequence of tests in the procedure. A No response in the Prime? field indicates to test the UUT at that channel on a subset of tests in the procedure. The subset of tests is determined by a Yes response in the All Chans? field. Therefore, tests with a No response in the All Chans? field will be run on prime channels only.

Below is an example of how the software would run if you had a procedure set up as follows:

Chan #	Test?	Prime?
Chan 01	Yes	Yes
Chan 02	Yes	No
Chan 03	No	No

Test Number	All Chan? Setting
Test 01	No
Test 02	Yes
Test 03	Yes
Test 04	No


The result would be:


- Chan 01 is used in Test 01, Test 02, Test 03, and Test 04.
- Chan 02 is used in 02, and Test 03 only.
- Chan 03 is not used.


The following table shows how to properly configure these settings according to your testing needs.


Testing Need	Necessary Field Settings			
	Test?	Prime?	All Chan?	
Test channel on all tests in sequence	Yes	Yes	Don't Care	
Test channel on a subset of tests in sequence	Yes	No	Yes on tests you want included in the testing subset	
Do not test this channel now, but retain information for later use	No	Don't Care	Don't Care	


How to Specify Channel Information












Chapter 3 Using the Software with FM Below Rev. A.14.00


Changing Pass/Fail Limits (Edit Specifications)


Specifications are values that set pass/fail limits for tests. Default values are available in the test software. These default values may be changed to suit your particular requirements.


The following describes how to change the pass/fail (upper and lower) limits in the HP 8920A,D Edit Specification screen. See "Pass/Fail Limit Descriptions (Specifications)" on page 173 for descriptions for each specification. For information on saving customized specifications, see "Saving a Test Procedure Using the Procedure Manager" on page 86.


How to Change Pass/Fail Limits



















Changing the Test Environment and Conditions (Edit Parameters)

The software uses parameters to optimize the test environment and conditions for your testing situation. Many of the parameters are determined by examining your test needs. Other parameters are determined by performing measurements to calibrate items in your system. Examples of parameters include cable losses, rated system deviation, and the audio test tone frequency your system requires. The HP 11807A software comes with default settings for parameters. The defaults should be reviewed for your particular needs. See "Test Parameter Descriptions" on page 136 for descriptions and default values for each parameter. For information on saving customized parameters, see "Saving a Test Procedure Using the Procedure Manager" on page 86.


The following describes how you can change parameters through the Edit Parameter screen to optimize your testing conditions.


How to Change the Test Environment and Conditions





















Saving a Test Procedure Using the Procedure Manager


A Test Procedure is a collection of pass/fail limits (specifications), the test environment and conditions (parameters), and a TEST sequence, saved in a file that customizes the test software to a specific application. You may save the file to a memory card or disk.


When you save a Procedure you will be saving parameters, specifications, and a test sequence, plus a library that contains the names of all parameters, specifications, and tests that are resident in the HP 11807A software. The library file comes from the HP 11807A software and cannot be modified. The library file will be automatically saved on the card or disk that is being used to store the new test procedure.


The following example shows how to save a new procedure to a memory card. For more information concerning procedures, see "Procedures" on page 255.


How to Save a Test Procedure


















Continue on next page









To run the saved procedure:

- 1) Load the Procedure.
- 2) Insert the original HP 11807B memory card.
- 3) Press Run Test.

The original card contains the full program needed to run your procedure.

Chapter 3
Using the Software with FN
Below Rev. A.14.00

Changing Test Execution Conditions

Test Execution Conditions define how your testing program starts and where and when test output occurs. You may decide to:

- Start the program automatically when the Test System is powered on. (Autostart)
- Stop testing when a measurement fails or continue through all of the tests without stopping. (On UUT Failure)
- Display (or print) only measurements that fail, or display (or print) all measurements that pass or fail. (Output Results)
- Pause between each measurement, or run through the entire test sequence. (Run Mode)
- Display output on CRT only, or display on CRT and print hardcopy. (Output Destination)

NOTE:


If printing test results is desired, after selecting **Printer** additional steps are necessary to connect and configure the printer. See "**Printing**" on page 241.

• Enter a title for an output heading for the displayed or printed results. (Output Heading). Select the field with the knob and enter the output heading by selecting the appropriate letters and the select Done.

Test Execution Conditions is located on the **TESTS** screen. Press TESTS to display them. To change a default setting, position the cursor to the desired field. Pressing the knob ("selecting") will toggle the underlined selection.

Test Execution Conditions settings (except for **Autostart**) are not retained after a power-down/ power-up cycle, and will return to their default settings. They are not stored on the memory card when a test procedure is saved.

How to Change Test Execution Conditions



Printing and Saving Test Results

Printing and saving test results are features of the HP 11807A software which require additional equipment and configuration. See "Printing" on page 241 for detailed descriptions and instructions for these features.

Chapter 3, Using the Software	e/HP 8920A FW Rev Below A.14.00
Customizing Testing	

Test, Parameter, and Pass/Fail Limit Descriptions

Introduction

Tests are a series of measurements, and one or more tests make up a procedure (see Chapter 2, "Using the Software/HP 8920B, or HP 8920A FW Above rev A.14.00," on page 25). While you may change the tests that make up a procedure, you may not change the measurements the test will perform. Generally, the order in which the tests are run is not important.

This chapter describes each test and the associated test parameters, pass/fail limits, and external equipment that are required. When you first load a test procedure or create a new test sequence, refer to this section to understand what test parameters and pass/fail limits are required for each test.

Tests are derived from the following industry standards:

• EIA – Electronic Industry Association, for 800 MHz Cellular Subscriber Units

EIA/IS-19-B EIA/TIA-90 EIA/TIA-553

NOTE:

Refer to chapter 2, "Using the Software/HP 8920B, or HP 8920A FW Above rev A.14.00" or chapter 3, "Using the Software/HP 8920A FW Rev Below A.14.00" in this manual for details about customizing a Test Procedure for testing your cellular phone.

TEST_01. CP Registration

This test reads the phone's Reverse Control Channel (RECC) data and outputs the following registration information:

Phone number.

Serial number.

Power class.

Transmission (continuous or discontinuous).

Bandwidth (20 MHz or 25 MHz).

A registration must be performed before any tests can be run, otherwise the operator is prompted to enter the UUT phone number during testing.

The test works as follows:

- The test set transmits the Registration ID message repeatedly, with the value of the REGID field set alternately to 0 and 500. This induces the phone to register with the test set
- If an error occurs in this test, all testing is stopped.

A CP registration test must be run at least once before any call processing tests can be run, otherwise the operator is prompted to enter the UUT phone number during testing. After CP registration is run once it does not need to be run again for the test set to be able to perform other tests. The registration data is remembered unless it is erased by loading new test software, registering a different radio, or executing a SCRATCH C command in IBASIC.

Pass/Fail Limits Used

none used

Test Parameters Used

- Parameter 1. AA Enter Ph#? [0=If Needed, 1=Always, Here]
- Parameter 3. CP Control Channel [1:799] or [991:1023]
- Parameter 4. CP DSAT Vector [0 thru 6]
- Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail]
- Parameter 6. CP SAT Tone
- Parameter 7. CP SID Number
- Parameter 9. RT External Path Loss
- Parameter 12. RT Nominal Supply Voltage
- Parameter 14. RT use DUPLEX OUT & ANT IN
- Parameter 27. RX RF Level for Signaling
- Parameter 45. TX TS Atten for Signaling [0,20,40]

TEST_02. CP Page

This test simulates a call to the mobile phone from the base station. Specifically, this test does the following:

- 1. The test set acts as a base station and pages the UUT.
- 2. 3 of 5 majority voting on the Reverse Control Message is performed.
- 3. Reverse Control Channel (RECC) information received from the UUT is printed.
- **4.** BCH error detection and correction of the Reverse Control Message is performed.
- 5. Each section of the page response message is tested, bit by bit.
- 6. Sends an Initial-Voice-Channel-Designation order to the UUT, directing it to tune to a voice channel obtained from the Channel Information (or Edit Freq) table. If the channel number from the table has an L, M, or U suffix, the phone will be directed to a narrow voice channel. If the channel number has no suffix, the phone will be directed to a wide voice channel.
- 7. Sends an ALERT order to the UUT by way of the Forward Voice Channel (FVC).

Pass/Fail Limits Used

none used

Test Parameters Used

- Parameter 1. AA Enter Ph#? [0=If Needed, 1=Always, Here]
- Parameter 3. CP Control Channel [1:799] or [991:1023]
- Parameter 4. CP DSAT Vector [0 thru 6]
- Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail]
- Parameter 6. CP SAT Tone
- Parameter 7. CP SID Number
- Parameter 9. RT External Path Loss
- Parameter 12. RT Nominal Supply Voltage
- Parameter 14. RT use DUPLEX OUT & ANT IN [0=no 1=yes]
- Parameter 27. RX RF Level for Signaling
- Parameter 45. TX TS Atten for Signaling [0,20,40]

TEST_03. TX Frequency Error

This test measures the difference between the unmodulated carrier frequency and the assigned carrier frequency. TX frequency error is measured on a voice channel with voice modulation off, and SAT modulation on.

The frequency error is expressed in parts-per-million (ppm).

Pass/Fail Limits Used

Pass/Fail Limit 22. TX Frequency Error

Test Parameters Used

NOTE:

The following parameters are used only if an external power supply has been configured to be used over HP-IB by the test set:

Parameter 10. RT High Supply Voltage Parameter 11. RT Low Supply Voltage Parameter 12. RT Nominal Supply Voltage

Parameter 13. RT Test at Extreme Settings [0=no 1=yes]

TEST_04. TX RF Power Output

This test measures the power available at the output terminals of the transmitter when connected to a 50 ohm load. This test is performed at the nominal supply voltage and can also be performed with high and low supply voltages for extreme measurements if a power supply is configured to the test set.

This test requires a programmable power supply if high-supply and low-supply power measurements are to be made.

Output power is expressed in either dBW or W, as determined by parameter 46.

Pass/Fail Limits Used

NOTE:

Normally, all 8 power levels are tested; however, parameter 41 allows you to select only the levels you want tested.

Pass/Fail Limits 29–36. TX Output Power @ Levels 0–7

Test Parameters Used

```
Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail] (This test runs slower if parameter 5 is set to print RVC data.)

Parameter 9. RT External Path Loss

Parameter 10. RT High Supply Voltage

Parameter 11. RT Low Supply Voltage

Parameter 12. RT Nominal Supply Voltage

Parameter 13. RT Test at Extreme Settings [0=no 1=yes]

Parameter 14. RT use DUPLEX OUT & ANT IN [0=no 1=yes]

Parameter 41. TX Output Power Levels Tested [BWD #]

Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]
```

Testing Conditions Fixed by the Software

• The power-level pass/fail limits for Class II and III radios are fixed by the software.

TEST_05. TX Modulation Deviation Limiting

Modulation deviation limiting of the UUT transmitter is tested by performing the following steps. The PK+ detector is used during the first pass and then the steps are repeated using the PK- detector.

- 1. The audio generator frequency is set to 1 kHz.
- 2. The audio generator level is set to produce 8 kHz deviation by the UUT (3 kHz deviation for narrow analog operation).
- 3. The audio generator level is increased by 20 dB.
- **4.** Steps 2 and 3 are repeated 3 times, and the maximum peak frequency deviation is held and reported.
- 5. The audio generator frequency is stepped from 300 Hz to 3 kHz while the audio generator level is maintained at the 20 dB overdrive. Size of the frequency steps is obtained from parameter 39. (If parameter 39=0, then the test will run at 1 kHz only.) Peak frequency deviation is repeated at each step.

NOTE:

Audio connections from the radio to the test set are required for this test.

Pass/Fail Limits Used

Pass/Fail Limit 23. TX Modulation Limiting Pass/Fail Limit 28. TX NAMPS Modulation Limiting

Test Parameters Used

NOTE:

High and low supply voltages are measured only if an external power supply has been configured to be used over HP-IB by the HP 8920A and if parameter 13 is set to test at extremes.

Parameter 8. RC Compandor is Always On Parameter 10. RT High Supply Voltage Parameter 11. RT Low Supply Voltage Parameter 12. RT Nominal Supply Voltage

Parameter 13. RT Test at Extreme Settings [0=no 1=yes]
Parameter 39. TX Frequency Deviation Step Frequency

Parameter 40. TX Mod Dev Limit 50 Hz HPF [0=off 1=on]

TEST_06. TX Audio Frequency Response

This test measures how closely the frequency deviation of the transmitter follows a 6 dB/octave pre-emphasis slope over a given frequency range. (This test is intended to be used between the audio response frequencies of 300 Hz and 3 kHz only.)

NOTE:

Audio connections from the radio to the test set are required for this test.

The test results indicate the flatness of the audio output as frequency is varied. The UUT's compressor is not disabled during this test.

Audio frequency response is expressed in dB error from the 6 dB/octave preemphasis slope.

Pass/Fail Limits Used

Pass/Fail Limit 12. TX Audio Response Dev From 6 dB/oct Pass/Fail Limit 13. TX Audio Response Roll >2.5 kHz

Test Parameters Used

Parameter 8. RC Compandor is Always On Parameters 32-34. TX Audio Response Start, Step, and Stop Frequencies

Testing Conditions Fixed by the Software

- Audio frequency response is measured at 2.9 kHz peak deviation for wide voice channels and 1.5 kHz peak deviation for narrow voice channels.
- The frequency response measurement is made with the RMS detector and is made with respect to a 1 kHz reference rate.

TEST_07. TX Audio Distortion

This test measures the level of the demodulated carrier's audio distortion.

NOTE:

Audio connections from the radio to the test set are required for this test.

The test set does not have expandor circuitry. If your testing conditions require correction for this situation, you must change the limits set in pass/fail limit 11 as required.

Transmitter audio distortion is expressed in percent.

Pass/Fail Limits Used

Pass/Fail Limit 11. TX Audio Distortion

Test Parameters Used

Parameter 8. RC Compandor is Always On

Testing Conditions Fixed by the Software

- Audio distortion is measured at 8 kHz deviation and a 1 kHz rate.
- 3 kHz deviation is used for narrow voice channels.

The measurement is made with the peak + detector and the 750 μ s de-emphasis network.

• If present, the C-message or CCITT bandpass filter will be used. If not, the 50 Hz HPF and 3 kHz LPF will be used. (Because the SAT tone is only partially removed by the 3 kHz LPF, distortion readings with it may be about 4 dB too high).

TEST_08. TX Signaling Tone/DST

If the channel is a wide voice channel, this test measures the signaling tone's frequency and peak deviation. Since the SAT tone is always on in this test, deviation is measured with the RMS detector, with and without the signaling tone on. The peak deviation of the signaling tone is calculated from the two readings. Therefore, test results indicate peak deviation, not peak+ or peak-.

If the channel is a narrow voice channel, the peak deviation of the digital signaling tone (DST) is measured and the DST sequence is decoded and reported in hexadecimal.

Since this test is run in the "maintenance mode" where the base station is waiting for an answer, the operator must press the send key on the handset to exit the test.

Applications:

The signaling tone (ST) is a 10 kHz tone generated by the phone on a wide voice channel and is transmitted to the cell site for confirming orders (Alert, Audit, Change Power, etc.), and for signaling flash and release requests.

The digital signaling tone (DST) performs the same function on the narrow voice channel that ST performs on the wide voice channel. DST is a 24 bit digital sequence transmitted continuously at 200 NRZ bits/second and producing an average peak deviation of 700 Hz. Each DST sequence is the logical inverse of a corresponding DSAT sequence.

CAUTION:

If the channel is a narrow voice channel, an open microphone on your UUT can affect the results of this test. If your UUT has an open microphone, this test must be performed in a quiet environment.

Pass/Fail Limits Used

Pass/Fail Limit 26. TX NAMPS DSAT Deviation Pass/Fail Limit 39. TX Signaling Tone Deviation Pass/Fail Limit 40. TX Signaling Tone Frequency

Testing Conditions Fixed by the Software

- The SAT tone or DSAT is present throughout this measurement
- The measurement is made with the RMS detector and the 750 μs de-emphasis network is not used.
- The 300 Hz HPF and 3 kHz LPF will be used.
- The 230 kHz IF filter is used.

TEST_09. TX FM Hum and Noise

This test measures the ratio of residual frequency modulation to the standard test modulation.

NOTE:

Audio connections from the radio to the test set are required for this test.

CAUTION:

The test set does not have expandor circuitry. If your testing conditions require correction for this situation, you must change the limits set in pass/fail limit 21, typically 3 dB.

FM hum and noise is expressed in dB, from the formula:

 $-20 \times \text{Log}(\text{Reference Deviation} \div \text{Present Deviation})$

Pass/Fail Limits Used

Pass/Fail Limit 21. TX FM Hum and Noise

Test Parameters Used

Parameter 8. RC Compandor is Always On

Testing Conditions Fixed by the Software

- TX FM hum and noise is measured from a reference taken at 8 kHz peak deviation at a 1 kHz rate with a SAT tone present.
- For narrow analog operation, the reference is taken at 3 kHz peak deviation with DSAT active.
- The SAT tone or DSAT is present throughout this measurement.
- The AF Analyzer C-Message filter is enabled (if present), the detector is changed to RMS, and a 0 dB reference is set.
- The 1 kHz modulation is turned off, and the TX FM hum and noise is measured.
- The phone's microphone must be muted for best results.

The 750 µs de-emphasis network is on.

TEST_10. TX SAT/DSAT

If the channel is a wide voice channel, this test measures the frequency error and peak deviation of the three SAT tones. The rms detector is used for measuring SAT tone deviation and the reading is converted to peak.

Also, this test uses the 6 kHz BPF option if it is installed. (If there is no filter and the UUT has an open microphone, the readings may be affected by background noise. In this case, mute the handset.)

If the channel is a narrow voice channel, the test set transmits DSAT sequence #3=25AD4D in hexadecimal. The peak deviation of the DSAT returned by the phone is measured and reported. An eye-pattern test is performed on the DSAT and the closure and phase jitter are measured and reported.

Applications:

The supervisory audio tones (SAT) are 5970, 6000, and 6030 Hz tones used for signaling. One of the three tones is added to the wide channel voice transmission by a cell site. The radio then detects the tone and modulates the transmitted voice-channel carrier with a constant (relative) phase tone which is regenerated from the received tone to establish a closed loop between the mobile (cellular radio) and the cell site.

Transmission of the SAT is suspended during transmission of wideband data on the reverse voice channel (RVC), but is not suspended when the signaling tone (ST) is sent.

The digital supervisory tone (DSAT) performs the same function on the narrow voice channel that SAT performs on the wide voice channel. DSAT is a 24 bit digital sequence transmitted continuously at 200 NRZ bits/second and producing an average peak deviation of 700 Hz. Seven different sequences are defined.

NOTE: The phone's microphone must be muted for best results.

Pass/Fail Limits Used

Pass/Fail Limit 25. TX NAMPS DSAT Closure Pass/Fail Limit 26. TX NAMPS DSAT Deviation Pass/Fail Limit 27. TX NAMPS DSAT Phase Jitter Pass/Fail Limit 37. TX SAT deviation Pass/Fail Limit 38. TX SAT Frequency Error

Test Parameters Used

Parameter 4. CP DSAT Vector [0 thru 6]

TEST_11. TX RVC Data Deviation

This test provides three possible modes of operation, determined by parameter "Parameter 48. TXT Trnsient/SS Data" on page 172.

The first method, selected by setting parameter 48 to 0=tran, measures the Peak+ and Peak- frequency deviation of the data in the entire Reverse Voice Channel (RVC) burst to ensure that it is within the specified limits.

The entire burst is tested by sending the FVC message 5 times while the peak+hold detector is on, and another 5 times while the peak-hold detector is on.

The second method, selected by setting parameter 48 to 1=bth, first performs the test on just the steady state portion of the RVC data signal, followed by a test of the entire signal (described above).

The steady state portion of the test is performed by measuring the RVC data signal between 20 msec and 50 msec following the beginning of the data burst. The peak + and - results are compared to values in pass/fail limit 41 *TX wideband data deviation*. The results of the transient portion of the test are compared to values in the pass/fail limit 42 *TX wideband data deviation transient*.

The third method, selected by setting parameter 48 to 2=ss, performs the test on just the steady state portion of the RVC data signal (as described above).

NOTE:

In all three methods, the UUT should blank the SAT tone before sending the RVC message; therefore, SAT deviation should not be included in the deviation measurement. If the UUT has an open microphone, the readings may be affected by background noise. In this case, mute the handset.

NOTE:

The second and third test methods use trigger delay capabilities and can only be performed on an HP 8920B. If you are using an HP 8920A with HP 11807A, the software will ignore the setting of parameter 48 and perform the test using the first method only.

Using the first method, Hewlett-Packard Company has found that some cellular telephones fail this test because the telephones produce a carrier frequency transient at the beginning of wideband data transmission. This causes the peak frequency deviation to exceed the maximum specification of $\pm 8~\rm kHz$ $\pm 10\%$ (or a total of $\pm 8.8~\rm kHz$) specified in the EIA/IS-19-B Standard. This transient typically occurs during the first 10 milliseconds of the wideband data transmission from the telephone. The HP 11807A Option 004 software measures the FM peak deviation during the entire period while the telephone transmits its data and holds and displays only the highest positive and negative peaks detected. The HP Test Set has a fast peak detector which captures the peak deviation that occurs over the entire period, including the deviation that occurs in the first 10 milliseconds. The measurement method conforms to the EIA/IS-19-B Standard.

Applications:

RVC data is Manchester-encoded data that is used for cellular system signaling and control. Manchester encoding is accomplished by transforming each NRZ (non-return to zero) binary one to a zero-to-one transition and each NRZ binary zero to a one-to-zero transition. The data stream is then used to modulate the transmitter carrier using direct, binary, frequency-shift keying (FSK).

On the wide voice channels, the data rate is 10 kilobits/second and the nominal peak transmitted deviation is 8 kHz. All other modulation sources to the transmitter are inhibited when the data is transmitted ("blank and burst").

On the narrow voice channels, the data rate is 100 bits/second and the nominal peak transmitter deviation is 700 Hz. The data words are inserted into the DSAT data stream. The transmitter is modulated simultaneously by voice audio and the data stream.

Pass/Fail Limits Used

Pass/Fail Limit 26. TX NAMPS DSAT Deviation
Pass/Fail Limit 41. TX Wideband Data Deviation
Pass/Fail Limit 42. TXT Wideband Data Deviation Transient

Test Parameters Used

Parameter 48. TXT Trnsient/SS Data [0=tran 1=bth 2=ss]

Test Conditions Fixed by the Software

- The measurement is made with the peak hold detector and the $750~\mu s$ de-emphasis network on.
- The <20 Hz HPF and >999 kHz LPF will be used.
- The 230 kHz IF filter is also used.

TEST_12. TX Compressor Response

This test measures the compressor's zero reference deviation and operating range. For every 2 dB change in input level, there should be a nominal output level change of 1 dB.

NOTE:

Audio connections from the radio to the test set are required for this test.

Compressor response is expressed in kHz for the zero reference deviation, and in dB of tracking error over the indicated operating range.

Applications:

A compressor is used in the phone's voice input circuitry to decrease the variability of the modulation due to volume changes from the talker. In combination with an expandor in the cell site receiver, this provides improved signal-to-noise-ratio in the demodulated audio.

Pass/Fail Limits Used

Pass/Fail Limit 14. TX Compressor Min Out @ >17.6 dB In Pass/Fail Limit 15. TX Compressor Track Error <0 Pass/Fail Limit 16. TX Compressor Track Error >0 Pass/Fail Limit 17. TX Compressor Zero Reference Deviation Pass/Fail Limit 24. TX NAMPS Compressor Zero Reference Deviation

Test Parameters Used

Parameter 8. RC Compandor is Always On Parameters 35-37. TX Compressor Start, Step, and Stop Levels

Testing Conditions Fixed by the Software

- Compressor response to different input levels is measured.
- The "zero crossing" deviation is first measured by applying a 1 kHz-rate input voltage to the UUT at the level required to obtain the desired deviation (2.9 kHz for wide analog or 1.5 kHz for narrow analog).
- The deviation is next set to 2.9 kHz (1.5 kHz for narrow analog) and a reference is taken with the rms detector.
- The input is then varied using the start, stop and step parameters 35-37 and the rms
 deviation is measured and the compressor response relative to the reference is
 calculated.

The sweep must go from high to low values of the independent variable, input level. For example: start=10 dB, stop=-20 dB, step=-5 dB.

For inputs ≥17.6 dB the compressor can limit (see the AMPS standard), therefore, the min @>17.6 dB pass/fail limit 14 is used for a lower limit and the reference deviation pass/fail limit 17 is projected up by an amount related to the present level for the upper pass/fail limit.

• The C-message audio filter or the CCITT audio filter is used if installed in the test system.

TEST_13. TX Current Drain

This test measures the average power supply current drawn by the UUT when it is operating. The transmitter's current drain is expressed in amps. This test can measure current drain using two methods. The test software first looks to see if an HP-IB power supply has been configured in the External Devices (or Edit Config) screen. If one has been configured, the current drain will be measured via the programmable power supply over HP-IB; see the procedure for *Configuring an HP-IB Power Supply* that follows. If an HP-IB power supply is not available, (HP-IB power supply not configured in External Devices (or Edit Config) screen), the software measures current drain through the rear-panel dc current measurement capability of the test set; see the procedure *Configuring the Rear Panel dc-Current Measurement* that follows.

This test is not specified by EIA/TIA standards.

A Hewlett-Packard programmable dc power supply is required for this test if an HP-IB power supply is to be configured. A power supply with sufficient voltage and current capabilities from the following series must be used (which uses SCPI commands):

- HP 664xA
- HP 665xA
- HP 667xA
- HP 668xA

Configuring an HP-IB Power Supply

The following must be done to setup the power supply through the HP-IB on the test set:

- 1. Connect the power supply's HP-IB interface to the test set's HP-IB interface with an appropriate length HP-IB cable.
- 2. Press TESTS.
- Select External Devices from the SET UP TEST SET list (or Edit Config from the Test Function field).
- **4.** Position the cursor to the **Inst#** field and select it.
- 5. Rotate knob until an empty Calling Name field appears, and select it.
- 6. Using the list of characters in the Choices menu, enter the words Power Supply in the Calling Name field. Select Done when complete.
- 7. Position the cursor to the **Model** field and select it (optional).
- **8.** Using the DATA keypad and list of characters in the **Choices** menu, enter the Model # and press ENTER.
- **9.** Position the cursor to the **Addr** (address) field and select it.
- **10.** Using the DATA keypad, enter 7xx (X = 1 through 30) for the HP-IB address and press ENTER
- 11. From the To Screen menu, select More.
- 12. From the Choices menu, select IO CONFIG.
- **13.** Position the cursor to the **Mode** field and select it.
- 14. From the Choices menu, select Control.
- **15.** Press TESTS to return to TESTS screen. The power supply is now ready to be controlled by the test set when the current drain test is run.

Configuring the Rear-Panel dc-Current Measurement

- 1. The dc-current measurement must be zeroed before the measurement. Access the test set's TESTS screen by pushing the TESTS key on the front panel.
- 2. Position the cursor to the AF ANL field under To Screen and select it.
- Position the cursor to the dc Current field and select it (this should be done before
 any current is applied to the test set's measurement terminals). The dc-current
 measurement is now zeroed.
- **4.** Use a dc power supply that provides the appropriate voltage and current for your UUT.
- **5.** Connect the positive lead of the power supply to the positive terminal (banana) of the dc-current measurement connector on the lower-left rear panel of the test set.
- **6.** Connect the negative terminal (banana) of the dc-current measurement connector to the positive terminal of the mobile unit's supply input.
- 7. Connect the negative terminal of the power supply directly to the negative terminal of the mobile unit's supply input.
- **8.** The software will automatically measure the current passing through the rear-panel connection. Be sure that there is no HP-IB power supply configured in the External Devices (or Edit Config) screen of the test set, see the procedure above for *Configuring an HP-IB Power Supply*.

Pass/Fail Limits Used

Normally, all 8 current-drain levels are tested; however, parameter 38 allows you to select only the levels you want.

```
Pass/Fail Limit 18. TX Current Drain @ Levels 0-3
Pass/Fail Limit 19. TX Current Drain @ Levels 4-7
```

Test Parameters Used

Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail] Parameter 38. TX Current Drain Levels Tested (#BWD)

Testing Conditions Fixed by the Software

• Only SAT modulation is on during the test.

TEST_14. RX Expandor

This test measures the expandor's zero reference level and operating range. For every 1 dB change in input level, there should be a nominal output level change of 2 dB.

NOTE:

Audio connections from the radio to the test set are required for this test.

Expandor response is expressed in dBV for the zero reference level, and in dB for the tracking error over the indicated operating range.

Applications:

An expandor is used to provide the complement of the compressor in the cell site transmitter. Together, the compressor and expandor provide improved signal-to-noise-ratio in the demodulated audio.

Pass/Fail Limits Used

Pass/Fail Limit 4. RX Expandor Track Error <0
Pass/Fail Limit 5. RX Expandor Track Error >0
Pass/Fail Limit 6. RX Expandor Zero Reference Level
Pass/Fail Limit 8. RX NAMPS Expandor Zero Reference Level

Test Parameters Used

Parameters 18-20. RX Expandor Start, Step, and Stop Levels Parameter 30. RX Set Audio Level Parameter 31. RX Tolerance for Setting Audio Level

Testing Conditions Fixed by the Software

The expandor response is measured at a 1 kHz rate and an RF input level of -50 dBm.

- A 2.9 kHz (1.5 kHz for narrow analog operation) deviation is applied and the "zero crossing" of the receiver is measured. This value is retained as the reference level.
- Deviation is then varied over the desired range and the expandor response relative to the "zero crossing" point is calculated.

The sweep must go from high values to low values of the independent variable, deviation. For example: start=10 dB, stop=-20 dB, step=-5 dB.

TEST_15. RX Audio Frequency Response

This test measures the ability of the receiver's audio output circuitry to follow a 6 dB/octave de-emphasis curve, as well as to follow an audio-bandpass response. The RF level for signaling (parameter 27) is applied with a constant deviation. The modulation rate is swept over the audio frequency-response range (determined by parameters 15-17).

NOTE:

Audio connections from the radio to the test set are required for this test.

Receiver audio frequency response is expressed in dB error from a 6 dB/octave curve.

Pass/Fail Limits Used

Pass/Fail Limit 2. RX Audio Response Dev from -6 dB/oct R1 Pass/Fail Limit 3. RX Audio Response Dev from -6 dB/oct R2

Test Parameters Used

Parameter 8. RC Compandor is Always On Parameters 15-17. RX Audio Response Start, Step, and Stop Frequencies Parameter 30. RX Set Audio Level Parameter 31. RX Tolerance for Setting Audio Level

Testing Conditions Fixed by the Software

A –50 dBm RF signal is applied to the receiver's antenna.

The -50 dBm RF signal is modulated to deviate to 2.9 kHz at a 1 kHz rate with a SAT tone present and a reference reading is made.

- The frequency rate is then swept over the desired range and the response measured.
- If the compandor is always on, a 2:1 correction is applied to the measured results.
- Narrow analog operation uses 1.5 kHz deviation and DSAT.

TEST_16. RX Audio Distortion

This test measures the distortion from the receiver when a standard test tone is applied to the radio.

NOTE:

Audio connections from the radio to the test set are required for this test.

Also, this test uses the C-Message or CCITT audio filters if either of these options are installed in the test set. Otherwise it uses the 300 Hz to 3 kHz filters.

Pass/Fail Limits Used

Pass/Fail Limit 1. RX Audio Distortion

Test Parameters Used

Parameter 30. RX Set Audio Level Parameter 31. RX Tolerance for Setting Audio Level

Testing Conditions Fixed by the Software

A –50 dBm RF signal is applied to the receiver's antenna.

The -50 dBm RF signal is modulated to deviate to 8 kHz at a 1 kHz rate with a 6000 Hz SAT tone present.

Narrow analog operation uses 3 kHz deviation and DSAT.

TEST_17. RX Hum and Noise

This test measures the ratio, expressed in dB, of:

- ☐ The residual audio output in the absence of modulation,
- ☐ To the rated audio output.

NOTE:

Audio connections from the radio to the test set are required for this test.

Pass/Fail Limits Used

Pass/Fail Limit 7. RX Hum and Noise

Test Parameters Used

Parameter 30. RX Set Audio Level Parameter 31. RX Tolerance for Setting Audio Level

Testing Conditions Fixed by the Software

A -50 dBm RF signal is applied to the receiver's antenna.

The -50 dBm RF signal is modulated to deviate to 8 kHz at a 1 kHz rate with a SAT tone present.

- The SAT tone is always on during this test.
- Narrow analog operation uses 3 kHz deviation and DSAT.
- The C-message filter is used if present.
- The phone's transmitter is not on.
- The ac voltmeter rms detector is used to measure the reference level and hum and noise.

TEST_18. RX SINAD

This test sets and measures the ratio, expressed in dB, of:

- Signal + Noise + Distortion,
- to Noise + Distortion.

The receiver SINAD is measured at the RF level for SINAD specified by parameter 28.

NOTE:

Audio connections from the radio to the test set are required for this test.

Receiver SINAD is measured at the receiver's audio output. This measurement differs from a distortion measurement in that it is usually conducted at low RF input levels where the noise contribution is significant.

This test is intended to measure receiver sensitivity. Receivers are typically required to provide at least 12 dB SINAD (less than 25% noise and distortion) for RF input levels below 1 microvolt.

Pass/Fail Limits Used

Pass/Fail Limit 10. RX SINAD

Test Parameters Used

NOTE:

High and low supply voltages are measured only if an external power supply has been configured to be used over HP-IB by the HP 8920A and if parameter 13 is set to test at extremes.

Parameter 10. RT High Supply Voltage

Parameter 11. RT Low Supply Voltage

Parameter 12. RT Nominal Supply Voltage

Parameter 13. RT Test at Extreme Settings [0=no 1=ves]

Parameter 25. RX NAMPS RF Level for SINAD

Parameter 26. RX NAMPS RF Level for SINAD at Extremes

Parameter 27. RX RF Level for Signaling

Parameter 28. RX RF Level for SINAD

Parameter 29. RX RF Level for SINAD at Extremes

Parameter 30. RX Set Audio Level

Parameter 31. RX Tolerance for Setting Audio Level

Testing Conditions Fixed by the Software

- The "RF level for SINAD" (parameter 28) is modulated to deviate to 8 kHz at a 1 kHz rate with a SAT tone present.
- The measurement is repeated at high and low supply voltages if parameter 13 is set to 1.
- Narrow analog operation uses 3 kHz deviation and DSAT.

TEST_19. RX FVC Order Message Error Rate

This test simulates a Forward Voice Channel (FVC) order message being sent from a cell site to the cellular radio and measures the Order Message Error rate.

The test works as follows:

- A Forward Voice Channel (FVC) audit message is sent 100 times and the number of acknowledgments from the UUT is counted.
- The RF level is set by parameter 21.
- If the UUT misses 10 acknowledgments in a row the test terminates.

FVC order message error rate is expressed in % .

Pass/Fail Limits Used

Pass/Fail Limit 9. RX Order Message Error Rate (OMER)

Test Parameters Used

Parameter 21. RX FVC Message Error Rate RF Level Parameter 45. TX TS Atten for Signaling

TEST_20. CP Release

This test simulates a cellular radio executing a release from the cell site after obtaining a voice channel.

The test works as follows:

- A release message is sent from the test set, then it waits two seconds before measuring the TX output power.
- You may use the following parameters to select your desired units for test results output:
 - dBWatts Set parameter 46 TX Units for Power Meas to 0=dBW
 - Watts Set parameter 46 TX Units for Power Meas to 1=Watts
 - dBm Set parameter 14 RT use DUPLEX OUT & ANT IN to 1=yes, and use the DU-PLEX OUT port for the forward channel, and the ANT IN port for the reverse channel.
- The output power should be < -25 dBW for the test to pass.

Test Parameters Used

Parameter 14. RT use DUPLEX OUT & ANT IN [0=no 1=yes]

Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]

TEST_21. CP Origination

This test simulates a call from the cellular phone to the base station (cell site). Specifically, this test does the following:

- 1. The test set simulates a control channel.
- **2.** The operator is instructed to dial 123 123 4567 after the UUT has service. (Service is indicated by the NO SERVICE light going off on the UUT.)
- **3.** Performs 3 of 5 majority voting on the Reverse Control Message.
- **4.** Performs BCH error detection and correction of the Reverse Control Message, Wideband data.
- 5. Tests each section of the origination message, bit by bit.
- **6.** Sends an Initial-Voice-Channel-Designation order to the UUT directing it to tune to a voice channel obtained from the **Channel Information** (or **Edit Freq**) table.

If the channel number from the table has an L, M, or U suffix, the phone will be directed to a narrow voice channel. If the channel number has no suffix, the phone will be directed to a wide voice channel.

TEST_22. OT No Audio Functional

These tests are designed to provide you with a quick evaluation of the cellular radio receiver and transmitter without the need for audio connections from the radio to the test set. The following tests are performed:

```
TEST_21. CP Origination
TEST_03. TX Frequency Error
TEST_04. TX RF Power Output
TEST_08. TX Signaling Tone/DST
TEST_10. TX SAT/DSAT
TEST_11. TX RVC Data Deviation
TEST_27. CP Hook Flash
RX tones functional
RX SINAD functional
TX microphone functional
```

The first eight tests in the above list are described individually in this chapter. The final three tests are available only as part of this test and they work as follows:

- When prompted, the operator is required to listen for tones from the receiver, and then select whether the test passed or failed.
- The operator is required to whistle into the transmitter and observe the deviation on the test set, and then select whether the test passed or failed.

Test Parameters Used

```
Parameter 25. RX NAMPS RF Level for SINAD
Parameter 27. RX RF Level for Signaling
Parameter 28. RX RF Level for SINAD
Parameter 29. RX RF Level for SINAD at Extremes
```

NOTE:

Also, see individual test descriptions for additional pass/fail limits and parameters associated with each test.

TEST_23. TX Quick General

These tests are designed to provide you with a quick evaluation of the cellular radio's transmitter capabilities.

NOTE: Audio connections from the radio to the test set are required for this test.

The following tests are included:

TEST_04. TX RF Power Output
TEST_03. TX Frequency Error
TEST_05. TX Modulation Deviation Limiting
TEST_07. TX Audio Distortion
TEST_06. TX Audio Frequency Response
TEST_12. TX Compressor Response
TEST_09. TX FM Hum and Noise
TEST_09. TX RVC Data Deviation
TEST_10. TX SAT/DSAT
TEST_08. TX Signaling Tone/DST

Also, see individual test descriptions for additional pass/fail limits and parameters associated with each test.

TEST_24. RX Quick General

These tests are designed to provide you with a quick evaluation of the cellular radio's receiver capabilities.

NOTE:

Audio connections from the radio to the test set are required for this test.

The following tests are performed:

TEST_18. RX SINAD

TEST_16. RX Audio Distortion

TEST_15. RX Audio Frequency Response

TEST_14. RX Expandor

TEST_17. RX Hum and Noise

Test Parameters Used

Parameter 27. RX RF Level for Signaling

NOTE:

Also, see individual test descriptions for additional pass/fail limits and parameters associated with each test.

TEST_25. CP Flow Chart

This test displays a flow-chart representing a cellular phone as it gains access to a system. Once a voice channel is obtained, you can test cellular-radio functions including handoffs, power-level changes, SAT/DSAT changes, hook flashes, and clearing the system. At each stage, reverse channel data is displayed for analysis, along with measurements of power, frequency error, deviation, and SAT.

Test Parameters Used

Parameter 2. AB MIN From? [0=RECC, 1=All 0's, 2=Phone #]

Parameter 3. CP Control Channel [1:799] or [991:1023]

Parameter 4. CP DSAT Vector [0 thru 6]

Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail]

Parameter 6. CP SAT Tone

Parameter 9. RT External Path Loss

Parameter 14. RT use DUPLEX OUT & ANT IN

Parameter 27. RX RF Level for Signaling

Parameter 45. TX TS Atten for Signaling

Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]

Running the MANUAL Test Procedure

The MANUAL Test Procedure uses TEST_25. There are a few things you need to know when you run this test.

- ☐ At the beginning of this test, the test set simulates a control channel. The cellular phone must tune to this control channel and decode the data stream in order to obtain service. When the phone succeeds at obtaining service, the NO SERVICE indicator on the phone will turn off. The control channel can be changed by selecting the Cntl Chan field.
- ☐ If the cellular phone fails to obtain service, refer to the section titled **chapter 6**, "**Problem Solving**," on page 271.
- ☐ When the cellular phone first obtains service, a phone registration must be done before paging can be done.

To register the phone, select the **Regist** field.

☐ After a phone registration is done, phone paging can be done.

Select the **Page** field to page the phone.

Dial a number and press the phone's SEND key to initiate an origination. Registration is not required for origination.

- ☐ Once a voice channel is obtained, refer to the flowchart on the screen and the associated fields to the right of the screen for operating functions.
 - maintence allows you to run a maintenance check of the phone's signaling tone, frequency, and deviation. For a narrow voice channel, the value of the digital signaling tone (DST) sequence is displayed in hexadecimal.
 - **clear 1s** allows you to clear the land station (ls).
 - clear ms allows you to clear the mobile station (ms).
 - chng chan allows you to change cellular phone channels.
 - **chng pwr** allows you to change cellular phone power.
 - chng sat/chng dsat allows you to change the Supervisory Audio Tone (SAT or DSAT).
 - **DTMF** allows you to measure the frequency error of the high tone and low tone from the DTMF generator in the phone.
 - **Hook Flash** allows you to transmit a hook flash number from the phone and receive and display it on the test set.

TEST_26. TX Switch Channels

This test measures transmitter frequency error, power, and SAT frequency error over a range of channels defined by parameters 42-44.

The test works as follows:

- The UUT's channel number is changed over the desired range indicated by parameters 42-44.
- The channels will all be wide voice channels or they will all be narrow voice channels as determined by the currently active entry in the **Channel Information** (or **Edit Freq**) table.
- For each wide channel, the TX output power, RF frequency error, and SAT frequency error is measured.
- For each narrow channel, the TX output power (at power level 0 only) and RF frequency error are measured and the DSAT sequence coming from the phone is decoded and displayed.
- Each time the channel is changed, the SAT frequency is changed to the next valid SAT tone or DSAT value.

Pass/Fail Limits Used

Pass/Fail Limit 22. TX Frequency Error Pass/Fail Limits 29–36. TX Output Power @ Levels 0–7 Pass/Fail Limit 38. TX SAT Frequency Error

Test Parameters Used

Parameter 4. CP DSAT Vector [0 thru 6]
Parameter 6. CP SAT Tone
Parameter 14. RT use DUPLEX OUT & ANT IN
Parameters 42-44. TX Switch Channels Start, Step, and Stop Channel
Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]

TEST_27. CP Hook Flash

This test verifies that the correct hook-flash number (3 digits) is correctly sent by the cellular radio.

The test works as follows:

- 1. A voice channel is established.
- 2. The operator is prompted to dial a 3-digit number and press the SEND key on the UUT.
- **3.** If the channel is a wide voice channel, the test detects the resulting signaling tone from the UUT and sends a "send-called-address" order to the UUT on the Forward Voice Channel (FVC). This step does not occur on narrow voice channels.
- **4.** The test receives the hook-flash number from the UUT on the Reverse Voice Channel and displays it. (The number is not compared to a specific value or number.)

Test Parameters Used

Parameter 45. TX TS Atten for Signaling

TEST_28. TX DTMF Frequency Error

This test measures the transmitter's Dual-Tone Multifrequency (DTMF) frequency error for the phone's key pad. The low tone (LT) and high tone (HT) DTMF frequencies for each selected key are checked to make sure that the frequencies are within the DTMF frequency error limits for their nominal values.

DTMF frequency error is expressed in %.

Applications:

There are two groups of sinusoidal high and low frequencies consisting of 1209, 1336, and 1477 Hz (HT's) in one group, and 609, 770, and 941 Hz (LT's) in the other group.

A DTMF signal is generated when a key is pressed on the handset. Each dialing key makes use of one assigned frequency from each group. The DTMF signal is encoded and transmitted for control purposes when dialing an origination from the phone.

Pass/Fail Limits Used

Pass/Fail Limit 20. TX DTMF Frequency Error

TEST_29. RX MRI

This test sweeps the level of the RF carrier generated by the HP 8920A on a forward voice channel. The RF level is stepped from a higher level to a lower level where the start level, stop level, and step size are set by the user via the parameter table. At each level step, the MRI Parameter Message is sent to the UUT with the RSSI and BER threshold fields set to zero. This induces the UUT to report the current status of its RSSI and BER measurements via the reverse voice channel. These RSSI and BER values are then displayed.

Applications:

MRI stands for Mobile Reported Interference, RSSI stands for Received Signal Strength Indicator, and BER stands for Bit Error Rate. NAMPS phones are able to report RSSI and BER values to the base station on command. The BER pertains to the signaling used on narrow voice channels. This test can only be run on a narrow voice channel.

Test Parameters Used

Parameters 22-24. RX MRI Start, Step, and Stop Levels Parameter 27. RX RF Level for Signaling

Test Parameter Descriptions

Test parameters are used to define the conditions under which a test will run. You may edit the test parameters to change the default values to meet your specific testing needs and conditions. Test parameters may be used in one or more tests.

For information on editing test parameters, see "How to Customize Testing" on page 35 or "Customizing Testing" on page 69.

Test parameters remain in battery-backed-up memory until you select a procedure to run. If you wish to prevent them from being lost when a new procedure is selected, you will have to have them in a procedure. See "Saving a Test Procedure" on page 52.

To print the list of test parameters, see "To print TESTS screens:" on page 249.

There are several different types of parameters:

- Additional Parameters (AE)
- Call Processing Parameters (CP)
- Running Conditions (RC)
- Receiver/Transmitter Parameters (RT)
- Receiver Parameters (RX)
- Transmitter Parameters (TX)

Parameter 1. AA Enter Ph#? [0=If Needed, 1=Always, Here]

This parameter specifies from where the test will get the phone number of the UUT. You may enter one of three options:

- (
- 1
- the 10 digit phone number of the UUT

Setting Parameter 01 AA Enter Ph#? to 0=If Needed tells the test set to prompt the user for the phone number of the UUT if:

- · The phone number is needed to perform the first test in a test sequence, AND
- A MIN was not obtained by the test set running a previous test procedure.

Setting Parameter 01 to 1=Always tells the test set to prompt the user for the phone number of the UUT each time the test procedure is run. (Note that if Parameter 02 AB MIN From? is set to 1=All 0's indicating an all zero MIN, the user is not prompted for a phone number). Setting Parameter 01 to anything other than 0=If Needed or 1=Always will cause the test set to use the number entered as a ten digit phone number for paging the UUT if one of the following conditions are also true:

- Parameter 02 AB MIN From? is set to 2=Phone #, indicating to the test set to get the MIN from the phone number.
- Parameter 02 is set to **0=RECC** and a MIN has not been previously entered into the test set by running a previous test procedure.

Example

If Parameter 01 is set to **1231234567** and Parameter 02 is set to **2=Phone#**, the test set will use a MIN corresponding to phone number 123-123-4567 to page the UUT.

NOTE:

If a registration or an origination is performed that causes a new MIN to be entered into the test, this new MIN will then be used instead of the MIN derived from the entered phone number.

Used in Tests

All tests (when a system initialization is done by the software).

Parameter 2. AB MIN From? [0=RECC, 1=All 0's, 2=Phone #]

This parameter specifies from where the test set will get the Mobile Identification Number (MIN) of the UUT.

Setting Parameter 02 to **0=RECC** causes the test set to get the MIN from the Reverse Control Channel (RECC) Data. The RECC Data (data sent on the control channel from the UUT to the test set) sent during a registration or an origination is read by the test set to obtain the MIN.

Setting Parameter 02 to **1=All 0's** causes the test set to use a MIN consisting of all zeros. An all zero MIN is an invalid MIN according to the IS-54 standard. Because some phones initially have an all zero MIN after being manufactured or serviced, this parameter (when set to **1=All 0's**) allows the test set to page phones with an all zero MIN.

NOTE:

An all zero MIN can also be entered into the test set by setting parameter 02 to **0=RECC** and getting the MIN from the RECC Data from a UUT that has an all zero MIN.

NOTE:

If Parameter 02 is set to 1=All 0's, then Parameter 01 AA Enter Ph#? is not used.

Setting Parameter 02 to **2=Phone** # causes the test set to derive the MIN from the phone number, depending on the entry in Parameter 01 **AA** Enter Ph#? described below:

- If Parameter 01 contains a phone number, the phone number in Parameter 01 is used to derive a MIN.
- If Parameter 01 is set to **0=If Needed** or **1=Always**, the user will be prompted for a phone number if needed. This phone number will be used to derive the MIN.

NOTE:

If a registration or an origination test is performed that causes a new MIN to be entered into the test set, this new MIN will then be used instead of the MIN obtained as specified by Parameter 02.

Used in Tests

All tests (when a system initialization is done by the software).

Parameter 3. CP Control Channel [1:799] or [991:1023]

This parameter is used to identify the control channel used by the UUT. Primary control channels for System A are numbered from 1 to 333. Primary control channels for System B are numbered from 334 to 366. Secondary control channels for System A are numbered from 667 to 716 and 991 to 1023. Secondary control channels for System B are numbered from 717 to 799. Some cellular phones are designed to work only on System A or only on System B. For these phones, the control channel specified by this parameter must correspond to the correct system in order to allow the phone to obtain service.

For Example:

If you want to use control channel 334 to set up a call with the UUT, you would enter **334** as the value.

It's Used in the Following Tests:

All Tests (where a forward control channel is obtained)

Parameter 4. CP DSAT Vector [0 thru 6]

This parameter allows you to set the Digital Supervisory Audio Tone (DSAT) sequence to be used on narrow voice channels:

The seven valid sequences are as follows:

#0 = 2556CB

#1 = 255B2B

#2 = 256A9B

#3 = 25AD4D

#4 = 26AB2B

#5 = 26B2AD

#6 = 2969AB

For Example:

If you want the first sequence shown above, you would enter a **0** as the value.

It's Used in the Following Tests:

All Tests (whenever a narrow voice channel is obtained)

Parameter 5. CP Prt RECC RVC Data [0=no 1=yes 2=fail]

This parameter allows you to print the Reverse Control Channel (RECC) and Reverse Voice Channel (RVC) messages to the display or printer.

The RECC message is a wideband data stream sent from the mobile station to the land station, and can consist of up to five words. The types of messages that can be transmitted over the RECC are:

- Page Response Message
- · Origination Message
- Order Confirmation Message
- Order Message

The RVC message is a wideband data stream sent from the mobile station to the land station, and can consist of one or two words. The types of messages that can be transmitted over the RVC are:

- Order Confirmation Message
- Called-Address Message

It's Used in the Following Tests:

All Tests (whenever the RECC or RVC messages are analyzed during testing)

Parameter 6. CP SAT Tone

This parameter allows you to set the Supervisory Audio Tone (SAT) frequency to be used on wide voice channels.

For Example:

If you want the SAT to be at 6000 Hz, you would enter 6000 as the value. All values are entered in Hz.

It's Used in the Following Tests:

All Tests (whenever a wide voice channel is obtained)

Parameter 7. CP SID Number

This parameter identifies the mobile station's System Identification (SID) number. The SID is stored as a 15 bit binary number in the mobile station's permanent security and identification memory.

This parameter should be equal to the UUT home system ID to perform testing in a non-roaming environment. Use an ID different than the UUT to test in a roaming environment.

Enter any number from 1 to 32767.

For Example:

If your UUT's SID number is decimal 11111, you would enter **11111** as the value.

It's Used in the Following Tests:

All Tests (whenever a System Initialization is done by the software)

Parameter 8. RC Compandor is Always On

This parameter allows you to indicate whether or not the compandor is always on.

If this parameter is set to 1 (Yes), the program assumes that the UUT's compressor circuitry is located before the pre-emphasis circuitry on the transmitter, and behind the de-emphasis circuitry in the receiver.

With the compandor always "ON" (set to 1), the effects of an "ideal expandor" are removed from the test results (of the RX Audio Frequency Response test 15, that is, the results are reduced in half). Also, the test operator is not prompted to turn the compandor "ON" and "OFF".

If this parameter is set to 0 (No), then the test operator will be prompted to "turn the Radio compandor ON" during testing. Some manual control of the phone's compandor state is required.

For Example:

If you do not want the compandor always on, you would enter 0 as the value. The value must be either a 0 for no, or a 1 for yes.

It's Used in the Following Tests:

TEST_05. TX Modulation Deviation Limiting

TEST_06. TX Audio Frequency Response

TEST 07. TX Audio Distortion

TEST_09. TX FM Hum and Noise

TEST_12. TX Compressor Response

TEST_15. RX Audio Frequency Response

TEST_23. TX Quick General

TEST_24. RX Quick General

Parameter 9. RT External Path Loss

This parameter allows you to set the amount of loss for any external cables or pads (attenuators) connected to the HP 8920A. Also use this parameter to compensate for path loss when the RF link between the cellular phone and the HP 8920A is accomplished via antennas (see parameter "Parameter 14. RT use DUPLEX OUT & ANT IN" on page 150). This loss is compensated for in power measurements and in signal generator level settings on the HP 8920A.

For Example:

If a 30 dB attenuator is connected in line with the UUT antenna, you would enter **30** as the value. The value must be entered in dB.

It's Used in the Following Tests:

All Tests (whenever a System Initialization is done by the software)

Parameter 10. RT High Supply Voltage

This parameter is used to set the UUT to the highest voltage rating that it is specified to operate at under extreme conditions. The high-supply voltage is set only when an external power supply is connected to the HP 8920A over HP-IB.

For Example:

If you want to set the power supply voltage to operate the UUT at +20% of the normal (Nominal) supply voltage, and your Nominal Supply Voltage is 13.2V, you would enter **15.8** as the value.

The value must be entered in Vdc.

It's Used in the Following Tests:

TEST_03. TX Frequency Error

TEST_04. TX RF Power Output

TEST_05. TX Modulation Deviation Limiting

TEST_18. RX SINAD

Parameter 11. RT Low Supply Voltage

This parameter is used to set the UUT to the lowest voltage rating that it is specified to operate at under extreme conditions. The low-supply voltage is set only when an external power supply is connected to the HP 8920A over HP-IB.

For Example:

If you want to set the power supply voltage to operate the UUT at -20% of the normal (Nominal) supply voltage, and your Nominal Supply Voltage is 13.2V, you would enter **10.6** as the value.

The value must be entered in Vdc.

It's Used in the Following Tests:

TEST_03. TX Frequency Error

TEST_04. TX RF Power Output

TEST_05. TX Modulation Deviation Limiting

TEST_18. RX SINAD

Parameter 12. RT Nominal Supply Voltage

This parameter is used to set the UUT to its nominal voltage rating that it is specified to operate at under normal conditions. This parameter is needed only when using a stand-alone power supply or battery-operated phone.

For Example:

If you want to set the power supply voltage to operate the UUT at 13.2V, you would enter 13.2 as the value.

The value must be entered in Vdc.

It's Used in the Following Tests:

All Tests (whenever a System Initialization is done by the software)

Parameter 13. RT Test at Extreme Settings [0=no 1=yes]

This parameter is used to activate all of the parameters that set extreme testing conditions for the UUT. If this parameter is set to 1 (yes) the following parameters may be used:

```
Parameter 10. RT High Supply Voltage
Parameter 11. RT Low Supply Voltage
Parameter 26. RX NAMPS RF Level for SINAD at Extremes
Parameter 29. RX RF Level for SINAD at Extremes
```

The software offers the capability to run certain tests at extreme supply voltage conditions. Extreme supply voltage conditions are high and low supply voltages that are used while testing is conducted. In order to use the extreme testing conditions, an HP-IB programmable power supply must be used. This power supply must be interfaced to the HP 8920A through an HP-IB interface cable. For more information on the types of power supplies supported by the software and how to configure the test system to control the power supply, see *Configuring an HP-IB Power Supply* located in the description of "TEST_13. TX Current Drain" on page 114.

For Example:

When this parameter is set to 0, the following tests are performed at the nominal dc power supply voltage. When this parameter is set to 1, the tests are performed at nominal, high, and low supply voltages.

It's Used in the Following Tests:

```
TEST_03. TX Frequency Error
TEST_04. TX RF Power Output
TEST_05. TX Modulation Deviation Limiting
TEST_18. RX SINAD
```

Parameter 14. RT use DUPLEX OUT & ANT IN

This parameter allows you to select the RF ports on the HP 8920A which will be used for cellular phone tests. A value of 0 causes the RF IN/OUT port to be used for both forward and reverse channels. A value of 1 causes the DUPLEX OUT port to be used for the forward channel and the ANT IN port to be used for the reverse channel.

Use of the DUPLEX OUT and ANT IN ports allows the RF link between the HP 8920A and the cellular phone to be established via antennas instead of coaxial cable. In either case, parameter 9: RT External Path Loss should be used to compensate for the path loss.

NOTE:

If the RF link is accomplished via antennas, it must be done inside a shielded environment to avoid interference with local cellular telephone service.

It's Used in the Following Tests:

All tests.

Parameters 15-17. RX Audio Response Start, Step, and Stop Frequencies

The RX Audio Frequency Response Start Frequency is the lowest modulation frequency used in the RX Audio Frequency Response test.

The RX Audio Frequency Response Step Frequency is the step-size used to vary the modulation frequency in the RX Audio Frequency Response test.

The RX Audio Frequency Response Stop Frequency is the highest modulation frequency used in the RX Audio Frequency Response test.

These parameters are used to set the start, stop and step frequency settings as the *RX Audio Frequency Response* test measures the degree of closeness to which the audio output of a receiver follows the 6 dB/octave de-emphasis curve.

For Example:

If you want the modulation frequency to be varied from 300 Hz to 3000 Hz in 500 Hz steps:

- You would enter . 3 as the *Audio Response Start Frequency* value.
- You would enter .5 as the Audio Response Step Frequency value.
- You would enter 3 as the Audio Response Stop Frequency value.

The value must be entered in kHz.

It's Used in the Following Test:

TEST_15. RX Audio Frequency Response

Parameters 18-20. RX Expandor Start, Step, and Stop Levels

The *RX Expandor Start Level* is the highest frequency deviation relative to the zero crossing level that is used in the RX Expandor test. It is expressed in dB.

The *RX Expandor Step Level* is the step-size used to vary the frequency deviation in the RX Expandor test. It is expressed in dB.

The *RX Expandor Stop Level* is the lowest frequency deviation relative to the zero crossing level that is used in the RX Expandor test. It is expressed in dB.

These parameters are used to set the start, step, and stop "relative" input levels to the Expandor circuitry for checking the output voltage-level changes for each input deviation.

For Example:

If you want to measure the Expandor's operating range over which it provides a nominal output level change of 2 dB for an input level change of 1 dB:

- You might enter **10** as the *Expandor Start* value.
- You might enter -5 as the *Expandor Step* value.
- You might enter **-20** as the *Expandor Stop* value.

The value must be entered in dB.

It's Used in the Following Test:

TEST_14. RX Expandor

NOTE:

The sweep must go from high values to low values of the deviation applied for the test to update properly (i.e., the step value must be a negative number).

Parameter 21. RX FVC Message Error Rate RF Level

This parameter sets the RF level for testing the Forward Voice Control (FVC) order message error rate.

For Example:

If you want the RF level for testing the FVC order message error rate to be at -110 dBm, you would enter -110 as the value.

It's Used in the Following Test:

TEST_19. RX FVC Order Message Error Rate

Parameters 22-24. RX MRI Start, Step, and Stop Levels

The *RX MRI start level* is the level of the RF carrier output by the HP 8920A at the beginning of the RX MRI test. The level will be decremented during the test, so this level is the highest one used.

The *RX MRI step level* is the step size used to vary the level of the RF carrier output by the HP 8920A during the RX MRI test. The level is decremented.

The *RX MRI stop level* is the final (lowest) level of RF carrier output by the HP 8920A during the RX MRI test.

For Example:

If you want the RF level to be varied from -75 dBm to -105 dBm in 5 dB steps:

- Enter -75 as the RX MRI start level.
- Enter -5 as the RX MRI step level.
- Enter -105 as the RX MRI stop level.

It's Used in the Following Test:

TEST_29. RX MRI

Parameter 25. RX NAMPS RF Level for SINAD

This parameter sets the RF signal level for measuring SINAD on narrow voice channels at the nominal power supply voltage.

For Example:

If you want the RF signal level to be at -118 dBm for SINAD measurements, you would enter -118 as the value.

The value must be entered in dBm.

It's Used in the Following Tests:

TEST_18. RX SINAD

Parameter 26. RX NAMPS RF Level for SINAD at Extremes

This parameter sets the RF signal level for measuring SINAD on narrow voice channels at the power supply voltage extremes.

Parameter 13, RT Test at Extreme Settings must be set to "yes" for Parameter 26, RX NAMPS RF Level for SINAD at Extremes to be activated.

For Example:

If you want the RF signal level to be at -115 dBm for SINAD measurements, you would enter -115 as the value.

The value must be entered in dBm.

It's Used in the Following Tests:

TEST_18. RX SINAD TEST_22. OT No Audio Functional

Parameter 27. RX RF Level for Signaling

This parameter sets the HP 8920A's RF signal generator level for acquiring the forward control channel in all tests.

For Example:

If you want to apply a -50 dBm signal, you would enter -50 as the value.

The value must be entered in dBm.

NOTE:

If the value entered is higher than -50 dBm, it may affect TEST_04. TX RF Power Output.

It's Used in the Following Tests:

It is used in all tests.

Parameter 28. RX RF Level for SINAD

This parameter sets the RF signal level for measuring SINAD on wide voice channels at the nominal power supply voltage.

For Example:

If you want the RF signal level to be at -116 dBm for SINAD measurements, you would enter -116 as the value.

The value must be entered in dBm.

It's Used in the Following Tests:

TEST_18. RX SINAD

TEST_22. OT No Audio Functional

Parameter 29. RX RF Level for SINAD at Extremes

This parameter sets the RF signal level for measuring SINAD on wide voice channels at the power supply voltage extremes.

Parameter 13, RT Test at Extreme Settings must be set to "yes" for Parameter 29, RX RF Level for SINAD at Extremes to be activated.

For Example:

If you want the RF signal level to be at -113 for SINAD measurements at extreme voltage levels, you would enter -113 as the value.

The value must be entered in dBm.

It's Used in the Following Tests:

TEST_18. RX SINAD

TEST_22. OT No Audio Functional

Parameter 30. RX Set Audio Level

This parameter determines whether or not screen prompts are displayed to help the operator set the volume control during all of the receiver tests.

To use this parameter, the test operator must have control or have access to the audio power (volume control) from the UUT's transceiver unit.

For Example:

If your radio is to be tested at 50% of rated audio power, enter the audio level in volts, for example 0.2 for 200 mV. The test operator is prompted to adjust to the correct volume level during testing. (The HP 8920A displays an "analog meter", correct adjustment is made when the meter needle is set in between the two longer lines on the meter.)

The value must be either a **0** for no, or a value for audio level in volts.

It's Used in the Following Tests:

TEST_14. RX Expandor

TEST_15. RX Audio Frequency Response

TEST_16. RX Audio Distortion

TEST_17. RX Hum and Noise

TEST_18. RX SINAD

TEST_24. RX Quick General

Parameter 31. RX Tolerance for Setting Audio Level

This parameter is used as the value of the maximum percentage of error that you are allowed for setting the UUT volume.

The value sets the tolerance window in the "analog meter" screen (refer to parameter "Parameter 30. RX Set Audio Level" on page 160) that is used to manually set the UUT volume during testing; the meter needle must be within the tolerance window (shown by two larger lines on the meter) before the program will accept the manually set UUT volume. The tolerance should be as accurate as the volume control will allow.

NOTE:

This parameter is only active when parameter 30 (RX Set Audio Level) is set to accept audio level in volts.

For Example:

Enter the value as a percentage of the desired audio level. For example, if the UUT's maximum audio power is 10 watts, and the tolerance for setting volume is set to 5%, the window will be 1 watt (which is 5% of 10 watts, the tolerance allows settings above and below the point determined by the audio level value converted from volts to watts).

It's Used in the Following Tests:

TEST_14. RX Expandor

TEST_15. RX Audio Frequency Response

TEST 16. RX Audio Distortion

TEST_17. RX Hum and Noise

TEST_18. RX SINAD

TEST_24. RX Quick General

Parameters 32-34. TX Audio Response Start, Step, and Stop Frequencies

The *TX Audio Response Start Frequency* is the lowest input signal frequency used in the TX Audio Frequency Response test.

The *TX Audio Response Step Frequency* is the step-size used to vary the input signal frequency in the TX Audio Frequency Response test.

The *TX Audio Response Stop Frequency* is the highest input signal frequency used in the TX Audio Frequency Response test.

These parameters are used to set the start, stop and step frequency settings by the TX Audio Frequency Response test to measure the degree of closeness to which the audio output of the transmitter follows the 6 dB/octave pre-emphasis curve.

For Example:

If you want the modulation frequency to vary from 300 Hz to 3000 Hz in 500 Hz steps:

- You would enter . 3 as the TX Audio Response Start Frequency value.
- You would enter .5 as the TX Audio Response Step Frequency value.
- You would enter 3 as the TX Audio Response Stop Frequency value.

The value must be entered in kHz.

It's Used in the Following Test:

TEST_06. TX Audio Frequency Response

Parameters 35-37. TX Compressor Start, Step, and Stop Levels

The *TX Compressor Start Level* is the lowest relative input level to the compressor that is used in the TX Compressor Response test.

The *TX Compressor Step Level* is the step-size used to vary the input level to the compressor in the TX Compressor Response test. This must be a negative number for the test to work properly.

The *TX Compressor Stop Level* is the highest relative input level to the compressor that is used in the TX Compressor Response test.

These parameters are used to set the start, step, and stop relative input levels to the Compressor circuitry for checking the output deviation for each input voltage level.

For Example:

If you want to measure the compressor's operating range over which it provides a nominal output level change of 1 dB for an input level change of 2 dB:

- You might enter 25 as the TX Compressor Start value.
- You might enter -5 as the TX Compressor Step value.
- You might enter -30 as the TX Compressor Stop value.

The values must be entered in dB.

It's Used in the Following Test:

TEST_12. TX Compressor Response

Parameter 38. TX Current Drain Levels Tested

This parameter allows you to measure current drain at any or all of the power levels (0-7) shown below.

For Example:

If you want to measure the transmitter current drain on the UUT when it is at Power Levels 1 and 4, you would enter 18 as the value, as follows:

This condition's range is based upon a Binary Weighted Decimal (BWD). As shown in the table below, you choose the power levels that will be measured for current drain and add their weighted values.

Power Level	7	6	5	4	3	2	1	0
Weighted Value	128	64	32	16	8	4	2	1

The parameter ranges from a minimum value of 1 to a maximum value of 255.

It's Used in the Following Test:

TEST_13. TX Current Drain

Parameter 39. TX Frequency Deviation Step Frequency

This parameter sets the frequency deviation step size for the TX Modulation Deviation Limiting test. Modulation limiting is measured between a start frequency of 300 Hz and a stop frequency of 3000 Hz (both values set by the software).

For Example:

If you want modulation limiting measured in step sized of 500 Hz, you would enter **0.5** as the value.

The value must be entered in kHz.

If you enter 0, modulation limiting will only be measured at a 1 kHz rate.

It's Used in the Following Test:

TEST_05. TX Modulation Deviation Limiting

Parameter 40. TX Mod Dev Limit 50 Hz HPF [0=off 1=on]

This parameter allows you to control the 50 Hz high-pass filter (HPF) for the TX Modulation Deviation Limiting test, for wide voice channel testing only.

For Example:

If you want to use the 50 Hz HPF, you would enter $\bf 1$ as the value. For a 0 value, the <20 Hz HPF filter is used.

It's Used in the Following Test:

TEST_05. TX Modulation Deviation Limiting

Parameter 41. TX Output Power Levels Tested

This parameter allows you to measure the output power at any or at all of the power levels (0-7) shown below.

For Example:

If you want to measure the transmitter output power when it is at Power Levels 2 and 4, you would enter **20** as the value, as follows:

This parameter's range is based upon a Binary Weighted Decimal (BWD). As shown in the table below, you choose the Power Levels that will be measured for output power and add their weighted values.

Power Level	7	6	5	4	3	2	1	0
Weighted Value	128	64	32	16	8	4	2	1

The parameter ranges from a minimum value of 1 to a maximum value of 255.

It's Used in the Following Test:

TEST_04. TX RF Power Output

Parameters 42-44. TX Switch Channels Start, Step, and Stop Channel

This parameter allows you to set the start, step, and stop channels for the TX Switch Channels test.

For Example:

If you want to start the TX Switch Channels test at channel 100 and stop at channel 600, making sure that channels 200-500 are also tested, you would enter:

- 100 as the start channel value.
- 100 as the step channel value.
- 600 as the stop channel value.

It's Used in the Following Test:

TEST_26. TX Switch Channels

Parameter 45. TX TS Atten for Signaling

This parameter sets the input attenuation in the HP 8920A RF Analyzer to attenuate the signal which is input to the test set (TS).

For Example:

If you want to have a 20 dB input attenuation to the HP 8920A, you would enter **20** as the value.

Values are entered as 0, 20, or 40 dB.

It's Used in the Following Tests:

All Tests (whenever signaling is done).

Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]

This parameter allows you to choose between dBWatts and Watts units for measuring the transmitter's RF power.

Values are entered as a 0 for dBW, or as a 1 for Watts. The value of this parameter also determines whether the entries for pass/fail limits 29 through 36 will be interpreted as watts or dBw.

It's Used in the Following Tests:

TEST_04. TX RF Power Output TEST_25. CP Flow Chart

TEST_26. TX Switch Channels

Parameter 47. TX Voltage for Compressor Zero Crossing

This parameter sets the voltage that is used to modulate the UUT transmitter (often called microphone sensitivity) for the purpose of measuring the resulting frequency deviation and comparing it to a specified compressor zero reference deviation.

For Example:

If you want the peak deviation of the carrier to occur at the zero reference point when 0.1 Vrms is applied to the transmitter microphone input, you would enter .1 as the value.

The value must be entered in Vrms.

It's Used in the Following Test:

TEST_05. TX Modulation Deviation Limiting

TEST_06. TX Audio Frequency Response

TEST_07. TX Audio Distortion

TEST_09. TX FM Hum and Noise

TEST_12. TX Compressor Response

NOTE: Not used in software revision B.01.03 or greater.

Parameter 48. TXT Trnsient/SS Data

This parameter requires trigger delay capabilities only available on the HP 8920B. HP 11807A software will ignore this parameter.

For HP 11807E software, this parameter allows the user to select between three modes of operation for the execution of TEST_11 TX RVC Data Deviation.

- Select 0=tran (transient) to perform the test on the entire RVC data signal returned from the UUT.
- Select 1=bth (both) to perform the test on just the steady state portion of the RVC data signal followed by a test of the entire signal. This option uses trigger delay capabilities and can only be performed on an HP 8920B.
- Select 2=ss (steady state) to test only the steady state portion of the signal. This option uses trigger delay capabilities and can only be performed on an HP 8920B.

It's Used in the Following Test:

TEST_11. TX RVC Data Deviation

Pass/Fail Limit Descriptions (Specifications)

Pass/Fail Limits define the values a measurement's result is compared against to determine if the UUT meets its specified standards.

For information on editing Pass/Fail Limits, see "Customizing Testing" on page 34.

The list of pass/fail limits is arranged alphabetically. The first few capital letters in the title of each pass/fail limit indicate what the pass/fail limit refers to (see Prefixes and Abbreviations at the beginning of this chapter).

Pass/Fail Limits remain in battery-backed-up memory until you select a procedure to run. If you wish to prevent them from being lost when a new procedure is selected you will have to save them in a procedure. See "Saving a Test Procedure" on page 52. To print the list of Pass/Fail Limits, see "Saving Tests Results" on page 264.

There are two types of pass/fail limits:

- Receiver Test pass/fail limits (RX)
- Transmitter Test pass/fail limits (TX)

Pass/Fail Limit 1. RX Audio Distortion

This sets the pass/fail limits that are used when the receiver's audio distortion is measured while receiving the RF level for signaling (parameter 27).

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Audio Harmonic Distortion

For Example:

If your standard states that audio distortion should not exceed 5% at a normal audio output, you would enter 5 as the Upper Limit. (Check upper limits.)

Limits must be entered in %.

It's Used in the Following Test:

TEST_16. RX Audio Distortion

Pass/Fail Limit 2. RX Audio Response Dev from -6 dB/oct R1

This sets the pass/fail limits for the receiver's audio output circuitry, when its audio response is tested against a standard 6 dB/octave de-emphasis curve. The audio response should not deviate beyond the pass/fail limit limits over the frequency range of 400 to 2400 Hz.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Voice Audio Frequency Response

For Example:

If your standard applies to receivers that are normally used with a handset or a line and indicates that the audio response should not deviate more than +1 to -3 dB over the frequency range of 400 to 2400 Hz, you would enter -3 as the Lower Limit and 1 as the Upper Limit. (Check both limits.)

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_15. RX Audio Frequency Response

Pass/Fail Limit 3. RX Audio Response Dev from -6 dB/oct R2

This sets the pass/fail limits for the receiver's audio output circuitry, when its audio response is tested against a standard 6 dB/octave de-emphasis curve. The audio response should not deviate beyond the pass/fail limit limits in the regions of 300 to 400 Hz and 2400 to 3000 Hz.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Voice Audio Frequency Response

For Example:

If your standard applies to receivers that are normally used with a handset or a line and indicates that the audio response should not deviate more than +1 to -6 dB over the frequency range of 300 to 400 Hz and 2400 to 3000 Hz, you would enter -6 as the Lower Limit and 1 as the Upper Limit. (Check both limits.)

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_15. RX Audio Frequency Response

Pass/Fail Limit 4. RX Expandor Track Error <0

This sets the pass/fail limits that are used when the expandor circuits are measured with the relative input levels below 0 dB; in this condition, the output voltage tolerance should be within the limits you set for the expandor track error. Pass/fail limits are determined by using any applicable standard, such as:


• EIA Standard: Expandor

For Example:

If your standard sets the output voltage tolerance to be ± 2 dB from the Expandor Curve shown below, you would enter -2 as the Lower Limit and 2 as the Upper Limit. Lower and Upper Limits must be entered in dB. (Check both limits.)

It's Used in the Following Test:

TEST_14. RX Expandor



Pass/Fail Limit 5. RX Expandor Track Error >0

This sets the pass/fail limits that are used when the expandor circuits are measured with the relative input levels above 0 dB; in this condition, the output voltage tolerance should be within the set limits. Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Expandor


For Example:

If your standard sets the output voltage tolerance to be ± 1 dB from the Expandor curve shown below, you would enter -1 as the Lower Limit and 1 as the Upper Limit. (Check both limits.)

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_14. RX Expandor



Pass/Fail Limit 6. RX Expandor Zero Reference Level

This sets the pass/fail limits that are used when the expandor's 0 dB reference level is measured on wide voice channels.

Pass/fail limits are determined by using any applicable standard, such as:

EIA Standard: Expandor


For Example:

If your standard states that the output voltage from the receiver should be -20 dBV rms ± 1 dB for a given frequency deviation (to produce the 0 dB reference level as shown below), you would enter -21 as the Lower Limit and -19 as the Upper Limit. (Check both limits.)

Lower and Upper Limits must be entered in dBV rms.

It's Used in the Following Test:

TEST_14. RX Expandor



Pass/Fail Limit 7. RX Hum and Noise

This sets the pass/fail limits for the hum and noise level of the receiver.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Hum and Noise

For Example:

If your standard sets the hum and noise level of the receiver to be at least 32 dB below the audio output for a 1 kHz modulated RF carrier at -50 dBm having a ± 8 kHz peak frequency deviation, you would enter -32 as the Upper Limit. (Check upper limits.)

Limits must be entered in dB.

It's Used in the Following Test:

TEST_17. RX Hum and Noise

Pass/Fail Limit 8. RX NAMPS Expandor Zero Reference Level

This sets the pass/fail limits that are used when the expandor's 0 dB reference level is measured on narrow voice channels.

Pass/fail limits are determined by using any applicable standard, such as:

EIA Standard: Expandor


For Example:

If your standard states that the output voltage from the receiver should be -20 dBV rms ± 1 dB for a given frequency deviation (to produce the 0 dB reference level as shown below), you would enter -21 as the Lower Limit and -19 as the Upper Limit. (Check both limits.)

Lower and Upper Limits must be entered in dBV rms.

It's Used in the Following Test:

TEST_14. RX Expandor



Pass/Fail Limit 9. RX Order Message Error Rate (OMER)

This sets the limits for testing the receiver as it processes the Forward Voice Control (FVC) order message.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: FVC Order Message

For Example:

If your standard states that the order-message error rate should not exceed 5%, you would enter 5 as the Upper Limit. (Check upper limits.)

Limits must be entered in percent.

It's Used in the Following Test:

TEST_19. RX FVC Order Message Error Rate

Pass/Fail Limit 10. RX SINAD

This sets the pass/fail limits used when SINAD is measured at the audio output of the receiver.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: RF Sensitivity

For Example:

If your standard defines the usable sensitivity measurement that results in 12 dB SINAD at the audio output of the receiver, you would enter **12** as the Lower Limit.

Limits must be entered in dB.

It's Used in the Following Test:

TEST_18. RX SINAD

Pass/Fail Limit 11. TX Audio Distortion

This sets the pass/fail limits for the audio distortion that is acceptable in the transmitter.

Pass/fail limits are determined by using any applicable standard, such as:

EIA Standard: Modulation Distortion and Noise

For Example:

If your standard states that the transmitter distortion should not exceed 5%, you would enter 5 as the Upper Limit.

Limits must be entered in %.

It's Used in the Following Test:

TEST_07. TX Audio Distortion

Pass/Fail Limit 12. TX Audio Response Dev From 6 dB/oct

This sets the pass/fail limits for the degree of closeness with which the frequency deviation of the transmitter follows the prescribed 6 dB/octave pre-emphasis characteristic curve over the range set by 32-34 TX audio response start, step, and stop frequency parameters.

Pass/fail limits are determined by any applicable standard, such as:

• EIA Standard: Transmit-Audio Response

For Example:

If your standard states that from 300 to 3000 Hz the audio frequency response should not vary more than -1 to +3 dB from a true 6 dB/octave pre-emphasis curve, you would enter -1 as the Lower Limit and 3 as the Upper Limit.

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_06. TX Audio Frequency Response

Pass/Fail Limit 13. TX Audio Response Roll >2.5 kHz

This sets the pass/fail limits of the audio frequency response roll-off that is acceptable when the audio input frequency is greater than 2.5 kHz.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Transmit-Audio Response

For Example:

If your standard states that an audio frequency roll-off of 6 dB/octave is permissible at audio input frequencies greater than $2.5~\mathrm{kHz}$, you would enter 0 as the Lower Limit and 6 as the Upper Limit.

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_06. TX Audio Frequency Response

Pass/Fail Limit 14. TX Compressor Min Out @ >17.6 dB In

This sets the pass/fail limits for the compressor's minimum (min) output peak frequency deviation when the compressor's relative input (in) voltage is greater than 17.6 dB.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Compressor


For Example:

If your standard states that a relative input voltage greater than 17.6 dB should produce the compressor's relative output deviation at a level which is at least 8.3 dB, you would enter 8.3 as the Lower Limit.

Limits must be entered in dB.

It's Used in the Following Test:

TEST_12. TX Compressor Response



Pass/Fail Limit 15. TX Compressor Track Error <0

This sets the pass/fail limits that are used when the compressor circuits are measured with the relative input levels below 0 dB; in this condition, the compressor's relative output deviation tolerance should be within the limits you set for the compressor track error.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Compressor


For Example:

If your standard sets the output voltage tolerance to be ± 1 dB from the Compressor Curve shown below, you would enter -1 as the Lower Limit and 1 as the Upper Limit.

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_12. TX Compressor Response



Pass/Fail Limit 16. TX Compressor Track Error >0

This sets the pass/fail limits that are used when the expandor circuits are measured with the relative input levels above 0 dB; in this condition, the compressor's relative output deviation tolerance should be within the limits you set for the compressor track error.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Compressor


For Example:

If your standard sets the output voltage tolerance to be ± 0.5 dB from the Compressor Curve shown below, you would enter -0.5 as the Lower Limit and 0.5 as the Upper Limit.

Lower and Upper Limits must be entered in dB.

It's Used in the Following Test:

TEST_12. TX Compressor Response



Pass/Fail Limit 17. TX Compressor Zero Reference Deviation

This sets the pass/fail limits that are used when the compressor's 0 dB reference deviation is measured on wide voice channels. The 0 dB reference deviation is found when an voltage input (the 47. TX voltage for compressor zero crossing parameter) to the transmitter produces an output at the transmitter equal to the specified peak frequency deviation.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Expandor

For Example:

If you standard states that the voltage input to the transmitter is a $-20 \, dBV \, rms \, 1 \, kHz$ tone which produces a peak frequency deviation of the carrier at the output of the transmitter of 2.9 kHz $\pm 0.17 \, kHz$, you would enter 2.73 as the Lower Limit and 3.07 as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST_12. TX Compressor Response

Pass/Fail Limit 18. TX Current Drain @ Levels 0-3

This sets the pass/fail limits for current used by the transmitter when the radio is enabled to transmit at RF output power levels 0-3. This pass/fail limit is used whenever the HP 8920A performs a system initialization prior to running a test when an external power supply is connected over HP-IB.

Pass/fail limits are determined by using any applicable standard, such as:

• UUT Specification: Current Consumption, Transmit

For Example:

If your radio pass/fail limit defines the transmitter's current consumption to be 4 amps for RF output power levels 0-3, you might enter 1 as the Lower Limit and 4 as the Upper Limit.

Lower and Upper Limits must be entered in Amps.

It's Used in the Following Tests:

All Tests (when a System Initialization is done)

TEST 13. TX Current Drain

Pass/Fail Limit 19. TX Current Drain @ Levels 4-7

This sets the pass/fail limits for current used by the transmitter when the radio is enabled to transmit at RF output power levels 4-7. This pass/fail limit is used whenever the HP 8920A performs a system initialization prior to running a test when an external power supply is connected over HP-IB.

Pass/fail limits are determined by using any applicable standard, such as:

• UUT Specification: Current Consumption, Transmit

For Example:

If your radio specification defines the transmitter's current consumption to be 2.7 Amps for RF output power levels 4-7, you might enter .5 as the Lower Limit and 2.7 as the Upper Limit.

Lower and Upper Limits must be entered in Amps.

It's Used in the Following Test:

TEST_13. TX Current Drain

Pass/Fail Limit 20. TX DTMF Frequency Error

This specification sets the pass/fail limits for the amount of frequency error allowable for the DTMF (Dual-Tone Multi-Frequency) signals.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Dual Tone Multifrequency (DTMF) Signaling, Transmitted Pulse Characteristics

For Example:

If your standard states that the seven tone frequencies in the high and low group DTMF signals should be within $\pm 1.5\%$ of their nominal values, you would enter – 1.5 as the Lower Limit and 1.5 as the Upper Limit.

Lower and Upper Limits must be entered in %.

It's Used in the Following Test:

TEST_28. TX DTMF Frequency Error

Pass/Fail Limit 21. TX FM Hum and Noise

This sets the pass/fail limits for the residual FM hum and noise measured from the radio.

Pass/fail limits are determined by using any applicable standard, such as:

- EIA Standard: FM Hum and Noise
- AMPS Standard: Residual Frequency Modulation (FM) Hum and Noise

For Example:

If your standard states that FM hum and noise should be at least 32 dB below the level of a 1 kHz tone at ± 8 kHz deviation, you would enter -32 as the Upper Limit.

Limits must be entered in dB.

It's Used in the Following Tests:

TEST_09. TX FM Hum and Noise

Pass/Fail Limit 22. TX Frequency Error

This sets the pass/fail limits for the radio's frequency stability.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Frequency Requirements, Frequency Stability

For Example:

If your standard states that the carrier frequency should be maintained within ± 2.5 parts per million (ppm) of any assigned channel frequency, you would enter -2.5 as the Lower Limit and 2.5 as the Upper Limit.

Lower and Upper Limits must be entered in ppm.

It's Used in the Following Tests:

TEST_03. TX Frequency Error

TEST_26. TX Switch Channels

Pass/Fail Limit 23. TX Modulation Limiting

This sets the pass/fail limits when the transmitter circuits are tested for their ability to prevent the transmitter from producing deviation in excess of the rated system deviation for wide voice channels.

Pass/fail limits are defined by any applicable standard, such as:

EIA Standard: Modulation Deviation Limiting

For Example:

If your standard states that the instantaneous peak and steady-state deviations of the transmitter should not exceed the rated system peak-frequency deviation of ± 12 kHz, you would enter 12 as the Upper Limit.

Limits must be entered in kHz.

It's Used in the Following Test:

TEST_05. TX Modulation Deviation Limiting

Pass/Fail Limit 24. TX NAMPS Compressor Zero Reference Deviation

This sets the pass/fail limits that are used when the compressor's 0 dB reference deviation is measured on narrow voice channels. The 0 dB reference deviation is found when an voltage input (the 47. TX voltage for compressor zero crossing parameter) to the transmitter produces an output at the transmitter equal to the specified peak frequency deviation.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Expandor

For Example:

If your standard states that the voltage input to the transmitter is a -20 dBV rms 1 kHz tone which produces a peak frequency deviation of the carrier at the output of the transmitter of 1.5 kHz ± 0.1 kHz, you would enter **1.40** as the Lower Limit and **1.60** as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST 12. TX Compressor Response

Pass/Fail Limit 25. TX NAMPS DSAT Closure

This sets the pass/fail limits that are used when closure of the eye pattern is measured for DSAT transmitted by the UUT on a narrow voice channel.

Pass/fail limits are determined using any applicable standard, such as:


TIA Standard: Sub-Audible Data

For Example:

If your standard states that the eye pattern closure must be greater than .65, you would enter .65 as the lower limit and 1 as the upper limit.

It's Used in the Following Test:

TEST_10. TX SAT/DSAT



Pass/Fail Limit 26. TX NAMPS DSAT Deviation

This sets the pass/fail limits that are used for peak frequency deviation measurements of the DSAT sequence transmitted by the UUT on a narrow voice channel.

Pass/fail limits are determined using any applicable standard, such as:

• TIA Standard: Sub-Audible Data

For Example:

If your standard states that the peak frequency deviation for the DSAT sequence shall be ± 700 Hz with a ± 10 % tolerance, you would enter 630 as the lower limit and 770 as the upper limit.

It's Used in the Following Test:

TEST_08. TX Signaling Tone/DST

TEST_10. TX SAT/DSAT

TEST_11. TX RVC Data Deviation

Pass/Fail Limit 27. TX NAMPS DSAT Phase Jitter

This sets the pass/fail limits that are used when phase jitter of the eye pattern is measured for DSAT transmitted by the UUT on a narrow voice channel.

Pass/fail limits are determined using any applicable standard, such as:


• TIA Standard: Sub-Audible Data

For Example:

If your standard states that the phase jitter of the eye pattern must be less than .15, you would enter .15 as the upper limit and 0 as the lower limit.

It's Used in the Following Test:

TEST_10. TX SAT/DSAT



Transmit Data Eye Pattern

Pass/Fail Limit 28. TX NAMPS Modulation Limiting

This sets the pass/fail limits when the transmitter circuits are tested for their ability to prevent the transmitter from producing deviation in excess of the rated system deviation for narrow voice channels.

Pass/fail limits are defined by any applicable standard, such as:

• EIA Standard: Modulation Deviation Limiting

For Example:

If your standard states that the instantaneous peak and steady-state deviations of the transmitter should not exceed the rated system peak-frequency deviation of ± 5 kHz, you would enter 5 as the Upper Limit.

Limits must be entered in kHz.

It's Used in the Following Test:

TEST_05. TX Modulation Deviation Limiting

Pass/Fail Limits 29–36. TX Output Power @ Levels 0–7

These pass/fail limits set the pass/fail limits for the output power levels measured at the transmitter's output terminals. Units for the pass/fail limits are set by parameter "Parameter 46. TX Units for Power Meas [0=dBW 1=Watts]" on page 170.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: RF Power Output Requirements, RF Power Output

For Example:

If you are testing Power Class 1 radios and your standard lists the power levels and states that the output powers should be maintained within the range of +2 dB and -4 dB of nominal values over a specified temperature range, you would enter the following:

Table 1 Parameter 46 TX Units for Power Meas set to 0=dBW

Power Level	Nominal Value (dBW)	Lower Limit(dBW)	Upper Limit (dBW)
Level 0	6	2	8
Level 1	2	-2	4
Level 2	-2	-6	0
Level 3	-6	-10	-4
Level 4	-10	-14	-8
Level 5	-14	-18	-12
Level 6	-18	-22	-16
Level 7	-22	-26	-20

Table 2 Parameter 46 TX Units for Power Meas set to 1=Watts

Power Level	Nominal Value (Watts)	Lower Limit(Watts)	Upper Limit (Watts)
Level 0	3.98	1.59	6.31
Level 1	1.59	0.631	2.51
Level 2	0.631	0.251	1.00
Level 3	0.251	0.100	0.398
Level 4	0.100	0.0398	0.159
Level 5	0.0398	0.0159	0.0631
Level 6	0.0159	0.00631	0.0251
Level 7	0.00631	0.00251	0.0100

It's Used in the Following Tests:

TEST_04. TX RF Power Output

TEST_26. TX Switch Channels

Pass/Fail Limit 37. TX SAT Deviation

This sets the pass/fail limits for the Supervisory Audio Tone (SAT) deviation.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Supervisory Audio Tone (SAT)

For Example:

If your standard states that the peak frequency deviation of each transponded SAT should be ± 2 kHz ± 0.2 kHz, you would enter 1.8 as the Lower Limit and 2.2 as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST_10. TX SAT/DSAT

Pass/Fail Limit 38. TX SAT Frequency Error

This sets the pass/fail limits for frequency error allowable when the Supervisory Audio Tone (SAT) is tested.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Supervisory Audio Tone (SAT)

For Example:

If your standard states that any one of the three SAT tones should not vary in frequency more than ± 1 Hz, you would enter -1 as the Lower Limit and 1 as the Upper Limit.

Lower and Upper Limits must be entered in Hz.

It's Used in the Following Tests:

TEST_10. TX SAT/DSAT

TEST_26. TX Switch Channels

Pass/Fail Limit 39. TX Signaling Tone Deviation

This sets the pass/fail limits for the Signaling Tone deviation.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Signaling Tone (ST)

For Example:

If your standard states that the nominal peak-frequency deviation of the carrier produced by the Signaling Tone should be $8~kHz \pm 0.8~kHz$, you would enter **7.2** as the Lower Limit and **8.8** as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST_08. TX Signaling Tone/DST

Pass/Fail Limit 40. TX Signaling Tone Frequency

This sets the pass/fail limits which are used when the Signaling Tone frequency is tested.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Signaling Tone (ST)

For Example:

If your standard states that the Signaling Tone should be a $10 \, \text{kHz} \pm 1 \, \text{Hz}$ tone, you would enter **9.999** as the Lower Limit and **10.001** as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST_08. TX Signaling Tone/DST

Pass/Fail Limit 41. TX Wideband Data Deviation

This sets the pass/fail limits for the Wideband Data deviation.

Pass/fail limits are determined by using any applicable standard, such as:

• EIA Standard: Wideband Data

For Example:

If your standard states that the Wideband Data frequency deviation should be ± 8 kHz with a ± 10 % tolerance, you would enter **7.2** as the Lower Limit and **8.8** as the Upper Limit.

Lower and Upper Limits must be entered in kHz.

It's Used in the Following Test:

TEST_11. TX RVC Data Deviation

Pass/Fail Limit 42. TXT Wideband Data Deviation Transient

This sets the pass/fail limits for the transient portion of the wideband data deviation measurement (TEST_11). This specification is only used if parameter 48 TXT trnsient/ss data [0=tran 1=bth 2=ss] is set to 1=bth (both), which causes the software to separately report the transient and steady state portions of the measurement.

It's Used in the Following Test:

TEST_11. TX RVC Data Deviation

Chapter 4, Test, Parameter, and Pass/Fail Limit Descriptions Pass/Fail Limit 42. TXT Wideband Data Deviation Transient				

5

Reference (Alphabetical)

This chapter provides detailed descriptions of the features and functions of the HP 11807A,E software. Topics are arranged alphabetically for quick, easy reference.

Conventions Used

Special presentations of text in this manual reflect the appearance of the item being referred to.

Examples of these special presentations are:

TESTS

A key on the test set.

Procedure:

Characters displayed on the CRT display

k1 (Run Test)

A USER key, in the key column next to the CRT. Run Test is displayed on the CRT

0.00000

A field on the CRT where entries can be made.

Titles of documentation are printed in italics.

The term Test Set refers to the HP 8920A,B,D.

In the steps in this manual the following words are used to describe cursor and entry actions:

- **select** refers to pressing the knob after positioning the cursor in front of the appropriate field (**inverse video** area).
- **choose** means to position the cursor in front of an item in the **Choices:** or **To Screen** menu in the lower right corner of the CRT display, and then press the knob.
- enter means to use the numeric keypad, and the ENTER key or measurement units keys
 to make entries to fields. In some procedures, enter is used to describe the action of
 entering characters into a field.

Copying Files

Files can be copied from one mass-storage device to another using IBASIC COPY commands. For example, to copy a file from an inserted memory card to the left drive of an external dual-disk drive with HP-IB address 700, press TESTS. Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field). Position the cursor to the IBASIC command line and select it. Using the character list that appears in the Choices menu, enter the following command:

```
COPY "MY_TEST:INTERNAL" TO "MYFILE:,700,0"
```

You can copy a file from a memory card to an SRAM memory card by loading the program from the memory card into the test set, inserting an initialized SRAM memory card, and then using the IBASIC SAVE command. Enter the following:

```
SAVE "MY_TEST:INTERNAL"
```

You can list the names of the files stored in a memory card or disk catalog by using the IBASIC CAT command. To display a list of file names on a memory card, enter the following:

```
CAT ": INTERNAL" or CAT
```

The mass storage powers-up to memory card as a default. If you did not change this setting, then ":INTERNAL" is optional. If you are entering many characters into the IBASIC command line, you may want to connect a terminal to the test set. See "Serial Connection" on page 242. You will also want to use a terminal if you have many files to list because file names displayed with the CAT IBASIC command scroll past the top of the test set's CRT display and cannot be scrolled down.

IBASIC is used when writing your own programs and is not explained in this manual. If you need to write your own IBASIC programs you may acquire the following manuals:

- HP 8920A,D
 - *HP Instrument BASIC User's Handbook* HP part number E2083-90000.
 - HP 8920A Programming Manual HP part number 08920-90220.
- HP 8920B
 - *HP Instrument BASIC User's Handbook Version 2.0* HP part number E2083-90005.
 - HP 8920B Programming Manual HP part number 08920-90222.

See also: "Data Collection (Saving and Retrieving Test Results)" on page 215, and "Initializing a Memory Card" on page 233.

Data Collection (Saving and Retrieving Test Results)

The software has the capability to save test results to an SRAM memory card, to a disk drive, or to a PC.

Collection to a Memory Card or Disk

You will have to make entries into the **External Devices** (Edit Config) screen to describe the type of data collection you are using.

To configure

External Devices entries:

- 1. Press TESTS
- Select External Devices from the SET UP TEST SET list (or Edit Cnfg from the Test Function field).
- 3. Position the cursor to the Calling Name field and select it.
- 4. Using the list of characters in the Choices menu, enter DATA C into the Calling Name next to Inst# 1. The entry will look like:
 - 1 DATA C

Note: For some SW revisions, DATA C will appear in the **Choices** menu. In this case, you may select DATA C, then Done instead of typing each character individually.

- 5. Position cursor to the Addr field and select it.
- **6.** Using the DATA keypad, enter a number into **Addr**, depending on the type of storage media you will be using (press ENTER when complete):

If you are using a memory card, enter 1 into the Addr:

1 DATA C 1

If you are using a disk drive, enter the HP-IB disk address. For example, if the drive you are using is set to 700, then the display needs to look like:

1 DATA C 700

Calling names can be entered in any order.

The test software supports data storage on Logical Interchange Format (LIF) and Disk Operating System (DOS) disk formats. Storage can be to any of the following file types:

- · ASCII files under LIF
- BDAT files under LIF
- · HP-UX files under LIF
- DOS files under DOS

You will be specifying the file type with the entry you make into the **Options** field immediately below **DATA** C. If no file type is entered, and the disk format is LIF, the software will select an HP-UX file type. If no file type is entered, and the disk format is DOS, the software will select a DOS file type. For example, if you are using a DOS file and you are not using an extension on the file name, the entry on this screen will look like:

1 DATA C 700

If you are using an ASCII, BDAT or HP-UX file, you can specify the number of records allocated to the file. The DOS file is automatically updated as data is stored, so record allocation is not required. If you are using HP-UX files, you will have to enter REC= to establish a usable number of records. REC=20480 sets the size to be the same as the default number of 256 byte records used for ASCII files (80×256) . You can enter the REC= after the file type. For example, to use an ASCII file with 200 records of 256 bytes each, you will enter ASCII REC=200 into the Options field.

NOTE:

For some software revisions, **REC=** and **ASCII REC=** will appear in the **Choices** menu. In this case, you may select **REC=** or **ASCII REC=**, enter the number of records using the **DATA** keypad, then select **Done**, instead of typing in each character individually.

The display will appear as follows:

The default number of records, used when no **REC=** entry is made, is 80.

Items in the **Options** field can be separated by a comma or a space.

See"Initializing a Disk" on page 225 if using a new disk. See "Initializing a Memory Card" on page 233 if using a new memory card. The file types under LIF can be used by the test set's IBASIC controller and some HP workstations. The DOS format is required if you wish to use the disk with a PC.

Table 3 Data Collection (Saving/Retrieving Tests) Configuration Summary

Inst#	Calling Name Options	Model	Addr	Description
first unused#	data collection		7xx ¹	To HP-IB disk drive
	Options ²	 	!	
	File types of ascii,		7xx ¹	LIF format
	or <i>bdat</i>			LIF format
	or $(ext)^3$			DOS file type
	or blank ⁴			DOS or HP-UX file type ⁴
	rec=xxxxx (number of records)			Number of records
first unused#	data collection		1	To memory card
	Options ²			
	File types of ascii,		7xx ¹	LIF format
	or <i>bdat</i>			LIF format
	or (ext) ³			DOS file type
	or blank ⁴			DOS or HP-UX file type ⁴
	rec=xxxxx (number of records)			Number of records
first unused#	data collection		9	Serial to external computer (laptop)

- 1. xx = Last two digits of HP-IB address.
- 2. These options apply to disk drive and memory card data collection. They do not apply when collecting data with Addr=9.
- 3. A DOS file name extension. For example, the file name may be CELL1.EXT.
- 4. DOS is used if the disk format is DOS. HP-UX is used if the disk format is LIF.

Retrieving Data from a Memory Card

To retrieve the test results after they have been saved on an SRAM memory card, you will have to run an IBASIC program. The following is a program to transfer data from a memory card to a terminal emulator. You can type the program lines into the IBASIC command line from a terminal emulator. See "Configuration for Terminal or PC Operation" on page 223.

To enter the data retrieval program:

- 1. Press TESTS.
- 2. Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field).
- 3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the **Choices** field, enter the following IBASIC program statements and commands.
- **4.** Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
- **5.** Enter the following program:

```
10 DIM A$[120]
```

Sets the string length to 120.

```
20 ASSIGN @File TO "RES:INTERNAL"; FORMAT ON
```

Opens a path to the memory card file called "RES" (for results).

```
30 ON ERROR GOTO 80
```

Exits at end of file if an error is encountered.

40 LOOP

Extracts file contents.

```
50 ENTER @File;A$
```

Transfers part of the file to the string.

```
60 OUTPUT 9;A$
```

The string is output at the Serial port.

70 END LOOP

Goes back to get more of the file.

80 END

End of the program.

6. Press k1(Run) to run the entered IBASIC program.

DIFFERENCE BETWEEN RUN AND RUN TEST The USER Run key, assigned as a default key on the TESTS (IBASIC Controller) screen, will start an IBASIC program that is resident in the test set's memory. The USER Run Test key, assigned as a default key on the TESTS screens, will load and run the program that is called from the Select Procedure Filename: and Select Procedure Location: entries on the TESTS Main Menu screen.

Collection to a PC

Test results can be output through the serial port. A variety of devices can receive the data. An HP Palmtop computer, PC, laptop, or terminal can be used. A terminal emulator can log the test results to a file. Examples of terminal emulator programs are HP AdvanceLink and ProComm, a product of DataStorm Technologies, Inc.

For example: Configuring an IBM-Compatible PC with HP AdvanceLink for DOS

- 1. Load and run HP AdvanceLink on your PC.
- **2.** Use the following tables to set the Global Configuration, Terminal Configuration, and Remote Configuration settings.

Table 4 Global Configuration Settings

FIELD	SETTING	FIELD	SETTING
Keyboard	USASCII	Memory Size	32K
Personality	НР	Plotter I/F	None
Language	English	HP Mode	Yes
Terminal Mode	Alphanumeric	Video Type	Select your display type
Remote to	enter PC's serial port #	Forms Path	Enter path if used
Printer I/F	None	Screen Size	Enter the size

Table 5 Terminal Configuration Settings

FIELD	SETTING	FIELD	SETTING
Terminal ID	2392A	Esc Xfer(N)	YES
Local Echo	OFF	ASCII 8 Bits	YES
CapsLock	OFF	FldSeparator	US
Start Col	01	BlkTerminator	RS
Bell	ON	ReturnDef	CR
XmitFnctn(A)	NO	Сору	Fields
SPOW(B)	NO	Type Ahead	NO
InhEolWrp(C)	NO	ROW Size	80
Line/Page(D)	LINE	Host Prmpt Char	D1
InhHndShk(G)	NO	Horiz. Scroll. Incr.	08
Inh DC2(H)	NO	Large [+] Key	+

 Table 6
 Remote Configuration Settings

FIELD	SETTING	FIELD	SETTING
Baud Rate	4800	SR(CH)	LO
Parity/Data Bits	None/8	Recv Pace	None
Eng Ack	No	Xmit Pace	None
Asterisk	OFF	CS(CB)Xmit	NO
Chk Parity	NO		

To set up for data collection to a PC:

- **1.** Press TESTS.
- 2. Select External Devices from the SET UP TEST SET list (or Edit Cnfg from the Test Function field).
- 3. Position the cursor to the Calling Name field and select it.
- 4. Using the list of characters in the Choices menu, enter DATA C (next to Inst# 1):
 - 1 DATA C
- 5. Position the cursor to the Addr field and select it.
- **6.** Using DATA keypad, enter **9** and press ENTER :
 - DATA C

Calling names can be entered in any order.

Configuration for Terminal or PC Operation

It is preferable to enter long strings of characters into fields using a terminal. The characteristics of the serial port, when used for instrument control from a terminal or terminal emulator, are determined by settings on the test set's I/O CONFIGURE screen.

Set the following:

- Serial Into Inst
- IBASIC Echo to On
- Inst Echo to On

Set the remaining configuration entries to match the settings of your terminal or PC program.

Equivalent Front-Panel Control Characters

The following table 10 on page 248 lists the terminal/computer keystrokes that equate to front-panel controls. Each equivalent character must be preceded by the Escape key.

For example, to remotely access the CONFIGURE screen, you type Esc, C on your terminal/computer. (Be sure to use upper-case C for this example.)

Alternate sequences for 5 commonly-used functions are also available. Hold down the Ctrl (control) key and select the corresponding key for the desired function. (Example: Ctrl/H moves the cursor to the left one space.)

```
ENTER -^J or ^M

CANCEL - ^C

BACKSPACE - ^H

KNOB_TURN_CW - ^R

KNOB_TURN_CCW - ^L
```

 Table 7
 Equivalent Front-Panel Control Characters

Function	Equiv. ESC Char.	Function	Equiv. ESC Char	Function	Equiv. ESC Char
CANCEL	!	SAVE	G	PRESET	i
PERCENT MHZ_V	(REF_SET	J	INCR_DIV_10	j
S_KHZ_MV)	METER	K	INCR_SET	k
BACKSPACE	-	AVG	L	INCR_TIMES_10	1
ENTER		LO_LIMIT	M	DOWN	m
RELEASE	0	HI_LIMIT	N	UP	n
k1	1	Е	R	SEVEN	0
k2	2	F	S	EIGHT	p
k3	3	В	U	NINE	q
k4	4	С	V	FOUR	r
k5	5	D	W	FIVE	s
k1_PRIME	6	A	X	SIX	t
k2_PRIME	7	EEX	Z	ONE	u
k3_PRIME	8	YES_ON_OFF	[TWO	v
ASSIGN	9	NO_PPM_W]	THREE	w
KNOB_TURN_CCW	<	RX	a	ZERO	х
KNOB_TURN_CW	>	TX	b	POINT	у
MSSG	A	DUPLEX	С	PLUS_MINUS	z
HELP	В	PREV	d	OHM_PCT_DEL_DBUV	{
CONFIG	С	TESTS_MAIN	e	DB_GHZ_DBM	I
HOLD	D	LOCAL	f	MS_HZ_UV	}
PRINT	Е	RECALL	g		I.
ADRS	F	MEAS_RESET	h		

Disks

Initializing a Disk

If you are starting with a blank disk, you will have to initialize it to the format you have chosen. Disk drives require specific commands to perform initialization. The test set's IBASIC commands to initialize some disks are described here. You should verify that the drive you are using can be controlled by the test set and that you are initializing a disk using a drive or PC that has a compatible format.

To initialize a disk to LIF in an HP-IB disk drive:

- 1. Verify that the test set **Mode** on the I/O CONFIGURE screen is set to **Control**:
 - a. Press TESTS.
 - b. Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field).
 - c. Position the cursor to the IBASIC command field and select it.
 - **d.** With the list of characters in the **Choices** menu, enter the following:

```
INITIALIZE ":,7xx,y"
```

where:

xx =the HP-IB address of the disk drive, and y =the unit number of the drive.

To initialize a disk to DOS in an HP-IB drive:

Follow the procedure for the LIF format, replacing the INITIALIZE statement with INITIALIZE "DOS:,7xx,y".

Retrieving Data from a Disk

One way to retrieve the test results from a disk is to run an IBASIC program. A program to transfer data from a disk to a terminal emulator is given below. You can type it into the IBASIC command line from the terminal emulator.

Be sure your program is saved, because it will be deleted from programmable memory. The file name for this example is "RES". The disk address is 700, and the drive number is 0. The entire file name is RES:,700,0.

To enter the data retrieval program:

- 1. Press TESTS.
- 2. Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field).
- 3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the Choices field, enter the following IBASIC program statements and commands.
- **4.** Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
- **5.** Enter the following program:

```
10 DIM A$[120]
```

Sets the string length to 120.

```
20 ASSIGN @File TO "RES:,700,0"
```

Opens a path to the file called "RES" (for results).

```
30 ON ERROR GOTO 80
```

Exits at end of file if an error is encountered.

```
40 LOOP
```

Extracts file contents.

```
50 ENTER @File;A$
```

Transfers part of the file to the string.

```
60 OUTPUT 9;A$
```

The string is output at the serial port.

```
70 END LOOP
```

Goes back to get more of the file.

80 END

End of the program.

6. Press k1 (Run) to run the entered IBASIC program.

Exiting a Program

Do not press RX or TX to exit the program. Selecting the RX TEST or TX TEST screen causes signal paths internal to the test set to be modified. If you exit the program to a screen other than RX TEST or TX TEST, the settings necessary to resume testing will be retained.

After you have made the manual settings you want, press the DUPLEX key as a last step before continuing the software. This will cause the test set to be properly set up.

Another way to safely exit is to:

- 1. Press CANCEL.
- 2. Press DUPLEX.
- 3. Press SHIFT SAVE.
- **4.** Using list of characters in the **Choices** menu, enter a register name or number.
- 5. Select Done.
- **6.** Operate the test set manually.
- 7. Press RECALL.
- **8.** Choose the name of the saved setup.
- 9. Press TESTS.
- 10. Press k2 (Continue.)

HP-IB Control Annunciators

The words, letters, and symbols at the top right corner of the CRT display indicate these conditions:

- R indicates remote operation from an external controller or IBASIC program in the test set. This letter will be displayed while the software is running.
- L indicates that the test set is listening, and is ready to receive a manual or remote command.
- T indicates that the test set is talking to another HP-IB device.
- s indicates that a service request has been generated.
- c indicates that the test set is currently an active controller. Control mode is set on the I/O CONFIGURE screen. The test set must be a controller if HP-IB peripherals are to be controlled.
- * indicates that an IBASIC program is running, or that the IBASIC controller is executing a command.
- ? indicates that an IBASIC program is waiting for a user response.
- indicates that the IBASIC program is paused.
- **SHIFT** indicates that the SHIFT key was pressed, and that the next key entry will be shifted. (Press SHIFT again to clear).

Memory Cards

Memory cards are inserted into the slot on the test set's front panel. The memory card is powered by the test set while it is inserted. Arrows printed on the memory card and the test set's front panel indicate the direction and orientation of card insertion.

Memory cards are used to store or retrieve the following:

- Software code
- An HP-supplied Procedure, containing:
 - A default TEST sequence
 - Default test parameter values
 - Default pass/fail limit values
- A Library file
- Procedures you make, optimized for your application
- Data collection files
- Channel Information
- · User defined keys

Three types of memory cards are available:

- Static Random Access Memory (SRAM)
 - SRAM cards have read and write capability. SRAM cards can be programmed and read with the test set.
- One-Time Programmable (OTP)
 - Once programmed with a suitable card programmer, OTP cards have read-only capability. OTP cards can be read with the test set, but cannot be programmed with the test set.

· Flash Memory

Flash cards have read and write capability. They can only be written to, or
programmed with a suitable card reader/programmer. Flash memory cards cannot
be written to, or programmed with a test set. Flash memory cards can be read by the
test set.

NOTE:

Hewlett-Packard-supplied software code and Hewlett-Packard procedure and library files are typically supplied on either OTP cards or flash cards. Flash cards can be distinguished from OTP cards by a small write protect (WP) switch in the end of the flash cards. SRAM cards also have a write protect or safe switch in the end of the card, but they also use a battery. Software and procedure/library files stored on a flash card cannot be overwritten by a test set regardless of the position of the write protect (WP) switch.

The software memory card can be removed after the program is loaded into the test set memory. The program will remain in memory after a power-down/power-up cycle, until a new program is loaded. Loading a new program will replace the existing program.

SRAM Memory Cards

A Static Random Access Memory (SRAM) Card can be used to store test results and procedures you make. The following parts can be used.

Table 8 SRAM Memory Card Products for HP 8920A,D

Memory	Product
32 kilobytes	HP 85700A
128 kilobytes	HP 85702A
256 kilobytes	HP 85704A
512 kilobytes	HP 85705A

Table 9 PCMCIA SRAM Memory Card Products for HP 8920B

Memory	Product
64 kilobytes	HP 83230A
256 kilobytes	HP 83233A
1 megabyte	HP 83231A

SRAM memory cards use a lithium battery (For HP 11807A: part number CR 2016 or HP part number 1420-0383. For HP 11807E: part number CR 2025 or HP part number 1420-0509). Programs and data will be retained for over one year if the memory card is stored at 25° C. The memory card is powered by the test set while it is inserted. Replace the battery while the memory card is inserted into a powered-up test set. To retain data and programs, it should be replaced annually. See the *HP 8920 User's Guide*. The write-protect switch on an SRAM memory card will write protect the card when it is set toward the outside of the card.

Memory Card Storage Space

Procedures use 12-16 records each. A Library uses 20-35 records. A single library must be included on the card. A record is 256 bytes. Approximately 11 kilobytes of overhead is required on each card.

Use the following formula to estimate the storage space needed:

Storage Space(in kilobytes) = (Number of Procedures \times 4.1) + 20

For example, if you want to save ten different procedures, you will need 61 kilobytes of memory. The 64 kilobyte or 128 kilobyte card is sufficient.

The storage space you need for data collection depends on the number of test results that are saved. You will need approximately 4 kilobytes per page of test results that you save. A page of test results is about 57 lines of CRT or printer output.

The storage space of smaller SRAM cards can be quickly used. If you are collecting large quantities of data, data collection using a PC or printer may be preferable.

Initializing a Memory Card

Initializing HP 11807A cards (Smart Cards) using the TESTS save/Delete Procedure screen automatically defaults to LIF format. Initializing HP 11807E cards (PCMCIA) using the TESTS save/Delete Procedure screen automatically defaults to DOS format. However, initializing cards from the Save/Delete Procedure screen is only available on HP 8920B or HP 8920A,D test sets with firmware above revision A.14.00. If these settings do not match your needs, or you have firmware below revision A.14.00, there is another method described below in which you may select the format.

- · Press TESTS.
- Select Save/Delete Procedure from the CUSTOMIZE TEST PROCEDURE list.
- Insert the SRAM card in the slot on the front panel. (Make sure the switch on the card is not in the write-protected position).
- Press k3 Init Card.
- Press Yes if you want to continue.

There are two ways to initialize a memory card to select the format. If you have a terminal emulator attached to the test set, you can type a command into the IBASIC command line. A second way to initialize a card is to run the ROM program RAM_MNG.

To initialize an SRAM card using IBASIC

- 1. Press TESTS.
- Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field).
- 3. Position the cursor to the IBASIC command line and select it.
- **4.** Using the list of characters under the **Choices** menu, enter the following IBASIC command:

For LIF format: INITIALIZE ":INTERNAL"

For DOS format: INITIALIZE "DOS:INTERNAL"

To initialize an SRAM card using RAM_MNG

- 1. Press TESTS.
- 2. Position the cursor to the Select Procedure Location (or Location) field and select it.
- 3. From the Choices menu, select ROM.
- Position the cursor to the Select Procedure Filename (or Procedure) field and select it.
- 5. From the Choices menu, select IB_UTIL (or RAM_MNG).
- 6. Press k1 (Run Test.)
- 7. Follow the displayed instructions.

NOTE: Loading RAM_MNG will delete any procedure or program in memory.

Retrieving Data from a Memory Card

To retrieve the test results after they have been saved on an SRAM memory card, you will have to run an IBASIC program. The following is program to transfer data from a memory card to a terminal emulator. You can type the program lines into the IBASIC command line from a terminal emulator. See "Configuration for Terminal or PC Operation" on page 223.

To enter the data retrieval program:

- 1. Press TESTS.
- 2. Select IBASIC Cntrl from the SET UP TEST SET list (or IBASIC from the Test Function field).
- 3. Position the cursor to the IBASIC command field (large field in the upper part of the display) and select it. From the list of characters in the Choices field, enter the following IBASIC program statements and commands.
- **4.** Enter **SCRATCH** to delete the previous IBASIC program. Be sure it's saved first.
- **5.** Enter the following program:

```
10 DIM A$[120]
```

Sets the string length to 120.

```
20 ASSIGN @File TO "RES:INTERNAL"; FORMAT ON
```

Opens a path to the memory card file called "RES" (for results).

```
30 ON ERROR GOTO 80
```

Exits at end of file if an error is encountered.

```
40 LOOP
```

Extracts file contents.

```
50 ENTER @File;A$
```

Transfers part of the file to the string.

```
60 OUTPUT 9;A$
```

The string is output at the serial port.

```
70 END LOOP
```

Goes back to get more of the file.

80 END

End of the program.

6. Press k1 (Run) to run the entered IBASIC program.

DIFFERENCE BETWEEN RUN AND RUN TEST

The USER Run key, assigned as a default key on the TESTS (IBASIC Controller) screen, will start an IBASIC program that is resident in the test set's memory. The USER Run Test key, assigned as a default key on the other TESTS screens, will load and run the program that is called from the Select Procedure Filename and Select Procedure Location entries on the TESTS Main Menu screen.

Parameters

Parameters are values you enter that optimize your use of the test software. Many of the parameters are determined by examining your test needs.

Default values are set into the software. Some of these values are derived from standard methods of measurement and some are derived from the industry standard requirements. Load a Procedure and select the **Test Parameters** screen from the **CUSTOMIZE TEST PROCEDURE** list, to see the default values.

You should verify that parameters are properly set after you select the tests to be placed in your procedure.

Parameters remain in battery-backed-up memory until you select a procedure to run. If you wish to prevent them from being lost when a new procedure is selected, you will have to save them in a procedure. See "Saving a Procedure" on page 255.

To print the parameters list, see "To print TESTS screens:" on page 249.

To edit a parameter value:

- 1. Press TESTS.
- Select Test Parameters from the CUSTOMIZE TEST PROCEDURE list (or Edit Parm from the Test Function field).
- 3. Position the cursor to the Parm# field and select it.
- **4.** Rotate the knob to the desired parameter number and select it.
- 5. Position the cursor to the **Value** field and select it.
- **6.** Enter the desired value using the DATA keypad and press ENTER.
 - **a.** Use the \Leftarrow key to backspace.
 - **b.** Press CANCEL to cancel entries and retain the old value.
- 7. Press k5 (Main Menu)(or TESTS) to return to the TESTS screen.

Pass/Fail Limits (specifications)

Pass/Fail Limits are values you enter that set passing limits for tests. Default values are available in the test software. They have been derived from standard methods of measurement.

Pass/Fail Limits do not have to be changed when you select a test or change the tests in your procedure. Each test has pass/fail limits that apply to it.

You should verify that pass/fail limits are properly set after you select the tests to be placed in your procedure. Lists of the pass/fail limits used by each of the tests are contained in **Chapter 4**, "**Test, Parameter, and Pass/Fail Limit Descriptions**" of this manual. A lock is provided to prevent access to the pass/fail limits. See "**Securing a Procedure**" on page 259.

Pass/fail limits remain in the test set's battery-backed-up memory until you select a procedure to run. If you wish to prevent pass/fail limits from being lost when a new procedure is selected, you will have to save them in a procedure. See "Saving a Procedure" on page 255.

To print the pass/fail limits list, see "To print TESTS screens:" on page 249.

To edit a pass/fail limit value:

- 1. Press TESTS.
- 2. Select Pass/Fail Limits from the CUSTOMIZE TEST SET list (or Edit Spec from the Test Function field).
- 3. Position the cursor to the Spec# field and select it.
- **4.** Rotate the knob to the desired pass/fail limit number and select it.
- 5. Position the cursor to the Lower Limit or the Upper Limit field and select it.
- **6.** Enter desired value using the DATA keypad and press ENTER.
 - **a.** Use the \Leftarrow key to backspace.
 - **b.** Press CANCEL to cancel entries and retain the old value.
- 7. Position the cursor to the **Check** field and select it.
- **8.** From the **Choices** menu, select the combination of upper and lower limits to be checked.

Pausing or Stopping a TEST

To pause the program, press CANCEL.

To stop the program, press SHIFT then CANCEL. This performs an IBASIC RESET operation.

CHANGING SETTINGS WHILE PAUSED

If you make changes to instrument settings while the program is paused, subsequent operation may be unpredictable. Error messages may or may not be displayed. See "Exiting a Program" on page 227.

To continue a paused 1. Press TESTS. program:

- 2. Press k1 (Continue.) The test time is displayed when the test is completed. This time includes the time that the program is paused and the time that it is waiting for connection and inputs to be made. If you are testing through midnight, the test time will not display properly.

Printing

You can print any of the following:

- Test results
- TESTS screens
 - "External Devices" (Edit Cnfg)
 - "Order of Tests" (Edit Seqn)
 - "Channel Information" (Edit Freq)
 - "Pass/Fail Limits" (Edit Spec)
 - "Test Parameters" (Edit Parm)

How to Print (task list) There are five basic steps to printing listed below. A detailed description of each of these steps is at the end of this section.

- 1. Check to see if your printer is supported by the test set (see "Supported Printers" on page 242).
- 2. Determine if your printer requires serial, parallel, or HP-IB connection. Connect the printer to the appropriate port on the test set (see"Printer Connection" on page 242.
- 3. Configure the test set for your printer and its interface (see "Configuring the Test Set for Printing" on page 245).
- 4. Instruct the test set what to print "To print test results:" on page 246).

Supported Printers

- HP ThinkJet printer
- HP QuietJet printer
- HP PaintJet printer
- HP DeskJet printer
- · HP LaserJet printer
- Epson FX-80 printer
- Epson LQ-850 printer

If you do not have one of these printers, consult your printer's manual for the correct printer settings to emulate one of the supported printers.

Printer Connection

HP-IB Connection

An HP-IB printer can be connected to the test set's rear-panel HP-IB connector with an HP-IB cable.

Serial Connection

A serial printer can be attached to the serial port. See figure 1, "Test Set RJ-11 Serial Port Connections," on page 243. Use the following RJ-11 pins for this connection.

- RJ-11 Pin 2 test set Receive Data
- RJ-11 Pin 4 Ground
- RJ-11 Pin 5 test set Transmit Data




Figure 1 Test Set RJ-11 Serial Port Connections

Parallel Connection

A parallel printer can be attached to the parallel port. Use the following figure for pin information.




Figure 2 Test Set Parallel Port Connections

Configuring the Test Set for Printing

If using a serial printer, you cannot use the serial port for other connections at the same time, such as Data Collection (saving test results). Serial port connections are shown earlier in this section.

PRINTER SETUP DIFFERENCES

The HP 8920A,D had several firmware enhancements, which are standard in the HP 8920B. The following "Setup Printer" section applies to users with:

- HP 8920A,D test sets with firmware above revision A.14.00.
- All HP 8920B test sets.

The test set's firmware revision is displayed on the top right corner of the configuration screen.

 Press SHIFT CONFIG to display the configuration screen and read the firmware revision.

If you have an HP 8920A with firmware revision below A.14.00, to the next section, titled "To Setup Printer Using HP 8920A FW Below Rev A.14.00" on page 250". Contact Hewlett-Packard at 1-800-922-8920 for details on upgrading your firmware if desired.

EXCEPTION: If you are using A.xx.xx revision software, you can not use the **Printer Setup** screen regardless of your firmware revision. Refer to the instructions for firmware below A.14.00.

To Setup Printer Using Any HP 8920B Or HP 8920A FW Above Rev A.14.00

- 1. Press TESTS
- 2. Select Printer Setup from the SET UP TEST SET list.
- 3. Position the cursor to Model and select the desired printer.
- **4.** Position the cursor to **Print Port** and select the desired port.
- **5.** (If HP-IB only) Position the cursor to **Printer Adrs** and enter the HP-IB address for your printer (0-30).
- **6.** Set the following options if desired:
 - **a.** Lines/Page (controls the number of lines, 20-120, printed on a page before a form feed is sent to the printer)
 - **b.** FF at Start (to cause a form feed at the start of a test sequence)
 - c. FF at End (to cause a form feed at the end of a test sequence)
- 7. From the To Screen menu, select More.
- 8. From the Choices menu, select IO CONFIG.
 - **a.** For Serial Printing, set the **Serial Baud** field and other serial communications fields listed under it to correspond to your printer's configuration.
 - b. For HP-IB Printing, set the Mode field to Control.
- 9. Press TESTS to return to the TESTS (Main Menu) screen.

To print test results:

- 1. Press TESTS
- 2. Select Printer Setup from the SET UP TEST SET list.
- 3. Position the cursor to Output Results To and select Printer.
- **4.** Position the cursor to **Output Results For** and select **All** if you want all results printed, or **Failures** if you want failures only printed.
- 5. (Optional) Position the cursor to Output Heading and enter your desired heading.

To send Escape Sequences to the printer

If you have revision B.xx.xx software, you may use the test set to send escape sequences to control printer options such as pitch, margins, paper size, etc... The software comes with some pre-defined escape sequences compatible with HP printers, listed below, or you have the option to enter others which are compatible with your printer (use your printer's user's manual for the available print features and corresponding escape sequences). This function is not available with revision A.xx.xx software.

The software already has an implied escape character for the first sequence, you need only to enter the escape sequence following the escape character. However, if you are linking two or more sequences together, you must use the ~ to indicate the escape character between each sequence. If the sequence exceeds the space allotted in the options field, you may continue with additional escape sequences in the next available Options field. You must however, still enter Escape Seq in the Calling Name field and the appropriate address in the Addr field for all subsequent entries.

How to send an Escape Sequence:

- 1. Press TESTS.
- 2. Select External Devices from the SET UP TEST SET list.
- 3. Position the cursor to the Inst# field and select it.
- 4. Rotate the knob until an empty Calling Name field appears, and select it.
- 5. Position the cursor to the Calling Name field and select it.
- 6. Select Escape Seg from the Choices menu.
- 7. Position the cursor to the **Addr** (address) field and select it.
- **8.** Using the DATA keypad, enter **9** for serial printers, **15** for parallel printers, or **7xx** for HP-IB printers, then press ENTER. .
- Position the cursor to the Options field (directly under Calling Name) and select it
- **10.** Select the desired escape sequence from the **Choices** menu if applicable, or enter an appropriate sequence using the list of characters below the choices.

Table 10 Escape Sequence Definitions for HP Printers

Escape Sequence	Print Feature
&166P	Sets page length to 66 lines
&172P	Sets page length to 72 lines
&16D	Sets lines per inch to 6 lines
&18D	Sets lines to inch to 8 lines
(s12h12v6T	Selects 12 characters per inch 12/72 inch character height gothic typeface
&a9L~&16E	Sets left margin to 9 characters top margin to 6 lines
(s12h12v6T~&a9L~&l6E	Selects 12 characters per inch 12/72 inch character height gothic typeface left margin to 9 characters top margin to 6 lines
&18d88P	Selects 8 lines per inch 88 lines per page
&18d96P	Selects 8 lines per inch 96 lines per page
(s16.67h12V~&a17L~&l6E	Selects 16.67 characters per inch 12/72 inch character height left margin to 17 characters top margin to 6 lines

To print TESTS screens:

TESTS screens include:

- "External Devices"
- "Order of Tests"
- "Channel Information"
- "Pass/Fail Limits"
- "Test Parameters"

The same general process is used to print the information for all of the above TESTS screens.

- **1.** Make sure that your printer is properly connected and configured as explained earlier in this section.
- 2. Press TESTS.
- 3. Select the CUSTOMIZE TEST PROCEDURE screen of your choice.
- 4. Press k3 (Print All) and select it.
- 5. Press TESTS to return to the TESTS (Main Menu) screen.

To Setup Printer Using HP 8920A FW Below Rev A.14.00

- 1. Press TESTS
- 2. Select Edit Cnfg from the Test Function field.
- 3. Position the cursor to the **Inst#** field and select it.
- 4. Rotate the knob until an empty Calling Name field appears, and select it.
- 5. Position the cursor to the Calling Name field and select it.
- **6.** Using the list of characters in the **Choices** menu, enter the word **Printer**. Select **Done** when complete.
- 7. Position the cursor to the **Model** field and select it (optional).
- 8. Using the DATA keypad, enter the Model # and press ENTER.
- 9. Position the cursor to the Addr (address) field and select it.
- **10.** Using the DATA keypad, enter **9** for serial printers, **15** for parallel printers, or **7xx** for HP-IB printers, then press ENTER. .
- Position the cursor to the Options field (directly under Calling Name) and select it.
- **12.** Using the list of characters from the **Choices** menu, the following commands may be entered. Separate the commands with commas (example; **LN=60**, **START**, **END**)
 - **a.** LN equals the number of printed lines per page.
 - **b. START** causes a form feed at the start of each printout.
 - **c. END** causes a form feed at the end of each printout.
- 13. From the To Screen menu, select More.
- 14. From the Choices menu, select IO CONFIG.
- **15.** For Serial Printers:
 - a. Set the Serial Baud field and other serial communications fields listed under it to correspond to your printer's configuration.
- 16. For HP-IB Printers:
 - a. Position the cursor to the **Mode** field and select it.
 - b. From the Choices menu, select Control.
 - c. Position the cursor to the Print Adrs field and select it.
 - **d.** Rotate the knob and select the HP-IB address of your printer.
 - e. Position the cursor to the Print To field. Pressing knob will toggle the underlined selection. Select to underline HP-IB.
- 17. Press TESTS to return to the TESTS screen.

To print test results

- Make sure that your printer is properly connected and configured as explained earlier in this section.
- 2. Press TESTS.
- 3. Position the cursor to the Output Results To: field (or the Output Destination field). Pressing knob will toggle the underlined selection. Select to underline Printer.
- **4.** Position the cursor to the **Output Heading** field and select it.
- 5. Using the list of characters in the **Choices** menu, enter a printout heading (optional). Select **Done** when the heading is complete.

To send Escape Sequences to the printer

If you have revision B.xx.xx software, you may use the test set to send escape sequences to control printer options such as pitch, margins, paper size, etc... You may enter sequences which are compatible with your printer (use your printer's user's manual for the available print features and corresponding escape sequences). This function is not available with revision A.xx.xx software.

The software already has an implied escape character for the first sequence, you need only to enter the escape sequence following the escape character. However, if you are linking two or more sequences together, you must use the ~ to indicate the escape character between each sequence. If the sequence exceeds the space allotted in the options field, you may continue with additional escape sequences in the next available Options field. You must however, still enter Escape Seq in the Calling Name field and the appropriate address in the Addr field for all subsequent entries.

How to send an Escape Sequence:

- 1. Press TESTS.
- 2. Select Edit Cnfg from the Test Function field.
- 3. Position the cursor to the Inst# field and select it.
- 4. Rotate the knob until an empty Calling Name field appears, and select it.
- 5. Position the cursor to the Calling Name field and select it.
- **6.** Enter **ESCAPE SEQ** using the characters in the **Choices** menu. Select **Done** when you are finished.
- 7. Position the cursor to the Addr (address) field and select it.
- **8.** Using the DATA keypad, enter **9** for serial printers, **15** for parallel printers, or **7xx** for HP-IB printers, then press ENTER. .
- Position the cursor to the Options field (directly under Calling Name) and select it.
- **10.** Select the desired sequence using the list of characters below the choices.

Table 11 Examples of Common Escape Sequences

Escape Sequence	Print Feature
&166P	Sets page length to 66 lines
&172P	Sets page length to 72 lines
&16D	Sets lines per inch to 6 lines
&18D	Sets lines to inch to 8 lines
(s12h12v6T	Selects 12 characters per inch 12/72 inch character height gothic typeface
&a9L~&l6E	Sets left margin to 9 characters top margin to 6 lines
(s12h12v6T~&a9L~&l6E	Selects 12 characters per inch 12/72 inch character height gothic typeface left margin to 9 characters top margin to 6 lines
&18d88P	Selects 8 lines per inch 88 lines per page
&18d96P	Selects 8 lines per inch 96 lines per page
(s16.67h12V~&a17L~&l6E	Selects 16.67 characters per inch 12/72 inch character height left margin to 17 characters top margin to 6 lines

To print TESTS screens

TESTS screens include:

- "Edit Cnfg"
- "Edit Seqn"
- "Edit Freq"
- "Edit Spec"
- "Edit Parm"

The same general process is used to print the information for all of the above TESTS screens.

- **1.** Make sure that your printer is properly connected and configured as explained earlier in this section.
- 2. Press TESTS.
- **3.** Select the TESTS screen you desire.
- 4. Press k3 (Print All) and select it.
- **5.** Press TESTS to return to the TESTS screen.

Procedures

A procedure is a collection of test parameters, pass/fail limits and a testing order, saved in a file that customizes the test software to a specific application. You may save the file on a memory card or disk.

You do not have to save a test sequence in a procedure. Each test can be standalone if desired. After you choose a procedure, you can choose which of the tests you want to run.

When you save a procedure you will only be saving test parameters, pass/fail limits and a testing order. The memory card or disk must also contain a library file. A library file contains the names of all of the test parameters, pass/fail limits and tests that are in the test software. The library you use will be the library that is supplied with your software. When you save your procedure, the library will be automatically saved on the same card or disk.

The procedure(s) supplied with your software will be listed in the **Choices:** column when you select the **Select Procedure Filename:** (or **Procedure**) field. Procedures will be displayed if your software memory card is plugged in.

Saving a Procedure

After you have set up the test software you can save the setup to an SRAM memory card, disk, or internal RAM memory by doing the following.

The memory card or disk you use must be initialized before its first use. See "Initializing a Memory Card" on page 233 or "Initializing a Disk" on page 225. If you are using a disk drive, you may have to enter the External Disk Specification into the TESTS External Devices screen (or Edit Cnfg screen). It will be used when the Select Procedure Location: field on the TESTS screen is Disk.

To save a procedure: 1. Press TESTS.

- 2. Select Save/Delete Procedure from the CUSTOMIZE TEST PROCEDURE list (or Proc Mngr from the Test Function field).
- 3. Position the cursor to the Select Procedure Location (or Location) field and select it.
- 4. From the Choices menu, select the desired location. The media must be initialized before a file can be saved. To initialize an SRAM card (HP 8920B or HP 8920A,D firmware above revision A.14.00 only, otherwise see "Initializing a Memory Card" on page 233):
 - **a.** Insert card in the slot on the test set's front panel.
 - **b.** Press k3 (Init Card)
 - c. Press Yes. Note: this will delete any procedures or programs from memory.

To initialize a RAM disk, see "Memory Cards/Mass Storage" in the HP 8920 Programmer's Guide.

- 5. Position the cursor to the Enter Procedure Filename (or Procedure) field and select it.
- 6. From the list of characters in the **Choices** menu, enter a filename. Filename must be nine characters or less. When filename is complete, position cursor to **Done** and select it. Procedure filenames that already exist on the card will appear at the top of the list of
- 7. If you selected Card, insert an initialized memory card into the slot on the test set's front-panel.
- 8. Verify that the card or other media is not write-protected. See "Memory Cards" on page 229.
- 9. Position the cursor to the Enter Description for New Procedure (or Comment for new procedure) field and select it. From the list of characters in the Choices menu, enter comments. When the comments are complete, position the cursor to **Done** and select it.
- 10. Position the cursor to the Procedure Library (or Library for new **procedure**) field and select **Current** (Current underlined). The name of the Library is displayed on the TESTS screen.
- 11. Position the cursor to the Code Location (or Program location for new procedure) field and select it.

From the Choices menu, choose memory Card, ROM, RAM or Disk. When a procedure is run, the test system will look in this location for a code file if it is not resident in the Test Set's battery-backed-up memory. This location will usually be the software memory card.

12. Press k1 (Save Proc) (or position the cursor to the Action field and select Make **Procedure**). A procedure will be saved at the location you chose.

Loading a Procedure

A procedure can be loaded from storage media into the test set's battery-backedup memory by doing the following.

To load a procedure: 1. Press TESTS.

- 2. Position the cursor to the Select Procedure Location (or Location) field and select it.
- 3. From the Choices menu, choose the desired location where the procedure is stored and select: Card, ROM, RAM or Disk.
- 4. Position the cursor to the Select Procedure Filename (or Procedure) field and select it.
- 5. From the **Choices** menu, choose the procedure file that you want to load.
- 6. Read the Description (or Comment) field to ensure that the loaded procedure file is the one you want.

Deleting a Procedure

Procedures can be removed from an SRAM memory card, disk or RAM by doing the following.

To delete a **Procedure**:

- 1. Press TESTS.
- 2. Select Save/Delete Procedure from the CUSTOMIZE TEST PROCEDURE list (or Proc Mngr from the Test Function field).
- Position the cursor to the Select Procedure Location (or Location) field and select it.
- **4.** From the **Choices** menu, select the desired location.
- 5. Position the cursor to the Enter Procedure Filename (or Procedure) field and select it.
- **6.** From the **Choices** menu, select the name of the procedure you wish to delete.
- 7. Press k2 (Del Proc) (or position the cursor to the Action field and select Delete Procedure).
- **8.** Press Yes if you wish to continue.

Securing a Procedure

After you have set up your test software with a testing order, channel information, test parameters, and pass/fail limits, you may wish to secure it. This operation will prevent the viewing and changing of those functions. You can select the items you wish to secure or un-secure. An IBASIC ROM program is stored in the Test Set's firmware to do this.

You can secure the procedure that is supplied with the test software. It is shipped un-secured.

After you make a procedure, you can secure it.

To secure a **Procedure**:

- 1. Press TESTS.
- Position the cursor to the Select Procedure Location (or Location) field and select it.
- 3. From the Choices menu, select ROM.
- Position the cursor to the Select Procedure Filename (or Procedure) field and select it.
- 5. From the Choices menu, select IB_UTIL (or SECURE_IT).
- 6. Press k1 (Run Test.)
- Select the location of the procedure you want to secure: k1 (memory Card) or k2 (RAM.)

NOTE:

RAM refers to the RAM Disk memory within the test set. Before selecting RAM, you must initialize the RAM as a disk. See "Initializing RAM Disks" on page 261.

- **8.** Proceed with the on-line instructions. You may wish to secure only one of the items, such as pass/fail limits.
- **9.** When you are prompted to enter the **pass number**, enter any sequence of numerals 0 through 9 using the DATA keypad. Enter 9 digits or less.

To un-secure a procedure:

To un-secure a procedure, you must know the pass number.

- 1. Press TESTS.
- Position the cursor to the Select Procedure Location (or Location) field and select it.
- 3. From the Choices menu, select ROM.
- **4.** Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and select it.
- 5. From the Choices menu, select IB_UTIL (or SECURE_IT).
- 6. Press k1 (Run Test.)
- 7. Select the location of the procedure you want to un-secure: k1 (memory Card) or k2 (RAM.)
- **8.** Enter the name of the procedure you wish to un-secure.
- 9. If the procedure has any item secured, you will be asked for the pass number.
- 10. Proceed with the on-line instructions. Select the items you wish to un-secure.
- 11. When you are prompted, enter the pass number using the DATA keypad.

RAM Disk

RAM disk is a section of internal memory that acts much like a flexible disk. Programs can be stored, re-stored, erased, and retrieved.

The RAM disk is partitioned into four separate volumes; 0-3. Each volume is treated as a separate disk. You can also specify the size of each disk in 256-byte increments.

The four RAM disk volumes are designated :MEMORY,0,0 to :MEMORY,0,3. For example, to catalogue the contents of RAM disk volume '0' from the IBASIC Cntrl screen, enter

CAT ": MEMORY, 0, 0"

Volume 0's contents can be viewed.

RAM DISK ERASURE

Any existing programs or formatting on RAM is erased if you use the RAM_MNG or COPY_PL ROM programs, or the SERVICE screen's RAM Initialize function. Therefore, you should only use RAM disks for short-term storage of files.

Initializing RAM Disks

Each RAM disk volume must be initialized before it can be used.

NOTE:

If you are using a RAM disk to store a test procedure, you must initialize the RAM disk volume 0. When the software saves a procedure to the Test Set's RAM, it automatically stores the procedure into the memory location volume 0. This is not changeable.

To initialize RAM disk Volume 0:

Volume 0 can be initialized using the **RAM_MNG** procedure stored on the internal ROM's **IB_UTIL** menu.

- 1. Press the TESTS key.
- 2. Position the cursor to the Select Procedure Location field and select it.
- 3. From the list in the Choices: menu, select ROM.
- 4. Position the cursor to the Select Procedure Filename field and select it.
- 5. From the list in the Choices menu, select **RAM_MNG**.

RAM_MNG is the RAM manager program.

6. Press the k1 (Run Test) key.

The program will begin execution.

- 7. Read the precautions provided on the Test Set's screen and then press the k1 (Yes) key to continue.
- 8. Press the k3 (Int RAM) key.

This selects the Test Set's internal RAM as the location to be initialized.

9. Enter the number of records you wish to initialize using the data key pad and then press the ENTER key.

50 records should be sufficient for saving a procedure.

10. Press the k1 (Yes) key to verify the number of records was entered correctly.

The internal RAM: MEMORY, 0,0 is initialized.

To initialize RAM volumes 1, 2, or 3:

Volumes 1, 2, and 3 must be initialized from the IBASIC Cntrl screen.

- **1.** Press the TESTS key.
- 2. Select IBASIC Cntrl from the SET UP TEST SET list (or the Test Function field).
- **3.** Position the cursor to the data entry field and select it.
- **4.** Using the list of characters from the **Choices**: menu, enter the following command:

```
INITIALIZE ":MEMORY,0,<volume number 1-3>",<volume size>
or
```

INITIALIZE ":MEMORY,0,1",50

The optional 'volume size' in the command lets you specify the memory area set aside for each disk in 256-byte blocks.

Chapter 5	, Reference	(Alphabetical)
Saving Te	ests Result	S

Saving Tests Results

See "Data Collection (Saving and Retrieving Test Results)" on page 215.

Serial Port

This 6-pin, RJ-11 serial port is used to input and output serial data. Serial data is used for entering programs, printing, and for sending test results to a connected controller, disk drive, or terminal.

Operating Considerations

The serial communications settings are defined on the I/O CONFIGURE screen. Ground is used with both IBASIC and all other serial connections. Transmit B and Receive B are exclusively used with IBASIC programs. Transmit and Receive are used with all other serial connections (see figure 3, "Test Set RJ-11 Serial Port Connections," on page 266).

The IBASIC Controller sends data to and receives data from the serial ports using address **9** for the primary port, and address **10** for Port B.

Use an RJ-11/25-pin RS-232 adapter (HP P/N 98642-66508) and RJ-11 cable (HP P/N 98642-66505) to connect the HP 8920A,B,D to a serial printer or terminal/computer.

RJ-11 CONNECTORS

RJ-11 cables and adapters can be wired several ways. If you buy a cable or adapter other than the HP parts listed, verify the connections for the pins indicated in the following **table** 12 before connecting cables to the instruments.

The following table 12 lists connections for Transmit, Receive, and Ground pins (address 9).

Table 12 Transmit, Receive, and Ground Pin Connections

HP 8920A/D RJ-11 Serial Port	t	Terminal/PC 25-Pi RS-232	n	Terminal/PC 9-Pin RS-232
Pin 2 (RX)	to	pin 2 (TX)	or	pin 3 (TX)
Pin 5 (TX)	to	pin 3 (RX)	or	pin 2 (RX)
Pin 4 (GND)	to	pin 7 (GND)	or	pin 5 (GND)




Figure 3 Test Set RJ-11 Serial Port Connections

Test Execution Conditions

In some situations, you may wish to change the way the software works when a test result is obtained. **Test Execution Conditions** allow you to do this.

Test Execution Conditions are accessed from the SET UP TEST SET list on the TESTS (Main Menu) screen. Press TESTS, then select Execution Cond to display them. (They are displayed directly on the main TESTS screen in firmware below revision A.14.00).

Test Execution Conditions are not retained after a power-down/power-up cycle.

The following Test Execution Conditions can be set as needed:

Output Results To: (Output Destination)

You can select either: Crt or Printer Default:Crt

You can specify where test results are to be placed. If you select Crt, results will be displayed on the test set's CRT. If you select Printer, test results will be sent to the CRT and to a printer. You must connect and configure a printer if you select Printer. See "Printing" on page 241.

Output Results For: (Output Results)

You can select either: All or Failures Default: All

You can specify if you want only the failed results to be displayed or printed. This will be useful if you generally do not print test results, and want to ensure that failed results are displayed or printed.

Output Heading

You can use this field to enter a heading that will be printed or displayed.

Select the Output Heading field. Use the knob to choose and enter the characters that you want to appear in the heading.

Choose **Done** when you are finished.

If Unit-Under-Test Fails (If UUT Fails)

You can select either: Continue or Stop Default:Continue

If you set this to Stop, and a pass/fail result is F, the program will stop.

Test Procedure Run Mode (Run Mode)

You can select either: Continuous or Single Step Default:Continuous

You can make tests pause at certain times. If you set this to **single Step**, the program will pause after a comparison is made between a test determination and the expected result. For example, tests will pause after the program compares the results to a specification. You can continue from the paused state by pressing k2 (Continue.)

Autostart Test Procedure on Power-Up

You can select either: On or Off Default: Off

You can set up the test set so that if the procedure was previously loaded, the procedure will be immediately executed when the test set is powered on.

USER Keys

When you are using the test set, you will see the following USER keys assigned appear at times in the top right corner of the display. These keys are assigned to the hard keys k1 through k5. In many cases, these keys can be used as "shortcuts" instead of positioning the cursor and selecting. USER keys are sometimes referred to as softkeys.

Clr Scr clears the test set's CRT display.

Continue continues the program after it has been paused.

Delet Stp is used to the edit items in a test sequence. When you press this key, the test in the displayed sequence that has its Step # highlighted (inverse video) will be deleted. The tests that follow in the sequence will be scrolled up by one step.

Del Proc is used to delete the selected procedure. When you press this key, you will be prompted to verify the command by pressing Yes.

Press **Done** when you want to exit a test or have completed a task. The program will continue if there is a next test in the sequence or if there are additional program steps in the test being run.

Help provides information on how to use the current TEST screen.

Init Card is used to initialize a memory card. Before you press this key, verify that the card is inserted correctly and not in the write-protected position.

Insrt stp is used to enter items into a test sequence. When you press this key, the test in the displayed sequence that has its step # highlighted (inverse video) will be copied into a new sequence location, immediately after the highlighted one. The tests that follow in the sequence will be scrolled down by one step. This key does nothing if there are no items in the sequence. Choose a test before using this key to insert another.

Main Menu is used to return to the main TESTS screen. The same result is achieved by pressing TESTS.

Page Up\Page Down are used to quickly display items in the list when some of the items won't fit on the screen.

Run starts an IBASIC program that has been loaded into the test set's memory.

Run Test loads and runs the program that is called from the procedure that has been entered into the TESTS screen Select Procedure Filename: entry. If the program is already loaded into the test set's memory, it will be started.

Save Proc is used to save the specified procedure.

sngl step steps the IBASIC program one line at a time. This is different from Continuous/Single Step run mode. See "Test Execution Conditions" on page 267.

Stop Test pauses the test software.

Take It causes the program to accept the setting of an adjustment, and proceed with the program. The test, determining if the adjustment is within limits, is ceased.

Yes\No are pressed when answering questions displayed on the test set's CRT display.

Problem Solving

If You Have a Problem Testing Your Radio

This section contains information for solving some of the most common problems related to using the HP 11807A,E radio-test software. All problems in this section have a single obvious symptom (shown in bold typeface at the top of each page), but many possible causes (listed in order from the most probable cause to the least probable cause).

NOTE:

If the test set displays an error that states "One or more self- tests failed", you have a hardware problem. In this case, refer to the test set's *Assembly Level Repair* manual.

If the problem has to do with operating the test set, you'll want to refer to the MESSAGE screen to list errors or operating messages that have occurred since the instrument was turned on. To do this, press the SHIFT and then the MSSG key.

Also, the *HP Instrument BASIC* manual describes any errors that happen as a result of running IBASIC programs.

If the test procedure doesn't run on an test set

 \Box Check to see that a test procedure file has been loaded into the test set.

In the upper left corner of the TESTS (Main Menu) screen, a file name should be seen in the Select Procedure field. If the field is blank, then a test procedure file has not been loaded.

To load a test procedure file:

- 1. Press TESTS.
- 2. Position the cursor to the Select Procedure Location (or Location) field and choose Card from the Choices menu.
- **3.** Position the cursor to the **Select Procedure Filename** (or **Procedure**) field and choose the test procedure file you want from the **Choices** menu.
- ☐ Check that you have selected k1 (Run Test) to start testing.
- ☐ Check the MESSAGE screen to see if an error is causing the test procedure to not run.

If you see the error message "Structures improperly matched" or "Improper context terminator", the software program was incorrectly loaded into the test set. In this case, refer to the directions on the next page.

NOTE:

Test procedure files are not the actual code or program needed to run the tests. You'll need to load the test procedure file, then run the selected tests with the memory card containing the program code inserted in the memory card slot. The program code remains loaded in the test set until another program is loaded.

If the HP 11807A,E program was incorrectly loaded

An error message like "Structures improperly matched" or "Improper context terminator" appears. It takes 2-4 minutes to load an HP 11807A program when k1 (Run Test) is first pressed. It takes approximately 15 seconds to load an HP 11807E program. Thereafter, it takes only a few seconds to run.

☐ Were the SHIFT CANCEL keys pressed or the memory card removed while the program was loading? If this was done, you will need to clear the RAM, or load another program and then re-load the HP 11807A,E program.

To clear RAM in the test set: (All SAVE registers are lost.)

- 1. Press TESTS.
- 2. Position the cursor to Select Procedure Location and choose ROM from the Choices menu.
- Position the cursor to Select Procedure Filename and choose IB_UTIL (or COPY PL) from the Choices menu.
- 4. Press k1 (Run test.)
- 5. Press k5 (CLEAR RAM.)
- **6.** Press TESTS, and re-load and run the test procedure you want.
- Check to see that the test set has enough RAM memory. To see if there's enough RAM memory:
- 1. Press TESTS.
- Position the cursor to Select Procedure Location and choose ROM from the Choices menu.
- 3. Position the cursor to Select Procedure Filename and choose LIST_OPTS from the Choices menu.
- 4. Press k1 (Run Test.)
- 5. If the screen displays OPTIONAL RAM, your test set has enough RAM memory. If OPTIONAL RAM is not displayed, refer to "Loading a Software Upgrade, FW below rev A.12.04 only" on page 66.

If the printer does not print the test results

- ☐ Check that the printer is turned on.
- ☐ Check that the HP-IB, parallel, or serial cable from the test set to the printer is connected.

If have firmware below revision A.14.00 OR you are using software with Revision A.xx.xx

- 1. Press TESTS.
- 2. Check that Printer was selected as the Output Destination in the Test Execution Conditions.
- 3. Check that the test set is correctly configured for HP-IB, parallel, or serial printing:

For a HP-IB printer:

- a. Check that the printer's Calling Name is "PRINTER" and its address is correctly set up in the External Devices (or Edit Cnfg) screen.
- **b.** Check that the I/O CONFIGURE screen has been set up correctly:
 - i. Mode=Control
 - ii. Print To=HP-IB
 - iii. Print Adrs=address of your printer

For a parallel printer:

a. Check that the printer's Calling Name is PRINTER and its address is set to15 in the External Devices (or Edit Cnfg) screen.

For a serial printer:

- a. Check that the printer's Calling Name is PRINTER and its address is set to9 in the External Devices (or Edit Cnfg) screen.
- **b.** Check that the I/O CONFIGURE screen has been set up correctly for the printer's baud rate, parity, and so forth.

Refer to the test set's *User's Guide* for details about configuring the printer.

If you have an HP 8920B or HP 8920A,D with firmware above revision A.14.00 AND you are using software with Revision B.xx.xx

- 1. Press TESTS.
- 2. Select Printer Setup from the SET UP TEST SET list.
- 3. Check that Printer was selected in the Output Results To:.
- 4. Check that the test set is correctly configured for HP-IB or serial printing:
 - a. Select Model and choose the most compatible printer model from the Choices menu.
 - b. Select Printer Port and choose which printer port you are using.
 - c. If the HP-IB port was selected, check that the correct Printer Adrs was entered.
 - **d.** If the Serial port was selected, check that the I/O CONFIGURE screen has been set up correctly for the printer's baud rate, parity, and so forth.

Refer to the test set's *User's Guide* for details about configuring the printer.

If you can't get the data-collection function to work

- ☐ Check that you have **DATA C** entered in the TESTS (**External Devices**) (or **Edit Config**) menu.
- 1. Press TESTS.
- 2. Select the External Devices screen, from the SET UP TEST SET list (or Edit Config from the Test Function field).
- **3.** Position the cursor to the **Calling Name** field, push the knob and enter:

DATA C.

- ☐ Check the **Model** field, it should be kept empty since it is not used.
- ☐ Check the **Addr** (address) field to make sure the correct address is entered for where the data is to be stored.
 - 1. If data is to be stored on an SRAM memory card, enter "1" into the Addr field.
 - **2.** If data is to be stored on an external computer through the test set's RS-232 serial port (if available), enter "**9**" into the **Addr** field.
 - 3. If data is to be stored on an external disk drive over HP-IB, enter an address of "700" or greater into the Addr field.
- ☐ Check the **Options** field to make sure it is correctly set up:
- 1. For an external disk drive (LIF format) or an SRAM memory card:
 - a. Enter ASCII for saving data as an ASCII file.
 - **b.** Enter **BDAT** for saving data as a Binary-Data file.
 - c. As an option, you may enter REC=xxx, where "xxx" is the number of records for each file. (The software defaults to 80 records. However, if too small a record size is used, you'll get an "End of file error" when the test is run.)
- For a DOS disk drive, you may keep the Options field empty, or you may enter any of the following key words:
 - **a.** Enter **ASCII** for saving data as an ASCII file.
 - **b.** Enter **BDAT** for saving data as a Binary-Data file.
 - c. Enter REC=xxx for the file's record size, where "xxx" is the number of records for each file. (The software defaults to 80 records. However, DOS systems automatically change record size if it's too small.)
 - **d.** Enter a (**dot extension**) of 3 characters or less for the file name. For example, all model ABCD radio's tested may be organized to have a ".ABC" file extension.

- ☐ Check the test set to make sure it's in the controller mode if you are using an external disk drive.
- 1. Access the I/O Configure screen from the More field in the To Screen menu.
- 2. Position the cursor to the Mode field and select Control.

NOTE:

When the test operator is prompted to enter a file name where data is to be stored, the protocol for the mass-storage device being used must be followed.

Hierarchial directory paths are not allowed, and all files are created with "FORMAT ON".

Also, when initializing a disk, use the following format ("7xx" is the disk address, "y" is the device selector):

DOS disk: INITIALIZE "DOS:CS80,7xx,y"

LIF disk: INITIALIZE ":,7xx,y"

If the cellular phone fails to obtain service

- ☐ Check test parameter 3 CP Control Channel to make sure it is set to the correct control channel for which your cellular phone is programmed to use. The range of control channels for phones programmed to use the "A band" is 313-333. The range of control channels for phones programmed to use the "B band" is 334-354.
- ☐ Check the antenna connection on the cellular phone. The cellular phone's antenna should be connected to the test set RF IN/OUT connector and not to the DUPLEX OUT connector.
- ☐ Check that the cellular phone is on frequency with the test set's timebase.

The test set Option 001 High-Stability Timebase is recommended for cellular phone testing.

If your test set is equipped with Option 001, use a frequency counter to ensure that the High-Stability timebase is on frequency.

If the cellular phone registers, but won't page

☐ Check the cellular phone to see if it is the type with all zeros in its Mobile Identification Number (MIN). In some cases, new cellular phones have not been programmed with a MIN number.

If it is, set parameter 2 CP all zero MIN number to 1 (for yes).

If the cellular phone fails the audio tests

- ☐ Check the specifications for the cellular phone to make sure they match with those entered in the HP 11807A,E software Pass/Fail Limits.
 - Select Pass/Fail Limits from the Customize Test Procedure list (or Edit Spec from the Test Function field), and note the limits that have been entered for the corresponding audio specifications.
- ☐ Check the audio connections from the cellular phone to the test set. Refer to the interconnection diagram in chapter 2 for details.
- ☐ Check the cellular phone to make sure the microphone is not active. (Mute the microphone input).

For a handset type phone, make sure the handset is on the "hook".

For a handheld type phone, make sure the handheld is muted

☐ Check the cellular phone to see if the audio lines carry other signals.

For example, if the audio lines carry other dc signals, a blocking capacitor in series with the test set is required.

If a cellular phone links up with a system, not the test set

Check to see if the testing area is in the proximity of a cell site.
Corrective action:
Raise the signal level of parameter 27, RX RF level for signaling to overpower the external cell-site signal.
Check to see if the cellular phone's antenna connector is connected to the test set RI IN/OUT connector.
Corrective action:
Connect a cable from the cellular phone to the test set RF IN/OUT connector.

CANCEL A key used to pause (stop) the IBASIC program running in the test set.

card Refers to the memory card containing the procedures for testing the unit-under-test.

Choices Refers to a field in the lower right of the screen that displays several possible functions for selection.

Continue Proceed with the IBASIC software program if it has been stopped (paused).

cursor Refers to the brightened region of the screen used to indicate the field/function currently being accessed.

Del Step A function to delete a step in the procedure.

Disp Loc A menu function which presents an assembly diagram that displays location of the adjustable component.

ESD ElectroStatic Discharge - A transfer of electric charge from one place to another. Devices can be damaged by the energy transferred during the discharge.

field An area on the CRT with an inverse video display (**example**) where entries can be made.

function Refers to a particular field, feature, or operation of the test set.

Help A feature providing specific information about how to use the current screen in the TESTS environment. This feature is accessed by pressing k4 (Help)from any TEST screen. Note: only

available in the HP 8920B and HP 8920A,D firmware above revision A.14.00.

HELP A feature providing additional test set information accessed by pressing SHIFT, then TX (HELP) keys. Help topics are listed in alphabetical order.

highlight Refers to the brightened region (cursor) of the screen used to indicate the field/function currently being accessed.

IBASIC Instrument BASIC is the computer language (code or software) used by the test set's built-in controller. The IBASIC software is downloaded from the OTP CARD into the test set's RAM. This software is then used to control the test set during autotesting the unit-under-test.

initialize A card or disk must be formatted prior to storing data. This may be done by pressing k3 (Init Card) on the TESTS (Save/Delete Procedure) screen. The default for PCMCIA cards (HP 11807E) is DOS format, and for Epson Cards (HP 11807A/B) is LIF format. See "Memory Cards" on page 229 for information on changing these default settings.

key (USER keys) Keys refer to any of the push buttons on the front panel of the test set. The USER keys are a specific grouping of keys labeled k1 to k5 which perform the associated numbered function in the action field located in the upper right of the screen. The USER keys are user programmable.

knob The large tuning dial for cursor control located in the center of the test set front panel. This knob is rotated to position the cursor on the screen and then pressed to select the particular field or function.

library A collection of the names of all of the parameters, pass/fail limits, and tests in the test software. The test software and the test set's firmware use the library, test software program code file, and a procedure to run a customized application program. A library is stored as a file on a memory card or other mass storage with its associated procedure files.

Location Where to retrieve or save a particular testing procedure, for example, to a disk, card, RAM, or PC.

measurement A series of calculations on data measured by the test set. These calculations provide a value to be compared against pass/fail limit values that verify the performance of the unit-under-test.

Main Menu The screen accessed by pressing the TESTS key, or k5 Main Menu. It is used to customize and execute (run) automated testing.

Also referred to as the "TESTS" screen.

menu The test set's screen displays various tasks to be selected with the cursor control knob or the USER keys; this display is the menu.

message The upper portion of the test set's screen is reserved for messages and prompts. Messages give an indication of the status of the test set, for example, **System initialization**.

OTP One Time Programmable (OTP) refers to a CARD on which code or date may only be stored once; similar to ROM. The HP 11807A/E software is shipped on an OTP memory card.

parameters Entries you make for calibration data, phone characteristics, or test customization. They give you flexibility in the way you use the software. Default values for parameters are present in the software.

pass/fail limits Pass/fail limits are the names of criteria verifying the performance of the unit-under-test. Usually, the associated measurement value must fall within the HI/LO limits of pass/fail values to verify performance of the unit-under-test. Default values in the test software have been derived from standard methods of measurement or from the unit-under-test requirements.

pause Using the CANCEL key pauses the running of IBASIC software in the test set and allows access to the keyboard functions. CONTINUE allows the software to proceed.

peak+/- max A detector in the test set that measures and computes the maximum of the absolute value of the positive and negative excursions of the measurement. For example, when an FM waveform with a +10 kHz and -9 kHz deviation is applied, 10 kHz will be displayed.

PRESET Sets the test set to its initial power-up state.

procedure A shortened label for test procedure. A procedure is a collection of channels, parameters, pass/fail limits, and testing order, saved in a file, that customizes the test software to a specific application. Procedures are made by editing existing channels, parameters, pass/fail limits, and testing order, and saving the resulting files to a memory card, disk or internal test set RAM.

prompts The upper portion of the test set (inverse video field) is reserved for prompts and messages. The prompt directs the user to take some action. Messages give an indication of the status of the test set.

RAM Random Access Memory - The memory in the test set that is used to store program code and data. The test set's RAM is battery-backed-up, retaining data and program codes when the power is turned off.

ROM Read Only Memory

Run Test Directs the test set to load the program from the current procedure and begin testing (may take up to two minutes).

save Save and store are used synonymously and refer to putting data or software on some memory device, such as, card or RAM.

screen Refers to the video display of the test set.

select To choose a particular field or function. Rotate the CURSOR CONTROL knob and position the highlighted cursor on the chosen field or function, then press the knob. An alternative method is to press the

numbered USER key having the same number as displayed alongside the desired function.

softkey The name of the set of keys next to the CRT display that can be assigned to certain special actions or fields. The keys are also called USER keys.

SRAM Static Random Access Memory - A data storage device. SRAM memory cards can be used with the test set to save programs and test results.

Step# Orders the sequence of tests, e.g. Step #1 may be Test_5, and Step #2 may be Test_26 and so on.

store Store and save are used synonymously and refer to putting data or software on some memory device, such as card, RAM.

tests Tests are a collection of measurements (or a series of other tests) which verify a particular specification value or operation of the UUT. A sequence of tests are contained in a test procedure.

TESTS screen The screen accessed by pressing the TESTS key. It is used to customize and execute (run) all automated testing. Also referred to as the "Main Menu".

USER keys A group of keys located immediately to the right of the test set's screen that allow the user to more rapidly select certain functions without rotating and pressing the knob. These key assignments are displayed in the upper right portion of the test set's screen. The number on the left of the function corresponds to the number on the user key k1 to k5.

values The scalar quantities or numbers inserted in the inverse video fields of the pass/fail limits or parameters. Units of measure (dB, inches, volts, watts, etc.) are contained in the pass/fail limits and test parameters.

Numerics Autostart Test Procedure on Power-Up, 268 1-800 help line, 23 AA Enter Ph#? parameter description, 137 AB MIN From? parameter description, 138 additional services available, 23 AdvanceLink, 220 AF Analyzer input gain attenuation, 169 ALERT order to the UUT, 97 all zero MIN number, 138 AMPS standard, 94, 112 antenna connection on the phone, 279 ASCII file type, 215 attenuation for signaling, 169 attenuator loss, 19 attenuators connected to HP 8920A, 145 audio connections from the cellular phone, 281 audio distortion pass/fail limit, 174, 184 audio distortion test for receiver, 120 for transmitter, 103 audio frequency response test for receiver, 119 for transmitter, 102 audio level setting it, 161 audio lines carry other dc signals, 281 audio output flatness, 102 audio power rated, 160 audio response deviation pass/fail limit, 175, 176, 185 audio response frequencies parameters, 151, 162

audio response roll pass/fail limit, 186

if the cellular phone fails, 281

audio tests

Autostart, 90

cable loss for pads and cables, 19 GANCEL, 240, 283 capacitor de blocking, 281 card how to insert, 30, 64 CAT BASIC command, 213 CCITT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels nor flowchart, 131 chng pwr on flowchart, 131 chng pwr on flowchart, 131 chng pwr on flowchart, 131 choses, 212, 283 choose, 212 Class II and III radios, 100 clear is on flowchart, 131 clear ms on flowchart, 13			
for pads and cables, 19 Bandpass, 6 kHz, filter, 19 BDAT file type, 215 Binary-Weighted Decimal (BWD), 164, 167 CAT IBASIC command, 213 CCITT filter, 120 cell site release, 125 cell-laste signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channels marrow, 40, 75 channels nor flowchart, 131 ching pur on flowchart, 131 ching sal/ching disat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear is on flowchart, 131 clear ms on flowchart, 1	В	C	•
Bandpass, 6 kHz, filter, 19 BCH error detection, 97 BCH error detection, 97 BDAT file type, 215 Binary-Weighted Decimal (BWD), 164, 167 167 168 Binary-Weighted Decimal (BWD), 164, 167 169 160 161 167 168 Binary-Weighted Decimal (BWD), 164, 167 168 Binary-Weighted Decimal (BWD), 164, 167 160 161 167 168 167 168 167 168 168	bandpass filter (BPF)	cable loss	•
BBAT file type, 215 Binary-Weighted Decimal (BWD), 164, 167 167 Capacitor de blocking, 281 card how to insert, 30, 64 CAT IBASIC command, 213 CCITT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels nor nlowchart, 131 ching pwr on flowchart, 131 ching sucking data on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 c	6 kHz option, 107	for pads and cables, 19	
de blocking, 281 card low to insert, 30, 64 CAT IBASIC command, 213 CCTTT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 changes and on flowchart, 131 ching bar on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear is on flowchart, 131 clear ms on flowchart, 131 clear is on flowchart, 131 c	Bandpass, 6 kHz, filter, 19	CANCEL, 240, 283	1
Binary-Weighted Decimal (BWD), 164, 167 167 Card MaxIC command, 213 CCITT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 can't link up with test set, 282 MIX number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels narrow, 40, 75 changes on flowchart, 131 chng su/ching dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 Clr Ser, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor	BCH error detection, 97	capacitor	•
how to insert, 30, 64 CAT IBASIC command, 213 CCITT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channels narrow, 40, 75 chang bar on flowchart, 131 chng sav'ching dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 Clr Ser, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor	BDAT file type, 215	dc blocking, 281	• •
CAT IBASIC command, 213 CCITT filter, 120 cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels narrow, 40, 75 change was a specifying information, 40, 75 change han on flowchart, 131 chng sav/fail limit, 188, 189 compressor zero-reference deviation pass/fail limit, 190, 197 configuration for data collection, 215 for terminal or PC operation, 223 CONFIGURE screen for printer, 275 configuration for data collection, 215 for terminal or PC operation, 233 configuration for data collection, 215 for terminal or PC operation, 230 configuration for data collection, 215 for terminal or PC operation, 230 configuration for data collection, 215 for terminal or PC operation, 230 configuration for data collection, 215 for terminal or PC operation, 230 configuration for data collection, 216 for terminal or PC operation, 230 configuration for data collection, 216 for terminal or PC operation, 230 configuration for data collection, 216 for terminal or PC operation, 20 configur	Binary-Weighted Decimal (BWD), 164,	card	
compressor zero-reference deviation pass/fail limit, 190, 197 configuration compressor zero-reference deviation pass/fail limit, 190, 197 configuration for data collection, 215 for data collection, 216 for printer, 242 connecting a printer	167	how to insert, 30, 64	compressor tracking error
cell site release, 125 cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chng chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flowchart, 131 Cl		CAT IBASIC command, 213	
cell-site signal to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chang chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flowchart, 1		CCITT filter, 120	
to overpower the external, 282 cellular phone antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels narrow, 40, 75 channels non flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor		cell site release, 125	pass/fail limit, 190, 197
cellular phone antenna connection on the, 279 audio connection, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 change han on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clar Ser, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor		cell-site signal	configuration
antenna connection on the, 279 audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chang chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 clear		to overpower the external, 282	
audio connections, 281 audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels narrow, 40, 75 channels narrow, 40, 75 change wr on flowchart, 131 chng pwr on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131		cellular phone	for terminal or PC operation, 223
audio tests, 281 can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chang chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor		antenna connection on the, 279	CONFIGURE screen
can't link up with test set, 282 MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channels numbers specifying information, 40, 75 channels narrow, 40, 75 chng chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart,		audio connections, 281	for printer, 275
MIN number, 280 registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chng chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flowchart, 131 Cle		audio tests, 281	configuring an IBM-compatible PC with
registers, but won't page, 280 won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channels narrow, 40, 75 channels narrow, 40, 75 channels on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flowchart, 131 Cler Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor the radio, 30, 64 connecting a printer, 242 connections parallel printer, 244 RJ-11 connector, 242 serial printer, 242 Continue, 269, 283 Continue USER key, 240 control channel parameter, 139 conventions used, 212 COPY_IBASIC command, 213 COPY_PL program, 274 copying files, 213 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain levels tested parameter, 164 current measurement, 19 current-measuring circuit, 114 current measurement, 19 current-measuring circuit, 114 compressor		can't link up with test set, 282	HP AdvanceLink, 220
won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chang chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flowchart, 131 Clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor connecting a printer, 242 connections parallel printer, 244 RJ-11 connector, 242 serial printer, 242 Continue, 269, 283 Continue USER key, 240 control channel parameter, 139 conventions used, 212 COPY IBASIC command, 213 COPY_PL program, 274 copying files, 213 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain test for transmitter, 114 current measurement, 19 current-measurement, 19 current-measuring circuit, 114 cursor, 283 customizing testing, 34, 69		MIN number, 280	connecting
won't roam if its off frequency, 279 Changing the Order of Tests, 36 channel information general description, 40 securing, 259 channels narrow, 40, 75 channels narrow, 40, 75 ching chan on flowchart, 131 ching sat/ching dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 Clear ms on flow		registers, but won't page, 280	the radio, 30, 64
channel information general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 chang chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 Clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor			connecting a printer, 242
general description, 40 securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 ching chan on flowchart, 131 ching sat/ching dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear is on flowchart, 131 Cler Scr, 269 C-Message filter, 19, 120 compressor RJ-11 connector, 242 serial printer, 242 Continue, 269, 283 Continue, 269, 284 Continue, 269, 240 Control chanel parameter, 139 control chanel parameter, 13			connections
securing, 259 channel numbers specifying information, 40, 75 channels narrow, 40, 75 channels on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain at levels 4-7 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain at levels 4-7 pass/fail li		channel information	parallel printer, 244
channel numbers specifying information, 40, 75 channels narrow, 40, 75 chng chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 current drain at levels 4-7 pass/fail limit, 192 current drain test current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 current measuring circuit, 114 current, 131 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 current measurement, 19 current-measuring circuit, 114 current measurement, 19 current-measuring circuit, 144 compressor		general description, 40	RJ-11 connector, 242
channel numbers specifying information, 40, 75 channels narrow, 40, 75 chng chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain test current drain test current drain test current drain est screen drain est current drain est		securing, 259	serial printer, 242
channels narrow, 40, 75 chng chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current measurement, 19 current-measuring circuit, 114 compandor is always on parameter, 144 compressor		channel numbers	Continue, 269, 283
channels narrow, 40, 75 chng chan on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current measurement, 19 current measuring circuit, 114 compandor is always on parameter, 144 compressor		specifying information, 40, 75	Continue USER key, 240
chng chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain test for transmitter, 114 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 compandor is always on parameter, 144 compressor			continuing a paused program, 240
chng chan on flowchart, 131 chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor parameter, 139 conventions used, 212 COPY_PL program, 274 copying files, 213 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 current, 144 customizing testing, 34, 69		narrow, 40, 75	control channel
chng pwr on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain tevels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 compandor is always on parameter, 144 compressor			parameter, 139
on flowchart, 131 chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 current drain tevels tested parameter, 164 current drain test current drain tevels 4-7 pass/fail limit, 191 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain evels tested parameter, 164 current drain test current drain test current drain test current drain test current drain tevels tested parameter, 164 current drain tevels tested current drain tevels tested parameter, 164 current drain at levels 4-7 pass/fail limit, 191 current drain at levels tested parameter, 164 current drain at levels 4-7 pass/fail limit, 191 current drain at levels tested parameter, 164 current drain at levels tested current drain test current dr		on flowchart, 131	conventions used, 212
chng sat/chng dsat on flowchart, 131 choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor copying files, 213 current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69 compressor		chng pwr	COPY IBASIC command, 213
chng sat/chng dsat on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor current drain at levels 0-3 pass/fail limit, 191 current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69 compressor		on flowchart, 131	COPY_PL program, 274
on flowchart, 131 Choices, 212, 283 choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor current drain at levels 0-3 pass/fail limit, 191 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69		chng sat/chng dsat	copying files, 213
choose, 212 Class II and III radios, 100 clear Is on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test current drain test current drain test parameter, 164 current measurement, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69 customizing testing, 34, 69			current drain at levels 0-3
choose, 212 Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor current drain at levels 4-7 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69		Choices, 212, 283	pass/fail limit, 191
Class II and III radios, 100 clear ls on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor Class II and III radios, 100 pass/fail limit, 192 current drain levels tested parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 customizing testing, 34, 69			current drain at levels 4-7
on flowchart, 131 clear ms on flowchart, 131 clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor parameter, 164 current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 current-measuring circuit, 114 current-measuring circuit, 114 current-measuring circuit, 144 customizing testing, 34, 69			pass/fail limit, 192
clear ms on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor current drain test for transmitter, 114 current measurement, 19 current-measuring circuit, 114 cursor, 283 customizing testing, 34, 69		clear ls	current drain levels tested
on flowchart, 131 Clr Scr, 269 C-Message filter, 19, 120 compandor is always on parameter, 144 compressor for transmitter, 114 current measurement, 19 current-measuring circuit, 114 cursor, 283 customizing testing, 34, 69		on flowchart, 131	parameter, 164
Clr Scr, 269 current measurement, 19 C-Message filter, 19, 120 current-measuring circuit, 114 compandor is always on parameter, 144 cursor, 283 current measurement, 19 current-measuring circuit, 114 cursor, 283 customizing testing, 34, 69 compressor		clear ms	current drain test
C-Message filter, 19, 120 current-measuring circuit, 114 compandor is always on parameter, 144 cursor, 283 customizing testing, 34, 69 compressor		on flowchart, 131	for transmitter, 114
C-Message filter, 19, 120 current-measuring circuit, 114 compandor is always on parameter, 144 customizing testing, 34, 69 compressor		Clr Scr, 269	
compandor is always on cursor, 283 parameter, 144 customizing testing, 34, 69 compressor		•	current-measuring circuit, 114
parameter, 144 customizing testing, 34, 69 compressor			cursor, 283
compressor		•	customizing testing, 34, 69
1		•	
zero reference deviation, 112		zero reference deviation, 112	

D	E	F
data collection	Edit Configuration	Factory Hot Line, 23
description, 215	data collection to a PC, 222	field, 283
entering the configuration for, 215	Edit Frequency, 40, 75	selecting a, 212
example configuration, 216	Edit Parameter, 50, 84	file name
memory card part numbers, 231	Edit Seqn field, 94	disk example, 226
retrieving data, 218, 226, 235	Edit Sequence, 71	file types, ASCII, BDAT, DOS, and HP-
saving to a memory card or disk, 215	Edit Spec, 238	UX, 215
to a PC, 220	Edit Specifications, 47, 81	files
to a PC, setting up, 222	EIA standard, 94	copying, 213
dc blocking capacitor, 281	EIA standards	filter
DC Current Measurement connectors, 19	for FM tests, 94	6 kHz Bandpass, 19
de-emphasis curve, 119, 175, 176	enter, 212	C-Message, 19
Del Proc, 269	ENTER key, 212	flash
Delet Stp, 269, 283	error	memory cards, 229
deleting a procedure, 258	Improper context terminator, 274	flow-chart test, 130
disk	improper context terminator, 273	FM hum and noise
initializing, 225	Structures improperly matched, 274	pass/fail limit, 194
initializing a RAM disk, 261	structures improperly matched, 273	FM hum and noise test
retrieving data from, 226	errors	for transmitter, 106
disk drive	from hardware problems, 272	Forward Voice Channel (FVC), 97
External Disk Specification, 255	from IBASIC, 272	Forward Voice Control (FVC)
disk formats, LIF and DOS, 215	from operating HP 8920A, 272	order message, 182
distortion	on MESSAGE screen, 272	frequency
audio, 103	escape sequences, 247	editing values, 40
distortion and noise, 122	rev B software with fw below A.14.00,	frequency counter
distortion, audio	251	to put timebase on frequency, 279
pass/fail limit, 184	exiting a program, 227	frequency deviation
Done, 269	expandor	caused by audio to UUT, 101
DOS disk format, 215	zero reference level, 117	frequency deviation step frequency
DOS file type, 215	expandor levels	parameter, 165
DSAT vector	parameters, 152	frequency error
parameter, 140	expandor test	pass/fail limit, 195
DTMF frequency error	for receiver, 117	frequency error test
pass/fail limit, 193	expandor tracking error	for transmitter, 99
DTMF frequency error test	pass/fail limit, 177, 178	front-panel control characters, 223
for transmitter, 134	expandor zero-reference level	FVC message error rate RF level
DUPLEX OUT	pass/fail limit, 179	parameter, 153
connector, 279	pass/fail limit, NAMPS, 181	FVC Order Message error rate test
	external path and cable loss	for receiver, 124
	parameter, 145	

H	I	\mathbf{L}
handoffs, 130	IBASIC, 283	library, 284
handset	copying files, 213	definition, 52, 86
type of phone, 281	initializing a disk, 225	saving, 52, 86, 255
hardware configurations, 19	retrieving data from a card, 218, 235	LIF disk format, 215
hardware errors, 272	retrieving data from a disk, 226	loading a procedure, 257
harmonic distortion, 174	TESTS screen, 34, 69	loading software, 30, 64
Help, 269	IBASIC commands	loading software upgrade, 66
high-pass filter, 166	entering from a terminal, 213	Location, 33, 68, 284
High-Stability timebase	IBASIC errors, 272	low-supply voltage
for cellular radio testing, 279	If Unit-Under-Test Fails, 268	parameter, 147
use a frequency counter, 279	If Unit-Under-Test-Fails, 56	
high-supply voltage	If UUT Fails, 268	
parameter, 146	Improper context terminator	
hook flash test, 133	error, 274	
hook flashes, 130	improper context terminator	
HP-IB	error, 273	
power supply, 19	industry standards	
HP-IB control annunciators, 228	for Option 004, 94	
HP-IB printer, 244, 275	Init Card, 269	
HP-IB printer connections, 242	initializing, 283	
HP-UX file type, 215	RAM disk, 261	
hum and noise	initializing a disk, 225	
pass/fail limit, 180	initializing an SRAM memory card, 233	
hum and noise test	input gain	
for receiver, 121	attenuation for AF Analyzer, 169	
for transmitter, 106	Insrt Stp, 269	
	instantaneous frequency deviation 101	

_	
J	
•	
•	
v	
)	

M	N	0
Main Menu, 269, 284	NAM	OMER
main power supplies, 19	Number Assignment Module, 95	pass/fail limit, 182
maintenance mode, 104	NAMPS	On UUT Failure, 90
maintence	entering narrow channel information,	operating errors, 272
on flowchart, 131	40, 75	Optional RAM message, 274
Manchester-encoded data, 108	NAMPS DSAT closure	order message, 141
measurement, 284	pass/fail limit, 198	order message error rate
measurements, 94	NAMPS DSAT deviation	pass/fail limit, 182
memory card, 283	pass/fail limit, 199	order of tests
memory cards	NAMPS DSAT phase jitter	printing, 241
are used for, 229	pass/fail limit, 200	saving, 256
determining whether it is OTP, flash, or	NAMPS modulation limiting	order-confirmation message, 141
SRAM, 229	pass/fail limit, 201	order-message error-rate test, 124
flash, 229	NAMPS RF level for SINAD	origination message, 141
how they're powered, 229	at extremes, parameter, 156	origination test
initializing, 233	parameter, 155	call processing, 126
inserting, 229	narrow channels	OTP
OTP, 18, 229	entering channel information, 40, 75	memory cards, 229
removing, 230	No, 269	OTP card, 284
retrieving data from, 218, 235	no audio functional tests, 127	OTP memory cards, 18
saving data to, 215	NO SERVICE indicator, 126	Output Destination, 90, 267
software, 30, 64	noise	Output Heading, 56, 90, 268
SRAM, 18, 229	into an open microphone, 107	output power at levels 0-7
SRAM battery part number, 231	noise and distortion, 122	pass/fail limit, 202
Static Random Access Memory (SRAM), 231	nominal-supply voltage parameter, 148	output power levels tested parameter, 167
storage space needed, 232	non-return to zero (NRZ), 108	output power test, 100
write protect switch, 231		Output Results, 90, 267
MESSAGE screen errors, 272		Output Results For, 56, 267
microphone		Output Results To, 56, 267
affected by noise, 107		•
make sure it's not active, 281		
sensitivity, 171		
mobile identification number, 280		
Mobile Identification Number (MIN),		
138		
modulation deviation limit 50 Hz HPF		
parameter, 166		
modulation deviation limiting test		

for transmitter, 101 modulation distortion, 184 modulation limiting pass/fail limit, 196 MRI levels parameters, 154

Page Down, 269 Page field, 130 page test, 97 Page Up, 269 page-response message, 141 paging and access channels, 108 parallel printer connections, 244 parameters, 284 editing values, 50, 84, 237 general description, 50, 84, 237 printing, 241 saving, 52, 86, 237, 256 securing, 259 part numbers memory card battery, 231 SRAM Memory Cards, 231 pass number, 259 pass/fail limits, 284 default values, 173 descriptions, 173 editing values, 47, 81, 239 general description, 47, 81, 238 printing, 241 saving, 238, 256 securing, 259 pause, 284 pausing a test, 240 PC collecting data to, 220 phone antenna connection on the, 279 audio connections, 281	configuring external, 19 current, 114 HP-IB supported supplies, 19 power-level changes, 130 predistortion, 112, 117 pre-emphasis curve, 185 pre-emphasis slope, 102 PRESET, 30, 64, 284 print options pitch, margins, paper size, typeface, 247, 251 printer does not print, 275 HP-IB, 244 HP-IB or serial, 275 output heading, 268 serial, 244 printers supported, 242 printing, 241 test results, 267 test results using firmware above revision A.14.00, 246 test results using firmware below revision A.14.00, 251 TESTS Screens, 249, 254 using A.xx.xx revision software, 245 Procedure, 33, 68 procedure, 94, 285 deleting, 258 general description, 52, 86, 255 loading into test set memory, 257 names, 255 saving, 52, 86, 255 securing, 259 un accurring, 260	quick general tests for receiver, 128 for transmitter, 127
•		
SRAM Memory Cards, 231		
•	1 0	
•	test results using firmware above revi-	
•		
editing values, 47, 81, 239	——————————————————————————————————————	
-	· · · · · · · · · · · · · · · · · · ·	
	· · · · · · · · · · · · · · · · · · ·	
	•	
	<u>e</u> ,	
	loading into test set memory, 257	
· · · · · · · · · · · · · · · · · · ·	<u> </u>	
audio tests, 281	un-securing, 260 what is saved, 255	
can't link up with test set, 282 MIN number, 280	program	
won't roam if its off frequency, 279	exiting a program, 227	
phone number, 95	incorrectly loaded, 274	
how to enter, 137	stored in test set memory, 230	
phone paging, 130	programmable power supplies, 19	
phone registers, but won't page, 280		
phone registration, 130		
power class, 95 power measurement		
units for measuring RF power, 170		
power output test, 100		
power supply		

ndex	ndex	ľ				
ıdex	ldex			5	ì	
ex	ex	ŀ	2		١	
9	æ	ŀ	ì		į	
×	×	ļ	1	•	į	
		ŀ	Ē			

_	DOMAN II	
R	ROAM indicator	S
radio	for origination, 126	SAT changes, 130
connecting, 30, 64	ROM, 285	SAT deviation
radio standards	Run, 269	pass/fail limit, 204
for FM, 94	Run Mode, 90, 268	SAT frequency error, 132, 205
RAM, 285	Run Test, 269, 285	SAT frequency error and Deviation test
disk, 261	difference between Run and, 218, 235	for transmitter, 107
initializing, 261	running tests, 26	SAT tone, 142
memory expansion, 19	overview, 28, 62	SAT tones, 107
RAM memory	RX MRI test, 135	save, 285
enough for the test set, 274		SAVE IBASIC command, 213
REC=		Save Proc, 269
default entry, 216		SAVE registers lost, 274
entering record number, 216		saving
REC= to set record size, 216		procedure, 52, 86
RECC message, 126, 141		test procedure, 52
RECC RCV Data		test results, 215
parameter, 141		saving a procedure, 255
receiver		SECURE IT ROM program, 259
quick general tests, 128		securing a procedure, 259
receiver hum and noise, 121		select, 212, 285
receiver sensitivity, 122		sensitivity
Regist field, 130		for the receiver, 122, 183
registration test, 95		sequence
release test		changing, 36
call processing, 125		editing, 71
retrieving data from a memory card, 218		general description, 36, 71
Reverse Control Channel (RECC), 97		saving, 52, 86
Reverse Control Message, 97		serial number, 95
RF level		Serial Port, 265
for signaling, 119		serial port connections
RF level for signaling		figure, 265
parameter, 157		serial printer, 244, 275
RF level for signalling		serial printer connections, 242
parameter, 282		set audio level
RF level for SINAD		parameter, 160
at extremes, parameter, 159		SID number, 143
parameter, 158		signaling attenuation, 169
RF power		signaling tone (ST), 104
units for measuring, 170		signaling tone (ST), 104 signaling tone deviation
RF power output test, 100		pass/fail limit, 206
RF sensitivity, 183		signaling tone frequency
RF signal level, 157		pass/fail limit, 207
RJ-11 connectors, 265		signaling tone test
rms detector, 104		for transmitter, 104
rms deviation, 112		•
· ·		signaling, tone/digital, 19 SINAD
roam if the phone won't 270		
if the phone won't, 279		pass/fail limit, 183

SINAD test	T	required order, 94
for receiver, 122	Take It, 269	running, 26
Sngl Step, 269	terminal emulator, 226	TESTS (Pass/Fail Limits) screen
softkey, 285	configuration, 223	entering into, 239
softkeys, 269	DataStorm Technologies, Inc. Pro-	TESTS screen, 285
software	Comm, 220	timebase
how to load, 33, 68	HP AdvanceLink, 220	High-Stability, 19
loading, 30, 64	test at extreme settings	tolerance for setting audio level
overview, 30, 62	parameter, 149	parameter, 161
stopping the, 240	Test Execution Conditions, 56, 90, 267	tone/digital signaling, 19
software revision A.xx.xx	Test Function	tracking error, 112, 117
printer setup, 245	Edit Frequency, 75	pass/fail limit, 177, 178
software upgrade	Edit Parameter, 50, 84	transmission
loading, 66	Edit Sequence, 71	continuous or discontinuous, 95
special display conventions used, 212	Edit Specifications, 47, 81	transmitter
specifications	Procedure Manager, 52, 86	quick general tests, 127
editing values, 47, 81	Test Functions, 69	transmitter current, 114
general description, 47, 81, 238	test parameters	transmitter distortion, 184
saving, 52, 86	default values, 136	TXT transient/steady state RVC data
specifying channel information	descriptions, 136	parameter, 172
general description, 40, 75	editing values, 237	
SRAM, 285	general description, 237	
memory cards, 229, 231	test procedure, 52	
SRAM memory cards, 18	saving, 255	
standards	Test Procedure Run Mode, 56, 268	
EIA and AMPS, 94	test procedures	
for FM tests, 94	don't run, 273	
for Option 004, 94	to load, 273	
steady-state frequency deviation, 101	test results	
Stop Test, 269	printing using firmware above revision	
stopping a test, 240	A.14.00, 246	
stopping the program	printing using firmware below revision	
using Test Execution Conditions, 56, 90, 267	A.14.00, 251	
Structures improperly matched	retrieving from a disk, 226	
error, 274	retrieving from a memory card, 218,	
structures improperly matched	235	
error, 273	saving, 215	
subscriber-unit	where sent, 267	
control functions, 108	test time, 240	
switch channels	testing order	
parameters, 168	securing, 259 testresults	
switch channels test	output failures, 267	
for transmitter, 132	tests, 285	
system ID, 95	entering a sequence of, 36, 71	
•	environment and conditions, 50, 84	
	pausing or stopping, 240	
	reference information, 94	

U upgrade loading software upgrade, 66 use DUPLEX OUT & ANT IN parameters, 150 user key, 212 USER keys, 269, 286 UUT phone number how to enter, 137 UUT volume level, 161

voice channels for handoff, 108 voltage for compressor zero crossing parameter, 171 volume level on the UUT, 161

wideband data
displayed by flowchart, 130
wideband data deviation
pass/fail limit, 208
wideband data deviation test
for transmitter, 108
wideband data deviation transient
pass/fail limit, 209
wideband data stream, 141

Y Yes, 269

7

zero reference level for expandor, 117