

**Quick Start
Guide**

**HP 37718A/19A
Communications
Performance Analyzer**

© Copyright Hewlett-Packard Ltd. 1998

All rights reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

HP Part No.
37718-90002

First edition, 09/98

Printed in U.K.

Documentation Warranty

The information contained in this document is subject to change without notice.

Hewlett-Packard makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties or merchantability and fitness for a particular purpose.

Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.


WARNING

For details of safety, see Safety information at the front of the Calibration manual.

Warning Symbols Used on the Product



The product is marked with this symbol when the user should refer to the instruction manual in order to protect the apparatus against damage.



The product is marked with this symbol to indicate that hazardous voltages are present



The product is marked with this symbol to indicate that a laser is fitted. The user should refer to the laser safety information in the Calibration Manual.

**HP 37718A/19A Communications
Performance Analyzer**

About This Book

The Quick Start Guide demonstrates the basic operation of the instrument.

This guide tells you how to select the displays that you want and how to use them to modify the instrument functions.





This guide also tells you about the front panel key functions, the indicators and the connectors.

Contents

Introducing the HP 37718A/19A Front Panel	7
Selecting Displays	8
Selecting Multiple or Single Windows	9
Moving Around Multiple Windows	10
Changing the Displayed Folder	11
Changing the Instrument Settings	12
Pop-upMenu Selection	13
Pop-Up Keypad	13
Making Selections with Pictorial & Graphic Displays	14
Transmitter Output SDH Payload Mapping	14
Using with a Monitor	15
Using the Other Front Panel Keys	16
Monitoring Status	18
Displaying Status History (Option 002 shown above)	18
General Alarm Indicators	19
PDH / DS _n Alarm Indicators	19
SDH Alarm Indicators	19
SONET Alarm Indicators	20

Getting Started

Getting Started shows you how to select displays and use them to change the instrument settings. Getting started includes the following:

- How to select single or multiple windows
- How to obtain the required display using the display select keys, **TRANSMIT** ; **RECEIVE** ; **RESULTS** ; **GRAPH** ; **OTHER**
- How to modify the display information, using    and  and the display softkeys or pop-up menus
- How to use the other front panel keys
- How to interpret the front panel status indicators
- How to connect to external equipment

Introducing the HP 37718A/19A Front Panel




Front panel keys and a display provide the operator interface to the HP 37718A/19A.

The display has two states, multiple (four), or a single window.

In the multiple window state, the active window is indicated by a different color to the three inactive windows.

Selecting Displays

The default display is a multiple page window. The displayed pages are: *Transmitter Output*, *Receiver Input*, *Results*, and either *Graph* or *Other* (Function).



TRANSMIT

Allows control of the settings associated with the generated signal.

RECEIVE

Allows control of the settings associated with the received signal.

RESULTS

Allows control of the test timing and graph storage and displays the selected measurement results.

GRAPH

Allows management of the stored graphical results.

OTHER

Allows control of Stored Settings, Settings Control, Floppy Disk, Logging, Remote Control, Time & Date, Miscellaneous (Keyboard Lock, Beep on Received Error, Suspend Test on Signal Loss, Graph Storage Resolution), Options (a list of Options fitted) and Option Enable, Self Test, Trigger Output, Calibration, and Color Control.


Getting Started
 Selecting Displays

Selecting Multiple or Single Windows

To select a single page window, press one of the display keys - **TRANSMIT**, **RECEIVE**, **RESULTS**, **GRAPH** or **OTHER** to make the required page active, then press **SINGLE WINDOW**.

To return to a multiple page window, press **MULTIPLE WINDOW**.

Example: To view the transmit page in a single window, press **TRANSMIT** to make the transmit window active.



Use **SINGLE WINDOW** to view the transmit page.

To change the page displayed in the single window, use one of the display keys **RECEIVE**, **RESULTS**, **GRAPH** or **OTHER**.

When you return to a multiple window, the current page will become the active page in the multiple window.



Getting Started Selecting Displays

Moving Around Multiple Windows

To make another of the displayed pages in a multiple window display active, press the display selection key for that page.

Example: The *Transmitter Output* page is active.



To make the *Receiver Input* page active. Press **RECEIVE**.



Similarly, press **RESULTS**, **OTHER** or **GRAPH** to make the page you want active. Note that the *Other* and *Graph* pages use the same (bottom right) window pane.

Getting Started

Selecting Displays

Changing the Displayed Folder

Some windows displayed with the **TRANSMIT** , **RECEIVE** and **RESULTS** keys contain folders. These folders can be selected with the **→** and **←** keys.

For example, the TRANSMITTER OUTPUT display below has three folders, MAIN SETTINGS, STRUCTURED PAYLOAD and TEST FUNCTION. In this example MAIN SETTINGS is selected



Example:

To change the folder from MAIN SETTINGS to STRUCTURED SETTINGS.



Press **→**



Changing the Instrument Settings

Settings that can be changed are displayed in a different color to the settings that are fixed. A highlighted cursor marks the current setting that can be changed.

Move the highlighted cursor about the display with    and .

The selections available for the highlighted setting appear in a menu at the bottom of the display, in this case **RS232** **HP IB** **DISK** **PARALLEL**. A selection is made with the relevant display key immediately below the menu.

When a field has more than five choices, as in **SPEED** shown here, a softkey labelled **MORE** is provided.

When **MORE** is selected the remainder of the menu is revealed.



Changing the Instrument Settings

Pop-up Menu Selection

A menu selection is available as an alternative to any group of soft keys. Display the menu with **SET**, and use **↑** and **↓** to make the selection.

To change to the new value, press **SET**. To exit the display without making the change, press **CANCEL**.

Example:



Pop-Up Keypad


The Pop-Up keypad display can be used to enter alphanumeric file and directory names, File descriptors and Disk labels.

- 1 Press **SET** to obtain the pop-up keypad.
- 2 Use **←** **→** to move across the rows and **↑** **↓** to move up and down the columns.
- 3 Choose the character required and press **SET**. Repeat until the name is entered.
- 4 Choose END and press **SET** to return to the original display.

Getting Started

Changing the Instrument Settings

Making Selections with Pictorial & Graphic Displays



In some cases selection is simplified with a pictorial or graphic "map" display. This facility is available where the display has a  symbol beside the setting. These displays are obtained in the same way as the pop-up menus using the **SET** key. Some of these displays include menus which allow the settings to be changed.



NOTE

Details of the pictorial display depend on the optional modules fitted to the instrument.

Transmitter Output SDH Payload Mapping


With the cursor in the MAPPING field, press **SET** to display the payload map.

To change between AU-layer, TU-layer and Payload layer selections, use  and .

To select the mapping you want, use  and .

To change to the new value, press **SET**. To exit the map display without making the change, press **CANCEL**.

Example:



Using with a Monitor

For ease of viewing at a distance, the instrument display may be presented on a monitor. The monitor should be connected to the HP 37718A/19A front panel VGA connector.

Using the Other Front Panel Keys



SMART TEST

Tests and scans payloads, signal structures, alarms and bit errors to attempt to configure the instrument to receive the incoming signal. Allows fast access to commonly used features.

RUN/STOP

Terminates the current test period or starts a new test period. The indicator above the key is on when a test period is in progress.

SINGLE

Adds a single bit error to the output data pattern each time the key is pressed.

LOCAL

Returns the instrument from Remote to Local control. The indicator above the key is on when the instrument is under Remote control.

PRINT NOW

The selected measurement results are logged, immediately, to the selected printer.

PAPER FEED

The paper in the internal printer is advanced.


Getting Started

Using the Other Front Panel Keys

CAUTION

Do not press **PAPER FEED** while loading a new roll of paper in the printer. A paper jam could result and disable the printer. Wait until the paper is fed through the printer mechanism before pressing **PAPER FEED**.

Monitoring Status



Displaying Status History (Option 002 shown above)

The Status indicators on the front panel convey information regarding the current status of the instrument. If an alarm has occurred during the current Test Period, the HISTORY indicator is on. To view which alarms have occurred, press and hold **SHOW**. When **SHOW** is released the status indicators return to displaying the current status.

SHOW

When pressed and held, the Status indicators display alarms that have been set during the current Test Period. This continues until **SHOW** is released at which time the current status is displayed. The HISTORY indicator is on to signify that an alarm has occurred during the current Test Period.

RESET

Resets the history store such that the historical and present status are the same. This can also be achieved by starting a new Test Period.

General Alarm Indicators

LOS	No data transitions at the input port.
PATTERN LOSS	The received data pattern is not in synchronization with the internally generated reference data.
ERRORS	A measured error has occurred. The indicator will remain lit for 100 ms.

PDH / DS_n Alarm Indicators

These are active when a PDH / DS_n signal is received

AIS	The All Ones AIS signal is detectable in the presence of a 1 in 10 ⁻³ error rate.
LOS	Frame alignment lost or out of alignment condition.
M/F LOSS	Multiframe alignment lost.
REMOTE ALARM	Remote alarm, x-bit or yellow alarm bit is set.
REMOTE M/F ALARM	Remote Multiframe Alarm bit is set.

SDH Alarm Indicators

These are active when an SDH signal is received.

FRAME LOSS	Loss Of Frame has been detected.
LOP	Loss of pointer has been detected.
MS-AIS	Multiplexer Section AIS has been detected.
AU-AIS	Path AIS has been detected.
CLOCK LOSS	The transmitter clock is not synchronized to the selected reference.
MS-RDI	Multiplexer Section RDI (FERF) has been detected.
HP-RDI	Path RDI (FERF) has been detected.
TU-AIS	TU Path AIS has been detected.
LP-RDI	TU Path RDI (FERF) has been detected.
POINTER ADJUST	A pointer change in the foreground signal has been detected.

SONET Alarm Indicators

These are active when an SONET signal is received.

FRAME LOSS	Loss Of Frame or Severely Errored Frame has been detected. Status message on bottom of display states which has occurred.
LOP	Loss of Pointer has been detected.
AIS-L	Line AIS has been detected.
AIS-P	STS Path AIS has been detected.
CLOCK LOSS	The transmitter clock is not synchronized to the selected reference.
RDI-L	Line Remote Defect Indication (RDI) has been detected.
RDI-P	STS Path RDI has been detected.
AIS-V	Virtual Tributary path AIS has been detected.
RDI-V	VT path RDI has been detected.
POINTER ADJUST	A pointer change in the foreground has been detected.

Index

A

AIS alarm indicator, 19

Alarm Indicator

 AIS, 19

 Errors, 19

 Frame loss, 19

 HP-RDI, 19

 LOF/OOF, 19, 20

 LP-RDI, 19

 M/Frame loss, 19

 MS-RDI, 19

 Pattern Loss, 19

 Pointer adjust, 19

 Remote alarm, 19

 Remote M/frame alarm, 19

 Signal Loss, 19

 TU-AIS, 19

 TU-LOP, 19

Alarm Indicators

 General, 19

 PDH / DS_n, 19

 SDH, 19

AU-AIS Alarm IndicatorAlarm Indicator

 AU-AIS, 19

Auto Setup key, 16

C

Changing settings on displays, 12

Changing settings with soft keys, 12

Clock Loss Alarm IndicatorAlarm Indicator

 Clock loss, 19

Cursor

 Introduction to, 12

 Moving, 12

D

Display on a monitor, 15

Displays

 Changing settings on, 12

DS_n Alarm Indicators, 19

E

Errors Alarm Indicator, 19

F

Folder

 Selecting, 11

Frame Loss Alarm Indicator, 19

G

Graph key, 8

Graphic displays as a selection aid, 14

H

History Keys, 18

HP-RDI Alarm Indicator, 19

I

Indicators

 Front Panel, 19

J

Jitter Alarm Indicators, 19

K

Keys

 Auto Setup, 16

 Graph, 8

 Local, 16

 Paper Feed, 16

 Print Now, 16

 Receive, 8

 Reset History, 18

 Results, 8

 Run / Stop, 16

 Show History, 18

 Transmit, 8

L

Local key, 16

LOF alarm indicator, 19, 20

Loss Of Pointer Alarm IndicatorAlarm Indicator

 AU-LOP, 19

LP-RDI Alarm Indicator, 19

M

M/Frame Loss Alarm Indicator, 19

Monitor, connecting, 15

MS-AIS Alarm IndicatorAlarm Indicator

 MS-AIS, 19

MS-RDI Alarm Indicator, 19

Multiple windows

 Moving between, 10

Multiple/single window selection, 9

O

OOF alarm Indicator, 19, 20

P

Paper Feed key, 16

Pattern Loss Alarm Indicator, 19

PDH / DS_n Alarms

 AIS, 19

 Frame Loss, 19

 M/Frame Loss, 19

 Remote Alarm, 19

 Remote M/Frame Alarm, 19

PDH Alarm Indicators, 19

Pictorial displays as a selection aid, 14

Pointer Adjust Indicator, 19

Pop-up menus

 As alternative to soft keys, 13

Print Now key, 16

R

Receive key, 8

Remote Alarm Indicator, 19

Remote M/Frame Alarm Indicator, 19

Reset History key, 18

Results key, 8

Run / Stop Key, 16

S

SDH Alarm Indicators, 19

SDH Alarms

 AU-AIS, 19

 Clock Loss, 19

 HP-RDI, 19

 Loss Of Pointer, 19

 LP-RDI, 19

 MS-AIS, 19

 MS-RDI, 19

 Pointer Adjust, 19

 TU-AIS, 19

SDH payload mapping with pictorial display, 14

Selectable display values, 12

Settings

 changing with soft keys, 12

Show History key, 18

Signal Loss Alarm Indicator, 19

Single/multiple window selection, 9

Soft key alternative, pop-up menu, 13

Index

Soft keys
 using, 12
Status Indicators, 18

T
The, 12
Transmit key, 8
TU-AIS Alarm Indicator, 19

Hewlett-Packard Sales and Service Offices

United States:

Hewlett-Packard Company
2101 Gaither Road
Rockville
MD 20850
(301) 258-2000

Hewlett-Packard Company
5201 Tollview Drive
Rolling Meadows
IL 60008
(708) 255-9800

Hewlett-Packard Company
1421 S. Manhattan Avenue
Fullerton
CA 92631
(714) 999-6700

Hewlett-Packard Company
2000 South Park Place
Atlanta
GA 30339
(404) 955-1500

Canada:

Hewlett-Packard Canada Ltd.
5150 Spectrum Way
Mississauga
Ontario
L4W 5G1
(416) 206-4725

Europe:

Hewlett-Packard
European Marketing Centre
PO Box 999
1180 AZ Amstelveen
The Netherlands

Japan:

Yokogawa-Hewlett-Packard Ltd.
Measurement Assistance Center
9-1, Takakura-Cho
Hachioji-Shi
Tokyo 192
Japan
(81) 426 48 0722

Latin America:

Hewlett-Packard
Latin America Region Headquarters
5200 Blue Lagoon Drive
9th Floor
Miami
Florida 33126
USA
(305) 267 4245/4220

Australia/New Zealand:

Hewlett-Packard Australia Ltd.
31-41 Joseph Street
Blackburn
Victoria 3130
Australia
Melbourne Caller 272 2555
(008) 13 1347

Far East:

Hewlett-Packard Pacific Ltd.
22-30/F Peregrine Tower
Lippo Centre
89 Queensway
Central
Hong Kong
(852) 848 7070

About This Edition

This is the 1st edition of the 37718-90002 manual. It documents the product as of September 1998. Edition dates are as follows:

1st Edition, Sept 1998

© Copyright Hewlett-Packard Ltd. 1998. All rights reserved. Reproduction, adaption, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

In This Book

This book demonstrates the basic operation of the instrument. It tells you how to select the displays that you want and how to use them to modify the instrument functions.

This guide also tells you about the front panel key functions, the indicators and the connectors.