

GPIB Command Syntax

for

E1966A 1xEV-DO Terminal Test Application Revision A.07
E1976A 1xEV-DO Rel 0 FTM Test Application Revision A.01
E6706A 1xEV-DO Lab Application Revision A.04
E6706T Special High Data Rate 1xEV-DO Lab Application T.01

Print Date: December 2006

1000-1931

www.agilent.com/find/E1966A
www.agilent.com/find/E1976A
www.agilent.com/find/E6706A
www.agilent.com/find/E6706T



NOTE: This guide is applicable to the E6706T, however there are a few exceptions which can be found in the Online User's Guide available at
<http://wireless.agilent.com/rfcomms/refdocs/1xevdo/default.php>

Notice

Information contained in this document is subject to change without notice.

All Rights Reserved. Reproduction, adaptation, or translation without prior written permission is prohibited, except as allowed under the copyright laws.

This material may be reproduced by or for the U.S. Government pursuant to the Copyright License under the clause at DFARS 52.227-7013 (APR 1988).

Agilent Technologies, Inc.
Learning Products Department
24001 E. Mission
Liberty Lake, WA 99019-9599
U.S.A.

Contents

Diagram Conventions	6
ABORt	9
AFGenerator	10
CALibration	11
CALCulate:SMONitor	12
CALL:APARameter	13
CALL:APPLication	14
CALL:AWGNoise	16
CALL:BAND	16
CALL:CCHannel	17
CALL:CCODE	17
CALL:CHANnel	17
CALL:CLPControl	18
CALL:CONNected	18
CALL:CONTrol	18
CALL:COUNt	19
CALL:COUNT:DTMonitor	23
CALL:CSTime	24
CALL:DATA	25
CALL:DCONNECTed	27
CALL:DORMant	27
CALL:FUNCTION:DATA	27
CALL:HANdoff	27
CALL:IDLE:DATA?	28
CALL:MACCHannel	28
CALL:MCCode	28
CALL:MS	29
CALL:OPERating:MODE	32
CALL:PARameter:SECTor	32
CALL:PLOGging	32
CALL:PNOFFset	33
CALL:POWER	33
CALL:PROTocol	33
CALL:RFGenerator	34
CALL:SCLose	34
CALL:SETup	34
CALL:SOPen?	35
CALL:STATus	36
CALL:TEST856	38
CALL:TOTal:POWer	39
CALL:TRIGger	39
CALL:WAVeform	39

Contents

DISPlay	40
FETCh:AFANalyzer	41
FETCh:CAPPower	43
FETCh:CPERror	43
FETCh:CFDTune	43
FETCh:CPOWER	44
FETCh:CTDPower	44
FETCh:CTXSpurious	44
FETCh:DAPower	45
FETCh:DOWQuality	45
FETCh:GAPPower	49
FETCh:SAUDio	50
FETCh:SMONitor	52
FETCh:TROPower	52
INITiate	53
READ	55
RFAnalyzer	57
RFGenerator:OUTPut	58
SETup:CONTinuous	59
SETup:AFANalyzer	59
SETup:CAPPower	61
SETup:CFDTune	62
SETup:CPERror	64
SETup:CPOWER	65
SETup:CTDPower	66
SETup:CTXSpurious	67
SETup:DAPower	68
SETup:DOWQuality	69
SETup:GAPPower	70
SETup:SAUDio	71
SETup:SMONitor	73
SETup:TROPower	75
STATus:OPERation	75
STATus:PRESet	76
STATus:QUEStionable	76
Status Byte Register	77
Standard Event Status Register	77
SYSTem:APPLication	78
SYSTem:AUDIO	79
SYSTem:BEEPer	79
SYSTem:COMMunicate	79
SYSTem:CONFigure	80

Contents

SYSTem:CORRection	80
SYSTem:CURRent:TA	80
SYSTem:DATE	81
SYSTem:ERRor?	81
SYSTem:FATal	81
SYSTem:INSTRument	81
SYSTem:MEASurement:RESet	81
SYSTem:PRESet	81
SYSTem:REGister	82
SYSTem:ROSCillator	82
SYSTem:SYNChronized	82
SYSTem:STATus	82
SYSTem:TIME	82
SYSTem:TZONe	83
SYSTem:UTC	83
IEEE 488.2 Common Commands	83

GPIB Syntax for E1966A, E1976A and E6706A/T

GPIB Syntax for E1966A, E1976A and E6706A/T

Diagram Conventions

Description




Diagram Description

Mnemonics are connected by lines. Each line can be followed in only one direction, as indicated by the arrow at the end of the line. Any combination of mnemonics that can be generated by starting at the root mnemonic and following the line in the direction of the arrow is syntactically correct.

GPIB Syntax for E1966A, E1976A and E6706A/T

The uppercase letters of a mnemonic represent the short form of the mnemonic, whereas the long form of a mnemonic is the short form followed by the lowercase letters. The test set accepts either the long form or the short form of the mnemonic. The mnemonics that are inside square brackets are optional. That is, a command operates the same whether or not the mnemonic in square brackets is used in the command.

The drawings show the proper use of spaces. Where spaces are required they are indicated by <sp>, otherwise no spaces are allowed between mnemonics.

Complex Command Description

Complex commands are valuable because they set the state of the parameter and a value for that parameter. For example, the command in the above figure that contains the mnemonic [:SAMPlitude] is a complex command because sets the state to ON as well as the amplitude. You can use parameters such as amplitude, frequency, gain, number, time, and value as a complex command. Refer to the specific command for the parameter that applies.

Data Type Description

num value	Integer, float or scientific values. For example, CALL:POWer -55.5 CALL:POWer -5.55E+001 CALL:CHANnel 525
string	Characters. The string will often need to be enclosed in single or double quotes, depending upon your programming environment. For example, CALL:UPLink:PRAChannel:ASUBchannels '111111111111' The string returned by the test set is enclosed by double quotes.
choice1 choice2 choice3	Specific character choices. For example, CALL:OPERating:MODE D2KTest SYSTem:COMMUnicate:GPIB:DEBug ON

Unit Type Description

Some commands have optional units of measurement. These are displayed in square brackets. If no units are specified in the command then the default unit in bold font is used. The test set accepts the specified unit either with or without a space inserted between the <num value> and the unit (for example, both 10S and 10 S are valid). The following table summarizes the units available.

Description	Optional Units	Example
-------------	----------------	---------

GPIB Syntax for E1966A, E1976A and E6706A/T

Amplitude (linear)	V MV	To set the spectrum monitor's timeout interval to 20 seconds, use any of the following formats: SETup:SMONitor:TIMEout:TIME 20 SETup:SMONitor:TIMEout:TIME 20S SETup:SMONitor:TIMEout:TIME 20 S
Power (logarithmic)	DBM DBW	
Level (relative)	DB	
Frequency	HZ KHZ MHZ GHZ	
Time	S MS US NS	
Percentage	PCT	

[:SElected] Mnemonic

The [:SElected] Mnemonic is an optional mnemonic that implies a current selection on the test set. Often there are other mnemonics that can be used in place of the [:SElected] mnemonic to configure a setting that is not the currently selected configuration on the test set. The mnemonics that can replace the [:SElected] mnemonic are listed in parentheses separated by vertical bars (|) in the description table title. An example of a command that contains the [:SElected] mnemonic is shown in the following table.


CALL[:CELL]:POWer:AMPLitude[:SElected]

CALL[:CELL]:POWer:AMPLitude:(CW|FDD)◀

Available mnemonics that can be used instead of the optional [:SElected] mnemonic.

Function	Sets/queries the desired cell power level. (See " Cell Power " information about desired versus current power levels.) The optional [:SElected] keyword in this command specifies whether the query applies to the current system type (see " CALL[:CELL]:POWer:AMPLitude? "). The settings for the CW operating mode are independent of operating modes.
Setting	Range: (This is the range of settings accepted, see " Cell Power Ranges " for the actual hardware range of the source) <ul style="list-style-type: none"> • FDD: -165 dBm/3.84MHz to +37 dBm/3.84MHz • CW: -177 dBm to +16 dBm

ABORT




Only applicable to the lab application or feature-licensed test application.

* Only applicable to the lab application.


GPIB Syntax for E1966A, E1976A and E6706A/T

AFGenerator



GPIB Syntax for E1966A, E1976A and E6706A/T

CALibration




GPIB Syntax for E1966A, E1976A and E6706A/T

CALCulate:SMONitor




CALL:APARameter




GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:APPLication



* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T




* Only applicable to the lab application and feature-licensed test application.


** Only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:AWGNoise




CALL:BAND




GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:CCHannel



CALL:CCODE




CALL:CHANnel




GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:CLPControl



CALL:CONNected




CALL:CONTrol




* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:COUNt




All of the commands shown in this diagram are only applicable to the lab application.




All of the commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T




All of the commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T



All of the commands shown in this diagram are only applicable to the lab application.


GPIB Syntax for E1966A, E1976A and E6706A/T



All of the commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:COUNt:DTMonitor



All commands shown in this diagram are only applicable to the lab application.


GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:CSTime




GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:DATA




All commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T




All commands shown in this diagram are only applicable to the lab application.

CALL:DCONNECTed




CALL:DORMant



* This command is only applicable to the lab application.

CALL:FUNCTION:DATA




* This command is only applicable to the lab application.

CALL:HANDoFF




GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:IDLE:DATA?




CALL:MACCHannel




* Only applicable to the lab application and feature-licensed test application.


CALL:MCCode



CALL:MS




GPIB Syntax for E1966A, E1976A and E6706A/T



* Only applicable to the lab application and feature-licensed test application.


GPIB Syntax for E1966A, E1976A and E6706A/T




* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:OPERating:MODE



CALL:PARameter:SECTor




CALL:PLOGging




All commands shown in this diagram are only applicable to the lab application.


CALL:PNOFFset



CALL:POWer




CALL:PROTocol




* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:RFGenerator



CALL:SCLose



CALL:SETup



GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:SOPen?

CALL → :SOPen →? (returns 1|0) →

↓ [:STATe]


GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:STATUs



* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T



* Only applicable to the lab application and feature-licensed test application.


GPIB Syntax for E1966A, E1976A and E6706A/T

CALL:TEST856




GPIB Syntax for E1966A, E1976A and E6706A/T


CALL:TOTal:POWer



CALL:TRIGger




CALL:WAVeform




GPIB Syntax for E1966A, E1976A and E6706A/T

DISPlay




GPIB Syntax for E1966A, E1976A and E6706A/T

FETCh:AFANalyzer




GPIB Syntax for E1966A, E1976A and E6706A/T




GPIB Syntax for E1966A, E1976A and E6706A/T


FETCh:CAPPower



FETCh:CPERror




FETCh:CFDTune




All commands shown in this diagram are only applicable to the lab application or feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T


FETCh:CPower



FETCh:CTDPower




FETCh:CTXSpurious




GPIB Syntax for E1966A, E1976A and E6706A/T

FETCh:DAPower




FETCh:DOWQuality




* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T




* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T



** Only applicable to the lab application and feature-licensed test application.*


GPIB Syntax for E1966A, E1976A and E6706A/T



* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T



FETCh:GAPPower




All commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A and E6706A/T

FETCh:SAUDio




GPIB Syntax for E1966A, E1976A and E6706A/T




GPIB Syntax for E1966A, E1976A and E6706A/T

FETCh:SMONitor




FETCh:TROPower



GPIB Syntax for E1966A, E1976A and E6706A/T


INITiate



Only applicable to the lab application or feature-licensed test application.

* Only applicable to the lab application.


GPIB Syntax for E1966A, E1976A and E6706A/T



Only applicable to the lab application or feature-licensed test application.


* Only applicable to the lab application.

READ




* Only applicable to the lab application or feature-licensed test application.

GPIB Syntax for E1966A, E1976A and E6706A/T



* Only applicable to the lab application.


RFANalyzer




GPIB Syntax for E1966A, E1976A and E6706A/T

RFGenerator:OUTPut



RFGenerator →:OUTPut → [:DESTination] → <sp>[IO|OUT] → ? (returns IO|OUT) →




SETup:CONTinuous



SETup:AFANalyzer




GPIB Syntax for E1966A, E1976A, and E6706A/T




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CAPPower




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CFDTune



All commands shown in this diagram are only applicable to the lab application or feature-licensed test application.


GPIB Syntax for E1966A, E1976A, and E6706A/T



All commands shown in this diagram are only applicable to the lab application or feature-licensed test application.



GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CPERror




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CPOWer




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CTDPower




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:CTXSpurious




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:DAPower




SETup:DOWQuality



* Only applicable to the lab application and feature-licensed test application.

GPIB Syntax for E1966A, E1976A, and E6706A/T



SETup:GAPPower




All commands shown in this diagram are only applicable to the lab application.

GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:SAUDio




GPIB Syntax for E1966A, E1976A, and E6706A/T




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETup:SMONitor




GPIB Syntax for E1966A, E1976A, and E6706A/T




GPIB Syntax for E1966A, E1976A, and E6706A/T

SETUp:TROPower



STATUs:OPERation




GPIB Syntax for E1966A, E1976A, and E6706A/T

STATus:PRESet

STATUS → :PRESet →

STATus:QUEStionable



GPIB Syntax for E1966A, E1976A, and E6706A/T

Status Byte Register

*STB?

*STB? _____ →

Standard Event Status Register

*ESR?

*ESR? _____ → Reads and clears the Std Event Status Register. _____ →

*ESE?


*ESE? _____ → Reads the Std Event Status Register
Enable Register _____ →

*ESE

*ESE _____ → Writes to the Std Event Status Register
Enable Register _____ →



GPIB Syntax for E1966A, E1976A, and E6706A/T

SYSTem:APPLication




GPIB Syntax for E1966A, E1976A, and E6706A/T


SYSTem:AUDio



SYSTem:BEEPer



SYSTem:COMMunicate




* Only applicable to lab application.

GPIB Syntax for E1966A, E1976A, and E6706A/T


SYSTem:CONFigure

SYSTem → :CONFigure → :INformation → :HARDware → :VERBOSE? →

SYSTem:CORRection




SYSTem:CURRent:TA



GPIB Syntax for E1966A, E1976A, and E6706A/T


SYSTem:DATE




SYSTem:ERRor?

SYSTem---> :ERRor? ---> (returns num value, string) --->

SYSTem:FATal




SYSTem:INSTRument



SYSTem:MEASurement:RESET


SYSTem---> :MEASurement---> :RESET --->

SYSTem:PRESet




GPIB Syntax for E1966A, E1976A, and E6706A/T


SYSTem:REGister




SYSTem:ROSCillator




SYSTem:SYNChronized




SYSTem:STATus




SYSTem:TIME



SYSTem:TZONE



SYSTem:UTC



IEEE 488.2 Common Commands

Description

***CLS** The *CLS, clear status command, is defined in “IEEE Std 488.2-1992”, 10.3. This command will also clear and close the error message screen on the test set’s display.

***ESE** The *ESE, standard event status enable command, is defined in “IEEE Std 488.2-1992”, 10.10.

***ESE?** The *ESE?, standard event status enable query, is defined in “IEEE Std 488.2-1992”, 10.11.

***ESR?** The *ESR?, standard event status register query, is defined in “IEEE Std 488.2-1992”, 10.12.

***IDN?** The *IDN?, identification query, is defined in “IEEE Std 488.2-1992”, 10.14.*IDN? is used to retrieve information about the test set in ASCII format.

*IDN?, returns ASCII codes 32 through 126 excluding comma and semicolon in four comma separated fields. Field 1 returns the manufacturer, field 2 returns the instrument model number, field 3 returns the serial number, field 4 returns 0.

***OPC** The *OPC, operation complete command, is defined in “IEEE 488.2-1992”, 10.18. *OPC causes the test set to continuously sense the No Operation Pending flag. When the No Operation Pending flag becomes TRUE, the OPC event bit in the standard event status register (ESR) is set to indicate that the state of all pending operations is completed. The *OPC common command is not recommended for use as an overlapped command.

***OPC?** The *OPC?, operation complete query, is defined in “IEEE Std 488.2-1992”, 10.19. The *OPC? query allows synchronization between the controller and the test set using either the message available (MAV) bit in the status byte, or a read of the output OPC?. The *OPC? query does not effect the OPC event bit in the Standard Event Status Register (ESR). The *OPC? common command is not recommended for use as an overlapped command.

GPIB Syntax for E1966A, E1976A, and E6706A/T

***OPT?** The *OPT?, option identification query, is defined in “IEEE Std 488.2-1992”, 10.20. Each option will have a unique name, that name will be retuned with the query.

***RST** The *RST, full preset command, is defined in “IEEE Std 488.2-1992”, 10.32. *RST is the recommended command when performing a full preset on the test set. A *RST restores the majority of settings to their default values.

- *RST sets trigger arm to single
- PRESet2 sets trigger arm to continuous

***SRE** The *SRE, service request enable command, is defined in “IEEE Std 488.2-1992”, 10.34. The parameter range for this command is 0 through 255.

***SRE?** The *SRE?, service request enable query, is defined in “IEEE Std 488.2-1992”, 10.35. Values returned by this query range from 0 through 255.

***STB?** The *STB?, read status byte query, is defined in “IEEE Std 488.2-1992”, 10.36. Values returned by this query range from 0 through 255.

***WAI** The *WAI, wait-to-continue command, is defined in “IEEE Std 488.2-1992”, 10.39. The *WAI command prevents the test set from executing any further commands or queries until all pending operation flags are false. The *WAI common command is not recommended for use as an overlapped command.

Index

To find a syntax equivalent for a field on the Test Set's display.	B	audio analyzer, 59 Default Gateway, 79 DELETE hardkey, 82 Detector Type, 71 Peak (audio analyzer), 60 RMS (audio analyzer), 60 Device Settling Time, 72 Device to Ping, 25 Digital Average Power, 45 Display Brightness, 40 Display Mode, 40 Distortion audio, 41 Swept Audio, 50 DRC Channel Gain, 29 DRC Value Fixed Mode Attribute, 14 DSC Channel Gain, 29 DSC Length, 29 DUT IP Address, 29
1. Find the field name on the Test Set's display.	C	Cal. Burst Mod Offset 1, 11 Cal. first IQ Modulator, 11 Cal. second IQ Modulator, 11 Calibrate Channel Power, 11 Calibrate Digital Avg Pwr, 11 Call Drop Timer, 18 Call Limit Mode, 18 Carrier Feedthrough, 45 CDMA System Time Information, 37 Cell Band, 16 Cell Band, Handoff, 34 Cell Channel, 17 Cell Power, 33, 36 Cell Power State, 36 Channel, 17 Channel Power, 44 Channel, Handoff, 34 Close Session, 34 Code Domain Power, 46 Code Domain Power + Noise, 48 Color Code, 17 Continuous, 59 Control Channel Data Rate, 17 Corrupted Bursts, 19, 23 Country Code, 28 Coupling, 10 Current Physical Layer Subtype, 37 Current System Type, 36 CW Operating Mode, 32
2. Look up the name in the alphabetical listing.	D	Data Connection State, 27 Data Connection State Change Detector, 27 Data Connection State Change Detector Timeout, 27 Data Connection Status, 36 Data Offset 153k6, 29 Data Offset 19k2, 29 Data Offset 38k4, 29 Data Offset 76k8, 29 Data Offset 9k6, 29 Data Offset Nom, 29 Data Throughout Monitor, 23 Date (yyyy.mm.dd), 81 Decode Errors, 19, 23 De-Emphasis State
3. Turn to the page indicated.	E	Eb/Nt, 37 End Data Connection, 27 Enhanced Access Rate, 14 Enhanced Test Application Protocol, 14 EVM, 45 Execute Handoff, 27 Expandor Reference Level audio analyzer, 60 Expected CW Power, 57 Expected Peak Voltage, 71 Expected Power DIGITAL856, 57 Expected Reverse Data Channel Info Packet Size, 36 T2P Transition, 37 Transmission Mode, 36 TxT2P Post-Transition, 37 TxT2P Pre-Transition, 37 External Trigger Type, 39 ExtRef, 82
Numerics	F	Filter Type, 71 100 Hz BW BPF (audio analyzer), 60 300 Hz to 15 kHz (audio analyzer), 60 50 Hz to 15 kHz (audio analyzer), 60 C-Message (audio analyzer), 60 None (audio analyzer), 60 FM Demodulation Setup Bandpass Filter State, 79
-0.885 MHz Offset, 44 0.885 MHz Offset, 44 -1.98 MHz Offset, 44 1.98 MHz Offset, 44 100 Hz BW BPF Center Frequency audio analyzer, 60		
A		
Abort Measurement, 9 Access Probe Power, 43 Ack Channel Gain, 29 ACK R-Data After, 28 Active Cell Operating Mode, 32 Alternate Ping Address, 25 Amplitude, 10 Application Configuration Expected Enhanced Access Rate, 36 Application Selection, 78 Application Setup, 78 Application Switch, 78 Application, Revision, License, 78 AT Direct Packets, 14 AT Max Power, 29 Audio Analyzer Setup SINAD/Distortion Fundamental Frequency, 60 Audio Frequency, 41 Audio Generator, 10 Audio Generator Coupling, 71 Audio Generator Level, 72 Audio Level, 42 Audio Out Port, 79 Auxiliary Pilot Channel Gain, 29 Auxiliary Pilot Channel Min Payload, 29 AWGN Power, 16, 36 AWGN Power State, 36		

Index

Deemphasis State, 79	Measurement Timeout	Ping Count, 25
Expander State, 79	Access Probe Power, 61	Ping Timeout, 25
Force Dormant, 27	audio analyzer, 60	Ping Timeout, 25
Frequency, 10	Channel Power, 65, 66	PN Offset, 33
Frequency (MHz)	Digital Average Power, 68, 70	power control
amplitude offset, 80	Graphical Access Probe Power,	reverse link, 18
Frequency Band, 16	70	reverse link step size, 18
Frequency Error, 45	Swept Audio, 72	Power Parameters, T2P
FTAP Rate, 14	TX Spurious Emissions, 67	Transition, 30
F-Traffic Config, 14	Message Log, 81	Power Parameters, Termination
F-Traffic Format, 14	Missing Bursts, 19, 23	Target, 30
FULL (preset) key, 76	Mobile Country Code, 28	Power Parameters, TxT2P
G	Multi-Measurement Count	Post-Transition, 30
gotolink SEL, 6	audio analyzer, 59	Power Parameters, TxT2P
GPIB Address, 79	Channel Power, 65, 66	Pre-Transition, 30
H	Digital Average Power, 68	Preamble Length, 13
Handoff, 27	Swept Audio, 71	Preferred Control Channel Cycle,
Handoff Cell Band, 34	TX Spurious Emissions, 67	17
Handoff Channel, 34	N	Preferred Control Channel Cycle
Hardware ID (Decimal), 29	Number	Mode, 18
Hardware ID (Hex), 29	amplitude offset, 80	PRESET key, 76
Hardware ID Type (Hex), 29	Number of Points, 71	Probe Initial Adjust, 13
H-ARQ Modulation, 28	O	Probe Num Step, 13
H-ARQ/L-ARQ Channel Level, 28	Offset (dB)	Probe Power Step, 13
I	amplitude offset, 80	Probe Sequence Max, 13
Idle State, 28	Open Loop Adjust, 13	Protocol Logging, 32
Initiate Measurements, 54	Operating Mode, 32	Protocol Rev, 33
Instrument Information	P	Pulse, 10
Test Application, 80	Packet Error Count, 43	Pwr Ctrl Size, 18
IntRef, 82	Packet Error Rate Confidence	R
L	Level, 64	RACHs, 19, 23
LAN IP Address, 79	Packet Error Rate Confidence	Rate 1M8 Supported Control, 18
Last Calibration, 11	Pass/Fail, 43	Rev Power Ctrl, 57
Limited TAP, GPIB Command, 14	Packet Error Rate Integrity, 43	Read Measurement, 56
M	Packet Error Rate Maximum	Receiver Power, 57
MAC Index, 37	Packet Count, 64	Receiver Power Control, 57
Magnitude Error, 45	Packet Error Rate Measurement	Register reacall hardkey, 82
Maskable Message Display State,	Results, 43	Release A Access Channel MAC
40, 79	Packet Error Rate Requirement,	Subtype, 33
Max Forward Packet Duration, 14	64	Release A Physical Layer
Max Frames Allowed for	Packet Loss, 25	Subtype, 33
Assignment, 19, 23	Packets Received, 25	Rev, License, 78
MCC, 28	Packets Tested, 43	reverse power control, 18
Meas Frequency, 57	Packets Transmitted, 25	RF Gen Freq Ctrl, 18
Measurement Frequency, 57	Pages, 19, 23	RF Generator Frequency, 34
Measurement Frequency Control,	P-ARQ Channel Level, 28	RF IN/OUT Amplitude Offset
57	Phase Error, 45	State, 80
MEASUREMENT RESET key, 81	Pilot Drop, 29	RF IN/OUT Amptd Offset, 80
Measurement Speed	Ping, 25	RF IN/OUT Amptd Offset Setup,
Channel Power, 66	Ping Count, 25	80
	Ping Setup	RF Output Port, 58
	Alternate Ping Address, 25	Rho, 45
	Device to Ping, 25	Round Trip (ms) min/avg/max, 25
		RPC Channel Level, 28
		RRI Gain Parameters, 29
		RTAP Rate, 14

Index

- Rvs Power Ctrl, 18
- S**
- SAVE hardkey, 82
 - Sector ID, 32
 - Session Application Type, 14
 - Session Open State, 35
 - Session Seed, 29
 - Short Packets Enabled Threshold, 14
 - SINAD, 42
 - Swept Audio, 50
 - SINAD/Distortion Fundamental Frequency
 - audio analyzer, 60
 - SINAD/Distortion State, 72
 - audio analyzer, 60
 - Single, 59
 - Slots to Measure, 69
 - Start Data Connection, 27
 - Start Frequency, 71
 - Start Ping, 25
 - step size
 - reverse link power control, 18
 - Stop Frequency, 71
 - Stop Ping, 25
 - Subnet Mask, 32, 79
 - Summary Results
 - Packet Loss, 25
 - Packets Received, 25
 - Packets Transmitted, 25
 - Round Trip (ms) min/avg/max, 25
 - Swept Audio, 50
- T**
- Test Application (instrument information), 80
 - Test Application Protocol, 14
 - Test Mode Forward Traffic Rate, 38
 - Test mode MAC Index, 38
 - Test Signal, 39
 - Thermal Power Null Adjust, 81
 - Time (hh:mm), 82
 - Time Error, 45
 - Time Zone (hh:mm), 83
 - Total RF Power, 37, 39
 - Total RF Power State, 37
 - Trigger, 39
 - Trigger Arm, 59
 - Access Probe Power, 61
 - audio analyzer, 59
 - Channel Power, 65, 66
 - Digital Average Power, 68, 70
 - Graphical Access Probe Power, 70