


3746 Nways Multiprotocol Controller  
Models 900 and 950



# Network Node Processor Installation and Maintenance (based on 7585 or 3172)





3746 Nways Multiprotocol Controller  
Models 900 and 950



# Network Node Processor Installation and Maintenance (based on 7585 or 3172)

**Note!**

Before using this information and the product it supports, be sure to read the general information under "Notices" on page xi.

**Fourth Edition (December 1997)**

The information contained in this manual is subject to change from time to time. Any such changes will be reported in subsequent revisions.

Order publications through your IBM representative or the IBM branch office serving your locality. Publications are not stocked at the address given below.

A form for readers' comments appears at the back of this publication. If the form has been removed, address your comments to:

IBM France  
Centre d'Etudes et Recherches  
Service 0798 - BP 79  
06610 La Gaude  
France

- FAX: 33 4 93 24 77 97
- E-mail: FRIBMQF5 at IBMMAIL
- IBM Internal Use: LGERCF at LGEPROFS
- Internet: rcf\_lagaude@vnet.ibm.com

When you send information to IBM, you grant IBM a non-exclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

© **Copyright International Business Machines Corporation 1996, 1997. All rights reserved.**

Note to U.S. Government Users — Documentation related to restricted rights — Use, duplication or disclosure is subject to restrictions set forth in GSA ADP Schedule Contract with IBM Corp.

---

# Contents

<b>Figures</b> . . . . .	vii
<b>Notices</b> . . . . .	xi
European Union (EU) Statement . . . . .	xi
Electronic Emission Notices . . . . .	xi
Trademarks and Service Marks . . . . .	xiii
<b>Product Safety Information</b> . . . . .	xv
General Safety . . . . .	xv
Safety Notices . . . . .	xv
Safety Notices for United Kingdom . . . . .	xv
Service Inspection Procedures . . . . .	xv
<b>About This Book</b> . . . . .	xvii
Who Should Use This Book . . . . .	xvii
How to Use This Book . . . . .	xvii
How This Book is Organized . . . . .	xvii
Where to Find More Information . . . . .	xviii
World Wide Web . . . . .	xviii
Online Documentation from CD-ROM . . . . .	xviii
Service Personnel Definitions . . . . .	xviii
<b>Summary of Changes</b> . . . . .	xix
<b>Chapter 1. Installing and Setting Up Your Network Node Processor</b> . . . .	1-1
Network Node Processor Overview . . . . .	1-2
Preparing Your Installation . . . . .	1-3
Installing Your Network Node Processor (7585) . . . . .	1-4
Installing the 7585 Network Node Processor - A . . . . .	1-6
Installing the 7585 System Unit (NNP-A) . . . . .	1-7
Connecting the 7585 (NNP-A) . . . . .	1-8
Installing the 7585 Network Node Processor - B . . . . .	1-9
Installing the 7585 System Unit (NNP-B) . . . . .	1-10
Installing a Second ac Outlet Distribution Box . . . . .	1-11
Connecting the 7585 Network Node Processor - B . . . . .	1-13
Installing Your Network Node Processor (3172) . . . . .	1-14
Installing the 3172 Network Node Processor - A . . . . .	1-16
Installing the 3172 System Unit (NNP-A) . . . . .	1-16
Connecting the 3172 (NNP-A) . . . . .	1-18
Installing the 3172 Network Node Processor - B . . . . .	1-19
Installing the 3172 System Unit (NNP-B) . . . . .	1-20
Installing a Second ac Outlet Distribution Box . . . . .	1-21
Connecting the 3172 Network Node Processor - B . . . . .	1-23
Installing the Code on the Network Node Processor . . . . .	1-24
Complete Your Installation . . . . .	1-28
<b>Chapter 2. Managing the Network Node Processor and the Control Point</b> . . . .	2-1
General Information . . . . .	2-2
Accessing the Network Node Processor Functions . . . . .	2-3
Installing or Removing a Network Node Processor . . . . .	2-4

Upgrading the LIC on a Network Node Processor (LIC on CD-ROM)	2-5
Restoring the LIC on a Network Node Processor (LIC on CD-ROM)	2-6
Changing the Active LIC (LIC on CD-ROM)	2-7
Modifying IP Parameters	2-8
Managing the Control Point and the NNP	2-9
Importing a Configuration	2-10
Exporting a Configuration	2-11
Accessing a Network Node Processor	2-13
Accessing IP Commands from the MOSS-E	2-15
Changing or Restoring LIC on a Network Node Processor (LIC on OD)	2-16
<b>Chapter 3. Network Node Processor Problem Determination</b>	<b>3-1</b>
MAP: Entry Point for Problem Isolation	3-1
MAP: Problem Isolation on Network Node Processor Based on 3172	3-6
MAP: Problem Determination on Network Node Processor Based on 7585	3-15
How to Install a Display and Keyboard on your Network Node Processor	3-18
<b>Chapter 4. Network Node Processor Based on 3172</b>	<b>4-1</b>
FRU Exchange on Network Node Processor Based on 3172	4-1
Adapter Card Exchange Procedure on NNP Based on 3172	4-4
Removing Adapter	4-4
Installing Adapter	4-6
Procedure After LAN Adapter Exchange on NNP Based on 3172	4-9
Procedure after Hard Disk Drive Exchange on NNP Based on 3172	4-11
Procedure after Processor Card exchange on NNP Based on 3172	4-14
Procedure after SCSI Card Exchange on NNP Based on 3172	4-17
Procedure after System Board or Battery Exchange on NNP Based on 3172	4-19
Procedure after Other FRUs Exchange on NNP Based on 3172	4-21
<b>Chapter 5. Network Node Processor Based on 7585</b>	<b>5-1</b>
MAP: 7585 Network Node Processor Troubleshooting	5-2
BEEP CODE INDEX	5-21
Display	5-23
Keyboard	5-24
Printer	5-24
Power-Supply Voltage Check (7585)	5-25
Power Voltage Setting	5-25
Undetermined Problems	5-26
Before Replacing a System Board	5-26
Devices List	5-27
RAM Memory Modules (SIMMs/DIMMs)	5-28
Memory Test	5-29
How to Run the 7585 Network Node Processor Diagnostics	5-32
FRU Exchange on Network Node Processor Based on 7585	5-34
Procedure After Board or Battery Exchange on NNP Based on 7585	5-36
Procedure After LAN Adapter Exchange on NNP Based on 7585	5-38
Procedure After Hard Disk Drive Exchange on NNP Based on 7585	5-43
Procedure After Other FRU Exchange on NNP Based on 7585	5-46
CE Leaving Procedure	5-47
<b>Appendix A. Parameter Worksheet</b>	<b>A-1</b>
Definition of Service LAN IP Addresses	A-1

<b>Appendix B. Controller Expansion Component Locations</b> . . . . .	B-1
<b>Appendix C. Network Node Processor Aids</b> . . . . .	C-1
Network Node Processor Based on 7585-P02 . . . . .	C-1
How to check the Device Configuration (7585-P02) . . . . .	C-1
Nways Switch Administration Station Configuration Reference Based on 7585-P02 . . . . .	C-1
How to Set the Cache Size Value . . . . .	C-13
How to check the SCSI Device Configuration (7585-P02) . . . . .	C-14
Devices List for the Network Node Processor (3172) . . . . .	C-16
Additional Information . . . . .	C-18
Devices List for the Network Node Processor (3172) . . . . .	C-21
SCSI Device Configuration . . . . .	C-21
Network Node Processor Hardware Configuration Reference (3172) . . . . .	C-22
<b>Appendix D. Network Node Processor External Cable References</b> . . . . .	D-1
Network Node Processor Cables for the 3746-900 . . . . .	D-1
Service Processor and Network Node Processor Cables for the 3746-950 . . . . .	D-2
Cable from the Network Node Processor Processor to the 8228 . . . . .	D-3
Interchange Circuit for Standard LAN Cable . . . . .	D-3
<b>Appendix E. Bibliography</b> . . . . .	E-1
Customer Documentation for the 3746 Model 950 . . . . .	E-1
Service Documentation for the IBM 3746 Model 950 . . . . .	E-3
Customer Documentation for the 3745 (Models 210, 310, 410, 610, 21A, 31A, 41A, and 61A), and 3746 (Model 900) . . . . .	E-5
Additional Customer Documentation for the 3745 Models 130, 150, 160, 170, and 17A . . . . .	E-9
Service Documentation for the IBM 3745 (Models 210, 21A, 310, 31A, 410, 41A, 610, and 61A) and 3746 (Model 900) . . . . .	E-10
Additional Service Documentation for the IBM 3745 Models 130, 150, 160, 170, and 17A . . . . .	E-14
<b>Glossary</b> . . . . .	X-1
<b>Index</b> . . . . .	X-7





---

## Figures

1-1.	Network Node Processor Environment	1-2
1-2.	Installing Label on the Front Side of the Network Node Processor (7585)	1-5
1-3.	Installing the NNP-A Brackets	1-6
1-4.	Installing the Captive Nuts for the 7585	1-6
1-5.	Installing the 7585 NNP-A Unit in the Controller Expansion (Front Side)	1-7
1-6.	Connecting the 7585 NNP-A	1-8
1-7.	Installing the NNP-B Brackets	1-9
1-8.	Installing the Captive Nuts for the 7585	1-9
1-9.	Installing the 7585 NNP-B Unit in the Controller Expansion (Front Side)	1-10
1-10.	Locating the Captive Nuts	1-11
1-11.	Installing the Captive Nuts	1-11
1-12.	Installing the Second ac Outlet Distribution Box	1-12
1-13.	Power Cord Installation	1-12
1-14.	Power Distribution	1-12
1-15.	Connecting the NNP-B (7585)	1-13
1-16.	Installing Label on the Front Side of the Network Node Processor (3172)	1-15
1-17.	Installing Label on the Rear Side of the Network Node Processor (3172)	1-15
1-18.	Installing the Network Node Processor Brackets (NNP Type 3172)	1-16
1-19.	Installing the 3172 NNP-A Unit in the Controller Expansion (Rear Side)	1-17
1-20.	Connecting the NNP-A	1-18
1-21.	Installing the NNP-B Brackets	1-19
1-22.	Installing the 3172 NNP-B Unit in the Controller Expansion (Rear Side)	1-20
1-23.	Locating the Captive Nuts	1-21
1-24.	Installing the Captive Nuts	1-21
1-25.	Installing the Captive Nuts	1-22
1-26.	Power Cord Installation	1-22
1-27.	Power Distribution	1-22
1-28.	Connecting the NNP-B	1-23
1-29.	3746-9x0 Menu	1-24
1-30.	Network Node Processor Menu	1-24
1-31.	NNP-A LIC Management Menu	1-25
1-32.	Network Node Processor IP Parameters Menu	1-25
1-33.	NNP-B LIC Management Menu	1-26
1-34.	Network Node Processor IP Parameters Menu	1-26
1-35.	Service Processor Front View (Type 7585)	1-27
1-36.	Service Processor Front View (Type 7585)	1-27
1-37.	NNP-A Licensed Internal Code Management	1-27
1-38.	Network Node Processor LIC Management Menu	1-28
1-39.	NNP-A Licensed Internal Code Management Information Message	1-28
2-1.	One 3745 and a 3746-900 APPN	2-2
2-2.	One 3746-950	2-2
2-3.	Network Node Processor Status	2-2
2-4.	3746-9x0 Maintenance Functions	2-3

2-5.	Network Node Processor Management Functions	2-3
2-6.	NNP-A Licensed Internal Code Management	2-4
2-7.	Installing or Removing a NNP-A	2-4
2-8.	SP Change Management Menu	2-5
2-9.	Service Processor Menu	2-5
2-10.	SP Change Management Menu	2-6
2-11.	Service Processor Menu	2-6
2-12.	SP Change Management Menu	2-7
2-13.	Service Processor Menu	2-7
2-14.	NNP Licensed Internal Code Management	2-8
2-15.	Modifying IP Parameters	2-8
2-16.	IP Parameters	2-8
2-17.	Manage Control Point on NNPs	2-9
2-18.	Managing the Control Point and NNPs	2-9
2-19.	CCM	2-10
2-20.	Importing a Configuration	2-10
2-21.	CCM	2-11
2-22.	Selecting a Configuration	2-11
2-23.	Exporting a Configuration	2-12
2-24.	Accessing a NNP	2-13
2-25.	Connecting to a NNP	2-13
2-26.	NNP Functions	2-14
2-27.	Terminating a Session	2-14
2-28.	Accessing IP Commands	2-15
2-29.	Telnet Access	2-15
2-30.	NNP Licensed Internal Code Management	2-16
2-31.	Changing or Restoring LIC on NNP.	2-16
3-1.	LAN attached to the Service Processor	3-6
3-2.	Network Node Processor Panel Based on 3172	3-7
3-3.	LAN attached to the Service Processor	3-15
3-4.	How to Connect the Display and the Keyboard on Network Node Processor	3-18
4-1.	IBM Controller Rack Locations	4-1
4-2.	Network Node Processor Cables	4-2
5-1.	Keyboard Connector Voltages	5-24
5-2.	Power Supply Connector Voltages	5-25
B-1.	Controller Expansion Inventory Chart (Front View).	B-2
B-2.	Controller Expansion Inventory Chart (Rear View).	B-3
B-3.	Installing Captive Nuts and Brackets for the Display, Drawer, SP and NNP Type 7585	B-4
B-4.	Installing Captive Nuts and Brackets for the Display, Drawer, SP and NNP Type 3172	B-5
B-5.	Installing Captive Nuts for LCBs	B-6
B-6.	Installing Captive Nuts for 8229s	B-7
B-7.	Installing Captive Nuts and Brackets for MAE	B-8
B-8.	Installing Brackets (PN 58G5752) for Processor Type 7585	B-9
B-9.	Installing Brackets for Processor Type 3172	B-10
B-10.	Units Installation in the Controller Expansion (SP Type 7585)	B-11
B-11.	Units Installation in the Controller Expansion (SP Type 7585 + MAE)	B-11
B-12.	Units Installation in the Controller Expansion (SP Type 3172)	B-12
B-13.	Units Installation in the Controller Expansion (SP Type 9585)	B-12
B-14.	Units Installation in the Controller Expansion (SP Type 9577)	B-13
B-15.	Connecting the Units to the ac Outlet Distribution Box.	B-13
C-1.	Network Node Processor Keyboard and Display Cables Installation	C-18

C-2.	Network Node Processor Keyboard and Display Cables Removal	C-20
D-1.	Network Node Processor Cables for 3746-900	D-1
D-2.	Service Processor and Network Node Processor Cables for 3746-950	D-2
D-3.	LAN Cable	D-3
D-4.	Adapter Cable (PN 60G1066)	D-4



---

## Notices

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM product, program, or service is not intended to state or imply that only IBM's product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any of IBM's intellectual property rights may be used instead of the IBM product, program, or service. Evaluation and verification of operation in conjunction with other products, except those expressly designated by IBM, is the user's responsibility.

IBM may have patents or pending patent applications covering subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to the IBM Director of Licensing, IBM Corporation, 500 Columbus Avenue, Thornwood, New York 10594, U.S.A.

---

## European Union (EU) Statement

This product is in conformity with the protection requirements of EU Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM can not accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

---

## Electronic Emission Notices

### Federal Communications Commission (FCC) Statement

**Note:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### Industry Canada Compliance Statement

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

**Avis de conformité aux normes d'Industrie Canada**

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

**Japanese Voluntary Control Council For Interference (VCCI) Statement**

This equipment is in the 1st Class category (information equipment to be used in commercial and/or industrial areas) and conforms to the standards set by the Voluntary Control Council for Interference by Information Technology Equipment aimed at preventing radio interference in commercial and industrial areas.

Consequently, when used in a residential area or in an adjacent area thereto, radio interference may be caused to radios and TV receivers, and so on.

Read the instructions for correct handling.

**Korean Communications Statement**

Please note that this device has been approved for business purpose with regard to electromagnetic interference. If you find this is not suitable for your use, you may exchange it for a non-business one.

**New Zealand Radiocommunications (Radio) Regulations**

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

---

## Trademarks and Service Marks

The following terms, denoted by an asterisk (\*), used in this publication, are trademarks or service marks of IBM Corporation in the United States or other countries:

ESCON  
IBM  
NetView

PS/2  
RETAIN  
VTAM

XGA

The following terms, denoted by a double asterisk (\*\*), used in this publication, are trademarks of other companies:

SX (Intel Corporation)





---

# Product Safety Information

---

## General Safety

This product meets IBM safety standards.

---

## Safety Notices

For *Safety Notices* refer to *IBM 3745 Communication Controller All Models*, *IBM 3746 Expansion Unit Model 900*, *IBM 3746 Nways Multinetwork Controller Model 950*, *Safety Information*, GA33-0400.

## Safety Notices for United Kingdom

1. The IBM 3746 Expansion Unit Model 900 and IBM 3746 Nways Multiprotocol Controller Model 950 are manufactured according to the International Safety Standard EN 60950 and as such are approved in the UK under the General Approval Number NS/G/1234/J/100003 for indirect connection to the public telecommunication network.
2. The network adapter interfaces housed within the IBM 3746 Expansion Unit Model 900 and IBM 3746 Nways Multiprotocol Controller Model 950 are approved separately, each one having its own independent approval number. These interface adapters, supplied by IBM, do not use or contain excessive voltages. An excessive voltage is one that exceeds 42.4 V peak ac or 60 V dc. They interface with the IBM 3746 Expansion Unit Model 900 and IBM 3746 Nways Multiprotocol Controller Model 950 using Safety Extra Low Voltages (SELV) only. In order to maintain the separate (independent) approval of the IBM adapters, it is essential that other optional cards, not supplied by IBM, do not use mains voltages or any other excessive voltages. Seek advice from a competent engineer before installing other adapters not supplied by IBM.

---

## Service Inspection Procedures

The Service Inspection Procedures help service personnel check whether the 3745/3746 conforms to IBM safety criteria. They have to be used each time the 3745/3746 safety is suspected. The *Service Inspection Procedures* section is located at the beginning of the:

- *3745 Communication Controller Models 210 to 61A Maintenance Information Procedures*, SY33-2054
- *3745 Communication Controller Models 130 to 17A Maintenance Information Procedures*, SY33-2070
- *3746-950 Service Guide*, SY33-2108
- *3746-900 Service Guide*, SY33-2116.

The 3745/3746 areas and functions checked through service inspection procedures are:

1. External covers
2. Safety labels

3. Safety covers and shields
4. Grounding
5. Circuit breaker and protector rating
6. Input power voltage
7. Test of emergency power OFF/control power switch.
8. Power-ON indicator

---

# About This Book

---

## Who Should Use This Book

---

The IBM personnel using this manual should be:

- Trained to service the network node processor, IBM 3745 Communication Controller, 3746-900, and 3746-950.
- Familiar with the network node processor service documentation,
- Familiar with the configuration of the 3745 Communication Controller, 3746-900, and 3746-950.

---

## How to Use This Book

This manual provides procedures for installing and maintaining a network node processor. To ensure the most efficient installation:

- Read the instructions carefully before attempting to do them,
- Complete each step before going to the next one,
- Go through the chapters sequentially.

---

## How This Book is Organized

- |                   |   |
|-------------------|---|
| <b>Chapter 1</b>  | Presents the procedures to install and connect the network node processor.          |
| <b>Chapter 2</b>  | Presents the procedures to manage the network node processor and the control point. |
| <b>Chapter 3</b>  | Presents the problem determination procedures for the network node processor.       |
| <b>Chapter 4</b>  | Gives the procedures to exchange the network node processor FRUs.                   |
| <b>Appendix A</b> | Gives the locations of the controller expansion components.                         |
| <b>Appendix B</b> | Provides network node processor aids.   |
| <b>Appendix C</b> | Provides network node processor aids.   |

A **service and customer documentation bibliography**, a **list of abbreviations**, and an **index** are provided at the end of this manual.

---

## Where to Find More Information

For a complete list of the network node processor, 3745, 3746-900, and 3746-950 customer and service information manuals, see at the end of this manual. In this *NNPIM*, references are made to the following publications:

*3745 Communication Controller Models 210 to 61A Maintenance Information Procedures*, SY33-2054

*3745 Communication Controller Models 130 to 17A Maintenance Information Procedures*, SY33-2070

*3746-950 Service Guide*, SY33-2108

*3746-900 Service Guide*, SY33-2116

*Nways Multiprotocol Controller Models 900 and 950 Migration and Planning Guide*, GA33-0349

*3745 Communication Controller Models A and 3746 Expansion Unit Model 900: Migration and Planning Guide*, GA33-0183

## World Wide Web

You can access the latest news and information about IBM network products, customer service and support, and microcode upgrades via the Internet at the URL: <http://www.ibm.com/>

## Online Documentation from CD-ROM

Starting at EC F12380 with the service processor is now shipped a CD which contains the LIC and a copy of the 3746 web site. You will find from this web page, marketing, PE, and all information about CCP products.

To access this page:

1. Insert the CD into the CD disk drive of the SP.
2. From the MOSS-E primary menu, click on **Information**
3. Double click on **CD-ROM documentation**
4. Then if you want to display the CCP documentation, click on **Documentation**
5. Click on **La Gaude Information Development: Communication Controllers Information**

**Note:** To have the very last version of the web site, connect to Internet at: <http://w3.lagaude.ibm.com/ccp/3746.htm>

---

## Service Personnel Definitions

See the *3745 Communication Controller Models 210 to 61A Maintenance Information Procedures*, SY33-2054, *3745 Communication Controller Models 130 to 17A Maintenance Information Procedures*, SY33-2070 or *3746-950 Service Guide*, SY33-2108.

---

## Summary of Changes

This revised edition gives information about the new procedures used to:

1. Upgrade the LIC on the NNP.
2. Restore the LIC.
3. Change the active LIC version.
4. Starting at EC F12380 and above, the LIC is shipped on a CD. On this CD you can get online documentation, for details refer to "Online Documentation from CD-ROM" on page xviii.



---

# Chapter 1. Installing and Setting Up Your Network Node Processor

Network Node Processor Overview . . . . .	1-2
Preparing Your Installation . . . . .	1-3
Installing Your Network Node Processor (7585) . . . . .	1-4
Installing the 7585 Network Node Processor - A . . . . .	1-6
Installing the 7585 System Unit (NNP-A) . . . . .	1-7
Connecting the 7585 (NNP-A) . . . . .	1-8
Installing the 7585 Network Node Processor - B . . . . .	1-9
Installing the 7585 System Unit (NNP-B) . . . . .	1-10
Installing a Second ac Outlet Distribution Box . . . . .	1-11
Connecting the 7585 Network Node Processor - B . . . . .	1-13
Installing Your Network Node Processor (3172) . . . . .	1-14
Installing the 3172 Network Node Processor - A . . . . .	1-16
Installing the 3172 System Unit (NNP-A) . . . . .	1-16
Connecting the 3172 (NNP-A) . . . . .	1-18
Installing the 3172 Network Node Processor - B . . . . .	1-19
Installing the 3172 System Unit (NNP-B) . . . . .	1-20
Installing a Second ac Outlet Distribution Box . . . . .	1-21
Connecting the 3172 Network Node Processor - B . . . . .	1-23
Installing the Code on the Network Node Processor . . . . .	1-24
Complete Your Installation . . . . .	1-28

# Network Node Processor Overview

The network node processor is based on an **7585-P02** or **IBM 3172 Model 003**, for 7585 refer to “Network Node Processor Based on 7585-P02” on page C-1, for 3172 refer to “Devices List for the Network Node Processor (3172)” on page C-16 and “Network Node Processor Hardware Configuration Reference (3172)” on page C-22 for details.




Figure 1-1. Network Node Processor Environment



---

## Preparing Your Installation

1. \_\_\_\_ You have received two diskettes with the Network Node Processor. Using a felt-tipped pen, identify one diskette as **Normal** and the other as **Backup**.
2. \_\_\_\_ Obtain from the customer the following **Parameter worksheet**:
  - “**Definition of Service LAN IP Addresses**” on page **A-1**

This parameter worksheet is part of the *3745 Communication Controller Models A and 3746 Models 900 and 950: Planning Guide*, GA33-0457 Appendix A and must be filled in by the customer. A copy of this parameter worksheet is given at the end of this manual see Appendix A, “Parameter Worksheet” on page A-1.

### Attention

The network node processor is connected to a **220V** power receptacle, if you connect other units on the ac outlet distribution box verify the voltage of these units.

### Go To

If you are installing a **Network Node Processor** type:

- **7585**, go to “Installing Your Network Node Processor (7585)” on page 1-4
- **3172**, go to “Installing Your Network Node Processor (3172)” on page 1-14


---

## Installing Your Network Node Processor (7585)


### 1. \_\_\_\_ **Unpack** Your Network Node Processor

For installing a **NNP-A** or a **NNP-B**, you need the following items to complete this installation:


- □ Network Node Processor (7585) and Power Cord



- □ Publications and diskette



- □ Brackets and screws



2. \_\_\_\_ Using label (PN 0782966), **identify** your Network Node Processor-A or Network Node Processor-B by sticking the appropriate label **A** on the front and rear side of the unit (refer to Figure 1-2).




Figure 1-2. Installing Label on the Front Side of the Network Node Processor (7585)

**Go To**

If you are installing:

- **NNP-A**, go to “Installing the 7585 Network Node Processor - A” on page 1-6
- **NNP-B**, go to “Installing the 7585 Network Node Processor - B” on page 1-9

## Installing the 7585 Network Node Processor - A

**Note:** The location of the NNP can be in different places in the controller expansion. It depends on the type of service processor and if other units are installed in this controller expansion. Go to Appendix B, “Controller Expansion Component Locations” on page B-1 and refer to Figure B-1 on page B-2 and Figure B-2 on page B-3 to determine with your customer where the NNP can be installed.

1. \_\_\_\_ Open the front and rear doors of the controller expansion, and locate the position to install the brackets used for the NNP-A (refer to Figure B-3 on page B-4). Install the left and right brackets **1** (PN 58G5752) and secure using four screws **2** (PN 2665527). If the captive nuts are already installed, go to step 1 on page 1-7, otherwise go to step 2.




Figure 1-3. Installing the NNP-A Brackets

2. \_\_\_\_ Refer to Figure 1-4 and install four captive nuts (PN 58G5766) on the left and right side of the controller expansion.




Figure 1-4. Installing the Captive Nuts for the 7585

## Installing the 7585 System Unit (NNP-A)

1. \_\_\_\_ Slide the network node processor unit in the controller expansion from the front side as shown in Figure 1-5., then fasten the unit using four screws (PN 1621230).




Figure 1-5. Installing the 7585 NNP-A Unit in the Controller Expansion (Front Side)

## Connecting the 7585 (NNP-A)

1. \_\_\_ Plug connector **1** of cable **A** (PN 6339098) to the token-ring card connector.
2. \_\_\_ Using a sticker, identify the cable **A** as the "network node processor cable" and plug connector **2** to **any plug** of the 8228 from **1 to 8**
3. \_\_\_ Connect power cord **3** from J2 to the ac outlet of the NNP-A.




Figure 1-6. Connecting the 7585 NNP-A

If the customer ordered a **NNP-B**, go to "Installing the 7585 Network Node Processor - B" on page 1-9, otherwise go to "Installing the Code on the Network Node Processor" on page 1-24.

## Installing the 7585 Network Node Processor - B

**Note:** The location of the NNP can be in different places in the controller expansion. It depends on the type of service processor and network node processor-A, and if other units are installed in this controller expansion. Go to Appendix B, “Controller Expansion Component Locations” on page B-1 and refer to Figure B-1 on page B-2 and Figure B-2 on page B-3 to determine with your customer where the NNP can be installed.

1. \_\_\_ Open the front and rear doors of the controller expansion and locate the position of the brackets used to install the NNP-B (if the service processor and the NNP-A are two 7585, refer to Figure B-3 on page B-4).
2. \_\_\_ Install the left and right brackets **1** (PN 58G5752) and secure using four screws **2** (PN 2665527). If the captive nuts are already installed, go to step 1 on page 1-10, otherwise go to step 3




Figure 1-7. Installing the NNP-B Brackets

3. \_\_\_ Refer to Figure 1-8 and install four captive nuts (PN 58G5766) on the left and right side of the controller expansion.




Figure 1-8. Installing the Captive Nuts for the 7585

## Installing the 7585 System Unit (NNP-B)

1. \_\_\_\_ Slide the network node processor unit in the controller expansion from the front side as shown in Figure 1-9, then fasten the unit using four screws (PN 1621230).




Figure 1-9. Installing the 7585 NNP-B Unit in the Controller Expansion (Front Side)

### Go To


Do you have to install a second **ac outlet distribution box** ?

- **Yes**, go to “Installing a Second ac Outlet Distribution Box” on page 1-11.
- **No**, go to “Connecting the 7585 Network Node Processor - B” on page 1-13.



## Installing a Second ac Outlet Distribution Box

1. \_\_\_\_ **Identify** the location to install the two captive nuts **A** (second hole from the left) , if already installed go to step 3, otherwise go to step2.



Rear View

Figure 1-10. Locating the Captive Nuts

2. \_\_\_\_ Refer to Figure 1-11 to **install** the two captive nuts (PN 58G5766).




Figure 1-11. Installing the Captive Nuts

3. \_\_\_\_ Refer to Figure 1-12 on page 1-12, using one lockwasher (PN 1622319), one starwasher (PN 1622347), and one screw (PN1673983), **connect** the ground jumper **A** (PN 63F2459) to the new ac outlet distribution box. Then, **install** the second ac outlet distribution box close to the first ac outlet distribution box and fasten using two screws **C** (PN 1621230).




Figure 1-12. Installing the Second ac Outlet Distribution Box

4. \_\_\_\_ Using the same washers and screw used to connect the first ac outlet distribution box, **connect** the other lead of the ground jumper **A** to the frame.
5. \_\_\_\_ Plug the power cord **A** (country dependant) into location **IN** of the ac outlet distribution box. Then route and connect the other lead of the power cord to the customer's power socket.




Figure 1-13. Power Cord Installation

6. \_\_\_\_ Switch or ask the customer to switch **ON** the circuit breaker to be used for the ac outlet distribution box.
7. \_\_\_\_ Verify that the phase is distributed as shown below: **if not, notify the customer and do not proceed until the problem is corrected.**




Figure 1-14. Power Distribution

## Connecting the 7585 Network Node Processor - B

1. \_\_\_\_ Plug connector **1** of cable **A** (PN 6339098) to the token-ring card connector.
2. \_\_\_\_ Using a sticker, identify the cable **A** as the "network node processor cable" and plug connector **2** to **any plug** of the 8228 from **1 to 8**
3. \_\_\_\_ Connect power cord **3** from J5 to the ac outlet of the NNP-B.




Figure 1-15. Connecting the NNP-B (7585)

Go to "Installing the Code on the Network Node Processor" on page 1-24.


---

## Installing Your Network Node Processor (3172)


### 1. \_\_\_ **Unpack** Your Network Node Processor

For installing a **NNP-A** or a **NNP-B**, you need the following items to complete this installation:


- Network Node Processor (3172) and Power Cord



- Publications and diskette



- Brackets and screws



2. \_\_\_\_ Using label (PN 80G0680), **identify** your Network Node Processor-A or Network Node Processor-B by sticking the appropriate label **A** on the front and rear side of the unit (refer to Figure 1-16 and Figure 1-17).




Figure 1-16. Installing Label on the Front Side of the Network Node Processor (3172)




Figure 1-17. Installing Label on the Rear Side of the Network Node Processor (3172)

#### Go To

If you are installing:

- **NNP-A**, go to “Installing the 3172 Network Node Processor - A” on page 1-16.
- **NNP-B**, go to “Installing the 3172 Network Node Processor - B” on page 1-19.

## Installing the 3172 Network Node Processor - A

**Note:** The location of the NNP can be in different places in the controller expansion. It depends on the type of service processor and if other units are installed in this controller expansion. Refer to Figure B-1 on page B-2 and Figure B-2 on page B-3 to determine with your customer where the NNP can be installed.

1. \_\_\_\_ Open the front and rear doors of the controller expansion and locate the position of the brackets used to install the network node processor-A. (if the service processor is a 3172, refer to Figure B-4 on page B-5).
2. \_\_\_\_ Install the left and right brackets **1** (PN 58G5752) and secure using four screws **2** (PN 2665527).
3. \_\_\_\_ When the NNP will be installed, install four screws **3** (PN 0782986)




Figure 1-18. Installing the Network Node Processor Brackets (NNP Type 3172)

### Installing the 3172 System Unit (NNP-A)

1. \_\_\_\_ If installed, remove the four pads located under the unit.
2. \_\_\_\_ Slide the network node processor unit in the controller expansion from the rear side as shown in Figure 1-19 on page 1-17.




Figure 1-19. Installing the 3172 NNP-A Unit in the Controller Expansion (Rear Side)

## Connecting the 3172 (NNP-A)

1. \_\_\_ Plug connector **1** of cable **A** (PN 6339098) to cable **B** (PN 60G1066).
2. \_\_\_ Using a sticker, identify the cable **A** as the "network node processor cable" and plug connector **2** to **any plug** of the 8228 from **1 to 8**
3. \_\_\_ Plug cable **B** to **slot 7** of the network node processor.
4. \_\_\_ Connect power cord **3** from J2 to the ac outlet of the NNP-A.

### Temporary Procedure

Connect the keyboard shipped with the network node processor to connectors K and M located at the rear side of the NNP.




Figure 1-20. Connecting the NNP-A

If the customer ordered a **NNP-B**, go to "Installing the 3172 Network Node Processor - B" on page 1-19, otherwise go to "Installing the Code on the Network Node Processor" on page 1-24.



## Installing the 3172 Network Node Processor - B

**Note:** The location of the NNP can be in different places in the controller expansion. It depends on the type of service processor and network node processor-A, and if other units are installed in this controller expansion. Refer to Figure B-1 on page B-2 and Figure B-2 on page B-3 to determine with your customer where the NNP can be installed.

1. \_\_\_\_ Open the front and rear doors of the controller expansion. Locate the position of the brackets used to install the NNP-B (if the service processor and the NNP-A are 3172, refer to Figure B-4 on page B-5).
2. \_\_\_\_ Install the left and right brackets **1** (PN 58G5752) and secure using four screws **2** (PN 2665527).
3. \_\_\_\_ When the NNP will be installed, install four screws **3** (PN 0782986)




Figure 1-21. Installing the NNP-B Brackets

## Installing the 3172 System Unit (NNP-B)

1. \_\_\_\_ If installed, remove the four pads located under the unit.
2. \_\_\_\_ Slide the network node processor unit in the controller expansion from the rear side as shown in Figure 1-22. Refer also to Appendix B, "Controller Expansion Component Locations" on page B-1.




Figure 1-22. Installing the 3172 NNP-B Unit in the Controller Expansion (Rear Side)


### Go To

Do you have to install a second **ac outlet distribution box** ?

- **Yes**, go to "Installing a Second ac Outlet Distribution Box" on page 1-21.
- **No**, go to "Connecting the 3172 Network Node Processor - B" on page 1-23.

## Installing a Second ac Outlet Distribution Box

1. \_\_\_\_ **Identify** the location to install the two captive nuts **A** (second hole from the left) , if already installed go to step 3, otherwise go to 2.



Rear View

Figure 1-23. Locating the Captive Nuts

2. \_\_\_\_ Refer to Figure 1-24 to **install** the two captive nuts (PN 58G5766).




Figure 1-24. Installing the Captive Nuts

3. \_\_\_\_ Refer to Figure 1-25 on page 1-22, using one lockwasher (PN 1622319), one starwasher (PN 1622347), and one screw (PN1673983), **connect** the ground jumper **A** (PN 63F2459) to the new ac outlet distribution box. Then, **install** the second ac outlet distribution box close to the first ac outlet distribution box and fasten using two screws **C** (PN 1621230).




Figure 1-25. Installing the Captive Nuts

4. \_\_\_\_ Using the same washers and screw used to connect the first ac outlet distribution box, **connect** the other lead of the ground jumper **A** to the frame.
5. \_\_\_\_ Plug the power cord **A** (country dependant) into location **IN** of the ac outlet distribution box. Then, route and connect the other lead of the power cord to the customer's power socket.




Figure 1-26. Power Cord Installation

6. \_\_\_\_ Switch or ask the customer to switch ON the circuit breaker to be used for the ac outlet distribution box.
7. \_\_\_\_ Verify that the phase is distributed as shown below: **if not, notify the customer and do not proceed until the problem is corrected.**




Figure 1-27. Power Distribution

## Connecting the 3172 Network Node Processor - B

1. \_\_\_ Plug connector **1** of cable **A** (PN 6339098) to cable **B** (PN 60G1066).
2. \_\_\_ Using a sticker, identify the cable **A** as the "network node processor cable" and plug connector **2** to **any plug** of the 8228 from **1 to 8**
3. \_\_\_ Plug cable **B** to **slot 7** of the network node processor.
4. \_\_\_ Connect power cord **3** from J5 to the ac outlet of the NNP-B.

### Temporary Procedure

Connect the keyboard shipped with the network node processor to connectors K and M located at the rear side of the NNP.




Figure 1-28. Connecting the NNP-B

Go to "Installing the Code on the Network Node Processor" on page 1-24.

## Installing the Code on the Network Node Processor

### Notes

For any unexpected message or error concerning the network node processor:

- Go to, “MAP: Entry Point for Problem Isolation” on page 3-1

For any other message or error displayed on the control panel, go to:

- The **START** page of the *3745 Communication Controller Models 210 to 61A Maintenance Information Procedures*, SY33-2054, if you are working on a **3745 Model X1A**.
- The **START** page of the *3745 Communication Controller Models 130 to 17A Maintenance Information Procedures*, SY33-2070, if you are working on a **3745 Model 17A**.
- Or go to the **START** page of the *3746-950 Service Guide*, SY33-2108, if you are working on a **3746-950**.

1. \_\_\_\_ Double click on the 3746-950 or 3746-900 icon where you are going to install the NNP.
2. \_\_\_\_ From the 3746-9x0 menu, click on **Network Node Processor (NNP) Management**.




Figure 1-29. 3746-9x0 Menu

3. \_\_\_\_ Double click on **(M) Install/Remove/Change/Restore LIC/NNP**.




Figure 1-30. Network Node Processor Menu

If you are installing:

- **NNP-A**, go to step 4 on page 1-25
- **NNP-B**, go to step 7 on page 1-26

4. \_\_\_\_ Select the NNP-A, then click on **Install NNP**.




Figure 1-31. NNP-A LIC Management Menu

5. \_\_\_\_ Read the information message, then click on **OK**.

6. \_\_\_\_ If necessary, modify the **IP address** for the **service processor, NNP-A,** and **3746 NN** according to the values recorded by the customer on the worksheet “**Definition of Service LAN IP Addresses**” on page A-1 . The **Subnet mask** can also be modified for the service processor but will be automatically updated for the **NNP-A,** and **3746 NN**. Otherwise keep the default values and record the hostnames for later use.

**Notes:**

- a. If the customer defines with CCM an IP configuration file, the IP address and the subnet mask for the adapter 2080 must be defined in the same IP subnet. That means in this example, IP address 192.9.200.4 and subnet mask 255.255.255.240.
- b. The hostnames can't be modified but they will be used in the alerts and alarms sent to NetView.




Figure 1-32. Network Node Processor IP Parameters Menu

Then go to step:

- **10 on page 1-27** , if you do **not** have to install a **NNP-B**
- **7 on page 1-26** , if you have to install a **NNP-B**

7. \_\_\_\_ Select the NNP-B, then click on **Install NNP**.




Figure 1-33. NNP-B LIC Management Menu

8. \_\_\_\_ Click on **OK**.

9. \_\_\_\_ If necessary, modify the **IP address** and the **Subnet mask** for the **NNP-B** according to the values recorded by the customer on the worksheet “**Definition of Service LAN IP Addresses**” on page A-1 . Otherwise keep the default values and record the hostnames for later use.

**Notes:**

- a. If the customer defines with CCM an IP configuration file, the IP address and the subnet mask for the adapter 2080 must be defined in the same IP subnet. That means in this example, IP address 192.9.200.4 and subnet mask 255.255.255.240.
- b. The hostnames can't be modified but they will be used in the alerts and alarms sent to NetView.




Figure 1-34. Network Node Processor IP Parameters Menu



10. \_\_\_\_ Click on **OK**, then insert the **Network Node Processor installation diskette** in the diskette drive of the **service processor**, then click on **OK**.

**Note:** The following figure is a view of a service processor based on a 7585, it can be a 3172, 9585 or a 9577.




Figure 1-35. Service Processor Front View (Type 7585)

11. \_\_\_\_ Select the type of NNP installed, then click on **OK**.




Figure 1-36. Service Processor Front View (Type 7585)

12. \_\_\_\_ When the process is completed, record the following procedures listed on Figure 1-37, then click on **OK**.




Figure 1-37. NNP-A Licensed Internal Code Management

13. \_\_\_\_ To follow the progress of the installation, read the messages prompted in 'Messages' box.

**Note:** It takes about 20 minutes to complete the installation




Figure 1-38. Network Node Processor LIC Management Menu

14. \_\_\_\_ As indicated in the following information message, remove the Network Node Processor installation diskette, then click on **OK**.




Figure 1-39. NNP-A Licensed Internal Code Management Information Message

15. \_\_\_\_ The installation is completed, click on **OK**, then click on **Close**.

## Complete Your Installation

### End of Network Node Processor Installation

Return where you left the previous installation procedure using one of the following guide, if you are installing a:

- **3746-900**, return to the *3746-900 Installation Guide*, SY33-2114.
- **3746-950**, return to the *3746-950 Installation Guide*, SY33-2107.

---

## Chapter 2. Managing the Network Node Processor and the Control Point

General Information . . . . .	2-2
Accessing the Network Node Processor Functions . . . . .	2-3
Installing or Removing a Network Node Processor . . . . .	2-4
Upgrading the LIC on a Network Node Processor (LIC on CD-ROM) . . . . .	2-5
Restoring the LIC on a Network Node Processor (LIC on CD-ROM) . . . . .	2-6
Changing the Active LIC (LIC on CD-ROM) . . . . .	2-7
Modifying IP Parameters . . . . .	2-8
Managing the Control Point and the NNP . . . . .	2-9
Importing a Configuration . . . . .	2-10
Exporting a Configuration . . . . .	2-11
Accessing a Network Node Processor . . . . .	2-13
Accessing IP Commands from the MOSS-E . . . . .	2-15
Changing or Restoring LIC on a Network Node Processor (LIC on OD) . . . . .	2-16

### Important Note

Procedures “Changing or Restoring LIC on a Network Node Processor (LIC on OD)” on page 2-16 applies to LIC EC **up to D46130**.  
For other EC level starting at **F12380 and above** refer to “Upgrading the LIC on a Network Node Processor (LIC on CD-ROM)” on page 2-5, or “Restoring the LIC on a Network Node Processor (LIC on CD-ROM)” on page 2-6.  
The LIC is shipped on an **OD** up to EC **D46130** then on a **CD** starting at EC **F12380**.

## General Information

Figure 2-1 represents the configuration of one communication controller with a 3745 base frame and a 3746-900 frame running APPN.

Figure 2-2 represents the configuration of one 3746-950.




Figure 2-1. One 3745 and a 3746-900 APPN




Figure 2-2. One 3746-950

The color of the network node processor icon gives the status of the nnp-a. This information can be obtained on-line from the information pulldown menu when selecting 'Legend'. Top to bottom the icon's color is: transparent, grey, blue, purple, white, and green.




Figure 2-3. Network Node Processor Status

## Accessing the Network Node Processor Functions

### Note

All maintenance functions are identified by an **(M)** preceding the text (example: see Figure 2-5 function "(M) Install/Remove/Change/Restore LIC").

1. Enter the **Service Processor Maintenance** password on the signon menu (default password: *IBM3745* or ask the customer if a specific password has been defined).
2. Double click on the **3746-900 or 3746-950 object icon** , you will get the following screen:




Figure 2-4. 3746-9x0 Maintenance Functions

3. Click on **Network Node Processor (NNP) Management**.




Figure 2-5. Network Node Processor Management Functions

## Installing or Removing a Network Node Processor

1. \_\_\_\_ Double click on **Install/Remove/Change/Restore LIC/NNP**




Figure 2-6. NNP-A Licensed Internal Code Management

2. \_\_\_\_ Select the NNP (A or B) then click on **Install NNP** or **Remove NNP**




Figure 2-7. Installing or Removing a NNP-A

## Upgrading the LIC on a Network Node Processor (LIC on CD-ROM)

### Notes:

1. This function is **not disruptive** as it modifies the LIC loaded on the non-active partition and it updates the SP and NNP LIC at the same time.
  2. It applies only on SP/NNP running LIC EC **F12380 and above** (using CD drive), for other EC **up to D46130**, refer to “**Changing or Restoring LIC on a Network Node Processor (LIC on OD)**” on page 2-16 .
1. \_\_\_\_ From the service processor menu, click on **Change Management**




Figure 2-8. SP Change Management Menu

2. \_\_\_\_ Insert the compact disk in the CD disk drive, double click on **Update SP (&NNP) LIC on non-active version**, then follow the prompts.




Figure 2-9. Service Processor Menu

3. \_\_\_\_ Then to activate the changes, use the function 'toggle to non-active version' to load and execute the new code in the processors (refer to “**Changing the Active LIC (LIC on CD-ROM)**” on page 2-7).

**Note:** If an NNP backup is installed, its code is also updated automatically.

---

## Restoring the LIC on a Network Node Processor (LIC on CD-ROM)

### Notes:

1. This function is **not disruptive** as it applies on the LIC loaded on the non-active partition. This function can be used to reload a back level of code.
  2. It applies only on SP/NNP running LIC EC **F12380 and above** (using CD drive), for other EC **up to D46130**, refer to “**Changing or Restoring LIC on a Network Node Processor (LIC on OD)**” on page 2-16 .
1. \_\_\_\_ From the service processor menu, click on **Change Management**




Figure 2-10. SP Change Management Menu

2. \_\_\_\_ Insert the compact disk into the CD disk drive and the configuration diskette into the diskette drive. Double click on **Restore SP (&NNP) LIC on non-active version**, then follow the prompts.




Figure 2-11. Service Processor Menu

3. \_\_\_\_ Then to activate the changes, use the function 'toggle to non-active version' to load and execute the new code in the processors (refer to “**Changing the Active LIC (LIC on CD-ROM)**” on page 2-7).

**Note:** If an NNP backup is installed, its code is also restored automatically.



---

## Changing the Active LIC (LIC on CD-ROM)

### Notes:

1. This function is **disruptive** and it is used to switch the non-active partition and the active partition. It reboots the SP and the NNPs (if any). Use this function after a LIC upgrade or a LIC reload to load the processors with the new LIC.
  2. It applies only on SP/NNP running LIC EC **F12380 and above** (using CD drive).
1. \_\_\_\_ From the service processor menu, click on **Change Management**




Figure 2-12. SP Change Management Menu

2. \_\_\_\_ Double click on **Switch to non-active version**, then follow the prompts.




Figure 2-13. Service Processor Menu

**Note:** If an NNP backup is installed, its active code is also switched to the non-active version.

## Modifying IP Parameters

1. \_\_\_\_ Double click on **Install/Remove/Change/Restore LIC/NNP**




Figure 2-14. NNP Licensed Internal Code Management

2. \_\_\_\_ Select the NNP (A or B) then click on **Modify IP Parameters...**




Figure 2-15. Modifying IP Parameters

3. \_\_\_\_ On this screen you can modify the IP address and Subnet mask parameters (press Help pushbutton for details).




Figure 2-16. IP Parameters

## Managing the Control Point and the NNP

1. \_\_\_\_ Double click on **Manage Control Point on NNPs**




Figure 2-17. Manage Control Point on NNPs

2. \_\_\_\_ From this screen, select the NNP (A or B) then you are able to:
  - a. Start, stop, or stop and restart a control point
  - b. Activate a specific configuration
  - c. Take a dump of a control point
  - d. Shutdown and restart a NNP
  - e. Manage NPM configuration.

**Note:** Press help pushbutton to get details.




Figure 2-18. Managing the Control Point and NNPs



## Exporting a Configuration

1. \_\_\_\_ Double click on **CCM - Controller Configuration and Management**




Figure 2-21. CCM

2. \_\_\_\_ Click on **OK**, click on **file**, then click on **Open**




Figure 2-22. Selecting a Configuration

3. \_\_\_\_ Select the configuration to be exported, then click on **Export**




Figure 2-23. Exporting a Configuration

4. \_\_\_\_ Insert a diskette in drive A, then click on **OK**

## Accessing a Network Node Processor

1. \_\_\_\_ Double click on **Connect to an NNP**




Figure 2-24. Accessing a NNP

2. \_\_\_\_ On the following screen, select the NNP (A or B) then click on **Connect**




Figure 2-25. Connecting to a NNP

3. \_\_\_\_ Click on **NNP Management**.




Figure 2-26. NNP Functions

4. \_\_\_\_ Click on **Session**, and click on **Terminate**. to close a session.




Figure 2-27. Terminating a Session



---

## Accessing IP Commands from the MOSS-E

1. \_\_\_\_ Double click on **IP Commands**




Figure 2-28. Accessing IP Commands

2. \_\_\_\_ On the following screen, enter the user ID and password (defaults are NNPIP and 37469X0A), then click on **enter**.  
You are now able to navigate within the internet protocol environment (for details refer to the *3745/17A-61A and 3746-900 Basic Operations Guide*, SA33-0177 or *3745 Communication Controller Models A and 3746 Expansion Unit Model 900: Migration and Planning Guide*, SA33-0356).




Figure 2-29. Telnet Access

## Changing or Restoring LIC on a Network Node Processor (LIC on OD)

**Note:** This procedure can be used only on SP/NNP running LIC EC level **up to D46130** (any suffix). For other ECs, starting with EC **F12380 and above**, use the procedures “Upgrading the LIC on a Network Node Processor (LIC on CD-ROM)” on page 2-5 or “Restoring the LIC on a Network Node Processor (LIC on CD-ROM)” on page 2-6.

Use the **Change** option to copy the control point (CP) from the service processor to the network node processor hard drive. This function is used following the installation of a new version of the Licensed Internal Code or after applying MCLs or MCFs concerning the CP.

The **Restore** option will be used after a hard disk replacement of the network node processor. For details see “Procedure after Hard Disk Drive Exchange on NNP Based on 3172” on page 4-11.

1. \_\_\_\_ Double click on **Install/Remove/Change/Restore LIC/NNP**




Figure 2-30. NNP Licensed Internal Code Management

2. \_\_\_\_ Select the NNP (A or B), then click on **Change LIC on NNP** or **Restore LIC on NNP**, then follow the prompts.




Figure 2-31. Changing or Restoring LIC on NNP.

---

## Chapter 3. Network Node Processor Problem Determination

### MAP: Entry Point for Problem Isolation

You are here because you have a problem on the network node processor.

001

Are you here for a network node processor power ON problem?

Yes No

002

- For service processor based on 3172 go to "MAP: Problem Isolation on Network Node Processor Based on 3172" on page 3-6.
- For service processor based on 7585 go to "MAP: Problem Determination on Network Node Processor Based on 7585" on page 3-15.

003

- Check that the suspected network node processor is powered ON.
- If not switch the power ON button to the ON position.

Is the network node processor powered ON?

Yes No

004

Check that the ac power cable of the network node processor is well connect at:

- The rear of the network node processor
- On the ac outlet distribution box.

Is the problem solved?

Yes No

005

Continue with Step 008 on page 3-2.

006

Problem solved. Go to "CE Leaving Procedure" on page 5-47.


---

007

Problem solved. Go to "CE Leaving Procedure" on page 5-47

---

008




**Fuse Location on ac outlet distribution box**

- On the ac outlet distribution box:
  - Fuse F1 controls the range of connectors J1 to J4
  - Fuse F2 controls the range of connectors J5 to J8.
- Check if other units are connected to the same range of connectors than the suspected unit.

**Are there other units connected to the same range than the suspected unit?**

Yes No




Go to Step 018 on page 3-3.

010

Check that the other units have their power ON/OFF switch to ON.

**Are other units powered ON?**

Yes No



Go to Step 013

012

Go to Step 021 on page 3-4.

---

013

Check the corresponding fuse.  
(Step 013 continues)

013 (continued)

Is the fuse OK?

Yes No

014

- Switch to OFF all the units controlled by this fuse.
- Exchange the defective fuse.
- Switch ON all the units controlled by this fuse.

Is the fuse blown again?

Yes No

015

Problem solved go to "CE Leaving Procedure" on page 5-47.

016

- Suspect a power problem in a unit powered through the ac outlet distribution box.
  - Switch to OFF all the units controlled by this fuse.
  - Exchange the fuse.
  - Switch one by one the units controlled by this fuse to identify the unit which has a problem.
  - Once you have identified the faulty unit continue with Step 025 on page 3-4.
- 

017

Suspect the ac wall socket.

---

018

Check the corresponding fuse.

Is the fuse OK?

Yes No

019

- Switch to OFF the network node processor controlled by this fuse.
- Exchange the defective fuse.
- Switch ON the network node processor.

Is the fuse blown again?

Yes No

020

Problem solved go to "CE Leaving Procedure" on page 5-47.

021

Suspect a power problem in the network node processor.

- If your network node processor is based on 3172, refer to the *3172 Interconnect Controller Maintenance Information Model 3*, SY27-0334 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 3172” on page 4-1.
  - If your network node processor is based on 7585, refer to the *7585 P02 Industrial Computer Installation, Operation, Hardware Maintenance*, S76H-3792 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.
- 

**022**

**Are all other units installed in the controller rack powered ON?**

Yes No

**023**

Suspect the ac wall socket.

**024**

Suspect a power problem in the network node processor.

- If your network node processor is based on 3172, refer to the *3172 Interconnect Controller Maintenance Information Model 3*, SY27-0334 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 3172” on page 4-1.
  - If your network node processor is based on 7585, refer to the *7585 P02 Industrial Computer Installation, Operation, Hardware Maintenance*, S76H-3792 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.
- 

**025**

According to the defective unit type select, the action to be performed.

Unit Type	Action
Service Processor	Refer to the service processor documentation.
Network Node Processor	<ul style="list-style-type: none"> <li>• If your network node processor is based on 3172, refer to the <i>3172 Interconnect Controller Maintenance Information Model 3</i>, SY27-0334 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 3172” on page 4-1.</li> <li>• If your network node processor is based on 7585, refer to the <i>7585 P02 Industrial Computer Installation, Operation, Hardware Maintenance</i>, S76H-3792 manual to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.</li> </ul>
Display	Exchange it. Refer to the corresponding <i>Service Processor Installation and Maintenance</i> manual on which the display is connected.
Optical Disk or CD-ROM	Exchange it. Refer to the corresponding <i>Service Processor Installation and Maintenance</i> manual on which the optical disk or the CD-ROM is connected.
Modem	Refer to the following modem documentation: <ul style="list-style-type: none"> <li>• For the IBM 7855, refer to the <i>7855 Modem Model 10 Guide to Operation</i>, GA33-0160</li> <li>• For the IBM 7857, refer to the <i>IBM 7857 Guide to Operation</i>, GA13-1839</li> <li>• For other modems, refer to the corresponding documentation.</li> </ul>
Other Units	Refer to the corresponding documentation shipped with the unit.

## MAP: Problem Isolation on Network Node Processor Based on 3172

You are here because you suspected:

- A network node processor problem.
- A connection problem between the network node processor and a 3746-900 or a 3746-950.
- A connection problem between the service processor and the network node processor.

The network node processor is powered ON.




Figure 3-1. LAN attached to the Service Processor

### Notes:

1. The network node processor is an optional feature which is present only when APPN is installed. A backup network node processor can be also present. Until four network node processors can be installed on the same LAN.
2. Up to two service processor access units (8228) can be used depending on the number of network node processor used.
3. Only 3745, 3746-900, 3746-950, service processor and network node processor can be connected to the LAN when APPN is installed.





## MAP (continued)

Code Displayed	Symptom Explanation	Action
<b>Ab02</b>	network node processor configuration file not found	Create CCM configuration
<b>Ab03</b>	network node processor supervisor received a STOP_CP command from operator	None
<b>Ab04</b>	network node processor configuration activation disabled	Activate configuration
<b>Ab07</b>	network node processor supervisor failed to read the network node processor system configuration	Check that the LAN cable is well connected on the rear of the network node processor and in the service processor access unit. If that does not solve the problem go to Step 005 on page 3-13
<b>Ab08</b>	network node processor supervisor failed to search the network node processor system configuration	
<b>Ab0A</b>	network node processor supervisor failed to read the network node processor system configuration 2	Check that the LAN cable is well connected on the rear of the network node processor and in the service processor access unit. If that does not solve the problem go to Step 005 on page 3-13
<b>Ab0b</b>	network node processor supervisor failed to search the network node processor system configuration 2	
<b>Ab0c</b>	CP is started and waiting connection with the 3746-9xx.	<ul style="list-style-type: none"> <li>• Check LAN connection of the 3746-9xx.</li> <li>• Perform a general IML on the 3746-9xx.</li> <li>• If problem not solved call your support.</li> </ul>
<b>Ab14</b>	network node processor supervisor received an invalid request	Call your support
<b>Ab21</b>	network node processorsupervisor has received a LINK_LOST command	<ul style="list-style-type: none"> <li>• Check the LAN between the network node processor and the 3746-9x0.</li> <li>• If the problem not solved call your support.</li> </ul>
<b>Ab22</b>	network node processorsupervisor has received a LINK_UP command	None
<b>Ab23</b>	network node processorsupervisor has received a LINK_READY command	None. Should disappears after few minutes. If always present call your support.
<b>Ab30</b>	network node processorsupervisor detected the linl operational with the 3746-9xx.	None. Normal operation.
<b>Ab31</b> <b>Ab36</b>	network node processor supervisor has detected a reboot threshold	<p>Power OFF the power ON the network node processor.</p> <ul style="list-style-type: none"> <li>• If you have always the same error code call your support.</li> <li>• If you have an other error code restart the problem determination.</li> <li>• Otherwise go to “CE Leaving Procedure” on page 5-47.</li> </ul>

<b>Code Displayed</b>	<b>Symptom Explanation</b>	<b>Action</b>
<b>Ab40</b>	network node processorsupervisor failed to start service processor program (EXITLIST)	<p>If this code stays permanently on the display:</p> <ul style="list-style-type: none"> <li>• Go to Step 005 on page 3-13.</li> <li>• If that does not solve the problem call your support.</li> </ul>
<b>Ab41</b>	network node processorsupervisor failed to start service processor program (SESSION_REGISTER)	
<b>Ab42</b>	network node processorsupervisor failed to start service processor program (SIM_INIT ERROR)	
<b>Ab43</b>	network node processorsupervisor failed to start service processor program (TIMER_SERVER)	
<b>Ab44</b>	network node processorsupervisor failed to start service processor program (TIMER_SERVER)	
<b>Ab60</b>	GETCPNAME failed (REBOOT_NNP)	
<b>Ab61</b>	Create synchro semaphore failed (REBOOT_NNP)	
<b>Ab62</b>	Remove synchro semaphore failed (REBOOT_NNP)	
<b>Ab66</b>	Remote procedure call (RPC) link error	<p>If this code permanently displayed</p> <p>Check that the LAN cable connection at the rear of the network node processor and in the service processor access unit. If that does not solve the problem suspect a network node processor LAN adapter card problem. Go to Chapter 4, "Network Node Processor Based on 3172" on page 4-1 to exchange the LAN adapter card.</p>
<b>Ab68</b>	System status thread exit	<ul style="list-style-type: none"> <li>• Go to Step 005 on page 3-13.</li> <li>• If that does not solve the problem call your support.</li> </ul>
<b>Ab90</b>	SRC server create queue error	<ul style="list-style-type: none"> <li>• Go to Step 005 on page 3-13.</li> <li>• If that does not solve the problem call your support.</li> </ul>
<b>Ab91</b>	CPWAITSRC error found	
<b>Ab92</b>	GETCPNAME error found	
<b>Ab93</b>	SRC thread exit	

## MAP (continued)

Code Displayed	Symptom Explanation	Action
<b>AbC1</b>	network node processor supervisor fatal error (create CP semaphore failed)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbC3</b>	network node processor supervisor fatal error (cannot read EULAASPS config.file)	
<b>AbC4</b>	network node processor supervisor fatal error (environment error)	
<b>AbC5</b>	network node processor supervisor fatal error (error setting CP semaphore)	
<b>AbC6</b>	network node processor supervisor fatal error (cannot read EULAASPS config.file)	
<b>AbC7</b>	network node processor supervisor fatal error (error setting CP semaphore)	
<b>AbC8</b>	network node processor supervisor fatal error (cannot read EULNCFG config.file)	
<b>AbC9</b>	network node processor supervisor fatal error (cannot read EULNCFG config.file)	
<b>AbCA</b>	network node processor supervisor fatal error (cannot read EULNCFG config.file)	
<b>AbCB</b>	network node processor supervisor fatal error (cannot read EULAASPS config.file)	
<b>AbCC</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP-1A THREAD)	
<b>AbCD</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP-1B THREAD)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbCE</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP2-A THREAD)	
<b>AbCF</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP2-B THREAD)	
<b>AbD0</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP-B THREAD)	
<b>AbD1</b>	network node processor supervisor fatal error (DOSALLOCSEG - SP CP-A THREAD)	

<b>Code Displayed</b>	<b>Symptom Explanation</b>	<b>Action</b>
<b>AbD2</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC SP STS THREAD)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbD3</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC CP STS THREAD)	
<b>AbD4</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC SP/CP STS THREAD)	
<b>AbD5</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC SP/CP THREAD)	
<b>AbD6</b>	network node processor supervisor fatal error (DOSALLOCSEG - MOSS-E REBOOT THREAD)	
<b>AbD7</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC CP CTRL. THREAD)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbD8</b>	network node processor supervisor fatal error (DOSALLOCSEG - RPC SRC THREAD)	
<b>AbD9</b>	network node processor supervisor fatal error (DOSALLOCSEG - REBOOT COUNT THREAD)	
<b>AbDA</b>	network node processor supervisor fatal error (trap occurred inside its code)	
<b>AbDC</b>	network node processor supervisor fatal error (cannot read EULNCFG config.file)	
<b>AbDD</b>	network node processor supervisor fatal error (search EULNCFG failed)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbDE</b>	network node processor supervisor fatal error (read VP2.INI file failed)	
<b>AbDF</b>	network node processor supervisor fatal error (read VPD2.INI file failed)	
<b>AbE0</b>	network node processor supervisor fatal error (session register failed)	
<b>AbE1</b>	network node processor supervisor fatal error (create backup NNP failed)	

## MAP (continued)

Code Displayed	Symptom Explanation	Action
<b>AbE2</b>	network node processor supervisor fatal error (update VPD failed)	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbE3</b>	network node processor supervisor fatal error (cannot init LAN global data)	
<b>AbE5</b>	network node processorRPC (remote procedure call) cannot decode arguments	
<b>AbE6</b>	network node processorRPC cannot decode results	
<b>AbE7</b>	network node processorRPC cannot send	
<b>AbE8</b>	network node processorRPC cannot receive	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbE9</b>	network node processorRPC call program version mismatch	
<b>AbEA</b>	network node processorRPC call authentication error	
<b>AbEB</b>	network node processorRPC call program unavailable	
<b>AbEC</b>	network node processorRPC call cannot decode arguments	
<b>AbED</b>	network node processorRPC call system error	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbEE</b>	network node processorRPC call unknown host	
<b>AbEF</b>	network node processorRPC call port mapper failure	
<b>AbF0</b>	network node processorRPC call program not registered	
<b>AbF1</b>	network node processorRPC call unspecified error	
<b>AbF2</b>	network node processorinit client host not found	<ul style="list-style-type: none"> <li>• Power OFF then ON the network node processor</li> <li>• If that does not solve the problem go to Step 005 on page 3-13</li> <li>• If the error persists call your support</li> </ul>
<b>AbF3</b>	network node processorinit client try again	
<b>AbF4</b>	network node processorinit client no recovery	
<b>AbF5</b>	network node processorinit client no address	
<b>AbF6</b>	network node processorCLNTTCP_CREATE Failed	
<b>AbF8</b>	CP RPC THREAD ABORTED	

Code Displayed	Symptom Explanation	Action
All other Codes	A SRC should have been generated.	Refer to the alarm message for explanation. If no SRC call your support. To display the alarms continue with Step 011 on page 3-14.

---

**005**

Return on the *service processor* console to load the licensed internal code on the NNP, using the following procedure:

- Return to the **MOSS-E View** window.
- Double click on the **3746-950** icon.
- On the **3746-900 Menu** select the **Network Node Processor (NNP) Management** option.
- On the **Network Node Processor (NNP) management** window double click on the **Install/change/Restore LIC/NNP** option.
- The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed.
- Select the NNP (A or B), then click on **Restore LIC on NNP**
- On the following window click on **OK**
- Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *service processor* then click on **OK**.
- Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *network node processor* then click on **OK**.
- The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed with a message for waiting (Installation duration is about 30 minutes).
- When installation is complete a message warns you to remove the **Network Node Processor Diskette Installation** from the *network node processor* then click on **OK**.
- A new message indicates that the "Network Node Processor LIC Restoration, Operation Successfully Completed", click on **OK**.
- The **3746-900/NNP Licensed Internal Code (LIC)** is displayed, click on **Close** to return to the **MOSS-E View** window.
- Power OFF then power ON the *network node processor*.

**Is the problem solved?**

Yes No

**006**

Go to Step 008.

**007**

Go to "CE Leaving Procedure" on page 5-47.

---

**008**

(Step **008** continues)

008 (continued)

Do you have the same code displayed on the network node processor control panel?

Yes No

009

Restart the problem determination.

010

Call your support

---

011

Return on the *service processor* console to display the alarms, using the following procedure:

- Return to the **MOSS-E View** window.
  - Double click on the **Service Processor** icon.
  - On the **Service Processor Menu** click on the **Problem Management** option.
  - Click on the **Display Alarms** option.
  - On the screen displayed look for the alarm text related to the network node processor which explains the problem. Correct it.
-



## MAP: Problem Determination on Network Node Processor Based on 7585

You are here because you suspected

- A network node processor problem
- A connection problem between the network node processor and a 3746-900 or a 3746-950.




Figure 3-3. LAN attached to the Service Processor

### Notes:

1. The network node processor is an optional feature which is present only when APPN is installed. A backup network node processor can be also present. Until four network node processors can be installed on the same LAN.
2. Up to two service processor access units (8228) can be used depending on the number of network node processor used.
3. Only 3745, 3746-900, 3746-950, service processor and network node processor can be connected to the LAN when APPN is installed.

### Important

To continue this procedure you must have a display and keyboard connected to the network node processor Refer to "How to Install a Display and Keyboard on your Network Node Processor" on page 3-18.

### 001

Switch OFF the network node processor, then after few seconds, switch ON the network node processor.

(Step 001 continues)

001 (continued)

**Is there something displayed on the network node processor attached display?**

Yes No

002

Go to "MAP: 7585 Network Node Processor Troubleshooting" on page 5-2.

003

**Is the service processor IML complete with MOSS-E View window displayed?**

Yes No

004

**Is there a message SYSxx-xxxxx (OS/2 message) displayed on screen?**

Yes No

005

Go to "MAP: 7585 Network Node Processor Troubleshooting" on page 5-2.

006

Call support for assistance.

---

007

**Is the keyboard locked?**

Yes No

008

Go to Step 012 on page 3-17.

009

- Check that the keyboard cable is properly plugged into the keyboard and into the rear of the service processor.

**Do you find the problem?**

Yes No

010

Replace the system board. Go to "FRU Exchange on Network Node Processor Based on 7585" on page 5-34

011

(Step 011 continues)

**011** (continued)

Go to Step 012.

---

**012**

- Check that the service processor LAN cable is correctly connected at the rear of the service processor and in the service processor access unit.
- Check that all the LAN cables are correctly connected in the service processor access unit.

**Did you find the problem?**

**Yes No**

**013**

- Run diagnostics on the service processor, go to “How to Run the 7585 Network Node Processor Diagnostics” on page 5-32 to identify the problem. Then if you have to exchange a FRU, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.

**014**

Problem solved go to “CE Leaving Procedure” on page 5-47.

---

## How to Install a Display and Keyboard on your Network Node Processor

- 1** Have a display and keyboard.
- 2** Power OFF the network node processor.
- 3** Connect the display and keyboard at the rear of the network node processor.




Figure 3-4. How to Connect the Display and the Keyboard on Network Node Processor

- 4** Connect the display power cable to a known working ac source.
- 5** Power ON the network node processor and the display.
- 6** Return to the procedure where you came from.

## Chapter 4. Network Node Processor Based on 3172

### Important

The procedures described here are only for network node processor with Pentium\* processor card.

### FRU Exchange on Network Node Processor Based on 3172

You are here to exchange a FRU on the network node processor.

Before any FRU exchange, you must remove the network node processor from the rack following the above procedure:

- 1 Locate the network node processor in the rack processor using Figure 4-1.
- 2 Switch OFF the network node processor using its power ON/OFF switch located on the front panel.




Figure 4-1. IBM Controller Rack Locations

- 3 On the rear of the network node processor disconnect all the cables.




Figure 4-2. Network Node Processor Cables

- 4 Slide out the network node processor from the rack and install it on a table to continue the FRUs removal.

**Warning**

Be careful the weight of the processor is about 19 kg.

- 5 Use the following table to find the procedure you need to follow to exchange a FRU.

Network Node Processor FRU to Exchange	Action
LAN Adapter XGA Adapter SCSI	Go to "Adapter Card Exchange Procedure on NNP Based on 3172" on page 4-4 for FRU replacement, then <b>return here</b> and continue with 6.
Other FRU	Go to the <i>3172 Interconnect Controller Maintenance Information Model 3, SY27-0334</i> manual chapter <i>Repairing the 3172 Model 3</i> for FRU replacement, then <b>return here</b> and continue with 6.

- 6 For setting up the Network Node Processor after FRU exchange use the following steps:


- a** Re-install all the covers of the processor.
- b** Slide the processor into the rack.
- c** At the rear of the network node processor re-connect all the cable previously removed (see Figure 4-2 on page 4-2).
- d** Some FRUs of the processor need and additional procedure after exchanging. Use the following table to find the MAP you need to follow, according to the FRU that you are exchanging.

<b>Network Node Processor FRU to Exchange</b>	<b>Action</b>
<b>System Board Battery</b>	Go to "Procedure after System Board or Battery Exchange on NNP Based on 3172" on page 4-19
<b>Hard Disk Drive</b>	Go to "Procedure after Hard Disk Drive Exchange on NNP Based on 3172" on page 4-11
<b>LAN Adapter</b>	Go to "Procedure After LAN Adapter Exchange on NNP Based on 3172" on page 4-9
<b>Processor Card</b>	Go to "Procedure after Processor Card exchange on NNP Based on 3172" on page 4-14
<b>SCSI Card</b>	Go to "Procedure after SCSI Card Exchange on NNP Based on 3172" on page 4-17
<b>Other FRUs</b>	Go to "Procedure after Other FRUs Exchange on NNP Based on 3172" on page 4-21

# Adapter Card Exchange Procedure on NNP Based on 3172

## Removing Adapter


- 1 Locate the adapter that you want to exchange.




Card	Slot Location
<i>XGA Adapter</i>	Slot 5
<i>LAN Adapter</i>	Slot 7
<i>SCSI</i>	Slot 8

- 2 Remove the top cover
  - a. Loosen the quarter-turn fasteners on the top of the processor.
  - b. Hold the edges of the top and lift up.
  - c. As you remove the top, note the position of the plastic baffle attached to the inside surface. You must reinstall the top so that the baffle covers the left side of the processor.
- 3 To loosen the left side piece.
  - a. Loosen, but not remove, the four screws with a screwdriver.
  - b. Holding the top of the sidepiece with both hands, lift straight up.






- 4** Locate the adapter retainer bracket, and remove the two screws from the front adapter retainer bracket and raise the bracket.



- 5** Loosen the retainer screw on the adapter you want to remove.
- 6** Pull the adapter firmly with both hands.


## Installing Adapter

- 1 Slide the adapter down the back of the base unit, above the card socket you intend to use, until the notch on the bottom of the card retainer straddles the retainer screw.




RearView

- 2 Align the separator notch on the edge connector of the adapter with the separator in the card socket.



- 3** Press the adapter into the notch at the bottom of the front retainer bracket.
- 4** Press the adapter firmly into the card socket.
- 5** Tighten the adapter retainer screw with your fingers.
- 6** Secure the front retainer bracket with its two screws.
- 7** Reinstall the sidepiece of the cover:
  - a. Hold the sidepiece so that the clips are on the bottom.
  - b. Slide the sidepiece down, so that the lips on the sides of the processor are between the sidepiece and the clamps on the cover.



- c. Make sure that the clips on the bottom of the sidepiece are attached firmly to the lip on the bottom of the processor.
- d. Tighten the four retainer screws with a screwdriver to clamp the side firmly.

**8** Reinstall the top of the cover:

- a. Position the top so that the plastic baffle is inside the top on the left as you face the front of the processor.
- b. Slide the top down, placing the top so that its edges overlap the top edges of the sidepiece.
- c. Tighten the four retainer screws with a screwdriver.

**9** Return and continue with step **6** on page **4-2** .

# Procedure After LAN Adapter Exchange on NNP Based on 3172

You are here after exchanging the LAN adapter card.

The default adapter data rate and the default RAM size must be changed using the following procedure.

- 1** Insert the **Reference Diskette A** in the network node processor.
- 2** Power ON the network node processor.
- 3** The following list provides the sequence of code when the network node processor reconfigures. Temporary errors will be displayed (code displayed on the operator panel with error LED ON). Press **Enter** on the operator panel keypad after each code appears.

<b>Code</b>	<b>Description</b>
<b>0000</b>	POST
<b>00A5</b>	Hardware configuration needed. Press <b>Enter</b> on the operator panel keypad.
<b>0000</b>	Loading the program
<b>ACF0</b>	Reconfiguration
<b>0000</b>	POST and loading the diagnostic programs
<b>1000</b>	Complete

- 4** Did **0000** appear, followed by **1000** within five minutes?

<b>Yes</b>	Continue with the step <b>5</b> .
<b>No</b>	A POST error occurred. Record the error code and refer to <i>3172 Interconnect Controller Status Codes, GA27-3951</i> to resolve the error.

- 5** Run the diagnostic tests on the LAN adapter card using the following steps:

**a** Before starting be sure that the LAN cable is:

- Connected on the rear of the LAN adapter card
- Disconnected from the service processor access unit.

**b** Key in **1**. **1001** appears.

**c** Press **Enter**. **d5Cb** appears.

**d** Remove **Reference Diskette A** and insert **Reference Diskette B**.

**e** Press **Enter**. **d5CC** appears.

**f** Remove **Reference Diskette B** and insert **Reference Diskette C**.

**g** Press **Enter**. After a short delay, **A000** appears.

**h** Key in **2**. **A002** appears.

**i** Press **Enter**. **bbbb** appears.

**j** Key in **00A6**.

**k** Press **Enter**. **71A6** appears. The test runs about 35 seconds.

**l** Did **A000** appear?

**Yes** Continue with the step **6** .

**No** **00A6** appears Check the LAN adapter card is well installed with its cable connected on the rear of the LAN adapter cable but not in the service processor access unit. Suspect the new LAN adapter card, contact your support.

**6** To exit, switch the power OFF (**O**) to the network node processor and remove the **Reference Diskette C**.

**7** Go to “CE Leaving Procedure” on page 5-47.

## Procedure after Hard Disk Drive Exchange on NNP Based on 3172

Reference Diskettes A, B, C are shipped with the network node processor.  
Use these diskettes to perform the following procedure.

**1** After disk drive exchange format the hard disk following these steps:

**a** Insert the **Reference Diskette A** in the network node processor.

**b** Power ON the network node processor.

**c** If temporary errors are displayed (code displayed on the operator panel with error LED ON), press **Enter** on the operator panel keypad.

Code	Description
0000	POST
XXXX	Temporary codes
0000	Loading the program
1000	Complete

**d** Did **0000** appear, followed by **1000** about 90 seconds later?

**Yes** Continue with the step **1e** .

**No** A POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes, GA27-3951* to resolve the error.

**e** Key in **2**. **1002** appears.

**f** Press **Enter**. **b000** appears.

**g** Key in **4**. **b000** appears.

**h** Press **Enter**. **b004** appears.

**i** Key in **F**. **b4FF** appears.

**j** To continue press **1**.

**k** Formatting proceeds for approximately 15 minutes. The **Channel 2 Online** indicator is lit and **0000** appears.

- The display is updated every 5 seconds, showing the percentage of the fixed disk that is formatted.
- When formatting is complete, the network node processor restarts.

**l** **1000** appears.

**2** Run the diagnostic tests on the hard disk drive using the following steps:

**a** Key in **1**. **1001** appears.

**b** Press **Enter**. **d5Cb** appears.

**c** Remove **Reference Diskette A** and insert **Reference Diskette B**.

**d** Press **Enter**. **d5CC** appears.

**e** Remove **Reference Diskette B** and insert **Reference Diskette C**.

**f** Press **Enter**. After a short delay, **A000** appears.

**g** Key in **2**. **A002** appears.

**h** Press **Enter**. **bbbb** appears.

**i** Key in **0070**.

**j** Press **Enter**. **0070** appears and the **Channel 2 Online** indicator is lit. The test runs about two minutes.

**k** Did **A000** appear?

**Yes** Continue with the step **2l**.

**No** Go to *3172 Interconnect Controller Maintenance Information Model 3, SY27-0334* for disk adapter problem investigation.

**l** Key in **2**. **A002** appears.

**m** Press **Enter**. **bbbb** appears.

**n** Key in **00d2**.

**o** Press **Enter**. **00d2** appears and the **Channel 2 Online** indicator is lit. The test run about two minutes.

**p** Did **A000** appear?

**Yes** Continue with the step **3**.

**No** Suspect the Disk that you have installed. Go to *3172 Interconnect Controller Maintenance Information Model 3, SY27-0334* for disk problem investigation.

**3** Power OFF the network node processor

**4** Remove the **Reference Diskette C** from the drive A.

**5** Power ON the network node processor **FEd7** code is displayed (No operating system found).

**6** Return on the *service processor* console to load the licensed internal code on the NNP, using the following procedure:

**a** Return to the **MOSS-E View** window.

**b** Double click on the **3746-950** icon.

**c** On the **3746-900 Menu** select the **Network Node Processor (NNP) Management** option.

**d** On the **Network Node Processor (NNP) management** window double click on the **Install/change/Restore LIC/NNP** option.



- e** The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed.
  - f** Select the NNP (A or B), then click on **Restore LIC on NNP**
  - g** On the following window click on **OK**
  - h** Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *service processor* then click on **OK**.
  - i** Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *network node processor* then click on **OK**.
  - j** The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed with a message for waiting (Installation duration is about 30 minutes).
  - k** When installation is complete a message warns you to remove the **Network Node Processor Diskette Installation** from the *network node processor* then click on **OK**.
  - l** A new message indicates that the "NNP LIC Restoration, Operation Successfully Completed", click on **OK**.
  - m** The **3746-900/NNP Licensed Internal Code (LIC)** is displayed, click on **Close** to return to the **MOSS-E View** window.
- 7** Is **0000** displayed on the *network node processor* operator panel?
- Yes**        Go to "CE Leaving Procedure" on page 5-47.
  - No**         See the alarm logged on the *service processor*

## Procedure after Processor Card exchange on NNP Based on 3172

You are here to reconfigure the network node processor after processor card exchange.

- 1** Insert the **Reference Diskette A** in the network node processor.
- 2** Power ON the network node processor.
- 3** The following list provides the sequence of code when the network node processor reconfigures. Temporary errors will be displayed (code displayed on the operator panel with error LED ON). Press **Enter** on the operator panel keypad after each code appears.

<b>Code</b>	<b>Description</b>
<b>0000</b>	POST
<b>ACF0</b>	Appears when the network node processor is being reconfigured.
<b>0000</b>	Loading the program
<b>1000</b>	Complete

- 4** Did **0000** appear, followed by **1000** within five minutes?
  - Yes** Continue with the Step **5** .
  - No** If a POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes*, GA27-3951 to resolve the error. If the configuration loop go to Step **17 on page 4-16** to boot first with the **Update BIOS** diskette, then continue with Step **1**

- 5** Did you have a **00A3** error code?
  - Yes** Continue with the step **6** .
  - No** Continue with the step **12 on page 4-15** .

**6** Key in **2**. **1002** appears.

**7** Press **Enter**. **b000** appears.

**8** Key in **1**. **b001** appears.

**9** Press **Enter**. **b100** appears and no indicators are lit.

**10** To set the date, follow these steps:

**a** Key in **3**. **b103** appears.

**b** Press **Enter**. **AAbb** appears and the **Channel 1 Online** indicator is lit.

**c** Key in the month and the day: for example, **0131** for January 31.

**d** Press **Enter**. **CCCC** appears.

**e** Key in the year: for example, **1991** for the year 1991.

**f** Press **Enter**.

**g** Does **AAbb** appear?

- Yes** The date is not valid. return to step **10c** .  
**No** **b100** appears and the **Channel 1 Online** indicator is not lit.  
Continue with step **11** .

**11** To set the time, follow these steps:

- a** Key in **4**. **b104** appears.
- b** Press **Enter**. **dddd** appears and the **Channel 1 Online** indicator is lit.
- c** Key in the time in the 24-hour format: for example, **1330** for 1:30p.m.
- d** Press **Enter**.
- e** Does **dddd** appear?

- Yes** The time is not valid. return to step **11c** .  
**No** **b100** appears and the **Channel 1 Online** indicator is not lit.  
Continue with step **12** .

**12** Switch OFF the network node processor

**13** Power ON the network node processor.

**14** Wait POST and loading program until

**15** Did **0000** appear, followed by **1000** about 90 seconds later?

- Yes** Continue with the step **16** .  
**No** A POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes, GA27-3951* to resolve the error.

**16** Run the diagnostic tests on the processor card using the following steps:

- a** Key in **1**. **1001** appears.
- b** Press **Enter**. **d5Cb** appears.
- c** Remove **Reference Diskette A** and insert **Reference Diskette B**.
- d** Press **Enter**. **d5CC** appears.
- e** Remove **Reference Diskette B** and insert **Reference Diskette C**.
- f** Press **Enter**. After a short delay, **A000** appears.
- g** Key in **2**. **A002** appears.
- h** Press **Enter**. **bbbb** appears.
- i** Key in **0000** and press **Enter** to test the processor board.
- j** Did **A000** appear?

- Yes** Continue with the step **17 on page 4-16** .

**No** Suspect another problem. Refer to the chapter **Maintenance Analysis Procedures** in the *3172 Interconnect Controller Maintenance Information Model 3*, SY27-0334

**17** Run the update POST Utility following these steps:

- a** Switch OFF the network node processor.
- b** Remove the **Reference Diskette C**.
- c** Insert the **Update POST** diskette.
- d** Switch ON the network node processor.
- e** **dc03** appears when the utility is running.
- f** When the update is complete **dc04** appears.
- g** Switch OFF the network node processor and remove the diskette.

**18** Go to “CE Leaving Procedure” on page 5-47.

## Procedure after SCSI Card Exchange on NNP Based on 3172

You are here to test the SCSI card after exchanging.

- 1** Insert the **Reference Diskette A** in the network node processor.
- 2** Power ON the network node processor.
- 3** If temporary errors are displayed (code displayed on the operator panel with error LED ON), press **Enter** on the operator panel keypad.

Code	Description
0000	POST
XXXX	Temporary codes
0000	Loading the program
1000	Complete

- 4** Did **0000** appear, followed by **1000** about 90 seconds later?
  - Yes** Continue with the step **5** .
  - No** A POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes, GA27-3951* to resolve the error.

- 5** Run the diagnostic tests on the hard disk drive using the following steps:

**a** Key in **1**. **1001** appears.

**b** Press **Enter**. **d5Cb** appears.

**c** Remove **Reference Diskette A** and insert **Reference Diskette B**.

**d** Press **Enter**. **d5CC** appears.

**e** Remove **Reference Diskette B** and insert **Reference Diskette C**.

**f** Press **Enter**. After a short delay, **A000** appears.

**g** Key in **2**. **A002** appears.

**h** Press **Enter**. **bbbb** appears.

**i** Key in **0070**.

**j** Press **Enter**. **0070** appears and the **Channel 2 Online** indicator is lit. The test runs about two minutes.

**k** Did **A000** appear?

**Yes** Continue with the step **5l** .

**No** Go to *3172 Interconnect Controller Maintenance Information Model 3, SY27-0334* for disk adapter problem investigation.

**l** Key in **2**. **A002** appears.

**m** Press **Enter**. **bbbb** appears.

**n** Key in **00d2**.

**o** Press **Enter**. **00d2** appears and the **Channel 2 Online** indicator is lit.  
The test run about two minutes.

**p** Did **A000** appear?

**Yes** Continue with the step **6** .

**No** Suspect a disk problem. Go to *3172 Interconnect Controller Maintenance Information Model 3, SY27-0334* for disk problem investigation.

**6** Switch OFF the network node processor.

**7** Remove the **Reference Diskette C** from the drive A.

**8** Go to “CE Leaving Procedure” on page 5-47.

## Procedure after System Board or Battery Exchange on NNP Based on 3172

You are here to reconfigure the network node processor after battery exchange.

- 1** Insert the **Reference Diskette A** in the network node processor.
- 2** Power ON the network node processor.
- 3** The following list provides the sequence of code when the network node processor reconfigures. Temporary errors will be displayed (code displayed on the operator panel with error LED ON). Press **Enter** on the operator panel keypad after each error code appears.

<b>Code</b>	<b>Description</b>
<b>0000</b>	POST
<b>00Ad</b>	Hardware configuration needed. Press <b>Enter</b> on the operator panel keypad.
<b>00A3</b>	Date and time not set. Press <b>Enter</b> on the operator panel keypad.
<b>0000</b>	Loading the program
<b>ACF0</b>	Reconfiguration
<b>1000</b>	Complete

- 4** Did **0000** appear, followed by **1000** within five minutes?
  - Yes** Continue with the step **5** .
  - No** A POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes, GA27-3951* to resolve the error.
- 5** Key in **2**. **1002** appears.
- 6** Press **Enter**. **b000** appears.
- 7** Key in **1**. **b001** appears.
- 8** Press **Enter**. **b100** appears and no indicators are lit.
- 9** To set the date, follow these steps:
  - a** Key in **3**. **b103** appears.
  - b** Press **Enter**. **AAbb** appears and the **Channel 1 Online** indicator is lit.
  - c** Key in the month and the day: for example, **0131** for January 31.
  - d** Press **Enter**. **CCCC** appears.
  - e** Key in the year: for example, **1991** for the year 1991.
  - f** Press **Enter**.
  - g** Does **AAbb** appear?
    - Yes** The date is not valid. return to step **9c** .

**No**            **b100** appears and the **Channel 1 Online** indicator is not lit.  
Continue with step **10 on page 4-20** .

**10** To set the time, follow these steps:

**a** Key in **4**. **b104** appears.

**b** Press **Enter**. **dddd** appears and the **Channel 1 Online** indicator is lit.

**c** Key in the time in the 24-hour format: for example, **1330** for 1:30p.m.

**d** Press **Enter**.

**e** Does **dddd** appear?

**Yes**            The time is not valid. return to step **10c** .

**No**             **b100** appears and the **Channel 1 Online** indicator is not lit.  
Continue with step **11** .

**11** To exit, switch the power OFF (**O**) to the network node processor and remove the **Reference Diskette A**.

**12** Go to "CE Leaving Procedure" on page 5-47.



## Procedure after Other FRUs Exchange on NNP Based on 3172

**1** Did you change the **operator panel**, the **diskette drive**, or the **power supply**?

**Yes**            Go to step **2** .

**No**             Go to “CE Leaving Procedure” on page 5-47.

**2** Refer to the *3172 Interconnect Controller Model 3 and Model 390 Diagnostics Guide*, GA27-4063 manual, and run tests on the components or on all components of the network node processor.

**3** Is the diagnostic error free?

**Yes**            Go to “CE Leaving Procedure” on page 5-47.

**No**             Follow the recommended action in the *3172 Interconnect Controller Model 3 and Model 390 Diagnostics Guide*, GA27-4063 manual.



---

## Chapter 5. Network Node Processor Based on 7585

MAP: 7585 Network Node Processor Troubleshooting	5-2
BEEP CODE INDEX	5-21
Display	5-23
Keyboard	5-24
Printer	5-24
Power-Supply Voltage Check (7585)	5-25
Power Voltage Setting	5-25
Undetermined Problems	5-26
Before Replacing a System Board	5-26
Devices List	5-27
RAM Memory Modules (SIMMs/DIMMs)	5-28
Memory Test	5-29
How to Run the 7585 Network Node Processor Diagnostics	5-32
FRU Exchange on Network Node Processor Based on 7585	5-34
Procedure After Board or Battery Exchange on NNP Based on 7585	5-36
Procedure After LAN Adapter Exchange on NNP Based on 7585	5-38
Procedure After Hard Disk Drive Exchange on NNP Based on 7585	5-43
Procedure After Other FRU Exchange on NNP Based on 7585	5-46
CE Leaving Procedure	5-47

## MAP: 7585 Network Node Processor Troubleshooting

### Note about POST error code

The zeros before and after the error code may be not present for some PS/2 models. Messages might appear on your screen as three-, four-, or five-character messages. When this occurs, add two zeros after the last character and one, two, or three zeros before the first character, so that you can look up the error as an eight-character message.

Example:

**101** displayed means 00010100

**1701** displayed means 00170100

**16680** displayed means 01668000

### Notes:

1. If you have both an error message and an incorrect audio response, diagnose the error message first.
2. If you cannot run the diagnostic tests, but did receive a POST error message, diagnose the POST error message.
3. If you did not receive any error message, look for a description of your error symptoms in the first part of this index.
4. Check all power supply voltages before you replace the system board. (See "Power-Supply Voltage Check (7585)" on page 5-25)
5. Check the hard disk drive jumper settings before you replace a hard disk drive. All supported hard disk drives use jumpers or tabs to set drives as either primary or secondary. Refer to the jumper instructions that came with your hard disk drives.

### Important

- Some errors are indicated with a series of beep codes. See "BEEP CODE INDEX" on page 5-21 for an explanation of the beep codes.
- For all system boards, the processor is a separate FRU from the system board; that is, the processor is not included with the system board FRU. See "Before Replacing a System Board" on page 5-26 before replacing the system board.

### 001

- Power-off the system.
- Check all cables and power cords.
- Make sure there are no diskettes in the drives.
- Set all display controls to the middle position.
- Power-on the system.

**Note:** If you get a POST error code, press the pause key (while the error code is on the screen). Write down any error codes that are displayed, then press F1 to continue.

(Step **001** continues)

001 (continued)

**DID YOU RECEIVE A POST ERROR CODE?**

Yes No

002

Go to Step 006 on page 5-14

003

**Check your FIRST POST ERROR with the following list.**

Symptom / Error	FRU / Action
<b>000</b> SCSI Adapter not enabled.	<b>Be sure adapter device and Bus Master fields are enabled in PCI configuration program. See documentation shipped with computer.</b>
<b>02X</b>	<b>SCSI Adapter</b>
<b>08X</b> Check SCSI terminator installation.	<b>SCSI Cable</b> SCSI Terminator SCSI Device SCSI Adapter
<b>101</b> Interrupt failure.	<b>System Board</b>
<b>102</b> Timer error.	<b>System Board</b>
<b>106</b>	<b>System Board</b>
<b>110</b> System board parity error.	<b>Memory Module</b> System Board
<b>111</b> I/O channel parity error.	<b>Reseat adapters</b> Any Adapter System Board
<b>114</b> External ROM checksum error.	<b>Memory Module</b> System Board
<b>129</b> Internal cache test error.	<b>Processor</b> L2 Cache Memory System Board
<b>151</b> Real-time clock failure.	<b>System Board</b>
<b>161</b> Bad CMOS battery.	<b>Run Configuration/Setup Utility</b> Clock Battery System Board
<b>162</b> And unable to run diagnostics.	<b>Diskette Drive</b> System Board Diskette Drive Cable
<b>162</b>	<b>Run Setup</b> Clock Battery System Board

**MAP (continued)**

<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>163</b> Clock not updating or invalid time set.	<b>Time and Date Set?</b> Clock Battery System Board
<b>164</b> POST detected a base memory or extended memory size mismatch error.	<b>Run Configuration/Setup Utility</b> See "RAM Memory Modules (SIMMs/DIMMs)" on page 5-28. System Board
<b>17X, 18X</b>	<b>C2 Security</b>
<b>175</b>	<b>Riser Card</b> System Board
<b>176</b>	<b>Covers were removed from the computer</b>
<b>177</b> Corrupted Administrator Password.	<b>Riser Card</b> System Board
<b>178</b>	<b>Riser Card</b> System Board
<b>183</b>	<b>Enter the administrator password</b>
<b>184</b> Password removed due to check-sum error.	<b>Enter new password</b>
<b>185</b> Corrupted boot sequence.	<b>Set configuration and reinstall the boot sequence</b>
<b>186</b>	<b>Riser Card</b> System Board
<b>189</b>	<b>More than three password attempts were made to access the computer</b>
<b>199</b>	<b>See "Devices List" on page 5-27</b>
<b>1XX</b> Not listed above.	<b>System Board</b>
<b>201</b> Memory data error.	<b>Memory Module</b> System Board
<b>225</b>	<b>Unsupported Memory</b>
<b>229</b> External cache test error.	<b>L2 Cache Memory</b> System Board
<b>2XX</b>	<b>See "RAM Memory Modules (SIMMs/DIMMs)" on page 5-28</b> Memory Module System Board
<b>301</b>	<b>Keyboard</b> Keyboard Cable System Board
<b>303</b> With an 8603 error.	<b>Mouse</b> Keyboard Keyboard Cable System Board
<b>303</b> With no 8603 error.	<b>Keyboard</b> Keyboard Cable System Board

<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>305</b>	<b>System Board</b> Keyboard Keyboard Cable Mouse
<b>3XX</b> Not listed above.	<b>Keyboard</b> Keyboard Cable System Board
<b>5XX</b>	<b>Display Adapter</b> (if installed) System Board
<b>601</b>	<b>Diskette Drive A</b> Diskette Drive Cable System Board
<b>604</b> And unable to run diagnostics.	<b>Diskette Drive A</b> Diskette Drive Cable System Board
<b>604</b> And able to run diagnostics.	<b>Diskette Drive B</b> Diskette Drive Cable System Board
<b>605</b> POST cannot unlock the diskette drive.	<b>Diskette Drive</b> Diskette Drive Cable System Board
<b>662</b>	<b>Diskette drive configuration error or wrong diskette drive type</b>
<b>663</b>	<b>Wrong media type</b>
<b>6XX</b> Not listed above.	<b>Diskette Drive</b> System Board External Drive Adapter Diskette Drive Cable Power Supply
<b>762</b> Math coprocessor configuration error.	<b>Run Setup</b> Math Coprocessor System Board
<b>7XX</b> Not listed above.	<b>Math Coprocessor</b> System Board
<b>962</b> Parallel port configuration error.	<b>Run Configuration</b> Parallel Adapter (if installed) System Board
<b>9XX</b>	<b>Printer</b> System Board
<b>1047</b>	<b>16-Bit AT Fast SCSI Adapter</b>
<b>10XX</b> (where X is not equal to digits above)	<b>Alternate Parallel Adapter</b> Riser Card
<b>107X</b> Check SCSI terminator installation.	<b>Check SCSI terminator installation.</b> SCSI Cable SCSI Terminator SCSI Device SCSI Adapter

**MAP (continued)**

<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>1101</b> Serial connector error, possible system board failure.	<b>Run Advanced Diagnostics</b>
<b>1101, 1102, 1106, 1108, 1109</b>	<b>System Board</b> Any Serial Device
<b>1107</b>	<b>Communications Cable</b> System Board
<b>1102</b> Card selected feedback error.	<b>Run Advanced Diagnostics</b>
<b>1103</b> Port fails register check.	<b>Run Advanced Diagnostics</b> System Board
<b>1106</b> Serial option cannot be turned off.	<b>Run Advanced Diagnostics</b> System Board
<b>1107</b>	<b>Serial Device Cable</b> System Board
<b>1110</b> Register test failed.	<b>Run Advanced Diagnostics</b> System Board
<b>1116</b> Interrupt error.	<b>Run Advanced Diagnostics</b>
<b>1117</b> Failed baud rate test.	<b>Run Advanced Diagnostics</b>
<b>1162</b> Serial port configuration error.	<b>Run Configuration</b> Serial Adapter (if installed) System Board
<b>11XX</b> Not listed above.	<b>System Board</b>
<b>1201</b>	<b>System Board</b> Any Serial Device
<b>1202, 1206, 1208, 1209, 12XX</b>	<b>Dual Async Adapter/A</b> System Board Any Serial Device
<b>12XX</b>	<b>Alternate Serial Adapter</b> Riser Card
<b>1207</b>	<b>Communications Cable</b> Dual Async Adapter/A
<b>13XX</b>	<b>Game Control Adapter</b> Riser Card
<b>1402</b> Printer not ready.	Information only
<b>1403</b> No-paper error, or interrupt failure.	Information only
<b>1404</b> System board timeout failure.	<b>Run Advanced Diagnostics</b>
<b>1405</b> Parallel adapter error.	<b>Run Advanced Diagnostics</b>
<b>1406</b> Presence test error.	<b>Run Advanced Diagnostics</b>



<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>14XX</b> Not listed above. Check printer before replacing system board.	<b>See “Printer” on page 5-24</b> System Board
<b>15XX</b>	<b>SDLC Adapter</b> Riser Card
<b>1692</b> Boot sequence error.	<b>Run FDISK to ensure at least one active partition is set active</b>
<b>16XX</b>	<b>36/38 Workstation Adapter</b>
<b>1762</b> Hard disk drive configuration error.	<b>Run Configuration/Setup Utility</b>
<b>1780</b> (Disk Drive 0) <b>1781</b> (Disk Drive 1) <b>1782</b> (Disk Drive 2) <b>1783</b> (Disk Drive 3)	<b>See “Power-Supply Voltage Check (7585)” on page 5-25</b> System Board Hard Disk Drive Hard Disk Cable Power Supply
<b>1962</b> Boot sequence error.	<b>Possible hard disk drive problem</b>
<b>209X</b>	<b>Diskette Drive</b> Diskette Cable 16-bit AT Fast SCSI Adapter
<b>20XX</b> Not listed above	<b>BSC Adapter</b> Riser Card
<b>21XX</b>	<b>SCSI Device</b> 16-bit AT Fast SCSI Adapter Alternate BSC Adapter Riser Card
<b>2401, 2402</b> If screen colors change.	<b>Display</b>
<b>2401, 2402</b> If screen colors are OK.	<b>System Board</b> Display
<b>2409</b>	<b>Display</b>
<b>2410</b>	<b>System Board</b> Display
<b>2462</b> Video memory configuration error.	<b>Run Configuration</b> Video Memory Modules Video Adapter (if installed) System Board
<b>3015, 3040</b> Check for missing wrap or terminator plug on the adapter.	<b>Network Attached?</b> LF Translator Cable Problem PC Network Adapter Riser Card
<b>30XX</b>	<b>PC Network Adapter</b> LF Translator Cable Problem? Riser Card

MAP (continued)

Symptom / Error	FRU / Action
3115, 3140	<b>Network Attached?</b> LF Translator Alternate PC Network-Adapter Cable Problem Riser Card
31XX	<b>Alternate PC Network Adapter</b> LF Translator Cable Problem? Riser Card
36XX	<b>GPIB Adapter</b> Riser Card
38XX	<b>DAC Adapter</b> Riser Card
4611, 4630	<b>Multiport/2 Interface Board</b> Multiport/2 Adapter
4612, 4613 4640, 4641	<b>Memory Module Package</b> Multiport/2 Adapter
4650	<b>Multiport Interface Cable</b>
46XX Not listed above.	<b>Multiport/2 Adapter</b> Multiport/2 Interface Board Memory Module
5600	<b>Financial System Controller Adapter</b>
5962 CD-ROM configuration error.	<b>Run Configuration</b> CD-ROM Drive CD-ROM Adapter System Board
62XX	<b>1st Store Loop Adapter</b> Adapter Cable
63XX	<b>2nd Store Loop Adapter</b> Adapter Cable
64XX	<b>Network Adapter</b>
71XX	<b>Voice Adapter</b>
74XX	<b>Display Adapter</b> (if installed) Riser Card
76XX	<b>Page Printer Adapter</b>
78XX	<b>High Speed Adapter</b>
79XX	<b>3117 Adapter</b>
80XX	<b>PCMCIA Adapter</b>
84XX	<b>Speech Adapter</b> Speech Control Assembly Riser Card
8601, 8602	<b>Pointing Device</b> (Mouse) System Board
8603, 8604	<b>System Board</b> Pointing Device (Mouse)

Symptom / Error	FRU / Action
<b>86XX</b> Not listed above	<b>Mouse</b> System Board
<b>89XX</b>	<b>PC Music Adapter</b> MIDI Adapter Unit Riser Card
<b>91XX</b>	<b>Optical Drive</b> Adapter
<b>96XX</b>	<b>SCSI Adapter</b> Any SCSI Device System Board
<b>10101, 10102, 10104</b> <b>10105, 10106, 10107</b> <b>10108, 10109, 10111</b> <b>10112, 10113, 10114</b> <b>10115, 10116</b>	<b>Have customer verify correct operating system device drivers are installed and operational</b> Modem
<b>10103, 10110, 101171</b>	<b>System Board</b> Data/Fax Modem
<b>10117</b> Not listed above.	<b>Check system speaker</b> Check PSTN cable External DAA (if installed) Modem
<b>10118</b>	<b>Run Diagnostics and verify the correct operation of the modem slot</b> Modem
<b>10119</b>	<b>Diagnostics detected a non-IBM modem</b> Modem
<b>10120</b>	<b>Check PSTN Cable</b> External DAA (if installed) Modem
<b>10132, 10133, 10134</b> <b>10135, 10136, 10137</b> <b>10138, 10139, 10140</b> <b>10141, 10142, 10143</b> <b>10144, 10145, 10146</b> <b>10147, 10148, 10149</b> <b>10150, 10151, 10152</b>	<b>Modem</b>
<b>10153</b>	<b>Data/Fax Modem</b> System Board
<b>101XX</b> Not listed above.	<b>Modem Adapter/A</b> Data/Fax Modem System Board
<b>10450, 10451, 10490</b> <b>10491, 10492, 10499</b> Read/write error.	<b>Run Advanced Diagnostics</b> Riser Card Hard Disk Drive System Board
<b>10452</b> Seek test error.	<b>Run Advanced Diagnostics</b>
<b>10453</b> Wrong drive type?	Information only

## MAP (continued)

Symptom / Error	FRU / Action
<b>10454</b> Sector buffer test error.	<b>Run Advanced Diagnostics</b>
<b>10455, 10456</b> Controller error.	<b>Run Advanced Diagnostics</b>
<b>10459</b> Drive diagnostic command error.	Information only
<b>10461</b> Drive format error	<b>Run Advanced Diagnostics</b>
<b>10462</b> Controller seek error.	<b>Run Advanced Diagnostics</b>
<b>10464</b> Hard Drive read error.	<b>Run Advanced Diagnostics</b>
<b>10467</b> Drive non-fatal seek error.	<b>Run Advanced Diagnostics</b>
<b>10468</b> Drive fatal seek error.	<b>Run Advanced Diagnostics</b>
<b>10469</b> Drive soft error count exceeded.	<b>Run Advanced Diagnostics</b>
<b>10470, 10471, 10472</b> Controller wrap error.	<b>Run Advanced Diagnostics</b>
<b>10473</b> Corrupt data. Low-level format might be required.	Information only
<b>10480</b>	<b>Hard Disk Drive (ESDI)</b> Drive Cable System Board
<b>10481</b> ESDI drive D seek error.	<b>Run Advanced Diagnostics</b>
<b>10482</b> Drive select acknowledgement bad.	<b>Run Advanced Diagnostics</b>
<b>106X1</b>	<b>Check Configuration</b> Ethernet Adapter
<b>10635</b>	<b>Power-off computer, wait ten seconds, then power-on the computer</b> Ethernet Adapter
<b>10651, 10660</b>	<b>Check Cables</b> Ethernet Adapter
<b>106XX</b> Not listed above.	<b>Ethernet Adapter</b>
<b>107XX</b>	<b>5.25-inch External Diskette Drive</b> 5.25-inch Diskette Drive Adapter/A
<b>109XX</b> Check the adapter cables.	<b>ActionMedia Adapter/A</b> System Board
<b>112XX</b> This adapter does not have cache.	<b>SCSI Adapter</b> Any SCSI Device System Board
<b>119XX</b>	<b>3119 Adapter</b>

Symptom / Error	FRU / Action
121XX	<b>Modem Adapter</b> Any Serial Device System Board
12902	<b>Run Diagnostics</b> System Board
12904	<b>Run Diagnostics</b> System Board
136XX	<b>ISDN Primary Rate Adapter</b> System Board
137XX	<b>System Board</b>
141XX	<b>Realtime Interface Co-Processor Portmaster Adapter/A</b>
143XX	<b>Japanese Display Adapter</b> System Board
14710, 14711	<b>System Board Display Adapter</b> Adapter Video Memory
148XX	<b>Display Adapter</b>
14901, 14902 1491X, 14922	<b>Display Adapter</b> System Board Display (any type)
14932	<b>External Display</b> Display Adapter
16101	<b>Riser Card Battery</b>
161XX	<b>FaxConcentrator Adapter</b>
164XX	<b>120MB Internal Tape Drive</b> Diskette Cable System Board
16500	<b>6157 Tape Attachment Adapter</b>
16520, 16540	<b>6157 Streaming Tape Drive</b> 6157 Tape Attachment Adapter
166XX, 167XX	<b>Token Ring Adapter</b> System Board Riser Card
18001 to 18029	<b>Wizard Adapter</b> Wizard Adapter Memory
18031 to 18039	<b>Wizard Adapter Cable</b>
185XXXX	<b>DBCS Japanese Display Adapter/A</b> System Board
20001 to 20003	<b>Image Adapter/A</b> <b>Image-I Adapter/A</b> Memory Module DRAM, VRAM
20004	<b>Memory Module DRAM, VRAM</b> Image Adapter/A Image-I Adapter/A
20005 to 20010	<b>Image Adapter/A</b> <b>Image-I Adapter/A</b> Memory Module DRAM, VRAM

**MAP (continued)**

<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>200XX</b> Not listed above.	<b>Image Adapter/A</b> <b>Image-I Adapter/A</b> Memory Module DRAM, VRAM System Board
<b>20101 to 20103</b>	<b>Printer/Scanner Option</b> Image Adapter/A Memory Module DRAM, VRAM
<b>20104</b>	<b>Memory Module DRAM, VRAM</b> Printer/Scanner Option Image Adapter/A
<b>20105 to 20110</b>	<b>Printer/Scanner Option</b> Image Adapter/A Memory Module DRAM, VRAM
<b>206XX</b>	<b>SCSI-2 Adapter</b> Any SCSI Device System Board
<b>208XX</b> Verify there are no duplicate SCSI ID settings on the same bus.	<b>Any SCSI Device</b>
<b>210XXXX</b> Internal bus, size unknown. <b>210XXX1</b> External bus, size unknown.	<b>SCSI Hard Disk Drive</b> SCSI Adapter or System Board SCSI Cable SCSI ID Switch (on some models)
<b>212XX</b>	<b>SCSI Printer</b> Printer Cable
<b>213XX</b>	<b>SCSI Processor</b>
<b>214XX</b>	<b>WORM Drive</b>
<b>215XXXC</b> <b>215XXXD</b> <b>215XXXE</b> <b>215XXXU</b> If an external device and power-on LED is off, check external voltages.	<b>CD-ROM Drive I</b> <b>CD-ROM Drive II</b> <b>Enhanced CD-ROM Drive II</b> <b>Any CD-ROM Drive</b> SCSI Cable SCSI Adapter or System Board
<b>216XX</b>	<b>Scanner</b>
<b>217XX</b> If an external device and power-on LED is off, check external voltages.	<b>Rewritable Optical Drive</b> SCSI Adapter or System Board SCSI Cable
<b>218XX</b> Check for multi-CD tray, or juke box.	<b>Changer</b>
<b>219XX</b>	<b>SCSI Communications Device</b>
<b>24201Y0, 24210Y0</b> Be sure wrap plug is attached.	<b>ISDN/2 Adapter</b> ISDN/2 Wrap Plug ISDN/2 Communications Cable
<b>273XX</b>	<b>1M bps Micro Channel Infrared LAN Adapter</b>
<b>27501, 27503</b> <b>27506, 27507</b>	<b>ServerGuard Adapter</b> System Board

Symptom / Error	FRU / Action
27502, 27504, 27510 27511, 27533, 27534 27536, 27537	ServerGuard Adapter
27509	Remove redundant adapters, run Auto Configuration program, then retest
27512	WMSELF.DGS diagnostics file missing WMSELF.DGS diagnostics file incorrect.
27535	3V Lithium Backup Battery ServerGuard Adapter
27554	Internal Temperature out of range ServerGuard Adapter
27555, 27556	ServerGuard Adapter Power Supply
27557	7.2V NiCad Main Battery Pack ServerGuard Adapter
27558, 27559 27560, 27561	PCMCIA Type II Modem ServerGuard Adapter
27562	External Power Control not connected External Power Control ServerGuard Adapter
27563, 27564	External Power Control ServerGuard Adapter
275XX	Update Diagnostic Software
27801 to 27879	Personal Dictation System Adapter System Board
27880 to 27889	External FRU (Speaker, Microphone)
I9990301 Hard disk reset failure.	Possible hard disk drive problem
I9990305 No startable device found.	Reset computer from diskette, or check for valid startup sequence
I999XXXX There is an optional SCSI adapter installed.	SCSI Hard Disk Drive SCSI Adapter SCSI Cable

#### DID YOU FIND YOUR POST ERROR CODE IN THE LIST?

Yes No

004

#### ***Error Range Is Not Listed***

If the error code *range* presented is not listed in this index, it may be generated by a device that requires an additional service package. Refer to that service package.

005

(Step 005 continues)

005 (continued)

- **Action:**
  - **Change the FRU suspected**, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.
  - **or perform the specified action.**

**006**

Check your network node processor symptom with the following list.

**ERROR MESSAGE**

Symptom / Error	FRU / Action
<b>Address Exceeds the Size of Your Memory</b> An invalid memory address was entered. Diagnostics Tests display this message during the Locate Bad Chips option.	<b>Enter the correct address.</b> Memory Module System Board
<b>Arithmetic Functions Failed</b> An error was detected during the CPU Test.	<b>Microprocessor</b> System Board
<b>Base Memory Test Failed</b> An error was detected in base memory.	<b>Memory Module</b> System Board
<b>Boot Sector Unreadable</b> A boot sector read error was detected on the hard disk drive.	<b>Hard Disk Drive</b> Hard Disk Drive Cable Hard Disk Drive Adapter (if installed) System Board
<b>Bus Noise Test Failed</b> RAM Test detected an error in the memory bus.	<b>Memory Module</b> System Board
<b>Butterfly Cylinder Access Test Failed</b> Hard Disk Drive Test detected mismatch between the data read and the data stored on the drive.	<b>Hard Disk Drive</b> Hard Disk Drive Cable Hard Disk Drive Adapter (if installed) System Board
<b>Clock Stopped</b> Real-time clock has stopped working.	<b>Real-Time Clock Assembly</b> System Board
<b>CMOS Clock Test Failed</b> Time and Date Settings for CMOS and DOS <b>do not</b> Match.	<b>Real-Time Clock Assembly</b> System Board
<b>Controller Diagnostic Test Failed</b> An error was detected while testing the Hard Disk Controller (Adapter).	<b>Hard Disk Drive Adapter</b> (if installed) Hard Disk Drive System Board
<b>Cylinder 0 errors</b> Test detected an error reading the first cylinder of the hard disk drive.	<b>Hard Disk Drive</b> Hard Disk Drive Adapter (if installed) System Board
<b>Device is Not Ready</b> <b>Ready the Device...</b> or <b>Press Any Key</b>	<b>Ensure the device is powered-on.</b> Replace failing device Device Adapter (if installed) System Board



Symptom / Error	FRU / Action
<b>Disk Error Encountered Opening Output File Press Any Key To Continue.</b>	<b>Hard Disk Drive</b> Hard Disk Drive Adapter (if installed) System Board
<b>DMA #X Failed</b> Main Components Test detected an error while testing the DMA controller.	<b>System Board</b>
<b>DMA Page Register Failed</b> DMA page register error	<b>System Board</b>
<b>Drive (x) Media (y) Mismatch</b> FAT ID mismatch with installed drive.	<b>Check diskette and diskette drive capacity.</b> Diskette Drive System Board
<b>Error in video buffer. Bad bits.</b> Video memory test error.	<b>Video Adapter</b> System Board Display
<b>Exception Interrupt In Protected Mode Diags Cannot Continue</b> Server error, remove one adapter at a time until the symptom goes away.	<b>Any Adapter</b> System Board Processor
<b>Extended Memory Test Failed</b> Extended memory error.	<b>Memory Module</b> System Board
<b>Floppy Drive Failed</b> Diskette drive(s) failed.	<b>Diskette Drive</b> System Board Diskette Drive Cable
<b>General Function Failed</b> Remove one adapter at a time until the symptom goes away.	<b>Any Adapter</b> System Board Processor
<b>Hard Drives Failed</b> Hard Disk Drive test error.	<b>Hard Disk Drive</b> Hard Disk Drive Adapter (if installed) System Board
<b>Incorrect DOS version</b>	<b>Ensure you are using DOS version 3.0 or higher.</b>
<b>INT Mask Register Failed</b> INT Mask Register error.	<b>Microprocessor</b> System Board
<b>Invalid Date</b> Clock/DOS date mismatch.	<b>Real-Time Clock Assembly</b> System Board
<b>Invalid Time</b> Clock/DOS time mismatch. Back-up clock and DOS time of day settings do not match.	<b>Real-Time Clock Assembly</b> System Board
<b>Linear Cylinder Access Test Failed</b> Hard disk drive error.	<b>Hard Disk Drive</b> Hard Disk Drive Cable Hard Disk Drive Adapter (if installed) System Board
<b>Logic Function Failed</b> CPU Logic test error.	<b>Microprocessor</b> System Board
<b>Loopback Error</b> COM Port Test or Parallel Port error.	<b>System Board</b> Wrap Plug A wrap plug must be installed to successfully complete these tests

MAP (continued)

Symptom / Error	FRU / Action
<b>Main Components Failed</b> System board error.	<b>System Board</b> Processor
<b>Memory test cannot run at this location in memory</b> Not enough free memory available to start the memory test.	<b>Memory Module</b> System Board
<b>Missing QAPLus/PRO Files(s)</b> One or more diagnostic support files are missing.	<b>Diagnostic Diskette</b>
<b>NO LOOP-BACK PLUG. Skipping External loopback test</b> No wrap plug installed.	<b>Install wrap plug on the serial port, rerun test</b> System Board
<b>Not ready</b> Printer not on-line or not ready.	<b>Ready Printer</b> Printer Printer Cable System Board
<b>No 'type-amatic' repeat</b> At least one repeat key must be tested during this test or an error will occur. Type-amatic test error.	<b>Keyboard</b> System Board
<b>Not used by any standard device</b> IRQ is not currently being used by a non-standard device.	<b>System Board</b>
<b>Numeric Proc Failed</b> NPU test error.	<b>Microprocessor</b> System Board
<b>Parallel Ports Failed</b> Test Report Summary message.	<b>System Board</b>
<b>Pass (N): ** Errors ** Drive (X) Failed</b> Diskette drive read/write test error.	<b>Diskette Drive</b> System Board Diskette Drive Cable
<b>Pass (N) Drive Not Ready</b> Diskette drive door is open or defective.	<b>Ensure diskette drive is ready</b> Diskette Drive System Board Diskette Drive Cable
<b>Pass (N): Drive (X) Write Protected or Unformatted</b>	<b>Insert a non-write protected, formatted diskette into the diskette drive; then rerun the test</b> Diskette Drive System Board Diskette Drive Cable
<b>Pass (N): Unknown Media Drive (X)</b> Diskette Drive Test error.	<b>Diskette</b> Diskette Drive System Board Diskette Drive Cable
<b>Place Hi-density Media in Drive</b> Media/drive mismatch.	<b>Diskette</b> Diskette Drive System Board Diskette Drive Cable
<b>Printer Failed</b> Printer powered-on and ready?	<b>Printer</b> Printer Cable System Board

<b>Symptom / Error</b>	<b>FRU / Action</b>
<b>Printer Fault</b> Printer powered-on and ready?	<b>Printer</b> Printer Cable System Board
<b>Printer Not Selected</b> Ensure the printer is powered-on and ready.	<b>Printer</b> Printer Cable System Board
<b>Program or File Not Found</b> <b>Press Any Key</b> Diagnostics cannot find the USER(N).COM file.	<b>Diagnostic Diskette</b> Diskette Drive System Board
<b>Program Too Big To Fit In Memory</b> Too many Terminate and Stay Resident programs in memory.	<b>Reboot the system from the Diagnostic Diskette</b>
<b>QAPIus/PRO Cannot Be Re-run Because Of Error In Relocating Program</b> Diagnostics failed to relocate the Diagnostics Test programs so the memory space it resides in was not tested.	<b>Diagnostic Diskette</b> Memory Module System Board
<b>RAM Memory Error in Block n. Bad bits n</b> Memory error.	<b>Memory Module</b> System Board
<b>RAM Test Failed</b> Memory error.	<b>Memory Module</b> System Board
<b>Read error on cylinder n</b> Hard disk drive format error.	<b>Hard Disk Drive</b> Hard Disk Drive Adapter (if installed) System Board
<b>Read Errors</b> Diskette drive read error.	<b>Diskette</b> Diskette Drive System Board Diskette Drive Cable
<b>Receive Error</b> Serial Port loopback test error.	<b>Serial Port Cable</b> System Board
<b>Refresh Failure</b> Diagnostics Test detected an error while testing the DMA controller's RAM refresh cycle.	<b>Memory Module</b> System Board
<b>RTC Interrupt Failure</b> Diagnostics Test cannot detect the Real-Time clock interrupt.	<b>Real-Time Clock Assembly</b> System Board
<b>Serial Chip Error</b> COM Port error, general.	<b>Serial Port Cable</b> System Board
<b>Serial Compare Error</b> COM Port error, information transmitted is not the same as information received.	<b>Serial Port Cable</b> System Board
<b>Serial Time-out Error</b> COM Port error, time interval is too long between transmitted and received data.	<b>Serial Port Cable</b> System Board

Symptom / Error	FRU / Action
<p><b>Serious Memory Error — Diags Cannot Continue</b> Memory Test error.</p>	<p><b>Memory Module</b> System Board</p>
<p><b>Sorry You Need A Mouse</b> Mouse or mouse driver was not detected.</p>	<p><b>Mouse</b> System Board</p>
<p><b>System Hangs</b> Go to "Undetermined Problems" on page 5-26.</p>	<p><b>Any device</b> Any adapter System Board</p>
<p><b>The Address Exceeds The Size Of Your Memory</b> An invalid memory address was entered. The Diagnostics Tests display this message during the Locate Bad Chips option under the interact menu if an invalid memory address was entered at the "Enter Memory Address Of Bad Chip" prompt.</p>	<p><b>Enter correct address</b> Memory Module System Board</p>
<p><b>That Number is Out Of Range</b> An invalid bit number was entered. Diagnostics Tests display this message during the Locate Bad Chips option.</p>	<p><b>Enter the correct number</b> Memory Module System Board</p>
<p><b>Too Many Errors — Test Aborted</b> Too many errors, the Diagnostics Test cannot continue.</p>	<p><b>Microprocessor</b> System Board</p>
<p><b>Transmit Error</b> Internal or external serial port loopback test failure.</p>	<p><b>Serial Port Cable</b> System Board</p>
<p><b>Video Adapter Failed</b> Test Result Summary, displayed if "Fail" was at the Quit/Fail/Pass menu of any video test.</p>	<p><b>Video Adapter</b> System Board Display</p>
<p><b>Write error on cylinder n</b> Hard disk drive write error.</p>	<p><b>Hard Disk Drive</b> Hard Disk Drive Adapter (if installed)</p>
<p><b>Write Errors</b> Diskette drive write error.</p>	<p><b>Diskette</b> Diskette Drive System Board Diskette Drive Cable</p>
<p><b>Write Protected or Unformatted</b> Diskette is Write Protected or not formatted.</p>	<p><b>Insert a non-write protected, formatted diskette into the diskette drive; then rerun the test</b> Diskette Drive System Board Diskette Drive Cable</p>
<p><b>You Cannot Delete the Motherboard</b> "Remove Board" option was selected. The Diagnostics Tests display this message during the Locate Bad Chips option.</p>	<p><b>Make the correct selection</b> Memory Module System Board Processor</p>
<p><b>Image Adapter/A Memory Test failure indicated by graphic of adapter.</b></p>	<p><b>Replace memory module (shown in the graphic)</b></p>

Symptom / Error	FRU / Action
SCSI ID on rotary switch does not match SCSI ID set in configuration. Verify drive switches inside cover are set to zero.	<b>Rotary Switch Circuit Board</b> Circuit Board Cable Tape Drive

## MISCELLANEOUS ERROR MESSAGES

Message/Symptom	FRU/Action
Changing colors.	<b>Display</b>
Clock Battery inaccurate.	<b>Clock Battery</b> System Board
Continuous beep.	<b>System Board</b>
Computer will <b>not</b> power-off.	<b>See “Power-Supply Voltage Check (7585)” on page 5-25</b> Power Switch System Board
Customer indicator lights not working, but computer works correctly.	<b>Customer Cable or Device</b> LED Board Power Supply (if used as power source) (Note: for easy checkout of LED board and power supply, swap the two LED cables.)
Dead computer.	<b>See “Power-Supply Voltage Check (7585)” on page 5-25</b> Power Switch Power Supply System Board
Diskette drive in-use light remains on or does not light when drive is active.	<b>Diskette Drive</b> System Board Diskette Drive Cable
Flashing cursor with an otherwise blank display.	<b>System Board</b> Primary Hard Disk Drive Hard Disk Drive Cable
Incorrect memory size during POST.	<b>Run the Memory tests</b> Memory Module System Board
“Insert a Diskette” icon appears with a known-good diagnostics diskette in the first 3.5-inch diskette drive.	<b>Diskette Drive</b> System Board Diskette Drive Cable Network Adapter
Intensity or color varies from left to right of characters and color bars.	<b>Display</b> System Board
No beep during POST but computer works correctly.	<b>Speaker</b> System Board

Message/Symptom	FRU/Action
No beep during POST.	<b>See “Undetermined Problems” on page 5-26</b> System Board Memory Module Any Adapter or Device Riser Card Power Cord Power Supply
No power, or fan not running.	<b>See “Power-Supply Voltage Check (7585)” on page 5-25</b>
Nonsystem disk or disk error-type message with a known-good diagnostic diskette.	<b>Diskette Drive</b> System Board Diskette Drive Cable
One long and two short beeps during POST.	<b>System Board</b>
One or both system cooling fans not running.	<b>See “Undetermined Problems” on page 5-26</b> Fan Cables Fan Power Supply
Other display symptoms not listed above (including blank or illegible display).	<b>See “Display” on page 5-23</b> System Board Display
Power-on indicator or hard disk drive in-use light not on, but computer works correctly.	<b>Power Supply</b> System Board LED Cables
Printer problems.	<b>See “Printer” on page 5-24</b>
Program loads from the hard disk with a known-good diagnostics diskette in the first 3.5-inch diskette drive.	<b>Check the Configuration/Setup Utility</b> Diskette Drive Diskette Drive Cable System Board Power Supply
Repeating short beeps.	<b>Keyboard (stuck key?)</b> Keyboard Cable System Board
Serial or parallel port device failure (system board port).	<b>External Device Self-Test OK?</b> External Device Cable System Board
Serial or parallel port device failure (adapter port).	<b>External Device Self-Test OK?</b> External Device Cable Alternate Adapter System Board Riser Card
Some or all keys on the keyboard do not work.	<b>Keyboard</b> Keyboard Cable System Board
Three short beeps during POST.	<b>See “RAM Memory Modules (SIMMs/DIMMs)” on page 5-28.</b> System Board

## BEEP CODE INDEX


In the following Beep Code Index, the numbers indicate the sequence and number of beeps. For example, a “2-3-2” error symptom (a burst of two beeps, three beeps, then a burst of two beeps) indicates a memory-module problem. (Continue with the Symptom-to-FRU index below for other beep/no-beep symptoms.)

<b>Beep Code</b>	<b>FRU/Action</b>
<b>1-1-3</b> CMOS read/write error	<b>Run Setup</b> System Board
<b>1-1-4</b> ROM BIOS check error	<b>System Board</b>
<b>1-2-X</b> DMA error	<b>System Board</b>
<b>1-3-X</b>	<b>Memory Module</b> System Board
<b>1-4-4</b>	<b>Keyboard</b> System Board
<b>1-4-X</b> Error detected in first 64KB of RAM.	<b>Memory Module</b> System Board
<b>2-1-1, 2-1-2</b>	<b>Run Setup</b> System Board
<b>2-1-X</b> First 64KB of RAM failed.	<b>Memory Module</b> System Board
<b>2-2-2</b>	<b>Video Card</b> System Board
<b>2-2-X</b> First 64KB of RAM failed.	<b>Memory Module</b> System Board
<b>2-3-X</b>	<b>Memory Module</b> System Board
<b>2-4-X</b>	<b>Run Setup</b> Memory Module System Board
<b>3-1-X</b> DMA register failed.	<b>System Board</b>
<b>3-2-4</b> Keyboard controller failed.	<b>System Board</b> Keyboard
<b>3-3-4</b> Screen initialization failed.	<b>Video Adapter</b> System Board Display
<b>3-4-1</b> Screen retrace test detected an error.	<b>Video Adapter</b> System Board Display
<b>3-4-2</b> POST is searching for video ROM.	<b>Video Adapter</b> System Board
<b>4</b>	<b>Video Adapter</b> System Board
All other beep code sequences.	<b>System Board</b>

Beep Code	FRU/Action
One long and one short beep during POST. Base 640KB memory error or shadow RAM error.	<b>Memory Module</b> System Board
One long beep and two or three short beeps during POST. (Video error)	<b>Display Adapter, if installed.</b> System Board <b>Note: This is normal when there is no display connected to the network node processor.</b>
Three short beeps during POST.	<b>System Board</b>
Continuous beep.	<b>System Board</b>
Repeating short beeps.	<b>Keyboard stuck key?</b> Keyboard Cable System Board

**DID YOU FIND YOUR SYMPTOM IN THE LIST?**

Yes No



Go to “Undetermined Problems” on page 5-26.



• **Action:**

- **Change the suspected FRU**, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.
- **or perform the specified action.**



---

## Display

If the screen is rolling, blooming, distorted, or cannot be adjusted for brightness and contrast, replace the display assembly with a known good display assembly, if possible. If that does not correct the problem, replace the system board.

**Note:** During the first two or three seconds after the display is powered on, the following might occur while the display synchronizes with the computer.

- Unusual patterns or characters
- Static, crackling, or clicking sounds
- A “power-on hum” on larger displays

A noticeable odor might occur on new displays or displays recently removed from storage.

These sounds, display patterns, and odors are normal; do not replace any parts.

To verify the operation of the display, do the following to run the display self-test.

**Note:** This test does not work on all displays. If the test does not work, but you suspect the display, replace it. If that does not solve the problem, reinstall the original display, then replace the system board.

1. Power off the computer and display.
2. Disconnect the display signal cable.
3. Power on the display.
4. Turn the brightness and contrast controls to their maximum setting.
5. Check for the following conditions:
  - The screen should be white or light gray, with a black margin (test margin) on the screen.
  - You should be able to vary the screen intensity by adjusting the contrast and brightness controls.

**Note:** The location of the test margin varies with the type of display. The test margin might be on the top, bottom, or one or both sides.

If you do not see any test margin on the screen, or if you cannot adjust either the brightness or contrast with their respective controls, replace the display.

If you are unable to correct the problem, go to “Undetermined Problems” on page 5-26.

---

## Keyboard

**Note:** If a mouse or other pointing device is attached, remove it to see if the error symptom goes away. If the symptom goes away, the mouse or pointing device is defective.

**001**

- Power-off the computer.
- Disconnect the keyboard cable from the system unit.
- Power-on the computer and check the keyboard cable connector on the system unit for the voltages shown.  
All voltages are  $\pm 5\%$ .

Pin	Voltage (Vdc)
1	+5.0
2	Not Used
3	Ground
4	+5.0
5	+5.0
6	Not Used




Figure 5-1. Keyboard Connector Voltages

### ARE THE VOLTAGES CORRECT?

Yes No

**002**

Replace the system board.

**003**

On keyboards with a detachable cable, replace the cable. If the problem remains or if the cable is permanently attached to the keyboard, replace the keyboard. If the problem remains, replace the system board.

---

---

## Printer

1. Make sure the printer is properly connected and powered on.
2. Run the printer self-test.

If the printer self-test does not run correctly, the problem is in the printer. Refer to the printer service manual.

If the printer self-test runs correctly, install a wrap plug in the parallel port and run the diagnostic tests to determine which FRU failed.

If the diagnostic test (with the wrap plug installed) do not detect a failure, replace the printer cable. If that does not correct the problem, replace the system board or adapter connected to the printer cable.

## Power-Supply Voltage Check (7585)

If the power-on indicator is not on or if the power-supply fan is not running, check the power cord for proper installation and continuity. Verify that the voltage-selector switch is set for the correct voltage (See "Power Voltage Setting").

If this setting is correct, check the power supply connector voltages shown in Figure 5-2. The power supply connector is located at the right rear of the system board.

**Note:** These voltages must be checked with the power supply cables connected to the system board.




Figure 5-2. Power Supply Connector Voltages

If the voltages are not correct, do the following.

- Check the power cord for continuity.
- Check the on/off switch for continuity.
- Replace the power supply.

## Power Voltage Setting

**The power supply on the 7585-P02 has a switch on it that must be manually set before the computer is powered up.** This switch is located in the area where the power cord plugs into the system unit. It is marked either "110/220" or "115/230".

Use the following instructions to set the switch. You can use a ball-point pen to slide the switch to the correct position.

- If the voltage range in your country is between 90 and 137 volts, set the switch so "110" or "115" is visible.
- If the voltage range in your country is between 180 and 265 volts, set the switch so "220" or "230" is visible.

### Attention

Be sure the voltage selection switch is in the correct position. If you set this switch to the wrong position, you might damage your computer when you turn it on.

---

## Undetermined Problems

If an undetermined problem exists, check the power supply voltages (see “Power-Supply Voltage Check (7585)” on page 5-25). If the voltages are correct, return here and continue with the following steps.

1. Power-off the computer.
2. Remove or disconnect the first (or next) of the following:
  - a. Non-IBM devices
  - b. External devices (modem, printer, or mouse)
  - c. Any adapters
  - d. Riser card
  - e. Memory modules, other than Bank 0
  - f. Extended video memory
  - g. External Cache
  - h. Hard drive
  - i. Diskette drive
3. Power-on the computer to re-test the system.
4. Repeat steps 1 through 3 until you find the failing device or adapter.

If all devices and adapters have been removed, and the problem continues, replace the system board (see “Before Replacing a System Board”). If the problem continues after replacing the system board, reinstall the old system board and replace the microprocessor (see “FRU Exchange on Network Node Processor Based on 7585” on page 5-34).

## Before Replacing a System Board

The processor is not included with the system board FRU; it is a separate FRU.

If you are instructed to replace the system board, you should do the following.

- Install the processor from the old system board onto the new system board.
- If any options (RAM modules, cache, or video memory) are on the old system board, install them onto the new system board.
- Ensure that all the new system board jumper settings are the same as the old system board jumper settings.

If the new system board does not correct the problem, reinstall the options back onto the old system board, reinstall the old system board, and replace the processor with a new one.

---

## Devices List

Follow the instructions on the screen for the installed devices list.

**Attention:**

A customized setup configuration (other than default settings) might exist on the computer you are servicing. Running the Configuration/Setup Utility program might alter those settings. Note the current configuration settings and verify that the settings are in place when service is complete.

**If the number of diskette drives shown in the installed devices list is not correct,** do the following.

1. Restart the computer.
2. Run the Configuration/Setup Utility program to correct the drive information.
3. Run the diagnostic tests.
4. If you cannot correct the drive information, replace FRUs, in the following order, until the problem goes away:
  - Diskette drive
  - Diskette-drive cable
  - System board

**If the number of hard disk drives shown in the installed devices list is not correct,** do the following.

1. Check the hard disk drive jumper settings. All supported hard disk drives use jumpers or tabs to set drives as either primary or secondary. Refer to the jumper instructions that came with your hard disk drives.
2. Check the voltages to the hard disk drives (see "Power-Supply Voltage Check (7585)" on page 5-25).
3. Restart the computer and check the configuration.
  - If the first drive is missing, replace the primary drive.
  - If any other drive is missing, replace that drive.
  - If all drives are missing, replace the primary drive.
  - If the problem remains, replace the drive cable.
  - If the problem still remains, replace the system board.

**If any other adapter or device is missing from the installed devices list, run the Configuration/Setup Utility program.** Check to see if any adapter or device is set to a conflicting address with any other adapter or device. Also be sure that any adapter or device missing from the list is not set to "disabled."

**Note:** If the device is still missing from the list, run the diagnostics provided with that device.

---

## RAM Memory Modules (SIMMs/DIMMs)

The 7585-P02 supports the following memory modules.

### **Dual In-line Memory Module (DIMM)**

Bank 0 is populated with a single 168-pin DIMM. This module can be 8MB, 16MB, and 32MB with a speed of 60 nanoseconds.

### **Single In-line Memory Modules (SIMM)**

Banks 1 and 2 are populated by pairs of 72-pin SIMMs. Memory SIMMs supported are 4MB, 8MB, 16MB, and 32MB with a speed of 60 nanoseconds. Memory SIMMs must be installed in pairs, one pair to a bank. Both SIMMs in either bank must be the same size and speed.

If a problem with memory modules is suspected, perform the memory test procedure. See "Memory Test" on page 5-29.

## Memory Test

### Important

To continue this procedure you must have a display and keyboard connected to the network node processor Refer to “How to Install a Display and Keyboard on your Network Node Processor” on page 3-18.

- 1** Power OFF the network node processor.
- 2** Insert the Diagnostics diskette into drive A.
- 3** Power ON the computer and the attached display.
- 4** Make a note of any POST errors you receive. Disregard 164 errors (memory size).
- 5** Did you received a 2XX POST error?  
**Yes** Go to **Step 15 on page 5-30** .  
**No** Continue with **Step 6** .
- 6** Did the computer boot from the diagnostic diskette and the following logo screen appear?

```
QAPlus/PRO
by Diagsoft
for
IBM

Press any key to continue
```

- Yes** Go to **Step 7** .  
**No** You might have to press Esc to continue.

When the previous screen is displayed continue with **Step 7** .

If the computer did not boot from the diagnostic diskette with the previous diagnostic logo screen displayed, go to “MAP: 7585 Network Node Processor Troubleshooting” on page 5-2.


- 7** Follow the prompts until the following window is displayed.

```
QAPlus/PRO

QAPlus/PRO Advanced Diagnostic

System is being analysed
```

- 8** Wait until the main Menu is displayed



**9** Select the **Diagnostics** option.

**10** The **Diagnostics Menu** menu is displayed.



**11** Select the **Module Tests**

**12** A window is displayed showing all groups.

**13** Select the **memory** , press the **Enter** key and follows the prompts.

**14** Did the memory tests finish without an error?


**No** Follow the instructions on the display. If there are no instructions on the display, go to **Step 23 on page 5-31** .

**Yes** Your computer memory is now functioning correctly. If you suspect an intermittent problem, start an error log.

**15** Press Esc to continue until the following screen is displayed:



**16** Follow the prompts until the following window is displayed.



**17** Wait until the main Menu is displayed



```
Main Menu
Diagnostics
System Info
Reports
Utility
Exit
```

**18** Select the **Diagnostics** option.

**19** The **Diagnostics Menu** menu is displayed.

```
Diagnostics
Quick Check
Module Tests
Options
```

**20** Select the **Module Tests**

**21** A window is displayed showing all groups.

**22** Select the **memory** , press the **Enter** key and follows the prompts.

**23** At the end of group testing follows the prompts. If you cannot run the memory test or the test does not find a problem, replace the memory modules, one pair/bank at a time, until the problem goes away. When the problem goes away, replace the last memory module removed. If that does not fix the problem, replace the system board.

---

## How to Run the 7585 Network Node Processor Diagnostics

### Important

To continue this procedure you must have a display and keyboard connected to the network node processor. Refer to "How to Install a Display and Keyboard on your Network Node Processor" on page 3-18.

Use the **Diagnostic** diskette to test the basic system hardware with the following procedure.

- 1** Power OFF the network node processor.
- 2** Insert the **Diagnostic** diskette in drive A.
- 3** Power ON the network node processor and the attached display.
- 4** Do not press **F1** when the icon appears.
- 5** If any POST errors appear after POST, make a note of the error(s) and press the **Esc** key.
- 6** The following window is displayed.

```
QAPlus/PRO
by Diagsoft
for
IBM

Press any key to continue
```

- 7** Follow the prompts until the following window is displayed.

```
QAPlus/PRO

QAPlus/PRO Advanced Diagnostic

System is being analysed
```

- 8** Wait until the main Menu is displayed.

```
Main Menu

Diagnostics
System Info
Reports
Utility
Exit
```

- 9** Select the **Diagnostics** option.
- 10** The **Diagnostics Menu** menu is displayed.

Diagnostics

Quick Check  
Module Tests  
Options

**11** Select the **Quick Check** option (for complete testing) or **Module Tests** (for testing part of your network node processor).

**12** A window is displayed showing which group is tested. At the end of group testing follows the prompts.

**Note:** Refer to the *7585 P02 Industrial Computer Installation, Operation, Hardware Maintenance, S76H-3792* to identify the problem. Then if you have to exchange an FRU, go to “FRU Exchange on Network Node Processor Based on 7585” on page 5-34.

---

## FRU Exchange on Network Node Processor Based on 7585

Before any network node processor FRU exchange, perform the above procedure:

- 1** Switch OFF the network node processor and the display (if you have already connected it to the network node processor).
- 2** On the rear of the network node processor disconnect all the cables.
- 3** If your network node processor is installed in the controller rack go to Step **4** . Otherwise go to Step **7** .
- 4** Remove the four screws which secure the network node processor in the rack. Slide out the network node processor from the rack and install it on a table to continue the FRUs removal.

### Attention

Be careful the weight of the processor is about 18 kg.

### FRU Exchange

- 5** Go to the *7585 P02 Industrial Computer Installation, Operation, Hardware Maintenance, S76H-3792* to replace the suspected FRU, then **return here** and continue with Step **6** .
- 6** For Setting up the network node processor after FRU exchange use the following steps:
  - a** Re-install all the covers of the network node processor.
  - b** If the network node processor was installed in a controller rack continue with Step **6c** . Otherwise go to Step **6e** .
  - c** Slide the network node processor into the rack.
  - d** Secure the network node processor using the four screws previously removed, then continue with Step **6e** .
  - e** At the rear of the network node processor re-connect all the cable previously removed.

## 7

### Important

To continue this procedure you must have a display and keyboard connected to the network node processor Refer to "How to Install a Display and Keyboard on your Network Node Processor" on page 3-18.


Use the following table to find the procedure you need to follow after exchanging an FRU.

<b>Network Node Processor FRU to Exchange</b>	<b>Action</b>
<b>Battery Board</b>	Go to "Procedure After Board or Battery Exchange on NNP Based on 7585" on page 5-36
<b>Hard Disk Drive</b>	Go to "Procedure After Hard Disk Drive Exchange on NNP Based on 7585" on page 5-43
<b>LAN Adapter</b>	Go to "Procedure After LAN Adapter Exchange on NNP Based on 7585" on page 5-38
<b>Other FRU</b>	Go to "Procedure After Other FRU Exchange on NNP Based on 7585" on page 5-46

# Procedure After Board or Battery Exchange on NNP Based on 7585


You are here after battery or board exchange.

- 1 Power ON the network node processor.
- 2 The following error screen is displayed:




**Note:** The errors displayed can be different from the errors shown in this screen.

- 3 Select the **continue** option. Another screen is displayed:



- 4 Select the **Automatically reconfigure system and continue** option. Another screen is displayed:



- 5 Select the **Continue** option. The **Configuration / Setup Utility** menu is displayed. Refer to the "Nways Switch Administration Station Configuration Reference Based on 7585-P02" on page C-1 to check and change your configuration according to the configuration reference.
- 6 When it is done select the **Save Settings** option and follow the prompts.
- 7 Select **Exit Setup**. You have the following screen:

Exit Setup

Do you want to exit the Setup Utility?

Yes, exit the Setup Utility

No, return to the Setup Utility

- 8** Select **Yes** that reboot the network node processor.
- 9** Go to “CE Leaving Procedure” on page 5-47.

## Procedure After LAN Adapter Exchange on NNP Based on 7585

You are here after LAN adapter card exchange.

### Important

For this procedure be sure that the LAN cable **is not connected** to the LAN adapter card.

- 1 Power ON the network node processor and the attached display.
- 2 The IBM logo, several messages, and OS/2 logo are displayed. Wait until the following window appears.

```
STARTUP.COMD
```

```
Loading. Please wait..
```

- 3 Press simultaneously the **Ctrl** and **C** keys.
- 4 A DOS window appears. Type the following command:  
EULANAID  
then press **Enter**.
- 5 The IBM LANAID window is displayed during loading. Wait until the following window is displayed.

```
LANAID V2.21 for IBM Auto/Turbo ISA Adapter
```

```
MAC Address           Alternate Format  
XX-XX-XX-XX-XX-XX    XX-XX-XX-XX-XX
```

```
      Select a function Below
```

- Adapter Configuration
- Software Installation
- Diagnostics

```
Exit  Help
```

- 6 Using the **Tab** key select the **Adapter Configuration**, then press **Enter**.
- 7 The following window is displayed.



```

View Adapter Configuration

Configurable          |          Hardware
-----|-----
Select <Suggest> or <Change> to make changes to the configuration below
Then press <Store> to store these changes to the adapter.

Mode          ISA 16          Adapter Plug and Play          Automatic
Remote IPL:   Disabled        Interrupt:                      9(2)
Data Rate:   16 MBps          I/O Address:                   A20-A23
Auto Sens    Disabled        ROM Address                    CC000-C0FFF
Bus Width    16 bits          RAM Address                    C0000-CBFFF

Suggest      Change      Defaults      Store
Done         Cancel    Help

```

**8** Using the **Tab** key select the **Change** and press **Enter**.

**9** The following window is displayed.

```

Change Configuration Parameters

Adapters Mode          Plug and Play          Other Parameters

Select each mode for a detailed description

Adapter Modes

- Enhanced Modes
- Auto 16 Mode
- ISA 16 Mode

OK          Cancel    Help

```

**10** Using the **Up** and **Down** keys select the **ISA 16 Mode** and press simultaneously **Alt** and **P** keys to select the **Plug and Play** window.

**11** The following window is displayed.

```

Change Configuration Parameters

Adapters Mode | Plug and Play | Other Parameters

Make any Changes to the configuration, then select <OK>

- Plug and Play Automatic Configuration
- Manual (locked) Configuration for Plug and Play systems
- Manual Configuration for no Plug and Play (legacy) systems

OK          Cancel    Help

```

**12** Press simultaneously the **Alt** and **R** keys.

**13** The following window is displayed.

Change Configuration Parameters	
Remote IPL	Data Rates
o Enable	o 16 Mbps
o Disable	o 4 Mbps
Auto Sense	Bus Wide
o Enable	o 16 Mbps
o Disable	o 8 Mbps
OK	Cancel Help

**14** Using the **Up**, **Down**, and **Tab** keys select:

- Remote IPL: **Disable**
- Data Rates: **16 Mbps**
- Auto Sense: **Disable**
- Bus Wide: **16 bits**

Select **OK** and press **Enter**.

**15** The following window is displayed.

View Adapter Configuration			
Configurable		Hardware	
Select <Suggest> or <Change> to make changes to the configuration below Then press <Store> to store these changes to the adapter.			
Mode	ISA 16	Adapter Plug and Play	Automatic
Remote IPL:	Disabled	Interrupt:	9(2)
Data Rate:	16 MBps	I/O Address:	A20-A23
Auto Sens	Disabled	ROM Address	CC000-C0FFF
Bus Width	16 bits	RAM Address	C0000-CBFFF
Suggest	Change	Defaults	Store
Done	Cancel	Help	

**16** Using the **Up** and **Down** keys select the **Store**, then press **Enter**.

**17** The adapter configuration is stored. Wait until the following window is displayed.

Storing Configuration
The adapter configuration settings that you have chosen are now stored.
NOTE: Changes made to the adapter do not become effective until your computer is powered OFF and back ON: A reboot will not activate the changes.
OK

**18** Press **Enter**.

**19** The following window is displayed.

View Adapter Configuration			
Configurable		Hardware	
Select <Suggest> or <Change> to make changes to the configuration below Then press <Store> to store these changes to the adapter.			
Mode	ISA 16	Adapter Plug and Play	Automatic
Remote IPL:	Disabled	Interrupt:	9(2)
Data Rate:	16 MBps	I/O Address:	A20-A23
Auto Sens	Disabled	ROM Address	CC000-C0FFF
Bus Width	16 bits	RAM Address	C0000-CBFFF
Suggest	Change	Defaults	Store
Done	Cancel	Help	

**20** Using the **Tab** key, select **Done**, then press **Enter**.

**21** The following window is displayed.

LANAID V2.21 for IBM Auto/Turbo ISA Adapter	
MAC Address	Alternate Format
xx-xx-xx-xx-xx-xx	xx-xx-xx-xx-xx
Select a function Below	
Adapter Configuration	
Software Installation	
Diagnostics	
Exit	Help

**22** Using the **Tab** key, select **Exit**, then press **Enter**.

**23** The following window is displayed.

LANAID	
This will exit LANAID	
If you have made configuration changes to your adapter, you must Power OFF your computer for the changes to become effective. A reboot will not activate the changes.	
Please remove any diskettes and restart your computer. Select <OK> to exit or <Cancel> to return to LANAID.	
OK	Cancel

**24** Using the **Tab** key, select **OK**, then press **Enter**.

- 25** Power OFF the network node processor.
- 26** Reconnect the LAN adapter cable to the rear of the LAN adapter card.
- 27** Disconnect the display and the keyboard previously installed.
- 28** Power ON the network node processor
- 29** Go to “CE Leaving Procedure” on page 5-47.

# Procedure After Hard Disk Drive Exchange on NNP Based on 7585

You are here after exchanging the hard disk drive.

- 1 Insert the **Diagnostic Diskette**
- 2 Power On the network node processor and the display.
- 3 When the following is displayed

```
Adaptec AHA<2940 Ultra/Ultra WBios v1.2  
(c) 1995 Adaptec, Inc. All rights Reserved.
```

```
<<<Press CCtrl><A> for SCSI Select (TM) Utility>>>  
SCSI ID : LUN NUMBER - : - 6:0 - IBM DFH5S2F
```

**Note**

**Note:** The device identification may be different.

- 4 Press simultaneously the **Ctrl** and the **A** key.
- 5 The following screen is displayed:

```
          AHA-2940- Ultra/Ultra W at Bus: Device 00:0Bh  
  
Would you like to configure the host adapter, or run the  
SCSI disk utilities? Select the option and press <Enter>.  
Press <F5> to switch between color and monochrome modes.  
Options  
Configure/View Host Adapter Settings  
SCSI Disk Utilities
```

- 6 Select the **SCSI Disk Utilities**

```
Select SCSI Disk and Press <Enter>  
  
SCSI ID -0 : No Device  
SCSI ID -1 : No Device  
SCSI ID -2 : No Device  
SCSI ID -3 : No Device  
SCSI ID -4 : No Device  
SCSI ID -5 : No Device  
SCSI ID -6 : IBM DFH5S2F      |d      (Note)  
SCSI ID -7 : AHA-2940 Ultra/Ultra W  
SCSI ID -8 : No Device  
SCSI ID -9 : No Device  
SCSI ID -10: No Device  
SCSI ID -11: No Device  
SCSI ID -12: No Device  
SCSI ID -13: No Device  
SCSI ID -14: No Device  
SCSI ID -15: No Device
```

**Note:** The device identification may be different.

- 7 Select the **SCSI ID -6: IBM DFH5S2F** (the device identification **IBM DFH5S2F** may be different).

```
Format Disk
Verify Disk Media
```

**8** Select the **Verify Disk Media** option. the following screen is displayed:

```
SCSI ID -6 IBM FFHS52F   |d   (Note)
Capacity: 2150 MBytes

This drive will be scanned for media defects. All
recoverable defects will be remapped.
Verify Disk?
Yes
No
```

**Note:** The device identification may be different.

**9** Select the **Yes** option. the following screen is while the diagnostic runs.

```
Verifying IBM DFHS52F   |d
Sector - ssssss          2150 Mbytes

xx% Complete

Press <Esc> to abort
```

**10** At the end of the diagnostic you obtain:

```
Disk Verification Complete
```

**11** Click on the **ESC** key until the following screen is displayed:

```
Exit Utility
Yes
No
```

**12** Select **Yes** the following screen is displayed:

```
Please press any key to reboot
```

**13** Is the diagnostic error free?

**No** Restart the problem determination.  
**Yes** You must restore the network node processor hard disk after its replacement, continue with **Step 14 on page 5-45**

- 14** Return on the *service processor* console to load the licensed internal code on the NNP, using the following procedure:
- a** Return to the **MOSS-E View** window.
  - b** Double click on the **3746-900** or **3746-950** icon.
  - c** On the **3746-9x0 Menu** select the **Network Node Processor (NNP) Management** option.
  - d** On the **Network Node Processor (NNP) management** window double click on the **Install/change/Restore LIC/NNP** option.
  - e** The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed.
  - f** Select the NNP (A or B), then click on **Restore LIC on NNP**
  - g** On the following window click on **OK**
  - h** Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *service processor* then click on **OK**.
  - i** Follow the prompts to insert the **Network Node Processor Diskette Installation** in the *network node processor* then click on **OK**.
  - j** The **3746-900/NNP Licensed Internal Code (LIC) Management** window is displayed with a message for waiting (Installation duration is about 30 minutes).
  - k** When installation is complete a message warns you to remove the **Network Node Processor Diskette Installation** from the *network node processor* then click on **OK**.
  - l** A new message indicates that the "NNP LIC Restoration, Operation Successfully Completed", click on **OK**.
  - m** The **3746-900/NNP Licensed Internal Code (LIC)** is displayed, click on **Close** to return to the **MOSS-E View** window.
- 15** Go to "CE Leaving Procedure" on page 5-47.

## Procedure After Other FRU Exchange on NNP Based on 7585

You are here after other FRU exchange.

**1** Run diagnostics (see “How to Run the 7585 Network Node Processor Diagnostics” on page 5-32).

**2** Is the diagnostic error free?

**No** Restart the problem determination.

**Yes** Return the network node processor to the customer, then go to “CE Leaving Procedure” on page 5-47.



## CE Leaving Procedure

**1** Check that:

- a** The network node processor is properly installed.
- b** All the cables previously removed are properly connected.
- c** The display and keyboard previously installed are disconnected.
- d** The network node processor IML is complete and linked with the service processor.

**2** At the beginning of the problem determination, did you modify the **Remote Support Facility** parameters, using the procedure described in the *Maintenance Information Procedure* for 3745 and 3746-900, or in the *Service Guide* for 3746-950?

- Yes**        Go to step **3** .  
**No**         Go to step **4** .

**3** Modify the **Remote Support Facility** parameters using the following steps:

- On the "MOSS-E VIEW" window, double click on the service processor icon.
- The "Service Processor Menu" window is displayed.
- Click on the "Configuration Management" option.
- Double click on the "Manage Remote Operations" option.
- On the "Remote Operation Management" window, select the "Remote operations authorization" option and click on "OK".
- On the "Remote Support Facility" window, select the two following options:
  - "Enable Remote Support Facility"
  - "Generate alerts"and click on "OK".
- Click on "Cancel" to return to "Service Processor Menu", then click on "Function" and "Exit" to return to the "MOSS-E View" window.
- On the "MOSS-E VIEW" window, click on "Program" in the action bar.
- Click on "Log off MOSS-E".
- Continue with step **4** .

**4** You should use the following list to ensure that the machine is in suitable condition for customer operation and that call information is recorded.

- If previously, you have worked on 3745 or 3746, be sure to have restore them at a correct status for customer application (MOSS online, 3746 online, FRU active in CDF-E).
- Ask the customer to restart his application.
- If you have a problem, call your support for assistance



---

## Appendix A. Parameter Worksheet

The worksheet in this appendix lists the MOSS-E parameters needed during the NNP installation.

When applicable, default parameter values are included (in parentheses) in the tables.

### Definition of Service LAN IP Addresses

For details, refer to chapter 'Service LAN IP Addresses (MOSS-E)' in *3745 Communication Controller Models A and 3746 Models 900 and 950: Planning Guide*, GA33-0457.

<i>Table A-1. For the Service Processor</i>	
IP address	(192.9.200.1)
Subnet mask	(255.255.255.240)

<i>Table A-2. For the Network Node Processor-A</i>	
IP address	(192.9.200.2)
Subnet mask	(255.255.255.240)

<i>Table A-3. For the Network Node Processor-B</i>	
IP address	(192.9.200.3)
Subnet mask	(255.255.255.240)

<i>Table A-4. For the 3746 NN</i>	
IP address	(192.9.200.4)
Subnet mask	(255.255.255.240)



---

## Appendix B. Controller Expansion Component Locations

If you want more information about:	Refer to
<ul style="list-style-type: none"><li>• Positioning the units in the front side of the controller expansion</li><li>• Positioning the units in the rear side of the controller expansion</li><li>• Installing captive nuts and brackets (for 7585)</li><li>• Installing captive nuts and brackets (for 3172, 9585, or 9577)</li><li>• Installing captive nuts for LCBs</li><li>• Installing captive nuts for 8229s</li><li>• Installing captive nuts and brackets for MAE</li><li>• Installing brackets for processor type 7585</li><li>• Installing brackets for processor type 3172</li><li>• Example of units installation (processor type 7585)</li><li>• Example of units installation (processor type 7585 + MAE)</li><li>• Example of units installation (processor type 3172)</li><li>• Example of units installation (processor type 9585)</li><li>• Example of units installation (processor type 9577)</li><li>• Connecting the units to the ac Outlet Distribution Box.</li></ul>	<ul style="list-style-type: none"><li>• Figure B-1 on page B-2</li><li>• Figure B-2 on page B-3</li><li>• Figure B-3 on page B-4</li><li>• Figure B-4 on page B-5</li><li>• Figure B-5 on page B-6</li><li>• Figure B-6 on page B-7</li><li>• Figure B-7 on page B-8</li><li>• Figure B-8 on page B-9</li><li>• Figure B-9 on page B-10</li><li>• Figure B-10 on page B-11</li><li>• Figure B-11 on page B-11</li><li>• Figure B-12 on page B-12</li><li>• Figure B-13 on page B-12</li><li>• Figure B-14 on page B-13</li><li>• Figure B-15 on page B-13</li></ul>






Figure B-2. Controller Expansion Inventory Chart (Rear View).

**Notes:**

1. The units dimensions are scaled to the size of the controller expansion diagram. The values represent the size used to setup the units in the controller expansion, it is not the size of the units themselves.
2. The attachment holes along each side of the controller expansion are divided into units of measure called EIA units. Each EIA unit (U) equals 44.5 millimeters (1.75 inches).
3. The controller expansion is 37 U high but only 35 are usable, one U must be reserved at the top and at the bottom for proper cooling.




Figure B-3. Installing Captive Nuts and Brackets for the Display, Drawer, SP and NNP Type 7585

**Note:** This symbol '■' identify the locations to install the captive nuts.






Figure B-4. Installing Captive Nuts and Brackets for the Display, Drawer, SP and NNP Type 3172

**Notes:**

1. This drawing can be used to setup the SP type **9585** or **9577**
2. This symbol '■' identify the locations to install the captive nuts.




Figure B-5. Installing Captive Nuts for LCBs

**Note:** This symbol '■' identify the locations to install the captive nuts.




Figure B-6. Installing Captive Nuts for 8229s

**Note:** This symbol '■' identify the locations to install the captive nuts.




Figure B-7. Installing Captive Nuts and Brackets for MAE

**Note:** This symbol '■' identify the locations to install the captive nuts.





Figure B-8. Installing Brackets (PN 58G5752) for Processor Type 7585



View A

Figure B-9. Installing Brackets for Processor Type 3172

- **1** bracket used to install the display (PN 58G5752)
- **2** screws used to install the SP and NNP (PN 0782986)




Figure B-10. Units Installation in the Controller Expansion (SP Type 7585)




Figure B-11. Units Installation in the Controller Expansion (SP Type 7585 + MAE)




Figure B-12. Units Installation in the Controller Expansion (SP Type 3172)




Figure B-13. Units Installation in the Controller Expansion (SP Type 9585)






Figure B-14. Units Installation in the Controller Expansion (SP Type 9577)




Figure B-15. Connecting the Units to the ac Outlet Distribution Box.



---

## Appendix C. Network Node Processor Aids

---

### Network Node Processor Based on 7585-P02

#### How to check the Device Configuration (7585-P02)

**Important**

Before continuing this procedure you **must** have installed a display and a keyboard on your network node processor. Refer to "How to Install a Display and Keyboard on your Network Node Processor" on page 3-18.

- 1** Power ON the network node processor
- 2** Press the **F1** key to invoke the configuration/Setup utility after POST completion, and continue with the "Nways Switch Administration Station Configuration Reference Based on 7585-P02."

#### Nways Switch Administration Station Configuration Reference Based on 7585-P02

The following window is displayed. From the following window select the different options and go to the new windows for checking.

Configuration/Setup Utility

Select Option:

- System Summary **1**
- Product Data **2**
- Device and I/O Ports **3**
- Date and Time **4**
- System Security **5**
- Start Options **6**
- Advanced Setup **7**
- ISA Legacy Resources **8**
- Advanced Power Management **9**

Save Settings  
Restore Settings  
Load Default Settings

Exit Setup

**1**

### System Summary

Processor	Pentium	
Processor Speed	200MHz	
Math Coprocessor	Internal	
System Memory	640 KB	
Extended Memory	95 MB	
Video Controller	S3 Incorporated. TRI064V+	
Cache Size	512 KB	(Note 1)
Cache State	Enabled	
Shadow RAM	384 KB	
System ROM	F000h-FFFFh	
Memory Type	Parity	
Diskette Drive A	2.88 MB 3.5"	(Note 2)
Diskette Drive B	Not Installed	
Hard Disk Drive 0	Not Installed	
Hard Disk Drive 1	Not Installed	
Hard Disk Drive 2	Not Installed	
Hard Disk Drive 3	Not Installed	

#### Notes:

1. If the value of the **Cache Size** is not correct, set it before continuing (see "How to Set the Cache Size Value" on page C-13).
2. The diskette drive can also be a: 1.44 MB 3.5".

**2**

Product Data

Machine type/ Model	7585LG1
Flash EEPROM Revision Level	LVKT21AUS
System Board Identifier	-A123456789
System Serial Number	xxxxxxx
BIOS Date	02/27/97

**3**

## Device and I/O Ports

Mouse	(Not Installed)	
Diskette Drive A:	(2.88 MB 3.5")	<b>(Note)</b>
Diskette Drive B:	(Not Installed)	

- Serial Port Setup...
- Parallel Port Setup...
- Video Setup...
- IDE Drives Setup...

**Note:** The diskette drive can also be a: 1.44 MB 3.5".

## Serial Port Setup

Serial Port A Address	(3F8h)
Serial Port A IRQ	(IRQ 4)
Infra Red Port Address	(Disabled)
Infra Red Port Address	(IRQ 3)

## Parallel Port Setup

Parallel Port	(Disabled)
Parallel Port Mode	(Standard)
Parallel Port Extended Mode	(Bidirectional)
Parallel Port Extended Mode DMA	(No DMA )
Parallel Port IRQ	(IRQ 7)

## Video Setup

Video Controller	S3 Incorporated. trio64V+
Video Memory	1024 KB
DDC Monitor checking	(Enabled)
Video interrupt	(Disabled)
Palette Spooling	(Enabled)

Video Display Type	(Custom )
Monitor Horizontal Frequency	(Not Supported)
Refresh Rate for ( 640 X 480)	(60 Hz)
Refresh Rate for ( 800 X 600)	(60 Hz)
Refresh Rate for (1024 X 768)	(43 Hz Interlaced)
Refresh Rate for (1180 X 1024)	(not supported)
Refresh Rate for (1600 X 1200)	(not supported)

IDE Drives Setup

- Hard Disk Drive 0
- Hard Disk Drive 1
- Hard Disk Drive 2
- Hard Disk Drive 3

Hard Disk Drive 0

Size (Not Installed)

**4**

Date and Time

Time	HH/MM/SS
Date	MM/JJ/YY

**5**

System Security

- Secure Hard Disk Drives and Diskettes Drives
- Power On Password
- Administrator Password

Secure Hard Disk Drives and Diskette Drives

Hard Disk Access (Enable )  
Diskette Drive Access (Enable )

Power-On Password

Enter your new Power-on password twice.

Enter Power-on Password ( )  
Enter Power-on Password Again ( )

Set or Change Power-on Password  
Delete Power-on Password

Password Prompt (ON)

Administrator Password

Enter your new Administrator password twice.

Enter Administrator Password ( )  
Enter Administrator Password Again ( )

Set or Change Administrator Password  
Delete Administrator Password

Power-on Password changeable by user (NO)



**6**

## Start Options

Keyboard Numlock State	(ON)
Keyboard Speed	(Fast)
Diskettes Operation	(Disabled)
Monitorles Operation	(Enabled)
Keyboardles Operation Mode	(Enabled)
First Startup Device	(Diskette Drive 0)
Second Startup Device	(Hard Disk 0 )
Third Startup Device	(Disabled )
Fourth Startup Device	(Disabled )
Power On Self-Test	(Quick) <b>(Note)</b>
Power On Log	(Enabled )
Power On F1/Esc Option	(Enabled )
Virus detection	(Disabled)

**Note:** If you want a complete testing of the network node station at power ON set this parameter to: Enhanced.

**7**

## Advanced Setup

## Warning:

Items on the following menus control advanced Hardware features if they are configured incorrectly, the system might malfunction.

- Memory Control
- Cache Control
- ROM Shadowing
- PCI Control
- Plug and Play Control

## Memory Control

Memory Access Speed (60ns Access)

## Cache Control

Cache State	(Enabled )	
Cache Size	512 KB	<b>(note)</b>

**Note:** You cannot set this value in this procedure. For changing the **Cache Size** value see the "How to Set the Cache Size Value" on page C-13.

### ROM Shadowing

F0000h-FFFFh (System BIOS)	(Enabled)
E8000h-EFFFFh	(Enabled)
E0000h-E7FFFh	(Enabled)
DC000h-DF000h	(Disabled)
D8000h-DB000h	(Disabled)
D4000h-D7000h	(Disabled)
D0000h-D3000h	(Disabled)
CC000h-CF000h	(Disabled)
C8000h-CB000h	(Disabled)
C0000h-C7FFFh (Adapter Video BIOS)	(Enabled)

### PCI Control

PCI Burst Mode (Enabled )

### Plug and Play Control

Set Device Mode (Enabled )

### ISA Legacy Resources

Information: ISA legacy Resources (DMA, Interrupts, Memory, and I/O Ports) are resources that are used by ISA adapter which are not Plug-and-Play adapters. Use this menu to indicate which resources are Used by ISA Legacy adapters. Resources used by the system are already indicated.

- Memory Resources
- I/O Ports Resources
- DMA Resources
- Interrupt Resources

### Memory Resources

A0000h-A3FFFh	(System Resource)
-	-
C6000h-C7FFFh	(System Resource)
C8000h-C9FFFh	(Available )
-	-
DE000h-DFFFFh	(Available )
E0000h-FFFFFh	(System Resource)
100000h-1FFFFh	(Available )
-	-
E00000h-EFFFFFFh	(Available )
F00000h-FFFFFFh	(Available )

### I/O Port Resources

100h-103h	(System Resource)
104h-107h	(System Resource)
108h-10Bh	(Available )
- -	-
170h-173h	(System Resource)
174h-177h	(System Resource)
178h-17Bh	(Available )
- -	-
1ECh-1EFh	(Available )
1F0h-1F3h	(System Resource)
1F4h-1F7h	(System Resource)
1F8h-1FBh	(Available )
- -	-
2F4h-2F7h	(Available )
2F8h-2FBh	(Available )
2FCh-2FFh	(Available )
300h-303h	(Available )
- -	-
370h-373h	(Available )
374h-377h	(System Resource)
378h-37Bh	(Available )
- -	-
3B0h-3B3h	(Available )
3B4h-3B7h	(System Resource)
- -	-
3B8h-3BBh	(System Resource)
3BCh-3BFh	(Available )
3C0h-3C3h	(System Resource)
- -	-
3DCh-3DFh	(System Resource)
3E0h-3E3h	(Available )
- -	-
3ECh-3EFh	(Available )
3F0h-3F4h	(System Resource)
- -	-
3FCh-3FFh	(System Resource)

### DMA Resources

Channel 0	(Available )
Channel 1	(Available )
Channel 2	(System Resource)
Channel 3	(Available )
Channel 4	(Available )
Channel 5	(Available )
Channel 6	(Available )
Channel 7	(Available )

### Interrupt Resources

0	(System Resource)
1	(System Resource)
2	(System Resource)
3	(Available )
4	(System Resource)
5	(Available )
6	(System Resource)
7	(Available )
8	(System Resource)
9	(Available )
10	(Available )
11	(Available )
12	(Available )
13	(System Resource)
14	(Available )
15	(Available )

## 9

### Advanced Power Management

APM BIOS Mode (Enabled )

- Automatic Hardware Power Management
- Activity Monitor
- Automatic Power On

### Automatic Hardware Power Management

Automatic Hardware Power Management	(Enabled)
Time to Level 1 Power Management	(15 min)
System Power	(ON)
Processor Speed	(25% )
Display	(Standby)
Time to Level 2 Power Management	(30 min)
System Power	(ON)
Processor Speed	(01% )
Display	(Suspend)
Time to Level 3 Power Management	(1 hr )
System Power	(ON)
Processor Speed	(01% )
Display	(OFF )
Hard File	(Enabled)

### Activity Monitor

Hard Files	(Enabled)
IRQ 1	(Enabled)
IRQ 2	(Enabled)
IRQ 3	(Enabled)
IRQ 4	(Enabled)
IRQ 5	(Enabled)
IRQ 6	(Enabled)
IRQ 7	(Enabled)
IRQ 8	(Enabled)
IRQ 9	(Disabled)
IRQ10	(Disabled)
IRQ11	(Disabled)
IRQ12	(Enabled)
IRQ13	(Enabled)
IRQ14	(Disabled)
IRQ15	(Disabled)

### Automatic Power On

Serial Port Ring Detect	(Disabled)
Modem Ring Detect	(Disabled)
Wake Up on Alarm	(Disabled)
Alarm Date MM/DD/YY	(MM/DD/YY)
Alarm Time	(HH:mm)

- LAN Wake Up

### LAN Wake Up

#### Warning

The following item controls LAN wake up requests only if a network adapter is installed in your system, the network adapter supports wake up requests, and the network adapter is configured properly

LAN Wake UpDetect	(Disabled)
-------------------	------------

## How to Set the Cache Size Value

- 1** From the **Configuration/Setup Utility** select the **Load Default Settings** option, then press the **Enter** key.
- 2** Exit from the **Configuration/Setup Utility** by selecting **Exit Setup** option.

```
Settings were changed
Do you want save them

Yes, save and exit the Setup utility
No, exit the Setup Utility without saving
No, return to the Setup Utility
```

- 3** Select the **Yes, save and exit the Setup utility** option, then press the **Enter** key.
- 4** When the IBM logo is displayed, press the **F1** key to display again the **Configuration/Setup Utility** and check that the **Cache Size** is well set at 256 KB.
- 5** Return to the procedure where you came from.

## How to check the SCSI Device Configuration (7585-P02)

### Important

To continue this procedure you must have a display and keyboard connected to the network node processor. Refer to "How to Install a Display and Keyboard on your Network Node Processor" on page 3-18.

**1** Power ON the network node processor.

**2** When the following is displayed

```
Adaptec AHA<2940 Ultra/Ultra WBios v1.2  
(c) 1995 Adaptec, Inc. All rights Reserved.
```

```
<<<Press CCtrl><A> for SCSI Select (TM) Utility>>>  
SCSI ID : LUN NUMBER - : - 6:0 - IBM DFH5S2F
```

**3** Press simultaneously the **Ctrl** and the **A** key.

**4** The following screen is displayed:

```
          AHA-2940- Ultra/Ultra W at Bus: Device 00:0Bh  
  
Would you like to configure the host adapter, or run the  
SCSI disk utilities? Select the option and press <Enter>.  
Press <F5> to switch between color and monochrome modes.  
          Options  
    Configure/View Host Adapter Settings  
          SCSI Disk Utilities
```

**5** Select the **Configure/View Host Adapter Settings**

```
          AHA-2940- Ultra/Ultra W at Bus: Device 00:0Bh  
  
Configuration  
  
SCSI Bus Interface Definition  
Host Adapter SCSI ID          7  
SCSI Parity Checking          Enabled  
Host Adapter SCSI Termination Automatic  
  
Additional Option  
Boot Device Options           Press<Enter>  
SCSI Device Configuration     Press<Enter>  
Advanced Configuration Options Press<Enter>  
  
<F6> - Reset to Host Addapter Defaults
```

**6** Select **SCSI Disk Utilities** option, then press **Enter**.



```
      AHA-2940- Ultra/Ultra W at Bus: Device 00:0Bh

      Would you like to configure the host adapter, or run the
      SCSI disk utilities? Select the option and press <Enter>.
      Press <F5> to switch between color and monochrome modes.
      Options
      Configure/View Host Adapter Settings
      SCSI Disk Utilities
```

**7** The following window appears while the SCSI ID number is incrementing.

```
Scanning SCSI ID: LUN Number : xx:0
```

**8** The following window is displayed.

```
      AHA-2940 Ultra/Ultra W at Bus Device 00:0Bh

      Select SCSI Disk and Press Enter

      SCSI ID  0: No Device
      ID  1: No Device
      ID  2: No Device
      ID  3: No Device
      ID  4: No Device
      ID  5: No Device
      ID  6: IBM  XP32275W
      ID  7: AHA-2940 Ultra/ultra W
      ID  8: No Device
      ID  9: No Device
      ID 10: No Device
      ID 11: No Device
      ID 12: No Device
      ID 13: No Device
      ID 14: No Device
      ID 15: No Device
```

Press the **Esc** key until a message ask you if you want to exit from the **Utility**.

Select the **Yes** option and press the **Enter** key. Follow the prompts.

---

## Devices List for the Network Node Processor (3172)

Use the following procedure to view the list of components in the network node processor.

- 1** Insert the **Reference Diskette A** in the network node processor.
- 2** Power ON the network node processor.
- 3** If temporary errors are displayed (code displayed on the operator panel with error LED ON), press **Enter** on the operator panel keypad.

<b>Code</b>	<b>Description</b>
<b>0000</b>	POST
<b>XXXX</b>	Temporary codes
<b>0000</b>	Loading the program
<b>1000</b>	Complete

- 4** Did **0000** appear, followed by **1000** about 90 seconds later?  
**Yes** Continue with the step 5.  
**No** A POST error occurred. Record the error code and refer to *3172 Interconnect Controller Status Codes, GA27-3951* to resolve the error.
- 5** Key in **1**. **1001** appears.
- 6** Press **Enter**. **d5Cb** appears.
- 7** Remove **Reference Diskette A** and insert **Reference Diskette B**.
- 8** Press **Enter**. **d5CC** appears.
- 9** Remove **Reference Diskette B** and insert **Reference Diskette C**.
- 10** Press **Enter**. After a short delay, **A000** appears.
- 11** Key in **1**. **A001** appears.
- 12** Press **Enter**. The first component number appears. Check with the following list.

<b>Code</b>	<b>Description</b>
<b>0146</b>	System board where 46 is the processor type (Pentium)
<b>02xx</b>	SIMMs where x is the amount of memory, in MB
<b>6001</b>	Fixed Disk Adapter
<b>9801</b>	XGA Adapter
<b>A601</b>	Token Ring 16/4
<b>d201</b>	Hard Disk
<b>F001</b>	Diskette drive
<b>F101</b>	Operator panel

**Note:** Additional information on you network node processor can be obtained with a display and keyboard installation, refer to “Additional Information” on page C-18.

## Additional Information

To check the following additional information:

- Devices List (see “Devices List for the Network Node Processor (3172)” on page C-21)
- Hardware Configuration (see “Network Node Processor Hardware Configuration Reference (3172)” on page C-22)
- SCSI Device Configuration (see “SCSI Device Configuration” on page C-21)

you must have a keyboard (QWERTY) and display connected to the network node processor.

Use the following procedure **1** and **2** in order to install the keyboard, the display and have access to the additional information:

When you have obtained the additional information, use procedure **3** to remove display and keyboard.

### **1** Keyboard and Display installation

- a** Power OFF the network node processor
- b** Connect the keyboard and mouse cable on the rear of the network node processor **1**.
- c** Connect the display on the rear of the XGA adapter card, in position 5 of the network node processor **2**.




Figure C-1. Network Node Processor Keyboard and Display Cables Installation

### **2** How to display the additional information

- a** Insert the **Reference Diskette A** in the network node processor
- b** Power ON the network node processor
- c** The **Reference Diskette Main Menu** is displayed.

- d** Select the **2-Diagnostics utilities** then press the **Enter** key.
- e** The **Diagnostic Utilities** is displayed.
- f** From there if you want:
- The **Devices List of the Network Node Processor**, go to step 2g.
  - The **Network Node Processor Hardware Configuration** go to step 2j.
  - The **SCSI Hardware Configuration** go to step 2n.
- g** Select the **1-Diagnostic Test** option and press the **Enter** key.
- h** Follow the prompts to remove the **Diskette Reference A** then insert successively the **Reference Diskette B** and the **Reference Diskette C**.
- i** Key in **1**, then press **Enter** to display the Device list.  
See “Devices List for the Network Node Processor (3172)” on page C-21.
- j** Select the **2-Diagnostics Utilities** option and press **Enter**.
- k** The **Diagnostics Utilities** window is displayed.
- l** Select the **6-Set configuration** option and press **Enter**.
- m** On the next **Set configuration** menu, select the **1-View Configuration** option and press **Enter** to display the hardware configuration.  
See “Network Node Processor Hardware Configuration Reference (3172)” on page C-22.
- n** Select the **2-Diagnostics Utilities** option and press **Enter**.
- o** The **Diagnostics Utilities** window is displayed.
- p** Select the **6-Set configuration** option and press **Enter**.
- q** On the next **Set configuration** menu, select the **7-Set View SCSI Device Configuration** option and press **Enter** to display the SCSI hardware configuration.  
See “SCSI Device Configuration” on page C-21.

### **3 Keyboard and display removal**

- a** Power OFF the network node processor
- b** Disconnect the keyboard and mouse cable on the rear of the network node processor **1**.
- c** Disconnect the display on the rear of the XGA adapter card, in position 5 of the network node processor **2**.




Figure C-2. Network Node Processor Keyboard and Display Cables Removal

## Devices List for the Network Node Processor (3172)

```
90MHz Pentium(tm) CPU Processor Board
Model 95 XP System Board
64MB System Memory, 64MB Enabled
Keyboard
1 Cached SCSI I/O Adapter
XGA-2 Display Adapter/A
Token-Ring Adapter 1
1 SCSI Hard Disks
1 Diskette Drive(s)
Hex Keypad/Display
```

## SCSI Device Configuration

Set and View SCSI Device Configuration

```
SCSI Configuration Verification..... (ENABLED)
Slot 8 - IBM PS/2 SCSI AdapterW/Cache
  SCSI Address (ID)..... 7
  SCSI Device Type..... Hard Disk
  Device Address (ID, LUN)..... 6,0
  Device Size..... 2255MB
  Presence Error Reporting..... (ENABLED)
  Operational Error Reporting.... (ENABLED)
```

# Network Node Processor Hardware Configuration Reference (3172)

View Configuration

## Total System Memory

Installed Memory..... 65536KB (64.0MB) **Note**  
Usable Memory..... 65152KB (63.6MB) **Note**

## Built in Features

Installed Memory..... 65536KB (64.0MB) **Note**  
Diskette Drive 0 Type..... 2.88MB 3.5"  
Diskette Drive 1 Type..... Not Installed  
Diskette Drive 2 Type..... Not Installed  
Math Coprocessor..... Installed  
Display F1 Prompt to Access System pro. YES  
Serial Port..... SERIAL 1  
Serial Transmit Arbitration Level..... Shared 4  
Serial Received Arbitration Level..... Shared 3  
Parallel Port Arbitration Level..... PARALLEL 1  
Parallel Port Arbitration Level..... Shared 7  
Preempt Enable/Disable..... Enable  
Usable System-Board Memory..... ECC  
Bypass System Progress on Error..... Disable  
Processor..... 90MHZ Pentium(tm) CPU

**Slot 1** - Empty

**Slot 2** - Empty

**Slot 3** - Empty

**Slot 4** - Empty

**Slot 5** - XGA-2 Display Adapter/A

Video I/O Address..... Instance 6: 2160h - 216Fh  
1 MB VRAM Aperture Base Address..... Disabled  
Video Arbitration Level..... Arbitration Level 13  
Video Fairness..... Fairness On  
ROM Address Range..... C2000h - C3FFFh

**Slot 6** - Empty

**Slot 7** - IBM Token-Ring Network 16/4 Adapter/A

Primary or Alternate adapter..... Primary  
Adapter Data Rate..... 16 Mbps  
ROM Address Range..... DA000/DBFFF  
RAM Size and Address Range..... 16 KB /DC000-DFFFF  
Interrupt Level..... Interrupt 2

**Slot 8** - IBM PS/2 SCSI AdapterW/Cache

I/O Address..... 3540-3547  
DMA Arbitration Level..... Level C  
Fairness On/Off..... On  
ROM Wait State Disable..... Enable Wait State  
SCSI Adapter Address (ID)..... 7  
ROM Address Range..... No Resources Allocated

**Note:** The memory size may be bigger.



## Appendix D. Network Node Processor External Cable References

### Network Node Processor Cables for the 3746-900




Figure D-1. Network Node Processor Cables for 3746-900

#### Notes:

1. For cable **1** refer to the appropriate *External Cable References* manual.
2. For cable **2**, **3**, **4**, **5**, and **6** refer to the appropriate *Service Processor Installation and Maintenance* manual.
3. For cable **7** and **8** refer to "Cable from the Network Node Processor Processor to the 8228" on page D-3.

## Service Processor and Network Node Processor Cables for the 3746-950




Figure D-2. Service Processor and Network Node Processor Cables for 3746-950

### Notes:

1. For cable **1** refer to the appropriate *External Cable References* manual.
2. For cable **2**, **3**, **4**, **5**, and **6** refer to the appropriate *Service Processor Installation and Maintenance* manual.
3. For cable **7** and **8** refer to "Cable from the Network Node Processor Processor to the 8228" on page D-3.

## Cable from the Network Node Processor Processor to the 8228

Refer to Figure D-1 on page D-1 and Figure D-2 on page D-2 reference **7** for details. This cable is a standard LAN cable.




Figure D-3. LAN Cable

## Interchange Circuit for Standard LAN Cable

Wire Nbr	Wire Color	Connector 1 Position	Connector 2 Position
1	SHIELD	GND	SHIELD
2	ORN	9	ORN
3	BLACK	5	BLACK
4	RED	1	RED
5	GREEN	6	GREEN

Cable Type	Length, m (ft)	Feature Code	Cable PN
Standard Fixed	2.4 m (8)	9088	6339098

**Note:** Some new network node processor LAN adapter cards (with a RJ45 connector) need an additional adapter cable **8** (PN 60G1066) to connect the standard LAN cable.




Figure D-4. Adapter Cable (PN 60G1066)

*Table D-3. Adapter Cable Pin Assignment*

9 Pin D Connector (P1)	RJ45 Connector (P2)	Wire color
9	6	ORN
5	3	BLK
1	4	RED
6	5	GRN

# Appendix E. Bibliography

## Customer Documentation for the 3746 Model 950












<p><i>Table E-1 (Page 1 of 2). Customer Documentation for the 3746 Model 950</i></p>		
<p>This customer documentation has the following formats:</p>		
 <p>Books</p>	 <p>Online</p>	 <p>Books and Diskettes</p>
<p><b>Finding Information</b></p>		
<p><b>3745 Models A and 3746 Books</b></p> <p>Starting with engineering change (EC) F12380, all of the books in the 3745 Models A and 3746 library are available on the CD-ROM that contains the Licensed Internal Code (LIC) for this EC.</p>		
<p><b>Preparing for Operation</b></p>		
	<p>GA33-0400</p>	<p><b>IBM 3745 Communication Controller All Models<sup>1</sup></b>  <b>IBM 3746 Expansion Unit Model 900</b>  <b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>Safety Information<sup>2</sup></b></p> <p>Provides general safety guidelines</p>
<p><b>Evaluating and Configuring</b></p>		
	<p>GA33-0180</p>	<p><b>IBM 3745 Communication Controller Models A<sup>3</sup></b>  <b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Overview</b></p> <p>Gives an overview of connectivity capabilities within SNA, APPN, and IP networking.</p>
	<p>GA33-0457</p>	<p><b>IBM 3745 Communication Controller Models A<sup>2</sup></b>  <b>IBM 3746 Expansion Unit Model 900 Models 900 and 950</b></p> <p><b>Planning Guide</b></p> <p>Planning for:</p> <ul style="list-style-type: none"> <li>• Field upgrades</li> <li>• Service processor and alert management configuration</li> <li>• Network integration (NCP, APPN, and IP control)</li> <li>• Physical installation.</li> </ul>



Table E-1 (Page 2 of 2). Customer Documentation for the 3746 Model 950

<b>Operating and Testing</b>		
	SA33-0356	<p><b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>User's Guide<sup>2</sup></b></p> <p>Explains how to:</p> <ul style="list-style-type: none"> <li>• Carry out daily routine operations on Nways controller</li> <li>• Install, test, and customize the Nways controller after installation</li> <li>• Configure user's workstations to remotely control the service processor using:                             <ul style="list-style-type: none"> <li>– DCAF program</li> <li>– Telnet client program.</li> </ul> </li> </ul>
	On-line information	<p><b>Controller Configuration and Management Application</b></p> <p>Provides a graphical user interface for configuring and managing a 3746 APPN/HPR network node and IP Router, and its resources. Is also available as a stand-alone application, using an OS/2 workstation. Defines and explains all the 3746 Network Node and IP Router configuration parameters through its on-line help.</p>
	SH11-3081	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Controller Configuration and Management: User's Guide<sup>2</sup></b></p> <p>Explains how to use CCM and gives examples of the configuration process.</p>
<b>Managing Problems</b>		
	On-line information	<p><b>Problem Analysis Guide</b></p> <p>An on-line guide to analyze alarms, events, and control panel codes on:</p> <ul style="list-style-type: none"> <li>• IBM 3745 Communication Controller Models A<sup>3</sup></li> <li>• IBM 3746 Nways Multiprotocol Controller Models 900 and 950.</li> </ul>
	SA33-0175	<p><b>IBM 3745 Communication Controller Models A<sup>3</sup></b>  <b>IBM 3746 Expansion Unit Model 900</b>  <b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>Alert Reference Guide</b></p> <p>Provides information about events or errors reported by alerts for:</p> <ul style="list-style-type: none"> <li>• IBM 3745 Communication Controller Models A<sup>3</sup></li> <li>• IBM 3746 Nways Multiprotocol Controller Models 900 and 950.</li> </ul>
<p><sup>1</sup> Models 130 to 61A.  <sup>2</sup> Documentation shipped with the 3746-950  <sup>3</sup> 3745 Models 17A to 61A.</p>		

## Service Documentation for the IBM 3746 Model 950

Table E-2 (Page 1 of 2). Service Documentation for the 3746 Model 950

This service documentation has the following formats:



SY33-2107

**IBM 3746 Nways Multiprotocol Controller Model 950  
Installation Guide<sup>1</sup>**

Provides instructions for installing or relocating the Nways Controller.



SY33-2108

**IBM 3746 Nways Multiprotocol Controller  
Model 950  
Service Guide<sup>1</sup>**

Provides procedures for isolating and fixing the IBM 3746-950 problems.



SY33-2115

**IBM 3745 Communication Controller Models A<sup>2</sup>  
IBM 3746 Expansion Unit Model 900  
IBM 3746 Nways Multiprotocol Controller Model 950  
Service Processor Installation and Maintenance<sup>3</sup>  
(Based on the 7585, 3172, 9585, or 9577)**

Provides information on installing and maintaining the service processor based on PS/2 Types 7585, 3172, 9585, or 9577. Can be for systems with microcode that has up to and including EC D46130 (any level) installed.



SY33-2120

**IBM 3745 Communication Controller Models A<sup>3</sup>  
IBM 3746 Expansion Unit Model 900  
IBM 3746 Nways Multiprotocol Controller Model 950  
Service Processor Installation and Maintenance<sup>4</sup>  
(Based on the 7585, 3172, or 9585)**

Provides information on installing and maintaining the service processor based on PS/2 Types 7585, 3172, or 9585. Can be for systems with microcode EC F12380 or higher installed.









SY33-2118

**IBM 3746 Nways Multiprotocol Controller Models 900 and 950  
Multiaccess Enclosure Installation and Maintenance<sup>4</sup>**

Provides information on installing and maintaining the Multiaccess Enclosure (MAE).

Table E-2 (Page 2 of 2). Service Documentation for the 3746 Model 950


	SY33-2112	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Network Node Processor Installation and Maintenance<sup>3</sup></b>  <b>(Based on the 7585 or 3172)</b></p>
<p>Provides information on installing and maintaining the network node processor based on the PS/2 Type 7585 or 3172.</p>		
	SY33-2117	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>External Cable Reference<sup>4</sup></b></p>
<p>Provides references to console and line cables used for connecting the IBM 3746 Models 900 and 950.</p>		
	S135-2015	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Parts Catalog<sup>4</sup></b></p>
<p>Provides reference information for ordering parts for the IBM 3746 Models 900 and 950.</p>		
	S135-2014	<p><b>IBM Controller Expansion</b></p> <p><b>Parts Catalog</b></p>
<p>Provides reference information for ordering parts for the controller expansion attached to the IBM 3745 Models A<sup>2</sup>, and 3746 Models 900 and 950.</p>		
<b>CD-ROM Bibliography</b>		
	ZK2T-8214	<p><b>IBM Networking</b></p> <p><b>Softcopy Collection Kit</b></p>
<p>Allows service manuals consulting via CD-ROM viewer. EMEA version.</p>		
	ZK2T-8187	<p><b>IBM Networking</b></p> <p><b>Softcopy Collection Kit</b></p>
<p>Allows service manuals consulting via CD-ROM viewer. US version.</p>		
<p><sup>1</sup> Documentation shipped with the 3746 Model 950  <sup>2</sup> 3745 Models 17A to 61A  <sup>3</sup> Documentation shipped with the processor  <sup>4</sup> Documentation shipped with the 3746 Models 900 and 950</p>		



# Customer Documentation for the 3745 (Models 210, 310, 410, 610, 21A, 31A, 41A, and 61A), and 3746 (Model 900)

Table E-3 (Page 1 of 4). Customer Documentation for the 3745 Models X10 and X1A, and 3746 Model 900

This customer documentation has the following formats:



## Finding Information

### **3745 Models A and 3746 Books**

Starting with engineering change (EC) F12380, all of the books in the 3745 Models A and 3746 library are available on the CD-ROM that contains the Licensed Internal Code (LIC) for this EC.



SA33-0172

### **IBM 3745 Communication Controller Models 210 to 61A IBM 3746 Expansion Unit Model 900**

#### **Customer Master Index<sup>1</sup>**

Provides references for finding information in the customer documentation library.

## Evaluating and Configuring



GA33-0092

### **IBM 3745 Communication Controller Models 210, 310, 410, and 610**

#### **Introduction**

Gives an introduction of the IBM Models 210 to 610 capabilities.  
For Models A refer to the *Overview*, GA33-0180.



GA33-0180

### **IBM 3745 Communication Controller Models A<sup>2</sup> IBM 3746 Nways Multiprotocol Controller Models 900 and 950**

#### **Overview**

Gives an overview of connectivity capabilities within SNA, APPN, and IP networking.

Table E-3 (Page 2 of 4). Customer Documentation for the 3745 Models X10 and X1A, and 3746 Model 900

	GA33-0457	<p><b>IBM 3745 Communication Controller Models A<sup>2</sup></b>  <b>IBM 3746 Expansion Unit Model 900</b>  <b>Models 900 and 950</b></p> <p><b>Planning Guide</b></p> <p>Planning for:</p> <ul style="list-style-type: none"> <li>• Field upgrades</li> <li>• Service processor and alert management configuration</li> <li>• Network integration (NCP, APPN, and IP control)</li> <li>• Physical installation.</li> </ul>
<b>Preparing Your Site</b>		
	GC22-7064	<p><b>IBM System/360, System/370, 4300 Processor</b></p> <p><b>Input/Output Equipment Installation Manual-Physical Planning</b>  (Including Technical News Letter GN22-5490)</p> <p>Provides information for physical installation for the 3745 Models 130 to 610. For 3745 Models A and 3746 Model 900, refer to the <i>Planning Guide</i>, GA33-0457.</p>
	GA33-0127	<p><b>IBM 3745 Communication Controller</b>  <b>Models 210, 310, 410, and 610</b></p> <p><b>Preparing for Connection</b></p> <p>Helps for preparing the 3745 Models 210 to 610 cable installation. For 3745 Models A refer to the <i>Connection and Integration Guide</i>, SA33-0129.</p>
<b>Preparing for Operation</b>		
	GA33-0400	<p><b>IBM 3745 Communication Controller All Models<sup>3</sup></b>  <b>IBM 3746 Nways Multiprotocol Controller</b>  <b>Models 900 and 950</b></p> <p><b>Safety Information<sup>1</sup></b></p> <p>Provides general safety guidelines.</p>
	SA33-0129	<p><b>IBM 3745 Communication Controller All Models<sup>3</sup></b>  <b>IBM 3746 Nways Multiprotocol Controller Model 900</b></p> <p><b>Connection and Integration Guide<sup>1</sup></b></p> <p>Contains information for connecting hardware and integrating network of the 3745 and 3746-900 after installation.</p>
	SA33-0416	<p><b>Line Interface Coupler Type 5 and Type 6</b>  <b>Portable Keypad Display</b></p> <p><b>Migration and Integration Guide</b></p> <p>Contains information for moving and testing LIC types 5 and 6.</p>

Table E-3 (Page 3 of 4). Customer Documentation for the 3745 Models X10 and X1A, and 3746 Model 900















	SA33-0158	<p><b>IBM 3745 Communication Controller All Models<sup>3</sup></b>  <b>IBM 3746 Nways Multiprotocol Controller Model 900</b></p> <p><b>Console Setup Guide<sup>1</sup></b></p>
<p>Provides information for:</p> <ul style="list-style-type: none"> <li>• Installing local, alternate, or remote consoles for 3745 Models 130 to 610</li> <li>• Configuring user workstations to remotely control the service processor for 3745 Models A and 3746 Model 900 using: <ul style="list-style-type: none"> <li>– DCAF program</li> <li>– Telnet Client program.</li> </ul> </li> </ul>		
<b>Customizing Your Control Program</b>		
	SA33-0178	<p><b>Guide to Timed IPL and Rename Load Module</b></p>
<p>Provides VTAM procedures for:</p> <ul style="list-style-type: none"> <li>• Scheduling an automatic reload of the 3745</li> <li>• Getting 3745 load module changes transparent to the operations staff.</li> </ul>		
<b>Operating and Testing</b>		
	SA33-0098	<p><b>IBM 3745 Communication Controller All Models<sup>4</sup></b></p> <p><b>Basic Operations Guide<sup>1</sup></b></p>
<p>Provides instructions for daily routine operations on the 3745 Models 130 to 610.</p>		
	SA33-0177	<p><b>IBM 3745 Communication Controller Models A<sup>2</sup></b>  <b>IBM 3746 Nways Multiprotocol Controller Model 900</b></p> <p><b>Basic Operations Guide<sup>1</sup></b></p>
<p>Provides instructions for daily routine operations on the 3745 Models 17A to 61A, and 3746 Model 900 operating as an SNA node (using NCP), APPN/HPR Network Node, and IP Router.</p>		
	SA33-0097	<p><b>IBM 3745 Communication Controller All Models<sup>3</sup></b></p> <p><b>Advanced Operations Guide<sup>1</sup></b></p>
<p>Provides instructions for advanced operations and testing, using the 3745 MOSS console.</p>		
	On-line Information	<p><b>Controller Configuration and Management Application</b></p>
<p>Provides a graphical user interface for configuring and managing a 3746 APPN/HPR Network Node and IP Router, and its resources. Is also available as a stand-alone application, using an OS/2 workstation. Defines and explains all the 3746 Network Node and IP Router configuration parameters through its online help.</p>		

Table E-3 (Page 4 of 4). Customer Documentation for the 3745 Models X10 and X1A, and 3746 Model 900

	SH11-3081	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Controller Configuration and Management: User's Guide<sup>5</sup></b></p>
Explains how to use CCM and gives examples of the configuration process.		
<b>Managing Problems</b>		
	SA33-0096	<p><b>IBM 3745 Communication Controller All Models<sup>3</sup></b></p> <p><b>Problem Determination Guide<sup>1</sup></b></p>
A guide to perform problem determination on the 3745 Models 130 to 61A.		
	On-line Information	<p><b>Problem Analysis Guide</b></p>
An online guide to analyze alarms, events, and control panel codes on:		
<ul style="list-style-type: none"> <li>• IBM 3745 Communication Controller Models A<sup>2</sup></li> <li>• IBM 3746 Nways Multiprotocol Controller Models 900 and 950.</li> </ul>		
	SA33-0175	<p><b>IBM 3745 Communication Controller Models A<sup>2</sup></b></p> <p><b>IBM 3746 Expansion Unit Model 900</b></p> <p><b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>Alert Reference Guide</b></p>
Provides information about events or errors reported by alerts for:		
<ul style="list-style-type: none"> <li>• IBM 3745 Communication Controller Models A<sup>2</sup></li> <li>• IBM 3746 Nways Multiprotocol Controller Models 900 and 950.</li> </ul>		
<p><sup>1</sup> Documentation shipped with the 3745.</p> <p><sup>2</sup> 3745 Models 17A to 61A.</p> <p><sup>3</sup> 3745 Models 130 to 61A.</p> <p><sup>4</sup> Except 3745 Models A.</p> <p><sup>5</sup> Documentation shipped with the 3746-900.</p>		



## Additional Customer Documentation for the 3745 Models 130, 150, 160, 170, and 17A

Table E-4. Additional Customer Documentation for the 3745 Models 130 to 17A		
This customer documentation has the following format:		
		
Finding Information		
	SA33-0142	<p><b>IBM 3745 Communication Controller Models 130, 150, 160, 170, and 17A IBM 3746 Nways Multiprotocol Controller Model 900 Customer Master Index<sup>1</sup></b></p> <p>Provides references for finding information in the customer documentation library.</p>
Evaluating and Configuring		
	GA33-0138	<p><b>IBM 3745 Communication Controller Models 130, 150, and 170 Introduction</b></p> <p>Gives an introduction about the IBM Models 130 to 170 capabilities, including Model 160.</p> <p>For Model 17A refer to the <i>Overview</i>, GA33-0180.</p>
Preparing Your Site		
	GA33-0140	<p><b>IBM 3745 Communication Controller Models 130, 150, 160, and 170 Preparing for Connection</b></p> <p>Helps for preparing the 3745 Models 130 to 170 cable installation.</p> <p>For 3745 Model 17A refer to the <i>Connection and Integration Guide</i>, SA33-0129.</p>
<p><sup>1</sup> Documentation shipped with the 3745.</p>		

# Service Documentation for the IBM 3745 (Models 210, 21A, 310, 31A, 410, 41A, 610, and 61A) and 3746 (Model 900)

Table E-5 (Page 1 of 4). Service Documentation for the 3745 Models x10 and x1A, and 3746 Model 900

This service documentation has the following formats:



## 3745 Models A and 3746 Books

Starting with engineering change (EC) F12380, all of the books in the 3745 Models A and 3746 library are available on the CD-ROM that contains the Licensed Internal Code (LIC) for this EC.



SY33-2080

### **IBM 3745 Communication Controller Models 210 to 61A Service Master Index<sup>1</sup>**

Provides references for finding information in the IBM 3745 Models X10 and X1A shipping group documentation.



SY33-2057

### **IBM 3745 Communication Controller Models 210 to 61A Installation Guide<sup>1</sup>**

Provides instructions for installing or relocating the IBM 3745 Models X10 and X1A.



SY33-2114

### **IBM 3746 Nways Multiprotocol Controller Model 900 Installation Guide<sup>2</sup>**

Provides instructions for installing or relocating a 3746-900.



SY33-2116

### **IBM 3746 Nways Multiprotocol Controller Model 900 Service Guide<sup>2</sup>**

Provides procedures for isolating and fixing the IBM 3746-900 problems.



SY33-2055

### **IBM 3745 Communication Controller Models 210, 310, 410, and 610 IBM 3746 Expansion Units Models A11, A12, L13, L14, and L15 Service Functions<sup>1</sup>**

Describes MOSS functions using the IBM 3745 Models X10 and X1A consoles.

Table E-5 (Page 2 of 4). Service Documentation for the 3745 Models x10 and x1A, and 3746 Model 900








	SY33-2054	<p><b>IBM 3745 Communication Controller Models 210 to 61A</b></p> <p><b>Maintenance Information Procedures<sup>1</sup></b></p>
<p>Provides procedures for isolating and fixing the IBM 3745 Models X10 and X1A problems.</p>		
	SY33-2115	<p><b>IBM 3745 Communication Controller Models A<sup>3</sup></b>  <b>IBM 3746 Expansion Unit Model 900</b>  <b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>Service Processor Installation and Maintenance<sup>4</sup></b>  <b>(Based on the 7585, 3172, 9585, or 9577)</b></p>
<p>Provides information on installing and maintaining the service processor based on PS/2 Types 7585, 3172, 9585, or 9577.          Can be for systems with microcode that has up to and including EC D46130 (any level) installed.</p>		
	SY33-2120	<p><b>IBM 3745 Communication Controller Models A<sup>3</sup></b>  <b>IBM 3746 Expansion Unit Model 900</b>  <b>IBM 3746 Nways Multiprotocol Controller Model 950</b></p> <p><b>Service Processor Installation and Maintenance<sup>4</sup></b>  <b>(Based on the 7585, 3172, or 9585)</b></p>
<p>Provides information on installing and maintaining the service processor based on PS/2 Types 7585, 3172, or 9585.          Can be for systems with microcode EC F12380 or higher installed.</p>		
	SY33-2118	<p><b>IBM 3746 Nways Multiprotocol Controller Models 900 and 950</b></p> <p><b>Multiaccess Enclosure Installation and Maintenance<sup>4</sup></b></p>
<p>Provides information on installing and maintaining the Multiaccess Enclosure (MAE).</p>		
	SY33-2112	<p><b>IBM 3746 Nways Multiprotocol Controller</b>  <b>Models 900 and 950</b></p> <p><b>Network Node Processor Installation and Maintenance<sup>4</sup></b>  <b>(Based on the 7585 or 3172)</b></p>
<p>Provides information on installing and maintaining the network node processor based on the PS/2 Type 7585 or 3172.</p>		
	SY33-2056	<p><b>IBM 3745 Communication Controller</b>  <b>Models 210 to 61A</b></p> <p><b>Maintenance Information Reference<sup>1</sup></b></p>
<p>Provides in-depth hardware reference information on the IBM 3745 Models X10 and X1A.</p>		

Table E-5 (Page 3 of 4). Service Documentation for the 3745 Models x10 and x1A, and 3746 Model 900




SY33-2075

**IBM 3745 Communication Controller  
All Models<sup>5</sup>**

**External Cable References<sup>1</sup>**

Provides references to console and line cables used for connecting the IBM 3745 Models 130 to 61A.




SY33-2117

**IBM 3746 Nways Multiprotocol Controller  
Models 900 and 950**

**External Cable Reference<sup>6</sup>**

Provides references to console and line cables used for connecting the IBM 3746 Models 900 and 950.



S135-2015

**IBM 3746 Nways Multiprotocol Controller  
Models 900 and 950**

**Parts Catalog<sup>6</sup>**

Provides reference information for ordering parts for the IBM 3746 Models 900 and 950.



S135-2010

**IBM 3745 Communication Controller  
Models 210 to 61A**

**Parts Catalog<sup>1</sup>**

Provides reference information for ordering IBM 3745 Models X10 and X1A parts.



S135-2014

**IBM Controller Expansion**


**Parts Catalog**

Provides reference information for ordering parts for the controller expansion attached to the IBM 3745 Models A<sup>3</sup>, and 3746 Models 900 and 950.



Table E-5 (Page 4 of 4). Service Documentation for the 3745 Models x10 and x1A, and 3746 Model 900


**CD-ROM Bibliography**



ZK2T-8214

**IBM Networking  
Softcopy Collection Kit**

Allows service manuals consulting via CD-ROM viewer. EMEA version.



ZK2T-8187

**IBM Networking  
Softcopy Collection Kit**


Allows service manuals consulting via CD-ROM viewer. US version.

- <sup>1</sup> Documentation shipped with the 3745.
- <sup>2</sup> Documentation shipped with the 3746-900.
- <sup>3</sup> 3745 Models 17A to 61A.
- <sup>4</sup> Documentation shipped with the processor.
- <sup>5</sup> 3745 Models 130 to 61A.
- <sup>6</sup> Documentation shipped with the 3746 Models 900 and 950.

## Additional Service Documentation for the IBM 3745 Models 130, 150, 160, 170, and 17A

Table E-6. Additional Service Documentation for the 3745 Models 1x0 and 17A

This service documentation has the following formats:




SY33-2079

**IBM 3745 Communication Controller  
Models 130, 150, 160, 170, and 17A**

**Service Master Index<sup>1</sup>**

Provides references for finding information in the IBM 3745 Models 1X0 and 17A shipping group documentation.




SY33-2067

**IBM 3745 Communication Controller  
Models 130, 150, 160, 170, and 17A**

**Installation Guide<sup>1</sup>**

Provides instructions for installing or relocating the IBM 3745 Models 1X0 and 17A.




SY33-2069

**IBM 3745 Communication Controller  
Models 130, 150, 160, and 170**

**Service Functions<sup>1</sup>**

Describes MOSS functions using the IBM 3745 Models 1x0 and 17A consoles.




SY33-2070

**IBM 3745 Communication Controller  
Models 130 to 17A**

**Maintenance Information Procedures<sup>1</sup>**

Provides procedures for isolating and fixing the IBM 3745 Models 1X0 and 17A problems.




S135-2012

**IBM 3745 Communication Controller  
Models 130 to 17A**

**Parts Catalog<sup>1</sup>**

Provides reference information for ordering IBM 3745 Models 1X0 and 17A parts.



SY33-2066

**IBM 3745 Communication Controller  
Models 130, 150, 160, and 170**

**Hardware Maintenance Reference<sup>1</sup>**

Provides in-depth hardware reference information on the IBM 3745 Models 1X0 and 17A.

<sup>1</sup> Documentation shipped with the 3745.

---

# Glossary

**ac.** alternating current

**ACPW.** AC power (box)

**AFD.** airflow detector

**alarm.** A message sent to the MOSS console. In case of an error a reference code identifies the nature of the error.

**alert.** A message sent to the host console. In case of an error a reference code identifies the nature of the error.

**AMD.** air moving device

**APPN.** advanced peer-to-peer networking

**ARC.** active remote connector

**ARC1A1.** ARC V.24 DCE attachment with 5 meter tethered cable

**ARC1A2.** ARC V.24 DCE attachment with 15 meter tethered cable

**ARC1B.** ARC V.24 DTE attachment with 15 meter tethered cable

**ARC1C.** ARC V.24 DCE 3745 interface with 5 meter tethered cable

**ARC1D.** ARC V.24 DTE 3745 interface with 5 meter tethered cable

**ARC1E.** ARC V.24 3174 AEA interface (1)

**ARC1F.** ARC V.24 3174 PCA EIA interface (1)

**ARC2A.** ARC V.25 autocal interface with 5 meter tethered cable

**ARC2C.** ARC V.25 autocal interface 3745 with 5 meter tethered cable

**ARC3A1.** ARC V.35 DCE attachment with 5 meter tethered cable

**ARC3A2.** ARC V.35 DCE attachment with 15 meter tethered cable

**ARC3B.** ARC V.35 DTE attachment with 15 meter tethered cable

**ARC3C.** ARC V.35 DCE 3745 interface with 5 meter tethered cable

**ARC3D.** ARC V.35 DTE 3745 interface with 5 meter tethered cable

**ARC4A1.** ARC X.21 DCE attachment with 5 meter tethered cable

**ARC4A2.** ARC X.21 DCE attachment with 15 meter tethered cable

**ARC4B.** ARC X.21 DTE attachment with 15 meter tethered cable

**ARC4C.** ARC V.21 DCE 3745 interface with 5 meter tethered cable

**ARC4D.** ARC V.21 DTE 3745 interface with 5 meter tethered cable

**ARC5A.** Reserved

**ARC5B.** Reserved

**ARC5C.** ARC RS-422 3708 interface (or RJ-11 connection) (1)

**ARC5D.** ARC RS-422 IBM Cabling System interface (1)

**ARC6A.** ARC V.25 autocal interface with 15 meter tethered cable

**ARC6C.** ARC V.25 autocal 3745 interface with 15 meter tethered cable

**BA.** basic access

**BAS.** basic board

**BATS.** basic assurance tests

**BER.** box event record

**BLPU.** basic level packaging unit

**BMI.** bit multiplex interface

**box event record (BER).** Information about an event detected by the controller. It is recorded on the disk/diskette and can be displayed on the operator console for event analysis.

**bps.** bits per second

**BSC.** binary synchronous communication

**BSI.** bus synchronism interface

**C.** Celsius

**C&SM.** customer and service information

**CA.** channel adapter

**cache.** A high-speed buffer storage that contains frequently accessed instructions and data; it is used to reduce access time.

**CB.** circuit breaker

**CBA.** controller bus adapter

**CBC.** controller bus coupler

**CBR.** circuit burst request

**CBSA.** controller bus and service adapter (CBSP+CBC+TIC3)

**CBSP.** controller bus and service processor

**CBTRA.** controller bus and token-ring adapter (TRP+CBC+TIC3)

**CBTRM.** cable terminator (IOC and DMA buses)

**CCITT.** Comite Consultatif International Telephonique et telegraphique

**CCU.** central control unit

**CDF.** configuration data file (3745)

**CDF-E.** configuration data file extended (37CS)

**CE.** customer engineer

**CEPT.** Comite Europeen des Postes et Telecommunications

**CLA.** communication line adapter (CLP+LICnn)

**CLDP.** controller load/dump program

**clear channel.** Mode of data transmission where the data passes through the DCE and network, and arrives at the receiving communication controller (for example, the IBM 3745) unchanged from the data transmitted. The DCE or network can modify the data during transmission because of certain network restrictions, but must ensure the received data stream is the same as the transmitted data stream.

**CLP.** communication line processor

**CMIP.** common management interface protocol

**CNM.** communication network management

**CP.** 1.communication processor 2.control program 3.circuit protector 4.control point

**CPLR.** coupler

**CPN.** customer problem number

**CPx.** FRU name of circuit protector

**CRC.** cyclic redundancy check character

**CS.** connectivity switch

**CSA.** common subassembly

**CSB.** connectivity switch bus

**CSC.** connectivity switch cable

**CSCE.** connectivity switch cable extension

**CSM.** centralized support module

**CSP.** central service point

**CSS.** control subsystem (3745)

**CTDA.** configuration target device (processor) address

**dc.** direct current

**DCAF.** Distributed Console Access Facility (licensed program)

**DCCS.** DC to connectivity subsystem

**DCE.** data circuit-terminating equipment

**DCDP.** DC distribution and protection (box)

**DCM.** diagnostic control monitor

**DCPW.** DC power box

**DICO.** DMA IOC connection card

**DM.** distribution manager

**DMA.** direct memory access

**DS.** data storage

**DSB.** data storage bus

**DSI.** data storage interface

**DSM.** data storage manager

**DSS.** data storage interface for SBA

**DSU.** data service unit (DCE-like for high-speed communication lines)

**DTE.** data terminal equipment

**EC.** engineering change

**EE.** extended edition

**EIA.** Electronic Industries Association

**EPO.** emergency power-off

**EPROM.** erasable PROM

**ESCA.** ESCON adapter

**ESCC.** ESCON coupler

**ESCON\*.** Enterprise Systems Connection

**ESCP.** ESCON processor

**ESD.** electrostatic discharge

**EXP.** expansion enclosure

**EXP1.** first expansion enclosure

**EXP2.** second expansion enclosure

**FCS.** frame check sequence

**FRU.** field-replaceable unit

**HCS.** Hardware Central Service

**HDLC.** high-level data link control

**hex.** hexadecimal

**host processor.** (1) A processor that controls all or part of a user application network. (2) In a network, the processing unit in which the access method for the network resides. (3) In an SNA network, the processing unit that contains a system services control point (SSCP). (4) A processing unit that executes the access method for attached communication controllers. Also called *host*.

**HPPB.** high-performance parallel bus

**HSC.** hardware support center

**HSF.** hardware service facility

**Hz.** Hertz

**IBM service representative.** An individual in IBM who performs maintenance services for IBM products or systems.

**IEEE.** Institute of Electrical and Electronics Engineers

**IML.** initial microcode load

**initial microcode load (IML).** The process of loading the microcode into a scanner or into MOSS.

**initial program load (IPL).** The initialization procedure that causes the 3745 control program to commence operation.

**IO.** input/output

**IOC.** input/output control

**IOCB.** input/output control bus

**IPL.** initial program load

**IRAM.** instruction random access memory

**ISO.** International Organization for Standardization

**kbps.** kilobits per second

**LA.** line adapter

**LAN.** local area network

**LCB.** line connection box

**LED.** light-emitting diode

**LIC.** line interface coupler

**LICx.** FRU name of line interface coupler type x (3745)

**LLC.** logical link control

**LS.** local storage

**LSA.** link service architecture

**LSCT.** LIM software configuration table

**LSM.** local storage manager

**LSSD.** level-sensitive scan design (total hardware latches chain collection)

**LU.** logical unit

**MAC.** medium access control

**MAE.** Multiaccess enclosure

**MAP.** maintenance analysis-procedure

**MAU.** multistation access unit

**MB.** megabyte; 1 048 576 bytes

**MCF.** microcode fix

**MCL.** microcode change level

**MES.** miscellaneous equipment specification

**MG.** motor generator

**MI.** maskable interrupt

**microcode.** A program, that is loaded in a processor (for example, the MOSS processor)

**MLA.** MOSS LAN adapter

**MMIO.** memory mapped input/output

**maintenance and operator subsystem (MOSS).** The part of the controller that provides operating and servicing facilities to the customer's operator and the IBM service representative.

**MOSS.** maintenance and operator subsystem (3745)

**MOSS-E.** maintenance and operator subsystem extended (37CS)

**NA.** network addressable

**NCP.** Network Control Program

**NDM.** netview distribution manager

**NetView.** An IBM licensed program used to monitor a network, manage it, and diagnose its problems.

**Network Control Program (NCP).** An IBM licensed program that provides communication controller support for single-domain, multiple-domain, and interconnected network capability.

**NMI.** non-maskable interrupt

**NMVT.** network management vector transport

**NNP.** network node processor

**NODA.** next origin device (processor) address

**NPM.** NetView performance monitor

**NTDA.** next target device (processor) address

**OEMI.** original equipment manufacturer's interface

**OLT.** online test

**online tests.** Testing of a remote data station concurrently with the execution of the user's programs (that is, with only minimal effect on the user's normal operation).

**OSI.** open system interconnect

**PA.** primary access

**PBC.** packet burst control

**PBG.** packet burst grant

**PCR.** 1.pico-processor command register 2.power check reset

**PICA.** process and intertask communication architecture

**PMH.** problem management hardware

**PN.** part number

**PNL.** control panel

**POR.** power-ON reset

**PP.** pico-processor

**PPB.** primary power box

**PRC.** processor

**PRDA.** packet request device (processor) address

**PROM.** programable read-only memory

**PS.** power supply

**PSI.** packet switch interface

**PSN.** public switched network

**PTCE.** product-trained CE

**PTF.** program temporary fix

**PTT.** Post, Telephone and Telegraph (agency)

**PU.** physical unit

**RETAIN.** Remote Technical Assistance Information Network

**RNR.** receiver not ready

**RPL.** remote program load

**RPO.** remote power-off

**RSC.** remote service center

**RSF.** remote support facility

**RVX.** stands for RS232, RS422, V.24-35, X.21-2x connections

**SATS.** specific assurance tests

**SBA.** switch bus adapter

**SBI.** switch bus interface

**SC.** switch control

- SDLC.** synchronous data link control
- SL.** service logic
- SNA.** Systems Network Architecture
- SNMP.** Simple network management protocol
- SPD1.** signal and power distribution type 1
- SPD2.** signal and power distribution type 2
- SPDL.** signal and power distribution card in LCB
- SPS.** service and power support
- SQL.** structured query language
- SRC.** system reference code
- SSA.** system service architecture
- SSCP.** system services control point
- STCn.** signal transfer card n
- SSS.** subsystem support service
- Systems Network Architecture (SNA).** The description of the logical structure, formats, protocols, and operational sequences for transmitting information through a user application network. The structure of SNA allows the users to be independent of specific telecommunication facilities.
- TB.** terminator block
- TDM.** time division multiplexing
- TDR.** technical data record
- TERC.** terminator card
- TIC1.** token-ring interface coupler type 1 (3745) running at speed of 4 Mbits
- TIC2.** token-ring interface coupler type 2 (3745) running at speed of 4 or 16 Mbits
- TIC3.** token-ring interface coupler type 3 (37CS) running at speed of 4 or 16 Mbits
- time out.** The time interval allotted for certain operations to occur.
- TPS.** two-processor switch
- TR.** token-ring
- TRA.** token-ring adapter (TRP+TIC3)
- TRFM.** transformer
- TRP.** token-ring processor
- TRS.** transmitter/receiver subassembly
- UEPO.** unit emergency power-off
- URSF.** universal remote support facility
- UTP.** Unshielded twisted pair cable
- V.** volt
- V.24.** CCITT V.24 recommendation
- V.25.** CCITT V.25 recommendation
- V.28.** CCITT V.28 recommendation
- V.35.** CCITT V.35 recommendation
- VPD.** vital product data
- VTAM\*.** Virtual Telecommunications Access Method
- VTL.** vendor technology logic
- W.** watt
- X.21.** CCITT X.21 recommendation
- X.25.** CCITT X.25 recommendation
- YZxxx.** wiring diagram





---

# Index

## Numerics

7585 network node processor  
other FRU exchange 5-46

## A

addresses  
IP in the LAN A-1

## C

cable  
From the network node processor to the 8228 D-3  
Controller Expansion Component locations B-1  
Controller Expansion locations

## D

diagnostics  
how to run  
network node processor diagnostics 5-32

## F

Function  
accessing a Network Node Processor 2-13  
accessing CCM 2-10  
accessing IP commands 2-15  
accessing the Network Node Processor  
functions 2-3  
activate a configuration 2-9  
changing the active LIC on a NNP-A 2-7  
changing/restoring LIC on a NNP-A 2-16  
dump a control point 2-9  
exporting a configuration 2-11  
importing a configuration 2-10  
installing/removing a NNP-A 2-4  
modifying IP parameters 2-8  
restoring the LIC on a NNP-A 2-6  
shutdown and restart a NNP-A 2-9  
start / stop a control point 2-9  
stop and restart a control point 2-9  
upgrading the LIC on a NNP-A 2-5

## H

How to  
check the hardware configuration C-18  
check the SCSI device configuration C-18  
run the network node processor diagnostics 5-32  
view the device list C-18

## I

Installation  
7585 system unit NNP-A 1-7  
7585 System unit NNP-B 1-10  
network node processor 1-1  
preparation 1-3  
System unit 1-14, 1-20

## L

leaving procedure

## M

Managing the Network Node Processor and the control  
point 2-1

## N

network node processor D-1, D-2  
board or battery exchange 5-36  
cables for 3746-900 D-1  
cables for 3746-950 D-2  
diagnostics 5-32  
FRU exchange 4-1, 5-34  
general information 2-2  
hard disk drive exchange 5-43  
LAN adapter exchange 5-38  
network node processor aids C-1  
overview 1-2  
problem determination 3-1  
troubleshooting 5-2  
typical devices list C-21  
network node processor configuration (7585-P02) C-1

## P

parameter  
worksheet A-1  
processor  
battery exchange 4-19  
hard disk drive exchange 4-11  
LAN adapter exchange 4-9  
other FRUs exchange 4-21  
processor card exchange 4-14  
SCSI card exchange 4-17  
system board 4-19

## S

service processor D-2  
cables for 3746-950 D-2

service processor (*continued*)  
external cable references D-1

---

## Readers' Comments — We'd Like to Hear from You

**3746 Nways Multiprotocol Controller  
Models 900 and 950  
Network Node Processor  
Installation and Maintenance  
(based on 7585 or 3172)  
Publication No. SY33-2112-03**

Please send us your comments concerning this book. We will greatly appreciate them and will consider them for later releases of the present book.

If you prefer sending comments by FAX or electronically, use:

- FAX: 33 4 93 24 77 97
- E-mail: FRIBMQF5 at IBMMAIL
- IBM Internal Use: LGERCF at LGEPROFS
- Internet: rcf\_lagaude@vnet.ibm.com

In advance, thank you.

Your comments:

\_\_\_\_\_  
Name

\_\_\_\_\_  
Address

\_\_\_\_\_  
Company or Organization

\_\_\_\_\_  
Phone No.



Fold and Tape

Please do not staple

Fold and Tape

PLACE  
POSTAGE  
STAMP  
HERE

IBM France  
Centre d'Etudes et Recherches  
Service 0798 - BP 79  
06610 La Gaude  
France

Fold and Tape

Please do not staple

Fold and Tape





Part Number: 29H4650

Printed in Denmark by IBM Danmark A/S

