

8275 Model 416 High Performance Ethernet
Workgroup Switch



User's Guide

8275 Model 416 High Performance Ethernet
Workgroup Switch



User's Guide

Note

Before using this information and the product it supports, be sure to read "Appendix A. Safety Information" on page 81 and "Appendix B. Notices" on page 93.

Second Edition (August 1999)

This edition applies to Release 1.1 of the IBM 8275 Model 416 High Performance Ethernet Workgroup Switch.

Order publications through your IBM representative or the IBM branch office serving your locality. Publications are not stocked at the address given below.

A form for readers' comments appears at the back of this publication. If the form has been removed, address your comments to:

Department CGF
Design & Information Development
IBM Corporation
PO Box 12195
Research Triangle Park NC 27709
U.S.A.

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

© **Copyright International Business Machines Corporation 1999. All rights reserved.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Figures	vii
Tables	ix
About this guide	xi
Who should use this guide	xi
How this guide is organized	xi
Accessing the softcopy library	xii
Online support.	xii
Obtaining service.	xii
Summary of Changes	xiii
Chapter 1. Introduction	1
Product overview.	1
Switch functions	1
Layer 2 switching	1
Virtual local area networks (VLANs)	2
Management and user interfaces	2
Security	3
Reliability and serviceability	3
Performance	3
Year 2000 (Y2K) Compliance	4
Hardware	4
Cabling requirements	4
Front panel	5
Switch LED status	7
Single-digit display	8
Base ports LEDs	9
Feature module LEDs	10
Physical characteristics	13
Chapter 2. Accessing the switch	15
Types of Connectivity	15
Out-of-band connection	15
In-band connection – Telnet, Web, SNMP.	17
Chapter 3. Configuring your switch	21
Configuring IP information	21
Remote configuration using DHCP or BootP.	21
Manual configuration using the terminal interface	21
Configuration Changes	23
Making configuration changes using the terminal interface	23
Making configuration changes using the Web interface	25
Making configuration changes using SNMP	26
Managing the configuration file.	26
Chapter 4. Using the Terminal Interface	27
Login panel.	27
The Main Menu	28
System information	28
Inventory information	29
System description	29

Management	31
Configuring network connection for the switch	31
Configuring serial port	33
Configuring for DHCP or BootP	34
Configuring the SNMP community	35
Configuring traps	38
Configuring Telnet	40
Ping	41
ARP cache	42
Device configuration	44
Configuring the switch	44
Configuring ports	45
Configuring port monitoring	46
Configuring spanning tree protocol (STP)	48
VLAN management	50
Statistics	55
Port summary statistics	56
Port detailed statistics	56
Switch summary statistics	57
Switch detailed statistics	58
Forwarding database information	58
User account management	59
System utilities	60
Saving applied changes	60
Logging out	60
Handling files	61
Reset utility	65
System reset menu	65
Resetting configuration data to factory default values	66
Resetting passwords to factory default values	67
Chapter 5. Using the Web Interface	69
Configuring for Web Access	69
Web Page Layout	69
Starting the Web Interface	70
Commands	70
Chapter 6. Using the SNMP Interface	73
MIBs supported	73
MIB II (RFC 1213)	73
Definitions of managed objects for bridges (RFC 1493)	74
IEEE 802.3 Ethernet MIB (RFC 1643)	74
Remote monitoring (RMON) MIB (RFC 1757)	75
IBM 8275-416 switch enterprise MIB	75
Port ifIndex values	75
Chapter 7. Troubleshooting and Obtaining Service	77
Diagnosing Problems	77
Obtaining Software	77
Troubleshooting in a Network	77
Start of Troubleshooting Process	77
Choosing a Troubleshooting Procedure	78
Procedure A	78
Procedure B	78
Procedure C	79
Procedure D	79

Procedure E	80
Obtaining Service	80
Appendix A. Safety Information.	81
Reference to Safety Booklet.	81
Safety Notice	86
Appendix B. Notices	93
Electronic Emission Notices.	94
Federal Communications Commission (FCC) Statement	94
Industry Canada Class A Emission Compliance Statement	94
Avis de conformité aux normes d'Industrie Canada	94
European Norm (EN) Statement	94
Japanese Voluntary Control Council for Interference (VCCI) Statement	95
Korean Communications Statement	95
Power line harmonics compliance	95
Taiwanese Class A Warning Statement.	96
Class 1 Laser Statement	96
Class 1 LED Statement	96
Trademarks.	96
Appendix C. Cable Pinout Diagrams	99
Straight-Through 10BASE-T/100BASE-TX Cables.	99
Straight-Through 10BASE-T/100BASE-TX Cables for STP	100
Crossover 10BASE-T/100BASE-TX Cables	100
Crossover 10BASE-T/100BASE-TX Cables for STP	101
EIA-232 Port	101
Null-Modem Cables	102
Appendix D. Interface Conventions for the Console.	103
Appendix E. Introduction to Virtual LANs (VLANs)	107
Virtual LANs	107
Benefits of VLANs	107
How VLANs ease change and movement.	107
How VLANs control broadcast traffic	107
How VLANs provide extra security	107
VLANs and the switch	108
Priority and traffic classes	108
Overview of IEEE 820.1Q VLAN support	109
Configuration examples	110
Using unique MAC addresses	113
Duplicate VLAN configurations and oversubscription of switch resources	113
Index	115
Glossary	123
Readers' Comments — We'd Like to Hear from You.	127

Figures

1. Front panel of the switch.	5
2. LEDs for the switch.	7
3. LEDs for the base 10/100BASE-TX ports on the switch.	9
4. LEDs for the 8-port 10/100BASE-TX feature module.	10
5. LEDs for the 8-port 100BASE-FX feature module.	11
6. LEDs for the 4-port 100BASE-FX feature module.	12
7. Out-of-band connectivity - locally attached terminal	16
8. Out-of-band connectivity - remotely attached terminal	16
9. In-band connection	18
10. Configuring BootP/static DHCP and network connection (IP information).	22
11. Login panel for terminal interface	27
12. Main menu for terminal interface	28
13. System information menu	29
14. Inventory information menu	29
15. System description menu	30
16. Management menu	31
17. Network connection configuration	32
18. Serial port configuration	33
19. SNMP community configuration	36
20. SNMP trap receiver configuration	37
21. Trap flags configuration	38
22. Trap log	39
23. Trap log status.	40
24. Telnet configuration	41
25. Ping.	42
26. ARP cache	43
27. Device configuration.	44
28. Switch configuration.	44
29. Port configuration.	45
30. Port monitoring	48
31. Spanning tree switch configuration/status	49
32. Spanning tree port configuration/status	50
33. VLAN management menu.	51
34. VLAN summary and configuration.	51
35. VLAN Configuration Menu	52
36. GARP configuration	53
37. 802.1Q port configuration	54
38. VLAN reset	55
39. Statistics Menu	56
40. Port summary statistics	56
41. Port detailed statistics	57
42. Switch summary statistics.	57
43. Switch detailed statistics	58
44. Forwarding database information	58
45. User account management	59
46. Save applied changes	60
47. Logout utility	61
48. Downloading a file to the switch	63
49. Uploading a file from the switch	64
50. System Reset menu.	65
51. System reset menu	66
52. Reset configuration data to factory defaults	67
53. Reset passwords to factory defaults	67

54. Web interface panel—example	70
55. Straight-Through UTP Cable (RJ-45 to RJ-45), T568A	99
56. Straight-Through UTP Cable (RJ-45 to RJ-45), T568B	99
57. Straight-Through STP Cable (RJ-45 to IBM Data Connector)	100
58. Crossover UTP Cable (RJ-45 to RJ-45), T568A.	100
59. Crossover UTP Cable (RJ-45 to RJ-45), T568B.	100
60. Crossover STP Cable (RJ-45 to IBM Data Connector Crossover)	101
61. Pinout of the EIA-232 Port	101
62. EIA-232 Null Modem Cable for Terminal with 25-Pin Connector	102
63. EIA-232 Null Modem Cable for Terminal with 9-Pin Connector	102
64. An Example of VLANs	108
65. Untagged device to untagged device configuration	110
66. 802.1Q-compliant device (tagging and GVRP) to 802.1Q-compliant device (tagging and GVRP) configuration.	111
67. Untagged device to 802.1Q compliant device (tagging and GVRP) configuration	112
68. Untagged device to 802.1Q-compliant device (tagging only) configuration	113

Tables

1.	Ethernet cable requirements	4
2.	LED status for the switch..	7
3.	Problem indications on the single-digit display when the Fault LED is ON.	8
4.	Status of LEDs for 16 base 10/100BASE-TX ports	9
5.	Status of LEDs for 8-port 10/100BASE-TX feature module.	10
6.	Status of LEDs for 8-port 100BASE-FX feature module	11
7.	Status of LEDs for 4-port 100BASE-FX feature module	12
8.	Summary of physical characteristics for the switch	13
9.	Connection methods and available user interfaces	15
10.	Messages - while downloading files	61
11.	Messages - while uploading files	62
12.	MIBs Supported by the Switch..	73
13.	Troubleshooting Symptoms and Actions	78
14.	Special Keys and Commands Used with the Terminal Interface	103
15.	Acceptable VLAN configurations with no feature modules	114

About this guide

This guide briefly describes the features and capabilities of the 8275 Model 416 High Performance Ethernet Workgroup Switch. However, its primary purpose is to describe how to use the capabilities offered by the switch to configure, obtain status information, and monitor performance of the switch in your network.

Who should use this guide

This guide is intended for the network administrator or person responsible for integrating, maintaining and monitoring the switch in your network. The person responsible for coordinating installation and service for the switch will also find this manual useful.

How this guide is organized

This guide contains the following chapters and appendixes:

- “Chapter 1. Introduction” on page 1 describes the functions and capabilities of the switch.
- “Chapter 2. Accessing the switch” on page 15 describes the various physical methods of accessing the switch.
- “Chapter 3. Configuring your switch” on page 21 describes initial configuration of IP information.
- “Chapter 4. Using the Terminal Interface” on page 27 describes the using functions of the terminal interface.
- “Chapter 6. Using the SNMP Interface” on page 73 contains information about using SNMP to manage the switch.
- “Chapter 5. Using the Web Interface” on page 69 introduces the Web interface.
- “Chapter 7. Troubleshooting and Obtaining Service” on page 77 gives suggestions for solving problems obtaining service.
- “Appendix A. Safety Information” on page 81 contains translated safety instructions to observe when performing troubleshooting procedures.
- “Appendix B. Notices” on page 93 lists important notices about the use of this product.
- “Appendix C. Cable Pinout Diagrams” on page 99 describes and illustrates pinout diagrams for Ethernet and null-modem cable connectors.
- “Appendix D. Interface Conventions for the Console” on page 103 describes the definitions and functions of special keys and commands that are used by the terminal interface.
- “Appendix E. Introduction to Virtual LANs (VLANs)” on page 107 briefly introduces concepts and terminology about virtual local area Networks (VLANs).

Accessing the softcopy library

Softcopy versions of 8275-416 product documentation are available from either the Documentation CD-ROM (shipped with the product) or the IBM Networking Products Web site. To access product documentation shipped on the CD-ROM, follow the instructions in the booklet that accompanies the CD-ROM. Visit the following Web site to access the 8275-416 documentation at:

<http://www.ibm.com/networking/support/docs.nsf/8275docs?OpenView>

Online support

To obtain support information, including technical tips, current product information, and code updates and fixes for the switch, visit the IBM Networking Tech Support page at:

<http://www.ibm.com/networking/support>

You may also subscribe to receive e-mail notifications about code updates, tips, and FAQs for your switch.

Obtaining service

If you need assistance in troubleshooting or you need service for your 8275-416, call IBM at:

- 1-800-772-2227 in the United States
- 1-800-426-7378 (1-800-IBM-SERV) in Canada.
- In other locations, contact your place of purchase.

Refer to your IBM Warranty for information concerning service for the product.

Summary of Changes

Changes in this revision are indicated with revision bars in the left margin and reflect:

- Revisions or additions from the Release Notes for Operational Code Version 1.0 (June 1999)
- The addition of the 4-Port 100BASE-FX Ethernet Feature Module
- The addition of the VLAN function (as well as VLAN and Spanning Tree Protocol introductory information)
- The addition of a new chapter about using SNMP to manage the switch
- All new terminal interface panels throughout Chapter 4 that reflect redesign and changes since Release 1.0 of the product.
- General editorial changes

Chapter 1. Introduction

This chapter briefly describes the functions, capabilities, and benefits of the 8275 Model 416 High Performance Ethernet Workgroup Switch. This information helps you to plan for and use the switch in your network.

Product overview

Fast Ethernet switching continues to evolve from high-end backbone applications to desktop-switching applications. The switch provides a low-cost and powerful Layer 2 switch solution. It is an attractive base switch offering with the following key functions:

- High-performance, Layer 2, managed switch
- 16 base ports (10/100BASE-TX), expandable from 20 to 32 even-numbered ports. The expansion can be with any combination of the following optional feature modules:
 - 8-Port 10/100BASE-TX
 - 8-Port 100BASE-FX
 - 4-Port 100BASE-FX
- Robust management support; VT100 terminal interface, Web interface, SNMP
- Backplane performance 10 gigabits per second Ethernet switching
- Desktop and segment switching infrastructure
- Affordable migration to higher-performance networks

As a network administrator, you have a choice of three easy-to-use management methods: VT100 terminal interface, Web-based, and Simple Network Management Protocol (SNMP). These management methods enable you to configure, manage, and control the switch locally or from anywhere on the network.

The Spanning Tree Protocol (STP) provides fault tolerance on the network.

Switch functions

This section describes the functional support included in the switch:

- Layer 2 switching
- Virtual local area networks (VLANs)
- Management and user interface
- Security
- Reliability and serviceability
- Performance
- Flow Control
- Year 2000 (Y2K) compliance

Layer 2 switching

The 8275-416 is a Layer 2 Ethernet switch in which frame forwarding is based on MAC addresses and VLAN membership. The switch supports the IEEE 802.1D (1998) and 802.1Q standards.

802.3x flow control

The switch supports 802.3x flow control, which, when enabled, allows the transmission of data frames to be inhibited for a specified period of time. The default for 802.3x flow control is *Disabled*. 802.3x flow control is valid only when the port is in full-duplex mode.

Broadcast storm recovery

The switch detects broadcast storms and automatically blocks broadcast traffic to minimize the impact of the broadcast storm on the rest of the network. You can enable or disable this function at a switch level. If broadcast storm recovery is enabled, each port will monitor incoming broadcast traffic. If the broadcast traffic exceeds 20 percent of the port speed, the broadcast traffic on this port is blocked until the broadcast traffic returns to 10 percent or below port speed. The default for broadcast storm recovery is *Disabled*.

Forwarding database

The switch port MAC addresses are stored in the forwarding database. An address learned by the switch is removed from the forwarding database after a period of time if no frames have been received from that address. The default value for the aging period is 300 seconds (5 minutes), but it can be changed by the user. The time values range from 10 seconds to 600 seconds.

The switch forwarding database stores 12 000 entries. When the database is full, no new entries are learned until an existing entry ages out. All frames with unknown destination addresses are multicast to all ports in the appropriate VLAN.

Virtual local area networks (VLANs)

The switch supports VLANs. “Appendix E. Introduction to Virtual LANs (VLANs)” on page 107 provides an introduction to VLANs. It describes concepts and terminology, as well as, the benefits of using VLANs. The switch is manageable only through the ports which are members of the Default VLAN (VLAN 1).

Figure 34 on page 51 and Figure 35 on page 52 show examples of the panels and descriptions of the parameters used to configure VLANs and add VLANs.

Management and user interfaces

Note: The switch is manageable using the Ethernet network only through the ports which are members of the Default VLAN (VLAN 1).

You have a choice of these easy-to-use management methods:

- A VT100 terminal interface allows you to fully manage the switch using a standard terminal or terminal emulator connected over the network using Telnet or connected to the switch’s serial port (EIA 232).
“Chapter 2. Accessing the switch” on page 15 describes how to access the switch using this interface and “Chapter 4. Using the Terminal Interface” on page 27 instructs you about using this interface.
- A Web-based interface enables you to manage the switch through standard Web browsers. There must be a physical path between the Web browser and the switch over the Ethernet network to use this method of connectivity.

“Chapter 2. Accessing the switch” on page 15 describes how to access the switch using this interface and “Chapter 5. Using the Web Interface” on page 69 instructs you about using this interface.

- The switch has a Simple Network Management Protocol (SNMP) agent that the network administrator can access with a standard network manager. The following MIBs (Management Information Base) are supported:
 - MIB II (RFC 1213)
 - 8275-416 Enterprise MIB
 - RMON MIB (RFC 1757)
 - Bridge MIB (RFC 1493)
 - IEEE 802.3 Ethernet (RFC 1643)
- The switch interoperates with the following SNMP Managers:
 - Any standard MIB browser (SNMPv1)
 - IBM Nways[®] Manager for Windows NT[®] (V2.0 or later)
 - IBM Nways Manager for HP-UX (V2.0 or later)
 - IBM Nways Manager for AIX[®] (V2.0 or later)

Security

User access security can be implemented using the following functions of the 8275-416:

- User Accounts: The switch supports up to six accounts (one user with read/write status and five with read-only status) for terminal interface and Web access. Access to the switch configuration panels is password protected. Only one user name with read/write status is allowed to be configured, which prevents potential conflicts in configuration changes. The default Read/Write user name is: *admin*, and the default password consists of blanks (no password). If you lose the password, contact your IBM service representative.
- SNMP read/write protection based on community name.

Reliability and serviceability

The switch:

- Provides a comprehensive power-on self-test (POST) that ensures that all of its components are functioning correctly.
- Controls a seven-segment LED that allows you to follow the boot sequence.
- Allows you to download software upgrades using any of the management methods.
- Allows you to implement parallel paths for network traffic through the use of spanning tree protocol (STP), which provides a level of fault tolerance and ensures that:
 - Redundant paths are disabled when the main paths are operational
 - Redundant paths are enabled if the main paths fail
- Allows you to configure a port to “see” traffic going into and out of another port on the switch (port monitoring).
- Provides statistics for all ports.

Performance

High performance, Layer 2 switching for the switch consists of:

- Switching for up to 32 ports
- Supporting up to 12 000 end stations

- Processing 64-byte packets at the following rates:
 - 14 880 packets per second to 10-Mbps ports.
 - 148 800 packets per second to 100-Mbps ports
- Detecting broadcast storms and preventing them from impacting the network (Broadcast Storm Recovery).

Year 2000 (Y2K) Compliance

The 8275-416 is Y2K compliant.

When used in accordance with its associated documentation, it is capable of correctly processing and/or receiving date data within and between the 20th and 21st centuries providing all other products (for example, hardware, software, and firmware) used with the switch properly exchange accurate date data.

For additional information about Year 2000 related topics, visit:

<http://www.ibm.com/year2000>

Hardware

Cabling requirements

Ethernet cables are *not* provided and must be separately purchased. You can order them through your IBM representative.

Table 1 shows cable type and length requirements. Cable requirements depend on the speed of the network. Cables and connecting hardware must meet the standards specified in the ANSI/TIA/EIA 856-A or CSA T529 standards.

Table 1. Ethernet cable requirements

Ethernet Type	Cable Requirements	Max. Cable Length
10BASE-T	Category 3, 4 or 5 100-ohm STP/UTP cable	100 m (328 ft)
100BASE-TX	Category 5, 100-ohm STP or UTP cable and connecting hardware	100 m (328 ft)
100BASE-FX	62.5-micron multimode fiber (MMF) cabling	2 km (6561 ft) at full- duplex; 412 m (1352 ft) at half-duplex

10/100BASE-TX

10BASE-T connections are MDX ports and operate correctly with standard Category 3, 4, or 5 100-ohm UTP or STP cable and connecting hardware, as specified in the ANSI/TIA/EIA 856-A or CSA T529 standards when connected to MDI ports. When connecting to other MDX ports, such as ports of other 8275-416 switches, you must use crossover cables.

Do not use telephone extension cables in 10/100BASE-TX networks. The wire pairs in those cables are not twisted and the cables do not meet other requirements for use in a 10BASE-T network.

For connections to 10/100BASE-TX networks, you can use only Category 5 STP or UTP cables.

100BASE-FX

For connection to 100BASE-FX networks, you can use only 62.5/125 MMF cabling with MTRJ connectors.

Front panel




Figure 1. Front panel of the switch.

Switch LEDs

Switch LEDs are located at the lower left corner of the front panel (left of the single-digit display) and are identified with a vertical bar (I), OK, and Fault. The LED identified with the vertical bar and the OK LED are Green; the Fault LED is amber. The states of the LEDs are *on*, *off*, or *blinking*. They are explained later in this chapter.

Single-Digit Display

The single-digit display is located at the lower left corner of the front panel as shown in Figure 2 on page 7. During diagnostics, the character displayed indicates the diagnostic test being executed. Once the switch is operational, the character displayed is its unit ID (Table 3 on page 8).

Serial Port (EIA 232)

The serial port is a standard DB-9 male connector that provides an EIA 232 serial interface (sometimes referred to as the out-of-band management port). Use a null-modem serial cable when connecting to a workstation (“Appendix C. Cable Pinout Diagrams” on page 99). Use a VT100 terminal emulator program to configure your terminal’s attached COM port as follows:

- 19200 baud
- 8 data bits
- 1 stop bit
- No parity
- Hardware flow control OFF

See “Chapter 2. Accessing the switch” on page 15 for more information about connectivity.

Ethernet 10/100BASE-TX Ports

The switch has 16 Ethernet 10/100BASE-TX ports. Each port has two LEDs located at the lower right and left of the connector. Status indications of the Port LEDs are explained later in this chapter.

Feature Module Slots 1 and 2

These feature modules are available to expand port connections for your switch:

- 8-Port 10/100BASE-TX Ethernet Feature Module, P/N 30L6661

- 8-Port 100BASE-FX Ethernet Feature Module, P/N 30L6662
- 4-Port 100BASE-FX Ethernet Feature Module, P/N 31L4054

Switch LED status

Switch LEDs are shown in Figure 2 and LED status is explained in the table that follows:




Figure 2. LEDs for the switch.

Table 2. LED status for the switch.

LEDs			Explanation
I (Green)	OK (Green)	Fault (Yellow)	
Off	Off	Off	No power is present, or there is a power supply failure. The switch is not operational.
On	On	Off	The switch is operational.
On	Blinking	Off	Configuration file or Operational Code file transfer is in process. Do not power-off or reset the switch.
On	Off	On	There is a hardware fault. The switch is not operational.
On	Off	Blinking	Diagnostics are in process. The switch is not yet operational.

Note: Any other state of the LEDs indicates an LED failure.

Single-digit display

The single-digit display (shown in Figure 2 on page 7) displays characters while diagnostics are running after power is applied to the switch. At the successful completion of diagnostics, the unit number appears in the display (for example, “1” indicates Unit Number 1). Table 3 gives the meaning of other digits that can be displayed and the corrective actions required.

Table 3. Problem indications on the single-digit display when the Fault LED is ON.

Character	Problem	Corrective Action
d	Board RAM problem	Replace the switch.
3	Detected an unsupported feature module.	Remove the feature module and update the operational code, or the feature module is not fully seated in its connector.
4	PIF fault on the feature module or base board.	If feature module Fault LED is On, remove the feature module. If no feature module Fault LED is On, replace the switch.
5 or 6	Non-volatile memory problem.	Replace the switch.
7	Switch memory problem.	Replace the switch.
8	Base board loopback problem.	Replace the switch.
9 or a	Feature module loopback problem.	<ul style="list-style-type: none">• 9 = Feature module in Slot 1 has the fault; remove this feature module.• a = Feature module in Slot 2 has the fault; remove this feature module.

Base ports LEDs

The switch has 16 base 10/100BASE-TX ports. LED status for these 16 base ports are shown in Figure 3 and they are explained in Table 4.




Figure 3. LEDs for the base 10/100BASE-TX ports on the switch

Table 4. Status of LEDs for 16 base 10/100BASE-TX ports

LED	Color	State	Explanation
Right Ethernet Port LED	Green	ON	Indicates a 100-Mbps port.
		OFF	Indicates a 10-Mbps port.
Left Ethernet Port LED	Green	ON	The link is up.
		OFF	The link is down.
		Blinking	Transmitting (Tx) and Receiving (Rx) traffic.

Feature module LEDs

Each feature module has an OK and a Fault LED located at the left side of the faceplate. The OK LED is green and the Fault LED is yellow. LED locations are shown in Figure 4, Figure 5 on page 11, and Figure 6 on page 12; LED status of the feature modules are explained in Table 5, Table 6 on page 11, and Table 7 on page 12.

Status LEDs for the 8-port 10/100BASE-TX ethernet feature module




Figure 4. LEDs for the 8-port 10/100BASE-TX feature module.

Table 5. Status of LEDs for 8-port 10/100BASE-TX feature module

LED	Color	State	Explanation
OK	Green	ON	There is power to feature module.
		OFF	There is no power to feature module, no power to the switch, or the module has failed.
Fault	Yellow	ON	There is a module fault.
		OFF	There is no module fault.
Right Ethernet Port LED	Green	ON	Indicates a 100-Mbps port.
		OFF	Indicates a 10-Mbps port.
Left Ethernet Port LED	Green	ON	The link is up.
		OFF	The link is down.
		Blinking	Transmitting (Tx) and Receiving (Rx) traffic.

Status LEDs for the 8-port 100BASE-FX ethernet feature module




Figure 5. LEDs for the 8-port 100BASE-FX feature module.

Table 6. Status of LEDs for 8-port 100BASE-FX feature module

LED	Color	State	Explanation
OK	Green	ON	There is power to the feature module.
		OFF	There is no power to the feature module, no power to the switch, or the module has failed.
Fault	Yellow	ON	There is a module fault.
		OFF	There is no module fault.
Port LED	Green	ON	Link is up.
		OFF	Link is down.
		Blinking	Transmitting (Tx) and receiving (Rx) traffic.

Status LEDs for the 4-port 100BASE-FX ethernet feature module




Figure 6. LEDs for the 4-port 100BASE-FX feature module.

Table 7. Status of LEDs for 4-port 100BASE-FX feature module

LED	Color	State	Explanation
OK	Green	ON	There is power to the feature module.
		OFF	There is no power to the feature module, no power to the switch, or the module has failed.
Fault	Yellow	ON	There is a module fault.
		OFF	There is no module fault.
Port LED	Green	ON	Link is up.
		OFF	Link is down.
		Blinking	Transmitting (Tx) and receiving (Rx) traffic.

Physical characteristics

Table 8 summarizes the physical characteristics for the switch:

Table 8. Summary of physical characteristics for the switch

Characteristic	Specification
Physical Dimensions	Height 63.0 mm (2.48 in.) 1.5 EIA rack units
	Width 440.0 mm (17.16 in.)
	Depth 355.6 mm (14 in.)
Weight (estimate)	6.0 kg (13 lb)
Minimum Service Clearance	Front 15.3 mm (6 in.) for cooling, cables, and to view LEDs
	Sides 50 mm (2 in.) for cooling
	Rear 15.3 mm (6 in.) for cooling and power cord
Environment	Operating Temperature 10° - 40° C (50° - 104° F)
	Operating Humidity 8% - 80%
	Storage Temperature 1° - 60° C (33.8° - 140° F)
	Storage Humidity 8% - 80%
	Shipment Temperature -40°C - 60°C (-40°F - 140°F)
	Shipment Humidity 5% - 100%

Chapter 2. Accessing the switch

This chapter explains the types of connections that you can use to physically access the switch. Once the connection is established, you will configure the IP information (either through the terminal interface or through DHCP or BootP), and then choose which user interface you want to use to manage it. Therefore, all interfaces support configuring the switch and obtaining information from it, thus providing greater flexibility in how you manage your switch.

Types of Connectivity

There are two connection methods used to physically access the switch:

- Out-of-band connectivity, which provides access to the switch through the EIA 232 port.
- In-band connectivity, which provides access to the switch from a remote station using the Ethernet network

Table 9 outlines the user interfaces that are available depending on your method of connection.

Table 9. Connection methods and available user interfaces

Type of Connection	Available User Interface
Out-of-band	Terminal interface via the EIA 232 port (terminal directly attached, or remotely attached to modem)
In-band	<ul style="list-style-type: none">• Terminal interface via Telnet• SNMP-based management interface• Web-based management interface

Out-of-band connection

Out-of-band connection lets you access your switch through the serial EIA 232 port. It can be either through a locally attached PC running VT100 terminal emulation software, or through a remotely attached PC running VT100 terminal emulation software connected to a modem.

Locally attached terminal

To establish out-of-band connectivity using a locally attached terminal, make the physical connections and set up using the following procedure:

1. Attach one end of a null-modem cable to the EIA 232 port of the switch as shown in Figure 7 on page 16, and the other end to the COM port of your PC (see “Appendix C. Cable Pinout Diagrams” on page 99).




Figure 7. Out-of-band connectivity - locally attached terminal

2. Configure the VT100 terminal emulation application as follows:
 - Baud rate: 19200
 - Parity: None
 - Data bits: 8
 - Stop bits: 1
 - Flow control: None
3. Log in to the terminal interface. The terminal interface requires you to log in with a user name and password. The user name can have either Read/Write or Read Only status. The default Read/Write user name is *admin* and the password consists of blanks (no password). The default Read Only user name is *guest* and the password consists of blanks (no password).
4. See "Appendix D. Interface Conventions for the Console" on page 103 for a description of terminal interface key definitions. You may need to configure your terminal emulation application to enable the use of these keys.

Remotely attached terminal

To establish out-of-band connectivity using a remotely attached terminal, make the physical connections using the following procedure:

1. Unpack the modem and install it according to the manufacturer's instructions.
2. Attach one end of the serial cable (not provided) to the EIA 232 port of the switch and the other end to your modem as shown in Figure 8.




Figure 8. Out-of-band connectivity - remotely attached terminal

3. Set up the modem that is attached to the switch by following these steps:
 - a. Configure the modem to use the same settings as those on your switch.

- Baud rate: 19200
 - Parity: None
 - Data bits: 8
 - Stop bits: 1
 - Flow control: None
- b. Configuration command syntax varies from modem to modem. Make sure that the modem has the following characteristics:
 - Asynchronous mode
 - Disable modem response
 - Disable flow control (for example, AT \Q)
 - Disable echo (for example, AT Q1)
 - Autoanswer mode on second ring (for example, AT SO=2)
 - Dumb mode - (No response in/out AT commands). This enables it to act as a “pass thru” device (setting the modem to dumb mode [])
 - c. Set up the remote modem and terminal.
 - d. After configuring the modem, save the configuration.
 - e. Establish a modem link as described in the modem user documentation.
 - f. Login to the terminal interface. The terminal interface requires you to login with a user name with read/write or read-only status and a password. The default read/write user name is *admin* and the password consists of blanks (no password). The default read-only user name is *guest* and the password consists of blanks (no password).
 - g. See “Appendix D. Interface Conventions for the Console” on page 103 for a description of terminal interface key definitions. You may need to configure your terminal emulation application to enable use of these keys.
4. To use in-band connectivity, you must configure the switch with IP information (IP address, subnet mask, and default gateway), and the port being used to access the switch must be on the Default VLAN (VLAN 1). You can configure IP information initially by using either of these methods:
 - DHCP or BootP
 - Terminal interface via the EIA 232 port.

To configure the IP information, see “Chapter 3. Configuring your switch” on page 21 for details.

In-band connection – Telnet, Web, SNMP

Note: To use in-band connectivity, you must configure the switch with its IP information (IP address, subnet mask, and default gateway), and have a path available through the Default VLAN (VLAN 1). See “Chapter 3. Configuring your switch” on page 21 for configuring BootP or DHCP and IP information for your switch.

In-band connectivity allows access to the switch using the data network (as shown in Figure 9 on page 18).




Figure 9. In-band connection

Terminal Interface – Telnet

Telnet console management can be performed through an Ethernet port (in-band connection). You must configure an IP address before using Telnet console management (Refer to “Chapter 3. Configuring your switch” on page 21 for initially configuring IP information for your switch).

You can use any Telnet application that emulates a VT100 terminal to establish a Telnet console management session. Up to five concurrent Telnet sessions are supported. For security, the Telnet session can be automatically logged off after a certain time of inactivity. You can configure the time of inactivity from 0 to 160 minutes; the default is 5 minutes.

The terminal interface is menu-driven and can be used to manage the switch through the EIA 232 port or a Telnet session. For security, a login user ID and password are required. Multiple user IDs and associated passwords can be created. Two levels of access privileges are supported: read/write and read only.

See “Appendix D. Interface Conventions for the Console” on page 103 for a description of the terminal keys. You may need to configure your terminal application to enable use of these keys.

See “Chapter 4. Using the Terminal Interface” on page 27 for a description of the terminal interface panels.

SNMP-Based Management Interface

The switch has an SNMP agent that supports SNMP Version 1 which allows it to be managed by any SNMP-based application (for example, Nways Campus Manager which supports the MIBs that the switch supports). See “Chapter 6. Using the SNMP Interface” on page 73 for details about the MIBs supported by the switch.

Web-Based Management Interface

The switch has a Web server that supports HTTP 1.1 or later, and HTML 4.0 or later. Your Web browser must support HTTP 1.1 or later, HTML 4.0 or later, and JavaScript© 1.2.

You can use the Web interface to access and change switch parameters. Menus similar to those available through the terminal interface are also displayed by the Web browser. To access the switch from a Web browser, you must have configured the IP information for the switch. You will need a valid login user ID and password. The accepted user IDs and passwords are the same as those configured for the terminal interface.

|
|
|
The is no specific logout command to end a Web session. The Web session will be automatically logged off after a period of inactivity. The inactivity timeout value that is configured for the Telnet session is used by the Web interface.

See “Chapter 5. Using the Web Interface” on page 69 for starting and using the Web interface.

Chapter 3. Configuring your switch

After hardware installation, you must configure the IP information for your switch in order to manage the switch using in-band connection.

First, you need to decide how you will access your switch. See “Chapter 2. Accessing the switch” on page 15 for details about in-band and out-of-band connection. It is assumed that when you come to this chapter you will already have established physical connectivity.

Configuring IP information

IP information can be initially assigned through either:

- DHCP or BootP (the default), or
- Terminal interface through the EIA 232 serial port

Remote configuration using DHCP or BootP

You can configure your switch from remote locations using DHCP (Dynamic Host Configuration Protocol) or BootP. BootP (documented in RFC 951 and RFC 1542) is a bootstrap protocol used by a diskless workstation to learn its IP address, the location of its boot file, and the boot server name. The switch supports “reserved” or static DHCP, documented in RFC 1541. The DHCP or BootP server must be available through the Default VLAN (VLAN 1).

To configure the IP information remotely using DHCP or BootP:

1. Select **Management Menu** from the Main Menu on the terminal interface.
2. Select **Network Connectivity Configuration Menu** from the Management Menu, then specify *BootP / Static DHCP* for the Network Configuration Protocol Current parameter. If you are not using BootP or DHCP, set the *Network Configuration Protocol Current* parameter with a value of *None* to reduce network traffic. You must reset the switch to activate the change.

Manual configuration using the terminal interface

To manually configure the IP information:

1. Log onto the terminal interface using the read/write user ID and password.
2. Select the **Management Menu** from the Main Menu.
3. Select **Network Connectivity Configuration Menu** from the Management Menu, then specify IP address, Subnet Mask, and Default Gateway. Also, ensure that *None* is specified for Network Configuration Protocol Current.




Figure 10. Configuring BootP/static DHCP and network connection (IP information).

IP Address

Unique IP address of your switch. Each IP parameter is made up of four decimal numbers. The numbers range from 0 to 255. The default for all IP parameters consists of "0"s (that is, 0.0.0.0).

Subnet Mask

The subnet mask for the LAN.

Default Gateway

Identifies the address of the default router if the switch is a node outside the IP range of the LAN.

Burned-in MAC Address

The default MAC address.

Locally Administered MAC Address

This is an additional parameter that you can configure. The following rules apply:

- Bit 6 of byte 0 (called the U/L bit) indicates whether the address is universally administered (B'0') or locally administered (B'1').
- Bit 7 of byte 0 (called the I/G bit) indicates whether the destination address is an individual address (B'0') or a group address (B'1').
- A locally administered address must have bit 6 On (B'1') and bit 7 Off (B'0').

MAC Address Type

Specifies if the burned-in MAC address or the locally-administered MAC address should be used. The burned-in MAC address is the default MAC address type.

Network Configuration Protocol Current

Specifies the network configuration protocol currently being used. Possible values are:

- BootP / Static DHCP: the switch periodically sends requests to a BootP or DHCP server until a response is received.
- None: the switch will be manually configured with IP information as specified on the Network Connectivity Configuration Menu.

Network Configuration Protocol on Next Reset

When you select BootP/Static DHCP (the default), the switch periodically

sends requests to a BootP or DHCP server until a response is received. You must specify None, if you want to manually configure the switch with the appropriate IP information. When this value is modified, you need to issue a Save and then reset the switch in order for the new value to take effect.

Web mode

Used to enable or disable access to the switch through the Web interface. When enabled, you can login to the switch from the Web interface. When disable is selected, you cannot login to the switch's Web server. Specifying Disable provides for more secure access to the switch. The default is Enable.

Note: Disabling the Web interface will not disable Web sessions that are in progress; no new Web sessions will be started.

Configuration Changes

This section describes how to make configuration changes, apply them, and retain the changes across a power cycle of the switch. It also provides you with specific information about making configuration changes using the terminal interface, Web interface, and SNMP interface.

You make configuration changes by entering data for one or more items. Configuration changes made by one user are also seen by other users who request the same data. Be aware that information displayed may be old data if you do not request the latest information before making any changes.

After you have make a configuration change and it is accepted:

- Selecting APPLY causes the change on the current panel to be applied but **not** retained across a reset or power cycle.
- Selecting SAVE causes the change on the current panel to be applied and all applied changes are retained across a reset or power cycle.

Making configuration changes using the terminal interface

This section provides information about making configuration changes, applying the changes, and retaining the changes across a power cycle when using the terminal interface.

Applying the configuration changes

On the terminal interface menus, field entries that can modified are enclosed in either square brackets ([]) or angle brackets (< >).

Square brackets identify an item that you can change by typing in text. As soon as you begin typing, the current value of the field is erased and is replaced by the new text. You cannot perform insert or overwrite in the field. You can use the following special keys while you are editing text fields:

- **Arrow keys:** These are ignored when you are editing a text field. On a field where you have made no modifications, use arrow keys to move the cursor to the appropriate field indicated by the direction of the arrow key.
- **Backspace:** Removes a character in front of the cursor.
- **Delete:** Gives the same result as the Back Space.

- **Enter:** The text is accepted and the cursor moves to the next field. On a text field where you have made no modifications, Enter moves the cursor to the next field.
- **Esc:** Stops editing the field and restores the original data.
- **Space Bar:** Is an allowable key to enter text.
- **Tab:** Performs the same function as the Enter key.
- **F4:** Save. Causes the configuration data to be saved and also applied if not already done.

Angle brackets identify an item that can be changed by selecting the desired option. The following special keys are used while selecting a configuration option:

- **Arrow keys:** The text is accepted and the cursor moves to the appropriate field indicated by the direction of the arrow key pressed. On a field where you have made no modifications, arrow keys move the cursor to the appropriate field.
- **Enter:** The text is accepted and the cursor moves to the next field. On a field where you have made no modifications, Enter moves the cursor to the next field.
- **Esc:** Stops modifying the field and restores the original data.
- **Space Bar:** Displays the next possible value for this field. Use it to cycle through the available options to select the desired value.
- **Tab:** Performs the same function as the Enter key.
- **F4:** Save. Causes the configuration data to be saved and also applied if not already done.

When processing data entered in a text field, all leading and trailing white-space characters are ignored (such as, space, Tab, Esc).

Once a configuration change is made and is accepted (the cursor is no longer on the field that was modified), the change is not put into effect until you select APPLY.

Saving the configuration changes

Note: To help remind you that a configuration change needs to be applied, APPLY always appears on the Command Bar.

When you select APPLY, the following actions occur:

1. All configuration changes that you made are checked for correct syntax.
2. If you entered invalid configuration data (for example, data value that is out of the supported range), an error message is displayed identifying the field that contained the error. Errors are reported one field at a time. All data must be valid before it can be applied.
3. When the data has been checked and you have corrected any errors, UNSAVED DATA is displayed in the upper right corner of the panel.

If you make configuration changes and then exit a panel without applying the changes, your changes may be lost. For example, the following results in losing any changes made on the panel:

- You make configuration changes on the current panel and you select any of the following commands:
 - MAIN MENU
 - PREV MENU

Note: Configuration changes are not automatically retained across a reset or a power cycle. To retain changes, you must select the Save command as described in the following section.

Saving the configuration changes across a reset or power cycle

To save configuration changes across a reset or power cycle, perform one of the following actions:

- Select **F4** (Save).
- Select **Save Applied Changes** on the System Utilities Menu.

If you select **SAVE** without previously having selected **APPLY** for recently made configuration changes, the changes are automatically applied.

If you request a switch reset without saving your configuration changes, you are prompted to save them. Reply **yes** to save the changes or **no** if you do not want to save them.

You are next prompted if you want to reset the switch. If you reply **yes**, the switch is reset regardless of whether you saved the changes or not.

Making configuration changes using the Web interface

This section provides information on making configuration changes, getting the changes put into effect, and retaining the changes across a power cycle when using the Web Interface.

On the Web pages, field entries that can be modified are displayed in a box with a white background. Depending on the field being modified, you can modify the text by either:

- Typing in the appropriate text over existing text (overwriting). If the data typed in is incorrect, the data entered is rejected and the original data is displayed.
- Selecting an option from one of the items displayed when the pull-down menu is selected. All items in a pull-down menu are correct.

Until you select **APPLY** or **SAVE**, you can restore any modified values to their original values by selecting the **Undo**.

Applying Configuration Changes

After you have modified the fields, select the **APPLY** or **SAVE** to process the changes. Selecting **APPLY** makes the changes take effect but the changes are not automatically retained across a reset or power cycle. Selecting **SAVE** makes the changes take effect and also results in the changes being retained across a reset or power cycle.

Before the Web Browser sends the request to the switch, the data for the fields changed are verified. If any field is invalid, an error message is displayed identifying the field that contains the error. Invalid data errors are reported one field at a time. All configuration changes must be valid before any of the changes are sent.

If you make configuration changes and then change the page without applying or saving the changes, the changes are not processed.

Saving configuration changes across a reset or power cycle

To save configuration changes to be retained across a reset or power cycle, select **SAVE**. Configuration changes can be permanently saved by either of these actions:

- Selecting **SAVE**.
- Going to the System Utilities Menu and selecting **Save All Applied Changes**.

Making configuration changes using SNMP

This section provides information on making configuration changes, getting the changes put into effect, and retaining the changes across a power cycle when using the SNMP interface.

You make configuration changes using SNMP by issuing SNMP Set commands to MIB objects that the switch supports as read/write.

Applying configuration changes

When the SNMP Set is received, the switch checks the data to ensure that it is valid. If it is invalid, the SNMP error code BADVALUE is returned in the SNMP Set Response. Otherwise, the configuration change is applied.

Saving configuration changes across a reset or power cycle

Configuration changes made using SNMP Set commands are not automatically retained across a reset or power cycle. To get these changes retained across a reset or power cycle, issue an SNMP Set to the **swDevCtrlSaveConfiguration** object supported by the switch private MIB.

Managing the configuration file

Your switch's configuration is written to a configuration file. Having this file available at a remote location would allow you to restore a corrupted switch configuration. System utilities allow you to upload files from the switch and download files to the switch.

From the System Utilities panel, you can select to **Upload File From Switch** or **Download File to Switch** to process a configuration file; just specify *Config File* as the file type on either panel. The switch must have a path available through Default VLAN (VLAN 1).

Chapter 4. Using the Terminal Interface

This chapter describes the switch terminal interface. The terminal interface panels are automatically refreshed every few seconds to provide you with current information.

Note: The panels shown in this chapter are intended to be representative and should not be assumed to be entirely accurate because they are subject to change before final shipment of the product.

Login panel

The Login panel is the first panel displayed when initializing the terminal interface. Figure 11 shows the Login panel; you need an approved user name and password to login.




Figure 11. Login panel for terminal interface

User Name

Can be up to 8 alphanumeric characters in length. The value is not case sensitive. The default is **admin** for a read/write user, and **guest** is the default for a read only user.

Password

Can be up to 8 alphanumeric characters in length. The value is not case sensitive. The default is no password.

The terminal interface provides a way to log out. From the Main Menu, select **LOGOUT** or select **System Utilities Menu**, then select **Logout**. When you have finished using the terminal interface, ensure you have saved all configuration changes before logging out.

The Main Menu

Following a successful login, the Main Menu appears (Figure 12). Information following in this section is arranged in the order of topics on the Main Menu.




Figure 12. Main menu for terminal interface

System Information Menu

Allows access to information that is maintained about the switch.

Management Menu

Contains selections associated with managing the switch.

Device Configuration

Contains selections associated with configuring the switch.

Statistics Menu

Contains selections for access to statistical data that is gathered for the switch.

User Account Management

Allows you to define users and passwords and their level of access.

System Utilities

Allows selection of the utilities available with the switch.

System information

The switch manages information about its installed hardware and software. System information contains read-only and read/write fields. The read-only fields are written when the switch is manufactured. Through configuration you can change only the read/write fields: *System Name*, *System Location* and *System Contact*. Changes to these fields must be saved to be effective. A reset is not necessary for the changes to be effective.

To access system information, select **System Information Menu** on the Main Menu. By selecting **Inventory Information Menu** and **System Description Menu**,

you can view information about your switch. Figure 13 shows your system information options.




Figure 13. System information menu

Inventory information

Figure 14 shows the Read-Only inventory information available for your switch.




Figure 14. Inventory information menu

System description

Figure 15 on page 30 shows the system information for your switch.

```

TELNET.EXE
IBM 8275-416 High Performance Switch
- System Description Menu -                                00:06:29:CB:50:00

Unit ID ... <1>

System Description..... IBM 8275-416 High Performance Switch
System Name..... [ ]
System Location..... [ ]
System Contact..... [ ]

System ObjectID..... 1.3.6.1.4.1.2.6.157
System IP Address ..... 9.37.250.6
System Up Time..... 0 Days, 15 Hours, 8 Mins, 20 Secs

MIBs Supported..... RFC 1213 MIB-2, RFC 1493 dot1dBridge,
                    RFC 1643 802.3, RFC 1757 RMON,
                    IBM 8275-416 MIB

Enter system name (Max 31 alpha-numeric characters).

APPLY MAIN MENU PREV MENU (F3) HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE

```

Figure 15. System description menu

System Name

The name assigned to the switch. Specify up to 31 alphanumeric characters. The default is blank.

System Location

Indicates the physical location of the switch. Specify up to 31 alphanumeric characters. The default is blank.

System Contact

Identifies the person responsible for your network (for example, you network administrator) Specify up to 31 alphanumeric characters. The default is blank.

Management

Select **Management Menu** on the Main Menu (Figure 16) to use the management functions of the switch.



Figure 16. Management menu

Configuring network connection for the switch

To configure the IP information, select **Management Menu** from the Main Menu, then select **Network Connectivity Configuration Menu** from the Management Menu. The Network Connectivity Configuration Menu appears as shown in Figure 17 on page 32.




Figure 17. Network connection configuration

You must configure the following IP information to establish in-band connectivity to the switch:

IP Address

Unique IP address for your switch. Each IP parameter is made up of four decimal numbers. The numbers range from 0 to 255. The default for all IP parameters consists of zeros (that is, 0.0.0.0).

Subnet Mask

The subnet mask for the LAN.

Default Gateway

Identifies the address of the default router if the switch is a node outside the IP range of the LAN.

Burned-in MAC Address

The burned-in MAC address is the default MAC address used.

Locally Administered MAC Address

This is an additional parameter that you can configure. The following rules apply:

- Bit 6 of byte 0 (called the U/L bit) indicates whether the address is universally administered (B'0') or locally administered (B'1').
- Bit 7 of byte 0 (called the I/G bit) indicates whether the destination address is an individual address (B'0') or a group address (B'1').
- A locally administered address must have bit 6 On (B'1') and bit 7 Off (B'0').

MAC Address Type

Specifies if the burned-in MAC address or the locally-administered MAC address should be used. The burned-in MAC address is the default MAC address type.

Network Configuration Protocol Current

Specifies the network configuration protocol currently being used. Possible values are:

- BootP / Static DHCP: the switch periodically sends requests to a BootP or DHCP server until a response is received.
- None: the switch will be manually configured with IP information as specified on the Network Connectivity Configuration Menu.

Network Configuration Protocol on next Reset

When you select BootP/Static DHCP (the default), the switch periodically sends requests to a BootP or DHCP server until a response is received. You must specify None, if you want to manually configure the switch with the appropriate IP information. When this value is modified, you need to issue a Save and then reset the switch in order for the new value to take effect.

Web mode

Used to enable or disable access to the switch through the Web interface. When enabled, you can login to the switch from the Web interface. When disable is selected, you cannot login to the switch's Web server. Specifying Disable provides for more secure access to the switch. The default is Enable.

Note: Disabling the Web interface will not disable Web sessions that are in progress; no new Web sessions will be started.

Configuring serial port

The switch allows you to access the switch through the serial EIA 232 port. This type of connectivity is called out-of-band connection. See "Chapter 2. Accessing the switch" on page 15 for descriptions of ways to access the switch.

On the Main Menu, select **Management Menu**. From the Management Menu, select **Serial Port Configuration Menu**. Figure 18 shows the parameters to configure the serial EIA 232 port.




Figure 18. Serial port configuration

You specify Login Timeout and Baud Rate:

Serial Port Login Timeout

Specifies the maximum connect time without console activity. The value is in a range from 0 to 160 minutes. A value of 0 indicates that a console can be connected indefinitely. The default value is 5 minutes.

Baud Rate

Specifies the communication rate of the terminal interface. Values can be 1200, 2400, 4800, 9600, 19200, 38400, 57600, or 115200. The default value is 19200.

Configuring for DHCP or BootP

If you do not want to manually configure the switch with IP information, the switch can obtain the IP information from a BootP or DHCP server. The switch must be accessible through a port which is a member of the Default VLAN ID 1. When BootP or DHCP is enabled, the switch periodically sends out requests until a response is received from either a DHCP or BootP server. The IP information in the BootP or DHCP response overlays any existing IP information in switch. The new IP information is not retained across a reset until you select **Save**.

Note: If you configure a switch with an IP address, then DHCP frames will effectively be ignored (that is, the configured IP address will have priority over the address received via DHCP). However, BootP frames will have priority over a configured IP address. A difference between BootP and DHCP frames is that DHCP frames have 0xFFFFFFFF as the destination MAC address, while BootP frames have the switch's individual MAC address as the destination address.

Configuring the DHCP

To configure the DHCP server for static DHCP, you must specify an IP address that will be assigned to the switch. This IP address is mapped to the switch's MAC address. The static DHCP does not obtain an IP address from a pool of addresses on a DHCP server unless one is explicitly set up for a given MAC address. For example, In Windows NT®, you must set up a reservation for the switch's MAC address. Assign an IP address from the pool of current addresses. Configure the router, IP address, and subnet mask for the switch's MAC address. The switch supports no other DHCP options.

Configuring the BootP

For BootP, the BootP server must have the appropriate information configured for the switch. A newly installed switch broadcast a BootP request over IP when it is powered on or reset. The BootP server, using information from its BOOTPTAB file, provides the switch with configuration information.

The following is an example of a BOOTPTAB file entry containing configuration information for the switch:

```
8275_416_Switch_1:ht=ethernet:ha=0004ac6b0980:\
    ip=10.1.7.7:gw=10.1.1.1:\
    sm=255.255.255.0

8275_416_Switch_2:ht=ethernet:ha=0004ac6b09C0:\
    ip=10.1.7.8:gw=10.1.1.1:\
    sm=255.255.255.0
```

Where:

ht	hardware type
ha	host hardware address
ip	host IP address
gw	gateway address list

sm subnet mask

Configuration information obtained from the BootP server is not saved unless you select **SAVE**. Next, configure the Network Configuration Protocol.

Configuring the switch for DHCP or BootP

If you are using DHCP or BootP, you must configure the appropriate information for the switch. To do so, configure the Network Configuration Protocol as follows:

1. On the Main Menu, select **Management Menu**.
2. On the Management Menu, select **Network Connectivity Configuration Menu**, then complete the network connection information shown in Figure 17 on page 32.

Configuring the SNMP community

The switch has an SNMP agent that complies with SNMP Version 1 (SNMPv1). For more about the SNMP specification, see the appropriate SNMP RFCs. The SNMP agent sends traps through TCP/IP to an external SNMP manager based on your SNMP configuration. SNMP configuration for the switch includes configuring the trap receiver and SNMP community parameters, which are described in the following text.

If you do not use the default community information, you must configure the SNMP agent with a community name for the switch. A community name is a name associated with the switch and with a set of SNMP managers allowed to manage it with a specified privileged level. You can add, change or delete communities. The switch does not have to be reset for changes to take effect. Up to six communities are simultaneously supported.

Community names in the SNMP community table must be unique. If you make multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

To configure your SNMP communities, select **SNMP Community Configuration Menu** from the Management Menu. Figure 19 on page 36 shows SNMP community information you need to specify.

```

TELNET.EXE
IBM 8275-416 High Performance Switch
- SNMP Community Configuration Menu -                                00:06:29:CB:50:00

Unit ID ... <1>

SNMP Community Name Client IP Address Client IP Mask Access Mode Status
-----
[public ] [0.0.0.0 ] [0.0.0.0 ] <Read Only > <Enable >
[private ] [0.0.0.0 ] [0.0.0.0 ] <Read/Write> <Enable >
[ ] [0.0.0.0 ] [0.0.0.0 ] <Read Only > <Delete >
[ ] [0.0.0.0 ] [0.0.0.0 ] <Read Only > <Delete >
[ ] [0.0.0.0 ] [0.0.0.0 ] <Read Only > <Delete >
[ ] [0.0.0.0 ] [0.0.0.0 ] <Read Only > <Delete >

Enter the switch's SNMP community name (Max 16 characters, case sensitive).

APPLY MAIN MENU PREV MENU (F3) HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE

```

Figure 19. SNMP community configuration

SNMP Community Name

This name identifies each SNMP community; the name can be up to 16 characters, and it is case-sensitive. A *public* community means users have read only access. A *private* community is for users who have read/write access. Two communities have default values. The default names are Public and Private. You can replace these default community names with unique identifiers for each community. The default values for the remaining four community names are blank.

Client IP Address

This attribute is an IP address (or portion thereof) from which this device will accept SNMP packets with the associated community. The requesting entity's IP address is logical-ANDed with the Client IP Mask and the result must match the Client IP Address. The default value is 0.0.0.0.

Note: If the Client IP Mask is set to 0.0.0.0, a Client IP Address of 0.0.0.0 matches all IP addresses.

Client IP Mask

This attribute is a mask to be logical-ANDed with the requesting entity's IP address before comparison with the Client IP Address. If the result matches with Client IP Address then the address is an authenticated IP address. For example, if the Client IP Address is 9.47.128.0 and the corresponding Client IP Mask is 255.255.255.0, a range of incoming IP addresses would match, that is, the incoming IP addresses could be a value in the following range: 9.47.128.0 to 9.47.128.255.

To have a specific IP address be the only authenticated IP address, set the Client IP Address to the required IP address and set the Client IP Mask to 255.255.255.255. The default for the Client IP Mask is 0.0.0.0.

Access Mode

This value can be read-only or read/write. A community with a read-only access allows for switch information to be displayed. A community with a read/write access allows for configuration changes to be made and for information to be displayed.

A community name with read-only access is restricted from viewing SNMP community and SNMP trap receiver information.

Status

This attribute has the following values: Enable, Disable and Delete on the terminal and Web interface and Active, Inactive, and Delete on SNMP.

A community status of Enable/Active means that the community is active, allowing SNMP managers associated with this community to manage the switch according to its access right.

A community status of Disable/Inactive means that the community is not active; no SNMP requests using this community will be accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable/Active.

A community status of Delete means that this name will be removed from the table. The default Status values for the default private and public community names are both Enable/Active. The default value is Delete/Inactive for the 4 undefined community names.

Configuring the trap receiver

Trap messages are sent across a network to an SNMP Network Manager. These messages alert the manager to events occurring within the switch or on the network. Up to six simultaneous trap receivers are supported.

IP Addresses in the SNMP trap receiver table must be unique. If you make multiple entries using the same IP address, the first entry is kept and processed and all duplicate entries are ignored.

To configure trap receivers, select **SNMP Trap Receiver Configuration Menu** on the Management Menu. Figure 20 shows the parameters you need to specify.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- SNMP Trap Receiver Configuration Menu - 00:06:29:CB:50:00

Unit ID ... <1>

SNMP Community Name      IP Address      Status
-----
[ ] [0.0.0.0] <Delete >
[ ] [0.0.0.0] <Delete >
[ ] [0.0.0.0] <Delete >
[ ] [0.0.0.0] <Delete >
[ ] [0.0.0.0] <Delete >
[ ] [0.0.0.0] <Delete >

Enter Trap Receiver's SNMP community name (Max 16 characters, case sensitive).

APPLY  MAIN MENU  PREV MENU (F3)  HELP (F1)

For changes, [overtyping] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 20. SNMP trap receiver configuration

Trap receiver parameters are:

SNMP Community Name

This is the SNMP community name of the remote network manager; the

name can be up to 16 characters, and is case-sensitive. The default value for the 6 undefined community names is Delete.

IP Address

Each IP address parameter is four decimal numbers. The numbers range from 0 to 255. The default IP address is 0.0.0.0.

Status

The status for trap receivers can be Enabled, Disabled, or Deleted. Trap receivers with Enabled status are active and the SNMP agent sends traps to them. Trap receivers with Disabled status are inactive and the SNMP agent does not send traps to them. Trap receivers with a Deleted status are removed from the table.

Configuring traps

Configuring trap conditions

You can optionally configure which traps that the switch should generate. You do this by selecting a status for the trap condition, that is, if it is either enabled or disabled. If a trap condition is enabled and the condition is detected, the switch's SNMP agent sends the trap to all enabled trap receivers. Otherwise, no condition is detected and no trap is sent. The default Status value for all Trap Conditions is Enabled. The switch does not have to be reset to implement the changes. Cold start traps are always generated; there are no associated trap conditions.

To configure trap conditions, select **Trap Menu** from the Management Menu. From the Trap Menu, select **Trap Flag Configuration Menu**, then enable or disable trap flags.

Figure 21 shows the trap flags that you can set.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Trap Flags Configuration Menu -                                00:06:29:CB:50:00

Unit ID ... <1>

Authentication Flag ..... <Enable >
Link Up/Down Flag ..... <Enable >
Multiple Users Flag ..... <Enable >
Spanning Tree Flag ..... <Enable >

Press Space bar to Enable/Disable sending traps on invalid SNMP access.

APPLY      MAIN MENU  PREV MENU (F3)  HELP (F1)

For changes, [overtyping] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 21. Trap flags configuration

These are the trap conditions that can be enabled/disabled:

Authentication Flag

Enable/Disable authentication Flag.

Link Up/Down Flag

Enable/Disable Link Up/Link Down traps for the entire switch. When set to Enable, the Link Up/Down traps will be sent only if the Link Trap flag setting associated with the port (Port Configuration Menu) is set to Enable.

Multiple Users Flag

Enable/Disable Multiple User traps. When the value is set to Enable, a Multiple User Trap is sent whenever someone logs in to the terminal interface (EIA 232 or Telnet) and there is already an existing terminal interface session.

Spanning Tree Flag

This flag enables the sending of new root traps and topology change notification traps. See “Appendix E. Introduction to Virtual LANs (VLANs)” on page 107 for more information.

Trap log

The switch maintains a Trap Log; it contains a maximum of 256 entries that wrap. Trap Log information is not retained across a switch reset.

Select **Trap Menu** from the Management Menu, then select **Trap Log Menu** from the Trap Menu. Figure 22 shows the entries in the trap log.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Trap Log Menu -                                00:06:29:CB:50:00

Unit ID ... <1>                                Page 1 of 4

Log      System Up Time      Trap
-----
35      0 days 15:07:30      Multiple Users: Unit: 1
34      0 days 15:02:49      Multiple Users: Unit: 1
33      0 days 14:46:23      Multiple Users: Unit: 1
32      0 days 00:08:46      Spanning Tree Topology Change: Unit: 1
31      0 days 00:08:45      Spanning Tree Topology Change: Unit: 1
30      0 days 00:08:45      Spanning Tree Topology Change: Unit: 1
29      0 days 00:08:32      Link Up: Unit: 1 Slot: 0 Port: 8
28      0 days 00:08:32      Link Up: Unit: 1 Slot: 0 Port: 6
27      0 days 00:08:32      Link Up: Unit: 1 Slot: 0 Port: 5
26      0 days 00:08:07      Link Down: Unit: 1 Slot: 0 Port: 8

Press Enter to display the Next Page.

NEXT PAGE    PREV PAGE    MAIN MENU    PREV MENU (F3)    HELP (F1)

Use Tab or Arrow keys to navigate. Press Enter to make a selection.
F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 22. Trap log

Each entry contains:

System Up Time

This entry shows how long the system has been up when the trap occurred.

Trap

This entry is the name of the trap condition, which can be:

- Cold Start
- Authentication Failure
- Link Up
- Link Down
- Multiple Users
- New Spanning Tree Root
- Spanning Tree Topology Change

Checking trap log status

To check how many traps have been generated, select **Trap Menu** from the Management Menu, then select **Trap Log Status Menu** from the Trap Menu.

You can choose to clear the trap log on this panel (Figure 23).

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Trap Log Status Menu -                                00:06:29:CB:50:00

Unit ID ... <1>

Number of Traps Since Last Reset ..... 35
Number of Traps Since Log Last Displayed .... 0

Clear Trap Log ..... <No >

Press Space bar to select <Yes> and then select APPLY to clear the trap log.

APPLY      MAIN MENU  PREV MENU (F3)  HELP (F1)

For changes, [overtime] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 23. Trap log status

You can perform this operation on this panel:

Clear Trap Log

Specify Yes or No. Yes causes the contents of the Trap Log to be erased. No causes the trap log to continue logging trap information after the last entry.

Configuring Telnet

You can manage the switch remotely using a Telnet connection. “Chapter 2. Accessing the switch” on page 15 describes setting up a Telnet connection. To configure for Telnet, select **Management Menu** from the Main Menu, then from the Management Menu, select **Telnet Configuration Menu** (Figure 24 on page 41).




Figure 24. Telnet configuration

The following parameters are for configuring a Telnet session with the switch:

Telnet Login Timeout

A session is active as long as the session has not remained idle for the value set. Specify a decimal value from 0 to 160 minutes. A value of 0 indicates that a Telnet session remains active indefinitely. The default is 5 minutes.

Note: Changing the timeout value for active sessions does not become effective until the session is reaccessed. Any keystroke will also activate the new timeout duration.

Maximum Number of Telnet Sessions

Specify a decimal value from 0 to 5. If the value is 0, no Telnet session can be established. The default value is 5.

Allow New Telnet Sessions

Specify Yes or No. Yes means that new Telnet sessions can be established until there are no more sessions available. No means that no new Telnet sessions are to be established. Any already established session remains active until the session is ended or an abnormal network error ends it. The default value is Yes.

Ping

The switch provides a ping utility that you can use to check connectivity between devices in a network. To use ping, the switch must be configured correctly for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. The switch can be pinged from any IP workstation with which the switch is connected through the Default VLAN (VLAN 1) (as long as there is a physical path between the switch and the workstation). The terminal interface allows you to send one ping, three pings or a continuous ping (one every second) to the target station.

To use Ping, select **Management Menu** from the Main Menu. Then select **Ping Menu** from the Management Menu (Figure 25 on page 42).




Figure 25. Ping

You must supply this information:

IP Address

The IP address of the target station. The value is 4 decimal bytes ranging from 0 to 256. The default is 0.0.0.0.

Ping Count

You can select one of these values; the default value is single:

- Single—one ping is sent to target station.
- Multiple—three pings are sent to the target station.
- Continuous—a ping is sent every second.

Command

Send is the only command. To stop sending pings, press any key that moves the cursor from the current field.

ARP cache

Select **Management Menu** from the Main Menu. Then select **ARP Cache Menu** from the Management Menu to displays the ARP cache for the switch.

This is used to check connectivity between the switch and other devices. The ARP cache identifies the MAC addresses of the IP stations communicating with the switch. Figure 26 on page 43 shows ARP Cache information.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- ARP Cache Menu -                                00:06:29:CB:50:00
Unit ID ... <1>                                    Page 1 of 1

  MAC Address          IP Address
  -----
00:06:29:21:76:99     9.37.250.1

Press Enter to display the Next Page.

NEXT PAGE    PREV PAGE    MAIN MENU    PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate. Press Enter to make a selection.
F2=toggle between menu text and Command Bar. F4=SAVE.
```

Figure 26. ARP cache

Device configuration

To configure the switch, select **Device Configuration Menu** on the Main Menu. Figure 27 shows your options.



Figure 27. Device configuration

Configuring the switch

The switch allows you to set a time after which the address will timeout, and to enable/disable broadcast storm recovery and 802.3x flow control. To set these values, select **Device Configuration Menu** from the Main Menu and then select **Switch Configuration Menu** (Figure 28).




Figure 28. Switch configuration

The value you specify is:

Address Aging Timeout

Indicates the timeout period (in seconds) for aging out dynamically learned forwarding information. The range is 10 to 600 (seconds). The default is 300 (seconds).

Broadcast Storm Recovery Mode

When you specify Enable for Broadcast Storm Recovery and the broadcast traffic on any Ethernet port exceeds 20 percent of the link speed, the switch blocks (discards) the broadcast traffic until the broadcast traffic returns to 10 percent or less.

When you specify Disable for Broadcast Recovery Mode, then the switch will not block any broadcast traffic on any Ethernet port. The default is Disable.

802.3x Flow Control Mode

Indicates if 802.3x flow control is enabled for the switch. The default is Disable. This value applies to only full-duplex mode ports.

Configuring ports

The switch is shipped from the factory with default port settings that allow it to automatically determine the port type and speed.

See “Chapter 3. Configuring your switch” on page 21 for details about making and saving configuration changes.

To configure the ports, select **Device Configuration Menu** from the Main Menu, then select **Port Configuration Menu** from the Device Configuration Menu (Figure 29).

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Port Configuration Menu -                                00:06:29:CB:50:00
Page 1 Of 2
Unit ID... <1>      Slot <_0>      10-100 Copper Ports
Port  STP  Admin   Physical  Physical  Link   Link   Link   IfIndex
-----  ---  -----  -----  -----  -----  -----  -----  -----
ALL  N/A  <----->  <----->  N/A      N/A      <----->  N/A
1    D    <Enable >  < Auto   >  10 Half  Link Down <Enable >  1
2    D    <Enable >  < Auto   >  10 Half  Link Down <Enable >  2
3    D    <Enable >  < Auto   >  10 Half  Link Down <Enable >  3
4    D    <Enable >  < Auto   >  10 Half  Link Down <Enable >  4
5    F    <Enable >  < Auto   >  100 Full  Link Up   <Enable >  5
6    F    <Enable >  < Auto   >  100 Full  Link Up   <Enable >  6
7    D    <Enable >  < Auto   >  10 Half  Link Down <Enable >  7
8    F    <Enable >  < Auto   >  100 Full  Link Up   <Enable >  8
Press Space Bar to select the slot number. Any unapplied changes will be lost.
NEXT PAGE      APPLY      MAIN MENU      PREV MENU (F3)  HELP (F1)
Use Tab or Arrow keys to navigate. Press Enter to make a selection.
F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 29. Port configuration

You can select or change the following values:

Slot This is a read/write field. The 16 base ports are associated with slot 0. A feature module in Slot 1 or Slot 2 can have ports 1 to 4, or 1 to 8 associated with them, depending on the type of feature module installed.

Port You can use the *All* option to change the value for all ports in this slot. You can specify Enable or Disable for the Admin Mode and Link Trap fields, and you can specify the following for the Physical Mode field:

- Auto: automatically negotiates the speed and duplex setting
- 100 Half: 100BASE-T half-duplex
- 100 Full: 100BASE-T full duplex
- 10 Half: 10BASE-T half duplex
- 10 Full: 100BASE-T full duplex
- 100FX Half: 100BASE-FX half duplex
- 100FX Full: 100BASE-FX full duplex

Note that when All is specified and you specify Disable in the Admin Mode field, you lose in-band connection to the switch.

Indicates the port number.

The feature slots are Slot 1 and Slot 2. Available feature modules have 4 and 8 ports.

Admin Mode

This is a configurable value and indicates if the port is enabled or disabled. The default for all ports is Enabled.

Physical Mode

This is a configurable value and indicates the speed and duplex setting for the port. The value of Auto (autodetect) is valid only for 10/100BASE-TX ports.

- Auto: automatically negotiates the speed and duplex setting
- 100 Half: 100BASE-T half-duplex
- 100 Full: 100BASE-T full duplex
- 10 Half: 10BASE-T half duplex
- 10 Full: 100BASE-T full duplex

Link Trap

This is a configurable value and can be Enabled or Disabled. It allows you to enable or disable link status traps by port. This parameter is only valid when Link Up/Down Flag is enabled on the Trap Flags Configuration Menu.

read only fields

The read only fields are:

- STP: a single letter indicating the current Spanning Tree Protocol (STP) state of the port, which can be:
 - D: disabled
 - B: blocking
 - L: listening
 - L: learning
 - F: forwarding
 - X: indicates port is diagnostically disabled
- Physical Status: indicates the port speed and if port is full-duplex or half-duplex.
- Link Status: indicates if the port link is up or down.
- IfIndex: When using SNMP, the interface index (ifIndex) is sometimes used to identify the specific interface being addressed. The ifIndex is determined by MIB II.

Configuring port monitoring

You can select any of the Ethernet ports as a probe to monitor forwarded traffic (not local traffic) with an external network analyzer. The selected probe port can monitor

(mirror) traffic from one port. The selected probe port also receives and transmits network traffic (tagged frames) which allows a device connected to the probe port to be managed over the network (in-band connectivity). However, the device must be 802.1Q aware to be remotely managed by the switch.

The monitoring port forwards frames with a VLAN membership which matches the monitored port. The monitoring port transmits all frames as tagged. The monitoring port does not participate in Spanning Tree Protocol (STP) and is always in a forwarding state when the link is up. The monitoring port does not forward local traffic, and it does not participate in GVRP.

Port Monitoring Operation

1. The monitoring port transmits all frames as tagged; therefore, a network analyzer is remotely manageable only if it is 802.1Q-aware.
2. The monitoring port is unable to transmit frames outside of its VLAN membership. Therefore, if the monitored port has ingress filtering disabled, any frames received or forwarded on that port, and which are not affiliated with a VLAN with which the monitored port is a member, will not be transmitted out of the monitoring port.
3. The monitoring port always transmits frames with the NCFI bit set. Therefore, frames not transmitted on the monitored port due to untagging and a set NCFI bit cannot be detected and filtered by the monitoring port. In this case, the monitoring port will transmit these frames, even though they are not transmitted by the monitored port. The existence of such frames in a network is expected to be a rare occurrence.
4. Frames not forwarded by the monitored port will not be monitored. These include:
 - Local frames
 - 802.3x PAUSE frames
 - Frames dropped due to ingress rules
 - Frames dropped due to forwarding rules

From the Main Menu, select **Device Configuration Menu** and then, select **Port Monitoring Menu** from the Device Configuration Menu (Figure 30 on page 48).




Figure 30. Port monitoring

Specify values for the following parameters:

Port Monitoring

Used to *Enable* or *Disable* the port monitoring function. The default is Disable.

Monitoring Port

This is the **slot.port** that the *monitored* data is sent to. This is the **slot.port** that a Network Analyzer is attached to. The slot can be 0, 1 or 2. The default is 0. The port range is 1 to 16 for Slot 0; 1 to 2, 1 to 4, or 1 to 8 for Slots 1 and 2.

When Port Monitoring is Enabled, make sure that the monitoring port is connected to a network analyzer and not to the network itself to avoid potential problems.

Port to be Monitored

This is the port from which data is captured and sent to the monitoring port (the port under analysis). The port range is 1 to 16 for Slot 0; 1 to 2, 1 to 4, or 1 to 8 for Slots 1 and 2.

Configuring spanning tree protocol (STP)

Spanning tree switch configuration/status

The switch participates in Spanning Tree Protocol (STP). STP allows you to configure redundant paths in the switch topology. The switch automatically blocks redundant paths to prevent loops (that is, make it fault tolerant). If an active path is broken and a backup path is available, the switch finds the redundant path and enables it. Without STP, a path failure means loss of connectivity for the affected part of the network.

The switch complies with the IEEE 802.1D standard. Refer to the IEEE 802.1D document for STP specifications. The switch supports one Spanning Tree Protocol (STP) for the entire switch.

To configure the Spanning Tree Protocol for the switch, select **Device Configuration Menu** from the Main Menu, then select **Spanning Tree Switch Configuration/Status Menu** or **Spanning Tree Port Configuration/Status Menu** from the Device Configuration Menu (Figure 31).

```

TELNET.EXE
IBM 8275-416 High Performance Switch
- Spanning Tree Switch Configuration/Status Menu -          00:06:29:CB:50:00
Unit ID ... <1>
STP Specification . . . . . IEEE 802.1D
STP Base MAC Address . . . . . 00:06:29:CB:50:00
STP Topology Change Count . . . . . 15
STP Time Since Topology Changed . . . 0 day 14 hr 49 min 13 sec
STP Designated Root . . . . . 4E20 00:04:AC:6B:0F:40
STP Root Port . . . . . 5
STP Root Cost . . . . . 100
STP Max. Age (seconds). . . . . 20
STP Hello Time (seconds). . . . . 2
STP Forward Delay (seconds) . . . . . 15
STP Hold Time (seconds) . . . . . 1
Spanning Tree Algorithm . . . . . <Enable >
STP Bridge Priority . . . . . [32768]
STP Bridge Max. Age (seconds) . . . . [20]
STP Bridge Hello Time (seconds) . . . [2 ]
STP Bridge Forward Delay (seconds). . [15]
Press Space Bar to Enable/Disable spanning tree protocol on the switch.
APPLY      MAIN MENU  PREV MENU (F3)  HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE

```

Figure 31. Spanning tree switch configuration/status

The following section lists and describes the STP configuration functions and related parameters.

Spanning Tree Algorithm

Indicates if the switch participates in Spanning Tree Protocol. A status of Enable means that the switch participates in the STP. Disable means that the switch does not participate in the STP. The default is Disable.

Bridge Priority

Decimal value that indicates the priority of the switch. The range is 0 to 65535. The lower the value, the higher the priority. The bridge with the lowest priority value becomes the root (IEEE 802.1D). The default is 32768.

Maximum Age Time

When the switch is root, Maximum Age Time is the time in seconds during which the configuration message used by the Spanning Tree Algorithm is discarded. The range is 6 to 40 seconds. The default is 20 seconds.

Hello Time

When the switch is root, Hello Time is the time in seconds that the switch waits before sending the next configuration message. The range is 1 to 10 seconds. The default is 2 seconds.

Forward Delay Time

This value specifies the time spent in “Listening and Learning” mode before forwarding packets. The range is 4 to 30 seconds. The default is 15 seconds.

Spanning tree port configuration/status

You can configure the Spanning Tree Protocol by ports. Select **Device Configuration Menu** from the Main Menu. Then select **Spanning Tree Port**

Configuration/Status Menu from the Device Configuration Menu (Figure 32).

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Spanning Tree Port Configuration/Status Menu -          00:06:29:CB:50:00

Unit ID ... <1>          Slot ... <0>          Port ID ... <1>

STP Port ID . . . . . 8001
STP Port Designated Root . . . . . 4E20 00:04:AC:6B:0F:40
STP Port Designated Cost . . . . . 100
STP Port Designated Bridge . . . . . 8000 00:06:29:CB:50:00
STP Port Designated Port . . . . . 8001
STP Port Forward Transitions Count . . . 0
STP Port State . . . . . Disabled

STP Port Priority . . . . . [128]
STP Port Path Cost . . . . . [100 ]

Press Space Bar to select the slot number. Any unapplied changes will be lost.

          APPLY      MAIN MENU      PREV MENU (F3)      HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 32. Spanning tree port configuration/status

The parameter values are:

Port Priority

Decimal value which indicates the priority of port on the switch. The range is 0 to 255. The default is 128.

Port Path Cost

This output is automatically calculated. The cost represents the shortest distance from any switch to the root switch interval for the unit announcing its presence on the network. The range is 1 to 65535. The port path cost defaults to 0, which means that the path cost will be assigned dynamically depending upon the detected speed of the port. A value of 100 is assigned to 10 Mbps ports, and a value of 19 is assigned to 100 Mbps ports.

VLAN management

“Appendix E. Introduction to Virtual LANs (VLANs)” on page 107 provides an introduction to the terminology and concepts for VLANs. It is helpful to review this material before you define values for the parameters associated with configuring VLANs.

From the Main Menu, select **Device Configuration**, and then select **VLAN Management Menu** to begin configuring VLANs for your switch (Figure 33 on page 51).




Figure 33. VLAN management menu

VLAN summary and configuration

From the VLAN Management Menu, select **VLAN Summary and Configuration Menu** to begin configuring your VLANs (Figure 34). Note that there are four panels on which you can define a total of 32 VLANs.




Figure 34. VLAN summary and configuration

The parameters for this panel are:

Unit ID

Selects the unit for which data is to be displayed or configured. In a non-stacked environment the Unit ID is 1.

VLAN Index

Sequential number of defined VLANs. You can configure 8 VLANs on each of 4 pages for up to 32 VLANs.

VLAN ID

VLAN identifier. It can be any number from 2 to 4094 (ID 1 is reserved for the default VLAN).

VLAN Name

An alphanumeric character string of up to 16 characters which identifies the VLAN. The default name is blank. The name for VLAN ID 1 is always *Default*.

VLAN Type

The type can be the Default VLAN, a static VLAN (one that is permanently configured and defined), or a dynamic VLAN (one that is created by GVRP registration). A VALN maked as "Dynamic" can be made "Static" by toggling in the *Type* field when the VLAN is being modified.

Adding or Modifying a VLAN

If you want to add a VLAN, move the cursor to the ADD VLAN command at the bottom of the panel and press Enter. To modify an existing VLAN, move the cursor to the line containing the VLAN and press Enter. You will be presented the VLAN Configuration Menu (Figure 35).

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- VLAN Configuration Menu -
                                00:06:29:CB:50:00
                                Page 1 of 2
VLAN Index:4      ID[127 ]      Name[          ]      Type: <Dynamic >
Delete VLAN: <No >
Unit ID... <1>    Slot < 0>      10-100 Copper Ports

Port  Participation      Tagging      Type
-----
All   <----->             <----->    N/A
1     <Exclude >             <Untagged>
2     <Exclude >             <Untagged>
3     <Include >              <Untagged>    Dynamic
4     <Exclude >             <Untagged>
5     <Exclude >             <Untagged>
6     <Exclude >             <Untagged>
7     <Exclude >             <Untagged>
8     <Exclude >             <Untagged>

Enter the VLAN ID (any unused VLAN ID 2 thru 4094).

NEXT PAGE      APPLY      MAIN MENU      PREV MENU (F3)  HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE
```

Figure 35. VLAN Configuration Menu

The parameters for this panel are:

Port This value is not selectable. Indicates by slot ID and port number which port is controlled by the fields on this line.

Slot ID

This value is not configurable. Indicates by slot ID and port number which port is controlled by the fields on this line.

Participation

Determines the degree of participation of this port in this VLAN. The values can be:

- Include: Indicates this port is always a member of this VLAN. This is equivalent to registration fixed.

- Exclude: Indicates this port is never a member of this VLAN. This is equivalent to registration forbidden.
- Autodetect: Specifies the port is to be dynamically registered in this VLAN by GVRP. The port will not participate in this VLAN unless a join request is received on this port. This is equivalent to registration normal.

Tagging

Indicates the tagging behavior for this port in the VLAN. The values can be:

- Tagged: Specifies to transmit traffic for this VLAN as tagged frames.
- Untagged: Specifies to transmit traffic for this VLAN as untagged frames.

Type

This value is not configurable. Indicates the port type. The values can be:

- Static: Indicates that the port is configured to be statically included in this VLAN.
- Dynamic: Indicates that this port is to be dynamically registered in this VLAN by GVRP.
- Monitor: Indicates that this is a monitoring port.
- blank (no text): Indicates that this port is excluded from being a member of this VLAN.

If a monitoring port is configured, its VLAN membership always follows the VLAN membership of the port being monitored. However, the VLAN Configuration Menu always displays the monitoring port's actual configuration; this configuration will take effect when the port is no longer a monitoring port.

Generic Attributes Registration Protocol (GARP) configuration

See Figure 36 for the GARP configuration parameters.

```

TELNET.EXE
IBM 8275-416 High Performance Switch
- GARP Configuration Menu -                                00:06:29:CB:50:00

Unit ID ... <1>

GARP Applications:

  GVRP . . . . . <Enable >

GARP Timers:

  Join Time . . . . . [20 ] centiseconds
  Leave Time . . . . . [60 ] centiseconds
  Leave All Time . . . . . [1000] centiseconds

Press Space bar to Enable/Disable switch GVRP. Overrides Enable on 802.1Q Menu.

      APPLY      MAIN MENU      PREV MENU (F3)      HELP (F1)

For changes, [overtyping] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE

```

Figure 36. GARP configuration

GVRP Used to enable or disable GVRP (GARP VLAN Registration Protocol). The default is Disabled.

GARP Timers

- Join Time: Specifies the interval between the transmission of GARP PDUs registering (or reregistering) membership for a VLAN or multicast

group. This value applies per port and per GARP. The value can be from 10 to 100 centiseconds (0.1 to 1.0 seconds). The default is 20 centiseconds (0.2 seconds).

- Leave Time: Specifies the period of time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service. Values can be from 200 to 6000 centiseconds (2.0 to 60 seconds). The default is 60 centiseconds (0.6 seconds).
- Leave All Time: Controls how frequently Leave All PDUs are generated. A Leave All PDU indicates that all registrations will be shortly unregistered. Participants will need to rejoin in order to maintain registration. This value applies per port and per GARP participation. The value can be from 200 to 6000 centiseconds (2.0 to 60 seconds). The default is 60 centiseconds (0.6 seconds).

802.1Q port configuration

See Figure 37 for parameters used to configure your 802.1Q ports.

```

TELNET.EXE
IBM 8275-416 High Performance Switch
- 802.1Q Port Configuration Menu -
00:06:29:CB:50:00
Page 1 of 2

Unit ID... <1>   Slot < 0>   10-100 Copper Ports

Port   Port   Acceptable   Ingress   GVRP
-----
All   <----> <-----> <-----> <----->
1     <1 > <Admit All> <Disable> <Enable >
2     <1 > <Admit All> <Disable> <Enable >
3     <1 > <Admit All> <Disable> <Enable >
4     <1 > <Admit All> <Disable> <Enable >
5     <1 > <Admit All> <Disable> <Enable >
6     <1 > <Admit All> <Disable> <Enable >
7     <1 > <Admit All> <Disable> <Enable >
8     <1 > <Admit All> <Disable> <Enable >
Press Space Bar to select the slot number.

NEXT PAGE   APPLY   MAIN MENU   PREV MENU (F3)   HELP (F1)

For changes, [overtyp] or <use space bar>. Press ESC to discard change. Use TAB
or Arrow keys to navigate. F2=toggle between menu text and Command Bar. F4=SAVE

```

Figure 37. 802.1Q port configuration

Port Indicates by a slot ID and port number which port is controlled by the fields on this line. *All* specifies all ports on all slots.

Port VLAN ID

Indicates the VLAN ID that this port will assign to untagged frames or priority-tagged frames received on this port. The value must be the ID of an existing VLAN. The default is 1.

Acceptable Frame Types

Specifies the frames that will be passed through this port. The values can be *VLAN only* or *Admit All*. For *VLAN only*, untagged frames or priority frames received on this port are discarded. For *Admit All*, untagged frames or priority frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the 802.1Q VLAN Specification.

Ingress Filtering

Indicates that ingress filtering is enabled or disabled. The default is Disabled. If disabled is specified, frames received with VLAN IDs which do not match the VLAN membership of the receiving port are admitted and forwarded to ports which are members of that VLAN.

GVRP Indicates that GVRP is enabled or disabled. The default is Disabled.

VLAN reset

This function allows you to reset VLAN configuration parameters to those default parameters provided by the factory.

See Figure 38 for an example of the panel used to reset a VLAN.




Figure 38. VLAN reset

Statistics

To access statistics, select **Statistics Menu** on the Main Menu. Traffic statistics are kept by port. Details and summaries of packets broadcast, transmitted, and switched, as well as error packets and discarded packets are the types of statistics kept for your switch.

Figure 39 on page 56 shows the types of statistics that you can select to view from the Statistics Menu.

After making your selection, the panels containing statistics will refresh every few seconds.

Note: A description for each statistic may be obtained by pressing Help on the associated Web statistics panel.




Figure 39. Statistics Menu

Port summary statistics

To view a summary of port statistics, select **Port Summary Statistics Menu** from the Statistics Menu. See Figure 40 for a summary of port statistics that are collected.




Figure 40. Port summary statistics

Port detailed statistics

To view detailed port statistics, select **Port Detailed Statistics Menu** from the Statistics Menu (Figure 41 on page 57). Detailed port statistics are collected and

can be viewed on four consecutive panels. To view the next panel, move the cursor to NEXT PAGE (at the bottom of each panel) and press Enter.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Port Detailed Statistics Menu -
00:06:29:CB:50:00
Page 1 of 4
ifIndex 1

Unit <1> Slot <0> Port <1> 10-100 Copper Ports

PACKETS RECEIVED SUCCESSFULLY          PACKETS RECEIVED (OCTETS)
Total . . . . . 0                      Total . . . . . 0
Unicast . . . . . 0                    64 . . . . . 0
Multicast . . . . . 0                  65-127 . . . . . 0
Broadcast . . . . . 0                  128-255 . . . . . 0
                                           256-511 . . . . . 0
                                           512-1023 . . . . . 0
                                           1024-1518 . . . . . 0
                                           > 1518 . . . . . 0

Press Space Bar to select the slot number.

NEXT PAGE  PREV PAGE  CLEAR CTRS  MAIN MENU  PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate.
F2=toggle between menu text and Command Bar.
```

Figure 41. Port detailed statistics

Switch summary statistics

To view a summary of switch statistics, select **Switch Summary Statistics Menu** from the Statistics Menu. See Figure 42 for a summary of the switch statistics that are collected.

```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Switch Summary Statistics Menu -
00:06:29:CB:50:00

Unit ID < 1 >                                ifIndex 1000

Packets Received Without Error . . . . . 105738
Broadcast Packets Received . . . . . 0
Packets Received With Error . . . . . 0
Packets Transmitted Without Error . . . . . 117534
Broadcast Packets Transmitted . . . . . 2613
Transmit Packet Errors . . . . . 0
Address Entries Currently In Use . . . . . 47
VLAN Entries Currently In Use . . . . . 4

Time Since Counters Last Cleared . . . . 15:15:55

Clear statistic counters associated with the switch.


CLEAR CTRS  MAIN MENU  PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate.
F2=toggle between menu text and Command Bar.
```

Figure 42. Switch summary statistics

Switch detailed statistics

To view detailed switch statistics, select **Switch Detailed Statistics Menu** from the Statistics Menu. See Figure 43 for the detailed switch statistics that are collected.



```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Switch Detailed Statistics Menu -
00:06:29:CB:50:00
Page 1 of 2
ifIndex 1000
Unit ID < 1 >

RECEIVE
Octets . . . . . 3432249
Total Pkts . . . . . 105777
Unicast Pkts . . . . . 7061
Multicast Pkts . . . . . 98716
Broadcast Pkts . . . . . 0
Pkts Discarded . . . . . 0

TRANSMIT
Octets . . . . . 7076214
Total Pkts . . . . . 117576
Unicast Pkts . . . . . 6773
Multicast Pkts . . . . . 108190
Broadcast Pkts . . . . . 2613
Pkts Discarded . . . . . 3

Press Enter to display the Next Page.


NEXT PAGE  PREV PAGE  CLEAR CTRS  MAIN MENU  PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate.
F2=toggle between menu text and Command Bar.
```

Figure 43. Switch detailed statistics

Forwarding database information

To view forwarding database information, select **Forwarding Database Menu** from the Statistics Menu. See Figure 44 for the forwarding database information.



```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Forwarding Database Menu -
00:06:29:CB:50:00
Unit ID ... <1> Show entries starting at: [00:06:29:CB:50:06]

MAC Address          Slot.Port          Status
-----
00:04:AC:58:54:29    0.05              Learned
00:04:AC:6B:01:00    0.05              Learned
00:04:AC:6B:0F:00    0.05              Learned
00:04:AC:6B:0F:40    0.05              Learned
00:04:AC:6B:0F:57    0.05              Learned
00:06:29:21:76:99    0.05              Learned
00:06:29:CB:0A:80    0.06              Learned
00:06:29:CB:50:00    0.01              Management
00:06:29:CB:50:05    0.05              Management
00:06:29:CB:50:06    0.06              Management

Press Enter to search the Forwarding Database for the specified MAC address.

SEARCH          MAIN MENU      PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate. Press Enter to make a selection.
F2=toggle between menu text and Command Bar. F4=SAVE.
```

Figure 44. Forwarding database information

User account management

On the Main Menu, select **User Account Management Menu**. Figure 45 shows the data entry panel for specifying your user names, passwords, and access mode.




Figure 45. User account management

The switch allows you to add and delete users and set user passwords for the switch. You are to provide the following information:

User Name

User name can be up to eight alphanumeric characters and is not case sensitive. Up to six user names (accounts) can be defined; one with read/write access mode and five with read only access mode.

Password

The password can be up to eight alphanumeric characters and is not case sensitive. A blank password indicates no password. The default value is blank.

Confirm Password

The confirm password can be up to eight alphanumeric characters and is not case sensitive. You should use the same password as defined in the Password field. A blank confirm password indicates no password. The default value is blank.

Access Mode

This value is not configurable. User access mode can be:

Read/Write

Only one user can be defined with read/write access mode per switch. This user can change the status of other users, add and delete users, change passwords and change configurations, and use system utilities.

Read Only

Up to five users can be defined with read only access mode per switch. When Read only users are logged in, the message READONLY appears at the top right corner of all panels.

A user with read only access is restricted from accessing the SNMP Community Configuration menu, SNMP Trap Receiver Configuration

menu, User Account Management menu, and System Utilities menu. When a read only user tries to modify a configuration parameter on a menu, the data is not accepted and is not processed.

Status

Status applies to Read only user names; status can be Enable, Disable or Delete. Enable means that the user name is authorized to access the switch. Disable means that the user name is not allowed to access the switch. Delete means the user will be removed from the list upon an apply or save. The status of the read/write user name is always Enabled.

System utilities

The system utilities can be used only by users with read/write access. You can use the system utilities by selecting **System Utilities Menu** on the Main Menu. Figure 46 shows the available utilities.

Saving applied changes

To permanently save configuration changes either select **F4** to save or go to the System Utilities Menu and select **Save Applied Changes**, as shown in Figure 46.




Figure 46. Save applied changes

Logging out

When you have finished using the terminal interface, ensure you have saved and applied all configuration changes before you log out. The terminal interface provides an orderly way to log out. One way is to use the **LOGOUT** command on the Main Menu. Another way to log out is to select **System Utilities Menu** from the Main menu, then select **Logout** as shown in Figure 47 on page 61.




Figure 47. Logout utility

Handling files

To upload or download a file, select **System Utilities Menu** from the Main Menu. Then make the appropriate selection from the System Utilities Menu.

The switch can download or upload files. Downloading is the transfer of files from a remote server into the switch. Uploading is the transfer of files from the switch to a remote server.

You can retrieve configuration settings from the switch as a binary file and send a binary configuration file to the switch. This allows you to back up the configuration or to easily update the configuration of multiple switches. Additionally, you can provide a configuration file to IBM support personnel for problem determination.

The last-saved configuration used by the switch is retained after a code update or a reset.

The switch displays result messages to indicate the status of a file transfer. Table 10 and Table 11 on page 62 show the messages along with explanations for each.

Downloading code or configuration to the switch

Table 10. Messages - while downloading files

Message	Explanation
TFTP in progress...	The switch has initiated the file transfer with the TFTP server.
Can't start...previous transfer is not complete yet!	Another TFTP operation is still taking place. Only one TFTP operation can occur at a given time. This includes both download and upload operations. Wait until the previous operation completes.

Table 10. Messages - while downloading files (continued)

Message	Explanation
TFTP receive complete...storing in flash...	For Code only: The file has been successfully transferred to the switch and passed all the verification tests. It is now being stored permanently in flash memory.
TFTP receive complete... updating configuration	For Configuration only: The switch has received the file and will verify its integrity. The file will be stored in flash if it passes the integrity checks. The switch will reset itself after storing the file in order for the newly loaded configuration to take effect.
File transfer operation completed successfully.	The file has successfully been stored in flash. The switch must be reset now for the new code to become operational.
File failed CRC check!	The switch received the file, but detected a CRC error. Because the file is corrupted, it will not be stored in flash. Try obtaining another copy of the file.
This file is not intended for this product!	The switch received the file, but detected that the file was not meant for the switch. The file will not be stored in flash. If this is for a code update, obtain the correct software image from the IBM Web site. If this is for configuration, make sure that the configuration file originated from a 8275-416 switch.
Failure while storing in flash!	The switch successfully received the file, and began storing the image in flash; however, an error occurred during the process. For code only, the flash is most likely corrupt now and new code will have to be downloaded via the bootcode utility function. For configuration, retry the download. If the file transfer still fails, contact your IBM service representative.
File transfer failed!	A general error occurred. The most likely cause for this message is when the switch cannot complete the TFTP operation. This may happen if you have not entered the correct IP address for the TFTP server, or if an IP address has not been set up on the switch. Check to see if your IP addresses are configured correctly. Also, make sure that you can ping the TFTP server from the Ping Menu. This error could also occur if you entered an incorrect path or file name. Check to make sure these fields match the file location on the TFTP server.

Uploading trap log, error log, configuration or system trace from the switch

Table 11. Messages - while uploading files

Message	Explanation
TFTP in process...	The switch has initiated the file transfer with the TFTP server.
Can't start...previous transfer is not complete yet!	Another TFTP operation is still taking place. Only one TFTP operation can occur at a given time. This includes both download and upload operations. Wait until the previous operation completes.

Table 11. Messages - while uploading files (continued)

Message	Explanation
Error while preparing file for transfer.	Before uploading a file, the switch must prepare that file for transfer. This message means that there was a problem either in reading the information required for making the file, or there was a problem creating the file. Contact your IBM service representative.
File transfer failed!	A general error occurred. The most likely cause of this message is when the switch cannot complete the TFTP operation. This may happen if you have not entered the correct IP address for the TFTP server, or if an IP address has not been set up on the switch. Check to see if your IP addresses are configured correctly. Also, make sure that you can ping the TFTP server from the Ping Menu. This error could also occur if you entered an incorrect path or file name. Check to make sure these fields match the file location on the TFTP server.
File transfer completed successfully	The switch successfully sent the file to the TFTP server.

Downloading a file to the switch

Downloading is the transfer of files from a remote server into the switch. The download operation is initiated by selecting **Download File to Switch Menu** on the System Utilities Menu (Figure 48). While the download is in process, you may see messages displayed. Table 10 on page 61 shows messages that can appear during the download process.




Figure 48. Downloading a file to the switch

Uploading a file from the switch

Uploading is the transfer of files from the switch to a remote server (Figure 49 on page 64).




Figure 49. Uploading a file from the switch

The following parameters apply to uploading and downloading of files.

File Type

The file types are:

For Download

- Code (the default)
- Configuration

For Upload

- Configuration
- Error log
- System trace
- Trap log (the default)

Upload or Download Mode

The mode is either XMODEM or TFTP. XMODEM is valid only when the file transfer is initiated by the serial EIA 232 port. The default value is XMODEM.

Start Transfer Now

Enter Yes or No. The value is No whenever the panel is initially displayed.

File Name

The file name can be up to 16 alphanumeric characters. The switch remembers the last file name used. The default value is blank.

File path can be appended to the file name if the string is less than 17 characters. Otherwise, the File Path field will need to be used and the File Name will be appended to the File Path as is. An example would be File Path set to **c:lftplcode1** and File Name set to **e1r1v1.opr**.

Note: File Name, File Path, and TFTP Server IP Address are applicable only if the Transfer Mode is TFTP.

File Path

The directory path where the file is located or where it is to be uploaded to. The switch remembers the last file path used. The default value is blank.

TFTP Server IP Address

The IP address of the server where the file is located. It is valid only when the Transfer Mode is TFTP. The address is 4 decimal bytes ranging from 0 to 255. The default value is zeros.

Reset utility

You can reset the switch without powering it off. Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted for confirmation if you want the reset to proceed. A successful reset is indicated by the LEDs on the switch.

After selecting Reset Menu from the System Utilities Menu, you are given the choice of the resets you can request as shown Figure 50.



```
TELNET.EXE
IBM 8275-416 High Performance Switch
- Reset Menu -
                                UNSAVED DATA
                                00:06:29:CB:50:00

System Reset Menu
Reset Configuration Data To Factory Defaults Menu
Reset Passwords To Factory Defaults Menu

Reset the switch.

MAIN MENU    PREV MENU (F3)  HELP (F1)

Use Tab or Arrow keys to navigate. Press Enter to make a selection.
F2=toggle between menu text and Command Bar.  F4=SAVE
```

Figure 50. System Reset menu

System reset menu

Reset the system by indicating the particular unit as shown in Figure 51 on page 66. You must identify the switch to reset. *None* is the default.




Figure 51. System reset menu

Resetting configuration data to factory default values

You can reset the configuration to factory default values without powering off the switch. The factory defaults are not restored until the switch is reset. The switch is automatically reset when this command is processed. You are prompted to confirm that you want the reset to proceed.

Reset the configuration data to the factory defaults by indicating the particular unit as shown in Figure 52 on page 67. You must identify the switch to reset. *None* is the default.




Figure 52. Reset configuration data to factory defaults

Resetting passwords to factory default values

You can reset user passwords to factory default values without powering off the switch. The factory defaults are not restored until the switch is reset. The switch is automatically reset when this command is processed. You are prompted to confirm that you want the reset to proceed.

Reset the passwords by indicating the particular unit as shown in Figure 53. You must identify the switch to reset. None is the default.




Figure 53. Reset passwords to factory defaults

Chapter 5. Using the Web Interface

You can manage your switch through your Web browser and Internet connection. This is referred to as Web-based management. To access the switch, your Web browser must support:

- HTML version 4.0, or later
- HTTP version 1.1, or later
- JavaScript™ version 1.2, or later

This chapter explains how to access the switch Web-based management panels to configure and manage your switch.

It is important to note that there are equivalent functions in the Web interface as in the terminal interface (that is, there are usually the same menus to accomplish a task). For example, when you log in, there is a Main Menu with the same functions available, and so on. The Web login session will be automatically logged off based on the Telnet timeout settings. There are several differences between the Web and terminal interface. For example, on the Web interface the entire forwarding database can be displayed, and the terminal interface only displays 10 entries starting at specified addresses.

So, if you have read “Chapter 3. Configuring your switch” on page 21 and “Chapter 4. Using the Terminal Interface” on page 27, navigating the Web interface will not be difficult. This chapter is a brief introduction to the Web interface.

Configuring for Web Access

To have Web access to the switch:

- Configure the switch for in-band connectivity (see “Chapter 2. Accessing the switch” on page 15).
- Enable Web mode (see “Configuring network connection for the switch” on page 31.)

Web Page Layout

A Web interface panel for the switch Web page consists of three frames (Figure 54 on page 70). Frame 1, across the top, appears a banner graphic of the switch. Frame 2, at the bottom-left displays a hierarchical-tree view. The tree consists of a combination of folders, subfolders, and configuration and status HTML pages. You can think of the folders and subfolders as branches and the configuration and status HTML pages as leafs. Only the selection of a leaf (not a folder or subfolder) will cause Frame 2 to display a new HTML page. A folder or subfolder has no corresponding Frame 3 HTML page. Frame 3, the bottom-right frame, displays the currently selected device configuration status or the user configurable information that you have selected from the tree view of Frame 2, or both. You can resize each of these frames. There are no fixed-sized frames.




Figure 54. Web interface panel—example

Starting the Web Interface

Note: You must configure the IP address of the switch before using the Web interface.

Follow these steps to bring up the switch Web interface:

1. Enter the IP address of the switch in the Web browser address field.
2. When the Login panel is displayed, enter the appropriate User Name and Password. The User Name and associated password are the same ones used for the terminal interface. Click on the **Login** button. The navigation tree is displayed in Frame 2, and the System Description Menu is displayed in Frame 3.
3. Make your selection by clicking on the appropriate item in the navigation tree in Frame 2.

Note: There is an inactivity timeout associated with a Web session. The timeout value is the same one that is used for Telnet sessions.

Commands

The following command buttons are used throughout the Web interface panels for the switch:

Undo Restores any changes made on the panel to their original value since the last Apply or Save.

- Save** Implements and saves the changes you just made. Some settings may require you to reset the system in order for them to take effect.
- Apply** Implements the changes you just made. Some settings may require you to reset the system for them to take effect.
- Refresh**
The Refresh button that appears next to the Apply button in Web interface panels refreshes the data on the panel.
- Restart**
Refreshes the list and displays the data starting at the beginning of the list.
- Next** Displays the next set of information in the list.

Chapter 6. Using the SNMP Interface

The switch has an SNMP agent that supports SNMPv1. This allows it to be managed by any SNMP-based application that supports the MIBs supported by the switch. The switch SNMP agent communicates with:

- Any standard MIB Browser (SNMPv1)
- IBM Nways Manager for Windows NT[®] V2.0 or later
- IBM Nways Manager for HP-UX V2.0 or later
- IBM Nways Manager for AIX[®] V2.0 or later

The SNMP-based application must specify the appropriate community name that the switch is configured to support. Real-time trap messages can be configured to be sent to designated trap receivers. All configuration information on the switch has read/write access via SNMP. All status information is also available via SNMP.

Refer to “Chapter 4. Using the Terminal Interface” on page 27 for details about configuring SNMP and SNMP trap receiver.

MIBs supported

Refer to the various SNMP RFCs that are supported because the SNMP specification is not described in this chapter. MIBs supported by the switch are shown in Table 12.

Table 12. MIBs Supported by the Switch.

MIBs Supported

MIB-II (RFC 1213)

Definitions of Managed Objects for Bridges (RFC 1493)

IEEE 802.3 Ethernet MIB (RFC 1643)

RMON MIB (RFC 1757)

IBM 8275-416 MIB

The latest 8275-416 MIBs can be obtained from our Web site at:

<http://www.ibm.com/networking/support>

Note: Exceptions to the 8275-416 support for the MIBs listed in Table 12 are described in the sections that follow in this chapter.

MIB II (RFC 1213)

The following are 8275-416 exceptions to the support of MIB II groups:

Address Translation (AT) Group

All the objects are read-only; none are read/write.

Interface Groups

For Ethernet ports, ifAdminStatus is a read-only object instead of read/write. To modify the status of a port interface via SNMP, swPortCtrlAdminMode in the 8275-416 private MIB must be used. There is no explicit ifAdminStatus associated for the Management Interface via MIB-II or any other MIB or access method.

IP Group

- ipNetToMediaTable is read-only; not read/write
- ipAddrTable is not supported
- ipRouteTable is not supported

EPG Group

Not supported.

The switch automatically collects and provides information for the MIB II groups that it supports. There are no additional configuration parameters to enable or disable this support.

Definitions of managed objects for bridges (RFC 1493)

RFC 1493 defines objects for managing MAC bridges based on IEEE 802.1D-1990 standard between local areas network (LAN) segments. The following objects are 8275-416 exceptions to definitions of managed objects for bridges:

dot1dStp

dot1dStpPortEnable is a read-only object. To modify the administrative state of an interface via SNMP, use swPortCtrlAdminMode in the 8275-416 private MIB.

dot1dSr Group

Not supported.

dot1dStatic Group

Not supported.

dot1dTP

Not supported.

dot1dTpLearnedEntryDiscards

Not supported.

IEEE 802.3 Ethernet MIB (RFC 1643)

RFC 1643 defines objects for managing Ethernet-like objects. The following objects are 8275-416 exceptions to IEEE 802.3 Ethernet MIB.

dot3StatsTable Group

The following objects are not supported:

- dot3StatsSQETestErrors
- dot3StatsDeferredTransmissions
- dot3StatsLateCollisions
- dot3StatsInternalMacTransmitErrors
- dot3StatsCarrierSenseErrors
- dot3StatsInternalMacReceiveErrors
- dot3StatsEtherChipSet

dot3CollTable Group

Not supported.

dot3Tests Group

Not supported.

dot3Errors Group

Not supported.

The switch automatically collects and provides information for the IEEE 802.3 Ethernet MIB groups that it supports. There are no additional configuration parameters to enable or disable this support.

Remote monitoring (RMON) MIB (RFC 1757)

The RMON MIB defines objects that allow a device to act like a network traffic analyzer monitoring flows and gathering data for all traffic on the network with varying degrees of detail. It is recommended that a Remote Monitor application be used to manipulate RMON MIB objects. Unexpected results can occur if an SNMP MIB browser is used to manipulate RMON MIB objects.

Note: The switch only supports up to 10 history buckets per history instance.

IBM 8275-416 switch enterprise MIB

Many of the items needed to obtain information from a switch are not available in standard MIBs. A private MIB for the switch (referred to as the IBM 8275-416 Switch Enterprise MIB) was created for these items.

The following objects in the 8275-416 MIB are not supported by this version of code:

- swPortMonitorNetworkConnection
- swDevTrapConsole

Whenever the above objects are accessed, the switch will return an SNMP GetResponse-PDU[2] error-status = no SuchName(2)

Port ifIndex values

When you use SNMP, the interface index (ifIndex) is sometimes used to identify the specific interface being addressed. On the switch, each Ethernet port is an interface and so is the IP agent being used to manage it (which is also referred to as the Management Interface).

The total number of ifIndex values in the switch is the number of installed ports plus 1. The "1" is for the Management Interface. The port ifIndex values for the switch ports start with 1 and increment by 1 for each port physically in the box. Each ifIndex value maps, one for one, with an Ethernet port. Example scenarios:

- If there are 32 ports (16 base ports, 8 ports in slot 1, 8 ports in slot 2)
 - ifIndex 1 is slot 0, port 1
 - ifIndex 9 is slot 0, port 9
 - ifIndex 17 is slot 1, port 1
 - ifIndex 25 is slot 2, port 1
- If there are 24 ports (16 base ports, 8 ports in slot 2)
 - ifIndex 1 is slot 0, port 1
 - ifIndex 9 is slot 0, port 9
 - ifIndex 25 is slot 2, port 1
- If there are 28 ports (16 base ports, 4 ports in slot 1 and the ports are on the right side of the card, 8 ports in slot 2)
 - ifIndex 1 is slot 0, port 1
 - ifIndex 9 is slot 0, port 9
 - ifIndex 21 is slot 1, port 1
 - ifIndex 25 is slot 2, port 1

The management interface will always have an ifIndex of 1000.

Chapter 7. Troubleshooting and Obtaining Service

Diagnosing Problems

This chapter contains procedures that help you to troubleshoot problems with your switch and its connections to other devices.

Be sure you read “Appendix A. Safety Information” on page 81 before proceeding.

Obtaining Software

To obtain support information, including technical tips, current product information, and code updates and fixes for the switch, visit the IBM Networking Tech Support page at:

<http://www.ibm.com/networking/support>

You can also subscribe to receive e-mail notifications about code updates, tips, and FAQs for your switch.

Troubleshooting in a Network

The switch terminal interface, Web interface, and SNMP management agent give you access to important statistics and other information about the network. To obtain these statistics, see “Chapter 4. Using the Terminal Interface” on page 27 and “Chapter 5. Using the Web Interface” on page 69 and select the appropriate panels.

Start of Troubleshooting Process

If one or more devices (such as workstations) connected to a switch are unable to communicate with other devices in the network, use the following steps to start the troubleshooting process:

1. Locate the switch to which the device is connected. Use the network sketch, the label on the cable connected to the device, or other network records to help you locate the switch.
2. Have available any documentation associated with the feature modules that are installed on the switch.
3. If you have an EIA 232 console session set up, (see “Chapter 2. Accessing the switch” on page 15), you can use it to determine if diagnostics have been completed correctly.
4. Observe the LEDs on the front panel of the switch. The location of these LEDs is shown in Figure 2 on page 7 with explanations of the LED status conditions in the accompanying table. Ignore the feature module LEDs at this time. Review this information before proceeding with the troubleshooting process.
5. If the LED status are not OK, locate the symptom that best describes the communication problem and the LED status you observed in Table 13 on page 78. Then go the section that contains the recommended actions for resolving the problem and follow that procedure.

Choosing a Troubleshooting Procedure

Use Table 13 to determine which troubleshooting procedure you should use. Unless otherwise stated, references to the OK and Fault LEDs are those on the switch.

Table 13. Troubleshooting Symptoms and Actions

Symptom and LED State	Action
The Fault LED and the OK LED are Off, and the fan is not running	Go to "Procedure A"
The Fault LED is blinking.	Diagnostics are still in progress...Wait
The Fault LED is On and there is a "1" in the single-digit display.	Go to "Procedure E" on page 80
The Fault LED is On and there is a character other than a "1" displayed in the single-digit display.	Go to "Procedure B"
None of the devices connected to the switch can communicate, the Fault LED is Off and the Power (I) LED is On.	Go to "Procedure C" on page 79
A single device connected to the switch is having trouble communicating.	Go to "Procedure D" on page 79
A feature module Fault LED is On.	Remove and replace the feature module.

Note: The term *segment* refers to a single cable or interconnected cables between a port and the device at the other end.

Procedure A

Use this procedure if all LEDs are Off:

1. Verify that the ac power outlet to which the switch power supply is connected is active. If an uninterruptible power supply (UPS) is being used to provide ac power, ensure that the UPS is working correctly.
2. Verify that the power cord is installed correctly.
3. If the preceding conditions are satisfied, the power supply is defective. See "Obtaining Service" on page 80.

Procedure B

Use this procedure if the Fault LED is On, and there is a character other than a "1" in the single-digit display:

1. Reset the switch by disconnecting the power cord from the outlet, waiting 10 seconds, and reconnecting the power cord to the outlet. If this corrects the problem, resume using the switch.
2. One or more faulty feature modules can cause this symptom, and the remaining ports might continue to operate.
 - a. If you have feature modules, remove them.
 - b. Reset the switch.
 - c. If the switch comes up, reinstall the feature modules one at a time, and reset the switch to determine the failing feature module.
3. If the problem is not corrected, the switch is defective. See "Obtaining Service" on page 80.

Procedure C

Use this procedure if all devices connected to the switch are having communication problems, the Fault LED is Off and the OK LED is On:

1. Reset the switch by disconnecting the power cord from the outlet, waiting 10 seconds, and reconnecting the power cord to the ac outlet.
 - If the problem goes away, resume using the switch.
 - If the status LEDs indicate a failure, go to “Procedure B” on page 78.
 - If the problem persists, check all the configuration parameters.
 - If the problem has still not been resolved, go to “Procedure D” and try to get individual ports working.

Procedure D

Use this procedure if one device connected to the switch is having a communication problem, the Fault LED is Off, the OK LED is On and other attached devices can communicate through the switch:

1. If the port LED is Off (left LED On 10/100BASE-TX port and single port LED On 100BASE-FX port):
 - Check the cable and the attached device.
 - Check the configuration settings to ensure they are OK.
2. If the port Link LED is On:
 - a. Go to the Port Configuration Menu. Check that the port is administratively enabled, has not been diagnostically disabled, has link up, and is in spanning tree forwarding state.
 - b. Go to the Port Monitoring Menu. Check that the port is not a monitoring port.
 - c. Go to the VLAN Management Menu. Check that the port is a member of the VLAN over which traffic from this device would transverse (this is usually VLAN 1). See “Appendix E. Introduction to Virtual LANs (VLANs)” on page 107 for more details.
 - d. Try pinging the attached device from another device in the same VLAN. (The switch is a member of VLAN 1; all ports are in VLAN 1 by default.)
 - e. If ping is received, go to Step 5.
 - f. If the ping is not received, go to Step 3.
3. Restart the communications program on the failed connected device.
 - If the communications program appears to start without errors, observe the port LED on the switch port. If it is On it might have gone away. Check the port configuration parameters for possible causes of the failure.
 - If the problem persists, go to Step 4.
4. For each device that is having a communication problem, connect its segment to another identically configured Ethernet port on the switch. Try each of the remaining ports to determine if the problem will go away.
 - If the problem goes away, the problem might be in the switch. See “Obtaining Service” on page 80.
 - If the problem persists, continue with Step 5.
5. The problem does not appear to be in the switch and the cables and devices connected to the switch. The problem might be in the network applications or other software running on the devices that are having the communication problem. Refer to the networking software documentation for software problem determination procedures, or consult your network administrator for assistance.

Procedure E

Any port failing Power-On self test diagnostics will be “diagnostically disabled” when the switch becomes operational. Ports not failing diagnostics will be unaffected and will initialize to their configured state. This fault tolerant feature allows the switch to provide levels of connectivity even in the event of hardware failures. A quick glance at the Fault LEDs allows you to determine if the switch has diagnostically disabled any ports.

If a “1” appears in the single-digit display and any Fault LED is on solid, ports have been diagnostically disabled. If a console is connected to the switch through the EIA 232 port, a list of problem ports is printed on the console immediately after diagnostics and before entering operational code. You can also examine the Port Configuration Menu accessible from the Device Configuration Menu. Any ports with an “x” in the “STP St” column have been diagnostically disabled. To isolate this problem:

1. Ensure that the feature modules are seated.
2. Reset the switch.
3. Replace any feature module if its LED is On; the feature module is defective.
4. Replace the switch if the its Fault LED is On; the switch is defective.

Obtaining Service

There are no user-serviceable parts inside the switch chassis. All feature modules are replaceable by the user.

If you need assistance in troubleshooting or you need service for your 8275–416, call IBM at:

- 1 800 772 2227 in the United States
- 1 800 426 7378 (1 800 IBM-SERV) in Canada.
- In other locations, contact your place of purchase.

Refer to your IBM Warranty for information concerning service for the product, or contact the place where you purchased the product.

Appendix A. Safety Information

Reference to Safety Booklet



Danger: Before you begin to install this product, read the safety information in *Caution: Safety Information—Read This First*, SD21-0030. This booklet describes safe procedures for cabling and plugging in electrical equipment.



Gevaar: Voordat u begint met de installatie van dit produkt, moet u eerst de veiligheidsinstructies lezen in de brochure *PAS OP! Veiligheidsinstructies—Lees dit eerst*, SD21-0030. Hierin wordt beschreven hoe u elektrische apparatuur op een veilige manier moet bekabelen en aansluiten.



Danger: Avant de procéder à l'installation de ce produit, lisez d'abord les consignes de sécurité dans la brochure *ATTENTION: Consignes de sécurité—A lire au préalable*, SD21-0030. Cette brochure décrit les procédures pour câbler et connecter les appareils électriques en toute sécurité.



Perigo: Antes de começar a instalar este produto, leia as informações de segurança contidas em *Cuidado: Informações Sobre Segurança—Leia Isto Primeiro*, SD21-0030. Esse folheto descreve procedimentos de segurança para a instalação de cabos e conexões em equipamentos elétricos.



危險：安裝本產品之前，請先閱讀
"Caution: Safety Information—Read
This First" SD21-0030 手冊中所提
供的安全注意事項。這本手冊將會說明
使用電器設備的纜線及電源的安全程序。



Opasnost: Prije nego što počnete sa instalacijom produkta, pročítajte naputak o pravilima o sigurnom rukovanju u Upozorenje: Pravila o sigurnom rukovanju - Prvo pročítaj ovo, SD21-0030. Ovaj privitak opisuje sigurnosne postupke za priključivanje kabela i priključivanje na električno napajanje.



Upozornění: než zahájíte instalaci tohoto produktu, přečtěte si nejprve bezpečnostní informace v pokynech „Bezpečnostní informace“ č. 21-0030. Tato brožurka popisuje bezpečnostní opatření pro kabeláž a zapojení elektrického zařízení.



Fare! Før du installerer dette produkt, skal du læse sikkerhedsforskrifterne i *NB: Sikkerhedsforskrifter—Læs dette først* SD21-0030. Vejledningen beskriver den fremgangsmåde, du skal bruge ved tilslutning af kabler og udstyr.



Gevaar Voordat u begint met het installeren van dit produkt, dient u eerst de veiligheidsrichtlijnen te lezen die zijn vermeld in de publikatie *Caution: Safety Information - Read This First*, SD21-0030. In dit boekje vindt u veilige procedures voor het aansluiten van elektrische apparatuur.



VAARA: Ennen kuin aloitat tämän tuotteen asennuksen, lue julkaisussa *Varoitus: Turvaohjeet—Lue tämä ensin*, SD21-0030, olevat turvaohjeet. Tässä kirjasessa on ohjeet siitä, miten sähkölaitteet kaapeloidaan ja kytketään turvallisesti.



Danger : Avant d'installer le présent produit, consultez le livret *Attention: Informations pour la sécurité — Lisez-moi d'abord*, SD21-0030, qui décrit les procédures à respecter pour effectuer les opérations de câblage et brancher les équipements électriques en toute sécurité.



Vorsicht: Bevor mit der Installation des Produktes begonnen wird, die Sicherheitshinweise in *Achtung: Sicherheitsinformationen—Bitte zuerst lesen*, IBM Form SD21-0030, lesen. Diese Veröffentlichung beschreibt die Sicherheitsvorkehrungen für das Verkabeln und Anschließen elektrischer Geräte.



Κίνδυνος: Πριν ξεκινήσετε την εγκατάσταση αυτού του προϊόντος, διαβάστε τις πληροφορίες ασφάλειας στο φυλλάδιο *Caution: Safety Information—Read this first*, SD21-0030. Στο φυλλάδιο αυτό περιγράφονται οι ασφαλείς διαδικασίες για την καλωδίωση των ηλεκτρικών συσκευών και τη σύνδεσή τους στην πρίζα.



Vigyázat: Mielőtt megkezdi a berendezés üzembe helyezését, olvassa el a *Caution: Safety Information—Read This First*, SD21-0030 könyvecskében leírt biztonsági információkat. Ez a könyv leírja, milyen biztonsági intézkedéseket kell megtenni az elektromos berendezés huzalozásakor illetve csatlakoztatásakor.



Pericolo: prima di iniziare l'installazione di questo prodotto, leggere le informazioni relative alla sicurezza riportate nell'opuscolo *Attenzione: Informazioni di sicurezza — Prime informazioni da leggere*, SD21-0030, in cui sono descritte le procedure per il cablaggio ed il collegamento di apparecchiature elettriche.



危険： 導入作業を開始する前に、安全に関する小冊子SD21-0030 の「最初にお読みください」(Read This First)の項をお読みください。
この小冊子は、電気機器の安全な配線と接続の手順について説明しています。



위험: 이 제품을 설치하기 전에 반드시 "주의: 안전 정보-시작하기 전에" (SD21-0030) 에 있는 안전 정보를 읽으십시오.



ОПАСНОСТ

Пред да почнете да го инсталирате овој продукт, прочитајте ја информацијата за безбедност:
"Предупредување: Информација за безбедност: Прочитајте го прво ова", SD21-0030.
Оваа брошура опишува безбедносни процедури за каблирање и вклучување на електрична опрема.



Fare: Før du begynner å installere dette produktet, må du lese sikkerhetsinformasjonen i *Advarsel: Sikkerhetsinformasjon — Les dette først*, SD21-0030 som beskriver sikkerhetsrutinene for kabling og tilkobling av elektrisk utstyr.



Uwaga:
Przed rozpoczęciem instalacji produktu należy zapoznać się z instrukcją: "Caution: Safety Information - Read This First", SD21-0030.
Zawiera ona warunki bezpieczeństwa przy podłączaniu do sieci elektrycznej i eksploatacji.



Perigo: Antes de iniciar a instalação deste produto, leia as informações de segurança *Cuidado: Informações de Segurança — Leia Primeiro*, SD21-0030. Este documento descreve como efectuar, de um modo seguro, as ligações eléctricas dos equipamentos.



ОСТОРОЖНО: Прежде чем установить этот продукт, прочтите Инструкцию по технике безопасности в документе "Внимание: Инструкция по технике безопасности -- Прочсть в первую очередь", SD21-0030. В этой брошюре описаны безопасные способы кабирования и подключения электрического оборудования.



Nebezpečnostvo: Pred inštaláciou výrobku si prečítajte bezpečnosté predpisy v Výstraha: Bezpečnosté predpisy - Prečítaj ako prvé, SD21-0030. V tejto brožúrke sú opísané bezpečnosté postupy pre pripojenie elektrických zariadení.



Pozor: Preden začnete z instalacijo tega produkta preberite poglavje: "Opozorilo: Informacije o varnem rokovanju-preberi pred uporabo," SD21-0030. To poglavje opisuje pravilne postopke za kabliranje.



Peligro: Antes de empezar a instalar este producto, lea la información de seguridad en *Atención: Información de Seguridad — Lea Esto Primero*, SD21-0030. Este documento describe los procedimientos de seguridad para cablear y enchufar equipos eléctricos.



Varning — livsfara: Innan du börjar installera den här produkten bör du läsa säkerhetsinformationen i dokumentet *Varning: Säkerhetsföreskrifter— Läs detta först*, SD21-0030. Där beskrivs hur du på ett säkert sätt ansluter elektrisk utrustning.



危險：

開始安裝此產品之前，請先閱讀安全資訊。

注意：

請先閱讀 - 安全資訊 SD21-0030

此冊子說明插接電器設備之電纜線的安全程序。

Safety Notice



Danger: Double-pole/neutral fusing in the power supply. Power might present in the product unless the power cord is unplugged.



Cuidado: Fusível bipolar/neutro na fonte de alimentação. Pode haver energia presente no produto, a menos que o cabo de alimentação esteja desconectado.



Waarschuwing:

Dubbelpool/neutrala zekering in de voedingseenheid. Er kan spanning in het product aanwezig zijn zolang de stekker in het stopcontact zit.



Pas på!

Strømforsyningsenheden; er sikret til brug ved 110 og 220 volt. Der kan være; spænding; i produktet, medmindre netledningen er trukket ud.



VAARA: Virtalähde on varustettu kaksinapaisella sulakkeella, jossa on myös maanapa. Tuotteessa voi olla jännite, jos verkkojohtoa ei ole irrotettu.



ATTENTION : L'un des deux fusibles est sur le neutre. L'alimentation électrique est protégée e par fusibles sur les deux pôles (phase et neutre). Pré sence de courant possible sauf si le cordon d'alimentation est débranché.



Achtung: Zweipolige bzw. Neutralleiter-Sicherung im Netzteil. Netzstecker ziehen, um sicherzustellen, daß; keine Spannung am Gerät; anliegt.



Attenzione: L'alimentatore contiene fusibili su fasi/neutro. Può essere presente tensione nell'apparecchiatura se il cavo di alimentazione è collegato.



Advarsel: Topolet/nøytral; sikring i strømforsyningsenheten.; Det kan være; strøm; i maskinen hvis ikke nettkabelen er dratt ut .



Cuidado:

Protecção (por fusíveis) bipolar com neutro na fonte de alimentação. A menos que o cabo de alimentação esteja desligado, o produto pode estar sob tensão.



Precaución: Hay una fusión de doble polo/neutro en la fuente de alimentación. El producto podría estar cargado eléctricamente a menos que el cable de alimentación esté desconectado.



WARNING: Nätaggregatet är dubbelpoligt avsäkrat. Det kan finnas ström i produkten sövida inte när 228;tkabeln urkopplad.



تحذير: القطب الثنائي أمحايد الانصهار في مصدر الطاقة .
يمكن أن تكون الكهرباء موجودة في المنتج ما لم يتم فصل سلك
الكهرباء.



Предупреждение: Дублирано - фаза/нула свързване в енергийното
захранване. Възможно е наличие на ел.енергия в уреда, докато
захранващият кабел не е изваден от контакта.



Opasnost: Energetski izvor opremljen je osiguračima na faznom i nultom
priključku. Uređaj može ostati pod naponom sve dok se priključni kabel ne
odvoji od utičnice.



注意：电源中装有双柱式/中性保险丝。除非未插入电源线，否则产品带电。



注意：電源供應器內含雙極/中性熔絲 (Double-pole/neutral fusing) 。未將電源線自插座拔掉前，本產品內部可能有電存在。



Pozor: V napájecím zdroji je dvupólové jištění (pojistka ve středním vodiči). Dokud není napájecí šňůra odpojená od sítě, může být zařízení pod napětím.



Προσοχή: Ασφάλεια δύο πόλων/ουδέτερου στην πηγή ρεύματος. Ενδέχεται να υπάρχει ηλεκτρική ισχύς στο προϊόν εάν δεν έχει αποσυνδεθεί το καλώδιο ρεύματος.



זהירות : נתיך דו-קוטבי/נייטרלי באספקת הכוח.
יש לנתק את כבל הכוח כדי למנוע זרם חשמל
במוצר.



Figyelem: A tápegységben kétpólusú biztosíték található. A termék kikapcsolt állapotban is feszültség alatt állhat, kivéve, ha a tápkábel ki van húzva.



注意：

この電源は、2極/中性線にヒューズを使用しています。
電源コードを抜いていない状態では電圧がかかっています。



주의: 전원 공급 장치에 양극/중성의 퓨즈가 있습니다.
전원 코드가 연결되지 않아도 제품 내에 전원이 잔류할 수 있습니다.



Uzmanību: Divpolu/neitrālā apvienotā strāvas apgāde.
Iespējams, ka produktā ir elektriskā strāva, ja strāvas vada
kontaktdakša nav izrauta no ligzdas.



Dėmesio: Įrenginyje yra atvirų dvigubų kontaktų su įtampa. Jeigu įrenginys neišjungtas, kai kurios dalys gali būti su įtampa.



Опасност: Во единицата за напојување има двополен осигурувач. Доколку кабелот за напојување не е исклучен, во производот може да биде присутна електрична енергија.



Uwaga: W zasilaczu zamontowany jest bezpiecznik.
Dopóki kabel zasilający nie zostanie odłączony w urządzeniu może występować napięcie.



Pericol: O siguranță neutră/două capete este în sursa de alimentare.
Tensiunea poate să fie prezentă în produs dacă nu este scos din priză
cablul de alimentare.



Осторожно: Источник питания с двухполюсным предохранителем. Устройство может быть под напряжением, пока вы не выдернете шнур из розетки.



Опасност: Извор напајања је опремљен осигурачима на фазном и нултом прикључку. У уређају може бити присутан напон осим ако је прикључни кабл одвојен од утичнице.



Výstraha: Poistky sú na oboch póloch napájacieho zdroja.
Pokiaľ nie je odpojená šnúra zo siete, zariadenie môže byť pod napätím.



Nevarnost: Pri napajalniku je zagotovljeno varovanje polov in nevtralnega vodnika. Napetost je lahko prisotna na izdelku, če priključnega kabla ne potegnemo iz vtičnice.



Dikkat: Güç kaynağı çift kutuplu, topraklı sigorta içerir. Güç kablosu prizden çekilmedikçe üründe elektrik bulunabilir.

Appendix B. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering the subject matter in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation
Licensing
2-31 Roppongi 3-chome, Minato-ku
Tokyo 106, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

Electronic Emission Notices

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada Class A Emission Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

Avis de conformité aux normes d'Industrie Canada

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Norm (EN) Statement

This product is in conformity with the protection requirements of EU Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to CISPR 22/European Standard EN 55022. The limits for Class A equipment were derived from commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) vom 30. August 1995 (bzw. der EMC EG Richtlinie 89/336)

Dieses Gerät ist berechtigt in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Konformitätserklärung nach Paragraph 5 des EMVG ist die IBM Deutschland Informationssysteme GmbH, 70548 Stuttgart.

Informationen in Hinsicht EMVG Paragraph 3 Abs. (2) 2:

Das Gerät erfüllt die Schutzanforderungen nach EN 50082-1 und EN 55022 Klasse A.
--

EN 55022 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden: "Warnung: dies ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funkstörungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen durchzuführen und dafür aufzukommen."

EN 50082-1 Hinweis: "Wird dieses Gerät in einer industriellen Umgebung betrieben (wie in EN 50082-2 festgelegt), dann kann es dabei eventuell gestört werden. In solch einem Fall ist der Abstand bzw. die Abschirmung zu der industriellen Störquelle zu vergrößern."

Anmerkung: Um die Einhaltung des EMVG sicherzustellen sind die Geräte, wie in den IBM Handbüchern angegeben, zu installieren und zu betreiben.

Japanese Voluntary Control Council for Interference (VCCI) Statement

This product is a Class A Information Technology Equipment and conforms to the standards set by the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). In a domestic environment this product may cause radio interference, in which case the user may be required to take adequate measures.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Korean Communications Statement

Please note that this device has been certified for business purpose with regard to electromagnetic interference. If you find this is not suitable for your use, you may exchange it for one of residential use.

Power line harmonics compliance

高調波ガイドライン適合品

Taiwanese Class A Warning Statement

警告使用者：
這是甲類的資訊產品，在
居住的環境中使用時，可
能會造成射頻干擾，在這
種情況下，使用者會被要
求採取某些適當的對策。

Class 1 Laser Statement

Class 1 Laser Product
Laser Klasse 1
Laser Klass 1
Luokan 1 Laserlaite
Appareil à Laser de Classe 1
To IEC 825-1:1993

Class 1 LED Statement

Class 1 LED Product
LED Klasse 1
LED Klass 1
Luokan 1 Ledlaite
Appareil à LED de Classe 1
To IEC 825-1:1993

Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States or other countries or both:

AIX
IBM
Nways

Microsoft, Windows, Windows NT, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

Java and all Java-based trademarks and logos are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Other company, product, and service names may be trademarks or service marks of others

Appendix C. Cable Pinout Diagrams

This appendix specifies Ethernet and null-modem cable pinouts.

Straight-Through 10BASE-T/100BASE-TX Cables




Figure 55. Straight-Through UTP Cable (RJ-45 to RJ-45), T568A




Figure 56. Straight-Through UTP Cable (RJ-45 to RJ-45), T568B

Straight-Through 10BASE-T/100BASE-TX Cables for STP

RJ-45 Pins	IBM Cabling System Data Connector Color Code
1	Red
2	Black
3	Green
6	Orange

Figure 57. Straight-Through STP Cable (RJ-45 to IBM Data Connector)

Crossover 10BASE-T/100BASE-TX Cables




Figure 58. Crossover UTP Cable (RJ-45 to RJ-45), T568A




Figure 59. Crossover UTP Cable (RJ-45 to RJ-45), T568B

Crossover 10BASE-T/100BASE-TX Cables for STP




Figure 60. Crossover STP Cable (RJ-45 to IBM Data Connector Crossover)

EIA-232 Port

Pin	Signal Name
Shell	CHS GND
3	TXD
2	RXD
7	RTS
8	CTS
6	DSR
5	SGND
1	DCD
4	DTR
9	RI

Figure 61. Pinout of the EIA-232 Port

Null-Modem Cables




Figure 62. EIA-232 Null Modem Cable for Terminal with 25-Pin Connector




Figure 63. EIA-232 Null Modem Cable for Terminal with 9-Pin Connector

Appendix D. Interface Conventions for the Console

Table 14 summarizes the meaning of special keys and commands that can be used by the terminal interface. You may need to configure your VT100 terminal emulation application to recognize some of these keys.

Active keys are clearly identified at the lower portion of each panel in the terminal interface.

Table 14. Special Keys and Commands Used with the Terminal Interface

Special Keys/ Text/Commands	Description
Brackets	<p>Identifies fields that can be modified.</p> <p>Angle (< >) Field entries surrounded by angle brackets identify an item that has a predefined set of options. Use the spacebar to toggle through the available values. If you press the Esc key before you move off the field, the current operational value is restored to the field. The change is not activated until Apply is selected.</p> <p>Square ([]) Field entries surrounded by square brackets identify an item that can be changed by typing in text. Characters within a text field cannot be modified using the cursor keys. No insert or overwrite modes can be performed in the field. The text in the field is erased and replaced by the new text. If you press the Esc key before you move off the field, the current operational value is restored to the field. The change is not activated until Apply is selected.</p>
Arrow Keys	<p>Use to move between items within the menu body, within the command Bar, between the menu body and command bar. Up and down arrow keys move the cursor between lines. Right and left arrow keys move the cursor between columns. Arrow keys are ignored when data is entered in a text field.</p> <p>Right Arrow Key The right arrow key moves the cursor to the next field to the immediate right.</p> <p>Left Arrow Key The left arrow key moves the cursor to the previous field to the immediate left.</p> <p>Down Arrow Key The down arrow key moves the cursor vertically down to the first character in the next row in the same position as the original row or wraps to the next section of the menu.</p> <p>Up Arrow Key: The up arrow key moves the cursor vertically up to the first character in the previous row in the same position as the original row or wraps to the next section of the menu.</p>

Table 14. Special Keys and Commands Used with the Terminal Interface (continued)

Special Keys/ Text/Commands	Description
Tab	Used to move to the next field. <ul style="list-style-type: none"> When navigating between fields, Tab is used to move forward to the next field and acts like the right arrow key. When in a text field which has been modified, Tab performs the same function as the Enter key. When in a text field and no text has been changed, Tab moves you to the next field.
Shift-Tab	Not supported by VT100
Ctrl-Tab	Not supported by VT100
Back Space	Used to remove the character in front of the cursor when entering text enclosed in square brackets.
Blinking Text	Warning or confirmation messages
Cursor	The software does not have control over the cursor shape. Cursor shape is controlled by the terminal emulation.
Delete	Acts like the Backspace key in a text field
End	Not supported
Enter	Used to make a selection. If you are: <ul style="list-style-type: none"> On a login panel and press Enter, the User ID and password are processed for login. On a non-leaf menu option and press Enter, the selected menu is displayed. (A non-leaf menu is a panel that contains a list of menu names that can be selected.) On the Unit ID or Slot ID and press Spacebar, the item toggles through the available values for that item. After a value is determined, pressing Enter updates the screen with the appropriate data for that unit ID and slot ID. On a field being modified and press Enter, the text is accepted and undergoes syntax checking and the cursor is moved to the next modifiable field. On a text field where no modifications have been made, Pressing Enter moves the cursor to the next field.
Esc	When modifying field data enclosed in square brackets ([]) or angle brackets (< >), press Esc to stop modifying the field and go back to the original data.
Home Key	Not supported
Insert	Not supported
Spacebar	When the cursor is on a modifiable field indicated by angle brackets, use the space bar to toggle through the options for that field. When the cursor is on a modifiable field indicated by square brackets, the space bar may be an allowable key to enter text.

Table 14. Special Keys and Commands Used with the Terminal Interface (continued)

Special Keys/ Text/Commands	Description
Function keys	<p>F1 Takes you to the Help Menu.</p> <p>F2 Toggles between the first item in the menu body and the Command bar.</p> <p>F3 Takes you back to the previous menu.</p> <p>F4 This is the Save key and is used to save changed configuration data. It is the same as going to the System Utilities Menu and selecting Save Configuration Changes. There is no undo after configuration changes have been saved. Pressing F4 after making configuration changes causes configuration changes to be automatically applied (F4 is used to Apply and Save configuration changes).</p>
MAC Addresses	<ul style="list-style-type: none"> • MAC addresses are displayed and entered as 12 hexadecimal digits in canonical format. • Any alphabetic character (A-F) is displayed as uppercase. When you enter the MAC address, uppercase and lowercase characters are accepted. • Any illegal characters for a MAC address are not accepted.
Uppercase Words in the Menu	Identifies commands.
READ ONLY	When in the upper right corner of the panel, indicates that the current user has read-only access.
UNSAVED DATA	When in the upper right corner of panel, indicates that there are unsaved changes; and that any changes made since the last SAVE was issued will not be retained across a power cycle.
SAVING DATA	After a SAVE is issued, indicates the Save is in process.
DATA SAVED	Save operation has completed successfully.
NEXT PAGE	Command used to display next panel.
PREV PAGE	Command used to display previous panel.
LOGOUT	Command used to end this login session.
CLEAR CTRS	Command used to set to 0 the counters associated with this panel.
SEND	Command used to begin sending pings.
APPLY	Command used to cause configuration changes to take effect. Apply appears on the panel once a change has been made.
REFRESH	Command used to refresh the panel with the current status or configured values.
MAIN MENU	Command used to display the Main Menu.
PREV MENU	Command used to display the previous menu.
HELP	Command used to display the Help Menu.

Appendix E. Introduction to Virtual LANs (VLANs)

Virtual LANs

A VLAN is defined as a group of location and topology independent devices that communicate as if they are on the same physical LAN. This means that the LAN segments are not restricted by the hardware that physically connects them; the segments are defined by flexible user groups that you create using various network management tools.

With VLANs, you can define your network according to:

- **Departmental groups:** For example, you can have one VLAN for the Marketing department, another for the Finance department, and another for the Development department.
- **Hierarchical groups:** For example, you can have one VLAN for directors, another for managers, and another for general staff.
- **Usage groups:** For example, you can have one VLAN for users of e-mail and another VLAN for users of multimedia application services.

Benefits of VLANs

Implementing VLANs has three main advantages:

- It eases the change and movement of devices on IP networks.
- It helps to control broadcast traffic.
- It provides extra security.

How VLANs ease change and movement

With traditional IP networks, network administrators spend much of their time dealing with moves and changes. If users move to a different IP subnet, the IP addresses of each device must be updated manually.

With a VLAN setup, if a device in VLAN 1 is moved to a port in another part of the network, you only need to specify that the new port is in VLAN 1.

How VLANs control broadcast traffic

With traditional networks, congestion can be caused by broadcast traffic that is directed to all network devices whether they require it or not. VLANs increase the efficiency of your network because each VLAN can be set up to contain only those devices that need to communicate with each other; therefore, limiting broadcast traffic to only those segments within the VLAN.

How VLANs provide extra security

Devices within each VLAN can communicate only with devices in the same VLAN.

Figure 64 on page 108 shows a network configured with three VLANs—one for each of the departments that access the network.




Figure 64. An Example of VLANs

The membership of VLAN 1 is restricted to ports 1, 2, 3, 4, and 5 of Switch A; membership of VLAN 2 is restricted to ports 4, 5, 6, 7, and 8 of Switch B while VLAN 3 spans both switches containing ports 6, 7, and 8 of Switch A and 1, 2, and 3 of Switch B.

In this simple example, each of these VLANs can be seen as a *broadcast domain*—physical LAN segments that are not constrained by their physical location.

VLANs and the switch

The switch supports VLANs that conform to the IEEE 802.1Q VLAN standard. This specifies a standard VLAN implementation that allows operation of VLANs across a multivendor network. This provides the services of traditional port-based VLANs, but also allows true interoperability with other devices that support the 802.1Q standard. In addition, the switch supports GVRP, a protocol that automates the registration of VLANs across networks.

The switch supports up to 32 user-configured VLANs (including the Default VLAN (VLAN 1)). A port may belong to multiple VLANs. This is useful if devices on a LAN segment belong to multiple VLANs.

Priority and traffic classes

The switch assigns a priority of “0” to untagged frames. Otherwise, the priority specified in the VLAN tag of the frame at the originating end-station is used to determine which of two priority queues is used for frame transmission. Frames with a priority of 0 to 3 are transmitted as low priority. Frames with a priority of 4 to 7 are transmitted at high priority. The mapping from user priority to traffic class is defined in table 7-2 of the IEEE P802.1D standard

Overview of IEEE 802.1Q VLAN support

The switch supports IEEE 802.1Q standards-based VLANs. This standard describes port-based VLANs as well as the methods to propagate VLAN memberships across compliant devices using GARP VLAN Registration Protocol (GVRP). Each frame contains information about the VLAN. This information is contained in a 4-byte tag that is inserted into each frame. This tag contains information concerning the VLAN that the device belongs to.

GVRP automates the configuration of VLAN information at the switch. When using devices that support GVRP, VLANs will automatically be created on the switch based on information being passed across the network from other GVRP-enabled devices in frames referred to as GVRP PDUs. This further eases change and movement as the administrator does not need to make any configuration changes at the switch, the change will automatically be detected and the necessary VLAN port membership changes made by the switch.

The switch provides configuration options that allow the use of devices that do not support tagging or GVRP. With proper configuration, both “legacy” devices and devices that support tagging or GVRP may be used on the same network.

These configuration options are described in the following sections.

Port VLAN ID (PVID)

The Port VLAN ID (PVID) specifies a VLAN ID for all untagged frames received on the port. Only one PVID can be configured per port. This setting is used to determine to which VLAN the untagged frames belong as they enter the switch. The specific use of this value will be discussed later in this appendix.

GARP VLAN registration protocol (GVRP)

The switch provides a feature that allows the automatic propagation of VLAN membership information across the network. This feature is facilitated by a new protocol called GARP VLAN Registration Protocol (GVRP) that is defined as a part of the IEEE 802.1Q standard. GVRP registration messages (PDUs) are sent across the network and received by GVRP-enabled devices (switches, adapters, and so on). This protocol allows devices to automatically join and leave VLANs. An advantage of this is that if a user moves from one network connection point to another, you would not have to manually reconfigure the switch ports to add the new switch port to the VLANs that the user belongs to.

GVRP messages are sent across the network with a group address of 0x0180C2000021. The GVRP PDUs use the the same DYAP/SSAP as Spanning Tree BPDUs. Older network analyzers often interpret these GVRP PDUs as Spanning Tree BPDUs. The switch allows you to disable the GVRP function on a switch basis or on an individual port basis.

Static versus dynamic VLANs

Two VLAN types, *static* and *dynamic* are associated with the switch. As the network administrator, you can manually configure static VLANs. Dynamic VLANs are created on the switch as a result of GVRP registration messages. Consequently, a dynamic VLAN is automatically removed from the switch if it is no longer being

used by other devices in the network. You can convert a dynamic VLAN to a static VLAN. Once this is done, the VLAN will remain configured on the switch until you remove it.

For each static VLAN configured on the switch, you can define the mode of participation for each port. There are three modes of participation:

- Include (registration fixed)
- Exclude (registration forbidden)
- Autodetect (normal registration)

When a port is configured to be included in a VLAN, the port is always a member of the specified VLAN. This is similar to port-based VLANs from other legacy products. VLAN membership of these ports will propagate across the network if GVRP is enabled. Ports should be included in a VLAN whenever VLAN membership of a port is desired to be guaranteed.

A port that is configured to be Autodetected does not initially belong to the given VLAN. However, the port may join the VLAN if a GVRP PDU is received on that port declaring membership in that VLAN. Ports may be left in Autodetect mode if the devices on the segment connected to the port all support GVRP and thus will register their VLANs with the port.

A port that is configured to be excluded is prevented from being a part of the specified VLAN. You can disable GVRP on a specific port or set of ports to ensure that they never join a VLAN by receiving and propagating GVRP PDUs.

Configuration examples

The following section will discuss some common network configuration scenarios and how the switch should be configured to ensure proper operation.

Untagged device to untagged device




Figure 65. Untagged device to untagged device configuration

This configuration consists of two untagged “legacy” devices connected to the switch. In order for these devices to communicate, they must be members of the same VLAN. In this case, the PVID of the ports that the devices are connected to

must be set to the VLAN that the devices are members of. In order to set the ports PVID, a VLAN must first be created with this VLAN ID. Additionally, both ports must be configured to untag frames for this VLAN.

After this configuration is complete, the frames from Station A will arrive at Port 1 untagged, and will then be tagged internally to the switch with the PVID (VLAN 5). These frames will be sent to port 12 which is a member of the same VLAN. Because the port is set to untagged frames for this VLAN, the tag will be removed and the frame sent to Device B untagged.

802.1Q-compliant device (tagging and GVRP) to 802.1Q-compliant device (tagging and GVRP)




Figure 66. 802.1Q-compliant device (tagging and GVRP) to 802.1Q-compliant device (tagging and GVRP) configuration

In this configuration, both devices support tagging and GVRP. Both devices are configured to transmit tagged frames for VLAN 5. GVRP must be enabled for the switch and for all ports which must participate in GVRP.

When Station A attempts to communicate with Station B, VLAN 5 (that Station A is a member of) is registered at Port 1 by GVRP. Likewise, Station B registers its membership with VLAN 5 on Port 12. Note that this VLAN will be dynamic because the network administrator has not explicitly configured the VLAN on the switch. Frames arrive at Port 1 from Device A, tagged for VLAN 5. These frames are forwarded to Port 12. The frames will be transmitted out of Port 12 tagged for receipt at Station B. Note that all frames in dynamically-created VLANs are transmitted as tagged.

Untagged device to 802.1Q compliant device (tagging and GVRP)




Figure 67. Untagged device to 802.1Q compliant device (tagging and GVRP) configuration

In this configuration, an untagged device, Station A, is attempting to communicate to a tagged device that is a member of the same VLAN. The network administrator first statically creates VLAN 5 on the switch to include Port 1 in this VLAN. Port 1 is configured to transmit frames untagged in VLAN 5 because Station A cannot comprehend tagged frames. Port 1 is configured with a PVID of 5 to ensure that untagged frames received on that port are assigned to VLAN 5.

Station B is also assigned to VLAN 5, and because it supports both tagging and GVRP it will automatically register its membership to VLAN 5. Because Station B resides off of Port 12, Port 12 must be configured to be either autodetected or always included in VLAN 5. Port 12 may be configured to transmit frames as either tagged or untagged because Station B is capable of handling both.

Frames from Station A arrive at Port 1 and are tagged with a VLAN ID equal to the PVID of Port 1 (VLAN 5). The frames are then switched to Port 12, where they are transmitted out of the switch either tagged or untagged, as configured. On the return path, frames tagged with VLAN 5 will arrive at Port 12, and will be received since the port is a member of VLAN 5. The frames will be switched to Port 1, and will be transmitted as untagged, as specified by the configuration of that port in that VLAN.

If any devices on a link cannot handle tagged frames, it would be best to configure the port to transmit frames as untagged in any VLAN in which those devices participate.

Untagged device to 802.1Q-compliant device (tagging only)




Figure 68. Untagged device to 802.1Q-compliant device (tagging only) configuration

The primary difference in this configuration is that Station B supports tagging, but not GVRP. As a result, VLAN membership information will not be propagated from Station B to the switch. Therefore, the network administrator must configure Port 12 to always be included in VLAN 5. If this is not done, Station B's frames will be dropped as they are received at the switch because the frame's VLAN tag does not match the port's VLAN membership set.

Once this configuration is complete, data flows as in the example above.

Using unique MAC addresses

All addresses in the network should be unique to ensure proper communication.

Duplicate VLAN configurations and oversubscription of switch resources

The 8275-416 allows you the flexibility of configuring VLANs with identical port memberships. However, duplicate VLANs can unnecessarily waste VLAN entries and be an indication that the network design needs to be reconsidered. Too many duplicate VLANs may also lead to an oversubscription of switch resources.

The 8275-416 always guarantees resources for all 32 ports in the Default VLAN (VLAN 1). Up to 31 additional VLANs may be configured or registered with the switch, with certain restrictions.

In a switch with no feature modules (that is, with only the 16 base ports which may potentially be members of any VLAN) up to 10 ports may be included or autodetected in *each* of the 31 available VLANs. Phrased alternatively, the switch supports *310 individual instances of port VLAN membership* distributed across non-Default VLANs in whatever fashion you choose. You can choose a configuration that "oversubscribes" the switch resources. However, unpredicted results may occur. You will be notified of potential oversubscriptions by the terminal

interface message Operation succeeded. WARNING: Resources exceeded! A similar message appears if you are using the Web interface to configure your switch.

Oversubscription of switch resources due to dynamic VLAN registration cannot be predicted. Therefore, oversubscription will only be indicated during configuration if the number of *statically included* instances of port VLAN membership exceeds the threshold of 310.

The following configuration example indicates an acceptable configuration for an 8275-416 *with no feature modules*:

Table 15. Acceptable VLAN configurations with no feature modules

Configuration	Non-Default VLAN Port Instances
16 ports in Default VLAN (VLAN 1)*	Not counted
16 ports each in 2 other VLANs *	32
10 ports each in 12 other VLANs	120
8 ports each in 16 other VLANs	128
9 ports each in 1 other VLAN	9
* Duplicate VLANs	Total 289

As the Table 15 shows, port membership can be distributed in many ways across many VLANs, and still not exceed the limits of the switch.

The two feature modules on the 8275-416 *together* have the same restrictions as the base ports of the switch. The addition of feature modules does *not* increase the number of non-Default VLAN port instances that can be supported by either the base ports or the two feature modules together. However, the addition of feature modules *does* double the number of non-Default VLAN port instances that can be supported across the entire switch, with 310 port instances distributed across the base ports and 310 port instances distributed across the feature module slots.

The limitation only exist for the number of ports used in either the top or bottom of the switch. There is *no* limitation using base ports and feature module ports in the same VLAN.

Although duplicate VLAN configurations can waste switch resources, there are some instances where they are useful. For instance, security concerns may be addressed by having devices on the same LAN segments belonging to different VLANs, but the VLANs having the same port membership. Another use for duplicate VLAN configurations would be if a switch is placed in the core or in an intermediate level of a network. The 8275-416 functions best as an edge device as opposed to as a core switch.

Index

Numerics

- 10/100BASE-TX feature module
 - faceplate for 10
- 100BASE-FX feature module
 - faceplate for 11
- 4-Port 100BASE-FX feature module
 - LEDs for 12
- 8-Port 10/100BASE-TX feature module
 - LEDs for 10
- 8-Port 100BASE-FX feature module
 - LEDs for 11
- 802.1Q Port 54
- 802.1Q port configuration 54
- 802.3x flow control 2
 - configuring for 45
 - default for 45
 - description of 45
- 8275-416
 - physical characteristics of 13

A

- acceptable frame types 54
- access mode, user account management
 - defaults values 59
 - description of 59
 - range of values 59
 - read only 59
 - Read Write 59
- accessing the switch 15
 - from a Web browser 18
 - in-band connection 17
 - out-of-band connection 15
 - SNMP-based management interface 18
 - terminal interface (EIA 232 port) 15
 - terminal interface (Telnet) 18
- address aging timeout
 - configuring for 45
 - default for 45
 - description of 45
- APPLY command 103
- ARP Cache 42
- ARP Cache Menu 42
- Authentication Failure, trap condition 38

B

- base port numbers 46
- baud rate 16, 17
- Baud rate
 - default for 33
 - description of 33
 - value range 33
- BootP 21
- brackets
 - angle 103
 - square 103
- Bridge MIB 3

- broadcast storm recovery 2
- Broadcast Storm Recovery
 - configuring for 45
 - default for 45
 - description of 45
- broadcast traffic 107

C

- cable requirements 4
 - lengths 4
 - types of 4
- cables
 - 100BASE-FX 4
 - 100BASE-TX 4
 - 10BASE-TX 4
- capabilities of 8275-416 1
- Category 3 4
- Category 4 4
- Category 5 4
- Clear, trap log operation 40
- CLEAR CTRS command 103
- client IP address 36
- client IP mask 36
- code download 64
- Commands
 - APPLY 103
 - CLEAR CTRS 103
 - HELP 103
 - LOGOUT 103
 - MAIN MENU 103
 - NEXT PAGE 103
 - PREV MENU 103
 - PREV PAGE 103
 - READ ONLY 103
 - REFRESH 103
 - SEND/STOP 103
 - UNSAVED DATA 103
- configuration
 - IP information 21
 - network connection 21
 - server 21
 - terminal interface 21
- configuration changes 23
 - applying 24
 - processing 24
 - via terminal interface 23
 - via Web interface 25
- configuration file 61
- configuration file download 64
- configuration file upload 64
- Configure Network Connectivity Menu
 - Default Gateway 31
 - description of 31
 - IP address 31
 - Subnet Mask 31
- configuring a modem 16
- configuring a port
 - numbering ports 45

- configuring a port monitoring
 - identifying the ports 46
 - numbering ports 46
- configuring GARP 53
- configuring IP 21
- configuring Spanning Tree
 - description of 48
 - method of redundancy 48
- configuring VLANs 50
- conformation of password, user account management
 - defaults values 59
 - description of 59
 - range of values 59
- connectivity 15
 - attaching a modem 16
 - SNMP-based management interface 18
 - Telnet 18
 - Web-based management interface 18
- Cost, Spanning Tree Protocol
 - default for 50
 - description of 50
- current status 53

D

- danger notices, translated 81
- data bits 16, 17
- default configuration
 - description of 66
- default gateway 17, 22
- detailed switch statistics 58
- Device Configuration Menu 28
 - 802.3x Flow Control Menu 44
 - Broadcast Storm Recovery Menu 44
 - Port Configuration Menu 44
 - Port Monitoring Menu 44
 - Spanning Tree Port Configuration/Status Menu 44
 - Spanning Tree Switch Configuration/Status Menu 44
 - Switch Configuration Menu 44
- DHCP (Dynamic Host Configuration Protocol) 21
- down arrow 103
- downloading code 64
- downloading configuration file 64
- downloading files to the switch 61
- Dynamic Host Configuration Protocol (DHCP) 21

E

- Enterprise MIB 3
- error log upload 64
- Ethernet cable types
 - Category 3 4
 - Category 4 4
 - Category 5 4
- Ethernet port LEDs 9

F

- F1 function keys 103
- F2 function keys 103

- F3 function keys 103
- F4 function keys 103
- factory default configuration, resetting of 66
- fault tolerance 48
- feature module LEDs 10
- feature module port numbers 46
- File Path 64
- File Type 64
- flow control 16, 17
- flow control, 802.3x 2
- Forward Delay Time, Spanning Tree Protocol
 - default for 49
 - description of 49
- forwarding database 2
- forwarding database statistics 58
- front panel of switch
 - description of 5
 - view of 5
- function keys
 - F1 103
 - F2 103
 - F3 103
 - F4 103

G

- GARP configuration 53
- GARP timers 53
- GVRP, for 802.1Q port configuration 55
- GVRP, for GARP configuration 53

H

- Handling Files utility
 - description of 61
 - file name 64
 - file path 64
 - file type 64
 - TFTP Server IP Address 65
 - transfer mode 64
 - use of 61
- hardware
 - physical characteristics of 13
- hardware description
 - cable requirements 4
 - front panel 5
 - LEDs 7
- Hello Time, Spanning Tree Protocol
 - default for 49
 - description of 49
- HELP command 103
- how to view detailed port statistics 56
- how to view detailed switch statistics 58
- how to view forwarding database statistics 58
- how to view port summary statistics 56
- how to view switch summary statistics 57

I

- in-band connection
 - BootP 17

- in-band connection *(continued)*
 - description of 17
 - DHCP 17
 - IP address 17
 - use of 17
- in-band connectivity 15
- ingress filtering 54
- IP address 17, 22
 - default value 38
 - format for 38
 - number ranges 38
- IP information 17
 - methods for changing 17
- IP information, configuring 21

L

- Layer 2 switching 1
- LEDs
 - for 4-Port 100BASE-FX feature module 12
 - for 8-Port 10/100BASE-TX feature module 10
 - for 8-Port 100BASE-FX feature module 11
 - for Ethernet ports 9
 - for feature modules 10
 - for the switch 7
- left arrow 103
- Link Up/Link Down, trap condition 39
- locally administered MAC address 22
- login name 27
- login panel
 - user name 27
 - user password 27
- login password 27
- LOGOUT command 103
- Logout utility
 - description of 60
 - use of 60

M

- MAC address type 22
- MAC addresses 103
- Main Menu
 - Device Configuration Menu 28
 - Management Menu 28
 - Statistics Menu 28
 - System Information Menu 28
 - System Utilities Menu 28
 - User Account Management Menu 28
- MAIN MENU command 103
- Management interfaces
 - VT100 terminal interface 2
- Management Menu 28
 - ARP Cache Menu 31
 - description of 31
 - functions available 31
 - how to access 31
 - Network Connectivity Configuration Menu 31
 - Ping Menu 31
 - Serial Port Configuration Menu 31
 - SNMP Community Configuration Menu 31
 - SNMP Trap Receiver Configuration Menu 31

- Management Menu 28 *(continued)*
 - Telnet Menu 31
 - Trap Menu 31
 - view of 31
- Maximum Age Time, Spanning Tree Protocol
 - default for 49
 - description of 49
- menu command
 - descriptions of 103
- MIB II 3
- MIBs supported
 - 8275-416 MIB 73
 - Bridge MIB 3
 - Enterprise MIB 3
 - MIB II 3
 - RFC 1213 73
 - RFC 1493 73
 - RFC 1643 73
 - RFC 1757 73
 - RMON MIB 3
 - Web page for latest 73
- modem
 - setting for 16
- modem configuration 16
- Multiple Users, trap condition 39

N

- Name trap log entry 39
- Network Configuration Protocol
 - Default for 32
 - description of 32
- Network Connectivity Configuration Menu 31
- NEXT PAGE command 103
- numbering ports 46

O

- obtaining service 80
- obtaining software 77
- operating environment
 - humidity 13
 - temperatures 13
- out-of-band connection
 - description of 15
 - locally attached 15
 - remotely attached 16
 - use of 15
- out-of-band connectivity 15

P

- parity 16, 17
- password
 - defaults for 27
 - description of 27
 - number supported 27
 - requirements for 27
- Password, user account management
 - defaults values 59
 - description of 59

Password, user account management (*continued*)

range of values 59

performance 3

physical characteristics

depth 13

height 13

operating environment 13

physical dimensions 13

service clearance 13

weight 13

width 13

physical dimensions 13

Ping

configuration of 41

description of 41

IP address 41

limits on number of 41

starting and stopping 41

Ping Menu 41

port configuration

numbering ports 45

port configuration, 802.1Q 54

port detailed statistics 56

port indicator 52

port LEDs 9

port monitoring 3

port monitoring configuration

default values 46

identifying the ports 46

numbering ports 46

port numbers 46

port statistics 3, 56

port summary statistics 56

port switching

number of ports 4

packet processing rates 4

port VLAN ID 54

PREV MENU command 103

PREV PAGE command 103

Priority, Spanning Tree Protocol

default for 49, 50

description of 49, 50

Private 36

product overview 1

protocols supported

802.3x protocol 2

IEEE P802.1D 1

IEEE P802.1Q 1

Public 36

R

READ ONLY 103

redundant paths 3, 48

REFRESH command 103

reliability 3

reset VLAN 55

resetting default configuration 66

resetting the switch 65, 66

RFC 1213 3

RFC 1493 3

RFC 1757 3

right arrow 103

RMON MIB 3

S

safety notices, translated 81

Save Applied Changes utility

description of 60

use of 60

security 107

access mode 59

configuring user names 59

configuring user password 59

read only 37

Read Write 37

SNMP read/write 3

status 59

user accounts 3

SEND/STOP command 103

Serial Port Configuration Menu

Baud rate 33

description of 33

Time out 33

service

telephone numbers for 80

Service

diagnosing problems 77

obtaining 77

obtaining software 77

service, Web site for 77

service clearance

front 13

rear 13

sides 13

serviceability 3

Simple Network Management Protocol (SNMP)

agent 3

Slot ID 52

SNMP-base management interface 18

SNMP-based management interface

description of 73

groups supported 73

MIBs supported 73

use of 73

SNMP community

client IP address 36

client IP mask 36

status 37

SNMP community access right

description of 36

read only 36

Read Write 36

SNMP Community Configuration Menu

access right 35

community name 35

description of 35

status 35

SNMP community name

default values 37

format for 37

SNMP Community Name

default names

Private 36

SNMP Community Name *(continued)*

- Public 36

- description of 36

- value length 36

SNMP interface

- applying configuration changes 26

- making configuration changes 26

- saving configuration changes 26

SNMP trap receiver

- community string 38

- configuration of 38

- description of 38

- IP address 38

- status 38

SNMP Trap Receiver Configuration Menu

- configuration of 37

- description of 37

- number supported 37

SNMP trap receiver status

- default values 38

- description of 38

software functions

- 802.3x flow control 2

- broadcast storm recovery 2

- forwarding database 2

- Layer 2 switching 1

Spanning Tree, trap condition 39

Spanning Tree Protocol (STP) 3

- configuring for 48

- defining Status 49

special keys

- Backspace 103

- brackets

- angle 103

- square 103

- Cntl-Tab 103

- Delete 103

- down arrow 103

- End 103

- Enter 103

- Esc 103

- Insert 103

- left arrow 103

- right arrow 103

- Shift-Tab 103

- Tab 103

- up arrow 103

statistics

- description of 55

- how to view 55

statistics, detailed port 56

statistics, detailed switch 58

statistics, forwarding database 58

statistics, port summary 56

statistics, summary switch 57

Statistics Menu 28

- contents of 55

- description of 55

- detailed port statistics 56

- summary of port statistics 56

Status, Spanning Tree Protocol

- default for 49

- description of 49

status, user account management

- defaults values 60

- description of 60

- Disable 60

- Enable 60

- range of values 60

- stop bits 16, 17

- STP (Spanning Tree Protocol) 3, 48

- subnet mask 17, 22

- summary switch statistics 57

switch

- cable requirements for 4

- capabilities of 1

- connectivity 15

- functions 1

- functions of 1

- hardware description of 4

- In-band method 15

- LED status 7

- methods of accessing 15

- out-of-band method 15

- overview of 1

- performance of 3

- reliability 3

- serviceability 3

- user interfaces available 15

- Web site for support 18

- Y2K (year 2000) 4

switch, resetting of

- description of 65

switch LED status 7

System Information Menu

- description of 28

- how to access 28

- options available 28

- view of 28

system trace upload 64

System Utilities Menu 28

- Debug Information Menu 60

- description of 60

- Download File to Switch Menu 60

- Logout 60

- Reset Menu 60

- Save Applied Changes 60

- Upload File to Switch Menu 60

- utilities available 60

T

tagging 53

Telnet configuration

- default number of sessions 40

- description of 40

- length of sessions 40

- limiting number of sessions 40

- sessions allowed 40

Telnet Login Timeout 41

Telnet Menu 40

- Telnet sessions
 - duration of 41
 - limiting new sessions 41
 - maximum number of 41
- terminal emulation setting
 - baud rate 16, 17
 - data bits 16, 17
 - flow control 16, 17
 - parity 16, 17
 - stop bits 16, 17
- terminal interface
 - applying changes 24, 25
 - blinking text 103
 - command descriptions 103
 - commands
 - APPLY 103
 - CLEAR CTRS 103
 - HELP 103
 - LOGOUT 103
 - MAIN MENU 103
 - NEXT PAGE 103
 - PREV MENU 103
 - PREV PAGE 103
 - REFRESH 103
 - SEND/STOP 103
 - UNSAVED DATA 103
 - configuring terminal emulation 15
 - Cursor 103
 - description of 2
 - Main Menu 28
 - making changes 23
 - menu commands 103
 - steps for connecting the terminal and switch 16
 - terminal interface
 - saving applied changes 25
 - use of 2
 - using the 27
 - via Telnet 18
 - via the EIA 232 serial port 15
- terminal interface (EIA 232)
 - description of 15, 18
 - use of 15, 18
- TFTP Server IP Address 65
- Time out
 - default for 33
 - description of 33
 - value range 33
- Time Stamp trap log entry 39
- traffic
 - broadcast 107
- Transfer Mode 64
- translations, safety notices 81
- trap conditions
 - Authentication Failure 38
 - Console Display 38
 - description of 38
 - Link Down 38
 - Link Up 38
 - Multiple Users 38
- trap configuration
 - conditions for 38

- trap configuration (*continued*)
 - description of 38
- trap log
 - description of 39
 - Name entry 39
 - number of entries 39
 - Time Stamp entry 39
 - valid operations of 39
- trap log upload 64
- Trap Menu 38
- traps
 - Authentication Failure 39
 - Cold Start 39
 - Link Down 39
 - Link Up 39
 - Multiple Users 39
 - New Spanning Tree Root 39
 - Spanning Tree Topology Change 39
 - Warm Start 39

U

- UNSAVED DATA command 103
- up arrow 103
- uploading configuration file 64
- uploading error log 64
- uploading files from the switch 61
- uploading system trace 64
- uploading trap log 64
- uppercase words 103
- user access
 - access mode 59
 - configuring user names 59
 - configuring user password 59
 - status 59
- user account management 59
- User Account Management Menu 28
- user name
 - defaults for 27
 - description of 27
 - number supported 27
 - requirements for 27
- User Name, user account management
 - defaults values 59
 - description of 59
 - range of values 59

V

- virtual local area networks (VLANs) 2
- VLAN, resetting 55
- VLAN configuration 50
- VLAN current status 53
- VLAN ID 52
- VLAN index 51
- VLAN management 50
- VLAN name 52
- VLAN participation 52
- VLAN port indicator 52
- VLAN Slot ID 52
- VLAN summary and configuration 51

- VLAN tagging 53
- VLAN type 52
- VLANs
 - benefits 107
 - overview 107
 - security 107
- VLANs (virtual local area networks) 2
- VT 100 terminal, configuration settings for 16

W

- Web-based management interface 18
- Web browser 18
- Web interface
 - making configuration changes 25
 - processing configuration changes 25
 - saving configuration changes 25
- Web sit for service 77
- weight 13

Y

- Y2K (year 2000)
 - compliance statement 4
 - Web site for 4
- year 2000 4

Glossary

AC. The Access Control field in frame header.

ACE. Address Copied Error. When a station reports this it indicates a problem with the station upstream rather than with itself, normally someone else on the Token Ring with this station's address. An isolating error.

Application Layer. Layer seven, the uppermost part of the OSI network layer model. This layer contains the user and application programs.

Backbone. The part of a network used as the primary path for transporting traffic between network segments.

Bandwidth. Information capacity, measured in bits per second, that a channel can transmit. The bandwidth of Ethernet is 10 Mbps, the bandwidth of Fast Ethernet is 100 Mbps. FDDI bandwidth is 100 Mbps. Token Ring bandwidth is 4/16 Mbps.

Bit. Either of the digits 0 or 1 when used in the binary numeration system. Eight bits equals a single byte. Broadcast . All good frames destined for the broadcast address, in other words sent out to all stations on the network. Some broadcasts are limited to the local network, and some broadcasts may cross onto other networks.

Broadcast. All good frames destined for the broadcast address, in other words, sent out to all stations on the network. Some broadcasts are limited to the local network, and some broadcasts may cross onto other networks.

Buffer. The space allocated to the storage of filtered packets as they are captured from the network. A probe only has a limited set of resources to hold buffer data. If one of the buffers uses all of the probe's resources, it will stop the other buffers from capturing packets. To conserve resources, you can slice packets or assign maximum sizes to buffers.

Bytes. The total number of bytes making up a frame - includes FCS octets.

Client. Any application that retrieves and displays data from probes or agents.

Collision. The best estimate of the number of collisions on an Ethernet segment.

Community Name. Also known as Community String. SNMP uses community names to limit access to certain device management functions. The Community Name used when accessing a device determines which functions may be accessed.

CRC Align Error. An Ethernet packet between 64 and 1518 octets long inclusive (includes FCS octets) - not an integral number of octets in length or has a bad FCS.

CSMA/CD Carrier. Carrier Sense Multiple Access with Collision Detection. The Ethernet protocol that allows each device to create and send its own data packets. CSMA/CD is used to avoid excessive collisions between packets as they are randomly transmitted. A CSMA/CD device first listens for other carriers, if it detects no other carriers, it will then allow the data packet to be transmitted. If a collision is detected, the device stops transmitting, waits a random length of time, and begins transmitting again

Data Link Layer. The second layer of the OSI reference model. This layer is responsible for controlling message traffic.

Data Packet (Packet). A sequence of binary digits, including data and control signals that is transmitted across a LAN.

Default Gateway. The IP address of a device, usually a router or gateway, to which the probe directs all packets not destined for its subnet.

ED. Ending Delimiter - a distinctive byte marking the end of a frame or a token.

Forwarding. The process of sending a frame towards its destination by an intranet working device.

Fragment Packet. An Ethernet packet less than 64 octets long (excludes frame bits but includes FCS octets) - not an integral number of packets in length or has a bad FCS.

GARP. See Generic Attributes Registration Protocol.

GARP VLAN Registration Protocol (GVRP). The IEEE 802.1p protocol that enables workstations to request admission to a specific VLAN rather than to a multicast domain.

Generic Attributes Registration Protocol (GARP). A protocol defined by IEEE 802.1p. There are two versions: GARP Multicast Registration Protocol (GMRP) and GARP VLAN Registration Protocol (GVRP).

GARP Multicast Registration Protocol (GMRP). The IEEE 802.1p protocol that enables workstations to request membership in a multicast domain. This joining action is called a leaf-initiated join. GMRP provides a standard protocol for sending traffic to only those ports that have requested multicast traffic. It is compatible with 802.1Q because it operates on a port basis.

GVRP. See GARP VLAN Registration Protocol.

HDLC. High-Level Data Link Control. OSI bit-orientated protocol.

Host. A device or computer on an IP network to which you can connect.

Jabber Packet. An Ethernet packet longer than 1518 octets (excludes frame bits but includes FCS octets) - not an integral number of octets in length or has a bad FCS.

ICMP. Internet Control Message Protocol. Internet protocol that reports errors and provides other information relevant to IP packet processing.

IEEE. Institute of Electrical and Electronics Engineers.

IETF. Internet Engineering Task Force, whose responsibilities include specification of protocols and recommendation of Internet standards via the Request for Comment (RFC) process.

Long Packet. See oversize packet.

MIB. Management Information Base.

Multicast. Good packets directed to the multicast address. Does not include broadcast packets. Multicasts are similar to broadcasts but have a more limited scope, for example they may be directed to all bridges on a ring.

Oversize Packet. An Ethernet packet longer than 1518 octets (including FCS octets) but otherwise well formed.

Network Layer. The third layer of the OSI reference model. This layer is responsible for controlling message traffic.

Octet. A digital unit of information comprising eight binary digits (bits) equivalent to a byte.

OSI. Open Systems Interconnection, a body of standards set by the International Standards Organization to define the activities that must occur when computers communicate. In the OSI Reference Model there are seven layers, and each contains a specific set of rules to follow at that point in the communication.

Packet. A unit of information that contains data, origin information; and destination information, which is switched as a whole through a network.

PACMIB. Port Address Correlation MIB maps port to host data and gathers port statistics for 3Com CoreBuilder devices on your network.

Probe. Station (or agent) responsible for gathering network data on a remote segment and passing it up to a central management station (or client). Usually configured and controlled by the client.

PDN. Public Data Network.

Physical Layer. The first layer of the OSI network layer model. This layer manages the transfer of individual bits of data over wires, or whatever medium, that is used to connect workstations and peripherals.

Presentation Layer. The sixth layer of the OSI network layer model. This layer controls the formatting and translation of data.

Protocol. A set of rules and procedures that govern the exchange of data between two communicating systems.

Protocol Number. The port or program number as defined by the parent protocol. For example, if you are adding a TCP child protocol, the protocol number will be the TCP port number.

PSTN. Public switched telephone network.

RMON. Remote MONitoring. Subset of SNMP MIB II which allows monitoring and management capabilities by addressing up to ten different groups of information. Defined in IETF document RFC 1757.

RMON2. Extends the capability of RMON to include protocols above the MAC layer.

Short Packet. See undersize packets.

Station. Any machine connected to the network - for example a fileserver, PC, workstation, printer or probe.

Subnet Mask. A filtering system for IP addresses. It defines the portion of the IP address used to identify the subnet. The remaining portion is used to represent host information. Devices and routers use the mask to identify the subnet on which a probe resides.

System Descriptor. A free-form field on RMON devices used by vendors to supply basic information about the device.

Transport Layer. The fourth layer of the OSI network layer model. This is responsible for error checking and correction, and some message flow control.

Trigger. A trigger represents a sequence of events that may occur on a network. When these events occur, an alarm is triggered.

Undersize Packets. An Ethernet packet less than 64 octets long (excluding frame bits but including FCS octets) but otherwise well formed.

Virtual Circuit. Circuit-like service provided by the software protocols of a network, enabling two end points to communicate as though connected by a physical circuit. Network nodes provide the addressing information needed in the packets that carry the source data to the destination.

Readers' Comments — We'd Like to Hear from You

8275 Model 416 High Performance Ethernet Workgroup Switch
User's Guide

Publication No. GC30-4026-01

Overall, how satisfied are you with the information in this book?

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Overall satisfaction	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

How satisfied are you that the information in this book is:

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Accurate	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Complete	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to find	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to understand	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Well organized	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Applicable to your tasks	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Please tell us how we can improve this book:

Thank you for your responses. May we contact you? Yes No

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you.

Name

Address

Company or Organization

Phone No.



Fold and Tape

Please do not staple

Fold and Tape



NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

Department CGFA—Design and Information Development
IBM Corporation
P.O. Box 12195
Research Triangle Park, NC, U.S.A. 27709-9990



Fold and Tape

Please do not staple

Fold and Tape



Printed in the United States of America
on recycled paper containing 10%
recovered post-consumer fiber.

Web sites:

8275-416 Documentation

<http://www.ibm.com/networking/support/docs.nsf/8275docs>

8275-416 Software Updates

<http://www.ibm.com/networking/support/downloads/8275>

8275-416 Product Support

<http://www.ibm.com/networking/support/8275>

GC30-4026-01

