Title: Field of Material (FBM) PN 80G4201

EXCHANGE a V35 ARC Card in IBM 3746 Model 900

Written by: JP. Aubin
Checked by: J. Combes
Approved by: D. Raczkowski

3746	PN 80G4201	EC D56205C	ECH60016		
FFBM	Page 1 of 5	22DEC94	12MAY03		

Before Installation (Steps 1 through 8)

1.0 Machines Affected

3746 Model 900

2.0 Related BMs and ECs

None.

3.0 BMs to be Installed

- 80G4201 Installation Instructions
- 29H4662 V35 ARC3A1 exchange and/or
- 29H4663 V35 ARC3A2 exchange and/or
- 29H4664 V35 ARC3C exchange and/or
- 29H4661 V35 ARC3A0 exchange

4.0 Preparation

- ___ 1. Familiarize yourself with the purpose and details of these removal installation instructions before negotiating machine time with the customer.
- __ 2. Check all the items and count parts listed on the BM(s) to be used to determine whether all parts were received.

5.0 Programming

None

6.0 Purpose and Description

Replace the V35 card with a new one and replace the part number label on the ARC.

3746	PN 80G4201	EC D56205C	ECH60016
FFBM	Page 2 of 5	22DEC94	12MAY03



7.0 Installation Time

FBM CE HOURS MACHINE HOURS SYSTEM HOURS.

80G4201 0.2 0.0 0.0

8.0 Tools/Materials Required

ESD kit (PN 6428316).

3746	PN 80G4201	EC D56205C	ECH60016		
FFBM	Page 3 of 5	22DEC94	12MAY03		

Installation (Steps 9 through 12)

9.0 Safety


Review the **Safety Notices** and the **Safety Inspection Procedures** located at the beginning of the 3745 *Maintenance Information Procedures (MIP*) manual (SY33-2054).

10.0 Details of Installation

When the ARCs to be unplugged are identified, ask the customer to deactivate the line(s) of the associated ARCs.

10.1 Hardware Exchange

Warning: Follow existing ESD procedures when handling logic parts.



- $_$ 1. Unfasten the two front captive screws 1.
- __ 2. Remove the ARC from the LCB.

Note: The top cover **2** and the bottom cover **3** are clipped together with four internal latches **4**.

- __ 3. In the second hole 5, on each side of the top cover 2 insert a screwdriver pushing on the four internal latches 4. Remove the top cover.
- __ 4. Remove the spring 6 (two screws).
- ___ 5. Unplug the connector 7 from the card 8.
- __ 6. Remove the card from the bottom cover.
- ___ 7. Install the new card coming with the BM.
- $\underline{}$ 8. Plug the connector $\overline{\mathbf{7}}$ in the new card $\overline{\mathbf{8}}$.
- 9. Reinstall the spring 6 (two screws).

3746	PN 80G4201	EC D56205C	ECH60016
FFBM	Page 4 of 5	22DEC94	12MAY03

© Copyright IBM Corp. 1994, 2003

		Installation	

12. Ask the customer to reactivate the line(s).	lab 11. Re	abel located on the side of the located on the side of the located in the LCE in the located in the LCE in the located in the lo	3.
	12. As	sk the customer to reactiva	ate the line(s).
Important note: The old cards must be returned to IBM.		Important note	e: The old cards must be returned to IBM.

3746
PN Pa