

7600+

**Precision LCR Meter
User and Service Manual**



Copyright © 2012 IET Labs, Inc.
Visit www.ietlabs.com for manual revision updates

7600+ im/February 2012

◆ PRECISION INSTRUMENTS FOR TEST AND MEASUREMENT ◆



IET LABS, INC.

534 Main Street, Westbury, NY 11590

www.ietlabs.com

TEL: (516) 334-5959 • (800) 899-8438 • FAX: (516) 334-5988

Contents

Warranty.....	ix
1 Specifications.....	xi
2 Introduction.....	1
2.1 Unpacking and Inspection.....	1
2.2 Product Overview	1
2.3 Controls and Indicators	2
2.4 Accessories Included.....	4
2.5 Accessories/Options Available	4
2.6 Installation.....	4
2.6.1 Power Requirements	4
2.6.2 Safety Inspection.....	5
2.6.3 Safety Symbols.....	8
2.6.4 Disposal.....	8
3 Operation.....	9
3.1 Startup.....	9
3.2 Connection to Device Under Test.....	9
3.3 Zeroing.....	10
3.4 Measurement Procedure.....	10
3.4.1 Default Measurement Conditions	11
3.5 Factory default measurement conditions	11
3.6 Menu Functions	12
3.6.1 Setup Menu	13
3.6.2 Primary Parameter.....	14
3.6.3 Secondary Parameter.....	17
3.6.4 Frequency.....	17
3.6.5 AC Test Signal.....	17
3.6.6 DC Bias Voltage	20
3.6.7 Range Hold	21
3.6.8 Range Locked	22
3.6.9 Measurement Delay	27
3.6.10 # to Average.....	27

3.6.11	Contact Check.....	27
3.6.12	I/O Menu.....	28
3.7	Display Type.....	29
3.7.1	Measured Parameters -.....	30
3.7.2	Deviation from Nominal –.....	30
3.7.3	% Deviation from Nominal –.....	30
3.7.4	Pass/Fail –.....	31
3.7.5	Bin Summary –.....	31
3.7.6	Bin Number –.....	32
3.7.7	No Display –.....	32
3.7.8	Nominal Value.....	32
3.7.9	Result Format.....	32
3.7.10	Trigger.....	32
3.7.11	Handler Interface.....	33
3.7.12	RS-232 Interface.....	33
3.7.13	IEEE-488.2 Interface.....	34
3.7.14	Print Results.....	34
3.7.15	Results to USB.....	34
3.7.16	Analysis Menu.....	41
3.7.17	Binning.....	43
3.7.18	Absolute Limit.....	44
3.7.19	Tolerance Percent.....	46
3.7.20	Secondary Low.....	46
3.7.21	Secondary High.....	46
3.7.22	View Bin Totals.....	47
3.7.23	Zero Bin Totals.....	47
3.7.24	Test Sequencing.....	47
3.8	Parameter Sweep.....	50
3.9	Median.....	51
3.9.1	Distortion Detection.....	51
3.9.2	Load Correction.....	52
3.9.3	Utilities Menu.....	53

3.9.4	Save Setup.....	54
3.9.5	Recall Setup	55
3.9.6	Setup Accuracy	55
3.9.7	Open / Short	58
3.9.8	Lock Out	59
3.9.9	Calibration.....	60
3.9.10	Set Time/Date	60
3.9.11	Usage/Cal Date	61
3.9.12	Set Contrast.....	61
3.9.13	Self Test	62
3.9.14	LCD Backlite	62
3.10	Input/Output Interface.....	62
3.11	Parallel Interface	66
3.12	IEEE-488.2 Interface Optional.....	67
3.13	Formats	76
3.13.1	Sample Program for National Instruments GPIB card.....	77
3.13.2	RS232 Interface.....	78
3.13.3	Results to Printer.....	79
3.14	Operation with Accessories	79
3.14.1	Rack Mount Kit (7000-00).....	80
3.14.2	BNC Cable Set, 1 Meter (7000-01), 2 Meter (7000-02).....	80
3.14.3	Kelvin Clip Leads (7000-03)	80
3.14.4	Alligator Clip Leads (7000-04).....	82
3.14.5	Chip Component Tweezers (7000-05).....	83
3.14.6	Low V, Axial/Radial Lead Component Test Fixture (7000-06).....	84
3.14.7	Open/Short Zeroing:	85
3.14.8	Low V, Chip Component Test Fixture (7000-07).....	85
3.14.9	Calibration Kit (7000-09)	87
3.14.10	Connection to "Type 874" Connectors	88
4	Error Messages.....	89
5	Theory	92
5.1	Basic Instrument Architecture.....	92

5.1.1	Processor Board	92
5.1.2	Power Supply	92
5.1.3	LCD Display/Keypad Panel	92
5.2	7600 Plus Instrument Module	93
5.2.1	Sine Wave Generator	93
5.2.2	Voltage Detector Channel	93
5.2.3	Current Detector Channel	93
5.2.4	A/D Converter	93
5.2.5	Digital Signal Processor	93
5.3	Options	93
5.3.1	IEEE-488 Board & Cable	93
6	Maintenance & Calibration	94
6.1	Bias Voltage Fuse Replacement	94
6.2	Resetting of Time and Date	94
6.3	Loss of Display Contrast	94
6.4	Calibration	95
6.4.1	Requirements for Re calibration	95
6.4.2	Instrument Return	96

Figures

Figure 1	7600 Plus Precision LCR Meter	1
Figure 2	Front Panel Controls & Indicators	2
Figure 3	Rear Panel Controls & Indicators	3
Figure 4	Fuse Drawer	5
Figure 5	Test Lead Configuration	9
Figure 6	Measured Results Display	11
Figure 7	Setup Menu	13
Figure 8	Primary Parameters	14
Figure 9	Series and Parallel Circuits for both Capacitive and Inductive Impedances	15
Figure 10	Phase Diagrams of Impedance	16
Figure 11	Phase Diagrams of Admittance	16
Figure 12	Secondary Parameter	17

Figure 13 AC Test Signal.....	17
Figure 14 Capacitive Reactance vs. Frequency	25
Figure 15 Inductive Reactance vs. Frequency.....	26
Figure 16 Measurement Accuracy	26
Figure 17 I/O Menu.....	28
Figure 18 Display Type.....	29
Figure 19 Measured Parameters Display	30
Figure 20 Deviation from Nominal Display	30
Figure 21 % Deviation from Nominal Display	31
Figure 22 PASS/FAIL.....	31
Figure 23 Bin Summary Display.....	31
Figure 24 Bin Number Display	32
Figure 25 RS-232 Setup Format	33
Figure 26 IEEE Setup Format	34
Figure 27 Analysis Menu	41
Figure 28 Binning	43
Figure 29 Absolute Limit.....	45
Figure 30 Absolute Limit (Numeric Entry).....	45
Figure 31 Absolute Limit (Engineering Units)	45
Figure 32 Tolerance Percent	46
Figure 33 Bin Totals	47
Figure 34 Sequence Setup (Test Conditions).....	47
Figure 35 Sequence Setup (Parameter Selection)	48
Figure 36 Sequence Binning.....	49
Figure 37 Sequence Results	49
Figure 38 Parameter Sweep	50
Figure 39 Sweep Table	50
Figure 40 Sweep Plot.....	51
Figure 41 Load Correction.....	52
Figure 42 Utilities Menu	53
Figure 43 Save Setup	54
Figure 44 Yes or No.....	54

Figure 45 Recall Setup.....	55
Figure 46 Setup Accuracy.....	56
Figure 47 Open / Short.....	59
Figure 48 Lockout.....	59
Figure 49 Set Time / Date.....	60
Figure 50 Usage / Cal Date.....	61
Figure 51 Set Contrast.....	61
Figure 52 I/O Interface Timing.....	64
Figure 53 I/O Interface Isolation.....	66
Figure 54 RS-232 Cable Configurations.....	79
Figure 55 BNC Cable Sets.....	80
Figure 56 Kelvin Clip Leads.....	81
Figure 57 Kelvin Test Leads Open/Short Zeroing.....	82
Figure 58 Alligator Clip Leads.....	82
Figure 59 Chip Component Tweezers.....	83
Figure 60 Low V, Axial and Radial Lead Component Test Fixture.....	84
Figure 61 Low V Chip Component Test Fixture.....	85
Figure 62 Calibration Kit.....	87
Figure 63 Connection to 874 Connectors.....	88

WARRANTY

We warrant that this product is free from defects in material and workmanship and, when properly used, will perform in accordance with applicable IET specifications. If within one year after original shipment, it is found not to meet this standard, it will be repaired or, at the option of IET, replaced at no charge when returned to IET. Changes in this product not approved by IET or application of voltages or currents greater than those allowed by the specifications shall void this warranty. IET shall not be liable for any indirect, special, or consequential damages, even if notice has been given to the possibility of such damages.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.



WARNING



OBSERVE ALL SAFETY RULES
WHEN WORKING WITH HIGH VOLTAGES OR LINE VOLTAGES.

**Dangerous voltages may be present inside this instrument. Do not open the case
Refer servicing to qualified personnel**

HIGH VOLTAGES MAY BE PRESENT AT THE TERMINALS OF THIS INSTRUMENT

WHENEVER HAZARDOUS VOLTAGES (> 45 V) ARE USED, TAKE ALL MEASURES TO
AVOID ACCIDENTAL CONTACT WITH ANY LIVE COMPONENTS.

USE MAXIMUM INSULATION AND MINIMIZE THE USE OF BARE
CONDUCTORS WHEN USING THIS INSTRUMENT.

Use extreme caution when working with bare conductors or bus bars.

WHEN WORKING WITH HIGH VOLTAGES, POST WARNING SIGNS AND
KEEP UNREQUIRED PERSONNEL SAFELY AWAY.



CAUTION



DO NOT APPLY ANY VOLTAGES OR CURRENTS TO THE TERMINALS OF THIS
INSTRUMENT IN EXCESS OF THE MAXIMUM LIMITS INDICATED ON
THE FRONT PANEL OR THE OPERATING GUIDE LABEL.

1 Specifications

Measurement Parameters: Capacitance (Cs/Cp), Inductance (Ls/Lp), Resistance (Rs/Rp), Dissipation (DF) and Quality (Q) Factors, Impedance (|Z|), Admittance |Y|, Phase Angle (θ), Equivalent Series Resistance (IESR), Conductance (Gp), Reactance (Xs), Susceptance (Bp)

Any two parameters measured and displayed simultaneously

Note: s = series, p = parallel, ESR equivalent to Rs

Measurement Ranges:	Z , R, X:	000.0001 m Ω to 99.99999 M Ω
	Y , G, B:	00000.01 μ S to 9.999999 MS
	C:	00000.01 fF to 9.999999 F
	L:	0000.001 nH to 99.99999 H
	D:	.0000001 to 99.99999
	Q:	.0000001 to 999999.9
	Phase Angle:	-180.0000 to +179.9999 degrees
	Delta %:	99.9999 % to +99.9999 %

Measurement Accuracy:	<u>Fast</u>	<u>Medium</u>	<u>Slow</u>
LCR:	$\pm 0.5\%^1$	$\pm 0.25\%^1$	$\pm 0.05\%^1$
DF:	± 0.005	± 0.0025	± 0.0005

0.25 x (normal accuracy) with Load Correction implemented and compared to user supplied standard.

In a range of $3\Omega \leq Z \leq 80k\Omega$, $100mV \leq \text{programmed } V \leq 1V$ or $100mV \leq (\text{programmed } I) \times (Z) \leq 1V$

Test Frequency: 10 Hz to 2 MHz

Resolution: 0.1 Hz from 10 Hz to 10 kHz

5 digits > 10 kHz, 4 digits > 100 kHz

¹ At optimum test signal levels, optimum DUT value and without calibration uncertainty error. Instrument accuracy reduced from nominal specifications when using 7000 accessory fixtures and cables. Best accuracy requires geometric consistency between that used during open/short zeroing and that used on fixtures and cables during actual measurement. Consistency may be difficult when using unshielded Kelvin clip and Tweezer type connections.

Accuracy: $\pm (0.01\% + 0.10 \text{ Hz})$

Measurement Speed: Fast Accuracy: 120 meas/sec
 Medium Accuracy: 16 meas/sec - 8 meas/sec below 150kHz
 Slow Accuracy: 2 meas/sec – 1 meas/sec below 150kHz
 * may be longer, depending on test conditions & frequency

Ranging: Automatic, Range Hold, or User-Selectable

Source Impedance: 25 Ω , 400 Ω , 6.4 k Ω or 100 k Ω , measurement range dependent

Trigger: Internal (automatic); External (via handler, RS-232 or IEEE 488.2 interfaces)

AC Test Signal 20 mV to 5.0 V (open circuit) in 5 mV steps, <500kHz

Voltage: 20 mV to 1.0 V (open circuit) in 5 mV steps, $\geq 500\text{kHz}$ to $\leq 1\text{MHz}$

20 mV to 0.5 V (open circuit) in 5 mV steps, >1MHz

Accuracy: $\pm (5\% + 1 \text{ mV}) < 100\text{kHz}$

$\pm (10\% + 1 \text{ mV}) 100\text{kHz}$ to 500kHz

$\pm (20\% + 1 \text{ mV}) 500\text{kHz}$ to 1MHz

$\pm (35\% + 1 \text{ mV}) > 1\text{MHz}$

AC Test Signal 250 μA to 100 mA (short circuit) in 50 μA steps

Current: Max Compliance: 3V < 500kHz, 1V from 500kHz - 1MHz; 0.5V > 1MHz

Accuracy: $\pm (5\% + 50 \mu\text{A}) < 100\text{kHz}$

$\pm (10\% + 50 \mu\text{A}) 100\text{kHz}$ to 500kHz

$\pm (20\% + 50 \mu\text{A}) 500\text{kHz}$ to 1MHz

$\pm (35\% + 50 \mu\text{A}) > 1\text{MHz}$

Bias Voltage: Internal: 2.0 V External: 0 to $\pm 200 \text{ V}$

Display: LCD Graphics with adjustable contrast and back light
 Results of Dual Measurement Parameters in engineering (7 digits)
 or scientific (5 digits) notation

Deviation from Nominal of Primary Parameter

% Deviation from Nominal of Primary Parameter

Instrument Setting and Test Conditions

Bin Limits and Pass/Fail Results

Plot of Primary Measurement Parameter vs. Test Conditions

Table of Measurement Parameters vs. Test Conditions

Sequenced Test Results Summary

Limit Detection:	15 bins total (10 pass, 4 fail, 1 no contact)
Interfaces:	Standard: RS-232, Handler, Printer Port, USB; Optional: IEEE488.2
Front Panel	Four terminal (BNC)
Environmental:	MIL-T-28800E, Type 3, Class 5, Style E & F. Operating: 0° to + 50° C. Storage: - 10° to + 60° C. Humidity: < 75% for 11° C to 30 ° C operating Altitude: <2000m, Installation Category 1, Pollution Degree 1
Mechanical:	Bench mount with tilt bail Dimensions: (w x h x d): 410 x 150 x 360mm Weight: 8kg net, 10.5kg shipping
Power Requirements:	90 to 250Vac 47 - 63 Hz 100W maximum
Other Features:	Charged Capacitor Protection: $\sqrt{8/C}$ for $V_{max} \leq 250 V$ $\sqrt{2/C}$ for $V_{max} \leq 1000V$ C = Capacitance in farads of the device under test
	Measurement Delay programmable from 0-1000 ms in 1 ms steps
	Measurement Averaging programmable from 1-1000
	Median value Mode
	Open and Short Circuit Zeroing at Multiple Frequencies
	Power Fail Protection (setting, results, & calibration data stored)
	Storage and Recall – Internal Memory, USB, ASCII format
	Self-Test Routines at Power-up
	Self Accuracy Calibration and Display
	Contact Check
Supplied:	151053 Instruction Manual, Power Cable, Calibration Certificate and Flash-118 USB Memory Stick

Ordering Information Catalog No.:**7600 Plus Precision LCR Meter****7600****Options & Accessories:**

Rack Mount Kit	7000-00
BNC Cable Set, 1 meter	7000-01
BNC Cable Set, 2 meters	7000-02
Kelvin Clip Leads	7000-03
Alligator Clip Leads	7000-04
Chip Component Tweezers	7000-05
Low Voltage Axial/Radial Lead Component Test Fixture	7000-06
Low Voltage Chip Component Test Fixture	7000-07
Calibration Kit	7000-09
RS232 Cable	630158
USB to RS232 Adapter	630250

2 Introduction

2.1 Unpacking and Inspection

Inspect the shipping carton before opening; if damaged, contact the carrier's agent immediately. Inspect the instrument for any damage. If the instrument appears damaged or fails to meet specifications, notify QuadTech or its local representative. Retain the shipping carton and packing material for future use such as returning for re calibration or service.

2.2 Product Overview

The 7600 Plus Precision LCR Meter is an automatic, user-programmable instrument for measuring a wide variety of impedance parameters. The 7600 Plus covers a frequency range from 10 Hz to 2 MHz with a basic measurement accuracy of 0.05%. The instruments high resolution graphics display and keypad makes for easy menu programming. Test conditions are stored and recalled from internal memory, eliminating wasted measurement setup time. Extensive pass/fail binning capability and measurements speeds of up to 120/sec makes the unit well suited for production applications.

The instruments unique measurement sequencing allows up to six parameters to be measured on a single pass. Additionally, a parameter can be plotted against a test condition variable, an invaluable technique for component design and product evaluation.

The 7600 Plus comes with RS-232, I/O port (handler), USB host port, and parallel interfaces, all standard, for remote control operation and communication with other instrumentation. The USB host port is included for program/data storage of test conditions and measurement results, and for transferring these files to a PC. The 7600 Plus can be used with most USB memory sticks. The memory stick can be installed and removed at anytime. The USB stick is automatically mounted when installed. The USB host port complies with USB v2.0 standard. The USB host port is not designed to be connected to a PC, Printer or USB hub.



Figure 1 7600 Plus Precision LCR Meter

2.3 Controls and Indicators

Figure 2 shows the controls and indicators on the front panel of the 7600 Plus.




Figure 2 Front Panel Controls & Indicators

Figure 3 shows the controls and indicators on the rear panel of the 7600 Plus.




Figure 3 Rear Panel Controls & Indicators

2.4 Accessories Included

151053 Instruction Manual	1
Calibration Certificate	1
Power Cord (CE units with international cord set)	1
Fuse (T2.5A, 250V, 5x20mm, for 115/220V operation)	1
FLASH-118 512Mbyte Memory Stick	1

2.5 Accessories/Options Available

Rack Mount Kit	7000-00
BNC Cable Set, 1 meter	7000-01
BNC Cable Set, 2 meters	7000-02
Kelvin Clip Leads	7000-03
Alligator Clip Leads	7000-04
Clip Component Tweezers	7000-05
Low Voltage Axial/Radial Lead Component Test Fixture	7000-06
Low Voltage Chip Component Test Fixture	7000-07
Calibration Kit	7000-09
RS232 Cable	630158
USB to RS232 Adapter	630250

2.6 Installation

The 7600 Plus contains a high resolution back lit LCD for convenient viewing. The optimum angle for viewing is straight onto the display. This means that for bench operation the front bail should sometimes be used to angle the instrument up and for rack installation it should be mounted somewhat at eye level.

2.6.1 Power Requirements

The 7600 Plus Precision LCR Meter can be operated from a power source between 90 and 250Vac at a power line frequency of 47 to 63Hz, no line voltage switching is necessary. Power connection to the rear panel is through an ac inlet module comprised of an ac connector and fuse drawer. Always use an outlet that has a properly connected protection ground. Before connecting the 3-wire power cord between the unit and AC power, verify the fuse is in accordance with the power source, T2.5A, 250V, 5x20mm (QuadTech PN 520049) for 115 or 220V source. The 7600 Plus is factory shipped with the 2.5A fuse in place. The instrument can be damaged if the wrong fuse is installed. To change the fuse, proceed as follows: Procedure

1. Make sure the unit has been disconnected from its ac power source for at least five minutes before proceeding.

2. Remove the fuse drawer by inserting a small flat head screwdriver behind the small tab to force the draw outward. Refer to Figure 4.
3. Once the fuse drawer has been completely removed from the instrument remove the clear fuse tray from the drawer by lifting upward slightly on the long narrow black locking tab. This will allow the fuse tray to be removed from the fuse drawer. This tray contains the active fuse, left side (secured by holder) and spare fuse on the right side (if present).
4. Remove the active fuse from the holder by prying upward using a small flat head screwdriver. Insert the replacement fuse into the fuse holder.
5. Once the fuse has been installed in the holder and spare fuse (if desired) installed in the right side of the tray insert the tray back into the fuse drawer, push in and lock. The two silver contacts on the fuse tray should be positioned towards the outside.
6. Once the fuse tray has been installed in the draw, reinstall the fuse drawer back into the instrument ac inlet module, push in and lock.




Figure 4 Fuse Drawer

2.6.2 Safety Inspection

WARNING

If this instrument is used in a manner not specified in this manual, the operator and the equipment are at risk.

1. Never touch the metal of the High Voltage probe directly. Touch only the insulated parts of the lead(s).
2. Never touch the test leads, test fixture or DUT in any manner (this includes insulation on all wires and clips) when the high voltage is applied and the red **DANGER** light is ON.
3. Before turning on the Guardian unit, make sure there is no device (DUT) or fixture connected to the test leads.
4. After each test, press the **[STOP]** (red) button for safety. This terminates the high voltage being applied to the output terminals.

5. When the red **DANGER** LED is lit or flashing, NEVER touch the device under test, the lead wires or the output terminals.
6. Before touching the test lead wires or output terminals make sure :
 - a) The red **[STOP]** button has been pressed
 - b) The red **DANGER** LED is OFF.
7. In the case of an emergency, turn OFF the POWER switch using a “hot stick” and disconnect the AC power cord from the wall. DO NOT TOUCH THE INSTRUMENT.
8. Position the equipment so it is easy to disconnect. Disconnect by means of the power plug or power connector.
9. If the **DANGER** LED does not go off when the **[STOP]** button is pressed, immediately stop using the tester. It is possible that the output voltage is still being delivered regardless of the TEST ON/OFF control signal.
10. When the instrument is remotely controlled, be extremely careful. The High Voltage Output is being turned On/Off with an external signal.

CAUTION

Before operating the instrument, inspect the power inlet module on the rear of the 7600 Plus to ensure that the **properly rated fuse is in place**, otherwise damage to unit is possible.

When the 7600 Plus is installed in a rack (using the QuadTech 7000-00 Rack Mount Kit) verify the unit is **secured using the cabinet mounting rails** and not solely by the front panel angle brackets.

In bench or rack mount applications, the instrument should be positioned with consideration for **ample airflow**. Verify an open space of at least 3 inches (75mm) behind the rear panel. The surrounding environment should be **free from excessive dust** to prevent contamination of electronic circuits.

The 7600 Plus is shipped with a standard U.S. power cord, QuadTech PN 4200-0300 (with Belden SPH-386 socket or equivalent, and 3 wire plug conforming to IEC 320) or with an approved international cord set. Make sure the instrument is only used with these cables (or other approved international cord set) that ensures the instrument is provided with **connection to protective earth ground**.

2.6.3 Safety Symbols

The product is marked with the following safety symbols.




Product will be marked with this symbol (ISO#3864) when it is necessary for the user to refer to the instruction manual in order to prevent injury or equipment damage.



Product marked with this symbol (IEC417) indicates presence of direct current.



Product will be marked with this symbol (ISO#3864) when voltages in excess of 1000V are present.



Indicates the grounding protect terminal, which is used to prevent electric shock from the leakage on chassis. The ground terminal must connect to earth before using the product.

Warning Procedure can cause hazard to human if the warning is neglected.

Caution Avoid product misuse. It may cause damage to the product itself and the DUT if the caution is neglected.


Note Important information or tips for the procedures and applications.

Warning Signal During Testing

“DANGER – HIGH VOLTAGE TEST IN PROGRESS, UNAUTHORIZED PERSONS
KEEP AWAY”

2.6.4 Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliances for disposal.



3 Operation

Once the 7600 Plus is powered up it is ready immediately for testing, at default test conditions, by pressing the **START** button. Any of these conditions and all other instrument operations can be changed by easy-to-use menu functions, for simplicity of understanding, descriptions and uses of all these functions refer to menu discussions starting on page 12. The Contents list in the front of this manual should be used for quickly locating specify subjects of interest.

3.1 Startup

Connect the instrument power cord to the source of proper voltage. **The instrument is to be used only with three-wire grounded outlets.**

Power is applied to the 7600 Plus by pressing the **POWER** button on the front panel. The instrument runs a self test and any error messages are displayed accordingly.

3.2 Connection to Device Under Test

The 7600 Plus unit employs a four terminal measurement configuration that permits easy, accurate and stable measurements and avoids mutual inductance, interference from measurement signals, noise and other factors inherent with other types of connections. To maintain measurement integrity QuadTech makes available a number of accessory cable sets and fixtures for connection directly to the front panel BNC connectors. Refer to section 2.5 on page 4 for a list of available accessories.




Figure 5 Test Lead Configuration

Figure 5 shows the 7600 Plus connector configuration and a typical four terminal connection to the device under test. **H and L on the 7600 Plus denote polarity of AC test signal at the measurement terminals as well as + and - polarity of DC bias voltage when applied to the DUT.**

WARNING

When DC bias is applied, the PH connection carries a positive DC voltage with respect to ground.

3.3 Zeroing

Before making measurements, the 7600 Plus should be zeroed to correct for test lead and/or fixture errors. During the zeroing process corrections are calculated and stored in instrument memory and applied to ongoing measurements. Measurement accuracy is specified at the end of the QuadTech one meter cable (7000-01). Perform the Open and Short circuit zeroing with the cables and fixtures to be used during testing. In order to maintain instrument accuracy with other cable lengths the instrument should be re calibrated using the QuadTech 7000-09 Calibration Kit and the alternate cable. Generally the unit should be zeroed at least once per day and each time test leads or fixture is changed. **It is not necessary to re-zero if the test frequency is changed.** The zeroing routine is accessed through the Utilities Menu as follows:

1. Press **MENU** key
2. Press **LEFT/RIGHT ARROW** to select Utilities menu
3. Press **UP/DOWN ARROW** key for Open / Short
4. Press **ENTER**

Follow the instructions shown on the LCD display for open and short circuit zeroing of test leads and/or fixture. During the **Open Test** the leads or fixture should be open with no component connected. During the **Short Test** leads should be connected or fixture shorted (using a clean copper wire, as short as possible). When zeroing, **Contact Check should be OFF, # to Average to 1 and Median OFF.**

3.4 Measurement Procedure

Whenever the 7600 Plus is powered up it is ready immediately to begin measuring at default test conditions. Initially, these conditions will be set to factory default but can be changed by the user and stored to overwrite factory default. **To initiate a test once a device is connected press START,** the LCD display shows the measured results and test conditions similar to the illustration of Figure 6.

NOTE:

For optimum measurements, warm up for 30 minutes.




Figure 6 Measured Results Display

3.4.1 Default Measurement Conditions

A set of default measurement conditions are initially established at the factory and stored in instrument memory. Default conditions are those that determine the instruments status on power up, thus the instrument is always set to a known state before any testing begins. These conditions can be changed by the user for tailoring to a specific application. Refer to section 3.9.4 on page 54.

3.5 Factory default measurement conditions

Under Setup Menu

Primary Parameter - Auto

Secondary Parameter - None

Frequency - 1 kHz

AC Test Signal - 1V

DC Bias Voltage - Off

Range Hold - Off

Range Locked - 0

Measurement Accuracy - Medium

Delay Time - 0

to Average - 1

Contact Check - Off

Under I/O Menu

Display Type - Measured Parameters

Nominal Value - None

Result Format - Scientific

Trigger - External

Handler - Off

RS-232 - Enabled

IEEE - Disable

Print Results – Off

Results to USB - Off

Under Analysis Menu

Binning - None

Test Sequencing - Off

Parameter Sweep - Off

Median - Off

Distort Detect - Off

Load Correction - Off

Under Utilities Menu

Lockout - Off

Backlite - On

3.6 Menu Functions

All programmable functions of the 7600 Plus are controlled by easy to use menu displays. The user enters the menu mode by selecting the **MENU** key which calls up four top level menus, **Setup, I/O, Analysis** and **Utilities**. Each one of these is comprised of a sub menu list whose functions are described in detail below. Finding ones way around the menu listing is accomplished using the **UP, DOWN, RIGHT** and **LEFT** arrow keys as indicated on the adjacent LCD display. **A highlighted menu function can be controlled by selecting the ENTER key, making the desired entry or selection and pressing ENTER again to implement.**

3.6.1 Setup Menu




Figure 7 Setup Menu

The first of the four main menus is **Setup**, shown above. Each function controls a 7600 Plus measurement condition and is described in detail below.

Setup	I/O	Analysis	Utilities
Primary Parameter			Auto
Secondary Parameter		None	Cs
Frequency - (numeric entry)		DF	Cp
AC Test Signal - Voltage		Q	Ls
- Current		ESR	Lp
- Value - (numeric entry)		θ	Rs
DC Bias Voltage - Off		Rp	Rp
- Int		Rs	DF
- Ext		Rp	Q
Range Hold - Off		Gp	Z
- On		Cs	Y
Range Locked - (numeric entry)		Cp	θ
Measurement Accuracy - Fast		Ls	ESR
- Medium		Lp	Gp
- Slow		Z	Xs
Measurement Delay - (numeric entry)		Y	Bp
# to Average - (numeric entry)		Xs	
Contact Check - Off		Bp	
- On			

3.6.2 Primary Parameter




Figure 8 Primary Parameters

Additional Parameters not shown and selected by UP/DOWN arrow keys include: θ , $|ESR|$, G_p , X_s , B_p

Any combination of two parameters can be measured and displayed simultaneously on the 7600 Plus, one referred to as the **Primary** (displayed first) and the other the **Secondary**. The instrument as powered up provides a default primary parameter selection of Auto, a feature which enables any passive component to be measured without knowing what type of component it is. Depending on the component type the primary and secondary default could be Cs & DF, Rs & Q, or Ls & Q. The parameter selection can be chosen by the operator through menu selection. Besides Auto, the following selections are possible and discussed in more detail below.

Cs - Capacitance in farads

$|Z|$ - Impedance in ohms

Cp - Capacitance in farads

$|Y|$ - Admittance in siemens

Ls - Inductance in henries

θ - Angle in degrees

Lp - Inductance in henries

$|ESR|$ -Equivalent series resistance in ohms

Rs - Resistance in ohms

G_p - Conductance in siemens

Rp - Resistance in ohms

X_s - Reactance in ohms

DF- Dissipation Factor (no units)

B_p - Susceptance in siemens

Q - Quality Factor (no units)

s = series equivalent circuit

p = parallel equivalent circuit

An impedance that is neither a pure resistance nor a pure reactance can be represented at any specific frequency by either a series or a parallel combination of resistance and reactance. Such a representation is called an equivalent circuit. The value of the primary measurement of a device depends on which equivalent circuit, series or parallel, is chosen to represent it. The manufacturer or user of a device specifies how a device is to be measured (usually series) and at what frequency. If this is not known, be sure to specify if the results were series or parallel and what the measurement frequency was.

Series and parallel equivalent circuits for a lossy inductor and lossy capacitor are shown in Figure 9.




Figure 9 Series and Parallel Circuits for both Capacitive and Inductive Impedances

Impedance is the parameter used to characterize electronic sensors, components, materials and circuits. Impedance $|Z|$ is defined as the opposition a device or circuit offers to the flow of ac current at a particular frequency and generally represented as a complex quantity consisting of a real part (resistance, R) and imaginary part (reactance, jX). Impedance can be expressed using the rectangular coordinate form ($R + jX$) or polar form as magnitude and phase angle ($|Z| \angle \theta$). Figure 10 shows the mathematical relationship between R , X , $|Z|$, and θ for both inductive and capacitive devices. In some cases it becomes mathematically practical to represent impedance using the reciprocal where $1/|Z| = |Y| = G + jB$, where $|Y|$ represents admittance, G conductance, and B susceptance. This mathematical relationship is shown in Figure 11 for inductive and capacitive devices.




Figure 10 Phase Diagrams of Impedance




Figure 11 Phase Diagrams of Admittance

Quality factor (Q) is used as a measure of a reactance's purity (how close it is to being a pure reactance, i.e. no resistance) and defined as the ratio of the energy stored in a device to the energy dissipated by the device. Q is dimensionless and is expressed as $Q = X/R = B/G$. One can see that Q is the tangent of the angle θ . Q is commonly applied to inductors and for capacitors the term generally used to express purity is Dissipation Factor (D), which is the reciprocal of Q .

Any parameter, primary or secondary, can be chosen as the default parameter at power up.

3.6.3 Secondary Parameter




Figure 12 Secondary Parameter

Additional Parameters not shown and selected by UP/DOWN arrow keys include: **Lp, |Z|, |Y|, Xs, Bp**

As in the primary parameter selection, any one parameter can be chosen by the operator for display. The instrument as powered up provides a default secondary parameter. When the default primary parameter is Auto the secondary parameter is dependent and determined by it. If the primary default is Cs the secondary defaults to D. If the primary default is Ls or Rs the secondary defaults to Q. The parameter selection can be chosen by the operator through menu selection.

3.6.4 Frequency

Numerical entry accepts up to **five digits with decimal**, of the desired test frequency between 10 Hz and 2 MHz. Resolution of setting is 0.1 Hz from 10 Hz to 10 kHz, 5 digits above 10 kHz.

Units of frequency, **Hz, kHz, or MHz** are selected by the **UP/DOWN** arrow keys.

3.6.5 AC Test Signal




Figure 13 AC Test Signal

Allows selection of the AC Signal Type as a **Voltage** source or **Current** source, RIGHT/LEFT arrow keys.

With Signal Type selected as **Voltage**, Signal Value accepts entry of a value between **0.020 and 5 volts*** (open circuit) in 0.005 V steps.

With Signal Type selected as **Current**, Signal Value accepts entry of a value between **0.00025 and .1 amp** (short circuit) in 0.00005 amp steps.

Numerical values can be entered directly with units. Units for voltage value, **mV** or **V** and units of current value, **μA**, **mA**, or **A** are selected by the UP/DOWN arrow keys. Any **numerical entries with resolution greater than 0.005V (5 mV) for voltage or 0.00005A (50 μA) for current will be truncated or ignored.**


In voltage mode the selected voltage is maintained at the instrument test terminals with the terminals open, but not necessarily at the device under test. In current mode the selected current is maintained at the device under test, independent of changes in the device's impedance. It should be noted that even though the maximum programmable current is 100 mA **the instrument is limited to a compliance voltage of 3 volts* in current mode**, i.e. (I) times (Z) must be less than 3 volts otherwise erratic measurement results could occur.

The current required to test a device may exceed 100 mA if the source voltage is programmed to greater than 2.5 V. To determine the current required use the following formula:

$$I = V_{prog} \div \sqrt{(25 + R_{dut})^2 + (X_{dut})^2}$$

If the current is greater than 100 mA, reduce the program voltage, otherwise unpredictable measurement results may occur.

* 1 volt above 500 kHz, 0.5 volts above 1 MHz



Maximum Test Frequency vs. Measured Inductance (In Current Mode)

3.6.6 DC Bias Voltage

--- Allows selection of a dc Bias Voltage of **Off, Internal or External**.

- **Off** - When selected **no dc bias** voltage is applied to the device under test.
- **Int** - When selected an internal bias voltage of **2 volts** is applied to the device under test. Internal bias can not be programmed if the AC Test Signal is programmed for > 4V at 500kHz.
- **Ext** - When selected an external bias voltage between **0 and ±200 volts** can be applied to the device under test by way of the rear panel external bias connection.

CAUTION

Make sure the **AC test Signal is selected for VOLTAGE and not Current** before switching to INT (internal) or EXT (external) bias. This also applies to the instrument's Default setup at power-up or any setups recalled from memory, they **MUST be set to VOLTAGE** before applying bias. If programmed to CURRENT the instrument can sustain damage from any external source or from a charge stored on the device under test

WARNING

When using external bias, unit must be programmed for EXT bias before the external bias supply is connected to the 7600 Plus.

External bias supply must be returned to zero volts and turned off before switching back to the OFF or INT mode.

The **BIAS ON indicator**, adjacent to the BNC measurement terminals, serves to indicate if external bias has been called for. It indicates that external bias connections have been switched in, **but not necessarily the presence of external bias**.

When dc bias is to be applied to a device observe the correct polarity when connecting the bridge or inserting the device in a test fixture. **Bias POSITIVE polarity is applied to the high terminals (PH, IH), and bias NEGATIVE polarity applied to the low terminals (PL, IL)**. It is good practice to wait approximately 1 second after initiating a measurement before taking a reading, this allows the device to stabilize after bias is applied. When the instrument is triggered remotely, a programmed delay is advisable to ensure that the device has stabilized.

If bias is required at voltages other than the internal 2 volts, an external bias can be used as discussed below.

- **Be sure that the voltage does not exceed ±200 volts.**
- A current limiting voltage supply is recommended, with a limit set at 200 mA.
- **The bias supply must be floating, DO NOT connect either side to ground.** When using a single polarity supply for positive or negative biasing, observe proper polarity when connecting to the 7600 Plus. For positive bias the positive output of the supply must be connected to **Bias Voltage +** and the negative to **Bias Voltage -**. The

opposite is true for negative bias, the negative output of the supply must be connected to the **Bias Voltage +** and the positive to **Bias Voltage -**.

- Generally the external circuit must provide switching for both application of bias after the device is connected and discharge before it is removed.
- A well-filtered supply is recommended. Hum can affect some measurements, particularly at power line frequencies. When applying a bias voltage there are effects to be aware of in watching for stabilization of the DUT: voltage and capacitance. Besides charging to a final voltage, there is also the stabilization of capacitance value itself. For example, some electrolytic capacitors respond slowly to a change in applied voltage, therefore the capacitance can be changing well after the voltage is stable. In general DC bias should only be applied to capacitors, **unreliable measurement results can occur if DC bias is applied to low impedance devices**. When applying external bias on capacitors below 200pF with an AC signal level below 100mV the instrument can exhibit excessive noise.

3.6.7 Range Hold

Allows selection of Range Hold **Off** or **On**. **To eliminate operator errors in range setting and ensure specified instrument accuracy the 7600 Plus Range Hold should generally be left Off**. There may be exceptions to this when repetitive measurements are to be made over a concentrated range of values and there is a desire to reduce test time by eliminating range switching.

- **Off** - When selected the instrument automatically **selects the optimum range** for the test voltage and test frequency selected and the impedance being measured.
- **On** - When selected the **range is held** based on the one currently selected, 1 through 59 in voltage mode or 33 through 159 in current mode. The one currently selected is best determined by measuring the device with Range Hold to Off. Measured results outside the bounds of a selected range will be indicated by an **OVER RANGE** or **UNDER RANGE** display message.

NOTE:

The 7600 Plus unit provides an extensive array of range switching based on the user test conditions selected and impedance being measured.

One of the most important uses of the range holding capability is to avoid range changes when the component is removed from a fixture when repetitive internal triggering is selected. With no component connected the instrument can go into a range search and time is lost when the next component is connected. Another use of range hold occurs when measuring components of the same nominal value whose actual values spread across the boundary of two ranges. If allowed to auto range, the units and decimal point can change with the range and confuse the operator. **It is important to note that when a range is held which is not the range the instrument auto ranging would have selected, some accuracy may be sacrificed.**

Under certain circumstances high Q inductors can cause extraneous overload conditions if they are tested at frequencies where the inductor resonates with the test leads. This situation can be avoided by one or more of the following: test at a voltage substantially below full scale voltage for a given range; use low capacitance cables; or test at a frequency below the resonant frequency of the inductor with the test leads.

3.6.8 Range Locked

Accepts entry of selected measurement ranges between **0 and 59 (as listed below)**, 0 for no range locked and others for the selected range. Measurement ranges are a function of the impedance being measured (Z), selected test frequency (F) and ac test voltage (V). For best measurement results the instrument is generally recommended to operate with Range Hold to **Off** and Range Locked to **0**. It is possible to calculate a range, based on Z, F and V, as detailed below.

AC Signal Voltage Mode

Measurement Range #'s			
1	17	33	49
2	18	34	50
3	19	35	51
5	21	37	53
6	22	38	54
7	23	39	55
9	25	41	57
10	26	42	58
11	27	43	59

Determine Range where $R\# = R1 + R2 + R3$

- where R1 = 1 and $K^* = 10 \mu\text{A}$ if $F < 25 \text{ kHz}$ and $I < 10 \mu\text{A}$
 = 17 and $K^* = 160 \mu\text{A}$ if $F < 200 \text{ kHz}$ and $I < 160 \mu\text{A}$
 = 33 and $K^* = 2.56 \text{ mA}$ if $I < 2.56 \text{ mA}$
 = 49 and $K^* = 40 \text{ mA}$ if $I \geq 2.56 \text{ mA}$

* value for K required in calculation of R3 below

$$I = \frac{V_i}{Z + 25}$$

- $V_i = 10\text{V}$ if $V \leq 0.1\text{V}$
 = V if $V > 0.1$ and < 1.01

$$= V/5 \text{ if } \geq 1.01$$

V = programmed ac test voltage

Z = impedance value Z in ohms of the device under test.

where R2 = 0 if $(I)(Z) > 0.25$

= 1 if $(I)(Z) > 0.1$

= 2 if $(I)(Z) > 0.025$

where R3 = 0 if $I / K > 0.25$

= 4 if $I / K > 0.1$

= 8 if $I / K > 0.025$

Note: above 1.5 MHz R2 and R3 are always 0 (zero)

AC Signal Current Mode

Measurement Range #'s			
33	49	133	149
34	50	134	150
35	51	135	151
37	53	137	153
38	54	138	154
39	55	139	155
41	57	141	157
42	58	142	158
43	59	143	159

Determine Range where $R\# = R + R1 + R2 + R3$

where R = 33 and $R_s = 400\Omega$ if $I \leq 2.2\text{mA}$

= 49 and $R_s = 25\Omega$ if $I > 2.2\text{mA}$

I = programmed ac test current

where R1 = 0 and $V_s = 1.0$ if E_{DUT} or $E_{DET} \leq 1.0$

= 100 and $V_s = 5.0$ if E_{DUT} or $E_{DET} > 1.0$

$E_{DUT} = (I)(Z)$ this value must be less than 3.0, reference paragraph 2.6.2.4 AC Test Signal

$$E_{\text{DET}} = (I) (R_s)$$

Z = impedance value Z in ohms of the device under test (refer to Figures 2-11 and 2-12 to help determine Z in terms of capacitive and inductive reactance).

where R_2 = 0 if $E_{\text{DUT}}/V_s > 0.25$

= 1 if $E_{\text{DUT}}/V_s \leq 0.25$

= 2 if $E_{\text{DUT}}/V_s \leq 0.1$

where R_3 = 0 if $E_{\text{DET}}/V_s > 0.25$

= 4 if $E_{\text{DET}}/V_s \leq 0.25$

= 8 if $E_{\text{DET}}/V_s \leq 0.1$




Figure 14 Capacitive Reactance vs. Frequency




Figure 15 Inductive Reactance vs. Frequency




Figure 16 Measurement Accuracy

Allows selection of Measurement Accuracy of **Fast, Medium** or **Slow**.

There is a tradeoff of measurement speed vs. accuracy. The meter will make a more precise and accurate measurement at a slower rate. The speed/accuracy tradeoff is as follows:

- **Fast** - Measurement time of 8.333 ms (or one frequency cycle, whichever is longer), nominal accuracy of **0.5%**.
- **Medium** - Measurement time is 125 ms, nominal accuracy of **0.25%**.

Note: Above 150kHz Measurement time is 62.5 ms

- **Slow** - Measurement time is 1 sec, nominal accuracy of **0.05%**.

Note: Above 150kHz Measurement time is 0.5 s

NOTE:

Measurement times may be longer depending on frequency and other test conditions.

One complete cycle of stimulus voltage is required for measurement.

For example: at 10 Hz, 100 ms (1 cycle) is required just to collect data.

3.6.9 Measurement Delay

Accepts entry of a delay time between **0 and 1000** in 1 ms steps. This is a programmable delay time from the internal or external trigger command to the start of the measurement. In many cases it is helpful to have a time delay before actually starting to take data. Such a delay allows time for switching transients or mechanical handling to settle.

3.6.10 # to Average

Accepts entry of the number of measurements to Average between **1 and 1000**. If the entered value is 1, averaging is disabled and the display is updated with each individual measurement. If the average is 2 to 1000 the final average value is displayed at the end of the measurement cycle and held until the end of the next measurement cycle.

Measurement accuracy can be improved as noted below and will be indicated on the AutoAcc display (but never less than 0.05% for primary parameter or 0.0005 for secondary parameter).

If the number to average is greater than 1:

Divide the primary accuracy by the square root of the number to average.


Divide the secondary accuracy by the square root of the number to average.

3.6.11 Contact Check


Allows selection of Contact Check **Off or On**. When on, any detection of contact failure or open circuit to the device under test will be indicated prior to the measurement. A contact failure is considered to be an open circuit greater than the open circuit calibration of the instrument. **Contact Check is generally recommended in automatic handler/production type applications with the 7600 Plus. For Contact Check operation, the Range Hold must be selected ON.**

NOTE:

A contact check is possible on three of the four Kelvin connections by a loss of voltage detecting technique, a failure on the PL connection can't be detected since it is at virtual ground potential, internal to the instrument. The contact check is likely to be unreliable when measuring devices of less than 100 mΩ of impedance.

3.6.12 I/O Menu**Figure 17 I/O Menu**

The second of the four main menus is **I/O**, shown above. Each function controls measurement results or instrument I/O interface and is described in detail below.



3.7 Display Type




Figure 18 Display Type

Allows selection from seven different modes of measurement display, these being:

3.7.1 Measured Parameters -

Display is the measured values of both the primary and secondary parameter, displayed along with decimal point and units. Each value is shown with **7 digits of resolution** (6 digits if the result is negative). The message **Measuring** is shown when a measurement is in process, with the exception of short measuring times.




Figure 19 Measured Parameters Display

3.7.2 Deviation from Nominal -

Display is the difference in value above or below a stored nominal value for the primary parameter. It should be noted that the nominal value is only shown in this display and the % Deviation display.




Figure 20 Deviation from Nominal Display

3.7.3 % Deviation from Nominal -

Display is the measurement in terms of a percent difference above or below (-) a stored nominal value. It should be noted that the nominal value is only shown in this display and the Deviation from Nominal display.




Figure 21 % Deviation from Nominal Display

3.7.4 Pass/Fail –

Display is measured results as a pass or fail only based on entered binning limits.




Figure 22 PASS/FAIL

3.7.5 Bin Summary –

Display is a summary of the entered bin limits and the total number of measurements made which meet the requirements of that bin since the bin counter was last reset.

Bin	Low LIMIT	High LIMIT	Total
1	90.00 k Ω	110.00 k Ω	250
2	100.00 k Ω	120.00 k Ω	100
3	110.00 k Ω	130.00 k Ω	90
4	120.00 k Ω	140.00 k Ω	80
5	130.00 k Ω	150.00 k Ω	75
11	PRI Pass SEC Fail LOW		60
12	PRI Pass SEC Fail HI		55
13	PRI Fail SEC Pass		50
14	PRI Fail SEC Fail		20
15	NO CONTACT		5
Totals:	Pass 595	Fail 190	785

Figure 23 Bin Summary Display

3.7.6 Bin Number –

Display is a bin assignment, along with the currently programmed test conditions, for the most recent measurement result.




Figure 24 Bin Number Display

3.7.7 No Display –

Instrument display is inhibited from indicating any measurement results. This is sometimes used for security reasons or for the purpose of reducing test time during remote operation.

3.7.8 Nominal Value

Allows entry of a Nominal Value for the primary parameter, which is the **basis for the measurement result in Deviation or % Deviation**. Accepts numerical entry up to seven digits with decimal. Units are selected by the UP/DOWN arrow keys and determined by the primary parameter selection, i.e. in Farads, Ohms, Henries, etc.

NOTE:

The nominal value has no relationship to nominal values entered during binning setup.

3.7.9 Result Format

Allows selection from two different measurement result formats **SCI and ENG**, for scientific or engineering units. Scientific units are expressed as an exponent and engineering units are expressed in ohms for resistance, farads for capacitance, henries for inductance, etc. For example e^3 in scientific units can be expressed as $k\Omega$ in engineering units; or e^{-3} in scientific units can be expressed as $m\Omega$ in engineering units, this is strictly user preference and convenience.

When scientific units are selected the results will always be displayed as some number of digits with decimal, exponent and units. When engineering units is selected the results will be displayed as some number of digits with decimal and units.

3.7.10 Trigger

Allows selection of two trigger modes, **Internal** or **External**.

- Internal - Measurement trigger is **automatic and continuous** once initiated with a START. If the STOP key is pressed in the middle of a measurement (with Range Hold set to OFF) any measurement range indication or displayed results is invalid.
- External - Measurement trigger is under **remote control** via front panel, handler, RS 232 or IEEE-488 interface.

3.7.11 Handler Interface

Allows user to turn Handler Interface function **On or Off**. When On is selected the input and output lines on the rear panel I/O interface connector are acknowledged. When Off is selected they are ignored.

3.7.12 RS-232 Interface




Figure 25 RS-232 Setup Format

Allows user setup of standard RS-232 interface formats. Choices include:

- Baud Rate** - 12, 24, 48, or 96 (for 1200, 2400, 4800, and 9600 respectively)
- Parity** - None, Even or Odd
- Data Bits** - 7 or 8
- Stop Bits** - 1 or 2
- Mode** - Talk or Talk/Listen

UP/DOWN arrow and **Enter** selects the desired format and then **LEFT/RIGHT** arrow and **ENTER** allows for selection of choices within each format.

3.7.13 IEEE-488.2 Interface




Figure 26 IEEE Setup Format

Note: IEEE Interface is an Option. If option is not installed, State cannot be enabled.

Allows user setup of IEEE-488 interface format. Choices include:

- Address** - 1 through 16
- Mode** - Talk or Talk/Listen
- State** - Disable or Enable

UP/DOWN arrow and **ENTER** selects the desired format and then **LEFT/RIGHT** arrow and **ENTER** allows for selection of choices within each format.

The instrument will function as either a Talk or a Talk/Listen device in a system depending on the choice made by the operator under Mode. Talk is generally suited to a simple system with no controller or other talkers, for example a printer. Talk/Listen denotes full programmability and is suited for use in a system that has a controller or computer to manage data flow. The "handshake" routine assures that the active talker proceeds slowly enough for the slowest listener.

3.7.14 Print Results

Allows user to output results to the parallel port by selection of **Off** or **On**. Before selecting **On** make sure the printer is connected and on-line.

File format for printing is the same as shown in the next paragraph under **Results to USB**. Lines not printed are indicated.

3.7.15 Results to USB

The 7600 Plus can be used with most USB memory sticks. The memory stick can be installed and removed at anytime. The USB stick is automatically mounted when installed. The USB host port complies with USB v2.0 standard. The USB host port is not designed to be connected to a PC, Printer or USB hub.

Allows user to store measurement results on flash drive. If a results file is not open, the user is prompted for the filename (up to 8 characters) and the file is opened.

To close a results file that is currently open, select Results to USB and close.

If a results file is open when a setup is saved, when the setup is later recalled the user will be prompted for a results file name.

When multiple tests are being conducted the results are stored to USB periodically (every 10 measurements) from an internal buffer. **To be sure of storing all results before power is shut down the file needs to be closed** as discussed earlier. It is also important to note that a file should be closed before changing or recalling a new set of test conditions, otherwise the stored measurement results would not be consistent with the setup conditions stored in the file.

The measurement results are stored as an comma separated ASCII text file under its assigned identifying number (up to 8 characters). The extension for Data is “.csv”

The test setup conditions are saved as a header at the beginning of a results file. A sample file format is shown below. Note that the results can be stored in either engineering or scientific terms dependent on what the user has selected for setup conditions. The format of the result string is as follows:

Label, Primary result, Units, Label, Secondary result, Units, Bin#<CR><LF>

Sample file format as follows.

Copyright QuadTech Inc. 2008		not printed
ENDHEADER		not printed
2000000.000000	;frequency	
5.000000	;primary parameter	
2.000000	;secondary parameter	
0.000000	;ac signal type	
0.100000	;ac signal value	
0.000000	;bias	
0.000000	;range	
1.000000	;rangelocked	
68.000000	;range relay	not printed
205.000000	;relay 2	
69.000000	;relay 3	
66.000000	;va	not printed
2.000000	;measurment speed	
0.000000	;delay time	
1.000000	;# to average	
0.000000	;contact check	
0.000000	;display type	

```

0.00000000009989577000    ;nominal value
0.000000    ;result format
1.000000    ;trigger
1.000000    ;handler
3.000000    ;baud
0.000000    ;parity
1.000000    ;data bits
0.000000    ;stop bits
1.000000    ;rs232 mode
1.000000    ;rs232 state
4.000000    ;IEEE address
1.000000    ;IEEE mode
0.000000    ;IEEE state
0.000000    ;print results
0.000000    ;result to USB

0.000000000000000000000000    ;low limit bin 0    not printed
0.000000000000000000000000    ;high limit bin 0    |
0.000000000000000000000000    ;nominal value bin 0    |
0.000000    ;limit format bin 0    |
0.000000000000000000000000    ;low limit bin 1    |
0.000000000000000000000000    ;high limit bin 1    |
0.000000000000000000000000    ;nominal value bin 1    |
0.000000    ;limit format bin 1    |
0.000000000000000000000000    ;low limit bin 2    |
0.000000000000000000000000    ;high limit bin 2    |
0.000000000000000000000000    ;nominal value bin 2    |
0.000000    ;limit format bin 2    |
0.000000000000000000000000    ;low limit bin 3    |
0.000000000000000000000000    ;high limit bin 3    |
0.000000000000000000000000    ;nominal value bin 3    |
0.000000    ;limit format bin 3    |
0.000000000000000000000000    ;low limit bin 4    |
0.000000000000000000000000    ;high limit bin 4    |
0.000000000000000000000000    ;nominal value bin 4    |

```

0.000000	;limit format bin 4	
0.00000000000000000000	;low limit bin 5	
0.00000000000000000000	;high limit bin 5	
0.00000000000000000000	;nominal value bin 5	
0.000000	;limit format bin 5	
0.00000000000000000000	;low limit bin 6	
0.00000000000000000000	;high limit bin 6	
0.00000000000000000000	;nominal value bin 6	
0.000000	;limit format bin 6	
0.00000000000000000000	;low limit bin 7	
0.00000000000000000000	;high limit bin 7	
0.00000000000000000000	;nominal value bin 7	
0.000000	;limit format bin 7	
0.00000000000000000000	;low limit bin 8	
0.00000000000000000000	;high limit bin 8	
0.00000000000000000000	;nominal value bin 8	
0.000000	;limit format bin 8	
0.00000000000000000000	;low limit bin 9	
0.00000000000000000000	;high limit bin 9	
0.00000000000000000000	;nominal value bin 9	
0.000000	;limit format bin 9	
0.00000000000000000000	;low limit bin 10	
0.00000000000000000000	;high limit bin 10	
0.00000000000000000000	;nominal value bin 10	
0.000000	;limit format bin 10	
0.00000000000000000000	;low limit bin 11	
0.00000000000000000000	;high limit bin 11	
0.00000000000000000000	;nominal value bin 11	
0.000000	;limit format bin 11	
0.00000000000000000000	;low limit bin 12	
0.00000000000000000000	;high limit bin 12	
0.00000000000000000000	;nominal value bin 12	
0.000000	;limit format bin 12	
0.00000000000000000000	;low limit bin 13	

0.00000000000000000000	;high limit bin 13	
0.00000000000000000000	;nominal value bin 13	
0.000000	;limit format bin 13	
0.00000000000000000000	;low limit bin 14	
0.00000000000000000000	;high limit bin 14	
0.00000000000000000000	;nominal value bin 14	
0.000000	;limit format bin 14	not printed
0.000000	;secondary low	
0.000000	;secondary high	
0.000000	;sequence	
0.000000	;sequence status	printed only if sequence enabled
1000.000000	;sequence frequency	
0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	
0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sequence status	
1000.000000	;sequence frequency	
0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	

0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sequence status	
1000.000000	;sequence frequency	
0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	
0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sequence status	
1000.000000	;sequence frequency	
0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	
0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sequence status	
1000.000000	;sequence frequency	

0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	
0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sequence status	
1000.000000	;sequence frequency	
0.000000	;sequence pri param	
0.000000	;sequence sec param	
0.000000	;sequence bias	
0.000000	;sequence ac signal type	
1.000000	;sequence ac signal value	
0.000000	;sequence delay	
0.000000	;sequence range	
0.000000	;sequence range relay	
0.000000	;sequence relay 2	
0.000000	;sequence relay 3	
0.000000	;sequence var relay	
1.000000	;sequence stop on fail	
0.000000	;sweep	printed only if sequence enabled
0.000000	;sweep parameter	
10.000000	;sweep begin	
1000.000000	;sweep end	
0.000000	;sweep step	
0.000000	;sweep result format	
0.000000	;median	
1.000000	;correction	

```

25.000000      ;correction primary nominal
50.000000      ;correction secondary nominal
1.000000       ;correction status
1000.000000    ;correction frequency
49.000000      ;correction range
5.000000       ;correction primary parameter
4.000000       ;correction secondary parameter
25.17072 Ω     ;correction measured primary
-.1947500      ;correction measured secondary
-0.170725      ;correction primary correction
50.194742      ;correction secondary correction
0.000000       ;enhanced distortion
0.000000       ;lockout
1.000000       ;backlite
    
```

ENDHEADER

```

Cs, 9.69573e-09, F, DF, 0.0052921, Bin, 1,,,,
Cs, 9.69645e-09, F, DF, 0.0052307, Bin, 1,,,,
Cs, 9.69575e-09, F, DF, 0.0052404, Bin, 1,,,,
Cs, 9.69583e-09, F, DF, 0.0052983, Bin, 1,,,,
Cs, 9.69698e-09, F, DF, 0.0053328, Bin, 1,,,,
    
```

The number of measurement results that can be stored is dependent on available memory and length of the data string. For example; if no limit is set the measurement string contains no bin results, thus the string has fewer characters. The same is true with header information: multiple headers (different test conditions) will consume more memory.

3.7.16 Analysis Menu





Figure 27 Analysis Menu

The third of the four main menus is **Analysis**, shown above. Each function controls the analysis of measurement results and is described in detail below.



3.7.17 Binning




Figure 28 Binning

The 7600 Plus provides sorting into **15 bins** (10 pass, 4 fail and 1 for no contact). For the binning function to be enabled, one or both of the two conditions must be met:

1. Bin 1 limits must be set (non-zero).
2. Secondary parameter must be set (not NONE) and secondary low/high limits must be set (non-zero).

These are assigned as follows:

Bins 1 through 10 - **Pass** bins for the primary parameter (**Pass** for secondary parameter if limit is entered)

Bin 11 - Primary parameter **pass** and secondary parameter **fail low**

Bin 12 - Primary parameter **pass** and secondary parameter **fail high**

Bin 13 - Primary parameter **fail** and secondary parameter **pass**

Bin 14 - Primary parameter **fail** and secondary parameter **fail**


Bin 15 - **No contact**

Note:

If no limit is entered for primary parameter but one is for the secondary parameter, bin assignment will be to Bin 1 for a **pass**, Bin 11 for a **fail low**, or Bin 12 for a **fail high**.

Bin assignment during the test sequencing mode of operation is entirely different.


Bin limits for the primary parameter can be entered in terms of absolute value or as a percent tolerance about a defined nominal. Two of the most common methods sorting is **nested** limits and **sequential** limits. Nested limits are a natural choice for sorting by % tolerance around a single nominal value with the lower number bins narrower than the higher numbered ones. Nested limits for three bins is illustrated below, note that limits do not have to be symmetrical as shown for bin 3.



Tolerance Percent

Bin	Nominal	% BELOW	% ABOVE
1	100.00 k	1.00	1.00
2	100.00 k	5.00	5.00
3	100.00 k	7.00	10.00

Sequential limits are a natural choice for sorting by absolute value. Sequential limits for three bins are illustrated below. It should be noted that the bins do not necessarily have to be adjacent. Depending on the specified limits for each they can be overlapping, adjacent or even isolated (gaps) from each other. Any overlap is assigned to the lower numbered bin and a gap would be assigned to the overall fail bin.



Absolute Limit

Bin	Low LIMIT	High LIMIT
1	85.00 k	90.00 k
2	90.00 k	100.00 k
3	100.00 k	120.00 k

3.7.18 Absolute Limit

Absolute limit selection allows for entry of both **upper and lower limit for each bin in absolute value. Valid range for each is -10^8 to 10^9 .** If zero is entered for Low or High, the previous value is cleared and that bin disabled. When limits are entered in terms of absolute value the same limits will automatically be shown in terms of percent on the Tolerance Percent Display. This automatic calculation should be used cautiously; imprecise displays and missed bin assignments are possible at the range extremes. Arrow up, down, left to right to select the limit of interest in either the low or high limit column as shown below (low limit for bin 5 is chosen in this example)

Absolute Limit		
Bin	Low LIMIT	High LIMIT
1	90.00 k	110.00 k
2	100.00 k	120.00 k
3	110.00 k	130.00 k
4	120.00 k	140.00 k
5	130.00 k	150.00 k
6	140.00 k	160.00 k
7	150.00 k	170.00 k
8	160.00 k	180.00 k
9	170.00 k	190.00 k
10	180.00 k	120.00 k

Figure 29 Absolute Limit

Once the limit of choice is selected by UP/DOWN, LEFT/RIGHT arrow and ENTER the numerical value can be entered directly as shown below (entry is 130 in this example).

Absolute Limit		
Bin	Low LIMIT	High LIMIT
1	90.00 k	110.00 k
2	100.00 k	120.00 k
3	110.00 k	130.00 k
4	120.00 k	140.00 k
5	130	150.00 k
6	140.00 k	160.00 k
7	150.00 k	170.00 k
8	160.00 k	180.00 k
9	170.00 k	190.00 k
10	180.00 k	200.00 k

Figure 30 Absolute Limit (Numeric Entry)

Then arrow up or down to select units from those available (k is chosen in this example).

Absolute Limit		
Bin	Low LIMIT	High LIMIT
1	90.00 k	110.00 k
2	100.00 k	120.00 k
3	110.00 k	130.00 k
4	120.00 k	140.00 k
5	130 k	150.00 k
6	140.00 k	160.00 k
7	150.00 k	170.00 k
8	160.00 k	180.00 k
9	170.00 k	190.00 k
10	180.00 k	120.00 k

Figure 31 Absolute Limit (Engineering Units)

Press ENTER to finalize the entry, the UP/DOWN, LEFT/RIGHT arrow to choose the next limit to be entered or changed.

3.7.19 Tolerance Percent

Tolerance Percent selection allows for entry of both **upper and lower limit in terms of percent below or above an entered nominal (both must be entered)**. When limits are entered in terms of percent the same limits will automatically be shown in terms of absolute value on the Absolute Value Display. Arrow up, down, left to right to select the nominal value or % limit of interest as shown below. The nominal value can be entered in the same fashion as the absolute limit is entered above, numerical value, then arrow Up or Down to select units. **Valid range is -10^8 to 10^9** . If zero is entered for Nominal, the entire row is cleared and that bin disabled. The % tolerance can be entered directly in increments of 0.01%, any increments smaller than this are rounded to the closest 0.01%. **Valid range for each is 0 to 100**. If zero is entered for %Below or %Above, the previous value is cleared and that bin disabled.

Tolerance Percent			
Bin	Nominal	% BELOW	% ABOVE
1	100.00 k	10.00	10.00
2	110.00 k	10.00	10.00
3	120.00 k	10.00	10.00
4	130.00 k	10.00	10.00
5	140.00 k	10.00	10.00
6	150.00 k	10.00	10.00
7	160.00 k	10.00	10.00
8	170.00 k	10.00	10.00
9	180.00 k	10.00	10.00
10	190.00 k	10.00	10.00

Figure 32 Tolerance Percent

3.7.20 Secondary Low

Accepts entry of numerical value for the low limit of the secondary parameter. Units are determined by the secondary parameter selection, i.e. in Farads, Ohms, Henries, etc. and selected by the UP/DOWN arrow keys. **Valid range is -10^3 to 10^4** .

NOTE:
Low limit must be less than the High limit

3.7.21 Secondary High

Accepts entry of numerical value for the high limit of the secondary parameter. Units are determined by the secondary parameter selection, i.e. in Farads, Ohms, Henries, etc. and selected by the UP/DOWN arrow keys. **Valid range is -10^3 to 10^4** .

NOTE:
High limit must be greater than the Low limit

3.7.22 View Bin Totals

Bin	Low LIMIT	High LIMIT	Total
1	90.00 k	110.00 k	250
2	100.00 k	120.00 k	100
3	110.00 k	130.00 k	90
4	120.00 k	140.00 k	80
5	130.00 k	150.00 k	75
11	PRI Pass SEC Fail LOW		60
12	PRI Pass SEC Fail HI		55
13	PRI Fail SEC Pass		50
14	PRI Fail SEC Fail		20
15	NO CONTACT		5
Totals:	Pass 595	Fail 190	785

HIT MENU TO RETURN TO MAIN MENU

Figure 33 Bin Totals

The total count for each bin is tracked from 0 to 999,999.

3.7.23 Zero Bin Totals

Bin count totals are all reset to zero when selected and returned to the Menu screen.

3.7.24 Test Sequencing

The 7600 Plus is capable of performing a sequence measurement containing up to **six different test steps**. Different measurement parameters and conditions can be defined for each test in the sequence.

Test sequencing can be selected as **Off, On or Edit**. Edit allows measurement parameters and test conditions to be changed for all six tests. It is important to note that **tests can only be enabled in sequence**, for example, one can enable tests 1 through 3 but not tests 1 and 3 only, i.e. it is not possible to skip a test. For optimum measure speed performance, whenever possible, set test conditions of test 1 to be the same as default conditions.

Sequence Setup Test 1

Test 1 Status	<input type="checkbox"/> Disable	Enable	
Primary Parameter			>>
Secondary Parameter			>>
Frequency	= 1.0000kHz		
DC Bias Voltage	<input type="checkbox"/> Off	Int	Ext
AC Signal Type	<input type="checkbox"/> Voltage		Current
AC Signal Value	= 1.000 V		
Measurement Delay (ms)	= 0		
Range Hold	<input type="checkbox"/> Off	On	
Stop on Fail	Off	<input type="checkbox"/> On	
Binning			>>

HIT MENU TO RETURN TO MAIN MENU

↑

↓

Prev Test

Next Test

Figure 34 Sequence Setup (Test Conditions)

If Range Hold is turned ON and this is the "first" sequence measurement, for each test the 7600 Plus automatically finds the correct range and completes a measurement (this range is saved for all future measurements) for that sequence only. It is important that the first part be "good" for the range hold to select the correct range. To repeat an auto range selection, turn sequences off and then back on again (making the next measurement taken the "first" sequence measurement).

Test conditions for each setup are selected as shown above except for the primary parameter, secondary parameter and binning, these are selected on individual menus as shown below. To change test conditions on any or all six tests select **Prev Test** or **Next Test** to access test conditions for that test.




Figure 35 Sequence Setup (Parameter Selection)

Bin assignment in the test sequence mode is defined as follows:

<u>Bin #</u>	<u>Assigned</u>
Bin 1	Test 1 (Primary parameter, fail)
Bin 2	Test 1 (Secondary parameter, fail)
Bin 3	Test 2 (Primary parameter, fail)
Bin 4	Test 2 (Secondary parameter, fail)
Bin 5	Test 3 (Primary parameter, fail)
Bin 6	Test 3 (Secondary parameter, fail)
Bin 7	Test 4 (Primary parameter, fail)
Bin 8	Test 4 (Secondary parameter, fail)
Bin 9	Test 5 (Primary parameter, fail)
Bin 10	Test 5 (Secondary parameter, fail)
Bin 11	Test 6 (Primary parameter, fail)
Bin 12	Test 6 (Secondary parameter, fail)
Bin 13	Unused
Bin 14	Pass Bin
Bin 15	Contact Check, fail

For the binning function to be enabled, Bin 1 limits must be set (non-zero). If zero is entered for Low or High, the previous value is cleared and that bin disabled. **Valid range for primary or secondary is -10^8 to 10^9** . All sequence binning limits must be entered on the display shown below and NOT the standard binning displays.

Sequence Setup Test 1		
Bin	Low LIMIT	High LIMIT
1 Pri	90.00 k	110.00 k
2 Sec	100.00 k	120.00 k

Figure 36 Sequence Binning

Test conditions of measurement sequences can be stored and/or recalled as part of test setups. If a test sequence is **stored as On**, the sequence will be executed once the Start button is pressed, if the test sequence is **stored as Off**, the sequence will be inactive until turned on.

Note that a sequence (of up to six tests) can be terminated on any test of the sequence if the user has specified **Stop on Fail** for that test. If Stop on Fail is not selected the sequence continues until a failure occurs in a test where Stop on Fail has been enabled or until the whole sequence has been completed. Once a sequence is complete, it will be binned to the first fail bin (1 thru 12) or if all tests pass, binned into the overall pass bin (14).

When a test sequence is turned on the results of the sequence are shown on the summary screen shown below. Measured values outside of specified limits are highlighted.

Sequence Results				
FAIL		BIN	5	
Test 1	Cs 1.561062 uF	DF	0.0089290	
Test 2	Cs 1.498650 uF	DF	0.0078950	
Test 3	Cs 1.278650 uF	DF	0.0067994	FAIL

Figure 37 Sequence Results

3.8 Parameter Sweep

The 7600 Plus is capable of displaying a **table or plot of measured results vs. a variable of frequency, voltage, or current.**

Sweep can be selected as **Off, On or Edit.** Edit allows sweep test conditions to be changed.




Figure 38 Parameter Sweep

Parameter is the variable test condition of **Frequency, Voltage or Current.**

Sweep Begin is the lower boundary of the sweep table or plot in **units of Hz, Volts or Amps.** The numerical value is entered directly and units selected by UP/DOWN arrow keys.

Sweep End is the upper boundary of the sweep in **units of Hz, Volts or Amps** and entered the same as Sweep Begin.

Sweep Step is the chosen number of increments in a sweep of **25, 50 100 or 200** where values are automatically selected, logarithmically over the specified begin to end range.

Sweep Format is selected to be **Table** as shown in Figure 39 or **Plot** as shown in Figure 40.

The screenshot shows a table titled "Plot Table" with the following data:

Frequency	Cs	DF
1.0000kHz	471.4576nF	0.003135
1.2915kHz	470.4563nF	0.003675
1.6681kHz	469.8878nF	0.003867
2.1544kHz	468.9983nF	0.010035
2.7825kHz	466.4532nF	0.010078
3.5938kHz	462.6634nF	0.011045
4.6415kHz	460.6645nF	0.012895
5.9948kHz	459.7892nF	0.014786
7.7426kHz	458.7845nF	0.016782
10.000kHz	456.5454nF	0.018544

Navigation arrows (up and down) are on the right, and "Prev Page" and "Next Page" buttons are at the bottom right.

Figure 39 Sweep Table

The sweep table lists the measurement results for primary and secondary parameter (unless none is selected) along with the test condition variable of frequency, voltage or current. A table can be comprised of 25, 50, 100 or 200 entries and the UP/DOWN arrow keys or Prev or Next Page used to scroll through the display.

NOTE:

Scroll is not functional when IEEE-488 is enabled.




Figure 40 Sweep Plot

The sweep plot shows the measurement results of the primary parameter (vertical axis) vs. the variable test condition of frequency, voltage or current (horizontal axis). It should be noted that space available on the display **limits the number of graduations and resolution of axis labeling**. The horizontal axis is labeled from the **Sweep Begin to the Sweep End** values as selected by the user with two additional labels in between (chosen logarithmically). The vertical axis is labeled from the **lowest measured value to the highest measured value** with four additional labels in between (chosen linearly).

3.9 Median

Allows for the selection of Median measurement mode to be **On** or **Off**. When selected each measurement will actually be three individual measurements, the **lowest and highest values discarded and the median value displayed**.

Measurement accuracy can be improved as noted below and will be indicated on the AutoAcc display (but never less than 0.05% for primary parameter or 0.0005 for secondary parameter).

With Median set to **On**:

Divide the primary accuracy by the square root of three.

Divide the secondary accuracy by the square root of three.

3.9.1 Distortion Detection

Allows for the selection of Distortion Detection mode to be **On** or **Off**. When set to On, the unit will detect distortion during a measurement and indicates the message "DISTORTION" if this condition occurs. When set to Off, distortion will not be detected during a measurement.

Distortion is dependent on programmed test conditions, connection to the device, device impedance and so indicated when the signal + noise + distortion divided by the signal exceeds 1.2. Distortion set to On is the recommended test condition and is particularly important for high precision measurements where test leads could resonate with the device under test. Distortion may want to be turned to Off in a "noisy" environment.

To ensure that stored setups are backward compatible Distortion On or Off is not saved in setups stored (internally or on USB flash drive). On instrument power down the Distort Detect will be restored to its last previous state.

3.9.2 Load Correction

Load correction allows the user to specify the value of the component under test (user supplied standard) and apply a correction to subsequent measurements of similar components under the same test conditions. This feature corrects for instrument non-linearity and for fixture effects which can be dependent on the test frequency, test voltage level or impedance range.

Measurement accuracy is 0.25 x (normal accuracy) with Load Correction implemented and compared to user supplied standard and for the same measurement conditions. (Same measurement conditions are test voltage, test frequency and 7600 Plus measurement range.)

This increased accuracy applies in a range of:

DUT's with impedance (Z) between 3Ω and 800kΩ, with
 programmed voltage from 100mV to 1V, or from 100mV
 to (programmed current) x (Z) ≤1V.

Load correction can be selected as **Off, On or Edit**. Edit allows the primary and secondary values to be entered, the parameter for these values is defined by the Primary and Secondary Parameter in the main Setup menu. After the nominal values have been entered, if **Measure** is selected for **ON**, the user presses **START** to initiate the correction measurement. While the measurement is being made, **Measuring Correction** will be displayed. After the correction measurement the actual **Measured Primary** and **Secondary** value will be displayed along with the selected **Freq, Range, Primary** and **Secondary** parameter. During the load correction measurement the instrument is automatically placed in the Slow Measurement Accuracy mode.




Figure 41 Load Correction

The Load Correction will only be made for the Frequency, Range, Primary and Secondary Parameter that was selected when the correction was determined. For example; if the correction measurement is made under the conditions of Cs, DF, at 1 MHz and range 49, these are the only conditions under which it will be applied.

3.9.3 Utilities Menu





Figure 42 Utilities Menu

The last of the four main menus is **Utilities**, shown above. Each function is described in detail below.



3.9.4 Save Setup




Figure 43 Save Setup

Allows a set of test conditions to be stored in instrument memory or on USB flash disk for later recall. Test conditions are those that are user programmable in the Setup and I/O menus.

To store the current set of test conditions as a new set in unit memory one needs to select **NEW** in the Save Setup menu and enter the identifying name up to 8 characters under which these conditions will be stored (allowable characters from the keypad include 0 through 9 and minus, characters can also include A through Z when operating from remote control). To save the setup under the name selected or to overwrite if the name already exists one needs to answer Yes or No.




Figure 44 Yes or No

To make the current set of test conditions the default (at power up) one needs to select **DEFAULT** in the Save Setup menu and overwrite the conditions currently stored. To prevent overwriting the default setup by mistake an additional level of safety exists where the operator is required to respond with Yes or No.

Selecting **del** will delete a set of test conditions and requires a Yes or No response.

When there are more setups than can fit on the display the page down key is active. If there is less than a whole page below, the display wraps around to the previous display.

Continuing to page down will eventually return to the first display of setups. The page down key is only shown when there are more setups than what is visible.

There are two ways to make the current set of test conditions overwrite an existing setup, one is to select that setup in the menu and answer Yes to overwrite and the other way is to enter the same name under New and answer Yes to overwrite.

File format for storing test conditions is the same as shown under Results to USB (page 34), all lines shown are saved as setup. The extension of a Setups file is “.c6r”. The setup files are compatible with 7600 Model B. The only difference is the extension. Changing the extension from Model B files to “.c6r” will allow files to be recalled in the 7600 Plus.

3.9.5 Recall Setup




Figure 45 Recall Setup

Allows a previously stored set of test conditions to be recalled from instrument memory. Test conditions are those that are user programmable in the Setup and I/O menus. To recall a set of test conditions one needs to arrow down or up to the desired set. **DEFAULT** is always one of the set of test conditions that can be recalled as discussed in the previous paragraph. Selecting **del** will delete a set of test conditions and requires a Yes or No response.

When there are more setups than can fit on the display the page down key is active. If there is less than a whole page below, the display wraps around to the previous display. Continuing to page down will eventually return to the first display of setups.

3.9.6 Setup Accuracy

Allows user to access the measurement calculation. Calculated accuracy is displayed for the instruments currently selected test conditions, as shown in the example below and **in accordance with the formulas for fast, medium or slow accuracy**. Factors affecting this calculation include frequency, ac test signal level, measurement accuracy and # to average, all test conditions under operator control on the Setup Menu. The selection of Median, on the Analysis Menu, also has an affect on the accuracy calculation.

The Accuracy, Average and Median can be changed on this screen as instructed for the purpose of evaluating their effect on the instrument accuracy calculation and the changes implemented if the operator so chooses. The frequency, AC signal or parameter selection

can only be changed on the Setup menu. **In summary**, this display shows instrument **accuracy for currently selected test conditions** or as a tool so the operator can see **what the accuracy would be** if certain conditions were selected.




Figure 46 Setup Accuracy

The basis for the AutoAcc calculation is based on the formulas below where A% = calculated primary accuracy for C, X, B with $D < 0.1$ and R, L, G with $Q < 0.1$ for optimum signal levels and test conditions.

For C, X, and B, with $D > 0.1$, multiply A% by $\sqrt{1+D^2}$

For R and G, with $Q > 0.1$, multiply A% by $\sqrt{1+Q^2}$

For L, with $Q < 10$, multiply A% by $\sqrt{1 + \frac{1}{Q^2}}$

Multipliers do not apply to 1 MHz Special Case Accuracy

For Fast Mode, R, L, C, X, G, B, |Z|, and |Y|

$$A\% = \pm \left[0.25 + \left(\left(0.25 + \frac{.125}{|Z_m|} + (|Z_m| * 10^{-6}) \right) * \left(\frac{0.2}{V_s} + 0.8 * \frac{V_{fs}}{V_s} + \frac{(V_s - 1)^2}{4} \right) * \left(0.4 + \frac{F_m}{10^4} + \frac{400}{F_m} \right) \right) \right] * K_t$$

For Medium Mode, R, L, C, X, G, B, |Z|, and |Y|

$$A\% = \pm \left[0.125 + \left(\left(0.125 + \frac{.1}{|Z_m|} + (|Z_m| * 10^{-6}) \right) * \left(\frac{0.2}{V_s} + 0.8 * \frac{V_{fs}}{V_s} + \frac{(V_s - 1)^2}{4} \right) * \left(0.4 + \frac{F_m}{3 * 10^4} + \frac{300}{F_m} \right) \right) \right] * K_t$$

For Slow Mode, R, L, C, X, G, B, |Z|, and |Y|

$$A\% = \pm \left[0.025 + \left(\left(0.025 + \frac{.09}{|Z_m|} + (|Z_m| * 10^{-7}) \right) * \left(\frac{0.2}{V_s} + 0.8 * \frac{V_{fs}}{V_s} + \frac{(V_s - 1)^2}{4} \right) * \left(0.7 + \frac{F_m}{10^5} + \frac{300}{F_m} \right) \right) \right] * K_t$$

V_s = Test voltage in voltage mode, $I * Z_m$ in current mode*

Z_m = Impedance of DUT F_m = Test frequency

K_t = 1 for 18° to 28°C, 2 for 8° to 38°C, and for 4 for 5° to 45°C

* For $I * Z_m > 3$, accuracy is not specified

$$V_{FS} = \begin{cases} 5.0 & \text{for } 1.000V < V_S \leq 5.000V \\ 1.0 & \text{for } 0.100V < V_S \leq 1.000V \\ 0.1 & \text{for } 0.020V \leq V_S \leq 0.100V \end{cases}$$

For $Z_m > 4 * Z_{RANGE}$ multiply A% by 2

For $Z_m > 16 * Z_{RANGE}$ multiply A% by 4

For $Z_m > 64 * Z_{RANGE}$ multiply A% by 8

In Voltage Mode

where $100k\Omega$ for $Z_m \geq 25k\Omega$

$Z_{RANGE} = 6k\Omega$ for $1.6k\Omega \leq Z_m < 25k\Omega$

$6k\Omega$ for $Z_m > 25k\Omega$ and $F_m > 25kHz$

400Ω for $100\Omega \leq Z_m < 1.6k\Omega$

400Ω for $Z_m > 1.6k\Omega$ and $F_m > 250kHz$

25Ω for $Z_m < 100\Omega$

In Current Mode

400Ω for $i < 2.5mA$

25Ω for $i > 2.5mA$

NOTE: Calculated Rs accuracy applies only when device under test is primarily reactive

Calculated ESR accuracy applies only when device under test is primarily capacitive

The unit is unspecified for $F_m > 1.0$ MHz and $V_S > 0.5V$ and for $F_m > 500$ kHz and $V_S > 1.0V$

D Accuracy

$$= \left[\frac{A\%}{100} + \frac{|D|}{50} \right] * \left[1 + \sqrt{\frac{F_m}{5 * 10^4}} \right]$$

θ Accuracy

$$= \frac{A\%}{20} * \left(\frac{180}{\pi} \right)$$

Q Accuracy

$$= \frac{A\%}{100} + \left[\frac{A\%}{100} + \frac{1}{50} \right] * |Q| + Q^2 \left[\frac{A_n}{100} + \frac{A\%}{500} \right]$$

ESR Accuracy

$$= \left(\frac{A\%}{100} \right) * Z_m$$

D = DF of unknown Q = Q of unknown

A% = calculated primary accuracy for all cases

1 MHz Special Case Accuracy

(1 MHz, C = 100pF to 1000 pF, Z_m 158 to 1.6k Ω , D or Q < 0.01, voltage mode, $V_S \leq 1V$)

Fast Mode Accuracy

$$A\% = \pm \left[\frac{A_n}{0.05} * \left(.067 * \left(1 + \frac{.2}{V_s} + \frac{V_s^2}{4} \right) \right) * \left(\frac{(2 * V_{FS} - V_s)}{V_{FS}} \right) + (A_n - .05) \right] * K_t$$

A_n = nominal accuracy 0.5.

Medium Mode Accuracy

$$A\% = \pm \left[\frac{A_n}{0.05} * \left(.067 * \left(0.8 + \frac{.2}{V_s} + \frac{V_s^2}{4} \right) \right) * \left(\frac{(2 * V_{FS} - V_s)}{V_{FS}} \right) + (A_n - .05) \right] * K_t$$

A_n = nominal accuracy 0.25.

Slow Mode Accuracy

$$A\% = \pm \left[\frac{A_n}{0.05} * \left(.067 * \left(0.55 + \frac{.2}{V_s} + \frac{V_s^2}{4} \right) \right) * \left(\frac{(2 * V_{FS} - V_s)}{V_{FS}} \right) + (A_n - .05) \right] * K_t$$

A_n = nominal accuracy 0.05.

NOTE:

Accuracy given by the equations is the measurement accuracy relative to calibration standards. Total accuracy equals the relative measurement accuracy plus the calibration uncertainty of the calibration standards.

3.9.7 Open / Short

The zeroing process automatically measures stray parameters and retains the data, which is used to correct measurements so that results represent parameters of the DUT alone without test lead or fixture capacitance. Measurement accuracy is specified at the end of the QuadTech one meter cable (7000-01). Open and short circuit zeroing should be done at the end of this cable. In order to maintain instrument accuracy with other cable lengths the instrument should be re calibrated using the QuadTech 7000-09 Calibration Kit and the alternate cable. Zeroing is recommended at the start of each work day or more often if leads, fixture or test configuration to the DUT is changed. **It is not necessary to re-zero if the test frequency is changed.** It is important to note, that anytime the instrument is zeroed it is done at a test voltage of 1 volt and frequencies of 10, 50, 100Hz, 1, 5, 10, 25, 50, 100, 250, 500, 750kHz, 1, 1.25, 1.5, 1.75 and 2MHz. Once Open/Short is selected in the menu and Enter key pressed the operator is prompted by instructions on the display for short or open zeroing as shown in Figure 47 below. When zeroing, **Contact Check should be OFF, # to Average to 1 and Median OFF.**

When the instrument measurement accuracy is selected for **SLOW** the unit will perform its Open/Short in this mode. When the instrument accuracy is selected for **MEDIUM** or **FAST** the unit will perform its Open/Short in the Medium mode. The Open/Short performed in the Slow mode is necessary only for measurements with extreme accuracy

requirements at very high or low impedance. Open/Short takes about 5 minutes in the Medium mode versus about 15 minutes in the Slow mode.

When **Quick Open & Short** is selected the zeroing process is performed as prompted on the display, in much less time and **only at the frequency currently selected** on the instrument. It is important to note that the quick open and short data is no longer valid if frequency is changed, if sweep or sequence is selected or instrument powered down.




Figure 47 Open / Short

3.9.8 Lock Out




Figure 48 Lockout

Allows user to turn keypad lock feature on or off. There are two choices that can be selected, **lockout only** and **lockout with setup recall**. In both modes only the START, STOP and MENU on the instrument front panel are active, all other keys disabled. The difference is that in **lockout with setup recall** the menu key also allows setups to be recalled from instrument memory.

When either is selected the operator must enter a password number up to 8 characters.

CAUTION

For security reasons, the password is not displayed when it is entered, so the password should be keyed in distinctly and remembered. Failure to remember an entered password requires the factory override, 760001

ENTER PASSWORD
(8 CHARACTERS MAXIMUM, default 760001)

* * * * *

Once the password is entered and entered again for verification, testing can begin by pressing START or the password cleared or changed by selecting MENU.

HIT <MENU> KEY TO ENTER PASSWORD

AND TO RETURN TO THE MENU

OR

HIT THE <START> KEY TO

START A MEASUREMENT

Once activated, only the START, STOP and MENU on the instrument front panel are active, all other keys are disabled. To turn the lockout feature off and reactivate menus select MENU (select Exit Lockout in Lockout with Setup Recall mode) and enter the previous password from the keypad, the instrument will again function as normal.

If Recall Setups is chosen in the Lockout with Setup Recall mode, the instrument functions as described in paragraph 2.6.5.2 under Recall Setup.

3.9.9 Calibration

Refer to Calibration on page 95. **INSTRUMENT CALIBRATION SHOULD ONLY BE PERFORMED BY QUALIFIED SERVICE PERSONNEL.**

3.9.10 Set Time/Date




Figure 49 Set Time / Date

Allows resetting of time and date into unit memory. This is used as the basis for the elapsed time counter and stored calibration date.

T (time) is entered in

HOURS (up to 2 digits, 0 through 23)

MINUTES (up to 2 digits, 0 through 59)

SECONDS (up to 2 digits, 0 through 59)

D (date) is entered in

MONTHS (up to 2 digits, 1 through 12)

DAYS (up to 2 digits, 1 through 31)

YEARS (4 digits, 1992 through 2037)

3.9.11 Usage/Cal Date




Figure 50 Usage / Cal Date

When selected, indicates the total elapsed time in hours that the unit has been powered up and the date of last calibration. The elapsed time is from the moment of initial use and may show some time when shipped from the factory. The calibration date is retained in instrument memory until the unit is re calibrated and then it is updated. When **cal data** is selected, the calibrated values are shown as entered from the Report of Calibration provided with the 7000-09 Calibration Kit previously used.

3.9.12 Set Contrast




Figure 51 Set Contrast

Allows adjustment of contrast on the LCD display. Use Up arrow to increase contrast or Down arrow to decrease. When the instrument is powered up it returns to the last set contrast, not some nominal level.

3.9.13 Self Test

When selected, runs a group of internal self tests to verify that calibration and open/short data are not corrupt.

3.9.14 LCD Backlite

Allows the backlite on the LCD display to be **Save** or **On**. When set to Save the backlite turns off automatically if no keypad has been hit for 5 minutes and turns back on with the touch of START, MENU or ENTER keys. When set to On the backlite is constantly on. The Save mode will prolong the life of the display.


3.10 Input/Output Interface

The 7600 Plus comes standard with an automatic component handler I/O interface port available through a 36 pin Centronics type connector located on the rear panel of the instrument. This port outputs signals to indicate measurement in process, measurement completed, and bin sorting judgments. The Handler Interface also has inputs for an external trigger signal and a safety interlock signal. All output lines are negative true, optically isolated, open collector. Pull-up resistors to allow operation from +5V to +24V logic must be implemented externally. Inputs are optically isolated, and can be current driven from either positive or negative true logic. Current limiting resistors to allow operation from +5V to +24V logic must be implemented externally.

Refer to Table 1 for signal names, pin numbers and functions as necessary for cable connections.

Table 1 I/O Interface Connections

Signal Name	Pin Number	Function
-Bin1	1	Bin Sorting Results (Bin1-Bin10)
-Bin2	19	All signals active low, open collector
-Bin3	2	
-Bin4	20	
-Bin5	3	
-Bin6	21	
-Bin7	4	
-Bin8	22	
-Bin9	6	
-Bin10	24	
-Bin11	7	Primary parameter pass, secondary fail low
-Bin12	25	Primary parameter pass, secondary fail high
-Bin13	8	Primary parameter fail, secondary pass
-Bin14	26	Primary parameter fail, secondary fail
-Bin15	9	No Contact
-Bin16	27	Unused
-EOT data valid.	29	End of Test, test completed; bin and measurement
-BUSY	30	Measurement/comparison in progress
TRIG+	14	Trigger high input
TRIG-	16	Trigger low input
START+	34	Isolated Trigger high input
START-	35	Isolated Trigger low input source
GND	11, 15, 33	System common
IGND	5, 10, 23, 28	Isolated common
+5V	12, 32	System +5V through 100 Ω
INT+	13	Interlock high input from external source
HTC	31	Handler timing control



Pin Configuration (Viewed from Rear Panel)

CAUTION

Do not apply an external source in excess of 5 volts with jumpers JP2401, JP2402, or JP2403 in place, otherwise the instrument can be damaged. The instrument is shipped with these jumpers in place and must be removed for optical isolation. These jumpers are discussed below.

The operation of START and TRIG circuits is identical. Both inputs are active low, for optical isolation they require a positive +5 to +24V external source and current limiting resistor to operate. START is always optically isolated. TRIG can be converted to a *isolated active low input* by removing jumper JP2402 on the I/O PCB. Both signals are open collector OR'ed on the I/O PCB; current flowing through the isolator input on either signal causes a single Start line to be pulled low.

The INTERlock signal can be optically isolated, and also requires a positive +5 to +24V external source and current limiting resistor to operate. This signal can be converted to a *isolated active low input* by removing jumper JP2403 on the I/O PCB. Current flowing through the isolator input causes the internal Interlock line to be driven low.

All bin and control outputs can be active low optically isolated open - collector drivers that pull each signal line to IGND (isolated common) when asserted. All outputs require a positive +5 to +24V external source (referenced to IGND) and pull-up resistor to operate as fully isolated signals. IGND can be isolated from system GND by removing jumper JP2401 on the I/O PCB. With jumper JP2401 in place, optical isolation is defeated, which allows the outputs to be pulled up to the system +5V with external resistors.




Figure 52 I/O Interface Timing

Test Initiation

- A test is initiated by activating either the START± or TRIG± inputs.
- The BUSY line is asserted low to indicate that a measurement is in progress.
- The EOT line is de-activated (asserted high) to indicate that the end of the test had not been reached
- Binning data from the previous test is still valid.

During a Test

- The START± or TRIG± inputs are released and return to their inactive state.
- The BUSY line is held low to indicate the 7600 Plus is making a measurement.
- The EOT line is held high (inactive) until the 7600 Plus is done making a measurement and bin data is valid.

End of Test

- The BUSY line is returned to high impedance (de-activated) to indicate that the 7600 Plus is done making a measurement and to signal the automatic component handler to advance the DUT to the binning station and insert the next DUT.
- Simultaneously, the EOT line is asserted low to indicate that the test is completed, bin data lines and measurement data are valid and can be read from the IEEE or RS-232 ports. Data must be valid a minimum of 10us before the trailing edge of BUSY and EOT.
- All data for the current test is valid, and will remain valid until the end of the next test. This includes comparator bins 1-10, primary and secondary parameter bins 11-15, and analog measurement data.

Electrical Characteristics

Inputs: START±, TRIG±

<u>Condition</u>	<u>Input Current</u>	<u>Input Voltage</u>
Active High		
Signal+ current driven, Signal- @ IGND	5 - 50 mA	5 - 24V
Active Low		
Signal-current driven, Signal+ @ V+(ext)	5 - 50 mA	5 - 24V

Outputs: -Bin1 -Bin16, -EOT, -BUSY

<u>Condition</u>	<u>Sink Current</u>	<u>Output Voltage</u>
		<i>Low</i> <i>High</i>
Binning signals	200 mA max (150mW)	≤ 0.5V 5 – 40V
Control signals	200 mA max (150mW)	≤ 0.5V 5 – 40V




Figure 53 I/O Interface Isolation

The outputs are optically isolated for added interfacing flexibility and to increase reliability by reducing noise pickup and ground loop interference. The optocouplers use open collectors, and can sink up to 200mA of current provided by an external source at up to 40V. No provisions for pull-up resistors are provided on - board. The isolated ground return can be floated, or connected to the 7600 Plus system ground for use with isolated handlers. The isolators are driven by inverting high current buffers.

All inputs are also optically isolated. Both anode and cathode of the input opto-isolators are available in the handler interface connector. Active high inputs can be achieved by grounding the cathode ("-" signal) and driving the anode ("+" signal), while connecting the anode to the external supply and sinking current through the cathode will result in active low drive. No provisions for current limiting resistors are provided on - board. All inputs are reverse bias protected; max. 5V reverse voltage, 50mA (60mW).

3.11 Parallel Interface

The 7600 Plus comes standard with a parallel printer port available through a connector (25 pin) on the rear panel of the instrument. This is a standard PC compatible interface for connection to a printer. Refer to Table 2 for signal names, pin numbers as necessary for cable connections.

Table 2 Parallel Interface Connections

Signal Name	Pin Number	Function
Outputs:		
-STROBE	1	Indicates that data is ready to read
0	2	Data bit 1
D1	3	Data bit 2
D2	4	Data bit 3
D3	5	Data bit 4
D4	6	Data bit 5
D5	7	Data bit 6
D6	8	Data bit 7
D7	9	Data bit 8
-AUTOFD	14	Auto paper feed
-INIT	16	Initializes printer
-SLCT IN	17	Selects printer
GROUND	18 - 25	Signal ground

Inputs:

-ACK	10	Indicates that data has been received and printer is ready to accept more data
BUSY	11	Indicates that printer can not receive data
PE	12	Indicates that printer is out of paper
SLCT	13	Indicates that printer is ready to receive data
-ERROR	15	Indicates printer error



Pin Configuration (Viewed from Rear Panel)

3.12 IEEE-488.2 Interface Optional

The 7600 Plus has an optional IEEE-488 interface with connection through a connector (24 pin) on the rear panel. This interface can be used to connect to a system containing a number of instruments and a controller in which each meets IEEE Standard 488.2 (Standard Digital Interface for Programmable Instrumentation). Refer to Table 3 for the command set.

The following functions have been implemented. Refer to the standard for an explanation of the function subsets, represented by the identifications below.

SH1	Source Handshake	PP1	Parallel Poll
AH1	Acceptor Handshake	DC1	Device Clear
T5	Talker	DT1	Device Trigger
L3	Listener	C0	Controller
SR1	Service Request	E2	Electrical Interface
RL1	Remote Local		

Table 3 IEEE & RS-232 Commands

Command	Function	Parameter(s)
<u>CONFigure:</u>		
FREQuency	Set the frequency from 10 to 2000000 Hz	0000000.00
PPARAmeter	Set the primary parameter	A(auto) CS CP LS LP RP RS DF Q Z Y P(phase angle) ESR GP XS BP
SPARAmeter	Set the secondary parameter	N(none) CS CP LS LP RP RS DF Q Z Y P(phase angle) ESR GP XS BP
ACTYpe	Set the AC test signal type to This command should be set prior to setting the ACValue.	V I
ACValue	Set the AC signal to value	0.0
BIAS	Set the bias to	INT EXT or OFF
RANGe	Set the range	AUTO or HOLD or #(1-59)
MACcuracy	Set the measurement accuracy	SLOW MEDIUM FAST
TDELay	Set the measurement delay	#####
AVERAge	Set # to average	###
MEDian	Set the median function to ON or OFF	ON OFF
DISTortion	Set distortion detection to ON or OFF	ON OFF
CChEck	Set the contact check to ON or OFF	ON OFF
DISPlay type	Set display type to	M (Measured Parameter)

		D (Deviation from Nominal)
		% (% Deviation from Nominal)
		B (Bin Number)
		S (Bin Summary)
		P (Pass/Fail)
		N (No Display)
TRIGger	Set the trigger to	INTernal EXTernal
NOMinal	Set the nominal value (for deviation or % deviation)	floating point #

CONFigure:**BINNING:****bin#**

ABS*	Set the low & high limit for the bin	low high (floating point #'s)
TOL	Set the % below, % above and nominal value	% below % above nominal (3 floating point #'s w/space between)
SECondary	Set the secondary low & high limit	low high (floating point #'s)
TRESet	Reset the bin totals to zero	
SUMMary?	Retrieve the bin summary data	
FRESult	Set the result format to	SCientific ENGineering
HANDler (state)	Turn handler port OFF or ON	ON OFF
RPRint	Turn print results ON or OFF	ON OFF
RUSBppy:	Results to USB	
DUPLicate	Save results as duplicate filename on flash drive	xxxxxxx
NEW	Save results as new filename on flash drive	xxxxxxx
APPend	Append results to existing filename	xxxxxxx
CLOSE	Close results of filename	xxxxxxx

SWEep:

PARAmeter	The parameter to sweep	F (frequency) V (voltage) I (current)
BEGIn	The beginning value	floating point number
END	The ending value	floating point number
STEP	The step to increment during the sweep	10 25 50 100 200
RDISplay	The result display for the sweep	T (table) P (plot)
SWEep	Set the sweep function to ON or OFF	ON OFF
VALid?	Is filename valid to save to battery backed up RAM? * Example CONF: BINN: BIN1: ABS 100 300	

CONFigure:**SAVe:**

DUPLicate xxxxxxx	Save setup as duplicate filename in battery backed up RAM	
NEW	Save setup as new filename in battery backed up RAM	
RECall filename	Recall setup filename from battery backed up RAM	
FVALid?	Is filename valid to save to flash drive?	xxxxxxx

FSAVe:

DUPLicate	Save setup as duplicate filename on flash drive	xxxxxxx
NEW	Save setup as new filename on flash drive	xxxxxxx
FRECall filename	Recall setup filename from flash drive	xxxxxxx
RVALid?	Is results filename valid?	xxxxxxx

SEQuence:

SEQuence	Set the sequence function to ON or OFF	ON OFF
TEST	Enable or Disable a test	test #(1-6) and ENable DISable
FREQuency	Set the frequency from 10 to 2000000 HZ	test # and #####.##
PPARAmeter	Set the primary parameter	test # and A(auto) RS RP LS LP CS CP DF Q Z Y P(phase angle) ESR GP XS BP

SPARAmeter	Set the secondary parameter	test # and N(none) RS RP LS LP CS CP DF Q Z Y P(phase angle)ESR GP XS BP
ACTYpe	Set the AC test signal type to (This command should be set prior to setting the ACValue)	test # and V I
ACVAlue	Set the AC signal to value	test # and 0.0
BIAS	Set the bias to	test # and INT EXT or OFF
RANGe	Set the range	test # and ON OFF
TDELay	Set the measurement delay	test # and #####
STOP	Stop on fail	test # and ON OFF

LOAD correction:

NOMInals	Set primary & secondary nominal values	primary secondary (floating point #'s)
MEASURE	Perform the Correction Measurement and set Load Correction to On	
ON	Set Load Correction to ON (valid only if a Correction Measurement has previously been made	
OFF	Set Load Correction to Off	

SYSTEM:

TIME	Set the time to hours, minutes	hh:mm
DATE	Set the date to month, day, year	mm/dd/yyyy
LOCKout state	Set the front panel lockout off or on	ON OFF
ELAPsed?	Query the elapsed time the machine has run	
DCALibration?	Query the calibration date	
BLCD	Turn lcd backlite ON or set to screen save	ON SAVE

Caution: Setting the remote LOCKout state with certain screens displayed on the unit can prevent one from entering or exiting lockout.

CALibrate:

DATA?	Returns the calibration data to the user
QUICKos	Perform quick open calibration

IEEE wait for SRQ OPC to indicate continue

Send Any command if desired to implement
 Send Fetch? This will continue calibration
 Receive Connect the Open Circuit. Ensure that the open is connected to the instrument
 Send CONTINUE
 Wait for SRQ OPC (operation complete, IEEE only)

Perform quick short calibration

Send Any command if desired to implement
 Send Fetch? This will continue calibration
 Receive Connect the Short Circuit. Ensure that the short is connected to the instrument
 Send CONTINUE
 Receive Complete (for RS232 only)
 Wait for SRQ OPC (operation complete, IEEE only)

SHORT

Perform short circuit calibration

The procedure for performing a remote short is as follows:

IEEE wait for SRQ OPC to indicate continue

Send Any command if desired to implement
 Send Fetch? This will continue calibration
 Receive Connect the Short Circuit. Ensure that the short is connected to the instrument
 Send CONTINUE
 Receive Complete (for RS232 only)
 Wait for SRQ OPC (operation complete, IEEE only)

OPEN

Perform open circuit calibration

The procedure for performing a remote open is as follows:

IEEE wait for SRQ OPC to indicate continue

Send Any command if desired to implement
 Send Fetch? This will continue calibration
 Receive Connect the Open Circuit. Ensure that the open is connected to the instrument
 Send CONTINUE

Receive Complete (for RS232 only)

Wait for SRQ OPC (operation complete, IEEE only)

FULL Perform full calibration

The procedure for performing full calibration is as follows:

IEEE wait for SRQ OPC to indicate continue

Send Any command if desired to implement

Send Fetch? This will continue calibration

Receive Connect the 374 Ω Standard. Ensure that the standard is connected to the instrument

Send CONTINUE

IEEE wait for SRQ OPC to indicate gain cal is done

Send Any command if desired to implement

Send Fetch? This will continue calibration

Receive Connect the open circuit. Ensure that the open is connected to the instrument

Send CONTINUE

IEEE wait for SRQ OPC to indicate open circuit cal is done

Send Any command if desired to implement

Send Fetch? This will continue calibration

Receive Connect the short circuit. Ensure that the standard is connected to the instrument

Send CONTINUE

IEEE wait for SRQ OPC to indicate short circuit cal is done

Send Any command if desired to implement

Send Fetch? This will continue calibration for the

next 4 standards

Receive Connect the standard. Ensure that the standard is connected to the instrument

Send CONTINUE

Send Any command if desired to implement

Send Fetch? This will continue calibration

Receive	Get prompt for Rnom and Qnom values at 1 kHz
IEEE wait for SRQ OPC to indicate current standard cal is done	
Send	Any command if desired to implement
Send	Fetch?
Receive	Get prompt for Rnom and Qnom values at 1 MHz or 50 kHz
IEEE wait for SRQ OPC to indicate range cal is done	
Send	Any command if desired to implement
Send	Fetch?

after last standard

IEEE wait for SRQ OPC
RS232 wait for Complete

MEASure

Triggers a measurement of the selected type. If sequence or sweep is enabled this command will trigger those type of measurements also. The result type is set by the display type parameter.

FETCh?

Fetches the most recent measurement results. The character sequence formats are as follows:

Normal Measurements:

<primary result name> <tab> <primary result> <tab> <units> <secondary result name>
<secondary result> <tab> <units> <tab> <bin or tab> <tab> <#> <tab> <pass string or fail string or tab> <tab> <retest or tab> terminated by a linefeed.

The secondary parameter will be blank when the parameter is set to NONE.

Sweep Measurement:

If sweep is enabled, fetch will give all of the results based on the number of steps selected with the normal measurement format.

FETCh?

Sequence Measurement:

If sequence is enabled, results will be sent for each test enabled.

1st line: <pass/fail bin> <tab> <#> ,

additional lines for tests enabled: <test> <tab> <#> <tab> <primary result> <tab> <units>
<tab> <secondary results> <tab> <units> <tab> <fail or tab> , .last line for tests enabled:

<test> <tab> <#> <tab> <primary result> <tab> <units> <tab> <secondary results> <tab> <units> <tab> <fail or tab> terminated by a linefeed.

Bin Summary Measurement:

Bins 1 - 10

<bin> <tab> <#> <tab> <low limit> <tab> <# or tab> <tab> <high limit> <tab> <# or tab> <tab> <total> <tab> <#> terminated by a linefeed.

Bins 11 - 15

<bin> <tab> <#> <tab> <bin description> <tab> <total> <tab> <#> terminated by a linefeed.

Last Line

<totals:> <tab> <pass> <tab> <#> <tab> <fail> <tab> <#> <tab> <#> <tab> <total> terminated by a linefeed.

LOADFetCh?

Returns load correction status Valid, measured primary & secondary values

or

Invalid

***IDN?**

Returns instrument identification "QuadTech,7600Plus,xx...xx,software version".

***ESR?**

x denotes serial number up to 10 digits

Returns the read of the event status register.

***STB?**

Returns the read of the status byte register.

***ESE?**

Returns the read of the event status enable register.

***SRE?**

Returns the read of the service request enable register.

***ESE**

Set the event status enable register value

***SRE**

Set the service request enable register value

***RST**

Reset the buffer

***TST?**

Self test query

***CLS**

Clear standard event status register

Note: Remote command can start with or without * symbol for compatibility.

3.13 Formats

IEEE 488.2 enables remote programming of all instrument functions, measurement conditions and comparator settings etc. Outputs include measurement conditions, open/short corrections, and measured values.

Data Formats

Data will be transmitted in ASCII NR3 format per IEEE488.2 sec. 8.7.4 and reproduced below. Note that there is always precisely one digit before the decimal point, and precisely three digits in the exponent.

Multiple results

For the case where a measurement produces multiple results (e.g. MEASure Cs, and DF), the individual numbers will be separated by commas per IEEE488.2 para. 8.4.2.2.

Sequences of Test (Sequence Mode) will be treated as a single Message Unit, with results separated by commas. If a particular test has “None” selected as a secondary parameter, no place will be reserved for the null result. As an example, a sequence of three tests asking for C/D, ESR, and Z/φ would appear as follows:

<data>,<data>,<data>,<data>,<data><NL>

All response messages will be terminated by the NL character together with the EOI line asserted.

Status Byte Register

<u>Bit</u>	<u>Decimal Value</u>	<u>Use</u>
7	128	None
6	64	SRQ, SPOL Resets
5	32	Summary of Standard Event Status Register*
4	16	Message Available
3	8	None
2	4	None
1	2	None
0	1	None

*The Status Byte Register is readable via the standard STB? as defined in para. 11.2.2.2 of the IEEE spec. The 7600 Plus will also implement an SRE register to enable each bit of the Status Byte Register per para 11.3.2 of the IEEE spec. This register shall be readable by a SRE? command and writable by a SRE <#> command.

Standard Event Status Register

<u>Bit</u>	<u>Decimal Value</u>	<u>Use</u>
7	128	Power Up Since Last Query

6	64	None
5	32	Command Error (Syntax)
4	16	Execution Error (Over Range, etc.)
3	8	No Contact
2	4	Query Error
1	2	None
0	1	Operation Complete

This register is read by executing an "ESR?" command, page 75 (except no *). Note that this is a destructive read. Reading the register clears it. Each bit of the Event register must be enabled in order to cause the ESB bit of the Status Register to be set. This enabling is done in the Standard Event Status Enable Register by issuing an ESE command.

3.13.1 Sample Program for National Instruments GPIB card

```
260 '*SAMPLE 7600 Plus BASIC PROGRAM FOR NATIONAL INSTRUMENTS
IEEE **
```

```
' Merge National DECL.BAS here
```

```
270 ADAP$="GPIB0" : DEV4$="Dev4": R$ = SPACES$(60)
```

```
280 CALL IBFIND (DEV4$,DEV4%)
```

```
290 CLS '***** SET CONDITIONS, MEASURE, AND DISPLAY DATA
*****
```

```
300 SET$="CONF:REC DEFAULT" : CALL IBWRT (DEV4%,SET$)
```

```
310 SET$="CONF:FREQ 1000.00" : CALL IBWRT (DEV4%,SET$)
```

```
320 SET$="CONF:PPAR CS" : CALL IBWRT (DEV4%,SET$)
```

```
330 SET$="CONF:SPAR DF" : CALL IBWRT (DEV4%,SET$)
```

```
340 SET$="CONF:MAC ENH" : CALL IBWRT (DEV4%,SET$)
```

```
350 SET$="CONF:NOM 0" : CALL IBWRT (DEV4%,SET$)
```

```
360 SET$="CONF:DISP M" : CALL IBWRT (DEV4%,SET$)
```

```
370 SET$="MEAS:" : CALL IBWRT (DEV4%,SET$)
```

```
380 FOR I = 1 TO 5000 : NEXT I
```

```
390 SET$="FETC?" : CALL IBWRT (DEV4%,SET$)
```

```
400 CALL IBRD (DEV4%,R$) : PRINT R$
```

```
410 CALL IBLOC (DEV4%)
```

```
420 END
```

3.13.2 RS232 Interface

The 7600 Plus comes standard with an RS232 serial port interface, available through a connector (9 pin) on the rear panel of the instrument, for connecting to a PC. The RS232 standard defines electrical specifications for the transmission of bit serial information. The use of the RS232 port requires five lines, receive data, transmit data, data terminal ready, data set ready and signal ground. With some controllers additional signals maybe required and are listed in Table 4 below. Refer to Figure 54 for null modem cable configuration to the standard db9 or db25 connector. Refer to Table 3 for the command set.

Table 4 RS232 Interface Connections

Signal Name	Pin Number	Function
Inputs:		
DCD	1	Data Carrier Detect
DSR	6	Data Set Ready
RXD	2	Receive Data
CTS	8	Clear to Send
RI	9	Ring Indicator
Outputs:		
RTS	7	Request to Send
TXD	3	Transmit Data
DTR	4	Data Terminal Ready
GND	5	Signal Ground

7600 Plus			Controller	
Pin #	Function		Pin #	Function
2	Receive data	Connect to	3	Transmit data
3	Transmit data		2	Receive data
4	Data terminal ready		6	Data set ready
5	Signal ground		5	Signal ground
6	Data set ready		4	Data terminal ready

db9 to db9 Cable Configuration

7600 Plus			Controller	
Pin #	Function		Pin #	Function
2	Receive data	Connect to	2	Transmit data
3	Transmit data		3	Receive data
4	Data terminal ready		6	Data set ready
5	Signal ground		7	Signal ground
6	Data set ready		20	Data terminal ready

db9 to db25 Cable Configuration

Figure 54 RS-232 Cable Configurations**3.13.3 Results to Printer**

The 7600 Plus can be setup to output to an RS-232 or IEEE printer.

RS-232 RS-232 must be selected on I/O Menu and format set IEEE must also be selected for Talk mode and Disable state.

IEEE IEEE must be selected on I/O Menu and set for Address, Talk mode and Enable state.

3.14 Operation with Accessories

A wide selection of accessories such as test leads, cables and fixtures are available from QuadTech to enhance the operation of the 7600 Plus Precision LCR Meter.

NOTE:

Instrument accuracy can be reduced from nominal specifications when using some 7000 accessory fixtures and cables. Best accuracy requires geometric consistency between that utilized during open/short zeroing and that utilized on fixtures and cables during the actual measurement process. This consistency may be especially difficult to achieve when using unshielded Kelvin clip and tweezer type connections.

3.14.1 Rack Mount Kit (7000-00)

The 7000-00 Rack Mount Kit is used to install the 7600 Plus in a rack mount configuration. The main components of the kit include front handles, front angle brackets, rear vertical trim pieces and rear support brackets. Assembly instructions (QuadTech Form # 150077) are provided with the kit.

3.14.2 BNC Cable Set, 1 Meter (7000-01), 2 Meter (7000-02)

The 7000-01 and 7000-02 are BNC to BNC cable sets used for connecting fixtures, component handlers or other measurement devices to the measurement terminals of the 7600 Plus. The only difference between the two is that the 7000-01 cable is 1 meter in length and the 7000-02 is 2 meters in length.




Figure 55 BNC Cable Sets

Connection to 7600 Plus:

<u>Connect to 7600 Plus</u>	<u>Cable Marking/Color</u>	<u>Connection to DUT</u>
PH (potential, high)	PH (Red/white)	Positive (+) terminal of DUT
IH (current, high)	IH (Red)	Positive (+) terminal of DUT
PL (potential, low)	PL (Black/white)	Negative (-) terminal of DUT
IL (current, low)	IL (Black)	Negative (-) terminal of DUT

Note: H and L denote polarity of AC test signal at 7600 Plus measurement terminals as well as the + and - polarity of DC bias voltage when applied.

3.14.3 Kelvin Clip Leads (7000-03)

The 7000-03 Kelvin Clip Leads provide a means for easily making four-terminal connections to passive sensors and components when they are tested by the 7600 Plus. This cable is especially useful for testing low-impedance devices that have large or non-standard terminations, devices such as electrolytic capacitors and inductors.




Figure 56 Kelvin Clip Leads

For this accessory an additional accuracy (for parameters listed) must be added to the standard instrument accuracy as defined by AutoAcc.

C: $\pm 1.5 \text{ pF}$ R: $\pm 10 \text{ m}\Omega$ L: $\pm 100 \text{ nH}$

Q: for $R > 100 \Omega$, $\pm 9 * \text{Freq} * R * 10^{-12} \text{ ppm}$

for $R < 100 \Omega$, $\pm (R/\text{Freq}) * 10^{-6} \text{ ppm}$

Measurement accuracy is very sensitive to connection geometry. The same connection geometry must be used for open/short compensation as for connection to the device under test.

Connection to 7600 Plus:

Connection to the 7600 Plus is made through four shielded cables with BNC connectors that mate directly with the measurement terminals of the 7600 Plus. The cables are color coded to facilitate proper connections as detailed below.

<u>Connect to 7600 Plus</u>	<u>Cable Marking/Color</u>	<u>Connection to DUT</u>
PH (potential, high)	PH (Red/white)	Positive (+) terminal of DUT
IH (current, high)	IH (Red)	Positive (+) terminal of DUT
PL (potential, low)	PL (Black/white)	Negative (-) terminal of DUT
IL (current, low)	IL (Black)	Negative (-) terminal of DUT

NOTE:

H and L denote polarity of AC test signal at 7600 Plus measurement terminals as well as the + and - polarity of DC bias voltage when applied

Open/Short Zeroing:

When these Kelvin Test Leads are used, an open/short-circuit "zeroing" procedure should be done (page 10) to correct for residual resistance and inductance. The following diagram shows how to connect the clips for the short-circuit "zero."




Figure 57 Kelvin Test Leads Open/Short Zeroing

3.14.4 Alligator Clip Leads (7000-04)

The 7000-04 Alligator Clip Leads is generally used to connect to devices that are multi-terminal, physically large or otherwise unsuited for one of the remote test fixtures. The lead set consists of a BNC to BNC cable, four banana plug adapters and four alligator clips. One of the banana plug adapters is supplied with a pigtail for connecting a "guard" if necessary.




Figure 58 Alligator Clip Leads

For this accessory an additional accuracy (for parameters listed) must be added to the standard instrument accuracy as defined by AutoAcc.

C: ± 1.0 pF R: ± (10 mΩ + R/5 * 10⁶)

Q: ± 50 ppm

for R > 100 Ω, ± 4 * Freq * R * 10⁻¹³ ppm

Measurement accuracy is very sensitive to connection geometry. The same connection geometry must be used for open/short compensation as for connection to the device under test.

Connection to 7600 Plus:


<u>Connect to 7600 Plus</u>	<u>Cable Marking/Color</u>	<u>Connection to DUT</u>
PH (potential, high)	PH (Red/white)	Positive (+) terminal of DUT
IH (current, high)	IH (Red)	Positive (+) terminal of DUT
PL (potential, low)	PL (Black/white)	Negative (-) terminal of DUT
IL (current, low)	IL (Black)	Negative (-) terminal of DUT
		Guard of DUT

NOTE:

H and L denote polarity of AC test signal at 7600 Plus measurement terminals as well as the + and - polarity of DC bias voltage when applied

3.14.5 Chip Component Tweezers (7000-05)

The 7000-05 Chip Component Tweezers can handle small unlead "chips" or SMDs (surface mounted devices), passive sensors, and components for testing on the 7600 Plus. A four-terminal Kelvin connection extends to the tip of the tweezers where the measurement becomes two-terminal, therefore series impedance of the connecting cables and internal tweezer connections do not affect the measurement. The small amounts of residual-tip resistance and inductance can be automatically corrected by using the 7600 Plus shorting function with the tips pressed together. Guard shields between the tweezer blades minimize capacitance between them. A correction for this small capacitance can be made using the 7600 Plus open circuit test with the tips held at a spacing equal to that of the component's contact spacing.

**Figure 59 Chip Component Tweezers**

For this accessory an additional accuracy (for parameters listed) must be added to the standard instrument accuracy as defined by AutoAcc.

C: ± 1.5 pF R: ± 10 m Ω L: ± 100 nH

Q: for $R > 100 \Omega$, $\pm 9 * \text{Freq} * R * 10^{-12}$ ppm

for $R < 100 \Omega$, $\pm (R/\text{Freq}) * 10^{-6}$ ppm

Measurement accuracy is very sensitive to connection geometry. The same connection geometry must be used for open/short compensation as for connection to the device under test.

Connection to 7600 Plus:

<u>Connect to 7600 Plus</u>	<u>Cable Marking</u>	<u>Connection to DUT</u>
PH (potential, high)	PH (Rd/Wh) or HS	+ to positive (+) terminal of DUT
IH (current, high)	IH (Rd) or HD	+ to positive (+) terminal of DUT
PL (potential, low)	PL (Bk/Wh) or LS	- to negative (-) terminal of DUT

IL (current, low) IL (Bk) or LD - to negative (-) terminal of DUT

The PH (HS) and IH (HD) cables connect to the fixed arm of the tweezers (+) and the PL (LS) and IL (LD) cables connect to the movable arm of the tweezers (-). To ensure valid measurements it is especially important to observe the correct polarity when DC bias is to be used.

3.14.6 Low V, Axial/Radial Lead Component Test Fixture (7000-06)

The 7000-06 Test Fixture, along with the BNC to BNC cable provided, is a method of convenient, reliable, guarded 4-terminal connection of radial and axial leaded sensors and components to the 7600 Plus. The 7000-06 consists of the test fixture and two axial lead adapters.




Figure 60 Low V, Axial and Radial Lead Component Test Fixture

For this accessory an additional accuracy must be added to the standard instrument accuracy as defined by AutoAcc.

For 1 MHz Special Case Accuracy

Primary readings: $\pm 0.06\%$

Secondary readings: ± 600 ppm

Connection to 7600 Plus (using 7000-01 or 7000-02 BNC Cable Sets):

<u>Connect to 7600 Plus</u>	<u>Cable Marking/Color</u>	<u>Connect to Test Fixture</u>
PH (potential, high)	PH (Red/white)	PH
IH (current, high)	IH (Red)	I H
PL (potential, low)	PL (Black/white)	PL
IL (current, low)	IL (Black)	IL

If the device under test (DUT) is a radial lead component it can be inserted directly into the fixture slots. The slots accommodate wires with diameters from 0.25 mm to 1 mm (AWG 30 to AWG 18 wire). If the DUT is an axial-lead component the two axial lead adapters should be installed in the fixture (by pushing vertically downward) and the component installed in them. These adapters accommodate wire with diameters up to 1.5 mm (AWG 15 wire). When removing, lift with a gentle tilt left or right, **never forward or back.**

3.14.7 Open/Short Zeroing:

Instrument zeroing should be performed once the test fixture is connected. For an open, a lead should be inserted in the + slot and another lead in the - slot to ensure good contact between the wiper blades, and for a short the + and - contacts should be shorted together with bus wire, the larger the better, but in accordance with wire sizes discussed above. It should be noted that if measurements are to be made on the very lowest range (20 mΩ full scale), readings could be in error, although small, by the resistance value of the short itself. The approximate value of the shorting wire can be determined by zeroing the instrument using the standard 4-terminal Kelvin clips and then measuring the resistance of the shorting wire.

3.14.8 Low V, Chip Component Test Fixture (7000-07)

The 7000-07 Test Fixture, along with the BNC to BNC cable provided, is a method of convenient, reliable, guarded 4-terminal connection of chip or surface mount sensors and components.




Figure 61 Low V Chip Component Test Fixture

Maximum Frequency:

2 MHz

Typical Residual Parameters (after performing open/short at DUT terminals):

$$C: < 0.15 (1 + 0.002/f) \text{pF} \quad L: < 10 (1 + 0.002/f) \text{nH} \quad R: < 1 (1 + f^2) \text{m}\Omega$$

where f = measurement frequency in MHz


Connection to 7600 Plus (using 7000-01 or 7000-02 BNC Cable Sets):

<u>Connect to 7600 Plus</u>	<u>Cable Marking/Color</u>	<u>Connect to Test Fixture</u>
PH (potential, high)	PH (Red/white)	PH
IH (current, high)	IH (Red)	I H
PL (potential, low)	PL (Black/white)	PL
IL (current, low)	IL (Black)	IL

Open/Short Zeroing:

Instrument zeroing should be performed once the test fixture is connected. Refer to the instrument zeroing instructions for further information. For an OPEN the DUT should be removed but the fixture spacing should be the same as the device. This can be done by tightening the screw that holds the contact, as shown below. For a SHORT the fixture contacts should be shorted together with a shorting block equivalent to spacing of the device under test.

Use of this fixture may result in an incremental error due to residuals at DUT terminals. Verify with a known standard and apply this offset to final measurements.



3.14.9 Calibration Kit (7000-09)

The 7000-09 Calibration kit consists of four calibration resistors, an open-circuit module and a short-circuit module. These standards are NIST traceable and used to re calibrate the 7600 Plus Precision LCR Meter. The four calibration resistors have nominal values of 24.9, 374 Ω ; 5.97 and 95.3 k Ω . R and Q values are given for all four resistors at 1 kHz, R and Q values are also given at 25 kHz for the 95.3 k Ω resistor, 250 kHz for the 5.97 k Ω resistor and both 500 kHz and 1 MHz for the other two resistors. Use the 1 MHz for calibration of 7600 Plus. Refer to Calibration on page 95.




Figure 62 Calibration Kit

3.14.10 Connection to "Type 874" Connectors

There are times when it may be desirable to connect the 7600 Plus to type 874 coaxial connectors that are found on some impedance standards. This connection can be made using either the 7000-01 or 7000-02 BNC to BNC Cable, two BNC Tees and two BNC to 874 adapters (see below).




Figure 63 Connection to 874 Connectors

Sources for BNC-to-874 Adapters:

Gilbert Engineering
P.O. Box 23189
Phoenix, AZ 85063
602-245-1050

Delta Electronics
416 Cabot Street
Beverly, MA 01915
508-927-1060

Pasternack Enterprises
P.O. Box 16759
Irvine, CA 92713
714-261-1920

4 Error Messages

- "AC CURRENT ERROR, SET TO 250 μ A" AC current level improperly set
- "AC VOLTAGE ERROR, SET TO 1V" AC voltage level improperly set
- "BAD CALIBRATION CODE ENTERED" Calibration code incorrectly entered
- "BAD CALIBRATION DATA" Calibration incorrect, re calibrate
- "BAD OPEN CALIBRATION DATA" Repeat Open test
- "BAD SETUP DATA READ FROM MEMORY" Setup data incorrect, reload
- "BAD SHORT CALIBRATION DATA" Repeat Short test
- "BIN CHECKSUM ERROR, TOTALS SET TO 0" Bin count incorrect
- "CRC ERROR ON USB" Stored setup lost or corrupt (cyclic-redundancy-check)
- "CURRENT MODE, BIAS SET TO OFF"
- "DISK WRITE PROTECT ERROR" Flash drive is write protected
- "ELAPSED TIME ERROR, SET TO 0" Elapsed time is incorrect and has been set to zero (battery for non-volatile memory may be defective)
- "ERROR DURING CALIBRATION" Calibration incorrect, re calibrate
- "ERROR DURING OPEN CALIBRATION" Repeat Open test
- "ERROR DURING SHORT CALIBRATION" Repeat Short test
- "FAILURE # SEE DOCUMENTATION" Hardware or software failure, 1 – 99 (# list not included in this manual)
- "FILE ACCESS VIOLATION" File selected from flash drive is Read Only
- "FILE DOES NOT EXIST" File name incorrect
- "FILE EXISTS" File already exists under the chosen name
- "FLASH DRIVE NOT READY" Flash drive defective or not inserted
- "GENERAL FAILURE, USB" Flash drive defective or not inserted
- "HANDLER PORT FAILURE" I/O port malfunction during power up
- "HARDWARE TIMER FAILURE, REBOOT" Hardware malfunction during power up
- "HIGH LIMIT LESS THAN LOW LIMIT" Limits incorrectly set
- "INTERNAL HARDWARE FAILURE, REBOOT" Hardware malfunction during power up
- "INVALID FREQUENCY SELECTED" Select a valid frequency
- "INVALID RANGE SELECTED" Select another range
- "LOW BATTERY VOLTAGE" Memory backup battery indicates low voltage; setups and instrument zero could be lost

"MAXIMUM # OF SETUPS REACHED" Maximum number of files have been stored

"NO IEEE 488 INTERFACE" Unit does not include IEEE-488

"NO INTERLOCK SIGNAL" Open interlock connection at rear panel I/O Port

"NO PASSWORD ENTERED" Password entry canceled, re-enter

"NO ZERO DATA FOUND" Unit requires zeroing

"PASSWORD DID NOT MATCH" Incorrect password entered

"PASSWORD NOT SAVED IN RAM" Error trying to save password, repeat

"PASSWORD VERIFICATION FAILURE" Wrong password entry for verification

"PRI & SEC MISMATCH, SET TO AUTO" Check parameter selection

"PRIMARY = AUTO, CAN'T UPDATE AUTOACC" Check parameter selection

"PRIMARY = AUTO, SECONDARY IGNORED" Check parameter selection

"PRINTER ERROR, CHECK PRINTER" Printer error

"PRINTER OUT OF PAPER" Printer out of paper

"QUICK OPEN / SHORT INVALID, RE-ZERO"

"REMOTE COMMAND INVALID" IEEE or RS232 command is incorrect (for example:
to set frequency use FREQuency)

"REMOTE COMMAND PARAMETER INVALID" IEEE or RS232 parameter is
incorrect (for example: frequency parameter can be
XXXXXXX.XX)

"REMOTE COMMAND PREFIX INVALID" IEEE or RS232 command prefix is
incorrect (for example: to configure unit use CONFigure)

"SHUT THE POWER OFF" Malfunction of instrument power source

"SWEEP BEGIN & END ARE EQUAL" Sweep range improperly set

"SWEEP BEGIN / END VALUES TOO CLOSE" Sweep range improperly set

"SWEEP BEGIN VALUE GREATER THAN END" Sweep range improperly set

"TIME / DATE ERROR, PLEASE SET" Reset time and date

"TOO MANY KEYS, LAST KEY IGNORED" Too many keys for entry field

"UNABLE TO READ FROM FLASH DRIVE" Flash drive defective or not inserted

"UNABLE TO READ THAT FILENAME" Selected file unreadable, improper format

"UNABLE TO WRITE TO REMOTE" IEEE or RS232 not setup correctly or IEEE
not present

"UNKNOWN COMMAND"

"UNKNOWN UNIT" Flash drive is not recognized (not present or defective)

"USB MEDIA DEFECT" Flash drive defective

"USB READ FAULT" Flash drive defective or not inserted

- "USB SAVE ERROR" Setup not properly saved
- "USB SECTOR UNFORMATTED" Flash drive is not formatted
- "USB SEEK ERROR" Flash drive defective or not inserted
- "USB WRITE FAULT" Flash drive defective or not inserted
- "VALID RANGE = low value - hi value" Entry invalid, should be between specified values
- "WARNING V > 1, BIAS NOT AT 2V" DC bias voltage incorrect

5 Theory

The 7600 Plus Precision LCR Meter consists of a standard mechanical package, LCD display/keypad, PC104 microprocessor module, and power supply. In addition there is the IEEE-488 card discussed briefly below.

5.1 Basic Instrument Architecture

5.1.1 Processor Board

The processor board provides the basic control for the 7600 Plus and mimics the IBM-PC architecture. Besides the central processing unit and memory modules, it includes SMX RTOS, keypad, USB and RS232 ports. The RS232 port is connected to its rear panel connector by a cable. The processor board is stacked on the Main Board. The processor board can have the IEEE-488 card stacked on it.

5.1.2 Power Supply

The power supply assembly consists of two modules, a +3V/+5V/-12V module towards the back of the instrument and a $\pm 12V$ module towards the front. The +3V/+5V/-12V supplies power to all digital functions. The $\pm 12V$ module supplies power to the analog section of the instrument board.

5.1.3 LCD Display/Keypad Panel

The front panel user interface is comprised of a molded silicon rubber keypad that actuates a membrane switch assembly. The keypad is environmentally sealed, designed for long life with all keys providing tactile feedback to the operator. The 2 1/2" x 4 3/4" LCD is a high resolution graphic display with on/off back light for visual clarity. Both keypad and display are connected to the instrument I/O board via ribbon cables.

5.2 7600 Plus Instrument Module

The QT 1 Instrument Board QT0807 instrument board, used in the Model 7600 Plus Precision LCR Meter, is the heart of the measurement system. There are five major parts to this board: sine wave generator, voltage detector channel, current detector channel, A/D converter, and Digital Signal Processor. Each is discussed below in brief.

5.2.1 Sine Wave Generator

All devices under test are tested by applying a sine wave of voltage or current. The sine wave is generated by an IC using the Direct Digital Synthesis technique. This allows generation of all frequencies from 10 Hz to 2 MHz with a high level of resolution.

5.2.2 Voltage Detector Channel

The sine wave test signal is applied to the unknown through the IH and IL leads, causing a voltage to appear across the unknown. This voltage, E_x , is measured by the PH and PL leads, filtered and amplified according to its level, and presented to one channel of the Dual A/D converter.

5.2.3 Current Detector Channel

The current flowing through the unknown is applied to a transadmittance amplifier with an internal standard in the feedback path. This arrangement causes a voltage to be generated across the standard resistor proportional to the current. This voltage is also filtered and amplified and presented to the second channel of the A/D converter.

5.2.4 A/D Converter

The two signals representing 'voltage across' and 'current through' the unknown are digitized by a dual 18-bit A/D converter. Samples are taken synchronously with the digital generation of the sine wave to obtain phase information.

5.2.5 Digital Signal Processor

The digitized voltage and current signals are applied to a high speed Digital Signal Processor where a mathematical algorithm (similar to a Fast Fourier Transform) extracts the in-phase and quadrature portions of the signal. This information is then used to calculate the complex impedance, Z , and the complex admittance, Y , of the unknown. These results are then used to compute the parameters requested by the user i.e. C, R, L, D, Q etc.

5.3 Options

5.3.1 IEEE-488 Board & Cable

Control available through the keyboard or available for display can be accessed over this interface. This board is mounted at the right rear of the unit stacked above the processor board. Connection to the IEEE-488 connector is via an interconnecting cable. IEEE option is 7000-22.

6 Maintenance & Calibration

Our warranty (at the front of this manual) attests to the quality of materials and workmanship in our products. If malfunction should be suspected or other information be desired, applications engineers are available for technical assistance. Application assistance is available in the U.S. by calling 800-253-1230 and asking for Applications Support. For support outside of the United States, please contact your local [QuadTech Distributor](#).

6.1 Bias Voltage Fuse Replacement



There are two bias voltage fuses. The fuses are type F0.25A, 250V, 5x20mm fast blow. Replace only with the same rated fuse. **Make sure the instrument is off and disconnected from its ac power source.** The fuses are located in the instrument on the back panel QT110407 board.

6.2 Resetting of Time and Date

If for some reason the Time and Date need to be reset.

It is very important that the time and date be reset and the instrument zeroed before proceeding with any measurements. Proceed as follows:

1. Press **MENU** key to select menu display.
2. Press **Right or Left Arrow** key to select Utilities menu.
3. Press **Up or Down Arrow** key to select Set Time/Date.
4. Press **ENTER** key to activate the entry field.
5. Set the current time and date as instructed on the display, refer to paragraph 2.6.5.7 if necessary. After the time and date have been reset press **MENU** to return to the menu display.
6. Press **Up or Down Arrow** key to select Zero.
7. Press **ENTER** key to activate the Zero routine and follow instructions on the instrument display.
8. Once the Time and Date have been reset and the instrument zeroed the 7600 Plus is ready for routine measurements. It's important to note that the elapsed time will have been reset back to zero during this process.

6.3 Loss of Display Contrast

If for some reason the instrument should lose its display contrast, it is possible to reset it easily using the procedure below. Loss of contrast would exhibit no display at all when the instrument is powered up.

Procedure for restoring loss of contrast:

1. Consider the SELECT buttons as labeled 1, 2, 3, and 4 from top to bottom.
2. Turn the instrument on and wait 10 seconds.

3. Press MENU key twice.
4. Press SELECT "4" one time.
5. Press SELECT "1" three times.
6. Press ENTER.
7. Press SELECT "1" many times till contrast returns to normal.
8. Press ENTER.
9. Arrow up to SAVE SETUP and save as DEFAULT.

If the above procedure fails to restore the contrast, try repeating. Failing restoration of the contrast may be indication of another instrument problem.

6.4 Calibration

Calibration of the 7600 Plus Precision LCR Meter is recommended on an annual basis. If the unit is to be returned to QuadTech for factory calibration, refer to section 6.4.2 for instructions. **Using the procedure below, the instrument can also be calibrated by a qualified service person if traceable calibration equipment and standards are available.**

CAUTION

To ensure maximum stability, the instrument should be powered up for a minimum of 1 hour before calibration.

6.4.1 Requirements for Re calibration

Temperature stabilized room at 23 degrees C (73.4 F)

QuadTech 7000-09 Calibration Kit

1. Select CALIBRATION on the Utilities menu.
2. Once ENTER is selected the calibration code of 7600225 must be entered to continue. This code is to prevent unauthorized personnel from effecting the instrument calibration. For security reasons it may be desirable to blank out the code (above) in this instruction manual.

The step by step instructions for this procedure is shown on the instrument display.

6.4.2 Instrument Return

Before returning an instrument to QuadTech for [Service](#) please obtain an [online Return Materials Authorization Number \(RMA#\)](#). This number, when placed on the outside of the shipping package, will speed processing at our Service Lab and will serve as a reference number for the time your unit is at QuadTech. Please contact our **Customer Care Center (CCC)** at **800-253-1230** for additional support. The CCC phone line is staffed from 8:00am to 5:00pm (EST).

It will be necessary to include a Purchase Order Number and credit card information to insure expedient processing, although units found to be in warranty will be repaired at no-charge. For any questions on repair costs or shipment instructions please contact our CCC Department at the above number. To safeguard an instrument during storage and shipping please use packaging that is adequate to protect it from damage, i.e., equivalent to the original packaging and mark the box "Delicate Electronic Instrument". Please follow online instructions for shipping materials back to QuadTech.