


User's Guide

Ultra Low Noise Current Source LDX-3620



 **ILX Lightwave**
Photonic Test & Measurement Instrumentation

ILX Lightwave Corporation · P. O. Box 6310 · Bozeman, MT, U.S.A. 59771 · U.S. & Canada: 1-800-459-9459 · International Inquiries: 406-586-1244 · Fax 406-586-9405
E-mail: support@ilxlightwave.com

www.ilxlightwave.com

SAFETY AND WARRANTY INFORMATION



The Safety and Warranty Information section provides details about cautionary symbols used in the manual, safety markings used on the instrument, and information about the Warranty including Customer Service contact information.

Safety Information and the Manual

Throughout this manual, you will see the words *Caution* and *Warning* indicating potentially dangerous or hazardous situations which, if not avoided, could result in death, serious or minor injury, or damage to the product. Specifically:

CAUTION

Caution indicates a potentially hazardous situation which can result in minor or moderate injury or damage to the product or equipment.

WARNING

Warning indicates a potentially dangerous situation which can result in serious injury or death.

WARNING

Visible and/or invisible laser radiation. Avoid direct exposure to the beam.

General Safety Considerations

If any of the following conditions exist, or are even suspected, do not use the instrument until safe operation can be verified by trained service personnel:

- Visible damage
- Severe transport stress
- Prolonged storage under adverse conditions
- Failure to perform intended measurements or functions

If necessary, return the instrument to ILX Lightwave, or authorized local ILX Lightwave distributor, for service or repair to ensure that safety features are maintained.

All instruments returned to ILX Lightwave are required to have a Return Authorization Number assigned by an official representative of ILX Lightwave Corporation.

SAFETY SYMBOLS











This section describes the safety symbols and classifications.

Technical specifications including electrical ratings and weight are included within the manual. See the Table of Contents to locate the specifications and other product information. The following classifications are standard across all ILX Lightwave products:

- Indoor use only
- Ordinary Protection: This product is NOT protected against the harmful ingress of moisture.
- Class I Equipment (grounded type)
- Mains supply voltage fluctuations are not to exceed $\pm 10\%$ of the nominal supply voltage.
- Pollution Degree II
- Installation (overvoltage) Category II for transient overvoltages
- Maximum Relative Humidity: $< 80\%$ RH, non-condensing
- Operating temperature range of $0\text{ }^{\circ}\text{C}$ to $40\text{ }^{\circ}\text{C}$
- Storage and transportation temperature of $-40\text{ }^{\circ}\text{C}$ to $70\text{ }^{\circ}\text{C}$
- Maximum altitude: 3000 m (9843 ft)
- This equipment is suitable for continuous operation.

Safety Marking Symbols

This section provides a description of the safety marking symbols that appear on the instrument. These symbols provide information about potentially dangerous situations which can result in death, injury, or damage to the instrument and other components.

 <p>Caution, refer to manual</p>	 <p>Earth ground Terminal</p>	 <p>Alternating current</p>	 <p>Visible and/or invisible laser radiation</p>
 <p>Caution, risk of electric shock</p>	 <p>Protective Conductor Terminal</p>	 <p>Caution, hot surface</p>	 <p>Frame or chassis Terminal</p>
 <p>On: In position of a bistable push control. The slash (I) only denotes that mains are on.</p>		 <p>Off: Out position of a bistable push control. The circle (O) only denotes that mains are off.</p>	

WARRANTY

ILX LIGHTWAVE CORPORATION warrants this instrument to be free from defects in material and workmanship for a period of one year from date of shipment. During the warranty period, ILX will repair or replace the unit, at our option, without charge.

Limitations

This warranty does not apply to fuses, lamps, defects caused by abuse, modifications, or to use of the product for which it was not intended.

This warranty is in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for any particular purpose. ILX Lightwave Corporation shall not be liable for any incidental, special, or consequential damages.

If a problem occurs, please contact ILX Lightwave Corporation with the instrument's serial number, and thoroughly describe the nature of the problem.

Returning an Instrument

If an instrument is to be shipped to ILX Lightwave for repair or service, be sure to:

- 1 Obtain a Return Authorization number (RA) from ILX Customer Service.
- 2 Attach a tag to the instrument identifying the owner and indicating the required service or repair. Include the instrument serial number from the rear panel of the instrument.
- 3 Attach the anti-static protective caps that were shipped with the instrument and place the instrument in a protective anti-static bag.
- 4 Place the instrument in the original packing container with at least 3 inches (7.5 cm) of compressible packaging material. **Shipping damage is not covered by this warranty.**
- 5 Secure the packing box with fiber reinforced strapping tape or metal bands.
- 6 Send the instrument, transportation pre-paid, to ILX Lightwave. Clearly write the return authorization number on the outside of the box and on the shipping paperwork. ILX Lightwave recommends you insure the shipment.

If the original shipping container is not available, place your instrument in a container with at least 3 inches (7.5 cm) of compressible packaging material on all sides.

Repairs are made and the instrument returned transportation pre-paid. Repairs are warranted for the remainder of the original warranty or for 90 days, whichever is greater.

Claims for Shipping Damage

When you receive the instrument, inspect it immediately for any damage or shortages on the packing list. If the instrument is damaged, file a claim with the carrier. The factory will supply you with a quotation for estimated costs of repair. You must negotiate and settle with the carrier for the amount of damage.

Comments, Suggestions, and Problems

To ensure that you get the most out of your ILX Lightwave product, we ask that you direct any product operation or service related questions or comments to ILX Lightwave Customer Support. You may contact us in whatever way is most convenient:

Phone (800) 459-9459 or (406) 586-1244

Fax (406) 586-9405

Email support@ilxlightwave.com

Or mail to:

ILX Lightwave Corporation
P. O. Box 6310
Bozeman, Montana, U.S.A 59771
www.ilxlightwave.com

When you contact us, please have the following information:

Model Number: _____

Serial Number: _____

End-user Name: _____

Company: _____

Phone: _____

Fax: _____

Description or sketch of what
is connected to the ILX
Lightwave instrument:

Description of the problem:

If ILX Lightwave determines that a return to the factory is necessary, you are issued a Return Authorization (RA) number. Please mark this number on the outside of the shipping box.

You or your shipping service are responsible for any shipping damage when returning the instrument to ILX Lightwave; ILX recommends you insure the shipment. If the original shipping container is not available, place your instrument in a container with at least 3 inches (7.5cm) of compressible packaging material on all sides.

We look forward to serving you even better in the future!

Table of Contents

CHAPTER 1 - GENERAL INFORMATION	1
1.1 Introduction.....	1
1.2 Product Overview.....	1
1.3 Specifications.....	2
1.4 Options and Accessories	3
CHAPTER 2 - OPERATION	4
2.1 Introduction.....	4
2.2 Installation.....	4
2.2.1 AC Power Considerations	4
2.2.2 Tilt-foot Adjustment	4
2.2.3 Rack Mounting	4
2.3 Front Panel Controls and Connectors	5
2.3.1 DC Power ON/OFF and Range Selection	5
2.3.2 Low Battery Indication	5
2.3.3 EXT Modulation	5
2.3.4 Ramp Modulation	6
2.3.5 MODE Selector	6
2.3.6 LIMIT Current Adjustment	6
2.3.7 OUTPUT On/Off	6
2.3.8 OUTPUT ADJUST Controls	7
2.3.9 DISPLAY Selector	7
2.3.10 Output 4-1/2 Digit LCD Display	7
2.3.11 OUTPUT SHORT Indicator.....	7
2.3.12 OUTPUT ERROR Indicator.....	8
2.4 Rear Panel Controls and Connectors	10
2.4.1 HIGH/LOW BANDWIDTH Selector	10
2.4.2 OUTPUT Connector (J401)	10
2.4.3 PHOTODIODE Feedback Gain Adjustments	10
2.4.4 PHOTODIODE Feedback Input Jack.....	10
2.4.5 RAMP TRIGger Output Jack	11
2.4.6 CHASSIS GROUND Connector.....	11
2.4.7 AC POWER/Battery Charge Switch	11
2.4.8 Fuse Holder	11
2.5 LDX-3620 Operation Procedures	13
2.5.1 Outline of Operation.....	13
2.5.2 Load Considerations	14
2.5.3 Safe Settings.....	15
2.5.4 Safety Interlock Connections	15

2.5.5	Laser Diode Connections and Shielding.....	16
2.5.6	Photodiode Feedback Connections.....	17
2.5.7	RAMP TRIGger Output Connections	17
2.5.8	Setting the LIMIT Current.....	20
2.5.9	Setting the Output in CONST CURRENT Mode	20
2.5.10	Setting the MODULATION Controls	20
2.5.11	Using the Internal RAMP Generator	21
2.5.12	Setting the Photodiode Feedback Gain	21
2.5.13	Setting the Laser Power in CONST POWER Mode.....	24

CHAPTER 3 - MAINTENANCE.....27

4.1	Introduction.....	27
4.2	Battery Maintenance.....	27
4.3	Battery Replacement	28
4.4	AC Line Voltage Selection	28
4.5	Fuse Replacement.....	29
4.6	Calibration.....	30
4.6.1	Display Calibration	30
4.6.2	MONITOR Current Display Calibration	31
4.6.3	OUTPUT ADJUST Calibration	32
4.6.4	LIMIT Current Calibration.....	32
4.6.5	RAMP SPAN Calibration	32
4.7	Disassembly	33

Index.....Index-i

Chapter 1

GENERAL INFORMATION

1.1- Introduction

This manual contains operation and maintenance information for the LDX-3620 Ultra Low Noise Current Source and its options. Chapter 2 contains control and connector descriptions and operation procedures. Chapter 3 has the theory of operation of the LDX-3620. Chapter 4 contains battery and maintenance information.

IMPORTANT

To those in a hurry to turn on and use the LDX-3620 without reading Chapter 2 of this manual, it is recommended that the IMPORTANT paragraphs be read since they contain information that may prevent the destruction of expensive laser diodes (see IMPORTANT in the index). The most important operating instructions are located in Section 2.5. Output connector pin-outs are found in Figure 2.3. Recommended cable shielding schemes are found in Figures 2.4 A through D and discussed in Sections 2.5.5 and 2.5.6. Figure 3.1 is a block diagram of the LDX-3620. Battery maintenance information is found in Section 4.2.

1.2 The LDX-3620 Ultra Low Noise Current Source

The LDX-3620 Ultra Low Noise Current Source provides laser diode users a power source for applications requiring current stabilities of better than 10 ppm and noise levels lower than 2 uA in the 5 Hz to 10 MHz band. Its features include:

- * Low noise, battery based design
- * Built-in battery charger
- * High output stability
- * Current limit protection
- * Two output current ranges: 200 mA and 500 mA
- * 4-1/2 digit resolution and display
- * Monitor photodiode current display
- * Photodiode feedback input for constant optical power operation
- * Internal ramp generator with trigger output
- * External modulation capability
- * Low battery shutdown protection
- * High/Low bandwidth switch

1.3 Specifications for the LDX-3620

<u>OUTPUT</u>	<u>0-200 mA RANGE</u>	<u>0-500 mA RANGE</u>
Output Current:	0-200 mA	0-500 mA
Compliance Voltage:	≥ 5 volts	≥ 4 volts
Noise and Ripple: (5 Hz - 10 MHz bandwidth)		
Battery operation	≤ 850 nA rms	≤ 2 uA rms
AC line operation	≤ 3 uA rms	≤ 8 uA rms
Noise and Ripple: (5 Hz - 10 KHz bandwidth)		
Battery operation	≤ 100 nA rms	≤ 500 nA rms
AC line operation	≤ 2 uA rms	≤ 6.5 uA rms
Noise Density: (Battery Operation)		
50/60 Hz	5.2 nA/rt Hz	11.5 nA/rt Hz
1 KHz	815 pA/rt Hz	2.6 nA/rt Hz
25 KHz	315 pA/rt Hz	795 pA/rt Hz
Stability:		
10-20 seconds		≤ 0.1 ppm
3-5 minutes		≤ 1 ppm
10-30 minutes		≤ 10 ppm
Temperature Coefficient:		≤ 10 ppm/ $^{\circ}$ C
Transients:		≤ 10 uA
Ramp Trigger:	Ramp start trigger for oscilloscope output; Optically isolated open collector TTL output	
Ramp Flyback Time:	700 uSec, approximately	
Output Connector:	Shielded 9-pin D-sub on rear panel	

CURRENT LIMIT

Range:	10-500 mA
Accuracy:	± 5 mA

DISPLAY

Type: 4-1/2 digit LCD

	<u>0-200 mA RANGE</u>	<u>0-500 mA RANGE</u>
Resolution:	0.01 mA	0.1 mA
Accuracy:	± 0.05 mA	± 0.6 mA

Reads units: LASER diode current in mA
MONITOR photodiode current in mA

MODULATION / FEEDBACK INPUTS

Photodiode Feedback

Input Type: Current input from external photodiode
Range: 20 uA to 2 mA for full scale output
Connectors: Rear Panel Isolated BNC Jack or
9-pin Rear Panel D-sub Connector

External Modulation Input

Bandwidth (3 dB point)

AC Coupled: 100 Hz to 1 MHz
DC Coupled: 0 Hz to 1 MHz

Transfer Function: 0-200 mA RANGE 0-500 mA RANGE
100 mA/V 250 mA/V

Connector: Isolated Front Panel BNC Jack

Internal Ramp Generator

Period: Adjustable 50 msec to 100 sec
Span Adjustment: 0-200 mA 0-500 mA

GENERAL

AC Power

Input Voltage Range 100-125 or 210-250 VAC
Line Frequency 50/60 Hz

Battery

+12 volt supply: 4.5 amp-hour sealed lead-acid battery (standard)
-12 volt supply: 1.2 amp-hour sealed lead-acid battery

Temperature Range

Operating: 0 to 40°C
Storage: -40 to 70°C

1.4 Options and Accessories

362038 Long Life Battery Option

The 362038 option is a second, user installable +12 volt battery which doubles the battery operation time at 500 mA. Instructions for battery installation are included with the 362038 option kit.

132 Rack Mount Kit

The 132 rack mount kit enables installation of the 3620 into a standard 19 inch wide rack. All hardware and instructions are included with the kit.

Chapter 2

OPERATION

2.1 Introduction

This chapter contains the following aspects of operation of the LDX-3620:

- * General power and installation considerations
- * A description of the front and rear panel controls and connectors
- * Step-by-step instructions on the set-up and use of the LDX-3620

2.2 Installation

Sections 2.2.1 through 2.2.3 discuss topics related to the installation of the LDX-3620.

2.2.1 AC Power/ Battery Charge Considerations

The LDX-3620 is normally configured at the factory for your power line voltage. The unit can be configured for 100-130 VAC or 210-230 VAC operation. Check to be sure that the correct range is marked on the rear panel. If it is not correct, see Section 4.4 for the procedure to change the line voltage range.

The AC power cord connects to the rear of the unit. Turning on the AC POWER switch on the rear panel charges the batteries while permitting full use of the LDX-3620's functions; however, noise will be increased in this configuration.

2.2.2 Tilt-foot Adjustment

The LDX-3620 can be tilted for easier viewing using the extensions on the front feet of the unit. These extenders can be rotated 90 degrees until they lock into position. To put the extenders flat against the bottom of the unit, firmly press them back.

2.2.3 Rack Mounting

The instructions and necessary hardware for mounting the LDX-3620 in a standard 19 inch wide instrument rack are available in the model 332 Rack Mounting Kit. Contact the factory for more information.

2.3 Front Panel Controls and Connectors

A brief description of the function of the front panel controls and connectors is contained in the following subsections. Refer to Figure 2.1.

2.3.1 DC POWER Key Switch and Output Range Selection

A three position key switch on the front panel of the LDX-3620 controls the power to the current source circuits:

- * Off center position
- * 200 mA 1/8 turn clockwise (CW)
- * 500 mA 1/8 turn counter-clockwise (CCW)

The front panel power key switch operates independently of the rear panel AC POWER switch. The rear panel switch controls only AC-line-power/battery-charge operation. With the rear panel switch turned on, the power LED above the front panel key switch will light up, indicating that AC power is on and that the batteries are charging.

2.3.2 Low Battery Indication and Shutdown

A "B" indicated on the display of the LDX-3620 means that the batteries should be recharged. Repeated operation of the unit to the point where the low battery "B" is indicated greatly reduces the battery life and is not recommended. See Section 4.2 for recommended battery maintenance.

If the batteries continue to be discharged after the low battery "B" indicator appears, shutdown circuits may turn off the output of the LDX-3620. Shutdown is indicated on the display when all of the decimal points are displayed. Use of the instrument will be disabled until the batteries have been recharged and the DC POWER key switch has been turned off and then on again.

2.3.3 EXT Modulation

An external voltage wave form can be used to modulate the LDX-3620 output when the modulation mode selection switch is set to either the EXT AC or EXT DC positions. The external signal is input through the front panel EXT BNC jack and is AC or DC coupled according to the mode switch position. The transconductance of the instrument is determined by the output current range selected by the DC POWER key switch; it is 100 mA/V in the 200 mA output range, or 250 mA/V in the 500 mA output range. Under all modes of operation, the output is clipped at the level set by the current LIMIT knob.

2.3.4 RAMP Modulation

The LDX-3620 output can be modulated using the internal ramp generator when the MODULATION selector switch is set to the RAMP position. The ramp period is variable between 50 mSec and 100 Sec via the RAMP PERIOD adjustment pot. The ramp peak-to-peak amplitude is adjusted using the RAMP SPAN front panel pot. A DC offset may be added to the ramp by using the OUTPUT ADJUST knobs.

Ramp fly-back time is approximately 700 microseconds. The ramp wave form will be clipped, should it try to exceed the current limit.

2.3.5 MODE Selector

The front panel MODE switch selects the feedback mode of the LDX-3620. In CONST CURRENT mode, the LDX-3620 is a voltage controlled current source that delivers a current proportional to the sum of the MODULATION section and OUTPUT ADJUST knob control signals.

In the CONST POWER mode, the LDX-3620 uses the photodiode feedback signal to determine how much current should be output to the laser or LED to maintain a constant light power. The output current increases until the photodiode feedback current equals a value proportional to the control signal set by the MODULATION and the OUTPUT ADJUST sections on the front panel. If the control signal is a DC level, then the output **optical power** is held constant. If the control signal is modulated, then the output **optical power** is modulated, so long as the bandwidth of the modulation is held below 20 Hz. Modulation frequency components higher than 20 Hz are attenuated, and the modulation becomes a mixture of optical-power modulation and current modulation.

2.3.6 LIMIT Current Adjustment

The LIMIT knob on the front panel sets the output current limit level. Setting this knob fully clockwise (CW) limits the LDX-3620 output current to 500 mA. Setting it fully counter-clockwise (CCW) limits the output to approximately 10 mA. **The current limit is active in all operating modes of the LDX-3620.** A more complete description of how to set current limit may be found in Section 2.5.8.

2.3.7 OUTPUT On/Off

The current output of the LDX-3620 is shorted by a mechanical switch and a JFET when the front panel OUTPUT push button switch is in the OFF/SHORT position (out). When the OUTPUT switch is set to the ON position, the short is removed and the JFET is turned off slowly. This brings the output current up slowly to the level determined by the OUTPUT ADJUST and MODULATION control signals.

When the output is shorted internally, the OUTPUT SHORT LED on the front panel will light up.

2.3.8 OUTPUT ADJUST Controls

The OUTPUT ADJUST, COARSE, and FINE knobs set the DC output level of the LDX-3620. The DC bias level is summed with the control signals derived from the MODULATION section to determine the final output level.

2.3.9 DISPLAY Selector

The display of the LDX-3620 indicates the average output current of the unit when the DISPLAY push button switch is in the LASER position (out). It displays the average photodiode feedback current input to the rear panel when the DISPLAY switch is in the MONITOR position (in).

Note: When in the MONITOR position (in), the display reads the negative value of the average photodiode current. This reminds the user that the display switch is in the MONITOR position.

2.3.10 Output 4-1/2 Digit LCD Display

The LDX-3620 output current and monitor photodiode current are displayed on a 4-1/2 digit liquid crystal display on the front panel of the instrument. When the DISPLAY push button is in the LASER position (out), the display reads the average current setting determined by the MODULATION and OUTPUT ADJUST controls. It does so even when the OUTPUT push button is in the OFF/SHORT position (out) and no current is delivered to the output. The resolution of the display depends on the range selected by the DC POWER key switch: 0.01 mA in the 200 mA setting and 0.1 mA in the 500 mA setting.

When the DISPLAY switch is in the MONITOR position (in), the display reads the (negative) average photodiode current input to the rear panel photodiode feedback inputs in milliamperes. This reading is negative to remind the user that the display is in the MONITOR position. The resolution of the display in MONITOR mode does not change with the output range selected by the DC POWER key switch.

The display also announces low battery charge by indicating a "B". If "low battery shutdown" occurs, the display reads zero current and all of the decimals are displayed (see Section 2.3.2).

2.3.11 OUTPUT SHORT Indicator

The green OUTPUT SHORT lamp lights up when the output is shorted by setting the OUTPUT on/off switch to the OFF/SHORT position (out). It is unlit when the OUTPUT is ON.

2.3.12 OUTPUT ERROR Indicator

The red OUTPUT ERROR indicator lights up when:

- *The output has reached the current LIMIT level, set by the LIMIT adjustment.
- *The output circuit is open.
- *The maximum compliance voltage of the LDX-3620 is insufficient to drive the load.

Table 2.1 lists the possible conditions leading to a lighted OUTPUT ERROR LED:

OUTPUT ERROR CONDITIONS

<u>Condition</u>	<u>Indicated By</u>
Current Limit	* OUTPUT ERROR LED is lit * Display reads value of LIMIT current
Open Circuit	* OUTPUT ERROR LED is lit * Display reads zero
Compliance Voltage Exceeded	* OUTPUT ERROR LED is lit * Display reads a non-zero value less than the LIMIT current

Table 2.1 OUTPUT ERROR Conditions



Figure 2.1 LDX-3620 Front Panel

2.4 Rear Panel Controls and Connectors

The following sections contain brief descriptions of the functions of the rear panel controls and connectors. Refer to Figure 2.2.

2.4.1 HIGH/LOW BANDWIDTH Selector

The BANDWIDTH selector switches a 0.1 μF capacitor in and out of the output circuit. This capacitor is connected directly across the output current posts. The capacitor is connected when the LOW bandwidth position is selected, and it is disconnected when the HIGH bandwidth position is selected.

In the HIGH position the modulated output bandwidth of the LDX-3620 is 1 MHz. With the switch in the LOW position the bandwidth across a 100 ohm load is cut to about 20 kHz. The LOW setting decreases noise and prevents oscillation of the LDX-3620 when it is connected to an inductive load, such as a bias "tee" circuit. This allows external modulation of the laser diode using the LDX-3620 as a bias current supply.

2.4.2 OUTPUT Connector (J401)

The rear panel 9-pin D-sub connector (J401) pin-outs are shown in Figure 2.3. The LDX-3620 output current is sourced (+) from pins 8 and 9 and the current returned (-) to pins 4 and 5. The monitor photodiode feedback current is input to pin 7 (+) and returned from pin 6 (-). The feedback leads should be shielded with an earth-ground shield available on pin 3. Sections 2.5.5 and 2.5.6 contain more detailed information on connections and grounding.

Pins 1 and 2 of the rear panel OUTPUT can be connected to an external safety interlock

switch to disable the LDX-3620 current output when the switch is opened. See Section 2.5.4 for instructions on the connection of an interlock switch.

2.4.3 PHOTODIODE Feedback Gain Adjustments

The photodiode feedback circuit gain is adjustable on the rear panel to accept full-scale feedback currents from 20 μA to 1 mA. An eight position switch provides COARSE gain adjustment, while a four-turn trimpot provides FINE adjustment. The adjustment procedure is described in Section 2.5.12.

2.4.4 PHOTODIODE Feedback Input Jack

The photodiode feedback current may optionally be input through a rear panel BNC jack. This jack is connected in parallel with pins 6 and 7 of the rear panel 9-pin D-subminiature connector.

2.4.5 RAMP TRIGger Output Jack

Optically isolated RAMP TRIGGER signals are output through two BNC jacks on the rear panel. The OSCILLOSCOPE output delivers a 200 mV square pulse with rising and falling edges of the pulse synchronized to the end and start of the output current ramp. This output remains high during the ramp flyback time of approximately 700 microseconds.

The OPEN COLLECTOR output is capable of driving a TTL load, but requires an external supply and pull-up resistor. See Section 2.5.7 for connection information.

2.4.6 CHASSIS GROUND Connector

Chassis ground is available on the rear of the unit through a banana jack connected to the LDX-3620 cabinet. When a three-wire line cord with earth-ground is used, the cabinet of the LDX-3620 is connected to the ground lead of the power cord.

2.4.7 AC POWER/Battery Charge Switch

AC line power operation and battery recharge is accomplished by connecting the AC line cord and turning on the AC Power switch on the rear panel. With this switch turned off, the LDX-3620 draws power from its internal battery supply. For lowest noise operation, the AC POWER switch should be OFF and the AC power cord disconnected.

2.4.8 Fuse Holder

The AC line fuse holder is on the rear panel. See Section 4.5 for fuse replacement information.





Figure 2.2 LDX-3620 Rear Panel
 Figure 2.3 Output Connector Pin-out

- 1, 2 Interlock
- 3 Chassis Ground
- 4, 5 Laser Cathode
- 6 PD Cathode (+)
- 7 PD Anode (-)
- 8, 9 Laser Anode



2.5 LDX-3620 Operation Procedures

Section 4.2 contains information concerning the battery operation of the LDX-3620. (Briefly: it recommends that the batteries be maintained as fully charged as possible to ensure long battery life.)

This section contains recommended procedures for operation of the LDX-3620 with a laser diode. It assumes that the batteries are adequately charged or that AC power is connected and on.

2.5.1 Outline of Operation

Operation of the LDX-3620 can be outlined briefly:

- 1) Set controls to a safe configuration (see Table 2.2) before connecting the laser and turning on the DC POWER key switch.
- 2) Connect the laser using one of the recommended shielding schemes (Figure 2.4). Be sure connections are secure and not prone to open should the cables be jostled or bumped (Section 2.5.5). Refer to Section 2.5.6 for photodiode feedback connections.
- 3) Leave the OUTPUT switch in the OFF/SHORT position (out). Turn on the DC power to the appropriate range and adjust the current LIMIT to a safe level for the particular laser being used (Section 2.5.8).
- 4) In CONST CURRENT mode, adjust the output current to the desired level with the OUTPUT ADJUST and/or MODULATION controls and turn ON the OUTPUT (in).
- 5) In CONST POWER mode, adjust the photodiode feedback gain to get maximum resolution on the OUTPUT ADJUST knobs. Then set the output power level with the OUTPUT ADJUST knobs.
- 6) Before turning off the DC POWER key switch, set the OUTPUT switch to the OFF/SHORT position (out).
- 7) Recharge the batteries by connecting the LDX-3620 to the AC line, and turn on the rear panel AC POWER switch.

The procedures for each of these steps are contained in the following subsections.

2.5.2 Load Considerations

The LDX-3620 is intended as a current source for laser diode and LED loads. When it is used with a resistive load, the resistance value of the limiting resistor should be selected so that the compliance voltage is not exceeded. For example, a laser diode which has a voltage drop of 1.8 volts may be connected in series with a limiting resistor. If the 200 mA range is selected on the LDX-3620, the guaranteed compliance voltage is +5 volts. If the current LIMIT is set to 100 mA, the maximum resistance value can be found by Ohm's Law:
($R = E / I$) $3.2 \text{ V} / 0.1 \text{ A} = 32 \text{ ohms}$.

If the LDX-3620 is to be used with an inductive load, such as a bias "tee" network, the LOW BANDWIDTH setting should be used. This is done to prevent possible oscillation of the LDX-3620.

IMPORTANT

If the LDX-3620 is to be connected to an inductive load, such as a bias "tee" network, the LOW BANDWIDTH setting (on the rear panel) should be used. This is necessary to prevent oscillation of the LDX-3620.

2.5.3 Safe Settings

Before turning the DC power on, the front panel controls should be set to a safe configuration. Table 2.2 lists the recommended settings.

RECOMMENDED SAFE SETTINGS

<u>Front Panel Control</u>	<u>Recommended Setting</u>
OUTPUT switch:	OFF/SHORT (out)
MODE knob:	CONST CURRENT
MODULATION knob:	OFF
DISPLAY switch:	LASER (out)
OUTPUT ADJUST knobs:	Fully counter-clockwise (CCW)
LIMIT knob:	Fully counter-clockwise (CCW)

Table 2.2 LDX-3620 Recommended Safe Initial Settings

2.5.4 Safety Interlock Connections

A safety interlock connection is available on pins 1 and 2 of the LDX-3620 rear panel OUTPUT connector. These pins must be shorted to enable the LDX-3620 current output. When this circuit is opened, the interlock turns off the current output, and the OUTPUT SHORT indicator lights up. Then when the circuit is re-closed, the output turns on slowly in the same manner as when the front panel OUTPUT push button switch is turned ON (in).

To use the interlock feature, the user must provide wires connected from the OUTPUT connector interlock pins to a normally closed, external, user supplied switch or relay. These connections must be electrically isolated from all other circuits.

The interlock pins are shorted together inside the hood of the mating male, 9pin D-sub output connector supplied with the LDX-3620.

2.5.5 Laser Diode Connections and Shielding

IMPORTANT

Before connecting the laser diode to the LDX-3620, be sure that the front panel OUTPUT switch is in the OFF/SHORT position (out). Before turning the OUTPUT on, be sure that the current LIMIT has been correctly set.

The LDX-3620 output is available through the 9-pin rear panel OUTPUT connector J401 (see Figure 2.3). The LDX-3620 sources current through pins 8 and 9 to the laser anode (+) and returns current from the cathode (-) through pins 4 and 5.

IMPORTANT

The cable connections to the laser must be secure enough that they won't open-circuit, should they be jostled or bumped. Should an open circuit occur during laser operation, DO NOT attempt to remake the circuit until the front panel OUTPUT switch has been released to the OFF/SHORT position (out). Remaking the circuit with the OUTPUT on will expose the laser to the maximum compliance voltage of the LDX-3620, which will probably result in laser damage.

A laser will probably be damaged if an open circuit occurs during laser operation while the output is on. The damage is caused by a momentary circuit break-and-remake, before the final circuit break. Therefore, always make sure that the cabling is secure. An open circuit is indicated by the front panel OUTPUT ERROR lamp and a zero current reading on the display.

If the LDX-3620 is to be used in CONST POWER mode, the photodiode feedback current should be sourced to pin 7 (+) and returned from pin 6 (-) of the rear panel 9-pin connector. Alternatively, the feedback current can be connected through the rear panel AUX. INPUT BNC connector, using the center conductor of the co-ax for the "+" connection, and the outer shield conductor for the "-" connection.

It is recommended that the connections to the LDX-3620 output be made by using twisted wire pairs, with an earth grounded shield, as shown in Figures 2.4 A through D. The output conductors are left floating, relative to earth-ground, to suppress AC power-on/power-off transients that may occur through an earth-ground return path. If the output circuit is earth-grounded at some point (such as through the laser package and mount), then the user must be careful to avoid multiple earth-grounds in the circuit. Multiple earth-grounds may provide circuit paths that induce spurious currents in the photodiode feedback circuit and output leads.

2.5.6 Photodiode Feedback Connections

Many laser diode modules contain an internal photodiode that monitors the back-facet emission of the laser. This photodiode is usually internally connected to either the laser anode or cathode. Figures 2.4 A through D show the recommended connections and shielding for the various configurations of laser diode modules and photodiode feedback schemes.

The feedback photodiode reverse-biasing supply shown in these figures must be supplied by the user. It is located in the circuit where it will not cause the common mode voltage of the feedback inputs to exceed their specified maximum of ± 6 volts, relative to the "-" current output terminal (pins 4 and 5 of J401). Noise from this biasing supply may contribute to the output noise levels; therefore, a battery with shielded connections is recommended.

If a feedback photodiode is used, which is electrically isolated from the laser, the feedback circuit must be resistively "tied" at some point to the output circuit. A large resistance of 1 Mohm, connected from the laser cathode to the photodiode anode, may be used in place of the direct connection (see Figure 2.4B). This is done to keep the feedback inputs within the specified maximum ± 6 volt common mode voltage, relative to the "-" laser current output (pins 4 and 5 of J401). The circuit of Figure 2.4B should be used, if feasible.

2.5.7 RAMP TRIGGER Output Connections

Two optically isolated RAMP TRIGGER outputs are provided on the LDX-3620 rear panel. The OSCILLOSCOPE output provides a voltage square pulse of up to 200 mV amplitude that is synchronized to the start and end of the output current ramp. The falling edge of the voltage pulse signals the start of the output current ramp. The rising edge signals the end of the ramp. This output remains high during the approximately 700 microsecond ramp flyback. The OSCILLOSCOPE output should be connected to an instrument with an input impedance greater than 100 Kohms.

The OPEN COLLECTOR output may be used to drive TTL circuits, but requires an external supply and pull-up resistor. This output "turns off" (stops conducting) at the beginning of each ramp cycle. It "turns on" (starts conducting) at the end of the current ramp. It remains "on" during the approximately 700 microsecond ramp flyback time. The pull-up voltage must be less than 25 volts, with the center conductor positive relative to the BNC shell. When "on" the OPEN COLLECTOR output sinks up to 10 mA. The "on" state power dissipation should be limited to 100 mW.

IMPORTANT

The OSCILLOSCOPE and OPEN COLLECTOR outputs cannot be used at the same time.




Figure 2.4A Common Laser Cathode - Photodiode Cathode




Figure 2.4B Common Laser Cathode - Photodiode Anode




Figure 2.1 C Common Laser Anode - Photodiode Cathode




Figure 2.1 D Common Laser Anode - Photodiode Anode

2.5.8 Setting the LIMIT Current

Once the "safe" settings have been made (see Table 2.2), the output current LIMIT should be adjusted to a safe level for the particular laser diode being used. (Refer to the max. current rating for your laser diode.)

- 1)Set the OUTPUT switch to the OFF/SHORT position (out); the OUTPUT SHORT LED should light up.
- 2)Set the DISPLAY push button switch to the LASER position (out).
- 3)Turn the COARSE output adjust knob to its maximum setting, fully clockwise (CW). The OUTPUT ERROR indicator should light up.
- 4)Adjust the LIMIT knob until the display reads the desired limit current.
- 5)Return the COARSE output adjust knob to its minimum setting, fully counter-clockwise (CCW). The OUTPUT ERROR indicator should be unlit.

2.5.9 Setting the Output in CONST CURRENT Mode

Before adjusting the output current of the LDX-3620 with the OUTPUT ADJUST knobs or the MODULATION controls, be sure that the current LIMIT has been properly set (Section 2.5.8) and that the laser circuit connections are secure. With that done:

- 1)Set the DISPLAY push button switch to the LASER position (out).
- 2)Adjust the COARSE and FINE output adjust knobs until the display reads the desired output current level.
- 3)Push the OUTPUT switch to the ON position (in).

The displayed current is being delivered to the load.

2.5.10 Setting the MODULATION Controls

The current output of the LDX-3620 can be controlled by an external voltage waveform. The transfer function of the modulation is 100 mA/V when the 200 mA output range is selected with the DC POWER key switch, or 250 mA/V when the 500 mA range is selected. The output current waveform should be monitored with an oscilloscope (connected across a resistor in series with the load) when making adjustments. The current LIMIT circuit may clip the output waveform. Also, trying to drive a negative current will cause the output stage internally to go to the rail. In that case, the output is slew rate-limited when the control voltage goes positive and tries to drive a positive current output. This can cause a non-linear output waveform. However, this will not cause a negative current to flow in the laser diode.

- 1)Connect the external modulation signal to the front panel EXT input BNC jack.
- 2)Select AC or DC coupling of the input with the corresponding position of the

MODULATION selector knob.

3) Push the OUTPUT switch to the ON position (in).

4) Set any desired offset DC output current with the OUTPUT ADJUST knobs.

The output current is the sum of the level set by the OUTPUT ADJUST knobs and the current programmed by the modulation signal. The display reads the average current delivered to the load.

2.5.11 Using the Internal RAMP Generator

When the MODULATION selector switch is in the RAMP position an internal ramp generator modulates the output current with a linear ramp waveform. Adjustments of the ramp span and period should be made while using an oscilloscope to monitor the output current (i.e. voltage drop across a resistor in series with the load). The current LIMIT circuit may clip the output waveform.

- 1) Set the MODULATION selector switch to the RAMP position.
- 2) Push the OUTPUT switch to the ON position (in).
- 3) Adjust the period of the ramp with the RAMP PERIOD knob.
- 4) Adjust the peak-to-peak amplitude of the ramp with the RAMP SPAN knob.
- 5) Set any desired offset DC output current with the OUTPUT ADJUST knobs.

The display reads the average current delivered to the load.

2.5.12 Setting the Photodiode Feedback Gain

The gain of the photodiode feedback circuit should be adjusted before operating the LDX-3620 in CONST POWER mode.

IMPORTANT

The LIMIT current level MUST be correctly set before switching the MODE selector to CONST POWER and turning the OUTPUT switch ON (in). Laser damage will result if the current level is not safely set. See Section 2.5.8 for setting the LIMIT current.

- 1) Set the front panel controls to the safe initial settings of Table 2.2.
- 2) Check that the LIMIT current is correctly set (see Section 2.5.8).
- 3) Using a small, flat blade, alignment screwdriver, set the COARSE photodiode feedback gain adjustment to its maximum setting. (If an improper tool is used, you may damage the nylon screw head).

Turn the COARSE adjustment to the vertical position. (The screwdriver blade will be horizontal. This is minimum gain.) Then turn it one more click counter-clockwise (CCW) to the maximum gain setting. Refer to Figure 2.5 for the gain switch setting.

The FINE gain adjustment need not be adjusted at this time.

- 4) Turn the front panel OUTPUT ADJUST knobs to their minimum settings, fully counter-clockwise (CCW).
- 5) Turn the front panel MODE selector to the CONST POWER position.
- 6) Push the OUTPUT switch to the ON position (in).

If the OUTPUT ERROR LED does not light up at this point in the procedure, continue on to Step 8.

If at this point the OUTPUT ERROR LED lights up and indicates a current limit condition, turn off the output and check that all connections are correctly made, and that the rear panel feedback gain adjustments are at their maximum settings. Retry Step 6.

- 7) Carefully increase the output level by slowly turning the OUTPUT ADJUST knob clockwise (CW) until the desired maximum output operating level has been reached. When the desired level has been reached, proceed to Step 8.

If the desired output level cannot be reached with the COARSE output adjust knob turned fully clockwise, then:

- a) Turn the OUTPUT ADJUST knobs fully counter-clockwise (CCW) again.
- b) Set the OUTPUT switch to the OFF/SHORT position (out).
- c) Decrease the photodiode feedback gain by turning the COARSE gain switch one more click counter-clockwise (CCW).

- d) Push the OUTPUT switch to the ON position (in).
- e) Repeat Step 7.
- 8) By alternately increasing the COARSE and FINE OUTPUT ADJUST knob settings and decreasing the FINE photodiode feedback gain trimmer, a full scale setting of the OUTPUT ADJUST knobs (both fully clockwise) can be made to deliver the desired maximum output power level. If this cannot be accomplished using the FINE gain adjustment trimmer, one more repetition of Step 7 may be required.
- 9) Push the DISPLAY switch to the MONITOR position (in) to display the photodiode current.

NOTE - When in the MONITOR position the display reads the negative value of the average photodiode current. This reminds the user that the display push button switch is in the MONITOR position (in).

- 10) Adjust the MODULATION and OUTPUT ADJUST controls to set the desired output optical power levels.

2.5.13 Setting the Laser Power in CONST POWER Mode

Whenever the MODE selector switch is in the CONST POWER position, the LDX-3620 maintains the output **optical power** in proportion to the control signals derived from the MODULATION and OUTPUT ADJUST sections of the front panel. After the photodiode feedback gain has been successfully adjusted, the output **optical power** level can be set:

- 1) Set the OUTPUT switch to OFF/SHORT (out).
- 2) Turn the MODE selector to CONST POWER.
- 3) Press the DISPLAY switch to the MONITOR position (in).

When in the MONITOR position, the display will read the negative value of the average photodiode current.

- 4) Press the OUTPUT switch to the ON position (in).
- 5) Adjust the MODULATION and OUTPUT ADJUST front panel controls as in CONST CURRENT mode, but keep in mind the following:

*The output **optical power** of the laser is proportional to the MODULATION and OUTPUT ADJUST control signals to the extent that the photodiode feedback current is proportional to the output optical power. Therefore, if proportionality of **optical power** to the control signals is important, the photodiode should be used in a reverse biased photoconductive mode. If **optical power** stability alone is required, then using the feedback photodiode in a photovoltaic mode should suffice.

*In CONST POWER mode, AC MODULATION components higher than about 20 Hz are attenuated, and the resulting modulation is a combination of current-modulation and power-modulation.

Chapter 3

MAINTENANCE

3.1 Introduction

This chapter discusses the recommended procedures for maintaining the LDX-3620 in good operating condition. Section 3.2 is especially important to read for an understanding of the requirements of the battery operation of the LDX-3620. AC line voltage selection and fuse replacement are covered in Sections 3.4 and 3.5. Section 3.6 contains the procedures for calibrating the LDX-3620. Section 3.7 covers procedures for disassembly of the enclosure. Section 3.8 contains the wiring diagrams for the internal wiring connectors.

3.2 Battery Maintenance

The battery life of the LDX-3620 depends on the frequency and degree of discharge of the batteries during use. With light use and proper maintenance, the batteries should last for more than 1100 recharge cycles (about four years of daily use). With heavy use battery lifetime can be degraded by as much as 60%. This can be improved by adding an extra +12 volt battery, the 3138 "Long Life" option.

The batteries are continuously charged whenever the LDX-3620 is connected to an AC power source and the rear panel AC power switch is turned on. Full recharge of the batteries takes about 8 hours.

The data of Table 3.1 suggest that long battery life results from maintaining the batteries as fully charged as possible and that short battery life will result from the practice of waiting until a low-battery condition is indicated before recharging the batteries.

If the LDX-3620 is to be stored for long periods, the batteries should be fully recharged for eight hours every 6-9 months to prevent a permanent loss of capacity due to self-discharge.

Battery life in recharge cycles can be estimated from Table 3.1 once one calculates the average "amp-hours" drawn from the LDX-3620 between recharges. This is calculated by multiplying the average time the unit is used between recharges by the average output current setting during use. The operation time includes the time when the OUTPUT push button is OFF (out) since turning off the output simply shunts the output current through a short internal to the LDX-3620.

ESTIMATED BATTERY LIFE

<u>Average Amp-hours</u>	<u>Expected Charge/ Recharge Cycles</u>	<u>Recharge Cycles With 3138 Option</u>
1.5	1100	
2.0	700	
2.5	400	1200
3.5	300	700
4.5	200	400
7.0	*	300
9.0	*	200

***Indicates that low-battery shutdown will prevent further discharge at these points.**

Table 3.1 Estimated Battery Lifetime

3.3 Battery Replacement

The batteries may be replaced by removing the push-on electrical spade connectors and the sheet-metal tie-downs, which are held in place with 6-32 machine screws. The negative 12 volt supply battery should be replaced by a Power Sonic model PS-1212 lead-acid battery (ILX P/N 597-613-211). The positive 12 volt supply battery is a Power Sonic model PS-1245 (ILX P/N 597-613-251).

3.4 AC Line Voltage Selection

AC line voltage selection is made with jumpers on the primary windings of the power transformer. 100-130 VAC operation is selected by connecting transformer lugs 1 and 5 to the neutral AC line, and lugs 2 and 6 to the "hot" AC line. 210-240 VAC operation is selected by connecting neutral AC line to lug 1, connecting lug 2 to 5 with a jumper, and connecting the "hot" AC line to lug 6.

The transformer lugs are numbered 1 to 6, with lug 1 being nearest the mounting legs on the side-rail of the LDX-3620. The transformer wiring is accessed by removing the bottom pan of the instrument. See Figure 3.1 for the correct AC line connections.

3.5 Fuse Replacement

The AC power fuse is located on the rear panel of the LDX-3620. Should replacement be necessary, first disconnect the power cord and turn the AC POWER switch OFF. Refer to Table 3.2 for the correct fuse ratings.

FUSE REPLACEMENT GUIDE

<u>Line Voltage</u>	<u>Replacement Fuse</u>
100-130 VAC	1 Amp, 3AG, Slow Blow
210-250 VAC	1/2 Amp, 3AG, Slow Blow

Table 3.2 Fuse Replacement

3.6 Calibration

Sections 3.6.1 through 3.6.5 outline the procedures for calibrating the front panel controls. Access to the adjustment trimpots on the circuit boards will require that the top of the instrument be removed. See Section 3.7 for the removal procedure.

The equipment required for the calibration procedures must be capable of: measuring a current of 500 mA to an accuracy of approximately 0.01 mA, and measuring 1 mA to an accuracy of 0.00005 mA. A good digital multimeter with 5-1/2 digit resolution is usually adequate for this purpose. An oscilloscope is needed to calibrate the RAMP SPAN of the internal ramp generator.

IMPORTANT

Calibration of the LDX-3620 should be performed only by qualified personnel. Potentially lethal or harmful voltages are present and exposed when the top of the unit is removed.

Refer to the component layout diagrams, Figures 3.5 through 3.7, to find the locations of the adjustment trimpots referred to in these procedures.

3.6.1 Display Calibration

Connect the ammeter across the current output of the LDX-3620 to monitor the output current. Make the following settings and adjustments:

- 1) Release the DISPLAY push button to the LASER position (out).
- 2) Turn the MODULATION mode selector switch to the OFF position.
- 3) Set the MODE select switch to CONST CURRENT.
- 4) Turn the current LIMIT knob fully clockwise (CW) to its maximum setting.
- 5) Turn ON the DC POWER key switch clockwise (CW) to the 200 mA range.
- 6) Push the OUTPUT switch to its ON position (in).
- 7) Turn the output adjust knobs clockwise (CW) until the calibration ammeter reads 200.00 mA.
- 8) Adjust trimpot R133 (on the front panel board) until the display reads 200.00 mA.

- 9) Turn the DC POWER key switch counter-clockwise (CCW) to the 500 mA range setting and adjust the OUTPUT ADJUST knobs until the calibration ammeter reads 500.0 mA.

If the output cannot be adjusted to 500.0 mA at this point, then turn the OUTPUT ADJUST knobs fully clockwise to their maximum settings. Alternately adjust LIMIT pot R229 and trimmer R103 (located near the OUTPUT switch on the front panel board) until the output reaches 500.0 mA according to the following guidelines:

- a) If the OUTPUT ERROR indicator is lit, adjust LIMIT pot R229 to increase the output current until the calibration ammeter reads 500.0 mA or continue adjustment a few turns after the OUTPUT ERROR indicator turns off. If the output current has reached 500.0 mA, proceed to Step 10. If not, proceed to Step 9b.
 - b) If the OUTPUT ERROR indicator is unlit, adjust R103 to increase the output current until the calibration ammeter reads 500.0 mA or continue adjustment a few turns after the OUTPUT ERROR indicator lights. If the output current has reached 500 mA, proceed to Step 10. If not, proceed to Step 9a.
- 10) Adjust R221 (located at the top rear of the side panel board) until the display reads 500.0 mA.

3.6.2 MONITOR Current Display Calibration

When the DISPLAY push button is in the MONITOR position, the display reads the (negative) value of the current input to the photodiode feedback pins 6 and 7 of the rear panel 9-pin connector (J401).

- 1) After the display has been calibrated (see Section 3.6.1), the LDX-3620 can be used to source 1 mA to the series combination of the photodiode feedback input and calibration ammeter. Make the following connections:
 - a) Connect the positive terminal of the calibration ammeter to pin 9 of the rear panel OUTPUT connector (J401).
 - b) Connect the negative terminal of the calibration ammeter to pin 7 of the OUTPUT connector (J401).
 - c) Connect pin 6 to pin 5 of the OUTPUT connector (J401).

Select the 200 mA current range with the DC power key switch, and set the Output current to 1.00 mA with the OUTPUT ADJUST knobs.

- 2) Push the DISPLAY push button to the MONITOR position (in).
- 3) Adjust R320 (on the rear panel board) until the calibration ammeter and the LDX-3620 display readings are the same.

3.6.3 OUTPUT ADJUST Calibration

After the display has been calibrated the OUTPUT ADJUST span can be calibrated:

- 1) Repeat the settings of Steps 1-6 of Section 3.6.1.
- 2) Turn the OUTPUT ADJUST knobs fully clockwise (CW) to their maximum setting.
- 3) Adjust R103 (located on the OUTPUT side of the front panel board) until the calibration ammeter reads 200.0 mA.

3.6.4 LIMIT Current Calibration

The current LIMIT knob must be calibrated to 500 mA at its maximum setting:

- 1) Repeat the settings of Steps 1-4 of Section 3.6.1.
- 2) Turn the OUTPUT ADJUST knobs fully clockwise to their maximum settings.
- 3) Turn the DC POWER range key switch counter-clockwise (CCW) to the 500 mA position.
- 4) Adjust LIMIT pot R229 until the output current reaches 500 mA.

3.6.5 RAMP SPAN Calibration

An oscilloscope is necessary to monitor the output current waveform in order to calibrate the RAMP SPAN adjustment.

- 1) Turn the DC POWER key switch counter-clockwise (CCW) to select the 500 mA range. Set the output current LIMIT to 201.0 mA using the procedure described in Section 2.5.8.
- 2) Turn the OUTPUT ADJUST knobs fully counter-clockwise (CCW) to their minimum setting and change the output current range to 200 mA with the DC power key switch.
- 3) Connect an oscilloscope to a resistor load connected across the LDX-3620

current output.

- 4) Turn the modulation mode selector switch to the RAMP position.
- 5) Turn the RAMP SPAN adjustment knob fully clockwise (CW) to its maximum setting.
- 6) Increase the ramp amplitude (with trimmer R116 (located near the center of the front panel board) until clipping of the output by the current limit circuit at the ramp maximum can be seen on the oscilloscope. Reverse the adjustment to the point where the clipping just disappears.

3.7 Disassembly

The top cover of the LDX-3620 can be removed after extracting the two countersunk screws on the sides of the instrument near the rear panel. The cover is then removed by sliding it rearward and lifting it off. The bottom of the instrument is removed in a similar fashion.

Index

AC coupled modulation	5, 20
AC power	
connections	11
fuse replacement	29
line voltage selection	28
operation	4, 11
Bandwidth	
LOW	10, 14
selector switch	10
specification	2
Battery	
lifetime	31-32
"long-life" option	3, 27
low battery indication	7
low battery shutdown	7
maintenance	27
recharge	4, 11, 27
replacement	32
Calibration procedures	30-33
Connections and shielding	11, 15-17
Constant Current mode	
mode switch	6
operation	20-23
Constant Power	
mode switch	6
operation	14, 24
photodiode feedback connections	10, 17
photodiode feedback gain adjustment	10, 21-23
Current Limit	6, 20
DC coupled modulation	5, 20
DC power	
operation	5, 14
on/off key switch	5
Disassembly	33
Display	
calibration	30-33
mode selection	7
Fuse replacement	11, 29
Gain, feedback adjustment	10, 21-23
Grounding and shielding	11, 15-17
Interlock connections	10, 15
LIMIT current set procedure	6, 20
Long-life battery option	3, 27
Low battery	

indication	7
shutdown	7
MODE selector switch	6, 27
Modulation	
external AC and DC coupled	5, 20
internal ramp	6, 21
Operation procedures	
AC power operation	4, 11
connections and shielding	11, 15-17
CONSTANT POWER operation	14, 21-24
external modulation	5, 20
LIMIT current setting	6, 20
output level adjustment	20-21, 23-24
ramp adjustment	21
range selection	5
Output	
current level display	7
current limit	6, 20
modulation	5-6, 20-21
noise specification	2
on/off	6, 7
optical power level display	7, 23
ramp trigger	11, 17
Photodiode feedback	
connections	10, 15-16
feedback current display	7, 23
gain adjust	21-23
Pin-out, 9-pin OUTPUT connector	10, 12, 13
Rack mount option	3, 4
Ramp	
operation	6, 21
trigger output	11, 17
Safe front panel settings	15
Safety interlock	10, 15
Shielding and connections	11, 15-17
Specifications	2-3
Trigger, ramp	10, 17