

LogView

Document Module 05-07-02

LogView

Understanding LogView.....1

Modes of LogView Operation.....2
Setup.....2
Monitor.....2
System Management.....3
Communication.....3
LogView Features and Capabilities...4
Software User-Interface.....5
Control Window (Toolbar and Pull-Down Menus)5
Spreadsheet Model.....6
Help Box7
User Input.....7
File Management.....8
File Organization.....8
Data File Generation.....9
Naming Format for Data Files.....9
Customizing the File Name.....10

Procedures.....12

Flowchart of a Simple Acquisition...13
Using an Attached LogBook.....13
Using LogBook “Unattached”.....15
Simple Data Logging.....15
Setting Up DBK Cards.....17
Using Multiple Timebases.....18
Using Digital 2-Point Calibration.....21
Using Digital Outputs As Alarms.....22
Using Exception Capturing.....24

Menu Descriptions.....25

File Menu.....25

N <u>e</u> w.....25
O <u>o</u> pen.....25
S <u>a</u> ve/Save <u>A</u> s.....26
U <u>p</u> load.....26
D <u>o</u> wnload/Download <u>A</u> s.....28
C <u>o</u> nfiguration Report..... 28
A <u>b</u> out <i>LogView</i> 29
A <u>u</u> thorization 29
E <u>x</u> it.....29

View Menu.....30

Hardware Configuration.....30
Analog Input Channel Configuration.....31
Digital and Counter Input Channel Configuration.....35
Output Channels Configuration.....36
Serial / GPS Channels (LogBook/360 Only).. 37
Calculated-Channel Configuration.....37
Equation Assistant 38
Bitwise Operators40
Logical Operators 40
Examples of Calculated Channels..... 41
Acquisition Configuration.....43
Trigger Parameters Setup 43
Scan Rate Setup 44
Event Marking/Time Stamping.....45
Preferences.....46

Device Menu.....48

Select PC-Card.....48
Select LogBook.....48
Attach.....48
Break.....48
Arm Acquisition.....48
Stop Acquisition.....48
LogBook Monitor49
Explorer.....50

Tools Menu.....51

Convert Binary Data.....51
Merging Binary Data.....53
View Data 54

Indicators Menu.....55

Bar Graph Meters.....55
Analog Meters.....55
Digital Meters.....56
Meters Configuration.....56
Enable Input Reading Column.....58
Start (or Stop) All Indicators.....58


Understanding LogView

LogView provides for easy setup and operation of LogBook. *LogView*'s flexibility can handle virtually any data-acquisition environment. The graphical Windows interface can display a variety of spreadsheets, dialog boxes, graphs, charts, and meters; and accepts user input from a mouse and keyboard. The easy-to-learn interface does not require programming or the configuration block diagrams.

It is important to understand the central role of the PC-Card in LogBook/*LogView* operation. When LogBook operates in a *stand-alone mode* (not attached to the PC), *LogView* must download the system and acquisition setup files to a PC-Card. The PC-Card must then be manually transferred to LogBook. Later LogBook's PC-Card must be transferred back to the PC for uploading. When LogBook and PC are attached in direct communication, *LogView* can download to [or upload from] LogBook in real time via the communications link.

Modes of LogView Operation

The next figure outlines *LogView's* functional modes to help you visualize what *LogView* can do. This functional organization is not the same as the menu organization.



Setup

System **Setup** includes the hardware, the channels in the scan, and the triggering. Before data acquisition can begin, all setups must be complete and the resulting setup file downloaded to the PC-Card in LogBook.

- **Hardware Configuration** asks you to set the software parameters to match your hardware. For some DBKs, you may need to adjust the DBK's jumpers and DIP switches—or at least verify that the *LogView* software setting matches the [DBK hardware setting \(pg. 30\)](#).
- **Channel Setup** pertains to using *LogView* to set the different types of channel parameters. These include label, On/off, range, units, format, user scaling, storage rates, and DBK software parameters. The types of channels that are set up through *LogView* are: [Analog Input \(pg. 31\)](#), [Digital Input \(pg.35\)](#), [Output Channels \(pg.36\)](#), [GPS/Serial Input \(pg.37\)](#), and [Calculated Channels \(pg.37\)](#). The flexibility of the Calculated Channel allows you to create a virtual channel based on math and logic functions of real channels (analog and digital), other virtual channels, and arbitrary numerical values.
- **Acquisition Configuration** asks you to determine when, how often, and for how long to get data readings. [Trigger/pre-trigger/post-trigger conditions](#) and [timebases](#) are discussed on [page pg.43](#).
- **System Calibration** allows you to perform 1- or 2-pt calibrations to fine-tune system accuracy.

Monitor

- **Monitor Acquisition.** In real-time, *LogView* can display system parameters and channel values in a spreadsheet style. If so desired, readings can be formatted into [bargraphs](#), [analog meters](#), and [digital indicators \(pg.55\)](#).
- **LogBook Monitor** shows you the status of the current acquisition and the LogBook system ([pg.49](#)).
- **Programmed Digital Outputs Used As Alarms.** The monitoring function can be automated via calculated channels and digital outputs to engage alarms when pre-defined conditions occur.
- **Display Recorded Data.** allows you to graphically view previously recorded data for analysis and comparison via a post-acquisition “view” program. The applicable “view” application is covered by PDF documentation that is automatically installed onto your PC's hard-drive as a part of LogBook product support, during software installation.

System Management

LogView allows you to manage aspects of an acquisition in progress and file saving/conversion:

- **Direct Acquisition Controls** of LogBook include manual triggering and setting reference marks (via [LogBook Monitor, pg.49](#)) and starting/stopping an acquisition. In these ways, *LogView* gives you immediate access to LogBook operation.
- **File Management** includes managing data/configuration files and converting data file formats. The *LogView* Explorer window allows you to manage files on the PC-Card.

Communication


Communication between *LogView* and LogBook is actually between the PC and a PC-Card. During the communication, the PC-Card can reside in a LogBook for **direct (attached) communication** or in the PC's PC-Card socket for **indirect (unattached) communication** (and later manually transferred to LogBook).

Whether direct or indirect, communication involves downloading and uploading:

- **Downloading** sends the acquisition setup file (created in *LogView's* Setup mode) to LogBook's PC-Card. LogBook uses the setup file to run the acquisition (also needs `logbook.sys`).
- **Uploading** receives recorded data from LogBook's PC-Card. After the data has been collected and temporarily saved on LogBook's PC-Card, the data must be uploaded to *LogView* for processing, conversion, use in other programs, and/or archival saving.


In the **Direct (Attached) Communication** mode, communication occurs through the electronic connection (cabling via serial or parallel port). While attached, LogBook can do 2-point calibration, look at current readings, and download/upload without handling the PC-Card.

Note: In some cases, data transfer may be faster by placing LogBook's PC-Card in the computer's PC-Card socket and bypassing the attached communication.



In the **Indirect (Unattached) Communication** mode, no electrical connection exists between the PC and LogBook. A PC-Card carrying the setup file and/or data must be physically transported between the PC and LogBook.

Note: The LBK1 remote operation terminal can be used with an unattached LogBook for limited control and monitoring. The LBK1 option is detailed in chapter 5 of the LogBook User's Manual.



LogView Features and Capabilities

In setting up an acquisition, LogView can:

- Configure parameters for all input, output, and calculated channels without using special programming skills.
- Provide flexible triggering to acquire continuous data, capture exceptions or, to trigger based on calculated channels.
- Configure and operate expansion chassis, including the DBK option cards and modules designed for various signal-conditioning environments.
- Provide utilities (convert units, calibrate sensors, calculate channels, control outputs/alarms, etc).

In handling data, LogView can:

- Download an acquisition setup file to a PC-Card for physical transport to a remote LogBook, or send the setup file directly to the PC-Card in a LogBook via the serial or parallel port.
- Upload the recorded data from LogBook by corresponding means.
- Create files for use by other Windows programs; e.g., database or analysis.

Utility-wise, LogView can:

- Calibrate all gains and offsets on a per-channel basis.
- Launch a separate “view” program that allows you to graphically view pre-recorded data.
- Interact with LogBook while the acquisition is taking place including manual trigger and event marking.

In monitoring an acquisition, LogView can:

- Display readings and status in real-time. On-screen indicators provide channel feedback during an acquisition. Channel values can be displayed in charts, bar graphs, analog meters, or digital readouts.
- Show system status including trigger status, errors, alarms, etc.

Software User-Interface

LogView's user-interface uses a control window with toolbar/menus and a spreadsheet model. Similar to other Windows-based programs, *LogView's* user interface will seem familiar and intuitive. Windows can be sized and placed to best fit your application. Several different meter styles are available to monitor data in real time if so desired.


Control Window (Pull-Down Menus and Toolbars)

File	View	Device	Tools	Indicators
New	Hardware Configuration	Select PC Card	Convert Binary Data	Bar Graph Meters
Open	Analog Input Channels	Select LogBook	Merge Binary Data	Analog Meters
Save	Digital Input Channels	Attach	View Data	Digital Meters
Save As	Output Channels	Break		Enable Input Reading Column
Download	GPS/Serial Input Channels	Arm Acquisition		Start All Indicators
Upload	Calculated Channels	Stop Acquisition		Stop All Indicators
Download As	Acquisition Configuration	LogBook Monitor		
Configuration Report	Preferences	Explorer		
About LogView				
Authorization				
Exit				


LogView Pull-down Menu Selections

LogView pull-down menus, represented by the above table are discussed in the section, *Menu Descriptions*. The following figure shows *LogView's* control window. Note that two sets of toolbar buttons reside just below the menu row.

Toolbar commands can be accessed in two ways: (1) via toolbar, or (2) via pull-down menu selection. Note that the pull-down menus include additional commands that do not have associated toolbar buttons.



LogView Control Window – LogBook Unattached



LogView Control Window – LogBook Attached

Legend


- | | |
|---|---|
| <ul style="list-style-type: none"> 1 – New Setup File 2 – Open Setup File 3 – Save Setup File 4 – Break PC from LogBook (<i>Shows when PC is attached</i>), or
– Attach PC to LogBook (<i>Shows when PC is unattached</i>) 5 – DownLoad to LogBook (<i>Shows when PC is attached</i>), or
– DownLoad to PC-Card (<i>Shows when PC is unattached</i>) 6 – UpLoad Acquisition Setup & Data to LogBook
(<i>Shows when PC is attached</i>), or
– UpLoad Acquisition Setup & Data to PC-Card
(<i>Shows when PC is unattached</i>) 7 – Arm (Start) Acquisition | <ul style="list-style-type: none"> 8 – Stop Acquisition 9 – Hardware Configuration 10 – Analog Input Setup 11 – Digital Input Setup 12 – Output I/O Setup 13 – GPS (Global Positioning System) / Serial IN Setup Option 14 – Calculated IN Channel Setup 15 – Acquisition Configuration 16 – View Data [via a post acquisition view application] |
|---|---|

Spreadsheet Model

LogView's interface uses a **spreadsheet model** of cells in rows and columns (see next figure):

- **Each row is a different channel.** Individually-controlled channels can be hardware-based or calculated; channels can be identified with user-specified labels.
- **Each column is a parameter related to the channel.** Some parameters can be user-set (user label, sample rate, etc.); others are read only (physical channel, readings from transducers, etc.).

Note: Generally, cells that are “grayed-out” rather than black are not subject to user input (e.g. physical channel, channel type); however, grayed-out Sample Rates under the Storage tab can be changed in the Acquisition Configuration Window.



Analog Input Channel Configuration Window, Spreadsheet Portion

LogView's spreadsheet-style setup provides a simple method of both viewing and configuring the parameters of the input, output, and calculated channels. Several spreadsheets are needed to display all the channels' parameters. *LogView's* spreadsheet windows include:

- **Analog Input Channel Configuration** (see page pg.31 for details) - This default-opening window has more parameter columns than will fit in view at one time. Therefore, the left-most (white) columns are shown in every view; these parameters include: Physical Channel, User Label, On/Off, Reading, Range, Units, and Channel Type. The right-most (shaded) columns vary depending on which folder tab is selected. Each tab (Storage, DBK Parameters, User Scaling, and 2-Point Calibration) has tab-specific parameters.
- **Digital and Counter Input Channel Configuration** (see page pg.35) - LogBook has three 8-bit digital ports and one high-speed 16-bit port configurable as inputs or outputs. Digital expansion cards can provide up to 192 digital bits. There are also 4 pulse-input ports that can count pulses for summing and/or frequency measurement.
- **Output-Channels Configuration** (see page pg.36) - This window shows all the currently-available digital and analog output channels. Each output channel is fed by a user-set source channel. Source channels can be chosen from any of the input (hardware) channels or calculated (virtual) channels.
- **Calculated-Channel Configuration** (see page pg.37) - *LogView* can derive virtual channels using standard math operators and functions (<, >, min, max., etc.). Virtual channels can be used to create alarms, reduce data statistically, develop sophisticated trigger equations, and manipulate input channel values for more useful output including simple control systems.


Help Box

The bottom of the spreadsheet contains a context sensitive Help Box for the selected field. As you configure channel parameters, the Help box identifies the field and provides pertinent user information. An example, taken from the previous figure, follows.

Example: In the above figure the User Label cell (of channel 1) is selected. The Help box identifies the field as "User-specified channel label" and states user options. In this case, they are (1) to type in a desired label, i.e., to provide the channel with more meaningful name [not to exceed 16 characters]; or (2) keep the default label of P1_CH00.

User Input

To set up channel parameters, first select the appropriate cell (highlighted in a bold box) with the mouse or keyboard arrow keys (up/down/sideways). Some cells allow you to key-in values from a keyboard (values such as user labels, offsets, etc.). When key-in cells are selected, a user-input box will appear where you can type in characters as needed (e.g., channel label in previous figure). Some cells allow you to choose the desired setting from a drop-down list; you select among the options, and the parameter is set. Other cells allow you to set numeric values with "spinner" up/down arrows that change the value incrementally (selecting a point between the spinners changes the mouse action into a virtual scroll bar—as you drag the mouse vertically, the numeric values change accordingly).



User-set parameters can be set individually per channel, or the same value can be “filled down” for an entire column. To apply the same column setting to multiple channels, use the spreadsheet’s **fill-down** feature. Select multiple cells in a column by dragging the mouse with the left mouse button (or using the <Shift> and arrow keys). **Enable the fill-down feature with the right mouse button.**

As a shortcut to toggle channel readings on or off, you can place the cursor in the Reading column and double-click the mouse. Another alternative is to double-click the column title, and every channel value in the column will change to the next value if such a value is list-selectable. Globally, you can switch all channel readings in the Indicators menu as Start All Indicators and Stop All Indicators.



For program windows that exhibit an “Apply” button, note that parameter changes will not be locked-in until the Apply button has been pressed (clicked).

File Management


LogView uses various types of files for its operation:

- **System.** **logbook.sys** is the file that actually operates LogBook. The file must reside on the PC-Card in LogBook in order for the system to power-on and work properly. All PC-Cards used with LogBook need to have the **logbook.sys** file.
- **Setup (Acquisition Configuration).** The filename extension for the acquisition setup file is **.LVC** (from *LogView* Configuration). This file is downloaded to LogBook’s PC-Card. The file contains parameter details for a particular acquisition (as configured in *LogView*). When swapping PC-Cards in a remote LogBook, the new PC-Card should have the same **.LVC** file.
- **Data.** Names for the data files use a long format convention as described below. The Preferences window from the View pull-down menu allows you to customize how your data files will be named.

File Organization

As data is uploaded to the PC, *LogView* first uploads the raw data file(s) and then converts them into the formats specified in the Preferences window. The raw binary files are placed in the DATA directory in the path specified during a configuration save. If the configuration was never saved the DATA directory will be created in the *LogView* working directory.

LogView creates a sub-directory within DATA for each file format selected. The figure to the right represents a typical file structure.



Data Filename Generation

Uploading can create one data file or many data files. A simple, completed data collection with one timebase will produce only one data file. More complex conditions will create multiple data files. When these conditions exist, *LogView* creates a *file-set* rather than a single file.

These **configurations** will create multiple data files during an upload.

- With multiple timebases enabled, *LogView* generates a separate file for each rate.
- With Auto Re-arm set greater than 0, multiple trigger blocks will be collected—each in a separate file.

These **events** will generate multiple file-sets.

- When LogBook configuration is re-armed through *LogView* or by cycling LogBook’s power, a new file-set is created.
- When a partial upload takes place with an attached LogBook, a new file-set is created.
- When a partial upload takes place from a PC-Card in the PC’s socket, a new file-set is created.

A partial upload saves part of the data from an active acquisition. Three ways to perform a partial upload:


- a) During an acquisition, connect your PC to LogBook and execute an upload. To make room for additional data, the uploaded data is deleted from the PC-Card.
- b) During an acquisition, swap the PC-Card in LogBook with a different card. Then insert the card into your PC, and perform an upload.
- c) Start an upload of any kind; then click Cancel while the upload is taking place.

Naming Format for Data Files


LogView names uploaded data files to make them easy to identify and organize. The File Converter Preferences window (Represented below) allows you to customize *LogView*’s naming process to suit your needs. Navigate as follows to access the window: View Pull-down menu ⇒ Preferences ⇒ File Converter. Preferences can be set so:

- Files will not be accidentally overwritten
- The use of several LogBooks is easy to manage.
- Test times and dates automatically embedded
- It is easy to identify files that are part of the same acquisition

The figure and table below define the full-field format for data files. As described in the next section, you may wish to turn off unneeded fields for simplicity.




seed	User-supplied identifier string (e.g., TOM1) provides easy identification of files associated with a specific test, person, or device-under-test.
#zzzzzz	When multiple LogBooks are being used, the 6-digit serial number identifies which LogBook was used to collect the data.
Ddd-mm-yy	The Date field represents the date the acquisition was initially armed. This date is not necessarily the date when the data was actually collected. It is possible LogBook was armed on Thursday but did not trigger until Saturday. The file-last-modified date shown as a file attribute in Windows Explorer (not LogView Explorer) is the date the file was uploaded to the PC.
Thh-mm-ss	The Time field represents the time the acquisition was initially armed. This time is not necessarily the time when the data was actually collected. It is possible LogBook was armed at noon but did not trigger until 2:00pm. The file-last-modified time shown as a file attribute in Windows Explorer (not LogView Explorer) is the date the file was uploaded to the PC.
Rx	The Rate field holds a number from 1 to 4 representing the scan rate for the file. If channels are stored at more than one rate, a file is created for each rate.
Bx-y	The Block field holds 2 numbers: x is the trigger block number, and y is the segment of the trigger block. A trigger block is segmented when partial uploads take place. Typically, y will be 1 when the entire trigger block is uploaded at once. The numbers are generated chronologically as they occur.
.ext	The filename extension for the data files and their explanatory header files (see following figure)



File Converter Preferences Window

This window is reached by navigating as follows: View Pull-down menu ⇒ Preferences ⇒ File Converter

Customizing the File Name



LogView Preferences Window, Upload Tab Selected

This window is reached by navigating as follows:
View Pull-down menu ⇒ Preferences ⇒ Upload Tab

Under certain conditions, all filename fields may not be needed. To turn off fields, simply enable or disable the check boxes in the **Upload tab of the Preferences window** (see figure here [and discussion on page pg.46](#)). Be aware that simplifying the filename removes the safeguards to prevent 2 files having the same name and causing an overwrite/lost information condition. If fields are disabled, overwrites are more likely to occur.

The following table suggests when it is safe to turn off various filename fields.

Condition	Recommendation
I want to overwrite old data every time I perform an upload.	No optional fields are required.
I only have one LogBook.	Turn off LogBook serial number field.
I use a new seed every time I upload.	Only the seed option is needed.
I often accumulate multiple acquisitions on the PC-Card and want to upload them at one time.	Make sure at least the time field is enabled; otherwise, acquisitions will be overwritten as they are uploaded.
I never perform partial uploads.	Don't need block number.

Example of all parameters: LAB1 #123456 D03-15-98 T12-04-12 R1 B1-1

SEED (user description string) = "LAB1"

LogBook serial number = 123456

Date armed = March 15, 1998

Time armed = 12:04:12PM

Rate = 1

Trigger block = 1, Segment = 1

Simplest application. If a new acquisition is uploaded, this file will be overwritten: R1 B1-1

Rate = 1

Trigger block = 1, Segment = 1


If all acquisitions are performed in the same day, the time can identify the files: T12-04-12 R1 B1-1

Time = 12:04:12pm

Rate = 1

Trigger block = 1, Segment = 1

The example below shows data files from an acquisition with 2 trigger blocks and 2 timebases; the acquisition was uploaded in segments. All the dates and times are the same because these trigger blocks are all part of the same acquisition. The first two files represent a continuous data collection—2 files exist because of partial uploads.



Example of Data Uploaded in Segments

Procedures


Because of *LogView's* flexibility, this manual can not detail every possible use of the system. Instead, these procedures explain how to perform typical tasks. Understanding these tasks will help you apply the principles to a variety of data acquisition environments. For your particular application, you may need to combine or alter these procedures. For more details, you may need to refer to related Menu Descriptions or procedures.

This section begins with a flowchart of a simple acquisition and then explains the following tasks and operational modes:

- Using an Attached LogBook.....pg. 13
- Using LogBook "Unattached".....pg. 15
- Simple Data Logging.....pg. 15
- Setting Up DBK Cards.....pg. 17
- Using Multiple Timebases.....pg. 18
- Using Digital 2-Point Calibration.....pg. 19
- Using Digital Outputs As Alarms...pg. 22
- Using Exception Capturing.....pg. 24

Flowchart of a Simple Acquisition


Consider the flowchart of a simple data acquisition. Whether LogBook is attached or unattached, the process is similar except for downloading and uploading. You begin the process in *LogView* by defining the parameters for an acquisition.



Basic Operational Flow of a LogBook Acquisition


Using an Attached LogBook

When using an attached LogBook, *LogView* communicates directly to the PC-Card in LogBook through the communication interface (serial or parallel).



After *LogView* recognizes the attached LogBook, an acquisition setup file can be downloaded to LogBook. After the acquisition, data can be uploaded from LogBook without handling the PC-Card. Note that steps 1 through 4 are often done during the initial installation.

1. On your PC with *LogView* already loaded, open control panel applet, and check Hardware Configuration. If no LogBook is present in the tree, click Add Device and a LogBook ID; otherwise, select a LogBook in the tree and click Properties.
2. Under LogBook Properties tab, enter or verify device name, the connection type, the protocol, a timeout duration; and then click Apply.
3. (if serial connection) Under Port Settings tab, select baud rate and related parameters; and then click Apply.
4. Verify proper LogBook connection and power-on; then, under the Test Hardware tab after, click the Test button. Testing will verify system parameters and then bench-mark system communication performance.



5. Launch *LogView* from your PC (unless you set up a shortcut, you can find *LogView* in the Programs group in the Start menu). The control window and the Analog Input Channel Configuration window should appear.
6. Under the Device menu in the control window, click Select LogBook. From the drop down list, select LogBook you just configured in the hardware tree; then click the Attach icon to establish a communications link. The Upload and DownLoad buttons in the Control Window should now be enabled (*LogView* recognizes when LogBook is attached and enables the applicable tools as seen by their lettering turning from gray to black).



7. In *LogView*'s [Analog Input Channel Configuration](#) (see page pg. 31) and [Acquisition Configuration](#) (see page pg. 43) windows, set up the channels and trigger parameters you wish to use (see [Simple Data Logging](#), page pg. 15).
8. Download the acquisition setup file just configured to LogBook
9. Click the Arm Acquisition button (▶). LogBook is now armed and ready to collect data when the trigger parameter is satisfied.
10. During the acquisition, you can monitor system status via LogBook Monitor window accessed from the Device pull-down menu. To verify proper operation, such monitoring is recommended for the first run of a new acquisition setup file.
11. After collecting data, click [Upload to pull the data into the PC](#) (see page pg. 26). Depending on the communication channel and size of data files, uploads take a variable amount of time. Uploads can also be done incrementally during an acquisition.

The next time you launch *LogView*, it will automatically look for the selected LogBook and attempt to attach itself. At this point, *LogView* and LogBook will be in constant communication. If you want to turn off LogBook's power or detach the communication cable, you should first select Break from the Device menu or Exit from the File menu.



PC-Cards purchased with LogBook have been initialized at the factory. PC-Cards purchased elsewhere must be initialized through *LogView*. The initialization procedure is discussed in the following paragraph.

Initializing a PC-Card


PC-Cards, that were purchased with LogBook, have been initialized. **PC-Cards purchased elsewhere must be initialized.** Initialization is accomplished as follows:

1. Place the PC-Card in the PC's corresponding socket.
2. Select the driver according to your card's documentation.
3. In *LogView*, under the Device menu, click Select PC-Card, then click OK.

LogView will check the card and initialize it as needed.

Using LogBook “Unattached”

When using a LogBook “unattached,” *LogView* does not communicate in real time with LogBook; instead, *LogView* downloads the acquisition setup file to a local PC-Card that can later be manually transferred to LogBook.



After the acquisition is complete, the PC-Card that collected data in LogBook must be manually transferred to the PC where *LogView* can then upload the data. The PC-Card must first be properly initialized :

1. Take any ATA PC-Card memory device, and insert it into a corresponding socket on the PC. If this is the 1st time this type of card has been inserted, Windows may require driver information. Follow the on-screen instructions, or refer to the documentation included with the PC-Card.
2. Launch *LogView* from your PC (unless you set up a shortcut, you can find *LogView* in the Programs group in the Start menu). The control window and the Analog Input Channel Configuration window should appear.
3. Under the Device menu, click Select PC-Card. Use the drop down list to tell *LogView* which drive letter is associated with the PC-Card. Note: as PC-Cards are inserted and removed from the sockets, Windows will arbitrarily assign drive letters. If 2 PC-Cards occupy 2 sockets, the order of their insertion usually dictates the assignment of drive letters. The Attach, Upload, and Download buttons on the Control Window should now be enabled.
4. In *LogView*'s Analog Input Channel Configuration and Acquisition Configuration windows, set up the channels and trigger parameters you wish to use (see *Simple Data Logging* below).
5. Download the acquisition setup file (**logbook.sys** will also be downloaded if not already present).
6. Eject (remove) the PC-Card from the PC socket, and transport it to the remote LogBook site. Insert the PC-Card into LogBook's socket, and power up LogBook. LogBook will automatically load the setup file and arm the system.
7. After the remote LogBook has collected all the data, remove the PC-Card from LogBook's socket, transport it to the PC, and insert it into the PC's socket. If *LogView* is running, it will soon recognize the presence of the card and enable the Upload and Download buttons.
8. Click Upload to pull the data into the PC.



After telling *LogView* which drive letters are associated with PC-Card disks, *LogView* will periodically poll the system for their presence. As cards are inserted and ejected, *LogView* will automatically enable and disable the Upload and Download buttons.





If a large quantity of data will be recorded, you should return to the remote LogBook in time to swap PC-Cards [before the first card is full]. Card swapping is discussed in the introduction chapter of the user's manual. All PC-Cards to be swapped must first be initialized as discussed in the previous section.

Simple Data Logging

To log data, you need to configure the hardware, set up the channels, and configure the acquisition parameters. The following steps are generic and will vary with different applications.


1. Launch *LogView*, and Attach *LogView* to your Logbook if working in an attached mode or to a PC-Card inserted in your PC if working in a remote, unattached mode (see previous 2 procedures if necessary).
2. Select New under the File menu or the “New” button, and give the acquisition setup file a name relevant to your application.
3. Click the Analog Input button to display the setup grid in the Analog Input Channel Configuration window. Turn all but the 1st 4 channels off (or as applicable) by placing the cursor in the On/Off column and double-clicking to toggle the setting on and off (unused channels that are left ON will limit the maximum scan rate possible). To change the Range for a particular channel, click the cursor on the affected and then use the drop down user input box to select an appropriate range (can be bipolar or unipolar).






Selecting Input Range for Channel P1-CH02

- Click the Digital Input button. Turn all the digital channels “Off”—or “On” as applicable.
- Click the Acquisition Configuration button or select that submenu from the View pull-down menu, and the Acquisition Configuration window will appear.
- From the Acquisition Configuration window, select all the parameters that define your desired acquisition. Under the Trigger tab, select Immediate as the trigger if you want to start the acquisition the moment the system is armed. Under the Post Trigger tab, select a duration of 1 minute. In the Scan Rate frame, set Base Rate A to 5 Hz (or as applicable) by typing in a value and selecting the proper unit.



Acquisition Configuration Window

- After verifying that all settings are as you desire, select Save under the File menu and associate a name to your acquisition setup file (if not already done so).
- From the main toolbar, click the Download button to send the setup file to LogBook’s PC-Card.
- To arm an attached LogBook, click the Arm button.
- To arm a remote LogBook, eject the PC-Card, transport it to LogBook, insert it into LogBook’s socket, and then apply power.
- To upload data from an attached LogBook during an acquisition or after the acquisition is complete, click the Upload button.
- To upload data from a remote LogBook after the acquisition is complete or as part of card swapping, eject the PC-Card from LogBook and transport to the PC’s socket; then click the Upload button.
- To inspect the data, click the View Data button. This will activate a “view” program, if installed.



or



or




Setting Up DBK Cards

DBK cards and modules provide channel expansion and signal conditioning. For proper operation, you must use *LogView* for software configuration of the DBK cards. All hardware configuration-related parameters can be found in the *LogBook Hardware Configuration Window* (sometimes referred to as a “hardware tree”).




Reference Note: The *DBK Option Cards and Modules User's Manual* (p/n 457-0905) contains parameter definitions and information as to which parameters are set in hardware and which are set in software.

1. Open the *LogBook Hardware Configuration Window* by clicking the Hardware Configuration button.
2. To add analog input DBKs, select P1 Analog I/O in the tree, and set its property to Single-ended. Digital DBKs use P2 port and are set up in a similar way.
3. Select a channel and assign it either a local channel or a specific DBK expansion module that will multiplex several channels into the same main channel. See following figure.



Setting Analog I/O Channel P1_CH00, DBK52 T/C Card Selected

4. Most DBKs have related cards and sub-channels as part of their method to multiplex up to 16 channels into each main channel. Click the appropriate checkboxes to set up the channels; and then OK to accept these settings. See following figure.



Selecting Applicable DBK4 Dynamic Signal Cards

5. Click the Analog Input button to view the newly setup channels in the [Analog Input Channel Configuration spreadsheet](#) (see page 31). Verify all channel numbers and assign user labels as desired.



Note: In some cases, such as with DBK19, channel values are returned in units of temperature, instead of volts.

6. From the *Analog Input Channel Configuration window*, select the DBK Parameters tab to view specific settings for each DBK channel. Set the DBK parameters at this time. If necessary, refer to the appropriate section of the *DBK Option Cards and Modules User's Manual* for an explanation of the parameters; for example, DBK4 programmable filter values and DBK7 debouncing times.



You can resize the *Analog Input Channel Configuration window* by dragging its right edge further to the right. This allows you to see up to four parameters for each channel.

Channel Configuration									
DBK4 Filter Cut-Off Frequency: 9.0 kHz									
Storage			DBK		User Scaling		2-Point Cal		
#	Physical Channel	User Label	Range	Units	Channel Type	DBK Parameters			
						Param.1	Param.2	Param.3	Param.4
1	P1_CH00_0_0	P1_CH00_0	0.0000 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=18.0 kHz	Exct=Enable	Clk=Enable
2	P1_CH00_0_1	P1_CH00_0	0.0000 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=18.0 kHz	Exct=Disable	Clk=Disable
3	P1_CH00_1_0	P1_CH00_1_0 On	-3.159 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=9.0 kHz	Exct=Disable	Clk=Enable
4	P1_CH00_1_1	P1_CH00_1_1 On	-3.159 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=18.0 kHz	Exct=Enable	Clk=Enable

Setting DBK Parameters in the Analog Input Channel Configuration Window

When configuring DBKs, the *LogBook Hardware Configuration Window* provides a means of setting up all manual hardware settings. Once configured, the analog and digital channel setup spreadsheets provide a means of setting up channel-specific, programmable features.



Some DBKs have hardware settings that must be manually set inside the DBK, such as jumpers or DIP switches. In these cases the parameter setting in *LogView* must match the actual hardware. Setting one does not automatically set the other; in other words, you must make configuration settings in both software and hardware, when applicable.

For specific DBK hardware configuration refer to the appropriate section of the *DBK Option Cards & Modules User's Manuals* (p/n 457-0905).

Using Multiple Timebases

LogBook is capable of storing channels at 4 independent timebases (one base rate and 3 rates that are divisions of the base rate). Two reasons for using multiple timebases are: first, to reduce the amount of storage required by saving slow channels at a slow rate—acquisition can last longer before filling up the PC-Card; and second, to provide noise reduction by averaging and thus enhance the value of the data.

1. Open the [Acquisition Configuration](#) window (see page pg. 43) by clicking the Acquisition Configuration button.
2. In the scan rate frame at the right of the window, set the Base Rate A to the maximum frequency required for any channel.



	Frequency	Divider
Base Rate A:	18 kHz	1
Rate B:	9000.0 Hz	2
Rate C:	4500.0 Hz	4
Rate D:	2250.0 Hz	8

Acquisition Configuration Window

3. Check all three rate checkboxes B, C, D. Type in a divider for rates B through D to create sub-rate sampling frequencies which are based on Base Rate A. *LogView* will compute and display the corresponding rates in frequency or period units.

Note: The higher the divider (right most column) the slower the scan rate.

- To reduce noise in sensitive channels like thermocouples, these channels can be sampled at a high rate but stored at a slower rate after mathematically averaging the intermediate values. By checking the Apply Noise Reduction Averaging checkbox, channels stored at a sub-rate will store the average of all of the values collected at the Base Rate A. Extraneous values that are obvious errors will have less effect on the data—it's also possible to set up a calculated channel that only accepts values within a defined range.
- Close the *Acquisition Configuration Window*.
- Click the Analog Input button to display the Analog Input Channel Configuration window. Under the Storage tab, note that the newly configured sample rates are enabled. The sample rate columns determine the rate at which each channel's data will be stored. Each enabled (On) channel can have data stored at sample rates A, B, C, D (or a combination, there of), see following figure.

#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	Sample Rates			
								A	B	C	D
1	P1_CH00_0_0	P1_CH00_0_0	On		-3.159 to 3.159	Volt	DBK4	Yes	Yes	Yes	Yes
2	P1_CH00_0_1	P1_CH00_0_1	On		-1.579 to 1.579	Volt	DBK4	Yes	Yes	No	Yes
3	P1_CH00_1_0	P1_CH00_1_0	On		-3.159 to 3.159	Volt	DBK4	Yes	No	Yes	No
4	P1_CH00_1_1	P1_CH00_1_1	On		-0.079 to 0.079	Volt	DBK4	Yes	No	No	No

Setting Sample Rates for Data Storage. Each enabled channel can be assigned up to four rates.

- Set the cells in these four columns to **Yes** or **No**, as desired, for all enabled (On) channels. Channels shown as “Off” are not sampled.
- Once configured, download the acquisition setup file, and initiate data collection.


Using Digital 2-Point Calibration



Remote LogBooks can not be calibrated. 2-point calibration can only be performed when LogBook is attached to the PC via a communication interface.

2-point calibration allows you to mathematically “trim out” inaccuracies in the measurement equipment and/or the transducer. By allowing the equipment to measure 2 known points in the measurement range, LogBook can calculate [linear constants \(the scale and offset\) to correct inaccuracies in its analog inputs \(see page pg. 33\)](#). For channels where only one known point can be applied and verified, *LogView* provides offset trimming.

- Click the **Attach** button to establish communication with LogBook.
- Click the **Analog Input** button to open the analog input spreadsheet.
- Click the 2-Point Calibration tab to expose the calibration columns. If some columns are obscured, scroll to the right to reveal them or resize the window by dragging the right edge further to the right. Note that the default **Cal Scale** and **Cal Offset** [mathematically applied to each channel] are 1 and 0, respectively (right-most columns).



Analog Input Channel Configuration, 2-Point Cal Tab Selected

Channel Type	2-Point Calibration							
	Set P1	Actual P1	Get P1	Set P2	Actual P2	Get P2	Cal Scale	Cal Offset
Direct	0.1		Execute	1.15		Execute	1.0	0.0
Direct			Execute			Execute	1.0	0.0
Direct			Execute			Execute	1.0	0.0

2-Point Cal Tab, Partial Close-up


4. Apply a voltage to channel 1 near the bottom end of the measurement range.
5. Type the known value into the **Set P1** column for the associated channel.
6. Click the Execute button under the **Get P1** heading. This allows you to read the channel and calculate the required offset. Note that the channel value read is now shown in the **Actual P1** column and the **Cal Offset** column now shows the correction factor.
7. Apply a voltage to channel 1 near the top of the measurement range.
8. Type the known value into the **Set P2** column for the associated channel.
9. Click the Execute button under the **Get P2** heading to read the channel and calculate the required offset and scale. Note that the channel value is now shown in the **Actual P2** column. The **Cal Offset** and **Cal Scale** columns now show the correction factors.



For channels using thermocouples, it may be impractical to provide more than one calibration point. In such cases, apply just one known point in Set P1, and click the corresponding Execute button. This will adjust the offset only, which is typically the source of most transducer error.



For strain gages, use the User Scaling tab to enter the transducers' transfer functions (e.g., volts to pounds), then use 2-point calibration to periodically trim the scale and offset. This eliminates the need to manually adjust sensors using hardware potentiometers.



User Scaling. Final Reading = Scale*RawReading + Offset

An Example of Using LogView for 2-Point Calibration

Once the trimpots have been physically adjusted during initial installation, periodic trimming can be performed through LogView's 2-Point software calibration. The LogView procedure does not require the use of trimpots and should not be confused with the 2-point method in which trimpots are mechanically calibrated as discussed in the DBK16 section of the DBK Option Cards and Modules User's Manual.

During the LogView software procedure, 1 or 2 loads are read and compared with expected values. The software automatically calculates and applies the necessary correction factors.

Storage		DBK Parameters			User Scaling			2-Point Cal							
#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	2-Point Calibration							
								Set P1	Actual P1	Get P1	Set P2	Actual P2	Get P2	Cal Scale	Cal Offset
1	P1_CH00	P1_CH00	On		0.1 to 500.1	lbs	Local	0.0	2.0	Execute	100.0	95.0	Execute	1.075	-2.15
2	P1_CH01	P1_CH01	On		0.0 to 2000.0	apples	Local			Execute			Execute	1.0	0.0
3	P1_CH02	P1_CH02	On		-10.0 to 10.0	Volt	Local			Execute			Execute	1.0	0.0

The above figure shows the columns in the **2-Point Calibration** tab. To fine tune the accuracy of the value coming from a linear sensor, LogView provides both 1- and 2-point calibration.

- **One-point calibration** can be used to zero a channel, such as a thermocouple channel, which is usually more accurate in scale than offset. One example of one-point calibration is that of placing a thermocouple in an ice bath and setting the 0°C point, and no other.
- **2-point calibration** determines the scale and offset factors to convert the raw readings into accurate calibrated readings. Two points of known (set) values must be compared with two actual sensor readings.


An example of 2-Point Calibration (via LogView Software).

To calibrate a strain-gage scale:

1. Unload the scale.
2. Enter a value of 0.0 into the *Set P1* column.
3. Click the *Get P1 Execute* button. This lets you read the actual sensor value (2.0 in the example).
4. Place a 100 lb. weight on the scale.
5. Enter a value of 100 into the *Set P2* column.
6. Click the *Get P2 Execute* button. This lets you read the actual sensor value (95.0 in the example).

LogView automatically computes the **Cal Offset** factor (near 0) and **Cal Scale** factor (near 1).


From this point on, LogView automatically applies the $y = mx + b$ equation to the incoming reading, resulting in a calibrated reading.



Using Digital Outputs As Alarms

Using *LogView's* [calculated channel capability](#) (see page pg. 37), digital outputs can be stimulated by events such as signal levels in analog inputs (e.g., to sound an alarm at a rising temperature before a test system over heats).


1. Click the Analog Input button to activate the *Analog Input Channel Configuration* window.
2. Turn on the analog input channel that you'd like to use to stimulate a digital output channel.
3. Click the Calculated Channel button to open the *Calculated Channel Configuration* window.
4. Click the Add New Channel button (located just right of the $F(x)$ button); or select "Add New Channel" from the Edit pull-down menu to activate the first or next calculated channel.
5. In the Calculated Function column, type in the following equation " $(P1_CH00 > 30.0) \& 1$ ". If you're not using channel 0, replace P1_CH00 with your channel tag. This equation will yield a 1 in its least significant bit when the value of channel 0 is above 30, and 0 when it is below 30.



Entering an Equation (Function Expression)




To verify accurate use of syntax, use the Equation Assistant $F(x)$ and the Validate button (see following figure). The Equation Assistant is accessed via the $F(x)$ button. Refer to [page pg. 38](#) for detailed information regarding the [Equation Assistant](#).



The Equation Assistant can be used to create and validate equations.

6. In the Calculated Channel setup grid, set the newly configured channel to “On.”
7. Close the Calculated Channel grid.
8. Click the Output I/O Setup button. If no digital output rows are present, click the Hardware Configuration button in the main toolbar and add a few digital I/O ports as outputs; e.g., the LBK2 DAC on the P3 port.



Selecting a Control Source

9. Select an output port; then set its Source to the calculated channel that we just configured. Unless you changed the label in the Calculated Channel grid, the source will be CALC_00.
10. Once configured, download the configuration to initiate data collection with the specified alarm output.

Using Exception Capturing

LogView can be set up to wait for defined events to occur, then capture data until another specified event. The triggering process is controlled through the [Acquisition Configuration window](#) (see page pg. 43). If Auto Re-arm is used, LogBook will then re-arm itself after each triggering sequence, waiting for the occurrence of the next trigger event. This setup allows LogBook to capture specific events rather than a continuous data stream that may be useless in some applications. Exception capturing is useful where continuous data would soon fill up the PC-Card with low-value data.



1. Click the Acquisition Configuration button to open the Acquisition Configuration window.
2. Set up the trigger parameter as required. The trigger can be set to various parameters including the level of an analog input channel where you can select a threshold and hysteresis with rising or falling edge. Trigger sources include analog input level, digital channel, immediate, absolute time, and manual Event Mark.



In the manual mode, you must select the Enable Event Mark checkbox so that the Event Mark buttons on LogBook Monitor window and on the LBK1 are activated.

Setting Up the Trigger Parameter

3. In the Pre-trigger tab, set up a duration of time occurring before the trigger event that you would like to save data for. Exception capturing is most effective when you can set trigger parameters to isolate the particular data of interest (e.g., all data 2 minutes before and after a specific event).
4. In the Post-trigger tab, you can set the stop event based on a duration, an analog or digital event, or a manual Event Mark.

5. Enable auto Re-arm by setting the field to 10.
6. Set up input channels as needed in the Analog Input Channel Configuration window.
7. Save the setup file, download it to the PC-Card, and start the acquisition.
8. After the data has been acquired, upload the data files from the PC-Card with *LogView's* Explorer or Upload button. Note that individual trigger blocks for each capture have indexed file names, with each name being unique.



Reference Note: The *File Management* section of this document module, [page 8](#), contains detailed information regarding filename structure.

Menu Descriptions

The rest of the document module describes each menu in detail, including all the related windows and parameters. The menus are presented in the order they appear in the control window and can be referred to as needed.

File Menu

New
Open
Save
Save As
Download
Upload
Download As
Configuration
Report
About LogView
Authorization
Exit

The File menu helps manage your data and configuration files. You can determine the file format, as well as how and where the files are saved in memory. As stated in the previous reference note, The *File Management* section of this document module, beginning on [page 8](#), contains detailed information regarding filename structure.

New




The New command allows you to create a new file. If you try to leave a configuration not yet saved, dialog box asks how “Do you want to save the current configuration?”; select Yes, No, or Cancel. The Save/Save As window will appear. Several icons in the top right of the window offer you help in navigating through files and levels of folders.


Open



The Open command allows you open a previously created configuration file.




Save



The **Save** command allows you to store the configuration file you are currently working on. The **Save As** command uses the same window as the Save command and allows you to enter a new file name. The current file remains unchanged from its last save.

Save As (no toolbar icon)



Upload



or



The Upload command uses *LogView's* Explorer to get data files from a PC-Card. The PC-Card can reside in LogBook if LogBook is attached to the PC or in the PC's card slot if the PC-Card was manually transferred from a remote LogBook.


Note: The Upload icon and the Explorer item in the Device menu can upload from both LogBook or the PC's card slot; in either case, the icon looks slightly different as shown at left.

When the Upload button is clicked:


- If only 1 acquisition file (inactive) resides on the PC-Card, all that data is uploaded to the PC's hard drive.
- If more than 1 acquisition file resides on the PC-Card, an exploring window will appear and allow you to select which acquisition files or trigger blocks you may wish to upload.
- (attached mode only) If the only acquisition file on the PC-Card is active, all acquired data will be uploaded. To prevent duplication of records and conserve storage space, data already uploaded is then deleted from the PC-Card.

The buttons at the bottom of the window (see following figure) allow you to:


- **Upload All** the files on the PC-Card to your PC's hard drive with the designated Path and delete data on the PC-Card if "Delete on Upload All" is selected in *LogView* Preferences. **Note:** with attached mode and an active acquisition, this is the only way to upload data.
- **Upload Selected** uploads only those files which you select.
- **Delete All** the files on the PC-Card.
- **Refresh** will refresh Explorer with data from an active acquisition.
- **Cancel** will close the dialog box.



If uploading an active file for the first time (using Upload All), the following window appears (here, **Cancel** will stop an upload in progress):



If uploading an active file that is already partially uploaded, the following window will appear:



Download



The Download command downloads the current *LogView* setup to LogBook if attached (or a PC-Card if LogBook is unattached) with the same name as the *LogView* setup name. If the current setup is default-named “Untitled”, a dialog box asks “Enter the acquisition name before *LogView* will download current configuration”. Select OK to save, Cancel to stop download process.

or




Download As...

(no toolbar icon)


The Download As... command works much like a Save As command and brings up the window shown at left. You can choose your own file name. When fields contain the correct data, select the Download button; or you may Cancel the operation.

The checkbox Start acquisition on “Power On” is default-checked so that a remote LogBook will begin an acquisition as soon as it is turned on. You can uncheck this box if you will be using an LBK1 to arm the acquisition or if you will be applying power to LogBook but not wanting to begin an acquisition immediately.




Configuration Report

Configuration Report allows you to save a report of the configuration parameters. An example follows.



Configuration Report Window (selected from File Pull-down Menu)



```
Untitled Configuration Report
(Created: 3/29/99 10:47:30 AM)

Clock Settings

Type: Internal Clock
Max Scan Rate: 100.0 kHz (0.01msec period)
Base Rate: 100.0 Hz
Scan Rate1: 100.0 Hz (divider=1)
Scan Rate2: Off
Scan Rate3: Off
Scan Rate4: Off

Trigger Block Settings

Pre-Trigger: Collect 0 scans
Trigger: When Armed
Post-Trigger: Collect 100 scans

Number of Re-arms: 0
Averaging: On
Mark Input: Off
Time Stamp: Off
```

```
Analog Inputs
All inputs are turned OFF

Digital Inputs
All inputs are turned OFF

Calculated Inputs
All inputs are turned OFF

Outputs
1. PhysicalName: P3_TimerDivisor0
   User Label: P3_TimerDivisor0
   Data Source: None
   Initial Value: 1 Dec
   Output Type: Local (Digital)
2. PhysicalName: P3_TimerDivisor1
   User Label: P3_TimerDivisor1
   Data Source: None
   Initial Value: 1 Dec
   Output Type: Local (Digital)
```


Sample Configuration Report (Condensed Image)

About LogView

Provides the software version number and a statement regarding copyright violations.

Authorization

The File Pull-Down menu includes an *Authorization* dialog box. If you have one or more of the following options: Modem Support, Upload Scheduler, or GPS Support, you must enter an appropriate authorization code to enable the applicable feature. If you do not have an authorization code you can obtain one from your service representative, or can enable the features for a 30-day trial period. It is possible for a code to authorize one, two, or three features, depending on how the options were ordered, for example, all three ordered during initial purchase or ordered separately over a period of time.



Authorization Dialog Box

Exit

The Exit command closes *LogView*. *LogView* can also be closed by selecting the “X” button at the top right of the Control Window. If entered data has not been downloaded (saved), a dialog box will appear with such a message.

View Menu

Hardware Configuration
Analog Input Channels
Digital Input Channels
Output Channels
GPS/Serial Input Channels
Calculated Channels
Acquisition Configuration
Preferences


The View menu includes configuration windows, most of them in the spreadsheet format. Descriptions of the View pull-down menu's selections follow.

Hardware Configuration




Selecting Hardware Configuration brings up the windows shown below. As you progress through the hardware tree, the window will prompt you for related information as needed. All 3 I/O ports (P1, P2, P3) are set up here.


Note: these windows only set up non-programmable parameters to match corresponding hardware settings. *LogView* cannot know these settings unless you enter them here. Some DBKs have programmable settings that must be set under the DBK Parameters tab of the Analog Input Channel Configuration window.




This figure shows user selecting the differential mode of analog input on P1.



This figure shows user selecting a particular DBK to be attached to channel 15 of P1.



This figure shows user selecting a particular DBK as assigned to 1 of 4 banks of channels on P2.



This figure shows user selecting LogBook's timer on P3's Digital I/O line.

Analog Input Channel Configuration



The analog input spreadsheet (see following figure) uses four tabs to group analog input parameters. Always visible are the Physical Channel, User Label, On/Off, real-time Reading, Range, Units, and Channel Type columns. Clicking a tab exposes one of the four sub-windows of parameters including Storage, DBK Parameters, User Scaling, or 2-Point Calibration.



If beneficial, adjust column width by placing the cursor on the line between columns (in the column header) and drag the line left or right as needed, for example, to enter a more descriptive user label.

The screenshot shows the 'Analog Input Channel Configuration' window. It features a menu bar with 'View' and 'Edit'. Below the menu bar is a 'Channel Configuration' section with four tabs: 'Storage', 'DBK Parameters', 'User Scaling', and '2-Point Cal'. The 'Storage' tab is active, displaying a table with 12 rows and 11 columns. The columns are: '#', 'Physical Channel', 'User Label', 'On/Off', 'Reading', 'Range', 'Units', 'Channel Type', and 'Sample Rates' (subdivided into A, B, C, and D). The table contains 12 channels, each with a unique physical channel ID (P1_CH00 to P1_CH11), a matching user label, an 'On' status, a range of -10.0 to 10.0, 'Volt' units, and 'Local' channel type. All sample rate options (A, B, C, D) are set to 'No'. Below the table is a 'Physical analog input point' field. Four callout lines point to specific elements: a lightbulb icon points to the 'Help box' text; a line points to the first row of the table; a line points to the column headers; and a line points to the tabs.

#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	Sample Rates			
								A	B	C	D
1	P1_CH00	P1_CH00	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
2	P1_CH01	P1_CH01	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
3	P1_CH02	P1_CH02	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
4	P1_CH03	P1_CH03	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
5	P1_CH04	P1_CH04	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
6	P1_CH05	P1_CH05	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
7	P1_CH06	P1_CH06	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
8	P1_CH07	P1_CH07	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
9	P1_CH08	P1_CH08	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
10	P1_CH09	P1_CH09	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
11	P1_CH10	P1_CH10	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No
12	P1_CH11	P1_CH11	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No

Physical analog input point.

Help box explains the use the current window, field, or cursor position

Channel List (1 per row - read channel's parameter values across the row)

Parameter Column Labels (all columns cannot be displayed at the same time)

Tabs to sub-windows to view related parameters

In the **User Label** column, use the default channel labels or insert your own labels of up to 16 characters (the column width is flexible). Labels are saved with the data so more meaningful channel names will appear in your post acquisition display-and-analysis software. For example, a calculated channel that controls an alarm can be so named; several channels that are combined for a calculated channel can be so named, etc.



When possible, use User Label names that closely resemble the Physical Channel names. This practice makes channel identification easier to remember and helps avoid confusion.

Example: If Physical Channel P1_CH01 was being used for an alarm, a User Label of P101Alarm would be logical.

In the **On/Off** column, use On to enable or Off to disable channels. System performance for the enabled channels is improved by disabling (not sampling) the channels not in use.

The **Reading** column displays the real-time channel value in the user's units. The immediate feedback by this column allows you to optimize range settings, verify scaling, or validate sensor calibration.

For the **Range** column, all LogBook channels and most DBK cards have a programmable gain amplifier (PGA) that provides multiple ranges. Adjusting the range allows you to zoom in or out on your signal for maximum signal resolution for the range needed. If the **Units** and/or **Scale** (from the User Scaling tab) are changed, the available ranges are presented in terms of the new units. For example, if a user scaling of $\times 20$ is applied to a channel to convert volts to PSI (pounds per square inch), the available range choices for that LogBook channel would be ± 200 PSI, ± 100 PSI, ± 50 PSI, 0-400 PSI, 0-200 PSI, etc.

The next figure shows the columns accessible with the **Storage** tab selected (default). If channels are sampled only to derive calculated channels or stimulate outputs, they do not need to be stored. For example, a channel can be sampled at a high rate to prevent aliasing while a calculated channel is used to derive and save its maximum every 10 seconds. In this case, only one sample every 10 seconds is saved, rather than thousands. The **Sample Rates** columns in read-only mode are set up in the Acquisition Configuration dialog box where up to 4 timebases can be defined. For applications with slow and fast signals, slow signals can be sampled at a slower rate, optimizing the system's storage capacity. The base rate A can be divided by 3 divisors for rates B, C, and D (see page pg. 44)

Storage											DBK Parameters			User Scaling		2-Point Cal	
#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	Sample Rates									
								A	B	C	D						
1	P1_CH00	P1_CH00	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No						
2	P1_CH01	P1_CH01	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No						
3	P1_CH02	P1_CH02	On		-10.0 to 10.0	Volt	Local	Yes	No	No	No						

Analog Input Channel Configuration, Storage Tab Selected

Storage											DBK Parameters				User Scaling		2-Point Cal	
#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	DBK Parameters										
								Param.1	Param.2	Param.3	Param.4							
1	P1_CH00_0_0	P1_CH00_0_0	On		-3.159 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=18.0 kHz	Exct=Enable	Clk=Enable							
2	P1_CH00_0_1	P1_CH00_0_1	On		-3.159 to 3.159	Volt	DBK4	Filter=Bypass	maxFq=18.0 kHz	Exct=Enable	Clk=Enable							

Analog Input Channel Configuration, DBK Parameters Tab Selected

The above figure shows the **DBK Parameters** tab used to configure channels with programmable DBK parameters. Depending on the DBK, values must be entered in the **Param.1** to **Param.4** columns. One such example is the DBK4 that requires filter settings; some other DBK cards also have programmable parameters.




Some DBKs have hardware switches and jumpers for configuration. When using such DBKs, corresponding parameters must be set in the LogBook Hardware Configuration window.

Storage											DBK Parameters				User Scaling		2-Point Cal	
#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	User Scaling										
								Scale	Offset									
1	P1_CH00	P1_CH00	On		0.1 to 500.1	lbs	Local	25.0	0.1									
2	P1_CH01	P1_CH01	On		0.0 to 2000.0	apples	Local	100.0	0.0									
3	P1_CH02	P1_CH02	On		-10.0 to 10.0	Volt	Local	1.0	0.0									

Analog Input Channel Configuration, User Scaling Tab Selected

The **User Scaling** tab shown above has **Scale** and **Offset** columns. In User Scaling, you create a **transfer function** so *LogView* will display units that are useful for your application. Here, you can arbitrarily define your **Units** (apples, oranges, whatever) based on the raw input value, typically Volts. To do so, type your new unit name in the Units column and select an appropriate range (e.g. unipolar). Then, enter its linear scale relation to the Volt (e.g. 25 pounds per Volt) and any offset from 0 (e.g. the empty basket measures 0.1 V). The reading and range columns change accordingly.



Storage		DBK Parameters		User Scaling		2-Point Cal		2-Point Calibration							
#	Physical Channel	User Label	On/Off	Reading	Range	Units	Channel Type	Set P1	Actual P1	Get P1	Set P2	Actual P2	Get P2	Cal Scale	Cal Offset
								1	P1_CH00	P1_CH00	On		0.1 to 500.1	lbs	Local
2	P1_CH01	P1_CH01	On		0.0 to 2000.0	apples	Local			Execute			Execute	1.0	0.0
3	P1_CH02	P1_CH02	On		-10.0 to 10.0	Volt	Local			Execute			Execute	1.0	0.0


Analog Input Channel Configuration, 2-Point Cal Tab Selected

Calibration. The above figure shows the columns in the **2-Point Calibration** tab. To fine tune the accuracy of the value coming from a linear sensor, *LogView* provides both 1- and 2-point calibration.

One-point calibration can be used to zero a channel—as in a thermocouple, which is usually more accurate in scale than offset. You might place the thermocouple in an ice bath and set just the 0°C point.

2-point calibration determines the scale and offset factors to convert the raw readings into accurate calibrated readings. 2 points of known (set) values must be compared with 2 sensor (actual) readings.


For example, to calibrate a strain-gage scale, unload the scale, type 0.0 into the Set P1 column, then click the Get P1 Execute button to read the actual sensor value (2.0). Place a known 100 lb weight on the scale; type 100 into the Set P2 column; then click the Get P2 Execute button to read the actual sensor value (95.0). *LogView* automatically computes the **Cal Offset** factor (near 0) and **Cal Scale** factor (near 1). From now on, *LogView* automatically applies the $y = mx + b$ calculation to the incoming reading to produce the calibrated reading.



Digital and Counter Input Channel Configuration



The basic LogBook system has three 8-bit digital ports and one high speed 16-bit port configurable as inputs or outputs in the *LogBook Hardware Configuration window* (see following figure). When configured as inputs, these ports appear in the Digital and Counter Input Channel Configuration spreadsheet. Also, four pulse-input ports can count pulses for summing and/or frequency measurement. Adding digital expansion cards provides up to 192 digital bits.




Configuring Digital I/O Port A as Input, and with Control Resolution as Individual Bits

#	Physical Channel	User Label	On/Off	Reading	Format	Channel Type	Sample Rate			
							A	B	C	D
1	P2_Port_A_0	P2_Port_A_0	On		Hex	Local	Yes	No	No	No
2	P2_Port_A_1	P2_Port_A_1	On		Hex	Local	Yes	No	No	No
3	P2_Port_A_2	P2_Port_A_2	On		Hex	Local	Yes	No	No	No
4	P2_Port_A_3	P2_Port_A_3	Off		Hex	Local	Yes	No	No	No
5	P2_Port_A_4	P2_Port_A_4	Off		Hex	Local	Yes	No	No	No
6	P2_Port_A_5	P2_Port_A_5	Off		Hex	Local	Yes	No	No	No
7	P2_Port_A_6	P2_Port_A_6	Off		Hex	Local	Yes	No	No	No
8	P2_Port_A_7	P2_Port_A_7	Off		Hex	Local	Yes	No	No	No

User-specified channel label. 16 characters maximum. Type in desired label or leave default.

Digital & Counter Input Channel Configuration Screen, Channels Configured for Individual Bits



Digital & Counter Input Channel Configuration, Each Channel as a Port of Bits

The **Physical Channel** column identifies the actual hardware port of the physical channel.

In the **User Label** column, you can use the default channel names or type in a more suitable label up to 32 characters in length. These labels are saved with the collected data.

The **On** column can enable (On) or disable (Off) individual channels. To maximize system performance, only channels that are enabled are sampled.

The **Reading** column displays the read-time value of the digital port in the format specified in the **Format** column.

Analog, digital, and pulse samples are all sampled together in LogBook. This makes time correlation possible. In the Acquisition Configuration dialog box, up to four timebases can be specified. A digital or pulse channel can be sampled at any or all of these timebases.




Channels sampled only to derive calculated channels, or to simulate outputs do not need to be stored.

Output Channels Configuration



The Output spreadsheet shows all of the currently available digital and analog output channels. Each output channel requires a source channel to feed it. Source channels can be chosen from an analog input for an analog output or from a digital input for a digital output.



Output Channel Configuration Window

The (physical) **Channel** column identifies the hardware channel assignment. The **User Label** column allows you to enter a more suitable channel name of up to 32 characters. The **Source** column designates the input or calculated channel used as the source of data for this output channel. An entry of None disables the output channels. The **Initial Value** column allows you to initialize the output to a specified value. The **Units** column indicates units for Initial Value. This column can not be edited. The default is Decimal.


Serial / GPS Channels (LogBook/360 Only)



LogBook/360 can store latitude, longitude, and altitude coordinates along with the analog and digital data from the attached transducers, providing it is connected to a Global Positioning System (GPS) receiver. LogView software provides an easy method for setting up the GPS channels. No programming, character string parsing, or protocol decoding is necessary.

LogBook/360 can provide direct support for any GPS receiver that conforms to the NMEA 0183 protocol standard. **GPS support is not provided for LogBook/300.**

GPS receivers must be purchased separately, and are available from a variety of sources. If purchasing a GPS make sure it conforms to the NMEA 0183 protocol standard.



LogBook Hardware Configuration



Reference Note: Refer to the *GPS & Serial Device Data Collection* section in chapter 5 of the LogBook User's Manual for detailed information.


Calculated-Channel Configuration



LogBook can derive virtual channels from real and/or virtual channels using math operators and functions. The resulting virtual channels can be used to:

- Create alarms based on any combination of signal levels from real channels and logical or mathematical functions of virtual channels
- Reduce data through statistical operations, comparisons, etc.
- Develop sophisticated trigger equations using a series of averaging, comparing of other real and virtual channels
- Manipulate input channel values for a more useful output (perhaps the quantity of interest cannot be measured directly but depends on a complex derivation from several measurements)
- Control external devices via digital output signals (like a simple Programmable Logic Controller)

Note: Calculated channels can have numeric values such as analog channel values. Calculated channels can also have digital values of 0 or 1. These channels can be stored in any one (or all 4) timebases set up in the *Acquisition Configuration Window*, in the same manner as other input channels.



Calculated Channel Configuration Windows with Calculation Function Examples

You can access the Calculated Channel Configuration window from the control window's View pull-down menu, or by using the Calc (fx) button. The window contains several columns that are easy to understand because of their labels, and their similarity to columns previously discussed. The Calculation Function column is a noted exception that is explained via the following four examples.

Note: Channel ID and Physical Channel nomenclature appear in the Calculation Function column. User Labels will not appear in the function column unless they are identical to a Channel ID, or a Physical Channel label.

Refer to the above screen shots for the examples which follow.



In addition to understanding the equation aspect of the following examples, you should also note the differences between the two types of configuration screens; i.e., an actual (real) channel and the calculated (virtual) channel.




Reference Note: You may wish to refer to math or programming books to derive calculation functions that suit your specific application.

Equation Assistant

The following window is opened by the F(x) button on the Calculated Channel Configuration window. The Equation assistant helps to ensure that the proper syntax is used in the Calculation Function column. Selecting the corresponding math and logic operators will enter the corresponding commands (these commands can also be typed in, but using the equation assistant can minimize syntax mistakes).



No recursion. A calculated channel cannot refer to itself directly or indirectly by creating a loop of inter-related calculations.



Equation Assistant Dialog Box

Equation Assistant Function Buttons					
Arithmetic					
-	+	*	/	%	^
(subtraction)	(addition)	(multiplication)	(division)	(modulus) ¹	(exponentiation)
Relational and Equality					
<=	>=	<	>	==	!=
(less than or equal to)	(greater than or equal to)	(less than)	(greater than)	(equal)	(not equal)
Bitwise Note: Bitwise functions are briefly discussed in the text which immediately follows this table.					
&		~	<<	>>	
(Bitwise And)	(Bitwise Or)	(Bitwise Not)	(Shift Left)	(Shift Right)	
Logical Note: Logical functions are briefly discussed in the related text which follows this table.					
And	Or	Not			

¹ **Note:** Modulus has several possible meanings. As used in the equation assistant, modulus is the remainder which results when the first operand is divided by the second. For example: the modulus for 3 % 3 is 0; the modulus for 3.257 % 3 is 0.257; and the modulus for 5 % 2 is 1.0.

Bitwise Operators

The bitwise operators perform bitwise-AND (&), bitwise-OR (|), and bitwise-Not (~) operations.

Syntax

AND-expression & equality-expression

OR-expression | Not-expression

Not-expression ~ AND-expression

The operands of bitwise operators must have integral types, but their types can be different. These operators perform the usual arithmetic conversions; the type of the result is the type of the operands after conversion.

& The bitwise-AND operator compares each bit of its first operand to the corresponding bit of its second operand. If both bits are 1, the corresponding result bit is set to 1. Otherwise, the corresponding result bit is set to 0.

Example: $10110000 \ \& \ 10010000 = 10010000$

| The bitwise-OR operator compares each bit of its first operand to the corresponding bit of its second operand. The operator is inclusive in that, if either bit is 1, the corresponding result bit is set to 1. Otherwise, the corresponding result bit is set to 0.

Example: $10110000 \ | \ 10010000 = 10110000$

~ The bitwise-NOT operator creates a bitwise compliment of its operand. Thus, a 0 switches to 1, and a 1 switches to 0.

Example: $\sim 10110000 = 01001111$

Bitwise Left Shift and Right Shift Operators: <<, >>

Syntax:

shift-expression << additive-expression

shift-expression >> additive-expression

The bitwise shift operators shift their first operand left (<<) or right (>>) by the number of positions the second operand specifies.

Example: $10110000 \ \ll \ 2 = 11000000$

Logical Operators

The logical operators perform logical AND, logical OR, and logical NOT operations.

Logical operators do not perform usual arithmetic conversions. Instead, they evaluate each operand in terms of its equivalence to 0. Thus, the result of a logical operation is either 0 or 1.

AND The logical-AND operator produces the value 1 if both operands have nonzero values. If either operand is equal to 0, the result is 0. If the first operand of a logical-AND operation is equal to 0, the second operand is not evaluated.

OR The logical-OR operator performs an inclusive-OR operation on its operands. The result is 0 if both operands have 0 values. If either operand has a nonzero value, the result is 1. If the first operand of a logical-OR operation has a nonzero value, the second operand is not evaluated.

The operands of logical-AND and logical-OR expressions are evaluated from left to right. If the value of the first operand is sufficient to determine the result of the operation, the second operand is not evaluated. This is called "short-circuit evaluation."

NOT The logical-negation (logical-NOT) operator produces the value 0 if its operand is true (nonzero) and the value 1 if its operand is false (0). The operand must be an integral, floating, or pointer value.

Examples of Calculated Channels

Example 1: **P1_CH14 > 23**


In this example the user wants to use CALC_00 as a logic indicator based on the state of physical channel P1_CH14; thus channel CALC_00 will read 1 or 0, depending on the value of the physical channel's reading.

The user created a calculation function: **P1_CH14 > 23**. The calculation channel is labeled **CALC_00** as seen in the following figure.

Assume P1_CH14 had a reading of 26.13. Since 26.13 is greater than the value 23 in the calculation function, CALC_00's reading would appear as 1.0. If the channel P1_CH14 reading drops to 23 or lower, CALC_00 will read 0.0. Note that CALC_00 can be used in additional equations as will be seen in example 2.

To obtain a calculation channel, select the *Calculated Channel Configuration* window's **Edit** pull-down menu, then select **Add Channel**. In regard to the calculation function column, the following steps highlight how to enter the function used in this first example, i.e., **P1_CH14>23**.

1. Ensure the physical channel to be referenced is enabled. In this case: P1_CH14.
2. Use the **Calc (y = fx)** button in the toolbar or Calculated Channels from the View pull-down menu to access the Calculated Channel Configuration Window.
3. Select the **Edit** pull-down menu (located on the Calculated Channel Configuration window).
4. Select **Add New** to add a calculation channel. In our first example this is **CALC_00**.
5. Click on the cell in the **Calculation Function Column**.
A **F(x)** button appears by the Enter Function Expression dialog box.
6. Use the **F(x)** button to access the *Equation Assistance dialog box*.
7. In the *Equation Assistant* box, double-click on the desired reference channel. P1_CH14. This entry will appear in the equation box, located just below the title bar. Note that you may type the channel, and other equation entries in this box, if desired.
8. From the Relational and Equality buttons (\leq , \geq , $<$, $>$, $=$, \neq) select the "greater than" symbol ($>$). This entry will appear in the equation box.




Equation Assistant Dialog Box

9. With the cursor placed after the greater than symbol, type 23.
10. Verify that your function appears correctly and click the **Validate** button. Validate will verify that you have a useable equation and will inform you when there is a problem with an equation. For example, you may have a missing parenthesis.
11. If necessary, correct your equation and validate the new one.
12. Click the **OK** button. This closes the Equation Assistant.

Though the previous ten steps pertain to the first example, aside from functional differences, the method is essentially the same for the remaining three examples. A figure and table have been placed after the examples to identify various button options available with the Equation Assistant.

Example 2: CALC_00 And(P1_CH15>24)



Look at row 2 in the *Calculated Channel Configuration* screen above. You will see that the user created a calculation function of **CALC_00 And(P1_CH15 > 24)** for the calculation channel having the channel ID of CALC_01. In this example the user wants to use CALC_01 as a logic indicator based on the state of both CALC_00 and physical channel P1_CH15.

In this example, channel CALC_01 will read 1 if both of the following are true:

- a) CALC_00 has a value of 1.0
- b) P1_CH15 has a value greater than 24

Assume that P1_CH14 had a channel reading of 23.09 and that P1_CH15 had a value of 21.81. In this case, CALC_00 will have a value of 1.0 because P1_CH14 is greater than 23. P1_CH14>23 was set in example 1.

In our example 2 function of **CALC_00 And(P1_CH15>24)** it is clear that although the first condition is satisfied, we can see that the second is not, since P1_CH15 has a reading of 21.81. Because both conditions are not satisfied, CALC_01 reads 0.0. Note that CALC_01 can be used in additional equations.

Example 3: P1_CH14+P1_CH15

Look at row 3 in the *Calculated Channel Configuration* screen (previous figure). You will see that the user created a calculation function of **P1_CH14+P1_CH15** for the calculation channel having the channel ID of CALC_02. In this example the user wants to use CALC_02 to indicate to sum of two physical channels, i.e., P1_CH14 and P1_CH15.

In this example, assume that:

- a) P1_CH14 reads 25 volts, and
- b) P1_CH15 reads 24 volts

In this case CALC_02 will be the sum, 49 volts.

Note that CALC_02 can be used in additional equations.

Example 4: P1_CH14*2

Look at row 4 in the *Calculated Channel Configuration* screen (previous figure). You will see that the user created a simple calculation function of **P1_CH14*2** for calculation channel CALC_03. In this example the user wants CALC_03 to read twice the value of physical channel P1_CH14.

Note that CALC_03 can be used in additional equations.

Acquisition Configuration




The Acquisition Configuration dialog box allows you to define trigger conditions including various parameters for pre-trigger, trigger, post-trigger, scan rate and timebase.

LogBook data can be collected in two basic ways depending on the trigger setup:

- Continuous. As a simple data logger in a strip chart mode, all data collected is then saved. The trigger source can be set to immediate and the post-trigger scan count set to infinite.
- Exception-only. As an exception-capturing system, collected data is saved only under specified conditions. Pre-trigger, post-trigger, and re-arm parameters allow you to collect only data around specified events, just the data of interest, nothing more. Thus memory is conserved, and post-analysis is easier.

The next figure shows a time line with data being collected continuously, but only the trigger block is logged to memory (the pre-trigger and post-trigger data combined is called a trigger block).




Trigger Parameters Setup


The following figures represent Trigger Setups with an Analog Channel as a trigger source (channel P1_CH14) and a Calculated Channel as a trigger source (CALC_00).

Other possible trigger sources are:

When Armed, Manual, Digital Channel (LogBook/360 only), and Absolute Time.



Trigger Setup Using an Analog Channel



Trigger Setup Using a Calculated Channel


The manual trigger can be implemented in the following ways:

- With a PC attached, you can trigger LogBook from *LogView's* LogBook Monitor window in the Device menu.
- Without a PC, you can use the Remote LogBook Terminal (LBK1) manual trigger button.

The auto re-arm feature allows for a large number of acquisitions to take place automatically, with each acquisition using the same settings. As soon as the previous trigger block is terminated, the system immediately re-arms itself, waiting for the trigger condition to be satisfied. The Number of Re-arms field allows you to specify how many triggered acquisitions to capture. For *exception-capturing*, specify the number of trigger blocks that should be collected before data logging is terminated. For continuous data logging, specify 1 trigger block.

If **Absolute Time** is selected for the trigger source, the window changes as shown in the figure at right. The parameters include the date and time as well as options for re-triggering after a specified duration.

A wide variety of trigger sources and stop events provide great flexibility in exception-capturing. If data collection is desired only under specific conditions, appropriate trigger conditions can be so specified. Besides the trigger event, you can define a pre-trigger and post-trigger for the trigger block. An example of *exception-capturing* would be to collect 100 pre-trigger scans and 1000 post-trigger scans every time a designated channel read a specified temperature.




Using Absolute Time as a Trigger Source




To conserve memory when collecting high-speed data, use the trigger to take snapshots of information only during the appropriate periods.

When using a trigger to start the acquisition, a pre-trigger count can be supplied so that information just before the trigger can be collected and saved (LogBook's buffer allows pre-trigger data to be stored temporarily until saved in a trigger block). The post-trigger definition specifies when the data collection activity should end.




Pre-Trigger Setup



Post-Trigger Setup

You can also use a calculated channel as a trigger source, but you must use an analog output or digital channel as an intermediary. The calculated channel can be based on real channels and user logic to create an analog output channel or a digital output channel that could then be the input for the trigger event or stop event. A calculated channel can describe virtually any combination of channel conditions. For example, you can develop a calculated channel called TRIG and specify it as the trigger channel. If the channel's equation is $TRIG = (Temp1 - Temp2) > 50.0^\circ$, the data collection process will be triggered when the difference between the 2 channels is greater than 50.0° .

Scan Rate Setup



Scan Rate Setup. Accomplished on the right-half of the Acquisition Configuration Window.

The Scan Rate block is the right half of the *Acquisition Configuration window* (see previous figure). To set the scan rate, you can use LogBook's "internal" clock, or an "external" clock. Brief descriptions follow.

Note: The scan-to-scan time is not recorded when tracking variable-speed events.

- **Internal Clock.** The scan-to-scan timing may be set by a fixed-frequency pacer clock. LogBook's time-of-day clock has 1/16-second resolution for data-logging applications where acquisitions must be performed at specific times during the day. The time of occurrence for each acquisition and its trigger are recorded with the data. The internal clock can be reset in the *LogBook Monitor window* in the Device menu.
- **External Clock.** Each scan may be individually started by an external TTL level trigger to allow the scan rate to track an external, variable-speed event (such as engine revolutions). The external clock signal is applied to LogBook through pin 20 of the P1 DB37 Analog I/O connector. The P1 pinout is included in chapter 4 of the LogBook User's Manual.

Question: Why is the Pin 20 [for the external clock] identified as PCRCLK output/input?

Answer: When LogBook is set for an external user-supplied pacer, pin 20 has an input function. When LogBook is set to make use of its internal FPGA (Frequency Pulse Gain Amplifier) supplied pacer, pin 20 is driven as an output. This allows instrumentation external to LogBook to be triggered in sync with LogBook scans.

Question: On what edge is the sample taken? Rising or Falling?

Answer: Rising edge, low-to-high direction, where the *minimum pulse high-time* equals the *low time* (100nsec).

For applications with both slow and fast phenomena, sampling slow signals at a slower rate while maintaining high rates for fast signals will conserve memory. For example, channel 1 may read fast signals like vibration and can be sampled at the high (base) rate; channel 2 may read slow signals like thermocouples and can be sampled at a lower rate. A Base Rate A and up to 3 more rates (B, C, D) can be configured; but only one base rate can be defined for the entire system and it should be set for the fastest scan required. The B, C, D rates must be integer (whole number) divisions of the base rate. It is also possible to scan the same channel at several rates.

Note: A separately indexed data file is created for each scan rate.

The checkbox "**Apply noise reduction averaging**" refers to auto-averaging for scan rates B, C, and D. All channels are scanned at the base rate; but they may also be scanned at divisions of the base rate. Two advantages to averaging are noise reduction by limiting the effect of extraneous readings and storage savings since fewer values are stored.

- **Averaging.** Checking this box, the readings from the base rate will be averaged, and the average value will be entered for the derived rate scan. If the scan rate B is $\frac{1}{4}$ of the base rate A, then four A readings will be averaged for each B reading.
- **No averaging.** Not checking this box, the readings at the derived scan rates will be exactly the same for that time-point as the base rate.

Event Marking/Time Stamping

The top right side of the Acquisition Configuration window allows you to manually mark events and/or insert an absolute time reference for each scan:

- **Enable Event Mark** sets up the acquisition for an operator to press the Event Mark button in the *LogBook Monitor window* or on the LBK1 remote operation terminal. Whenever the button is pressed, that data point is added to the data file.
- **Enable Time Stamp** sets up the acquisition to automatically add the time (to ms) and date to the data file for every scan.


Preferences

(no toolbar icon)


LogView allows you to set various parameters to make your application more useful and convenient. These preference settings are divided into 4 tabs as shown in the figures on the right.

Most of the options cover default use of filenames and validating changes to files.


As explained in the *File Management* section (see page pg. 9), *LogView* can generate multiple data files for an acquisition and then automatically name them. These names have a long format with several fields (seed, serial number, date armed, time armed, trigger block/segment). Unless you need the long-format name to prevent file overwrites, you can uncheck the fields you don't need. For example, if only using one LogBook, the serial number is not needed.



LogView Preferences, General Tab Selected




LogView Preferences, Download Tab Selected



LogView Preferences, Upload Tab Selected

For data conversion:

- 1) Select the *LogView* Preferences “General Tab.”
- 2) Click on the “File Converter” button. The *File Converter Preferences* dialog box appears.
- 3) Select the formats you want to save your data in.
- 4) If desired, check to automatically delete the source data file after conversion. The default avoids automatic deletion of the source data file.
- 5) Select the overwriting-related preference you desire. The default is to “Validate overwriting of each existing file.”



File Converter Preferences Dialog Box

Device Menu

Select PC Card
Select LogBook
Attach
Break
Arm Acquisition
Stop Acquisition
LogBook Monitor
Explorer

The Device menu allows you to choose devices in your system, attach or break connection to the system, and to start and stop an acquisition.

Select PC-Card

(no toolbar icon)

Select PC-Card allows you to choose which drive on your computer you wish to make active for uploading and downloading—especially relevant if your computer has more than one PC-Card slot.




Select PC-Card

Select LogBook

(no toolbar icon)

Select LogBook allows you to choose devices from your system and then verify or change the communication port settings.



Select LogBook



Attach allows you to establish connection with a LogBook. If no LogBook is connected, *LogView* will automatically attach to a PC-Card in the user-specified PC-Card drive (specified in the “Select PC-Card” dialog box).



Break allows you to break the connection with an attached LogBook.



Arm Acquisition Arms the acquisition for the selected device. The scan will begin when the selected trigger condition is met.




Stop Acquisition will disarm the acquisition for the selected device. No data will be collected despite trigger conditions until the acquisition is armed (started).

LogBook Monitor

(no toolbar icon)

The LogBook Monitor provides a system status report on the current acquisition (if in progress). The window allows provides access to manual-trigger and chart-marking functions. You can access LogBook's Explorer by clicking the button in the lower right-hand corner of the screen. The Explorer allows you to search the PC-Card for acquisition files and the indexed trigger blocks within the acquisition files (see following section for more Explorer information).



LogBook Monitor

The acquisition status is only updated every 1 or 2 seconds; the status for scans at a faster rate may not be updated before the scan is finished.

Whenever you select the **Event Mark** button during an acquisition, *LogView* notes the exact time to time-correlate the marked instant with data collected then. This function is like marking a strip chart to draw attention to a particular time frame. These marks can be seen later while reviewing the data in an independent view application.



The Enable Event Mark (in the Acquisition Configuration window) must be checked in order for the LogBook Monitor to be enabled. This event-marking feature is also accessible via LBK1.



Max Swap Time (Maximum Disk Swap Time) is the estimated amount of time that the user has to remove and replace LogBook's PCMCIA card without interruption to LogBook's active acquisition.

The Manual Trigger button is available here and will activate the trigger or post-trigger event immediately when selected (also accessible via the LBK1).

Under LogBook Settings, you can read the current time of LogBook's clock. You can reset LogBook's clock to the PC's clock by selecting the **Reset Clock** button.


The Error box contains an error number and brief description of the error. These [error codes](#) are provided near the end of this manual. Not all errors are fatal to the acquisition.

Explorer

(no toolbar icon)

The Explorer window can be reached from the Device menu or from its button in the *LogBook Monitor window*. Explorer allows you to search the PC-Card for acquisition files and the indexed trigger blocks within the acquisition files. The Exploring windows look first at the acquisitions saved to disk and then deeper into each trigger block within an acquisition.

The [convention for naming files](#) is described on [page pg. 9](#). In the following example (see figure below), TriggerBlock_2-2 uses “TriggerBlock” as the seed and “2-2” to indicate the 2nd segment of the 2nd trigger block. The binary data file ends with the .bin extension understood in the *LogView Explorer*.



LogBook Explorer Window, Two Examples

Tools Menu

Convert Binary Data

Merge Binary Data

View Data

The Tools menu provides three selections:

- **Convert Binary Data** - allows you to convert raw binary data (*.bin files) into other formats that you may find more useful.
- **Merge Binary Data** – allows you to *merge Rate files* and to *concatenate Trigger Block segments*.
- **View Data** – Accesses the independent view program for graphing and analysis of previously recorded data.

Convert Binary Data

(no toolbar icon)

The **Convert Binary Data** menu option allows you to convert raw binary data (*.bin files) into other formats that you may find more useful. You must first select an existing binary file to be converted. The filename can be typed in or selected by the Browse button that leads to a folder/file search window. After a file is selected (or multiple files), you can toggle check-boxes on/off for each format type. When ready to begin the conversion, select the Convert button and set up the destination folder/filename.

Data collected with LogBook can be uploaded to your PC's hard disk in any or all of several data formats for post-acquisition analysis. Some of the available file formats include Snap Master, DADiSP, Matlab, and ASCII (Excel) which is compatible with most software for analysis. *LogView* creates the necessary header files for each data format so that the software can use the channel labels, the timebase information, and other parameters.

Converted data files are placed in format-specific subdirectories of the binary source file directory.

Rates, Trigger Blocks, and Segments

LogBook has the capacity to save channel data at four independent rates. For each enabled rate, a file is created. For example, if all four rates are being used, four files will be present after an upload. Depending on the *Upload Preference* settings (as discussed in [Preferences, page pg. 46](#)), the file names will look similar to the following.

TEST R1 B1-1.BIN	“TEST” is the name of the acquisition configuration.
TEST R2 B1-1.BIN	“Rn” shows the rate number. R1 through R4 is Rate1 through Rate 4.
TEST R3 B1-1.BIN	“Bn-m” shows the trigger block and segment numbers.
TEST R4 B1-1.BIN	For example, B1-1 indicates “Block1, Segment 1.”

Note: Files with high rates take up more memory than files with slow rates.

Auto Re-arm is used when multiple trigger events need to be captured. When the auto re-arm feature is enabled, LogBook will arm itself, wait for a trigger, collect the pre- and post-trigger, then re-arm itself and repeat the process.

The pre- and post-trigger data surrounding a trigger point is called a Trigger Block. A new file is created for each Trigger Block. If only one *rate* is used and three *Trigger Blocks* are collected, the file names would look similar to the following.

TEST R1 B1-1.BIN	In each case, R1 indicates Rate 1. B1, B2, and B3 indicate Trigger Blocks 1, 2, and 3, respectively. The “-1”, in each case, indicates Segment 1.
TEST R1 B2-1.BIN	
TEST R1 B3-1.BIN	

Uploads can be performed while data is being collected. For applications that require continuous acquisition, uploads can be performed periodically to make space for additional data. **Each uploaded portion of a single Trigger Block is called a Segment.** If one rate is used and a Trigger Block was uploaded in five *Segments*, the file names would look similar to the following.

TEST R1 B1-1.BIN	In each case, R1 indicates Rate 1. B1 indicates Trigger Block 1, and “-1” through “-5” indicates Segment 1 through Segment 5.
TEST R1 B1-2.BIN	
TEST R1 B1-3.BIN	
TEST R1 B1-4.BIN	
TEST R1 B1-5.BIN	


Merging and Concatenating

LogView's *raw binary format* can not be used by other programs; however, LogView can convert its data files into popular file formats used by other display and analysis packages. The conversion can be performed automatically during an upload, or manually after the upload using the *Convert Binary Data* utility (found under the **Tools** pull-down menu).

In addition to providing for file format conversion, the *Convert Binary Data* utility also has the ability to *merge Rate files* and to *concatenate Trigger Block segments*. Examples follow shortly.

- When *merging Rate files*, the utility takes the appropriate rate files and combines them into one file.
- When *concatenating segments*, the utility joins the appropriate segment files, making one continuous Trigger Block file.
- When both *Merge* and *Concatenate* are enabled, Trigger blocks with multiple rates (that were uploaded in segments) can all be consolidated into one file.


The *Convert Binary Data* utility lists all the raw binary files in the DATA directory. Select the desired file(s) and click Convert to initiate the process. In this way, any Trigger Block, Segment, or Rate file can be individually converted.



Sample Screen from the Convert Binary Data Utility

Merging Binary Data

(no toolbar icon)



Preparing to Merge Subrates


A screen similar to that shown in the above figure appears when the “Merge Binary Data” is selected from the Tools pull-down menu. On this window, when the *Merge Subrates* box is checked, the *Convert Binary Data* utility groups the related Rate files together and displays a single item. In the example below this single item is:


TEST R* B1-1.BIN.

The number of files that this item describes is now shown in size column of the list box (4 files). Selecting **TEST R* B1-1.BIN** and then clicking the *Execute* button (lower right) will convert and merge the files.

TEST R1 B1-1.BIN -----> TEST R* B1-1.BIN
TEST R2 B1-1.BIN |
TEST R3 B1-1.BIN |
TEST R4 B1-1.BIN |

Concatenating (Linking) Segments





File Convert Utility Screen Shown Both Before and After Selecting “Concatenate Segments”


When the *Concatenate Segments* box is checked, the File Convert utility groups the Segment files together and displays a single item. In the example, the single item is **TEST R1 B1-*.BIN**. The number of files that this item describes is now shown in size column of the list box (5 files). Selecting **TEST R1 B1-*.BIN** and then clicking the *Execute* button (lower right of utility) will both convert and concatenate the files.

```

TEST R1 B1-1.BIN -----> TEST R1 B1-*.BIN
TEST R1 B1-2.BIN |
TEST R1 B1-3.BIN |
TEST R1 B1-4.BIN |
TEST R1 B1-5.BIN |
  
```

Note: For applications that require continuous data collection, the *Upload Scheduler* can periodically upload the data to a local PC, creating new space on the LogBook’s PC-Card. The Upload Scheduler is discussed in the *LBK Options* chapter of the LogBook User’s Manual.

View Data



The **View Data** button launches an independent post-data acquisition view program, if installed. Examples of view programs are DIAdem and the eZ-Analyst set of view applications. The *Post Acquisition Data Analysis User’s Guide* PDF documents the applicable application(s). The PDF document is automatically installed onto your computer’s hard-drive as a part of LogBook product support at the time of software installation.

Indicators Menu

Bar Graph Meters
Analog Meters
Digital Meters
Enable Input Reading Column
Start All Indicators
Stop All Indicators

Along with displaying channel data in real time in the setup spreadsheets, *LogView* also provides auxiliary real-time indicators.


The meter windows simulate the look of popular meter types: the bar graph, the analog dial, and the digital readout. Within each meter type, you can adjust their display properties to fit your needs. Such properties include number of channels, high/low limits, peak hold, trend indicator, etc.

Next, each meter type is shown; and then, their configuration is discussed (they all work in a similar way).

Bar Graph Meters

(no toolbar icon)


Selecting the Bar Graph Meter icon brings up the Bar Graph window to display several channels in bar graph format. To activate the display, select the Start button on the left side of the toolbar (or Start All Indicators in the pull-down menu or in the toolbar). You can vary the number of channels (32 max) displayed by selecting the input box at the end of the toolbar. The Grid button (next to last item on toolbar) is used to arrange the display for convenient reading. The pushpin icon in the center of the toolbar locks this window on top of other windows until you unlock it by selecting the pushpin again.



Analog Meters

(no toolbar icon)


Selecting the Analog Meter icon brings up the Analog Meters window to display several channels in a dial/gage format. To activate the display, select the Start button on the left side of the toolbar (or Start All Indicators in the pull-down menu or in the toolbar). You can vary the number of channels (32 max) displayed by selecting the input box at the end of the toolbar. The Grid button (next to last item on toolbar) is used to arrange the display for convenient reading. The pushpin icon in the center of the toolbar locks this window on top of other windows until you unlock it by selecting the pushpin again.



Digital Meters

(no toolbar icon)

Selecting the Digital Meters icon brings up the Digital Meters window to display several channels in numeric format. To activate the display, select the Start button on the left side of the toolbar (or Start All Indicators in the pull-down menu or in the toolbar). You can vary the number of channels (32 max) displayed by selecting the input box at the end of the toolbar. The Grid button (next to last item on toolbar) is used to arrange the display for convenient reading. The pushpin icon in the center of the toolbar locks this window on top of other windows until you unlock it by selecting the pushpin again.




Meters Configuration

The toolbars and pull-down menus for the three meter types are identical except that Digital Meters does not have a Reset Peak Hold icon.




Meters Toolbar Icons		
Item	Name	Function
	Start	Starts meters.
	Stop	Stops meters.
	Reset Peak Hold Indicator	Resets the floating markers. Upon reset, the markers will instantly adjust to indicate the highest and lowest values reached since the time of the reset. <i>This feature does not apply to the Digital Meters.</i>
	Stay On Top (Push pin)	Locks or unlocks the meter window on top of other windows.
	Print	Sends the meter(s) display image to connected printer.
	Rows x Columns	Opens a small menu with "row x column" arrangement options. <i>Example:</i> When the number of meters is 6 the grid options will be: 6x1, 3x2, 2x3, and 2x4 with the first number being the number of rows. If you then select 3x2 you will have 3 rows of meters with 2 meters per row.
	Number of Meters	Specifies the number of meters to appear on the screen. Up to 32 meters can be selected.

The meters windows each have a Control and View pull-down menu, as indicated by the following figure. These menu items correspond to the toolbar icons described above.



A meters configuration menu (lower left corner of figure) will appear when you place the mouse pointer over a meter and click the right mouse button. This menu allows you to access various dialog boxes for changing parameters for meters. The steps for configuring a meter are detailed below.

Note: The *Show Peak Hold Indicator / Reset Peak Hold Indicator* selections are not an option for Digital Meters and do not appear on the configuration window for digital meters.



Meter Configuration Menu and Related Dialog Boxes

Configuring a Meter

1. Bring up the desired meter group (Bar Graph, Analog, or Digital).
2. Place the mouse cursor over the meter to reconfigure.
3. Click on the right mouse button. A Meters Configuration Menu will appear (see figure above).
4. Select the desired option from the meter configuration menu.
5. If a dialog box is required, for example, to change a limit, enter in the new value in the appropriate parameter box and press "Apply" or "OK." Pressing "Apply" implements your changes, but keeps the dialog box open, allowing you to make additional changes. Pressing "OK" implements your changes and closes the dialog box.

The previous figure and the next table and the previous figure serve as a quick reference to meters configuration.

Configure Meter Settings, Function Descriptions	
Function	Description
Select Channel	Select a new channel for display. The selected channel will replace the one currently seen in the meter. Note that double-clicking the left mouse button in the meter region will also bring up a dialog box which allows you to select a new channel.
Set Scale	Set the high and low points of the scale as well as define the decimal place format.
Show Peak Hold Indicator	Places high and low uni-directional floating markers on the scale to indicate the highest and lowest values reached up to the present time. This feature does not apply to the Digital Meters selection.
Reset Peak Hold Indicator	Resets the floating markers. Upon reset, the markers will instantly adjust to indicate the highest and lowest values reached since the time of the reset. This feature does not apply to the Digital Meters selection.
Show Trend Indicator	Displays a pointer to indicate the direction of the trend. Note that during rapid meter fluctuations the increase and decrease pointers will appear to blink simultaneously.
Set Limits	Provides a way of establishing high and low limit set-points.
Show Limits	Displays limits by adding color (red for high, blue for low) to the scale regions which equal and exceed the set limit values. For Digital Meters the limits are indicated by red numbers and an upper red bar for hitting or exceeding the high limit; and blue numbers and a lower blue bar when reaching or exceeding the low limit.
Properties	Allows setting and showing limits, as well as opening the Scale dialog box.

You can access a different dialog box from the one initially selected. For example, from the Set Scale dialog box you can select Limits to access the Set Limits/Show Limits display, as well as select “Misc.” which allows you to “Show Trend Indicator” and “Show Peak Hold Indicators.”

Mouse buttons

- Left: Double-clicking the left mouse button in a meters scale area brings up a channel selection pop-up menu.
- Right: Single-clicking the right mouse button in a meters scale area brings up a configuration pop-up menu.

Enable Input Reading Column

(no toolbar icon)

This command enables/disables the “Reading” column of the Analog Input Channel Configuration spreadsheet to provide a numeric view of incoming data. This function toggles on and off when the menu item is repeatedly selected.

Note: With the input reading columns ON, no modifications to program parameters may be performed.

Start (or Stop) All Indicators

(no toolbar icon)

Starting or Stopping all indicators affects several windows if open, including: Reading column, Charts, Bar Graph Meters, Analog Meters, and Digital Meters. **Note:** you can start or stop any of these active windows separately using their own Start or Stop (Pause) buttons.

Error Codes

Software Errors

These errors can appear in the LogBook Monitor window of LogView.

0	No Error	240	Invalid Version
Command Error Definitions			
100	Command Error	241	Hardware Error
101	Invalid Character	250	Hardware Missing
102	Syntax Error	251	Mass Storage Error
103	Invalid Separator	252	Missing Media
104	Data Type Error	253	Corrupt Media
105	GET Not Allowed	254	Media Full
108	Parameter Not Allowed	255	Directory Full
109	Missing Parameter	256	File Name Not Found
110	Command Header Error	257	File Name Error
111	Header Separator Error	258	Media Protected
112	Program Mnemonic Too Long	260	Expression Error
113	Undefined Header	261	MathError In Expression
114	Header Suffix Out Of Range	270	Macro Error
120	Numeric Data Error	271	Macro Syntax Error
121	Invalid Character In Number	272	Macro Execution Error
122	Mantissa Too Large	273	Illegal Macro Label
Not Defined In SCPI			
123	Exponent Too Large	274	Macro Parameter Error
124	Too Many Digits	275	Macro Definition Too Long
128	Numeric Data Not Allowed	276	Macro Recursion Error
130	Suffix Error	277	Macro Redefinition Not Allowed
131	Invalid Suffix	278	Macro Header Not Found
134	Suffix Too Long	280	Program Error
138	Suffix Not Allowed	281	Cannot Create Program
140	Character Data Error	282	Illegal Program Name
141	Invalid Character Data	283	Illegal Variable Name
144	Character Data Too Long	284	Program Currently Running
148	Character Data Not Allowed	285	Program Syntax Error
150	String Data Error	286	Program Runtime Error
151	Invalid String Data	290	Memory Use Error
154	String Data Too Long	291	Out Of Memory
158	String Data Not Allowed	292	Referenced Name Does Not Exist
160	Block Data Error	293	Referenced Name Already Exists
161	Invalid Block Data	294	Incompatible Type
168	Block Data Not Allowed	Device-Specific Error Definitions	
170	Expression Command Error	300	Device Specific Error
171	Invalid Expression	310	System Error
178	Expression Data Not Allowed	311	Memory Error
180	Macro Definition Error	312	PUD Memory Lost
183	Invalid Inside Macro Definition	313	Calibration Memory Lost
184	Macro Parameter Command Error	314	Save Recall Memory Lost
Execution Error Definitions			
200	Execution Error	315	Configuration Memory Lost
201	Invalid While In Local	320	Storage Fault
202	Settings Lost Due To RTL	321	Device Out Of Memory
203	Command Protected	330	Self Test Failed
210	Trig Error	340	Calibration Failed
211	Trig Ignored	350	Queue Overflow
212	Arm Ignored	360	Communication Error
213	Init Ignored	361	Parity Error In Program Message
214	Trig Deadlock	362	Framing Error In Program Message
215	Arm Deadlock	363	Input Buffer Overrun
220	Parameter Error	Query Error Definitions	
221	Settings Conflict	400	Query Error
222	Data Out Of Range	410	Query Interrupted
223	Too Much Data	420	Query Unterminated
224	Illegal Parameter Value	430	Query Deadlocked
225	Operation Out Of Memory	440	Query Unterminated After Indef Response
230	Lists Not Same Length	Power On Event Definitions	
231	Data Corrupt Or Stale	500	Lbk Event Power On
232	Data Questionable	600	Lbk Event User Request
233	Invalid Format	700	Lbk Event Request Control
		800	Lbk Event Operation Complete
		900	Outputs Deteriorating
		905	Losing Trigger Events
		906	Losing Stop Events

Hardware Errors

The following is a list of fatal hardware errors. LogBook's ERROR LED indicator (on the front panel) will blink on/off the number of times indicated by the flash code. If the LogBook is attached to an LBK1, the corresponding control terminal message will be displayed (otherwise, you must count the LED flashes to determine the error). Note that flash codes 08, 09, and 17 are associated with multiple errors and thus require an LBK1 to determine which error applies.

ERROR LED

<u>Flash Code</u>	<u>Control Terminal Message</u>
1	NS486 Chip Revision Changed Error
2	Watchdog Timeout Error
3	Flash Startup Code Checksum Error
4	Flash FPGA Code Checksum Error
5	DRAM initialization not complete Error
6	DRAM Sizing Error
7	1 MB DRAM SIMM - Insufficient Memory
8	DRAM Address Line Error
8	DRAM Data Line Error
8	DRAM Integrity Test Error
9	SRAM Address Line Error
9	SRAM Data Line Error
9	SRAM Integrity Test Error
10	SRAM Low Battery Error
11	FPGA Load Error
12	Real Time Clock Low Battery Error
13	DRAM Parity Error
14	Analog Output Slot Empty
15	Calibration Table Verification Error
16	ADC Self Calibration Error
17	TRAP: Divide by Zero, or Divide Overflow
17	TRAP: Debug Trap; Hardware Breakpoint
17	TRAP: Non-Maskable Interrupt (NMI)
17	TRAP: Software Breakpoint
17	TRAP: INT0 Instruct.: Overflow Detected
17	TRAP: BOUND instruction: Range Exceeded
17	TRAP: Invalid Opcode
17	TRAP: Coprocessor Not Available
17	TRAP: Double Fault
17	TRAP: Coprocessor Segment Overrun
17	TRAP: Invalid Task State Segment
17	TRAP: Segment Not Present
17	TRAP: Stack Exception
17	TRAP: General Protection Fault
18	Printf Floating Point Error
19	FPGA PC-Card File Checksum Error
20	FPGA PC-Card File Load Error

DRAM = Dynamic Random Access Memory (the 4- or 16-MB SIMM board)
SRAM = Static Random Access Memory