

JVC

VIDEO CASSETTE RECORDER

HR-J790EU HR-J794EU

SHOWVIEW[®]
DELUXE

VHS
PAL

SQP[®]B

Hi-Fi

INSTRUCTIONS

LPT0627-001A
COPYRIGHT © 2001 VICTOR COMPANY OF JAPAN, LTD.



Printed in Malaysia
1201 MNV*ID*PJ

SAFETY FIRST	1
Buttons, Connectors and Indicators	2
Basic Connections	3
Initial Settings	4
Auto Set Up.....	4
Preset Download.....	4
Language Set.....	4
T-V Link Functions	5
Satellite Receiver Control Set	5
Playback	6
Recording	7
SHOWVIEW[®] System Setup	8
Timer Recording	9
SHOWVIEW [®] Timer Programming.....	9
Express Timer Programming.....	9
24 Hour Express Timer Programming.....	10
Checking, canceling or changing programme settings.....	10
Automatic Satellite Programme Recording.....	10
Editing	11
Editing with another video recorder or a camcorder	11
Audio Dubbing.....	11
System Connections	12
Connecting to a satellite receiver.....	12
Connecting/Using a decoder	12
Connecting/Using a stereo system	12
Subsidiary Settings	12
Mode Set.....	12
Clock Set.....	13
Tuner Set	13
Video Channel Set.....	16
Specifications	16

WARNING

There are two different types of SECAM colour systems: SECAM-L, used in FRANCE (also called SECAM-West), and SECAM-B, used in Eastern European countries (also called SECAM-East).

1. This recorder can also receive SECAM-B colour television signals for recording and playback.
2. Recordings made of SECAM-B television signals produce monochrome pictures if played back on a video recorder of SECAM-L standard, or do not produce normal colour pictures if played back on a PAL video recorder with SECAM-B system incorporated (even if the TV set is SECAM-compatible).
3. SECAM-L prerecorded cassettes or recordings made with a SECAM-L video recorder produce monochrome pictures when played back with this recorder.
4. This recorder cannot be used for the SECAM-L standard. Use a SECAM-L recorder to record SECAM-L signals.

IMPORTANT

- Please read the various precautions on pages 1 and 2 before installing or operating the recorder.
- It should be noted that it may be unlawful to re-record pre-recorded tapes, records, or discs without the consent of the owner of copyright in the sound or video recording, broadcast or cable programme and in any literary, dramatic, musical, or artistic work embodied therein.

For Italy:

"It is declared that this product, brand JVC, conforms to the Ministry Decree n. 548 of 28 Aug.'95 published in the Official Gazette of the Italian Republic n. 301 of 28 Dec.'95"

The STANDBY/ON ϕ /I button does not completely shut off mains power from the unit, but switches operating current on and off. " ϕ " shows electrical power standby and "I" shows ON.

Video tapes recorded with this video recorder in the LP (Long Play) mode cannot be played back on a single-speed video recorder.

VHS[®] SQPB[®] HQ[®] SHOWVIEW[®]
PAL DELUXE

- Cassettes marked "VHS" (or "S-VHS") can be used with this video cassette recorder. However, S-VHS recording is not possible with this model.
- This model is equipped with SQPB (S-VHS QUASI PLAYBACK) that makes it possible to play back S-VHS recordings with regular VHS resolution.
- HQ VHS is compatible with existing VHS equipment.
- SHOWVIEW is a registered trademark of Gemstar Development Corporation. The SHOWVIEW system is manufactured under licence from Gemstar Development Corporation.

SAFETY FIRST

Safety Precautions

The rating plate and the safety caution are on the rear of the unit.

WARNING: DANGEROUS VOLTAGE INSIDE

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

CAUTION

- When you are not using the recorder for a long period of time, it is recommended that you disconnect the power cord from the mains outlet.
- Dangerous voltage inside. Refer internal servicing to qualified service personnel. To prevent electric shock or fire hazard, remove the power cord from the mains outlet prior to connecting or disconnecting any signal lead or aerial.

When the equipment is installed in a cabinet or a shelf, make sure that it has sufficient space on all sides to allow for ventilation (10 cm or more on both sides, on top and at the rear).

When discarding batteries, environmental problems must be considered and the local rules or laws governing the disposal of these batteries must be followed strictly.

Failure to heed the following precautions may result in damage to the recorder, remote control or video cassette.

1. **DO NOT** place the recorder ...
 - ... in an environment prone to extreme temperatures or humidity.
 - ... in direct sunlight.
 - ... in a dusty environment.
 - ... in an environment where strong magnetic fields are generated.
 - ... on a surface that is unstable or subject to vibration.
2. **DO NOT** block the recorder's ventilation openings or holes. (If the ventilation openings or holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.)
3. **DO NOT** place heavy objects on the recorder or remote control.
4. **DO NOT** place anything which might spill on top of the recorder or remote control. (If water or liquid is allowed to enter this equipment, fire or electric shock may be caused.)
5. **DO NOT** expose the apparatus to dripping or splashing.
6. **DO NOT** use this equipment in a bathroom or places with water. Also **DO NOT** place any containers filled with water or liquids (such as cosmetics or medicines, flower vases, potted plants, cups, etc.) on top of this unit.
7. **DO NOT** place any naked flame sources, such as lighted candles, on the apparatus.
8. **AVOID** violent shocks to the recorder during transport.

MOISTURE CONDENSATION

Moisture in the air will condense on the recorder when you move it from a cold place to a warm place, or under extremely humid conditions—just as water droplets form on the surface of a glass filled with cold liquid. Moisture condensation on the head drum will cause damage to the tape. In conditions where condensation may occur, keep the recorder's power turned on for a few hours to let the moisture dry.

How to use the remote control

Before use, insert the batteries in the correct directions as indicated under the battery cover. The remote control can operate most of your recorder's functions, as well as basic functions of JVC TV sets.

- Point the remote control toward the receiving window on the recorder.
- The maximum operating distance of the remote control is about 8 m.
- To operate your JVC TV, while holding down **TV**, press the corresponding button: **⏻/⏪**, **TV/VCR**, **TV PR +/-**, **TV ▲+/-** (TV Volume), **⏻/⏪** (TV Muting).

NOTE:

If the remote control does not work properly, remove its batteries, wait for a few seconds, replace the batteries and then try again.

Video heads cleaning


The heads get dirty in the following cases:

- in an environment prone to extreme temperature or humidity
 - in a dusty environment
 - flaw, dirt or mold on video tapes
 - continuous usage for a long time
- Use a dry cleaning cassette — TCL-2 — when:

- Rough, poor picture appears while a tape is played back.
- The picture is unclear or no picture appears.
- "USE CLEANING CASSETTE" appears on the screen (only with "O.S.D." set to "ON" (⏻ 12)).

Usable cassettes

- Compact VHS camcorder recordings can be played on this recorder. Simply place the recorded cassette into a VHS Cassette Adapter and it can be used just like any full-sized VHS cassette.
- This recorder is equipped with SQPB (S-VHS QUASI PLAYBACK) that lets you watch tapes recorded in the S-VHS format and the SP mode with regular VHS resolution.
 - * SQPB does not deliver Super VHS resolution.
- This recorder can record on regular VHS and Super VHS cassettes. However, it will record regular VHS signals only.
 - * S-VHS recording is not possible with this recorder.



ATTENTION:

To mobile phone users:



Using a mobile phone in the vicinity of the recorder may cause picture vibration on the TV screen or change the screen to a blue back display.

On placing the recorder:


Some TVs or other appliances generates strong magnetic fields. Do not place such appliance on top of the recorder as it may cause picture disturbance.

Buttons, Connectors and Indicators


Front Panel



Rear Panel




Remote control



* PDC recording is not possible in Central and Eastern Europe.

On-screen display

If you press **OK** on the remote control when "O.S.D." is set to "ON", you can see the current recorder status on the screen. To clear the on-screen display, press **OK** again. The indications are not recorded even if the recorder is in the recording mode.



1 Recorder operation mode

2 Tape speed

3 Tape direction

4 Time counter

5 Tape remaining time

6 Audio mode

7 Tape position*

* The position of "I" in relation to "0" (Beginning) or "+" (End) shows the current position on the tape.

8 VPS/PDC* indicator

* PDC recording is not possible in Central and Eastern Europe.

9 Type of broadcast

10 Current day/month/year

11 Clock

12 Channel and auxiliary input

13 Cassette loaded mark

Basic Connections


1 Check contents

Make sure the package contains all of the accessories listed in "Specifications" (16).

2 Situate recorder

Place the recorder on a stable, horizontal surface.

3 Connect recorder to TV



RF Connection

1 Disconnect the TV aerial cable from the TV.

2 Connect the TV aerial cable to the ANT. IN connector on the rear of the recorder.

3 Connect the provided RF cable between the RF OUT connector on the rear of the recorder and the TV's aerial connector.

AV Connection

If your TV is equipped with a 21-pin SCART connector, perform AV connection to improve picture quality during tape playback.

1 Connect the aerial, recorder and TV as shown in the illustration.

2 Connect an optional 21-pin SCART cable between the L-1 IN/OUT connector on the rear of the recorder and the TV's 21-pin SCART connector.

4 Connect recorder to mains

Plug the mains power cord into a mains outlet.

Initial Settings

After the $\psi/1$ is pressed for the first time to power on the recorder, the recorder starts Auto Set Up or Preset Download.

ATTENTION:

If you have connected the recorder to a TV offering T-V Link via a fully-wired 21-pin SCART cable and if the TV is turned on, the recorder automatically performs the Preset Download even if you perform Auto Set Up.

Before starting:

- Perform "Basic Connections" (☞ 3).
- Set the TV to its AV mode (with AV connection) or UHF channel 36 (with RF connection).

Auto Set Up

— Auto Channel Set/Auto Clock Set*/Auto Guide Program Number Set*

* If you select a country in Central or Eastern Europe, set the clock and Guide Program Number manually.

1 Turn on recorder

Press $\psi/1$. The Country Set screen appears on the screen.


- If you have connected your TV to the recorder with RF connection and the on-screen display appearing on UHF channel 36 looks distorted, perform "Video Channel Set" (☞ 16).



2 Select your country

Press \triangle/∇ to place the pointer next to your country, then press **OK**. The language is automatically selected for the on-screen display depending on the country you have selected. The AUTO SET/T-V LINK screen appears.


- If you select BELGIUM or SUISSE and press **OK**, the Language Set screen appears. Press \triangle/∇ to place the pointer next to the desired language, then press **OK**. Go to step 3.
- If you select MAGYARORSZÁG, ČESKÁ REPUBLIKA, POLSKA or OTHER EASTERN EUROPE, press **OK**. The Clock Set screen appears. Press \triangle/∇ until the desired time appears, then press **OK** or \triangleright . Set the date and year in the same way. (Holding \triangle/∇ changes the time in 30-minute intervals, or changes the date in 15-day intervals.) Then press **MENU** and go to step 3.



3 Perform Auto Set Up

Press \triangle/∇ to place the pointer next to "AUTO SET" and press **OK** or \triangleright .

- If you are using the display panel, press \triangle/∇ to select "Auto" and press **OK** or \triangleright .



- Do NOT press any button during Auto Set Up. When the Auto Set Up is completed, "SCAN COMPLETED" appears for about 5 seconds, then the normal screen appears.

4 Check results



If both Auto Channel Set and Clock Set have been performed successfully, the correct current time is displayed.

Turn on the TV and select its video channel or AV mode. Then make sure that all necessary stations have been stored in the recorder's memory by using the **PR** button(s).

If Auto Channel Set has succeeded but Clock Set has not, "1" is displayed.


1 Turn on the TV and select its video channel or AV mode. Then make sure that all necessary stations have been stored in the recorder's memory by using the **PR** button(s).

2 Perform "Clock Set" (☞ 13).



If both Auto Channel Set and Clock Set have failed, "--:--:--" is displayed.

Make sure the cables are connected properly. Turn off the recorder once, then turn the recorder back on again. The Country Set screen appears on the screen. Perform Auto Set Up or Preset Download again.



Preset Download

— Auto Channel Set by downloading preset data from TV/Auto Clock Set*/Auto Guide Program Number Set*

* If you select a country in Central or Eastern Europe, set the clock and Guide Program Number manually.

ATTENTION:

You can use this function only with a TV offering T-V Link, etc.* Be sure to use a fully-wired 21-pin SCART cable.

* Compatible with TVs offering T-V Link, EasyLink, Megalogic, SMARTLINK, Q-Link, DATA LOGIC or NexTView Link via fully-wired 21-pin SCART cable. The degree of compatibility and available functions may differ by system.


Before starting:

Perform steps 1 – 2 of "Auto Set Up".

1 Perform Preset Download

Press \triangle/∇ to place the pointer next to "T-V LINK" and press **OK** or \triangleright .

- If you are using the display panel, press \triangle/∇ to select "CH --" and press **OK** or \triangleright .



- Do NOT press any button during Preset Download. When Preset Download is completed, "COMPLETED" appears for about 5 seconds, then the normal screen appears.

2 Check results

Perform step 4 of "Auto Set Up".

3 Set video channel to off

Perform "Video Channel Set" (☞ 16).

NOTES:

- Depending on the area, the recorder cannot perform Auto Set Up or Preset Download properly.
- In the area where no TV station transmits a PDC (Programme Delivery Control) signal, the recorder can perform neither Auto Clock Set nor Auto Guide Program Number Set.
- If you have moved to a different area, perform "Video Channel Set" (☞ 16) (with RF connection), "Tuner Set" (☞ 13) and "Clock Set" (☞ 13) as required.
- If a new station starts broadcasting in your area, perform "Tuner Set" (☞ 13) and, if necessary, "Video Channel Set" (☞ 16).

Language Set

You can change the language setting manually as required.

1 Access Main Menu screen, then Auto Channel Set screen

Press **MENU**. Press \triangle/∇ to place the pointer next to "AUTO CH SET", then press **OK** or \triangleright .



2 Select your country

Press \triangle/∇ to place the pointer next to your country, then press **OK** or \triangleright .

3 Select language

Press \triangle/∇ to place the pointer next to the desired language.

- You do not have to press **OK**; pressing **OK** enters AUTO SET/T-V LINK screen.

4 Return to normal screen

Press **MENU**.

T-V Link Functions

When you connect the recorder to your TV via a fully-wired 21-pin SCART cable, the following functions are available. You can use these functions only with a TV offering T-V Link, etc.* For details, refer to the instruction manual of your TV.

* Compatible with TVs offering T-V Link, EasyLink, Megalocic, SMARTLINK, Q-Link, DATA LOGIC or NexTVView Link via fully-wired 21-pin SCART cable. The degree of compatibility and available functions may differ by system.

NexTVView Link

You can download the EPG (Electronic Programme Guide) information from your TV for timer-programming on the recorder.

TV Auto Power On


The TV will turn on and be set to its AV mode automatically whenever you play a tape.

VCR Auto Standby

You can use your TV's remote control to turn off the recorder.

Direct Rec

You can easily start recording the programme that you are watching on your TV. When you use this function, set "DIRECT REC" to "ON". (☞ 12)



5 Turn on satellite receiver

Turn on the satellite receiver's power.

6 Access Main Menu screen, then Initial Set screen

Press **MENU**. Press $\Delta \nabla$ to place the pointer next to "INITIAL SET", then press **OK** or \triangleright .


7 Access Sat Control Set screen

Press $\Delta \nabla$ to place the pointer next to "SAT CONTROL SET", then press **OK** or \triangleright .

8 Enter satellite receiver's brand

Press the appropriate **number keys** to enter the brand code from the following list, then press **OK**.

- If the code you entered is invalid, the code field will be reset. Enter the correct code again.



BRAND NAME	CODE	BRAND NAME	CODE
JVC	73	MASPRO	70
AMSTRAD	60, 61, 62, 63, 92	NOKIA	87, 94
CANAL	81	PACE	65, 67, 74, 86, 92
SATELLITE		PANASONIC	74, 92
CANAL +	81	PHILIPS	66, 84, 101
D-BOX	85	RADIX	78
ECHOSTAR	78	RFT	69
ECHOSTAR	82	SABA	97
(VIA DIGITAL)		SAGEM	83, 90
FINLUX	68	SALORA	68
FORCE	89	SAMSUNG	83
GALAXIS	88	SIEMENS	64
GRUNDIG	64, 65, 102	SKYMASTER	69, 98
HIRSCHMANN	64, 78, 99	TECHNISAT	66, 100
HUMAX	88	THOMSON	97
ITT NOKIA	68	TPS	83
KATHREIN	70, 71, 96	TRIAX	91
LUXOR	68	WISI	64
MASCOM	93		

9 Select satellite receiver's channel for testing

Press the appropriate **number keys** to enter the channel position on the satellite receiver, then press **OK**. The recorder enters the test mode.

10 Check result of the test

If the satellite receiver's channel number has been changed to the same one as you set in step 9 ...

Press $\Delta \nabla$ to place the pointer next to "CHANGED TO ...", then press **OK** or \triangleright to finish the Sat Control Set mode.

If the satellite receiver's channel number has not been changed correctly ...

Press $\Delta \nabla$ to place the pointer next to "NOT CHANGED", then press **OK** or \triangleright . Then perform the procedure again from step 8.

NOTE:

The Satellite Controller may not function properly with some types of satellite receiver.

Satellite Receiver Control Set

When you use an optional Satellite Controller and perform the following settings, you can control your satellite receiver's channel for timer recording. Approximately 20 seconds before the timer recording starts, the recorder sets its input mode to "L-2" and the Satellite Controller switches the satellite receiver's channels.

NOTE:


The Satellite Controller does not function for 24 Hour Express Timer Programming.

1 Situate Satellite Controller

Place the Satellite Controller so that the path between its transmitter and the satellite receiver's remote sensor is unobstructed.

2 Attach Satellite Controller

Fix securely using the adhesive strip attached on the back of the Satellite Controller.



3 Make connections

Connect the recorder's L-2 IN/DECODER connector to the satellite receiver's 21-pin SCART connector.

4 Connect Satellite Controller to recorder

Connect the Satellite Controller to the SAT CONTROL connector on the rear panel.



Playback

Basic Playback

Turn on the TV and select the video channel or AV mode.

1 Load a cassette

Make sure the window side is up, the rear label side is facing you and the arrow on the front of the cassette is pointing towards the recorder.



- Do not apply too much pressure when inserting.
- The recorder turns on, and the counter is reset, automatically.
- If the cassette's record safety tab has been removed, playback begins automatically.

2 Start playback

Press ►.

During playback

Stop playback

Press ■ on the remote OR Press ■/▲ on the recorder control.

Pause playback and view still picture

Press ■. OR Push the JOG dial.
 • Press ► to resume normal playback. • Push the JOG dial again to resume normal playback.

Pause and Frame-by-Frame playback

Press ■ to pause, then press ◀◀ or ▶▶ (or ■) repeatedly. OR Push the JOG dial to pause, then turn the JOG dial to the left or right.
 • Press ► to resume normal playback. • Push the JOG dial again to resume normal playback.

High-Speed Search


Press ◀◀ or ▶▶. OR Turn the JOG dial quickly to the left or right.

- Press ► to resume normal playback.
- If you press and hold ◀◀ or ▶▶ for more than 2 seconds, simply releasing it cancels the picture search, and normal playback resumes.

Variable Speed Search (including slow-motion)

Press ◀◀ or ▶▶ repeatedly. OR Turn the JOG dial to the left or right.

- Press ► to resume normal playback.
- Each time you press ◀◀ or ▶▶ or each time JOG dial passes a click position, the playback speed changes. To decrease the speed during picture search, press the opposite direction button repeatedly or turn the dial in the opposite direction.
- During still picture, press and hold ▶▶ to start forward (or ◀◀ to start reverse) slow motion playback. When you release the button, still picture resumes. During still picture, holding ■ for more than 2 seconds also starts forward slow motion playback. If you press ■ again, still picture resumes.



Reverse ← → Forward

Reverse search 3 steps	Reverse play	Reverse slow motion 2 steps	Slow motion 2 steps	Normal play	Forward search 4 steps
---------------------------	--------------	--------------------------------	------------------------	-------------	---------------------------

When the tape is not running

Rewind/fast-forward at high speed

Press ◀◀ or ▶▶. OR Turn the JOG dial quickly to the left or right.

Eject the cassette

Press ■/▲.
 • You can also eject the cassette when the recorder is turned off.

Turn off the recorder

Press ⏻.

ATTENTION:

In the search, still, slow-motion or frame-by-frame playback mode,

- the picture will be distorted
- the noise bars will appear
- there will be a loss of color with an LP-recorded tape

Playback Features

Adjusting tracking condition

Automatic tracking adjustment

When a new cassette is loaded, the recorder enters the automatic tracking mode.

Manual tracking adjustment

If automatic tracking cannot eliminate noises well during playback, adjust the tracking manually.

1 Press /// during playback to activate manual tracking.

2 Press PR + or – to eliminate the noises. Press it briefly for a fine adjustment, or press and hold for a coarse adjustment.

- Press /// again to reactivate automatic tracking.

Selecting Soundtrack

Your recorder is capable of recording three soundtracks (HIFI L ▶, HIFI L ◀ R and NORM) and plays back the one you select. Pressing AUDIO changes the soundtrack as follows:

- HIFI L ▶ ◀ R : For Hi-Fi stereo tapes
- HIFI L ▶ : For main audio of Bilingual tapes
- HIFI ◀ R : For sub audio of Bilingual tapes
- NORM : For audio-dubbed tapes
- HI FI NORM : For audio-dubbed tapes

NOTE:

Set "O.S.D." to "ON" to display the indications on the screen. (☞ 12)

Automatic operations after rewinding

— Next Function Memory

The Next Function Memory "tells" the recorder what to do after rewinding. Ensure that the recorder is in stop mode.

• For Automatic Playback Start

Press ◀◀, then press ► within 2 seconds.

• For Automatic Power Off

Press ◀◀, then press ⏻ within 2 seconds.

• For Automatic Timer Standby

Press ◀◀, then press ⏻ within 2 seconds.

NOTE:

It is not possible to select the Automatic Timer Standby function if the cassette's record safety tab is removed.

Playing back tape repeatedly (100 times)

— Repeat Playback

During playback, press and hold ► for more than 5 seconds. “▷” on the display panel starts blinking slowly. To stop playback, press ■ on the remote control or ■/▲ on the recorder.

NOTE:

Pressing ►, ◀◀, ▶▶ or || also stops Repeat Playback.

Locating beginning of recordings

— Index Search

Index codes are placed on the tape at the beginning of each recording when recording on this recorder.

1 While the tape is not running, press ◀ or ▷ (◀◀ or ▶▶) to start search.



2 To access a recording of 2 to 9 index codes away, press ◀ or ▷ (◀◀ or ▶▶) repeatedly until the correct number is displayed on the screen (only if “O.S.D.” is set to “ON” (☞ 12)).

Example:

To locate the beginning of B from the current position, press ◀ twice.

To locate the beginning of D from the current position, press ▷ once.

• Playback begins automatically when the desired recording is located.



Locating beginning of timer recordings

— Instant Review


After ensuring that the recorder is turned off and that the timer mode is disengaged, press **REVIEW**.

• The recorder turns on, and rewinds to the index code indicating the beginning of the last timer-recorded programme, then begins playback automatically.

• You can access a programme as far as 9 index codes away from the current tape position. For example, if you have timer-recorded 3 programmes, the REVIEW indicator and “3” blink. To watch the first of the 3 programmes, press **REVIEW** three times.

• The number of recorded programmes is not displayed on the display panel after Automatic Satellite Programme Recording.

• The Instant Review function can also operate if the recorder is turned on.



Skipping unwanted portions

— Skip Search

Press **30 SEC** once to 4 times during playback. Each press initiates a 30-second period of high-speed playback (up to 2 minutes). When the specified portion of the tape is skipped, normal playback resumes automatically. To return to normal playback during Skip Search, press ►.

Recording

Accidental erasure prevention

To prevent accidental recording on a recorded cassette, remove its record safety tab. To record on it later, cover the hole with adhesive tape.



Record safety tab

Basic Recording

Turn on the TV and select the video channel or AV mode.

1 Load a cassette

Make sure the record safety tab is intact. If not, cover the hole with adhesive tape before inserting the cassette.

• The recorder turns on, and the counter is reset, automatically.

2 Select recording channel

Press **PR+/-** or the **number keys**. Or push the **JOG** dial, then turn it to the left or right.

• You can select channel in the stop mode or recording pause mode.

3 Set tape speed

Press **SP/LP** (//). The current setting for the tape speed appears on the display panel and the screen for about 5 seconds. Press **SP/LP** (//) again to change the setting while tape speed is displayed.

4 Start recording

On the recorder, press ●. Or on the remote control, while holding ●, press ►.

• If the tape reaches its end during recording, the recording stops and “○” and “▷” on the display panel blink. Press ■/▲ on the recorder to eject the cassette or press ◀◀ on the remote control to rewind the tape.

• When “DIRECT REC” is set to “ON” (☞ 12), if you press any button just after pressing ● on the recorder (or ● and ► on the remote control), the recorder may not function properly.

During recording

Pause recording

Press ||.

• Press ► to resume recording.

• You can select channel in the recording pause mode.

Stop recording

Press ■ on the remote control.

OR Press ■/▲ on the recorder.

Recording Features

Recording Resume Function

If there is a power outage during recording (or Instant Timer Recording, or timer recording), the recording will resume automatically when the power is restored to the recorder. (No setting is required for this function.)

NOTE:

If a power outage exceed the recorder's memory backup time, Recording Resume Function does not work.

Tape Remaining Time/Time Counter

Press -:-:- to display the tape remaining time and time counter on the screen. To reset the time counter, press **0000**.

NOTES:

• Set “O.S.D.” to “ON” to display the indications on the screen. (☞ 12)

• Depending on the type of tape used, the tape remaining time may not appear right away, or is not correct. “-:-:-” may sometimes appear, or the display may blink on occasion.

Watching one programme while recording another

Once recording is in progress, all you need to do is to set the channel controls on the TV for the station you wish to view.

- The programme selected with the TV's channel controls appears on the screen, while the one selected with the **PR+/-** is recorded on the tape.
- If a decoder is connected to the recorder, you can select a scrambled channel as well with the TV channel controls.

Specifying recording length

— Instant Timer Recording (ITR)

During recording, press **●** on the recorder repeatedly until the desired recording length appears on the display panel. "○" on the display panel starts blinking.

- Each time you press the button, recording length increases in 30-minute intervals (up to 6 hours).
- The recorder turns off after recording is finished.
- To cancel an ITR, press **■** on the remote control or **■/▲** on the recorder.

Receiving stereo and bilingual programmes

Your recorder is equipped with a Sound-Multiplex decoder (A2) and a Digital stereo sound decoder (NICAM) as well, making reception of stereo and bilingual broadcasts possible.

When the channel is changed, the type of broadcast being received will be displayed on the screen for a few seconds.

Type of broadcast being received	On-screen display
A2 Stereo	ST
A2 Bilingual	BIL.
Regular Monaural	(none)
NICAM Stereo	ST NICAM
NICAM Bilingual	BIL. NICAM
NICAM Monaural	NICAM

- To listen to a stereo programme, press **AUDIO** until "HIFI L **▶** R" appears on the screen.
- To listen to a bilingual programme, press **AUDIO** until "HIFI L **▶**" or "HIFI **◀** R" appears on the screen.
- To listen to the standard (regular monaural) audio while receiving a NICAM broadcast, press **AUDIO** until "NORM" appears on the screen.

NOTE:

Set "O.S.D." to "ON" to display the indications on the screen. (☞ 12)

To record stereo and bilingual programmes (A2)

- Stereo programmes are automatically recorded in stereo on the Hi-Fi audio track (with the normal audio track recording mixed L and R channel sound).
- Bilingual programmes are automatically recorded in bilingual on the Hi-Fi audio track. The main soundtrack is recorded on the normal audio track.

To record NICAM stereo and bilingual programmes

The NICAM audio programme is recorded on the Hi-Fi audio track, and the standard audio programme on the normal audio track.

NOTES:

- If the quality of stereo sound being received is poor, the broadcast may be received in monaural with better quality.
- Before playing back a programme recorded in stereo, or a bilingual programme, refer to "Selecting Soundtrack" (☞ 6).

SHOWVIEW® System Setup

Set the Guide Program numbers manually only in the following cases:

- When you select a country in Central or Eastern Europe for country setting.
- **OR**
- When timer-programming with the SHOWVIEW system, the channel position, where the station you wish to record is received on your recorder, is not selected.
- **OR**
- When you add a channel after Auto Set Up, Preset Download or Auto Channel Set has taken place.
- **OR**
- When you wish to timer-record a satellite programme with the SHOWVIEW system.

Guide Program Number Set

"Guide Program (GUIDE PROG) number" refers to the assigned TV station numbers, according to broadcast area, for the SHOWVIEW timer recording. The Guide Program numbers can be found in most TV listings.

- If the Guide Program numbers are not set properly when you timer-record a TV programme using the SHOWVIEW system, the recorder will record a TV programme of a different station. When programming the timer using the SHOWVIEW system, be sure to check the desired channel is selected correctly.

1 Access Main Menu screen, then Initial Set screen

Press **MENU**. Press **△▽** to place the pointer next to "INITIAL SET", then press **OK** or **▷**.

2 Access Guide Program Set screen

Press **△▽** to place the pointer next to "GUIDE PROG SET", then press **OK** or **▷**.

3 Input Guide Program number

Press **△▽** to select the Guide Program number as shown in the TV listing, then press **OK** or **▷**.

4 Input receiving channel number

Press the **number key "0"** to select "TV PROG" or "SAT".

Press **△▽** to select the number of the channel on which the Guide Program number's broadcast is received, then press **OK** or **▷**.

- To timer-record a satellite programme with the SHOWVIEW system, you need to install an optional Satellite Controller and perform the procedure described in "Satellite Receiver Control Set" (☞ 5).
- Repeat steps **3** – **4** as necessary.

5 Return to normal screen

Press **MENU**.



Timer Recording

Up to 8 timer recording programmes can be made.

Before starting:

- If you select a country in Central or Eastern Europe for country setting, perform "Guide Program Number Set" (☞ 8).
- Set the clock properly. (☞ 13)
- Set "COLOUR SYSTEM" to the appropriate mode. (☞ 13)
- Load a cassette with the record safety tab intact.


NOTES:

- PDC recording is not possible in Central and Eastern Europe.
- If all the 8 programmes have already been set, "PROGRAM FULL" appears on the screen.
- If there is a conflict in the timer schedule and one programme overlaps with another, the programme starting earlier or programme with the lower programme number will be recorded.
- After timer recording is completed, the recorder turns off automatically.
- If the tape reaches its end during timer recordings, the recording stops and "⊖", "○" and "▷" on the display panel blink. Press ⊖ to disengage timer, then press ■/▲ on the recorder to eject the cassette or press ⊖/▶ then press ◀◀ on the remote control to rewind the tape.
- You can programme the timer recording while a regular recording is in progress; the menu screens will not be recorded.


SHOWVIEW® Timer Programming

The SHOWVIEW numbers are the numbers next to the programme in most TV listing.


- 1 Press **PROG** to access the SHOWVIEW NO. screen.



- 2 Press the appropriate **number keys** to input the SHOWVIEW number, then press **OK**. The SHOWVIEW program screen appears.



- Make sure the channel position number you wish to record is displayed; if not, see "SHOWVIEW® System Setup" (☞ 8) and set the Guide Program number correctly.
- If the number you entered is invalid, "ERROR" appears on the screen. Press X and input a valid SHOWVIEW number.
- If the "GUIDE PROG SET" screen appears, set the Guide Program number. To set the Guide Program number for the satellite broadcast station, press the **number key "0"** to change "TV PROG" to "SAT". Press ◀▽ to input the channel position number on which your recorder or satellite receiver receives that station. Then press **OK** or ▷ to set the Guide Program number. The SHOWVIEW Program screen appears.



- To set the tape speed, press **SP/LP (//)**.
- To set the VPS/PDC mode, press **VPS/PDC**.
- To change the stop time, press **STOP+/-**.
- To timer-record daily (Monday–Friday) or weekly serials, press **DAILY** or **WEEKLY**. Pressing the button again makes the "DAILY" or "WEEKLY" display disappear.

- 3 Press **OK** or **PROG**.

- 4 Press ⊖. The recorder turns off automatically and "⊖" is displayed on the display panel.

To timer-record a satellite broadcast using the SHOWVIEW system:


- 1 Perform "Satellite Receiver Control Set" (☞ 5).
- 2 Perform steps 1 – 4. In step 2, you cannot set "VPS/PDC" to "ON".
- 3 Leave the satellite receiver's power on.

Express Timer Programming

- 1 Press **PROG** to access the SHOWVIEW screen, then press **START+/-**. The program screen appears.

- 2 Press **START+/-**, **STOP+/-**, **DATE+/-** or **PR+/-** repeatedly to enter the start time, stop time, date or channel.

- Press and hold **START+/-** or **STOP+/-** to increase the time in 30-minute intervals.
- To set the tape speed, press **SP/LP (//)**.
- To set the VPS/PDC mode, press **VPS/PDC**.
- To timer-record daily (Monday–Friday) or weekly serials, press **DAILY** or **WEEKLY**. Pressing the button again makes the "DAILY" or "WEEKLY" display disappear.



- 3 Press **OK** or **PROG**.

- 4 Press ⊖. The recorder turns off automatically and "⊖" is displayed on the display panel.

To timer-record a satellite broadcast using Express Timer Programming:

- 1 Perform "Satellite Receiver Control Set" (☞ 5).
- 2 Perform steps 1 – 4. In step 2, press the **number key "0"** to change "TV PROG" to "SAT". Then press **PR+/-** to enter the channel position for the satellite broadcast. You cannot set "VPS/PDC" to "ON".
- 3 Leave the satellite receiver's power on.

VPS/PDC Recording

Now available from some TV stations, PDC (Programme Delivery Control) and VPS (Video Programme System) are service designed to assure safe, accurate timer recording. With this system, your recorder will start and stop recording when the preset TV programmes actually start and end — even if the broadcast time of a preset TV programme is changed.

NOTE:

When you use Express Timer Programming, set the start time (VPS or PDC time) exactly as advertised in the TV listing.


How to check if the station being received transmits a VPS/PDC signal (Excepting in Central and Eastern Europe)

- 1 Press **--:--** until the channel position appears on the display panel.
- 2 Hold down **START+** for about 5 seconds. "VPS/PDC" appears blinking on the screen. If a VPS/PDC signal is detected from the station, "VPS/PDC" will stop blinking. If no VPS/PDC signal is detected from the station, "VPS/PDC" will blink at a slower rate.
- 3 Press **--:--** or **START+** again to return to normal screen.

24 Hour Express Timer Programming

You can programme a timer recording that starts within 24 hours.

1 Press **24H EXPRESS** \odot . The start time indicator (\rightarrow) starts blinking on the display panel.



Start time



Stop time



Channel



2 Turn the **JOG** dial to the left or right to set the start time.

- One click stop of the **JOG** dial changes the time in 5-minute intervals.

3 Push the **JOG** dial. The stop time indicator (\rightarrow) starts blinking on the display panel. Turn the **JOG** dial to the left or right to set the stop time.

4 Push the **JOG** dial. Turn the **JOG** dial to the left or right to select the channel.

- To set the tape speed, press **SP/LP** (//). The current setting for the tape speed appears on the display panel for about 5 seconds. Press **SP/LP** (//) again to change the setting while tape speed is displayed.
- You can cancel the setting at any time by pressing and holding the **JOG** dial for more than 3 seconds. Repeat the steps **2** – **4**.

5 Press **24H EXPRESS** \odot . The recorder turns off automatically and “ \odot ” is displayed on the display panel.

NOTES:

- If “Err” appears on the display panel, repeat the above steps again.
- When a menu screen is shown, you cannot use 24 Hour Express Programming function. Press **MENU** to return to normal screen, and try again.
- You can use 24 Hour Express Programming function also when the recorder is turned off.

Checking, canceling or changing programme settings

1 Disengage timer recording standby mode

Press \odot , then press ψ /I.

- When “AUTO TIMER” is set to “ON” (12), press only ψ /I.

2 Access Program Check screen

Press \odot ?.

	START	STOP	CH	DATE
1	8:00	10:00	3	24.12
2	10:00	10:45	2	25.12
3	11:30	13:00	1	25.12
4				
5				
6				
7				
8				

\odot ?1: NEXT

3 Access Program screen

Press \odot ? again. Each time you press \odot ?, the next programme’s screen appears.

4 Cancel or change programme setting

To cancel a programme, press X.

To change a programme, press the appropriate button: **START**+/-, **STOP**+/-, **DATE**+/-, **DAILY**, **WEEKLY**, **PR**+/-, **VPS/PDC** and/or **SP/LP** (//).

- To change “TV PROG” to “SAT” for the channel position, press the number key “0”.

START	STOP
8:00	10:00
SP	VPS PDC OFF
DATE	TV PROG
24.12	3
	WDR

\odot ?1: NEXT

5 Return to normal screen

Press \odot ? repeatedly until no Program screen is shown.

6 Re-engage timer recording standby mode

Press \odot . The recorder turns off automatically and “ \odot ” is displayed on the display panel.

- When “AUTO TIMER” is set to “ON” (12), the timer recording standby mode automatically resumes when you turn off the recorder.

Automatic Satellite Programme Recording

You can automatically record a satellite programme which is timer-programmed on your satellite receiver.

1 Connect a satellite receiver to the L-2 IN/DECODER connector on the rear panel.

2 Set timer programme on satellite receiver referring to its instruction manual.

3 Load a cassette with the record safety tab intact.

4 Set “L-2 SELECT” to “AV” or “SAT”. (13)

5 To set the tape speed, press **SP/LP** (//). The current setting for the tape speed appears on the display panel or the screen for about 5 seconds. Press **SP/LP** (//) again to change the setting while tape speed is displayed.

6 Press **SAT** \odot for more than 2 seconds. The recorder turns off automatically and enter the Automatic Satellite Programme Recording mode (the **SAT** \odot indicator lights up). When signals come into the recorder from the satellite receiver, the recorder starts recording (the **SAT** \odot indicator blinks). The recorder stops recording and turns off when signals stop coming in.

NOTES:

- Be sure not to turn on the satellite receiver before the programme starts broadcasting; otherwise, the recorder starts recording when the satellite receiver is turned on.
- To disengage the Automatic Satellite Programme Recording mode, press **SAT** \odot (the **SAT** \odot indicator goes off).
- Depending on the type of satellite receiver, Automatic Satellite Programme Recording may not be compatible.
- B.E.S.T. does not work in the Automatic Satellite Programme Recording mode.
- Power Save mode does not work in the Automatic Satellite Programme Recording mode.
- Just Clock does not work in the Automatic Satellite Programme Recording mode.

Editing with another video recorder or a camcorder

You can use your recorder as the source player or the recording deck. You can use a camcorder as the source player and your recorder as the recording deck. Refer also to the other components' instruction manuals for connection and its operations.

1 Make connections

Connection with another video recorder

- 1 When using your recorder as the source player ... connect its L-1 IN/OUT connector to the recording deck.
- 2 When using your recorder as the recording deck ... connect its L-1 IN/OUT or L-2 IN/DECODER connector to the source player.

Connection with a camcorder

Connect the camcorder's AUDIO/VIDEO OUT connectors to the recorder's front panel AUDIO/VIDEO input connectors.

- When using a monaural camcorder, connect its AUDIO OUT connector to the AUDIO L input connector on your recorder.
- When the JVC camcorder is equipped with the Master Edit Control, you can control the recorder from the camcorder. Connect the mini-plug cable (not supplied with this recorder) between the PAUSE connector on the recorder and the EDIT connector on the camcorder.

2 Load cassettes

Insert the playback cassette into the source player and the cassette to be recorded on into the recording deck.

3 Select input mode on recording deck

Select the correct external input on the recording deck. On this recorder, press **AUX** and/or **PR+/-**.

Connection with another video recorder

Select "L-1" for the L-1 IN/OUT connector, or "L-2" for the L-2 IN/DECODER connector.

Connection with a camcorder

Select "F-1".

4 Select edit mode

Select the appropriate edit mode for the components if such a mode is equipped.

- On this recorder, set "PICTURE CONTROL" to "EDIT". (☞ 12)

5 Start playback

Engage the Play mode of the source player.

6 Start recording

Engage the Record mode of the recording deck.


Audio Dubbing

Audio Dubbing replaces the normal audio sound of a previously recorded tape with a new soundtrack.

1 Make connections

Connect an audio component to the AUDIO input connectors on the recorder's front panel.

- When connecting a monaural audio component, use only the recorder's AUDIO L input connector.



2 Select input mode on recording deck

Press **AUX** and/or **PR** to select "F-1".

3 Locate start point, and engage Audio Dubbing mode

Load a cassette and press **▶** on the recorder. Press **II** at the point where you want to start dubbing, then press **A.DUB**.

- The recorder enters the Audio Dubbing Pause mode. ("○" blinks, and "▷" lights on the display panel.)
- To perform Audio Dubbing with audio mixing, press **AUDIO** twice.

* *Audio Dubbing with audio mixing is not possible if you are using a monaural audio component, or if you don't have an audio mixer.*

4 Start dubbing

Engage the Play mode of the audio component, then press **▶** on the recorder. Audio Dubbing begins at this point.

- To pause dubbing, press **II**. Press **▶** to resume dubbing.

5 End Audio Dubbing

Press **■** on the remote control or **■/▲** on the recorder, then engage the Stop mode of the audio component.

NOTES:

- When monitoring the sound during Audio Dubbing, the normal soundtrack is automatically selected. If you wish to hear the mixed sound (Hi-Fi + Normal soundtracks), press **AUDIO** to select "HI FI NORM".
- Audio Dubbing stops automatically when the counter reaches "0:00:00", and the recorder enters the Play mode. Check the counter reading on the screen before dubbing.
- Audio Dubbing is also possible using the rear panel L-1 IN/OUT or L-2 IN/DECODER connector. When using these 21-pin SCART connectors, be sure to select the correct input mode ("L-1" or "L-2") in step 2.
- Audio Dubbing is not possible with cassettes whose record safety tab has been removed.
- When playing back an audio-dubbed tape, press **AUDIO** to select the soundtrack you wish to hear. (☞ 6, "Selecting Soundtrack")

System Connections

NOTE:

When you select a country in Central or Eastern Europe for country setting, you cannot use decoder with this recorder.

Connecting to a satellite receiver

Connect the decoder to the satellite receiver's connector if you have a decoder, L-1 IN/OUT connector to TV's connector, and L-2 IN/DECODER connector to the satellite receiver's connector. Then connect the satellite receiver and TV.

- Set "L-2 SELECT" to "AV". (☞ 13)
- To record a programme via the satellite receiver, set the input mode to "L-2" by pressing **AUX** and/or **PR+/-**.
- To receive a scrambled broadcast, descramble the signal with the satellite receiver.
- For details, refer to the instruction manual for the satellite receiver and decoder.

Connecting/Using a decoder

You can enjoy the variety of programming that is available through scrambled channels.

- 1 Set "L-2 SELECT" to "DECODER". (☞ 13)
- 2 Connect the recorder's L-2 IN/DECODER connector to the decoder's 21-pin SCART connector using a 21-pin SCART cable.
- 3 Perform the procedure as described in "When receiving a scrambled broadcast" (☞ 14).

Connecting/Using a stereo system

You can listen to the soundtrack through your stereo system. Connect the AUDIO OUT L and R connectors on the recorder to the AUX IN or TAPE MONITOR connectors on your stereo system's receiver or amplifier.

- When listening to sound through the connected stereo system, turn the TV's volume down completely.

Subsidiary Settings

Mode Set

You can change various mode settings.

- Turn on the recorder and the TV, and set your TV to its AV mode or video channel.



1 Access Main Menu screen, then Mode Set screen

Press **MENU**. Press Δ/∇ to place the pointer next to "MODE SET", then press **OK** or \triangleright .



2 Select mode

Press Δ/∇ to place the pointer next to the item you want to set.



3 Change setting

Press **OK** or \triangleright . The default setting is **bold** in the following table. Press **MENU** to return to normal screen.

■ B.E.S.T. — ON / OFF

When B.E.S.T. (Biconditional Equalized Signal Tracking) system is set to "ON", the recorder checks the condition of the tape in use during playback and recording, and compensates to provide the highest-possible pictures. When B.E.S.T. works, "bEst" appears blinking on the display panel. B.E.S.T. takes place whenever you play back a tape or start recording after inserting a cassette.

NOTE:

The recorder checks the tape condition for about 7 seconds, then starts recording. To make sure you record the desired scene or programme completely, perform the following steps:

- 1 Press and hold **II**, and press **●**. After about 7 seconds, the recorder re-enters Record Pause mode.
- 2 Press **▶** to start recording.

■ PICTURE CONTROL — AUTO(NORM) / EDIT / SOFT / SHARP

This function helps you to adjust the playback picture quality according to your preference.

AUTO(NORM): Normally select this. Picture quality is adjusted automatically. When "B.E.S.T." is "OFF", "NORM" will appear instead of "AUTO".

EDIT: Minimizes picture degradation during editing (recording and playback).

SOFT: Reduces image coarseness when viewing overlaid tapes containing much noise.

SHARP: Clearer, sharper-edged picture when viewing images with much flat, same-coloured surfaces such as cartoons.

NOTE:

Select "EDIT" when you are editing tapes. After you finish editing, select "AUTO".

■ AUTO TIMER — ON / OFF

● When this function is set to "ON":

The timer recording standby mode is automatically engaged when the recorder is turned off. It is temporarily canceled when the recorder is turned on. You do not have to press \odot to engage or disengage the timer recording standby mode.

● When this function is set to "OFF":

Press \odot to engage or disengage the timer recording standby mode.

■ O.S.D. — ON / OFF

When this function is set to "ON", various recorder status information (on-screen display) appears on the screen.

NOTE:

When you use the recorder as the source player for editing a tape, be sure to set this function to "OFF". Otherwise, the recorder status information will be recorded on the edited tape.

■ DIRECT REC — ON / OFF

When this function is set to "ON", you can easily start recording the programme that you are watching on your TV. Press and hold **●** and press **▶** on the remote control, or press **●** on the recorder.

NOTES:

- When you use this function, be sure to use a TV offering T-V LINK, etc. and connect a fully-wired 21-pin SCART cable between the recorder and the TV.
- When "DIRECT REC" is set to "ON", if you press any button just after pressing **●** on the recorder (or **●** and **▶** on the remote control), the recorder may not function properly.

■ AUTO SP→LP TIMER — ON / OFF

When this function is set to "ON", the recorder automatically switches to LP mode to allow complete recording if there is not enough tape to record the entire programme while timer-recording in SP mode.

For example, recording a programme of 210 minutes in length onto a 180 minute tape.

Approximately 150 minutes Approximately 60 minutes

SP mode	LP mode
---------	---------

Total 210 minutes

NOTES:

- If you have programmed the recorder to timer-record 2 or more programmes, do not use this function, but change the tape speed manually during timer programming.
- There may be some noise and sound disturbance where the tape speed switches from SP to LP mode on the tape.
- This function is not available during ITR (Instant Timer Recording), and will not work properly with any tapes longer than E-180 or with some tapes of shorter lengths.
- If you perform timer recording with both this function and VPS/PDC activated, and the programme goes beyond its originally scheduled length, sometimes the programme cannot be recorded in its entirety.

POWER SAVE — ON / OFF

When this function is set to "ON", you can reduce the power consumption while the recorder is turned off.

NOTES:

- During Power Save mode,
 - the display panel is turned off,
 - the Just Clock does not work,
 - and the picture may be distorted momentarily when you turn on/off the recorder.
- Power Save does not work in the following cases:
 - When "L-2 SELECT" is set to "DECODER" or "SAT",
 - or when the recorder is in the timer recording standby mode,
 - or in the Automatic Satellite Programme Recording mode,
 - or when the recorder's power is turned off after timer-recording or ITR (Instant Timer Recording).

L-2 SELECT — A/V / DECODER / SAT

Select the appropriate mode depending on the type of unit connected to the L-2 IN/DECODER connector of the recorder.

A/V: To use the recorder as the recording deck with the player connected to the L-2 IN/DECODER connector, or to use the satellite receiver connected to the L-2 IN/DECODER connector.
DECODER: To use a decoder connected to the L-2 IN/DECODER connector.

- When you select a country in Central or Eastern Europe for country setting, you cannot use a decoder with this recorder.
- SAT:** To view a satellite programme with the TV set while the recorder is turned off.
- When the recorder is in stop or recording mode, press **TV/VCR** to turn off the VCR indicator on the display panel. If you turn on the recorder when the satellite receiver's power is off, nothing appears on the screen. In this case, turn on the satellite receiver, or set the TV to its TV mode, or press **TV/VCR** to set the recorder to the video mode.

COLOUR SYSTEM — PAL/NTSC / MESECAM

You can play back PAL, NTSC and MESECAM tapes, or record PAL and SECAM* signals on this recorder. Select the appropriate colour system.

* SECAM signals will be recorded as MESECAM on this recorder; MESECAM is the designation for tapes with SECAM signals that have been recorded on a MESECAM-compatible PAL video cassette recorder.

PAL/NTSC: To record PAL signals, or playback a PAL or NTSC tape.
MESECAM: To record SECAM signals, or play back a MESECAM tape.

NOTES:

About NTSC Playback

- Some TVs shrink the picture vertically and place black bars at the top and bottom of the screen, or cut off the top and bottom portions of superimposed displays. This is not a malfunction.
- The picture may roll up and down. This can be corrected if your TV has the V-HOLD control function.
- The counter and tape remaining time readings will be incorrect.

- During search, still, or frame-by-frame playback, the picture will be distorted, and there may be a loss of colour.

AUTO POWER OFF — 3H / OFF

When this function is set to "3H", the recorder turns off automatically if no operation is done in 3 hours. "AUTO POWER OFF IN 3MIN" appears on the screen 3 minutes before the recorder is turned off.

Clock Set

- Turn on the recorder and the TV, and set your TV to its AV mode or video channel.

1 Access Main Menu screen, then Initial Set screen

Press **MENU**. Press $\Delta\nabla$ to place the pointer next to "INITIAL SET", then press **OK** or \triangleright .


2 Access Clock Set screen

Press $\Delta\nabla$ to place the pointer next to "CLOCK SET", then press **OK** or \triangleright .

3 Set time, date and year

Press $\Delta\nabla$ until the desired time appears, then press **OK** or \triangleright . Set the date and year in the same way.

- Holding $\Delta\nabla$ changes the time in 30-minute intervals, or changes the date in 15-day intervals.



4 Set Just Clock

Set to "ON" or "OFF" by pressing $\Delta\nabla$, then press **OK** or \triangleright .

Just Clock

The Just Clock function provides accurate time keeping through automatic adjustments at regular intervals, by reading data from a PDC signal. Normally, set "JUST CLOCK" to "ON".

NOTES:

- Just Clock may not function properly depending on the reception condition.
- When you select a country in Central or Eastern Europe for country setting, you cannot use Just Clock. Skip steps 4 – 5.

5 Set source channel position

The recorder is preset to receive clock setting and adjustment data from channel position 1. Press $\Delta\nabla$ to set the channel position to the number representing the station transmitting clock setting data, then press **OK** or \triangleright .

6 Start clock

Press **MENU**.

Tuner Set

Perform the following steps only if the tuner has not been set correctly by Auto Set Up or Preset Download, or if you have moved to a different area, or if a new station starts broadcasting in your area.

The recorder needs to memorise all necessary stations in channel positions in order to record TV programmes. Auto Channel Set automatically assigns all receivable stations in your area.

NOTE:

When you select a country in Central or Eastern Europe for country setting, Guide Program numbers are not set automatically. (☞ 8, "Guide Program Number Set")

Auto Channel Set

1 Access Main Menu screen, then Auto Channel Set screen

Press **MENU**. Press $\Delta\nabla$ to place the pointer next to "AUTO CH SET", then press **OK** or \triangleright .

2 Select your country

Press $\Delta\nabla$ to place the pointer next to your country, then press **OK** or \triangleright .


3 Select language

Press $\Delta\nabla$ to place the pointer next to the desired language.

4 Perform Auto Channel Set

Press **OK** twice. When Auto Channel Set is completed, "SCAN COMPLETED" is displayed on the screen for about 5 seconds, then the Confirmation screen appears.

- When you select a country in Central or Eastern Europe for country setting, station names (ID) are not stored automatically. Change station names manually. (☞ 15)



5 Return to normal screen

Press **MENU**.

NOTES:

- Depending on reception conditions, the stations may not be stored in order, and the station names may not be stored correctly.
- If no sound accompanies the picture or the audio sounds unnatural on some channels, select the appropriate TV system for those channels.
- To delete stations with poor reception condition, refer to "Deleting a channel" (☞ 14).

Manual Channel Set


Store channels that were not stored during Auto Set Up, Preset Download or Auto Channel Set.

ATTENTION:

Guide Program numbers are not set when channels are stored manually. Perform "Guide Program Number Set" (☞ 8).

1 Access Main Menu screen, then Confirmation screen

Press **MENU**. Press $\Delta\nabla$ to place the pointer next to "MANUAL CH SET", then press **OK** or \triangleright .




2 Select position

Press $\Delta\nabla \triangleleft \triangleright$ until an open channel position begins blinking, then press **OK**. The Manual Channel Set screen appears.

3 Select band


Press $\Delta\nabla$ to select CH (regular) or CC (cable), then press \triangleright .



4 Input channel

Press the **number keys** to input the channel number you want to store. Input "0" before any single number entries.

- To input the registered station name (ID), press \triangleright until "----" begins blinking, then press $\Delta\nabla$.
- When "L-2 SELECT" is set to "A/V" or "SAT", the "DECODER" setting cannot be changed. (☞ 13)
- When you select a country in Central or Eastern Europe for country setting, "TV SYSTEM" setting appears instead of "DECODER" setting. When you can see the picture but can hear no audio, select appropriate TV system (For Central or Eastern Europe: D/K or for Western Europe: B/G).



Press \triangleright until D/K or B/G blinking. Then press $\Delta\nabla$ to select D/K or B/G.

Major Countries	TV System
Austria, Denmark, Finland, Holland, Italy, Norway, Spain, Switzerland, Sweden, Germany, Egypt	B/G
China, Mongolia, Rumania, Bulgaria, Czech Rep., Slovakia, Hungary, Poland, Russia	D/K

5 Store new channel

Press **OK**.

- Repeat steps 2 – 5 as necessary.

6 Return to normal screen

Press **MENU**.

Deleting a channel

1 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).

2 Select position

Press $\Delta\nabla \triangleleft \triangleright$ to until the channel you want to delete begins blinking.

3 Delete channel

Press **X**. The channel directly beneath the cancelled one moves up one line.

- Repeat steps 2 – 3 as necessary.

4 Return to normal screen

Press **MENU**.

Changing station channel positions

1 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).



2 Select position

Press $\Delta\nabla \triangleleft \triangleright$ until the station you want to move begins blinking, then press **OK**. The channel number (CH) and the station name (ID) begin blinking.

3 Select new position

Press $\Delta\nabla \triangleleft \triangleright$ to move the station to the new position, then press **OK**.

Example: If you moved the station in position 4 to position 2, the stations originally in positions 2 and 3 each move down one space.



- Repeat steps 2 – 3 as necessary.

4 Return to normal screen

Press **MENU**.

When receiving a scrambled broadcast

NOTE:

When you select a country in Central or Eastern Europe for country setting, you cannot use decoder with this recorder.

1 Select decoder mode

Set "L-2 SELECT" to "DECODER". (☞ 13)

2 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).

3 Select position

Press $\Delta\nabla \triangleleft \triangleright$ to select the channel broadcasting scrambled programmes, then press **OK** twice.

4 Change decoder setting

Press \triangleright until "OFF" begins blinking, and set it to "ON" by pressing $\Delta\nabla$. Then press **OK**.

- Repeat steps 3 – 4 as necessary.

5 Return to normal screen

Press MENU.

Changing station name (A)

1 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).

2 Select position

Press $\Delta \nabla \triangleleft \triangleright$ until the desired channel begins blinking, then press **OK** twice. The Manual Channel Set screen appears.

3 Select station name

Press \triangleright until the station name (ID) begins blinking. Press $\Delta \nabla$ until the desired station name appears, then press **OK**.

- Repeat steps 2 – 3 as necessary.

4 Return to normal screen

Press MENU.

Changing station name (B)

1 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).

2 Select position

Press $\Delta \nabla \triangleleft \triangleright$ until the desired channel begins blinking, then press **OK** twice. The Manual Channel Set screen appears.

3 Select character for station name

Press \triangleright until the first letter of the station name (ID) begins blinking.

4 Enter new character

Press $\Delta \nabla$ to cycle through the characters, then press \triangleright . Enter the remaining characters the same way (maximum of 4). After entering all characters, press **OK**.

- The characters available for the station name (ID) are A–Z, 0–9, –, *, +, _ (space).
- If you make a mistake, press \triangleleft until the incorrect character begins blinking. Then enter the correct character by pressing $\Delta \nabla$.

5 Return to normal screen

Press MENU.

Fine-tuning channels

1 Access Confirmation screen

Perform step 1 of "Manual Channel Set" (☞ 14).

2 Select position

Press $\Delta \nabla \triangleleft \triangleright$ until the channel you want to tune begins blinking, then press **OK** twice. The Manual Channel Set screen appears.

3 Perform tuning

Press \triangleright until "+/-" begins blinking, then press $\Delta \nabla$ until the picture is its clearest. Then press **OK**.

- Repeat steps 2 – 3 as necessary.

4 Return to normal screen

Press MENU.

TV station and ID list

ID*	STATION NAME	ID*	STATION NAME
1000	TV1000	ODE	ODEON
3SAT	3SAT	ORF1	ORF1
9LIV	9LIVE	ORF2	ORF2
ADLT	ADULT	ORF3	ORF3
ANT3	ANTENA3	OWL3	OWL3
ARD	ARD	PREM	PREMIERE
ARTE	ARTE	PRO7	PRO7
B1	BERLIN1	RAI1	RAI1
BBC	BBC GROUP	RAI2	RAI2
BBC1	BBC1	RAI3	RAI3
BBC2	BBC2	RET4	RETE4
BR3	BAYERN3	21	TELE21
C+	CANAL PLUS	RTBF	RTBF1 / 2
C1	PORTUGUSES	RTL	RTL
CAN5	CANALE5	RTL2	RTL2
CANV	KETNET CANVAS	RTL4	RTL4
CH4	CHANNEL4	RTL5	RTL5
CH5	CHANNEL5	RTP	RTP
CHLD	CHILD	S4	SCHWEIZ4
CINE	CINEMA	SAT1	SAT1
CLUB	TELECLUB	SBS	SBS
CMT	CMT	SF1	SF1
CNN	CNN	SF2	SF2
CSUR	ANDALUCIA	SHOW	SHOW
DISC	DISCOVERY	SIC	SOCIEDADE
DR	DR TV	SKY	SKY CHANNEL
DR2	DR2	SKYN	SKY NEWS
DRS	DRS	SPRT	SPORT
DSF	DSF	SRTL	SUPER RTL
ETB1	ETB1	STAR	STAR-TV
ETB2	ETB2	SVT1	SVT1
EURO	EURONEWS	SVT2	SVT2
EUSP	EUROSPORTS	SWR	SUEDWEST3
FEMM	FEMMAN	TCC	TCC
FILM	FILM	TELE	TELE
FNET	FILMNET	TEL5	TELE5
FR2	France2	TF1	TF1
FR3	France3	TMC	TELEMONTECARLO
GALA	GALAVISION	TNT	TNT INT
HR3	HESSEN3	TRT	TRT INT
INFO	INFO-KANAL	TSI	TSI
ITA1	ITALIA1	TSR	TSR
ITA7	ITALIA7	TV1	BRTN TV1
ITV	ITV	TV2	TV2
JSTV	JSTV	TV4	TV4
KA2	KA2	TV5	TV5
KAB1	KABEL1	TV6	TV6
KAN2	KANAL2	TVE1	TVE1
LOCA	LOCAL	TVE2	TVE2
M6	M6	TVG	TV GALICIA
MB	MBR	TVI	TV INDEPENDENT
MBC	MCM	TVN	TV NORGE
MCM	MDR	VCR	VIDEO
MDR	MOVIE	VERO	VERONICA
MOVE	MTV	VH-1	VH-1
MTV	MTV3	VIVA	VIVA
MTV3	NORD3	VIV2	VIVA2
N3	N-TV	VMTV	VIDEO MUSIC
N-TV	NBC SUPER	VOX	VOX
NBC	NDR3	VT4	VT4
NDR3	NED1	VTM	VTM
NED1	NED2	WDR1	West1
NED2	NED3	WDR3	West3
NED3	NEWS	YLE1	YLE1
NEWS	NICK	YLE2	YLE2
NICK	NRK	ZDF	ZDF
NRK	NRK2	ZTV	ZTV
NRK2			

* The "ID" abbreviation is what is shown on-screen in lieu of the station name. The "ID" abbreviation is listed in the Confirmation screen and is displayed on the screen when the recorder is tuned to a different station.

Video Channel Set

Video channel (RF output channel) is the channel on which your TV receives picture and sound signals from the recorder through the RF cable.

Perform the following steps only if interference appears in the TV picture after you have moved to a different area or a new station has started broadcasting in your area, or if you change the connection from RF connection to AV connection, or vice versa.


If you have connected the recorder to your TV via the AV connection, set the video channel to off.

If you have connected the recorder to your TV via the RF connection, set the correct video channel.

- Make sure the recorder's power is off and there is no cassette inserted in the recorder.


1 Access Video Channel Set mode

Hold down **■**/**▲** on the recorder until the display panel shows the following.



2 Set RF output system

The blinking number on the display indicates the RF output system of your country. Press **△**/**▽** to set to "1" or "2", then press **OK**. (1: B/G 2: D/K)




Major Countries	TV System
Austria, Denmark, Finland, Holland, Italy, Norway, Spain, Switzerland, Sweden, Germany, Egypt	B/G
China, Mongolia, Rumania, Bulgaria, Czech Rep., Slovakia, Hungary, Poland, Russia	D/K

3 Set video channel

With AV connection

Press **PR -** until the display panel shows "1 - -" (or "2 - -").

- Now the video channel is set to off.




With RF connection

Press **PR +** or **-** to set the video channel to a vacant position between 22 and 69 which is not occupied by any local station in your area.

(Example) If channel 50 is available in your area, set the video channel to 50.

Then, set your TV to UHF channel 50.

- If the two vertical white bars appear clearly on the screen as shown on the right, go to step 4.
- If the two vertical white bars do not appear clearly, re-set the video channel to another vacant position and try again.



4 Exit Video Channel Set mode

Press **OK**.

With AV connection

To view picture signals from the recorder, set your TV to its AV mode.

With RF connection

The channel on which the two vertical white bars appear clearly is your video channel. To view picture signals from the recorder, set your TV to the video channel.

Specifications

GENERAL

Power requirement	: AC 220 V – 240 V~, 50 Hz/60 Hz
Power consumption	
Power on	: 15 W
Power off	: 4.0 W
Temperature	
Operating	: 5°C to 40°C
Storage	: -20°C to 60°C
Operating position	: Horizontal only
Dimensions (W x H x D)	: 400 mm x 94 mm x 270 mm
Weight	: 3.4 kg
Format	: VHS PAL standard
Maximum recording time	
(SP)	: 240 min. with E-240 video cassette
(LP)	: 480 min. with E-240 video cassette

VIDEO/AUDIO

Signal system	: PAL-type colour signal and CCIR monochrome signal, 625 lines 50 fields
Recording system	: DA4 (Double Azimuth) head helical scan system
Signal-to-noise ratio	: 45 dB
Horizontal resolution	: 250 lines
Frequency range	
Normal audio	: 70 Hz to 10,000 Hz
Hi-Fi audio	: 20 Hz to 20,000 Hz
Input/Output	: 21-pin SCART connectors: IN/OUT x 1, IN/DECODER x 1 RCA connectors: VIDEO IN x 1, AUDIO IN x 1, AUDIO OUT x 1

TUNER/TIMER

TV channel storage capacity	: 99 positions (+AUX position)
Tuning system	: Frequency synthesized tuner
Channel coverage	
VHF	: 47 MHz – 89 MHz/ 104 MHz – 300 MHz/ 302 MHz – 470 MHz
UHF	: 470 MHz – 862 MHz
Aerial output	: UHF channels 22 – 69 (Adjustable)
Memory backup time	: Approx. 10 min.

ACCESSORIES

Provided accessories	: RF cable, Infrared remote control unit, "R6" battery x 2
Optional accessories	: Satellite Controller RM-SD1

Specifications shown are for SP mode unless specified otherwise. E. & O.E. Design and specifications subject to change without notice.