



# JVC



## MICRO COMPONENT SYSTEM

# UX-P30

—Consists of CA-UXP30 and SP-UXP30




SP-UXP30

CA-UXP30

SP-UXP30

COMPACT  
**disc**  
DIGITAL AUDIO


## INSTRUCTIONS



# Warnings, Cautions and Others

---

## **CAUTION— (standby/on) button!**

Disconnect the mains plug to shut the power off completely.  
The  (standby/on) button in any position does not disconnect the mains line.

The power can be remote controlled.

## **CAUTION**

To reduce the risk of electrical shocks, fire, etc.:

1. Do not remove screws, covers or cabinet.
2. Do not expose this appliance to rain or moisture.

## **CAUTION**

- Do not block the ventilation openings or holes.  
(If the ventilation openings or holes are blocked by a newspaper or cloth, etc., the heat may not be able to get out.)
- Do not place any naked flame sources, such as lighted candles, on the apparatus.
- When discarding batteries, environmental problems must be considered and local rules or laws governing the disposal of these batteries must be followed strictly.
- Do not expose this apparatus to rain, moisture, dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

## IMPORTANT FOR LASER PRODUCTS

1. CLASS 1 LASER PRODUCT
2. **CAUTION:** Do not open the top cover. There are no user serviceable parts inside the unit; leave all servicing to qualified service personnel.
3. **CAUTION:** Visible and invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to beam.
4. REPRODUCTION OF LABEL: CAUTION LABEL, PLACED INSIDE THE UNIT.


<b>CAUTION:</b> Invisible laser radiation when open and interlock failed or defeated. AVOID DIRECT EXPOSURE TO BEAM. (e)	<b>ADVARSEL:</b> Usynlig laserstråling ved åbning, når sikkerhedsafbrydere er ude af funktion. Undgåudsættelse for stråling. (d)	<b>WARNING:</b> Osynlig laserstråling när denna del är öppnad och spårren är urkopplad. Betrakta ej strålen. (s)	<b>VARO:</b> Avattaessa ja suojalukitus ohitettaessa olet alltiina näkymättömälle lasersäteilylle. Älä katso säteeseen. (f)
--------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------

### CAUTION: Proper Ventilation


To avoid risk of electric shock and fire, and to prevent damage, locate the apparatus as follows:

- 1 Front:  
No obstructions and open spacing.
- 2 Sides/ Top/ Back:  
No obstructions should be placed in the areas shown by the dimensions below.
- 3 Bottom:  
Place on a level surface. Maintain an adequate air path for ventilation by placing on a stand with a height of 10 cm or more.

Front View



Side View



# Introduction

---

We would like to thank you for purchasing one of our JVC products. Before operating this unit, read this manual carefully and thoroughly to obtain the best possible performance from your unit, and retain this manual for future reference.

## About This Manual

---

This manual is organized as follows:

- **The manual mainly explains operations using the buttons on the remote control. You can use the buttons both on the remote control and on the unit for the same operations if they have the same or similar names (or marks), unless mentioned otherwise.**
- Basic and common information that is the same for many functions is grouped in one place, and is not repeated in each procedure. For instance, we do not repeat the information about turning on/off the unit, setting the volume, changing the sound effects, and others, which are explained in the section “Common Operations” on pages 9 and 10.
- The following symbols are used in this manual:



Gives you warning and caution to prevent damage or risk of fire/electric shock.

Furthermore, gives you information which is not good for obtaining the best possible performance from the unit.



Gives you information and hints you had better know.

## Precautions

---

### Installation

- Install in a place which is level, dry and neither too hot nor too cold—between 5°C and 35°C.
- Install the unit in a location with adequate ventilation to prevent internal heat buildup in the unit.
- Leave sufficient distance between the unit and the TV.
- Keep the speakers away from the TV to avoid interference with TV.



DO NOT install the unit in a location near heat sources, or in a place subject to direct sunlight, excessive dust or vibration.

### Power sources

- When unplugging the unit from the wall outlet, always pull on the plug, not the AC power cord.



DO NOT handle the AC power cord with wet hands.

### Moisture condensation

Moisture may condense on the lens inside the unit in the following cases:

- After starting heat the room
  - In a damp room
  - If the unit is brought directly from a cold to a warm place
- Should this occur, the unit may malfunction. In this case, leave the unit turned on for a few hours until the moisture evaporates, unplug the AC power cord, then plug it in again.

### Others

- Should any metallic object or liquid fall into the unit, unplug the AC power cord and consult your dealer before operating any further.
- If you are not going to operate the unit for an extended period of time, unplug the AC power cord from the wall outlet.



DO NOT disassemble the unit since there are no user serviceable parts inside.

If anything goes wrong, unplug the AC power cord and consult your dealer.

# Contents


---


<b>Location of the Buttons and Controls</b> .....	<b>3</b>	<b>Playing Back Discs (CD/CD-R/CD-RW)</b> .....	<b>13</b>
Front Panel .....	3	Playing Back the Entire Disc—Normal Play .....	13
Remote Control .....	5	Basic Disc Operations .....	14
<b>Getting Started</b> .....	<b>6</b>	Programming the Playing Order of the Tracks	
Supplied Accessories .....	6	—Program Play .....	14
Putting the Batteries into the Remote Control .....	6	Playing at Random—Random Play .....	15
Connecting Antennas .....	6	Repeating Tracks—Repeat Play .....	15
Connecting Speakers .....	7	Prohibiting Disc Ejection—Tray Lock .....	15
Connecting Other Equipment .....	8	<b>Playing Back Tapes</b> .....	<b>16</b>
<b>Common Operations</b> .....	<b>9</b>	Playing Back a Tape .....	16
Turning On the Power .....	9	<b>Recording</b> .....	<b>17</b>
Setting the Clock .....	9	Recording on a Tape .....	17
Selecting the Sources and Starting Play .....	9	Disc Direct Recording .....	18
Adjusting the Volume .....	10	One Track Recording .....	18
Reinforcing the Bass Sound .....	10	<b>Using the Timers</b> .....	<b>19</b>
Selecting the Sound Modes .....	10	Using Daily Timer and Recording Timer .....	19
<b>Listening to FM and AM Broadcasts</b> .....	<b>11</b>	Using Sleep Timer .....	20
Tuning in a Station .....	11	<b>Maintenance</b> .....	<b>21</b>
Presetting Stations .....	11	<b>Troubleshooting</b> .....	<b>22</b>
Tuning in a Preset Station .....	12	<b>Specifications</b> .....	<b>22</b>

# Location of the Buttons and Controls

Become familiar with the buttons and controls on your unit.

## Front Panel





See pages in the parentheses for details.


### Front Panel

- 1 Disc tray
- 2 Display window
- 3 STANDBY lamp (9)
- 4  $\Phi/I$  (standby/on) button (9, 15, 20)
- 5 Remote sensor
- 6 CLOCK button (9)
- 7 TIMER button (19, 20)
- 8 Cassette holder
- 9 PHONES jack (10)
- 10  $\blacktriangle$  (disc tray open/close) button (13)
- 11 SOUND button (10)
- 12 AHB (Active Hyper Bass) PRO button (10)
- 13 Source buttons  
CD  $\blacktriangleright/\parallel$  (play/pause), TAPE  $\blacktriangleleft/\blacktriangleright$  (play), FM/AM,  
and AUX  
*Pressing one of these buttons also turns on the unit.*
- 14 VOLUME + / - control (10)
- 15 Multi operation buttons  
 $\blacktriangleleft\blacktriangleleft$  (reverse search),  $\blacksquare$  (stop), and  $\blacktriangleright\blacktriangleright$  (forward search)
- 16  $\triangle$  (cassette holder open) portion (16 – 18)
- 17 REV.MODE (reverse mode) button (16 – 18)
- 18 REC (recording) button (17, 18)

### Display Window


- 1 Tape operation indicators
  - $\blacktriangleleft/\blacktriangleright$  (tape direction) and  $\blacktriangleleft\blacktriangleright$  (reverse mode)
- 2 Timer indicators
  - $\odot$  (timer), DAILY (Daily Timer), REC (Recording Timer), and SLEEP (Sleep Timer)
- 3 REC indicator
- 4 CLOCK indicator
- 5 Disc play mode indicators
  - PRGM (program), RANDOM, and repeat ( $\blacktriangleleft/\blacktriangleright$  ALL)
- 6 BASS (Active Hyper Bass Pro) indicator
- 7 SOUND (sound mode) indicator
- 8 Tuner operation indicators
  - MONO and ST (stereo)
- 9 Main display
  - Shows the source name, frequency, etc.

# Remote Control



See pages in the parentheses for details.

- 1 REPEAT button (15)
- 2 DISPLAY button (9)
- 3 PROG (program) button (14)
- 4 RANDOM button (15)
- 5 SOUND MODE button (10)
- 6 AUTO PRESET button (11)
- 7 CD ▲ (disc tray open/close) button (13)  
*Pressing this button also turns on the unit.*
- 8 CD ►/|| (play/pause) button (9, 13, 14)  
*Pressing this button also turns on the unit.*
- 9 ◀◀ (reverse search) button (11, 14 – 16)
- 10 ■ (stop) button (13 – 18)
- 11 CANCEL button (14)
- 12 AHB (Active Hyper Bass) PRO button (10)
- 13 STANDBY/ON ⏻/⏻ button (9)
- 14 SLEEP button (20)
- 15 AUX button (9)  
*Pressing this button also turns on the unit.*
- 16 FM/AM button (9, 11, 12)  
*Pressing this button also turns on the unit.*
- 17 TAPE ◀▶ (play) button (9, 16)  
*Pressing this button also turns on the unit.*
- 18 FM MODE button (11)
- 19 ▶▶ (forward search) button (11, 14 – 16)
- 20 SET button (12, 14)
- 21 MULTI KEY > / < buttons (12, 14, 15)
- 22 VOLUME + / - buttons (10)





## Supplied Accessories


Make sure that you have all the following items. The number in the parentheses indicates the quantity of each piece supplied.

- AM loop antenna (1)
- FM antenna (1)
- Remote control (1)
- Batteries (2)

If anything is missing, consult your dealer immediately.

## Putting the Batteries into the Remote Control


Insert the batteries—R6(SUM-3)/AA(15F)—into the remote control, by matching the polarity (+ and –) on the batteries with the + and – markings on the battery compartment. When the remote control can no longer operate the unit, replace both batteries at the same time.



- DO NOT use an old battery together with a new one.
- DO NOT use different types of batteries together.
- DO NOT expose batteries to heat or flame.
- DO NOT leave the batteries in the battery compartment when you are not going to use the remote control for an extended period of time. Otherwise, it will be damaged from battery leakage.

## Connecting Antennas

### FM antenna



- 1 Attach the FM antenna to the FM 75 Ω COAXIAL terminal.
- 2 Extend the FM antenna.
- 3 Fasten it up in the position which gives you the best reception, then fix it on the wall, etc.




#### About the supplied FM antenna

The FM antenna supplied with this unit can be used as temporary measure. If reception is poor, you can connect an outdoor FM antenna.


#### To connect an outdoor FM antenna

Before connecting it, disconnect the supplied FM antenna.



A 75 Ω antenna with coaxial type connector (IEC or DIN 45325) should be used.

## AM antenna



- 1 **Connect the AM loop antenna to the AM LOOP terminals as illustrated.**
- 2 **Turn the AM loop antenna until you have the best reception.**

### To connect an outdoor AM antenna


When reception is poor, connect a single vinyl-covered wire to the AM EXT terminal and extend it horizontally. The AM loop antenna must remain connected.



#### For better reception of both FM and AM

- Make sure the antenna conductors do not touch any other terminals and connecting cords.
- Keep the antennas away from metallic parts of the unit, connecting cords, and the AC power cord.


## Connecting Speakers



- 1 **Press and hold the clamp of the speaker terminal on the rear of the unit.**
- 2 **Insert the end of the speaker cord into the terminal.**

Match the polarity of the speaker terminals: Red ⊕ to red ⊕ and black ⊖ to black ⊖.

- If the cords are covered with insulation, remove a short section of insulation at the end of each cord by twisting and pulling it off.



- 3 **Release the finger from the clamp.**



- DO NOT connect speakers while the power is on.
- DO NOT connect more than one speaker to each speaker terminal.

**IMPORTANT:** Use only speakers with the same speaker impedance as indicated by the speaker terminals on the rear of the unit.

---

## Connecting Other Equipment


You can connect audio equipment—used only as a playback device.



- DO NOT connect any equipment while the power is on.
- DO NOT plug in any equipment until all connections are complete.

### To connect audio equipment

Be sure that the plugs of the audio cords are colored: White plugs and jacks are for left audio signals, and red ones for right audio signals.



**For playing the other equipment** through this unit, connect between the audio output jacks on the other equipment and AUX jacks by using audio cords (not supplied).

### Now, you can plug the AC power cord.

**IMPORTANT:** Be sure to check all connections to be done before plugging the AC power cord into a wall outlet.


# Common Operations

## Turning On the Power

When you press the play button—CD ►/II, TAPE ◀▶ or the source selecting button—FM/AM and AUX, the unit automatically turns on and starts playback if the source is ready.

**To turn on the unit,** press STANDBY/ON ◯/I (or ◯/I on the unit).

The STANDBY lamp on the unit goes out.



**To turn off the unit (on standby),** press STANDBY/ON ◯/I (or ◯/I on the unit) again.

The STANDBY lamp lights up.

- The CLOCK indicator flashes on the display until you set the built-in clock. After setting the clock, the clock time will appear on the display while the power is off.
- A little power is always consumed even while the unit is on standby.

**To switch off the power supply completely,** unplug the AC power cord from the AC outlet.



**When you unplug the AC power cord or if a power failure occurs**

The clock is reset to “0:00” right away, while the tuner preset stations (see page 11) will be erased in a few days.

## Setting the Clock

Before operating the unit any further, first set the clock built in this unit. When you plug the AC power cord into the wall outlet, the CLOCK indicator starts flashing on the display. You can set the clock when the unit is either turned on or in standby mode.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

**On the unit ONLY:**

- 1 Press CLOCK for more than 2 seconds.**

The hour digits start flashing on the display.





- 2 Press ►► or ◀◀ to adjust the hour, then press CLOCK.**

The minute digits start flashing on the display.



- 3 Press ►► or ◀◀ to adjust the minute, then press CLOCK.**

The CLOCK indicator remains lit on the display.



### To check the clock time

Press DISPLAY (or CLOCK on the unit) while playing any source.

- Each time you press the button, the source indication and the clock time alternate on the display.



- When you unplug the AC power cord or if a power failure occurs, the clock loses the setting and is reset to “0:00.” You need to set the clock again.
- The clock may gain or lose 1 to 2 minutes per month.


## Selecting the Sources and Starting Play

**To play back CDs,** press CD ►/II. (See pages 13 – 15.)

**To play back tapes,** press TAPE ◀▶. (See page 16.)

**To listen to the FM/AM broadcasts,** press FM/AM. (See pages 11 – 12.)


**To select the external equipment as the source,** press AUX.




## Adjusting the Volume

You can adjust the volume level only while the unit is turned on. The volume level can be adjusted between “VOLUME 0” and “VOLUME 40.”

When using the remote control, press VOLUME + to increase the volume or press VOLUME – to decrease it.



When using the unit, turn VOLUME + / – clockwise (+) to increase the volume or counterclockwise (–) to decrease it.



VOLUME 15



### For private listening

Connect a pair of headphones to the PHONES jack. No sound comes out of the speakers. Be sure to turn down the volume before connecting or putting on headphones.



DO NOT turn off (on standby) the unit with the volume set to an extremely high level; otherwise, a sudden blast of sound can damage your hearing, speakers and/or headphones when you turn on the unit or start playing any source next time. REMEMBER you cannot adjust the volume level while the unit is on standby.


## Reinforcing the Bass Sound

You can reinforce the bass sound to maintain rich (“AHB 1” and “AHB 2”), full bass at low volume. This function only affects the playback sound, but does not affect your recording.

To get the effect, press AHB (Active Hyper Bass) PRO until “AHB 1” or “AHB 2” appears on the display. The BASS indicator also lights up on the display.



Each time you press the button, the bass sound change as follows:



“AHB 2” has much more bass reinforcement effect than “AHB 1.”

To cancel the effect, press AHB PRO until “AHB OFF” appears on the display. The BASS indicator goes off.


## Selecting the Sound Modes

You can select one of the 4 preset sound modes. This function only affects the playback sound, but does not affect your recording.

To select the sound modes, press SOUND MODE (or SOUND on the unit) until the sound mode you want appears on the display. The SOUND indicator also lights up on the display.



Each time you press the button, the sound modes change as follows:



**ROCK:** Gives a heavy sound. Boosts low and high frequency.

**POP:** Good for vocal music.

**CLASSIC:** Good for classical music.

**JAZZ:** Gives a feeling of live atmosphere. Good for acoustic music.

**FLAT:** The sound mode is canceled. The SOUND indicator goes off.

# Listening to FM and AM Broadcasts

## Tuning in a Station

### 1 Press FM/AM.

The unit automatically turns on and tunes in the previously tuned station—either FM or AM.


- Each time you press the button, the band alternates between FM and AM.



### 2 Press and hold ►► or ◄◄ for more than 1 second.

The unit starts searching for stations and stops when a station of sufficient signal strength is tuned in.

If a program is broadcasted in stereo, the ST (stereo) indicator lights up.




To stop searching, press ►► or ◄◄.



**When you press ►► or ◄◄ briefly and repeatedly**  
The frequency changes step by step.

### To change the FM reception mode

When an FM stereo broadcast is hard to receive or noisy, press FM MODE on the remote control so that the MONO indicator lights up on the display. Reception improves.



To restore the stereo effect, press FM MODE again so that the MONO indicator goes off. In this stereo mode, you can hear stereo sounds when a program is broadcasted.

## Presetting Stations

You can preset 30 FM and 15 AM stations—using either automatic presetting or manual presetting.

In some cases, test frequencies have been already memorized for the tuner since the factory examined the tuner preset function before shipment. This is not a malfunction. You can preset the stations you want into memory by following the presetting method.

### To preset stations automatically—Automatic Presetting

You need to preset stations separately for the FM and AM bands.

#### On the remote control ONLY:

### 1 Press FM/AM to select the band.

The unit automatically turns on and tunes in the previously tuned station—either FM or AM.

- Each time you press the button, the band alternates between FM and AM.



### 2 Press and hold AUTO PRESET for more than 2 seconds.

Local stations with strong signals are searched and stored in memory automatically.

When automatic presetting is over, the station stored in preset number 1 is received.



### 3 Repeat steps 1 and 2 to store stations for the other band.



**When you cannot automatically store stations you want**  
Stations with weak signals cannot be detected with this automatic presetting. To store such a station, use the manual presetting.

## To preset stations manually—Manual Presetting


- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 2 again.

### On the remote control ONLY:


#### 1 Tune in the station you want to preset.

- See “Tuning in a Station” on page 11.

#### 2 Press SET.




#### 3 Press MULTI KEY > or MULTI KEY < to select a preset number.



#### 4 Press SET again.

**STORE 1**



The tuned station in step 1 is stored in the preset number selected in step 3.

- Storing a new station on a used number erases the previously stored one.



**When you unplug the AC power cord or if a power failure occurs**

The preset stations will be erased in a few days. If this happens, preset the stations again.

## Tuning in a Preset Station

### On the remote control ONLY:


#### 1 Press FM/AM.

The unit automatically turns on and tunes in the previously tuned station—either FM or AM.

- Each time you press the button, the band alternates between FM and AM.




#### 2 Press MULTI KEY > or MULTI KEY < to select a preset number.



# Playing Back Discs (CD/CD-R/CD-RW)

This unit has been designed to playback the following discs—CD, CD-R, and CD-RW.

Continued use of irregular shape discs (heart-shape, octagonal, etc.) can damage the unit.



## General Notes

In general, you will have the best performance by keeping your discs and the mechanism clean.

- Store discs in their cases, and keep them in cabinets or on shelves.
- Keep the unit's disc tray closed when not in use.

## When playing a CD-R or CD-RW


User-edited CD-Rs (CD-Recordable) and CD-RWs (CD-ReWritable) can be played back only if they are already "finalized".

- Usually you can play back your original CD-Rs or CD-RWs recorded in music CD format. However, sometimes they may not play depending on their characteristics or recording conditions.
- Before playing back CD-Rs or CD-RWs, read their instructions or cautions carefully.
- Some CD-Rs or CD-RWs may not be played back on this unit because of their disc characteristics, damage or stain on them, or if the player's lens is dirty.
- CD-RWs may require a longer readout time. This is caused by the fact that the reflectance of CD-RWs is lower than for regular CDs.


## Playing Back the Entire Disc—Normal Play

### 1 Press CD ▲ (or ▲ on the unit).

The unit automatically turns on and the disc tray comes out.



### 2 Place a disc correctly on the circle of the disc tray, with its label side up.



- When using a CD single (8 cm), place it on the inner circle of the disc tray.

### 3 Press CD ►/||.

The disc tray automatically closes and the first track of the CD starts playing.




Track number      Elapsed playing time

- The CD automatically stops when the last track of the CD has finished playing.

To stop playing, press ■.




Total track number      Total playing time



To remove the disc, press CD ▲ (or ▲ on the unit).



- **If the disc cannot be read correctly (because it is scratched, for example)**  
"00 0000" appears on the display.
- **If no disc is inserted**  
"NO DISC" appears on the display.
- **If a unreadable CD-R or CD-RW is inserted**  
"BLANK CD" appears on the display.

 DO NOT try to open or close the disc tray by hand as it will be damaged.



## Basic Disc Operations

While playing a disc, you can do the following operations.

### To stop play for a moment

Press CD ►/||.

While pausing, the elapsed playing time flashes on the display.




To resume playing, press CD ►/|| again.

### To go to another track

Press MULTI KEY > / MULTI KEY < or ►►/◄◄ repeatedly before or during playback.


- MULTI KEY > or ►►: Skips to the beginning of the next or succeeding tracks.
- MULTI KEY < or ◄◄: Goes back to the beginning of the current or previous tracks.



### To locate a particular point in a track

During play, press and hold ►►| or |◄◄.

- ►►|: Fast-forwards the tracks.
- |◄◄: Fast-reverses the tracks.



## Programming the Playing Order of the Tracks —Program Play

You can arrange the order in which tracks play before you start playing. You can program up to 20 tracks.



### On the remote control ONLY:

#### 1 Load a disc.

- If the current playing source is not the CD player, press CD ►/||, then ■ before going to the next step.


#### 2 Press PROG (program).

The PRGM (program) indicator lights up on the display.



- If a program has been stored in memory, the program is called up.

#### 3 Press MULTI KEY > or MULTI KEY < to select the track number, then press SET.




#### 4 Repeat step 3 to program other tracks you want.

#### 5 Press CD ►/||.

The tracks are played in the order you have programmed.



To stop playing, press ■.



To exit from Program play mode, press ■ before or after playing. The PRGM (program) indicator goes off. All the programmed tracks will be cleared.

- Disc ejection also erases the program.

### To check the program contents

You can check the program contents by pressing PROG (program) on the remote control. The programmed tracks are shown in the programmed order.



### To modify the program

Before or after playing, you can erase the last programmed track by pressing CANCEL on the remote control.



- Each time you press the button, the last programmed track is erased from the program.

To add tracks in the program before playing, simply select the track numbers you want to add by following step 3 of the programming procedure.



- If you try to program the 21st track "FULL" will appear on the display.
- If the total playing time is 100 minutes or more The total playing time will not be shown. "--:--" will appear on the display.

## Playing at Random—Random Play

The tracks will play in no particular order when you use this mode.

### On the remote control ONLY:


**To use Random play mode,** press RANDOM before or during playing. The RANDOM indicator lights up on the display.



The tracks are played at random. Random play ends when all the tracks are played once.

**To skip the current track,** press ►| or MULTI KEY >. You cannot go back to the previous track by pressing ◀◀ or MULTI KEY <.

**To stop playing,** press ■. Random play mode is also canceled.




**To exit from Random play mode,** press RANDOM again before or during playing. Random play mode is canceled and Normal play resumes.

## Repeating Tracks—Repeat Play

You can have all the tracks, the program or individual track currently playing to repeat as many times as you like.


### On the remote control ONLY:

**To repeat playing,** press REPEAT before or during playing. Each time you press the button, Repeat play mode changes as follows, and the following indicator lights up on the display:



- ◀: Repeats one track.
- ◀ALL: In Normal play mode, repeat all the tracks.  
In Program play mode, repeat all the tracks in the program.  
In Random play mode, repeats all the tracks in random order.

**To stop playing,** press ■.



**To cancel Repeat play,** press REPEAT repeatedly until the repeat indicator goes off from the display.

- In Random play ◀ cannot be selected. If ◀ is selected when you press RANDOM, it is canceled (goes off).
- Repeat mode remains in effect even when you change the play mode.

## Prohibiting Disc Ejection—Tray Lock

You can lock the disc tray and prohibit to eject the disc.

- This is possible only while the unit is turned on.

### On the unit ONLY:

**To prohibit disc ejection,** press ⏻/I (standby/on) while holding ■. (If the disc tray is opened, close it first.) “LOCKED” appears for a while, and the disc tray is locked.

LOCKED


**To cancel the prohibition and unlock the disc,** press ⏻/I (standby/on) while holding ■. “UNLOCKED” appears for a while, and the disc tray is unlocked.

UNLOCKED



**If you try to eject the disc**

“LOCKED” appears to inform you that the disc tray is locked.




# Playing Back Tapes


You can play back type I tapes.

## Playing Back a Tape


**1** Press  on the unit.





**2** Put a cassette in with the exposed part of the tape down.







**3** Close the cassette holder gently.



**4** Press TAPE .


The unit automatically turns on and the tape play starts. The tape direction indicator ( or ) flashes slowly on the display.



- Each time you press the button, the tape direction changes.
  -  : plays the front side.
  -  : plays the reverse side.



When the tape plays to the end, the deck automatically stops if the reverse mode is set to  or . (See “To play both sides—Reverse Mode.”)




To stop playing, press .




To fast-wind to the left or to the right, press  or  while the tape is not running.

The tape direction indicator ( or ) starts flashing quickly on the display.



To remove the cassette, press  on the unit.



### To play both sides—Reverse Mode


You can set the deck to play just one side of a tape, both sides once, or both sides continuously.






#### On the unit ONLY:

##### Press REV.MODE.

- Each time you press the button, reverse mode changes as follows:

REV.MODE



- : The deck automatically stops after playing both sides of the tape. (Stops when playback in the  direction is finished.)
- : The deck continues to play both sides of the tape until  is pressed.
- : The deck automatically stops after playing one side of the tape.



The use of the C-120 or longer tape is not recommended, since characteristic deterioration may occur and this tape easily jams in the pinch rollers and the capstans.

# Recording

## IMPORTANT:


- It may be unlawful to record or play back copyrighted material without the consent of the copyright owner.
- The recording level is automatically set correctly, so it is not affected by the VOLUME, AHB (Active Hyper Bass) PRO, and SOUND MODE settings. Thus, during recording you can adjust the sound you are actually listening to without affecting the recording level.
- If recordings you have made have excessive noise or static, the unit may be too close to a TV. Increase the distance between the TV and the unit.
- You can use type I tapes for recording.

## To protect your recording

Cassettes have two small tabs on the back to protect from unexpected erasure or re-recording.

To protect your recording, remove these tabs.

To re-record on a protected tape, cover the holes with adhesive tape.




## To keep the best recording and playback sound quality

If the heads, capstans, and pinch rollers of the cassette decks become dirty, the following will occur:

- Impaired sound quality
- Discontinuous sound
- Fading
- Incomplete erasure
- Difficulty in recording

## To clean the heads, capstans, and pinch rollers

Use a cotton swab moistened with alcohol.



## To demagnetize the heads

Turn off the unit, and use a head demagnetizer (available at electronics and audio shops).




### At the start and end of cassette tapes

There is leader tape which cannot be recorded onto. Thus, when recording CDs or radio broadcasts, wind the leader tape first to ensure that the recording will be made without any music part lost.

## Recording on a Tape

### On the unit ONLY:

- 1 Put a recordable cassette in with the exposed part of the tape down.



- 2 Close the cassette holder gently.

- If you want to record on both sides of a tape, see “To record on both sides—Reverse Mode.”

- 3 Check the recording direction for the tape.

- If the tape direction is not correct, press TAPE ◀▶ twice then ■ to change the tape direction.

- 4 Start playing the source—FM, AM or auxiliary equipment connected to AUX jacks.


- When the source is the CD player, see “Disc Direct Recording” on page 18.

- 5 Press REC.


The REC indicator lights up on the display and recording starts.



To stop recording, press ■.



To remove the cassette, press △ on the unit.



## To record on both sides—Reverse Mode

Press REV.MODE on the unit until the ↔ indicator is lit.




- When using the reverse mode for recording, start recording in the forward (▶) direction first. Otherwise, recording will stop when recording is done only on one side (reverse) of the tape.

## Disc Direct Recording

Everything on the disc goes onto the tape in the same order as it is on the disc, or according to the order you have made for Program play.

### On the unit ONLY:

- 1 Put a recordable cassette in with the exposed part of the tape down.



- 2 Place a disc correctly on the circle of the disc tray, with its label side up.


- If the current playing source is not the CD player, press CD ►/||, then ■ before going to the next step.
- If you want to record on both sides of a tape, see “To record on both sides—Reverse Mode.”
- If you do not want pauses of about 4 seconds recorded between selections, press CD ►/|| twice. If nothing is done, non-recorded pause will be automatically recorded between selections.

- 3 Press REC.


The REC indicator lights up on the display and recording starts. After recording, the CD player and cassette deck automatically stop.



To stop recording, press ■. The tape stops after 4 seconds.



To remove the cassette, press △ on the unit.



### To record on both sides—Reverse Mode

Press REV.MODE on the unit until the ◀▶ indicator is lit.

- When using the reverse mode for Disc Direct Recording, start recording in the forward (▶) direction first. When the tape reaches its end while recording a song in the forward direction (▶), the last song will be re-recorded at the beginning of the reverse side (◀). If you start recording on the reverse side (◀), recording will stop when recording is done only on one side (reverse) of the tape.




## One Track Recording

This recording method is convenient when you record tracks while playing a disc. You can only record your favorite songs on the tape.

### On the unit ONLY:

- 1 Put a recordable cassette in with the exposed part of the tape down.



- 2 Play the track on the disc you wish to record.

- 3 Press REC.

The CD player returns to the beginning of that track and the track is recorded on the tape. After recording, the CD player and cassette deck automatically stop.



- 4 Repeat steps 2 and 3 to record other tracks you want.



### When making SLEEP timer settings while doing Disc Direct recording

Set enough time to allow for the disc to finish playing; otherwise the power will go off before recording is completed.

# Using the Timers

There are three timers available—Daily Timer, Recording Timer, and Sleep Timer.

Before using the timers, you need to set the clock built in the unit (see page 9). When you press **TIMER** on the unit for more than 3 seconds, the display alternates between “ADJUST” and “CLOCK” for about 5 seconds.

## Using Daily Timer and Recording Timer

You can set the timer whether the unit is on or off.

When the on-time comes, the unit automatically turns on (the ☺ indicator flashes just before the on-time, and continues flashing while the timer is operating). Then, when the off-time comes, the unit automatically turns off (on standby). The timer setting remains in memory until you change it.

- When the **DAILY** indicator is lit on the display, the timer acts as the Daily Timer. Once the Daily Timer has been set, it will be activated at the same time everyday until the timer is turned off.
- When the **REC** indicator is lit on the display, the timer acts as the Recording Timer. After the Recording Timer has been performed, the details of the setting remain stored but the timer is turned off.

### Before you start...

When using “TUNER” as the source to play, make sure to select the desired station before turning off the power.

- There is a time limit in doing the following steps. If the setting is canceled before you finish, start from step 1 again.

### On the unit ONLY:

#### 1 Press and hold **TIMER** for more than 3 seconds.

The timer (☺) indicator lights up, and the timer mode indicator (**DAILY** or **REC**) and the current on-time flash on the display.

The unit enters on-time setting mode.



#### 2 Set the on-time you want the unit to turn on at.

- 1) Press **▶▶** or **◀◀** to set the hour, then press **TIMER**.
- 2) Press **▶▶** or **◀◀** to set the minute, then press **TIMER**.

The unit enters off-time setting mode.




#### 3 Set the off-time you want the unit to turn off (on standby) at.

- 1) Press **▶▶** or **◀◀** to set the hour, then press **TIMER**.
- 2) Press **▶▶** or **◀◀** to set the minute, then press **TIMER**.

The unit enters source selecting mode.

#### 4 Press **▶▶** or **◀◀** to select the timer mode (Daily Timer or Recording Timer) and the source to play, then press **TIMER**.

- Each time you press **▶▶** or **◀◀**, the timer mode and the source change as follows:



**DAILY TUNER:** tunes into the last station you were listening to. (Daily Timer)

**REC TUNER:** records the last station you were listening to. (Recording Timer)

- Put a recordable cassette into the deck.

**DAILY CD:** plays a CD. (Daily Timer)


**DAILY TAPE:** plays a tape. (Daily Timer)

- Make sure that the tape direction is correct.

#### 5 Press **▶▶** or **◀◀** to set the volume level.

- You can select the volume level (“VOLUME 0” to “VOLUME 40” and “VOLUME -”). If you select “VOLUME -,” the volume is set to the last level when the unit has been turned off.

**To turn off the volume while the Recording Timer (REC TUNER) is working, set the volume level “VOLUME 0.”**



**6** Press **TIMER** to complete the timer setting.



**7** Press **⏻/⏻** (standby/on) to turn off the unit (on standby) if you have set the timer with the unit turned on.



- When the timer turns on the unit, the timer (⏻) indicator and the selected timer mode indicator (DAILY or REC) start flashing.

**To cancel the setting**, press and hold **TIMER** until the timer (⏻) indicator goes off from the display.



- **If the unit is turned on when the timer-on time comes**  
Timer does not work.
- **When you unplug the AC power cord or if a power failure occurs**  
The timer will be canceled. You need to set the clock first, then the timer again.

## Using Sleep Timer

With Sleep Timer, you can fall asleep to music. You can set Sleep Timer when the unit is turned on.

### How Sleep Timer actually works

The unit automatically turns off after the specified time length passes.


### On the remote control ONLY:

#### **1** Press **SLEEP**.

The time length until the shut-off time appears and the **SLEEP** indicator lights up on the display.



- Each time you press the button, the time length changes as follows:



#### **2** Wait for about 5 seconds after specifying the time length.

**To check the remaining time until the shut-off time**, press **SLEEP** once so that the remaining time until the shut-off time appears for about 5 seconds.

**To change the shut-off time**, press **SLEEP** repeatedly until the desired time length appears on the display.

**To cancel the setting**, press **SLEEP** repeatedly until the **SLEEP** indicator goes off.

- Sleep Timer is also canceled when you turn off the unit.



- **If you set the Sleep Timer after Daily Timer starts playing the selected source**  
Daily Timer is canceled.
- **If you set the Sleep Timer after Recording Timer starts recording**  
Recording Timer is canceled, but recording continues until Sleep Timer shuts off the power.


# Maintenance

To get the best performance of the unit, keep your discs, tapes, and mechanism clean.

## Handling discs



- Remove the disc from its case by holding it at the edge while pressing the center hole lightly.
- Do not touch the shiny surface of the disc, or bend the disc.
- Put the disc back in its case after use to prevent warping.



- Be careful not to scratch the surface of the disc when placing it back in its case.
- Avoid exposure to direct sunlight, temperature extremes, and moisture.



### To clean the disc

Wipe the disc with a soft cloth in a straight line from center to edge.



DO NOT use any solvent—such as conventional record cleaner, spray, thinner, or benzine—to clean the disc.

## Cleaning the unit


### • Stains on the unit

Should be wiped off with a soft cloth. If the unit is heavily stained, wipe it with a cloth soaked in water-diluted neutral detergent and wrung well, then wipe clean with a dry cloth.

### • Since the unit may deteriorate in quality, become damaged or get its paint peeled off, be careful about the followings:

- DO NOT wipe it with a hard cloth.
- DO NOT wipe it strong.
- DO NOT wipe it with thinner or benzine.
- DO NOT apply any volatile substance such as insecticides to it.
- DO NOT allow any rubber or plastic to remain in contact with it for a long time.

## Handling cassette tapes



- If the tape is loose in its cassette, take up the slack by inserting a pencil in one of the reels and rotating.
- If the tape is loose, it may get stretched, cut, or caught in the cassette.



- Be careful not to touch the tape surface.



- Avoid the following places to store the tape:
  - In dusty places
  - In direct sunlight or heat
  - In moist areas
  - On a TV or speaker
  - Near a magnet



# Troubleshooting

If you are having a problem with your unit, check this list for a possible solution before calling for service. If you cannot solve the problem from the hints given here, or the unit has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom	Cause	Action
No sound is heard.	<ul style="list-style-type: none"> <li>• Connections are incorrect or loose.</li> <li>• Headphones are connected.</li> </ul>	<ul style="list-style-type: none"> <li>• Check all connections and make corrections. (See pages 6 to 8.)</li> <li>• Disconnect the headphones.</li> </ul>
Hard to listen to broadcasts because of noise.	<ul style="list-style-type: none"> <li>• Antennas are disconnected.</li> <li>• The AM loop antenna is too close to the unit.</li> <li>• The FM antenna is not properly extended and positioned.</li> </ul>	<ul style="list-style-type: none"> <li>• Reconnect the antennas correctly and securely.</li> <li>• Change the position and direction of the AM loop antenna.</li> <li>• Extend the FM antenna at the best position.</li> </ul>
The disc tray does not open or close.	The AC power cord is not plugged in.	Plug the AC power cord.
The disc does not play.	The disc is placed upside down.	Place the disc with the label side up.
The disc sound is discontinuous.	The disc is scratched or dirty.	Clean or replace the disc. (See page 21.)
The cassette holder cannot be opened.	Power supply from the AC power cord has been cut off while the tape was running.	Turn on the unit.
Impossible to record.	Small tabs on the back of the cassette are removed.	Cover the holes with adhesive tape.
Operations are disabled.	The built-in microprocessor may malfunction due to external electrical interference.	Unplug the AC power cord and then plug it back in.
Unable to operate the unit from the remote control.	<ul style="list-style-type: none"> <li>• The path between the remote control and the remote sensor on the unit is blocked.</li> <li>• The batteries are exhausted.</li> </ul>	<ul style="list-style-type: none"> <li>• Remove the obstruction.</li> <li>• Replace the batteries.</li> </ul>

# Specifications

*Design and specifications are subject to change without notice.*

## Amplifier

Output Power:  
 44 W (22 W + 22 W) at 4 Ω (MAX.)  
 40 W (20 W + 20 W) at 4 Ω (10 % THD)  
 Audio input sensitivity/Impedance (at 1 kHz)  
 AUX: 400 mV/48 kΩ  
 Speakers/Impedance: 4 Ω – 16 Ω

## Tuner

FM tuning range: 87.50 MHz – 108.00 MHz  
 AM tuning range: 522 kHz – 1 629 kHz

## CD player

Dynamic range: 85 dB  
 Signal-to-noise ratio: 90 dB  
 Wow and flutter: Immeasurable

## Cassette deck

Frequency response  
 Normal (type I): 50 Hz – 14 000 Hz  
 Wow and flutter: 0.15 % (WRMS)

## Speaker

Speaker units  
 Woofer: 8 cm cone x 1  
 Tweeter: 2 cm cone x 1  
 Impedance: 4 Ω  
 Dimensions (approx.):  
 160 mm x 256 mm x 197 mm (W/H/D)  
 Mass (approx.): 2.1 kg each

## Supplied Accessories

See page 6.

## General

Power requirement: AC 240 V  $\sim$ , 50 Hz  
 Power consumption: 50 W (at operation)  
 4.2 W (on standby)  
 Dimensions (approx.):  
 505 mm x 256 mm x 294 mm (W/H/D)  
 Mass (approx.): 8.5 kg

