

# JVC




## COMPACT VHS CAMCORDER

# GR-AX670

ENGLISH



### *The Logical Choice*



*The only compact video cassettes that can be used with your VHS VCR\**

\*with Cassette Adapter

### *Compact VHS*



## INSTRUCTIONS

LYT0002-041B

# EN

**Dear Customer,**

Thank you for purchasing the JVC Compact VHS camcorder. Before use, please read the safety information and precautions contained in the following pages to ensure safe use of your new camcorder.

**Using This Instruction Manual**

- All major sections and subsections are listed in the Table Of Contents (☞ pg. 3).
- Notes appear after most subsections. Be sure to read these as well.
- Basic and advanced features/operation are separated for easier reference.

**It is recommended that you . . .**

- ..... refer to the Index (☞ pgs. 42 – 44) and familiarize yourself with button locations, etc. before use.
- ..... read thoroughly the Safety Precautions that follow and cautions (☞ pgs. 45, 46). They contain extremely important information regarding the safe use of your new camcorder.

# SAFETY PRECAUTIONS

**WARNING:**  
**TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.**

**CAUTIONS:**

- To prevent shock, do not open the cabinet. No user serviceable parts inside. Refer servicing to qualified personnel.
- When you are not using the AC Power Adapter/Battery charger for a long period of time, it is recommended that you disconnect the power cord from AC outlet.




- Camcorder is designed exclusively for the VHS-C video cassette. Only cassettes marked VHS-C can be used with this unit.
- HQ VHS is compatible with existing VHS equipment.

**Warning on lithium battery**

The battery used in this device may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble, heat above 100°C or incinerate.

Replace battery with Panasonic (Matsushita Electric), Sanyo or Maxell CR2025; use of another battery may present a risk of fire or explosion.

- Dispose of used battery promptly.
- Keep away from children.
- Do not disassemble and do not dispose of in fire.

**Crossed Out Dust Bin Mark**

Cd

- The Crossed Out Dust Bin Mark on the battery pack indicates that the product complies with Directives 91/157/EEC and 93/86/EEC.
- Nickel-Cadmium (Ni-Cd) battery pack must be recycled or disposed of properly.

This camcorder is designed to be used with PAL-type colour television signals. It cannot be used for playback with a television of a different standard. However, live recording is possible anywhere. Use the BN-V12U/V22U/V25U battery packs and, to recharge them, the provided multi-voltage AC Power Adapter/Charger. (An appropriate conversion adapter may be necessary to accommodate different designs of AC outlets in different countries.)


**NOTES:**

- *The rating plate (serial number plate) and safety caution are on the bottom and/or the back of the main unit.*
- *The rating plate (serial number plate) of the AC Power Adapter/Charger is on its bottom.*


This unit is produced to comply with Standard IEC Publ. 65.

- Program Manager (☞ pg. 14 – 25)
- Programme AE with Special Effects (☞ pgs. 14, 15)
  - Auto Mode Lock
  - Auto Mode Release
  - Electronic Fog Filter • ND Effect
  - Sepia • Twilight • Sports
  - 1/1000 sec. High Speed Shutter
  - 1/2000 sec. High Speed Shutter
- Picture Stabilizer (☞ pg. 18)
- Digital Hyper Zoom (☞ pg. 11)
- Digital Fades/Wipes (☞ pg. 19)
- EasyEdit with Random Assemble Editing (☞ pg. 33 – 35)


## PROVIDED ACCESSORIES




• AC Power Adapter/  
Charger AA-V11EG




• Battery Pack  
BN-V12U



• Cassette Adapter  
C-P7U




• Shoulder Strap



• Cable Adapter



• Lithium Battery  
CR2025




• DC cord




• AUDIO/VIDEO  
(A/V) cable


|   |           |
|---|-----------|
| <b>GETTING STARTED</b>                        | <b>4</b>  |
| Power .....                                   | 4         |
| Clock (Lithium) Battery Insertion/Removal ... | 6         |
| Viewfinder Adjustment .....                   | 6         |
| Date/Time Setting .....                       | 7         |
| Tape Length Setting .....                     | 8         |
| Loading/Unloading A Cassette .....            | 8         |
| Grip Adjustment .....                         | 9         |
| Shoulder Strap Attachment .....               | 9         |
| Tripod Mounting .....                         | 9         |
| <b>RECORDING</b>                              | <b>10</b> |
| Basic Recording .....                         | 10        |
| Basic Features .....                          | 11        |
| Advanced Features .....                       | 14        |
| <b>PLAYBACK</b>                               | <b>28</b> |
| Using The Cassette Adapter .....              | 28        |
| Basic Connections .....                       | 29        |
| Basic Playback .....                          | 30        |
| Features .....                                | 31        |
| <b>EDITING</b>                                | <b>32</b> |
| Tape Dubbing .....                            | 32        |
| Random Assemble Editing [R.A.Edit] .....      | 33        |
| <b>USING REMOTE CONTROL UNIT</b>              | <b>36</b> |
| Insert Editing .....                          | 38        |
| Audio Dubbing .....                           | 39        |
| <b>TROUBLESHOOTING</b>                        | <b>40</b> |
| <b>INDEX</b>                                  | <b>42</b> |
| Controls .....                                | 42        |
| Connectors .....                              | 43        |
| Indicators .....                              | 43        |
| Other Parts .....                             | 43        |
| Viewfinder .....                              | 44        |
| <b>CAUTIONS</b>                               | <b>45</b> |
| <b>SPECIFICATIONS</b>                         | <b>47</b> |



Charge marker



**\*\* CHARGE MARKER**  
A charge marker is provided on the battery pack to help you remember whether it has been charged or not. Two colors are provided (red and black)—you choose which one means charged and which means discharged.



**ATTENTION:**

Before detaching the power source, make sure that the camcorder's power is turned off. Failure to do so can result in a camcorder malfunction.

**Power**

This camcorder's 3-way power supply system lets you choose the most appropriate source of power.

**NOTES:**

- No function is available without power supply.
- Use only specified power supply.
- Do not use provided power supply units with other equipment.

**CHARGING THE BATTERY PACK**

**SUPPLY POWER**

**1** Connect the charger's AC power cord to a wall outlet. The power indicator lights.

**ATTACH BATTERY PACK**

**2** Align the marks and slide the battery pack in the direction of the arrow until it locks in place. The CHG. indicator lights.

**DETACH BATTERY PACK**

**3** When charging is completed, the END indicator lights. Slide the battery pack opposite the direction of the arrow.

| BATT. PACK | CHARGE                 | DISCHARGE              |
|------------|------------------------|------------------------|
| BN-V12U    | approx. 1 hr. 10 min.  | approx. 3 hrs. 30 min. |
| BN-V22U    | approx. 2 hrs. 10 min. | approx. 7 hrs.         |
| BN-V25U    | approx. 2 hrs. 40 min. | approx. 10 hrs.        |

**USING THE BATTERY PACK**

**ATTACH BATTERY PACK**

**1** Hook its top end to the camcorder and push the battery pack in until it locks in place.

**DETACH BATTERY PACK**

**2** Slide BATT. RELEASE and pull out the battery pack.

| BATT. PACK | APPROXIMATE RECORDING TIME |
|------------|----------------------------|
| BN-V12U    | 1 hr. 5 min.               |
| BN-V22U    | 2 hrs. 15 min.             |
| BN-V25U    | 3 hrs.                     |

**\*\*REFRESH**


The AC power adapter features a REFRESH function that allows you to fully discharge the battery pack before recharging.

**To discharge the battery . . .**

..... attach the battery pack to the adapter as shown in the illustration to the left. Then push REFRESH. The REFRESH indicator lights when discharging starts, and goes out when discharging is complete.

## NOTES:

- The recording time per charge is affected by such factors as the time spent in Record/Standby mode and the frequency of zooming. It is safer to have spare battery packs.
- Charging times noted on page 4 are for fully discharged battery pack, and discharging times are for fully charged battery pack.
- Charging and discharging times vary according to the ambient temperature and the status of the battery pack.
- Remember to set the charge marker after charging a battery pack or after detaching a discharged one from your camcorder.
- Perform the REFRESH function after no less than 5 chargings.
- High temperatures can damage the battery pack, so use only where good ventilation is available. Don't allow it to discharge in container, such as a bag.
- If you stop recharging or discharging part way through, make sure to remove the battery pack before unplugging the adapter's AC cord.
- Remove the battery pack from the adapter immediately after discharging.
- To avoid interference with reception, do not use the AC Power Adapter/Charger near a radio.
- Make sure you unplug the DC cord before charging or discharging the battery pack.
- A blinking CHG. indicator means that the battery pack has become hot. Wait until it cools down to continue.
- The CHG. indicator may not light properly with a brand new battery pack, or with one that's been stored for an extended period. In this case, remove and reattach the battery pack and recharge it. The CHG. indicator should light during recharging. If not, contact your nearest JVC dealer.



## USING A CAR BATTERY

Use the optional Car Battery Charger/Adapter (connect as shown in the above illustration).

## NOTES:

- When using the car battery, leave the engine idling.
- The optional Car Battery Charger (BH-V3E) can also be used to charge the battery pack.
- When using the optional Car Battery Charger, refer to the respective instruction booklet.

## USING AC POWER



Use the AC Power Adapter (connect as shown in the above illustration).

## NOTE:

The supplied AC Power Adapter/Charger features automatic voltage selection in the AC range from 110 V to 240 V.

## Clock (Lithium) Battery Insertion/Removal

This battery is necessary for clock operation and to perform date/time settings.



### SWITCH OFF POWER

- 1 Switch off the unit's power and remove the power supply unit.

### OPEN COVER

- 2 Open the clock battery compartment cover while pressing the release tab.

### REMOVE BATTERY (when replacing)

- 3 Insert a pointed, non-metallic object between the battery and the compartment (A) and pull the battery out.

### INSERT BATTERY

- 4 Ensuring the plus (+) side is up, insert a CR2025 lithium battery and push it in.

### CLOSE COVER

- 5 Close the compartment cover until it clicks in place.

### NOTE:

See "SAFETY PRECAUTIONS" (pg. 2) for information on safe handling of lithium batteries.

## Viewfinder Adjustment

### POSITION VIEWFINDER


- 1 Adjust the viewfinder manually for best viewability (see illustration at left).

### SELECT MODE


- 2 Set the power switch to CAMERA.

### ADJUST DIOPTR

- 3 Turn the diopter adjustment control until the indications in the viewfinder are clearly focused.




Set POWER to "CAMERA".



Menu Screen

|                  |      |
|------------------|------|
| Gain Up          | S.LX |
| Tele Macro       | OFF  |
| Interval Timer   | OFF  |
| Rec Time         | OFF  |
| JLIP ID NO.      | 07   |
| Tally            | ON   |
| Set Character    |      |
| <b>Date/Time</b> |      |
| END :MENU KEY    |      |

Set Time and Date Screen




## Date/Time Setting

- 1 **SELECT MODE**  
First set the power switch to "CAMERA". Turn the PROGRAM AE select dial to any position except AUTO LOCK.
- 2 **ACCESS MENU SCREEN**  
Press MENU.
- 3 **SELECT FUNCTION**  
Press - to move the highlight bar down to "Date/Time", then press NEAR. The Set Date And Time screen appears.
- 4 **SET DATE/TIME**  
Press FAR or NEAR until the item you want to set begins blinking, then press + or - to until the correct setting appears.
  - If you decide you want to return the date and time to the previous settings, press FAR or NEAR to move the highlight bar to "Cancel", then press MENU.
  - If you're satisfied with the settings, go on to step 5.
- 5 **START CLOCK OPERATION**  
Once you've set the day, month, year and time, press FAR or NEAR until "Set" begins to blink, then press MENU. The Menu screen reappears.
- 6 **CLOSE MENU**  
Press MENU.

### NOTES:

- To display the date and time in the viewfinder and on a connected TV, see "Date/Time Insert" ( pg. 22).
- If, in step 4, you input an invalid date (30. 2, 31. 6, etc.) and perform step 5, "Input Error" appears blinking at the bottom of the screen. Press +, -, FAR or NEAR to input the correct number.



## Tape Length Setting

Set the tape length according to the length of the tape used.

### 1 SET TAPE LENGTH

- 1 Press T30•45•60 until the required indication appears in the viewfinder. T30 = 30 minutes of recording time, T45 = 45 minutes, and T60 = 60 minutes.

### NOTE:

The tape remaining time (pg. 10) displayed in the viewfinder is correct only if the correct tape length has been selected.

## Loading/Unloading A Cassette

### 1 OPEN CASSETTE HOLDER


Slide EJECT until the holder opens. Do not use force to open.

### 2 INSERT/REMOVE CASSETTE

Make sure the label is facing outward.

### 3 CLOSE CASSETTE HOLDER


Press PUSH and make sure the holder is closed and locked.



### NOTES:

- A cassette holder can't be opened unless a power supply is attached.
- Make sure that the tape is not slack when loading the cassette. If there is any slack, turn the gear on the cassette in the direction of the arrow to take up the slack.
- Make sure the Erase Protection tab is in the position that allows recording. If not, slide the tab. Some cassettes have removable tabs. If the tab has been removed, cover the hole with adhesive tape.
- The cassette holder can't be opened while the camcorder is in the record mode.






Recording Start/Stop button

## Grip Adjustment

- 1 EXPAND LOOP**  
Separate the Velcro strip.
- 2 INSERT HAND**  
Pass your right hand through the loop and grasp the grip.
- 3 ADJUST STRAP LENGTH**  
Adjust so your thumb and fingers can easily operate the Recording Start/Stop button and Power Zoom lever. Refasten the Velcro strip.


## Shoulder Strap Attachment




- 1 ATTACH STRAP**  
Following the illustration at left, thread the strap through the top of the eyelet ①, then fold it back and thread it through the keeper ②, and then through the buckle ③. Repeat the procedure to attach the other end of the strap to the other eyelet, making sure the strap isn't twisted.
- 2 ADJUST LENGTH**  
Adjust as shown in the illustration at left ①, then slide both keepers snug against the eyelets to prevent slipping ②.

## Tripod Mounting

- 1 ALIGN AND TIGHTEN**  
Align the screw and camera direction stud on the tripod with the camera's mounting socket and stud hole. Then tighten the screw.



## Tape remaining time indicator

**NOTE:**

You should already have performed the procedures listed below. If not, do so before continuing.

- Power (☞ pg. 4)
- Date/Time Setting (☞ pg. 7)
- Tape Length setting (☞ pg. 8)
- Grip Adjustment (☞ pg. 9)

**LOAD A CASSETTE**

- Slide EJECT to open the cassette holder, then insert the cassette with the label facing out. Press PUSH to ensure the holder is closed and locked.

**ENTER RECORD-STANDBY MODE**

- Slide the LENS COVER open/close switch to open the lens cover, then set the power switch to "CAMERA".

- The power indicator lights and the camcorder enters the Record-Standby Mode.
- The scene you're aimed at appears on the viewfinder screen, with the word "PAUSE" superimposed upon it.

**START SHOOTING**

- Press the RECORDING START/STOP button.

- The tally lamp lights while recording is in progress, and "REC" appears in the viewfinder.




**STOP RECORDING**

- Press the RECORDING START/STOP button again to stop recording.

- The camcorder re-enters the Record-Standby mode.

**NOTES:**

- A cassette holder can't be opened unless a power supply is attached.
- There may be a delay after you slide EJECT until the holder opens. Do not use force.
- The tape's remaining time is displayed in the viewfinder as shown.
- The indicated remaining time is approximate.
- The time required to calculate the remaining tape length, and the accuracy of the calculation, may vary according to the type of tape used.
- The tape remaining time displayed in the viewfinder is correct only if the correct tape length has been selected (☞ pg. 8).
- "TAPE END" appears when the tape reaches its end, and the power goes off automatically if left in this condition for 5 minutes. "TAPE END" also appears when a cassette whose tape is already at its end is loaded.
- If the Record-Standby mode continues for 5 minutes without performing Zoom or any other operations, the camcorder's power shuts off automatically. Set the Power switch to "POWER OFF", and then back to "CAMERA" to turn the camcorder on again.
- If the Recording Start/Stop button is pressed after the Record-Standby mode has continued for over 5 minutes, recording may not start immediately.
- If you're recording on a cassette from the middle, use the RETAKE function (☞ pg. 12) to find the end of the last recording so you don't erase any of it.
- The LENS COVER warning blinks for about 10 seconds when the camcorder is turned on, when the cover is closed.



**FEATURE:**  
**PURPOSE:**

**OPERATION:**

**NOTES:**

## Zooming


To produce the zoom in/out effect, or an instantaneous change in image magnification.

### 36X Hyper zoom


Digital circuitry doubles the maximum 18x magnification offered by optical zoom.

- 1) To zoom in, slide the Zoom Lever toward "T".
- 2) To zoom out, slide toward "W".

- *During Hyper Zoom, the speed increases the further you slide the Zoom Lever.*
- *Focusing may become unstable during Hyper Zoom. In this case, set the zoom while in Record-Standby, set manual focus or Focus Lock (pg. 16, 17), then zoom in or out in Record mode.*
- *The Zoom Level Indicator (■) only moves during optical zoom. Once the Zoom Level indicator reaches the top of the zoom indicator bar, all magnification from that point is through digital processing.*
- *During digital image processing, the quality of the image may suffer.*



|  |   |
|--|---|
| <p><b>FEATURE:</b></p> <p><b>PURPOSE:</b></p> <p><b>OPERATION:</b></p> <p><b>NOTE:</b></p> | <p><b>Quick Review</b></p> <p>To check the end of the last recording.</p> <p>1) Press “<b>C</b>” and release quickly during the Record–Standby mode.</p> <ul style="list-style-type: none"> <li>• Tape is rewound for about 2 seconds and played back automatically, then pauses in Record–Standby mode for the next shot.</li> </ul> <p><i>Distortion may occur at start of playback. This is normal.</i></p>      |
| <p><b>FEATURE:</b></p> <p><b>PURPOSE:</b></p> <p><b>OPERATION:</b></p> <p><b>NOTE:</b></p> | <p><b>Retake</b></p> <p>To re-record certain segments.</p> <p>1) Make sure the camcorder is in the Record–Standby mode.</p> <p>2) Press either <b>RETAKE</b> button to reach the start point for new recording.</p> <p>Pressing “F” fast-forwards the tape and pressing “R” reverses it.</p> <p>3) Press Recording Start/Stop to start recording.</p> <p><i>Noise may appear during Retake. This is normal.</i></p> |



**FEATURE:**  
**PURPOSE:**

**OPERATION:**

**NOTES:**

### Quick Rec




To record a scene for 5 seconds, providing quick scene transitions like those seen in TV programmes.

1) During Record-Standby, press and release **QUICK REC**. Recording starts, and after 5-second recording is finished, the camcorder reenters the Record-Standby mode automatically.

- To continue shooting longer than 5 seconds, press and hold **QUICK REC**. Recording continues as long as **QUICK REC** is kept pressed.

- *The Fade/Wipe ( pg. 19) cannot be activated by pressing **QUICK REC**.*
- ***QUICK REC** cannot be used during Animation and Time-Lapse ( pg. 27).*

1 second later, the mode is activated.



## Programme AE With Special Effects

All you have to do to access any of the variety of shooting effects is to turn the PROGRAM AE select dial.

### SELECT MODE

**1** Turn the PROGRAM AE select dial until the symbol of the function you want is aligned with the mark.

- The selected mode's name and its indication are displayed in the viewfinder for approx. 1 second. Then the name disappears, and only the indication remains. The mode is activated.
- When Auto Mode Lock or Auto Mode Release mode is selected, only the mode's name is displayed. Then the name disappears and the mode is activated.

### NOTES:

- Only one effect can be engaged at a time.
- The screen becomes slightly reddish when the Fade/Wipe (pg. 19) is used in the Sepia mode.
- The screen becomes slightly dark in the High Speed Shutter mode. Use in well-lighted situations.
- In the High Speed Shutter or Sports modes, picture colour may be adversely affected if subject is lit by alternating discharge-type light sources such as fluorescent or mercury-vapour lights.

| DIAL SYMBOL | VIEWFINDER INDICATION | MODE           |
|-------------|-----------------------|----------------|
| LOCK        | Auto Lock             | Auto Mode Lock |

### Auto Mode Lock

Locks the camcorder in Full Auto mode, preventing incorrect operation due to accidental button pressing during shooting.

- In this mode the following controls are disabled; FADE/WIPE, WIDE, TITLE, DISPLAY, M.W.B (Manual White Balance), Manual Focus, Focus Lock, Exposure Control and MENU

|         |              |                   |
|---------|--------------|-------------------|
| RELEASE | Auto Release | Auto Mode Release |
|---------|--------------|-------------------|

### Auto Mode Release

Re-enables the controls that were disabled by Auto Mode Lock.

|    |          |                       |
|----|----------|-----------------------|
| FG | FG : Fog | Electronic Fog Filter |
|----|----------|-----------------------|

### Electronic Fog Filter

Makes the picture look misty white, as when an external fog filter is attached to the lens. Softens the image and gives it a “fancy” look.


|    |                |           |
|----|----------------|-----------|
| ND | ND : ND Effect | ND Effect |
|----|----------------|-----------|

### ND Effect

A black mist darkens the picture, as when an ND filter is used. Helps to counter the effects of glare on the subject.

|  |   |       |
|--|---|-------|
|  |  Sepia | Sepia |
|--|---|-------|




### Sepia

The scene being shot is recorded in sepia-tinted (reddish-brown) monochrome, giving the effect of an older movie. Use together with Wide ( pg. 20) for the authentic look of a classic Hollywood movie.

| DIAL SYMBOL   | VIEWFINDER INDICATION  | MODE     |
|---|--|----------|
|  |  Twilight | Twilight |

### Twilight


Dusk, twilight scenery, fireworks, etc., look more natural and dramatic. The following happens when Twilight mode is selected:

- Auto gain control is turned off.
- White Balance is set to “” (outdoor mode), but can also be manually changed to another mode ( pg. 23).
- Auto Focus becomes available only in the range of 10 m to infinity. To focus when the subject-to-camera distance is less than 10 m, use manual focusing ( pg. 17).

|   |  |        |
|---|--|--------|
|  |  Sports | Sports |
|---|--|--------|

### Sports

High shutter speed clearly captures fast-moving action.

|        |  |                                   |
|--------|--|-----------------------------------|
| 1/1000 |  1 S 1/1000 | 1/1000 sec.<br>High Speed Shutter |
|--------|--|-----------------------------------|



|        |  |                                   |
|--------|--|-----------------------------------|
| 1/2000 |  2 S 1/2000 | 1/2000 sec.<br>High Speed Shutter |
|--------|--|-----------------------------------|

### High-Speed Shutter (1/1000s., 1/2000s.)

Captures faster action than Sports mode.



Focus  
detection zone



PROGRAM AE select dial

## Focusing

### Auto Focus

The camcorder's Full Range AF system offers continuous shooting ability from close-up to infinity. However, correct focus may not be obtainable in the situations listed below (in these cases use manual focusing):

- When two subjects overlap in the same scene.
- When illumination is low.\*
- When the subject has no contrast (difference in brightness and darkness), such as a flat, one-colour wall, or a clear, blue sky.\*
- When a dark object is barely visible in the viewfinder.\*
- When the scene contains minute patterns or identical patterns that are regularly repeated.
- When the scene is affected by sunbeams or light reflecting off the surface of a body of water.
- When shooting a scene with a high-contrast background.

\* The low-contrast warning “▲▲” appears in the viewfinder.

### Focus Lock

This feature locks the focus in place, which is especially helpful in the following situations:

- When things pass between your subject and the camcorder. Engage the focus lock function to lock your subject in before recording.
- When you want your subject to be focused, and to appear in a corner of the screen. First, center on the subject and focus using auto focus mode. Then engage the focus lock function and move the camcorder until the subject is where you want it.

### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### LOCK FOCUS

- 2 Press **FAR** or **NEAR**. The focus lock indication “▲▲” appears in the viewfinder.


### RELEASE FOCUS LOCK

- 3 Press **FAR** and **NEAR** simultaneously. The focus lock indication disappears.

## NOTES:

- If the lens is smeared or blurred, accurate focusing is not possible. Keep the lens clean, wiping with a piece of soft cloth if it gets dirty. When condensation occurs, wipe with a soft cloth or wait for it to dry naturally.
- When shooting a subject close to the lens, zoom-out first (☞ pg. 11). If zoomed-in in the auto focus mode, the camcorder could automatically zoom out depending on the distance between the camcorder and the subject. \*When Tele Macro (☞ pg. 25) is activated, the camcorder will not zoom out automatically.





## Manual Focus

### NOTE:

You should already have made the necessary viewfinder adjustments (☞ pg. 6). If you haven't, do so before continuing.

### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### ADJUST FOCUS

#### To farther subject . . .

- 2 Press and hold **FAR**. The Manual Focus indications "▲▲" appear and "◀" blinks. Go to step 3.

#### To nearer subject . . .

- Press and hold **NEAR**. The Manual Focus indications "▲▶" appear and "▶" blinks. Go to step 3.

### LOCK FOCUS


- 3 Release **FAR** or **NEAR**. The focus indication is replaced by the focus lock indication "▲▲" and the adjusted focus is locked in.

### RELEASE MANUAL FOCUS MODE

- 4 Press **FAR** and **NEAR** simultaneously. The Manual Focus mode is immediately released and the focus lock indication disappears.

### NOTES:

- Be sure to focus the lens in the maximum telephoto position when you use the Manual Focus mode. If you focus in on a certain subject in the wide-angle position, sharply focused images cannot be obtained when zoomed up because the depth-of-field is reduced at longer focal lengths.
- When the focus level cannot be adjusted any farther or closer, "▲" or "▶" will blink.



## Picture Stabilizer

This feature compensates for unstable images caused by camera-shake, particularly noticeable at high magnification.


### 1 ACTIVATE PICTURE STABILIZER

Press **P.STABILIZER**. "P" appears in the viewfinder.

- To switch off the Picture Stabilizer, press **P.STABILIZER**. The indicator disappears.

### NOTES:

- Accurate stabilization may not be possible if hand shake is excessive, or under the following conditions:
  - When shooting subjects with vertical or horizontal stripes
  - When shooting dark or dim subjects
  - When shooting subjects with excessive backlighting
  - When shooting scenes with movement in various directions
  - When shooting scenes with low-contrast backgrounds
- Switch off Picture Stabilizer when recording with the camcorder on a tripod.



## Exposure Control

This feature automatically adjusts the iris for the best available picture quality, but you can override and make the adjustment manually.

### 1 SELECT MODE

Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### 2 BRIGHTEN IMAGE

Press + (maximum +06). The Exposure level indicator appears in the viewfinder.

OR . . .

### DARKEN IMAGE


Press - (maximum -06). The Exposure level indicator appears in the viewfinder.

When you want to return to the factory setting . . .


### 3 RESTORE INITIAL SETTING

Press + and - simultaneously. The standard setting is immediately restored and the Exposure level indicator disappears.


[Ex. : Black Fader]



Function indication



SELECT button



PROGRAM AE select dial

SET button

**NOTES:**

- Pressing and holding the Recording Start/Stop button allows you to record a black blank screen, or a mosaic pattern if Mosaic Fader is selected.
- The screen becomes slightly reddish when the Fade/Wipe is used with Sepia ( pg. 15).

**Fade/Wipe**

These effects let you make pro-style scene transitions. Fade- or wipe-in works at recording start, and fade- or wipe-out works at recording end or when you enter Record-Standby mode.

**1 SELECT MODE**

Turn the PROGRAM AE select dial to any position except AUTO LOCK.

**2 SELECT FUNCTION**

Press **SELECT** repeatedly until "► Fade/Wipe" appears.

**3 ENGAGE FADE- OR WIPE-STANDBY MODE**

Press **SET** to cycle through the modes as shown at left. Once the desired mode appears, it is selected and reserved.

- The selected mode's name and its indication are displayed in the viewfinder for approx. 2 seconds. Then the name disappears, and only the indication remains.

**4 START RECORDING**

Press Recording Start/Stop to start recording and activate fade- or wipe-in.

**OR . . .****END RECORDING**

Press Recording Start/Stop to end recording and engage fade- or wipe-out.

**5 TO CANCEL FADE- OR WIPE-STANDBY MODE**

While "► Fade/Wipe" is displayed, press **SET** twice.

- "OFF" is displayed for approx. 2 seconds and the reserved fade or wipe is cancelled.

**[Bk] Black Fader**

Fades in/out to a black screen.

**[Mosaic] Mosaic Fader**


Gradually turns/returns the picture into/from a mosaic pattern.

**[Shutter] Shutter Wipe**

A black screen moves in from the top and bottom, closing over the image like a shutter, or a new image pushes open the black screen vertically from the centre.

**[Slide] Slide Wipe**

A black screen moves in from the left to gradually cover the image, or a new image moves in from right to left.



## Wide

This feature allows you to record black bars at the top and bottom of the screen to produce a cinema-like “wide-screen” effect.

### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### SELECT FUNCTION


- 2 Press **SELECT** repeatedly until “▶Wide” appears.

### ENGAGE WIDE MODE

- 3 Press **SET**.

### RESTORE NORMAL SCREEN

- 4 Press **SET** again while “▶Wide” appears.



## Instant Titles

The camcorder has eight preset titles in memory. You can superimpose one of them above a previously stored title as shown in the illustration to the left.

### DISPLAY

#### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

#### SELECT FUNCTION

- 2 Press **SELECT** repeatedly until “▶Title” appears.


#### SELECT PRESET TITLE

- 3 Engage the Record-Standby mode, then press **SET** to cycle through the preset titles until the desired title is displayed.

## NOTES:

- To delete the Instant Title during recording, press **SELECT** repeatedly until “▶Title” appears then press **SET**.
- To recall a title, press **SET** again.


**SELECT**



**SET**

**PROGRAM AE select dial**





## Date/Time Character Insert

This feature allows you to display date, time and characters in your viewfinder and on a connected color monitor, record them manually or automatically, and even make your own titles.

### NOTE:

You should already have performed the Date/Time Setting procedure (☞ pg. 7). If you haven't, do so before continuing.

### DISPLAY

#### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

#### SELECT DISPLAY

- 2 Press SELECT repeatedly until "►Disp." appears.

#### CHOOSE DISPLAY MODE

- 3 Press SET while in Record-Standby to cycle through the modes as shown in the illustration at left.

### NOTES:

- The selected display can be recorded.
- If you don't want to record the display, select Date-off mode before shooting.
- If you want to delete the display during shooting, engage the Record-Standby mode, press SELECT repeatedly until "►Disp." appears then press SET and select the Date-off mode.

### AUTO DATE RECORD


Your camcorder automatically records the date for about 5 seconds after recording is initiated in the following situations:

- After changing the date.
- After loading a cassette.
- After Auto Date Record mode is selected by pressing SET.


In this mode, the date is replaced after 5 seconds with "Auto Date".

### NOTES:

- Setting PROGRAM AE to LOCK always engages the Auto Date Record mode, and disables all other modes.
- In the Auto Date Record mode, if the date changes while you're shooting, the date indication is recorded for about 5 seconds from that point. It is not recorded during any other recordings made on that day.






SELECT



SET

PROGRAM AE select dial

White balance mode indicator



## Manual White Balance Adjustment (M.W.B.)

This camcorder's Automatic Colour Temperature system senses the colour temperature of the ambient lighting for automatic white balance adjustment. However, precise colour adjustment is not possible under the following conditions:

- When an object is in various shades of the same colour.
- When a predominantly red or brown object is being shot outdoors.

In these cases, use the camcorder's built-in preset filters for white balance adjustment.

### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### SELECT FUNCTION

- 2 Press **SELECT** repeatedly until "►M.W.B." appears.

### SELECT WHITE BALANCE

- 3 Press **SET** (Manual White Balance) until the required indication appears in the viewfinder.

"MWB" ..... With a memorized personal White Balance setting (see below)

"☀" ..... Outdoors on sunny day

"☁" ..... Outdoors on cloudy day

"💡" ..... Light source is halogen or tungsten lamp

### MWB

MWB sets the colour temperature for the subject's light source so you can shoot with natural colours that are unaffected by surroundings, even when there are multiple subjects with different colour temperatures.

### SELECT MODE

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK.

### ADJUST FOCUS

- 2 Point the camcorder at a white, flat object such as a sheet of white paper, and adjust focus manually (☞ pg. 17).


### ADJUST WHITE BALANCE

- 3 Press **SET** until "MWB" appears, then press and hold **SET** for more than 3 seconds.

- "MWB" blinks in the viewfinder during adjustment, then stops blinking but stays lit when adjustment is complete.


## NOTES:

- To switch to automatic white balance adjustment, press **SET** until the indication disappears, or turn the PROGRAM AE select dial to "AUTO LOCK".
- Re-adjust the White Balance when the lighting has changed, when the camcorder has been turned on and off again, or when the PROGRAM AE select dial's position has been changed.
- It is helpful to connect your camcorder to a colour monitor when adjusting the white balance ("Basic Connections" ☞ pg. 29).
- When adjusted by putting coloured paper in front of the subject in step 2 ("ADJUST FOCUS"), this unit makes its colour temperature standard for automatic white balance. So you can enjoy shooting with different colours. For example, when adjusting with red, blue or yellow colours, the image becomes the colour which approximates to green, orange or purple respectively.



|                |             |
|----------------|-------------|
| <b>Gain Up</b> | <b>S.LX</b> |
| Tele Macro     | OFF         |
| Interval Timer | OFF         |
| Rec Time       | OFF         |
| JLIP ID NO.    | 07          |
| Tally          | ON          |
| Set Character  |             |
| Date/Time      |             |
| END :MENU KEY  |             |

|                   |               |
|-------------------|---------------|
| Gain Up           | ▶ <b>NORM</b> |
| <b>Tele Macro</b> | ▶ <b>ON</b>   |
| Interval Timer    | 1min          |
| Rec Time          | 1/2s          |
| JLIP ID NO.       | 07            |
| Tally             | ON            |
| Set Character     |               |
| Date/Time         |               |
| END :MENU KEY     |               |



If "Gain Up" or "Tele Macro" in the Menu has been changed from the factory settings, this mark appears in the viewfinder.

## Using Menu For Detailed Adjustment

This camcorder is equipped with Program Manager, an easy-to-use, on-screen menu system that simplifies many of the more detailed camcorder settings.

- 1 SELECT MODE**  
Turn the PROGRAM AE select dial to any position except AUTO LOCK.
- 2 ACCESS MENU SCREEN**  
Press MENU.
- 3 SELECT FUNCTION**  
Press + or - to place the highlight bar on the desired function.
- 4 MAKE SETTING**  
The setting procedure depends on the function you select.  
*If you select Gain Up, Tele Macro, Interval Timer, Rec Time, JLIP ID NO. or Tally, . . .*  
.... press FAR or NEAR to cycle through the choices until the desired setting appears.  
*If you select Set Character or Date/Time, . . .*  
.... press NEAR to access the selection menu for each function (Set Character – pg. 21; Date/Time – pg. 7).
- 5 CLOSE MENU**  
Press MENU. The normal screen reappears.

### NOTE:

The menu is available only in the Record-Standby mode.





## MENU

|                |  |  |
|----------------|--|--|
| Gain Up        | S.LX   | To record a subject in a dark lit environment. When it is more convenient to shoot the subject with a brighter image even if the picture becomes slightly coarse. Automatically selected when the PROGRAM AE select dial is set to AUTO LOCK mode. (S.LX : Super LoLux)  |
|                | ▶ NORM   | To record a subject in a dimly lit environment. When it is more convenient to shoot with a less coarse picture although the subject becomes slightly dark.   |
|                | ▶ OFF  | Allows you to shoot dark scenes with no picture brightness adjustment.   |
| Tele Macro     | OFF  | Usually set to this position.  |
|                | ▶ ON   | Usually the distance to a subject where the lens is in focus depends on the zoom magnification. Unless there is a distance more than 1m to the subject, the lens is out of focus at the maximum telephoto setting. When set to "ON", you can shoot a subject as large as possible at a distance of approx. 60 cm.<br><ul style="list-style-type: none"> <li>Depending on the zoom position, the lens may go out of focus.</li> </ul> |
| Interval Timer | OFF  | This feature allows you to set the parameters for Self-Timer (☞ pg. 26) and Time-Lapse recording (☞ pg. 27).   |
|                | 15s  |  |
|                | 30s  |  |
|                | 1min<br>5min   |  |
| Rec Time       | OFF  | This feature allows you to set the parameters for Animation and Time-Lapse recording (☞ pg. 27).   |
|                | 1/4s   |  |
|                | 1/2s   |  |
|                | 1s<br>5s   |  |
| JLIP ID NO.    | This number is necessary when connecting the camcorder to a device such as a computer using the J terminal (JLIP). The numbers range from 01 to 99. Factory setting is 07. |  |
| Tally          | ON   | The tally lamp comes on to signal the start of recording.  |
|                | OFF  | The tally lamp remains off at all times.   |
| Set Character  | Allows you to input characters. (☞ pg. 21).  |  |
| Date/Time      | Allows you to set the current date and time (☞ pg. 7).   |  |

 = Factory setting and when the PROGRAM AE Select Dial is set to AUTO LOCK

**NOTE:**

During shooting in low light, Auto Focus accuracy may decrease even when Gain Up is used. In this case, use Manual Focus (☞ pg. 17).



## Self-Timer

You can set the delay between pressing **RECORDING START/STOP** and the actual start of recording. If you secure the camcorder, you (or whomever is operating the camcorder) can enter the scene before recording starts.

### NOTE:

Make sure the camcorder is in the Record-Standby mode before performing the following steps.

## ACCESS MENU SCREEN

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK, then press **MENU**.

## SET INTERVAL TIME

- 2 Press – or + to move the highlight bar down to “Interval Timer”, then press **FAR** or **NEAR** to cycle through the choices. Stop when the desired time appears. Choose from “15s”, “30s”, “1min”, “5min”, or select to turn the function “OFF”.

## CLOSE MENU

- 3 Press **MENU**.


## START DELAYED RECORDING

- 4 Press **RECORDING START/STOP**. The tally lamp begins blinking, and the blinking frequency increases about 5 seconds before recording is to start. Once recording begins, the lamp stops blinking but stays lit.

### To Release Self-Timer . . .

.... while the tally lamp is blinking, press **RECORDING START/STOP** to stop the blinking, then set “Interval Timer” to “OFF”.

|                       |            |
|-----------------------|------------|
| Gain Up               | S.LX       |
| Tele Macro            | OFF        |
| <b>Interval Timer</b> | <b>OFF</b> |
| Rec Time              | OFF        |
| JLIP ID NO.           | 07         |
| Tally                 | ON         |
| Set Character         |            |
| Date/Time             |            |
| END :MENU KEY         |            |



## Animation

Give stationary scenes or objects an illusion of movement. This function allows you to shoot a series of pictures, each slightly different, of the same object for a brief period of time.

### NOTE:

Make sure the camcorder is in the Record-Standby mode before performing the following steps.

#### ACCESS MENU SCREEN

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK, then press **MENU**.

#### SET RECORDING TIME

- 2 Press – or + to move the highlight bar down to “**Rec Time**”, then press **FAR** or **NEAR** to cycle through the choices. Stop when the desired time appears. Choose from “1/4s”, “1/2s”, “1s”, “5s”, or select to turn the function “OFF”. Then press **MENU** to close Menu screen.

#### START RECORDING

- 3 Press the Recording Start/Stop button after focusing on the subject. The recording stops automatically after the selected period of time.

#### ASSEMBLE SERIES OF PICTURES

- 4 Repeat step 3 for the desired number of pictures.

#### RELEASE ANIMATION MODE

- 5 Set “**Rec Time**” in the Menu screen to “OFF”.

### NOTES:

- For best results, make sure the camcorder is secured when shooting in Animation or Time-Lapse mode.
- Fade/Wipe-in/out cannot be performed during Animation or Time-Lapse shooting.
- Before performing other operations following Animation or Time-Lapse recording, make sure the Animation or Time-Lapse mode is deactivated.

## Time-Lapse

You can record sequentially at preset time spans. Leaving the camcorder aimed at a specific subject, you can record subtle changes over an extended period of time.

### NOTE:

Make sure the camcorder is in the Record-Standby mode before performing the following steps.

#### ACCESS MENU SCREEN

- 1 Turn the PROGRAM AE select dial to any position except AUTO LOCK, then press **MENU**.

#### SET INTERVAL BETWEEN RECORDINGS

- 2 Press – or + to move the highlight bar down to “**Interval Timer**”, then press **FAR** or **NEAR** to cycle through the choices. Stop when the desired time appears. Choose from “15s”, “30s”, “1min”, “5min”, or select to turn the function “OFF”.

#### SET RECORDING TIME



- 3 Press – or + to move the highlight bar down to “**Rec Time**”, then press **FAR** or **NEAR** to cycle through the choices. Stop when the desired time appears. Choose from “1/4s”, “1/2s”, “1s”, “5s”, or select to turn the function “OFF”. Then press **MENU** to close Menu screen.

#### START TIME-LAPSE RECORDING


- 4 Press the Recording Start/Stop button. Recording and intervals alternate automatically.

#### RELEASE TIME-LAPSE MODE


- 5 To release when the tally lamp is not blinking, set “**Rec Time**” and “**Interval Timer**” in the Menu screen to “OFF”. To release when the tally lamp is blinking, press the Recording Start/Stop button to stop the blinking, then set “**Interval Timer**” and “**Rec Time**” in the Menu screen to “OFF”.



Compact video cassette



Recording safety hole



## Cassette Adapter

Use this to play back a VHS-C video cassette recorded with this camcorder. It is fully compatible with any VHS video cassette recorder. The C-P7U adapter is battery powered and automatically performs tape loading and unloading.

### INSERT BATTERY

- 1 Slide the battery cover up to remove it, and install one "R6(AA)" size battery as shown in the illustration at left. Then reattach the cover.

### INSERT CASSETTE IN ADAPTER

- 2 Slide the latch to open the adapter compartment door, then insert the cassette and close the compartment door.

### PLAY BACK ON CONNECTED VCR

- 3 Load the cassette adapter into the VCR and play the tape back as you would any other.

### REMOVE CASSETTE FROM ADAPTER

- 4 Slide the latch and the compartment door opens automatically. Then insert your finger in the hole on the underside of the adapter as shown in the illustration at left, push up and remove the cassette.

## NOTES:


- During tape loading and unloading, do not touch the reels for safety and tape protection.
- During special-effect playback (slow motion, still frame, etc.), the picture may vibrate or noise bars may appear on the screen.
- To record on a VCR using a compact cassette and the adapter, cover the adapter's recording safety hole with adhesive tape.

There are three basic types of connections. When making the connections, refer also to your VCR and TV instruction manuals.

## Connection To A VCR [A] (Editing, Dubbing and Playback)

### NOTE:

Use the provided Audio and Video cables.



## CONNECT CAMCORDER TO VCR

- 1 As shown in the illustration at left, connect the Audio and Video cables between the AUDIO and VIDEO connectors on the camcorder and those on the VCR.

## SUPPLY POWER

- 2 Turn on the camcorder, the VCR and the TV.

## SELECT MODE

- 3 Set the VCR to its AUX input mode, and set the TV to its VIDEO mode.

## Connection To A TV With A/V Input Connectors [B] (Playback ONLY)

### NOTE:


Use the provided Audio and Video cables.

## CONNECT CAMCORDER TO TV

- 1 As shown in the illustration at left, connect the Audio and Video cables between the AUDIO and VIDEO connectors on the camcorder and those on the TV.

## SELECT MODE

- 2 Set the TV to its VIDEO or AV mode (as specified in its instructions).



### NOTES:


- It is recommended to use the AC Power Adapter/Charger as the power supply instead of the battery pack.
- To monitor the picture and sound from the camcorder without inserting a tape, set the camcorder's Power switch to "CAMERA", then set your TV to the appropriate input mode.
- If you have a TV or speakers that are not specially shielded, do not place the speakers adjacent to the TV as interference will occur in the camcorder playback picture.

## Connection To A TV With NO A/V Input Connectors (Playback ONLY)

### NOTE:

Use the optional RF-V5E RF unit.

\* Refer to the RF-V5E instruction manual for connection procedure.

**NOTE:**

Make sure you connect your camcorder as directed in "Basic Connections" (pg. 29).

**LOAD A CASSETTE**

- 1 Slide EJECT to open the cassette holder, then insert the cassette with the label facing out. Press PUSH to ensure the holder is closed and locked.

**SELECT MODE**

- 2 Set the Power switch to "PLAY". The Power On indicator lights.

**PLAYBACK**

- 3 Press **PLAY/PAUSE**. The playback picture appears in the viewfinder and the connected TV.

**STOP PLAYBACK**


- 4 Press **STOP**.

**Rewind or Fast-forward the tape**


Press **REW** to rewind, or **FF** to fast-forward the tape during Stop mode.

**NOTE:**

The camcorder shuts off automatically after about 5 minutes in Stop mode or Still Playback mode. To turn on again, set the Power switch to "POWER OFF", then to "PLAY".



|  |   |
|--|---|
| <p><b>FEATURE:</b><br/><b>PURPOSE:</b></p> <p><b>OPERATION:</b></p> <p><b>NOTES:</b></p> | <p><b>Manual Tracking</b></p> <p>To eliminate noise bars that appear on the screen during playback.</p> <p>1) Press either +/- button as many times as necessary for best picture.</p> <p>● To reset <i>TRACKING</i> to the original preset, press both + and - buttons simultaneously.</p> <p>● Manual Tracking may not work with tapes recorded on other VCRs or camcorders.</p>  |
| <p><b>FEATURE:</b><br/><b>PURPOSE:</b><br/><b>OPERATION:</b></p> <p><b>NOTE:</b></p>     | <p><b>Still Playback</b></p> <p>To pause during playback.</p> <p>1) Press <b>PLAY/PAUSE</b> during playback.</p> <p>2) To resume normal playback, press <b>PLAY/PAUSE</b> again.</p> <p><i>Noise bars appear and pictures may become monochrome during Still Playback. This is normal.</i></p>  |
| <p><b>FEATURE:</b><br/><b>PURPOSE:</b><br/><b>OPERATION:</b></p> <p><b>NOTE:</b></p>     | <p><b>Shuttle Search</b></p> <p>To allow high-speed search in either direction.</p> <p><b>Forward Search</b></p> <p>1) Press <b>FF</b> during playback.</p> <p><b>Reverse Search</b></p> <p>1) Press <b>REW</b> during playback.</p> <p><i>Noise bars appear and pictures may become monochrome or darken in Shuttle Search. This is normal.</i></p>  |
| <p><b>FEATURE:</b><br/><b>PURPOSE:</b><br/><b>OPERATION:</b></p> <p><b>NOTES:</b></p>    | <p><b>Counter Memory Function</b></p> <p>To make it easier to locate a specific tape segment.</p> <p>1) Press <b>COUNTER R/M</b> and hold for more than 2 seconds. The counter resets to "0:00:00".</p> <p>2) Press <b>COUNTER R/M</b>. "M" appears.</p> <p>3) After recording or playback, press <b>STOP</b>, then <b>REW</b>. The tape automatically stops at or close to 0:00:00.</p> <p>4) Press <b>PLAY/PAUSE</b> to start playback.</p> <p>● The counter memory functions in the <i>FF</i> and <i>REW</i> modes.</p> <p>● To disable Counter Memory Function, press <b>COUNTER R/M</b> so the "M" disappears.</p> |



## Tape Dubbing

### 1 CONNECT EQUIPMENT

Following the illustration at left, connect the camcorder and the VCR.

### 2 PREPARE FOR DUBBING

Set the camcorder's Power switch to "PLAY", turn on the VCR's power, and insert the appropriate cassettes in the camcorder and the VCR.

### 3 SELECT VCR MODE

Engage the VCR's AUX and Record-Pause modes.

### 4 FIND EDIT-IN POINT

Engage the camcorder's Play mode to find a spot just before the edit-in point. Once it's reached, press **PAUSE** on the camcorder.

### 5 START EDITING

Press **PLAY** on the camcorder and engage the VCR's Record mode.

### 6 STOP EDITING TEMPORARILY

Engage the VCR's Record-Pause mode and press **PAUSE** on the camcorder.

### 7 EDIT MORE SEGMENTS


Repeat steps 4 through 6 for additional editing, then stop the VCR and camcorder when finished.



## Random Assemble Editing [R.A.Edit]

Create edited videos easily using your camcorder as the source player. You can select up to 8 "cuts" for automatic editing, in any order you like. R.A.Edit is more easily performed when the MBR (Multi-Brand Remote RM-V704U or RM-V700U) is set to operate with your brand of VCR (see VCR CODE LIST), but can also be performed by operating the VCR manually.

- The RM-V704U/V700U is available optionally.



RM-V704U or RM-V700U

### VCR CODE LIST

| VCR BRAND NAME  | BUTTONS (A) (B)                 | VCR BRAND NAME                                | BUTTONS (A) (B)                                      |
|-----------------|---------------------------------|---|--|
| AKAI            | 6 2<br>6 4<br>7 7               | PHILIPS                                       | 1 9<br>9 5<br>1 1<br>9 4<br>9 1<br>9 6<br>1 2<br>3 3 |
| BLAUPUNKT       | 1 3                             | SANYO   | 3 6<br>3 5   |
| FERGUSON        | 9 7<br>9 8<br>3 2               | SELECO, REX                                   | 9 1<br>9 6   |
| GRUNDIG         | 1 4<br>3 4                      | SHARP   | 1 5<br>1 0   |
| HITACHI         | 6 6<br>6 3                      | SONY  | 6 5<br>6 0<br>3 9<br>3 1                             |
| JVC A<br>B<br>C | 8 1<br>9 6<br>9 3               | THOMSON,<br>TELEFUNKEN,<br>SABA,<br>NORDMENDE | 9 1<br>9 6<br>9 7<br>3 2                             |
| MITSUBISHI      | 6 7<br>6 8                      | TOSHIBA                                       | 6 9<br>6 1   |
| NEC             | 3 7<br>3 8                      |   |  |
| PANASONIC       | 1 3<br>1 7<br>1 1<br>9 4<br>1 8 |   |  |

## SET REMOTE/VCR CODE

### 1 SET REMOTE TO OPERATE VCR

Turn off the power to the VCR and point the remote toward the VCR's infrared sensor. Then, referring to the VCR CODE LIST on the left, press and hold **MBR SET**, and press button (A) and then (B).

- The code is automatically set once you release the **MBR SET** button, and the VCR's power comes on.

### 2 OPERATE THE VCR

Make sure the VCR's power is on. Then, while holding **VCR CTL**, press the button on the remote for the desired function. The functions the remote can control are PLAY, STOP, PAUSE, FF, REW and VCR REC STBY (you don't need to press **VCR CTL** for this one).

*You're now ready to try Random Assemble Editing.*

## IMPORTANT

Although the MBR is compatible with JVC VCRs and those of many other makers, it may not work with yours or may offer limited functions.

## NOTES:

- If the VCR's power doesn't come on in step 1, try another code from the VCR CODE LIST.
- Some brands of VCR don't come on automatically. In this case, turn the power on manually and try step 2.
- If the RM-V704U/V700U is not able to control the VCR, use the controls on the VCR.

## MAKE CONNECTIONS

### 1 CONNECT TO . . .

#### A JVC VCR EQUIPPED WITH REMOTE PAUSE TERMINAL

Connect the editing cable to the Remote PAUSE terminal.



#### B JVC VCR NOT EQUIPPED WITH REMOTE PAUSE TERMINAL

Connect the editing cable to the R.A.EDIT connector.

#### C NON-JVC VCR WITH NEITHER

Connect the editing cable to the RM-V704U/V700U's Pause-In jack.

All other connections are as shown in the illustration on page 34.



|         | IN      | OUT      |
|---------|---------|----------|
| 1       | 0:00:25 | --:--:-- |
| 2       |         |          |
| 3       |         |          |
| 4       |         |          |
| 5       |         |          |
| 6       |         |          |
| 7       |         |          |
| 8       |         |          |
| COUNTER | 0:00:25 |          |
| TOTAL   | 0:00:00 |          |



|         | IN      | OUT      |
|---------|---------|----------|
| 1       | 0:00:25 | 0:01:05  |
| 2       | 0:03:18 | 0:03:51  |
| 3       | 0:02:33 | 0:02:53  |
| 4       | 0:04:11 | --:--:-- |
| 5       |         |          |
| 6       |         |          |
| 7       |         |          |
| 8       |         |          |
| COUNTER | 0:04:11 |          |
| TOTAL   | 0:01:13 |          |

**2 PREPARE CAMCORDER**  
Insert a recorded tape and set the Power switch to "PLAY".

**3 PREPARE VCR**  
Turn the power on, insert a recordable tape and engage the AUX mode (refer to VCR's instructions).

**SELECT SCENES**

**1 ACCESS R.A. EDIT COUNTER DISPLAY**  
Press **PLAY/PAUSE**, then press **R.A. EDIT** and the counter display appears in the viewfinder and the screen of the connected TV.

**2 REGISTER BEGINNING OF SCENE**  
Press **REW** or **FF** to locate the beginning of a scene you want, then press **IN/OUT** to register that point. The data appears under IN on the display.

**3 REGISTER END OF SCENE**  
Press **REW** or **FF** to locate the end of the scene and press **IN/OUT** to register it. The data appears under **OUT** on the display. The total time of the registered scene(s) is displayed at the bottom of the screen.


**4 REGISTER ADDITIONAL SCENES**  
Repeat steps 2 and 3 for each additional scene (as many as 8).

**5 MAKE CORRECTIONS**  
Press **CANCEL** during steps 2 and 3 to erase the most recently registered point.


**NOTES:**

- The RM-V704U/V700U can be used to operate other camcorder functions as well. Point the RM-V704U/V700U at the camcorder's remote sensor and press any of the following buttons (function appears in parentheses):
  - ON/OFF (camcorder R.A. EDIT)
  - IN/OUT (camcorder IN/OUT)
  - CANCEL (camcorder CANCEL)
- There must be at least one second between an in-point and its corresponding out-point.
- To ensure correct operation, leave at least 15 seconds open between scenes.
- Blank portions of tape cannot be registered as in-points or out-points.
- If it takes more than 5 minutes to search for an in-point, the VCR's Record-Pause mode is cancelled and editing doesn't take place.
- Pressing **R.A.EDIT** clears all in- and out-points from memory.
- Leave a small margin for error around each in-point to ensure the scene is recorded in its entirety.

## ORIGINAL TAPE (camcorder)



## EDITED TAPE (VCR)



## AUTOMATIC EDITING TO VCR

## ENGAGE VCR'S RECORD-PAUSE MODE

- 1 Point the remote control toward the VCR's infrared sensor and press **VCR REC STBY**, or manually engage the VCR's Record-Pause mode.

## BEGIN AUTOMATIC EDITING


- 2 Press **EDIT** on the camcorder, and the previously selected scenes are copied to the VCR in the specified order.

## END AUTOMATIC EDITING


- 3 When all selected scenes have been copied, the camcorder and VCR enter the still or pause mode. Press **STOP** on both units.

- When finished editing, be sure to disconnect the editing cable and the audio/video cable.

## NOTES:

- If you performed step 1  on page 33 ("MAKE CONNECTIONS"), keep the remote control pointed at the VCR during editing.
- The on-screen display only appears while the camcorder searches for each scene.
- There may be noise at in- or out-points on the edited tape with certain VCRs.


## SUPPLEMENTAL INFORMATION ON THE REMOTE CONTROL



Using the RM-V704U/V700U, it is also possible to perform deck-to-deck Random Assemble Editing. The playback deck must be an R.A. Edit-capable JVC VCR. The recording deck can be...



- a VCR other than JVC, or
- a JVC VCR which has **neither** a Remote PAUSE nor an R.A. EDIT connector

## How to use:

- Connect the playback deck and RM-V704U/V700U as shown on the left.
- Set the RM-V704U/V700U to correspond to the brand of the recording deck. ( pg. 33)
- For Random Assemble Editing procedure, please refer to the instruction manual of the JVC VCR you are using as the playback deck.

## Notes:

- RM-V704U/V700U cannot be used to control the playback deck.
- RM-V704U/V700U is capable of controlling basic operations of the recording deck. While pressing VCR CTL, press PLAY, STOP, PAUSE, FF or REW for these functions. (Not possible with some brands and models). Other buttons cannot be used.
- To put the recording deck in the Record-Pause mode, use the controls on the recording deck itself.



RM-V704U or RM-V700U  
(optional)

The Full-Function Remote Control Unit can operate this camcorder from a distance as well as the basic operations (PLAY, STOP, PAUSE, FF, and REW) of your VCR. This remote control unit makes additional recording functions possible.

## Installing The Battery

### 1 PULL OUT BATTERY HOLDER

Pull out the battery holder according to the type of remote control unit you have.

Type ① : Pull out the battery holder while sliding the lock hole.

Type ② : Pinch the release tab and pull out the battery holder.

### 2 INSERT BATTERY


Making sure the plus (+) side is up, insert the lithium battery (CR2025)\* into the battery holder.

### 3 REPLACE BATTERY HOLDER

Insert the battery holder into the remote control unit, and push the holder until it clicks into place.


\* Read the caution concerning lithium batteries (☞ pg. 2).

| BUTTONS                             | FUNCTIONS   |  |
|-------------------------------------|---|--|
|                                     | With the camcorder's power switch set to "CAMERA".                  | With the camcorder's power switch set to "PLAY". |
| ① PAUSE IN Connector                | —   | ☞ pg. 34   |
| ② Infrared beam transmitting window | Transmits the beam signal.  |  |
| ③ MBR SET Button                    | —   | ☞ pg. 33   |
| ④ INT. TIME Button                  | Self-Timer/Time-Lapse (☞ pg. 37)                                    | —  |
| ⑤ REC TIME Button                   | Animation/Time-Lapse (☞ pg. 37)                                     | —  |
| ⑥ FF Button                         | Retake (forward) (☞ pg. 12)   | FF/FF Shuttle Search (☞ pg. 30)                  |
| ⑦ REW Button                        | Retake (rewind)/Quick Review (☞ pg. 12)                             | Rew/Rew Shuttle Search (☞ pg. 30)                |
| ⑧ PAUSE Button                      | —   | Pause (☞ pg. 30)                                 |
| ⑨ PLAY Button                       | —   | Playback start (☞ pg. 30)                        |
| ⑩ START/STOP Button                 | Functions same as the Recording Start/Stop button on the camcorder. |  |
| ⑪ VISS Button                       | Index Code marking (☞ pg. 37)                                       | —  |
| ⑫ ZOOM (T/W) Buttons                | Zoom in and out (☞ pg. 11)  | —  |
| ⑬ VCR CTL Button                    | —   | ☞ pg. 33   |
| ⑭ A.DUB Button                      | —   | Audio dubbing (☞ pg. 39)                         |
| ⑮ STOP Button                       | —   | Stop (☞ pg. 30)                                  |
| ⑯ INSERT Button                     | —   | Insert Editing (☞ pg. 38)                        |
| ⑰ R.A.EDIT Buttons                  | —   | ☞ pg. 34   |





When using the remote control, be sure to point it at the remote sensor. The above illustration shows the approximate transmitted beam effective area for indoor use. The transmitted beam may not be effective or may cause incorrect operation outdoors or when the remote sensor is directly exposed to sunlight or powerful lighting.

**Interval Timer Indicator**



**Rec Time Indicator**



RM-V704U or RM-V700U (optional)

**FEATURE:**  
**PURPOSE:**

**OPERATION:**

**Self-Timer, Animation and Time-Lapse**

The remote control lets you set/release Interval Timer and Rec Time functions as well as the Menu screen.

**Self-Timer**

**1) Set**

Instead of performing steps 1 through 3 on pg. 26 ("Self-Timer"), press **INT. TIME** on the remote control. Each time **INT. TIME** is pressed, the Interval Timer indicator appears, changing in the following order: 15s, 30s, 1min, 5min and No indication (off).

**2) Release**

Instead of setting "Interval Timer" to "OFF" in the Menu, press **INT. TIME** on the remote control until the Interval Timer indicator disappears.

**Animation**

**1) Set**

Instead of performing steps 1 and 2 on pg. 27 ("Animation"), press **REC TIME** on the remote control. Each time **REC TIME** is pressed, the Rec Time indicator appears, changing in the following order: 1/4s, 1/2s, 1s, 5s and No indication (off).

**2) Release**

Instead of using the Menu in step 5 on pg. 27, press **REC TIME** on the remote control until the Rec Time indicator disappears.

**Time-Lapse**

**1) Set**

Instead of performing steps 1 through 3 on pg. 27 ("Time-Lapse"), press **INT. TIME** and **REC TIME** on the remote control. Each time **INT. TIME** is pressed, the Interval Timer indicator appears, changing in the following order: 15s, 30s, 1min, 5min and No indication (off). Each time **REC TIME** is pressed, the Rec Time indicator appears, changing in the following order: 1/4s, 1/2s, 1s, 5s and No indication (off).

**2) Release**

Instead of using the Menu in step 5 on pg. 27, press **INT. TIME** and **REC TIME** on the remote control until the indicators disappear.

**NOTE:**

Also refer to pgs. 26 and 27.

**FEATURE:**  
**PURPOSE:**

**OPERATION:**




**NOTE:**

**Index Code Marking**

To give you automatic access to any selected point on a recording.

1) Press **VISS** once to place the index code. "INDEX" blinks in the viewfinder during marking.

If **VISS** is pressed during Record-Standby mode, the mark is placed where **RECORDING START/STOP** is pressed.



RM-V704U or RM-V700U  
(optional)

## Insert Editing

You can record a new scene into a previously recorded tape, replacing a section of the original recording with minimal picture distortion at the in- and out-points. The original audio remains unchanged.

### NOTE:

Use the RM-V704U or RM-V700U remote control unit to perform this procedure.

## SELECT MODE

- 1 Set the Power switch to "PLAY".

## FIND EDIT-OUT POINT

- 2 Play back the tape, locate the point and press **PAUSE** on the camcorder or the remote control.

## RESET COUNTER

- 3 Press and hold **COUNTER R/M** for more than 2 seconds to reset the tape counter, then press for less than 1 second and make sure "M" appears in the viewfinder.

## FIND EDIT-IN POINT

- 4 Press **REW** to go a little beyond the beginning of the scene you want to replace, press **PLAY** to view the recorded tape, and press **PAUSE** at exactly at the point where the new scene should start.

## ENGAGE INSERT EDITING MODE

- 5 Press and hold **INSERT**, and without releasing **INSERT**, press and release **PAUSE**. The Insert mode is engaged. When the scene the camcorder is aimed at appears on the screen, go to the next step.

## BEGIN INSERT EDITING


- 6 Press **RECORDING START/STOP**. When the counter reaches "0:00:00", editing stops automatically and the camcorder enters the Insert-Pause mode.

## END INSERT EDITING

- 7 Press **STOP**.

### NOTES:

- After step 5, Retake (pg. 12) can be performed.
- The tape may stop slightly before or after the designated end point, and noise bars may appear. Neither indicates a defect in the unit.
- Only video signal is recorded in the Insert Editing mode.



RM-V704U or RM-V700U  
(optional)

## Audio Dubbing

You can record a new soundtrack on a prerecorded tape (normal audio only).

\*\* Perform steps 1, 2 and 3 of the Insert Editing procedure (pg. 38) before continuing.

- The sound comes from the built-in mike (or an external mike if connected).

### FIND EDIT-IN POINT

- 1 Press **REW** to go a little beyond the beginning of the scene onto which you want to dub new audio, press **PLAY** to view the recorded tape, then press **PAUSE** at exactly the point where dubbing should start.

### ENGAGE AUDIO DUB STANDBY MODE

- 2 Press and hold **A. DUB**, and without releasing **A. DUB**, press and release **PAUSE**.

### BEGIN AUDIO DUBBING

- 3 Press **PLAY**. When the counter reaches "0:00:00", Audio Dubbing stops automatically and the camcorder enters the Audio Dub-Standby mode.

### END AUDIO DUBBING

- 4 Press **STOP**.

## NOTES:

- Do not press **FF** or **REW** during Audio Dub-Standby, or the edit points will not be accurate.
- If the mike is too close to the TV, or if the TV's volume is too high, whistling or howling may occur.

## NOTES (for Insert Editing and Audio Dubbing):


- Insert Editing and audio Dubbing may not work correctly if the tape contains blank segments, or if the recording speed was changed during the original recording.
- To edit/dub onto a tape with the recording safety tab removed, cover the hole with adhesive tape.
- Do not press **STOP** during Insert Editing or Audio Dubbing, or the edit points will not be accurate.
- During Insert Editing and Audio Dubbing, when Insert-Pause or Audio Dub-Standby is engaged, the counter may go slightly past "0:00:00". Recording, however, stops at exactly 0:00:00.

| SYMPTOM   | POSSIBLE CAUSE(S)  |
|---|--|
| <b>POWER</b>  |  |
| No power is supplied.   | <ul style="list-style-type: none"> <li>● The battery pack has not been attached correctly (☞ pg. 4).</li> <li>● The battery pack is not charged (☞ pg. 4).</li> <li>● The power supply has not been correctly connected (☞ pg. 5).</li> </ul>  |
| The power suddenly goes off and doesn't come back on by itself. | <ul style="list-style-type: none"> <li>● The battery pack has completely discharged.</li> <li>● Remove the cassette and disconnect the power source, then after a few minutes, try turning the power back on. If it still doesn't come on, consult your nearest JVC dealer.</li> </ul> |
| <b>RECORDING</b>  |  |
| Recording cannot be performed.                                  | <ul style="list-style-type: none"> <li>● The recording tape's Erase Protection tab is missing. Cover the hole with adhesive tape. (Some tapes have sliding tabs. In this case, check the position of the tab.)</li> </ul>  |
| Recording does not start.                                       | <ul style="list-style-type: none"> <li>● The camcorder Power switch has not been set to "CAMERA" (☞ pg. 10).</li> </ul>  |
| <b>PLAYBACK</b>   |  |
| The tape is running, but there's no playback picture.           | <ul style="list-style-type: none"> <li>● The TV has not been set to its VIDEO mode.</li> <li>● If A/V connection is used, the TV's VIDEO/TV switch has not been set to VIDEO.</li> <li>● The RF unit has not been set to the correct channel.</li> </ul>                               |
| Noise bars appear in the playback picture.                      | <ul style="list-style-type: none"> <li>● Manual Tracking has not been performed (☞ pg. 31).</li> </ul>   |
| Playback picture is blurred or interrupted.                     | <ul style="list-style-type: none"> <li>● The video heads are dirty or worn out. Consult your nearest JVC dealer for head cleaning or replacement.</li> </ul>   |
| The counter indication is blurred during Still playback.        | <ul style="list-style-type: none"> <li>● This is normal.</li> </ul>  |
| <b>TAPE TRANSPORT</b>   |  |
| The tape stops during fast-forward or rewind.                   | <ul style="list-style-type: none"> <li>● The Counter Memory Function has been activated (☞ pg. 31).</li> </ul>   |
| Rewinding or fast-forwarding cannot be performed.               | <ul style="list-style-type: none"> <li>● The tape is already fully wound on one reel or the other.</li> </ul>  |






| SYMPTOM  | POSSIBLE CAUSE(S)  |
|--|--|
| <b>OTHER</b>   |  |
| <b>The tape won't eject.</b>   | <ul style="list-style-type: none"> <li>● The battery pack is running low.</li> </ul>   |
| <b>Some functions are not available.</b>   | <ul style="list-style-type: none"> <li>● The PROGRAM AE select dial is set to "AUTO LOCK".</li> </ul>  |
| <b>Vertical white lines appear when shooting a very bright object.</b>                           | <ul style="list-style-type: none"> <li>● This sometimes occurs when the contrast between the background and the object is great. It is not a defect of the camcorder.</li> </ul>   |
| <b>Bright, crystal-shaped spots appear in the viewfinder.</b>                                    | <ul style="list-style-type: none"> <li>● Sunlight is directly entering the lens.</li> </ul>  |
| <b>An error number (i.e. E03) appears in the viewfinder.</b>                                     | <ul style="list-style-type: none"> <li>● Turn the camcorder's power off, then disconnect the power source. After a few minutes, try turning the power on again. If the error number still appears in the viewfinder, consult your nearest JVC dealer.</li> </ul> |
| <b>The image is out of focus.</b>  | <ul style="list-style-type: none"> <li>● The diopter needs to be adjusted (☞ pg. 6).</li> <li>● The scene being shot is adversely affecting the operation of Auto Focus (☞ pg. 16).</li> </ul>   |
| <b>A character generator title and the date and time displays disappear from the viewfinder.</b> | <ul style="list-style-type: none"> <li>● If you remove the power source from the camcorder while the power is on, all settings and selections are erased. Make sure to turn the camcorder's power off before disconnecting the power source.</li> </ul>          |
| <b>The wrong date and time are displayed/recorded.</b>   | <ul style="list-style-type: none"> <li>● If you have not performed Date/Time Setting (☞ pg. 7), the date and time are not displayed/recorded correctly. Be sure that Date/Time setting is carried out.</li> </ul>  |
| <b>Even though the Lens Cover is open, the Lens Cover Warning indicator blinks.</b>              | <ul style="list-style-type: none"> <li>● The Lens Cover Warning indicator may blink when the camcorder is used in dark areas, regardless of the position of the Lens Cover.</li> </ul>   |

The camcorder is a microcomputer-controlled device. External noise and interference (from a TV, a radio, etc.) might prevent it from functioning properly. In such cases, first disconnect its power supply unit (battery pack, AC Power Adapter/Battery Charger, etc.) and clock battery; and then re-connect it and proceed as usual from the beginning.



## Controls

- |  |            |  |        |
|--|------------|--|--------|
| ① Diopter Adjustment .....                       | pg. 6      | ⑩ REW Button .....                     | pg. 30 |
| ② QUICK REC Button .....                         | pg. 13     | ⑪ RETAKE R [Quick Review] Button ..... | pg. 12 |
| ③ Power Zoom Lever .....                         | pg. 11     | ⑫ FF Button .....                      | pg. 30 |
| ④ BATT. [Battery] RELEASE Switch .....           | pg. 4      | ⑬ RETAKE F Button .....                | pg. 12 |
| ⑤ Recording Start/Stop Button .....              | pg. 10     | ⑭ PLAY/PAUSE Button .....              | pg. 30 |
| ⑥ POWER Switch .....                             | pg. 10, 30 | ⑮ SELECT Button .....                  | pg. 19 |
| ⑦ STOP Button .....                              | pg. 30     | ⑯ SET Button .....                     | pg. 19 |
| ⑧ Tape Length [T30•45•60]<br>Select Button ..... | pg. 8      | ⑰ P. [Picture] STABILIZER Button ..... | pg. 18 |
| COUNTER R [Reset]/M [Memory]<br>Button .....     | pg. 31     | ⑱ MENU Button .....                    | pg. 24 |
| ⑨ EDIT Button .....                              | pg. 35     | ⑳ PROGRAM AE Select Dial .....         | pg. 14 |
| ⑩ R.A.EDIT CANCEL Button .....                   | pg. 34     | ㉑ Multi-Function Control               |        |
| ⑪ R.A.EDIT Button .....                          | pg. 34     | • Exposure +/- .....                   | pg. 18 |
| ⑫ R.A.EDIT IN/OUT Button .....                   | pg. 34     | • Focus FAR/NEAR .....                 | pg. 16 |
|  |            | • Menu Setting Change .....            | pg. 24 |
|  |            | • Tracking +/- .....                   | pg. 31 |
|  |            | ㉒ PUSH Button .....                    | pg. 8  |
|  |            | ㉓ EJECT Switch .....                   | pg. 8  |



## Connectors


- 24** J terminal (JLIP (Joint Level Interface Protocol) Connector.)  
(Located beneath the jack cover)
- Connect the Editing Cable when performing Random Assemble Editing (☞ pg. 34).
  - It is used to connect the camcorder to a device such as a personal computer.
- For further detail consult your nearest JVC dealer. Information (in English) is also available at our home page: <http://www.jvc-victor.co.jp/>
- 25** External MIC jack (capped) ..... ☞ pg. 39
- 26** DC IN Jack ..... ☞ pg. 5
- The jacks **27** to **29** are located beneath the jack cover.
- 27** VIDEO OUT Jack ..... ☞ pg. 29
- 28** RF DC OUT Jack ..... ☞ pg. 29
- 29** AUDIO OUT Jack ..... ☞ pg. 29

## Indicators

- 30** Tally Lamp ..... ☞ pg. 10
- 31** Power On Indicator ..... ☞ pg. 10

## Other Parts

- 32** • Camera sensor  
Be careful not to cover this area; built-in here is the sensor necessary for shooting.
- Remote sensor ..... ☞ pg. 37
- 33** Microphone ..... ☞ pg. 39
- 34** Shoulder Strap Eyelets ..... ☞ pg. 9
- 35** Clock Battery Compartment ..... ☞ pg. 6
- 36** Battery Pack Mount ..... ☞ pg. 4
- 37** Electronic Viewfinder ..... ☞ pg. 6
- 38** LENS COVER Switch ..... ☞ pg. 10
- 39** Grip Strap ..... ☞ pg. 9
- 40** Tripod Mounting Socket ..... ☞ pg. 9



## Viewfinder Indications

- ① **Cassette Warning/Remaining Tape Time** ..... pg. 10  
When no cassette is inserted: the Cassette ( ) Warning blinks.  
When Erase Protection tab is not in the position that allows recording: the Cassette ( ) Warning lights. Otherwise, the Remaining Tape Time is displayed.
- ②, ⑦ **PROGRAM AE Indicator** ..... pg. 14  
Displayed at ② for approx. 1 second when the PROGRAM AE select dial is switched from one position to another. Then only the indicator remains at ⑦.
- ②, ⑧ **Fade/Wipe Standby Indicator** ..... pg. 19  
Displayed at ② for approx. 2 seconds when the Fade/Wipe is switched from one function to another by pressing the SET button. Then only the indicator remains at ③.
- ③ **Program Manager Function Indication** ... pg. 19  
Appears when the PROGRAM AE select dial is set to any position other than AUTO LOCK.
- ④ **Tape Length Display** ..... pg. 8
- ⑤ **Zoom Indicator bar** ..... pg. 11
- ⑥ **Recording Indicator** ..... pg. 10
- ⑨ **Picture Stabilizer Indicator** ..... pg. 18
- ⑩ **Interval Time/Recording Time Indicator** ..... pg. 26
- ⑪ • **Record-Standby Mode Indicator** ..... pg. 10  
• **Lens Cover Warning: LENS COVER ..** pg. 10
- ⑫ **Instant Title Display** ..... pg. 20
- ⑬ **Date/Time Character Display** ..... pg. 22
- ⑭ **Battery Pack Remaining Power Indicator**  
Changes as follows according to the battery pack's remaining power level: " " .  
When the power is almost gone, the indicator blinks, then the unit shuts off. Replace the battery pack with a fully charged one.  
(**Note:** The symbol containing 3 darkened squares — — does not necessarily mean that the battery pack is fully charged.)
- ⑮ **Focus Indicator** ..... pg. 16
- ⑯ **Exposure Level Indicator** ..... pg. 18
- ⑰ **White Balance Mode Indicator** ..... pg. 23
- ⑱ **Menu Setting Change Indicator** ..... pg. 24
- ⑲ **Index Code Marking** ..... pg. 37
- ⑳ **Clock Warning**  
Once the power is turned on and the indicator blinks for about 10 seconds, perform the date and time settings ( pg. 7 ). After setting is complete, turn the power off and disconnect the power source. If you re-connect it and turn the power on and the indicator is blinking, that means that the clock (lithium) battery is either not installed or has discharged. Install, or replace the old battery with, a new one ( pg. 6 ).
- ㉑ • **Tape End Display: TAPE END** ..... pg. 10  
Appears when the end of the tape is reached during playback, recording or fast-forward.  
• **Condensation Warning:**   
When this indication appears, all functions are disabled. Turn the unit off (without removing the power source) for a few hours, and when you turn it on again the indicator should disappear.

## General Battery Precautions


- When the C-P6U or C-P7U (cassette adapter) is not functioning even when correctly operated, the batteries are exhausted. Replace them with fresh ones.
- Use only the following batteries:  
C-P6U or C-P7U ..... R6 (AA) size

Please make note of the following rules for battery use. When misused, batteries can leak or explode.

1. Refer to the instructions when replacing the battery.
2. **Do not** expose batteries to excessive heat as they can leak or explode.
3. **Do not** dispose of batteries in a fire.
4. Remove batteries from the unit if it is to be stored for an extended period to avoid battery leakage which can cause malfunctions.

## Battery Packs

The supplied battery pack is a nickel-cadmium battery. Before using the supplied battery pack or an optional battery pack, be sure to read the following cautions:



Terminals

1. **To avoid hazard . . .**
  - .... **do not** burn.
  - .... **do not** short-circuit the terminals.
  - .... **do not** modify or disassemble.
  - .... use only specified chargers.
2. **To prevent damage and prolong service life . . .**
  - .... **do not** subject to unnecessary shock.
  - .... avoid repeated charging without fully discharging.
  - .... charge in an environment where temperatures are within the tolerances shown in the chart below. This is a chemical reaction type battery—cooler temperatures impede chemical reaction, while warmer temperatures can prevent complete charging.
  - .... store in a cool, dry place. Extended exposure to high temperatures will increase natural discharge and shorten service life.
  - .... avoid prolonged uncharged storage.
  - .... remove from charger or powered unit when not in use, as some machines use current even when switched off.

3. **To prevent damage to the camcorder . . .**
  - .... replace the battery pack when it begins to deliver less recording time per charge.

### NOTE:

*It is normal for the battery pack to be warm after charging, or after use.*

#### Temperature Ranges

|                 |               |
|-----------------|---------------|
| Charging .....  | 10°C to 35°C  |
| Operation ..... | 0°C to 40°C   |
| Storage .....   | -10°C to 30°C |

### NOTES:

- *Recharging time is based on room temperature of 20°C.*
- *The lower the temperature, the longer recharging takes.*

## Cassettes

To properly use and store your cassettes, be sure to read the following cautions:

### 1. During use . . .

- .... make sure the cassette bears the VHS-C mark.
- .... be aware that recording onto prerecorded tapes automatically erases the previously recorded video and audio signals.
- .... make sure the cassette is positioned properly when inserting.
- .... do not load and unload the cassette repeatedly without allowing the tape to run at all. This slackens the tape and can result in damage.
- .... do not open the front tape cover. This exposes the tape to fingerprints and dust.

### 2. Store cassettes . . .

- .... away from heaters or other heat sources.
- .... out of direct sunlight.
- .... where they won't be subject to unnecessary shock or vibration.
- .... where they won't be exposed to strong magnetic fields (such as those generated by motors, transformers or magnets).
- .... vertically, in their original cases.

## Main Unit

### 1. For safety, DO NOT . . .

- .... open the camcorder's chassis.
- .... disassemble or modify the unit.
- .... short-circuit the terminals of the battery pack. Keep it away from metallic objects when not in use.
- .... allow inflammables, water or metallic objects to enter the unit.
- .... remove the battery pack or disconnect the power supply while the power is on.
- .... leave the battery pack attached when the camcorder is not in use.

### 2. Avoid using the unit . . .

- .... in places subject to excessive humidity or dust.
- .... in places subject to soot or steam such as near a cooking stove.
- .... in places subject to excessive shock or vibration.
- .... near a television set.
- .... near appliances generating strong magnetic or electric fields (speakers, broadcasting antennas, etc.).
- .... in places subject to extremely high (over 40°C) or extremely low (under 0°C) temperatures.

### 3. DO NOT leave the unit . . .

- .... in places of over 50°C.
- .... in places where humidity is extremely low (below 35%) or extremely high (above 80%).
- .... in direct sunlight.
- .... in a closed car in summer.
- .... near a heater.

### 4. To protect the unit, DO NOT . . .

- .... allow it to become wet.
- .... drop the unit or strike it against hard objects.
- .... subject it to shock or excessive vibration during transportation.
- .... keep the lens directed at extremely bright objects for long periods.
- .... direct the eyepiece of the viewfinder at the sun.
- .... carry it by holding the viewfinder.
- .... swing it excessively when using the shoulder strap.

### 5. This camcorder features a built-in head cleaner which automatically cleans the heads and head drum when a cassette is loaded or unloaded. If, however, the heads become dirty and cause blurriness or interruption in the playback picture, consult your nearest JVC dealer.

### About moisture condensation . . .

- You have observed that pouring a cold liquid into a glass will cause drops of water to form on the glass' outer surface. This same phenomenon occurs on the head drum of a camcorder when it is moved from a cool place to a warm place, after heating a cold room, under extremely humid conditions or in a place directly subjected to the cool air from an air conditioner.
- Moisture on the head drum can cause severe damage to the video tape, and can lead to internal damage to the camcorder itself.

### Serious malfunctioning

If malfunctioning occurs, stop using the unit immediately and consult your local JVC dealer.

## For Your Maintenance

### 1. After Use

- ① Set the power switch to POWER OFF to turn off the camcorder.
- ② Slide EJECT to open the cassette holder, then remove the cassette.
- ③ Close and lock the cassette holder by pressing PUSH.
- ④ Press BATT. RELEASE to remove the battery pack.
- ⑤ Slide the LENS COVER open/close switch to close the lens cover.


### 2. Cleaning The Camcorder

- ① **CLEAN EXTERIOR**  
Wipe gently with a soft cloth.
- ② **CLEAN LENS**  
Blow it with a blower brush, then wipe gently with lens cleaning paper.
- ③ **REMOVE EYEPIECE**  
Turn the eyepiece counterclockwise and pull it out.
- ④ **CLEAN VIEWFINDER**  
Remove dust using a blower brush.
- ⑤ **RE-ATTACH EYEPIECE**  
Align the marks, re-attach the eyepiece and turn it clockwise.

### NOTES:

- Avoid using strong cleaning agents such as benzine or alcohol.
- Cleaning should be done only after the battery pack has been removed or other power units have been disconnected.
- Mold may form if the lens is left dirty.

## GENERAL

|                        |  |
|------------------------|--|
| Format                 | : VHS PAL standard   |
| Power source           | : DC 6 V  |
| Power consumption      | : 5.7 W  |
| Signal system          | : PAL-type   |
| Video recording system |  |
| Luminance              | : FM recording   |
| Colour                 | : Converted sub-carrier direct recording<br>Conforms to VHS standard                       |
| Cassette               | : <b>VHS</b> cassette  |
| Tape speed             | : 23.39 mm/sec   |
| Recording time         |  |
| Max.                   | : 60 minutes<br>(with EC-60 cassette)  |
| Operating temperature  | : 0°C to +40°C   |
| Operating humidity     | : 35% to 80%   |
| Storage temperature    | : -20°C to +50°C   |
| Weight                 | : Approx. 825 g  |
| Dimensions             | : 112 (W) x 112 (H) x 229 (D) mm   |

## CAMERA

|                          |  |
|--------------------------|--|
| Pick up                  | : 1/4" format CCD  |
| Lens                     | : F1.6, f = 3.8 to 68.4 mm, 18:1 power zoom lens with auto iris and macro control, filter diameter 46 mm |
| Viewfinder               | : Electronic viewfinder with 0.5" B/W CRT  |
| White balance adjustment | : Auto/Manual adjustment   |



## VIDEO

|        |   |
|--------|---|
| Output | : 1 Vp-p, 75 ohms, unbalanced (via VIDEO out connector) |
|--------|---|

## AUDIO

|                           |   |
|---------------------------|---|
| Output                    | : -8 dBs, 1 k-ohm (via AUDIO out connector)               |
| External microphone input | : -68 dBs, high impedance, unbalanced with ø3.5 mm (MONO) |

## AC POWER ADAPTER/BATTERY CHARGER (AA-V11EG)

|                   |   |
|-------------------|---|
| Power requirement | : AC 110 to 240 V~, 50/60 Hz  |
| Power consumption | : 23 W  |
| Output            | : DC 8.5 V  , 1.3 A (CHARGE), DC 6.3 V  , 1.8 A (VTR) |
| Charging system   | : Constant current, peak detection, timer controlled  |
| Dimensions        | : 150 (W) x 42 (H) x 68 (D) mm  |
| Weight            | : Approx. 350 g   |

## CASSETTE ADAPTER (C-P7U)

|            |                                 |
|------------|---------------------------------|
| Dimensions | : 188 (W) x 25 (H) x 104 (D) mm |
| Weight     | : Approx. 240 g                 |
| Accessory  | : "R6 (AA)"-size battery x 1    |

## Provided Accessories ..... pg. 3

## Optional Accessories

- **Battery Packs BN-V12U, BN-V22U, BN-V25U**
- **Car Battery Charger BH-V3E**
- **RF Unit RF-V5E**
- **Compact VHS-C Cassettes EC-60/45/30**
- **Active Carrying Bag CB-V7U**
- **Wireless Remote Control Unit RM-V704U or RM-V700U**

Some accessories are not available in some areas. Please consult your nearest JVC dealer for details on accessories and their availability.

*E.&O.E. Design and specifications subject to change without notice.*

EN

GR-AX670

**JVC**  
VICTOR COMPANY OF JAPAN, LIMITED