

KENWOOD
sovereign

Connection and Setup Guide

How to Connect And Setup Your

Entré

Entertainment Hub

Connecting and Setting Up Your New Kenwood Sovereign Entré

Welcome to the Connection and Setup Guide for your new Kenwood Sovereign Entré. With Entré, you can enjoy traditional media, like FM/AM radio, CDs, and movies, alongside exciting new media, such as MP3s and Internet radio. Entré allows you to control, organize and enjoy your collections from one easy-to-navigate interface.

Use this guide to connect all your current audio and video components— Entré has a variety of connection jacks so you can customize your entertainment setup.

Many of Entré's features require Entré to be connected to the Internet, a Kenwood Sovereign DVD/CD changer, Kenwood CD changer with CDDDB capability, and/or a Kenwood Sovereign Receiver. Features requiring external products or services are noted throughout the manual.

Entré is a dynamic product. Software updates will allow Kenwood and OpenGlobe to provide new functions and capabilities. Refer to the Kenwood USA website at www.kenwoodusa.com for the latest information regarding your new Entré.

OpenGlobe, the OpenGlobe logo, CE-Commerce and entertain simplicity are trademarks of OpenGlobe, Inc.




CDDDB is a registered trademark and GraceNote is a trademark of CDDDB, Inc. (dba GraceNote)

All other trademarks are property of their registered owners.


Unpacking

Unpack your new Entré carefully and make sure that all of the accessories are present:


1 mono mini jack cable




1 RS232C cable




1 telephone cable




1 S-Video cable




Remote control



2 stereo audio cables



2 digital optical cables



batteries



If any accessories are missing, or if the Entré is damaged or fails to operate, notify your dealer immediately. If your Entré was shipped to you directly, notify your shipper immediately. Kenwood recommends that you retain the original carton and packing materials in case you need to move or ship the Entré in the future.

Before Applying Power

Read this section carefully to ensure safe operation.

Kenwood Sovereign Entré is designed for operation on AC 120 V only. Entré must be connected to a 120V AC outlet that supplies constant voltage. Do not

use an outlet controlled by a switch, or the switched power outlet on your Entré or other audio component.

Safety Precautions


Read this section carefully to ensure safe operation.



Prevent electric shock:

- Do not expose your Entré to rain or moisture.
- Do not remove the cover (or back). There are no user serviceable parts inside. If your Entré requires repair, take it to an authorized service outlet.

The following icons indicate the presence of uninsulated dangerous voltage that may be of sufficient magnitude to cause electric shock:



Internet Connection

Many of Entré's capabilities, including downloading CD information, connecting to Internet radio stations, or automatic software updates, require a specific type of Internet connection.

You *must* have a third-party Internet service provider (ISP) to access those features.



Because free ISPs, AOL, and CompuServe do not use standard methods of Internet connectivity, and do not open their networks to outside users, you can not use these ISPs with Entré.



To obtain an ISP via OpenGlobe, begin the Quick Start Setup process (see "How Do I Power-Up Entré for the Very First Time?" on page 19) and call the toll-free number given to you during the process.

How Do I Reset Entré?

If Entré fails to respond to front panel or remote commands or if it responds erroneously, use the following procedure to reset it:

- Hold the **POWER** button down until the Standby Indicator begins to flash on and off. Then release the **POWER** button.
- When the Standby Indicator stops flashing and is lit constantly, push the **POWER** button to turn Entré on.

Table of Contents

Connecting and Setting Up Your New Kenwood Sovereign Entré	iii
Unpacking.....	iii
Before Applying Power.....	iv
Safety Precautions	iv
Internet Connection	iv
How Do I Reset Entré?	iv
Chapter 1: Setting Up and Configuring Your Entré	1
How Do I Connect to My TV?	2
Watching TV without Turning on Entré	3
How Do I Connect to My Receiver or Amplifier?	4
Connecting a Kenwood Sovereign Receiver	5
Connecting Any Other Primary Receiver.....	5
How Do I Connect to My Kenwood Sovereign DVD or CD Changer?.....	6
How Do I Connect to My Kenwood Sovereign DVD Changer and a Non-Kenwood Receiver?	8
Connecting a Non-Kenwood Receiver to Entré	9
Connecting a Kenwood Sovereign DVD Changer to Entré.....	9
Connecting a Non-Kenwood Receiver to a Kenwood Sovereign DVD Changer.....	9
How Do I Set Up My Remote?	10
Loading Batteries.....	10
Entering Product Codes	10
Finding Unlisted Product Codes.....	11
Using Picture within a Picture.....	11
Swapping the Picture within a Picture.....	11

Selecting an Alternate Audio Source	11
Selecting an Alternate Video Source	11
How Do I Program My Kenwood LCD Remote for Entré?	12
Identifying the Remote's TV2 Input as the Entré Input	13
Teaching the Entré Remote Button Functions into the Receiver Remote	14
Using the Receiver Remote to Control Entré	16
How Do I Connect My Entré to the Internet?.....	17
Finding Supported Internet Service Providers.....	17
How Do I Power-Up Entré for the Very First Time?.....	19
How Do I Configure Internet Setup?.....	20
Continuing Quick Start with a Dialup Modem	22
Continuing Quick Start with a HomePNA Connection	23
Continuing Quick Start with an Ethernet Connection	25
How Do I Configure Entré's Setup Menus?	28
Entering User Information.....	28
Entering Internet Configuration Information.....	28
Entering Preferences.....	28
Entering Audio and Video Settings.....	28
Entering Changer Management Information.....	28
Entering Security and Parental Controls	29
Entering Utilities Information	29
Appendix A: Program Codes	31
Setup Codes for Cable Converters	31
Setup Codes for Satellite Receivers	32
Setup Codes for TVs	33

Table of Contents

Appendix B: Specifications	37
Audio	37
Video	37
Drive	37
Dimensions and Weight	37
Index	39

Chapter 1: Setting Up and Configuring Your Entré


To enjoy your Entré you will need to connect it to your existing home entertainment system. Making the proper connections ensures you can fully integrate Entré with the other components of your existing entertainment system. Entré enhances your ability to enjoy media through the Internet as well as acting as a librarian for your existing media formats.

This chapter contains the following sections:

How Do I Connect to My TV?	page 2
How Do I Connect to My Receiver or Amplifier?	page 4
How Do I Connect to My Kenwood Sovereign DVD or CD Changer?	page 6
How Do I Set Up My Remote?	page 10
How Do I Program My Kenwood LCD Remote for Entré?	page 12
How Do I Connect My Entré to the Internet?	page 17
How Do I Power-Up Entré for the Very First Time?	page 19
How Do I Configure Internet Setup?	page 20
How Do I Configure Entré's Setup Menus?	page 28

How Do I Connect to My TV?

How Do I Connect to My TV?



How Do I Connect to My TV?, continued

Connect a video cable from Entré's Video Output jack to your TV's Video IN jack shown above.

Before making any video connections to the TV you must choose the type of connection you will use:


- Component video connections provide the best video quality; S-Video connections provide video quality that is superior to standard composite video connections.
- If your A/V receiver is a Kenwood model with Universal Video™ or Universal Video™ HD, connect Entré to the TV using the highest quality connection type possible, and connect your receiver to Entré using that same type of connection. See your receiver's Setup and Connection Guide for more information about connecting video components to your receiver.
- If your A/V receiver is not a Kenwood model with Universal Video™ or Universal Video™ HD, connect Entré to the TV using the same type of video connection that is being used between the rest of your video components and your A/V receiver. (You must use the same type of connection for all of your video components.)
- If your TV does not have any video connections at all (it only has antenna connections), you must purchase an RF modulator that converts video signals into antenna signals to use your TV with Entré. You should be able to find an RF modulator at a store specializing in electronic parts.
- If you previously connected your TV directly to your VCR, you must now connect it through Entré.

Watching TV without Turning on Entré

The connection described here sets your TV up as a monitor you can use to view media played on your other video devices (such as a VCR or DVD player) via Entré. You can still watch TV without having to use Entré—simply turn on your TV as you normally do.

How Do I Connect to My Receiver or Amplifier?

How Do I Connect to My Receiver or Amplifier?



How Do I Connect to My Receiver or Amplifier?, continued

Do not plug in Entré or devices to AC power until you have connected all your devices.

This section focuses on the connections from your receiver to Entré. Please refer to your receiver's instructions for more detail about its connection jacks and capabilities.

Connecting a Kenwood Sovereign Receiver

Review the information under "Before making any video connections to the TV". It contains important notes about the types of connections you can make.

1. Connect one of the included optical digital cables from the receiver's OPTICAL DIGITAL Out jack to Entré's DIGITAL OPTICAL In jack and connect the other included optical digital cable from Entré's DIGITAL OPTICAL Out jack to the receiver's CD-R OPTICAL DIGITAL jack, as shown.



If you use the optical digital cable, be sure to remove the protective cover from the optical jack before connecting. Please retain the cover and store it in a safe place.

2. Connect the video cable from the receiver's MONITOR OUT jack to Entré's Video Input jack as shown. Use the same type of connection that you used between Entré and your TV (see pages 2-3).
3. Connect the included RS-232C cable from the receiver's RS-232C jack to Entré's RS-232C jack as shown.



The RS-232C cable included with Entré has female connectors at both ends. If you are substituting a commercially available RS-232C cable, make sure that it has female connectors on both ends.

4. Connect one stereo audio cable from the receiver's CD-R REC OUT jacks to Entré's ANALOG REC IN jacks. Connect another stereo audio cable from Entré's ANALOG PLAY OUT jacks to the receiver's CD-R PLAY IN jacks as shown.



If you don't use Entré's analog connections, you may not be able to record certain copy-protected media that can only be recorded using Entré's analog inputs.

Connecting Any Other Primary Receiver

1. Examine the receiver's available inputs and outputs. Select an input set for Entré that has an optical digital input, analog play (tape monitor) outputs, and analog record (tape monitor) inputs associated with it. Note which input you select: this will become the receiver's Entré input.
2. Connect a stereo audio cable from the receiver's TAPE MONITOR OUT (Rec) jacks to Entré's ANALOG REC IN jacks. Connect another stereo audio cable from Entré's ANALOG PLAY OUT jacks to the receiver's TAPE MONITOR IN (Play) jacks.
3. Connect a digital optical cable from Entré's DIGITAL OPTICAL OUT jack to the receiver's DIGITAL OPTICAL IN jack. If the receiver has a DIGITAL OUT jack, and depending on what type it is (either coaxial or optical), connect it to one of Entré's DIGITAL IN jacks.



If you use the optical digital cable, be sure to remove the protective cover from the optical jack before connecting. Please retain the cover and store in a safe place.


4. Connect a video cable from the receiver's video MONITOR OUT jack to Entré's VIDEO INPUT jack. Use the same type of connection that you used between Entré and your TV (see pages 2-3).



Do NOT plug Entré's power cord into the receiver's switched accessory outlet. Plug Entré's power cord only into a wall outlet that receives constant power.

How Do I Connect to My Kenwood Sovereign DVD or CD Changer?

How Do I Connect to My Kenwood Sovereign DVD or CD Changer?



How Do I Connect to My Kenwood Sovereign DVD or CD Changer?, continued

Entré can control the following Kenwood DVD and CD changers:

- DVD: DV-5900M, DV-5050M
- CD: CD-425M, CD-4700M

Do not plug in Entré or devices to AC power until you have connected all your devices.

Connect the included RS-232D cable from the DVD or CD changer's RS-232D jack to Entré's RS 232C to CD/DVD Changer jack as shown.



The RS-232C cable included with Entré has female connectors at both ends. If you are substituting a commercially available RS-232C cable, make sure that it has female connectors on both ends.

For all other connections between the DVD/CD changer and receiver/amplifier, refer to the instruction manuals for those components.




If you are using Entré with a Kenwood Sovereign DVD changer and a non-Kenwood Sovereign receiver, follow the connection instructions on pages 8–9.



If you are daisy-chaining more than one Kenwood Sovereign DVD changer, Entré will only control the changer in the chain designated 'Main', not those designated 'Sub 1' and 'Sub 2'.

How Do I Connect to My Kenwood Sovereign DVD Changer and a Non-Kenwood Receiver?

How Do I Connect to My Kenwood Sovereign DVD Changer and a Non-Kenwood Receiver?



How Do I Connect to My Kenwood Sovereign DVD Changer and a Non-Kenwood Receiver?, continued

Do not plug in Entré or devices to AC power until you have connected all your devices.

This section focuses on the connections from your Kenwood Sovereign DVD changer and a non-Kenwood receiver to Entré. Please refer to your receiver and DVD player's instructions for more detail about their connection jacks and capabilities.



Though the diagram on page 8 shows a DV-5900M DVD changer, you can connect a DV-5050M changer to Entré as well.

Connecting a Non-Kenwood Receiver to Entré

Review the information under "Before making any video connections to the TV". It contains important notes about the types of connections you can make.

1. Examine the receiver's available inputs and outputs. Select an input set for Entré that has an optical digital input, analog play (tape monitor) outputs, and analog record (tape monitor) inputs associated with it. Note which input you select: this will become the receiver's Entré input.
2. Connect one of the included optical digital cables from the receiver's OPTICAL DIGITAL Out jack to Entré's DIGITAL OPTICAL In jack and connect the other included optical digital cable from Entré's DIGITAL OPTICAL Out jack to the receiver input's OPTICAL DIGITAL jack, as shown.



Be sure to remove the protective cover from the optical jack before connecting. Please retain the cover and store it in a safe place.

3. Connect the video cable from the receiver's MONITOR OUT jack to the TV or Monitor's VIDEO IN jack as shown. Use the same type of connection that you use between Entré and the receiver.
4. Connect one stereo audio cable from the receiver's ANALOG RECORD OUTPUT jacks to Entré's ANALOG REC IN jacks, as shown. Connect another stereo audio cable from Entré's ANALOG PLAY OUT jacks to the receiver's ANALOG PLAY INPUT jacks, as shown.



If you don't use Entré's analog connections, you may not be able to record certain copy-protected media that can only be recorded using Entré's analog inputs.

5. Connect one video cable from the receiver's VIDEO INPUT to Entré's VIDEO OUTPUT, as shown.

Connecting a Kenwood Sovereign DVD Changer to Entré

1. Connect a digital audio cable from the changer's DIGITAL COAXIAL OUT jack to Entré's DIGITAL COAXIAL IN jack, as shown.
2. Connect a video cable from the changer's VIDEO OUTPUT jack to Entré's COMPOSITE VIDEO INPUT jack, as shown.
3. Connect the included RS-232C cable from the changer's RS-232 jack to Entré's RS-232 jack as shown.



Since the DVD player makes a digital connection to Entré, Entré must make additional digital input and output connections to the receiver. See step 2 in "Connecting a Non-Kenwood Receiver to Entré" on this page.

Connecting a Non-Kenwood Receiver to a Kenwood Sovereign DVD Changer

Connect three stereo audio cables from the receiver's 6-CHANNEL ANALOG INPUT to the DVD changer's 6-CHANNEL ANALOG OUTPUT as shown.




If you have a DV-5050M, connect one stereo audio cable from the DVD player's MIX LINE OUTPUT to the receiver's DVD analog input.

How Do I Set Up My Remote?

Loading Batteries


1. Remove the cover.
2. Insert two AA batteries as illustrated below:



3. Close the cover.

Entering Product Codes

The remote supplied with your Entré is programmed to work with a number of different brands of home entertainment devices such as TV, DSS, and cable boxes. The code listings in the “Appendix A: Program Codes” on page 31 show all available codes for different manufacturers.



To enter the correct product code:

1. Look up the brand name of the device you want the remote to work with.
2. Press the button for the device you wish to control (TV, DSS, or CBL (cable)), then press and hold the **CODE SETUP** button on the remote.



The LED on the top of the remote will blink twice, indicating the system is ready for you to enter a four-digit code.

3. Enter the appropriate code from the code listings, making sure the LED blinks once after every digit is entered.



Ensure the LED blinks twice after entering the last digit of the code. This tells you the code is valid for the device you selected. If the code you enter is incorrect, the LED will blink only once after the last digit.



If you enter an incorrect code, or pause 10 seconds while pressing the numeric buttons to enter the product code, the remote will automatically exit the code setup program. Press the **CODE SETUP** button again to start over.

Finding Unlisted Product Codes

If the code list does not list the brand of your unit, you can cycle through the available codes stored on your remote in order to locate a working code.

To cycle through the available codes:

1. Press the **CODE SETUP** button on the remote
2. Press the **9** button
3. Press the **9** button again
4. Press the **1** button

The remote will enter the first available code cycle for you to test. For example, if you want to enter a specific code for your TV but discover there are no codes listed for your TV, run through all the available codes to locate a code that is compatible with your TV. In order to select or test other codes:

1. Press the **CODE SETUP** button if your TV responds to the code cycle in order to program the code into the remote.
2. Press the **MODE** button (the TV button, if you are looking for a code for your TV) to advance to the next available code cycle if your TV fails to respond to inputs from the remote. Continue until you locate a code with the correct available functions for your TV.



If your device does not respond to any of the available codes, the Entré remote cannot be programmed to control it.

Using Picture within a Picture

While in the TV mode, press the PIP button to enable the Picture within a Picture feature available with some TVs. Please refer to your TV's instructions for more information about its capabilities.

Swapping the Picture within a Picture

Press the **PIP SWAP** button to swap the larger picture for the smaller one in the upper corner of the TV screen.

Selecting an Alternate Audio Source

While in the TV mode, press **ALT AUDIO** to switch to Second Audio Program (SAP).

Selecting an Alternate Video Source

Use the **INPUT SELECT** button to switch from Entré to broadcast TV, Cable, Satellite, or your VCR.

Press this button:	To view:
TV	Broadcast TV or VCR
CABLE	Cable TV
DSS	Satellite TV

How Do I Program My Kenwood LCD Remote for Entré?

How Do I Program My Kenwood LCD Remote for Entré?

You can use the remote included with your Kenwood Sovereign receiver to control Entré. If your receiver came with a PowerTouch® touch-screen controller, see page 18 of “How To Use and Enjoy Your Entré Entertainment Hub” for information.

If your receiver came with an LCD screen-learning remote, you need to program the remote to control Entré and teach the button commands from Entré’s remote into the receiver’s remote.


First you need to identify the LCD remote’s TV2 input as the one with Entré connected to it (CD-R). See “Identifying the Remote’s TV2 Input as the Entré Input” on page 13. Then you need to teach the button functions from the Entré remote into the receiver’s remote. See “Teaching the Entré Remote Button Functions into the Receiver Remote” on page 14.




For the best way to program your receiver remote so it maintains the functionality of the Entré remote, see “Using the Receiver Remote to Control Entré” on page 16.

Identifying the Remote's TV2 Input as the Entré Input


1. Press **TV**. The display will show:




2. Press **MENU**. The display will show:




3. Press **SETUP**. The display will show:




4. Press **ENTER**. The display will show:




5. Press **DOWN** repeatedly until the display shows:




6. Press **ENTER**. The display will show:



7. Press **DOWN** repeatedly until the display shows:



8. Press **ENTER**. The display will show:




How Do I Program My Kenwood LCD Remote for Entré?


9. Press **ENTER**. The display will show:



10. Press **ENTER**. The display will show:




11. Press **HOME**. The display will show:




Teaching the Entré Remote Button Functions into the Receiver Remote

1. Place the Entré remote and the receiver remote on a table “head-to-head”, about 4 inches apart:




2. Press the **TV** button on the receiver remote. The display will show:


(If the display does not show this, repeat the steps in “Identifying the Remote’s TV2 Input as the Entré Input” on page 13.)



3. Press the **LEARN** button on the receiver remote. The display will show:



4. Press the button on the receiver remote you want to learn the new function onto. The display will show:




How Do I Program My Kenwood LCD Remote for Entré?

5. Within 5 seconds, hold down the button on the Entré remote that you want to learn onto the receiver remote, until the receiver remote's display shows:





- If unsuccessful, the display will show:
Repeat steps 3-5.



6. Repeat steps 3-5 for each function button you want to learn onto the receiver remote.


To maintain similarity of function between the two remotes, we suggest that you learn Entré functions onto the receiver remote according to the following diagrams:



How Do I Program My Kenwood LCD Remote for Entré?

Using the Receiver Remote to Control Entré

1. Press the TV button on the receiver remote. The display will show:



2. Use the buttons you programmed on the receiver remote to control Entré.

How Do I Connect My Entré to the Internet?

Finding Supported Internet Service Providers

You must have a compatible third-party Internet Service Provider (ISP) in order to use Entré to access the Internet. Because free ISPs, AOL, and CompuServe do not use standard methods of Internet connectivity, and do not open their networks to outside users, you cannot use these ISPs with Entré. If you do not currently have a supported ISP, during the setup process you will be given a phone number to call to set up an account with a supported ISP, or you can establish an account on your own with a supported ISP.

There are three different ways to establish a connection to the Internet:

- If you have a dialup ISP, connect the Input phone line to the phone jack labeled “Wall” on the back of Entré.



You can plug a telephone into the phone jack labeled “Phone” on the back of Entré.




Use a minimum of No. 26 AWG wire for telephone cables.

- If you have either DSL or cable modem service, you will need to purchase an Ethernet adapter and connect Entré as shown below.



Entré supports the CATC NetMate Link (#U-ETH-NM02) Ethernet adapter, which is available from Kenwood via the Kenwood USA Web site at www.kenwoodusa.com. Go to the Kenwood Shop link to purchase an adapter, or check for an updated list of other supported adapters.




How Do I Connect My Entré to the Internet?

- If you have a HomePNA network, you will need to connect to Entré as shown below.



Use a minimum of No. 26 AWG wire for telephone cables.



How Do I Power-Up Entré for the Very First Time?

After you have made all of the connections described earlier, plug Entré's power cord directly into a wall outlet that receives constant power.



Do not plug Entré into a receiver's switched accessory outlet or other outlet that does not receive constant power.

After you plug Entré's power cord into the wall outlet, its Standby indicator will flash. Wait for the indicator to stop flashing. Once the Standby indicator remains constantly lit, press the Power button to turn Entré on.

How Do I Configure Internet Setup?

Entré accesses the Internet through OpenGlobe, using its built-in modem, or your external DSL or cable modem box. OpenGlobe provides easy access to Entré's Internet resources, such as disc information databases, Internet radio, and CE-commerce opportunities. Whenever Entré accesses the Internet for information or CE-commerce, it does so via the OpenGlobe portal, at no cost to you. By connecting to the Internet, you enable important features in Entré, such as playing Internet radio, downloading movie or music information, and accessing new Entré software updates.


When you turn on Entré for the first time, you must complete a Quick Start setup process.



As part of the set-up process, it will require approximately 15 minutes for Entré to download Internet and AM/FM radio information from the Internet. If Entré is connected to a compatible Kenwood Sovereign DVD or CD changer, it can also require up to 4 hours to download the disc and title information if the changer is full. During the entire set-up process, Entré requires a constant Internet connection. Please plan accordingly if you use a dial-up connection.

The very first time you turn on Entré, the following introduction screen appears on your TV:



1. Press  to continue. The first Quick Start screen appears:




The first screen contains some basic navigation instructions to help you complete the Quick Start process.





Each Quick Start screen contains a few common elements:






The Quick Start - Internet screen appears:



The following table explains what each screen element does:

This screen element:	Does this:
	Opens a help topic to assist you with the screen you're on.
	Shows you how much of the Quick Start setup you've completed.
	Takes you to the previous screen.
	Takes you to the next screen.

2. Press  to move to the next Quick Start screen.


- If you have a supported ISP (see page 17), press , and go to step 4. If you do not have a supported ISP, navigate to the **No** button on the screen and press .

The Internet Service Provider Setup screen appears:




How Do I Configure Internet Setup?



You must have an ISP to enjoy Entré. To obtain an ISP, call the toll-free number on the screen, then press  to continue with setup.

Once you register with an ISP, the Quick Start - Network Access screen appears:



4. Choose the type of Internet access you have and press .


Depending on your Internet connection, the Quick Start setup process will vary. For information about continuing Quick Start with:

- A dialup modem, see this page.
- A HomePNA connection, see page 23.
- An Ethernet connection, see page 25.


Continuing Quick Start with a Dialup Modem


When you select a dialup modem, Entré automatically checks for a dial tone on the connected line. Once it finds a dial tone, the Quick Start - Dialup ISP screen appears:



If Entré does not detect a dial tone, ensure that Entré is properly connected to your phone line, then press  to return to the Quick Start process.

1. Highlight **next** if you have a supported ISP.



If you use AOL, Compuserve, or a free ISP, highlight **more information** and press . Press  again to continue setup.

- Enter the login name, password, and dialup number(s) for your dialup service account.



The *login name*, *login password*, and *dialup number 1* fields are all required.




Some ISPs require that you type your entire e-mail address, (for example, "jsmith@isp.net"), as opposed to just your username ("jsmith").



When you enter a password in the *login password* field, the characters will appear as entered. However, once you move past that field, each character will appear as an asterisk.





If your ISP connection is a local call, leave the Area Code field of the phone number empty.


When you have completed the information, press . The Quick Start - Dialing Preferences screen appears:




- Enter any Internet connection dialing preferences. For example, if you need to dial 9 to get an outside line, you would need to enter **9** in the "dialing

prefix" field. When you have completed the information, press . The Quick Start - Zip Code screen appears:



- Enter your Zip Code in the field. To complete setup, press . Entré will automatically install Internet radio stations and download information about FM/AM radio stations based on the Zip Code you entered. When Entré is finished, the following screen will appear:



Press  to begin enjoying Entré.


Continuing Quick Start with a HomePNA Connection


A Home Phone Network Alliance (HomePNA) connection allows you to use your phone line as if it were a mini-computer network in your home—without tying up a phone line. Once you connect your computer to a HomePNA

How Do I Configure Internet Setup?

adapter, you can plug Entré into a phone line and access your computer's Internet connection anywhere in the house.

If you have a HomePNA connection, Entré automatically checks for a connected HomePNA network before continuing the Quick Start setup. Once it finds the network, the Quick Start - IP Addressing screen appears:





If there is no connected network detected, check your HomePNA connections. Once the problem is resolved, press  to return to the Quick Start process.


Specify from this screen whether your network uses a dynamic or static IP address.

When your network uses a *static IP address*, it always connects Entré to the Internet using the same IP address. Every Internet-connected device in your home (your computer, for example) uses a different IP address. The advantage of this method is that you can be certain which IP address Entré uses. However, you must keep track of which IP addresses you assign when adding new devices.


When your network uses *dynamic IP addresses*, it uses a range of addresses to connect Entré to the Internet. Each Internet-connected device in your home will also connect using that range of addresses. The advantage to dynamic IP addressing is that you don't have to remember which IP addresses you've assigned. However, you must ensure that you have enough addresses to support all of your devices.


If you're not sure what type of IP address your network uses, select Dynamic.

If your Internet connection uses a *dynamic IP address*, press . The Quick Start -Zip Code screen appears. Enter your Zip Code in the field. To complete setup, press . Entré will automatically install Internet radio stations and download information about FM/AM radio stations. When Entré is finished, the following screen will appear:



Press  to begin enjoying Entré.

If your Internet connection uses a *static IP address*, move to the **Static** button on the screen and press . The Quick Start - Static IP Info screen appears:





Enter the IP address information provided by your ISP or network administrator.





The "IP address", "subnet mask", gateway address", and "DNS 1" fields are required.

Press . The Quick Start - Zip Code screen appears:



Enter your Zip Code in the field. To complete setup, press . Entré will automatically install Internet radio stations and download information about FM/AM radio stations. When Entré is finished, the following screen will appear:




Press  to begin enjoying Entré. If the connection is not successful, see page 27.

Continuing Quick Start with an Ethernet Connection

If you have an Ethernet connection (DSL, cable modem, or LAN), Entré automatically checks for a USB-to-Ethernet adapter before continuing. Once it finds the adapter, the Quick Start - IP Addressing screen appears:




If there is no connected network detected, you must purchase a USB-to-Ethernet adapter in order to connect to the Internet with Entré. One compatible adapter is the CATC NetMate Link (#U-ETH-NM02), which is available from Kenwood via the Kenwood USA Web site at www.kenwoodusa.com. Go to the Kenwood Shop link to purchase an adapter. For a list of other compatible adapters, see the Kenwood USA Web site. Once you have connected the adapter, press  to return to the Quick Start process.


When your network uses a *static IP address*, it always connects Entré to the Internet using the same IP address. Every Internet-connected device in your home (your computer, for example) uses a unique IP address. The advantage of this method is that you can be certain which IP address Entré uses. However, you must keep track of which IP addresses you assign when adding new devices.


When your network uses *dynamic IP addresses*, it uses a range of addresses to connect Entré to the Internet. Each Internet-connected device in your home will also connect using that range of addresses. The advantage to dynamic IP addressing is that you don't have to remember which IP addresses you've assigned. However, you must ensure that you have enough addresses to support all of your devices.


How Do I Configure Internet Setup?

If you're not sure what type of IP address your network uses, select Dynamic.


If your home Ethernet network uses a *dynamic IP address*, press . The Quick Start - Zip Code screen appears:



Enter your Zip Code in the field. To complete setup, press . Entré will automatically install Internet radio stations and download information about FM/AM radio stations. When Entré is finished, the following screen will appear:



Press  to begin enjoying Entré.

If your Ethernet network uses a *static IP address*, move to the **Static** button on the screen and press . The Quick Start - Static IP Info screen appears:





Enter the IP address information provided by your ISP or network administrator.




The "IP address", "subnet mask", "gateway address", and "DNS 1" fields are required.

Press . The Quick Start - Zip Code screen appears:




Enter your Zip Code in the field. To complete setup, press . Entré will automatically install Internet radio stations and download information about FM/AM radio stations. When Entré is finished, the following screen will appear:



Press  to begin enjoying Entré.



After you complete Quick Start, and you've begun using Entré, you can still change any Internet configurations or your User Profile from Entré Setup. Press  to access Entré Setup.

If the connection is not successful, or you cancel the connection:

A screen appears, prompting you to do one of the following:

- *Return to the Quick Start process* to change the information entered. Select the **next** button on the screen.
- *Retry the connection.* Select the **retry** button on the screen.
- *Cancel the connection* and use Entré without connecting to the Internet. Select the **cancel** button on the screen.



If you cancel the connection at this point, you will not be able to access many of Entré's features, which include: downloading CD or DVD information, connecting to Internet radio stations, or automatically updating Entré. However, you can reconnect to the Internet later, enabling those options. After you complete Quick Start, and you've begun using Entré,



you can still change any Internet configurations or your User Profile from Entré Setup. Press  to access Entré Setup.



If you have trouble connecting to the Internet, see "How Do I Solve Internet Connection Problems?" on page 134 of "How to Use and Enjoy Your Entré Entertainment Hub" for Internet troubleshooting tips.

How Do I Configure Entré's Setup Menus?

After configuring Entré for the Internet, it is ready to use. However, Entré has many settings and functions that make it more flexible and enhance its capabilities. These options are accessed via the Setup menu:

Press  to access the Setup Menu. To exit the Setup mode at any time, press  again.

Entering User Information

Zip Code: You already entered this information during the Internet Setup process. If you move, enter your new Zip Code here.

Time Zone: Entré automatically establishes your Time Zone based on the Zip Code you enter during the Quick Start process. If you move, you may need to change your Time Zone here.

Remote Administration: Allows you to use the Internet and a PC to manually modify the library of your Entré's disk information that is stored in a secure area on the OpenGlobe Web site. You can perform these modifications remotely at any time and later use Entré's Web Sync function to transfer the modified information into your Entré. (See Web Sync, in Utilities on page 29, for more information.)

1. Point your Web browser to <http://www.openglobe.net/kenwood>
2. Enter the login number and password shown on Entré's Remote Administration screen
3. Follow the instructions on the screen

Privacy Policy: This is the Kenwood and OpenGlobe privacy policy.

Entering Internet Configuration Information

You have already entered this information during the Internet Setup process. If you change your Internet access (new ISP, upgrade to DSL, etc.), you need to return to this screen and update this information.


Entering Preferences

Music Recording Preferences: You can choose from different bit rates for MP3 music encoding. For more information, see "Recording from a CD to Entré's Storage System" on page 67 of "How to Use and Enjoy Your Entré Entertainment Hub".

Screen Saver Preferences: Select the amount of time Entré must be inactive before its screen saver activates.

Nightly Update Preferences: On the first day it is operational, then once a week thereafter, Entré will automatically check the OpenGlobe server for software updates, and if any are available, Entré will automatically install the update in itself. Use this screen to have Entré look for the upgrades during the time period that it will least likely be in use.

Entering Audio and Video Settings

Audio Input Selection: Tell Entré what type of component is connected to each of its audio inputs: analog, optical digital, and coaxial digital. Press 

until the type of component connected to the input is displayed, then use



to move to the next input.

Screen Centering: Use to center the image on your TV screen.

Brightness, Contrast, and Sharpness: Use the test images on these screens to easily adjust your TV controls to achieve the best picture possible.

Color Bars: Use this test pattern to easily adjust your TV's color and tint controls.

Entering Changer Management Information

Quick Lookup: You can have Entré check the connected changer to see if any discs have been added or removed, and get disc information for any that have.

Lookup Range: You can have Entré get disc information for a specific range of discs in a connected changer.

Lookup All: You can have Entré get disc information for all discs in a connected changer. (With a full changer, this can take between 3 and 4 hours if you have a dial-up Internet connection and it will be continuously on during this period.)

Changer Statistics: You can have Entré give you information about how many and what types of discs are in a connected changer, and how many have unknown disc information.

Entering Security and Parental Controls

Password Protection: Set up a numeric password to access the Setup Menu.

Movie Ratings: You can have Entré hide all movies above the rating you choose. For example, if you decide to hide all movies with a rating above PG-13, an R-rated DVD in your changer will not show up on the Movie Guide screen. (This will not block direct access to discs from the changer's controls.) See your DVD player's instruction manual for information about its ratings feature.

Entering Utilities Information

Web Sync: Uploads modifications to your music library information to a secure area on the OpenGlobe Web site, and downloads that modified information into your Entré. (See Remote Administration, in User Information on page 28, for more information.)

Update Software: You can have Entré search the OpenGlobe server and download the latest software updates. Entré will also automatically do this once a week. (See Nightly Update Preferences, in Preferences, for more information.)

Restore Factory Defaults: Use this selection to restore Entré's system to its factory defaults.



This function deletes all of the music files you have stored on Entré's high-capacity music storage system, and should be used only if Entré suffers a serious operational failure. We recommend that you back up your music files periodically on CD-Rs. For more information on making backup CD-Rs, see "Recording a Mix of MP3 Tracks from the Music Storage System onto a CD-R or CD-RW" on page 70.

How Do I Configure Entré's Setup Menus?

Appendix A: Program Codes

Setup Codes for Cable Converters

A			
ABC.....	0003, 0008 0014, 0017 0007, 0011 0013,0001 0033		
Allegro.....	0153, 0315		
Americast.....	0899		
Antronix.....	0022, 0207		
Archer.....	0153, 0797 0022, 0207 0039		
B			
BBT.....	0267		
Belcor.....	0056		
Bell & Howell.....	0014		
Bell South.....	0899		
C			
Cable Star.....	0056		
Cabletenna.....	0022		
Cableview.....	0022		
Century.....	0153		
Citizen.....	0153, 0315		
Colour Voice.....	0025, 0031		
Comband.....	0232	Hitachi.....	0011
Comtronics.....	0040, 0060	Hytex.....	0007
Contec.....	0019	J	
D		Jasco.....	0015, 0153 0315
Digi.....	0637	Jerrold.....	0003, 0476 0012, 0810 0276, 0014 0015, 0011 0024
E		L	
Eastern.....	0002	Linsay.....	0440
Emerson.....	0797	M	
Everquest.....	0015, 0040	Macom.....	0033
F		Magnavox.....	0027
Focus.....	0400	Memorex.....	0000
G		Motorola.....	1106
GC Electronics.....	0056, 0207 0016	Movie Time.....	0063, 0156
GE.....	0232	N	
Garrard.....	0153	NSC.....	0063, 0156 0070
Gemini.....	0015, 0797 0070, 0242	Nexus.....	0770
General Instrument.....	0476, 0810, 0276, 0011	Novaplex.....	0618
GoldStar.....	0144, 0040	O	
Goodmind.....	0797, 0770	Oak.....	0019, 0007
H, I		Optimus.....	0021
Hamlin.....	0020, 0259 0009, 0034 0273	P	
		Panasonic.....	0000, 0107 0021
		Panther.....	0637
		Paragon.....	0000
		Philips.....	0305, 0317 0153, 0025 0031, 0027 0242, 0290 0028, 0029 0030
		Pioneer.....	0144, 0877 0533, 0023 0260
		Pioneer.....	0533
		Popular Mechanics.....	0400
		Prelude.....	0770
		Pulsar.....	0000
		Q	
		Quasar.....	0000
		R	
		RCA.....	0021
		Radio Shack.....	0015, 0315, 0797, 0883
		Realistic.....	0207
		Recoton.....	0400
		Regal.....	0020, 0259 0273

Appendix A: Program Codes

Regency..... 0002
 Rembrandt..... 0011, 0070
 Runco 0000

S
 SL Marx 0040
 Samsung 0144, 0040
 Scientific Atlanta 0008, 0477
 0877, 0017
 0006
 Seam 0510
 Signal..... 0015, 0040
 Signature..... 0011
 Sprucer 0021
 StarSight..... 0422, 0542
 Starcom 0003, 0015
 Stargate..... 0015, 0040
 0797, 0770
 Starquest..... 0015
 Sylvania 0001

T
 TFC..... 0310
 TV86..... 0063
 Tandy..... 0258
 TeleCaption..... 0221
 Teleview..... 0040

Texscan..... 0001
 Timeless..... 0418
 Tocom 0012, 0013
 Toshiba 0000
 Tusa 0015

U
 Unika..... 0153, 0022
 0207
 United Artists 0007
 Universal 0153, 0191
 0022, 0056
 0207, 0039
 0077

V
 Viewstar..... 0063, 0258
 0027, 0060

W - Z
 Zenith..... 0525, 0000
 0899, 0054
 Zentek 0400

Setup Codes for Satellite Receivers

A
 AlphaStar 0772

B, C
 Chaparral..... 0216, 0053

D, E
 Echostar..... 0775, 1005
 0280, 0269
 0159
 Expressvu 0775

F, G
 General Instrument..... 0361, 0627
 0869

H
 HTS..... 0775
 Hitachi..... 0819
 Homecable..... 0238
 Hughes Network Systems 0749

I
 IQ..... 0210
 IQ Prism 0210

J, K
 JVC..... 0775
 Janeil 0152
 Jerrold 0361, 0627

L
 Legend 0269

M
 Magnavox..... 0724, 0722
 Memorex..... 0724, 0269

N, O
 Next Level 0869

P, Q
 Panasonic 0701, 0152
 Philips..... 0724, 0722
 1076
 Primestar 0361, 0627

R
 RCA..... 0566, 0143
 0855, 0392
 Radio Shack..... 0869
 Realistic 0052

S
 STS..... 0210
 Samsung..... 1109
 Sony 0639
 Star Choice..... 0869
 Star Trak 0180

T
 Toshiba 0749, 0790
 0082

U

Uniden 0724, 0722
 0052, 0238
 0074, 0076

V - Z

Zenith 0856

Setup Codes for TVs**A**

A-Mark 0003
 AOC 0030, 0019
 0185, 0003
 0052, 0137

Abex 0032
 Admiral 0093, 0463
 Adventura 0046
 Aiko 0092
 Akai 0030
 Alaron 0179, 0183
 Ambassador 0177
 America Action 0180
 Ampro 0751
 Anam 0180, 0068
 0004
 Anam National 0055
 Archer 0003
 Audiovox 0451, 0180
 0623, 0092
 0003

B

Baysonic 0180
 Belcor 0019

Bell & Howell 0154, 0016
 Bradford 0180
 Brockwood 0019
 Brooksonic 0236, 0463
 0003

C

CCE 0217, 0329
 CXC 0180
 Candle 0030, 0056
 0046, 0186
 Carnivale 0030
 Carver 0054
 Celebrity 0000
 Cinal 0451, 0092
 Citizen 0060, 0030
 0056, 0092
 0039, 0280
 0046, 0186

Clairtone 0185
 Concerto 0056
 Contec 0180, 0185
 0157, 0158
 Craig 0180
 Crosley 0054
 Crown 0180, 0039

Curtis Mathes 0047, 0747
 1147, 1347
 0054, 0154
 0051, 0451
 0093, 0060
 0030, 0056
 0145, 0016
 0166, 0466
 0039

D

Daewoo 0451, 0019
 0623, 0624
 0092, 0039
 0091
 Daytron 0019
 Denon 0145
 Dumont 0017, 0019
 Dwin 0720, 0774

E

Electroband 0000, 0185
 Electrohome 0381, 0389
 0409
 Emerson 0154, 0236
 0463, 0180
 0178, 0179
 0019, 0623
 0624, 0177
 0185, 0282
 0039, 0280
 0038, 0158
 0183, 0182
 Envision 0030

Appendix A: Program Codes

F		Hitachi..... 0056, 0145	L	Midland..... 0047, 0747
Fisher..... 0154, 0159		0016, 0151	LG 0056	0017, 0051
Fujitsu 0179, 0683		0032, 0038	LXI..... 0047, 0747	0135, 0039
Funai 0180, 0179		0279, 0413	0054, 0154	0032
0171		0409	0156, 0178	Minutz..... 0021
Futuretech 0180	I		0148	Mitsubishi 0093, 0150
	Infinity 0054		Logik 0016	0178, 0019
	Inteq..... 0017		Luxman 0056	Motorola 0093, 0055
G	J			Multitech..... 0180, 0217
GE 0047, 0747	JBL..... 0054		M	
1147, 1347	JCB 0000		MEI..... 0185	N
0051, 0451	JVC 0053, 0182		MGA 0150, 0030	NAD..... 0156, 0178
0093, 0178	0160		0178, 0019	0166
0021, 0055	Janeil 0046		MTC 0060, 0030	NEC..... 0030, 0056
0282, 0135			0056, 0019	0019, 0497
0027, 0279			0185, 0091	NTC 0092
0029, 0174	K			Nikko 0030, 0178
Gibraltar 0017, 0030	KEC 0180		Magnavox..... 0054, 1254	0092
0019	KMC..... 0106		0030, 0179	Noblex 0430
GoldStar 0030, 0178	KTV 0180, 0030		0187, 0096	Noshi..... 0018
0056, 0019	0185, 0039		0020, 0186	
0032, 0001	0280, 0217		0386, 0024	
0409, 0106	0183		0028	
0002	Kawasho 0158		Majestic..... 0016, 0015	O
Gradiente 0053, 0056	Kaypani 0052		Marantz 0054, 0030	Onwa 0180
0392	Kenwood 0030, 0019		Matsushita 0250	Optimus 0154, 0250
Grunpy 0180, 0179	Kloss 0046, 0024		Megatron..... 0178, 0145	0166
	0078		0003	Optonica 0093, 0165
H	Konka 0707, 0628		Memorex..... 0154, 0250	Orion 0236, 0463
Hallmark..... 0178	0632, 0638		0463, 0150	0179
Harley Davidson 0179	0703		0178, 0179	
Harman/Kardon 0054, 0078			0056, 0016	P
Harvard 0180, 0068			0106	Panasonic 0051, 0250
				0055, 0226

Penney..... 0047, 0747
 1347, 0156
 0051, 0060
 0030, 0178
 0021, 0056
 0019, 0018
 0135, 0039
 0003, 0027
 0032, 0002

Philco 0054, 0463
 0030, 0145
 0019, 0096
 0020, 0028

Philips..... 0054

Pilot..... 0030, 0019
 0039

Pioneer 0166, 0679
 0038

Portland..... 0019, 0092
 0039

Princeton 0717

Prism 0051

Proscan..... 0047, 0747

Proton..... 0178, 0466
 0003, 0052

Pulsar..... 0017, 0019

Q
 Quasar..... 0051, 0250,
 0055, 0165

R
 RCA..... 0047, 0747
 1047, 1147
 1247, 1347
 1447, 0090
 0051, 0093
 0019, 0679
 0018, 0135
 0038, 0029
 0174, 0278

Radio Shack..... 0047, 0747
 0154, 0180
 0030, 0178
 0056, 0019
 0165, 0039
 0032, 0409

Realistic 0154, 0180
 0030, 0178
 0056, 0019
 0165, 0039
 0032

Rhapsody..... 0185, 0183

Runco 0017, 0030
 0603, 0497

S
 SSS 0180, 0019

Sampo 0030, 0039
 0052, 0032

Samsung 0060, 0030
 0178, 0056
 0019, 0032
 0329, 0427
 0482

Samsux 0039

Sansei 0451

Sansui..... 0463

Sanyo 0154, 0159
 0146, 0484

Scimitsu 0019

Scotch 0178

Scott..... 0236, 0180
 0178, 0179
 0019

Sears..... 0047, 0747
 0054, 0154
 0156, 0178
 0179, 0056
 0171, 0159
 0146, 0015
 0148

Semivox..... 0180

Semp..... 0156

Sharp..... 0093, 0688
 0165, 0039
 0386, 0157

Shogun 0019

Signature 0016

Simpson..... 0187, 0186

Sony 0000, 0080
 0111, 0011

Soundesign 0180, 0178
 0179, 0186

Spectricon 0003, 0137

Squareview 0171

Starlite 0180

Supre-Macy 0046

Supreme..... 0000

Sylvania 0054, 0030
 0096, 0020
 0381, 0028

Symphonic 0171

T
 TMK 0178, 0056
 0177

TNCi..... 0017

Tandy 0093

Tatung 0055, 0003

Technics..... 0051, 0250

Technol Ace..... 0179

Techwood..... 0051, 0056
 0003

Teknika..... 0054, 0180
 0150, 0060
 0179, 0056
 0019, 0016
 0092, 0039
 0186, 0312

Telefunken..... 0056

Toshiba 0154, 0156
 0060

Toshiba 1256

Tosonic 0185

Totevision 0039

Trical..... 0157

Appendix A: Program Codes

U						
Universal.....	0027	Vidtech.....	0178, 0019	0165, 0096	Y	
		Viking.....	0046, 0312	0020, 0080	Yamaha.....	0030, 0019
V				0027, 0111		
Vector Research	0030	W, X		0028, 0029	Z	
Victor.....	0053	Wards.....	0054, 0030	0174	Zenith.....	0017, 0463
Vidikron.....	0054, 0242		0178, 0021	White Westinghouse....		0624, 0016
			0179, 0056			0092
			0019, 0016		Zonda.....	0003

Appendix B: Specifications

Audio

Frequency Response: 20Hz – 20kHz \pm 0.5dB

THD: <0.003% (1kHz)

Signal-to-Noise Ratio: 100dB

Channel Separation: 95dB (1kHz)

Input Impedance: 47 kohms

Output Impedance: 200 ohms

Video

Bandwidth (pass-through): 45MHz (Component), 6.5MHz (Composite)

Drive

CD-ROM Read Speed: 24X

CD-R Write Speed: 10X

CD-RW Write Speed: 4X

Dimensions and Weight

Width: 17-5/16"

Height: 4-1/2"

Depth: 11-1/2"

Weight: 14.3 lb.

Index

- A**
 - accessories iii
 - adding
 - devices 11
 - alternate audio or video source 11
 - amplifier. *See receiver*
 - applying power, guidelines iv
 - audio
 - selecting alternate source 11
 - B**
 - batteries, loading into remote 10
 - C**
 - cable
 - modem, setting up 25
 - cables
 - included with Entré iii
 - CD changer
 - connecting 6
 - changer, connecting CD or DVD 6
 - changing
 - Picture within a Picture (PIP) .. 11
 - choosing
 - alternate audio or video
 - source 11
 - completing Internet setup 27
 - configuring
 - Internet setup 19
 - connecting
 - CD, DVD changer 6
 - receiver 4
 - Kenwood Sovereign 5, 9
 - other 5, 9
 - TV 2
 - connection
 - Internet requirements iv
 - D**
 - devices
 - adding to remote 11
 - dialup modem, Quick Start setup ... 22
 - Digital Subscriber Line. *See DSL*
 - DSL, setup 25
 - DVD changer
 - connecting 6
 - E**
 - entering
 - product codes 11
 - Entré
 - accessories iii
 - resetting iv
 - Ethernet
 - connection, Quick Start 25
 - F**
 - finding
 - product codes 11
 - H**
 - HomePNA
 - setup 23
 - I**
 - inserting batteries 10
 - Internet
 - connecting
 - on-screen 19
 - physical 12
 - connection requirements iv
 - setup
 - on-screen 19
 - physical 12
 - K**
 - Kenwood Sovereign
 - CD or DVD changer,
 - connecting 6
 - receiver, connecting 5, 9
 - L**
 - loading batteries 10
 - local area network (LAN), setup 25
 - O**
 - other primary receiver,
 - connecting 5, 9
 - P**
 - Picture within a Picture (PIP),
 - using 11
 - power, applying safely iv
 - precautions, safety iv
 - primary receiver, connecting 5, 9
 - product codes, entering 11
 - programming, remote 11
 - Q**
 - Quick Start 20–27
 - R**
 - receiver, connecting 4–5
 - remote
 - loading batteries 10
 - programming 10
 - resetting, Entré iv
 - S**
 - safely, applying power iv
 - safety precautions iv
 - selecting
 - audio sources 11
 - setup
 - dialup modem 22
 - DVD or CD changer 6–7
 - Ethernet connection 25
 - HomePNA connection 23
 - Internet
 - on-screen 19–27
 - physical 17
 - receiver 4–5
 - remote 11
 - TV 2–3
 - sources
 - selecting
 - alternate audio 11
 - swapping, Picture within a Picture . 11
 - switching
 - Picture within a Picture 11
- T**
 - television. *See TV*
 - troubleshooting
 - Entré iv
 - tuner. *See receiver*
 - TV
 - connecting 2–3
 - watching without turning
 - on Entré 3
 - U**
 - unlisted program codes, finding 11
 - unpacking Entré iii
 - unresponsive
 - Entré iv
 - using
 - Picture within a Picture 11
 - V**
 - viewing
 - TV without Entré 3
 - W**
 - watching
 - TV without Entré 3

