



Read this first

Warranty	1-1
1. Warranty and Product Support	1-1
1.2 Product Assistance	1-1
1.3 Maintenance Agreements	1-1
1.4 Staying Up to Date	1-2
1.5 Service and Repair	1-2
1.6 How to return a Product	1-2
1.7 What Comes with Your Scope	1-2

General Information	2-1
2.1 Product Assistance	2-1
2.2 Installation for Safe and Efficient Operation	2-1
Operating Environment	2-1
Safety Symbols	2-1
Power Requirements	2-3
Cleaning and Maintenance	2-3
Power On	2-3

Specifications	3-1
3.1 Vertical	3-1
3.2 Triggering System	3-1
3.3 Standard Triggers	3-1
3.4 Optional SMART Triggers®	3-2
3.5 Documentation and Connectivity	3-2
3.6 Measure, Zoom, and Math Tools	3-3
3.7 Automatic Setup	3-3
3.8 Setup and Waveform Storage	3-3
3.9 Outputs	3-3
3.10 Environmental and Safety	3-4
3.11 Physical Dimensions	3-4
3.12 General	3-4
3.13 Warranty & Calibration	3-4



Theory of Operation	4-1
4.1 System Block Diagram	4-1
4.2 Main Board	4-2
4.2.1 Front End	4-3
4.2.2 Analog to Digital Converter	4-5
4.2.3 Trigger	4-6
4.2.4 Time Base	4-9
4.2.5 Calibrator	4-10
4.2.6 Scan DAC	4-10
4.2.7 Main Board Control	4-10
4.3 Computer	4-11
4.3.1 Operating System	4-11
4.3.2 Memory	4-11
4.3.3 Interfaces	4-11
4.3.4 Storage Devices	4-11
4.3.5 Video port	4-11
4.4 PCI Card	4-12
4.4.1 PCI Interface	4-12
4.4.2 Local bus for acquisition	4-13
4.4.2.1 Control	4-13
4.4.2.2 Acquisition Data	4-13
4.4.3 Dallas OneWire Interface	4-13
4.4.4 Audio amplifire	4-13
4.5 Front Panel	4-13
4.5.1 Key board	4-14
4.5.2 Panel Board	4-14
4.5.2.1 Encoders	4-14
4.5.2.2 Touchscreen Interface	4-14
4.6 Display and Touchscreen	4-15
4.6.1 Color LCD Module	4-15
4.6.2 Backlight Inverter	4-15
4.6.3 Touch Screen	4-15
4.6.4 LVDS receiver	4-15
4.7 Power Supply	4-16
4.7.1 Input Voltages	4-16
4.7.2 Output Voltages	4-17
4.7.3 Basic Operation	4-17
4.7.3.1 Pre-converter	4-17
4.7.3.2 Main Converter	4-17
4.7.3.3 House Keeping Power Supply	4-17
4.7.3.4 +5VDIG and 3.3V DC/DC(Daughter Board)	4-17
4.7.3.5 +5VANA and 2.5V DC/DC (Daughter Board)	4-18
4.7.3.6 +9 and 12V DC/DC (Daughter Board)	4-18
4.7.3.7 -5V and -12V Forward converter	4-18
4.7.3.8 Filter Circuits (Daughter Boards)	4-18
4.7.4 Connector Assignments	4-18
4.7.5 Output Voltage Adjustment Range	4-21
4.7.6 +5VSB Standby Supply Rail	4-21

Theory of Operation

4.7.7	Control	4-21
4.7.7.1	Output Enable OUTPUT-EN/ (active low)	4-21
4.7.7.2	Line Frequency Synchronization Output Signal (LFS)	4-21
4.7.7.3	PWR_OK signal	4-21
4.7.8	Over-Current Protection	4-22
4.7.9	Over-Temperature Protection	4-22
4.7.10	Over-Voltage Protection	4-22

Theory of Operation - List of Figures

Figure 4-1	WaveSurfer Block Diagram	4-1
Figure 4-2	Acquisition Block Diagram	4-2
Figure 4-3	Front End Block Diagram 1	4-4
Figure 4-4	Front End Block Diagram 2	4-5
Figure 4-5	HAM631 System Architecture	4-5
Figure 4-6	Channel Mode	4-6
Figure 4-7	Trigger Block	4-8
Figure 4-8	Time Base Block Diagram	4-9
Figure 4-9	Calibrator Block Diagram	4-10
Figure 4-10	PCI Card Block Diagram	4-12
Figure 4-11	Front Panel Block Diagram	4-13
Figure 4-12	Display & Touchscreen Block Diagram	4-15
Figure 4-13	Power Supply Block Diagram	4-16



Performance Verification

5.1	Introduction	5-1
5.1.1	List of Tested Characteristics	5-1
5.1.2	Calibration Cycle	5-1
5.2	Test Equipment Required	5-2
5.2.1	Test Records	5-2
5.3	Turn On	5-2
5.4	Input Impedance	5-3
5.4.1	Channel Input Impedance	5-3
5.4.2	External Trigger Input Impedance	5-7
5.5	Leakage Current	5-9
5.5.1	Channel Leakage Current	5-9
5.5.2	External Trigger Leakage Current	5-12
5.6	Peak-Peak Noise Level	5-14
5.7	DC Accuracy	5-16
5.7.1	Positive DC Accuracy	5-16
5.7.2	Negative DC Accuracy	5-19
5.8	Offset Accuracy	5-20
5.8.1	Positive Offset Accuracy	5-20
5.8.2	Negative Offset Accuracy	5-22
5.9	Bandwidth	5-23
5.9.1	Description	5-23
5.10	Trigger Level	5-28
5.10.1	Description	5-28
5.10.2	Channel Trigger at 0 Division Threshold	5-28
5.10.3	Channel Trigger at +2.5 Divisions Threshold	5-31
5.10.4	Channel Trigger at -2.5 Divisions Threshold	5-32
5.11	Time Base Accuracy	5-34
5.11.1	Description	5-34
5.11.2	Clock Verification Procedure	5-34

Maintenance

6.1	Introduction	6-1
6.1.1	Safety Precautions	6-1
6.1.2	Anti-static Precautions	6-1
6.3	Software Update Procedure	6-2
6.3.1	Installing New X-Stream DSO Application Software	6-2
6.3.2	Software End User License Agreement	6-3
6.3.3	Installing Device Drivers	6-7
6.3.4	Restoring the Operating System	6-8
6.3.5	Software Options	6-12
6.3.5.1	Changing Software Option Key	6-12
6.4	Board Exchange Procedure	6-13
6.4.1	PCI Board Exchange Procedure	6-13
6.4.2	Hard Drive Replacement Procedure	6-13
6.4.2.1	Required items	6-13
6.4.2.2	Preparation of host machine	6-13
6.4.2.3	Copying necessary files to share them through network	6-14
6.4.2.4	Creating a network-ready startup disk	6-15
6.4.2.5	Updating the hard disk (through a network)	6-18
6.4.2.6	Setup at the first startup	6-20
6.4.2.7	Validating the software	6-22
6.4.2.8	Initialization of panel setup	6-22
6.4.2.9	BIOS setting	6-23
6.5	Battery Exchange Procedure	6-26
6.6	Update BIOS	6-26
6.7	Equipment and Spare Parts Recommended for Service	6-27
6.7.1	Test Equipment Required	6-27
6.7.2	WaveSurfer Spare Parts	6-27
6.8	Service Menu	6-28
6.8.1	Accessing Service Menu	6-28
6.8.2	Mainframe Tests	6-29
6.8.2.1	Front Panel Test	6-29
6.9	Calibration Procedures	6-31
6.9.1	System Power Supply Calibration Procedure	6-31
6.9.2	Touch Screen Calibration Procedure	6-33
6.9.3	Front/ACQ System Adjustments	6-35
6.9.3.1	Internal reference voltage adjustment	6-35
6.9.3.2	Front end adjustment	6-36
6.9.3.3	TDC adjustment	6-39
6.9.3.4	Trigger delay adjustment	6-39
6.9.3.5	Trigger hysteresis adjustment	6-40
6.9.3.6	Event trigger delay adjustment	6-40
6.9.3.7	Odd path adjustment	6-41
6.9.3.8	Trigger analog time adjustment	6-42
6.9.3.9	Adjustment of time difference between channels	6-44
6.9.3.10	Speaker volume adjustment	6-45
6.10	Troubleshooting and Flow Charts	6-45
6.10.1	Introduction	6-45



Maintenance

6.10.2	Repair Level	6-45
6.10.3	Initial Troubleshooting	6-46
6.10.4	Power Supply Problem	6-48
6.10.5	No Display (Internal or External)	6-49
6.10.6	Internal Display Problem	6-51
6.10.7	Boot Up Sequence	6-52
6.10.8	Front Panel Controls or Touch Screen Does not Operate	6-53
6.10.9	Timebase Problem	6-57
6.10.10	Remote Control Problem	6-58
6.10.11	Vertical Accuracy Problem	6-59
6.10.12	Bandwidth Problem	6-60
6.10.13	Line Trigger Problem	6-61

Mechanical Parts & Removal

7.1	Over All Replaceable Parts	7-1
7.2	Over All Block Diagram	7-3
7.3	Disassembly Flow Charts	7-4
7.4	OUTER Replaceable Parts	7-5
7.5	REAR & SIDE Replaceable Parts	7-5
7.6	FRONT Panel Assy	7-9
7.7	FRONT Bezel Assy	7-14
7.8	FRAME Assy (MAIN, POWER & CPU BOARD)	7-15
7.9	Spare Parts	7-16