


Disney

DVD2100-PA-A

# SERVICE MANUAL

---

DVD VIDEO PLAYER & VIDEO CASSETTE RECORDER



ORIGINAL  
MFR'S VERSION B


## SERVICING NOTICES ON CHECKING

### 1. KEEP THE NOTICES

As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

### 2. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  mark, the designated parts must be used.

### 3. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board.

The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

### 4. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

## HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

#### 1. MODEL NUMBER and VERSION LETTER.

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

#### 2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

## WHEN REPLACING DVD DECK

### [ Removing the DVD Deck ]


Before removing Pick Up PCB and DVD PCB connector, short circuit the position shown in **Fig. 1** using a soldering iron. If you remove the DVD Deck with no soldering, the Laser may be damaged.

### [ Installing the DVD Deck ]

Remove all the soldering on the short circuit position after the connection of Pick Up PCB and DVD PCB connector.

### NOTE

- Before your operation, please read "PREPARATION OF SERVICING".
- Use the Lead Free solder.
- Manual soldering conditions
  - Soldering temperature:  $320 \pm 20^{\circ}\text{C}$
  - Soldering time: Within 3 seconds
  - Soldering combination: Sn-3.0Ag-0.5Cu
- When Soldering/Removing of solder, use the drawing equipment over the Pick Up Unit to keep the Flux smoke away from it.



## PREPARATION OF SERVICING

The laser diode used for a pickup head may be destroyed with external static electricity. Moreover, even if it is operating normally after repair when static electricity discharge is received at the time of repair, the life of the product may be shortened.

Please perform the following measure against static electricity, be careful of destruction of a laser diode at the time of repair.

- Place the unit on a workstation equipped to protect against static electricity, such as conductive mat.
- Soldering iron with ground wire or ceramic type is used.
- A worker needs to use a ground conductive wrist strap for body.

## TAPE REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Top Cabinet, Front Cabinet and DVD Block. (Refer to item 1 of the **DISASSEMBLY INSTRUCTIONS.**)
2. Remove the screw (1) of the Deck Chassis and remove the Loading Motor. (Refer to Fig. 2)
3. Rotate the Pinch Roller Cam in the direction of the arrow by hand to slacken the Video Tape.
4. Rotate the Clutch Ass'y either directions to wind the Video Tape in the Cassette Case.
5. Repeat step 3~4. Then take out the Video Cassette from the Deck Chassis. Be careful not to scratch on the tape.




Fig. 1




Fig. 2

## DISC REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Back Cabinet and TV//DVD/VCR Block. (Refer to item 1 of the **DISASSEMBLY INSTRUCTIONS.**)
2. Rotate the Main Gear in the direction of the arrow by hand. (Refer to Fig. 1)
3. Manually open the Tray.




Fig. 1

## PARENTAL CONTROL - RATING LEVEL 4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '7' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 3 seconds.
5. The On Screen Display message 'PASSWORD CLEAR' will appear.
6. The 4 digit password has now been cleared

## ABOUT LEAD FREE SOLDER (PbF)

### Distinction of PbF PCB:

PCBs (manufactured) using lead free solder will have a PbF printing on the PCB.  
(Please refer to figures.)



### Caution:

- Pb free solder has a higher melting point than standard solder;  
Typically the melting point is 50°F~70°F(30°C~40°C) higher.  
Please use a soldering iron with temperature control and adjust it to 650°F ± 20°F (350°C ± 10°C).  
In case of using high temperature soldering iron, please be carefull not to heat too long.
- Pb free solder will tend to splash when heated too high (about 1100°F/ 600°C).
- All products with the printed circuit board with PbF printing must be serviced with lead free solder.  
When soldering or unsoldering, completely remove all of the solder from the pins or solder area,  
and be sure to heat the soldering points with the lead free solder until it melts sufficiently.

### Recommendations

Recommended lead free solder composition is Sn-3.0Ag-0.5Cu.

# TABLE OF CONTENTS

<b>SERVICING NOTICES ON CHECKING</b> .....	A1-1
<b>HOW TO ORDER PARTS</b> .....	A1-1
<b>WHEN REPLACING DVD DECK</b> .....	A1-2
<b>PREPARATION OF SERVICING</b> .....	A1-2
<b>TAPE REMOVAL METHOD AT NO POWER SUPPLY</b> .....	A1-3
<b>DISC REMOVAL METHOD AT NO POWER SUPPLY</b> .....	A1-3
<b>PARENTAL CONTROL-RATING LEVEL</b> .....	A1-3
<b>ABOUT LEAD FREE SOLDER (PbF)</b> .....	A1-4
<b>TABLE OF CONTENTS</b> .....	A2-1
<b>GENERAL SPECIFICATIONS</b> .....	A3-1~A3-6
<b>DISASSEMBLY INSTRUCTIONS</b>	
1. REMOVAL OF MECHANICAL PARTS AND P. C. BOARDS .....	B1-1, B1-2
2. REMOVAL OF VCR DECK PARTS .....	B2-1~B2-6
3. REMOVAL OF DVD DECK PARTS .....	B3-1~B3-3
4. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC .....	B4-1, B4-2
<b>KEY TO ABBREVIATIONS</b> .....	C1-1, C1-2
<b>SERVICE MODE LIST</b> .....	C2-1
<b>PREVENTIVE CHECKS AND SERVICE INTERVALS</b> .....	C3-1, C3-2
<b>WHEN REPLACING EEPROM (MEMORY) IC</b> .....	C4-1
<b>SERVICING FIXTURES AND TOOLS</b> .....	D1-1
<b>PREPARATION FOR SERVICING</b> .....	D1-1
<b>MECHANICAL ADJUSTMENTS</b> .....	D2-1~D2-4
<b>ELECTRICAL ADJUSTMENTS</b> .....	D3-1, D3-2
<b>BLOCK DIAGRAMS</b>	
DVD .....	E-1, E-2
Y/C/AUDIO/CCD/HEAD AMP .....	E-3, E-4
SYSCON .....	E-5, E-6
OPERATION/DISPLAY .....	E-7, E-8
Hi-Fi/DEMODULATOR .....	E-9, E-10
TUNER/JACK .....	E-11, E-12
POWER .....	E-13, E-14
<b>PRINTED CIRCUIT BOARDS</b>	
DVD .....	F-1, F-2
VCR .....	F-3~F-6
OPERATION/OPERATION2 .....	F-7, F-8
<b>SCHEMATIC DIAGRAMS</b>	
MPEG/MICON/DSP/RF_AMP .....	G-1, G-2
MEMORY .....	G-3, G-4
MOTOR DRIVE .....	G-5, G-6
AUDIO/VIDEO .....	G-7, G-8
Y/C/AUDIO/CCD/HEAD AMP .....	G-9, G-10
SYSCON .....	G-11, G-12
TUNER/JACK .....	G-13, G-14
OPERATION/DISPLAY .....	G-15, G-16
Hi-Fi/DEMODULATOR .....	G-17, G-18
POWER .....	G-19, G-20
OPERATION 1 .....	G-21, G-22
OPERATION 2 .....	G-23, G-24
<b>INTERCONNECTION DIAGRAM</b> .....	G-25, G-26
<b>WAVEFORMS</b> .....	H-1, H-2
<b>MECHANICAL EXPLODED VIEW</b> .....	I1-1, I1-2
<b>CHASSIS EXPLODED VIEWS</b> .....	I2-1, I2-2
<b>DVD DECK EXPLODED VIEWS</b> .....	I3-1
<b>MECHANICAL REPLACEMENT PARTS LIST</b> .....	J1-1
<b>CHASSIS REPLACEMENT PARTS LIST</b> .....	J2-1
<b>DVD DECK REPLACEMENT PARTS LIST</b> .....	J3-1
<b>ELECTRICAL REPLACEMENT PARTS LIST</b> .....	J4-1, J4-2

# GENERAL SPECIFICATIONS

<b>G-1</b>	<b>Outline of the product</b>		DVD VIDEO PLAYER & VHS Player / Recorder		
<b>G-2</b>	<b>DVD System</b>	Color System	NTSC		
		Disc	DVD, CD-DA, CD-R/RW		
		Disc Diameter	120 mm , 80 mm		
		Drive	DM3PA		
		Search speed	Actual	Fwd 4 steps	
				2-45 times (DVD) 4-40 times (CD)	
		Slow speed	Actual	Rev 4 steps	
2-45 times (DVD) 4-40 times (CD)					
<b>G-3</b>	<b>VCR System</b>	System	VHS Player / Recorder		
		Video System	NTSC		
		Hi-Fi STEREO	Yes		
		NTSC PB(PAL60Hz)	No		
		Deck	OVD-7		
		Heads	Video Head	4Head	
			FM Audio Head	2Head	
			Audio / Control	Mono/Yes	
		Erase (Full Track Erase)	Yes		
		Erase (Normal Audio Track Erase)	No		
		Tape Speed	Rec	PAL	-
			Play	NTSC	SP/SLP
			Rec	PAL	-
			Play	NTSC	SP/LP/SLP
		Fast Forward / Rewind Time (Approx.) at 25°C	with Cassette	FF:4'50"/REW:2'30"	
				T-120	
		Forward/Reverse	NTSC or PAL-M	SP/LP/SLP = 3x,5x / 7x,9x / 9x,15x	
Picture Search	PAL or SECAM	-			
Frame Advance		Yes			
Slow Speed		1/10			
<b>G-4</b>	<b>Tuning System</b>	Broadcasting System	US System M		
		Tuner and Receive CH	System	1Tuner	
			Destination	US (w/CATV)	
			CH Coverage	2-69,4A,A-5~ A-1,A-I, J~ W, W+1-W+84	
		Intermediate Frequency	Picture (FP)	45.75 MHz	
			Sound (FS)	41.25 MHz	
			FP-FS	4.50 MHz	
		Preset CH		-	
		RF Converter Output		Yes	
			Channel	3 or 4 ch	
			Level / Impedance	66 dBu / 75 Ohm	
			Sound Selector	No	
		Stereo / Dual TV Sound		US-ST	
Tuner Sound Muting		Yes			
<b>G-5</b>	<b>Power</b>	Power Source	AC	120V 60Hz	
			DC	-	
		Power Consumption	Stand by	18 W at 120V 60Hz	
			Per Year	2 W at 120V 60Hz -- W	
		Protector	Power Fuse	Yes	
Safety Circuit	Yes				
IC Protector (Micro Fuse)	No				
<b>G-6</b>	<b>Regulation</b>	Safety	UL / CSA		
		Radiation	FCC / IC		
		Laser	DHHS		
<b>G-7</b>	<b>Temperature</b>	Operation	5°C - 40°C		
		Storage	-20°C - 60°C		
<b>G-8</b>	<b>Operating Humidity</b>		Less than 80% RH		
<b>G-9</b>	<b>Signal</b>	Video Signal	Output Level	1 V p-p/75 ohm (DVD,VCR)	
			S/N Ratio (Weighted)	65 dB(DVD) 50 dB(VCR)	
			Horizontal Resolution	500 Lines (DVD) 230 Lines(VCR Mode)	

# GENERAL SPECIFICATIONS

	RGB Signal	Output Level	-
	Audio Signal	Input Level Microphone	-
		Input Level Line	-
		Output Level Line	-8 dBm/ 1k ohm (VCR, 0dBm=0.775Vrms) -12dBm/ 1k ohm
		Digital Output Level	0.5 V p-p / 75 ohm(DVD)
		S/N Ratio at (Weighted)	90dB(DVD), 42dB(VCR at SP)
		Harmonic Distortion (1KHz) Typical	0.02% (1KHz) (DVD) , 1.5% (1KHz) (VCR)
		Frequency Response : DVD Mode at DVD	4 Hz - 22 KHz
		DVD Mode at VIDEO CD	-
		DVD Mode at CD	4 Hz - 20 KHz
		VCR Mode at SP	100Hz - 10 KHz
		VCR Mode at LP	-
		VCR Mode at SLP	100Hz - 4 KHz
	Hi-Fi Audio Signal	Dynamic Range : More than	90dB
		Frequency Response	20Hz ~20kHz
Wow And Flutter : Less than		0.01 %Wrms	
Channel Separation : More than		60 dB	
Harmonic Distortion : Less than		0.01	
<b>G-10</b>	<b>On Screen Display (DVD)</b>	Menu	Yes
		Menu Type	Icon
		Language	Yes
		Menu	Yes
		Subtitle	Yes
		Audio	Yes
		OSD Language (Set up Language)	Yes
		Video	Yes
		TV Screen Size	Yes
		OSD Display On/Off	Yes
		Picture Mode(Video/Film/Auto)	Yes
		JPEG Interval	No
		E.B.L. (Enhanced Black Level)	No
		Audio	Yes
		DRC (Dynamic Range Control)	Yes
		Dialogue On:DRC(TV)/ Off:DRC(Std)	No
		dts Decode	No
		Surround On/Off	No
		System	Yes
		Disc/Card Slot	No
		Password Lock/Unlock	Yes
		Rating Level	Yes
		Select Files	No
		HDMI(480p/1080i/720p)	No
		Output	No
		Open	Yes
		Close	Yes
		No disc	Yes
		Reading	Yes
		Play	Yes
		Still/Pause	Yes
		Stop	Yes
		PBC	No
		Prohibit Mark	Yes
		Step	Yes
		Skip (>> )	Yes
		Skip ( <<)	Yes
		Random	Yes (CD)
		Repeat	Yes
		Slow+	Yes
Slow-	No		
Search+	Yes		
Search-	Yes		
Jump	Yes		
Resume	Yes		
Title No.	Yes		
Chapter No.	Yes		
Track No.	Yes		



# GENERAL SPECIFICATIONS

		Time	Yes
		Subtitle No.	Yes
		Angle No.	Yes
		Vocal On/Off	No
		Audio No.	Yes
		Audio Stereo L/R	No
		Zoom	Yes
		Marker No.	Yes
		Surrond On/Off	No
		Program Play Back	Yes (CD)
		MP3/WMA	
		Folder Name	No
		File Name	No
		File No	No
		Time	No
		Track No	No
		Progressive Scan Out ON/OFF	No
<b>On Screen Display(VCR)</b>	<b>Menu</b>		Yes
		Menu Type	Character
		Timer Rec Set	Yes
		Auto Repeat On/Off	Yes
		SAP On/Off	Yes
		CH Set-Up	Yes
		TV/CABLE	Yes
		Auto CH Memory	Yes
		Add/Delete	Yes
		System Set Up	Yes
		Clock Set	Yes (Calendar 12H)
		Language	Yes
		No Noise Back Ground	Yes
		Auto Clock	Yes
		Standard Time	Yes
		Daylight Saving Time	Yes
		G-CODE(or SHOWVIEW or PLUSCODE)No. Entry	No
		Stereo, Audio Output, SAP	Yes
		Play/Stop/FF/Rew/Rec/OTR/Pause/Eject/Tape In/Repeat (Symbol Mark)	Yes
		CH	Yes
		Clock	Yes
		Repeat	Yes
		Tape Counter	Yes
		Index	Yes
		Tape Speed	Yes
		ATR / Manual Tracking	Yes
		ZERO Return	Yes
		Hi-Fi	Yes
<b>G-11</b>	<b>OSD Language</b>	DVD OSD	English / French / Spanish
		VCR OSD	English / French / Spanish
<b>G-12</b>	<b>Clock,Timer and Timer Back-up</b>	Calendar	1990/1/1 ~ 2081/12/31
		Timer Events	8 Program/ 1 Month
		One Touch Recording Max Time	6 Hours
		Timer Back-up (at Power Off Mode)	30min
<b>G-13</b>	<b>Display</b>	DISPLAY	No
		DISPLAY type	--
		Clock/Counter,CH,Timer Rec,OTR, Play Rec,FF(Cue),Rew(Rev),Stop,ATR,Eject	--
		VCR	--
		DVD	--
		CD	--
		Clock	--
		AM	
		PM	
		Counter	--
		VCR	--
		DVD	--
		CD	--
		Eject	--
		Counter Remain	--
		Play	--
		Stop	--
		Rec	--
		FF / Cue	--

## GENERAL SPECIFICATIONS

		REW / Review	--	
		Pause / Still	--	
		OTR (ITR)	--	
		T-Rec	--	
		Chapter	--	
		TITLE	--	
		TRACK	--	
		Repeat	--	
		Hi-Fi	--	
		SP	--	
		LP	--	
		SLP	--	
		CH	--	
		RF Output CH	--	
		Tape In	--	
		Remocon Custom Code	--	
		Progressive Scan Out	--	
<b>G-14</b>	<b>Remote Control</b>	Unit	RC-JT	
		Glow in Dark Remocon	No	
		Remocon Format	Orion	
		Format	NEC	
		Custom Code	71-8E	
		Power Source	Voltage(D.C)	3V
			UM size x pcs	UM-4 x 2 pcs
		Total Keys	44 Keys	
		Keys	Power	Yes
			DISPLAY/CALL	Yes
			1	Yes
			2	Yes
			3	Yes
			4	Yes
			5	Yes
			6	Yes
			7	Yes
			8	Yes
			9	Yes
			0	Yes
			Input Select	No
			Input Select / PROGRESSIVE	No
			UP/CH+	Yes
			DOWN/CH-	Yes
			LEFT/ SET- / TRACKING-	Yes
		RIGHT/ SET+ / TRACKING+	Yes	
		VCR/DVD	Yes	
		TV/VCR	Yes	
		DVD MENU	Yes	
		TITLE	Yes	
		SETUP MENU/VCR MENU	Yes	
		SELECT/ENTER	Yes	
		CLEAR/CANCEL	Yes	
		RETURN	Yes	
		PLAY	Yes	
		STOP	Yes	
		PAUSE/STILL/STEP	Yes	
		FF(Cue)/SEARCH+	Yes	
		REW(Review)/SEARCH-	Yes	
		REC/OTR	Yes	
SKIP+ / INDEX+	Yes			
SKIP- / INDEX-	Yes			
AUDIO / AUDIO SELECT	Yes			
ANGLE/COUNTER RESET	Yes			
SUBTITLE/ATR	Yes			
PLAY MODE/SPEED	Yes			
T-REC	Yes			
CLOCK / COUNTER	No			
JUMP/ZERO RETURN	Yes			
ZOOM	Yes			
REPEAT A-B	Yes			
SLOW (Forward)	Yes			

## GENERAL SPECIFICATIONS

		MARKER	Yes		
		OPEN/CLOSE	Yes		
		EJECT	Yes		
G-15	Features (DVD)	Auto Power Off	No		
		Parental Lock	Yes		
		Video CD Playback	No		
		MP3 Playback	No		
		WMA Playback	No		
		JPEG Playback	No		
		Progressive Scan Out	No		
		Digital Out	Dolby Digital	Yes	
			MPEG	Yes	
			PCM	Yes	
			DTS	No	
		Down Mix Out	(Dolby Digital)	Yes	
			(DTS)	No	
		Spatializer (N-2-2)		No	
		Screen Saver		Yes	
Tray Lock		No			
Auto Stop		No			
Audio DAC		192kHz / 24bit			
	Features (VCR)	Auto Head Cleaning	Yes		
		Auto Power Off	No		
		Forward/Reverse Picture Search	Yes		
		VIDEO PLUS+ (SHOWVIEW, G-CODE)	No		
		One Touch Playback	No		
		Auto CH Memory	Yes		
		AREA CODE	No		
		Auto Clock Set	Yes		
		Index Search	Yes		
		SQPB	No		
		CATV	Yes		
		Energy Star	No		
		MTS (SAP)	Yes		
CM Skip (30sec x 6 Times)	No				
Copy (Disc to Tape)	No				
G-16	Accessories	Owner's Manual	Language	English / French	
			w/Guarantee Card	No	
		Remote Control Unit		Yes	
		Guarantee Card		Yes	
		Registration Card		No	
		Warning Sheet		No	
		Service Station List		No	
		Important Tag		No	
		AC Plug Adapter		No	
		Quick Set-up Sheet		No	
		Battery		No	
			UM size x pcs	--	
		AC Cord		No	
		AV Cord (1.2m)		Yes	
		75 Ohm Coaxial Cable (0.9m)		Yes	
		S-Video Cable		No	
		21pin cable		No	
		800 No Sticker		No	
		Toll Free Insert Sheet		No	
		Safety Tip		No	
Disney Leaflet		No			
Aladdin Coupon		No			
G-17	Interface	Switch	Front	Power	Yes
				Play	Yes
				Eject (VCR)	Yes
				Stop	Yes
				Rec/OTR	Yes
				Open/Close (DVD)	Yes
				CH +	Yes
				CH -	Yes
				FF/ Search(>>)	Yes
				Rew/Search(<<)	Yes
				Still/Pause	No

## GENERAL SPECIFICATIONS

		Shuttle (Search/REV/FWD)	No
		DVD/VCR	Yes
		Main Power SW	No
	Rear	Attenuator	No
		S-Video/Component Video Selector	No
		RF Out (Slide SW)	No
		Main Power SW	No
	Volume	Phones Volume	No
		Mic Volume	No
		Echo Volume	No
		Rec/OTR	No
	Terminals	Front	Video In
			No
		Audio In	No
		Rear	Video Output
			RCA x1 (Yellow) S-Video x 1 (DVD Signal Only)
			Audio Output
			RCA x 4 (Stereo, White/Red) Coaxial x 1 (Digital Audio,DVD Signal Only)
			Optical Out (Option)
			No
			Video Input (Option)
			No
			Audio Input (Option)
			No
			RF Input / Output
			Yes
			Euro Scart
			No
			AC Inlet
			No
	Indicator	LED	Power
			Yes(GREEN)
			Rec
			Yes (RED)
			T-Rec
			Yes (RED)
			TV/VCR
			Yes (RED)
			DVD
			Yes (RED)
			VCR
			Yes (RED)
			Surround
			No
			Level Meter
			No
<b>G-18</b>	<b>Set Size</b>	Approx. W x D x H (mm)	497.5 x 295 x 149.5
<b>G-19</b>	<b>Weight</b>	Net (Approx.)	4.8 kg(10.5lbs)
		Gross (Approx.)	6.5 kg(14.3lbs)
<b>G-20</b>	<b>Carton</b>	Master Carton	No
		Content	--- Sets
		Material	--- / ---
		Dimensions W x D x H(mm)	---
		Description of Origin	---
		Gift Box	Material
			Single / Full Color
			W/Color Photo Label
			No
			Dimensions W x D x H(mm)
			565 x 408 x 231
			Description of Origin
			Yes
		Drop Test	Natural Dropping At 1 Corner / 3 Edges / 6 Surfaces
		Height (cm)	80 cm
		Container Stuffing	1,160 Sets/40' container
<b>G-21</b>	<b>Material</b>	Cabinet	Front
			PS 94V2 or More / DECABROM
			Top
			PS 94V2 or More / DECABROM
			Bottom
			PS 94V2 or More / DECABROM
		PCB	Non-Halogen Demand
			No
			Eyelet Demand
			No
<b>G-22</b>	<b>Environment</b>	Environmental standard requirement	Green procurement of ORION
		Pb-free	Phase3 (Phase3A)

# DISASSEMBLY INSTRUCTIONS

## 1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

### 1-1: TOP CABINET/FRONT CABINET/ OPERATION 1/2 PCB AND LEG CLASSIC (L,R) (Refer to Fig. 1-1)

1. Remove the 2 screws (1).
2. Remove the LEG, Classic (L,R) Ass'y in the direction of arrow (A).
3. Remove the screw (2).
4. Remove the Top Cabinet in the direction of arrow (B).
5. Remove the 5 screws (3).
6. Remove the Top Cabinet in the direction of arrow (C).
7. Disconnect the following connector: **(CP680 and CP682)**.
8. Unlock the 9 supports (4).
9. Remove the Front Cabinet in the direction of arrow (D).
10. Remove the 9 screws (5).
11. Remove the Operation 1/2 PCB in the direction of arrow (E).




Fig. 1-1

### 1-2: FLAP (Refer to Fig. 1-2)

1. Open Flap to 90° and flex in direction of arrow (A), at the same time slide in direction of arrow (B).
2. Then lift in direction of arrow (C).




Fig. 1-2

### 1-3: DVD DECK/DVD PCB (Refer to Fig. 1-3)

1. Short circuit the position shown in **Fig. 1-3** using a soldering iron. If you remove the DVD Deck with no soldering, the Laser may be damaged.
2. Unlock the support (1) and remove the Deck Top Holder in the direction of arrow (A).
3. Remove the 2 screws (2).
4. Remove the 2 screws (3).
5. Disconnect the following connectors: **(CP501, CP8001)**.
6. Remove the DVD Deck in the direction of arrow (B).
7. Remove the 2 screws (4).
8. Disconnect the following connectors: **(CP2301, CP2302 and CP2303)**.
9. Remove the DVD PCB in the direction of arrow (C).
10. Remove the 3 screws (5).
11. Remove the Front Angle in the direction of arrow (D).




Fig. 1-3

# DISASSEMBLY INSTRUCTIONS

## NOTE

1. Before your operation, please read "PREPARATION OF SERVICING".
2. Use the Lead Free solder.
3. Manual soldering conditions
  - Soldering temperature:  $320 \pm 20^{\circ}\text{C}$
  - Soldering time: Within 3 seconds
  - Soldering combination: Sn-3.0Ag-0.5Cu
4. When Soldering/Removing of solder, use the drawing equipment over the Pick Up Unit to keep the Flux smoke away from it.
5. When installing the DVD Deck, remove all the soldering on the short circuit position after the connection of Pick Up PCB and DVD PCB connector.

## 1-4: VCR DECK (Refer to Fig. 1-4)

### NOTE

Do not remove the cable at the FE Head section. The FE Head may be damaged if you remove the cable by force.

1. Remove the screw (1).
2. Remove the FE Head.
3. Move the Cassette Holder Ass'y to the back side.
4. Remove the 2 screws (2).
5. Remove the 2 screws (3).
6. Disconnect the following connectors:  
**(CP101, CP102 and CP3001).**
7. Remove the VCR Deck in the direction of arrow.




Fig. 1-4

## 1-5: VCR PCB (Refer to Fig. 1-5)

1. Remove the screw (1).
2. Remove the 3 screws (2).
3. Remove the 2 screws (3).
4. Remove the VCR PCB in the direction of arrow.




Fig. 1-5

## 1-6: BOTTOM, PLATE/BOTTOM CABINET AND LEG, BACK (L, R) (Refer to Fig. 1-6)

1. Remove the 4 screw (1).
2. Remove the Bottom, Holder.
3. Remove the Bottom, Plate in the direction of arrow (A).
4. Remove the 4 screws (2).
5. Remove the 2 screws (3).
6. Remove the Bottom, Cabinet and LEG, Black (L,R) in the direction of arrow (B).




Fig. 1-6

# DISASSEMBLY INSTRUCTIONS

## 2. REMOVAL OF VCR DECK PARTS

### 2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Extend the 2 supports ①.
2. Slide the 2 supports ② and remove the Top Bracket.

#### NOTE

1. After installation of the Top Bracket, bend the support ① so that the Top Bracket is fixed.




Fig. 2-1

### 2-2: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




Fig. 2-2

### 2-3: LINK UNIT (Refer to Fig. 2-3)

1. Set the Link Unit to the Eject position.
2. Unlock the support ①.
3. Remove the (A) side of the Link Unit first, then remove the (B) side.




Fig. 2-3

### 2-4: LINK LEVER/FLAP LEVER (Refer to Fig. 2-4)

1. Extend the support ①.
2. Remove the Link Lever.
3. Remove the Flap Lever.




Fig. 2-4

### 2-5: LOADING MOTOR/WORM (Refer to Fig. 2-5-A)

1. Remove the screw ①.
2. Remove the Loading Motor.
3. Remove the Worm.




Fig. 2-5-A

#### NOTE

1. In case of the Worm installation, check if the value of the Fig. 2-5-B is correct.
2. In case of the Loading Motor installation, hook the wire on the Cassette Opener as shown Fig. 2-5-C.
3. When installing the wires between Capstan DD Unit and Loading Motor, connect them correctly as shown Fig. 2-5-D.




Fig. 2-5-B

# DISASSEMBLY INSTRUCTIONS




Fig. 2-5-C




Fig. 2-5-D

## 2-6: TENSION ASS'Y (Refer to Fig. 2-6-B)

1. Turn the Pinch Roller Cam clockwise so that the Tension Holder hook is set to the position of Fig. 2-6-A to move the Tension Arm Ass'y.
2. Remove the Tension Spring.
3. Unlock the 2 supports ① and remove the Tension Band.
4. Unlock the support ② and remove the Tension Arm Ass'y.
5. Unlock the support ③ and remove the Tension Connect.
6. Float the hook ④ and turn it clockwise then remove the Tension Holder.




Fig. 2-6-A




Fig. 2-6-B

### NOTE

1. In case of the Tension Band installation, note the direction of the installation. (Refer to Fig. 2-6-C)
2. In case of the Tension Band installation, install correctly as Fig. 2-6-D.
3. In case of the Tension Connect installation, install as the circled section of Fig. 2-6-E.




Fig. 2-6-C




Fig. 2-6-D




Fig. 2-6-E

## 2-7: T BRAKE ARM/T BRAKE BAND (Refer to Fig. 2-7-A)

1. Remove the T Brake Spring.
2. Turn the T Brake Arm clockwise and bend the hook section to remove it.
3. Unlock the 2 supports ① and remove the T Brake Band.




Fig. 2-7-A

### NOTE

1. In case of the T Brake Band installation, install correctly as Fig. 2-7-B.




Fig. 2-7-B



# DISASSEMBLY INSTRUCTIONS

## 2-8: S REEL/T REEL/IDLER ARM ASS'Y/IDLER GEAR (Refer to Fig. 2-8-A)

1. Remove the S Reel and T Reel.
2. Remove the 2 Polyslider Washers ①.
3. Remove the Idler Arm Ass'y and Idler Gear.

### NOTE

1. Take care not to damage the gears of the S Reel and T Reel.
2. The Polyslider Washer may remain on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch section "A" of S Reel and T Reel. (Use gloves.) (Refer to Fig. 2-8-A) Touching may leave stains on section "A".
5. When you install the reel, clean the shaft and grease it (FG-84M). (If you do not grease, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)




Fig. 2-8-A

### NOTE

1. In case of the S Reel and T Reel installation, check if the correct parts are installed. (Refer to Fig. 2-8-B)
2. In case of the Idler Arm Ass'y installation, install correctly as Fig. 2-8-C. And also set it so that the section "B" of Fig. 2-8-A is placed under the Main Chassis tab.




Fig. 2-8-B




Fig. 2-8-C

## 2-9: CASSETTE OPENER/PINCH ROLLER BLOCK/ P5 ARM ASS'Y (Refer to Fig. 2-9-A)

1. Unlock the support ① and remove the Cassette Opener.
2. Remove the Pinch Roller Block and P5 Arm Ass'y.




Fig. 2-9-A

### NOTE

1. Do not touch the Pinch Roller. (Use gloves.)
2. In case of the Pinch Roller Block and the Pinch Roller Cam installation, install correctly as Fig. 2-9-B.




Fig. 2-9-B



## 2-10: A/C HEAD (Refer to Fig. 2-10-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.

### NOTE


1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-10-B.
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).

# DISASSEMBLY INSTRUCTIONS



## 2-11: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-11)

1. Remove the screw ①.
2. Remove the FE Head.




## 2-12: AHC ASS'Y/CYLINDER UNIT ASS'Y (Refer to Fig. 2-12)

1. Unlock the support ① and remove the AHC Ass'y.
2. Disconnect the following connector: **(CD2001)**.
3. Remove the 3 screws ②.
4. Remove the Cylinder Unit Ass'y.


### NOTE

1. When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.



## 2-13: CAPSTAN DD UNIT (Refer to Fig. 2-13)


1. Remove the Capstan Belt.
2. Remove the screw ①.
3. Remove the Capstan Holder.
4. Remove the 3 screws ②.
5. Remove the Capstan DD Unit.



# DISASSEMBLY INSTRUCTIONS


## 2-14: MAIN CAM/PINCH ROLLER CAM/JOINT GEAR (Refer to Fig. 2-14-A)

1. Remove the E-Ring ①, then remove the Main Cam.
2. Remove the E-Ring ②, then remove the Pinch Roller Cam and Joint Gear.




### NOTE

1. In case of the Pinch Roller Cam and Main Cam installation, install them as shown in the circled section of Fig. 2-14-B so that the markers meet. (Refer to Fig. 2-14-B)
- And also can be seen the Main Chassis hole through the Main Cam maker hole.




## 2-15: LOADING GEAR S/T UNIT (Refer to Fig. 2-15-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Main Rod, Tension Lever, Loading Arm S Unit and Loading Arm T Unit.




### NOTE

1. When you install the Loading Arm S Unit, Loading Arm T Unit and Main Loading Gear, align each marker. (Refer to Fig. 2-15-B)




## 2-16: CLUTCH ASS'Y/RING SPRING/CLUTCH LEVER/ CLUTCH GEAR (Refer to Fig. 2-16-A)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Ass'y and Ring Spring.
3. Remove the Clutch Lever.
4. Remove the Coupling Gear, Coupling Spring and Clutch Gear.



### NOTE


1. In case of the Clutch Ass'y installation, install it with inserting the spring of the Clutch Ass'y into the dent of the Coupling Gear. (Refer to Fig. 2-16-B)



# DISASSEMBLY INSTRUCTIONS



## 2-17: CASSETTE GUIDE POST/INCLINED BASE S/T UNIT/P4 CAP/LED REFLECTOR (Refer to Fig. 2-17-A)

1. Remove the P4 Cap.
2. Unlock the support ① and remove the Cassette Guide Post.
3. Remove the Inclined Base S/T Unit.
4. Remove the screw ②.
5. Remove the LED Reflector.



### NOTE

1. Do not touch the roller of Guide Roller.
2. In case of the P4 Cap installation, install it with parallel for "A" and "B" of Fig. 2-17-B.
3. In case of the Cassette Guide Post installation, install correctly as the circled section of Fig. 2-17-C.



# DISASSEMBLY INSTRUCTIONS

## 3. REMOVAL OF DVD DECK PARTS

### NOTE

1. Disassemble only the DVD DECK PARTS parts listed here. Minute adjustments are needed if the disassembly is done. If the repair is needed except listed parts, replace the DVD MECHA ASS'Y.

### 3-1: TRAY (Refer to Fig. 3-1-A)

1. Set the Tray opened. (Refer to the DISC REMOVAL METHOD AT NO POWER SUPPLY)
2. Unlock the 2 supports ① and remove the Tray.




Fig. 3-1-A

### NOTE

1. In case of the Tray installation, install them as the circled section of Fig. 3-1-B so that the each markers are met.




Fig. 3-1-B

### 3-2: MAIN CHASSIS ASS'Y (Refer to Fig. 3-2-A)

1. Remove the screw ①.
2. Unlock the 2 supports ②.
3. Remove the Insulator (R) from the Main Frame Ass'y.
4. Remove the Main Chassis Ass'y.




Fig. 3-2-A

### NOTE

1. In case of the Main Chassis Ass'y, install it from (1) to (4) in order. (Refer to Fig. 3-2-B)
2. In case of the Main Chassis Ass'y installation, hook the wire on the Main Frame Ass'y as shown Fig. 3-2-C.




Fig. 3-2-B




Fig. 3-2-C

### 3-3: LOADING MOTOR PCB ASS'Y/ LOADING BELT (Refer to Fig. 3-3-A)

1. Remove the Loading Belt.
2. Remove the screw ①.
3. Remove the 2 screws ②.
4. Remove the Loading Motor PCB Ass'y.
5. Remove the Pulley Gear.




Fig. 3-3-A

# DISASSEMBLY INSTRUCTIONS

## NOTE

1. In case of the Pulley Motor installation, check if the value of the Fig. 3-3-B is correct.
2. When installing the Loading Motor PCB Ass'y, install it correctly as Fig. 3-3-C.
3. In case of the Loading Motor PCB Ass'y installation, hook the wire on the Main Frame Ass'y as shown Fig. 3-3-C.




Fig. 3-3-B




Fig. 3-3-C

## 3-4: RACK LOADING/MAIN GEAR/PULLEY GEAR (Refer to Fig. 3-4-A)

1. Press down the catcher ① and slide the Rack Loading.
2. Unlock the support ② and remove the Pulley Gear.
3. Remove the Main Gear.




Fig. 3-4-A

## NOTE

1. In case of the Rack Loading installation, do not mesh it to the Main Gear as shown the Fig. 3-4-B.




Fig. 3-4-B

## 3-5: CLAMPER ASS'Y (Refer to Fig. 3-5-A)

1. Press the Clamper and rotate the Clamper Plate clockwise, then unlock the 3 supports ①.
2. Remove the Clamper Plate, Clamper Magnet and Clamper.




Fig. 3-5-A

## NOTE

1. In case of the Clamper Ass'y installation, install correctly as Fig. 3-5-B.




Fig. 3-5-B

## 3-6: TRAVERSE HOLDER/INSULATOR (F)/INSULATOR (R) (Refer to Fig. 3-6-A)

1. Remove the Traverse Holder.
2. Remove the 2 Insulator (F).
3. Remove the Insulator (R).




Fig. 3-6-A

## NOTE

1. In case of the Insulator (F) installation, install correctly as Fig. 3-6-B.
2. In case of the Insulator (R) installation, install correctly as Fig. 3-6-C.






Fig. 3-6-B

# DISASSEMBLY INSTRUCTIONS






## 3-7: SWITCH PCB ASS'Y/MIDDLE GEAR/FEED MOTOR (Refer to Fig. 3-7-A)

1. Remove the screw ①.
2. Remove the Switch PCB Ass'y.
3. Unlock the support ②.
4. Remove the Middle Gear.
5. Remove the 2 screws ③.
6. Remove the Feed Motor.
7. Remove the Motor Gear.



### NOTE

1. In case of the Motor Gear installation, check if the value of the Fig. 3-7-B is correct.
2. When installing the wire of the Switch PCB Ass'y, install it correctly as Fig. 3-7-C.
3. After the assembly of the Main Chassis Ass'y, hook the wire on the Main Chassis Ass'y as shown Fig. 3-7-D.






## 3-8: FFC WIRE HANDLING

1. When installing the FFC, fold it correctly and install it as shown from Fig. 3-8-A to Fig. 3-8-C.

### NOTE

1. Do not make the folding lines except the specified positions for the FFC.



# DISASSEMBLY INSTRUCTIONS


## 4. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC

### REMOVAL

1. Put Masking Tape (cotton tape) around the Flat Package IC to protect other parts from any damage. (Refer to Fig. 4-1.)

#### NOTE


Masking is carried out on all the parts located within 10 mm distance from IC leads.



2. Heat the IC leads using a blower type IC desoldering machine. (Refer to Fig. 4-2.)

#### NOTE


Do not rotate or move the IC back and forth until IC can move back and forth easily after desoldering the leads completely.



3. When IC starts moving back and forth easily after desoldering completely, pickup the corner of the IC using a tweezers and remove the IC by moving with the IC desoldering machine. (Refer to Fig. 4-3.)

#### NOTE


Some ICs on the PCB are affixed with glue, so be careful not to break or damage the foil of each IC leads or solder lands under the IC when removing it.



4. Peel off the Masking Tape.
5. Absorb the solder left on the pattern using the Braided Shield Wire. (Refer to Fig. 4-4.)

#### NOTE

Do not move the Braided Shield Wire in the vertical direction towards the IC pattern.







# DISASSEMBLY INSTRUCTIONS

## INSTALLATION

1. Take care of the polarity of new IC and then install the new IC fitting on the printed circuit pattern. Then solder each lead on the diagonal positions of IC temporarily. (Refer to Fig. 4-5.)




2. Supply the solder from the upper position of IC leads sliding to the lower position of the IC leads. (Refer to Fig. 4-6.)




3. Absorb the solder left on the lead using the Braided Shield Wire. (Refer to Fig. 4-7.)

### NOTE

Do not absorb the solder to excess.



4. When bridge-soldering between terminals and/or the soldering amount are not enough, resolder using a Thin-tip Soldering Iron. (Refer to Fig. 4-8.)



5. Finally, confirm the soldering status on four sides of the IC using a magnifying glass. Confirm that no abnormality is found on the soldering position and installation position of the parts around the IC. If some abnormality is found, correct by resoldering.

### NOTE

When the IC leads are bent during soldering and/or repairing, do not repair the bending of leads. If the bending of leads are repaired, the pattern may be damaged. So, be always sure to replace the IC in this case.

## KEY TO ABBREVIATIONS

<b>A</b>	<b>A/C</b>	: Audio/Control	<b>H.SW</b>	: Head Switch	
	<b>ACC</b>	: Automatic Color Control	<b>Hz</b>	: Hertz	
	<b>AE</b>	: Audio Erase	<b>I</b>	<b>IC</b>	: Integrated Circuit
	<b>AFC</b>	: Automatic Frequency Control		<b>IF</b>	: Intermediate Frequency
	<b>AFT</b>	: Automatic Fine Tuning		<b>IND</b>	: Indicator
	<b>AFT DET</b>	: Automatic Fine Tuning Detect		<b>INV</b>	: Inverter
	<b>AGC</b>	: Automatic Gain Control	<b>K</b>	<b>KIL</b>	: Killer
	<b>AMP</b>	: Amplifier	<b>L</b>	<b>L</b>	: Left
	<b>ANT</b>	: Antenna		<b>LED</b>	: Light Emitting Diode
	<b>A.PB</b>	: Audio Playback		<b>LIMIT AMP</b>	: Limiter Amplifier
	<b>APC</b>	: Automatic Phase Control		<b>LM, LDM</b>	: Loading Motor
	<b>ASS'Y</b>	: Assembly		<b>LP</b>	: Long Play
	<b>AT</b>	: All Time		<b>L.P.F</b>	: Low Pass Filter
	<b>AUTO</b>	: Automatic		<b>LUMI.</b>	: Luminance
	<b>A/V</b>	: Audio/Video	<b>M</b>	<b>M</b>	: Motor
<b>B</b>	<b>BGP</b>	: Burst Gate Pulse		<b>MAX</b>	: Maximum
	<b>BOT</b>	: Beginning of Tape		<b>MINI</b>	: Minimum
	<b>BPF</b>	: Bandpass Filter		<b>MIX</b>	: Mixer, mixing
	<b>BRAKE SOL</b>	: Brake Solenoid		<b>MM</b>	: Monostable Multivibrator
	<b>BUFF</b>	: Buffer		<b>MOD</b>	: Modulator, Modulation
	<b>B/W</b>	: Black and White		<b>MPX</b>	: Multiplexer, Multiplex
<b>C</b>	<b>C</b>	: Capacitance, Collector		<b>MS SW</b>	: Mecha State Switch
	<b>CASE</b>	: Cassette	<b>N</b>	<b>NC</b>	: Non Connection
	<b>CAP</b>	: Capstan		<b>NR</b>	: Noise Reduction
	<b>CARR</b>	: Carrier	<b>O</b>	<b>OSC</b>	: Oscillator
	<b>CH</b>	: Channel		<b>OPE</b>	: Operation
	<b>CLK</b>	: Clock	<b>P</b>	<b>PB</b>	: Playback
	<b>CLOCK (SY-SE)</b>	: Clock (Syscon to Servo)		<b>PB CTL</b>	: Playback Control
	<b>COMB</b>	: Combination, Comb Filter		<b>PB-C</b>	: Playback-Chrominance
	<b>CONV</b>	: Converter		<b>PB-Y</b>	: Playback-Luminance
	<b>CPM</b>	: Capstan Motor		<b>PCB</b>	: Printed Circuit Board
	<b>CTL</b>	: Control		<b>P. CON</b>	: Power Control
	<b>CYL</b>	: Cylinder		<b>PD</b>	: Phase Detector
	<b>CYL-M</b>	: Cylinder-Motor		<b>PG</b>	: Pulse Generator
	<b>CYL SENS</b>	: Cylinder-Sensor		<b>P-P</b>	: Peak-to Peak
<b>D</b>	<b>DATA (SY-CE)</b>	: Data (Syscon to Servo)	<b>R</b>	<b>R</b>	: Right
	<b>dB</b>	: Decibel		<b>REC</b>	: Recording
	<b>DC</b>	: Direct Current		<b>REC-C</b>	: Recording-Chrominance
	<b>DD Unit</b>	: Direct Drive Motor Unit		<b>REC-Y</b>	: Recording-Luminance
	<b>DEMODO</b>	: Demodulator		<b>REEL BRK</b>	: Reel Brake
	<b>DET</b>	: Detector		<b>REEL S</b>	: Reel Sensor
	<b>DEV</b>	: Deviation		<b>REF</b>	: Reference
<b>E</b>	<b>E</b>	: Emitter		<b>REG</b>	: Regulated, Regulator
	<b>EF</b>	: Emitter Follower		<b>REW</b>	: Rewind
	<b>EMPH</b>	: Emphasis		<b>REV, RVS</b>	: Reverse
	<b>ENC</b>	: Encoder		<b>RF</b>	: Radio Frequency
	<b>ENV</b>	: Envelope		<b>RMC</b>	: Remote Control
	<b>EOT</b>	: End of Tape		<b>RY</b>	: Relay
	<b>EQ</b>	: Equalizer	<b>S</b>	<b>S. CLK</b>	: Serial Clock
	<b>EXT</b>	: External		<b>S. COM</b>	: Sensor Common
<b>F</b>	<b>F</b>	: Fuse		<b>S. DATA</b>	: Serial Data
	<b>FBC</b>	: Feed Back Clamp		<b>SEG</b>	: Segment
	<b>FE</b>	: Full Erase		<b>SEL</b>	: Select, Selector
	<b>FF</b>	: Fast Forward, Flipflop		<b>SENS</b>	: Sensor
	<b>FG</b>	: Frequency Generator		<b>SER</b>	: Search Mode
	<b>FL SW</b>	: Front Loading Switch		<b>SI</b>	: Serial Input
	<b>FM</b>	: Frequency Modulation		<b>SIF</b>	: Sound Intermediate Frequency
	<b>FSC</b>	: Frequency Sub Carrier		<b>SO</b>	: Serial Output
	<b>FWD</b>	: Forward		<b>SOL</b>	: Solenoid
<b>G</b>	<b>GEN</b>	: Generator		<b>SP</b>	: Standard Play
	<b>GND</b>	: Ground		<b>STB</b>	: Serial Strobe
<b>H</b>	<b>H.P.F</b>	: High Pass Filter		<b>SW</b>	: Switch

## KEY TO ABBREVIATIONS

<b>S</b>	<b>SYNC</b>	:	Synchronization
	<b>SYNC SEP</b>	:	Sync Separator, Separation
<b>T</b>	<b>TR</b>	:	Transistor
	<b>TRAC</b>	:	Tracking
	<b>TRICK PB</b>	:	Trick Playback
	<b>TP</b>	:	Test Point
<b>U</b>	<b>UNREG</b>	:	Unregulated
<b>V</b>	<b>V</b>	:	Volt
	<b>VCO</b>	:	Voltage Controlled Oscillator
	<b>VIF</b>	:	Video Intermediate Frequency
	<b>VP</b>	:	Vertical Pulse, Voltage Display
	<b>V.PB</b>	:	Video Playback
	<b>VR</b>	:	Variable Resistor
	<b>V.REC</b>	:	Video Recording
	<b>VSF</b>	:	Visual Search Fast Forward
	<b>VSR</b>	:	Visual Search Rewind
	<b>VSS</b>	:	Voltage Super Source
	<b>V-SYNC</b>	:	Vertical-Synchronization
	<b>VT</b>	:	Voltage Tuning
<b>X</b>	<b>X'TAL</b>	:	Crystal
<b>Y</b>	<b>Y/C</b>	:	Luminance/Chrominance

## SERVICE MODE LIST

This unit is provided with the following SERVICE MODES so you can repair, examine and adjust easily.

To enter to the SERVICE MODE function, press and hold both buttons simultaneously on the main unit or on the main unit and on the remote control for more than the standard time in the appropriate condition. (See below chart.)

In case of the main unit and remote control, press the remote control buttons first, then press the main unit buttons.

Set Condition	Set Key	Set Key	Standard Time	Operations
VCR mode	CH UP	FF	2 sec.	PLAY/REC total hours are displayed on the TV Monitor. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF HOURS USED).  Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
VCR mode	CH UP	PLAY	2 sec.	Initialization of factory VCR data. NOTE: Do not use this for normal servicing. If you set a factory initialization, the memories are reset such as the clock setting, the channel setting, and PLAY/REC total hours.
VCR mode (Playback)	CH UP	STOP	2 sec.	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT".
Power Off	CH DOWN	POWER	2 sec.	VCR operation mode at no connection of DVD. Refer to the "PREPARATION FOR SERVICING" NOTE: Although the DVD is connected, the DVD mode cannot be selected.

Set Condition	Set Key	Remocon Key	Standard Time	Operations
DVD mode (No disc)	REC/OTR	4	2 sec.	Initialization of factory DVD data. NOTE: Do not use this for normal servicing. This function will only work without the setting of DVD disc at DVD mode. While pressing the Remocon Key for more than 2 seconds, press the Set Key simultaneously.
DVD mode (No disc)	STOP	7	3 sec.	Releasing of PARENTAL LOCK. Refer to the "PARENTAL CONTROL - RATING LEVEL". NOTE: The function will only work without the setting of DVD disc at DVD mode.

Method	Operations
Press the ATR button on the remote control for more than 2 seconds during PLAY.	Adjusting of the Tracking to the center position. Refer to the "MECHANICAL ADJUSTMENT" (GUIDE ROLLER) and "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
Make the short circuit between the test point of SERVICE and the GND.	The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape. Refer to the "PREPARATION FOR SERVICING"

# PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage.

Parts replacing time does not mean the life span for individual parts.

Also, long term storage or misuse may cause transformation and aging of rubber parts.

The following list means standard hours, so the checking hours depends on the conditions.

Time Parts Name	500 hours	1,000 hours	1,500 hours	2,000 hours	2,500 hours	Notes
Audio Control Head	■	■	■	●	●	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	●	●	
Capstan Belt		●	●	●	●	Clean the rubber, and parts which the rubber touches.
Pinch Roller	■	●	●	●	●	
Capstan DD Unit		●	●	●	●	
Loading Motor					●	
Tension Band		●	●	●	●	
T Brake Band		●	●	●	●	
Clutch Ass'y		●	●	●	●	
Idler Arm Ass'y		●	●	●	●	
Capstan Shaft	■	■	■	■	■	
Tape Running Guide Post	■	■	■	■	■	
Cylinder Unit	■	●	●	●	●	Clean the Head

■ : Clean

● : Check it and if necessary, replace it.

## CONFIRMATION OF HOURS USED

PLAY/REC total hours can be checked on the screen.

Total hours are displayed in 16 system of notation.

**NOTE: If you set factory initialization, the total hours is reset to "0".**

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.  
The Fig. 1 screen will appear on TV Monitor.
4. After the confirmation of using hours, turn off the power.




Fig. 1

Initial setting content of MEMORY IC.

PLAY/REC total hours.

= (16 x 16 x 16 x thousands digit value)

+ (16 x 16 x hundreds digit value)

+ (16 x tens digit value)

+ (ones digit value)

# PREVENTIVE CHECKS AND SERVICE INTERVALS


## CLEANING

### NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

### 1. AUDIO CONTROL HEAD

Clean the Audio Control Head with a cotton stick soaked by alcohol. Clean the full erase head in the same manner. **(Refer to the figure below.)**



### 2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use gauze moistened with isopropyl alcohol.

### 3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). **(Refer to the figure below.)**

### NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



## WHEN REPLACING EEPROM (MEMORY) IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

**NOTE: INI 34 and INI 35 cannot be set. Because, the total time for the PLAY/REC of the main unit is recorded.**

INIT	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
00	0E	D0	FC	60	C4	64	4A	86	0B	2B	86	32	0A	08	0A	02
10	AF	97	95	8A	A0	57	31	04	88	A5	9F	3A	00	10	BF	00
20	3A	11	22	70	61	3A	3A	00	0B	00	40	85	9A	B0	00	37
30	03	17	---	---	---	---	---	---	---	---	---	---	---	---	---	---

**Table 1**

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.  
ADDRESS and DATA will appear on TV Monitor as **Fig 1**.













**Fig. 1**

4. ADDRESS is now selected and should "blink". Using the Tracking + or - button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
5. Press ENTER to select DATA. When DATA is selected, it will "blink".
6. Again, step through the DATA using Tracking + or - button until required DATA value has been selected.
7. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 7 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.

**After the data input, set to the initializing of shipping.**

10. Turn on the POWER, and set to the VCR mode.
  11. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
  12. After the finishing of the initializing of shipping, the unit will turn off automatically.
- The unit will now have the correct DATA for the new MEMORY IC.

## SERVICING FIXTURES AND TOOLS

<p><b>(For 2 heads model)</b> VHS Alignment Tape JG001 (VN<sub>2</sub>S-LI6<sup>3</sup>) JG001A (VN<sub>2</sub>S-CO<sup>13</sup>) JG001Q (VN<sub>2</sub>S-LI6<sup>3</sup>H) JG001T (VN<sub>2</sub>S-X6<sup>3</sup>)</p> 	<p><b>(For 4 heads model)</b> VHS Alignment Tape JG001B (VN<sub>1</sub>S-LI6<sup>3</sup>) JG001I (VN<sub>1</sub>S-CO<sup>13</sup>) JG001P (VN<sub>1</sub>S-LI6<sup>3</sup>H) JG001S (VN<sub>1</sub>S-X6<sup>3</sup>)</p> 	<p>JG002B Adapter JG002E Dial Torque Gauge (10~90gf•cm) JG002F (60~600gf•cm)</p> 	<p>JG005 Post Adjustment Screwdriver Part No. SV-TG0-030-000 (small)</p> 
<p>JG153 X Value Adjustment Screwdriver</p> 	<p>JG022 Master Plane</p> 	<p>JG024A Reel Disk Height Adjustment Jig</p> 	<p>JG100A Torque Tape (VHT-063)</p> 
<p>JG154 Cable</p> 	<p>JG185 Tentelometer</p> 		

Ref. No.	Part No.	Parts Name	Remarks
JG001	APJG001000	VHS Alignment Tape	Monoscope, 6KHz ( <b>For 2 heads model</b> )
JG001A	APJG001A00	VHS Alignment Tape	Color Bar, 1KHz ( <b>For 2 heads model</b> )
JG001Q	APJG001Q00	VHS Alignment Tape	Hi-Fi Audio ( <b>For 2 heads model</b> )
JG001T	APJG001T00	VHS Alignment Tape	X Value Adjustment ( <b>For 2 heads model</b> )
JG001B	APJG001B00	VHS Alignment Tape	Monoscope, 6KHz ( <b>For 4 heads model</b> )
JG001I	APJG001I00	VHS Alignment Tape	Color Bar, 1KHz ( <b>For 4 heads model</b> )
JG001P	APJG001P00	VHS Alignment Tape	Hi-Fi Audio ( <b>For 4 heads model</b> )
JG001S	APJG001S00	VHS Alignment Tape	X Value Adjustment ( <b>For 4 heads model</b> )
JG002B	APJG002B00	Adapter	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	APJG002E00	Dial Torque Gauge (10~90gf•cm)	Brake Torque (T Reel Ass'y)
JG002F	APJG002F00	Dial Torque Gauge (60~600gf•cm)	VSR Torque, Brake Torque (S Reel)
JG005	APJG005000	Post Adjustment Screwdriver	Guide Roller Adjustment
JG153	APJG153000	X Value Adjustment Screwdriver	X Value Adjustment
JG022	APJG022000	Master Plane	Reel Disk Height Adjustment
JG024A	APJG024A00	Reel Disk Height Adjustment Jig	Reel Disk Height Adjustment
JG100A	APJG100A00	Torque Tape (VHT-063)	Playback Torque, Back Tension Torque During Playback
JG154	APJG154000	Cable	Used to connect the test point of SERVICE and GROUND
JG185	APJG185000	Tentelometer	Confirmation of Tape Tension on Playback

## PREPARATION FOR SERVICING

- While pressing the CH DOWN button on the set for more than 2 seconds, press the POWER button on the set simultaneously at the Power OFF. Although the DVD is connected, the DVD mode cannot be selected.
- Short circuit between **TP3001** and **Ground** with the cable JG154.  
(The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape.)
- In case of using a cassette tape, press the STOP/EJECT button to insert or eject a cassette tape.  
Turn on the power and re-check the cable before checking the trouble points.

**When you servicing with connection of DVD, perform the operations above step 2 to step 3.**



# MECHANICAL ADJUSTMENTS

## 1. CONFIRMATION AND ADJUSTMENT

Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)

### 1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

- Turn on the power and set to the STOP mode.
- Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
- While turning the reel and confirm the following points. Check if the surface "A" of reel disk is lower than the surface "B" of reel disk height adjustment jig (**JG024A**) and is higher than the surface "C". If it is not passed, place the height adjustment washers and adjust to 10(+2, -0)mm.
- Adjust the other reel in the same way.




Fig. 1-1-A




Fig. 1-1-B

### 1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

- Set to the PLAY mode.
- Adjust the adjusting section for the Tension Arm position so that the Tension Arm top is within the standard line of Main Chassis.
- While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.




Fig. 1-2-A




Fig. 1-2-B

### 1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

- Load a video tape (T-120) recorded in standard speed mode. Set the unit to the PLAY mode.
- Install the tentelometer (**JG185**) as shown in **Fig. 1-3**. Confirm that the meter indicates  $20 \pm 2\text{gf}$  in the beginning of playback.

#### • USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)

- After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
- Confirm that the right meter of the torque tape indicates 50~90gf•cm during playback in SP mode.
- Confirm that the left meter of the torque tape indicates 25~40gf•cm during playback in SP mode.




Fig. 1-3

# MECHANICAL ADJUSTMENTS

## 1-4: CONFIRMATION OF VSR TORQUE

1. Install the Torque Gauge (**JG002F**) and Adapter (**JG002B**) on the S Reel. Set to the Picture Search (Rewind) mode. (Refer to Fig.1-4-B)
2. Then, confirm that it indicates 120~180gf•cm.

### NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.



## 1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the S Reel.
3. Install the Torque Gauge (**JG002F**) and Adapter (**JG002B**) on the S Reel. Turn the Torque Gauge (**JG002F**) clockwise.
4. Then, confirm that it indicates 60~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the T Reel.
3. Install the Torque Gauge (**JG002E**) and Adapter (**JG002B**) on the T reel. Turn the Torque Gauge (**JG002E**) counterclockwise.
4. Then, confirm that it indicates 30~50gf•cm.



### NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	S Reel side: S Reel/Tension Band/Tension Connect/Tension Arm Ass'y T Reel side: T Reel/T Brake Band//T Brake Spring/T Brake Arm

## 2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM



Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

### 2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (**JG001** or **JG001B**). (Refer to **SERVICING FIXTURE AND TOOLS**)
2. Connect CH-1 of the oscilloscope to **TP101 (Envelope)** and CH-2 to **TP3002 (SW Pulse)**.
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (**JG005**) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the **ELECTRICAL ADJUSTMENTS**)

### NOTE

After adjustment, confirm and adjust A/C head. (Refer to item 2-2)



## MECHANICAL ADJUSTMENTS

### 2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD

When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001** or **JG001B**). (Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
  - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
  - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
  - a) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.




Fig. 2-2-A




Fig. 2-2-B




Fig. 2-2-C

### 2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)

1. Confirm and adjust the height of the Reel Disk. (Refer to item 1-1)
2. Confirm and adjust the position of the Tension Post. (Refer to item 1-2)
3. Adjust the Guide Roller. (Refer to item 2-1)
4. Confirm and adjust the Audio/Control Head. (Refer to item 2-2)
5. Connect CH-1 of the oscilloscope to **TP3002**, CH-2 to **TP101** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001S** or **JG001T**). (Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-3**.





Fig. 2-3

### 2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP101** and CH-2 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001P** or **JG001Q**). (Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
6. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
7. If the difference are more than 3 steps, set the X Value adjustment driver (**JG153**) to ④ of **Fig. 2-2-B**. Change the X Value and adjust it so that the value becomes within 2 steps.

# MECHANICAL ADJUSTMENTS

## 3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- |                                   |  |
|-----------------------------------|--|
| 1. Tension Connect                | 6. P4 Post   |
| 2. Tension Arm                    | 7. T Brake Spring                                  |
| 3. Guide Roller                   | 8. T Reel  |
| 4. Audio/Control Head             | 9. S Reel  |
| 5. X value adjustment driver hole | 10. Adjusting section for the Tension Arm position |

# ELECTRICAL ADJUSTMENTS

Read and perform this adjustment when repairing the circuits or replacing electrical parts or PCB assemblies.

## 1. BASIC ADJUSTMENT

### CAUTION

- When you exchange IC and Transistor with a heat sink, apply silicon grease (**YG6260M**) on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)

### 1-1: PG SHIFTER



#### CONDITIONS

MODE-PLAYBACK

Input Signal-Alignment Tape (**JG001P**)


#### INSTRUCTIONS

1. Connect CH-1 on the oscilloscope to **TP3002** and CH-2 to **J8001 (Video Out)**.
2. Playback the alignment tape. (**JG001P**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press both CH UP button on the set and the STOP button on the set for more than 2 seconds.




# ELECTRICAL ADJUSTMENTS


## 2. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)



# DVD BLOCK DIAGRAM




# Y/C/AUDIO/CCD/HEAD AMP BLOCK DIAGRAM







# SYSCON BLOCK DIAGRAM




# OPERATION/DISPLAY BLOCK DIAGRAM




# Hi-Fi/DEMODULATOR BLOCK DIAGRAM



# TUNER/JACK BLOCK DIAGRAM




## POWER BLOCK DIAGRAM






PRINTED CIRCUIT BOARDS  
VCR (INSERTED PARTS)  
SOLDER SIDE




PRINTED CIRCUIT BOARDS  
VCR (CHIP MOUNTED PARTS)  
SOLDER SIDE






# PRINTED CIRCUIT BOARDS

## OPERATION SOLDER SIDE




## OPERATION 2 SOLDER SIDE





# MEMORY SCHEMATIC DIAGRAM

## (DVD PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130  
DME031

# MOTOR DRIVE SCHEMATIC DIAGRAM (DVD PCB)



**DM3P(05SD)**

FROM/TO LOADER

CP2301  
09-5000-024-001-001

1	GND
2	F
3	Vref
4	VCC
5	E
6	D
7	C
8	SW1(DVD/CD)
9	VRF(RF_OUT)
10	B
11	A
12	VR(DVD)
13	VR COM
14	VR(CD)
15	GND
16	LD(CD)
17	PD/GND
18	LD(DVD)
19	GND
20	NC
21	T DRV
22	T RTN
23	F DRV
24	F RTN

CP2302  
00\_6232\_005\_006\_800+

5	LD-
4	LD+
3	OPEN
2	GND(D)
1	CLOSE

CP2303  
00\_6232\_006\_006\_800+

6	SW(GND)
5	LIMIT SW
4	SLD-
3	SLD+
2	SP1-
1	SP1+

FROM/TO MPEG/MICON/DSP/RF\_AM

- ← DVD\_CD
- ← DVD\_LD
- ← CD\_LD
- ← VR\_DVD
- ← VR\_CD
- ← RF
- ← OPU\_A
- ← OPU\_B
- ← OPU\_C
- ← OPU\_D
- ← OPU\_E
- ← OPU\_F
- ← VC
- ← HOME
- ← GND (GND\_GND)
- ← TOUT\_SW
- ← TIN\_SW
- ← P.CON\_A5V
- ← TRACK\_PWM
- ← FOCUS\_PWM
- ← P.CON+3.3V
- ← DRVSB
- ← SPINDLE\_PWM
- ← SLED\_PWM
- ← ADCIN\_7
- ← ADCIN\_5
- ← ADCIN\_6
- ← VCC+9V
- ← M\_GND
- ← SPDL\_SENS+
- ← SPDL\_SENS-
- ← TRAY\_CLOSE
- ← TRAY\_OPEN

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.


**ATTENTION** LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130  
DME031

# AUDIO/VIDEO SCHEMATIC DIAGRAM (DVD PCB)



FROM/TO TUNER/JACK


CP8101_1 (CP8001)
IMSA-9604S-14F
V SW 14
Y(G) 13
DVD-H 12
DVD RESET 11
ZERO 10
AUDIO-R 9
GND 8
AUDIO-L 7
GND 6
V(R) 5
GND 4
U(B) 3
GND 2
CVBS 1

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


- ◁ PLAYBACK COLOR SIGNAL
- ◀ PLAYBACK LUMINANCE SIGNAL
- ◄ AUDIO SIGNAL (PB)

- ◀ R.SIGNAL + COMPONENT SIGNAL (U)
- ◄ B.SIGNAL + COMPONENT SIGNAL (V)



PCB130  
DME031

# Y/C/AUDIO/CCD/HEAD AMP SCHEMATIC DIAGRAM (VCR PCB)



FROM/TO POWER

FROM/TO HI-FI/DEMODULATOR

FROM/TO CYL

FROM/TO HEAD AUDIO CONTROL

TO FULL ERASE HEAD

FROM/TO TUNER/JACK


FROM/TO SYSCON

- ▶▶▶ PLAYBACK VIDEO SIGNAL
- ▶▶▶ RECORD COLOR SIGNAL
- ▶▶▶ RECORD LUMINANCE SIGNAL
- ▶▶▶ AUDIO SIGNAL (REC)
- ▶▶▶ AUDIO SIGNAL (PB)
- ▶▶▶ PLAYBACK COLOR SIGNAL
- ▶▶▶ PLAYBACK LUMINANCE SIGNAL
- ▶▶▶ TUNER VIDEO SIGNAL

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.






NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

CAUTION: DIGITAL TRANSISTOR




PCB010  
DME043

# SYSCON SCHEMATIC DIAGRAM (VCR PCB)




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.



PCB010 DME043

# TUNER/JACK SCHEMATIC DIAGRAM (VCR PCB)



CAUTION: DIGITAL TRANSISTOR

CAUTION: DIGITAL TRANSISTOR

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED WITH A WARNING SYMBOL ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN AVERTISSEMENT ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIÈCES.

- PLAYBACK VIDEO SIGNAL
- TUNER VIDEO SIGNAL
- PLAYBACK LUMINANCE SIGNAL
- PLAYBACK COLOR SIGNAL

- RECORD COLOR SIGNAL
- RECORD LUMINANCE SIGNAL
- AUDIO SIGNAL(REC)
- AUDIO SIGNAL(PB)
- DIGITAL AUDIO SIGNAL(PB)




# OPERATION/DISPLAY SCHEMATIC DIAGRAM (VCR PCB)

FROM/TO OPERATION2

CP652\_1 (CP682)  
00\_6232\_018\_006\_800+

18	NC
17	GND
16	NC
15	GND
14	NC
13	GND
12	KEY-A
11	KEY-B
10	VCR LED
9	GND
8	REM IN
7	AT+5.2V
6	GND
5	POWER ON LED
4	TV/VCR LED
3	REC LED
2	T-REC LED
1	DVD LED



FROM/TO SYSCON


- ← DVD\_LED
- ← VCR\_LED
- ← 1G/VCR/T-REC\_LED
- ← 2G/DUB/REC\_LED
- ← 3G/TV/VCR\_LED
- REM\_IN
- KEY-B
- KEY-A
- ← VIDEO\_MUTE-H

FROM/TO POWER


- ← P.CON+5V
- ← AT+5.2V
- ← GND

FROM/TO OPERATION1


5	DVD_LED
4	GND
3	NC
2	KEY-A
1	KEY-B



CAUTION: DIGITAL TRANSISTOR



CAUTION: DIGITAL TRANSISTOR




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCB010  
DME04

# Hi-Fi/DEMODULATOR SCHEMATIC DIAGRAM (VCR PCB)




NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

◁ AUDIO SIGNAL (REC)  
 ◀ AUDIO SIGNAL (PB)

PCB010 DME043

# POWER SCHEMATIC DIAGRAM (VCR PCB)



**CAUTION** FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE FUSE 2.5A 125V (F501).

**ATTENTION** POUR UNE PROTECTION CONTINUE LES RISQUES D'INCENDIE N'UTILISER QUE DES FUSIBLE DE MEME TYPE 2.5A 125V (F501).

**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIECES REPAREES PAR UN ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRIRES DANS LA NOMENCLATURE DES PIECES.

**NOTE:** THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


**NOTE:** THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

**CAUTION:** DIGITAL TRANSISTOR

- FROM/TO Y/C/AUDIO/ICCD/H.AMP
  - P.CON+5V
  - GND
- FROM/TO SYSCON
  - TX
  - RX
  - AT+5.2V
  - DVD\_POWER\_CTL
  - VCR\_POWER\_ON-L
  - POWER\_FAIL
  - AT+5V(M-CON)
  - AT+12.6\_V
  - P.CON+5V
  - GND
  - MOTOR\_GND
- FROM/TO TUNER/JACK
  - P.CON+9V
  - SPDIF
  - +32V
  - AT+5.2V
  - P.CON+5V
  - P.CON+12V
  - GND
- FROM/TO OPERATION/DISPLAY
  - P.CON+5V
  - AT+5.2V
  - GND
- FROM/TO HI-FI/DEMODULATOR
  - P.CON+9V
  - P.CON+5V
  - AT+5.2V
  - GND
- FROM/TO MPEG/MICON/DSP/RF AMP
 


CP501 (CD4002)	A2001WV2-11P	GND(D)	1
		GND(D)	2
		TX	3
		RX	4
		GND(M)	5
		P.CON+9V	6
		P.CON+5V	7
		UNREG+3.8V	8
		UNREG+3.8V	9
		GND(A)	10
		SPDIF	11

# OPERATION 1 SCHEATIC DIAGRAM




PCB270  
DEE072

# OPERATION 2 SCHEMATIC DIAGRAM



PCB280  
DEE073

# INTERCONNECTION DIAGRAM












**CAUTION** SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION** LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIÈCES.


NOTE: THIS INTERCONNECTION DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

# WAVEFORMS


## MPEG/MICON/DSP/RF\_AMP






## Y/C/AUDIO/CCD/HEAD AMP



## SYSCON



## AUDIO/VIDEO















**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.



# WAVEFORMS

## Hi-Fi/DEMODULATOR

## TUNER/JACK




## TUNER/JACK



**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.




# MECHANICAL EXPLODED VIEW






## CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315071000	MG-33	AB
	Y31D011000	FG-84M	AC
	Y315041000	FL-721	AD
	Y315141000	G-313Y	AE

**NOTE:** Applying positions AA, AB, AC, AD and AE for the grease are displayed for this section. Check if the correct grease is applied for each position.

# DVD DECK EXPLODED VIEW



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315121000	SF-112	AB

**NOTE:** Applying positions AA and AB for the grease are displayed for this section.  
Check if the correct grease is applied for each position.

# MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION		
101	7A701A217A	FRONT CABI ASS'Y		
101A	701WPJC809	CABINET,FRONT		
101B	712WPJC063	FLAP,DVD		
101C	712WPJC064	FLAP,VCR		
101D	713WPA0338	GLASS,LED1		
101E	713WPA0339	GLASS,LED2		
101F	713WPA0340	GLASS,LED3		
101G	713WPA0341	GLASS,LED-BUTTON		
101H	713WPA0342	GUIDE,REMOCON		
101I	738WPJA014	BUTTON,OPEN		
101J	738WPJA015	BUTTON,FRAME		
101K	738WPJA016	BUTTON,FRAME PRINCESS		
101L	742WKA0001	SPRING,DVD-FLAP		
101M	743WKA0042	SPRING,FLAP		
101N	761WPA0335	HOOK,BOTTOM		
101O	761WPA0345	HOOK,TOP(L)		
101P	761WPA0346	HOOK,TOP(R)		
102	7A702A079A	CABINET BOTTOM ASS'Y		
102A	702WPBA189	CABINET,BOTTOM		
102B	704WPA0037	LEG,BACK(L)		
102C	704WPA0038	LEG,BACK(R)		
103	701WPA0751	HOLDER,DECK		
104	702WPBA188	CABINET,TOP		
105	761WPA0261	HOLDER,DVD BR		
106	85OP700038	HOLDER,END SENSOR		
107	702WSA0217	PLATE,BOTTOM		
108	722616A025	SHEET,RATING		
109	761WPA0321	HOLDER,DVD BL		
110	753WUA0065	SPRING,EARTH		
111	726000A073	SHEET CAUTION		
112	761WPA0262	HOLDER,DECK TOP		
113	752WSA0290	SHIELD,COMPO		
114	701WPA0686	HOLDER,DECK		
115	725000A082	SHEET,BACK PR		
116	761WSAA025	ANGLE,FRONT		
117	702WSA0212	CABINET,TOP		
118	8965TS1010	CUSHION	65TS10-10(10x10x25)	
119	7A704A003A	LEG PRINCESS (R)ASS'Y		
120	7A704A004A	LEG PRINCESS (L)ASS'Y		
121	761WPA0332	HOLDER,BOTTOM		
122	8965TS1017	CUSHION	65TS10-10(17.5x20x14)	
201	8109130B9U	SCREW,TAP TITE(B)R	PAN	3x29
202	810923070U	SCREW TAP TITE(B) R	BIND	3x7
203	8109130A0U	SCREW TAP TITE(B)	WH7	3x10
204	810923080U	SCREW TAP TITE(B)	BIND	3x8
205	8109K3060U	SCREW,TAP TITE(B)	BIND(3D)	3x6
206	810713040U	SCREW,TAP TITE(S)	PAN	3x4
207	811022680U	SCREW TAP TITE(P)	BIND	2.6x8
208	810F13080U	SEMS(F)		3x8
209	810722660U	SCREW,TAP TITE(S)	BIND	2.6x6
210	811022680U	SCREW TAP TITE(P)	BIND	2.6x8
211	8154D3033U	SCREW,TAP TITE(B)	WH8	3x33R
212	8110630A0U	SCREW TAP TITE(P)	BRAZIER	3x10
---	791WHAA112	GIFT,SHEET		
---	792WHA0561	PACKAGE,TOP		
---	792WHA0562	PACKAGE,BOTTOM		
---	793WCDC552	GIFT,BOX		
---	A2F3PEH975	INSTRUCTION BOOK KIT		
---	J2F3PE02A	WARRANTY SHEET(E/F)		
---	J2F3PE21A	INSTRUCTION BOOK		
---	JB5UD200	POLYBAG INSTRUCTION(RED CAUTION)		

# CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300	A2F3PDH420K	DECK ASSY A2F3PDH420K	501	810722680U	SCREW,TAP TITE(S) BIND M2.6x8
301	85OA400245	PINCH ROLLER BLOCK VA2	502	83ETW3000U	E-RING 3
302	85OA500026	AHC ASS'Y	503	810722640U	SCREW,TAP TITE(S) BIND M2.6x4
303	85OP200290	BELT,CAPSTAN (S)	504	810212060U	SCREW,PAN M2x6
304	85OP600581	WORM	505	810912660U	SCREW,TAP TITE(B) PAN M2.6x6
305	85OP500083	BASE,AC HEAD	506	810A13040U	SCREW/WASHER(A) M3x4
306	85OP800324	SPRING,AC HEAD	507	810A12650U	SCREW/WASHER(A) M2.6x5
307	85OA000528	MAIN CHASSIS ASS'Y	508	82Q264713N	POLYSLIDER WASHER 2.6x4.7xT0.13
308	85OA200089	CLUTCH ASS'Y	509	82P184505N	POLYSLIDER WASHER(CUT) 1.8x4.5xT0.5
309	85OA200092	ARM IDLER ASS'Y	510	810722660U	SCREW,TAP TITE(S) BIND 2.6x6
310	85OA300068	LOADING ARM S UNIT	CD1501	122H071704	CORD JUMPER 2H071704
311	85OA300070	LOADING ARM T UNIT	CD1502	122Y021902	CORD JUMPER 2Y021902
312	85OA400223	INCLINED BASE T UINT 3S	H5001	1523Q91004	HEAD,AUDIO CONTROL VTR-1X2RPE22-772
313	85OA400249	P5 ARM ASS'Y 2	H5002	1543Q02014	HEAD (FULL ERASE) VTR-1X2ERS11-154
314	85OA400248	TENSION ARM ASS'Y 2	△ M101	1596S98002	MOTOR,LOADING MDB2B66B
315	85OA400231	INCLINED BASE S UNIT	△ M2001	1510S98044	CAPSTAN DD UNIT F2QVB73B
316	85OA900234	CASS HOLDER ASS'Y	△ M2003	1589S11025	MICRO MOTOR I20AL34K
317	85OP900745	CASS,OPENER	△ UN4001	A2F3PDH500	CYLINDER UNIT ASS'Y A2F3PDH500
318	85OP700035	REFLECTOR,LED			
319	85OP900755	BRACKET, TOP 3V			
320	85OP400554	HOLDER,CAPSTAN			
321	85OA900233	LINK UNIT			
322	85OP000496	POST,CASS GUIDE			
323	85OP200316	REEL,S (S)			
324	85OP200317	REEL,T (S)			
325	85OP200308	GEAR, IDLER			
326	85OP200311	GEAR,CLUTCH			
327	85OP200312	GEAR,COUPLING			
328	85OP200313	LEVER,CLUTCH			
329	85OP300194	GEAR,MAIN LOADING			
330	85OP400490	LEVER,TENSION			
331	85OP400492	HOLDER,TENSION			
332	85OP400520	CAP.P4			
333	85OP400542	BAND,TENSION			
334	85OP400533	CONNECT,TENSION			
335	85OP600573	ARM,BRAKE T			
336	85OP600584	BAND,BRAKE T			
337	85OP600577	CAM,PINCH ROLLER			
338	85OP600578	CAM,MAIN			
339	85OP600585	ROD,MAIN			
340	85OP600582	GEAR,JOINT			
341	85OP800322	SPRING,TENSION			
342	85OP800360	SPRING,BRAKE T			
343	85OP800355	SPRING,COUPLING			
344	85OP800356	SPRING,RING			
345	85OP900754	LEVER,LINK			
346	85OP900744	LEVER,FLAP			

# DVD DECK REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
△ 600	A2F3PDH650	DVD MECHA ASS'Y	A2F3PDH650
601	92P100109A	HOLDER, TRAVERSE	
602	92P100094A	CLAMPER	
603	92P100088A	GEAR, MOTOR	
604	92P100108A	GEAR, MIDDLE	
605	92P200013A	INSULATOR(F)	
606	92P200014A	INSULATOR(R)	
607	92SBB0029A	LOADER SUB ASS'Y	
608	92P100095A	GEAR, PULLEY	
609	92P100097A	PULLEY, MOTOR	
610	92P100096A	GEAR, MAIN	
611	92P200012A	BELT, LOADING	
612	92P000014A	PLATE, CLAMPER	
613	92P100093A	RACK, LOADING	
614	92P100091A	FRAME, MAIN	
615	92P100092A	TRAY	
616	800WFAA008	CUSHION C	
617	7230007850	SHEET, FFC	
701	811022680U	SCREW TAP TITE(P) BIND	2.6x8
702	814011723U	SCREW, PAN	M1.7x2.3 P3
703	816112080U	SEMS. TAP TITE(P) PAN	W10 2x8
704	814011730U	SCREW, PAN	M1.7x3 P3
705	811022080U	SCREW, TAP TITE(P) BIND	2x8
CD2001	122H001901	CORD JUMPER	2H001901
CD2301	122H062102	CORD JUMPER	2H062102
CD2302	122H052601	CORD JUMPER	2H052601
△ M2602	1515S98003	FEED MOTOR	BCZ3B03B
△ M2603	1596S18003	MOTOR, LOADING	BCZ3B52B
PCB610	A5R801V610	PCB ASS'Y	DED003A
PCB640	A2F401H640	PCB ASS'Y	DED012B
SW1	0515S32002	SWITCH	SSS-13-2
SW2	0500101037	PUSH SWITCH	ESE22MH24

# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>RESISTORS</b>			<b>ICS</b>		
△ R501	R0G3K2335K	RC 3.3M OHM 1/2W	△ IC2301	I03F065650	IC LA6565-TE-L-E
△ R502	R3X181010J	R,METAL OXIDE 1 OHM 1W	IC2304	I07J003580	IC BA10358FV-E2
△ R503	R002T2155J	RC 1.5M OHM 1/2W	IC3001	I54F50147A	IC OEC0147A
△ R504	R002T2561J	RC 560 OHM 1/2W	IC3003	I9UF032310	IC PST3231NR
△ R512	R3X181683J	R,METAL OXIDE 68K OHM 1W	IC3099	A2F3P4H015	INIT DATA BR24L02F-WE2
△ R516	R63881R22J	R,FUSE 0.22 OHM 1W	IC4001	ICQK068620	IC ZR36862PQCG
△ R517	R002T2102J	RC 1K OHM 1/2W	IC4002	I57J0L02F0	IC BR24L02F-WE2
<b>CAPACITORS</b>			<b>TRANSISTORS</b>		
△ C501	E02LF2222M	CE 2200 UF 16V	△ IC4003	I07F9E00W0	IC BA33E00WHFP-TR
△ C502	P2122B224M	CMP 0.22 UF 275V ECQUL	IC4005	IFLJ0632H7	IC K4S641632H-UC75
△ C504	E02LF1222M	CE 2200 UF 10V	IC4007	ICMJ0CEKE8	IC SST39VF800A-70-4C-EKE
△ C505	E02LU2101M	CE 100 UF 16V	IC8001	I04J045800	IC RC4580IDR
△ C511	E62QFC470M	CE 47 UF 200V	IC8003	I0UF015110	IC MM1511XNRE
△ C513	C03L0R7H2K	CC 220 PF 2KV R	IC8005	I0UF015010	IC MM1501XNRE
△ C514	E02LU2101M	CE 100 UF 16V	IC8102	I17F017530	IC PCM1753DBQR
△ C515	C0J0B0514K	CC 0.01 UF 500V B	Q101	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ C516	CC3LE0MH3M	CC 0.0022UF 250V	Q102	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ C518	E61FF0222D	CE 2200 UF 6.3V	Q103	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
△ C519	E02LU2101M	CE 100 UF 16V	Q104	TCAT032034	TRANSISTOR, SILICON KTC3203_Y-AT
△ C525	C03L0R7U2K	CC 680 PF 2KV R	Q105	TAATA12660	TRANSISTOR,SILICON KTA1266-AT(Y,GR)
△ C526	CC3LE0MH3M	CC 0.0022UF 250V	Q107	T6YJ1037K0	TRANSISTOR,SILICON 2SA1037AKT146R,S
△ C531	C0JTB05S2K	CC 560 PF 500V B	Q109	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ C540	E62QFC470M	CE 47 UF 200V	Q301	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
<b>DIODES</b>			△ Q501	T25F035630	FET 2SK3563(ORION_Q)
D501	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q502	TCAT032034	TRANSISTOR, SILICON KTC3203_Y-AT
△ D502	D2WXN40050	DIODE SILICON 1N4005-EIC	△ Q503	TCAT03209Y	TRANSISTOR SILICON KTC3209_Y-AT
△ D503	D2WXN40050	DIODE SILICON 1N4005-EIC	△ Q504	TAAT012714	TRANSISTOR, SILICON KTA1271_Y-AT
D504	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q505	TD3T018350	TRANSISTOR SILICON 2SD1835S/T-AA
△ D505	D2WXN40050	DIODE SILICON 1N4005-EIC	Q506	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D506	D2WXN40050	DIODE SILICON 1N4005-EIC	△ Q507	TCAT032034	TRANSISTOR, SILICON KTC3203_Y-AT
△ D507	D23TGP15J0	DIODE SILICON RGP15J-G23	Q509	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D508	D1VT001330	DIODE,SILICON 1SS133T-77	△ Q510	TD3T018350	TRANSISTOR SILICON 2SD1835S/T-AA
D509	D2WXGP10J0	DIODE RECTIFIER RGP10J-EIC	Q513	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ D510	D97U02201B	DIODE ZENER MTZJ22B T-77	Q514	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ D511	D2LKB340L0	DIODE SCHOTTKY SB340L-6737	Q666	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D512	D1VT001330	DIODE,SILICON 1SS133T-77	Q668	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D513	D2WXN40050	DIODE SILICON 1N4005-EIC	Q2301	T67J1036K0	TRANSISTOR SILICON 2SA1036KT146
D514	D97U01201B	DIODE,ZENER MTZJ12B T-77	Q2302	T67J048TL0	TRANSISTOR SILICON 2SA2048TL
△ D515	D28T21DQNA	DIODE SCHOTTKY 21DQ04N-TA2B1	Q2303	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D516	D97U05R11B	DIODE,ZENER MTZJ5.1B T-77	Q2304	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D518	D1VT001330	DIODE,SILICON 1SS133T-77	Q2305	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
△ D519	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77	Q3002	0002700690	PHOTO COUPLER RPI-303
△ D522	D28T0ERB20	DIODE RECTIFIER 10ERB20-TA1B2	Q3003	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
△ D523	D97U03301B	DIODE,ZENER MTZJ33B T-77	Q3004	0002700680	PHOTO COUPLER RPI-352C40N
D524	D1VT001330	DIODE,SILICON 1SS133T-77	Q3005	0002700680	PHOTO COUPLER RPI-352C40N
D526	D97U03R31B	DIODE,ZENER MTZJ3.3B T-77	Q3006	0000M00390	PHOTO TRANSISTOR ST-304L
△ D527	D2WXN40050	DIODE SILICON 1N4005-EIC	Q3007	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D528	D1VT001330	DIODE,SILICON 1SS133T-77	Q3008	0000M00390	PHOTO TRANSISTOR ST-304L
△ D529	D2WXN40050	DIODE SILICON 1N4005-EIC	Q8001	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D680	0021E2Q140	LED LTL-1CHEE-002A	Q8002	TNYJD05001	COMPOUND TRANSISTOR DTC144EKAT146
D681	0021E2Q140	LED LTL-1CHEE-002A	Q8003	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D682	0021E2Q140	LED LTL-1CHEE-002A	Q8004	TAATA12660	TRANSISTOR,SILICON KTA1266-AT(Y,GR)
D683	0021E2Q140	LED LTL-1CHEE-002A	Q8005	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D684	0021E2Q140	LED LTL-1CHEE-002A	Q8006	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D686	0021E5Q210	LED LTL-1CHGE-002A	Q8007	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D2303	DD7R0S3550	DIODE SILICON 1SS355 TE-17	Q8008	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D2304	DD7R0S3550	DIODE SILICON 1SS355 TE-17	Q8009	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D3001	0010E00330	INFRARED LED LTE-3271T-012A-O	Q8010	TPYJA05001	COMPOUND TRANSISTOR DTA143EKAT146
D3002	D1VT001330	DIODE,SILICON 1SS133T-77	Q8011	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D3007	D1VT001330	DIODE,SILICON 1SS133T-77	Q8012	T8YJ2412K0	TRANSISTOR SILICON 2SC2412KT146 R,S
D3009	D1VT001330	DIODE,SILICON 1SS133T-77	Q8019	T6YJ1037K0	TRANSISTOR,SILICON 2SA1037AKT146R,S
D4002	DD7R0S3550	DIODE SILICON 1SS355 TE-17	Q8020	T6YJ1037K0	TRANSISTOR,SILICON 2SA1037AKT146R,S
D4003	DD7R0S3550	DIODE SILICON 1SS355 TE-17	Q8023	T6YJ1037K0	TRANSISTOR,SILICON 2SA1037AKT146R,S
D4004	DD7R0S3550	DIODE SILICON 1SS355 TE-17	Q8101	TNYJD05001	COMPOUND TRANSISTOR DTC144EKAT146
D4005	DD7R0S3550	DIODE SILICON 1SS355 TE-17	<b>COILS &amp; TRANSFORMER</b>		
D8004	D1VT001330	DIODE,SILICON 1SS133T-77	L101	031626010R	COIL,BIAS OSC 1626010
D8005	D1VT001330	DIODE,SILICON 1SS133T-77	L102	02167F101J	COIL 100 UH
D8006	D1VT001330	DIODE,SILICON 1SS133T-77	L103	021LA65R6K	COIL 5.6 UH
D8101	DD7R0S3550	DIODE SILICON 1SS355 TE-17	L104	02167F220J	COIL 22 UH
D8111	DD7R0S3550	DIODE SILICON 1SS355 TE-17	L107	02167F220J	COIL 22 UH
D8112	DD7R0S3550	DIODE SILICON 1SS355 TE-17	L301	02167F220J	COIL 22 UH
<b>ICS</b>			△ L501	029X000117	COIL,LINE FILTER SS11VL-05230
IC101	I03F3206ME	IC LA71206M-MPB-E	L505	02167F220J	COIL 22 UH
△ IC501	I1KJ9A431A	IC KIA431A-AT	L506	02167E220K	COIL 22 UH
△ IC502	I1KA98R09A	IC KIA78R09API	L701	021LA6220J	COIL 22 UH
△ IC503	000220002W	PHOTO COUPLER PS2561AL1-1-V(W)	L702	021LA6220J	COIL 22 UH
IC701	I03F670BM0	IC LA72670BM-L-MPB-E	L703	02167F220J	COIL 22 UH



# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>COILS &amp; TRANSFORMER</b>			<b>MISCELLANEOUS</b>		
L704	02167F220J	COIL 22 UH	CP2301	069GYOT119	CONNECTOR PCB SIDE 09-5000-024-001-001
L705	02167F220J	COIL 22 UH	CP2302	069EV53030	CONNECTOR PCB SIDE 00_6232_005_006_800+
L3002	02167E220K	COIL 22 UH	CP2303	069EV63030	CONNECTOR PCB SIDE 00_6232_006_006_800+
L3003	021LA6120J	COIL 12 UH	△CP3001	06972C0010	CONNECTOR PCB SIDE TMC-J12P-B2
L4001	02167F2R2J	COIL 2.2 UH	CP681A	067U003029	WIRE HOLDER B2013H02-3P
L8001	021LA6R33M	COIL 0.33 UH	CP681B	067U003029	WIRE HOLDER B2013H02-3P
L8002	021LA6R33M	COIL 0.33 UH	CP8001	069J7E0599	CONNECTOR PCB SIDE IMSA-9604S-14C
L8006	02167F101J	COIL 100 UH	CP8101	069J7E0589	CONNECTOR PCB SIDE IMSA-9604S-14F
L8007	02167F101J	COIL 100 UH	△F501	081PC2R505	FUSE 51MS025L
L8009	02167F101J	COIL 100 UH	FH501	06710T0009	HOLDER,FUSE EYF-52BCY
L8010	02167F101J	COIL 100 UH	FH502	06710T0009	HOLDER,FUSE EYF-52BCY
L8104	02167F1R0K	COIL 1 UH	OS680	077Q037002	REMOTE RECEIVER PIC-37143TH5
L8105	02167F1R0K	COIL 1 UH	TM601	076R0JT020	TRANSMITTER R56-0539
△T501	0481291244	TRANSFORMER,SWITCHING 81291244	△TU301	0162300044	RF UNIT 115-V-HA35ARE
<b>JACKS</b>			X101	100DT3R528	CRYSTAL HC-49/U
J8001	060J411031	RCA JACK MSP-213V1-432_NI_LF	X3001	100GT01006	CRYSTAL B10000C001
J8006	060J411033	RCA JACK MSP-213V1-732_NI_LF	X3002	100DA32R01	CRYSTAL DT-26
J8008	063D700008	JACK MDC-070V-B_LF	X4001	100BT02701	CRYSTAL HC-49U/S
<b>SWITCHES</b>			<b>RESISTOR</b>		
SW680	0504R01T38	SWITCH TACT EVQ11L05R	RC.....		CARBON RESISTOR
SW681	0504R01T38	SWITCH TACT EVQ11L05R			
SW682	0504R01T38	SWITCH TACT EVQ11L05R			
SW683	0504R01T38	SWITCH TACT EVQ11L05R			
SW684	0504R01T38	SWITCH TACT EVQ11L05R			
SW691	0504R01T38	SWITCH TACT EVQ11L05R			
SW692	0504R01T38	SWITCH TACT EVQ11L05R			
SW693	0504R01T38	SWITCH TACT EVQ11L05R			
SW694	0504R01T38	SWITCH TACT EVQ11L05R			
SW695	0504R01T38	SWITCH TACT EVQ11L05R			
SW696	0504R01T38	SWITCH TACT EVQ11L05R			
SW3001	0508S11001	SWITCH (LEAF) LSA-1144EAU			
<b>P.C.BOARD ASSEMBLIES</b>			<b>CAPACITORS</b>		
PCB010	A2F3PEH010	PCB ASS'Y DME043A	CC.....		CERAMIC CAPACITOR
PCB130	A2F3PEH130	PCB ASS'Y DME031A	CE.....		ALUMI ELECTROLYTIC CAPACITOR
PCB270	A2F3PEH270	PCB ASS'Y DEE072A	CP.....		POLYESTER CAPACITOR
PCB280	A2F3PEH280	PCB ASS'Y DEE073A	CPP.....		POLYPROPYLENE CAPACITOR
<b>MISCELLANEOUS</b>			CPL.....		PLASTIC CAPACITOR
B501	024HT03563	CORE,BEADS W4BRH3.5X6X1.0X2	CMP.....		METAL POLYESTER CAPACITOR
B2301	0246C51024	CORE,BEADS MMZ1608R102CT	CMP.....		METAL PLASTIC CAPACITOR
B2302	0246C51024	CORE,BEADS MMZ1608R102CT	CMP.....		METAL POLYPROPYLENE CAPACITOR
B2303	0246C51024	CORE,BEADS MMZ1608R102CT			
B2304	0246C51024	CORE,BEADS MMZ1608R102CT			
B2305	0246C51024	CORE,BEADS MMZ1608R102CT			
B4001	0246C51024	CORE,BEADS MMZ1608R102CT			
B4002	0246C51024	CORE,BEADS MMZ1608R102CT			
B4003	0246C51024	CORE,BEADS MMZ1608R102CT			
B4005	0246C51024	CORE,BEADS MMZ1608R102CT			
B4006	0246C51024	CORE,BEADS MMZ1608R102CT			
B4007	0246C51024	CORE,BEADS MMZ1608R102CT			
B4008	0246C51024	CORE,BEADS MMZ1608R102CT			
B4009	0246C51024	CORE,BEADS MMZ1608R102CT			
B4010	0246C51024	CORE,BEADS MMZ1608R102CT			
B4011	0246C51024	CORE,BEADS MMZ1608R102CT			
B4012	0246C51024	CORE,BEADS MMZ1608R102CT			
B4013	0246C51024	CORE,BEADS MMZ1608R102CT			
B4014	0246C51024	CORE,BEADS MMZ1608R102CT			
B4016	0246C51024	CORE,BEADS MMZ1608R102CT			
B4018	0246C51024	CORE,BEADS MMZ1608R102CT			
B8103	0246C51024	CORE,BEADS MMZ1608R102CT			
CD102	122F041508	CORD JUMPER 2F041508			
CD103	W9L6012042	FLAT CABLE AWM2468 AWG26 2C BLACK 120MM			
△CD501	1209414910	CORD AC BUSH 9414910			
CD680	122H050801	CORD JUMPER 2H050801			
CD681	WAL6812038	FLAT CABLE AWM2468 AWG26 3C GRAY 120MM			
CD682	122H011001	CORD JUMPER 2H011001			
CP101	0697290620	CONNECTOR PCB SIDE TOC-C09X-A1			
CP102	069J740599	CONNECTOR PCB SIDE IMSA-9604S-04C			
CP103	067U002019	WIRE HOLDER B2013H02-2P			
CP501	069S2B0629	CONNECTOR PCB SIDE A2001WV2-11P			
CP651	069J750589	CONNECTOR PCB SIDE IMSA-9604S-05F			
CP652	069EVI3030	CONNECTOR PCB SIDE 00_6232_018_006_800+			
CP680	069J750589	CONNECTOR PCB SIDE IMSA-9604S-05F			
CP682	069EVI3050	CONNECTOR PCB SIDE 00_6232_018_102_800+			
CD4002	06C32B1104	CORD CONNECTOR C32B1104			
CD6002	06CPL02006	CABLE CPL02006			
CD6003	06CPBA2006	CORD,RCA PIN TD-OR0201R			
CD8001	122F0E1001	CORD JUMPER 2F0E1001			

SPEC.NO.	M2F3-PEH
O/R NO.	K572303