


Memorex[®]

MVD4540C

SERVICE MANUAL

DVD VIDEO PLAYER & VHS VIDEO CASSETTE RECORDER



ORIGINAL
MFR'S VERSION A

CAUTION

THIS DIGITAL VIDEO PLAYER EMPLOYS A LASER SYSTEM.


TO ENSURE PROPER USE OF THIS PRODUCT, PLEASE READ THIS SERVICE MANUAL CAREFULLY AND RETAIN FOR FUTURE REFERENCE. SHOULD THE UNIT REQUIRE MAINTENANCE, CONTACT AN AUTHORIZED SERVICE LOCATION-SEE SERVICE PROCEDURE.

USE OF CONTROLS, ADJUSTMENTS OR THE PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

TO PREVENT DIRECT EXPOSURE TO LASER BEAM, DO NOT TRY TO OPEN THE ENCLOSURE. VISIBLE LASER RADIATION MAY BE PRESENT WHEN THE ENCLOSURE IS OPENED. DO NOT STARE INTO BEAM.

Location of the required Marking

The rating sheet and the safety caution are on the rear of the unit.



CERTIFICATION: COMPLIES WITH FDA RADIATION PERFORMANCE STANDARDS, 21 CFR SUBCHAPTER J.

PREPARATION OF SERVICING

The laser diode used for a pickup head may be destroyed with external static electricity.

Moreover, even if it is operating normally after repair, when static electricity discharge is received at the time of repair, a life of product may become short.

Please perform the following measure against static electricity, be careful of destruction of a laser diode enough at the time of repair, and work.

- It works on the desk which performed measures against static electricity, such as conductive mat.
- Soldering iron with ground wire or ceramic type is used.
- A worker needs to use a ground conductive wrist strap for body.

IMPORTANT SERVICE SAFETY INFORMATION

Safety precautions to be followed during servicing:

- 1. Parts marked with an \triangle are critical parts for safety. Replace only with the one described in the parts list.
- 2. Before returning the DVD product to the customer, make the appropriate leakage current check or resistance measurements to ensure that exposed parts are properly insulated from the supply circuit.

A leakage current check is recommended for this unit. Plug the AC line cord directly into a 120V 60Hz AC outlet (do not use an isolation transformer for this check). Use a leakage current tester (Fig. 1) or a metering system which complies with Underwriters Laboratories (UL 1409). Measure for current from all exposed metal parts of the cabinet to a known earth ground: particularly, any exposed metal part having a return path to the chassis. Any current measured must not exceed 0.5mA. Any measurement not within the limits outlined above are indicative of a potential shock hazard and corrective action must be taken before returning the unit to the customer.




Fig. 1 AC Leakage Test

IMPORTANT SAFEGUARDS

1. READ INSTRUCTIONS

All the safety and operating instructions should be read before the unit is operated.

2. RETAIN INSTRUCTIONS

The safety and operating instructions should be retained for future reference.

3. HEED WARNINGS

All warnings on the unit and in the operating instructions should be adhered to.

4. FOLLOW INSTRUCTIONS

All operating and use instructions should be followed.

5. CLEANING

Unplug this unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. ATTACHMENTS

Do not use attachments not recommended by the unit's manufacturer as they may cause hazards.

7. WATER AND MOISTURE

Do not use this unit near water. For example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.

8. ACCESSORIES

Do not place this unit on an unstable cart, stand, tripod, bracket, or table. The unit may fall, causing serious injury, and serious damage to the unit. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer.

- 8A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

9. VENTILATION

Slots and openings in the cabinet and in the back or bottom are provided for ventilation, to ensure reliable operation of the unit, and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the unit on a bed, sofa, rug, or other similar surface. This unit should never be placed near or over a radiator or heat source. This unit should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

10. POWER SOURCES

This unit should be operated only from the type of power source indicated on the rating plate. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For units intended to operate from battery power, or other sources, refer to the operating instructions.

11. GROUNDING OR POLARIZATION

This unit is equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. If your unit is equipped with a 3-wire grounding-type plug, a plug having a third (grounding) pin, this plug will only fit into a grounding-type power outlet. This too, is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.

12. POWER-CORD PROTECTION

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

13. LIGHTNING

To protect your unit from a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the unit due to lightning and power line surges.

14. POWER LINES

An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits, as contact with them might be fatal.

15. OVERLOADING

Do not overload wall outlets and extension cords, as this can result in a risk of fire or electric shock.

16. OBJECT AND LIQUID ENTRY

Do not push objects through any openings in this unit, as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid into the unit.

PORTABLE CART WARNING
(symbol provided by RETAC)



S3125A

17. OUTDOOR ANTENNA GROUNDING

If an outside antenna or cable system is connected to the unit, be sure the antenna or cable system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

18. SERVICING

Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

19. DAMAGE REQUIRING SERVICE

Unplug this unit from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the unit.
- c. If the unit has been exposed to rain or water.
- d. If the unit does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the unit to its normal operation.
- e. If the unit has been dropped or the cabinet has been damaged.
- f. When the unit exhibits a distinct change in performance, this indicates a need for service.

20. REPLACEMENT PARTS

When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original parts.

Unauthorized substitutions may result in fire, electric shock or other hazards.

21. SAFETY CHECK

Upon completion of any service or repairs to this unit, ask the service technician to perform safety checks to determine that the unit is in proper operating condition.

22. WALL OR CEILING MOUNTING

The product should be mounted to a wall or ceiling only as recommended by the manufacturer.

23. HEAT

The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

24. DISC TRAY

Keep your fingers well clear of the disc tray as it is closing. It may cause serious personal injury.

25. CONNECTING

When you connect the product to other equipment, turn off the power and unplug all of the equipment from the wall outlet. Failure to do so may cause an electric shock and serious personal injury. Read the owner's manual of the other equipment carefully and follow the instructions when making any connections.

26. SOUND VOLUME

Reduce the volume to the minimum level before you turn on the product. Otherwise, sudden high volume sound may cause hearing or speaker damage.

27. SOUND DISTORTION

Do not allow the product output distorted sound for a longtime. It may cause speaker overheating and fire.

28. HEADPHONES

When you use the headphones, keep the volume at a moderate level. If you use the headphones continuously with high volume sound, it may cause hearing damage.

29. LASER BEAM

Do not look into the opening of the disc tray or ventilation opening of the product to see the source of the laser beam. It may cause sight damage.

30. DISC

Do not use a cracked, deformed, or repaired disc. These discs are easily broken and may cause serious personal injury and product malfunction.


31. NOTE TO CATV SYSTEM INSTALLER

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

IMPORTANT SAFEGUARDS

(CONTINUED)

EXAMPLE OF ANTENNA GROUNDING AS PER THE NATIONAL ELECTRICAL CODE



WHEN REPLACING DVD DECK

[When the removal of the DVD Deck]

Before removing Pick Up PCB and DVD PCB connector, make the short circuit on the position as shown **Fig. 1** using a soldering. If you remove the DVD Deck with no soldering, the Laser may be damaged.

[When the installation of the DVD Deck]

Remove all the soldering on the short circuit position after the connection of Pick Up PCB and DVD PCB connector.




Fig. 1

TAPE REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Top Cabinet, Front Cabinet and DVD Block. (Refer to item 1 of the **DISASSEMBLY INSTRUCTIONS.**)
2. Remove the screw ① of the Deck Chassis and remove the Loading Motor. (Refer to Fig. 2)
3. Rotate the Pinch Roller Cam in the direction of the arrow by hand to slacken the Video Tape.
4. Rotate the Clutch Ass'y either of the derections to wind the Video Tape in the Cassette Case.
5. Repeat the above step 3~4. Then take out the Video Cassette from the Deck Chassis. Be careful not to scratch on the tape.




Fig. 1




Fig. 2

DISC REMOVAL METHOD AT NO POWER SUPPLY

1. Remove the Back Cabinet and TV//DVD/VCR Block. (Refer to item 1 of the **DISASSEMBLY INSTRUCTIONS.**)
2. Rotate the Main Gear in the direction of the arrow by hand. (Refer to Fig. 1)
3. Draw the Tray.




Fig. 1

PARENTAL CONTROL - RATING LEVEL 4 DIGIT PASSWORD CANCELLATION

If the stored 4 digit password in the Rating Level menu needs to be cancelled, please follow the steps below.

1. Turn Unit ON.
2. Press and hold the '7' key on the remote control unit.
3. Simultaneously press and hold the 'STOP' key on the front panel.
4. Hold both keys for more than 3 seconds.
5. The On Screen Display message 'PASSWORD CLEAR' will appear.
6. The 4 digit password has now been cleared

CONTENTS

CAUTION	A1-1
PREPARATION OF SERVICING	A1-1
IMPORTANT SERVICE SAFETY INFORMATION	A1-2
IMPORTANT SAFEGUARDS	A1-3~A1-5
WHEN REPLACING DVD DECK	A1-6
TAPE REMOVAL METHOD AT NO POWER SUPPLY	A1-7
DISC REMOVAL METHOD AT NO POWER SUPPLY	A1-7
PARENTAL CONTROL-RATION LEVEL	A1-7
CONTENTS	A2-1
GENERAL SPECIFICATIONS	A3-1~A3-7
DISASSEMBLY INSTRUCTIONS	
1. REMOVAL OF MECHANICAL PARTS AND P. C. BOARDS	B1-1, B1-2
2. REMOVAL OF VCR DECK PARTS	B2-1~B2-6
3. REMOVAL OF DVD DECK PARTS	B3-1~B3-3
4. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC	B4-1, B4-2
KEY TO ABBREVIATIONS	C1-1, C1-2
SERVICE MODE LIST	C2-1
PREVENTIVE CHECKS AND SERVICE INTERVALS	C3-1, C3-2
WHEN REPLACING EEPROM (MEMORY) IC	C4-1
SERVICING FIXTURES AND TOOLS	D1-1
PREPARATION FOR SERVICING	D1-1
MECHANICAL ADJUSTMENTS	D2-1~D2-4
ELECTRICAL ADJUSTMENTS	D3-1, D3-2
BLOCK DIAGRAMS	
DVD	E-1, E-2
Y/C/AUDIO/CCD/HEAD AMP	E-3, E-4
SYSTEM CONTROL	E-5, E-6
OPERATION/DISPLAY	E-7, E-8
Hi-Fi/DEMODULATOR	E-9, E-10
TUNER/JACK	E-11, E-12
POWER	E-13, E-14
PRINTED CIRCUIT BOARDS	
DVD	F-1, F-2
VCR/OPERATION	F-3~F-6
LOADING MOTOR/SW	F-7, F-8
SCHEMATIC DIAGRAMS	
MPEG/MICON/DSP	G-1, G-2
MEMORY	G-3, G-4
RF AMP/DSP	G-5, G-6
AUDIO/VIDEO	G-7, G-8
Y/C/AUDIO/CCD/HEAD AMP	G-9, G-10
SYSCON	G-11, G-12
TUNER/JACK	G-13, G-14
OPERATION/DISPLAY	G-15, G-16
Hi-Fi/DEMODULATOR	G-17, G-18
POWER	G-19, G-20
OPERATION/LED	G-21, G-22
LOADING MOTOR/SW	G-23, G-24
INTERCONNECTION DIAGRAM	G-25, G-26
WAVEFORMS	H-1~H-3
MECHANICAL EXPLODED VIEW	I1-1
CHASSIS EXPLODED VIEWS	I2-1, I2-2
DVD DECK EXPLODED VIEW	I3-1
MECHANICAL REPLACEMENT PARTS LIST	J1-1
CHASSIS REPLACEMENT PARTS LIST	J2-1
DVD DECK REPLACEMENT PARTS LIST	J3-1
ELECTRICAL REPLACEMENT PARTS LIST	J4-1, J4-2

GENERAL SPECIFICATIONS

G-1	Outline of the product		DVD VIDEO PLAYER & VHS Player / Recorder		
G-2	DVD System	Color System	NTSC		
		Disc	DVD, CD-DA, CD-R/RW		
		Disc Diameter	120 mm , 80 mm		
		Deck	Disc Loading System Motor	Front Disc Loading 3 Motors	
		Pick up		1-Lens 2-Beams System	
		Playback time (Max)	DVD 1-Layer DVD 2-Layer CD VIDEO CD	135min (4.7GB) 245min (8.5GB) 74min --min	
		Search speed	Actual	Fwd	4 steps 2-45 times (DVD) 4-40 times (CD)
				Rev	4 steps 2-45 times (DVD) 4-40 times (CD)
		Slow speed	Actual	Fwd	1/7-1/2 times --
				Rev	-- --
		G-3	VCR System	System	VHS Player / Recorder
				Video System	NTSC
Hi-Fi STEREO	Yes				
NTSC PB(PAL60Hz)	No				
Deck	DECK Loading System Motor			OVD-7 Front 3	
Heads	Video Head			4Head	
	FM Audio Head			2Head	
	Audio / Control			Mono/Yes	
	Erase (Full Track Erase)			Yes	
	Erase (Normal Audio Track Erase)			No	
Tape Speed	Rec			PAL NTSC	- SP/SLP
	Play			PAL NTSC	- SP/LP/SLP
Fast Forward / Rewind Time (Approx.) at 25oC				FF:4'50"/REW:2'30"	
	with Cassette			T-120	
Forward/Reverse	NTSC or PAL-M			SP/LP/SLP = 3x,5x / 7x,9x / 9x,15x	
Picture Search	PAL or SECAM			-	
Frame Advance		Yes			
Slow Speed		1/10			
G-4	Tuning System	Broadcasting System	US System M		
		Tuner and Receive CH	System	1Tuner	
			Destination	US (w/CATV)	
			Tuning System	F-Synth	
			Input Impedance	VHF/UHF 75 OHM	
			CH Coverage	2-69,4A,A-5- A-1,A-1, J- W, W+1-W+84	
		Intermediate Frequency	Picture (FP)	45.75 MHz	
			Sound (FS)	41.25 MHz	
			FP-FS	4.50 MHz	
		Preset CH		-	
		RF Converter Output		Yes	
			Channel	3 or 4 ch	
			Level / Impedance	66 dBu / 75 Ohm	
			Sound Selector	No	
		Stereo / Dual TV Sound		US-ST	
Tuner Sound Muting		Yes			

GENERAL SPECIFICATIONS

G-5	Power	Power Source	AC DC	120V 60Hz -
		Power Consumption	Stand by Per Year	18 W at 120V 60Hz 2 W at 120V 60Hz -- W
		Protector	Power Fuse Safety Circuit IC Protector(Micro Fuse)	Yes Yes No
G-6	Regulation	Safety		UL
		Radiation		FCC
		Laser		DHHS
G-7	Temperature	Operation		5oC - 40oC
		Storage		-20oC - 60oC
G-8	Operating Humidity			Less than 80% RH
G-9	Signal	Video Signal	Output Level	1 V p-p/75 ohm (DVD,VCR)
			S/N Ratio (Weighted)	65 dB(DVD) 50 dB(VCR)
			Horizontal Resolution	500 Lines (DVD) 230 Lines(VCR Mode)
		RGB Signal	Output Level	-
			Audio Signal	Input Level Microphone
		Input Level Line		-8 dBm/ 50k ohm (VCR, 0dBm=0.775Vrms)
		Output Level Line		-8 dBm/ 1k ohm (VCR, 0dBm=0.775Vrms) -12dBm/ 1k ohm (DVD, -20dBfs 0dBfs=2.0Vrms)
		Digital Output Level	0.5 V p-p / 75 ohm(DVD)	
		S/N Ratio at (Weighted)	90dB(DVD), 42dB(VCR at SP)	
		Harmonic Distortion (1KHz) Typical	0.02% (1KHz) (DVD) , 1.5% (1KHz) (VCR)	
		Frequency Response : DVD Mode at DVD	4 Hz - 22 KHz	
		DVD Mode at VIDEO CD	-	
		DVD Mode at CD	4 Hz - 20 KHz	
		VCR Mode at SP	100Hz - 10 KHz	
		VCR Mode at LP	-	
VCR Mode at SLP	100Hz - 4 KHz			
Hi-Fi Audio Signal	Dynamic Range : More than	90dB		
	Frequency Response	20Hz ~20kHz		
	Wow And Flutter : Less than	0.01 %Wrms		
	Channel Separation : More than	60 dB		
	Harmonic Distortion : Less than	0.01		

GENERAL SPECIFICATIONS

G-10	On Screen Display (DVD)	Menu	Yes
		Menu Type	Character
		Language	Yes
		Menu	Yes
		Subtitle	Yes
		Audio	Yes
		Picture	Yes
		TV Screen Size	Yes
		OSD Display On/Off	Yes
		JPEG Interval	No
		Select Files	No
		E.B.L. (Enhanced Black Level)	No
		Sound	Yes
		DRC (Dynamic Range Control)	Yes
		Dialogue On:DRC(TV)/ Off:DRC(Std)	No
		dts Decode	No
		Output (5.1ch/2ch)	No
		Surround On/Off	No
		Center On/Off	No
		Sub Woofer On/Off	No
		Parental	Yes
		Password Lock/Unlock	Yes
		Rating Level	Yes
		Other	Yes
		OSD Language (Set up Language)	Yes
		Output (RGB / Composite)	No
		Open	Yes
		Close	Yes
		No disc	Yes
		Reading	Yes
		Play	Yes
		Still/Pause	Yes
		Stop	Yes
		Prohibit Mark	Yes
		Step	Yes
		Skip (>>)	Yes
		Skip (<<)	Yes
		Random	Yes (CD, MP3)
		Repeat	Yes
		Slow+ ##	Yes
		Slow- ##	No
		Search+ ##	Yes
		Search- ##	Yes
		Jump	Yes
		Resume	Yes
		Title No.	Yes
		Chapter No.	Yes
		Track No.	Yes
		Time	Yes
		Subtitle No.	Yes
Angle No.	Yes		
Vocal On/Off	Yes		
Audio No.	Yes		
Audio Stereo L/R	No		
Zoom	Yes		
Marker No.	Yes		
Spatializer (N-2-2)	No		
Program Play Back	Yes (CD, MP3)		
MP3	Folder Name	Yes	
	File Name	Yes	
	File No	Yes	
	Time	Yes	
	Track No	Yes	
	Progressive Scan Out ON/OFF	Yes	

GENERAL SPECIFICATIONS

	On Screen Display(VCR)	Menu	Yes	
		Menu Type	Character	
		Timer Rec Set	Yes	
		Auto Repeat On/Off	Yes	
		SAP On/Off	Yes	
		CH Set-Up	Yes	
		TV/CABLE	Yes	
		Auto CH Memory	Yes	
		Add/Delete	Yes	
		System Set Up	Yes	
		Clock Set	Yes (Calendar 12H)	
		Language	Yes	
		No Noise Back Ground	Yes	
		Auto Clock	Yes	
		Standard Time	Yes	
		Daylight Saving Time	Yes	
		G-CODE(or SHOWVIEW or PLUSCODE)No. Entry	No	
		Stereo, Audio Output, SAP	Yes	
		Play/Stop/FF/Rew/Rec/OTR/Pause/Eject/Tape In/Repeat (Symbol Mark)	Yes	
		CH/AV(LINE)	Yes	
Clock	Yes			
Repeat	Yes			
Tape Counter	Yes			
Index	Yes			
Tape Speed	Yes			
ATR / Manual Tracking	Yes			
ZERO Return	Yes			
Hi-Fi	Yes			
G-11	OSD Language	DVD OSD VCR OSD	English / French / Spanish English / French / Spanish	
G-12	Clock,Timer and Timer Back-up	Calendar	1990/1/1 ~ 2081/12/31	
		Timer Events	8 Program/ 1 Month	
		One Touch Recording Max Time	6 Hours	
		OTPB Valid Time	No	
		Timer Back-up (at Power Off Mode)	5sec	
G-13	Display	DISPLAY	Yes	
		DISPLAY type	LED Module (Green, "Rec" &Timer symbol = Red)	
		Clock/Counter,CH,Timer Rec,OTR, Play Rec,FF(Cue),Rew(Rev),Stop,ATR,Eject	No	
		VCR	Yes	
		DVD	Yes	
		CD	Yes	
		Clock	Yes (12h)	
			AM PM	No
		Counter	VCR DVD CD	Yes (hour:min) Yes (hour:min) Yes (min:sec)
		Eject		Yes
		Counter Remain		No
		Play		Yes
		Stop		No
		Rec		Yes
		FF / Cue		No
		REW / Review		No
		Pause / Still		Yes
		OTR (ITR)		No
		T-Rec		Yes
		Chapter		No
		TITLE		No
		TRACK		Yes
		Repeat		No
		Hi-Fi		No
		SP		No
		LP		No
		SLP		No
		CH		Yes
		RF Output CH		Yes
		Tape In		Yes
		Remocon Custom Code		No
		Progressive Scan Out		Yes

GENERAL SPECIFICATIONS

G-14	Remote Control	Unit	RC-JN	
		Glow in Dark Remocon	No	
		Format	NEC	
		Custom Code	71-8E	
		Power Source	Voltage(D.C) UM size x pcs	3V UM-4 x 2 pcs
		Total Keys		46 Keys
		Keys	Power	Yes
			DISPLAY	Yes
			1	Yes
			2	Yes
			3	Yes
			4	Yes
			5	Yes
			6	Yes
			7	Yes
			8	Yes
			9	Yes
			0	Yes
			Input Select	No
			Input Select / PROGRESSIVE	Yes
			UP/CH+	Yes
			DOWN/CH-	Yes
			LEFT/ SET- / TRACKING-	Yes
			RIGHT/ SET+ / TRACKING+	Yes
			VCR/DVD	Yes
			TV/VCR	Yes
			DVD MENU	Yes
			TOP MENU	Yes
			SETUP MENU/VCR MENU	Yes
			ENTER	Yes
			CANCEL	Yes
			RETURN	Yes
			PLAY	Yes
			STOP	Yes
			PAUSE/STILL/STEP	Yes
			FF(Cue)/SEARCH+	Yes
			REW(Review)/SEARCH-	Yes
			REC/OTR	Yes
			SKIP+ / INDEX+	Yes
			SKIP- / INDEX-	Yes
			AUDIO / AUDIO SELECT	Yes
			ANGLE/COUNTER RESET	Yes
			SUBTITLE/ATR	Yes
	PLAY MODE/SPEED	Yes		
	T-REC	Yes		
	CLOCK / COUNTER	Yes		
	JUMP/ZERO RETURN	Yes		
	ZOOM	Yes		
	REPEAT A-B	Yes		
	SLOW (Forward)	Yes		
	MARKER	Yes		
	OPEN/CLOSE	Yes		
	EJECT	Yes		
G-15	Features (DVD)	Auto Power Off	No	
		Parental Lock	Yes	
		Video CD Playback	No	
		MP3 Playback	Yes	
		WMA Playback	No	
		JPEG Playback	No	
		Progressive Scan Out	Yes	
		Digital Out	Dolby Digital	Yes
			MPEG	Yes
			PCM	Yes
			DTS	Yes
		Down Mix Out	(Dolby Digital)	Yes
			(DTS)	No
			Spatializer (N-2-2)	No
			Screen Saver	No
			Tray Lock	No
	Auto Stop	No		
	Audio DAC	192kHz / 24bit		

GENERAL SPECIFICATIONS

Features (VCR)	Auto Head Cleaning	Yes	
	Auto Tracking	Yes	
	HQ (VHS Standard High Quality)	Yes	
	Auto Power On, Auto Play, Auto Rewind, Auto Eject	Yes	
	Auto Power Off	No	
	Forward/Reverse Picture Search	Yes	
	VIDEO PLUS+ (SHOWVIEW, G-CODE)	No	
	One Touch Playback	No	
	Auto CH Memory	Yes	
	AREA CODE	No	
	Auto Clock Set	Yes	
	Index Search	Yes	
	SQPB	No	
	CATV	Yes	
	Energy Star	No	
	MTS (SAP)	Yes	
	CM Skip (30sec x 6 Times)	No	
Copy (Disc to Tape)	No		
G-16 Accessories	Owner's Manual	Language w/Guarantee Card	English / Spanish Yes
	Remote Control Unit		Yes
	Guarantee Card		No
	Registration Card		No
	Warning Sheet		No
	Service Station List		No
	Important Tag		No
	AC Plug Adapter		No
	Quick Set-up Sheet		No
	Battery		No
		UM size x pcs	--
	AC Cord		No
	AV Cord (1.2m)		Yes
	75 Ohm Coaxial Cable (0.9m)		Yes
	S-Video Cable		No
	21pin cable		No
	800 No Sticker		No
Toll Free Insert Sheet		No	
Safety Tip		No	

GENERAL SPECIFICATIONS

G-17	Interface	Switch	Front	Power	Yes	
				Play	Yes	
				Eject (VCR)	Yes	
				Stop	Yes	
				Rec/OTR	Yes	
				Open/Close (DVD)	Yes	
				CH +	Yes	
				CH -	Yes	
				FF/ Search(>>)	Yes	
				Rew/Search(<<)	Yes	
				Still/Pause	No	
				Shuttle (Search/REV/FWD)	No	
				DVD/VCR	Yes	
				Main Power SW	No	
				Rear	Attenuator	No
		S-Video/Component Video Selector	Yes			
		RF Out (Slide SW)	No			
		Main Power SW	No			
		Volume	Phones Volume		No	
		Terminals	Front	Mic Volume	No	
				Echo Volume	No	
				Rec/OTR	No	
				Rear	Video In	RCA x1 (Yellow)
					Audio In	RCA x 2 (Stereo, White/Red)
			Rear	Video Output	RCA x1 (Yellow) S-Video x 1 (DVD Signal Only) Component x1 (RCA 3pin,DVD Signal Only)	
				Audio Output	RCA x 4 (Stereo, White/Red) Coaxial x 1 (Digital Audio,DVD Signal Only)	
				Optical Out (Option)	Yes (Digital Audio,DVD Signal Only)	
				Video Input (Option)	No	
				Audio Input (Option)	No	
		Indicator	LED	RF Input / Output	Yes	
				Euro Scart	No	
				AC Inlet	No	
				Power	No	
Rec	No					
T-Rec	No					
TV/VCR	No					
DVD	Yes (RED)					
VCR	Yes (RED)					
Surround	No					
Level Meter	No					
G-18	Set Size	Approx. W x D x H (mm)		430 x 227 x 99		
G-19	Weight	Net (Approx.)		3.5 kg(7.7lbs)		
		Gross (Approx.)		4.5 kg(9.9lbs)		
G-20	Carton	Master Carton			No	
			Content	--- Sets		
			Material	--- / ---		
			Dimensions W x D x H(mm)	---		
		Description of Origin	---			
		Gift Box			Yes	
			Material	Double / Brown		
			W/Color Photo Label	No		
			Dimensions W x D x H(mm)	497 x 340 x 180		
		Design	As Per BUYER 's			
		Description of Origin	Yes			
		Drop Test			Natural Dropping At 1 Corner / 3 Edges / 6 Surfaces	
Height (cm)	80 cm					
Container Stuffing		2,011 Sets/40' container				
G-21	Material	Cabinet	Front	PS 94V2 or More / DECABROM		
		PCB	Non-Halogen Demand	No		
			Eyelet Demand	No		
G-22	Environment	Pb Free	Lead-free Solder	No		
			Other	No		
		Cd Free			No	

DISASSEMBLY INSTRUCTIONS

1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

1-1: TOP CABINET/FRONT CABINET/OPERATION PCB (Refer to Fig. 1-1)

1. Remove the 5 screws ①.
2. Remove the Top Cabinet in the direction of arrow (A).
3. Disconnect the following connector: (CP651).
4. Unlock the 8 supports ②.
5. Remove the Front Cabinet in the direction of arrow (B).
6. Remove the 2 screws ③.
7. Remove the Operation PCB in the direction of arrow (C).




Fig. 1-1

1-2: FLAP (Refer to Fig. 1-2)

1. Open Flap to 90° and flex in direction of arrow (A), at the same time slide in direction of arrow (B).
2. Then lift in direction of arrow (C).




Fig. 1-2

1-3: DVD DECK/DVD PCB (Refer to Fig. 1-3)

1. Make the short circuit on the position as shown Fig. 1-3 using a soldering. If you remove the DVD Deck with no soldering, the Laser may be damaged.
2. Unlock the support ① and remove the Deck Top Holder in the direction of arrow (A).
3. Remove the 2 screws ②.
4. Remove the 2 screws ③.
5. Disconnect the following connectors: (CP501, CP8001).
6. Remove the DVD Deck in the direction of arrow (B).
7. Remove the 2 screws ④.
8. Remove the DVD PCB in the direction of arrow (C).
9. Remove the 3 screws ⑤.
10. Remove the Front Angle in the direction of arrow (D).




Fig. 1-3

NOTE

When the installation of the DVD Deck, remove all the soldering on the short circuit position after the connection of Pick Up PCB and VCR PCB connector.


DISASSEMBLY INSTRUCTIONS

1-4: VCR DECK (Refer to Fig. 1-4)

NOTE


Do not remove the cable at the FE Head section. The FE Head may be damaged if you remove the cable by force.

1. Remove the screw ①.
2. Remove the FE Head.
3. Move the Cassette Holder Ass'y to the back side.
4. Remove the 2 screws ②.
5. Remove the 2 screws ③.
6. Disconnect the following connectors:
(CP101, CP102, CP3001).
7. Remove the VCR Deck in the direction of arrow.



1-5: VCR PCB (Refer to Fig. 1-5)

1. Remove the screw ①.
2. Remove the 5 screws ②.
3. Remove the 2 screws ③.
4. Remove the 3pin Shield.
5. Remove the VCR PCB in the direction of arrow.



DISASSEMBLY INSTRUCTIONS

2. REMOVAL OF VCR DECK PARTS

2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Extend the 2 supports ①.
2. Slide the 2 supports ② and remove the Top Bracket.

NOTE

1. After the installation of the Top Bracket, bend the support ① so that the Top Bracket is fixed.




Fig. 2-1

2-2: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




Fig. 2-2

2-3: CASSETTE SIDE L/R (Refer to Fig. 2-3-A)

1. Remove the Locker Spring.
2. Unlock the 4 supports ① and then remove the Cassette Side L/R.
3. Unlock the support ② and then remove the Locker R.




Fig. 2-3-A

NOTE

1. In case of the Locker R installation, check if the one position of Fig.2-3-B are correctly locked.
2. When you install the Cassette Side R, be sure to move the Locker R after installing.




Fig. 2-3-B

2-4: LINK UNIT (Refer to Fig. 2-4)

1. Set the Link Unit to the Eject position.
2. Unlock the support ①.
3. Remove the (A) side of the Link Unit first, then remove the (B) side.




Fig. 2-4

2-5: LINK LEVER/FLAP LEVER (Refer to Fig. 2-5)

1. Extend the support ①.
2. Remove the Link Lever.
3. Remove the Flap Lever.




Fig. 2-5

DISASSEMBLY INSTRUCTIONS

2-6: LOADING MOTOR/WORM (Refer to Fig. 2-6-A)

1. Remove the screw ①.
2. Remove the Loading Motor.
3. Remove the Worm.




Fig. 2-6-A

NOTE

1. In case of the Worm installation, check if the value of the Fig. 2-6-B is correct.
2. In case of the Loading Motor installation, hook the wire on the Cassette Opener as shown Fig. 2-6-C.
3. When installing the wires between Capstan DD Unit and Loading Motor, connect them correctly as shown Fig. 2-6-D.




Fig. 2-6-B




Fig. 2-6-C




Fig. 2-6-D

2-7: TENSION ASS'Y (Refer to Fig. 2-7-B)

1. Turn the Pinch Roller Cam clockwise so that the Tension Holder hook is set to the position of Fig. 2-7-A to move the Tension Arm Ass'y.
2. Remove the Tension Spring.
3. Unlock the 2 supports ① and remove the Tension Band.
4. Unlock the support ② and remove the Tension Arm Ass'y.
5. Unlock the support ③ and remove the Tension Connect.
6. Float the hook ④ and turn it clockwise then remove the Tension Holder.




Fig. 2-7-A




Fig. 2-7-B

NOTE

1. In case of the Tension Band installation, note the direction of the installation. (Refer to Fig. 2-7-C)
2. In case of the Tension Band installation, install correctly as Fig. 2-7-D.
3. In case of the Tension Connect installation, install as the circled section of Fig. 2-7-E.




Fig. 2-7-C




Fig. 2-7-D




Fig. 2-7-E

DISASSEMBLY INSTRUCTIONS

2-8: T BRAKE ARM/T BRAKE BAND (Refer to Fig. 2-8-A)

1. Remove the T Brake Spring.
2. Turn the T Brake Arm clockwise and bend the hook section to remove it.
3. Unlock the 2 supports ① and remove the T Brake Band.




Fig. 2-8-A

NOTE

1. In case of the T Brake Band installation, install correctly as Fig. 2-8-B.




Fig. 2-8-B

2-9: S REEL/T REEL/IDLER ARM ASS'Y/IDLER GEAR (Refer to Fig. 2-9-A)

1. Remove the S Reel and T Reel.
2. Remove the 2 Polyslider Washers ①.
3. Remove the Idler Arm Ass'y and Idler Gear.

NOTE

1. Take care not to damage the gears of the S Reel and T Reel.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel. (Use gloves.) (Refer to Fig. 2-9-A) Do not adhere the stains on it.
5. When you install the reel, clean the shaft and grease it (FG-84M). (If you do not grease, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)




Fig. 2-9-A

NOTE

1. In case of the S Reel and T Reel installation, check if the correct parts are installed. (Refer to Fig. 2-9-B)
2. In case of the Idler Arm Ass'y installation, install correctly as Fig. 2-9-C. And also set it so that the section "B" of Fig. 2-9-A is placed under the Main Chassis tab.




Fig. 2-9-B





Fig. 2-9-C

DISASSEMBLY INSTRUCTIONS


2-10: CASSETTE OPENER/PINCH ROLLER BLOCK/ P5 ARM ASS'Y (Refer to Fig. 2-10-A)

1. Unlock the support ① and remove the Cassette Opener.
2. Remove the Pinch Roller Block and P5 Arm Ass'y.



NOTE

1. Do not touch the Pinch Roller. (Use gloves.)
2. In case of the Pinch Roller Block and the Pinch Roller Cam installation, install correctly as Fig. 2-10-B.





2-11: A/C HEAD (Refer to Fig. 2-11-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.


NOTE

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-11-B.
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).



2-12: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-12)

1. Remove the screw ①.
2. Remove the FE Head.




2-13: AHC ASS'Y/CYLINDER UNIT ASS'Y (Refer to Fig. 2-13)

1. Unlock the support ① and remove the AHC Ass'y.
2. Disconnect the following connector: (CD2001)
3. Remove the 3 screws ②.
4. Remove the Cylinder Unit Ass'y.

NOTE



1. When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.



DISASSEMBLY INSTRUCTIONS


2-14: CAPSTAN DD UNIT (Refer to Fig. 2-14)

1. Remove the Capstan Belt.
2. Remove the screw ①.
3. Remove the Capstan Holder.
4. Remove the 3 screws ②.
5. Remove the Capstan DD Unit.




2-16: LOADING GEAR S/T UNIT (Refer to Fig. 2-16-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Main Rod, Tension Lever, Loading Arm S Unit and Loading Arm T Unit.




2-15: MAIN CAM/PINCH ROLLER CAM/JOINT GEAR (Refer to Fig. 2-15-A)

1. Remove the E-Ring ①, then remove the Main Cam.
2. Remove the E-Ring ②, then remove the Pinch Roller Cam and Joint Gear.



NOTE

1. When you install the Loading Arm S Unit, Loading Arm T Unit and Main Loading Gear, align each marker. (Refer to Fig. 2-16-B)



NOTE

1. In case of the Pinch Roller Cam and Main Cam installation, install them as the circled section of Fig. 2-15-B so that the each markers are met. (Refer to Fig. 2-15-B)

DISASSEMBLY INSTRUCTIONS

2-17: CLUTCH ASS'Y/RING SPRING/CLUTCH LEVER/ CLUTCH GEAR (Refer to Fig. 2-17-A)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Ass'y and Ring Spring.
3. Remove the Clutch Lever.
4. Remove the Coupling Gear, Coupling Spring and Clutch Gear.




Fig. 2-17-A

NOTE

1. In case of the Clutch Ass'y installation, install it with inserting the spring of the Clutch Ass'y into the dent of the Coupling Gear. (Refer to Fig. 2-17-B)




Fig. 2-17-B

2-18: CASSETTE GUIDE POST/INCLINED BASE S/T UNIT/P4 CAP/LED REFLECTOR (Refer to Fig. 2-18-A)

1. Remove the P4 Cap.
2. Unlock the support ① and remove the Cassette Guide Post.
3. Remove the Inclined Base S/T Unit.
4. Remove the screw ②.
5. Remove the LED Reflector.




Fig. 2-18-A

NOTE

1. Do not touch the roller of Guide Roller.
2. In case of the P4 Cap installation, install it with parallel for "A" and "B" of Fig. 2-18-B.
3. In case of the Cassette Guide Post installation, install correctly as the circled section of Fig. 2-18-C.




Fig. 2-18-B




Fig. 2-18-C

DISASSEMBLY INSTRUCTIONS

3. REMOVAL OF DVD DECK PARTS

NOTE

1. Do not disassemble the DVD DECK PARTS except listed parts here. Minute adjustments are needed if the disassemble is done. If the repair is needed except listed parts, replace the DVD MECHA ASS'Y.

3-1: TRAY (Refer to Fig. 3-1-A)

1. Set the Tray opened. (Refer to the DISC REMOVAL METHOD AT NO POWER SUPPLY)
2. Unlock the 2 supports ① and remove the Tray.




Fig. 3-1-A

NOTE

1. In case of the Tray installation, install them as the circled section of Fig. 3-1-B so that the each markers are met.




Fig. 3-1-B

3-2: MAIN CHASSIS ASS'Y (Refer to Fig. 3-2-A)

1. Remove the screw ①.
2. Unlock the 2 supports ②.
3. Remove the Insulator (R) from the Main Frame Ass'y.
4. Remove the Main Chassis Ass'y.




Fig. 3-2-A

NOTE

1. In case of the Main Chassis Ass'y, install it from (1) to (4) in order. (Refer to Fig. 3-2-B)
2. In case of the Main Chassis Ass'y installation, hook the wire on the Main Frame Ass'y as shown Fig. 3-2-C.




Fig. 3-2-B




Fig. 3-2-C

3-3: LOADING MOTOR PCB ASS'Y/ LOADING BELT (Refer to Fig. 3-3-A)

1. Remove the Loading Belt.
2. Remove the screw ①.
3. Remove the 2 screws ②.
4. Remove the Loading Motor PCB Ass'y.
5. Remove the Pulley Gear.






Fig. 3-3-A

DISASSEMBLY INSTRUCTIONS


NOTE

1. In case of the Pulley Motor installation, check if the value of the Fig. 3-3-B is correct.
2. When installing the Loading Motor PCB Ass'y, install it correctly as Fig. 3-3-C.
3. In case of the Loading Motor PCB Ass'y installation, hook the wire on the Main Frame Ass'y as shown Fig. 3-3-C.




3-4: RACK LOADING/MAIN GEAR/PULLEY GEAR (Refer to Fig. 3-4-A)

1. Press down the catcher ① and slide the Rack Loading.
2. Unlock the support ② and remove the Pulley Gear.
3. Remove the Main Gear.




NOTE

1. In case of the Rack Loading installation, do not mesh it to the Main Gear as shown the Fig. 3-4-B.




3-5: CLAMPER ASS'Y (Refer to Fig. 3-5-A)

1. Press the Clamper and rotate the Clamper Plate clockwise, then unlock the 3 supports ①.
2. Remove the Clamper Plate, Clamper Magnet and Clamper.




NOTE

1. In case of the Clamper Ass'y installation, install correctly as Fig. 3-5-B.




3-6: TRAVERSE HOLDER/INSULATOR (F)/INSULATOR (R) (Refer to Fig. 3-6-A)

1. Remove the Traverse Holder.
2. Remove the 2 Insulator (F).
3. Remove the Insulator (R).



NOTE

1. In case of the Insulator (F) installation, install correctly as Fig. 3-6-B.
2. In case of the Insulator (R) installation, install correctly as Fig. 3-6-C.



DISASSEMBLY INSTRUCTIONS




Fig. 3-6-C

3-7: RACK FEED ASS'Y/SWITCH PCB ASS'Y/FEED MOTOR (Refer to Fig. 3-7-A)

1. Remove the screw ①.
2. Remove the Rack Feed Ass'y.
3. Remove the screw ②.
4. Remove the Switch PCB Ass'y.
5. Remove the 2 screw ③.
6. Remove the Feed Motor.
7. Remove the Motor Gear.




Fig. 3-7-A

NOTE

1. When pushing the Rack Feed in the direction of the arrow, it should be restored to the original position by the spring force. (Refer to Fig. 3-7-B)
2. In case of the Motor Gear installation, check if the value of the Fig. 3-7-C is correct.
3. When installing the wire of the Switch PCB Ass'y, install it correctly as Fig. 3-7-D.
4. After the assembly of the Main Chassis Ass'y, hook the wire on the Main Chassis Ass'y as shown Fig. 3-7-E.




Fig. 3-7-B




Fig. 3-7-C




Fig. 3-7-D




Fig. 3-7-E

DISASSEMBLY INSTRUCTIONS


4. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC

REMOVAL

1. Put the Masking Tape (cotton tape) around the Flat Package IC to protect other parts from any damage. (Refer to Fig. 4-1.)

NOTE


Masking is carried out on all the parts located within 10 mm distance from IC leads.



2. Heat the IC leads using a blower type IC desoldering machine. (Refer to Fig. 4-2.)

NOTE


Do not add the rotating and the back and forth directions force on the IC, until IC can move back and forth easily after desoldering the IC leads completely.



3. When IC starts moving back and forth easily after desoldering completely, pickup the corner of the IC using a tweezers and remove the IC by moving with the IC desoldering machine. (Refer to Fig. 4-3.)

NOTE


Some ICs on the PCB are affixed with glue, so be careful not to break or damage the foil of each IC leads or solder lands under the IC when removing it.



4. Peel off the Masking Tape.
5. Absorb the solder left on the pattern using the Braided Shield Wire. (Refer to Fig. 4-4.)

NOTE


Do not move the Braided Shield Wire in the vertical direction towards the IC pattern.




DISASSEMBLY INSTRUCTIONS

INSTALLATION

1. Take care of the polarity of new IC and then install the new IC fitting on the printed circuit pattern. Then solder each lead on the diagonal positions of IC temporarily. (Refer to Fig. 4-5.)




2. Supply the solder from the upper position of IC leads sliding to the lower position of the IC leads. (Refer to Fig. 4-6.)




3. Absorb the solder left on the lead using the Braided Shield Wire. (Refer to Fig. 4-7.)

NOTE

Do not absorb the solder to excess.



4. When bridge-soldering between terminals and/or the soldering amount are not enough, resolder using a Thin-tip Soldering Iron. (Refer to Fig. 4-8.)



5. Finally, confirm the soldering status on four sides of the IC using a magnifying glass. Confirm that no abnormality is found on the soldering position and installation position of the parts around the IC. If some abnormality is found, correct by resoldering.

NOTE

When the IC leads are bent during soldering and/or repairing, do not repair the bending of leads. If the bending of leads are repaired, the pattern may be damaged. So, always be sure to replace the IC in this case.

KEY TO ABBREVIATIONS

A	A/C	: Audio/Control	H.SW	: Head Switch	
	ACC	: Automatic Color Control	Hz	: Hertz	
	AE	: Audio Erase	I	IC	: Integrated Circuit
	AFC	: Automatic Frequency Control		IF	: Intermediate Frequency
	AFT	: Automatic Fine Tuning		IND	: Indicator
	AFT DET	: Automatic Fine Tuning Detect		INV	: Inverter
	AGC	: Automatic Gain Control	K	KIL	: Killer
	AMP	: Amplifier	L	L	: Left
	ANT	: Antenna		LED	: Light Emitting Diode
	A.PB	: Audio Playback		LIMIT AMP	: Limiter Amplifier
	APC	: Automatic Phase Control		LM, LDM	: Loading Motor
	ASS'Y	: Assembly		LP	: Long Play
	AT	: All Time		L.P.F	: Low Pass Filter
	AUTO	: Automatic		LUMI.	: Luminance
	A/V	: Audio/Video	M	M	: Motor
B	BGP	: Burst Gate Pulse		MAX	: Maximum
	BOT	: Beginning of Tape		MINI	: Minimum
	BPF	: Bandpass Filter		MIX	: Mixer, mixing
	BRAKE SOL	: Brake Solenoid		MM	: Monostable Multivibrator
	BUFF	: Buffer		MOD	: Modulator, Modulation
	B/W	: Black and White		MPX	: Multiplexer, Multiplex
C	C	: Capacitance, Collector		MS SW	: Mecha State Switch
	CASE	: Cassette	N	NC	: Non Connection
	CAP	: Capstan		NR	: Noise Reduction
	CARR	: Carrier	O	OSC	: Oscillator
	CH	: Channel		OPE	: Operation
	CLK	: Clock	P	PB	: Playback
	CLOCK (SY-SE)	: Clock (Syscon to Servo)		PB CTL	: Playback Control
	COMB	: Combination, Comb Filter		PB-C	: Playback-Chrominance
	CONV	: Converter		PB-Y	: Playback-Luminance
	CPM	: Capstan Motor		PCB	: Printed Circuit Board
	CTL	: Control		P. CON	: Power Control
	CYL	: Cylinder		PD	: Phase Detector
	CYL-M	: Cylinder-Motor		PG	: Pulse Generator
	CYL SENS	: Cylinder-Sensor		P-P	: Peak-to Peak
D	DATA (SY-CE)	: Data (Syscon to Servo)	R	R	: Right
	dB	: Decibel		REC	: Recording
	DC	: Direct Current		REC-C	: Recording-Chrominance
	DD Unit	: Direct Drive Motor Unit		REC-Y	: Recording-Luminance
	DEMOD	: Demodulator		REEL BRK	: Reel Brake
	DET	: Detector		REEL S	: Reel Sensor
	DEV	: Deviation		REF	: Reference
E	E	: Emitter		REG	: Regulated, Regulator
	EF	: Emitter Follower		REW	: Rewind
	EMPH	: Emphasis		REV, RVS	: Reverse
	ENC	: Encoder		RF	: Radio Frequency
	ENV	: Envelope		RMC	: Remote Control
	EOT	: End of Tape		RY	: Relay
	EQ	: Equalizer	S	S. CLK	: Serial Clock
	EXT	: External		S. COM	: Sensor Common
F	F	: Fuse		S. DATA	: Serial Data
	FBC	: Feed Back Clamp		SEG	: Segment
	FE	: Full Erase		SEL	: Select, Selector
	FF	: Fast Forward, Flipflop		SENS	: Sensor
	FG	: Frequency Generator		SER	: Search Mode
	FL SW	: Front Loading Switch		SI	: Serial Input
	FM	: Frequency Modulation		SIF	: Sound Intermediate Frequency
	FSC	: Frequency Sub Carrier		SO	: Serial Output
	FWD	: Forward		SOL	: Solenoid
G	GEN	: Generator		SP	: Standard Play
	GND	: Ground		STB	: Serial Strobe
H	H.P.F	: High Pass Filter		SW	: Switch

KEY TO ABBREVIATIONS

S	SYNC	:	Synchronization
	SYNC SEP	:	Sync Separator, Separation
T	TR	:	Transistor
	TRAC	:	Tracking
	TRICK PB	:	Trick Playback
	TP	:	Test Point
U	UNREG	:	Unregulated
V	V	:	Volt
	VCO	:	Voltage Controlled Oscillator
	VIF	:	Video Intermediate Frequency
	VP	:	Vertical Pulse, Voltage Display
	V.PB	:	Video Playback
	VR	:	Variable Resistor
	V.REC	:	Video Recording
	VSF	:	Visual Search Fast Forward
	VSR	:	Visual Search Rewind
	VSS	:	Voltage Super Source
	V-SYNC	:	Vertical-Synchronization
	VT	:	Voltage Tuning
X	X'TAL	:	Crystal
Y	Y/C	:	Luminance/Chrominance

SERVICE MODE LIST

This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.

To enter to the SERVICE MODE function, press and hold both buttons simultaneously on the main unit or on the main unit and on the remote control for more than a standard time in the appropriate condition. (See below chart.)

In case of the main unit and remote control, press the remote control buttons first, then press the main unit buttons.

Set Condition	Set Key	Set Key	Standard Time	Operations
VCR mode	CH UP	FF	2 sec.	PLAY/REC total hours are displayed on the TV Monitor. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF HOURS USED). Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
VCR mode	CH UP	PLAY	2 sec.	Initialization of the factory on VCR. NOTE: Do not use this for the normal servicing. If you set a factory initialization, the memories are reset such as the clock setting, the channel setting, and PLAY/REC total hours.
VCR mode (Playback)	CH UP	STOP	2 sec.	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT".
Power Off	CH DOWN	POWER	2 sec.	VCR operation mode at no connection of DVD. Refer to the "PREPARATION FOR SERVICING" NOTE: Although the DVD is connected, the DVD mode cannot be selected.

Set Condition	Set Key	Remocon Key	Standard Time	Operations
DVD mode (No disc)	REC/OTR	4	2 sec.	Initialization of the factory on DVD. NOTE: Do not use this for the normal servicing. This function will only work without the setting of DVD disc at DVD mode. While pressing the Remocon Key for more than 2 seconds, press the Set Key simultaneously.
DVD mode (No disc)	STOP	7	3 sec.	Releasing of PARENTAL LOCK. Refer to the "PARENTAL CONTROL - RATING LEVEL". NOTE: The function will only work without the setting of DVD disc at DVD mode.

Method	Operations
Press the ATR button on the remote control for more than 2 seconds during PLAY.	Adjusting of the Tracking to the center position. Refer to the "MECHANICAL ADJUSTMENT" (GUIDE ROLLER) and "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
Make the short circuit between the test point of SERVICE and the GND.	The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape. Refer to the "PREPARATION FOR SERVICING"

PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage.

Parts replacing time does not mean the life span for individual parts.

Also, long term storage or misuse may cause transformation and aging of rubber parts.

The following list means standard hours, so the checking hours depends on the conditions.

Time Parts Name	500 hours	1,000 hours	1,500 hours	2,000 hours	2,500 hours	Notes
Audio Control Head	■	■	■	●	●	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	●	●	
Capstan Belt		●	●	●	●	Clean the rubber, and parts which the rubber touches.
Pinch Roller	■	●	●	●	●	
Capstan DD Unit		●	●	●	●	
Loading Motor					●	
Tension Band		●	●	●	●	
T Brake Band		●	●	●	●	
Clutch Ass'y		●	●	●	●	
Idler Arm Ass'y		●	●	●	●	
Capstan Shaft	■	■	■	■	■	
Tape Running Guide Post	■	■	■	■	■	
Cylinder Unit	■	●	●	●	●	Clean the Head

■ : Clean

● : Check it and if necessary, replace it.

CONFIRMATION OF HOURS USED

PLAY/REC total hours can be checked on the screen.

Total hours are displayed in 16 system of notation.

NOTE: If you set a factory initialization, the total hours is reset to "0".

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.
The Fig. 1 screen will appear on TV Monitor.
4. After the confirmation of using hours, turn off the power.




Fig. 1

Initial setting content of MEMORY IC.

PLAY/REC total hours.

= (16 x 16 x 16 x thousands digit value)

+ (16 x 16 x hundreds digit value)

+ (16 x tens digit value)

+ (ones digit value)

PREVENTIVE CHECKS AND SERVICE INTERVALS


CLEANING

NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

1. AUDIO CONTROL HEAD

Clean the Audio Control Head with the cotton stick soaked by alcohol. Clean the full erase head in the same manner. **(Refer to the figure below.)**



2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). **(Refer to the figure below.)**

NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



WHEN REPLACING EEPROM (MEMORY) IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

NOTE: INI 34 and INI 35 cannot be set. Because, the total time for the PLAY/REC of the main unit is recorded.

INIT	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
00	0E	10	DC	60	64	64	4A	86	0B	2B	86	32	0A	08	0A	01
10	AF	97	95	8A	A0	57	31	04	88	A5	9F	3A	00	10	BF	00
20	3A	11	22	70	61	2A	3A	00	0B	00	40	C5	9A	B0	00	37
30	03	17	---	---	---	---	---	---	---	---	---	---	---	---	---	---

Table 1

1. Connect the set to TV Monitor.
2. Turn on the POWER, and set to the VCR mode.
3. Press both CH UP button on the set and the FF button on the set for more than 2 seconds.
ADDRESS and DATA will appear on TV Monitor as **Fig 1**.














Fig. 1

4. ADDRESS is now selected and should "blink". Using the Tracking + or - button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
5. Press ENTER to select DATA. When DATA is selected, it will "blink".
6. Again, step through the DATA using Tracking + or - button until required DATA value has been selected.
7. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 7 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.

After the data input, set to the initializing of shipping.

10. Turn on the POWER, and set to the VCR mode.
 11. Press both CH UP button on the set and the PLAY button on the set for more than 2 seconds.
 12. After the finishing of the initializing of shipping, the unit will turn off automatically.
- The unit will now have the correct DATA for the new MEMORY IC.

SERVICING FIXTURES AND TOOLS

<p>(For 2 heads model) VHS Alignment Tape JG001 (VN₂S-LI6³) JG001A (VN₂S-CO¹³) JG001Q (VN₂S-LI6³H) JG001T (VN₂S-X6³)</p> 	<p>(For 4 heads model) VHS Alignment Tape JG001B (VN₁S-LI6³) JG001I (VN₁S-CO¹³) JG001P (VN₁S-LI6³H) JG001S (VN₁S-X6³)</p> 	<p>JG002B Adapter JG002E Dial Torque Gauge (10~90gf•cm) JG002F (60~600gf•cm)</p> 	<p>JG005 Post Adjustment Screwdriver Part No. SV-TG0-030-000 (small)</p> 
<p>JG153 X Value Adjustment Screwdriver</p> 	<p>JG022 Master Plane</p> 	<p>JG024A Reel Disk Height Adjustment Jig</p> 	<p>JG100A Torque Tape (VHT-063)</p> 
<p>JG154 Cable</p> 	<p>JG185 Tentelometer</p> 		

Ref. No.	Part No.	Parts Name	Remarks
JG001	APJG001000	VHS Alignment Tape	Monoscope, 6KHz (For 2 heads model)
JG001A	APJG001A00	VHS Alignment Tape	Color Bar, 1KHz (For 2 heads model)
JG001Q	APJG001Q00	VHS Alignment Tape	Hi-Fi Audio (For 2 heads model)
JG001T	APJG001T00	VHS Alignment Tape	X Value Adjustment (For 2 heads model)
JG001B	APJG001B00	VHS Alignment Tape	Monoscope, 6KHz (For 4 heads model)
JG001I	APJG001I00	VHS Alignment Tape	Color Bar, 1KHz (For 4 heads model)
JG001P	APJG001P00	VHS Alignment Tape	Hi-Fi Audio (For 4 heads model)
JG001S	APJG001S00	VHS Alignment Tape	X Value Adjustment (For 4 heads model)
JG002B	APJG002B00	Adapter	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	APJG002E00	Dial Torque Gauge (10~90gf•cm)	Brake Torque (T Reel Ass'y)
JG002F	APJG002F00	Dial Torque Gauge (60~600gf•cm)	VSR Torque, Brake Torque (S Reel)
JG005	APJG005000	Post Adjustment Screwdriver	Guide Roller Adjustment
JG153	APJG153000	X Value Adjustment Screwdriver	X Value Adjustment
JG022	APJG022000	Master Plane	Reel Disk Height Adjustment
JG024A	APJG024A00	Reel Disk Height Adjustment Jig	Reel Disk Height Adjustment
JG100A	APJG100A00	Torque Tape (VHT-063)	Playback Torque, Back Tension Torque During Playback
JG154	APJG154000	Cable	Used to connect the test point of SERVICE and GROUND
JG185	APJG185000	Tentelometer	Confirmation of Tape Tension on Playback

PREPARATION FOR SERVICING

- While pressing the CH DOWN button on the set for more than 2 seconds, press the POWER button on the set simultaneously at the Power OFF. Although the DVD is connected, the DVD mode cannot be selected.
- Short circuit between **TP3001** and **Ground** with the cable JG154.
(The BOT, EOT, and the Reel Sensor do not work and the VCR deck can be operated without a cassette tape.)
- In case of using a cassette tape, press the STOP/EJECT button to insert or eject a cassette tape.
Turn on the power and re-check the cable before checking the trouble points.

When you servicing with connection of DVD, perform the operations above step 2 to step 3.

MECHANICAL ADJUSTMENTS



1. CONFIRMATION AND ADJUSTMENT

Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)



1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

- Turn on the power and set to the STOP mode.
- Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
- While turning the reel and confirm the following points. Check if the surface "A" of reel disk is lower than the surface "B" of reel disk height adjustment jig (**JG024A**) and is higher than the surface "C". If it is not passed, place the height adjustment washers and adjust to 10(+2, -0)mm.
- Adjust the other reel in the same way.



1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

- Set to the PLAY mode.
- Adjust the adjusting section for the Tension Arm position so that the Tension Arm top is within the standard line of Main Chassis.
- While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.




1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

- Load a video tape (T-120) recorded in standard speed mode. Set the unit to the PLAY mode.
- Install the tentelometer (**JG185**) as shown in **Fig. 1-3**. Confirm that the meter indicates $20 \pm 2\text{gf}$ in the beginning of playback.

• USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)

- After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
- Confirm that the right meter of the torque tape indicates 50~90gf•cm during playback in SP mode.
- Confirm that the left meter of the torque tape indicates 25~40gf•cm during playback in SP mode.



MECHANICAL ADJUSTMENTS

1-4: CONFIRMATION OF VSR TORQUE

1. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Set to the Picture Search (Rewind) mode. (Refer to Fig.1-4-B)
2. Then, confirm that it indicates 120~180gf•cm.

NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.



1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the S Reel.
3. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Turn the Torque Gauge (JG002F) clockwise.
4. Then, confirm that it indicates 60~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4-B)

1. Once set to the Fast Forward mode then set to the Stop mode. While, unplug the AC cord when the Pinch Roller Block is on the position of Fig. 1-4-A.
2. Move the Idler Ass'y from the T Reel.
3. Install the Torque Gauge (JG002E) and Adapter (JG002B) on the T reel. Turn the Torque Gauge (JG002E) counterclockwise.
4. Then, confirm that it indicates 30~50gf•cm.



NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	S Reel side: S Reel/Tension Band/Tension Connect/Tension Arm Ass'y T Reel side: T Reel/T Brake Band//T Brake Spring/T Brake Arm

2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM



Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (JG001 or JG001B). (Refer to SERVICING FIXTURE AND TOOLS)
2. Connect CH-1 of the oscilloscope to TP101 (Envelope) and CH-2 to TP3002 (SW Pulse).
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (JG005) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the ELECTRICAL ADJUSTMENTS)

NOTE

After adjustment, confirm and adjust A/C head. (Refer to item 2-2)






MECHANICAL ADJUSTMENTS

2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD


When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001** or **JG001B**). (Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
 - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
 - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
 - a) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.



2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)

1. Confirm and adjust the height of the Reel Disk. (Refer to item 1-1)
2. Confirm and adjust the position of the Tension Post. (Refer to item 1-2)
3. Adjust the Guide Roller. (Refer to item 2-1)
4. Confirm and adjust the Audio/Control Head. (Refer to item 2-2)
5. Connect CH-1 of the oscilloscope to **TP3002**, CH-2 to **TP101** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001S** or **JG001T**). (Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-3**.




2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP101** and CH-2 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001P** or **JG001Q**). (Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press and hold the ATR button on the remote control more than 2 seconds to set tracking to center.
6. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
7. If the difference are more than 3 steps, set the X Value adjustment driver (**JG153**) to ④ of **Fig. 2-2-B**. Change the X Value and adjust it so that the value becomes within 2 steps.

MECHANICAL ADJUSTMENTS

3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- | | |
|-----------------------------------|--|
| 1. Tension Connect | 6. P4 Post |
| 2. Tension Arm | 7. T Brake Spring |
| 3. Guide Roller | 8. T Reel |
| 4. Audio/Control Head | 9. S Reel |
| 5. X value adjustment driver hole | 10. Adjusting section for the Tension Arm position |

ELECTRICAL ADJUSTMENTS

Read and perform this adjustment when repairing the circuits or replacing electrical parts or PCB assemblies.

1. BASIC ADJUSTMENT

CAUTION

- When you exchange IC and Transistor for a heat sink, apply the silicon grease (**YG6260M**) on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)

1-1: PG SHIFTER



CONDITIONS

MODE-PLAYBACK

Input Signal-Alignment Tape (**JG001B**)


INSTRUCTIONS

1. Connect CH-1 on the oscilloscope to **TP3002** and CH-2 to **Video Out Jack**.
2. Playback the alignment tape. (**JG001B**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press both CH UP button on the set and the STOP button on the set for more than 2 seconds.




ELECTRICAL ADJUSTMENTS


2. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)




DVD BLOCK DIAGRAM




Y/C/AUDIO/CCD/HEAD MAP BLOCK DIAGRAM




SYSTEM CONTROL BLOCK DIAGRAM




OPERATION/DISPLAY BLOCK DIAGRAM




HIFI/DEMODULATOR BLOCK DIAGRM



TUNER/JACK BLOCK DIAGRAM




POWER BLOCK DIAGRAM




PRINTED CIRCUIT BARDS


DVD (TOP SIDE)




DVD (BOTTOM SIDE)



**PRINTED CIRCUIT BARDS
VCR/OPERATION (INSERTED PARTS)
SOLDER SIDE**




PRINTED CIRCUIT BARDS
VCR (CHIP MOUNTED PARTS)
SOLDER SIDE




PRINTED CIRCUIT BOARDS


LOADING MOTOR (INSERTED PARTS) SOLDER SIDE




LOADING MOTOR (CHIP MOUNTED PARTS) SOLDER SIDE



SW SOLDER SIDE



MPEG/MICON/DSP SCHEMATIC DIAGRAM (DVD PCB)



← DIGITAL AUDIO SIGNAL (PB)

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


FROM/TO AUDIO/VIDEO	
→	SYS_MUTE
→	DVD-H
→	V_SW
→	DAC_VIDEO_A
→	DAC_VIDEO_C
→	DAC_VIDEO_B
→	DAC_VIDEO_D
→	ASDATA0
→	ABCLK
→	ALRCLK
→	AMCLK
→	MD
→	MC
→	ML
→	RESET
→	P.CON+5V
→	GND

FROM/TO RF AMP/DSP	
→	TRAY_OPEN
→	TRAY_CLOSE
→	HOME
→	SPDL_SENS
→	TOUT_SW
→	TIN_SW
→	RFA_SDEN
→	RFA_DATA
→	RFA_SCLK
→	AAF_CE
→	AAF_FE
→	AAF_TE
→	VR_SEL
→	TRAY_OPEN
→	TOUT_SW
→	TRAY_CLOSE
→	TIN_SW
→	SMUTE
→	VBIASS1
→	VBIASS0
→	DEFECT
→	MIRR
→	LDON
→	SMUTE
→	TRACK_DAC
→	FOCUS_DAC
→	SPINDLE_PWM
→	SLED_PWM

FROM/TO POWER	
→	P.CON+5V
→	P.CON+3.3V
→	VCC+9V
→	P.CON+5V
→	P.CON+5V
→	UNREG+3.8V
→	UNREG+3.8V
→	UNREG+3.8V
→	GND(A)
→	SPDIF

PCB130
VMD343

MEMORY SCHEMATIC DIAGRAM (DVD PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

RF AMP/DSP SCHEMATIC DIAGRAM

(DVD PCB)

FROM/TO MPEG/MICON/DSP




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PCB130
VMD343

AUDIO/VIDEO SCHEMATIC DIAGRAM

(DVD PCB)



	1	2	3	4
A	Y	G	CVBS	Y
B	V	R	Y	V
C	U	B	C	U
D	C	CVBS	CVBS	CVBS

FROM/TO TUNER/JACK	
CP8101_2 (CP8001)	
IMSA-9604S-14F	
V SW	14
Y(G)	13
DVD-H	12
DVD RESET	11
ZERO	10
AUDIO-R	9
GND	8
AUDIO-L	7
GND	6
V(R)	5
GND	4
U(B)	3
GND	2
CVBS	1


PCB130
VMD343

- ◁ PLAYBACK COLOR SIGNAL
- ◁ PLAYBACK LUMINANCE SIGNAL
- ◁ PLAYBACK VIDEO SIGNAL
- ◁ COMPONENT SIGNAL(U)
- ◁ COMPONENT SIGNAL(V)
- ◁ AUDIO SIGNAL(PB)

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


Y/C/AUDIO/CCD/HEAD AMP SCHEMATIC DIAGRAM (VCR PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


CAUTION: DIGITAL TRANSISTOR



- ▶▶▶ PLAYBACK VIDEO SIGNAL
- ▶▶▶ RECORD COLOR SIGNAL
- ▶▶▶ RECORD LUMINANCE SIGNAL
- ▶▶▶ AUDIO SIGNAL(REC)
- ▶▶▶ AUDIO SIGNAL(PB)
- ▶▶▶ PLAYBACK COLOR SIGNAL
- ▶▶▶ PLAYBACK LUMINANCE SIGNAL
- ▶▶▶ TUNER VIDEO SIGNAL

PCB010
VMD335

SYSCON SCHEMATIC DIAGRAM (VCR PCB)




FROM/TO POWER

TX	←
RX	←
DVD_POWER_CTL	←
AT+12.6_V	←
P.CON+5V	←
AT+5V(M-CON)	←
VCR_POWER_ON-L	←
POWER_FAIL	←
AT+5.2V	←
GND	←
MOTOR_GND	←

FROM/TO DECK

CP3001	←
TMC-J12P-B2	←
1 CAP FG	←
2 CAP VCO	←
3 VCC	←
4 CAP M/F/R	←
5 I LIMIT	←
6 MOTOR GND	←
7 GND	←
8 LD/CY VCO	←
9 CAP CTL	←
10 LDM CTL	←
11 CYL FG/PG	←
12 CYL CTL	←



NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

- ▶ RECORD LUMINANCE SIGNAL
- ▶ RECORD COLOR SIGNAL
- ▶ PLAYBACK LUMINANCE SIGNAL
- ▶ PLAYBACK COLOR SIGNAL

PCB010
VMD335

TUNER/JACK SCHEMATIC DIAGRAM

(VCR PCB)



FROM/TO AUDIO/VIDEO

FROM/TO Y/C/AUDIO/CCD/HAMP

FROM/TO SYSSCON

FROM/TO HI-FI/DEMODULATOR

FROM/TO POWER

CAUTION: DIGITAL TRANSISTOR

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

- PLAYBACK VIDEO SIGNAL
- TUNER VIDEO SIGNAL
- PLAYBACK LUMINANCE SIGNAL
- PLAYBACK COLOR SIGNAL
- RECORD COLOR SIGNAL
- RECORD LUMINANCE SIGNAL
- AUDIO SIGNAL (REC)
- AUDIO SIGNAL (PB)

PCB010 VMD335

OPERATION/DISPLAY SCHEMATIC DIAGRAM (VCR PCB)



CAUTION: DIGITAL TRANSISTOR


CAUTION: DIGITAL TRANSISTOR

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCB010
VMD335

HI-FI/DEMODULATOR SCHEMATIC DIAGRAM (VCR PCB)



NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

◁ AUDIO SIGNAL (REC)
 ◀ AUDIO SIGNAL (PB)

PCB010
VMD335

OPERATION/LED SCHEMATIC DIAGRAM

(OPERATION PCB)




PCB270
VEDA46

NOTE: THE DC VOLTAGE EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

LOADING MOTOR/SW SCHEMATIC DIAGRAM

(SW PCB)




(LOADING MOTOR PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

INTERCONNECTION DIAGRAM





CAUTION SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIECES.


NOTE: THIS INTERCONNECTION DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

WAVEFORMS




MPEG/MICON/DSP









Y/C/AUDIO/CCD/HEAD AMP






MEMORY



RF_AMP/DSP


















AUDIO/VIDEO



NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


WAVEFORMS

SYSCON




NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

WAVEFORMS




TUNER/JACK




NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

MECHANICAL EXPLODED VIEW




CHASSIS EXPLODED VIEW (TOP VIEW)



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315071000	MG-33	AB
	Y31D011000	FG-84M	AC
	Y315041000	FL-721	AD
	Y315141000	G-313Y	AE

NOTE: Applying positions AA, AB, AC, AD and AE for the grease are displayed for this section. Check if the correct grease is applied for each position.


CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315071000	MG-33	AB
	Y31D011000	FG-84M	AC
	Y315041000	FL-721	AD
	Y315141000	G-313Y	AE

NOTE: Applying positions AA, AB, AC, AD and AE for the grease are displayed for this section. Check if the correct grease is applied for each position.

DVD DECK EXPLODED VIEW



CLASS	PART NO.	PART NAME	MARK
GREASE	Y315061000	G-555G	AA
	Y315131000	SF-112	AB

NOTE: Applying positions AA and AB for the grease are displayed for this section. Check if the correct grease is applied for each position.

MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
101	7A7010032A	FRONT CABI ASS'Y	
101A	701WPC393	CABINET,FRONT	
101B	711WPDA628	PLATE,DISPLAY	
101C	712WPJB882	FLAP	
101D	713WPA0193	GLASS,LED-VCR	
101E	713WPA0194	GLASS,LED-DVD	
101F	735WPB0258	BUTTON,FRAME-DVD	
101G	735WPB0259	BUTTON,FRAME-VCR	
101H	743WKA0042	SPRING,FLAP	
101I	800WFAA015	CUSHION,LEG	
102	701WPA0686	HOLDER,DECK	
103	701WPA0751	HOLDER,DECK	
104	702WSA0216	PLATE,BOTTOM	
105	7230007787	SHEET,JACK	
106	752WSA0290	SHIELD,COMPO	
107	761WPA0261	HOLDER,DVD BR	
108	761WPA0321	HOLDER,DVD BL	
109	761WSAA025	ANGLE,FRONT	
110	85OP700038	HOLDER,END SENSOR	
111	722A08A154	SHEET,RATING	
112	752WUAA001	SHIELD,3PIN	
113	753WUA0065	SPRING,EARTH	
114	702WSA0212	CABINET,TOP	
115	712WPB0162	PLATE,TRAY-FRONT	
116	8965TS1010	CUSHION 65TS10-10	10x20x25
117	7235630010	SHEET,DVD	
118	761WPA0262	HOLDER,DECK TOP	
119	723000A698	SHEET,DISPLAY	
120	800WB00004	FIBER WASHER	7x3.2xT0.5
201	8154D3033U	SCREW,TAP TITE(B) WH8	3x33R
202	8109I30A0U	SCREW,TAP TITE(B) WH7	3x10
203	8109I30B9U	SCREW,TAP TITE(B) R PAN	3x29
204	810923070U	SCREW,TAP TITE(B) R BIND	3x7
205	810923080U	SCREW,TAP TITE(B) BIND	3x8
206	8109K30601	SCREW,TAP TITE(B) BIND(3D)	3x6
207	811022680U	SCREW,TAP TITE(P) BIND	2.6x8
208	810713040U	SCREW,TAP TITE(S) PAN	3x4
209	810722660U	SCREW,TAP TITE(S) BIND	2.6x6
210	810F13080U	SEMS(F)	3x8
---	791WHA0100	GIFT SHEET	
---	792WHA0558	PACKAGE,FRONT	
---	792WHA0117	PACKAGE,BACK	
---	793WCD1569	GIFT BOX	
---	A2D811X975	INSTRUCTION BOOK KIT	
---	J2D81121A	INSTRUCTION BOOK	
---	J3J81702C	WARRANTY SHEET	
---	JB5U0200	POLYBAG,INSTRUCTION	

CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
300	A2D801T420K	DECK ASSY A2D801T420K	501	8107226804	SCREW,TAP TITE(S) BIND 2.6x8
301	85OA400240	PINCH ROLLER BLOCK (VA)	502	83ETW30000	E-RING 3.0
302	85OA500026	AHC ASS'Y	503	8107226404	SCREW,TAP TITE(S) BIND 2.6x4
303	85OP200290	BELT,CAPSTAN (S)	504	8102120604	SCREW,PAN M2x6
304	85OP600581	WORM	505	8109126604	SCREW,TAP TITE(B) PAN 2.6x6
305	85OP500083	BASE,AC HEAD	506	810A130404	SCREW/WASHER(A) M3x4
306	85OP800324	SPRING,AC HEAD	507	810A126504	SCREW/WASHER(A) M2.6x5
307	85OA000459	MAIN CHASSIS ASS'Y	508	82Q264713N	POLYSLIDER WASHER 2.6x4.7xT0.13
308	85OA200089	CLUTCH ASS'Y	509	82P184505N	POLYSLIDER WASHER(CUT) 1.8x4.5xT0.5
309	85OA200090	ARM IDLER ASS'Y	510	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
310	85OA300065	LOADING ARM S UNIT	CD1501	122H071704	CORD JUMPER 2H071704
311	85OA300066	LOADING ARM T UNIT	CD1502	122Y021902	CORD JUMPER 2Y021902
312	85OA400223	INCLINED BASE T UUNIT 3S	H5001	1523Q91004	HEAD,AUDIO CONTROL VTR-1X2RPE22-772
313	85OA400232	P5 ARM ASS'Y 2	H5002	1543Q02014	HEAD (FULL ERASE) VTR-1X2ERS11-154
314	85OA400235	TENSION ARM ASS'Y 2	△ M101	1596S98001	MOTOR (LOADING) MDB2B66
315	85OA400231	INCLINED BASE S UNIT	△ M2001	1510S98042	CAPSTAN DD UNIT F2QVB73
316	85OP800367	SPRING,LOCKER	M2003	1589S11020	MICRO MOTOR I2OAL34
317	85OP900736	CASS,HOLDER	△ UN4001	A5L1046500	CYLINDER UNIT ASS'Y A5L1046500
318	85OP900748	CASS,SIDE L			
319	85OP900749	CASS,SIDE R			
320	85OP900739	LOCKER,R			
321	85OA900228	LINK UNIT			
322	85OP000496	POST,CASS GUIDE			
323	85OP200316	REEL,S (S)			
324	85OP200317	REEL,T (S)			
325	85OP200308	GEAR,IDLER			
326	85OP200311	GEAR,CLUTCH			
327	85OP200312	GEAR,COUPLING			
328	85OP200313	LEVER,CLUTCH			
329	85OP300194	GEAR,MAIN LOADING			
330	85OP400490	LEVER,TENSION			
331	85OP400492	HOLDER,TENSION			
332	85OP400520	CAP.P4			
333	85OP400542	BAND,TENSION			
334	85OP400533	CONNECT,TENSION			
335	85OP600573	ARM,BRAKE T			
336	85OP600584	BAND,BRAKE T			
337	85OP600577	CAM,PINCH ROLLER			
338	85OP600578	CAM,MAIN			
339	85OP600579	ROD,MAIN			
340	85OP600582	GEAR,JOINT			
341	85OP800322	SPRING,TENSION			
342	85OP800360	SPRING,BRAKE T			
343	85OP800355	SPRING,COUPLING			
344	85OP800356	SPRING,RING			
345	85OP900743	LEVER,LINK			
346	85OP900744	LEVER,FLAP			
347	85OP900745	CASS,OPENER			
348	85OP700035	REFLECTOR,LED			
349	85OP900746	BRACKET,TOP 3V			
350	85OP400549	HOLDER,CAPSTAN			

DVD DECK REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
600	A2D801X650	DVD MECHA ASS'Y	A2D801X650
601	92P100098A	HOLDER, TRAVERSE	
602	92P100094A	CLAMPER	
603	92P100088A	GEAR, MOTOR	
604	92AAA0013A	FEED RACK ASS'Y	
605	92P200013A	INSULATOR(F)	
606	92P200014A	INSULATOR(R)	
607	92SBB0020A	LOADER SUB ASS'Y	
608	92P100095A	GEAR, PULLEY	
609	92P100097A	PULLEY, MOTOR	
610	92P100096A	GEAR, MAIN	
611	92P200012A	BELT, LOADING	
612	92P000014A	PLATE, CLAMPER	
613	92P100093A	RACK, LOADING	
614	92P100091A	FRAME, MAIN	
615	92P100100A	TRAY	
616	92P100089A	RACK, FEED 1	
617	92P100090A	RACK, FEED 2	
618	92P300020A	SPRING, RACK FEED	
701	811022680U	SCREW, TAP TITE(P) BIND	2.6x8
702	814011723U	SCREW, PAN	M1.7x2.3 P3
703	816112080U	SEMS. TAP TITE(P) PAN W10	2x8
704	814011730U	SCREW, PAN	M1.7x3 P3
705	811022080U	SCREW, TAP TITE(P) BIND	2x8
CD2001	122H001901	CORD JUMPER	2H001901
CD2301	122H062102	CORD JUMPER	2H062102
CD2302	122H052601	CORD JUMPER	2H052601
△ M2602	1515S98002	FEED MOTOR	BCZ3B03
M2603	1596S18002	LOADING MOTOR	BCZ3B52
PCB610	A2D801X610	PCB ASS'Y	VEDA47A
PCB640	A5M4016640	PCB ASS'Y	DED002A
SW1	0515S32002	SWITCH	SSS-13-2
SW2	0500101037	PUSH SWITCH	ESE22MH24

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
RESISTORS			ICS		
△ R501	R0G3K2335K	RC 3.3M OHM 1/2W	IC4007	ICMJ0800A8	IC SST39VF800A-70-4C-EK-D
△ R502	R3X181010J	R,METAL OXIDE 1 OHM 1W	IC8001	I0QJ045800	IC NJM4580M(Te1)
△ R503	R002T2155J	RC 1.5M OHM 1/2W	IC8005	I0UF015010	IC MM1501XNRE
△ R504	R002T2561J	RC 560 OHM 1/2W	IC8102	I17F017530	IC PCM1753DBQR
△ R512	R3X181683J	R,METAL OXIDE 68K OHM 1W	TRANSISTORS		
△ R516	R63581R22J	R,FUSE 0.22 OHM 1W	Q101	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
△ R517	R002T2102J	RC 1K OHM 1/2W	Q102	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
CAPACITORS			Q103	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
△ C501	E02LF2222M	CE 2200 UF 16V	Q104	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
△ C502	P2122B224M	CMP 0.22 UF 275V ECQUL	Q105	TAATA12660	TRANSISTOR,SILICON KTA1266-AT(Y,GR)
△ C505	E02LU2101M	CE 100 UF 16V	Q107	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
△ C511	E62QFC470M	CE 47 UF 200V	Q109	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
△ C513	C03L0R7H2K	CC 220 PF 2KV R	Q301	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
△ C514	E02LU2101M	CE 100 UF 16V	△ Q501	T25F035630	FET 2SK3563(ORION-Q)
△ C515	C0J0B0514K	CC 0.01 UF 500V B	△ Q502	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
△ C516	CC3LE0MH3M	CC 0.0022UF 250V	△ Q503	TCAT03209Y	TRANSISTOR,SILICON KTC3209_Y-AT
△ C518	E61FF0222D	CE 2200 UF 6.3V	△ Q504	TAAT012714	TRANSISTOR,SILICON KTA1271_Y-AT
△ C519	E02LF1222M	CE 2200 UF 10V	△ Q505	TD3T012070	TRANSISTOR,SILICON 2SD1207(S,T)-AE
△ C521	E02LU2101M	CE 100 UF 16V	Q506	TNAAC05002	COMPOUND TRANSISTOR KRC103SRTK
△ C522	E02LU5220M	CE 22 UF 50V	△ Q507	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT
△ C525	C0PLRR7U2K	CC 680 PF 2KV R	Q509	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ C526	CC3LE0MH3M	CC 0.0022UF 250V	△ Q510	TD3T012070	TRANSISTOR,SILICON 2SD1207(S,T)-AE
△ C540	E62QFC470M	CE 47 UF 200V	Q513	T8YJ2412K0	TRANSISTOR,SILICON 2SC2412KT146 R,S
DIODES			Q514	T8YJ2412K0	TRANSISTOR,SILICON 2SC2412KT146 R,S
D501	D1VT001330	DIODE,SILICON 1SS133T-77	Q651	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
△ D502	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q652	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D503	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q653	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D504	D1VT001330	DIODE,SILICON 1SS133T-77	Q654	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
△ D505	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q655	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D506	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q656	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D507	D23TGP15J0	DIODE,SILICON RGP15J-G23	Q657	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D508	D1VT001330	DIODE,SILICON 1SS133T-77	Q658	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D509	D2WXGP10J0	DIODE,RECTIFIER RGP10J-EIC	Q659	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
△ D510	D97U02201B	DIODE,ZENER MTZJ22B T-77	Q660	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D511	D2LKB340L0	DIODE,SCHOTTKY SB340L-6737	Q661	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
D512	D1VT001330	DIODE,SILICON 1SS133T-77	Q662	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D513	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q663	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D514	D97U01201B	DIODE,ZENER MTZJ12B T-77	Q664	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
△ D515	D28T21DQN4	DIODE,SCHOTTKY 21DQ04N-TA2B1	Q665	TAAA1504SY	TRANSISTOR,SILICON KTA1504S_Y_RTK
D516	D97U05R11B	DIODE,ZENER MTZJ5.1B T-77	Q666	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D518	D1VT001330	DIODE,SILICON 1SS133T-77	Q2601	T67J1036K0	TRANSISTOR,SILICON 2SA1036KT146
D519	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77	Q2602	T67J048TL0	TRANSISTOR,SILICON 2SA2048TL
D520	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q2603	T27T030180	FET 2SK3018
△ D522	D28TELS6N6	DIODE,RECTIFIER 10ELS6N-TA1B2	Q2604	T27T030180	FET 2SK3018
△ D523	D97U03301B	DIODE,ZENER MTZJ33B T-77	Q2605	T27T030180	FET 2SK3018
D524	D1VT001330	DIODE,SILICON 1SS133T-77	Q3002	0002700690	PHOTO COUPLER RPI-303
D526	D97U03R31B	DIODE,ZENER MTZJ3.3B T-77	Q3003	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D527	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q3004	0002700680	PHOTO COUPLER RPI-352C40N
D528	D1VT001330	DIODE,SILICON 1SS133T-77	Q3005	0002700680	PHOTO COUPLER RPI-352C40N
D651	0021E2Q140	LED LTL-1CHEE-002A	Q3006	0000M00390	PHOTO TRANSISTOR ST-304L
D656	D2WXN40050	DIODE,SILICON 1N4005-EIC	Q3007	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D685	0021E2Q140	LED LTL-1CHEE-002A	Q3008	0000M00390	PHOTO TRANSISTOR ST-304L
D2601	DDARDS1200	DIODE,SILICON KDS120RTRK	Q8001	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D3001	0010E00330	INFRARED LED LTE-3271T-012A-O	Q8002	TNYJD05001	COMPOUND TRANSISTOR DTC144EKAT146
D3002	D1VT001330	DIODE,SILICON 1SS133T-77	Q8003	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
D3007	D1VT001330	DIODE,SILICON 1SS133T-77	Q8004	TAATA12660	TRANSISTOR,SILICON KTA1266-AT(Y,GR)
D3009	D1VT001330	DIODE,SILICON 1SS133T-77	Q8005	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D8004	D1VT001330	DIODE,SILICON 1SS133T-77	Q8006	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D8005	D1VT001330	DIODE,SILICON 1SS133T-77	Q8007	TPYJC05001	COMPOUND TRANSISTOR DTA124EKAT146
D8006	D1VT001330	DIODE,SILICON 1SS133T-77	Q8008	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D8111	DDRL41480	DIODE,SILICON MCL4148	Q8009	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
D8112	DDRL41480	DIODE,SILICON MCL4148	Q8010	TPYJA05001	COMPOUND TRANSISTOR DTA143EKAT146
ICS			Q8011	TNYJC05001	COMPOUND TRANSISTOR DTC124EKAT146
IC101	I03F3206M0	IC LA71206M-MPB	Q8012	TCAA3875SY	TRANSISTOR,SILICON KTC3875S_Y_RTK
△ IC501	I0CJ9AILP0	IC TL431AILP	COILS & TRANSFORMERS		
△ IC502	I1KA98R09A	IC KIA78R09API	L101	031626010R	COIL,BIAS OSC 1626010
△ IC503	000220002W	PHOTO COUPLER PS2561AL1-1-V(W)	L102	02167F101J	COIL 100 UH
IC701	I03F670BM0	IC LA72670BM-L-MPB-E	L301	02167F220J	COIL 22 UH
IC2301	I03F065650	IC LA6565-TE-L-E	△ L501	029X000117	COIL,LINE FILTER SS11VL-05230
IC2601	ICQK067080	IC ZR36708TQC	L505	02167F220J	COIL 22 UH
IC3001	I54F50147A	IC OEC0147A	L506	021W7A220K	COIL 22 UH
IC3003	I9UF032310	IC PST3231NR	L701	021LA6220J	COIL 22 UH
IC3099	S2D801XE01	MEMORY DATA S-24C02BFJ-TB	L702	021LA6220J	COIL 22 UH
IC4001	ICQK06762V	IC ZR36762PQCG_V	L703	02167F220J	COIL 22 UH
IC4002	I5HJ002BF0	IC S-24C02BFJ-TB	L704	02167F220J	COIL 22 UH
IC4003	I0BF97KWM0	IC SI-3007KWM-TL	L705	02167F220J	COIL 22 UH
IC4005	IF3J00HGT7	IC HY57V641620HGT-7	L3002	021W7A220K	COIL 22 UH

ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
COILS & TRANSFORMERS			*** RESISTORS ***		
L3003	021LA6120J	COIL 12 UH	NR4001	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L4001	02167F2R2J	COIL 2.2 UH	NR4002	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8001	021LA6R33M	COIL 0.33 UH	NR4003	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8002	021LA6R33M	COIL 0.33 UH	NR4004	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8102	02167F1R0K	COIL 1 UH	NR4005	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8103	02167F1R0K	COIL 1 UH	NR4006	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8104	02167F1R0K	COIL 1 UH	NR4007	110P4101M4	R.NETWORK 4D03WGJ0101T5E
L8105	02167F1R0K	COIL 1 UH	NR4008	110P4101M4	R.NETWORK 4D03WGJ0101T5E
△ T501	0481291244	TRANSFORMER, SWITCHING 81291244	OS651	077Q037009	REMOTE RECEIVER PIC-37043LO-H
JACKS			OS8001	07AQ000009	OPTICAL DEVICE OFTG038101
J8001	060J411031	RCA JACK MSP-213V1-432_NI_LF	TM601	076R0JN01A	TRANSMITTER R56-0532
J8003	060J401099	RCA JACK MSP-281V42-B	△ TU301	0162300042	RF UNIT 115-V-H035ARE
J8004	060J401098	RCA JACK MSP-281V40-B	V651	0040H54010	LED DISPLAY CO2D0M3-A
J8005	060J421039	RCA JACK MSP-281V31-A	X101	100DT3R528	CRYSTAL HC-49/U
J8006	060J411033	RCA JACK MSP-213V1-732_NI_LF	X3001	100GT01006	CRYSTAL B1000C001
J8007	060J411032	RCA JACK MSP-213V1-652_NI_LF	X4001	100BT02701	CRYSTAL HC-49U/S
J8008	063D700008	JACK MDC-070V-B_LF			
SWITCHES			RESISTOR		
SW651	0504101T34	SWITCH, TACT EVQ21505R	RC..... CARBON RESISTOR		
SW652	0504101T34	SWITCH, TACT EVQ21505R			
SW653	0504101T34	SWITCH, TACT EVQ21505R	CAPACITORS		
SW654	0504101T34	SWITCH, TACT EVQ21505R	CC..... CERAMIC CAPACITOR		
SW655	0504101T34	SWITCH, TACT EVQ21505R	CE..... ALUMI ELECTROLYTIC CAPACITOR		
SW685	0504R01T38	SWITCH, TACT EVQ11L05R	CP..... POLYESTER CAPACITOR		
SW686	0504R01T38	SWITCH, TACT EVQ11L05R	CPP..... POLYPROPYLENE CAPACITOR		
SW687	0504R01T38	SWITCH, TACT EVQ11L05R	CPL..... PLASTIC CAPACITOR		
SW688	0504R01T38	SWITCH, TACT EVQ11L05R	CMP..... METAL POLYESTER CAPACITOR		
SW689	0504R01T38	SWITCH, TACT EVQ11L05R	Cmpl..... METAL PLASTIC CAPACITOR		
SW690	0504R01T38	SWITCH, TACT EVQ11L05R	CMPP..... METAL POLYPROPYLENE CAPACITOR		
SW3001	0508S11001	SWITCH (LEAF) LSA-1144EAU			
SW8001	0510Y24001	SWITCH SLIDE SK42H01G9A			
P.C. BOARD ASSEMBLIES					
PCB010	A2D811H010	PCB ASS'Y VMD335A			
PCB130	A2D814H130	PCB ASS'Y VMD343A			
PCB270	A2D804X270	PCB ASS'Y VEDA46A			
MISCELLANEOUS					
B501	024HT03563	CORE, BEADS W4BRH3.5X6X1.0X2			
B2601	024HC31022	CORE, BEADS FCM2012H-102T04			
B2602	024HC31022	CORE, BEADS FCM2012H-102T04			
B2603	024HC31022	CORE, BEADS FCM2012H-102T04			
B2604	024HC31022	CORE, BEADS FCM2012H-102T04			
B2605	024HC31022	CORE, BEADS FCM2012H-102T04			
B4001	024HC31022	CORE, BEADS FCM2012H-102T04			
B4002	024HC31022	CORE, BEADS FCM2012H-102T04			
B4003	024HC31022	CORE, BEADS FCM2012H-102T04			
B4004	024HC31022	CORE, BEADS FCM2012H-102T04			
B4005	024HC31022	CORE, BEADS FCM2012H-102T04			
B4006	024HC31022	CORE, BEADS FCM2012H-102T04			
B4007	024HC31022	CORE, BEADS FCM2012H-102T04			
B4008	024HC31022	CORE, BEADS FCM2012H-102T04			
B4010	024HC31022	CORE, BEADS FCM2012H-102T04			
B8001	024HC31022	CORE, BEADS FCM2012H-102T04			
B8002	024HC31022	CORE, BEADS FCM2012H-102T04			
B8003	024HC31022	CORE, BEADS FCM2012H-102T04			
B8103	024HC31022	CORE, BEADS FCM2012H-102T04			
CD102	122F041508	CORD, JUMPER 2F041508			
△ CD501	1209414910	CORD, AC BUSH 9414910			
CD681	122H051202	CORD, JUMPER 2H051202			
CP101	0697290620	CONNECTOR PCB SIDE TOC-C09X-A1			
CP102	069J740599	CONNECTOR PCB SIDE IMSA-9604S-04C			
CP103	067U002019	WIRE HOLDER B2013H02-2P			
CP501	069S2B0629	CONNECTOR PCB SIDE A2001WV2-11P			
CP651	069J750589	CONNECTOR PCB SIDE IMSA-9604S-05F			
CP681	069J750589	CONNECTOR PCB SIDE IMSA-9604S-05F			
CD4002	06CU2B1101	CORD, CONNECTOR CU2B1101			
CD6002	06CPL02006	CABLE CPL02006			
CD6003	06CPBA2003	CORD, RCA PIN TD-020301-3			
CD8001	122F0E1001	CORD, JUMPER 2F0E1001			
CP2601	069GYOT119	CONNECTOR PCB SIDE 09-5000-024-001-001			
CP2602	069EV53010	CONNECTOR PCB SIDE 00_6232_005_006_800			
CP2603	069EV63010	CONNECTOR PCB SIDE 00_6232_006_006_800			
CP3001	06972C0010	CONNECTOR PCB SIDE TMC-J12P-B2			
CP8001	069J7E0599	CONNECTOR PCB SIDE IMSA-9604S-14C			
CP8101	069J7E0589	CONNECTOR PCB SIDE IMSA-9604S-14F			
△ F501	081PC2R505	FUSE 51MS025L			
FH501	06710T0009	HOLDER, FUSE EYF-52BCY			
FH502	06710T0009	HOLDER, FUSE EYF-52BCY			

SPEC.NO.	M2D8-11H
O/R NO.	K462001