


# Memorex®

## MVT2196

# SERVICE MANUAL

COLOR TELEVISION/  
VIDEO CASSETTE RECORDER

ORIGINAL  
MFR'S VERSION A



VHS

### SPECIFICATIONS

#### (TV SECTION)

**PICTURE SIZE:** 19 inch  
**SYSTEM:** NTSC  
**FREQUENCY RANGE**  
VHF: 2-13ch  
UHF: 14-69 ch  
CATV: 14-36 (A)-(W) ch  
37-59 (AA)-(WW) ch  
60-85 (AAA)-(ZZZ) ch  
86-94 (86)-(94) ch  
95-99 (A-5)-(A-1) ch  
100-125 (100)-(125) ch  
01 (5A) ch

**INTERMEDIATE FREQUENCY**  
Picture IF Carrier Frequency: 45.75 MHz  
Sound IF Carrier Frequency: 41.25 MHz

**SOUND INTERMEDIATE FREQUENCY:** 4.5 MHz  
**MAXIMUM OUTPUT POWER:** 2.5 W  
**10% THD OUTPUT POWER:** 2.0 W  
**SPEAKER:** 16 ohm x 2  
**POWER SOURCE:** AC 120V, 60Hz  
**POWER CONSUMPTION:** 86 Watts

#### (VCR SECTION)

**OPERATING TEMPERATURE:** 5°C to 40°C  
**STORAGE TEMPERATURE:** -20°C to 60°C  
**VIDEO RECORDING SYSTEM:** VHS, 2 rotary heads helical scanning system  
Luminance: FM azimuth recording  
Color Signal: Converted subcarrier phase shift recording

**HEADS:** Video: 2 Rotary Heads  
Audio/Control: 1 Stationary Head  
Erase: 1 Full Track Erase Head

**TAPE WIDTH:** 12.65 mm high density tape  
**AUDIO TRACK:** 1 track  
**F.FWD TIME:** Approx. 3' 40"(T-120 Cassette)  
**REW TIME:** Approx. 2' 50"(T-120 Cassette)  
**TAPE SPEED:** SP: 33.35 mm/sec  
LP: 16.67 mm/sec  
SLP: 11.12 mm/sec

**INPUT LEVEL:** Video: 1.0Vp-p, 75 ohm unbalanced  
Audio: 300mV, 50k ohm unbalanced

**OUTPUT LEVEL:** Video: 1.0Vp-p, 75 ohm unbalanced  
Audio: 300mV, 1k ohm unbalanced

**WEIGHT:** 48.4 lbs  
**DIMENSIONS:** 19 1/2"(W) x 18 5/9"(D) x 19 1/16"(H)

SPEC.NO.	M546-09A
O/R NO.	W935009

Design and specifications are subject to change without notice.



**MVT2196**

# **SERVICE MANUAL**

---

**COLOR TELEVISION/VIDEO CASSETTE RECORDER**

**REVISION 1  
MFR'S VERSION C**

MFR'S VERSION	IC101	M2001
A	OEC7034A	EP15BB
C	OEC7034B	F2QSB02



---

Please file this revision with the original version.

## Change of IC1001

### DIFFERENCES

REF. NO.	MFR'S VERSION A		MFR'S VERSION C	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
IC1001	I56F57034A	IC OEC7034A	I56F57034B	IC OEC7034B
PCB010	A54609A01A	SYSCON PCB ASS'Y VM9149A	A54609A01B	SYSCON PCB ASS'Y VM9149A

### NOTE FOR THE REPLACING OF MEMORY IC

ADDRESS	MFR'S VERSION A	MFR'S VERSION C
	DATA	DATA
14	94	04

## Change of CAPSTAN DD UNIT

### CHASSIS REPLACEMENT PARTS LIST


REF. NO.	MFR'S VERSION A		MFR'S VERSION C	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
M2001	1594J98007	CAPSTAN DD UNIT EP15BB	1510398030	CAPSTAN DD UNIT F2QSB02

### NOTE FOR THE REPLACING OF MEMORY IC

ADDRESS	MFR'S VERSION A	MFR'S VERSION C
	DATA	DATA
10	6C	C0
11	2B	68
12	21	5C
13	15	53

SPEC.NO.	M546-09A
O/R NO.	W995015

# Y/C/AUDIO/HEAD AMP SCHEMATIC DIAGRAM




- ▶ RECORD LUMINANCE SIGNAL
- ▶ PLAYBACK LUMINANCE SIGNAL
- ▶ RECORD COLOR SIGNAL
- ▶ PLAYBACK COLOR SIGNAL
- ▶ TUNER VIDEO SIGNAL
- ▶ AUDIO SIGNAL(REC)
- ▶ AUDIO SIGNAL(PB)

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PC8010  
VM9149

# MICON SCHEMATIC DIAGRAM



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE RESISTOR MARKED F IS FUSE RESISTOR. THE ALUMI ELECTROLYTIC CAPACITOR MARKED NP IS NON POLAR ONE.

CAUTION: SINCE THESE PARTS MARKED BY  $\Delta$  ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARABLES PAR UN  $\Delta$  ETANT DANGEREUSES AU POINT DE VUE SECURITE, UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIECES.


CAUTION: DIGITAL TRANSISTOR



- $\triangleleft$  TUNER VIDEO SIGNAL
- $\blacktriangleleft$  DEFLECTION SIGNAL
- $\blacktriangleleft$  CAPSTAN AFC SIGNAL
- $\blacktriangleleft$  CYLINDER AFC SIGNAL
- $\blacktriangleleft$  CYLINDER APC SIGNAL
- $\blacktriangleleft$  R.SIGNAL
- $\blacktriangleleft$  G.SIGNAL
- $\blacktriangleleft$  B.SIGNAL

PCB010 VM9149

# POWER SCHEMATIC DIAGRAM



FROM TV POWER

1	GND
2	AT+12V
3	AT+12V
4	P.CON+9V
5	AT+5.6V
6	MOTOR GND
7	AT+30V
8	POWER_FAIL(DC)
9	-NC
10	-NC

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIECES.

PCB810 VM9149


# IN/OUT SCHEMATIC DIAGRAM



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


CAUTION: DIGITAL TRANSISTOR



◁ TUNER VIDEO SIGNAL  
 ⇨ AUDIO SIGNAL

PC8010  
 VM8149

# CHROMA/IF SCHEMATIC DIAGRAM



- ◀ TUNER VIDEO SIGNAL
- ▲ R SIGNAL
- ▲ G SIGNAL
- ▲ B SIGNAL
- ◀ DEFLECTION SIGNAL
- ◀ LUMINANCE SIGNAL
- ◀ COLOR SIGNAL

CAUTION: SINCE THESE PARTS MARKED BY  $\Delta$  ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

ATTENTION: LES PIÈCES REPAREES PAR UN  $\Delta$  ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRIRES DANS LA NOMENCLATURE DES PIÈCES.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


CAUTION: DIGITAL TRANSISTOR



PC8010 VM9149



# SOUND AMP SCHEMATIC DIAGRAM



↔ AUDIO SIGNAL

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY .

ATTENTION: LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIECES.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE .


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

PC8010  
VM9149

# TV POWER SCHEMATIC DIAGRAM



CAUTION: FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE FUSE: 5A 125V (F501, ICP503, ICP504, 2.5A 250V (F502), 4A 125V (ICP502) AND 2A 125V (ICP505).  
 ATTENTION: POUR UNE PROTECTION CONTINUE LES RISQUES D'INCENDIE N'UTILISER QUE DES FUSIBLES DE MEME TYPE.  
 CAUTION: ICP502, ICP503, ICP504 AND ICP505 ARE MANUFACTURED BY LITTELFUSE INC., TYPE 251.





NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


ATTENTION: LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.


CAUTION: DIGITAL TRANSISTOR



IS THE LIVE CONNECTION CAUTION:



# DEFLECTION SCHEMATIC DIAGRAM



- FROM TO CHROMA/IF
- 1 SOUND GND
  - 2 SOUND -B
  - 3 VCR POWER H
  - 4 TV POWER H
  - 5 GND
  - 6 H.OUT
  - 7 V.PULSE
  - 8 V.OUT
  - 9 A.C.
  - 10 A.F.C.
  - 11 X.RAY

- FROM TO TV POWER
- TV POWER H
  - VCR POWER H
  - SOUND -B
  - SOUND GND
  - P.CONV-9V
  - P.CONV-125V
  - GND

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


ATTENTION: LES PIÈCES RÉPARÉES PAR UN ÉTAIENT DANGEREUSES AN POINT DE VUE SECURITE. UTILISER QUE CELLS DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.


NOTE: THE RESISTOR MARKED F IS FUSE RESISTOR. THE ALUMI ELECTROLYTIC CAPACITOR MARKED NP IS NON POLAR ONE.

PCB070  
TM9416

# CRT SCHEMATIC DIAGRAM



◀ R.SIGNAL  
 ▲ G.SIGNAL  
 ◀◀ B.SIGNAL




CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

# OPERATION SCHEMATIC DIAGRAM




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SÉCURITÉ, N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

TUNER VIDEO SIGNAL  
 AUDIO SIGNAL


# DECK SCHEMATIC DIAGRAM



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

# INTERCONNECTION DIAGRAM




CAUTION: SINCE THESE PARTS MARKED BY  $\Delta$  ARE CRITICAL FOR SAFETY USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN  $\Delta$  ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRIRES DANS LA NOMENCLATURE DES PIÈCES.


NOTE: THIS INTERCONNECTION DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

## WAVEFORMS

### POWER(TV)




① 5.0V 20ms/div




⑥ 50.0V 20μs/div

### Y/C/AUDIO/HEAD AMP




⑪ PB  
0.5V 0.5ms/div


### DEFLECTION



② 2.0V 20μs/div




⑦ 50.0V 20μs/div




⑫ PB  
100mV 1ms/div


### DEFLECTION



③ 0.5V 5ms/div




⑧ 10.0V 5ms/div




⑬ PB  
50mV 0.5ms/div


### POWER(TV)



④ 200mV 20μs/div




⑨ 20.0V 20μs/div




⑭ PB  
0.5V 20μs/div


### CRT



⑤ 50.0V 20μs/div



⑩ 500mV 5μs/div




⑮ POWER ON  
0.5V 20μs/div


NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.




# WAVEFORMS




①⑥ REC  
100mV 20 $\mu$ s/div




②① PB  
1.0V 0.5ms/div




②⑥ POWER ON  
0.5V 10ms/div




①⑦ POWER ON  
0.5V 1ms/div




②② PB  
1.0V 5ms/div




②⑦ POWER ON  
20.0V 20 $\mu$ s/div



①⑧ POWER ON  
50mV 1ms/div




②③ PB  
1.0V 5ms/div




②⑧ POWER ON  
5.0V 5ms/div

## MICON




①⑨ PB  
1.0V 10ms/div




②④ POWER ON  
1.0V 10 $\mu$ s/div


## IN/OUT




②⑨ POWER ON  
0.5V 20 $\mu$ s/div



②⑩ PB  
0.5V 0.5ms/div



②⑤ POWER ON  
1.0V 20 $\mu$ s/div




③⑩ POWER ON  
200mV 20 $\mu$ s/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


## WAVEFORMS

### CHROMA/IF




③① POWER ON  
0.5V 1ms/div


### SOUND AMP




③⑥ POWER ON  
200mV 1ms/div




③② POWER ON  
50mV 1ms/div



③③ POWER ON  
0.5V 20μs/div




③④ POWER ON  
200mV 20μs/div




③⑤ POWER ON  
10.5V 20μs/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


# MECHANICAL EXPLODED VIEW



# MECHANICAL EXPLODED VIEW




# CHASSIS EXPLODED VIEW (TOP VIEW)



CLASS	PART NO.	MARK
GREASE	G-555G	AA
	G-488M	AB
	FL-721	AC
OIL	KYODO OIL SLIDAS No. 150	BA

**NOTE:** Applying positions AA, AB, AC and BA for the grease or oil are displayed for this section. Check if the correct grease or oil is applied for each position.

# CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	PART NO.	MARK
GREASE	G-555G	AA
	G-488M	AB
	FL-721	AC
OIL	KYODO OIL SLIDAS No. 150	BA

**NOTE:** Applying positions AA, AB, AC and BA for the grease or oil are displayed for this section. Check if the correct grease or oil is applied for each position.

# MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION
101	A54609A720	CABINET,FRONT ASS'Y
102	752WSA0144	SHIELD,CASE HEAD AMP
103	753WUA0051	SPRING,EARTH HEAD AMP
104	771WPAA010	PLATE,JACK
105	761WPA0145	HOLDER,FBT
106	----	HEAT SINK
107	----	HEAT SINK
108	----	HEAT SINK
109	----	HEAT SINK
110	----	METAL SPACER
111	8995034000	CORD CLIP UL CO.
112	----	COATING CLIP
113	701WPJ0839	CABINET,FRONT
114	711WPA0114	PLATE,FRONT
115	712WPJ0621	FLAP
116	713WPA0075	GUIDE,REMOCON
117	769WSA0008	WASHER CRT T=2
118	735WPJ0114	BUTTON,FRAME
119	735WPA0402	BUTTON,REC
120	743WKA0032	SPRING,FLAP
121	7230006830	SHEET,LED
122	702WPA0565	CABINET,BACK
123	752WSA0145	PLATE,DECK SHIELD
124	----	HEAT SINK
125	761WPA0157	HOLDER,DECK
126	761WPA0161	HOLDER,BACK
127	890PS70100	PUSH SPACER
128	7220001059	SHEET,CSA WARNING
129	7220001107	SHEET,HWC
130	722A080002	SHEET,RATING
131	7230006818	SHEET,CAUTION
132	741WUA0012	SPRING,EARTH
133	753WSA0123	PLATE,SPEAKER
134	800WFA0005	CUSHION 10x15xT3
135	753WSA0118	PLATE,EARTH-SYSCON
136	7260000308	SHEET,CRT SERVICEMAN
137	----	HEAT SINK
138	800WR00066	SHEET CRT SUPPORT(D)
201	8117540B04	SCREW,TAPPING(B0) TRUSS 4x20
202	8117540A64	SCREW,TAPPING(B0) TRUSS 4x16
203	8117140A24	SCREW,TAPPING(B0) PAN 4x12
204	8110630A24	SCREW,TAP TITE(P) BRAZIER 3x12
205	8110630A04	SCREW,TAP TITE(P) BRAZIER 3x10
206	8110630804	SCREW,TAP TITE(P) BRAZIER 3x8
207	8110230A02	SCREW,TAP TITE(P) BIND 3x10
208	8110330804	SCREW,TAP TITE(P) FLAT 3x8
209	8110630604	SCREW,TAP TITE(P) BRAZIER 3x6
210	8107630604	SCREW,TAP TITE(S) BRAZIER 3x6
211	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
212	8109630802	SCREW,TAP TITE(B) BRAZIER 3x8
213	810A130B04	SCREW/WASHER(A) M3x20
214	8300495207	NUT
215	810A130804	SCREW/WASHER(A) M3x8
216	810A130604	SCREW/WASHER(A) M3x6
217	810B130A04	SCREW/WASHER(B) M3x10
218	810B130804	SCREW/WASHER(B) M3x8
219	8121J50B54	SCREW,TAPPING(B0) GW20 5x28
220	82A97A4077	WASHER 9.7x14xT0.7
---	791WHA0025	LAMIFILM BAG
---	792WHAA025	PACKAGE, TOP
---	792WHAA026	PACKAGE,BOTTOM
---	793WCD1151	GIFT BOX
---	JA5K0100	POLY BAG
---	J5451001	INSTRUCTION BOOK

## CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
301	85OA500022	AHC ASS'Y	501	8107126A04	SCREW,TAP TITE(S) PAN 2.6x10
302	85OP200270	BELT,CAPSTAN	502	8107226804	SCREW,TAP TITE(S) BIND 2.6x8
303	85OP900689	LEVER,REC	503	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
304	85OP500083	BASE,AC HEAD	504	8109126604	SCREW,TAP TITE(B) PAN 2.6x6
305	85OP800324	SPRING,AC HEAD	505	810A126804	SCREW/WASHER(A) M2.6x8
306	85OA000297	MAIN CHASSIS ASS'Y	506	810B126404	SCREW/WASHER(B) M2.6x4
307	85OA200072	CLUTCH ASS'Y	507	8102120604	SCREW,PAN M2x6
308	85OA200073	ARM,IDLER ASS'Y	508	8102120304	SCREW,PAN M2x3
309	85OP600553	ARM,S-S BRAKE	509	8102130304	SCREW,PAN M3.0x3.0
310	85OA200076	T REEL ASS'Y	510	82Q3154C5N	POLYSLIDER WASHER 3.1x5.4xT0.25
311	85OA300061	LOADING ARM S ASS'Y	511	82P266005N	POLYSLIDER WASHER(CUT) 2.6x6.0xT0.5
312	85OA300062	LOADING ARM T ASS'Y	512	82Q264713N	POLYSLIDER WASHER 2.6x4.7xT0.13
313	85OA400102	GUIDE ROLLER ASS'Y	513	82P184505N	POLYSLIDER WASHER(CUT) 1.8x4.5xT0.5
314	85OA400171	BASE,INCL S ASS'Y	514	83ETW30000	E-RING 3.0
315	85OA400172	BASE,INCL T ASS'Y	515	810A123504	SEMS A M2.3x5.0
316	85OA400185	P5-2 ARM ASS'Y	516	810A123A04	SCREW/WASHER(A) M2.3x10
317	85OA400174	PINCH ROLLER BLOCK	517	82A2675051	WASHER 2.6x7.5xT0.5
318	85OA400175	TENSION ARM ASS'Y			
319	85OA400176	TENSION BAND ASS'Y	CP101	069R740018	CONNECTOR PCB SIDE 52044-0445
			CP102	0694220139	CONNECTOR PCB SIDE 173979-2
320	85OA400178	PINCH ROLLER LEVER ASS'Y			
321	85OA600182	BRAKE T ASS'Y	H5001	1523D91034	HEAD (AUDIO CONTROL) HVMXA1072A
322	85OA600183	CAP BRAKE ARM ASS'Y	H5002	1543D02013	HEAD (FULL ERASE) HVFHP0032A
323	85OA900213	LINK ASS'Y			
324	85OA900216	LINK LEVER ASS'Y	△ M101	1596P78001	MOTOR (LOADING) MXN13FB11H
325	85OP200261	LEVER,CLUTCH	△ M2001	1594J98007	CAPSTAN DD UNIT EP15BB
326	85OP200262	RING,CLUTCH	M2003	1589V11006	MICRO MOTOR EP14BC
327	85OP200263	GEAR,CLUTCH			
328	85OP200271	REEL,S	PCB550	A4C701B550	DECK PCB ASS'Y VE8851
329	85OP200273	STOPPER,REEL S			
			Q101	0000700320	TRANSISTOR,PHOTO RPT-38PB113
			Q102	0000700320	TRANSISTOR,PHOTO RPT-38PB113
330	85OP200274	SPACER,LINK LEVER			
331	85OP300178	GEAR,MAIN LOADING			
332	85OP300179	GEAR,LOADING S	△ UN4001	A54501A500	CYLINDER UNIT ASS'Y A54501A500
333	85OP300180	GEAR,LOADING T			
334	85OP300185	HOLDER,LOADING GEAR			
335	85OP400472	ADJUST,TENSION			
336	85OP400492	HOLDER,TENSION			
337	85OP400474	LEVER,TENSION			
338	85OP400475	COVER,P4			
339	85OP600543	GEAR,JOINT			
340	85OP600544	GEAR,MIDDLE			
341	85OP600545	CAM,MAIN			
342	85OP600546	CAM,P5			
343	85OP600547	CAM,PINCH ROLLER			
344	85OP600548	ROD,MAIN			
345	85OP700035	REFLECTOR,LED			
346	85OP800318	SPRING,LOADING GEAR			
347	85OP800319	SPRING,P5			
348	85OP800321	SPRING,BRAKE T			
349	85OP800322	SPRING,TENSION			
350	85OP800323	SPRING,CAP BRAKE			
351	85OP800325	SPRING,LOCKER			
352	85OP800326	SPRING,LINK			
353	85OP800328	SPRING,DAMPER			
354	85OP800330	SPRING,RING			
355	85OP800332	SPRING,S-S BRAKE			
356	85OP900680	OPENER,CASS			
357	85OP900683	CASS SIDE L			
358	85OP900684	CASS SIDE R			
359	85OP900702	TAPE GUIDE L(P,R)			
360	85OP900686	TAPE GUIDE R			
361	85OP900687	COVER,SENSOR L			
362	85OP900688	LEVER,FLAP			
363	85OP900690	CASS HOLDER			
364	85OP900691	LOCKER,L			
365	85OP900692	LOCKER,R			
366	85OP900694	SPRING,PACK			
367	85OP900695	BRACKET,TOP			
368	85OP900696	SPRING,CASS EARTH			
369	85OP600540	DRIVER,WORM			
370	85OP400485	O-RING			
371	85OP600541	WORM			
372	85OP600542	BRACKET,MOTOR			
373	85OPAA0282	SHIELD,DRUM MOTOR3			
374	85OPAA0333	COLLAR,SHIELD			



# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>RESISTORS</b>					
△ R418	R4X5T41R5F	R,METAL			1.5 OHM 1/4W
△ R439	R4X5T4223F	R,METAL			22K OHM 1/4W
	R425T4223F	R,METAL			22K OHM 1/4W
△ R440	R4X5T4822F	R,METAL			8.2K OHM 1/4W
	R425T4822F	R,METAL			8.2K OHM 1/4W
△ R441	R4X5T4104F	R,METAL			100K OHM 1/4W
	R425T4104F	R,METAL			100K OHM 1/4W
△ R442	R4X5T4153F	R,METAL			15K OHM 1/4W
	R425T4153F	R,METAL			15K OHM 1/4W
△ R443	R4X5T4222F	R,METAL			2.2K OHM 1/4W
	R425T4222F	R,METAL			2.2K OHM 1/4W
△ R444	R4X5T4153F	R,METAL			15K OHM 1/4W
△ R447	R65582680J	R,FUSE			68 OHM 1/2W
△ R448	R3K181102J	R,METAL			1K OHM 1W
△ R449	R5Y2CE682J	R,CEMENT			6.8K OHM 7W
△ R450	R655812R2J	R,FUSE			2.2 OHM 1W
△ R500	R21202275K	R,SOLID			2.7M OHM 1/2W
△ R501	R5Y2CE2R2J	R,CEMENT			2.2 OHM 7W
△ R505	R3X28B473J	R,METAL OXIDE			47K OHM 3W
△ R510	R3X28B1R2J	R,METAL			1.2 OHM 3W
△ R512	R3X181273J	R,METAL OXIDE			27K OHM 1W
△ R517	R3X20B2R2J	R,METAL OXIDE			2.2 OHM 3W
△ R526	R3X28B1R2J	R,METAL			1.2 OHM 3W
△ R542	R33681R15J	R,METAL			0.15OHM 1W
△ R802	R3X18A153J	R,METAL OXIDE			15K OHM 2W
△ R805	R3X18A153J	R,METAL OXIDE			15K OHM 2W
△ R810	R3X18A153J	R,METAL OXIDE			15K OHM 2W
△ R1005	R615J12R7J	R,FUSE			2.7 OHM 1W
<b>CAPACITORS</b>					
	C354	E02L03222M	CE		2200 UF 25V
△	C407	E02L03222M	CE		2200 UF 25V
	C421	E53Z04102M	CE		1000 UF 35V VZ
	C423	P411F3474J	CMPP		0.47 UF 250V ECWF or
		P447F2474J	CMPP		0.47 UF 200V FHS or
		P411F2474J	CMPP		0.47 UF 200V
△	C424	P414F9682H	CMPP		0.0068UF 1.6KV ECWH
△	C425	C01BBP7K2K	CC		270 PF 2KV BP
△	C431	E02LTD100M	CE		10 UF 250V
△	C433	E53ZT8220M	CE		22 UF 100V VZ
	C434	P3N1F2223J	CPP		0.022 UF 200V
	C450	C01BBP713K	CC		0.001 UF 2KV BP
△	C502	C13HB07H3K	CC		0.0022UF 2KV B
△	C503	C13HB07H3K	CC		0.0022UF 2KV B
△	C506	P2122B224M	CMP		0.22 UF 250V ECQUL
△	C507	E51CGC471M	CE		470 UF 200V
△	C508	C034E0JH3M	CC		0.0022UF 125V MX
△	C510	E53ZT4101M	CE		100 UF 35V VZ
△	C511	E53ZT2471M	CE		470 UF 16V VZ
	C514	C01BBP7K3K	CC		0.0027UF 2KV BP
	C517	C01BBP7W2K	CC		820 PF 2KV BP
△	C521	E53VFB221M	CE		220 UF 160V
△	C524	E53ZT3471M	CE		470 UF 25V VZ
△	C526	E53ZT1471M	CE		470 UF 10V VZ
△	C530	C034E0JH3M	CC		0.0022UF 125V MX
△	C531	E02LT2102M	CE		1000 UF 16V
△	C532	E53ZT2471M	CE		470 UF 16V VZ
△	C537	E02LT5R47M	CE		0.47 UF 50V
		E01VT5R47M	CE		0.47 UF 50V
△	C540	E53ZTB100M	CE		10 UF 160V
△	C541	E62DFB470M	CE		47 UF 160V
	C560	C01BBP7H3K	CC		0.0022UF 2KV BP
	C801	C01BBP7H3K	CC		0.0022UF 2KV BP
	C819	C01BBP7H3K	CC		0.0022UF 2KV BP
△	C1001	E02LT3101M	CE		100 UF 25V
	C1045	CHG0B0412K	CC		100 PF 50V B
<b>DIODES</b>					
	D401	D28T11E1N1	DIODE,SILICON		11E1N-TA1B2
△	D408	D94TA27011	DIODE,ZENER		HZ27-1L TD
△	D409	D94TA11B13	DIODE,ZENER		HZ11B3L TD
△	D411	D28T10ELS6	DIODE,RECTIFIER		10ELS6TA1B2
△	D412	D28T10ELS6	DIODE,RECTIFIER		10ELS6TA1B2
△	D413	D28T10ELS6	DIODE,RECTIFIER		10ELS6TA1B2
△	D501	D2LTGP15M0	DIODE,RECTIFIER		GP15M-G23
△	D502	D2LTGP15M0	DIODE,RECTIFIER		GP15M-G23
△	D503	D2LTGP15M0	DIODE,RECTIFIER		GP15M-G23
△	D504	D2LTGP15M0	DIODE,RECTIFIER		GP15M-G23
△	D505	D28T21DQN9	DIODE,SCHOTTKY		21DQ09N-TA2B1
	D506	D28T10ELS6	DIODE,RECTIFIER		10ELS6TA1B2
	△ D509	D28T21DQN9	DIODE,SCHOTTKY		21DQ09N-TA2B1
	△ D510	D2BTRU2AM0	DIODE,SILICON		RU2AM V1
	△ D511	D28TELS2N2	DIODE,RECTIFIER		10ELS2N-TA1B2
	△ D512	D28T21DQN9	DIODE,SCHOTTKY		21DQ09N-TA2B1
	△ D515	D97U03001B	DIODE,ZENER		MTZJ30B T-77
	D516	D1VT001330	DIODE,SILICON		1SS133T-77
	D517	D1VT001330	DIODE,SILICON		1SS133T-77
	D518	D1VT001330	DIODE,SILICON		1SS133T-77
	△ D519	D28T21DQN9	DIODE,SCHOTTKY		21DQ09N-TA2B1
	D521	D1VT001330	DIODE,SILICON		1SS133T-77
	D523	D1VT001330	DIODE,SILICON		1SS133T-77
	D526	D1VT001330	DIODE,SILICON		1SS133T-77
	D528	D97U05R61B	DIODE,ZENER		MTZJ5.6B T-77
	D529	D1VT001330	DIODE,SILICON		1SS133T-77
	D601	D97U09R11B	DIODE,ZENER		MTZJ9.1B T-77
	D603	D1VT001330	DIODE,SILICON		1SS133T-77
	D604	D1VT001330	DIODE,SILICON		1SS133T-77
	D605	D28T11ESN1	DIODE,SILICON		11ES1N-TA1B2
	D791	002132Q040	LED		SLZ-936C-11-S-T1
	D792	002132Q040	LED		SLZ-936C-11-S-T1
	D793	002132Q040	LED		SLZ-936C-11-S-T1
	D1001	D28T11E1N1	DIODE,SILICON		11E1N-TA1B2
	D1003	0010600060	LED		SID1050CM
	D1004	D92T1120B0	DIODE,ZENER		RD12FB-T7
	D1005	D28T11E1N1	DIODE,SILICON		11E1N-TA1B2
	D1006	D23U1003A3	DIODE,SCHOTTKY		SB10-03A3
	D1008	D28TQ504N0	DIODE,SCHOTTKY		11EQS04N-TA1B2
	D1011	D23U1003A3	DIODE,SCHOTTKY		SB10-03A3
	D1014	D97U05R11B	DIODE,ZENER		MTZJ5.1B T-77
	D4001	D1VT001330	DIODE,SILICON		1SS133T-77
	D4004	D97U05R61B	DIODE,ZENER		MTZJ5.6B T-77
	D4201	D97U05R61B	DIODE,ZENER		MTZJ5.6B T-77
	D4202	D23U1003A3	DIODE,SCHOTTKY		SB10-03A3
	D4207	D97U06R81B	DIODE,ZENER		MTZJ6.8B T-77
<b>ICS</b>					
△	IC352	I0FSP75230	IC		AN7523
△	IC401	I03SD78400	IC		LA7840
△	IC501	I2BT066240	IC		STR-F6624
△	IC502	I0Q0978050	IC		NJM7805FD
△	IC503	I0GA909RD0	IC		PQ09RD08
△	IC504	I0QK978120	IC		NJM7812FA
		I1KA978120	IC		KIA7812PI
△	IC506	000210001R	PHOTO COUPLER		ON3171R
	IC601	I0Q0978050	IC		NJM7805FD
△	IC604	I03FE76814	IC		LA76814M-MPB
△	IC1001	I56F57034A	IC		OEC7034A
	IC1002	I9UJ0T600H	IC		PST600H
△	IC1003	I07SQ955AN	IC		BA6955AN
	IC1099	A54601A015	IC		M24C02-BN6
	IC4001	I03F371170	IC		LA71170M-MPB
<b>TRANSISTORS</b>					
	Q351	T8YJ2412K0	TRANSISTOR,SILICON		2SC2412KT146 R,S
	Q405	TC3Q026210	TRANSISTOR,SILICON		2SC2621(D,E)-RAC
△	Q406	TDFUF024990	TRANSISTOR,SILICON		2SD2499
△	Q501	TC3T029090	TRANSISTOR,SILICON		2SC2909(S,T)-AA
△	Q502	TA3T1371A0	TRANSISTOR,SILICON		2SA1371(D,E)-AE
△	Q503	TCWQ4160E0	TRANSISTOR,SILICON		2SC4160-OEC-YAC11
△	Q504	TCST02001L	TRANSISTOR,SILICON		2SC2001(C)-T_L
	Q506	TNYTJ03001	COMPOUND TRANSISTOR		DTC114TSTP
	Q507	TCST009450	TRANSISTOR,SILICON		2SC945(C)-T(P,Q)
		TCLT009450	TRANSISTOR,SILICON		2SC945A(C)-T(P,Q)
	Q513	TNYTB03001	COMPOUND TRANSISTOR		DTC114ESTP
	Q602	T6YJ1037K0	TRANSISTOR,SILICON		2SA1037AKT146R,S
	Q605	TAST00733Q	TRANSISTOR,SILICON		2SA733(C)-T_Q
	Q607	TNYJC05001	COMPOUND TRANSISTOR		DTC124EKAT146
	Q608	T6YJ1037K0	TRANSISTOR,SILICON		2SA1037AKT146R,S
	Q620	TB3T008920	TRANSISTOR,SILICON		2SB892(S,T)-AE
	Q621	TNYJB05001	COMPOUND TRANSISTOR		DTC114EKAT146
△	Q804	TC3F042170	TRANSISTOR,SILICON		2SC4217(D,E)-RAC
△	Q805	TC3F042170	TRANSISTOR,SILICON		2SC4217(D,E)-RAC
△	Q806	TC3F042170	TRANSISTOR,SILICON		2SC4217(D,E)-RAC
	Q1001	0002G00540	PHOTO COUPLER		GP1S566
	Q1002	T8YJ2412K0	TRANSISTOR,SILICON		2SC2412KT146 R,S
	Q1003	0002G00550	PHOTO COUPLER		GP1S94L
	Q1004	TNYJC05001	COMPOUND TRANSISTOR		DTC124EKAT146
	Q1005	0002G00540	PHOTO COUPLER		GP1S566

# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>TRANSISTORS</b>					
Q1006	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	SW798	0504201T31 SWITCH,TACT SKHVBED010
Q1009	0002G00550	PHOTO COUPLER	GP1S94L	SW799	0504201T31 SWITCH,TACT SKHVBED010
Q1014	TNYJC05001	COMPOUND TRANSISTOR	DTC124EKAT146	SW1001	0508221001 SWITCH (LEAF) SPVF130100
Q1015	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	<b>VARIABLE RESISTORS</b>	
Q1016	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	VR502	V1263L2BTC VOLUME,SEMI FIXED RH063MCN2R
Q1017	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	<b>P.C.BOARD ASSEMBLIES</b>	
Q1018	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	PCB010	A54609A01A PCB ASSY VM9149A
△ Q1019	TB3001134R	TRANSISTOR,SILICON	2SB1134R	PCB030	A54609A03A PCB ASSY TE9980A
Q1023	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	PCB070	A54609A07A PCB ASSY TM9416A
Q1024	TNYJA05001	COMPOUND TRANSISTOR	DTC143EKAT146	PCB110	A54609A11A PCB ASSY TC9274A
Q4001	TCWT022740	TRANSISTOR,SILICON	2SC22274(E,F)-AA	PCB550	A4C701B550 SEE CHASSIS REPLACEMENT PARTS LIST
Q4002	TCWT022740	TRANSISTOR,SILICON	2SC22274(E,F)-AA	<b>MISCELLANEOUS</b>	
Q4003	TAWT0984K0	TRANSISTOR,SILICON	2SA984K(E,F)-AA	B502	024AT03482 CORE,BEADS BL02RN2-R62T4
Q4004	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	B504	024AT03655 CORE,BEADS BL01RN1-A63T6
Q4005	TA3T013180	TRANSISTOR,SILICON	2SA1318(S,T)-AA	B505	024DT03581 CORE,BEADS LFP3A-M3R2TA
Q4006	TCKT013170	TRANSISTOR,SILICON	2SC1317(Q,R,S)-T	B602	024AT03655 CORE,BEADS BL01RN1-A63T6
Q4007	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	B4002	024AT03655 CORE,BEADS BL01RN1-A63T6
Q4009	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	B4003	024AT03655 CORE,BEADS BL01RN1-A63T6
Q4010	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CD351	06CH27080A CORD,CONNECTOR CH27080A
Q4011	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S	CD352	06CH12416A CORD,CONNECTOR CH12416A
Q4012	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S	CD353	06CH12415A CORD,CONNECTOR CH12415A
Q4013	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CD401	068101410A CORD,CONNECTOR 8101410A
Q4204	TNYJB05001	COMPOUND TRANSISTOR	DTC114EKAT146	△ CD501	120R614909 CORD,AC 0R614909
Q4205	TNYJB05001	COMPOUND TRANSISTOR	DTC114EKAT146	CD601	068101411A CORD,CONNECTOR 8101411A
Q4206	TNYJB05001	COMPOUND TRANSISTOR	DTC114EKAT146	CD757	06CH2A014A CORD,CONNECTOR CH2A014A
Q4210	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S	CD801	068M82025A CORD,CONNECTOR 8M82025A
Q4212	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S	CD803	122E054402 CORD,JUMPER 2E054402
<b>COILS &amp; TRANSFORMERS</b>					
L005	02A6A8A0A1	CORE,FERRITE	HF57T18.5*10*10	CD810	06CH2A014A CORD,CONNECTOR CH2A014A
L101	02A6A8A0A1	CORE,FERRITE	HF57T18.5*10*10	CD820	06CH2B027A CORD,CONNECTOR CH2B027A
L401	021679472K	COIL	4.7 MH	CD850	06CH25086A CORD,CONNECTOR CH25086A
L402	0221000013	COIL,LINEARITY	ELH5L4112	CF601	102E245R71 FILTER,SAW M1958M
L403	021U6D680K	COIL	68 UH	CP351	069E270129 CONNECTOR PCB SIDE 8283_0712_00_000
△ L501	029K000074	COIL,LINE FILTER	9-000074	CP352	069X120249 CONNECTOR PCB SIDE B2B-EH-A
△ L502	029X000065	COIL,LINE FILTER	SU16V-20030	CP353	069X120249 CONNECTOR PCB SIDE B2B-EH-A
△ L503	028R200026	COIL,DEGAUSS	8R200026	CP401	069W450039 CONNECTOR PCB SIDE TV-50P-05-V2
L511	02A1281872	CORE,TRIDAL	KR16TT281807D	CP501	0697320039 CORD UX CONNECTOR THL-P03P-B1
L602	021LA6150K	COIL	15 UH	CP502	069W420029 CONNECTOR PCB SIDE TV-50P-02-A1
L604	021LA6R56M	COIL	0.56 UH	CP603	069E260129 CONNECTOR PCB SIDE 8283_0612_00_000
L605	021673101K	COIL	100 UH	CP757	069E2A0129 CONNECTOR PCB SIDE 8283_1012_00_000
L607	021673101K	COIL	100 UH	CP801	069W320018 CONNECTOR PCB SIDE TS-80P-02-V1
L608	0216A6150K	COIL	15 UH	CP807	069W010010 CONNECTOR PCB SIDE 005P-2100
L610	0336020388	COIL VIDEO IFT	3602038	CP810	069E2A0129 CONNECTOR PCB SIDE 8283_1012_00_000
L611	021673101J	COIL	100 UH	CP820	069E2B0129 CONNECTOR PCB SIDE 8283_1112_00_000
L613	0216A6470K	COIL	47 UH	CP850	069E250129 CONNECTOR PCB SIDE 8283_0512_00_000
L1001	021LA62R2K	COIL	2.2 UH	CD1001	122L04090A CORD,JUMPER 2L04090A
L4001	0326230038	COIL,TRAP	2623003	CD1002	122F051702 CORD,JUMPER 2F051702
L4002	02167D101K	COIL	100 UH	CD4001	122L061501 CORD,JUMPER 2L061501
L4003	031626007S	COIL,BIAS OSC	1626007	CP1002	06CH22076A CORD,CONNECTOR CH22076A
L4004	02167D101K	COIL	100 UH	CP1004	0697280590 CONNECTOR PCB SIDE TMC-J08P-B1
L4005	021673101J	COIL	100 UH	CP1005	069R750028 CONNECTOR PCB SIDE 52045-0545
L4006	021673101J	COIL	100 UH	CP1006	069R740028 CONNECTOR PCB SIDE 52045-0445
L4007	0216A6560K	COIL	56 UH	CP4001	0697240600 CONNECTOR PCB SIDE TOC-C04X-B1
L4008	0216A6121K	COIL	120 UH	CP4004	0697120320 CONNECTOR PCB SIDE TMC-T02X-E1
L4009	021673101J	COIL	100 UH	CP4005	069R760028 CONNECTOR PCB SIDE 52045-0645
L4010	021673221K	COIL	220 UH	CP803A	067R105019 WIRE HOLDER 51052-0500
L4012	021673101K	COIL	100 UH	CP803B	067R105019 WIRE HOLDER 51052-0500
L4014	021LA6680K	COIL	68 UH	CUS011	800WF00004 CUSHION-A
L4015	021673101J	COIL	100 UH	CUS012	800WF00019 CUSHION-C
L4205	021673101K	COIL	100 UH	CUS013	800JF00197 CUSHION-B
T401	03305Y002S	TRANS,HORIZONTAL DRIVE	305Y002	△ F501	081PA05003 FUSE 233005-MB000
△ T501	048140045W	TRANSFORMER,SWITCHING	8140045W	△ F502	080PA2R501 FUSE 23302.5-MB000
<b>JACKS</b>					
△ J351	0602131012	JACK,RCA,3.5	HSJ2630-010070	△ FB401	043220045F TRANSFORMER FLYBACK 3220045F
J701	0602101020	JACK,RCA	JPJ3811-01-430	FH501	06710T0006 HOLDER,FUSE EYF-52BC
△ J801	066C130015	SOCKET,CATHODE RAY TUBE	CVT3275-5102	FH502	06710T0006 HOLDER,FUSE EYF-52BC
J4201	063P000064	JACK,PLATE	T6582-ABCC	FH504	06710T0006 HOLDER,FUSE EYF-52BC
<b>SWITCHES</b>					
SW751	0504201T31	SWITCH,TACT	SKHVBED010	△ ICP502	083PC04002 MICRO FUSE 251004
SW791	0504201T31	SWITCH,TACT	SKHVBED010	△ ICP503	083PC05002 MICRO FUSE 251005
SW792	0504201T31	SWITCH,TACT	SKHVBED010	△ ICP505	083PC02002 MICRO FUSE 251002
SW793	0504201T31	SWITCH,TACT	SKHVBED010	OS753	077Q000017 REMOTE RECEIVER PIC-28143TH5
SW794	0504201T31	SWITCH,TACT	SKHVBED010	△ RY501	0560Q10114 RELAY SDT-SS-109DM
SW795	0504201T31	SWITCH,TACT	SKHVBED010	△ SP351	070J133008 SPEAKER AA0316S1
SW796	0504201T31	SWITCH,TACT	SKHVBED010	△ SP352	070J133008 SPEAKER AA0316S1
SW797	0504201T31	SWITCH,TACT	SKHVBED010	△ TH501	DF20G3R0Q0 DEGAUSS ELEMENT PTH451C460BG3R0Q140T
				TM010	07660CG010 TRANSMITTER SBJU20003A
				△ TU601	0145K00050 TUNER UHF-VHF TECC1040PG31A

# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	
<b>MISCELLANEOUS</b>			
△ V801	098Q200482	CRT	A48AGY13X78
X604	100W3R5702	CRYSTAL	3.579545MHz
X1001	100CA01203	CRYSTAL	12MHz
X1002	100C32R803	CRYSTAL	32.768KHz
X4001	1006A3R504	CRYSTAL	3.579545MHz

**RESISTOR**

RC..... CARBON RESISTOR


**CAPACITORS**

CC..... CERAMIC CAPACITOR  
 CE..... ALUMI ELECTROLYTIC CAPACITOR  
 CP..... POLYESTER CAPACITOR  
 CPP..... POLYPROPYLENE CAPACITOR  
 CPL..... PLASTIC CAPACITOR  
 CMP..... METAL POLYESTER CAPACITOR  
 CMPL..... METAL PLASTIC CAPACITOR  
 CMPP..... METAL POLYPROPYLENE CAPACITOR







PRINTED CIRCUIT BOARDS  
SYSCON  
SOLDER SIDE



# PRINTED CIRCUIT BOARDS OPERATION



## DECK



## SERVICING NOTICES ON CHECKING

### 1. KEEP THE NOTICES


As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

### 2. AVOID AN ELECTRIC SHOCK

There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.

### 3. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  mark, the designated parts must be used.

### 4. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

### 5. TAKE CARE TO DEAL WITH THE CATHODE-RAY TUBE

In the condition that an explosion-proof cathode-ray tube is set in this equipment, safety is secured against implosion. However, when removing it or serving from backward, it is dangerous to give a shock. Take enough care to deal with it.

### 6. AVOID AN X-RAY

Safety is secured against an X-ray by considering about the cathode-ray tube and the high voltage peripheral circuit, etc.

Therefore, when repairing the high voltage peripheral circuit, use the designated parts and make sure not modify the circuit.

Repairing except indicates causes rising of high voltage, and it emits an X-ray from the cathode-ray tube.

### 7. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

#### (INSULATION CHECK PROCEDURE)

1. Unplug the plug from the AC outlet.
2. Remove the antenna terminal on TV and turn on the TV.
3. Insulation resistance between the cord plug terminals and the external exposure metal **[Note 2]** should be more than 1M ohm by using the 500V insulation resistance meter **[Note 1]**.
4. If the insulation resistance is less than 1M ohm, the inspection repair should be required.

#### **[Note 1]**

If you have not the 500V insulation resistance meter, use a Tester.

#### **[Note 2]**

External exposure metal: Antenna terminal

## HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

### 1. MODEL NUMBER and VERSION LETTER

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

### 2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.



# CONTENTS


<b>SPECIFICATIONS</b> .....	COVER
<b>SERVICING NOTICES ON CHECKING</b> .....	A-1
<b>HOW TO ORDER PARTS</b> .....	A-1
<b>CONTENTS</b> .....	A-2
<b>DISASSEMBLY INSTRUCTIONS</b>	
1.REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS .....	B1-1, B1-2
2.REMOVAL OF DECK PARTS .....	B2-1~B2-5
<b>KEY TO ABBREVIATIONS</b> .....	C1-1, C1-2
<b>SERVICE MODE LIST</b> .....	C2-1
<b>PREVENTIVE CHECKS AND SERVICE INTERVALS</b> .....	C3-1, C3-2
<b>NOTE FOR THE REPLACING OF MEMORY IC</b> .....	C4-1
<b>SERVICING FIXTURES AND TOOLS</b> .....	C5-1
<b>PREPARATION FOR SERVICING</b> .....	C5-2
<b>MECHANICAL ADJUSTMENTS</b> .....	D1-1~D1-4
<b>ELECTRICAL ADJUSTMENTS</b> .....	D2-1~D2-6
<b>BLOCK DIAGRAMS</b>	
TV BLOCK DIAGRAM .....	E-1, E-2
Y/C/AUDIO/HEAD AMP/IN/OUT .....	E-3, E-4
MICON/POWER/OPERATION .....	E-5, E-6
<b>PRINTED CIRCUIT BOARDS</b>	
MAIN/CRT .....	F-1, F-2
SYSCON .....	F-3~F-6
OPERATION/DECK .....	F-7, F-8
<b>SCHEMATIC DIAGRAMS</b>	
Y/C/AUDIO/HEAD AMP .....	G-1, G-2
MICON .....	G-3, G-4
POWER .....	G-5, G-6
IN/OUT .....	G-7, G-8
CHROMA/IF .....	G-9, G-10
SOUND AMP .....	G-11, G-12
TV POWER .....	G-13, G-14
DEFLECTION .....	G-15, G-16
CRT .....	G-17, G-18
OPERATION .....	G-19, G-20
DECK .....	G-21, G-22
<b>INTERCONNECTION DIAGRAM</b> .....	G-23, G-24
<b>WAVEFORMS</b> .....	H-1~H-3
<b>MECHANICAL EXPLODED VIEWS</b> .....	I-1, I-2
<b>CHASSIS EXPLODED VIEWS</b> .....	I-3, I-4
<b>MECHANICAL REPLACEMENT PARTS LIST</b> .....	J1-1
<b>CHASSIS REPLACEMENT PARTS LIST</b> .....	J2-1
<b>ELECTRICAL REPLACEMENT PARTS LIST</b> .....	J3-1~J3-3

# DISASSEMBLY INSTRUCTIONS

## 1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

### 1-1: BACK CABINET (Refer to Fig. 1-1)


1. Remove the 6 screws ①.
2. Remove the 2 screws ② which are used for holding the Back Cabinet.
3. Remove the Back Cabinet in the direction of arrow.



### 1-2: CRT PCB (Refer to Fig. 1-2)


**CAUTION: BEFORE REMOVING THE ANODE CAP, DISCHARGE ELECTRICITY BECAUSE IT CONTAINS HIGH VOLTAGE. BEFORE ATTEMPTING TO REMOVE OR REPAIR ANY PCB, UNPLUG THE POWER CORD FROM THE AC SOURCE.**

1. Remove the Anode Cap. (Refer to REMOVAL OF ANODE CAP)
2. Disconnect the following connectors: (CP801 and CP850).
3. Remove the CRT PCB in the direction of arrow.




### 1-3: TV/VCR BLOCK (Refer to Fig. 1-3)

1. Remove the 2 screws ①.
2. Disconnect the following connectors: (CP757, CP353, CP352, CP401, CP502 and CP351).
3. Unlock the support ②.
4. Remove the TV/VCR Block in the direction of arrow.



### 1-4: MAIN PCB (Refer to Fig. 1-4)


1. Remove the 2 screws ②.
2. Remove the 3 screws ③.
3. Disconnect the following connectors: (CP810, CP820 and CD401).
4. Remove the Main PCB in the direction of arrow.



## DISASSEMBLY INSTRUCTIONS


### 1-5: DECK SHIELD PLATE (Refer to Fig. 1-5)

1. Remove the 2 screws ①.
2. Remove the screw ②.
3. Remove the Deck Shield Plate in the direction of arrow.




### 1-6: DECK CHASSIS (Refer to Fig. 1-6)

1. Remove the 3 screws ①.
2. Disconnect the following connectors:  
(CP1005 , CP1006 , CP4001, CP4004 and CP4005).
3. Remove the Deck Chassis in the direction of arrow.



### 1-7: JACK PLATE AND SYSCON PCB (Refer to Fig. 1-7)

1. Remove the screw ①.
2. Remove the Syscon PCB in the direction of arrow (A).
3. Remove the screw ②.
4. Remove the nut ③.
5. Remove the washer ④.
6. Unlock the 2 supports ⑤.
7. Remove the Jack Plate in the direction of arrow (B).



# DISASSEMBLY INSTRUCTIONS

## 2. REMOVAL OF DECK PARTS

### 2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Remove the 2 screws ①.
2. Slide the 2 supports ② and remove the Top Bracket.

#### NOTE

When you install the Top Bracket, install the screw (1) first, then install the screw (2).




Fig. 2-1

### 2-2: FLAP LEVER/TAPE GUIDE R (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the back side.
2. Remove the Polyslider Washer ①.
3. Unlock the support ② and remove the Flap Lever.
4. Unlock the 3 supports ③ and remove the Tape Guide R.




Fig. 2-2

### 2-3: TAPE GUIDE L (Refer to Fig. 2-3-A)

1. Move the Cassette Holder Ass'y to the back side.
2. Unlock the 2 supports ① and remove the Tape Guide L.
3. Remove the REC Lever. (Recorder only)




Fig. 2-3-A

#### NOTE

When you install the Tape Guide L, install as shown in the circle of Fig. 2-3-B. (Refer to Fig. 2-3-B)




Fig. 2-3-B

### 2-4: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-4)

1. Move the Cassette Holder Ass'y to the front side.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




Fig. 2-4

### 2-5: CASSETTE SIDE L/R (Refer to Fig. 2-5)

1. Remove the Locker Spring.
2. Unlock the 4 supports ① and then remove the Cassette Side L/R.

#### NOTE

When you install the Cassette Side L/R, be sure to move the Locker L/R after installing.





Fig. 2-5

# DISASSEMBLY INSTRUCTIONS


## 2-6: LINK ASS'Y (Refer to Fig. 2-6)

1. Set the Link Ass'y to the Eject position.
2. Remove the (A) side of the Link Ass'y first, then remove the (B) side.




## 2-7: LOADING MOTOR ASS'Y (Refer to Fig. 2-7)

1. Remove the Link Lever.
2. Remove the Dumper Spring.
3. Remove the 2 screws ①.
4. Unlock the support ② and remove the Loading Motor Ass'y.
5. Unlock the 2 supports ③ and remove the Deck PCB (BOT).




## 2-8: SENSOR COVER L (Refer to Fig. 2-8)

1. Unlock the support ① and remove the Sensor Cover L.
2. Unlock the 2 supports ② and remove the Deck PCB (EOT).




## 2-9: TENSION ASS'Y (Refer to Fig. 2-9-A)

1. Move the Inclined S Ass'y to the back side.
2. Unlock the support ① and remove the S Reel Stopper.
3. Remove the Tension Spring.
4. Unlock the support ② and remove the Tension Arm Ass'y.
5. Remove the Tension Adjust.
6. Unlock the 2 supports ③ and remove the Tension Band Ass'y.
7. Unlock the support ④ and remove the Tension Holder.




### NOTE

When you install the Tension Adjust, install as shown in Fig. 2-9-B. (Refer to Fig. 2-9-B)



## 2-10: T BRAKE ASS'Y (Refer to Fig. 2-10)

1. Remove the T Brake Spring.
2. Remove the T Brake Ass'y.



# DISASSEMBLY INSTRUCTIONS

## 2-11: S REEL/T REEL ASS'Y (Refer to Fig. 2-11)

1. Remove the Idler Ass'y.
2. Remove the S Reel and T Reel Ass'y.
3. Remove the 2 Polyslider Washers ①.

### NOTE

1. Take care not to damage the gears of the S Reel, T Reel Ass'y and Idler Ass'y.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel Ass'y. (Use gloves.) **(Refer to Fig. 2-11)** Do not adhere the stains on it.
5. When you install the reel, clean the shaft and oil it (KYODO OIL Slidas #150). (If you do not oil, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. **(Refer to MECHANICAL ADJUSTMENT)**




Fig. 2-11

## 2-12: PINCH ROLLER ASS'Y/P5 ARM ASS'Y (Refer to Fig. 2-12-A)

1. Remove the P5 Spring.
2. Remove the screw ①.
3. Unlock the 2 supports ② and remove the Cassette Opener.
4. Remove the Pinch Roller Ass'y, Pinch Roller Lever and P5 Arm Ass'y.




Fig. 2-12-A

### NOTE

1. Do not touch the Pinch Roller Ass'y. (Use gloves.)
2. When you install the Pinch Roller Ass'y, install as shown in the circle. **(Refer to Fig. 2-12-B)**




Fig. 2-12-B

## 2-13: A/C HEAD (Refer to Fig. 2-13-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.

### NOTE

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-13-B. **(Refer to Fig. 2-13-B)**
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).




Fig. 2-13-A




Fig. 2-13-B

## 2-14: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-14)

1. Remove the screw ①.
2. Remove the FE Head.




Fig. 2-14


# DISASSEMBLY INSTRUCTIONS

## 2-15: CYLINDER UNIT ASS'Y (Refer to Fig. 2-15)

1. Remove the 3 screws ①.
2. Remove the Cylinder Unit Ass'y.


### NOTE

When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.




## 2-16: CAPSTAN DD UNIT (Refer to Fig. 2-16)

1. Remove the Capstan Belt.
2. Remove the 3 screws ①.
3. Remove the Capstan DD Unit.




## 2-17: MIDDLE GEAR/MAIN CAM (Refer to Fig. 2-17-A)

1. Remove the Polyslider Washer ①, then remove the Middle Gear.
2. Remove the E-Ring, then remove the Main Cam, Link Lever Spacer and P5 Cam.
3. Remove the Polyslider Washer ②, then remove the Pinch Roller Cam.
4. Remove the Polyslider Washer ③, then remove the Joint Gear.



### NOTE

When you install the Pinch Roller Cam, P5 Cam and Main Cam, align each marker. (Refer to Fig. 2-17-B)




## 2-18: CLUTCH ASS'Y (Refer to Fig. 2-18)

1. Remove the Polyslider Washer ①.
2. Remove the Clutch Ass'y, Ring Spring, Ring Clutch, Gear Clutch and Polyslider Washer ②.

### NOTE


When you install the Clutch Ass'y, oil the shaft (KYODO OIL Slidas #150).



# DISASSEMBLY INSTRUCTIONS


## 2-19: LOADING GEAR S/T ASS'Y (Refer to Fig. 2-19-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Remove the Capstan Brake Spring.
3. Slide the Main Rod and remove the Capstan Brake Arm Ass'y.
4. Remove the Main Rod.
5. Remove the Tension Lever.
6. Unlock the 2 supports ② and remove the Clutch Lever.
7. Remove the screw ③ and washer ④.
8. Remove the LED Reflector.
9. Remove the Loading Arm S Ass'y and Loading Arm T Ass'y.
10. Remove the Loading Gear S and Loading Gear T.
11. Remove the Loading Gear Spring.



### NOTE

When you install the Loading Arm S Ass'y, Loading Arm T Ass'y and Main Loading Gear, align each marker. (Refer to Fig. 2-19-B)




## 2-20: INCLINED S/T ASS'Y (Refer to Fig. 2-20)

1. Remove the S-S Brake Spring.
2. Unlock the support ① and remove the Loading Gear Holder.
3. Remove the S-S Brake Arm.
4. Remove the Inclined S.
5. Remove the Inclined T.
6. Remove the 2 screws ②, then remove the Guide Roller and O-Ring.

### NOTE

Do not touch the roller of Guide Roller.





## KEY TO ABBREVIATIONS

<b>A</b>	<b>A/C</b>	: Audio/Control	<b>H.SW</b>	: Head Switch	
	<b>ACC</b>	: Automatic Color Control	<b>Hz</b>	: Hertz	
	<b>AE</b>	: Audio Erase	<b>I</b>	<b>IC</b>	: Integrated Circuit
	<b>AFC</b>	: Automatic Frequency Control		<b>IF</b>	: Intermediate Frequency
	<b>AFT</b>	: Automatic Fine Tuning		<b>IND</b>	: Indicator
	<b>AFT DET</b>	: Automatic Fine Tuning Detect		<b>INV</b>	: Inverter
	<b>AGC</b>	: Automatic Gain Control	<b>K</b>	<b>KIL</b>	: Killer
	<b>AMP</b>	: Amplifier	<b>L</b>	<b>L</b>	: Left
	<b>ANT</b>	: Antenna		<b>LED</b>	: Light Emitting Diode
	<b>A.PB</b>	: Audio Playback		<b>LIMIT AMP</b>	: Limiter Amplifier
	<b>APC</b>	: Automatic Phase Control		<b>LM, LDM</b>	: Loading Motor
	<b>ASS'Y</b>	: Assembly		<b>LP</b>	: Long Play
	<b>AT</b>	: All Time		<b>L.P.F</b>	: Low Pass Filter
	<b>AUTO</b>	: Automatic		<b>LUMI.</b>	: Luminance
	<b>A/V</b>	: Audio/Video	<b>M</b>	<b>M</b>	: Motor
<b>B</b>	<b>BGP</b>	: Burst Gate Pulse		<b>MAX</b>	: Maximum
	<b>BOT</b>	: Beginning of Tape		<b>MINI</b>	: Minimum
	<b>BPF</b>	: Bandpass Filter		<b>MIX</b>	: Mixer, mixing
	<b>BRAKE SOL</b>	: Brake Solenoid		<b>MM</b>	: Monostable Multivibrator
	<b>BUFF</b>	: Buffer		<b>MOD</b>	: Modulator, Modulation
	<b>B/W</b>	: Black and White		<b>MPX</b>	: Multiplexer, Multiplex
<b>C</b>	<b>C</b>	: Capacitance, Collector		<b>MS SW</b>	: Mecha State Switch
	<b>CASE</b>	: Cassette	<b>N</b>	<b>NC</b>	: Non Connection
	<b>CAP</b>	: Capstan		<b>NR</b>	: Noise Reduction
	<b>CARR</b>	: Carrier	<b>O</b>	<b>OSC</b>	: Oscillator
	<b>CH</b>	: Channel		<b>OPE</b>	: Operation
	<b>CLK</b>	: Clock	<b>P</b>	<b>PB</b>	: Playback
	<b>CLOCK (SY-SE)</b>	: Clock (Syscon to Servo)		<b>PB CTL</b>	: Playback Control
	<b>COMB</b>	: Combination, Comb Filter		<b>PB-C</b>	: Playback-Chrominance
	<b>CONV</b>	: Converter		<b>PB-Y</b>	: Playback-Luminance
	<b>CPM</b>	: Capstan Motor		<b>PCB</b>	: Printed Circuit Board
	<b>CTL</b>	: Control		<b>P. CON</b>	: Power Control
	<b>CYL</b>	: Cylinder		<b>PD</b>	: Phase Detector
	<b>CYL-M</b>	: Cylinder-Motor		<b>PG</b>	: Pulse Generator
	<b>CYL SENS</b>	: Cylinder-Sensor		<b>P-P</b>	: Peak-to Peak
<b>D</b>	<b>DATA (SY-CE)</b>	: Data (Syscon to Servo)	<b>R</b>	<b>R</b>	: Right
	<b>dB</b>	: Decibel		<b>REC</b>	: Recording
	<b>DC</b>	: Direct Current		<b>REC-C</b>	: Recording-Chrominance
	<b>DD Unit</b>	: Direct Drive Motor Unit		<b>REC-Y</b>	: Recording-Luminance
	<b>DEMODO</b>	: Demodulator		<b>REEL BRK</b>	: Reel Brake
	<b>DET</b>	: Detector		<b>REEL S</b>	: Reel Sensor
	<b>DEV</b>	: Deviation		<b>REF</b>	: Reference
<b>E</b>	<b>E</b>	: Emitter		<b>REG</b>	: Regulated, Regulator
	<b>EF</b>	: Emitter Follower		<b>REW</b>	: Rewind
	<b>EMPH</b>	: Emphasis		<b>REV, RVS</b>	: Reverse
	<b>ENC</b>	: Encoder		<b>RF</b>	: Radio Frequency
	<b>ENV</b>	: Envelope		<b>RMC</b>	: Remote Control
	<b>EOT</b>	: End of Tape		<b>RY</b>	: Relay
	<b>EQ</b>	: Equalizer	<b>S</b>	<b>S. CLK</b>	: Serial Clock
	<b>EXT</b>	: External		<b>S. COM</b>	: Sensor Common
<b>F</b>	<b>F</b>	: Fuse		<b>S. DATA</b>	: Serial Data
	<b>FBC</b>	: Feed Back Clamp		<b>SEG</b>	: Segment
	<b>FE</b>	: Full Erase		<b>SEL</b>	: Select, Selector
	<b>FF</b>	: Fast Forward, Flipflop		<b>SENS</b>	: Sensor
	<b>FG</b>	: Frequency Generator		<b>SER</b>	: Search Mode
	<b>FL SW</b>	: Front Loading Switch		<b>SI</b>	: Serial Input
	<b>FM</b>	: Frequency Modulation		<b>SIF</b>	: Sound Intermediate Frequency
	<b>FSC</b>	: Frequency Sub Carrier		<b>SO</b>	: Serial Output
	<b>FWD</b>	: Forward		<b>SOL</b>	: Solenoid
<b>G</b>	<b>GEN</b>	: Generator		<b>SP</b>	: Standard Play
	<b>GND</b>	: Ground		<b>STB</b>	: Serial Strobe
<b>H</b>	<b>H.P.F</b>	: High Pass Filter		<b>SW</b>	: Switch

## KEY TO ABBREVIATIONS

<b>S</b>	<b>SYNC</b>	:	Synchronization
	<b>SYNC SEP</b>	:	Sync Separator, Separation
<b>T</b>	<b>TR</b>	:	Transistor
	<b>TRAC</b>	:	Tracking
	<b>TRICK PB</b>	:	Trick Playback
	<b>TP</b>	:	Test Point
<b>U</b>	<b>UNREG</b>	:	Unregulated
<b>V</b>	<b>V</b>	:	Volt
	<b>VCO</b>	:	Voltage Controlled Oscillator
	<b>VIF</b>	:	Video Intermediate Frequency
	<b>VP</b>	:	Vertical Pulse, Voltage Display
	<b>V.PB</b>	:	Video Playback
	<b>VR</b>	:	Variable Resistor
	<b>V.REC</b>	:	Video Recording
	<b>VSF</b>	:	Visual Search Fast Forward
	<b>VSR</b>	:	Visual Search Rewind
	<b>VSS</b>	:	Voltage Super Source
	<b>V-SYNC</b>	:	Vertical-Synchronization
	<b>VT</b>	:	Voltage Tuning
<b>X</b>	<b>X'TAL</b>	:	Crystal
<b>Y</b>	<b>Y/C</b>	:	Luminance/Chrominance

## SERVICE MODE LIST

This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.

The both pressing of set key and remote control key will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.

Set Key	Remocon Key	Operations
VOL. (-) MIN	0	Releasing of V-CHIP PASSWORD.
VOL. (-) MIN	2	Horizontal position adjustment of OSD. NOTE: Also can be adjusted by using the Adjustment MENU. Refer to the "ELECTRICAL ADJUSTMENT" (OSD HORIZONTAL).
VOL. (-) MIN	3	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	4	Adjust the PG SHIFTER manually. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	5	Adjusting of the Tracking to the center position. NOTE: Also can be adjusted by pressing the ATR button for more tan 2 seconds during PLAY.
VOL. (-) MIN	6	POWER ON total hours and PLAY/REC total hours are displayed on the screen. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF USING HOURS).  Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "NOTE FOR THE REPLACING OF MEMORY IC".
VOL. (-) MIN	9	Display of the Adjustment MENU on the screen. Refer to the "ELECTRICAL ADJUSTMENT" (On-Screen Display Adjustment).

Method	Operations
Press the ATR button on the remote control for more than 2 seconds during PLAY.	Adjusting of the Tracking to the center position. Refer to the "MECHANICAL ADJUSTMENT" (GUIDE ROLLER) and "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
Make the short circuit between the test point of SERVICE and the GND.	The EOT/BOT/Reel sensor do not work at this moment. Refer to the "PREPARATION FOR SERVICING"

## PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage. Unless maintenance is properly carried out, the following service intervals may be quite shortened as harmful effects may be had on other parts. Also, long term storage or misuse may cause transformation and aging of rubber parts.

Time Parts Name	500 hours	1,000 hours	1,500 hours	2,000 hours	3,000 hours	Notes
Audio Control Head	■	■	■	■	■	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	■	■	
Capstan Belt			■	■	●	Clean the rubber, and parts which the rubber touches.
Pinch Roller	■	■	■	■	■ ●	
Capstan DD Unit					●	
Loading Motor					●	
Tension Band					●	
Capstan Shaft	■	■	■	■	■	
Tape Running Guide Post	■	■	■	■	■	Replace when rolling becomes abnormal.
Cylinder Unit	■	■	■	■	●	Clean the Head


- : Clean
- : Replace

### CONFIRMATION OF USING HOURS

POWER ON total hours and PLAY/REC total hours can be checked on the screen. Total hours are displayed in 16 system of notation.

**NOTE: The confirmation of using hours will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.**

1. Set the VOLUME to minimum.
2. While holding down VOLUME button on front cabinet, press key 6 on remote control simultaneously.
3. After the confirmation of using hours, turn off the power.



(16 x 16 x 16 x thousands digit value) + (16 x 16 x hundreds digit value) + (16 x tens digit value) + (ones digit value)

# PREVENTIVE CHECKS AND SERVICE INTERVALS


## CLEANING

### NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

### 1. AUDIO CONTROL HEAD

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol and clean the audio control head by wiping it horizontally. Clean the full erase head in the same manner. **(Refer to the figure below.)**



### 2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

### 3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). **(Refer to the figure below.)**

### NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



## NOTE FOR THE REPLACING OF MEMORY IC


If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

**NOTE: Initial Data setting will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 30 minutes before Power On or alternatively, discharge backup capacitor.**

ADDRESS	DATA	ADDRESS	DATA	ADDRESS	DATA	ADDRESS	DATA
00	83	0A	23	14	94	1E	44
01	6D	0B	24	15	A0	1F	05
02	07	0C	00	16	61	20	79
03	00	0D	00	17	44	21	05
04	00	0E	00	18	A9	22	3E
05	00	0F	00	19	0F	23	2A
06	04	10	6C	1A	04	24	39
07	8B	11	2B	1B	C2	25	00
08	31	12	21	1C	5F	26	00
09	16	13	15	1D	F9	27	30

**Table 1**












1. Enter DATA SET mode by setting VOLUME to minimum.
2. While holding down VOLUME button on front cabinet, press key 6 on remote control simultaneously.
3. ADDRESS and DATA should appear as FIG 1.



**Fig. 1**

4. ADDRESS is now selected and should "blink". Using the SET + or - keys on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
5. Press ENTER to select DATA. When DATA is selected, it will "blink".
6. Again, step through the DATA using SET + or - until required DATA value has been selected.
7. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
8. Repeat steps 4 to 7 until all data has been checked.
9. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input. The unit will now have the correct DATA for the new MEMORY IC.

## SERVICING FIXTURES AND TOOLS


<p><b>(For 2 heads model)</b>  VHS Alignment Tape  JG001 (VN<sub>2</sub>S-LI6<sup>3</sup>)  JG001A (VN<sub>2</sub>S-CO1<sup>3</sup>)  JG001Q (VN<sub>2</sub>S-LI6<sup>3</sup>H)  JG001T (VN<sub>2</sub>S-X6<sup>3</sup>)</p> 	<p><b>(For 4 heads model)</b>  VHS Alignment Tape  JG001B (VN<sub>1</sub>S-LI6<sup>3</sup>)  JG001I (VN<sub>1</sub>S-CO1<sup>3</sup>)  JG001P (VN<sub>1</sub>S-LI6<sup>3</sup>H)  JG001S (VN<sub>1</sub>S-X6<sup>3</sup>)</p> 	<p>JG002B Adapter  JG002E Dial Torque Gauge  (10~90gf•cm)  JG002F (60~600gf•cm)</p> 	<p>JG005 Post Adjustment  Screwdriver  Part No. SV-TG0-030-000  <small>(small)</small></p> 
<p>JG153 X Value Adjustment  Screwdriver</p> 	<p>JG022 Master Plane</p> 	<p>JG024A Reel Disk Height  Adjustment Jig</p> 	<p>JG100A Torque Tape  (VHT-063)</p> 
<p>JG154 Cable</p> 	<p>JG162C Cable (10 Pins)  JG162D Cable (11 Pins)  JG162Y Cable (5 Pins)</p> 	<p>Tentelometer</p> 	

Part No.	Remarks
JG001	Monoscope, 6KHz <b>(For 2 heads model)</b>
JG001A	Color Bar, 1KHz <b>(For 2 heads model)</b>
JG001Q	Hi-Fi Audio <b>(For 2 heads model)</b>
JG001T	X Value Adjustment <b>(For 2 heads model)</b>
JG001B	Monoscope, 6KHz <b>(For 4 heads model)</b>
JG001I	Color Bar, 1KHz <b>(For 4 heads model)</b>
JG001P	Hi-Fi Audio <b>(For 4 heads model)</b>
JG001S	X Value Adjustment <b>(For 4 heads model)</b>
JG002B	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	Brake Torque (T Reel Ass'y)
JG002F	VSR Torque, Brake Torque (S Reel)
JG005	Guide Roller Adjustment
JG153	X Value Adjustment
JG022/JG024A	Reel Disk Height Adjustment
JG100A	Playback Torque, Back Tension Torque During Playback
JG154	Used to connect the test point of SERVICE and GROUND
JG162C/JG162D	Used to connect the Syscon PCB and Main PCB
JG162Y	Used to connect the Syscon PCB and CRT PCB

## PREPARATION FOR SERVICING

### How to use the Servicing Fixture

1. Unplug the connector CP351, CP352, CP757 and CP353, then remove the TV/VCR Block from the set.
  2. Unplug the connector CP810, CP820, CP850 and CD401, then remove the Main PCB from the VCR Block.
  3. Connect as shown in the below figure using the Service Fixture.
    - Connect the Syscon PCB to the Main PCB with the cable JG162C and JG162D.
    - Connect the Syscon PCB to the CRT PCB with the cable JG162Y.
  4. Remove the Operation PCB from the set, then connect it with the Syscon PCB.  
If necessary, connect CP351 (Front A/V Jack Input Terminal)
  5. Short circuit between TP1001 and Ground with the cable JG154.
- (Refer to MAJOR COMPONENTS LOCATION GUIDE)**  
The EOT, BOT and Reel Sensor do not work at this moment.
6. At that time, the STOP/EJECT button is available to insert and eject the Cassette Tape.





# MECHANICAL ADJUSTMENTS



## 1. CONFIRMATION AND ADJUSTMENT

Read the following NOTE before starting works.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)
- When you activate the deck without the Cassette Holder, short circuit between **TP1001** and **GND**. (Refer to **ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE**) In this condition the BOT/EOT/Reel Sensor will not function.



### 1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

1. Turn on the power and set to the STOP mode.
2. Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
3. Confirm that "A" of the reel disk is lower than "B" of the reel disk height adjustment jig (**JG024A**), and is higher than "C". If it is not enough height, adjust to  $10(+0.2, -0)$  mm with the height adjustment washer.
4. Adjust the other reel in the same way.



### 1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

1. Set to the PLAY mode.
2. Adjust the Tension Adjust until the length from the edge of the Tension Arm to the standard line of the Main Chassis is  $0.5 \pm 0.25$ mm. After this adjustment, confirm that the cut position is located in "A" area as shown in **Fig. 1-2-B**. If it is located in "B" area, adjust again.
3. While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.




### 1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

1. Load a video tape (T-120) recorded in standard speed mode. Set the unit to the PLAY mode.
2. Install the tentelometer as shown in **Fig. 1-3**. Confirm that the meter indicates  $20 \pm 2$ gf in the beginning of playback.

#### • USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)

1. After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
2. Confirm that the right meter of the torque tape indicates  $70 \sim 130$ gf•cm during playback in SP mode.
3. Confirm that the left meter of the torque tape indicates  $25 \sim 40$ gf•cm during playback in SP mode.



## MECHANICAL ADJUSTMENTS

### 1-4: CONFIRMATION OF VSR TORQUE

1. Operate within 4~5 seconds after the reel disk begins to turn.
2. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Set to the Rewind mode. (Refer to Fig.1-4)
3. Then, confirm that it indicates 120~180gf•cm.

#### NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.

### 1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (Refer to Fig. 1-4)

1. Set to the STOP mode.
2. Move the Idler Ass'y from the S Reel.
3. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Turn the Torque Gauge (JG002F) clockwise.
4. Then, confirm that it indicates 70~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4)

1. Set to the STOP mode.
2. Move the Idler Ass'y from the T Reel Ass'y.
3. Install the Torque Gauge (JG002E) and Adapter (JG002B) on the T reel. Turn the Torque Gauge (JG002E) counterclockwise.
4. Then, confirm that it indicates 35~60gf•cm.




Fig. 1-4

#### NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	T Brake Spring/Tension Spring

## 2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM

Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

### 2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (JG001 or JG001B). (Refer to SERVICING FIXTURE AND TOOLS)
2. Connect CH-1 of the oscilloscope to TP4001 (Envelope) and CH-2 to TP1002 (SW Pulse).
3. Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (JG005) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begins to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the ELECTRICAL ADJUSTMENTS)

#### NOTE

After adjustment, confirm and adjust A/C head. (Refer to item 2-2)




Fig. 2-1-A




Fig. 2-1-B

## MECHANICAL ADJUSTMENTS

### 2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/CONTROL HEAD

When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001** or **JG001B**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
  - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
  - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/ Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
  - c) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.




Fig. 2-2-A




Fig. 2-2-B




Fig. 2-2-C

### 2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)


1. Confirm and adjust the height of the Reel Disk.  
(Refer to **item 1-1**)
2. Confirm and adjust the position of the Tension Post.  
(Refer to **item 1-2**)
3. Adjust the Guide Roller. (Refer to **item 2-1**)
4. Confirm and adjust the Audio/Control Head.  
(Refer to **item 2-2**)
5. Connect CH-1 of the oscilloscope to **TP4001**, CH-2 to **TP1002** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001S** or **JG001T**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-1-A**.

### 2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP4001**, CH-2 to **TP1002** and CH-3 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001P** or **JG001Q**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the TRACKING-AUTO button on the remote control more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
6. Confirm that the difference between these counted steps number in the above items are within 2 steps. If the difference are more than 3 steps, do Tape Running Adjustment again. (Refer to **item 2-3**)

# MECHANICAL ADJUSTMENTS

## 3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- |                                   |                      |
|-----------------------------------|----------------------|
| 1. Tension Adjust                 | 7. P4 Post           |
| 2. Tension Arm                    | 8. T Brake Spring    |
| 3. Guide Roller                   | 9. T Reel Ass'y      |
| 4. P1 Post                        | 10. Idler Ass'y      |
| 5. Audio/Control Head             | 11. S-S Brake Spring |
| 6. X value adjustment driver hole | 12. S Reel           |

# ELECTRICAL ADJUSTMENTS

## 1. ADJUSTMENT PROCEDURE

Read and perform these adjustments when repairing the circuits or replacing electrical parts or PCB assemblies.

### CAUTION

When replacing IC's or transistors, use only specified silicon grease (**YG6260M**).  
(To prevent the damage to IC's and transistors.)

### On-Screen Display Adjustment

1. Unplug the AC plug for more than 30 minutes to set the clock to the non-setting state. (To release the Back-Up immediately, take the short circuit between **C1003** and **GND** at the Power Off.) Then, set the volume level to minimum.
2. Press the VOL. DOWN button on the set and the channel button (**9**) on the remote control simultaneously to display adjustment mode on the screen as shown in **Fig. 1-1**.

### NOTE

Use the channel buttons (**1-8**) on the remote control to select the options shown in **Fig. 1-1**.  
Press the channel button (**0**) on the remote control to end the adjustments.

- |                 |        |
|-----------------|--------|
| 1. H/V          |        |
| 2. AKB          |        |
| 3. COLOR TEMP   |        |
| 4. PICTURE      |        |
| 5. OTHERS       |        |
| 6. TEST PATTERN |        |
| 7. STEREO/SAP   |        |
| 8. (VOL TEST)   | 0. END |

Fig. 1-1

## 2. BASIC ADJUSTMENTS (VCR SECTION)

### 2-1: PG SHIFTER

1. Connect CH-1 on the oscilloscope to **TP1002** and CH-2 to **TP4201**.
2. Playback the alignment tape. (**JG001A**)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press the VOL. DOWN button on the set and the channel button (**3**) on the remote control simultaneously until the indicator REC disappears. If the indicator REC disappears, adjustment is completed.

### (If the above adjustments doesn't work well:)

5. Press the VOL. DOWN button on the set and the channel button (**3**) on the remote control simultaneously until the indicator REC disappears.
6. When the REC indicator is blinking, press both VOL. DOWN button on the set and the channel button (**4**) on the remote control simultaneously and adjust the Tracking +/- button until the arising to the down of Head Switching Pulse becomes  $6.5 \pm 0.5H$ .  
(Refer to **Fig. 2-1-A, B**)
7. Press the Tracking Auto button.




Fig. 2-1-A




Fig. 2-1-B

### 2-2: RF AGC DELAY

1. Receive the monoscope pattern.
2. Connect the digital voltmeter between the **pin 5 of CP603** and the **pin 1 (GND) of CP603**.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (**5**) on the remote control. The **Fig. 2-2** appears on the display.
4. Press the channel button (**1**) on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the digital voltmeter is  $2.3 \pm 0.05V$  (70dB).

- |                 |           |
|-----------------|-----------|
| 1. RF AGC DELAY |           |
| 2. VIDEO LEVEL  |           |
| 3. FM LEVEL     |           |
| 4. OSD H        |           |
| 5. CUT OFF      |           |
| 6.              |           |
| 7.              |           |
| 8.              | 0. RETURN |

Fig. 2-2

### 2-3: VCO FREERUN

1. Receive the monoscope pattern. (AFT off)
2. Connect the digital voltmeter to **TP601**.
3. Adjust the **L610** until the digital voltmeter is  $3.1 \pm 0.05V$ .

## (TV SECTION)

### 2-4: CONSTANT VOLTAGE

1. Using the remote control, set the brightness and contrast to normal position.
2. Connect the digital voltmeter to **TP401**.
3. Set condition is AV MODE without signal.
4. Adjust the **VR502** until the DC voltage is  $135 \pm 0.5V$ .

# ELECTRICAL ADJUSTMENTS

## 2-5: CUT OFF

1. Place the set with Aging Test for more than 15 minutes.
2. Set condition is AV MODE without signal.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(5)** on the remote control. The **Fig. 2-2** appears on the display.
5. Press the channel button **(5)** on the remote control.
6. Adjust the **Screen Volume** until a dim raster is obtained.

## 2-6: FOCUS

1. Using the remote control, set the brightness and contrast to normal position.
2. Receive the monoscope pattern.
3. Turn the Focus Volume fully counterclockwise once.
4. Adjust the **Focus Volume** until picture is distinct.

## 2-7: SUB BRIGHTNESS (TV)

1. Receive the monoscope pattern. (RF Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
4. Press the channel button **(1)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the white 10% is starting to be visible.

1. BRIGHT
2. CONTRAST
3. COLOR
4. TINT
5. SHARPNESS
6. OSD CONT
- 7.
8. 0. RETURN


Fig. 2-3

## 2-8: SUB BRIGHTNESS (AV)

1. Receive the monoscope pattern. (Audio Video Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
4. Press the channel button **(1)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the white 10% is starting to be visible.

## 2-9: SUB COLOR (TV)

1. Receive the color bar pattern. (RF Input)
2. Connect the synchro scope to **TP801**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
5. Press the channel button **(3)** on the remote control.
6. Adjust the VOLTS RANGE VARIABLE knob of the synchro scope until the range between white 100% and 0% is set to 4 scales on the screen of the synchro scope.
7. Press the VOL. UP/DOWN button on the remote control until the red color level is adjusted to 100% of the white level. (**Refer to Fig. 2-4**)



## 2-10: SUB COLOR (AV)

1. Receive the color bar pattern. (Audio Video Input)
2. Connect the synchro scope to **TP801**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
5. Press the channel button **(3)** on the remote control.
6. Adjust the VOLTS RANGE VARIABLE knob of the synchro scope until the range between white 100% and 0% is set to 4 scales on the screen of the synchro scope.
7. Press the VOL. UP/DOWN button on the remote control until the red color level is adjusted to 100% of the white level. (**Refer to Fig. 2-4**)

## 2-11: SUB TINT (TV)

1. Receive the color bar pattern. (RF Input)
2. Connect the synchro scope to **TP803**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
5. Press the channel button **(4)** on the remote control.
6. Press the VOL. UP/DOWN button on the remote control until the section "A" becomes a straight line. (**Refer to Fig. 2-5**)

# ELECTRICAL ADJUSTMENTS




Fig. 2-5

## 2-12: SUB TINT (AV)

1. Receive the color bar pattern. (Audio Video Input)
2. Connect the synchro scope to **TP803**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(4)** on the remote control. The **Fig. 2-3** appears on the display.
5. Press the channel button **(4)** on the remote control.
6. Press the VOL. UP/DOWN button on the remote control until the section "A" becomes a straight line. (Refer to **Fig. 2-5**)

## 2-13: HORIZONTAL PHASE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(1)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the SHIFT quantity of the OVER SCAN on right and left becomes minimum.




Fig. 2-6

## 2-14: VERTICAL SIZE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 2-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(3)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the horizontal over scan is equal to the vertical over scan.

## 2-15: VERTICAL LINEALITY

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(5)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the SHIFT quantity of the OVER SCAN on upside and downside becomes minimum.

## 2-16: VERTICAL POSITION

1. Receive the color bar pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(1)** on the remote control. The **Fig. 2-6** appears on the display.
4. Press the channel button **(4)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the horizontal line of the color bar comes to approximate center of the CRT.

## 2-17: OSD HORIZONTAL

1. Receive the color bar pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(5)** on the remote control. The **Fig. 2-2** appears on the display.
4. Press the channel button **(4)** on the remote control.
5. Press the VOL. UP/DOWN on the remote control until the difference of A and B becomes minimum. (Refer to **Fig. 2-7**)





Fig. 2-7

# ELECTRICAL ADJUSTMENTS


## 3. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (VCR SECTION)





# ELECTRICAL ADJUSTMENTS

(TV SECTION)



# ELECTRICAL ADJUSTMENTS

## 4. PURITY AND CONVERGENCE ADJUSTMENTS

### NOTE

1. Turn the unit on and let it warm up for at least 30 minutes before performing the following adjustments.
2. Place the CRT surface facing east or west to reduce the terrestrial magnetism.
3. Turn ON the unit and demagnetize with a Degauss Coil.

### 4-1: STATIC CONVERGENCE (ROUGH ADJUSTMENT)

1. Tighten the screw for the magnet. Refer to the adjusted CRT for the position. **(Refer to Fig. 4-1)**  
If the deflection yoke and magnet are in one body, untighten the screw for the body.
2. Receive the green raster pattern from the color bar generator.
3. Slide the deflection yoke until it touches the funnelside of the CRT.
4. Adjust center of screen to green, with red and blue on the sides, using the pair of purity magnets.
5. Switch the color bar generator from the green raster pattern to the crosshatch pattern.
6. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
7. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.
8. Adjust the crosshatch pattern to change to white by repeating steps 6 and 7.

### 4-2: PURITY

### NOTE

Adjust after performing adjustments in section 4-1.

1. Receive the green raster pattern from color bar generator.
2. Adjust the pair of purity magnets to center the color on the screen.  
Adjust the pair of purity magnets so the color at the ends are equally wide.
3. Move the deflection yoke backward (to neck side) slowly, and stop it at the position when the whole screen is green.
4. Confirm red and blue colors.
5. Adjust the slant of the deflection yoke while watching the screen, then tighten the fixing screw.




Fig. 4-1

### 4-3: STATIC CONVERGENCE

### NOTE

Adjust after performing adjustments in section 4-2.


1. Receive the crosshatch pattern from the color bar generator.
2. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
3. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.

### 4-4: DYNAMIC CONVERGENCE

### NOTE


Adjust after performing adjustments in section 4-3.

1. Adjust the differences around the screen by moving the deflection yoke upward/downward and right/left. **(Refer to Fig. 4-2-a)**
2. Insert three wedges between the deflection yoke and CRT funnel to fix the deflection yoke. **(Refer to Fig. 4-2-b)**



UPWARD/DOWNWARD SLANT RIGHT/LEFT SLANT


Fig. 4-2-a




WEDGE POSITION

Fig. 4-2-b

# TV BLOCK DIAGRAM



# Y/C/AUDIO/HEAD AMP/IN/OUT BLOCK DIAGRAM



# MICON/POWER/OPERATION BLOCK DIAGRAM

