


***Memorex***<sup>®</sup>

**MVT2197**

# **SERVICE MANUAL**

**COLOR TELEVISION/VIDEO CASSETTE RECORDER**



**VHS**

**ORIGINAL  
MFR'S VERSION A**

**Memorex<sup>®</sup>**

**MVT2197**

# **SERVICE MANUAL**

**COLOR TELEVISION/VIDEO CASSETTE RECORDER**

**REVISION 1  
MFR'S VERSION B**

**VHS**

MFR'S VERSION	IC4001
A	LA71200M-MPB
B	LA71201M-MPB

# Change of IC


## ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	MFR'S VERSION A		MFR'S VERSION B	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
IC4001	I03F3200M0	IC LA71200M-MPB	I03F301MN0	IC LA71201M-N-MPB
R1085			R801R7225J	RC 2.2M OHM 1/10W
R4018	R903N8822J	RC 8.2K OHM 1/8W	R903N8123J	RC 12K OHM 1/8W
R4021	R903N8273J	RC 27K OHM 1/8W	R903N8223J	RC 22K OHM 1/8W
R4034	R903N8104J	RC 100K OHM 1/8W	R903N8823J	RC 82K OHM 1/8W
R4044	R801R7104J	RC 100K OHM 1/10W	R801R7474J	RC 470K OHM 1/10W
R4050	R903N8473J	RC 47K OHM 1/8W		DEL
R4052	R903N8682J	RC 6.8K OHM 1/8W	R903N8822J	RC 8.2K OHM 1/8W
R4053	R903N8562J	RC 5.6K OHM 1/8W	R903N8682J	RC 6.8K OHM 1/8W
C4050	E50HU5010M	CE 1 UF 50V	E50HU5R22M	CE 0.22 UF 50 V
PCB800	A57908A01A	SYSCON PCB ASS'Y VMX210A	A57908A010	SYSCON PCB ASS'Y (VERSION B) VMX210A


SYSCON PCB's are interchangeable.

### PRINTED CIRCUIT BOARDS SYSCON/CRT

**(INSERTED PARTS)  
SOLDER SIDE  
(MFR'S VERSION B)**




**(CHIP MOUNTED PARTS)  
SOLDER SIDE  
(MFR'S VERSION B)**



ADD W261

ADD R1085

# MICON SCHEMATIC DIAGRAM (SYSCON PCB) (MFR'S VERSION B)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

CAUTION: DIGITAL TRANSISTOR


- ◁ TUNER VIDEO SIGNAL
- ◁ DEFLECTION SIGNAL
- ◁ CAPSTAN AFC SIGNAL
- ◁ CYLINDER AFC SIGNAL
- ◁ CYLINDER APC SIGNAL

PCB800 VMX210


SPEC.NO.	M579-08A
O/R NO.	W165007

# WAVEFORMS


## Y/C/AUDIO/HEAD AMP




① PB  
0.5V 20 $\mu$ s/div




⑥ POWER ON  
0.5V 10ms/div




⑪ PB  
0.5V 0.5ms/div




② POWER ON  
100mV 0.1 $\mu$ s/div




⑦ POWER ON  
1.0V 10 $\mu$ s/div



⑫ PB  
1.0V 5ms/div




③ PB  
10mV 20 $\mu$ s/div




⑧ PB  
1.0V 10ms/div


## POWER




⑬ 5.0V 20ms/div



④ REC  
10.0V 5 $\mu$ s/div




⑨ PB  
1.0V 5ms/div




⑭ 500mV 5 $\mu$ s/div

## MICON




⑤ POWER ON  
1.0V 20 $\mu$ s/div



⑩ PB  
1.0V 0.5ms/div


## DEFLECTION




⑮ 0.5V 5ms/div

NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


## WAVEFORMS




①⑥ 10.0V 5ms/div



②① 50.0V 20 $\mu$ s/div




①⑦ 2.0V 20 $\mu$ s/div




①⑧ 200mV 20 $\mu$ s/div

### CRT




①⑨ 50.0V 20 $\mu$ s/div



②⑦ 50.0V 20 $\mu$ s/div


NOTE: The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

# MECHANICAL EXPLODED VIEW







# MECHANICAL EXPLODED VIEW



# CHASSIS EXPLODED VIEW (TOP VIEW)



# CHASSIS EXPLODED VIEW (BOTTOM VIEW)



CLASS	MARK
GREASE	AA
OIL	BA

**NOTE:** Applying positions AA and BA for the grease or oil are displayed for this section. Check if the correct grease or oil is applied for each position.

# MECHANICAL REPLACEMENT PARTS LIST

REF. NO.	PART.NO	DESCRIPTION
101	A57908A720	CABINET,FRONT ASSY
102	701WPJA839	CABINET,FRONT
103	711WPA0114	PLATE,FRONT
104	712WPJ0621	FLAP
105	713WPA0075	GUIDE,REMOCON
106	735WPJ0114	BUTTON,FRAME
107	735WPA0402	BUTTON,REC
108	743WKA0032	SPRING,FLAP(COMBO)
109	7230006830	SHEET,LED
110	85OP700036	HOLDER EOT SENSOR
111	753WSA0123	PLATE,SPEAKER
112	800WFA0033	CUSHION
113	800WQ00048	FELT,SHEET
114	741WUA0019	SPRING,EARTH
115	7220001107	SHEET,HWC
116	723000A853	FILM,DECORATION
117	753WUAA006	SPRING,EARTH H/AMP
118	753WSA0130	SHIELD,COVER H/AMP
119	761WPA0196	HOLDER,DECK
120	753WSA0118	PLATE,EARTH-SYSCON
121	752WSA0209	SHIELD,CASE H/AMP
122	752WSA0232	PLATE,DECK SHIELD ASSY
123	702WPA0671	CABINET,BACK
124	722A08A078	SHEET,RATING
125	7220001119	SHEET,CSA WARNING
126	7260000323	SHEET,CRT SERVICEMAN
201	8110630A04	SCREW,TAP TITE(P) BRAZIER 3x10
202	8110630804	SCREW,TAP TITE(P) BRAZIER 3x8
203	8121F50B84	SCREW,TAPPING(BO) GW20 FLAT 5x28
204	8109I30A04	SCREW,TAP TITE(B) WH7 3x10
205	8109630802	SCREW,TAP TITE(B) BRAZIER 3x8
206	8110330804	SCREW,TAP TITE(P) FLAT 3x8
207	8117540B04	SCREW,TAPPING(BO) TRUSS 4x20
208	8117140A24	SCREW,TAPPING(BO) PAN 4x12
209	8117540A64	SCREW,TAPPING(BO) TRUSS 4x16
210	8117540804	SCREW,TAPPING(BO) TRUSS 4x8
211	8110630A24	SCREW,TAP TITE(P) BRAZIER 3x12
212	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
---	792WHAA025	PACKAGE, TOP
---	792WHAA026	PACKAGE,BOTTOM
---	793WCDA976	GIFT BOX
---	JA5K0100	POLY BAG
---	J5790801	INSTRUCTION BOOK
---	791WHA0025	LAMIFILM BAG
---	A57908A975	INSTRUCTION BOOK KIT

## CHASSIS REPLACEMENT PARTS LIST

REF. NO.	PART.NO	DESCRIPTION	REF. NO.	PART.NO	DESCRIPTION
300	A57806A420A	DECK ASSY A57806A420A	501	8107126A04	SCREW,TAP TITE(S) PAN 2.6x10
301	85OA500022	AHC ASS'Y	502	8107226804	SCREW,TAP TITE(S) BIND 2.6x8
302	85OP200290	BELT,CAPSTAN (S)	503	8107226604	SCREW,TAP TITE(S) BIND 2.6x6
303	85OP900710	LEVER,REC	504	8109126604	SCREW,TAP TITE(B) PAN 2.6x6
304	85OP500083	BASE,AC HEAD	505	83ETW30000	E-RING 3
305	85OP800324	SPRING,AC HEAD	506	8107226404	SCREW,TAP TITE(S) BIND 2.6x4
306	85OA000449	MAIN CHASSIS ASS'Y (3V)	507	8102120604	SCREW,PAN M2x6
307	85OA200082	CLUTCH ASS'Y(S2)	508	810A126504	SCREW/WASHER(A) M2.6x5
308	85OA200088	ARM IDLER ASS'Y 3V	509	810A130504	SCREW/WASHER(A) M3x5
309	85OP600556	ARM,SS BRAKE (S)	510	810A123504	SEMS A M2.3x5.0
310	85OP200292	REEL,T (S)	511	82P266005N	POLYSLIDER WASHER(CUT) 2.6x6.0xT0.5
311	85OA300061	LOADING ARM S ASS'Y	512	82Q2647C5N	POLYSLIDER WASHER 2.6x4.7xT0.25
312	85OA300062	LOADING ARM T ASS'Y	513	82P184505N	POLYSLIDER WASHER(CUT) 1.8x4.5xT0.5
313	85OP900714	COVER SENSOR L3	CP101	069R740018	CONNECTOR PCB SIDE 52044-0445
314	85OA400220	INCLINED BASE S UNIT 3V	H5001	1523D91034	HEAD (AUDIO CONTROL) HVMXA1072A
315	85OA400221	INCLINED BASE T UNIT 3V	H5002	1543D02013	HEAD (FULL ERASE) HVFHP0032A
316	85OA400199	P5-3 ARM ASS'Y(S)	△ M101	1596P78001	MOTOR (LOADING) MXN13FB11H
317	85OA400205	PINCH ROLLER BLOCK	△ M2001	1594S98001	CAPSTAN DD UNIT F2QSB36
318	85OA400175	TENSION ARM ASS'Y	△ M2003	1589S11014	MICRO MOTOR I2OAL03
319	85OA400216	TENSION BAND ASS'Y 3V	PCB550	A4C831B550	PCB VE8851E
320	85OA400178	PINCH ROLLER LEVER ASS'Y	Q101	0000700320	TRANSISTOR,PHOTO RPT-38PB113
321	85OA600197	BRAKE T ASS'Y 3V	△ UN4001	A4E101A500	CYLINDER UNIT ASS'Y A4E101A500
322	85OP500087	HOLDER SPRING(SV)			
323	85OA900223	LINK UNIT(SV)			
324	85OP900716	LEVER,LINK(SV)			
325	85OP200284	LEVER,CLUTCH (S)			
326	85OP200285	ACTUATOR,CLUTCH			
327	85OP200298	GEAR,COUPLING(S2)			
328	85OP200291	REEL,S (S)			
329	85OP600566	WORM(SV)			
330	85OP600567	BRACKET,MOTOR(SV)			
331	85OP300193	GEAR,MAIN LOADING			
332	85OP300179	GEAR,LOADING S			
333	85OP300180	GEAR,LOADING T			
334	85OP300189	HOLDER,LOADING GEAR (S-ZV)			
335	85OP400472	ADJUST,TENSION			
336	85OP400492	HOLDER,TENSION			
337	85OP400490	LEVER,TENSION			
338	85OP400520	CAP.P4			
339	85OP600543	GEAR,JOINT			
340	85OP600544	GEAR,MIDDLE			
341	85OP600572	CAM,MAIN(S)			
342	85OP600546	CAM P5			
343	85OP600565	CAM,PINCH ROLLER			
344	85OP600561	ROD,MAIN(S)			
345	85OP700035	REFLECTOR,LED			
346	85OP800318	SPRING LOADING GEAR			
347	85OP800334	SPRING,P5 (S)			
348	85OP800335	SPRING,BRAKE T (S)			
349	85OP800322	SPRING,TENSION			
350	85OP800336	SPRING,CAP BRAKE (S)			
351	85OP800342	SPRING,LOCKER (S)			
352	85OP900695	BRACKET,TOP			
353	85OP900713	LOCKER,R2			
354	85OP800330	SPRING,RING			
355	85OP800337	SPRING,SS BRAKE (S)			
356	85OP900680	OPENER,CASS			
357	85OP900722	CASS SIDE L(SV)			
358	85OP900723	CASS SIDE R(SV)			
359	85OP900728	TAPE GUIDE L(P,R)			
360	85OP900694	SPRING,PACK			
361	85OP800341	SPRING,P/R ARM			
362	85OP900688	LEVER,FLAP			
363	85OP900717	CASS HOLDER(SV)			
364	85OP900696	SPRING,CASS EARTH			
365	85OP900729	TAPE GUIDE R			

# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>RESISTORS</b>			<b>DIODES</b>		
R410	R00202272J	RC 2.7K OHM 1/2W	△ D507	D28015DF60	DIODE,SILICON 15DF6
△ R415	R002T22R2J	RC 2.2 OHM 1/2W	D508	D1VT001330	DIODE,SILICON 1SS133T-77
△ R420	R801R7682F	RC 6.8K OHM 1/10W	△ D510	D2WXRJ2AM0	DIODE,SILICON RU2AM-EIC
△ R439	R801R7223F	RC 22K OHM 1/10W	△ D512	D2WXB290S0	DIODE,SILICON SB290S
△ R440	R903N8513J	RC 51K OHM 1/8W	D513	D1VT001330	DIODE,SILICON 1SS133T-77
△ R441	R903N8563J	RC 56K OHM 1/8W	D514	D1VT001330	DIODE,SILICON 1SS133T-77
△ R442	R801R7153F	RC 15K OHM 1/10W	△ D515	D97U03301B	DIODE,ZENER MTZJ33B T-77
△ R444	R801R7273F	RC 27K OHM 1/10W	△ D517	D2WT11ES10	DIODE,SILICON 11ES1-EIC
△ R447	R65582680J	R,FUSE 68 OHM 1/2W	D518	D1VT001330	DIODE,SILICON 1SS133T-77
△ R449	R65584680J	R,FUSE 68 OHM 1/4W	△ D519	D2WXB290S0	DIODE,SILICON SB290S
△ R450	R6558A2R2J	R,FUSE 2.2 OHM 2W	D520	D28TQS04N0	DIODE,SCHOTTKY 11EQS04N-TA1B2
R500	R0G3K2275K	RC 2.7M OHM 1/2W	D521	D1VT001330	DIODE,SILICON 1SS133T-77
△ R501	R5Y2CD2R2J	R,CEMENT 2.2 OHM 5W	D524	D97U06R21B	DIODE,ZENER MTZJ6.2B T-77
△ R508	R002T2563J	RC 56K OHM 1/2W	D525	D23U1003A3	DIODE,SCHOTTKY SB10-03A3
△ R510	R002T2124J	RC 120K OHM 1/2W	D526	D23U1003A3	DIODE,SCHOTTKY SB10-03A3
△ R512	R002T2563J	RC 56K OHM 1/2W	D527	D1VT001330	DIODE,SILICON 1SS133T-77
△ R529	R4X5T4272F	R,METAL 2.7K OHM 1/4W	D528	D97U05R61B	DIODE,ZENER MTZJ5.6B T-77
△ R542	R33681R18J	R,METAL 0.18OHM 1W	D601	D1VT001330	DIODE,SILICON 1SS133T-77
△ R543	R635U4681J	R,FUSE 680 OHM 1/4W	D602	D97U08R21A	DIODE,ZENER MTZJ8.2AT-77
R630	R002T4222J	RC 2.2K OHM 1/4W	D605	D2WT11ES10	DIODE,SILICON 11ES1-EIC
△ R632	R3X18A221J	R,METAL OXIDE 220 OHM 2W	D608	D23U1003A3	DIODE,SCHOTTKY SB10-03A3
△ R802	R3X18A123J	R,METAL OXIDE 12K OHM 2W	D609	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77
△ R805	R3X18A123J	R,METAL OXIDE 12K OHM 2W	D610	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77
△ R810	R3X18A123J	R,METAL OXIDE 12K OHM 2W	D611	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77
R1080	R002T4010J	RC 1 OHM 1/4W	D612	D1VT001330	DIODE,SILICON 1SS133T-77
R1084	R002T4102J	RC 1K OHM 1/4W	D613	D1VT001330	DIODE,SILICON 1SS133T-77
R4068	R801R7225J	RC 2.2M OHM 1/10W	D614	D1VT001330	DIODE,SILICON 1SS133T-77
<b>CAPACITORS</b>			<b>ICs</b>		
C354	E02LF2222M	CE 2200 UF 16V	△ IC351	I01DP75110	IC AN7511
C402	E02L04102M	CE 1000 UF 35V	△ IC401	I01TD55220	IC AN5522
△ C407	E02L03102M	CE 1000 UF 25V	△ IC502	I2BT066230	IC STR-G6623
C423	P4J7F3394J	CMPP 0.39 UF 250V PMS	IC601	I06FC61206	IC M61206FP
△ C424	P4N8FJ682H	CMPP C 0.0068UF 1.25KV	IC1001	I56F57059A	IC OEC7059A
△ C425	C0JLYR7B3K	CC 0.0012UF 2KV YR	IC1003	IC7J0311A0	IC R3111N311A/C-TR
△ C431	E02LTD100M	CE 10 UF 250V	IC1004	I03DQ18800	IC LB11880
C432	P235W1104J	CMP 0.1 UF 100V MKT	IC1099	A57908A015	IC S-24C04BDP-LA
C433	E02LT3470M	CE 47 UF 25V	IC4001	I03F3200M0	IC LA71200M-MPB
△ C502	C0JTB0513K	CC 0.001 UF 500V B	<b>TRANSISTORS</b>		
△ C503	C0JTB0513K	CC 0.001 UF 500V B	Q401	TNAAC05002	COMPOUND TRANSISTOR KRC103RTK
△ C506	P2472B224M	CMP 0.22UF 275V PHE840	△ Q402	TAAT01281Y	TRANSISTOR,SILICON KTA1281_Y
△ C507	E51CGC471M	CE 470 UF 200V	Q403	TNAAJ05003	COMPOUND TRANSISTOR KRC111RTK
△ C510	E5EZT4101M	CE 100 UF 35V	Q404	TPYJD05001	COMPOUND TRANSISTOR DTA144EKAT146
△ C511	E5EZT3471M	CE 470 UF 25V	△ Q405	TC3T02271E	TRANSISTOR,SILICON 2SC2271E-AE
C514	C0JLYR7K3K	CC 0.0027UF 2KV YR	△ Q406	TD30026270	TRANSISTOR,SILICON 2SD2627LS-CBC11
△ C516	C0JTB05Q2K	CC 470 PF 500V B	△ Q501	0002500450	PHOTO COUPLER TLP621(GR)
C517	C0JLYR7H3K	CC 0.0022UF 2KV YR	△ Q505	TD3Q018250	TRANSISTOR,SILICON 2SD1825Z-YAC11
△ C521	E62NFB101M	CE 100 UF 160V	Q507	TCATC31980	TRANSISTOR,SILICON KTC3198-AT(Y,GR)
△ C522	E02LTB010M	CE 1 UF 160V	Q601	T6YJ1037K0	TRANSISTOR,SILICON 2SA1037AKT146R,S
△ C523	E02LT4471M	CE 470 UF 35V	Q602	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT or
△ C524	E5EZ02222M	CE 2200 UF 16V	Q603	TCAT032034	TRANSISTOR,SILICON 2SC120Y(TPE2)
C525	E02L00102M	CE 1000 UF 6.3V	Q604	TC5T021204	TRANSISTOR,SILICON KTC3203_Y-AT or
△ C530	C034F0JQ3M	CC 0.0047UF 125V MX	Q605	TCAT032034	TRANSISTOR,SILICON KTC3203_Y-AT or
C535	C0JLYR7U2K	CC 680 PF 2KV YR	Q606	TC5T021204	TRANSISTOR,SILICON 2SC120Y(TPE2)
C560	C0JLYR713K	CC 0.001 UF 2KV YR	Q608	TNYJB05001	COMPOUND TRANSISTOR DTC114EKAT146
△ C659	E50HU0101M	CE 100 UF 6.3V	Q609	TNAAB05003	COMPOUND TRANSISTOR KRC102RTK
△ C660	CSORF0415Z	CC 0.1 UF 50V F	Q611	TNAAB05003	COMPOUND TRANSISTOR KRC102RTK
C801	C0HHB07H3K	CC 0.0022UF 2KV B	△ Q804	TC3F042170	TRANSISTOR,SILICON 2SC4217(D,E)-RAC
C819	C0HHB07H3K	CC 0.0022UF 2KV B	△ Q805	TC3F042170	TRANSISTOR,SILICON 2SC4217(D,E)-RAC
C1007	CHGTF0415Z	CC 0.1 UF 50V F			
C1091	CHGTX02L3M	CC 0.0033UF 16V X			
C4025	E50HU0221M	CE 220 UF 6.3V			
<b>DIODES</b>					
D401	D2WT011E10	DIODE,SILICON 11E1-EIC			
D402	D2LTPG06J0	DIODE,SILICON RMPG06J-G3			
D403	D97U03001B	DIODE,ZENER MTZJ30B T-77			
D404	D97U03001B	DIODE,ZENER MTZJ30B T-77			
D405	D2WT011E10	DIODE,SILICON 11E1-EIC			
△ D408	D94TA27011	DIODE,ZENER HZ27-1L TD			
△ D409	D94TA11B13	DIODE,ZENER HZ11B3L TD			
D410	D97U06R81B	DIODE,ZENER MTZJ6.8B T-77			
△ D412	D2LTPG06J0	DIODE,SILICON RMPG06J-G3			
△ D413	D2LTPG06J0	DIODE,SILICON RMPG06J-G3			
△ D501	D4LZBL06L0	DIODE GBL06L-6177			
D502	D1VT001330	DIODE,SILICON 1SS133T-77			
D504	D1VT001330	DIODE,SILICON 1SS133T-77			
D505	D2WXB290S0	DIODE,SILICON SB290S			
D506	D2LTPG06J0	DIODE,SILICON RMPG06J-G3			


# ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION		
<b>TRANSISTORS</b>			<b>MISCELLANEOUS</b>				
△ Q806	TC3F042170	TRANSISTOR,SILICON	2SC4217(D,E)-RAC	CF603	1011T4R504	FILTER,CERAMIC	EFCT4R5YS5A
Q1002	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CF604	1011T4R517	FILTER,CERAMIC	EFCT4R5MW5
Q1003	0002700530	PHOTO COUPLER	RPI-352Q01R	CP351	0694260139	CONNECTOR PCB SIDE	173979-6
Q1004	TNAAC05002	COMPOUND TRANSISTOR	KRC103RTK	CP353	0694270139	CONNECTOR PCB SIDE	173979-7
Q1005	0002700590	PHOTO COUPLER	RPI-301	△ CP401	069X450029	CONNECTOR PCB SIDE	B05B-DVS
Q1007	TNAAB05003	COMPOUND TRANSISTOR	KRC102RTK	△ CP502	069W420029	CONNECTOR PCB SIDE	TV-50P-02-A1
Q1008	TNAAB05003	COMPOUND TRANSISTOR	KRC102RTK	CP757	06942A0139	CONNECTOR PCB SIDE	1-173979-0
Q1009	0002700530	PHOTO COUPLER	RPI-352Q01R	CP801	069W320018	CONNECTOR PCB SIDE	TS-80P-02-V1
Q1013	0000100380	PHOTO TRANSISTOR	PNA2604M010R	CD1001	122L040904	CORD JUMPER	2L040904
Q1023	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CD1002	122F071901	CORD JUMPER	2F071901
Q4001	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)	CD4001	122L061501	CORD JUMPER	2L061501
Q4002	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)	CP1003	0694240139	CONNECTOR PCB SIDE	173979-4
Q4003	TPAAC05002	COMPOUND TRANSISTOR	KRA103RTK	CP1004	0697280590	CONNECTOR PCB SIDE	TMC-J08P-B1
Q4005	TAATA12660	TRANSISTOR,SILICON	KTA1266-AT(Y,GR)	CP1005	069J770029	CONNECTOR PCB SIDE	IMSA-9604S-07Z14
Q4006	TCAT032034	TRANSISTOR, SILICON	KTC3203_Y-AT or	CP1006	069J740029	CONNECTOR PCB SIDE	IMSA-9604S-04Z14
	TC5T021204	TRANSISTOR,SILICON	2SC2120Y(TPE2)	CP4001	0697240600	CONNECTOR PCB SIDE	TOC-C04X-B1
Q4007	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CP4002	069J760029	CONNECTOR PCB SIDE	IMSA-9604S-06Z11 or
Q4009	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S		069X760019	CONNECTOR PCB SIDE	06FE-BT-VK-N
Q4010	T6YJ1037K0	TRANSISTOR,SILICON	2SA1037AKT146R,S	CP4003	0697120320	CONNECTOR PCB SIDE	TMC-T02X-E1
Q4011	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CP851A	067R010019	WIRE HOLDER	51048-1000
Q4012	T8YJ2412K0	TRANSISTOR,SILICON	2SC2412KT146 R,S	CP851B	067R010019	WIRE HOLDER	51048-1000
Q4204	TNYJB05001	COMPOUND TRANSISTOR	DTC114EKAT146	CUS011	800WFAA006	CUSHION A	
				CUS012	800WFAA008	CUSHION C	
<b>COILS &amp; TRANSFORMERS</b>							
L401	021679472K	COIL	4.7 MH	△ F501	081PC05004	FUSE	51MS050LCC
△ L502	029T000092	COIL,LINE FILTER	1R0A103F24	△ F502	081PC2R504	FUSE	51MS025LCC
△ L503	028R200029	COIL,DEGAUSS	8R200029	△ FB401	043219011F	TRANSFORMER,FLYBACK	FQI-20B001
L601	0216A61R2K	COIL	1.2 UH	FH501	06710T0006	HOLDER,FUSE	EYF-52BC
L603	02167F470J	COIL	47 UH	FH502	06710T0006	HOLDER,FUSE	EYF-52BC
L605	021LA61R2K	COI	1.2 UH	FH503	06710T0006	HOLDER,FUSE	EYF-52BC
L607	021LA6220K	COIL	22 UH	FH504	06710T0006	HOLDER,FUSE	EYF-52BC
L612	021LA66R8K	COIL	6.8 UH	OS753	077Q037002	REMOTE RECEIVER	PIC-37143TH5 or
L801	021673101K	COIL	100 UH		077Q000017	REMOTE RECEIVER	PIC-28143TH5
L1001	021LA62R2K	COIL	2.2 UH	△ SP351	070W133014	SPEAKER	P-300S-2
L4001	02167F220J	COIL	22 UH	△ TH501	DF5EL3R0A0	DEGAUSS ELEMENT	ZPB45BL3R0A
L4003	02167F101J	COIL	100 UH	TM101	076N0CG010	TRANSMITTER	RC-CG010
L4004	02167F101J	COIL	100 UH	△ TU601	0145K00055	TUNER,VHF-UHF	TECC1040PG32D
L4005	02167F470J	COIL	47 UH	△ V801	098Q200481	CRT W/DY	A48AGY13X77
L4006	02167F470J	COIL	47 UH	X602	100CT3R505	CRYSTAL	HC-49/C
L4009	02167F101J	COIL	100 UH	X1001	100CT01207	CRYSTAL	HC-49/U-S
T401	03305Y0018	TRANS,HORIZONTAL DRIVE	305Y001	X1002	100DA32R01	CRYSTAL	DT-26
△ T501	048129015S	TRANSFORMER,SWITCHING	8129015S	X4001	100CT3R502	CRYSTAL	HC-49/U
T4001	031626009R	COIL,BIAS OSC	1626009				
<b>JACKS</b>							
△ J351	060G131014	RCA JACK	HTJ-035-28A	RESISTOR			
J701	060Q401075	RCA JACK	AV2-24D-5	RC.....	CARBON RESISTOR		
△ J801	066C130015	SOCKET,CATHODE RAY TUBE	CVT3275-5102	CAPACITORS			
<b>SWITCHES</b>							
SW751	0504101T34	SWITCH,TACT	EVQ21505R	CC.....	CERAMIC CAPACITOR		
SW791	0504101T34	SWITCH,TACT	EVQ21505R	CE.....	ALUMI ELECTROLYTIC CAPACITOR		
SW792	0504101T34	SWITCH,TACT	EVQ21505R	CP.....	POLYESTER CAPACITOR		
SW793	0504101T34	SWITCH,TACT	EVQ21505R	CPP.....	POLYPROPYLENE CAPACITOR		
SW794	0504101T34	SWITCH,TACT	EVQ21505R	CPL.....	PLASTIC CAPACITOR		
SW795	0504101T34	SWITCH,TACT	EVQ21505R	CMP.....	METAL POLYESTER CAPACITOR		
SW796	0504101T34	SWITCH,TACT	EVQ21505R	CMPL.....	METAL PLASTIC CAPACITOR		
SW797	0504101T34	SWITCH,TACT	EVQ21505R	CMPP.....	METAL POLYPROPYLENE CAPACITOR		
SW798	0504101T34	SWITCH,TACT	EVQ21505R				
SW799	0504101T34	SWITCH,TACT	EVQ21505R				
SW1001	0508221001	SWITCH (LEAF)	SPVF130100				
<b>VARIABLE RESISTOR</b>							
VR502	V1163L2BTC	VOLUME,SEMI FIXED	EVNCYAA03BY2				
<b>P.C. BOARD ASSEMBLIES</b>							
PCB030	A57909A03A	PCB ASS'Y	TEXA28A				
PCB110	A57904A11A	PCB ASS'Y	TCX353A				
PCB800	A57908A01A	PCB ASS'Y	VMX210A				
<b>MISCELLANEOUS</b>							
B402	024AT03655	CORE,BEADS	BL01RN1-A63T6				
B502	024AT03482	CORE,BEADS	BL02RN2-R62T4				
B503	024AT03655	CORE,BEADS	BL01RN1-A63T6				
B505	024AT03482	CORE,BEADS	BL02RN2-R62T4				
B602	024AT03655	CORE,BEADS	BL01RN1-A63T6				
B604	024AT03481	CORE,BEADS	BL02RN1-R62T2				
CD351	06CH27090A	CORD CONNECTOR	CH27090A				
CD352	06CH12435A	CORD CONNECTOR	CH12435A				
△ CD501	1207414905	CORD AC BUSH	7414905				
CD757	06CH2A019A	CORD CONNECTOR	CH2A019A				
CD801	06CU82039A	CORD CONNECTOR	SM1098-009-1A				
CF601	1022T45R72	FILTER,SAW	SAF45MFY220ZR				

SPEC.NO.	M579-08A
O/R NO.	W145020



# Y/C/AUDIO/CCD/HEAD AMP SCHEMATIC DIAGRAM (SYSCON PCB)



FROM POWER  
P.CON+5V  
GND

FROM/TO CYL  
CP4001\_1  
TCC-C04X-B1  
4 SP-CH1 (R)  
3 SP\_COM  
2 SP-CH2 (L)  
1

FROM/TO HEAD AUDIO CONTROL  
CP4002  
IMSA-9604S-06Z14  
6 AUDIO PB  
5 AUDIO REC  
4 CTL+  
3 CTL-  
2 AE HEAD(-)  
1 AE HEAD(+)

TO FULL ERASE HEAD  
CP4003  
TMC-T02X-E1  
2 FE HEAD(GND)  
1 FE HEAD(HOT)

FROM/TO IN/OUT  
FRONT\_AUDIO  
FRONT\_VIDEO  
Y/C\_AUDIO  
Y/C\_VIDEO

FROM/TO MICON  
Y/C\_CLK  
Y/C\_DATA  
Y/C\_CS  
V.REC\_ST\_H

VCR\_A\_MUTE  
DUMMY\_V.SYNC  
CTL-  
CTL+  
H.AMP\_SW1

ENV\_DET  
H.SW  
SD\_VIDEO  
SD\_SYNC

FROM/TO CHROMA/IF  
TU\_VIDEO  
FRONT\_VIDEO  
SD\_VIDEO  
DUMMY\_V.SYNC  
P.CON+5V  
Y/C\_VIDEO  
SD\_VIDEO  
DUMMY\_V.SYNC  
P.CON+5V

- ◀ DEFLECTION SIGNAL
- ◀ AUDIO SIGNAL(REC)
- ▶ AUDIO SIGNAL(PB)
- ▶ TUNER VIDEO SIGNAL
- ▶ PLAYBACK VIDEO SIGNAL
- ▶ RECORD LUMINANCE SIGNAL
- ▶ RECORD COLOR SIGNAL
- ▶ PLAYBACK COLOR SIGNAL
- ▶ PLAYBACK LUMINANCE SIGNAL


CAUTION: DIGITAL TRANSISTOR

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

PCB800  
VMX210

# MICON SCHEMATIC DIAGRAM (SYSCON PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

CAUTION: DIGITAL TRANSISTOR

- ▶ R.SIGNAL
- ▶ G.SIGNAL
- ▶ B.SIGNAL
- ▶ PLAYBACK VIDEO SIGNAL
- ▶ DEFLECTION SIGNAL
- ▶ CAPSTAN AFC SIGNAL
- ▶ CYLINDER AFC SIGNAL
- ▶ CYLINDER APC SIGNAL

FROM/TO Y/C/AUDIO/HEAD AMP

FROM/TO CHROMA/IF


FROM/TO IN/OUT

TO SOUND AMP

FROM/TO DEFLECTION

PCB800 VMX210


# IN/OUT SCHEMATIC DIAGRAM (SYSCON PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


CAUTION: DIGITAL TRANSISTOR



- ◀ B.SIGNAL
- ◀ AUDIO SIGNAL(REC)
- ◀ AUDIO SIGNAL(PB)
- ◀ RECORD LUMINANCE SIGNAL
- ◀ RECORD COLOR SIGNAL
- ◀ PLAYBACK COLOR SIGNAL
- ◀ PLAYBACK LUMINANCE SIGNAL
- ◀ TUNER VIDEO SIGNAL

PCB800  
VMX210

# CHROMA/IF SCHEMATIC DIAGRAM (SYSCON PCB)



- ◀ R.SIGNAL
- ▲ G.SIGNAL
- ◀ B.SIGNAL
- ▣ DEFLECTION SIGNAL
- ◀ AUDIO SIGNAL (REC)
- ▶ AUDIO SIGNAL (PB)
- ◀▶ PLAYBACK VIDEO SIGNAL
- ◀▶ TUNER VIDEO SIGNAL

CAUTION: DIGITAL TRANSISTOR

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY Δ ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES RÉPARÉES PAR UN Δ ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

PCB800 VMX210

# SOUND AMP SCHEMATIC DIAGRAM (SYSCON PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIÈCES.

PCB800  
VMX210

# POWER SCHEMATIC DIAGRAM (SYSCON PCB)



CAUTION: FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE FUSE 5A 125V (F501) AND 2.5A 125V (F502)

ATTENTION: POUR UNE PROTECTION CONTINUE LES RISQUES D'INCENDIE N'UTILISER QUE DES FUSIBLE DE MEME TYPE 5A 125V (F501) ET 2.5A 125V (F502)


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARÉES PAR UN ETANT DANGEREUSES AU POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIECES.

# DEFLECTION SCHEMATIC DIAGRAM (SYSCON PCB)




NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


CAUTION: SINCE THESE PARTS MARKED WITH  $\Delta$  ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES REPARÉES PAR UN  $\Delta$  ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIÈCES.


CAUTION: DIGITAL TRANSISTOR



CAUTION: DIGITAL TRANSISTOR




# CRT SCHEMATIC DIAGRAM (CRT PCB)



FROM CHROMA/IF	
CP851B (CP851A)	51048-1000
10	GND
9	CUT_OFF
8	G.OUT
7	B.OUT
6	R.OUT
5	NC
4	HEATER
3	H_GND1
2	NC
1	180V

PCB110  
TCX353

FROM DEFLECTION  
CP801 (CD801)  
TS-80P-02-V1



- ◀ R.SIGNAL
- ◀ G.SIGNAL
- ◀ B.SIGNAL

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.


NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARÉES PAR UN ETANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIECES.



# OPERATION SCHEMATIC DIAGRAM (OPERATION PCB)



FROM/TO IN/OUT

10	REMOCON_IN	←
9	GND	←
8	AT+5V	←
7	POWER_ON_L	←
6	NC	←
5	KEY_A	←
4	T-REC_LED	←
3	REC_LED	←
2	KEY_B	←
1	NC	←

FROM/TO IN/OUT

7	FRONT_VIDEO_IN	←
6	GND	←
5	FRONT_AUDIO_IN	←
4	SOUND_GND	←
3	SOUND_OUT	→
2	SP_OUT	→
1	GND	←



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIÈCES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRITES DANS LA NOMENCLATURE DES PIÈCES.

TUNER VIDEO SIGNAL  
 AUDIO SIGNAL(REC)

PCB030  
TEXA28

# DECK SCHEMATIC DIAGRAM (DECK PCB)




CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY .

ATTENTION: LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AN POINT DE VUE SECURITE N'UTILISER QUE CELLS DECRITES DANS LA NOMENCLATURE DES PIECES.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER DURING PLAYBACK.

NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE .

# INTERCONNECTION DIAGRAM




NOTE: THIS INTERCONNECTION DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

ATTENTION: LES PIECES REPARÉES PAR UN ÉTANT DANGEREUSES AU POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.


# TV BLOCK DIAGRAM



# Y/C/AUDIO/CCD/HEAD AMP BLOCK DIAGRAM




# MICON/IN/OUT/OPERATION/DECK BLOCK DIAGRAM




PRINTED CIRCUIT BOARDS


OPERATION  
SOLDER SIDE



DECK  
SOLDER SIDE



PRINTED CIRCUIT BOARDS  
SYSCON/CRT (INSERTED PARTS)  
SOLDER SIDE







## SERVICING NOTICES ON CHECKING

### 1. KEEP THE NOTICES


As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

### 2. AVOID AN ELECTRIC SHOCK

There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.

### 3. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  mark, the designated parts must be used.

### 4. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

### 5. TAKE CARE TO DEAL WITH THE CATHODE-RAY TUBE

In the condition that an explosion-proof cathode-ray tube is set in this equipment, safety is secured against implosion. However, when removing it or serving from backward, it is dangerous to give a shock. Take enough care to deal with it.

### 6. AVOID AN X-RAY

Safety is secured against an X-ray by considering about the cathode-ray tube and the high voltage peripheral circuit, etc.

Therefore, when repairing the high voltage peripheral circuit, use the designated parts and make sure not modify the circuit.

Repairing except indicates causes rising of high voltage, and it emits an X-ray from the cathode-ray tube.

### 7. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

#### (INSULATION CHECK PROCEDURE)

1. Unplug the plug from the AC outlet.
2. Remove the antenna terminal on TV and turn on the TV.
3. Insulation resistance between the cord plug terminals and the external exposure metal **[Note 2]** should be more than 1M ohm by using the 500V insulation resistance meter **[Note 1]**.
4. If the insulation resistance is less than 1M ohm, the inspection repair should be required.

#### **[Note 1]**

If you have not the 500V insulation resistance meter, use a Tester.

#### **[Note 2]**

External exposure metal: Antenna terminal  
Earphone jack

## HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

### 1. MODEL NUMBER and VERSION LETTER

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

### 2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

# CONTENTS

<b>SERVICING NOTICES ON CHECKING</b> .....	A1-1
<b>HOW TO ORDER PARTS</b> .....	A1-1
<b>CONTENTS</b> .....	A2-1
<b>GENERAL SPECIFICATIONS</b> .....	A3-1~A3-5
<b>DISASSEMBLY INSTRUCTIONS</b>	
1. REMOVAL OF MECHANICAL PARTS AND P. C. BOARDS .....	B1-1
2. REMOVAL OF DECK PARTS .....	B2-1~B2-5
3. REMOVAL OF ANODE CAP .....	B3-1
<b>KEY TO ABBREVIATIONS</b> .....	C1-1, C1-2
<b>SERVICE MODE LIST</b> .....	C2-1
<b>PREVENTIVE CHECKS AND SERVICE INTERVALS</b> .....	C3-1, C3-2
<b>NOTE FOR THE REPLACING OF MEMORY IC</b> .....	C4-1
<b>SERVICING FIXTURES AND TOOLS</b> .....	C5-1
<b>PREPARATION FOR SERVICING</b> .....	C5-1
<b>MECHANICAL ADJUSTMENTS</b> .....	D1-1~D1-4
<b>ELECTRICAL ADJUSTMENTS</b> .....	D2-1~D2-5
<b>BLOCK DIAGRAMS</b>	
TV .....	E-1, E-2
Y/C/AUDIO/CCD/HEAD AMP .....	E-3, E-4
MICON/IN/OUT/OPERATION/DECK .....	E-5, E-6
<b>PRINTED CIRCUIT BOARDS</b>	
OPERATION/DECK .....	F-1, F-2
SYSCON/CRT .....	F-3~F-6
<b>SCHEMATIC DIAGRAMS</b>	
Y/C/AUDIO/CCD/HEAD AMP .....	G-1, G-2
MICON .....	G-3, G-4
IN/OUT .....	G-5, G-6
CHROMA/IF .....	G-7, G-8
SOUND AMP .....	G-9, G-10
POWER .....	G-11, G-12
DEFLECTION .....	G-13, G-14
CRT .....	G-15, G-16
OPERATION .....	G-17, G-18
DECK .....	G-19, G-20
<b>INTERCONNECTION DIAGRAM</b> .....	G-21, G-22
<b>WAVEFORMS</b> .....	H-1, H-2
<b>MECHANICAL EXPLODED VIEWS</b> .....	I-1, I-2
<b>CHASSIS EXPLODED VIEWS</b> .....	I-3, I-4
<b>MECHANICAL REPLACEMENT PARTS LIST</b> .....	J1-1
<b>CHASSIS REPLACEMENT PARTS LIST</b> .....	J2-1
<b>ELECTRICAL REPLACEMENT PARTS LIST</b> .....	J3-1~J3-2

## GENERAL SPECIFICATIONS

G-1	TV System	CRT	CRT Size / Visual Size	19 inch / 480.0mmV	
			CRT Type	Normal	
			Deflection	90 degree	
			Magnetic Field BV/BH	+0.45G / 0.18G	
			Color System	NTSC	
			Speaker	1Speaker	
				Position	Front
				Size	3 Inch
				Impedance	8 ohm
			Sound Output	MAX	1.5 W
		10%(Typical)	1.0 W		
G-2	VCR System	System		VHS Player / Recorder	
		Video System		NTSC	
		Hi-Fi STEREO		No	
		NTSC PB		-	
		Deck	DECK	OVD-6S	
			Loading System	Front	
			Motor	3	
		Heads	Video Head	2 Head	
			FM Audio Head	No	
			Audio /Control	Mono	
			Erase(Full Track Erase)	Yes	
		Tape	Rec	PAL	-
		Speed		NTSC	SP/SLP
			Play	PAL	-
				NTSC	SP/LP/SLP
			Fast Forward / Rewind Time (Approx.)	Cassette	FF:4'50"/REW:2'30" at T-120
	Forward/Reverse	NTSC or PAL-M	SP/LP/SLP=3x,5x/7x,9x/9x,15x		
	Picture Search				
	Frame Advance	Slow	-		
	Slow Speed	Variable Slow	-		
G-3	Tuning System	Broadcasting System		US Sysytem M	
		Tuner and	System	1Tuner	
		Receive CH	Destination	USA/CANADA+CATV	
			Tuning System	F-Synth	
			Input Impedance	VHF/UHF 75 ohm	
			CH Coverage	2~69, 4A,A-5~A-1, A-1, J~W,W+1~W+84	
		Intermediate	Picture(FP)	45.75MHz	
		Frequency	Sound(FS)	41.25MHz	
			FP-FS	4.5MHz	
			Preset CH	No	
	Stereo/Dual TV Sound	No			
G-4	Signal	Video Signal	Input Level	1 V p-p/75 ohm	
			Output Level	-	
			S/N Ratio (Weighted)	50 dB	
			Horizontal Resolution at SP Mode	220 Lines	
		Audio Signal	Input Level	RCA-8dB/50Kohm	
			Output Level	-	
		Hi-Fi Audio Signal	Dynamic Range : More than	-	
			Wow And Flutter : Less than	-	
	Channel Separation : More than	-			
	Harmonic Distortion : Less than	-			
G-5	Power	Power Source	AC	120V 60Hz	
			DC	-	
		Power Consumption		at AC	86 W at 120V 60Hz
				at DC	-
			Stand by (at AC) Per Year		5 W at 120V 60 Hz -
	Protector	Power Fuse	Yes		
		Dew Sensor	No		
G-6	Regulation	Safety		UL/CSA	
		Radiation		FCC/DOC	
		X-Radiation		DHHS/HWC	
G-7	Temperature	Operation		+5oC ~ +40oC	
		Storage		-20oC ~ +60oC	
G-8	Operating Humidity			Less then 80% RH	

# GENERAL SPECIFICATIONS

G-9	On Screen Display	Menu	Yes	
		Menu Type	Character	
		Timer Rec Set	Yes	
		Channel Setup	Yes	
			TV/CATV	Yes
			Auto ch Memory	Yes
			Add/Delete	Yes
			Guide ch Set	No
			TV Setup	Yes
			V-chip Set	No
			On/Off Timer Set	Yes
			Picture	Yes
			Audio	No
			Sap On/Off	No
			Auto Repeat On/Off	Yes
			System Setup	Yes
			Clock Set	Yes
			Language	Yes
			Auto Clock On/Off	Yes
			Standard Time	Yes
			Daylight Saving Time	Yes
			Commercial Advance	No
			Marking On/Off	No
			Blueback On/Off	No
			Playback Auto/Manual	No
			Unmarked Tape	No
			Movie Advance	No
			Go To Movie	No
			Go To Preview	No
			G-CODE(or SHOWVIEW or PLUSCODE)No. Entry	No
			Clock	Yes
			CH/AV	Yes
			Tape Counter(Linear Counter)	Yes
			Tape Speed	Yes
			Sleep Time	Yes
			Stereo/Audio Output	No
			Bilingual	No
			SAP	No
			Control Volume	Yes
			Level Bright / Contrast / Sharpness/Color	Yes
	Tint	Yes		
	Bass/Treble/Balance	No		
	Manual Tracking	Yes		
	Play/Stop/FF/Rew/Rec/OTR/T-Rec/Pause/Eject/Tape In (Symbol Mark)	Yes		
	Auto Tracking/Manual Tracking	Yes		
	Caption / Text	Yes		
	Index	No		
	Muting	Yes		
	Hi-Fi	No		
	Repeat	Yes		
	Zero Return	No		
	DEW	No		
G-10	OSD Language	OSD Language Setting	English French Spanish English	
G-11	Clock,Timer and Timer Back-up	Calendar	1990/1/1 ~ 2081/12/31	
		Timer Events	8 prog/ 1 month	
		One Touch Recording Max Time	5 Hours	
		OTPB Valid Time	No	
		Sleep Timer Max Time	120 min.	
		Step	10 min.	
		On/Off Timer Program(On Tim / Off Tim)	1 prog.	
		Auto Shut Off No Signal	15 min.	
		No Operation	-	
	Timer Back-up (at Power Off Mode)	5 sec.		

## GENERAL SPECIFICATIONS

G-12	Remote Control	Unit	RC-CG
		Glow in Dark Remocon	Yes
		Power Source	3V
		Voltage(D.C)	UM-3 x 2 pcs
		UM size x pcs	
		Total Keys	41 Keys
		Keys	
		Power	Yes
		1	Yes
		2	Yes
		3	Yes
		4	Yes
		5	Yes
		6	Yes
		7	Yes
		8	Yes
		9	Yes
		0	Yes
		CH Up	Yes
		CH Down	Yes
		Volume Up	Yes
		Volume Down	Yes
		Input Select	Yes
		Play	Yes
		F.Fwd	Yes
		Rew	Yes
		Pause/Still	Yes
		Stop	Yes
		Rec/OTR	Yes
		Eject	Yes
		Counter Reset	Yes
		Speed	Yes
		Timer Rec	Yes
		TV Monitor	Yes
		Quick View	Yes
		Program	Yes
		Slow	No
		Auto Tracking	Yes
		Set/Tracking+	Yes
		Set/Tracking -	Yes
		Menu	Yes
		Enter	Yes
		Cancel	Yes
		Call	Yes
		TV/Caption/Text	Yes
		Sleep Timer	Yes
		Muting	Yes
		Zero Return	Yes
		CM Skip	Yes
		Audio Select	No
G-13	Features	Auto Head Cleaning	Yes
		Auto Tracking	Yes
		HQ (VHS Standard High Quality)	Yes
		Auto Power On, Auto Play, Auto Rewind, Auto Eject	Yes
		VIDEO PLUS+(SHOWVIEW,G-CODE)	No
		Auto Clock	Yes
		Forward / Reverse Picture Search	Yes
		One Touch Playback	No
		Auto CH Memory	Yes
		Closed Caption	Yes
		TV Auto Shut off Function	Yes
		End Call	No
		Index Search	No
		SQPB	No
		CATV	Yes
		CM Skip(30sec x 6 Times)	Yes
		Comb Filter	No
		TV Monitor	Yes
		Program Extend	No
		Choke Coil	No
		Energy Star	Yes
		Dirty Head	No
		V-chip	YES
		USA V-chip	
		CANADA V-chip	No
		CM Advance	No
		Movie Advance	No

## GENERAL SPECIFICATIONS

<b>G-14</b>	<b>Accessories</b>	Owner's Manual	Language w/Guarantee Card	English/French Yes	
		Remote Control Unit		Yes	
		Rod Antenna	Poles	-	No
			Terminal	-	
			w/300 ohm to 75 ohm Antenna Adapter	-	
		Loop Antenna	Terminal	-	No
		U/V Mixer			No
		DC Car Cord (Center+)			No
		Guarantee Card			No
		Warning Sheet			No
		Circuit Diagram			No
		Antenna Change Plug			No
		Service Facility List		NO	
		Important Safeguard			No
		Dew/AHC Caution Sheet			No
		AC Plug Adapter			No
		Quick Set-up Sheet			No
		Battery	UM size x pcs	-	No
		AC Cord			No
		AV Cord (2Pin-1Pin)			No
Registration Card			No		
ESP Card			No		
300 ohm to 75 ohm Antenna Adapter			No		
<b>G-15</b>	<b>Interface</b>	Switch	Power	Yes	
			Play	Yes	
			Pause/Still	No	
			System Select	No	
			One Touch Playback	No	
			Channel Up	Yes	
			Channel Down	Yes	
			F.FWD/Cue	Yes	
			Eject/Stop	Yes	
			Main Power SW	No	
			Volume Up	Yes	
			Volume Down	Yes	
			Rew/Rev	Yes	
			Rec/OTR	Yes	
			Input Select	No	
		Indicator	Power	Red	
			Rec/OTR	Red	
			T-Rec	Red	
			On Timer	No	
			CS	No	
		Key Light up	Rec/OTR	No	
			One Touch Playback	No	
			Play	No	
		Terminals	Front	Video Input	RCAx1
				Audio Input	RCAx1
				Other Terminal	Head Phone(Stereo & Mono, 3.5mm)
			Rear	Video Input	No
				Audio Input	No
				Video Output	No
Audio Output	No				
Euro Scart	No				
Diversity	No				
Ext Speaker	No				
DC Jack 12V(Center +)	No				
VHF/UHF Antenna Input	F Type				
AC Inlet	No				
<b>G-16</b>	<b>Set Size</b>			Approx. W x D x H (mm)	489 x 470.5 x 479.5
<b>G-17</b>	<b>Weight</b>	Net (Approx.)	19.0 kg (41.8 lbs)		
		Gross (Approx.)	22.0 kg (48.5 lbs)		

# GENERAL SPECIFICATIONS

<b>G-18</b>	<b>Carton</b>	Master Carton	No	
		Content	-	
		Material	-	
		Dimensions W x D x H(mm)	-	
		Description of Origin	-	
		Gift Box	Yes	
		Material	Double/White	
		Dimensions W x D x H(mm)	559 x 538 x 555	
		Design	As per Buyer's	
		Description of Origin	No	
		Drop Test	Natural Dropping At	1 Corner / 3 Edges / 6 Surfaces
		Height (cm)		46
Container Stuffing(40' container)		352 Sets		
<b>G-19</b>	<b>Cabinet Material</b>	Cabinet Front	PS 94V0 DECABROM	
		Cabinet Rear	PS 94V0	



# DISASSEMBLY INSTRUCTIONS

## 1. REMOVAL OF MECHANICAL PARTS AND P.C. BOARDS

### 1-1: BACK CABINET (Refer to Fig. 1-1)

1. Remove the 4 screws ①.
2. Remove the screw ②.
3. Remove the AC cord from the AC cord hook ③.
4. Remove the Back Cabinet in the direction of arrow.




Fig. 1-1

### 1-2: CRT PCB (Refer to Fig. 1-2)

**CAUTION: BEFORE REMOVING THE ANODE CAP, DISCHARGE ELECTRICITY BECAUSE IT CONTAINS HIGH VOLTAGE. BEFORE ATTEMPTING TO REMOVE OR REPAIR ANY PCB, UNPLUG THE POWER CORD FROM THE AC SOURCE.**

1. Remove the Anode Cap.  
(Refer to REMOVAL OF ANODE CAP)
2. Disconnect the following connectors:  
(CP801 and CP851).
3. Remove the CRT PCB in the direction of arrow.




Fig. 1-2

### 1-3: TV/VCR BLOCK (Refer to Fig. 1-3)

1. Remove the 2 screws ①.
2. Disconnect the following connectors:  
(CP757, CP353, CP401 and CP502).
3. Unlock the support ②.
4. Remove the TV/VCR Block in the direction of arrow.




Fig. 1-3

### 1-4: DECK CHASSIS AND SYSCON PCB (Refer to Fig. 1-4)

1. Remove the 3 screws ①.
2. Remove the 2 screws ②.
3. Remove the screw ③.
4. Remove the screw ④.
5. Disconnect the following connectors:(CP1004, CP1005, CP1006, CP4001, CP4002 and CP4003).
6. Remove the Deck Chassis and Deck Shield Plate in the direction of arrow (A).
7. Remove the screw ⑤.
8. Remove the Syscon PCB in the direction of arrow (B).




Fig. 1-4

# DISASSEMBLY INSTRUCTIONS

## 2. REMOVAL OF DECK PARTS

### 2-1: TOP BRACKET (Refer to Fig. 2-1)

1. Remove the 2 screws ①.
2. Slide the 2 supports ② and remove the Top Bracket.

#### NOTE

When you install the Top Bracket, install the screw (1) first, then install the screw (2).




Fig. 2-1

### 2-2: FLAP LEVER/TAPE GUIDE R (Refer to Fig. 2-2)

1. Move the Cassette Holder Ass'y to the back side.
2. Remove the Polyslider Washer ①.
3. Remove the Flap Lever.
4. Unlock the 3 supports ② and remove the Tape Guide R.




Fig. 2-2

### 2-3: TAPE GUIDE L (Refer to Fig. 2-3-A)

1. Move the Cassette Holder Ass'y to the back side.
2. Unlock the 2 supports ① and remove the Tape Guide L.
3. Remove the REC Lever. (Recorder only)




Fig. 2-3-A

#### NOTE

When you install the Tape Guide L, install as shown in the circle of Fig. 2-3-B. (Refer to Fig. 2-3-B)




Fig. 2-3-B

### 2-4: CASSETTE HOLDER ASS'Y (Refer to Fig. 2-4)

1. Move the Cassette Holder Ass'y to the front side so that the Link Ass'y doesn't slip out.
2. Push the Locker R to remove the Cassette Side R.
3. Remove the Cassette Side L.




Fig. 2-4

### 2-5: CASSETTE SIDE L/R (Refer to Fig. 2-5)

1. Unlock the 4 supports ① and then remove the Cassette Side L/R.
2. Remove the Cassette Earth Spring.

#### NOTE

1. When you install the Cassette Side R, be sure to move the Locker R after installing.
2. After the installation of the Cassette Holder, then install the Cassette Earth Spring.




Fig. 2-5

# DISASSEMBLY INSTRUCTIONS

## 2-6: LINK UNIT (Refer to Fig. 2-6)

1. Set the Link Unit to the Eject position.
2. Remove the (A) side of the Link Unit first, then remove the (B) side.




Fig. 2-6

## 2-7: LOADING MOTOR ASS'Y (Refer to Fig. 2-7)

1. Remove the Link Lever.
2. Remove the screw ①.
3. Remove the Loading Motor Ass'y.
4. Unlock the 2 supports ② and remove the Deck PCB (BOT).




Fig. 2-7

## 2-8: SENSOR COVER L3 (Refer to Fig. 2-8)

1. Unlock the support ① and remove the Sensor Cover L3.




Fig. 2-8

## 2-9: TENSION ASS'Y (Refer to Fig. 2-9-B)

1. Move the Inclined S Ass'y to the back side.
2. Remove the Tension Spring.
3. Unlock the support ① and remove the Tension Arm Ass'y.
4. Remove the Tension Adjust.
5. Unlock the 2 supports ② and remove the Tension Band Ass'y.
6. Float the hook ③ and turn it clockwise then remove the Tension Holder.
7. Remove the SS Brake Spring.
8. Remove the SS Arm Brake.




Fig. 2-9-B

### NOTE

When you install the Tension Adjust, install as shown in Fig. 2-9-C. (Refer to Fig. 2-9-C)




Fig. 2-9-C

## 2-10: T BRAKE ASS'Y (Refer to Fig. 2-10)

1. Remove the T Brake Spring.
2. Turn the T Brake Ass'y clockwise and bend the hook section to remove it.




Fig. 2-10

# DISASSEMBLY INSTRUCTIONS

## 2-11: S REEL/T REEL (Refer to Fig. 2-11)

1. Remove the S Reel and T Reel.
2. Remove the 2 Polyslider Washers ①.

### NOTE

1. Take care not to damage the gears of the S Reel and T Reel.
2. The Polyslider Washer may be remained on the back of the reel.
3. Take care not to damage the shaft.
4. Do not touch the section "A" of S Reel and T Reel. (Use gloves.) (Refer to Fig. 2-11) Do not adhere the stains on it.
5. When you install the reel, clean the shaft and oil it. (If you do not oil, noise may be heard in FF/REW mode.)
6. After installing the reel, adjust the height of the reel. (Refer to MECHANICAL ADJUSTMENT)




Fig. 2-11

## 2-12: PINCH ROLLER BLOCK/P5-3 ARM ASS'Y (Refer to Fig. 2-12-A)

1. Remove the P5 Spring.
2. Remove the screw ①.
3. Unlock the 2 supports ② and remove the Cassette Opener.
4. Remove the Pinch Roller Block, Pinch Roller Arm Spring, Pinch Roller Lever Ass'y and P5-3 Arm Ass'y.




Fig. 2-12-A

### NOTE

1. Do not touch the Pinch Roller. (Use gloves.)
2. When you install the Pinch Roller Block, install as shown in the circle of Fig. 2-12-B. (Refer to Fig. 2-12-B)




Fig. 2-12-B

## 2-13: A/C HEAD (Refer to Fig. 2-13-A)

1. Remove the screw ①.
2. Remove the A/C Head Base.
3. Remove the 3 screws ②.
4. Remove the A/C Head and A/C Head Spring.

### NOTE

1. Do not touch the A/C Head. (Use gloves.)
2. When you install the A/C Head Spring, install as shown in Fig. 2-13-B. (Refer to Fig. 2-13-B)
3. When you install the A/C Head, tighten the screw (1) first, then tighten the screw (2), finally tighten the screw (3).




Fig. 2-13-A




Fig. 2-13-B

## 2-14: FE HEAD (RECORDER ONLY) (Refer to Fig. 2-14)

1. Remove the screw ①.
2. Remove the FE Head.




Fig. 2-14


# DISASSEMBLY INSTRUCTIONS

## 2-15: AHC ASS'Y/CYLINDER UNIT ASS'Y (Refer to Fig. 2-15)

1. Unlock the support ① and remove the AHC Ass'y.
2. Remove the 3 screws ②.
3. Remove the Cylinder Unit Ass'y.


### NOTE

When you install the Cylinder Unit Ass'y, tighten the screws from (1) to (3) in order while pulling the Ass'y toward the left front direction.




## 2-16: CAPSTAN DD UNIT (Refer to Fig. 2-16)

1. Remove the Capstan Belt.
2. Remove the 3 screws ①.
3. Remove the Capstan DD Unit.




## 2-17: MIDDLE GEAR/MAIN CAM (Refer to Fig. 2-17- A)

1. Remove the Polyslider Washer ①, then remove the Middle Gear.
2. Remove the E-Ring, then remove the Main Cam, P5 Cam, Pinch Roller Cam and Joint Gear.




### NOTE

When you install the Pinch Roller Cam, P5 Cam and Main Cam, align each marker. (Refer to Fig. 2-17- B)



## 2-18: CLUTCH ASS'Y (Refer to Fig. 2-18)


1. Remove the Capstan Brake Spring.
2. Remove the Polyslider Washer ①.
3. Remove the Clutch Ass'y, Ring Spring and Coupling Gear.
4. Unlock the 2 supports ② and remove the Clutch Lever.



# DISASSEMBLY INSTRUCTIONS


## 2-19: LOADING GEAR S/T ASS'Y (Refer to Fig. 2-19-A)

1. Remove the E-Ring ① and remove the Main Loading Gear.
2. Slide the Main Rod and remove the Spring Holder.
3. Remove the Main Rod, Tension Lever, Clutch Actuator, Idler Arm Ass'y.
4. Remove the screw ②.
5. Remove the LED Reflector.
6. Remove the Loading Arm S Ass'y and Loading Arm T Ass'y.
7. Remove the Loading Gear S and Loading Gear T.
8. Remove the Loading Gear Spring.




### NOTES

1. When you install the Loading Arm S Ass'y, Loading Arm T Ass'y and Main Loading Gear, align each marker. (Refer to Fig. 2-19-B)



2. When you install the Clutch Actuator, install as shown in the circle of Fig. 2-19-C. (Refer to Fig. 2-19-C)




## 2-20: INCLINED S/T ASS'Y (Refer to Fig. 2-20)

1. Remove the Cap P4.
2. Remove the screw ①.
3. Unlock the support ② and remove the Loading Gear Holder.
4. Remove the Inclined S Unit.
5. Remove the Inclined T Unit.

### NOTE

Do not touch the roller of Guide Roller.



# DISASSEMBLY INSTRUCTIONS

## 3. REMOVAL OF ANODE CAP

Read the following **NOTED** items before starting work.

- \* After turning the power off there might still be a potential voltage that is very dangerous. When removing the Anode Cap, make sure to discharge the Anode Cap's potential voltage.
- \* Do not use pliers to loosen or tighten the Anode Cap terminal, this may cause the spring to be damaged.

### REMOVAL

1. Follow the steps as follows to discharge the Anode Cap.  
**(Refer to Fig. 3-1.)**

Connect one end of an Alligator Clip to the metal part of a flat-blade screwdriver and the other end to ground. While holding the plastic part of the insulated Screwdriver, touch the support of the Anode with the tip of the Screwdriver. A cracking noise will be heard as the voltage is discharged.




Fig. 3-1

2. Flip up the sides of the Rubber Cap in the direction of the arrow and remove one side of the support.  
**(Refer to Fig. 3-2.)**




Fig. 3-2

3. After one side is removed, pull in the opposite direction to remove the other.

### NOTE

Take care not to damage the Rubber Cap.

### INSTALLATION

1. Clean the spot where the cap was located with a small amount of alcohol. **(Refer to Fig. 3-3.)**




Fig. 3-3

### NOTE

Confirm that there is no dirt, dust, etc. at the spot where the cap was located.

2. Arrange the wire of the Anode Cap and make sure the wire is not twisted.
3. Turn over the Rubber Cap. **(Refer to Fig. 3-4.)**




Fig. 3-4

4. Insert one end of the Anode Support into the anode button, then the other as shown in **Fig. 3-5.**




Fig. 3-5

5. Confirm that the Support is securely connected.
6. Put on the Rubber Cap without moving any parts.

## KEY TO ABBREVIATIONS

<b>A</b>	<b>A/C</b>	: Audio/Control	<b>H.SW</b>	: Head Switch	
	<b>ACC</b>	: Automatic Color Control	<b>Hz</b>	: Hertz	
	<b>AE</b>	: Audio Erase	<b>I</b>	<b>IC</b>	: Integrated Circuit
	<b>AFC</b>	: Automatic Frequency Control		<b>IF</b>	: Intermediate Frequency
	<b>AFT</b>	: Automatic Fine Tuning		<b>IND</b>	: Indicator
	<b>AFT DET</b>	: Automatic Fine Tuning Detect		<b>INV</b>	: Inverter
	<b>AGC</b>	: Automatic Gain Control	<b>K</b>	<b>KIL</b>	: Killer
	<b>AMP</b>	: Amplifier	<b>L</b>	<b>L</b>	: Left
	<b>ANT</b>	: Antenna		<b>LED</b>	: Light Emitting Diode
	<b>A.PB</b>	: Audio Playback		<b>LIMIT AMP</b>	: Limiter Amplifier
	<b>APC</b>	: Automatic Phase Control		<b>LM, LDM</b>	: Loading Motor
	<b>ASS'Y</b>	: Assembly		<b>LP</b>	: Long Play
	<b>AT</b>	: All Time		<b>L.P.F</b>	: Low Pass Filter
	<b>AUTO</b>	: Automatic		<b>LUMI.</b>	: Luminance
	<b>A/V</b>	: Audio/Video	<b>M</b>	<b>M</b>	: Motor
<b>B</b>	<b>BGP</b>	: Burst Gate Pulse		<b>MAX</b>	: Maximum
	<b>BOT</b>	: Beginning of Tape		<b>MINI</b>	: Minimum
	<b>BPF</b>	: Bandpass Filter		<b>MIX</b>	: Mixer, mixing
	<b>BRAKE SOL</b>	: Brake Solenoid		<b>MM</b>	: Monostable Multivibrator
	<b>BUFF</b>	: Buffer		<b>MOD</b>	: Modulator, Modulation
	<b>B/W</b>	: Black and White		<b>MPX</b>	: Multiplexer, Multiplex
<b>C</b>	<b>C</b>	: Capacitance, Collector		<b>MS SW</b>	: Mecha State Switch
	<b>CASE</b>	: Cassette	<b>N</b>	<b>NC</b>	: Non Connection
	<b>CAP</b>	: Capstan		<b>NR</b>	: Noise Reduction
	<b>CARR</b>	: Carrier	<b>O</b>	<b>OSC</b>	: Oscillator
	<b>CH</b>	: Channel		<b>OPE</b>	: Operation
	<b>CLK</b>	: Clock	<b>P</b>	<b>PB</b>	: Playback
	<b>CLOCK (SY-SE)</b>	: Clock (Syscon to Servo)		<b>PB CTL</b>	: Playback Control
	<b>COMB</b>	: Combination, Comb Filter		<b>PB-C</b>	: Playback-Chrominance
	<b>CONV</b>	: Converter		<b>PB-Y</b>	: Playback-Luminance
	<b>CPM</b>	: Capstan Motor		<b>PCB</b>	: Printed Circuit Board
	<b>CTL</b>	: Control		<b>P. CON</b>	: Power Control
	<b>CYL</b>	: Cylinder		<b>PD</b>	: Phase Detector
	<b>CYL-M</b>	: Cylinder-Motor		<b>PG</b>	: Pulse Generator
	<b>CYL SENS</b>	: Cylinder-Sensor		<b>P-P</b>	: Peak-to Peak
<b>D</b>	<b>DATA (SY-CE)</b>	: Data (Syscon to Servo)	<b>R</b>	<b>R</b>	: Right
	<b>dB</b>	: Decibel		<b>REC</b>	: Recording
	<b>DC</b>	: Direct Current		<b>REC-C</b>	: Recording-Chrominance
	<b>DD Unit</b>	: Direct Drive Motor Unit		<b>REC-Y</b>	: Recording-Luminance
	<b>DEMODO</b>	: Demodulator		<b>REEL BRK</b>	: Reel Brake
	<b>DET</b>	: Detector		<b>REEL S</b>	: Reel Sensor
	<b>DEV</b>	: Deviation		<b>REF</b>	: Reference
<b>E</b>	<b>E</b>	: Emitter		<b>REG</b>	: Regulated, Regulator
	<b>EF</b>	: Emitter Follower		<b>REW</b>	: Rewind
	<b>EMPH</b>	: Emphasis		<b>REV, RVS</b>	: Reverse
	<b>ENC</b>	: Encoder		<b>RF</b>	: Radio Frequency
	<b>ENV</b>	: Envelope		<b>RMC</b>	: Remote Control
	<b>EOT</b>	: End of Tape		<b>RY</b>	: Relay
	<b>EQ</b>	: Equalizer	<b>S</b>	<b>S. CLK</b>	: Serial Clock
	<b>EXT</b>	: External		<b>S. COM</b>	: Sensor Common
<b>F</b>	<b>F</b>	: Fuse		<b>S. DATA</b>	: Serial Data
	<b>FBC</b>	: Feed Back Clamp		<b>SEG</b>	: Segment
	<b>FE</b>	: Full Erase		<b>SEL</b>	: Select, Selector
	<b>FF</b>	: Fast Forward, Flipflop		<b>SENS</b>	: Sensor
	<b>FG</b>	: Frequency Generator		<b>SER</b>	: Search Mode
	<b>FL SW</b>	: Front Loading Switch		<b>SI</b>	: Serial Input
	<b>FM</b>	: Frequency Modulation		<b>SIF</b>	: Sound Intermediate Frequency
	<b>FSC</b>	: Frequency Sub Carrier		<b>SO</b>	: Serial Output
	<b>FWD</b>	: Forward		<b>SOL</b>	: Solenoid
<b>G</b>	<b>GEN</b>	: Generator		<b>SP</b>	: Standard Play
	<b>GND</b>	: Ground		<b>STB</b>	: Serial Strobe
<b>H</b>	<b>H.P.F</b>	: High Pass Filter		<b>SW</b>	: Switch



## KEY TO ABBREVIATIONS

<b>S</b>	<b>SYNC</b>	:	Synchronization
	<b>SYNC SEP</b>	:	Sync Separator, Separation
<b>T</b>	<b>TR</b>	:	Transistor
	<b>TRAC</b>	:	Tracking
	<b>TRICK PB</b>	:	Trick Playback
	<b>TP</b>	:	Test Point
<b>U</b>	<b>UNREG</b>	:	Unregulated
<b>V</b>	<b>V</b>	:	Volt
	<b>VCO</b>	:	Voltage Controlled Oscillator
	<b>VIF</b>	:	Video Intermediate Frequency
	<b>VP</b>	:	Vertical Pulse, Voltage Display
	<b>V.PB</b>	:	Video Playback
	<b>VR</b>	:	Variable Resistor
	<b>V.REC</b>	:	Video Recording
	<b>VSF</b>	:	Visual Search Fast Forward
	<b>VSR</b>	:	Visual Search Rewind
	<b>VSS</b>	:	Voltage Super Source
	<b>V-SYNC</b>	:	Vertical-Synchronization
	<b>VT</b>	:	Voltage Tuning
<b>X</b>	<b>X'TAL</b>	:	Crystal
<b>Y</b>	<b>Y/C</b>	:	Luminance/Chrominance

## SERVICE MODE LIST

This unit provided with the following SERVICE MODES so you can repair, examine and adjust easily.

To enter SERVICE MODE, unplug AC cord till lost actual clock time. Then press and hold Vol (-) button of main unit and remocon key simultaneously.

The both pressing of set key and remote control key will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 5 seconds before Power On.

Set Key	Remocon Key	Operations
VOL. (-) MIN	0	Releasing of V-CHIP PASSWORD.
VOL. (-) MIN	1	Initialization of the factory. NOTE: Do not use this for the normal servicing.
VOL. (-) MIN	2	Horizontal position adjustment of OSD. NOTE: Also can be adjusted by using the Adjustment MENU. Refer to the "ELECTRICAL ADJUSTMENT" (OSD HORIZONTAL).
VOL. (-) MIN	3	Adjust the PG SHIFTER automatically. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	4	Adjust the PG SHIFTER manually. Refer to the "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
VOL. (-) MIN	5	Adjusting of the Tracking to the center position. NOTE: Also can be adjusted by pressing the ATR button for more than 2 seconds during PLAY.
VOL. (-) MIN	6	POWER ON total hours and PLAY/REC total hours are displayed on the screen. Refer to the "PREVENTIVE CHECKS AND SERVICE INTERVALS" (CONFIRMATION OF USING HOURS).  Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "NOTE FOR THE REPLACING OF MEMORY IC".
VOL. (-) MIN	8	Writing of EEPROM initial data. NOTE: Do not use this for the normal servicing.
VOL. (-) MIN	9	Display of the Adjustment MENU on the screen. Refer to the "ELECTRICAL ADJUSTMENT" (On-Screen Display Adjustment).

Method	Operations
Press the ATR button on the remote control for more than 2 seconds during PLAY.	Adjusting of the Tracking to the center position. Refer to the "MECHANICAL ADJUSTMENT" (GUIDE ROLLER) and "ELECTRICAL ADJUSTMENT" (PG SHIFTER).
Make the short circuit between the test point of SERVICE and the GND.	The EOT/BOT/Reel sensor do not work at this moment. Refer to the "PREPARATION FOR SERVICING"

## PREVENTIVE CHECKS AND SERVICE INTERVALS

The following standard table depends on environmental conditions and usage. Unless maintenance is properly carried out, the following service intervals may be quite shortened as harmful effects may be had on other parts. Also, long term storage or misuse may cause transformation and aging of rubber parts.

Time Parts Name	500 hours	1,000 hours	1,500 hours	2,000 hours	3,000 hours	Notes
Audio Control Head	■	■	■	■	■	Clean those parts in contact with the tape.
Full Erase Head (Recorder only)	■	■	■	■	■	
Capstan Belt			■	■	●	Clean the rubber, and parts which the rubber touches.
Pinch Roller	■	■	■	■	■ ●	
Capstan DD Unit					●	
Loading Motor					●	
Tension Band					●	
Capstan Shaft	■	■	■	■	■	
Tape Running Guide Post	■	■	■	■	■	Replace when rolling becomes abnormal.
Cylinder Unit	■	■	■	■	●	Clean the Head


- : Clean
- : Replace

### CONFIRMATION OF USING HOURS

POWER ON total hours and PLAY/REC total hours can be checked on the screen. Total hours are displayed in 16 system of notation.

**NOTE: The confirmation of using hours will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 5 seconds before Power On.**

1. Set the VOLUME to minimum.
2. While holding down VOLUME button on front cabinet, press key 6 on remote control simultaneously.
3. After the confirmation of using hours, turn off the power.



(16 x 16 x 16 x thousands digit value) + (16 x 16 x hundreds digit value) + (16 x tens digit value) + (ones digit value)

# PREVENTIVE CHECKS AND SERVICE INTERVALS


## CLEANING

### NOTE

After cleaning the heads with isopropyl alcohol, do not run a tape until the heads dry completely. If the heads are not completely dry and alcohol gets on the tape, damage may occur.

### 1. AUDIO CONTROL HEAD

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol and clean the audio control head by wiping it horizontally. Clean the full erase head in the same manner. **(Refer to the figure below.)**



### 2. TAPE RUNNING SYSTEM


When cleaning the tape transport system, use the gauze moistened with isopropyl alcohol.

### 3. CYLINDER

Wrap a piece of chamois around your finger. Dip it in isopropyl alcohol. Hold it to the cylinder head softly. Turn the cylinder head counterclockwise to clean it (in the direction of the arrow). **(Refer to the figure below.)**

### NOTE

Do not exert force against the cylinder head. Do not move the chamois upward or downward on the head. Use the chamois one by one.



## NOTE FOR THE REPLACING OF MEMORY IC


If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

**NOTE: Initial Data setting will not be possible if clock has been set. To reset clock, either unplug AC cord and allow at least 5 seconds before Power On.**

INI	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
00	88	1B	C2	63	43	14	34	09	51	38	10	96	19	00	00	21
10	B2	9A	92	93	00	00	00	15	08	00	A9	0F	04	3E	06	04
20	06	29	01	15	10	60	32	3A	DA	D7	10	15	20	25	26	27
30	28	29	2A	2C	2E	30	32	34	36	38	3A	3C	3E	40	41	42
40	43	44	45	46	47	48	49	4A	4B	4C	4D	4E	4F	50	51	52
50	53	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F	60	61	62
60	63	64	66	69	6D	74	79	7C	7E	7F	---	---	---	---	---	---

**Table 1**











1. Enter DATA SET mode by setting VOLUME to minimum.
2. While holding down VOLUME button on front cabinet, press key 6 on remote control simultaneously. ADDRESS and DATA should appear as FIG 1.



**Fig. 1**

3. ADDRESS is now selected and should "blink". Using the PLAY or STOP button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
4. Press ENTER to select DATA. When DATA is selected, it will "blink".
5. Again, step through the DATA using PLAY or STOP until required DATA value has been selected.
6. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
7. Repeat steps 3 to 6 until all data has been checked.
8. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input. The unit will now have the correct DATA for the new MEMORY IC.

## SERVICING FIXTURES AND TOOLS

<p><b>(For 2 heads model)</b>  VHS Alignment Tape  JG001 (VN<sub>2</sub>S-LI6<sup>3</sup>)  JG001A (VN<sub>2</sub>S-CO1<sup>3</sup>)  JG001Q (VN<sub>2</sub>S-LI6<sup>3</sup>H)  JG001T (VN<sub>2</sub>S-X6<sup>3</sup>)</p> 	<p><b>(For 4 heads model)</b>  VHS Alignment Tape  JG001B (VN<sub>1</sub>S-LI6<sup>3</sup>)  JG001I (VN<sub>1</sub>S-CO1<sup>3</sup>)  JG001P (VN<sub>1</sub>S-LI6<sup>3</sup>H)  JG001S (VN<sub>1</sub>S-X6<sup>3</sup>)</p> 	<p>JG002B Adapter  JG002E Dial Torque Gauge  (10~90gf•cm)  JG002F (60~600gf•cm)</p> 	<p>JG005 Post Adjustment  Screwdriver  Part No. SV-TG0-030-000  <small>(small)</small></p> 
<p>JG153 X Value Adjustment  Screwdriver</p> 	<p>JG022 Master Plane</p> 	<p>JG024A Reel Disk Height  Adjustment Jig</p> 	<p>JG100A Torque Tape  (VHT-063)</p> 
<p>JG154 Cable</p> 	<p>Tentelometer</p> 		

Ref. No.	Part No.	Remarks
JG001	APJG001000	Monoscope, 6KHz <b>(For 2 heads model)</b>
JG001A	APJG001A00	Color Bar, 1KHz <b>(For 2 heads model)</b>
JG001Q	APJG001Q00	Hi-Fi Audio <b>(For 2 heads Hi-Fi model)</b>
JG001T	APJG001T00	X Value Adjustment <b>(For 2 heads model)</b>
JG001B	APJG001B00	Monoscope, 6KHz <b>(For 4 heads model)</b>
JG001I	APJG001I00	Color Bar, 1KHz <b>(For 4 heads model)</b>
JG001P	APJG001P00	Hi-Fi Audio <b>(For 4 heads Hi-Fi model)</b>
JG001S	APJG001S00	X Value Adjustment <b>(For 4 heads model)</b>
JG002B	APJG002B00	VSR Torque, Brake Torque (S Reel/T Reel Ass'y)
JG002E	APJG002E00	Brake Torque (T Reel Ass'y)
JG002F	APJG002F00	VSR Torque, Brake Torque (S Reel)
JG005	APJG005000	Guide Roller Adjustment
JG153	APJG153000	X Value Adjustment
JG022/JG024A	APJG022000/APJG024A00	Reel Disk Height Adjustment
JG100A	APJG100A00	Playback Torque, Back Tension Torque During Playback
JG154	APJG154000	Used to connect the test point of SERVICE and GROUND

## PREPARATION FOR SERVICING

### How to use the Servicing Fixture

1. Unplug the connector CP757 and CP353, then remove the TV/VCR Block from the set.
2. Remove the Operation PCB from the set, then connect it with the Syscon PCB.  
If necessary, connect CP353. (Front A/V Jack Input Terminal)
3. Short circuit between **TP1001** and **Ground** with the cable JG154.  
**(Refer to MAJOR COMPONENTS LOCATION GUIDE)**
4. The EOT, BOT and Reel Sensor do not work at this moment.  
At that time, the STOP/EJECT button is available to insert and eject the Cassette Tape.

# MECHANICAL ADJUSTMENTS



## 1. CONFIRMATION AND ADJUSTMENT

Read the following NOTES before starting work.

- Place an object which weighs between 450g~500g on the Cassette Tape to keep it steady when you want to make the tape run without the Cassette Holder. (Do not place an object which weighs over 500g.)
- When you activate the deck without the Cassette Holder, short circuit between **TP1001** and **GND**. (Refer to **ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE**) In this condition the BOT/EOT/Reel Sensor will not function.



### 1-1: CONFIRMATION AND ADJUSTMENT OF REEL DISK HEIGHT

1. Turn on the power and set to the STOP mode.
2. Set the master plane (**JG022**) and reel disk height adjustment jig (**JG024A**) on the mechanism framework, taking care not to scratch the drum, as shown in **Fig. 1-1-A**.
3. Confirm that "A" of the reel disk is lower than "B" of the reel disk height adjustment jig (**JG024A**), and is higher than "C". If it is not enough height, adjust to  $10(+0.2, -0)$  mm with the height adjustment washer.
4. Adjust the other reel in the same way.



### 1-2: CONFIRMATION AND ADJUSTMENT OF TENSION POST POSITION

1. Set to the PLAY mode.
2. Adjust the Tension Adjust until the edge of the Tension Arm is positioning within 0.5mm range from the standard line center of Main Chassis. After this adjustment, confirm that the cut position is located in "A" area as shown in **Fig. 1-2-B**. If it is located in "B" area, adjust again.
3. While turning the S Reel clockwise, confirm that the edge of the Tension Arm is located in the position described above.




### 1-3: CONFIRMATION OF PLAYBACK TORQUE AND BACK TENSION TORQUE DURING PLAYBACK

1. Load a video tape (T-120) recorded in standard speed mode. Set the unit to the PLAY mode.
2. Install the tentelometer as shown in **Fig. 1-3**. Confirm that the meter indicates  $20 \pm 2$ gf in the beginning of playback.

#### • USING A CASSETTE TYPE TORQUE TAPE (**JG100A**)

1. After confirmation and adjustment of Tension Post position (Refer to item 1-2), load the cassette type torque tape (**JG100A**) and set to the PLAY mode.
2. Confirm that the right meter of the torque tape indicates  $60 \sim 110$ gf•cm during playback in SP mode.
3. Confirm that the left meter of the torque tape indicates  $25 \sim 40$ gf•cm during playback in SP mode.



## MECHANICAL ADJUSTMENTS

### 1-4: CONFIRMATION OF VSR TORQUE

1. Operate within 4~5 seconds after the reel disk begins to turn.
2. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Set to the Rewind mode. (Refer to Fig.1-4)
3. Then, confirm that it indicates 120~180gf•cm.

#### NOTE

Install the Torque Gauge on the reel disk firmly. Press the REW button to turn the reel disk.


### 1-5: CONFIRMATION OF REEL BRAKE TORQUE

(S Reel Brake) (Refer to Fig. 1-4)

1. Set to the STOP mode.
2. Move the Idler Ass'y from the S Reel.
3. Install the Torque Gauge (JG002F) and Adapter (JG002B) on the S Reel. Turn the Torque Gauge (JG002F) clockwise.
4. Then, confirm that it indicates 60~100gf•cm.

(T Reel Brake) (Refer to Fig. 1-4)

1. Set to the STOP mode.
2. Move the Idler Ass'y from the T Reel.
3. Install the Torque Gauge (JG002E) and Adapter (JG002B) on the T reel. Turn the Torque Gauge (JG002E) counterclockwise.
4. Then, confirm that it indicates 45~70gf•cm.



#### NOTE

If the torque is out of the range, replace the following parts.

Check item	Replacement Part
1-4	Idler Ass'y/Clutch Ass'y
1-5	T Brake Spring/Tension Spring

## 2. CONFIRMATION AND ADJUSTMENT OF TAPE RUNNING MECHANISM



Tape Running Mechanism is adjusted precisely at the factory. Adjustment is not necessary as usual. When you replace the parts of the tape running mechanism because of long term usage or failure, the confirmation and adjustment are necessary.

### 2-1: GUIDE ROLLER

1. Playback the VHS Alignment Tape (JG001 or JG001B). (Refer to SERVICING FIXTURE AND TOOLS)
2. Connect CH-1 of the oscilloscope to TP4001 (Envelope) and CH-2 to TP1002 (SW Pulse).
3. Press and hold the Tracking-Auto button on the remote control for more than 2 seconds to set tracking to center.
4. Trigger with SW Pulse and observe the envelope. (Refer to Fig. 2-1-A)
5. When observing the envelope, adjust the Adjusting Driver (JG005) slightly until the envelope will be flat. Even if you press the Tracking Button, adjust so that flatness is not moved so much.
6. Adjust so that the A : B ratio is better than 3 : 2 as shown in Fig. 2-1-B, even if you press the Tracking Button to move the envelope (The envelope waveform will begin to decrease when you press the Tracking Button).
7. Adjust the PG shifter during playback. (Refer to the ELECTRICAL ADJUSTMENTS)

#### NOTE

After adjustment, confirm and adjust A/C head. (Refer to item 2-2)








## MECHANICAL ADJUSTMENTS

### 2-2: CONFIRMATION AND ADJUSTMENT OF AUDIO/ CONTROL HEAD

When the Tape Running Mechanism does not work well, adjust the following items.

1. Playback the VHS Alignment Tape (**JG001 or JG001B**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
2. Confirm that the reflected picture of stamp mark is appeared on the tape prior to P4 Post as shown in **Fig. 2-2-A**.
  - a) When the reflected picture is distorted, turn the screw ① clockwise until the distortion is disappeared.
  - b) When the reflected picture is not distorted, turn the screw ① counterclockwise until little distortion is appeared, then adjust the a).
3. Turn the screw ② to set the audio level to maximum.
4. Confirm that the bottom of the Audio/ Control Head and the bottom of the tape is shown in **Fig. 2-2-C**.
  - c) When the height is not correct, turn the screw ③ to adjust the height. Then, adjust the 1~3 again.



### 2-3: TAPE RUNNING ADJUSTMENT (X VALUE ADJUSTMENT)


1. Confirm and adjust the height of the Reel Disk.  
(Refer to **item 1-1**)
2. Confirm and adjust the position of the Tension Post.  
(Refer to **item 1-2**)
3. Adjust the Guide Roller. (Refer to **item 2-1**)
4. Confirm and adjust the Audio/Control Head.  
(Refer to **item 2-2**)
5. Connect CH-1 of the oscilloscope to **TP4001**, CH-2 to **TP1002** and CH-3 to **HOT side of Audio Out Jack**.
6. Playback the VHS Alignment Tape (**JG001S or JG001T**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
7. Press and hold the Tracking-Auto button on the remote control for more than 2 seconds to set tracking to center.
8. Set the X Value adjustment driver (**JG153**) to the ④ of **Fig. 2-2-B**. Adjust X value so that the envelope waveform output becomes maximum. Check if the relation between Audio and Envelope waveform becomes (1) or (2) of **Fig. 2-1-A**.

### 2-4: CONFIRM HI-FI AUDIO (Hi-Fi model only)

1. Connect CH-1 of the oscilloscope to **TP4001**, CH-2 to **TP1002** and CH-3 to the **Hi-Fi Audio Out Jack**.
2. Playback the VHS Alignment Tape (**JG001P or JG001Q**).  
(Refer to **SERVICING FIXTURE AND TOOLS**)
3. Press and hold the Tracking-Auto button on the remote control for more than 2 seconds to set tracking to center.
4. Press the Tracking Up button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
5. Press the Tracking Down button and count number of steps which the audio output is changed from Hi-Fi (10KHz) to MONO (6KHz).
6. Confirm that the difference between these counted steps number in the above items are within 2 steps. If the difference are more than 3 steps, do Tape Running Adjustment again. (Refer to **item 2-3**)

# MECHANICAL ADJUSTMENTS

## 3. MECHANISM ADJUSTMENT PARTS LOCATION GUIDE



- |                       |                                   |
|-----------------------|-----------------------------------|
| 1. Tension Adjust     | 6. X value adjustment driver hole |
| 2. Tension Arm        | 7. P4 Post                        |
| 3. Guide Roller       | 8. T Brake Spring                 |
| 4. P1 Post            | 9. T Reel                         |
| 5. Audio/Control Head | 10. S Reel                        |

# ELECTRICAL ADJUSTMENTS

## 1. BEFORE MAKING ELECTRICAL ADJUSTMENTS

Read and perform these adjustments when repairing the circuits or replacing electrical parts or PCB assemblies.

### CAUTION

- Use an isolation transformer when performing any service on this chassis.
- Before removing the anode cap, discharge electricity because it contains high voltage.
- When removing a PCB or related component, after unfastening or changing a wire, be sure to put the wire back in its original position.  
Inferior silicon grease can damage IC's and transistors.
- When replacing IC's and transistors, use only specified silicon grease (YG6260M).  
Remove all old silicon before applying new silicon.

### On-Screen Display Adjustment

1. Unplug the AC plug for more than 5 seconds to set the clock to the non-setting state. Then, set the volume level to minimum.
2. Press the VOL. DOWN button on the set and the Channel button (9) on the remote control simultaneously to appear the adjustment mode on the screen as shown in Fig. 1-1.




Fig. 1-1

3. Use the Channel UP/DOWN button or Channel button (0-9) on the remote control to select the options shown in Fig. 1-2.
4. Press the MENU button on the remote control to end the adjustments.

NO.	FUNCTION	NO.	FUNCTION
00	OSD H	13	BRIGHTNESS
01	CUT OFF	14	CONTRAST
02	RF DELAY	15	COLOR
03	VIF VCO	16	TINT
04	H VCO	17	SHARPNESS
05	H PHASE	18	FM LEVEL
06	V SIZE	19	LEVEL
07	V SHIFT	20	SEPARATION 1
08	R DRIVE	21	SEPARATION 2
09	B DRIVE	22	TEST MONO
10	R CUT OFF	23	TEST STEREO
11	G CUT OFF	24	X-RAY TEST
12	B CUT OFF		

Fig. 1-2

## 2. BASIC ADJUSTMENTS (VCR SECTION)

### 2-1: PG SHIFTER

1. Connect CH-1 on the oscilloscope to TP1002 and CH-2 to pin 4 of CP1003.
2. Playback the alignment tape. (JG001A)
3. Press and hold the Tracking-Auto button on the remote control more than 2 seconds to set tracking to center.
4. Press the VOL. DOWN button on the set and the channel button (3) on the remote control simultaneously until the indicator REC disappears. If the indicator REC disappears, adjustment is completed.

(If the above adjustments doesn't work well:)

5. Press the VOL. DOWN button on the set and the channel button (3) on the remote control simultaneously until the indicator REC disappears.
6. When the REC indicator is blinking, press both VOL. DOWN button on the set and the channel button (4) on the remote control simultaneously and adjust the Tracking +/- button until the arising to the down of Head Switching Pulse becomes  $6.5 \pm 0.5H$ .  
(Refer to Fig. 2-1-A, B)
7. Press the Tracking Auto button.




Fig. 2-1-A




Fig. 2-1-B

### 2-2: VCO FREERUN

1. Place the set with Aging Test for more than 10 minutes.
2. Receive the VHF HIGH.
3. Disconnect the Antenna while receiving the VHF HIGH and set to the Noise screen.
4. Once turn off the Power and turn on the Power again.
5. Approx. 3 seconds later, input the Antenna again.
6. Connect the digital voltmeter between the pin 5 of CP351 and the pin 1 (GND) of CP351.
7. Activate the adjustment mode display of Fig. 1-1 and press the channel button (03) on the remote control to select "VIF VCO".
8. Press the VOL. UP/DOWN button on the remote control until the digital voltmeter is 2.5V.
9. After the 2.5V adjustment, countdown the VIF VCO step No. by 1 step with the VOL. DOWN button.

# ELECTRICAL ADJUSTMENTS

## 2-3: RF AGC

1. Receive the VHF HIGH (63dB).
2. Connect the digital voltmeter between the **pin 5 of CP351** and the **pin 1 (GND) of CP351**.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(02)** on the remote control to select "RF DELAY".
4. Press the VOL. UP/DOWN button on the remote control until the digital voltmeter is 2.9V.

## (TV SECTION)

### 2-4: CONSTANT VOLTAGE

1. Connect the digital voltmeter to the **TP601**.
2. Set condition is AV MODE without signal.
3. Using the remote control, set the brightness and contrast to normal position.
4. Adjust the **VR502** until the digital voltmeter is  $135 \pm 0.5V$ .

### 2-5: CUT OFF

1. Adjust the unit to the following settings.  
R CUT OFF=128, G CUT OFF=128, B CUT OFF=128,  
BRIGHTNESS=128, CONTRAST=100
2. Place the set with Aging Test for more than 15 minutes.
3. Set condition is AV MODE without signal.
4. Using the remote control, set the brightness and contrast to normal position.
5. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(01)** on the remote control to select "CUT OFF".
6. Adjust the **Screen Volume** until a dim raster is obtained.

### 2-6: WHITE BALANCE

**NOTE:** Adjust after performing CUT OFF adjustment.

1. Place the set with Aging Test for more than 15 minutes.
2. Receive the color bar pattern.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(10)** on the remote control to select "R CUT OFF".
5. Using the VOL. UP/DOWN button on the remote control, adjust the R CUT OFF.
6. Press the CH. UP/DOWN button on the remote control to select the "R DRIVE", "B DRIVE", "G CUT OFF" or "B CUT OFF".
7. Using the VOL. UP/DOWN button on the remote control, adjust the R DRIVE, B DRIVE, G CUT OFF or B CUT OFF.
8. Perform the above adjustments 6 and 7 until the white color is looked like a white.

### 2-7: FOCUS

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Turn the Focus Volume fully counterclockwise once.
4. Adjust the **Focus Volume** until picture is distinct.

### 2-8: HORIZONTAL PHASE

1. Receive the center cross signal from the Pattern Generator.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(05)** on the remote control to select "H PHASE".
4. Press the VOL. UP/DOWN button on the remote control until the right and left screen size of the vertical line becomes the same.

### 2-9: VERTICAL SHIFT

1. Receive the center cross signal from the Pattern Generator.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(07)** on the remote control to select "V SHIFT".
4. Press the VOL. UP/DOWN button on the remote control until the horizontal line becomes fit to the notch of the shadow mask.

### 2-10: VERTICAL SIZE

1. Receive the cross hatch signal from the Pattern Generator.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(06)** on the remote control to select "V SIZE".
4. Press the VOL. UP/DOWN button on the remote control until the rectangle on the center of the screen becomes square.
5. Receive a broadcast and check if the picture is normal.

### 2-11: SUB BRIGHTNESS

1. Receive the monoscope pattern. (RF Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(13)** on the remote control to select "BRIGHTNESS".
4. Press the VOL. UP/DOWN button on the remote control until the white 10% is starting to be visible
5. Receive the monoscope pattern. (Audio Video Input)
6. Press the INPUT SELECT button on the remote control to set to the AV mode. Then perform the above adjustments 2-4.

### 2-12: SUB CONTRAST

1. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(14)** on the remote control to select "CONTRAST".
2. Press the VOL. UP/DOWN button on the remote control until the contrast step No. becomes "100"
3. Press the INPUT SELECT button on the remote control to set to the AV mode.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(14)** on the remote control.
5. Press the VOL. UP/DOWN button on the remote control until the contrast step No. becomes "100"

## ELECTRICAL ADJUSTMENTS

### 2-13: SUB TINT

1. Receive the color bar pattern. (RF Input)
2. Connect the oscilloscope to **TP801**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (**16**) on the remote control to select "TINT".
5. Press the VOL. UP/DOWN button on the remote control until the section "A" becomes a straight line. **(Refer to Fig. 2-2.)**
6. Receive the color bar pattern. (Audio Video Input)
7. Press the INPUT SELECT button on the remote control to set to the AV mode. Then perform the above adjustments 2~5.




Fig. 2-2

### 2-14: SUB COLOR

1. Receive the color bar pattern. (RF Input)
2. Connect the oscilloscope to **TP803**.
3. Using the remote control, set the brightness, contrast, color and tint to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (**15**) on the remote control to select "COLOR".
5. Adjust the VOLTS RANGE VARIABLE knob of the oscilloscope until the range between white 100% and 0% is set to 4 scales on the screen of the oscilloscope.
6. Press the VOL. UP/DOWN button on the remote control until the red color level is adjusted to 110% of the white level. **(Refer to Fig. 2-3)**
7. Receive the color bar pattern. (Audio Video Input)
8. Press the INPUT SELECT button on the remote control to set to the AV mode. Then perform the above adjustments 2~6.




Fig. 2-3

### 2-15: OSD HORIZONTAL

1. Activate the adjustment mode display of **Fig. 1-1**.
2. Press the VOL. UP/DOWN button on the remote control until the difference of A and B becomes minimum. **(Refer to Fig. 2-4)**





Fig. 2-4


# ELECTRICAL ADJUSTMENTS

## 3. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE



FOCUS VOLUME  
SCREEN VOLUME

SYSCON



CRT

# ELECTRICAL ADJUSTMENTS

## 4. PURITY AND CONVERGENCE ADJUSTMENTS

### NOTE

1. Turn the unit on and let it warm up for at least 30 minutes before performing the following adjustments.
2. Place the CRT surface facing east or west to reduce the terrestrial magnetism.
3. Turn ON the unit and demagnetize with a Degauss Coil.

### 4-1: STATIC CONVERGENCE (ROUGH ADJUSTMENT)

1. Tighten the screw for the magnet. Refer to the adjusted CRT for the position. **(Refer to Fig. 4-1)**  
If the deflection yoke and magnet are in one body, untighten the screw for the body.
2. Receive the green raster pattern from the color bar generator.
3. Slide the deflection yoke until it touches the funnel side of the CRT.
4. Adjust center of screen to green, with red and blue on the sides, using the pair of purity magnets.
5. Switch the color bar generator from the green raster pattern to the crosshatch pattern.
6. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
7. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.
8. Adjust the crosshatch pattern to change to white by repeating steps 6 and 7.

### 4-2: PURITY

### NOTE

Adjust after performing adjustments in section 4-1.

1. Receive the green raster pattern from color bar generator.
2. Adjust the pair of purity magnets to center the color on the screen.  
Adjust the pair of purity magnets so the color at the ends are equally wide.
3. Move the deflection yoke backward (to neck side) slowly, and stop it at the position when the whole screen is green.
4. Confirm red and blue colors.
5. Adjust the slant of the deflection yoke while watching the screen, then tighten the fixing screw.




Fig. 4-1

### 4-3: STATIC CONVERGENCE

### NOTE

Adjust after performing adjustments in section 4-2.


1. Receive the crosshatch pattern from the color bar generator.
2. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
3. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.

### 4-4: DYNAMIC CONVERGENCE

### NOTE


Adjust after performing adjustments in section 4-3.

1. Adjust the differences around the screen by moving the deflection yoke upward/downward and right/left. **(Refer to Fig. 4-2-a)**
2. Insert three wedges between the deflection yoke and CRT funnel to fix the deflection yoke. **(Refer to Fig. 4-2-b)**



UPWARD/DOWNWARD SLANT RIGHT/LEFT SLANT

Fig. 4-2-a



WEDGE POSITION

Fig. 4-2-b



**MVT2197 Serie A**

# **SERVICE MANUAL**

**COLOR TELEVISION/VIDEO CASSETTE RECORDER**

**REVISION 1  
MFR'S VERSION C**



MFR'S VERSION	CRT
B	A48LGS30X19N45
C	A48AGY13X77

Please file the revision with the original version.

---



# Change of CRT

## ELECTRICAL REPLACEMENT PARTS LIST

REF. NO.	MFR'S VERSION B		MFR'S VERSION C	
	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
⚠ V801	098Y200480	CRT W/DY A48LGS30X19N45	098Q200481	CRT W/DY A48AGY13X77
⚠ R450	R6558A3R3J	R,FUSE 3.3 OHM 2W	R6558A2R2J	R,FUSE 2.2 OHM 2W
⚠ C424	P4N8FJ562H	CMPP 0.0056UF 1.25KV	P4N8FJ682H	CMPP 0.0068UF 1.25KV
C425	C03L0R713K	CC 0.001 UF 2KV R	C03L0R7E3K	CC 0.0015UF 2KV R
PCB010	A5A403C010	SYSCON PCB ASS'Y (VERSION B) VMA227A	A5A403A010	SYSCON PCB ASS'Y (VERSION C) VMA227A
C809	CS0RB04S2K	CC 560 PF 50V B	CS0KB04Q2K	CC 470 PF 50V B
C810	CS0RB04N2K	CC 390 PF 50V B	CS0RB04Q2K	CC 470 PF 50V B
C811	CS0RB04N2K	CC 390 PF 50V B	CS0KB04Q2K	CC 470 PF 50V B
⚠ J801	066X120014	SOCKET,CRT HPS3200-010501	066C130015	SOCKET,CRT CVT3275-5102
PCB110	A5A403CA110	CRT PCB ASS'Y (VERSION B) TCA377A	A5A402A110	CRT PCB ASS'Y (VERSION C) TCA377A

SYSCON PCB's and CRT PCB's are not interchangeable.

SPEC.NO.	M5A4-03A
O/R NO.	W215017