

## For Your Safety

# Nikon

## COOLPIX 990



This document contains important safety information. Read this document in its entirety before using your COOLPIX 990 or the software provided with your camera.

Should you notice smoke or an unusual smell coming from the equipment or from the AC adapter (available separately), unplug the AC adapter and remove the batteries immediately, taking care to avoid burns. Continued operation could result in injury. After removing the batteries, take the equipment to a Nikon-authorized service center for inspection.

**⚠ Do not use in the presence of flammable gas**  
Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.

**⚠ Do not place camera strap around neck**  
Placing the camera strap around your neck could result in strangulation. Special care should be taken to avoid placing the strap around the neck of an infant or child.

**⚠ Do not disassemble**  
Touching the product's internal parts could result in injury. In the event of a malfunction, the product should be repaired only by a qualified technician. Should the product break open as the result of a fall or other accident, remove the batteries and/or AC adapter and then take the product to a Nikon-authorized service center for inspection.

### Warnings and Cautions

The symbols listed below are used in this guide and in other documentation to indicate warnings and cautions that should be read before use.

#### ⚠ Warning

This symbol is used to mark warnings that should be read before use to prevent possible injury.

#### ✔ Caution

This symbol indicates where caution should be exercised to avoid damaging your Nikon product.

### Safety Precautions

To prevent injury, observe the following safety precautions when using your Nikon product.

#### ⚠ Do not look at the sun through the viewfinder

Viewing the sun or other strong light source through the viewfinder could cause permanent visual impairment.

#### ⚠ Turn off immediately in the event of malfunction

#### ⚠ Observe proper precautions when handling batteries

Batteries may leak or explode if improperly handled. Observe the following precautions when handling batteries for use in this product:

- Be sure the product is off before replacing the batteries. If you are using the AC adapter, be sure it is unplugged.
- Use only 1.5V AA (LR6) batteries. The battery indicator has been designed to report the condition of alkaline batteries. Optimum camera performance is however obtained with lithium ion or nickel metal-hydrate batteries. Because of their short life-span, the use of manganese batteries is not recommended. Using other types of battery could cause fire.
- When inserting batteries, align their positive (+) and negative (-) poles as shown in the label at the entry to the battery chamber.
- When replacing the main batteries, replace all batteries at the same time using only one type of battery. Do not mix batteries of different types or use old batteries together with new.
- Do not short-circuit or disassemble the batteries. Do not attempt to recharge non-rechargeable batteries.
- Do not expose the batteries to flame or to excessive heat or moisture.
- Batteries are prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the batteries when no charge remains.
- When the product is used continuously for a long time on battery power, the batteries may become hot. Due caution should be observed when removing the batteries.

#### ⚠ Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

#### ⚠ Keep out of reach of children

Particular care should be taken to prevent infants from putting batteries or other small parts into their mouths.

#### ⚠ Do not walk while looking through viewfinder

Walking while looking through the camera's viewfinder or color LCD monitor could result in a fall or other injury.

#### ⚠ Removing memory cards

Memory cards may become hot during use. Observe due caution when removing memory cards from the camera.

#### ⚠ CD-ROMs

The CD-ROMs on which the software and manuals are distributed should not be played back on audio CD equipment. Playing CD-ROMs on an audio CD player could cause hearing loss or damage the equipment.

#### ⚠ Observe caution when operating the flash

Using the flash close to your subject's eyes could cause temporary visual impairment.

#### ⚠ Do not put fingers or clothing into the camera hinge

Your camera features a hinged body which allows the lens and viewfinder to rotate 270°. Be careful not to catch your fingers, hair, or clothing in the hinge.

#### ⚠ When using the viewfinder

When operating the mode dial with your eye to the viewfinder, care should be taken not to put your finger in your eye accidentally.

### Cautions

Observe the following precautions to ensure that you continue to get the most from your Nikon product.

- ✔ **Keep dry**  
This product is not waterproof, and may malfunction if immersed in water or exposed to high levels of humidity.
- ✔ **Keep free of salt, sand, and dust**  
After using your camera at the beach or seaside, wipe off any sand or salt with a lightly dampened cloth and then dry your camera thoroughly.
- ✔ **Do not touch the lens with your fingers**  
The proper procedure for cleaning the lens is described in the COOLPIX 990 Reference Manual.
- ✔ **Handle the lens and all moving parts with care**  
Do not apply force to the lens or to the battery, card, or connector covers. These parts are especially susceptible to damage.
- ✔ **Do not unplug the product or remove batteries while the product is on**  
Do not unplug the product or remove the batteries while the camera is on, or while images are being recorded or deleted from memory. Forcibly cutting power to the product in these circumstances could result in loss of data or in damage to the internal circuitry or memory. To prevent an accidental interruption of power, avoid carrying the product from one location to another while the AC adapter is connected.
- ✔ **Do not drop**  
The product may malfunction if subjected to strong shocks or vibration. When carrying the device, attach the strap as shown at right and keep it around your wrist.



- ✔ **Keep away from strong magnetic fields**  
Do not use or store this device in the vicinity of equipment that produces strong electromagnetic radiation or magnetic fields. The magnetic fields produced by equipment such as radio transmitters or household television sets could interfere with the color monitor, damage data stored on the flash memory card, or affect the product's internal circuitry.
- ✔ **Avoid sudden changes in temperature**  
Sudden changes in temperature, such as occur when entering or leaving a heated building on a cold day, can cause condensation inside the device. To prevent condensation, place the device in its carrying case or a plastic bag before exposing it to sudden changes in temperature.
- ✔ **Batteries**  
When you turn the device on, check the battery level displayed in the control panel to determine whether the batteries need to be replaced. Batteries need to be replaced when the battery-level indicator is flashing.  
On cold days, the capacity of batteries tends to decrease. When taking pictures outside in cold weather, keep a spare set of warm batteries on hand.
- ✔ **Memory cards**  
Observe the following precautions when handling CompactFlash memory cards:
  - Turn the power off before inserting or removing memory cards. Inserting or removing cards with the power on could render them unusable.
  - Insert memory cards as shown in the illustration at right. Inserting cards upside down or backwards could damage the camera or the card.



### Notice for customers in Canada

#### CAUTION

This class B digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations.

#### ATTENTION

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

### Notices

#### Concerning the Manuals Provided with This Product

- Reproduction, in whole or in part, of any of the manuals provided with your Nikon product requires prior permission from Nikon.
- The information contained in these manuals is subject to change without notice.
- While Nikon has made every effort to produce perfect manuals, we appreciate any opportunity for improvement. Should you find any mistakes, we would be grateful if you were to kindly let us know. The address of Nikon's representative in your area is provided separately.

#### Disclaimer of Liability

- Nikon does not accept liability for damages resulting from the use of this product.

### Trademark Information

Apple, the Apple logo, Macintosh, and QuickTime are registered trademarks of Apple Computer, Inc. Finder, Macintosh PC Exchange, Power Macintosh and PowerBook are trademarks of Apple Computer, Inc. IBM and IBM PC/AT are registered trademarks of International Business Machines Corporation. PowerPC is a trademark of International Business Machines Corporation, used under license. Microsoft is a registered trademark, and Windows, MS-Windows and Windows NT trademarks, of Microsoft Corporation. Internet Explorer is a product of Microsoft Corporation. i486 and Pentium are trademarks of Intel Corporation. Internet is a trademark of Digital Equipment Corporation. Netscape and Netscape Navigator are registered trademarks of Netscape Communications Corporation. CompactFlash is a trademark of SanDisk Corporation. Adobe and Acrobat are registered trademarks of Adobe Systems Inc. All other trade names mentioned in this manual or the other documentation provided with your Nikon product are trademarks or registered trademarks of their respective holders.

### Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that has been digitally copied or reproduced by means of a scanner, digital camera, or other device is punishable by law.

#### • Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds, or local government bonds, even if such copies or reproductions are stamped "Sample".

The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited.

Unless the prior permission of the government has been obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

#### • Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards, and tickets, such as passes and meal coupons.

#### • Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is prohibited except when it is done for personal use at home or for similar restricted and non-commercial use.

### A Note on Memory Cards

Your digital camera uses CompactFlash flash-memory cards to store photographs. While any card conforming to CompactFlash specifications can be used, performance may vary depending on the make of card. Nikon CompactFlash memory cards are recommended.

### Notice for customers in the U.S.A.

#### Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

#### CAUTIONS

##### Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

##### Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Nikon Inc.,  
1300 Walt Whitman Road, Melville, New York  
11747-3064, U.S.A.  
Tel.: 516-547-4200

