

PAMS Technical Documentation

RAE-3 NU* Series PDA

7. Service Software Instructions

CONTENTS –Troubleshooting

	Page No
Service Software	7 – 5
General	7 – 5
Hardware requirements for Windows 3.1x	7 – 5
Hardware requirements for Windows 95	7 – 5
Software Environment of the Support Modules	7 – 5
Required Servicing Equipment	7 – 6
Installation	7 – 7
Mechanical Connections	7 – 7
Installing the software on PC Hard Disk	7 – 7
Common Properties of the User Interface	7 – 8
Login Dialog	7 – 8
Main Window	7 – 9
Using Help	7 – 9
Software upgrade guide	7 – 10
Equipment Setup instructions	7 – 10
Setting up the PC	7 – 11
Setting up BUS Configuration for WinTesla	7 – 11
Programming with WinTesla Interface	7 – 12
WinTesla Interface	7 – 12
Before programming	7 – 12
Programming procedure	7 – 12
ROM/MCU image	7 – 12
Formatting the User memory	7 – 18
Installing All_Nokia_92XX_data_XX.SIS -package	7 – 18
After Programming	7 – 19
Troubleshooting for the N9210 SW upgrade	7 – 20
Wintesla Tuning	7 – 22
RF tuning after repairs	7 – 22
Equipment Setup for RF Tuning without Removing Covers ..	7 – 23
RX Calibration	7 – 24
RX Filter Calibration (Automatic)	7 – 27
RX AM Suppression (automatic)	7 – 29
EGSM	7 – 29
PCN	7 – 31
TX Power Tuning	7 – 33
EGSM tuning	7 – 33
PCN tuning	7 – 35
TX I/Q Tuning	7 – 37
Common tuning procedure	7 – 38
Initial set-up PCN	7 – 39

7. Service Software Instructions

Technical Documentation

IQ Tuning using Spectrum Analyzer	7 – 40
EGSM	7 – 40
Spectrum Analyzer Settings	7 – 40
Phone Settings	7 – 40
PCN	7 – 45
Spectrum Analyzer Settings	7 – 45
Phone Settings	7 – 45
Energy Management (EM) Calibration	7 – 50
Equipment Setup for Energy Management calibration ...	7 – 50
Energy Management Calibration procedure	7 – 51

Service Software

General

Wintesla software is used to perform service functions of the RAE-3 PDA. This SW consists of Wintesla service software and product specific DLL's (Dynamically Linked Libraries).

To run WinTesla SW, a parallel port software protection device (PKD-1) must be connected to the PC to perform flashing functions. If only controls are necessary, RAE-3 can be controlled using equipment setup described in the WinTesla RS chapter.

The test functions send test messages from PC to MS and receive results and show them in the PC display. The messages to the phone can be sent via DAU-9C cable.

Note: if this software is to be run on laptops, the power saving feature MUST be switched off.

Hardware requirements for Windows 3.1x

The recommended minimum hardware standard to run Service Software is any computer which is 386 33 MHz or greater with at least 4 MB of memory and VGA type display (640 x 480). This assumes that only the WinTesla with After Sales Support Modules is active, i.e. other Windows packages are not running in the background.

Hardware requirements for Windows 95

The recommended minimum hardware standard to run Service Software is any computer which has Pentium processor, memory 8 MB and meets HW requirements recommended by Microsoft.

Software Environment of the Support Modules

The Service Software user interface is intended for the following environments: Microsoft Windows 3.1x (enhanced mode) and Windows 95/98 and NT. Detailed information about Windows and application usage can be found from the Microsoft Windows Users Guide.

As an ordinary Windows application, the main idea in the user interface is that selections are made with menus, push buttons and shortcut keys. Selections can be done by using keyboard and/or mouse. There is always a status bar displayed at the bottom of the main window which contains information about current actions.

Required Servicing Equipment

- Computer: At least IBM 80386 or compatible with one unused serial port (COM1 or COM2)*), one parallel port (LPT1), hard disk recommended
- Operating System: DOS Version 3.2 or later
- If PCLStart in use: DOS 6.22 and IBM 80486 or compatible
- Display: Any 80–character text display
- Service software version for 3.5” disk (product code: 0774080)

Rest of the needed service equipment depends on what kind of operations service personnel wants to perform.

*) Note: A number of PC's of an older generation use the Intel, National Semiconductor, or United Micro-electronics IC 8250 as the serial port UART. This is a comparatively inefficient circuit for current purposes and does not necessarily support the M2BUS adapter at 9600 baud. The newer UART's NS16450 and NS16550AF of National Semiconductor offer solutions for these problems.

Installation

Mechanical Connections

Caution: Make sure that you have switched off the PC and the printer before making connections.

Caution: Do not connect the PKD-1 key to the serial port. You may damage your PKD-1 !

The software controls RAE-3 via a separate adapter connected to the serial port of the PC, and to the phone bottom connector (DAU-9C cable).

Attach the dongle PKD-1 to the parallel port 1 (25-pin female D-connector) of the PC. When connecting PKD-1 to the parallel port, be sure that you insert the computer side of the PKD-1 to the PC (male side). If you use a printer on parallel port 1, install the PKD-1 between the PC and your printer cable.

The PKD-1 should not affect devices working with it. If some errors occur (errors in printing are possible) please try printing without the PKD-1. If printing is OK without the PKD-1 please contact your dealer. We will offer you a new PKD-1 in exchange for your old one.

The program is delivered on a diskette and is copy protected with a dongle PKD-1. It must be present in parallel port when using Service software.

Installing the software on PC Hard Disk

The program can also be installed on the hard disk, which is recommendable to obtain a maximum data access rate.

Keep the original diskette safe to enable upgrading of the program !

If you plan to use PCL Start service software, you must install it before installing Service software, see PCL Start installation instructions.

To install the new Service software program, follow the steps below:

-
1. insert the new Service software diskette into drive A: of your computer
 2. start Windows, and open File Manager
log into drive a: *type A: and press <Enter>*
 3. start INSTALL.EXE and *type C: and press <Enter>*
install Service software to drive C:

To install product specific DLL's, take your RAE-3 DLL disks, and repeat the steps above.

Common Properties of the User Interface

This chapter describes how the User Interface CLF must appear to the user.

The User Interface **MUST** be capable of being driven without the use of a mouse, as the service engineer rarely has space on the bench to use a mouse.

Login Dialog

When the Service Software application is invoked, by checking on the Service Software icon, the **Login** dialog box (Figure 1) will be displayed on the screen.




Figure 1. Login dialog box

Nokia logo and application name bitmap (–)

Displays Nokia logo and name of the application.

Application version static text (–)

Contains the name and version of the application.

Copyright notice static text (–)

Copyright is informed as: **“Nokia Mobile Phones (c) 1995–1999. All Rights Reserved”**.

Login Box edit box (–)

The user Login ID edit box, where the user enters his faultlog user name. (See Faultlog User Guide)

OK button (default key)

The user name is stored in memory and the dialog box is closed. When the dialog box is closed, the application starts.

Cancel button (ESC)

The Dialog box is closed and application is started, but the Faultlog feature is disabled.

Help button (F1)

Activates the Windows Help application and displays context sensitive Help.

Main Window

When Wintesla opens the basic screen, product specific DLL's must be activated using mouse to select Product → Open and select RAE-3

Using Help

When DLL's are active, the menu bar contains several items, including help texts, as shown in Figure 2.




Figure 2. Menu bar

Instructions for service software use can be found in the help texts. Step by step instructions for complex operations like SW upgrades and tunings can be found in the end of this chapter.

Software upgrade guide

Equipment Setup instructions

1. Once a FPS-8 box is used for the first time it has to be activated according to the instructions included in the FPS-8 package.
2. Connect the box, cables and PC according to the drawing (see Figure 3)




Figure 3. Flashing setup

Item:	Service accessory:	Type	Product code:
1	Prommer	FPS-8	0750123
.....	incl. 2 pcs 8MB SRAM module	SF 12	0080346
2	AC/DC Adapter FRIWO (Included in FPS-8 sales pack) FW7207/6	0680032
3	D9 – D9 Cable (Included in FPS-8 sales pack) AXS-4	0730090
4	Printer Cable (Included in FPS-8 sales pack)		0730029
5	Service Battery	BBL-3B	0770206
6	Service Cable	SCH-8	0730137
7	Software protection key	PKD-1	0750018
8	Service SW diskette 3.5" for Wintesla		0774046
9	Service SW diskette 3.5" for RAE-3		0775293

Setting up the PC

1. Install dongle drivers from CD-ROM (d:\32bit_Dongle_Driver\dk2wn32.exe –directory)
2. Install WinTesla version (version 6.43 or later) from CD-ROM (d:\wintesla\wt_inst.exe –directory)
3. Install the RAE–3 DLL's from CD-ROM (d:\dlls\lv04_X0_00\Disk1\setup.exe –directory)

Setting up BUS Configuration for WinTesla

Once Wintesla is first time used the Connection from PC to FPS–8 has to be configured according to the instructions bellow (see Figure 4, Figure 5).

1. Start WinTesla software (c:\WinTesla\Stesla.exe)



Figure 4.

2. Set Bus Configuration for WinTesla according to Figure 2 below:

Open Bus Configuration –window by going **”Configure”** –> **”Buses...”**

Set COM port **”1”** , Hardware Type **”COMBOX”** and Media **”MBUS”** (see Figure 5).




Figure 5. Set Bus Configuration

Programming with WinTesla Interface

WinTesla Interface

These instructions are valid when using:

- WinTesla version 6.43 or later
- RAE-3, RAE-5 and RAB-3 AMS dll release v04.00.00 or later
- PKD-1 dongle

Before programming

Save backup data to memory card. Note that the memory card must be inserted in the Communicator.

1. Press the Office application button, select the File manager application and press Open.
2. Press the Menu key and select *Memory card > Backup to memory card...*
3. Press Backup to backup all the Communicator data to the memory card.

Programming procedure

ROM/MCU image

1. Start WinTesla software
2. Insert BBL-3B service battery in the Communicator.
3. Connect SCH-8 cable to the Communicator bottom connector.
4. Select *Product -> Open -> RAE-3* for N9290 (see Figure 6)




Figure 6. Product Open

Note: If Win Tesla is already running, and the Communicator is on, press "F5" to initialize connection.

- 2. Select *Dealer* → *Flash Phone...*




Figure 7. Wintesla user interface when the Communicator is running and initialization has been successful.

6. *Flash Phone* dialog opens.
7. Select *Market Area* (or select the correct PPM image by pressing the lower '...').
8. Select *MCU Image* by pressing upper '...' (if the correct MCU image is not automatically selected).
9. Press the **Flash** button (see Figure 8)




Figure 8. Flash phone –dialog

10 . Once the program is prompting for restoring user data choose NO if you do not want to save the existing user settings, else select YES . (see Figure 9)




Figure 9. Saving user settings to file

11. Programming starts (takes about 10 minutes)

12. If you have selected NO to answer the previous question in step 10 the user settings will be updated after flash programming . Press the OK button (see Figure 10 .)




Figure 10. Restoring Default User settings

13. After Flash programming complete message press OK button and close the *Flash Phone* dialog (see Figure 11)




Figure 11. Flash programming completed

14 Disconnect the BBL-3 service battery and the SCH-8 cable from the Communicator.

Formatting the User memory

15. Insert the BLL–3 standard battery to restart the Communicator.
16. Open the cover.
17. When you see the Welcome screen, immediately press and hold down the **Ctrl+Shift+F** keys. The "F" key must be pressed last. Then press the 'Format*' button (see Figure 12)



Figure 12. Flash programming completed

Installing All_Nokia_92XX_data_XX.SIS -package

18. Insert the MMC that includes the correct SIS package. The same language and version as in the ROM image (same as 'Market Area' in Figure 8).
19. Install All_Nokia_92XX_data_XX.SIS
 - Open the Install/Remove program
 - press the Extras application button
 - Select the Control Panel application and then the Install/Remove application.
 - Install SIS package.
 - Press Install new button
 - Press Browse button,
 - Select Memory card by pressing Arrow key once
 - Press OK button
 - Select All_Nokia_92XX_data_XX.SIS and press OK.

After Programming

Restore data from the Memory Card.

- Press the Office application button, select the File Manager application and press Open
- Press the Menu key and select *Memory card > Restore from memory card...*
- Press **Restore** to restore all the backed-up memory card data to the Communicator.

Now you have new software in the Communicator !

Troubleshooting for the N9210 SW upgrade

If something went wrong during flashing:

If you have a dead RAE-3

1. Do not try to switch phone on
2. Use product-> Open-> RAE-3. (Figure 13)

Wintesla will prompt you " Did not find a phone in current connection! " Answer Yes.




Figure 13. Flash menu selection

3. Then use Dealer > Flash Phone (Figure 14)




Figure 14. Wintesla dialog when the RAE-3 is not running

- 4. Because user settings cannot be read, Wintesla will prompt you "Failed to communicate with phone. Settings cannot be saved. Do you want to continue?" Answer Yes.




Figure 15. Wintesla cannot read user settings

- 5. If Flash authority ID writing fails () after flashing:
..... FPS-8 may not be activated,




Figure 16. Flash authority ID writing failed

Wintesla Tuning

Prior to any tuning the phone must be initialized:

Connect the phone to a PC with a DAU-9P cable

Start Wintesla-Service-Software and

Select	<u>P</u> roduct		Alt+p
		Open...	
		RAE-3	
Select:	<u>P</u> roduct		Alt+p
		Initialize	Alt+l
		Normal Mode	F5

RF tuning after repairs

Different repairs require different tuning. In general it is necessary to determine in which section the repair was done to establish which tunings to perform. To determine if RF tuning is necessary after repair it is important that the functionality of the repaired circuit is understood well. In case the circuit is not fully understood it might be wise to play it safe and do RF tunings in accordance with the table below.

In general repairs in the TX part will require tuning of "TX Power" and "TX I/Q" tuning.

In general repairs in the RX part or PLL will always require "RX Calibration" and in some cases require AM Suppression tuning (Automatic) and RX Filter Calibration (Automatic).

Other parts interfacing to TX, RX or PLL might require tuning, but common sense should be used.

If it can be ruled out that a component change affects RF performance, e.g. the microphone B200, there is no need to do any RF tuning.

Equipment Setup for RF Tuning without Removing Covers




Figure 17. Tuning set-up 1

Item:	Service accessory:	Type	Product code:
1	Service car kit	HCL-1	0770265
2	Service Battery	BBL-3B	0770206
3	Modular T-Adapter		4626134
4	Service MBUS Cable	DAU-9S	0730108
5	Software protection key	PKD-1	0750018
6	Service SW diskette 3.5" for Wintesa		0774046
7	Service SW CD for RAE-3		0775291

RX Calibration

The "RX calibration" is used to determine gain at different gain–settings for front–end and Hagar and needs to be done in both bands, but the calibration only have to be started once, it will automatically proceed to the PCN band after EGSM.

Select: Tuning

Alt+t

RX Calibration

r




Figure 18.

Note: Always use the latest Wintesla support DLLs

Connect an external generator to the phones RF connector and set the generator as the window tells you.

Click OK in the Wintesla window, now a new window pops up:

Change the level on the generator as the window tells you.

Click OK in the Wintesla window, now a new window pops up:




Figure 19.




Figure 20.

Difference between the gain steps should be $\sim 10\text{dB} \pm 1\text{dB}$.
Change the level and frequency on the generator as the window tells you.
Click OK in the Wintesla window, now a new window pops up:




Figure 21.

Change the level and frequency on the generator as the window tells you.
Click OK in the Wintesla window, now a new window pops up:




Figure 22.

Change the level and frequency on the generator as the window tells you. Click OK in the Wintesla window, now a new window pops up:




Figure 23.

Difference between the gain steps should be $\sim 10\text{dB} \pm 1\text{dB}$.
Click Save in the Wintesla window.
RX calibration is now completed.




Figure 25.

RX filter calibration is now completed and the "RX Measurements" window can be closed by clicking "Close"

Click Measure, A window now pops–up:




Figure 27.

Note: Always use the latest Wintesla support DLLs

Connect an external generator to the antenna connector of the phone and set-up the generator.

Click OK in the Wintesla window, the RSSI value is updated in the RX Measurements window.




Figure 28.

Click "Save ". The "RX AM suppression tuning" is now completed in EGSM.

PCN

Select: Product Alt+p
Band b
PCN p
Select: Tuning Alt+t
RX Measurements

A window now pops-up:




Figure 29.

In the "Select Function" frame select function "RX AM Suppression (Automatic)"
Click Measure, A window now pops-up:



Figure 30.

Note: Always use the latest Wintessa support DLLs

Connect an external generator to the antenna connector of the phone and set-up the generator.

Click OK in the Wintessa window, the RSSI value is updated in the RX Measurements window.




Figure 31.

Click "Save ". The "RX AM suppression tuning" is now completed in PCN.

TX Power Tuning

This tuning must be done in both bands.

Note: TX Power tuning must be done with a peak power meter, e.g. Rohde & Schwarz model NRVD with a Rohde & Schwarz Peak Power Sensor TDMA Model NRV-Z31 and a suitable attenuator.

The use of power meter in GSM testers is likely to cause larger error than the use of a dedicated power meter and might cause the phone to be non-compliant with GSM specifications.

EGSM tuning

- Select: Product Alt+p
- Band b
- EGSM e
- Select: Testing Alt+e
- RF Controls r

A window now pops-up (Figure 32):




Figure 32. RF Controls

Set Active unit to TX

Set TX Data Type: to Rand

Click Apply

Click Close

Select: Tuning

Alt+t

TX Power...

Alt+P

A window now pops-up (Figure 33):




Figure 33.

Tune levels 19, 15, 5 and Base in accordance with the target values.

Click calculate, check if the other levels match the targets, correct if necessary.

Click Save when all values matches the targets.

A window now pops-up:




Figure 35.

Tune levels 15, 11, 0 and Base in accordance with the target values.
Click calculate, check if the other levels match the targets, correct if necessary.
Click Save when all values matches the targets.

TX I/Q Tuning

This tuning must be done in both bands.

- Select: Product Alt+p
- Band b
- EGSM e
- Select: Testing Alt+e
- RF Controls r

A new pop up window appears




Figure 36.

- Set Active unit to TX
- Set TX Data Type: to Cont1
- Click Apply
- Click Close and continue to next stage

Common tuning procedure

Select: Tuning

Alt+t

TX I/Q...

Alt+q

A window now pops-up (Figure 37) :




Figure 37.

The carrier and +67kHz signal should now be tuned to a minimum. (Figure 38)

The buttons in the "TX I and Q DC Offset:" will change the level of the carrier.

The buttons in the "Amplitude and Phase Difference:" window will change the level of the +67kHz signal.

When minimum values are reached, click Save.




Figure 38.

IQ Tuning using Spectrum Analyzer

EGSM

Spectrum Analyzer Settings

Use an appropriate attenuator 10 or 20dB insertion loss and set the Reference Level Offset according to insertion loss from the phone to the Spectrum Analyzer.

Set the Spectrum Analyzer according to the following settings.

Parameter	EGSM
Center frequency	902 MHz
Frequency span	300 kHz
Resolution Bandwidth	3 kHz
Video Bandwidth	3 kHz
Sweep time	3 s
Detector type	Max. peak
reference level	35 dBm
Marker 1	902.06771 MHz
Marker 2	902 MHz
Marker 3	901.93229 MHz

Phone Settings

Connect the phone to the computer and to the Spectrum Analyzer.

Using WinTesla to select the following:

Product

Band

EGSM

This selects the EGSM band. Then select the following:

Testing

RF Controls...

A window pops up (Figure 40):




Figure 40.

Set "TX Data Type" to "Cont1", press "Apply", then press "Close". The window closes.

Select the following:

Tuning

Tx I/Q...

A window pops up:




Figure 41.

This is the "Tx I/Q Tuning" window.

Set the Power Level to "10". Then the Spectrum Analyzer shows a plot like this (Figure 42):




Figure 42.

Marker 1 shows the wanted signal. Marker 2 and marker 3 show the unwanted signals.

In the "Tx I/Q Tuning" window use "TX I DC Offset" and "TX Q DC Offset" to adjust the spurious at 902.0MHz (Marker 2) to the minimum level.




Figure 43.

Then the Spectrum Analyzer shows a plot like this (Figure 44):




Figure 44.

In the "Tx I/Q Tuning" window use "Amplitude Difference" and "Phase Difference" to adjust the spurious at 901.93229 MHz (Marker 3) to the minimum level.




Figure 45.

Then the Spectrum Analyzer shows a plot like this (Figure 46):




Figure 46.

In the "Tx I/Q Tuning" window press "Save" and the optimal values are stored in the phone. The window closes.

Note: The optimal values for "TX I and Q Offset" and "Amplitude and Phase Difference" vary from phone to phone.

PCN

Spectrum Analyzer Settings

Use an appropriate attenuator 10 or 20dB insertion loss and set the Reference Level Offset according to insertion loss from the phone to the Spectrum Analyzer.

Set the Spectrum Analyzer according to the following settings.

Parameter	PCN
Center frequency	1747.8 MHz
Frequency span	300 kHz
Resolution Bandwidth	3 kHz
Video Bandwidth	3 kHz
Sweep time	3 s
Detector type	Max. peak
reference level	35 dBm
Marker 1	1747.73229 MHz
Marker 2	1747.8 MHz
Marker 3	1747.86771 MHz

Phone Settings

Connect the phone to the computer and to the Spectrum Analyzer.

Using WinTesla to select the following:

Product

Band

PCN

This activates the PCN band. Then select the following:

Testing

RF Controls...

A window pops up:




Figure 47.

Set "TX Data Type" to "Cont1", press "Apply", then press "Close". The window closes.

Select the following:

Tuning

Tx I/Q...

A window pops up:




Figure 48.

Select "EEPROM Values" and a new window pops up:




Figure 49.

This is the "Tx I/Q Tuning" window.

Set the Power Level to "5". Then the Spectrum Analyzer shows a plot like this (Figure 50):




Figure 50.

In the "Tx I/Q Tuning" window use "TX I DC Offset" and "TX Q DC Offset" to adjust the spurious at 1747.8MHz (Marker 2) to the minimum level.




Figure 51.

Then the Spectrum Analyzer shows a plot like this (Figure 52):




Figure 52.

Marker 1 shows the wanted signal. Marker 2 and marker 3 show the unwanted signals.

In the "Tx I/Q Tuning" window use "Amplitude Difference" and "Phase Difference" to adjust the spurious at 1747.86771MHz (Marker 3) to the minimum level.




Figure 53.

Then the Spectrum Analyzer shows a plot like this:




Figure 54.

In the "Tx I/Q Tuning" window press "Save" and the optimal values are stored in the phone. The window closes.

Note: *The optimal values for "TX I and Q Offset" and "Amplitude and Phase Difference" vary from phone to phone.*

Energy Management (EM) Calibration

Equipment Setup for Energy Management calibration

NOTE: EM values can not be tuned in module jig MJS-14




Figure 55. Tuning set-up 2

Item:	Service accessory:	Type	Product code:
1	Dummy Service Battery	BBL-3B	0770206
2	DC Cable	SCB-3	0730114
3	Service MBUS Cable	DAU-9C	0730138
4	Calibration unit	JBE-2	0775290
5	Software protection key	PKD-1	0750018
6	Service SW diskette 3.5" for Wintesla		0774046
7	Service SW CD for RAE-3		0775291

Energy Management Calibration procedure

NOTE: This can not be done in module jig MJS-14. EM calibration is possible only when phone is completely assembled.

- Connect DAU-9C cable and BBL-3B battery to the Communicator
- Connect BBL-3B to the calibration unit JBE-2 and DC cable SCB-3 between phone and calibration unit.
- Connect JBE-2 to laboratory power supply which is adjusted to 8.0V
- Start Wintesla service SW
- Select Tuning → Energy Management Calibration
- Run calibrations separately or all at once as described in the following list. Connect 10.5V to the calibration unit JBE-2 as prompted by service SW.
- Select calibrations:
 - Select 1.Run Battery & charger default values checkbox
 - Select 2.Battery voltage checkbox
 - Select 3.Charger voltage checkbox
 - Select 4.Battery size checkbox
 - Select 5.Battery temperature checkbox
 - Select 6.Charge current
- Select Save without confirmation, if you don't want confirm all the selected calibration values before saving
- Run calibrations by pressing Run button
- Set supply voltage back to 8.0 V

This page intentionally left blank.