



This manual is for reference and historical purposes, all rights reserved.

**This page is copyright© by M. Butkus, NJ.**

This page may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

This is the full text and images from the manual. This may take 3 full minutes for the PDF file to download.

**If you find this manual useful, how about a donation of \$3 to: M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701 and send your e-mail address so I can thank you. Most other places would charge you \$7.50 for a electronic copy or \$18.00 for a hard to read Xerox copy.**

**This will allow me to continue to buy new manuals and pay their shipping costs.**

**It'll make you feel better, won't it?**

**If you use Pay Pal or wish to use your credit card,  
click on the secure site on my main page.**



*Butkus, US*

*Sue &  
Ding Hall*





INSTRUCTIONS

OLYMPUS  
*Pen* **EE-2**

OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN

When you read this brochure, please hold the camera in your hands actually. Pay attention to the positions of the hands shown in the pictures, because each picture indicates the right positions of your hands.





**Main features:** ● **Film size:** 24×18mm using regular 35mm film cassette ● **Lens:** D. Zuiko F/3.5 f=28mm (4 elements in 3 groups) ● **Shutter:** Olympus Shutter (Auto) Programmed EE system 1/40 sec, 1/200 sec. (Manual) 1/40 sec. X-synchro. contact; Automatic shutter release button locking system for under exposure ● **Manual lens opening:** F/3.5~F/22 at 1/40 sec. ● **Viewfinder:** Luminous bright frame finder (magnification 0.5) with red warning signal for under exposure ● **Film loading:** EL (Easy Loading) system ● **Film winding:** Thumb winding at camera rear; self-cocking for prevention of blank and double exposure ● **Film counter:** Exposed counting; self-resetting type ● **Film rewinding:** Crank type, with self-holding rewind button ● **Focusing:** Fixed focus (1.5m or 5 feet~infinity) ● **Exposure meter:** Automatic exposure adjustment by built-in electric eye meter with automatic shutter locking system ● **Light measuring range:** EV8.94~EV17.14 (ASA100) ● **Film speed setting:** ASA25~ASA400 ● **Rear cover operation:** Hinge type ● **Accessory shoe:** Cordless flash contact ● **Size & weight:** 108 (4¼) width×66 (2½) height×43 (1½) depth in mm (inches), 335 gr. (12 oz.)



## 1. Set the camera to manual system

Turn the ASA setting ring to set any one of the yellow numbers marked on the ring to the center dot, so that the auto system is switched to manual system. Then the shutter can be released freely regardless of light conditions.




1



## 2. Open the rear cover and load the camera with film

Pull out the rear cover lock. The cover will open automatically. Then pull up the rewinding knob. Put the film cassette into the film compartment. Push the rewinding knob in. If the knob cannot be pushed in completely, turn it slightly clockwise or counterclockwise while maintaining pressure.

2



### 3. Engage the film with the take-up spool

Hold the camera with your left hand. With the right hand, pull out the film end to such extent that it reaches the take-up spool. Insert the film end into any of the six slots on the take-up spool, keeping it away from direct sunlight. Be sure that the gear teeth on the sprocket spool engage the perforations of both sides of the film, winding the film on to the take-up spool. Close the rear cover.

3


### 4. Check the film counter

Wind the film and release the shutter button. Repeat this motion two or three more times until the red triangle of the film counter points to "1". From this point, start taking pictures. Whenever you wind the film, be sure you wind it all the way. Otherwise you cannot release the shutter button.

If the rewind knob turns during the repeated motion, this shows that the film is being advanced properly.

4






## 5. Set the ASA film speed

Make sure of the ASA film speed indicated on the film package you use. Turning the ASA setting ring, set the ASA film speed number (white number) to the center dot. Then the camera is switched to the automatic exposure system.

**ASA**

ASA 25 • 50 • 80 100 125 160 200 250  
320 400 (The first dot indicates ASA 32  
& 40, and the second one indicates ASA  
64.)



## 6. Free from focusing

Pen EE-2 has a fixed focusing lens system in it, so you are free from focusing (when the camera-to-subject distance is from 1.5m to infinity).



## 7. Compose the picture and release the shutter


Look through the viewfinder and place the subject in the center of the white frame. Press the shutter release button with the flat part of the index finger, but NOT with the tip of the finger. When the subject is too dim, the shutter can not be released, and a red warning signal comes up in the viewfinder. In this case, move the subject to an area that has more light, or use a flashgun. When taking pictures, hold the camera firmly as shown in the pictures below.

7





no. 4551275



### 8. Rewind the film:

When a roll of film is completely exposed, rewind the film. DO NOT attempt to advance the film. The film is completely exposed, when the red triangle of the film counter points the number 72 (in case of a 36-exposure roll), 40 (a 20-exposure roll), 24 (a 12-exposure roll), depending upon the length of film used. Press the rewind button on the bottom of the camera body. Lift the rewind crank and turn it in the direction of arrow. The crank is tight while the film is being rewound, but when the end of the film leaves the take-up spool, the crank will become loose. Then open the rear cover and pull out the film rewind knob. Remove the film, keeping it away from direct sunlight.

8

## Flash Photography



(1) The use of either a flashgun or an electronic flash is recommended if red warning signal appears in the viewfinder. We recommend our compact Pen Flash CL. It is very handy as it is cordless.

(2) In flash photography, set the camera to manual system, turning the ASA setting ring (See "1" in preceding page). Look at the instruction in the bulb-package to determine the F number. Set the F number on the ASA setting ring to the center dot. The shutter speed is set at  $1/40$  sec. automatically.

(3) Insert the Pen Flash CL into the accessory shoe (with built-in cordless contact) at the top of the camera; where it connects electrically to the shutter-diaphragm mechanism. The Pen Flash CL exposure chart is stuck on the rear of the flash.

(4) When using an ordinary flashgun or electronic flash, insert the unit into the accessory shoe and attach the flash connecting plug into the synchronizing socket of the camera.


## Handy Accessories

### Filter

Use 43.5mm screw-in type.



### No filter



### Filter Types and Characteristics:

<b>U V</b>	Eliminates undesirable ultra-violet rays and gives clear pictures. Also usable constantly for lens protection. (For black-and-white film)
<b>Y 2</b>	Accentuates contrasts, for example, by darkening a blue sky and bringing white clouds into relief, and produces three-dimensional effects. (For black-and-white film)
<b>1- A</b>	(skylight) - Like UV, eliminates stray ultra-violet rays and prevents pictures from assuming a bluish tone. Usable for lens protection. (For colour film)
<b>81 C</b>	(for cloudy weather) - Designed for colour photography, prevents a bluish tone from its entering pictures taken under cloudy or rainy weather.
<b>82 C</b>	(for morning and evening) - Designed for colour photography, prevents a yellow-reddish tone from its entering pictures taken during morning or evening hours when red rays abound.
<b>ND4X</b>	Reduces the quantity of light entering to the lens to one-fourth. Usable either for colour or black-and-white photography.
<b>Con-ver-sion</b>	Used when taking pictures with Tungsten type film under daylight (For colour

### Pen Flash CL

The compact Pen Flash CL, accepting AG-1 bulb and AG-1B (for colour photography), can be connected electrically by slipping its foot on to the accessory shoe.



### OLYMPUS PS-200

The Olympus PS-200 Electronic Flash operates on penlight batteries, and can be used with the cameras which have hot shoe contact. Its power source is two 1.5V penlight batteries, carbon/zinc or alkaline. The number of flashes is 200 from set of fresh alkaline batteries. Guide number 14 in meter or 45 in feet (ASA 100), color temperature 5,800° kelvin. It measures 31×55×64mm (1¼×2¾×2½") and weighs 75 grams (2⅝ oz.).

**Give the camera  
the care  
it deserves:**

- \* Dust and moisture are enemies of your camera. Be sure to store the camera in a dry and well ventilated place.
- \* Don't touch the lens with your fingers. If touched, wipe it with a clean unstarched cotton cloth. Fingerprints, if not wiped off immediately, will eventually not be removable.
- \* After using the camera on the beach, be sure to wipe the surface of the camera with a soft cloth so that no salt or other corrosive substance will be left on it.
- \* If the camera should need service, bring it immediately to your dealer, who is an OLYMPUS service agent.



# OLYMPUS

OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN  
43-2 Hatagaya 2-chome, Shibuya-ku, Tokyo, Japan