

Contents**OPERATING
INSTRUCTIONS****Getting Started**

<i>Names and Functions of Parts</i>	6
---	---

Operation

<i>Startup and Shutdown</i>	8
<i>Keyboard and Touch Pad</i>	10
<i>Battery Power</i>	12
<i>Replacing</i>	15
<i>Recharging</i>	16
<i>Refreshing</i>	17
<i>Hardware Expansion</i>	18
<i>Multimedia Pocket (MP)</i>	18
<i>PC Cards</i>	19
<i>Memory Expansion</i>	20
<i>Expansion Bus Port</i>	21
<i>Hard Disk Drive</i> <i>(For technicians at your nearest Panasonic Dealer)</i>	22
<i>Infrared Data Transfer</i>	23
<i>Setup Utility</i>	24

Troubleshooting

<i>Diagnostics Program (DIAG25)</i>	25
<i>Error Codes</i>	25
<i>Dealing with Problems</i>	26
<i>Reinstalling Windows</i>	28

Appendix

<i>Floppy Disk Drive</i>	30
<i>Hardware Technical Data</i>	31
<i>Display Properties</i>	32
<i>LIMITED USE LICENSE AGREEMENT</i>	33
<i>Specifications</i>	36
<i>For LCD</i>	38
<i>Index</i>	39

Introduction





Thank you for purchasing the Panasonic's CF-25 series computer. You will find that this computer offers many convenient functions, and can be connected to a variety of optional peripheral devices. Please read the Operating Instructions thoroughly for smooth operation of your new computer.

◆NOTE◆

Also, please see the README file, as it contains important information.


Checklist

Confirm that the following items are supplied.

- Computer 
- AC adapter and AC Cord (CF-AA1526) 
- Function Seal
- Cap Sheet  (⇒P.6)
- Windows® 95 System Pack
- Operating Instructions 
- TRANXIT REGISTRATION CARD
- TRANXIT ACCESSORY CATALOGUE
- LIMITED WARRANTY (US)
- USER REGISTRATION (US)
- LIMITED WARRANTY (CANADA)
- WARRANTY STATEMENT (CANADA)

◆NOTE◆

Please affix the function seal that is supplied on the keyboard.



Copyright

This manual is copyrighted by Matsushita Electric Industrial Co., Ltd. with all rights reserved. No part of this manual may be reproduced in any form without the prior written permission of Matsushita Electric Industrial Co., Ltd. No patent liability is assumed with respect to the use of the information contained herein.

©Matsushita Electric Industrial Co., Ltd. 1997. All Rights Reserved.

Disclaimer

Computers and manuals are subject to change without notice. Matsushita Electric Industrial Co., Ltd. assumes no liability for damage incurred directly or indirectly from errors, omissions or discrepancies between the computer and the manuals.

Trademarks

IBM® is a registered trademark, and PS/2™ is a trademark of International Business Machines Corporation.

Microsoft®, MS-DOS® and Windows® are registered trademarks of Microsoft Corporation of the United States and/or other countries.

Intel® and Pentium® are registered trademark or trademark of Intel Corporation.

CardWorks™ is a trademark of SystemSoft Corporation.

TranXit™ is a trademark of Puma Corporation.

Panasonic® is a registered trademark of Matsushita Electric Industrial Co., Ltd.

Conventions

NOTE

NOTE provides a useful fact or helpful information.

CAUTION

CAUTION indicates a condition that may result in minor injury or slightly moderate injury.

WARNING

WARNING indicates a hazard that may result in moderate injury or serious injury, even death.

Lithium Battery

Lithium Battery!

This computer contains a lithium battery to enable the date, time, and other data to be stored in it.

Should only be exchanged by service personnel.

Warning! Risk of explosion from incorrect installation or misapplication!

Litium batteri!

Denna dator innehåller ett litium batteri som avänds för att lagra datum, tid och annan data.

Bör endast bytas av servicepersonal. Explosionsfara vid felaktig hantering.

For U.S.A.

Federal Communications Commission Radio Frequency Interference Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the Panasonic Service Center or an experienced radio/TV technician for help.

Warning

To assure continued compliance, use only shielded interface cables when connecting to a computer or peripheral. Also, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

For U.K.

Warning

This apparatus must be earthed for your safety.

To ensure safe operation the three-pin plug must be inserted only into a standard three-pin power point which is effectively earthed through the normal household wiring.

Extension cords used with the equipment must be three-core and be correctly wired to provide connection to earth. Wrongly wired extension cords are a major cause of fatalities.

The fact that the equipment operates satisfactorily does not imply that the power point is earthed and that the installation is completely safe.



For your safety, if you have any doubt about the effective earthing of the power point, consult a qualified electrician.

FOR YOUR SAFETY PLEASE READ THE FOLLOWING TEXT CAREFULLY

This appliance is supplied with a moulded three pin mains plug for your safety and convenience.

A 3 amp fuse is fitted in this plug.

Should the fuse need to be replaced please ensure that the replacement fuse has a rating of 3 amps and that it is approved by ASTA or BSI to BS 1362.

Check for the ASTA mark  or the BSI mark  on the body of the fuse.

If the plug contains a removable fuse cover you must ensure that it is refitted when the fuse is replaced.

If you lose the fuse cover the plug must not be used until a replacement cover is obtained.

A replacement fuse cover can be purchased from your local Panasonic Dealer.

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR THE SOCKET OUTLET IN YOUR HOME THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY.

THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13 AMP SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below.

If in any doubt please consult a qualified electrician.


Warning: THIS APPLIANCE MUST BE EARTHED.

Important

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow:	Earth
Blue:	Neutral
Brown:	Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured GREEN-and-YELLOW must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol  coloured GREEN or GREEN-and-YELLOW.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured BLACK.


The wire which is coloured Brown must be connected to the terminal which is marked with the letter L or coloured RED.

The mains plug on this equipment must be used to disconnect the mains power.

Please ensure that a socket outlet is available near the equipment and shall be easily accessible.

■ How to replace the fuse

Open the fuse compartment with a screwdriver and replace the fuse.



Warnings

- This equipment is not designed for connection to an IT power system.
(An IT system is a system having no direct connections between live parts and Earth; the exposed-conductive-parts of the electrical installation are earthed.
An IT system is not permitted where the computer is directly connected to public supply systems in the U.K.)
- Disconnect the mains plug from the supply socket when the computer is not in use.

This equipment is produced to BS800/1983.

For German

■ Warnung bezüglich der Lithiumbatterie (Sicherungsbatterie)

Lithiumbatterie!

Dieser Computer enthält eine Lithiumbatterie zur Sicherung von Datum und Uhrzeit der eingebauten Uhr sowie anderer Systemdaten im Speicher bei einer Unterbrechung der Hauptstromversorgung. Diese Sicherungsbatterie darf nur von Kundendienstpersonal ausgewechselt werden.

Warnung! Bei falschem Gebrauch besteht Explosionsgefahr! Entsorgung gebrauchter Batterien nach Angaben des Herstellers.

For France

■ Avertissement concernant la pile au lithium (pile de sauvegarde)

Pile au lithium!

Le micro-ordinateur renferme une pile au lithium qui permet de sauvegarder certaines données comme la date et l'heure notamment. Elle ne devra être remplacée que par un technicien qualifié.

Avertissement! Risque d'explosion en cas de non respect de cette mise en garde!

Precautions

The CF-25 was developed based on thorough research into the real-world portable computing environments. Exhaustive pursuit of usability and reliability under harsh conditions led to innovations such as the magnesium alloy exterior, MCM (multichip module) technology based cool-running Pentium® processor, vibration damped hard disk drive and floppy disk drive, flexible internal connections, sealed LCD and keyboard, dust proof hinges and the revolutionary "Shirato" ruggedized LCD screen mounting system. The CF-25's outstanding engineering has been tested using the stiff MIL-STD- 810E (for vibration and shock) and IP (for dust and water) based procedures.

As with any portable computer device precautions should be taken to avoid any damage. The following usage and handling procedures are recommended.

■ Usage



Avoid Extreme Heat and Cold

Do not store or use the computer in locations exposed to heat, direct sunlight, or extreme cold.

Avoid moving the computer between locations with large temperature differences.

Operation: 5 °C to 35 °C (41 °F to 95 °F)

Storage: -20 °C to 60 °C (-4 °F to 140 °F)

Avoid Direct Sunlight on the LCD Panel

The LCD panel should not be exposed to direct sunlight or ultraviolet light.




Avoid Humidity Liquids and Dust

Do not store or use the computer in locations exposed to high humidity, liquids (including rain) or dust.



Prevent Shock

Avoid subjecting the computer to severe vibrations or impact. Do not place the computer inside a car trunk.



Avoid Radio Frequency Interference

Do not place the computer near a television or radio receiver.

■ Handling



Avoid Magnetic Fields

Keep the computer away from magnets.



Avoid Stacking

Do not place heavy objects on top of the computer.



Keep Small Objects Away

Do not insert paper clips or other small objects into the computer.



Do Not Disassemble the Computer

Do not attempt to disassemble your computer.

Avoid Excessive Force to the LCD Panel

Do not apply excessive downward force on the display when it is completely opened, especially when plugs and/or cables are connected to the rear of the computer.

Carry the Computer Properly

- Do not carry the computer without first turning off the power.
- Do not hold the computer by the LCD panel if the computer is open.
- Do not move the computer while a floppy disk is inserted.

■ Maintenance

Surface of the LCD Panel

- Soak a piece of gauze or soft cloth sufficiently in isopropyl alcohol only, and wipe the panel gently. Using excessive force may scratch the panel. Avoid wiping with a dry cloth, since this can damage the surface of the polarizing plate. Also, be sure not to use water and perfumes, as these liquids can dissolve the coloration of the polarizing plate.

Areas other than the Display

- Gently wipe other areas using a soft cloth pre-soaked in water or a neutral cleaner and wrung out thoroughly. Do not use solvents like benzene and thinner, nor chemical cloths.

Handling the AC Adapter

- Do not twist or pull the AC power cord forcefully. Doing so may damage the connections.
- Use only the specified AC adapter (Factory Control Number: CF-AA1526) with your computer. Using an AC adapter other than the one supplied might damage the battery and/or the computer.
- When the DC plug is not connected to the computer, disconnect the AC cord from your AC wall outlet as well. If the cord is kept connected, a very low level of power equivalent to approximately 1.5 watts will be consumed.
- Problems such as sudden voltage drops/surges may arise during periods of thunder and lightning. Since this could adversely affect your computer, the uninterruptible power supply is highly recommended.

Against Computer Viruses


- Anti-virus software is not supplied. However, you should obtain such software if you plan to transfer files actively or to use the Internet.

Cables

- Use of an interface cable longer than 3m (118.11 inches) is not recommended.

Names and Functions of Parts

Front



◆CAUTION◆
Do not use a pencil. Pencil lead can break off inside the computer and damage the computer's circuitry.


To remove the handle, use a screwdriver to remove the screws. When replacing the handle make sure that the screws have been firmly fastened. After removing the handle, please affix the two caps from the cap sheet that is supplied.

- Green ➔ Power on / CPU normal speed mode
- Orange ➔ Power on / CPU slow speed mode (The CPU cools down)

◆NOTE◆
When the temperature of the CPU rises, the processing speed is automatically reduced to protect the CPU from overheating. When the temperature of the CPU drops, the normal processing speed is automatically restored.

◆NOTE◆
The characteristics of the anti-reflection coating on the LCD may cause fingerprints and smudges to appear more visible when compared to standard LCD panels. If necessary, these can be easily removed by following the LCD panel cleaning instructions found on page 5.

Back and Bottom



◆MEMO◆

- Volume adjustment
 - Fn + Increase volume.
 - Fn + Decrease volume.
- Display brightness adjustment
 - Fn + Increase brightness. (Low → Middle → High)
 - Fn + Decrease brightness. (High → Middle → Low)
- LED Indicator

Caps Lock	NumLk	ScrLk	Key Pad	Multimedia Pocket	Hard Disk
■	■	■	■	■	■
E F					

When the LED indicator goes on, do not turn the computer off. Do not remove/insert a floppy disk.

When the LED indicator goes on, do not turn the computer off.

◆CAUTION◆


Do not allow the ports/connectors to get wet. Always make sure they are covered. If they do happen to get wet, wipe them using a soft cloth immediately.

Startup and Shutdown

Inserting the Battery pack ▶

Insert the provided battery pack (⇒ P.15).

Connecting the AC Adapter ▶



◆NOTE◆


Use only the specified AC adapter (CF-AA1526).

- ① Connect the AC cord to the AC adapter.
- ② Plug the AC cord into an AC outlet.
- ③ Plug the AC adapter into the computer.

◆MEMO◆

The supplied battery is not charged. When using the computer for the first time, be sure to charge the battery pack before using the computer. Connecting the AC adapter automatically starts the charging process. Check the battery indicator to confirm the current charging status.

Power On ▶



Lift the latch and open up the display.

◆CAUTION◆

Do not turn the computer off immediately after turning it on. Also, allow at least 10 seconds to elapse after you have switched off the power and want to turn the computer back on again.

Slide the power switch toward the rear of the computer and hold it there for about one second.


◆CAUTION◆

When the power is turned on at the first time, before you use software programs furnished with this product, please read through "LIMITED USE LICENSE AGREEMENT" (⇒ P.33). Then remove the seal.

First time computer is started only ▶

Windows 95 Setup

- ① Select settings for your region, then click [Next].
- ② Select your Keyboard Layout, then click [Next].
(for U.S.A. : "United States 101", for U.K. : "British")
- ③ Type your name and the name of your company, then click [Next].
- ④ The License Agreement should be displayed. Read the Agreement, check "I accept the agreement", and click [Next].
- ⑤ Type in the product number printed on the Certificate of Authenticity; the Certificate is attached to the "Introducing Microsoft Windows 95 book" included in the "Windows 95 system pack". Click [Next].
- ⑥ Click [Finish] to start Wizard.
- ⑦ If the instruction to restart appears, click [OK].
- ⑧ Set the correct Date & Time and Time Zone, then click [Close]. (Note: These settings can be changed later.)
- ⑨ If you want to install your printer driver(s), click [Next]. Follow the prompts on the screen to specify the printer(s). Otherwise, click [Cancel]. (Note: Printer drivers can be added later.)

- ⑩ Close the "Welcome to Windows 95" screen.
- ⑪ You can now use Windows 95, but in order to set the Panasonic original environment and create back-up disks, select  (Panasonic Setup icon). Windows restarts. If Windows does not restart, press the RE-SET button.

Firstaid FD etc. creation

Create back-up disks of the software preinstalled in your computer. Be sure to have 6 2HD-type floppy disks on hand. Please backup your disks in the following order:

- Firstaid FD
- Panasonic Tools Disk
- CardWorks™ INSTALLATION Disk
- TranXit Disk (2)
- DRIVERS DISK


```

- Firstaid FD          1
- Panasonic Tools Disk 1
- CardWorks™ Installation Disk 1
- TranXit Disk 1,2    2
- Drivers Disk        1
.
.
.
If you have the floppy disks in hand, press any key and advance to
the next step. Any data on these disks will, however, be destroyed.
If the floppy disks are not currently available, turn off the power
until they are.
.....
Press any key to continue...
    
```



Ready to create Firstaid FD.
Insert a floppy disk in drive A and press any key.

Please remove the diskette and write protect it.
Press any key to continue...

Startup screen



Shutdown



NOTE

- Make sure to create "Firstaid FD" etc. that will allow you to reinstall the operating system if necessary.
- Do not switch the power off or put the computer into the suspend or hibernation mode while the "Firstaid FD" etc. is being created.

Beginning with the next time you turn on the computer, this screen will be displayed as soon as power is switched on.

To set the user password, start the Setup utility. (⇒ P.24)

You can turn your computer off by selecting "Shut Down..." from the "Start" menu.

MEMO

You can also restart your computer in the MS-DOS mode by selecting "Restart the computer in the MS-DOS mode?"


Keyboard and Touch Pad

The system is equipped with a keyboard and touch pad for input to the computer.


Key combinations for accessing special functions ▶

Fn + Power Switch →


Powers off the computer and nullifies the hibernation function. Use this combination only after saving all open files, closing all open applications, and exiting Windows.

Fn +  →


Toggles the speaker on and off.

Fn +  →


Enters the suspend mode immediately. The display resumes when the power switch is pressed. Please affix the function seal that is supplied.(⇒P.2)

Fn +  →

Gives the current battery power status.


Fn +  →

Powers off the hard disk drive motor and backlight of the display to conserve power. The backlight goes on again when any key is pressed. Power to the hard disk drive resumes when the hard disk is accessed.


Fn +  →


- Toggles the numeric key pad on and off. When the key pad is on, the corresponding LED indicator lights and numerical values can be input.
- Pressing the Fn key when the key pad is on turns it off, and vice versa. When NumLk is activated in conjunction with the key pad, the shaded keys operate as shown.

NumLk on & KeyPad on




NumLk off & KeyPad on




Fn +  →

Increase volume.

Fn +  →

Decrease volume.

Fn +  →


Increase brightness. (Low → Middle → High)

Fn +  →

Decrease brightness. (High → Middle → Low)

Touch Pad ▶


The touch pad is used to move the cursor in the same way as a mouse would.



Move the tip of your finger lightly over the surface to move the cursor. Tapping lightly on the surface has the same effect as clicking the left mouse button.


◆NOTE◆
 If "Left-handed" is selected in the mouse settings, tapping the touch pad will have the same effect as clicking the left button of the touch pad.

Click




➔ Click the left button once or tap the surface once lightly.

Double click



➔ Click the left button twice in rapid succession or tap the surface twice lightly in rapid succession.

Drag



➔ Move the cursor to the object you want to drag. Hold down the left button with one finger while moving another finger over the surface or double-tap the pad without releasing your finger and drag the object. Releasing the left button or lifting your finger from the pad, respectively, will "drop" the object.

◆CAUTION◆

- Be sure never to press the POWER switch while the suspend or hibernation process is being carried out. Also, do not input from the keyboard or the touch pad or move the mouse. The processing may not be executed correctly.
- Movement of the cursor may be affected if oil, etc., gets on the touch pad. Be sure that the touch pad is clean at all times. Use a clean cloth with some water and a little detergent or media head cleaner to gently wipe the touch pad.

Battery Power

This computer contains the following two types of batteries.

Main Battery: (Ni-MH rechargeable battery pack)
Removable battery that runs the computer without the AC adapter.



Clock Battery: Battery that is housed inside the computer and maintains the clock and settings.

◆NOTE◆

- The battery pack will become somewhat warm during normal use. This is not a malfunction.
- The operating time may differ from the display depending on the charging and discharging temperatures and battery wear.

◆CAUTION◆

- When transporting spare batteries inside a package, briefcase, etc., it is recommended that the batteries be stored in a plastic bag.
- Exposure to strong shock (such as being dropped on the floor) can cause the battery pack to malfunction.
- Do not touch the terminals on the battery pack. Damaged terminals may cause system performance failure.
- Do not expose the battery pack to open flame.
- Do not throw the battery pack into a fire or water.
- Use the battery pack only with the computer for which it was designed.
- Do not directly connect the negative and positive terminal on the battery pack.
- If, due to damage, battery electrolyte comes in contact with skin or clothing, wash it off quickly and thoroughly with water. Consult with your physician if you feel something is wrong with you physically.

When  +  are pressed, the remaining battery charge is shown by the four indicators.



90 ~ 100%



65 ~ 90%



35 ~ 65%



10 ~ 35%



[Blinking] The battery pack is not installed or the remaining battery charge is not known.

◆NOTE◆

When the RESET button is pressed or when a battery pack has been replaced, the remaining battery charge will not be recognized. The four LED indicators will blink to show this. If the battery pack is charged fully or discharged until the red indicator lights, the remaining battery charge becomes to be shown.

Battery Indicator ▶

Battery Indicator	Battery Status	Action
Orange	Charging	Please continue normal use.
Green	Fully charged	Please continue normal use.
Red	<p>Power low</p> <p>■ Hibernation function is enabled:</p> <ul style="list-style-type: none"> - The beeper sounds at the same time. - The computer automatically enters the hibernation mode a few minutes after the beeper sounds. <p>■ Hibernation function is disabled:</p> <ul style="list-style-type: none"> - The beeper sounds several minutes later. - The computer automatically turns off a few minutes after the beeper sounds. 	<p>Connect the AC adapter to the computer. Replace the main battery with a fully charged one.</p> <p>If recharging is not possible at this time, immediately save any open files on your disk and turn off the power.</p> <p>When the indicator remains red for a long time, proceed with refreshing unless there has been a sudden change in temperature.</p>
Blinking red	The battery or AC adapter may not have been connected properly.	<p>Make the proper connections. (⇒ P.8.15)</p> <p>If the problem persists, contact the Panasonic Service Center. (Trouble may have occurred in the battery, charging controller, etc.)</p>
Blinking orange	Refreshing	Please wait until refreshing finishes. Press ESC if you wish to abort.
Blinking green	Refreshing required	Refresh the battery pack. (⇒ P.17)
Blinking orange for 5 seconds after the AC adapter is connected.	The temperature is outside the range of approximately 5°C to 35°C (41°F to 95°F).	Please wait until the temperature falls within the allowable range.

Conserving Battery Power ▶

"Power management" conserves battery power and enables the computer to be operated to the maximum extent possible.

The computer enters the standby mode immediately after **Fn** + **F10 Standby** are pressed. In this mode, the HDD motor and display is turned off.

In order to achieve maximum battery power, in the setup utility, set "Power Saving" in "Power Management" to "Advanced".

◆NOTE◆

- Certain applications may not run when "Power Saving" is set to "Advanced" or "Standard". If this is the case, set "Power Saving" to "OFF".
- When Windows is activated, select [Start]-[Settings]-[Control Panel]-[Power], and confirm that the "Allow Windows to manage power use on this computer." check box has been checked at "Power". The default setting is "checked".

A Shorter Than Expected Battery Drive Time ▶

Your computer may experience a shallow charge-discharge cycle characterized by computer operation for a short period of time followed by battery charging. Repetition of such cycles will decrease your battery's operating time temporarily. The above should be kept in mind if you decide to run the computer off the battery after it has been running off the AC adapter for an extended period of time.

The computer automatically determines the need for battery refreshing. In such cases, the screen will display a message reminding you to refresh the battery, after the computer has been started up. In this case, the battery indicator blinks in green to indicate the need for battery refreshing. Refreshing is commenced after any key is pressed. Also, if you leave a fully charged battery for 2 to 4 weeks in temperatures above 35°C (95°F), the battery's operating time may decrease temporarily.

These conditions are not due to a fault in the battery. Normal performance can generally be restored by fully charging and then discharging the battery two or three times in succession. In order to fully discharge the battery in a short period of time, a battery refresh tool (BATTREF.COM) is provided (⇒P.17). Please note that the battery operating time may vary drastically depending on the types of installed options.

◆NOTE◆

Replace the battery pack if the amount of time the computer can be operated on a full charge drops to approximately one half of the normal duration.

Hints on How to Use Battery Pack ▶


If you plan to leave the computer idle for an extended period of time (approximately two months or more), first discharge the battery using the "refresh" method, next, charge the battery pack until the charge level reaches 50%, then remove it from the computer and store it in a cool, dry place. (Refer to the Operating Instructions for information on removing the battery.)


Excessive discharging of the battery can occur if it is left in the computer for extended periods of disuse, possibly shortening its service life or causing damage to the computer. (Note that the battery will not discharge if the AC adapter is left connected, so it does not have to be taken out in such cases.)

Replacing

The battery pack is an item that at some point will require a replacement. If the usage time of a battery pack becomes noticeably short, and repeated recharging does not restore its performance, the battery pack should be replaced with a new one [part number: CF-VZS250A(Ni-MH) or CF-VZS251(Li-Ion)].


Removal ▶



Turn the computer off by pressing  and holding the power switch in the ON position simultaneously.




Turn the computer over.



Use a screwdriver to loosen the two screws located toward the front of the computer.




Remove the cover.




Slide the battery pack toward the outside edge to remove it.

Mounting ▶

Drop a new battery pack into the pocket.



Slide the battery pack inward until it is firmly in place.



Replace the cover and tighten the two screws.

◆NOTE◆

- Always switch the computer off and disconnect the AC adapter before replacing a battery pack.
- The battery pack may malfunction if it is exposed to strong shocks. Caution should be exercised.

Recharging

The battery is automatically charged when the AC adapter is plugged into a socket. Rapid charging commences when the POWER switch is turned off. Normal charging takes place when the POWER switch is turned on.

Charging will terminate (Battery indicator changes from orange to green) automatically when the battery is fully charged. In this state, it will remain fully charged as long as the AC adapter is connected.

The AC adapter will become warm during charging or while in use; this is normal.

◆NOTE◆

If the battery pack is subjected to temperatures outside of the specified 5°C to 35°C (41°F to 95°F) range, charging will not commence. Under this circumstance, the battery indicator will blink for 5 seconds. Charging will commence automatically once the temperature falls within the allowable range. The battery temperature may rise as high as 60°C (140°F) during charging.

◆CAUTION◆

- Always allow the battery to become completely discharged (low battery alarm sounds) before recharging .
- Since the battery is not pre-charged, be absolutely sure to charge these batteries before using the computer for the first time. Charging commences automatically after the AC adapter is connected.
- A new battery or a battery that has not been used for a prolonged period of time will not be fully charged after it has been charged/recharged only once.
- It is recommended not to charge a battery that has not been completely discharged first (low battery alarm sounds).
- Do not charge a battery in any other computer or by using a recharger other than the one specified.
- When the duration of a battery's operation has fallen by half or so, repeat the battery refresh operation two or three times. If nothing happens even after this, the battery has reached the end of its life span and should be replaced with a new one.
- Installing and attempting to charge a battery pack that is already fully charged, or installing and removing a battery pack several times in quick succession, can result in overcharging and cause the battery to heat up. Such treatment can damage the battery pack.

Refreshing

Battery refreshing involves power discharging and recharging (the latter only if the AC adapter is connected.) Follow the instructions below to execute the battery refresh tool after the battery becomes fully charged. The battery refreshing time ranges between three and five hours, depending on the state of the battery.

Battery refresh is available only for Ni-MH battery (CF-VZS250A or CF-VZS252).

◆NOTE◆

Do not execute "BATTREF" at the "MS-DOS" prompt in Windows. Execute this program after restarting the computer in the MS-DOS mode.

- ① Exit any application programs that may be running, click "Start" and then click "Shut Down". Select "Restart the computer in MS-DOS mode?" and click "Yes".
- ② After making sure that the display panel is open and the LCD is 'ON', type the following at the MS-DOS prompt.

```
battref .
```

- ③ A verification message will appear. Press .
- ④ The computer is automatically rebooted, and the screen shown below appears.

Press any key to refresh battery, or ESC to boot.

◆NOTE◆

If the LCD panel is closed when using the external display, the messages "Please Open LCD panel." will appear. Follow the instructions on the screen.

- ⑤ Press any key to start discharging of the battery. The screen shown below appears during the battery refreshing.

Leave the computer on until the POWER indicator goes off, even if the screen goes off.

Refresh battery.

Don't touch unit until all LEDs have turned off. LCD will go off prior to this.

Refresh can take up to 5 hrs. Press ESC to cancel and boot.

When the POWER indicator goes off, battery charging commences automatically. If the AC adapter is not connected, connect it to charge the battery fully.

◆NOTE◆

When charging a completely discharged battery, ensure the proper refresh effect by leaving the AC adapter plugged in until the battery indicator changes to green (which indicates a complete recharge).

The battery indicator becomes orange (charging mode) quite quickly, but charging is not performed for the first one hour in order to increase the charging efficiency.

Hardware Expansion

Multimedia Pocket (MP)

The multimedia pocket houses the floppy disk drive (FDD) that comes with this computer. The FDD can be replaced with an optional unit.


Optional units : CD-ROM Pack (CF-VCD252)


Second Battery Pack (CF-VZS252)

◆NOTE◆

Do not replace a unit in the multimedia pocket with another when the computer is in the suspend or hibernation mode. Doing so could damage the unit or prevent the new unit from being recognized properly.

Removal ▶



Turn the computer off by pressing  and holding the computer switch in the ON position simultaneously.



Turn the unit over.



Open the cover.




Slide the MP release toward the MP device.

The MP device should slide out.



Pull out the device.



Mounting ▶

◆CAUTION◆

- Make sure that the position of the peripheral connector is located as shown in the illustration below.
- Gently install / remove any multimedia pocket device. Do not use excessive force when installing.


Insert an MP unit into the slot.



Push the unit in until it snaps into place.



Confirm that the MP release has returned to its original position.



◆CAUTION◆


You may use the floppy disk drive as an external unit that is connected through the parallel port, by using an optional FDD cable (CF-VCF351). Some precautions are necessary, as described below, since problems may arise.

- Do not move the drive while accessing data on the floppy.
- Firmly hold both sides of the drive when removing a disk. If pressure is applied from the top, excessive force should be avoided.
- When you need to format 2HD type floppy disk at the MS-DOS prompt, please type the command as noted below. Without this option, the disk will not be formatted correctly.

FORMAT A: /F:1.44

PC Cards

Type I or II




15mm (0.197")
15mm (0.197")
15mm (0.197")

The PCMCIA card slots accept PC cards that conform to the PC card standard.

Up to three Type I/II (thickness: 5 mm (0.197 inch) or less) cards can be inserted.

Type III




10.5mm (0.414")

Or, one Type I/II and one Type III card (1.8-inch hard disk drive, etc.) can be inserted; the Type III card can only be inserted into the bottom slot.

◆NOTE◆


- In order to use PC cards, the appropriate PC card device drivers must be installed.
- Make sure that the combined operating current of your PC cards does not exceed the maximum allowable current of the card slots. If the output current limit (3.3V, 400mA; 5V, 400mA; 12V, 120mA) is exceeded, malfunction may result.
- Only the bottom slot can support a Zoomed Video (ZV) card.

Mounting ▶




Insert your PC card and slide it in until it is firmly in place. As you slide the card in, a button will pop out that enables you to remove the card. (NOTE: The PC card should have an arrow indicating how it is to be inserted.)

Removal ▶



Button

Press the button to displace the card.



Remove the card by pulling it out.

◆NOTE◆

If you use CardWorks software, please refer to its on-line Quick Reference Guide. (Click [Start]-[Programs]-[Panasonic]-[CardWorks Quick Reference Guide].)

Memory Expansion


A RAM module may be installed in the computer to increase the computer's memory.

RAM module specifications
144 pins, 60/70 ns, 3.3 V, SO-DIMM, EDO

◆NOTE◆

Do not add or remove additional memory while the computer is in the suspend or hibernation mode. Doing so could damage the unit or prevent the module from being properly recognized.

Mounting ▶




Turn the computer off by pressing **[Fn]** and holding the power switch in the ON position simultaneously.





Use a screwdriver to loosen the two screws located toward the front of the computer.




Remove the cover.




Put the RAM module into the slot diagonally; the side with the metal connectors goes into the slot. Then, press down on the module until it snaps into place and is held firmly down by the hooks.




Removal ▶



Pull the hooks on both sides outwards.




Gently remove the RAM module from the slot.



Replace the cover and tighten the two screws.

Expansion Bus Port


The expansion bus port gives added functionality to the computer by enabling it to be connected to an optional port replicator (CF-VEB251).



Refer to the instruction manuals for the port replicator for details on installation.

◆MEMO◆

The port replicator (CF-VEB251) is equipped with the same connection terminals as the computer (with the exception of the headphone connector and infrared communication port). By connecting your peripheral devices to the port replicator, you can save yourself the trouble of having to connect and disconnect several cables everytime you transport the computer.



Hard Disk Drive (For technicians at your nearest Panasonic Dealer)

◆CAUTION◆


If your hard disk needs to be replaced, be sure to have it replaced at a Panasonic Service Center. If you replace the hard disk yourself and later encounter problems, Panasonic will not bear any responsibility.

The hard disk drive is extremely sensitive to shock; dropping it (not the computer) from a height of about 3 cm (1 inch) onto a hard surface can permanently damage it. Also, the internal electronic circuitry can be easily damaged by exposure to static electricity.

◆NOTE◆

Do not remove the hard disk while the computer is in the suspend or hibernation mode. In this case, data may be lost when the hard disk is removed.

Removal ▶



Turn the computer off by pressing **Fn** and holding the power switch in the ON position simultaneously.



Turn the computer over.



Use a screwdriver to loosen the two screws located toward the front of the computer.



Remove the outer cover.






Remove the dampers protective cover.




Lift out the hard disk.



Detach the cable connected to the hard disk.



Mounting ▶



Attach a new hard disk.





Return the hard disk into the computer. Be sure that the damper does not get entangled at the bottom of the hard disk.



Place the damper protective cover back onto the computer.




Replace the cover and tighten the two screws.



Infrared Data Transfer

Using the computer's built-in infrared communication port (IrDA compliant), you can transfer data to and from other computers with an infrared port.



Infrared Communication Port

◆NOTE◆


Infrared data transfer requires that the handle not be blocking the channel of communications.

◆NOTE◆

Assuming two computers, it is necessary to make the appropriate settings on both computers so that the addresses of the infrared communication ports can be used. It is recommended that the distance between the two infrared communication ports is between 20 cm (0.65 feet) and 50 cm (1.64 feet).

Data transfer may be affected if there is a TV, VCR, wireless headphone set, incandescent bulb, or stove nearby, or if the computers are in direct sunlight.

Click [Start]-[Programs]-[TranXit]-[TranXit].



TranXit can be used to perform data synchronization (updating the file and data information on both computers to the latest version) and to transfer files between two computers.

◆NOTE◆

- TranXit must be installed on both computers for data transfer. Also, it is necessary to assign a different "Computer Name" to each computer; use [Setup]-[Computer Name] to change the name.
- If you use TranXit software, please refer to its on-line Quick Reference Guide. (Click [Start]-[Programs]-[Panasonic]-[TranXit Quick Reference Guide].)
- Exit TranXit software before entering the suspend or hibernation mode. Start TranXit again after the computer resumes.


Setup Utility

Follow the procedure below to specify operating environment settings (device port addresses and IRQs, passwords security, drive protection and reduced power consumption) for the computer.

Startup ▶

Power on.

Press **F1** when the messages "Press F1 for Setup" appear.
(These messages appear only for a few seconds. Setup utility does not run if you delay pressing **F1**.)



Refer to the On-line Help.
(Please press **F1** .)

Specify your operating environment settings (device port addresses and IRQs, password security, drive protection and power consumption) and select [Save Settings].

Select [Exit Setup].

MEMO

Suspend Function : When **F1** + **F7** is pressed, this function maintains the state of the computer (i.e., data remains on memory) until the power is turned back on. It enables you to resume an unfinished operation immediately. The function works only when the battery pack is kept in the computer or the AC adapter is connected.

Hibernation Function : When the power is turned off in this mode, the data in memory is saved onto the hard disk, and when the power is turned back on, the computer is restored to the state it was in before the power was turned off. When this function is enabled, all data is saved even when no power is being supplied to the computer. When the computer is turned on, its previous state(i.e., when the power was last turned off) is displayed.

You can set the 3-type passwords in order to prevent unwanted access to your computer. (When the computer is waiting for inputting the password, the four battery indicators blink.)

User Password : The password when the computer starts up.

Coffee break Password : The password when you leave your desk for a short period. After **Alt** + **Ctrl** + **F9** , **F10** , **F11** or **F12** (set by "Key Combination") are pressed, only by inputting the coffee break password can the computer resume operation. The coffee break password also serves as the user password. Therefore, set the user password first to enable the coffee break password.

Supervisor Password : The password to protect what has been registered for "Supervisor Setup".

NOTE

- Before attempting to remove or install a RAM module, multimedia pocket or port replicator etc. disable the hibernation function.
- The system may not recognize a mouse, modem, PC card, IrDA or other serial devices when its power is turned back on, after the system had been in the suspend or hibernation mode. In this case, re-initialize the device or computer.
- When using the touch pad or external mouse (serial or PS/2 type), do not enter the suspend or hibernation mode. The next time the computer resumes, it may not be possible to use these devices.
- Do not press the power switch or enter the suspend or hibernation mode while the hard disk or MP indicator is on since the computer is still accessing the drive.
- The suspend and hibernation functions cannot be used under an operating system other than Windows 95 or when diagnostics program (DIAG25) or Setup utility has been started.
- Do not use the suspend or hibernation function when an application program which uses the CD has been started. Instability in operation may result.
- If the system enters the suspend or hibernation mode upon pressing **Shift**, the state of the keyboard remains with pressing **Shift** when the system resumes. In this case, press **Shift** again and release it.

Diagnosics Program (DIAG25)

Follow the procedure below to check whether each part of your computer is operating properly.

Set "Power Saving" to "OFF" in the Setup utility.



Insert the "Firstaid FD" into the floppy disk drive and restart the computer.



Type the following:

DIAG25

- 1 Boot
- 2 Restore HDD to factory default (Beginners)
- 3 Restore HDD to factory default (Advanced)

A:\WINDOWS\COMMAND>

Error Codes

If a problem occurs with your hardware, a POST Start up Error(s) is displayed along with an error code(s), follow the on-screen instructions.

Setup: Setup utility (⇒P.24) is started. Run [Load Default Settings (PnP)].

The Setup Utility must be run again to input the appropriate operating environment settings.

Exit: Ignore the error message(s), and restart the computer.

Code	Description
062	Boot failure--default configuration used
101	System Board Failure
102	System Board Failure
106	System Board Failure
114	Adapter ROM Error
151	System Board Failure
161	Bad CMOS Battery
162	Configuration Change Has Occurred
162	Configuration Error
163	Date and Time Incorrect
173	Configuration Change Has Occurred
177	The security passwords have been corrupted
201	Memory Size Error
301	Keyboard Error
303	Keyboard Error
604	Diskette Drive Error
605	Diskette Drive Error
1780	Hard Disk Error
1800	PCI Error
1801	PCI Error
1802	PCI Error
1803	PCI Error
1804	PCI Error
1805	PCI Error
8601	Pointing Device Error
19990301	Hard disk failure
19990305	An operating system could not be found

Dealing with Problems

Read this section if your computer is not operating properly. Note that some problems may be caused by the software in your system. If you are ultimately unable to correct a problem, consult your nearest Panasonic dealer.

Startup ▶

Power does not come on.	→	<ul style="list-style-type: none">• Is the AC adapter plugged into the power supply connector of the computer and an AC outlet?• Is the battery pack sufficiently charged and mounted correctly?• Does the computer operate normally after it has been restarted by pressing the reset button?
Nothing appears on the display screen.	→	<ul style="list-style-type: none">• If the low power consumption function has caused the display to dim, pressing the space bar will restore it.• Have you selected an external display using the Setup utility?• Adjust screen brightness. (⇒ P.7)
Can't remember password.	→	Consult your nearest Panasonic dealer.
"Post Start Up Error(s)" is displayed.	→	Refer to "Error Codes" (⇒ P.25).
Memory counting speed is very slow. Windows start up and processing speed is very slow.	→	Run "Load Default Settings (PnP)" in the Setup utility. This will restore the Setup utility's settings to their default values (except the password settings), then the Setup utility must be run once again for you to input the appropriate operating environment settings. (The processing speed depends on the application software used, so this operation may not cause the processing speed to increase.)

During operation ▶

Date or time display is incorrect.	→	<ul style="list-style-type: none">• Use [Control Panel] in Windows 95 or the DATE and TIME commands in the MS-DOS mode to set the date/time to their proper values. If problems persist, consult your nearest Panasonic dealer.• The clock battery (lithium battery) may be running low on power. Consult your nearest Panasonic dealer.
Computer stops working.	→	If you are running the computer off the battery pack, the battery may be out of power. Connect the AC adapter.
Red battery indicator lights. Repeated beeps sound while the computer is in use.	→	The battery power is low. Save your data and turn off the computer, and then replace or recharge the battery pack.
Red battery indicator lights and a beep sounds.	→	The battery temperature has risen due to the electrical discharge caused by a large load. Connect the AC adapter, set the power-saving function, and turn down the brightness of the display.
Red battery indicator flashes on and off.	→	Are the AC adapter and battery pack both correctly connected? If the red indicator flashes even after reconnecting them, consult your nearest Panasonic dealer.
The battery indicator remains red for a long time.	→	Fully charge the battery pack, switch on the computer, disconnect the AC adapter, and allow the battery pack to discharge completely.
The POWER indicator becomes orange and the CPU processing speed drops.	→	The CPU processing speed will slow automatically to protect the CPU from overheating. The CPU will return to its normal processing speed once it has cooled.

Display ▶

An afterimage appears.

➔ If an image is displayed for a prolonged period of time, an afterimage may appear. This is not a malfunction. The afterimage will disappear when a different screen is displayed.

The motion of a mouse cursor is not smooth.

➔ Click [Start]-[Settings]-[Control Panel]-[Mouse]-[Motion] and check [Show pointer trails].

Drives ▶

Cannot access floppy disk drive.

- Is the floppy disk drive properly installed?
- Has the floppy disk been inserted correctly?
- Has the floppy disk been correctly initialized?
- Has the Setup utility been used to disable the floppy disk drive?

Cannot write to floppy disk.
Cannot format floppy disk.

- Is the floppy disk write-protected?
- Did you enter the correct command and parameters?

Cannot access hard disk drive.

➔ Consult your nearest Panasonic dealer.

Peripheral equipment ▶

Printer does not work.

- Is the cable connected properly?
- Is the printer powered on?
- Is the printer on-line?
- Has the Setup utility been used to set "Parallel Port (Address)" to "Automatic (PnP)", "378" or "3BC"?

External mouse or trackball connected to the serial port does not work.

- Is the cable connected properly?
- Is the mouse's device driver running? Refer to the manual accompanying your mouse.
- Is the mouse connected to both the serial port and the ext. mouse/keyboard port?
- Has the Setup utility been used to set "Internal Pointing Device" to "Disable"?

External mouse or trackball connected to the PS/2 port does not work.

➔ In some circumstances, if a PS/2 external mouse with a serial interface conversion function is connected to the port, it may not operate normally. Connect it to the serial port.

PC cards cannot be used.

- Check the orientation of the card, and make sure it is firmly in place.
- Use only specified cards.
- It is necessary to update drivers to Windows 95. Contact the card manufacturer.
- Be sure to reboot the computer after installing a PC card driver or other device drivers.
- Check the I/O port used by the PC card.
- When the PC card cannot be used after the computer resumes from the suspend or hibernation function, remove the PC card, then install it again.

The RAM module cannot be used.

➔ Check the orientation of the card, and make sure it is firmly in place.

Reinstalling Windows

If the situation calls for a reinstallation of Windows, please follow the instructions below. The CD-ROM pack (CF-VCD252) and the FDD cable (CF-VCF351) are needed for the following reinstallation procedure.

◆CAUTION◆

- Prepare the 6 floppy disks [Firstaid FD (1), Panasonic Tools Disk (1), CardWorks Installation Disk (1), TranXit Disk (2), Drivers Disk (1)] that you saved as backup.
- Please be aware of the following:
 - All data in your computer will be lost. Be sure to back up all files before proceeding.
 - Remove all external devices: the ports/connectors must be free. Also remove all PC cards from their slots.

① With the power off, insert the "FirstaidFD" into the drive. Then, turn the power on.

② The following screen will appear:

1. Boot
2. Restore HDD to factory default (Beginners)
3. Restore HDD to factory default (Advanced)

Select option 1.

③ Type the following:

A: \up\windows\command\Setup25 /F

④ The following screen will appear:

1. Boot
2. Restore HDD to factory default (Beginners)
3. Restore HDD to factory default (Advanced)

<For Beginners (Returning to near-factory default settings)>

Select option 2.

From this point on, follow the instructions on the display.

The computer will be restarted several times during the reinstallation process. When an indication appears on the screen after a restart, select option 2.

<For Advanced Users (Returning drive C to its default condition)>

◆CAUTION◆

This is possible when the hard disk is partitioned. If the hard disk is compressed, please uncompress it.

Select option 3.

⑤ When your computer asks you to insert the "Panasonic Tools FD", Please do so. (It will then ask you to reinsert the "Firstaid FD": simply follow the instructions).

⑥ Insert the Windows95 CD-ROM when instructed. Follow the instructions on the display. (Note: This step takes approximately one hour.)

◆NOTE◆

- For each selection, choose the default setting.
- Be sure to select "Sound, MIDI or Video Capture Card" from the "Analyzing Your Computer" screen during the installation.
- Have a blank floppy disk ready and use it to create a Startup Disk. After creating the Startup Disk, remove it from the drive. And then, insert the "Firstaid FD" and click [OK].

⑦ Click [Finish] when the Windows 95 Setup has finished.

⑧ Click [Close] on the Time Zone Screen.

⑨ Select [Cancel] on the printer setup screen.

⑩ Click [OK] to restart the computer. The system reboots automatically.

⑪ Click [Close] on the Welcome screen.

⑫ After reinstallation, click [Control Panel]-[Power]-[Disk Drives]. Clear both [When powered by AC power:] and [When powered by batteries:] check boxes. Click [OK].

⑬ Click [Control Panel]-[System]-[Device Manager]. Remove all items from "Ports (COM&LPT)" and "Sound, video and game controller". If the message to restart Windows while deleting them, click [No]. Then insert the "DRIVERS DISK" into the drive.


Floppy Disk Drive

Compatible floppy disks ▶


Type	Data recording density	Data recording capacity
2HD (Double sided, High density, Double track)	High	1.44 MB
2DD (Double sided, Double density, Double track)	Low	720 KB

Preventing accidental erasure of data ▶

Set the tab to write protect to prevent your data from being erased or overwritten accidentally.



Inserting and removing floppy disks ▶



◆NOTE◆

Handling a disk in the following ways can cause data to become corrupted or can result in the disk becoming stuck in the drive.

- Sliding the shutter on the disk manually.
- Exposing the disk to a magnetic field.
- Storing the disk in locations prone to high temperatures, low pitched noise, dampness, or dust.
- Applying more than one label on the disk.

Hardware Technical Data

To install expansion cards in the computer, follow the procedure below to obtain an address map. The, select values for the interrupt level (IRQ), I/O port address and memory range and DMA channel that are not being used.

Displaying an address map ▶

- ① Select [Start]-[Settings]-[Control Panel]-[System].
- ② Select [Device Manager].
- ③ Click [Properties].

Printing an address map ▶

- ① Select [Start]-[Settings]-[Control Panel]-[System].
- ② Select [Device Manager].
- ③ Click [Print].
- ④ Click the [System Summary] box and then click [OK].

The standard I/O addresses are listed below.


0000H	-	00FFH	(System Board)
x1F0H	-	x1F7H	(Hard disk drive)
x220H	-	x22FH	(Sound controller)
x2F8H	-	x2FFH	(Infrared communication port)
x378H	-	x37FH	(Parallel port)
x388H	-	x38BH	(FM synthesizer)
x3B0H	-	x3BBH	(Display controller)
x3C0H	-	x3DFH	(Display controller)
x3E0H	-	x3E3H	(PC card controller)
x3F0H	-	x3F7H	(Floppy disk drive)
x3F8H	-	x3FFH	(COM port)

An "X" at the beginning of an address indicates that the address cannot be used, regardless of its value.

Display Properties

The display resolution, number of colors, etc. can be set as followings.

- ① Select [Start]-[Settings]-[Control Panel].
- ② Select [Display].
- ③ Select [Settings].



- ④ Set [Color palette], [Desktop area] and [Font size], and click [OK].

◆NOTE◆

The monitor setting can be changed by selecting [Advanced Properties].

LIMITED USE LICENSE AGREEMENT

THE SOFTWARE PROGRAM(S) ("PROGRAMS") FURNISHED WITH THIS PANASONIC® PRODUCT ("PRODUCT") ARE LICENSED ONLY TO THE END-USER ("YOU"), AND MAY BE USED BY YOU ONLY IN ACCORDANCE WITH THE LICENSE TERMS DESCRIBED BELOW. YOUR USE OF THE PROGRAMS SHALL BE CONCLUSIVELY DEEMED TO CONSTITUTE YOUR ACCEPTANCE OF THE TERMS OF THIS LICENSE.

Matsushita Electric Industrial Co., Ltd. ("MEI") has developed or otherwise obtained the Programs and hereby licenses their use to you. You assume sole responsibility for the selection of the Product (including the associated Programs) to achieve your intended results, and for the installation, use and results obtained therefrom.

LICENSE

- A. MEI hereby grants you a personal, non-transferable and non-exclusive right and license to use the Programs in accordance with the terms and conditions stated in this Agreement. You acknowledge that you are receiving only a LIMITED LICENSE TO USE the Programs and related documentation and that you shall obtain no title, ownership nor any other rights in or to the Programs and related documentation nor in or to the algorithms, concepts, designs and ideas represented by or incorporated in the Programs and related documentation, all of which title, ownership and rights shall remain with MEI.
- B. You may use the Programs only on the single Product which was accompanied by the Programs.
- C. You and your employees and agents are required to protect the confidentiality of the Programs. You may not distribute or otherwise make the Programs or related documentation available to any third party, by time-sharing or otherwise, without the prior written consent of MEI.
- D. You may not copy or reproduce, or permit to be copied or reproduced, the Programs or related documentation for any purpose, except that you may make one (1) copy of the Programs for backup purposes only in support of your use of the Programs on the single Product which was accompanied by the Programs. You shall not modify, or attempt to modify, the Programs.
- E. You may transfer the Programs and license them to another party only in connection with your transfer of the single Product which was accompanied by the Programs to such other party. At the time of such a transfer, you must also transfer all copies, whether in printed or machine readable form, of every Program, and the related documentation, to the same party or destroy any such copies not so transferred.
- F. You may not remove any copyright, trademark or other notice or product identification from the Programs and you must reproduce and include any such notice or product identification on any copy of any Program.

YOU MAY NOT REVERSE ASSEMBLE, REVERSE COMPILE, OR MECHANICALLY OR ELECTRONICALLY TRACE THE PROGRAMS, OR ANY COPY THEREOF, IN WHOLE OR IN PART.

YOU MAY NOT USE, COPY, MODIFY ALTER, OR TRANSFER THE PROGRAMS, OR ANY COPY THEREOF, IN WHOLE OR IN PART, EXCEPT AS EXPRESSLY PROVIDED IN THE LICENSE.

IF YOU TRANSFER POSSESSION OF ANY COPY OF ANY PROGRAM TO ANOTHER PARTY EXCEPT AS PERMITTED IN PARAGRAPH E ABOVE, YOUR LICENSE IS AUTOMATICALLY TERMINATED.

TERM

This license is effective only for so long as you own or lease the Product, unless earlier terminated. You may terminate this license at any time by destroying, at your expense, the Programs and related documentation together with all copies thereof in any form. This license will also terminate effective immediately upon occurrence of the conditions therefor set forth elsewhere in this Agreement, or if you fail to comply with any term or condition contained herein. Upon any such termination, you agree to destroy, at your expense, the Programs and related documentation together with all copies thereof in any form.

YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS. YOU FURTHER AGREE THAT IT IS THE COMPLETE AND EXCLUSIVE STATEMENT OF THE AGREEMENT BETWEEN US, WHICH SUPERSEDES ANY PROPOSAL OR PRIOR AGREEMENT, ORAL OR WRITTEN, AND ANY OTHER COMMUNICATIONS BETWEEN US, RELATING TO THE SUBJECT MATTER OF THIS AGREEMENT.

Beschränkten Nutzungslizenzvertrages

Das (die) mit diesem Panasonic®-Produkt (im weiteren als "Produkt" bezeichnet) gelieferte(n) Programm(e) (im weiteren als "Programme" bezeichnet) wird (werden) nur für den Gebrauch durch den Endnutzer (im weiteren als "der Käufer" bezeichnet) lizenziert und darf (dürfen) ausschließlich gemäß den unten aufgeführten Lizenzbedingungen benutzt werden. Der Gebrauch der Programme durch den Käufer gilt als konkludente Zustimmung des Käufers zu den Bestimmungen dieser Lizenz.

Die Programme wurden von Matsushita Electric Industrial Co., Ltd. (im weiteren als "MEI" bezeichnet) entwickelt oder sie wurden auf andere Weise von MEI erworben, und MEI lizenziert die Programme hiermit für den Gebrauch des Käufers. Der Käufer übernimmt die alleinige Verantwortung dafür, daß die Wahl des Produkts (einschließlich der zugehörigen Programme) die beabsichtigten Zwecke erfüllt, sowie für die Installation, den Gebrauch und die damit erzielten Ergebnisse.

Lizenz

- A. Hiermit erteilt MEI dem Käufer das persönliche, nicht übertragbare und nicht ausschließliche Recht und die Lizenz zur Nutzung der Programme gemäß den Bestimmungen und Bedingungen dieser Vereinbarung. Der Käufer bestätigt, daß er lediglich eine BESCHRÄNKTE LIZENZ ZUM GEBRAUCH der Programme und der dazugehörigen Dokumentation erhält und daß mit dieser Lizenz kein Rechtsanspruch, kein Besitzanspruch und keine anderen Rechte verbunden sind, weder auf die Programme und die dazugehörige Dokumentation, noch auf die Algorithmen, Konzepte, Ausführungen und Ideen, die von den Programmen und der dazugehörigen Dokumentation dargestellt werden oder in diese aufgenommen sind, und daß alle Rechte bei MEI verbleiben.
- B. Der Käufer darf die Programme nur mit genau dem Produkt verwenden, zu dessen Lieferumfang die Programme gehören.
- C. Der Käufer und seine Angestellten und Bevollmächtigten sind zum Schutz der Vertraulichkeit der Programme verpflichtet. Der Käufer darf die Programme und die dazugehörige Dokumentation ohne vorherige schriftliche Genehmigung von MEI nicht an Dritte weitergeben oder sie auf andere Weise, einschließlich von Time-Sharing, Dritten zugänglich machen.
- D. Der Käufer darf die Programme und die dazugehörige Dokumentation zu keinerlei Zwecken kopieren oder reproduzieren und darf auch nicht zulassen, daß sie von anderen kopiert oder reproduziert werden, außer daß der Käufer eine (1) Kopie der Programme ausschließlich für Sicherungszwecke und nur zur Unterstützung der Verwendung der Programme mit genau dem Produkt erstellen darf, zu dessen Lieferumfang die Programme gehören. Der Käufer darf die Programme weder modifizieren noch solche Modifikationen versuchen.
- E. Der Käufer darf die Programme und eine diesbezügliche Benutzerlizenz nur zusammen mit der Übergabe genau des Produktes, zu dessen Lieferumfang die Programme gehören, an einen Dritten übergeben. Zur Zeitpunkt einer solchen Übergabe ist der Käufer verpflichtet, sämtliche von ihm erstellten Kopien, sowohl in gedruckter, als auch in Maschinensprache abgefaßter Form, jedes einzelnen Programms und der dazugehörigen Dokumentation an die gleiche Person zu übergeben und alle nicht übergebenen Kopien zu zerstören.
- F. Der Käufer darf kein Copyright, Warenzeichen oder keine andere Bekanntmachung oder Produktkennzeichnung von den Programmen entfernen und muß jede solche Bekanntmachung oder Produktkennzeichnung auf jeder Kopie eines der Programme reproduzieren.

Der Käufer darf die Programme und davon erstellten Kopien, weder insgesamt noch teilweise, nicht im Reversierverfahren assemblieren, kompilieren oder auf mechanischem bzw. elektronischem Wege abtasten. Der Käufer darf die Programme und deren erstellte Kopien, weder insgesamt noch teilweise benutzen, kopieren, modifizieren, verändern oder weitergeben, es sei denn dies ist im Rahmen dieser Lizenz gestattet.

Falls der Käufer eine Kopie eines der Programme, außer gemäß Absatz E, an Dritte weitergibt, wird diese Lizenz automatisch außer Kraft gesetzt.

Laufzeit der Lizenz

Diese Lizenz ist nur so lange gültig, wie der Käufer das Produkt zu eigen hat oder im Leasing-Verfahren betreibt, falls sie nicht vorher widerrufen wird. Der Käufer darf diese Lizenz zu einem beliebigen Zeitpunkt aufheben, indem er die Programme und die dazugehörige Dokumentation zusammen mit allen davon in jeglicher Form erstellten Kopien auf eigene Kosten zerstört. Diese Lizenz wird außerdem mit sofortiger Wirkung aufgehoben, wenn eine der oben aufgeführten Bedingungen eintritt oder der Käufer irgendetwas Bestimmungen oder Bedingungen dieser Lizenzvereinbarung verletzt. Der Käufer verpflichtet sich, nach einer solchen Aufhebung der Lizenz die Programme und die dazugehörige Dokumentation zusammen mit allen davon in jeglicher Form erstellten Kopien auf eigene Kosten zu zerstören.

Der Käufer bestätigt, diese Vereinbarung gelesen und verstanden zu haben, und verpflichtet sich, ihre Bestimmungen und Bedingungen einzuhalten. Der Käufer bestätigt weiterhin, daß es sich bei der vorliegenden Vereinbarung um eine vollständige und ausschließliche Aufzeichnung der Vereinbarung zwischen dem Käufer und MEI handelt, die alle Vorschläge oder früheren Vereinbarungen, in mündlicher oder schriftlicher Form, sowie jegliche Unterredungen zwischen dem Käufer und MEI in Bezug auf die Gegenstände der vorliegenden Vereinbarung ablöst.

Contrat de licence d'usage limité

Le(s) logiciel(s) (les "Logiciels") fournis avec ce produit Panasonic® (le "Produit") sont exclusivement concédés en licence à l'utilisateur ultime ("vous"), et ils ne peuvent être utilisés que conformément aux clauses contractuelles ci-dessous. En utilisant les logiciels, vous vous engagez de manière définitive à respecter les termes, clauses et conditions des présentes.

Matsushita Electric Industrial Co., Ltd. ("MEI") a mis au point ou obtenu les Logiciels et vous en concède l'utilisation par les présentes. Vous assumez l'entière responsabilité du choix de ce Produit (y compris des Logiciels associés) pour obtenir les résultats escomptés, ainsi que de l'installation, de l'utilisation et des résultats obtenus.

Licence

- A. MEI vous octroie par les présentes le droit et la licence personnels, non cessibles et non exclusifs d'utiliser les Logiciels conformément aux termes, clauses et conditions de ce Contrat. Vous reconnaissez ne recevoir qu'un droit limité d'utiliser les Logiciels et la documentation les accompagnant et vous vous engagez à n'obtenir aucun droit de titre, propriété ni aucun autre droit vis-à-vis des Logiciels et de la documentation les accompagnant ni vis-à-vis des algorithmes, concepts, dessins, configurations et idées représentés par ou incorporés dans les Logiciels et la documentation les accompagnant, dont les titres, propriété et droits resteront tous à MEI.
- B. Vous ne pouvez utiliser les Logiciels que sur le Produit unique qui est accompagné par les Logiciels.
- C. Vous et vos employés ou agents êtes requis de protéger la confidentialité des Logiciels. Vous ne pouvez ni distribuer ni mettre les Logiciels et la documentation les accompagnant à la disposition d'un tiers, par partage de temps ou de quelque autre manière que ce soit, sans l'autorisation écrite préalable de MEI.
- D. Vous ne pouvez ni copier ni reproduire ni permettre la copie ni la reproduction des Logiciels ni de la documentation les accompagnant pour quelque fin que ce soit, à l'exception d'une (1) copie des Logiciels à des fins de sauvegarde uniquement pour soutenir votre utilisation des Logiciels sur le Produit unique qui est accompagné par les Logiciels. Vous ne pouvez ni modifier ni tenter de modifier les Logiciels.
- E. Vous ne pouvez céder les Logiciels et en octroyer la licence à une autre partie qu'en rapport avec votre cession du Produit unique qui est accompagné par les Logiciels à cette autre partie. Au moment de cette cession, vous devez céder également toutes les copies, que ce soit sous forme imprimée ou lisible par la machine, de tous les Logiciels ainsi que de la documentation les accompagnant, à la même partie ou détruire les copies non cédées.
- F. Vous ne pouvez retirer aucune marque de droits d'auteur, marque ou autre ni aucune identification de produit des Logiciels et vous devez reproduire et inclure toutes ces notices ou identifications de produit sur toutes les copies des Logiciels.

Vous ne pouvez assembler en sens inverse, compiler en sens inverse ni retracer les Logiciels ni aucune de leurs copies, de façon électronique ou mécanique, en tout ou en partie.

Vous ne pouvez utiliser, copier, modifier, altérer ni céder les Logiciels ni aucune de leurs copies, en tout ou en partie à l'exception de ce qui est expressément stipulé dans ce contrat.

Si vous cédez la possession de toute copie ou de tout Logiciel à une autre partie, à l'exception de ce qui est autorisé au paragraphe E ci-dessus, votre licence est automatiquement résiliée.

Termes, clauses et conditions

Cette licence n'est effective que pour la durée de possession ou de crédit-bail du Produit, à moins d'une résiliation antérieure. Vous pouvez résilier cette licence à tout moment en détruisant, à vos frais, les Logiciels et la documentation les accompagnant avec toutes leurs copies, sous quelque forme que ce soit. Cette licence sera également résiliée, avec application immédiate, si les conditions de résiliation définies ailleurs dans ce contrat se sont réalisées ou si vous ne respectez pas les termes, clauses et conditions qui y sont contenues. Au moment de la résiliation, vous acceptez de détruire, à vos frais, les Logiciels et la documentation les accompagnant avec toutes leurs copies, sous quelque forme que ce soit.

Vous reconnaissez avoir lu ce contrat, en avoir compris toute la substance et avoir accepté de respecter ses termes, clauses et conditions. Vous reconnaissez en outre qu'ils sont la description complète et exclusive du contrat conclu entre nous, contrat qui remplace et annule toute proposition ou contrat précédent, écrit ou oral, et toute autre communication entre nous, relativement à l'objet du présent contrat.

Specifications

Model No.	CF-25FJF4DAM	
CPU	Pentium® Processor (150 MHz, 2.9 V)	
Cache Memory	Internal Cache : 16 KB External Cache : 256 KB	
LCD	12.1" Non Glare Active Matrix (TFT) 800 X 600	
VRAM	2 MB	
Memory	16 MB (Expandable to 48 MB)	
Floppy Disk Drive	1.44 MB (Double-sided, High-density, Double track) 720 KB (Double-sided, Double-density, Double track)	
Hard Disk Drive*1	2 GB*2 (16 msec / Enhanced IDE)	
Sound	16 bits 44.1 kHz	
Speaker	Mono Speaker (built in)	
Keyboard	Windows 95 Keyboard (87keys)	
Pointing Device	Touch Pad	
Indicator	LED X 8 (Battery, Power, CapsLock, NumLk, ScrLk, Key Pad, MP, HD)	
Slots	PC (PCMCIA) Card Slots: 3 Slots for Type I or II / 1 Slot for Type III (supports ZV Port (bottom slot)), Output current limit: 3.3 V: 400 mA, 5 V: 400 mA, 12 V: 120 mA Expansion RAM Slot, Multimedia Pocket Slot	
Ports	Parallel Port:	Dsub 25-pin female
	Serial Port:	Dsub 9-pin male
	Ext. Display Port:	Mini Dsub 15-pin female
	Ext. Mouse / Keyboard Port:	Mini DIN 6-pin female
	Expansion Bus Port:	Dedicated 80-pin female
	Headphone Connector:	Stereo output (Miniature jack, 3.5 DIA) Impedance 32 Ω Output power 4 mW (impedance 32 Ω) X 2
	DC-IN Connector:	Mini jack
	Infrared Communication Port:	IrDA compliant (Speed: 115,200 bit/sec)
Battery	Battery Pack:	Ni-MH (Nickel Metal Hydride) rechargeable battery pack, 9.6 V, 3600 mAh Operating Time : 2.0-3.2 hours (Depending on the conditions) Charging Time : Power on : approx. 4.5 hours*3 Power off : approx. 2.2 hours*3
	Clock Battery:	Coin type lithium battery, 3.0 V Operating Time: approx. 10 years
Power Saving	Suspend function, Hibernation function, Standby function	
Software	Operating Environment:	Microsoft® Windows® 95 (pre-installed)
	Utility Programs:	Setup, Diagnostics, CardWorks™, TranXit™
AC Adapter	100 - 240 V AC 50 / 60 Hz Auto Sensing / Switching 15 V DC, 2.6 A	
Security	Password function (Supervisor Password, User Password, Coffee break Password)	
Physical Dimensions (Width X Height X Depth)	299 mm (11.8") X 59 mm (2.3") X 237 mm (9.3") (Not including protrusions)	
Weight	3.5 kg (7.7 lbs) + handle 0.2 kg (0.4 lbs)	
Environment (Temperature/ Humidity range)	Operating: 5 °C to 35 °C (41 °F to 95 °F) / 30 % to 80 % RH (no condensation) Storage: -20 °C to 60 °C (-4 °F to 140 °F) / 30 % to 90 % RH (no condensation)	

*1 The hard disk drive contains a partition (approx. 90 MB) for system use.

*2 1 GB = 10⁹ bytes

*3 These values serve only as guidelines.

Model No.	CF-25EGC4DAM	
CPU	Pentium® Processor (133 MHz, 2.9 V)	
Cache Memory	Internal Cache : 16 KB External Cache : 256 KB	
LCD	10.4" Non Glare Active Matrix (TFT) 800 X 600	
VRAM	2 MB	
Memory	16 MB (Expandable to 48 MB)	
Floppy Disk Drive	1.44 MB (Double-sided, High-density, Double track) 720 KB (Double-sided, Double-density, Double track)	
Hard Disk Drive* ¹	1.44 GB* ² (16 msec / Enhanced IDE)	
Sound	16 bits 44.1 kHz	
Speaker	Mono Speaker (built in)	
Keyboard	Windows 95 Keyboard (87keys)	
Pointing Device	Touch Pad	
Indicator	LED X 8 (Battery, Power, CapsLock, NumLk, ScrLk, Key Pad, MP, HD)	
Slots	PC (PCMCIA) Card Slots: 3 Slots for Type I or II / 1 Slot for Type III (supports ZV Port (bottom slot)), Output current limit: 3.3 V: 400 mA, 5 V: 400 mA, 12 V: 120 mA Expansion RAM Slot, Multimedia Pocket Slot	
Ports	Parallel Port:	Dsub 25-pin female
	Serial Port:	Dsub 9-pin male
	Ext. Display Port:	Mini Dsub 15-pin female
	Ext. Mouse / Keyboard Port:	Mini DIN 6-pin female
	Expansion Bus Port:	Dedicated 80-pin female
	Headphone Connector:	Stereo output (Miniature jack, 3.5 DIA) Impedance 32 Ω Output power 4 mW (impedance 32 Ω) X 2
	DC-IN Connector:	Mini jack
	Infrared Communication Port:	IrDA compliant (Speed: 115,200 bit/sec)
Battery	Battery Pack:	Ni-MH (Nickel Metal Hydride) rechargeable battery pack, 9.6 V, 3600 mAh Operating Time : 2.0-3.2 hours (Depending on the conditions) Charging Time : Power on : approx. 4.5 hours* ³ Power off : approx. 2.2 hours* ³
	Clock Battery:	Coin type lithium battery, 3.0 V Operating Time: approx. 10 years
Power Saving	Suspend function, Hibernation function, Standby function	
Software	Operating Environment:	Microsoft® Windows® 95 (pre-installed)
	Utility Programs:	Setup, Diagnostics, CardWorks™, TranXit™
AC Adapter	100 - 240 V AC 50 / 60 Hz Auto Sensing / Switching 15 V DC, 2.6 A	
Security	Password function (Supervisor Password, User Password, Coffee break Password)	
Physical Dimensions (Width X Height X Depth)	299 mm (11.8") X 59 mm (2.3") X 237 mm (9.3") (Not including protrusions)	
Weight	3.3 kg (7.3 lbs) + handle 0.2 kg (0.4 lbs)	
Environment (Temperature/ Humidity range)	Operating: 5 °C to 35 °C (41 °F to 95 °F) / 30 % to 80 % RH (no condensation) Storage: -20 °C to 60 °C (-4 °F to 140 °F) / 30 % to 90 % RH (no condensation)	

*¹ The hard disk drive contains a partition (approx. 90 MB) for system use.

*² 1 GB = 10⁹ bytes

*³ These values serve only as guidelines.

For LCD

Resolution (Pixels)	Color	LCD	Refresh Rate (Hz)	
			CRT (Max.)	LCD/SIM
640 x 480	256 High Color (16 bits) True Color (24 bits)	The screen is displayed in the center of LCD.	85	CRT is also displayed as the same size as LCD.
800 x 600	256 High Color (16 bits) True Color (24 bits)	Full screen		
1024 x 768	256 High Color (16 bits)	Part of the display may exceed the boundaries. (The screen can be scrolled by moving the cursor to the edges of the display.)		

Index

A	
AC Adapter	8
AC Cord	8
B	
Battery Indicator	6,13
Battery	12
Battery Power	12
C	
CardWorks	19,29
Click	11
D	
DC-IN Connector	6
Diagnostics Program	25
Display (LCD)	6,38
Double Click	11
Drag	11
E	
Error Codes	25
Expansion Bus Port	7,21
Ext. Mouse/Keyboard Port	6
Ext. Display Port	7
F	
Firstaid FD	9
Floppy Disk Drive	30
H	
Hard Disk Drive	22
Hardware Expansion	18
Headphone Connector	6
I	
Infrared Communication Port (IrDA Compliant)	6,23
Infrared Data Transfer	23
k	
Keyboard	6,10
Key Combinations	10
L	
License Agreement	8,33
M	
Multimedia Pocket	7,18
Memory Expansion	20
MP Release	7,18
MS-DOS Mode	9
P	
Parallel Port	7
PC Card Slots	6,19
Port Replicator	21
Power Indicator	6
Power Switch	6,8
Precautions	5
R	
RAM Module	20
Reinstalling Windows	28
Reset Button	6
S	
Serial Port	7
Setup Utility	24
Shutdown	9
Speaker (Built-in)	7
Specifications	36
Startup	8
T	
Touch Pad	6,11
TranXit	23
W	
Windows 95 Setup	8

Customer's Record

Model No. _____	Dealer's Name _____
Serial No. _____	_____
or	
Code No. _____	Dealer's Address _____
Date of Purchase _____	_____



As an ENERGY STAR Partner, Panasonic has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

Outline of the International ENERGY STAR Office Equipment Program

The international ENERGY STAR Office Equipment Program is an international program that promotes energy saving through the use of computers and other office equipment. The program backs the development and dissemination of products with functions that effectively reduce energy consumption. It is an open system in which business proprietors can participate voluntarily. The targeted products are office equipment such as computers, displays, printers, facsimiles, and copiers. Their standards and logos are uniform among participating nations.