

Panasonic®

Operating Instructions Portable CD Player

SL-CT520 SL-CT521C

Dear Customer

Thank you for purchasing this product.
Before connecting, operating or adjusting this product, please read these instructions completely.
Please keep this manual for future reference.



Panasonic Consumer Electronics Company,
Division of Matsushita Electric Corporation of America
One Panasonic Way Secaucus, New Jersey 07094 <http://www.panasonic.com>

Panasonic Sales Company,
Division of Matsushita Electric of Puerto Rico, Inc. ("PSC")
Ave. 65 de Infantería, Km. 9.5 San Gabriel Industrial Park, Carolina,
Puerto Rico 00985
Panasonic Canada Inc.
5770 Ambler Drive, Mississauga, Ontario L4W 2T3 www.panasonic.ca
© 2004 Matsushita Electric Industrial Co., Ltd.
Printed in China

RQT7814-P
F1004TT0

Troubleshooting guide

Before requesting service, make the following checks. If you are in doubt about some of the check points, or if the remedies indicated in the chart do not solve the problem, refer to the "Customer Services Directory" on page 3 if you reside in the U.S.A., or refer to the "Product information" on page 3 if you reside in Canada.

<p>No play.</p>	<ul style="list-style-type: none"> •The HOLD function is on. Release HOLD (←page 5). •The batteries may be depleted (←page 5). •The disc isn't correctly set. •The disc is scratched or dirty. (Tracks may be skipped particularly with MP3 discs.) •There is moisture on the lens. Wait for about an hour and then try again. •The lens is dirty: clean it with a blower (recommended product: SZZP1038C). If the lens gets marked with fingerprints, gently wipe them off with a cotton swab. •The unit may not read a track properly if shaken strongly during disc reading. •If there is no data between sessions on a multi-session disc, play may not be possible. •If there is a large amount of JPEG data etc. within a MP3 file, sound may be muted and play may not be possible. •If the disc contains data with different formats, sound may be muted and play may not be possible. •If a CD-ROM format disc contains MP3 and other files, only the MP3 files will be playable. 	<p>Cannot specify point A or B.</p>	<p>You may not be able to specify point A or B at the end of disc.</p>
<p>No sound or there is a lot of noise.</p>	<ul style="list-style-type: none"> •Ensure the plugs are inserted firmly. •Wipe the plugs with a clean cloth. •The sound may be interrupted or there may be noise when playing MP3 if the recording quality is poor. •The elapsed playing time disappears and sound is interrupted if bumps continue repeatedly. •Separate this unit from mobile telephones. 	<p>Cannot change the Digital Re-master mode, anti-skip mode.</p>	<p>If [◀] or [▶] is pressed before [MEMORY] you cannot change the mode.</p>
<p>Play doesn't resume from the last point stopped.</p>	<ul style="list-style-type: none"> •This doesn't work during random play. •It may not work correctly under some conditions. 	<p>Digital Re-master does not work.</p>	<p>Depending on the type of MP3 disc recording, the effect may not appear.</p>
<p>Play doesn't start from the first track.</p>	<ul style="list-style-type: none"> •Random play modes may be on (←page 6). •Play resumes from where last stopped (←page 5, Play). (If the lid is opened while the unit is turned off, the resume function may not be cancelled.) 	<p>Cannot skip albums.</p>	<p>You cannot skip from the last to first album, or vice versa, during play.</p>
<p>Cannot search through tracks.</p>	<p>You cannot search through a disc with MP3 files.</p>	<p>Cannot hear the remote control's operation tone.</p>	<p>The operation tone may be off (←page 6).</p>
		<p>The remote control does not work properly.</p>	<ul style="list-style-type: none"> •Remove the plug and reinsert it as fully as possible. •Use only the included remote control to operate this unit.
		<p>Cannot recharge.</p>	<ul style="list-style-type: none"> •You aren't using the special rechargeable batteries (←page 5). •You must insert two batteries before you can charge them. •The unit must be off before you can charge.
		<p>The AC adaptor becomes warm during recharging.</p>	<p>This is normal.</p>
		<p>The batteries are taking a long time to recharge.</p>	<p>The batteries may take as long as 4.5 hours to recharge under some conditions.</p>
		<p>Play time is short after recharging.</p>	<ul style="list-style-type: none"> •This may occur the first time you charge the batteries or if you haven't used them for a long time. Play time should be restored after a few recharges. •The batteries can go flat if you leave the AC adaptor connected after charging is complete. •If play is extremely short even after fully recharging the batteries, the batteries may have exceeded their life (Rechargeable batteries can be recharged approximately 300 times). Please purchase new nickel-metal hydride rechargeable batteries (HHR-4AGA/2B).
		<p>The battery indicator fails to appear or is incorrect.</p>	<ul style="list-style-type: none"> •The indicator does not appear when the AC adaptor is connected. •The indicator may not appear correctly when using the rechargeable and dry cell batteries at the same time and under certain conditions.
		<p>The unit stops working.</p>	<p>Disconnect then reconnect all power sources (batteries and AC adaptor).</p>
		<p>Power cuts off.</p>	<p>If you connect or disconnect the AC adaptor, the power cuts off even if batteries are inserted.</p>

Caution

Discontinue use if you experience discomfort with the earphones or any other parts that directly contact your skin. Continued use may cause rashes or other allergic reactions.

■ Batteries

- Do not peel off the covering on the batteries and do not use if the covering has been peeled off.
- Align the poles + and - correctly when inserting the batteries.
- Do not mix different types of batteries or old and new batteries.
- Remove the batteries if you do not intend to use the unit for a long time.
- Do not throw into a fire, short-circuit, disassemble, or subject to excessive heat.
- Do not attempt to recharge dry cell batteries.
- When carrying batteries in a pocket or bag, ensure no metal objects such as necklaces are placed together with them. Contact with metal may cause short-circuiting which can cause a fire.
- Keep out of the reach of small children. Accidental swallowing of batteries can result in stomach and intestinal damage.

■ CDs

- Do not use irregularly shaped CDs.
- Do not use non-specification discs.
- Do not use CDs printed with label printers available on the market.
- Do not use CDs with labels and stickers that are coming off or with adhesive exuding from under labels and stickers.

■ Listening



Do not play your headphones or earphones at a high volume. Hearing experts advise against continuous extended play.

If you experience a ringing in your ears, reduce volume or discontinue use.

Do not use while operating a motorized vehicle. It may create a traffic hazard and is illegal in many areas.

You should use extreme caution or temporarily discontinue use in potentially hazardous situations.

Even if your headphones or earphones are the open-air type designed to let you hear outside sounds, don't turn up the volume so high that you can't hear what's around you.

Sound can be deceiving. Over time your hearing "comfort level" adapts to higher volumes of sound. So what sounds "normal" can actually be loud and harmful to your hearing.

Guard against this by setting your equipment at a safe level BEFORE your hearing adapts.

To establish a safe level:

- Start your volume control at a low setting.
- Slowly increase the sound until you can hear it comfortably and clearly, and without distortion.

Once you have established a comfortable sound level:

- Leave it there.

WARNING:

TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK OR PRODUCT DAMAGE, DO NOT EXPOSE THIS APPARATUS TO RAIN, MOISTURE, DRIPPING OR SPLASHING AND THAT NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS.

CAUTION!

THIS PRODUCT UTILIZES A LASER. USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE. DO NOT OPEN COVERS AND DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.

The socket outlet shall be installed near the equipment and easily accessible or the mains plug or an appliance coupler shall remain readily operable.

IMPORTANT SAFETY INSTRUCTIONS

Read these operating instructions carefully before using the unit. Follow the safety instructions on the unit and the applicable safety instructions listed below. Keep these operating instructions handy for future reference.

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not use this apparatus near water.
- 6) Clean only with dry cloth.
- 7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11) Only use attachments/accessories specified by the manufacturer.
- 12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13) Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



Marking sign is located on bottom of the unit.

MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson multimedia.

THE FOLLOWING APPLIES ONLY IN THE U.S.A.

CAUTION:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any unauthorized changes or modifications to this equipment would void the user's authority to operate this device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product service

- Damage requiring service**—The unit should be serviced by qualified service personnel if:
 - The AC power supply cord or AC adaptor has been damaged; or
 - Objects or liquids have gotten into the unit; or
 - The unit has been exposed to rain; or
 - The unit does not operate normally or exhibits a marked change in performance; or
 - The unit has been dropped or the cabinet damaged.
- Servicing**—Do not attempt to service the unit beyond that described in these operating instructions. Refer all other servicing to authorized servicing personnel.
- Replacement parts**—When parts need replacing ensure the servicer uses parts specified by the manufacturer or parts that have the same characteristics as the original parts. Unauthorized substitutes may result in fire, electric shock, or other hazards.
- Safety check**—After repairs or service, ask the servicer to perform safety checks to confirm that the unit is in proper working condition.

The model number and serial number of this product can be found on either the back or the bottom of the unit.

Please note them in the space provided below and keep for future reference.

MODEL NUMBER _____
SERIAL NUMBER _____

User memo:

DATE OF PURCHASE _____
DEALER NAME _____
DEALER ADDRESS _____
TELEPHONE NUMBER _____

Product information

For product information or assistance with product operation:

In the U.S.A., refer to "Customer Services Directory" below.

In Canada, contact the Panasonic Canada Inc. Customer Care Centre at 905-624-5505, or visit the website (www.panasonic.ca), or an authorized Servicentre closest to you.

ONLY FOR U.S.A.

Panasonic Consumer Electronics Company,
Division of Matsushita Electric Corporation of America
One Panasonic Way Secaucus, New Jersey 07094

Panasonic Sales Company, Division of Matsushita Electric of Puerto Rico, Inc.,
Ave. 65 de Infantería, Km. 9.5
San Gabriel Industrial Park, Carolina, Puerto Rico 00985

Panasonic Audio Products Limited Warranty

Limited Warranty Coverage

If your product listed below does not work properly because of a defect in materials or workmanship, Panasonic Consumer Electronics Company or Panasonic Sales Company (collectively referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

Product or Part Name	Parts	Labor
Radio, Clock Radio, Radio with Tape Player or Recorder, Portable CD Player, IC Recorder, Headphone Stereo, Tape Recorder, Speaker	One (1) Year	One (1) Year
Rechargeable batteries (in exchange for defective item)	Ten (10) Days	Not Applicable
SD Memory Card (in exchange for defective item)	Ninety (90) Days	Not Applicable

During the "Labor" warranty period there will be no charge for labor. During the "Parts" warranty period, there will be no charge for parts. You must mail-in your product during the warranty period. This Limited Warranty excludes both parts and labor for batteries, antennas, and cosmetic parts (cabinet). This warranty only applies to products purchased and serviced in the United States or Puerto Rico. This warranty is extended only to the original purchaser of a new product which was not sold "as is". A purchase receipt or other proof of the original purchase date is required for warranty service.

To obtain service in the USA please contact:

Panasonic Services Company, Panasonic Plus Department
20421 84th Avenue South
Kent, WA 98032
Tel: 1-800-833-9626 Fax: 1-800-237-9080

For assistance in Puerto Rico call Panasonic Sales Company (787)-750-4300 or fax (787)-768-2910. When shipping the unit carefully pack and send it prepaid, adequately insured and preferably in the original carton. Include a letter detailing the complaint and provide a day time phone number where you can be reached.

Customer Services Directory

Obtain Product Information and Operating Assistance; locate your nearest Dealer or Servicenter; purchase Parts and Accessories; or make Customer Service and Literature requests by visiting our Web Site at: <http://www.panasonic.com/consumersupport> or, contact us via the web at:

<http://www.panasonic.com/contactinfo>

You may also contact us directly at:

1-800-211-PANA (7262),
Monday-Friday 9 am-9 pm; Saturday-Sunday 10 am-7 pm, EST.

For hearing or speech impaired TTY users, TTY: 1-877-833-8855

Limited Warranty Limits And Exclusions

This warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, introduction of sand, humidity or liquids, commercial use such as hotel, office, restaurant, or other business or rental use of the product, or service by anyone other than a Factory Servicenter or other Authorized Servicer, or damage that is attributable to acts of God.

THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE".

THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. (As examples, this excludes damages for lost time, cost of having someone remove or re-install an installed unit if applicable, travel to and from the servicer, loss of or damage to media or images, data or other memory or recorded content. The items listed are not exclusive, but are for illustration only.)

ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the exclusions may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Servicenter. If the problem is not handled to your satisfaction, then write to the warrantor's Consumer Affairs Department at the addresses listed for the warrantor.

PARTS AND SERVICE, WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY, ARE YOUR RESPONSIBILITY.

Accessory Purchases

Purchase Parts, Accessories and Instruction Books online for all Panasonic Products by visiting our Web Site at: <http://www.pasc.panasonic.com> or, send your request by E-mail to: npcparts@us.panasonic.com You may also contact us directly at:
1-800-332-5368 (Phone) 1-800-237-9080 (Fax Only) (Monday-Friday 9 am to 8 pm, EST.)
Panasonic Services Company
20421 84th Avenue South, Kent, WA 98032
(We Accept Visa, MasterCard, Discover Card, American Express, and Personal Checks)

For hearing or speech impaired TTY users, TTY: 1-866-605-1277

Service in Puerto Rico

Matsushita Electric of Puerto Rico, Inc. Panasonic Sales Company/
Factory Servicenter:
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park, Carolina,
Puerto Rico 00985
Phone (787) 750-4300, Fax (787) 768-2910

Supplied Accessories

Check the packing carton for these accessories.

- **1 Wired remote control:** N2QCBD000049

For U.S.A.

- **1 Pair of stereo headphones:** LOBAD0000173

For Canada

- **1 Pair of stereo earphones:** LOBAB0000183

SL-CT520 ONLY

- **1 External battery case:** RFA2666-H

SL-CT521C ONLY

- **1 Car power adaptor:** SH-CDC12PEY
- **1 Car stereo cassette adaptor:** SHCDM10B1PYK

Use numbers indicated when ordering replacements or optional accessories from your Panasonic dealer.

(Product numbers correct as of October 2004. These may be subject to change.)

To order accessories in the U.S.A., refer to "Accessory Purchases" on page 3.

Display

hold	The HOLD function is on. Release HOLD (⇄page 5).
no disc	<ul style="list-style-type: none"> ● You haven't inserted a disc or it isn't inserted correctly. ● You have inserted a disc this unit cannot play.
open	The disc lid is open.
F	The program already contains 20 tracks.
MP3	Reading MP3 files.

Specifications

Audio (CD-DA)

Sampling frequency: 44.1 kHz
No. of channels: 2 (left and right, stereo)

Frequency response: 20 Hz to 20,000 Hz (+0.5 dB to -7.0 dB)

Headphone output level: RMS max. 8 mW+8 mW/16 Ω (adjustable)

Pickup

Light source: Semiconductor laser
Wavelength: 780 nm

MP3

Supported bit rates (Supports variable bit rates): 32 kbps to 320 kbps (128 kbps is recommended)

Supported sampling frequency: 48 kHz/44.1 kHz/32 kHz

Maximum number of items (total no. of albums and tracks): 999
Maximum album levels: 100

General

Power supply: DC input (via AC adaptor, not included): DC 4.5 V

Operational temperature range: 0 °C-40 °C (32 °F-104 °F)

Rechargeable temperature range: 5 °C-40 °C (41 °F-104 °F)

Play time:

Using on a flat stable surface at 25 °C (77 °F), EQ is off, Hold is on, Anti-skip is on POS 1 (CD-DA), recommended bit rate (MP3:128 kbps), and the Digital Re-master is off (MP3). Play times are in hours and approximate.

Batteries used	MP3 disc	CD-DA disc
2 alkaline batteries (LR03)	45	26
SL-CT520 2 alkaline batteries (LR6)	110	60
SL-CT520 4 alkaline batteries (2 LR03+2 LR6)	155	86
2 optional rechargeable batteries (HHR-4AGA/2B)	30	16
SL-CT520 2 optional rechargeable (HHR-4AGA/2B) and 2 alkaline (LR6) batteries	140	76

Recharging time: About 3.5 to 4.5 hours
 ● The play time may be less depending on the operating conditions.
 ● Play time will be considerably reduced when playing CD-RW.

Dimensions (W×H×D): 136.7 mm×19.9 mm×136.7 mm (5³/₈"×²⁵/₁₆"×5³/₈")

Mass: 179 g (6.3 oz.) (with batteries)
155 g (5.5 oz.) (without batteries)

Note:

Specifications are subject to change without notice.

Mass and dimensions are approximate.


Connections

Turn off this unit and the other equipment before connection.

Insert each plug fully. [Plug type: 3.5 mm (1/8 in.) stereo]

When the unit is connected to other equipment, adjust the volume on the connected equipment.

(Product numbers correct as of October 2004. These may be subject to change.)



Note on CD-R and CD-RW

(CD-DA/MP3 only)

For CD-DA format, use a music disc and finalize* it after recording. The unit may not be able to play some discs due to the condition of the recording.


*A process performed after recording that enables CD-R/CD-RW players to play audio CD-R and CD-RW.

Playing MP3

MP3: A method of compressing data with little loss to the original sound quality.

■ When creating MP3 files to play on this unit


Disc formats: ISO9660 level 1 and level 2 (except for extended formats)



■ Unit limitations

- This unit is compatible with multi-session discs but if there are a lot of sessions it takes more time for play to start. Keep the number of sessions to a minimum to avoid this.
- This unit cannot play files recorded using packet write.
- Depending on how you create MP3 files, they may not play in the order you numbered them or may not play at all.

Dry cell batteries (not included)



- Fit the battery lid so it is secure and flush with the battery compartment. If it comes loose, it may scratch your discs.

SL-CT520 ONLY


External battery case

You can get longer play time by attaching this case. (The unit will also work when using the case only.)



The battery indicator

This indicator appears when the unit is on.



- Before play starts the battery indicator level may temporarily go down or flash although the batteries are not drained. It appears correctly once you start play.

Rechargeable batteries (not included) Charge before initial use.

As a safety precaution this unit is constructed so it is not possible to charge ordinary batteries. For details, check with your dealer.


When charging, use only the following Panasonic Nickel-metal hydride rechargeable batteries.
HHR-4AGA/2B (set of 2)

You cannot charge any other type of rechargeable/dry cell batteries.



Turn the unit off (⇄below) before charging.

- Insert the same way as the dry cell batteries.



Charging starts.

The “CHG” lamp lights.
During charging, “ ” scrolls on the remote control.

Charging complete.

The “CHG” lamp goes out.

- You can charge the batteries before they are fully discharged.

AC adaptor (not included)

The unit will also work when using the AC adaptor only. Connect the AC adaptor (⇄above).

Car power adaptor (SL-CT521C ONLY)

Refer to the separate installation instructions.

Button control guide

Open lid	OPEN ▶	Slide in direction of arrow. Inserting/removing a disc
Play	▶/■ (Remote control) ▶/■ (Main unit)	Lights while playing MP3 Press. Current track number Elapsed play time of track ● Play begins from where last stopped (Resume function). (This will be cancelled if you open the lid.)
Skip	▶▶ (Forward) ◀◀ (Backward)	Press. ● Press [▶▶] twice consecutively to skip to the previous track during play. ● You cannot use [▶▶] to skip to the previous track during random and random repeat (⇄page 6) modes.
Search	▶▶ (Forward) ◀◀ (Backward)	During play, press and hold. ● You can only search within the current track except for during all track repeat (⇄page 6) and regular play.
Album skip	▶▶ (Forward) ◀◀ (Backward)	Until the album you want appears, press and hold. Album number Number of tracks

Volume control (0-25)	+ (Increase) - (Decrease)	Press.
Pause	▶/■ (Main unit)	Press. ● Press again to restart play.
Stop/Turn off	▶/■ (Remote control) ■ (Main unit)	Press. CD-DA 11 51:52 Number of tracks Total play time MP3 ALBUM 6 - 25 Number of albums Number of tracks ● Press and hold to turn the unit off. (Remote control)/ Press again to turn the unit off. (Main unit) ● If the unit is left in stop mode for approximately 10 minutes, the unit turns itself off automatically.
HOLD (Function lock)	HOLD ▶	Slide in direction of arrow. (Slide in opposite direction to cancel.) ● The unit and remote control each have independent HOLD switches.


Using the Remote Control

EQ button



Changing the sound quality

Each time you press [EQ], while displayed



- "3d-1" or "3d-2" disappears after being selected and "3D" appears instead.
- The effect may differ with different kinds of music.
- Depending on the recording conditions, sound may be interrupted when switching between EQ settings.
- If you select 3d-1 or 3d-2 then try playing a disc that contains both CD-ROM format and CD-DA format tracks, there will be a brief noise when the disc changes from playing the CD-ROM format track to the CD-DA format one.

Changing the remote control operation tone

Each time you press and hold [EQ]




MODE button



Play modes

Each time you press [MODE]



■ Specifying the AB segment

Press [MEMORY] at the start point (A) and once more at the end point (B).




- Stop or skip (↔page 5) to cancel.
- If you do not specify point B this will automatically be set as the end of the disc. Repeat begins when this point is reached. You can specify point B again by pressing [MEMORY].

- You cannot select "RND" and "A B" while playing MP3.

Playing only the tracks in a selected album (Album mode)

MP3

Each time you press and hold [MODE]



- To select another album (↔page 5, Album skip)
- You cannot turn album mode on during program play (↔below).

MEMORY button



Program desired tracks only (Program play)

While stopped, use [◀◀] or [▶▶] to select the track, then press [MEMORY].

Will appear after [MEMORY] is pressed



Repeat to program up to 20 tracks.

Play	▶/■	Press after all desired tracks have been programmed.
Confirm	MEMORY	Press during play.
Cancel	▶/■	Press during play. ("M" disappears.)

Changing the anti-skip mode (CD-DA)

The anti-skip function (ANTI-SKIP SYSTEM) reduces or eliminates skipping caused by vibration. You can change the anti-skip memory time.

While stopped, each time you press and hold [MEMORY]



Sound enhanced mode, 10-second anti-skip memory

Anti-skip enhanced mode, 45-second anti-skip memory

- You cannot change the memory time for MP3. It's a maximum of 100 seconds for MP3 recorded at 128 kbps.

Enjoying more natural sound (Digital Re-master)

MP3

You can regenerate signal frequency lost during compression, restoring the sound to near pre-compression form.

While stopped, each time you press and hold [MEMORY]

