


PCN3

Operating Instructions

Rice Cooker
SR-3NA



 **National**

Before using this cooker, please read these instructions completely.

ENGLISH P3 - P4

在使用本機前，請詳細閱讀此使用說明書。

中文 P5 - P6

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plugs, and Rice Cooker, except lid and pan, in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
12. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
13. Do not use appliance for other than intended use.

14. SAVE THESE INSTRUCTIONS

This product is intended for household use.


NOTE

- A. A short power supply cord set is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- B. Longer cord set or extension cords are available and may be used if care is exercised in their use.
- C. If a longer cord set or extension cord is used,
 - (1) the marked electrical rating of the cord set or extension cord should be at least as great as the electrical rating of the appliance,
 - (2) the longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

This appliance has a polarized plug: (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

PARTS IDENTIFICATION

各部位名稱




SPECIFICATIONS 規格

Model	型號	SR-3NA	
Power consumed	消耗電力	200 W	200瓦
Capacity	容量	0.18L ~ 0.27L (2 ~ 3 cups) 0.18公升 ~ 0.27公升(二 ~ 三杯)	
Cord length	電線長	Approx. 1 m	約1公尺

HOW TO USE

1. Measure rice with the provided measuring cup. One cup of uncooked rice will make about 3 cups of cooked rice.



2. Wash rice 4 or 5 times with fresh water in a separate bowl. Wash until water becomes relatively clear.
3. Put the rice into the pan and add water. As a rule, add water to uncooked rice in the following standard proportions.

(See SOME HELPFUL HINTS)

RICE (No. of cups)	WATER (No. of cups)
2	2-2 ¹ / ₃
3	3-3 ² / ₃


4. Place the pan directly on the internal heating plate, and make sure that the pan is properly located on the heating plate by turning it slightly to the right and left as shown.

(see CAUTION)
Before placing the pan in the cooker, wipe off water and moisture from the outside (especially the bottom) of the pan.



5. Cover with the lid.
6. Insert the plug firmly into a wall outlet.

7. Press the switch button down to the "ON" position. Make sure the pilot lamp is on. When the rice is done, the switch will turn off automatically, the lamp will go out and a click will be heard.



8. Even after the switch is off, leave the lid on for at least 15 minutes to steam rice.
9. Unplug after use. Grasp plug, not the cord.

SOME HELPFUL HINTS

- Always tasty rice.

With your National Automatic Rice Cooker you can have uniformly cooked rice, you can even cook rice to your personal taste and preference. Taste of cooked rice depends upon the quality of the rice and the length of time it is soaked in water before being placed into the cooker.

Add more water than specified for softer, more fluffy rice; less water for firmer rice.

- Rice may bubble over.

If you use too much water or if the cooker is tilted, rice may bubble over.

To prevent rice from bubbling over, add water accurately using the cup included.

(Refer to HOW TO USE, Item 3.)

HOW TO CLEAN THE COOKER

Do not immerse the body into water or spray water onto it. Wipe it clean with a wet dishcloth which has been wrung out after being soaked in hot water.

CAUTION


Be sure that the rice cooker is always kept clean, and especially that there is no foreign matter between the pan and the heating plate, or the pan is not dented or deformed. In such cases, the switch may turn off too soon, so the rice will not be properly cooked, or the heating plate may be deformed causing damage to the cooker. Always be sure to use the cooker properly for long, trouble-free service.

* Handling of the pan


If you drop the pan accidentally, if you hit it on a hard surface, or if you place it on another heat source (ex. gas stove), it may become dented or deformed. In such cases, the pan may not maintain a close contact with the heating plate and you will not be able to serve delicious rice.

1. Foreign matter is between the pan and the heating plate.
2. The pan is not sitting properly in the cooker and it does not contact the heating plate adequately.
* For example:
(A) The pan may be caught on the edge of the body.
(B) The bottom of the pan may be sitting on the ledge above the heating plate.
3. Never soak the body in water. When you wash the pan, be sure to remove it from the body.
Never use abrasive powder or steel wool when washing the pan or the lid.
4. When the pan is sitting properly on the heating plate, heat flows directly to the pan and gives superior performance. Place the pan directly on the heating plate and turn it slightly to the right and left to make sure it is in the proper position.
5. Non-stick coated pan may discolor with age. This is normal.
Do not use metal utensils with Non-stick coated pan.

WRONG



RIGHT



使用要領

1. 請用量杯量米。1 杯米大致能煮成相當於該杯 3 杯的米飯。



2. 用清潔的淡水在別的盆子中洗米 4 ~ 5 次。一直洗到盆中的洗米水呈澄清狀態的程度。

3. 將米連水一起投入於電鍋之內鍋中。按規定調整其水量。

(請參照「建議點滴」一項中之說明)

米 (杯數)	水 (杯數)
2	2-2 $\frac{1}{3}$
3	3-3 $\frac{2}{3}$

4. 請將內鍋直接放在加熱板上。如圖所示，向左、右側輕輕地轉動內鍋，便可使之固定得當。(請參照「使用上須知」一項中之說明)

當要將內鍋裝入於電鍋之中以前，內鍋外側，尤其是內鍋底上的水滴一定要拭擦乾淨才行。



5. 蓋上蓋子。
6. 再將電線插頭插入電源插座。

7. 按下開關。
隨之而指示燈就照亮才是。
飯煮好了，電源就自動地斷開，而指示燈就熄滅，隨之而就有「喀啞」的一聲響出。



8. 電源斷開了之後，尚須保持蓋子原樣不動起碼達 15 分鐘以上，以便利用剩餘的熱氣開米飯。
9. 電鍋用完後拔下插銷，抓住插頭拔下，而不是電線。

建議點滴

● 可口米飯，隨心所欲

只要是 National 的自動煮飯電鍋，煮熟均勻，可口美味，隨心所欲，米飯之味道及硬軟程度總要取決於米之質量，以及未投入於電鍋煮以前的浸漬時間之長短。水多於所定的程度時就軟，少時則硬。

● 防止起泡溢出

水量過多或電鍋斜歪時，總未免會起泡溢出。為避免之，應該按照內鍋側壁上所示的水位綫(請參照上述第 3 項說明)，控制得宜所需的水量。

電鍋之洗淨要領

電鍋本體不宜直接浸於水中或澆水在其身上洗滌之。應該用抹布浸過熱水擰緊後加以拭擦才好。

使用上須知

電鍋經常要保持清潔，特別要留意的是，不得有異物夾在內鍋和熱板之間。內鍋當然亦不宜有凹凸不平的痕跡。要不然，往往會使電源斷開得過快，以致使米飯煮成不熟的狀態，甚至還會使熱板起形變以致損傷整個電鍋。只要使用得當，保證經久耐用，不會發生意外。


★內鍋使用上須知

在內鍋的使用上應該指出的是，不得粗枝大葉對待之這一點。否則必將會使之起形變或留下凹凸不平的痕跡。例如由於不小心，偶而使之落下，受到碰傷，或把它攔在瓦斯爐等不同熱源之上使用均不宜。內鍋一旦留下凹凸不平的痕跡或起形變，就無從和熱板緊密相處，自然亦就無從為人而提供美味可口的米飯了。

1. 有異物夾在內鍋和熱板之間。
2. 內鍋在電鍋中的定位狀態不適宜，以致使之和熱板的接觸不得當。
例如：(A) 內鍋就偏靠在電鍋的一邊。
(B) 內鍋底就偏靠在熱板的一邊上。
3. 不宜連電鍋之本體一起澆水洗之。當要洗淨內鍋時，定要從電鍋取出來行之。切忌使用去污粉或鋼絲刷洗之。內鍋如此，護蓋亦然。
4. 內鍋正確地設定在熱板之上。
因為內鍋可以受到熱板之均勻的直接預熱，性能就得到充分的發揮。
將內鍋攔在熱板上之後，隨手稍向左，右方向轉動便可使之固定得當。
5. 長時間使用後，可防止飯粒黏住的塗有薩米夫論表面膜的內鍋會有所褪色。這是正常現象。不要用金屬器具來刷洗塗有薩米夫論表面膜的內鍋。

不適正

1.



2.




3.



適正

4.





**Panasonic Company (West) of America,
 Division of Panasonic Consumer Electronics Company
 Specialty Product Section**

6550 Katella Ave.
 Cypress, CA 90630

QY00A247

MAT0110-0

Printed in Thailand