

Features

Optional PowerPass modules further enhance the reliability of the Powerware 9 Prestige by providing the following:


- Maintenance Bypass Switch to perform maintenance or upgrade your UPS without powering down your critical systems
- Surge protection in the absence of the UPS electronics module during maintenance
- Various receptacle or hardwired configurations
- Increased surge protection for your load
- Galvanic isolation for increased protection
- A transformer that allows power output of 120V and a combination of 120V and 208V-240V

Powerpass Primer Prestige 6000



The Powerware Prestige 6000


ups can be connected to your equipment via a plug-and-play PowerPass or a hardwire PowerPass (Hardwire is a direct connection from the utility distribution panel to the UPS). Use the questions in this guide to determine the need for or to correctly specify a Powerware Prestige 6000 PowerPass Module.






1.	What is the voltage of the incoming utility: 200, 208, 220, 230 or 240 volts? Note: For most U.S. facilities the incoming utility is 208V or 240V.			1 Incoming Utility Voltage			
2.	 a. Your UPS red the spec a mainte a hardw your UP 	ified input voltage of the quires a PowerPass if: cified input voltage is a cenance bypass is require vire connection is specifically system requires galvantagy not require a PowerPa	combination of 100V-12 d. ed. See section 4c. ic isolation.	0V with 200V–240V.	_		ge(s) Required
3.	5-15R*	septacle types required for pecified? See sections 6	L5-30R	6-15R* * Available L5-20 and	on the EPD		No. Required
PLU	JG AND PLAY					Н,	ARDWIRE OPTION


Receptacles Hardwire Output




(2) L5-30R; (8) 5-15R




PPDM **B** (2) L6-20R; (8) 5-15R



PPDM C (2) L6-30R; (8) 5-15R



PPDM **D** (2) L14-30R; (8) 5-15R



PPDM E Hardwire

- Using the information compiled on the opposite page, and the illustrations above, choose the appropriate PowerPass for your Prestige 6000 UPS application.
 - a. If incoming utility is 208V, choose from these options:

UPS OUTPUT	PPDM	PART NUMBER
120V Output (2) L5-30R	Α	101711106-001
120V and 208V Output (2) L6-20R	В	101711106-002
120V and 208V Output (2) L6-30R	C	101711106-003
120V and 240V Output (2) L14-30R	D	101711106-004


b. If incoming utility is 200V, 220V, 230V or 240V choose from these options:

UPS OUTPUT P	PDM	PART NUMBER
100V-120V Output (2) L5-30R	Α	101711106-005
100V–120V and 200V–240V Output (2) L6-20R	В	101711106-006
100V-120V and 200V-240V Output (2) L6-30R	С	101711106-007
100V-120V and 200V-240V Output (2) L14-30R	D	101711106-008

If a hardwire configuration, choose from these options:

UPS OUTPUT	PPDM	PART NUMBER
120V and 208V Output	E	101711105-001
120V and 240V Output	E	101711105-002
120V and 240V Output (50Hz)	E	101711105-003

If the PowerPass options above do not match your application, call your help desk or your value-added distributor for additional options. Options like the Extended Power Distribution Module (EPDM) figured below. The EPDM features customizable receptacle options with breakers and mounting options.



Specifications

Nominal Input Voltage

Input Voltage Range Overvoltage and Undervoltage Limits for Automatic Bypass

(Nominal Values)

Nominal Input Frequency

Operating Input Frequency Range

Maximum Output Apparent Power

Inrush Current

Overcurrent / Input Protection

Backfeed Protection

Maximum Output Current

Nominal Output Frequency

Line Synchronization Range

Steady State Voltage Regulation

Earth Ground Leakage Current

Agency Listings / Compliances

Transient Response (RMS)

Current Crest Factor

Input Power Factor (@ full load and nominal line)

Single phase with floating or grounded neutral;

Model 208: xxx PowerPass: 208 Vac or 220 Vac (split phase, 60 Hz only);

Model 240: xxx PowerPass: 200 Vac, 220 VAC, 230 Vac, 240 Vac

170 - 276 Vac

Overvoltage: 113% of inverter set point

Undervoltage: 80% of inverter set point; Determined by PPU

50 - 60 Hz 45 – 65 Hz

300A or less for 1 cycle

Input Supplementary Circuit Breaker

All-pole break > 0.90; 0.95 typical

Nominal Output Voltages 100/200 Vac; 110/220 Vac; 115/230 Vac; 120/208 Vac; 120/240 Vac; 127/220 Vac

25 Amperes

6000 @ 240V output 5750 @ 230V output 5500 @ 220V output 5200 @ 208V output 5000 @ 200V output

50 or 60 Hz ± 3 Hz

3:1 acceptable; Transformer impedance may reduce crest ratio

± 10% ± 3%

GENERAL

FN50091-2 **Electromagnetic Interference**

CISPR22-A (EN55022 Class A) IEC801-2 ESD level 3 IEC801-3 RES level 2 IEC801-4 EFT level 2

IEC 1000-2-2 / 1000-4-1 (Immunity to low frequency signals) FCC Part 15 (Class A)

Noise Attenuation: Common Mode Rejection > 60 dB @ 100 kHZ Noise Attenuation: Transverse Mode Rejection > 80 dB @ 100 kHZ Up to 5% of input current UL 1778 and corresponding cUL

EN60950; EN50091-1 CE Mark (specific models only)

Input/Output Connections, Plug-and-Play Models Output connections (depending on model) 5-15R, 5-20R, L5-30R, L6-20R,

> L6-30R or L14-30R Hardwire terminal block

ENVIRONMENTAL

15°C - 30°C **Operating Temperature; Normal** 10°C - 40°C Operating Temperature; Minimum/Maximum

Storage Temperature

Input/Output Connections, Hardwire Models

Elevation

Relative Humidity (Noncondensing)

Heat Dissipation @ Full Load Online Heat Dissipation @ Full Load On Battery Cooling

Approximately 2800 BTU/hour Approximately 3500 BTU/hour

Forced Air

5% - 95%

-20°C - 60°C

MECHANICAL

Dimensions 10" h x 11.1" w x 15.75" d

254mm h x 281.9mm w x 400mm d

0 - 1230 meters (4000 feet) without derating

Weight 82 lb.; 37 kg **Shipping Weight** 87 lb.; 40 kg

* Specifications subject to change without notice.

Invensys Powerware Division 8609 Six Forks Road Raleigh, NC 27615 U.S.A. Toll Free: 1.877.797.9273 or 919.872.3020 Fax: 1.800.753.9433 www.powerware.com

Europe/Middle East/Africa Finland: +358.9.452.661

Southeast Asia Singapore: 65-8610377

China and North Asia Hong Kong: 852.2745.6682

Shinagawa Tokyo: 813.3447.5251

Australia and South Pacific Sydney, Australia: 612..9878.5000

Canada Toronto, Ontario: 416.798.0112 Brazil Sao Paulo, Brazil: 55.11.3933.8555/855.8500

Mexico Col. Napoles C.P., Mexico 525.527.61.69/ 525.488.33.33

