



**Programmable AC Source  
31120/31180 and 31120A/31180A  
User's Manual**

Version A2  
November 2009  
P/N 150926 A2

# Legal Notices

The information in this document is subject to change without notice.

QuadTech, Inc. makes no warranty of any kind with regards to this manual, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

QuadTech, Inc. shall not be held liable for errors contained herein or direct, indirect, special, incidental or consequential damages in connection with the furnishing, performance or use of this material.

## **QuadTech, Inc.**

[www.quadtech.com](http://www.quadtech.com) or 800-253-1230

Copyright Notices. Copyright 2008-2009 QuadTech, Inc. all rights reserved. Reproduction, adaptation or translation of this document without prior written permission is prohibited, except as allowed under the copyright laws.

# Warranty

All QuadTech, Inc. instruments are warranted against defects in material and workmanship for a period of one year after date of shipment. QuadTech, Inc. agrees to repair or replace any assembly or component found to be defective, under normal use during this period.

QuadTech's obligation under this warranty is limited solely to repairing any such instrument, which in QuadTech's sole opinion proves to be defective within the scope of the warranty when returned to the factory or to an authorized service center. Transportation to the factory or service center is to be prepaid by purchaser. Shipments should not be made without prior authorization by QuadTech, Inc.

This warranty does not apply to any products repaired or altered by persons not authorized by QuadTech, or not in accordance with instructions furnished by QuadTech. If the instrument is defective as a result of misuse, improper repair, or abnormal conditions or operations, repairs will be billed at cost.

QuadTech assumes no responsibility for its product being used in a hazardous or dangerous manner either alone or in conjunction with other equipment. High voltage used in some instruments may be dangerous if misused. Special disclaimers apply to these instruments. QuadTech assumes no liability for secondary charges or consequential damages and in any event, QuadTech's liability for breach of warranty under any contract or otherwise, shall not exceed the purchase price of the specific instrument shipped and against which a claim is made.

Any recommendations made by QuadTech for use of its products are based upon tests believed to be reliable, but QuadTech makes no warranty of the results to be obtained. This warranty is in lieu of all other warranties, expressed or implied, and no representative or person is authorized to represent or assume for QuadTech any liability in connection with the sale of our products other than set forth herein.

**QuadTech, Inc.**

800-253-1230

[www.quadtech.com](http://www.quadtech.com)

# Material Contents Declaration

A regulatory requirement of The United States of America defined by specification SJ/T 11364-2006 mandates that manufacturers provide material contents declaration of electronic products, and for QuadTech, Inc. products are as below:

Part Name	Hazardous Substances					
	Lead	Mercury	Cadmium	Hexavalent Chromium	Polybrominated Biphenyls	Polybromodiphenyl Ethers
	Pb	Hg	Cd	Cr <sup>6+</sup>	PBB	PBDE
PCBA	×	○	○	○	○	○
CHASSIS	×	○	○	○	○	○
ACCESSORY	×	○	○	○	○	○
PACKAGE	○	○	○	○	○	○

“○” indicates that the level of the specified chemical substance is less than the threshold level specified in the standards of SJ/T-11363-2006 and EU 2005/618/EC.

“×” indicates that the level of the specified chemical substance exceeds the threshold level specified in the standards of SJ/T-11363-2006 and EU 2005/618/EC.

1. QuadTech is not fully transitioned to lead-free solder assembly at this moment, however, most of the components used are RoHS compliant.
2. The environment-friendly usage period of the product is assumed under the operating environment specified in each product’s specification.

## Disposal

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliances for disposal at least for free of charge.



# Safety Summary

The following general safety precautions must be observed during all phases of operation, service and repair of this instrument. Failure to comply with these precautions or specific WARNINGS given elsewhere in this manual will violate safety standards of design, manufacture and intended use of the instrument. *QuadTech* assumes no liability for the customer's failure to comply with these requirements.

## **BEFORE APPLYING POWER**

Verify that the power is set to match the rated input of this power supply.

## **PROTECTIVE GROUNDING**

Make sure to connect the protective grounding to prevent an electric shock before turning on the power.

## **NECESSITY OF PROTECTIVE GROUNDING**

Never cut off the internal or external protective grounding wire, or disconnect the wiring of protective grounding terminal. Doing so will cause a potential shock hazard that may bring injury to a person.

## **FUSES**

Only fuses with the required rated current, voltage, and specified type (normal blow, time delay, etc.) should be used. Do not use repaired fuses or short-circuited fuse holders. To do so could cause a shock or fire hazard.

## **DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE**

Do not operate the instrument in the presence of flammable gases or fumes.

## **DO NOT REMOVE THE COVER OF THE INSTRUMENT**






Operating personnel must not remove the cover of the instrument. Component replacement and internal adjustment can be done only by qualified service personnel. Removing any covers without written consent will void the warranty.

---

### **WARNING**

1. Lethal voltage. AC source may output 426V peak-voltage.
  2. Touching the connected circuit or output terminal on the front or rear panel when power is on, may result in death.
-

# Safety Symbols

	<p><b>DANGER</b> – High voltage.</p>
	<p><b>Explanation:</b> To avoid injury, death of personnel, or damage to the instrument, the operator must refer to an explanation in the instruction manual.</p>
	<p><b>Protective grounding terminal:</b> To protect against electrical shock in case of a fault. This symbol indicates that the terminal must be connected to ground before operation of equipment.</p>
<p> <b>WARNING</b></p>	<p>The <b>WARNING</b> sign denotes a hazard. It calls attention to a procedure, practice, or the like, which, if not correctly performed or adhered to, could result in personal injury. Do not proceed beyond a <b>WARNING</b> sign until the indicated conditions are fully understood and met.</p>
<p> <b>CAUTION</b></p>	<p>The <b>CAUTION</b> sign denotes a hazard. It may result in personal injury or death if not noticed timely. It calls attention to procedures, practices and conditions.</p>

# Revision History

The following lists the additions, deletions and modifications in this manual at each revision.

<b>Date</b>	<b>Version</b>	<b>Revised Sections</b>
Nov. 2009	A1	Initial Release
April 2010	A2	Add 31120A and 31180A Sections 5, 6 and Appendix B





## Table of Contents

<b>1.</b>	<b>General Information .....</b>	<b>13</b>
1.1	Introduction .....	13
1.2	Key Features.....	13
1.3	Specifications .....	13
1.4	Names of Parts .....	16
1.4.1	Front Panel .....	16
1.4.2	Rear Panel .....	18
<b>2.</b>	<b>Installation .....</b>	<b>21</b>
2.1	Initial Inspection.....	21
2.2	Preparation for Use.....	21
2.3	Requirements for Input Power .....	21
2.3.1	Ratings.....	21
2.3.2	Input Connection.....	21
2.4	Output Connection .....	23
2.5	Remote Sense Connection.....	24
2.6	Power-On Procedure .....	25
2.7	Maintenance & Cleaning.....	26
2.8	Common Environment Conditions.....	26
<b>3.</b>	<b>Local Operation.....</b>	<b>27</b>
3.1	Introduction .....	27
3.2	Using Keyboard & RPG.....	27
3.3	MAIN PAGE (Output Setting & Measurement).....	30
3.3.1	OUTPUT: More Setting .....	32
3.3.2	Measurement Setting .....	50
3.3.3	Waveform Viewer .....	54
3.3.4	Limitation.....	55
3.4	CONFIG Function Key .....	56
3.4.1	Interface.....	57
3.4.2	External Vref.....	61
3.4.3	Display .....	63
3.4.4	Power-ON Status.....	64
3.4.5	Protection .....	65
3.4.6	Others .....	66
3.4.7	Calibration.....	68
3.4.8	System Information.....	68
3.4.9	Factory Default.....	69
3.5	PHASE Function Key .....	69
3.5.1	3_Phase Mode .....	69
3.5.2	1_Phase Mode .....	70
3.6	CURSOR Function Key .....	70
3.7	LOCK Function Key .....	71
3.8	OUTPUT Function Key .....	71
3.9	LOCAL/REMOTE Function Key .....	71
3.10	SAVE/RECALL Function Key.....	72
3.10.1	Save/Recall Output Setting .....	72

3.10.2	Save/Recall System Data .....	73
3.11	Protection .....	74
<b>4.</b>	<b>Calibration .....</b>	<b>77</b>
4.1	Introduction .....	77
4.2	Manual Calibration.....	78
4.2.1	Output Voltage and Measurement Calibration.....	79
4.2.2	Current Measurement Calibration.....	88
4.2.3	External Vref Calibration.....	93
<b>5.</b>	<b>31120A and 31180A Transient Generator .....</b>	<b>97</b>
5.1	Overview .....	97
5.2	List Mode .....	97
5.3	Pulse Mode.....	102
5.4	Step Mode .....	106
5.5	Synthesis Waveform .....	111
5.6	Inter-harmonics Waveform .....	115
5.7	Harmonic Waveform.....	119
<b>6.</b>	<b>Parallel Operation .....</b>	<b>127</b>
6.1	Parallel Connection of AC Source .....	127
6.2	Parallel Connection .....	128
6.3	Setting Up.....	128
6.3.1	Setting the AC Source to Slave .....	128
6.3.2	Setting the Slave of Mixed AC Source and QTA615103 .....	129
6.3.3	Setting the AC Source to Master.....	131
6.4	Troubleshooting .....	132
6.4.1	When the Connecting Cable Falls.....	132
6.4.2	Parallel Setting Error.....	133
<b>7.</b>	<b>Theory of Operation.....</b>	<b>135</b>
7.1	Overview .....	135
7.2	Description of Overall System .....	135
<b>8.</b>	<b>Self Test and Troubleshooting .....</b>	<b>137</b>
8.1	Overview .....	137
8.2	Self Test.....	137
8.3	Troubleshooting .....	138
<b>9.</b>	<b>Remote Operation .....</b>	<b>139</b>
9.1	Introduction .....	139
9.1.1	USB Interface.....	139
9.1.2	GPIB Interface.....	139
9.1.3	RS-232C Interface.....	140
9.1.4	Ethernet Interface .....	140
9.2	Introduction to Programming .....	141
9.2.1	Conventions.....	141
9.2.2	Numerical Data Formats .....	141
9.2.3	Boolean Data Format .....	141
9.2.4	Character Data Format .....	141
9.2.5	Basic Definition.....	142
9.3	Traversal of the Command Tree.....	143
9.4	Execution Order .....	143
9.5	Commands of AC Source.....	144

9.5.1	Common Command Dictionary .....	144
9.5.2	Instrument Command Dictionary.....	145
9.6	Command Summary.....	178
<b>Appendix A</b>	<b>TTL Signal Pin Assignments .....</b>	<b>181</b>
<b>Appendix B</b>	<b>Built-in DST Waveform (31120A and 31180A only) .....</b>	<b>182</b>



# 1. General Information

## 1.1 Introduction

The QuadTech, Inc. 31120/31180 Series is a highly efficient programmable AC Source, which provides a low distortion sine wave output for power accuracy. The DSP microprocessor generates an accurate, stable output voltage and frequency. The PWM designed, power stage allows apparent power into loads. The front panel has a RPG (Rotary Pulse Generator) and keypad control for setting the output voltage and frequency. The LCD gives users a complete operating status. Remote programming is accomplished by the GPIB bus or RS-232C serial port.

## 1.2 Key Features

### A. Configuration

- Local operation by the keypad on the front panel
- Remote operation via GPIB or RS-232C interface
- Remote control a terminal on front or rear panel using the QuadTech Digital Controller A615101 (optional)
- Protection against over-power, over-current, over-temperature and fan failure
- Thermostatically controlled fan speed
- Built-in output isolation relays

### B. Input/Output

- Selectable output voltage with full scale of 150V/300V/Auto (3 ranges)
- Analog (simulation) reference voltage for remote control
- V, I, P, CF, PF, Idc, Vdc, Ipk, Is, VA and VAR measurement
- Remote inhibited control
- AC ON/OFF output signal

## 1.3 Specifications

Following lists the specifications of model 31120/31180. All specifications are tested by QuadTech's standard test procedures, and follow remote sense for connection under the condition of  $25 \pm 1^\circ\text{C}$  and resistive load unless specified otherwise.

Model	31120	31180
<b>AC OUTPUT RATING</b>		
Single Phase Power	12K VA	18K VA
3-Phase Power	12K VA	18K VA
Power per Phase	4K VA	6K VA
<b>VOLTAGE</b>		
Range	150V/300V/Auto	
Output Voltage	0~150V / 0~300V	
Accuracy	0.2%+0.2%F.S.	
Resolution	0.1 V	
Distortion *1	0.3% @50/60Hz, 1%@15- 1KHz, 1.5%@>1KHz	
Line Regulation	0.1%	
Load Regulation *2	0.2%	
Temp. Coefficient	0.02% per degree from 25°C	
<b>MAXIMUM CURRENT (single phase)</b>		
RMS	96A / 48A	144A / 72A
Peak (CF=4)	384A / 192A	576A / 288A
<b>MAXIMUM CURRENT (each of 3-phase)</b>		
RMS	32A / 16A	48A / 24A
Peak (CF=4)	128A / 64A	192A / 96A
<b>FREQUENCY</b>		
Range	DC, 15-1.5KHz	
Accuracy	0.15%	
<b>PHASE ANGLE</b>		
Range	0 ~ 360°	
Resolution	0.3°	
Accuracy	<0.8°@50/60Hz	
<b>DC OUTPUT RATING (single phase)</b>		
Power	6K VA	9K VA
Voltage	212V / 424V	212V / 424V
Current	48A / 24A	72A / 36A
<b>DC OUTPUT RATING (each of 3-phase)</b>		
Power	2K VA	3K VA
Voltage	212V / 424V	212V / 424V
Current	16A / 8A	24A / 12A
<b>INPUT 3 PHASE RATING (per phase)</b>		
Power Type	3 Phase, Delta or Y connection	
Voltage Range	190-250V (Delta: L-L, Y: L-N)	
Frequency Range	47-63 Hz	
Max. Current	Delta: 80A Y: 70A	Delta: 120A Y: 90A
<b>MEASUREMENT</b>		
<b>VOLTAGE</b>		
Range	150V / 300V	
Accuracy	0.2%+0.2%F.S.	
Resolution	0.1 V	

<b>CURRENT (per phase)</b>		
Range	8A/32A/128A <sub>peak</sub>	12A/48A/192A <sub>peak</sub>
Peak per Phase	128A	192A
Accuracy (rms)	0.4%+0.3%F.S.	
Accuracy (peak)	0.4%+0.6%F.S.	
Resolution	0.006A / 0.025A / 0.1A	
<b>POWER</b>		
Accuracy	0.4%+0.4% F.S.	
Resolution	0.1 W	
<b>OTHERS</b>		
Efficiency *3	0.75 (Typical)	
Size (H×W×D)	1163×546×700 mm	1163×546×700 mm
	45.78×21.5×27.56 inch	45.78×21.5×27.56 inch
Weight	220 kg / 505.29 lbs	240 kg / 533.92 lbs
Protection	OVP, OCP, OPP, OTP, FANFAIL	
Remote Interface	GPIB, RS-232, USB, Ethernet	
<b>TEMPERATURE RANGE</b>		
Operation	0 °C to 40 °C	
Storage	-40 °C to 85 °C	
Humidity	30 % to 90 %	
Safety & EMC	CE	

**Notes:**

- \*1 : Maximum distortion is tested under output 125VAC (150V RANGE) and 250VAC (300V RANGE) with maximum current to linear load.
- \*2 : Load regulation is tested by sine wave and remote sense.
- \*3 : Efficiency is tested on input voltage: 230V.

## 1.4 Names of Parts

### 1.4.1 Front Panel





















Figure 1-1 Front Panel

Item	Symbol	Description
1		<b>Display:</b> The 6.5" LCD displays the configuration, output setup, and measurement results.
2		<b>Indicator LED:</b> It is the Power-On indicator surrounding the rotary knob showing the activation status.
3		<b>RPG Rotary:</b> Users can turn the RPG rotary to adjust the voltage, frequency and input programmed data or options.
4		<b>Cursor Movement Keys:</b> These four keys move the cursor in different directions respectively. In normal mode, pressing any of these four keys will change the cursor position.
5		<b>SAVE or RECALL:</b> Press this on MAIN PAGE to save the output setting, see 3.10.1. By pressing this key on CHOICE PAGE, users can save the system data, see 3.10.2.
6		<b>OUT/QUIT:</b> Press this key to Enable/Disable the output voltage of the AC source.
7		<b>LOCAL/REMOTE:</b> It switches the control mode from "Remote" to "LOCAL" for front panel input.
8		<b>OUTPUT SETTING:</b> Changes the screen to "Output: More Setting" for additional settings.
9		<b>CURSOR:</b> It is used to set or adjust the value.
10		<b>LOCK:</b> Press it for 1 second can lock up "all keys" and the "rotary."



		Press it for three seconds to unlock them.
11		<b>PHASE:</b> It sets single/3 Phase.
12		<b>CONFIG:</b> It changes the screen to “config choose page” for various settings.
13		<b>Numeric and Decimal:</b> Users can use “numeric keys” and “decimal key” to input digital data.
14		<b>Backward and Decreasing:</b> Press this key to delete the inputted number. It shows " - " if no number exists.
15		<b>EXIT:</b> Press it to return to previous screen.
16		<b>Main Power Switch:</b> It turns on or shut off the power.
17		<b>Indicator:</b> It refers to the description on screen for parameter and function setting.
18		<b>ENTER</b> : It confirms the setting of parameter.
19	REMOTE CONTROL	<b>Remote Control Terminal:</b> It can work with QuadTech Digital Controller A615101 (optional) for remote control.

## 1.4.2 Rear Panel






Figure 1-2 Rear Panel

Item	Symbol	Description
1	Rear Panel Output Interface	It includes Ext.V/TTL, Remote Control, GPIB and USB, etc.
2	I/O Terminal Case	It has the input/output terminal. The connector inputs power source from the mains (3_Phase power) and outputs power source to the UUT.
3	Ext. Vref./TTL I/O	It inputs the control waveform amplitude from external analog (simulated) signal with TTL transmission control signal (Fault_out, Remote inhibit and AC_ON.)
4	Remote Controller	It can work with QuadTech Digital Controller A615101 (optional) for remote control.
5	SYSTEM BUS	It is applicable for signal transmission in between 2 AC Sources connected in parallel.
6	Ethernet	It is the terminal that can be controlled by network (LAN).
7	USB	It is used to connect the remote controller to computer for remote operation.
8	RS-232C	It is a 9-pin D type male connector that transmits control commands among distant PCs for remote operation.
9	GPIB Connector	Remote controller uses GPIB bus to connect the PC via the connector for remote operation.
10	Cable Connector	Select the mapping cable connector for different input cable ( $\Delta$ -Y).
11	Remote Sense Connector	It is the terminal that senses the load directly to avoid any voltage drop when connecting cable. Ensure the "SL" terminal of remote sense connector is connected to the "L" terminal of Load, and the "SN" is connected to the "N" of Load. Reverse polarity cannot be

		connected.
12	Input Connecting Terminal	It connects the mains to AC Source as input.
13	Output Connection Terminal	It connects to UUT for output.
14	I/O Cable Secure Strip	It secures the input/output connection cable.

## 2. Installation

### 2.1 Initial Inspection

Before shipment, this instrument was inspected and found to be free of mechanical and electrical defects. As soon as the instrument is unpacked, inspect for any damage that may have occurred in transit. Save all packing materials in case the instrument has to be returned. If damage is found, please file claim with carrier immediately. Do not return the instrument to QuadTech without prior approval.

### 2.2 Preparation for Use

First the instrument must be connected to an appropriate AC line input. Since the instrument is cooled by fans, it must be installed in a place with good circulation of air. It should be in an area where the ambient temperature does not exceed 40°C.

### 2.3 Requirements for Input Power

#### 2.3.1 Ratings

Input Voltage Range	:	190-250 V <sub>LL</sub> , 3_Phase, 4-wire $\Delta$ , or 329-433 V <sub>LL</sub> , 3_Phase, 5-wire Y
Input Frequency	:	47-63 Hz
Maximum Current	:	31120 $\Delta$ : 80A, Y: 70A 31180 $\Delta$ : 120A, Y: 90A

---

#### **WARNING**

The AC Source may be damaged if the input voltage exceeds the configured range.

---

#### 2.3.2 Input Connection

The input terminal block is located beneath the device's rear panel. The power cord should be rated at least 85°C and the current rating of power line input must be greater than or equal to the maximum current rating of AC Source.

---

#### **WARNING**

There are two different input voltage ratings. One is 380 V<sub>LL</sub> 3\_Phase with 5-wire (Y), and the other is 220 V<sub>LL</sub> 3\_Phase with 4-wire ( $\Delta$ ). Be sure to verify the main voltage before use. The connection for both is the same, however, it is necessary to switch the  $\Delta$ - Y switch on the rear panel to appropriate position.

---

See Figure 2-2 and perform the steps below accordingly:

1. Remove the safety cover from the back of the AC Source.
2. Connect the wire to the AC Source terminal blocks (see Figure 2-2.)
3. Slide the safety cover over the AC input terminal strip.
4. Secure it with the I/O cable trim strip and screws.
5. Assemble the safety cover back to the AC Source.

---

**⚡ CAUTION**

To protect the operators, the wire connected to GND terminal must be connected to the earth. Under no circumstances shall this AC Source be operated without adequate grounding.

---




Figure 2-1 Input Selector

---

**ⓘ NOTICE**

If users change the Δ-Y switch to Y when the actual input wiring is Δ, the buzzer inside the instrument will beep for warning during power-on. Users need to power off and change the Δ-Y switch to Δ to resolve the problem.

---

---

**ⓘ NOTICE**

1. Installation of the wire must be conducted by professional personnel complying with local electrical codes.
  2. If the input wiring selection is 220V 3~ (□ type) Max 120A/Phase, the specification of Circuit Breaker configured for □ type needs to be 220Vac/80A (31120) & 120A (31180) at least.
  3. If the input wiring selection is 380V 3~ (Y type) Max 70A/Phase, the specification of Circuit Breaker configured for Y type needs to be 380Vac/70A (31120) & 90A (31180) at least.
-




Figure 2-2 3-Phase Power Input Connection (Y Connection) 190-250 V




Figure 2-3 3-Phase Power Input Connection (Delta Connection) 190-250 V

**ⓘ NOTICE**

Please be aware of the color distinction of insulation tube or the wire before connecting the power wire. The black insulation tube or power wire is used for L1, L2 and L3, the blue insulation tube or power wire is used for NEU while the green insulation tube or power wire is used for GROUND.

## 2.4 Output Connection

The output terminal block is located at the rear of AC Source. The Load is connected to the output terminals. To meet the safety requirements, the I/O input/output wires need to be tied up by a safety strip and the cover must be secured. The wire diameter should be large enough to connect to the load so that it will not overheat when outputting current, see Figure 2-5.

**NOTICE**

The output terminal labeled “L” is the “+” terminal and the output terminal labeled “COM/N” is the “-” terminal when output voltage contains DC composition.

**WARNING**

For proper ventilation, the hardware should be placed at least 1 meter distance from the device front and rear panel. Do not place the hardware against the wall or other objects.

## 2.5 Remote Sense Connection

The remote sense function of AC Source monitors the voltage at the load and performs automatic compensation to ensure the voltage delivered to load is the one programmed.

Remove the connecting wires “ $\psi 1$ ”, “ $\psi 2$ ”, “ $\psi 3$ ” and “COM” from Remote Sense terminal, and connect remote sense to load as Figure 2-4 shows. As the sensing leads transmit only a few milliamperes, the sensing wires are much thinner than the load leads. The sensing leads are part of the feedback circuit of AC Source, so they must be low resistance for the best performance. Connect the sensing leads carefully so that they will not be open-circuited. If the sensing leads are disconnected or become open-circuited during operation, the AC Source may unable to output. The sensing leads must be a twisted pair to minimize the interference from external voltage. The sensing leads need to be connected to the load as close as possible.




Figure 2-4 Output & Remote Sense Connection







Figure 2-5 Input/Output Wire Securing Diagram

## 2.6 Power-On Procedure

### ⚡ CAUTION

Before turning on the instrument, all protective earth terminals, extension cords and devices connected to the instrument must be connected to a protective earth ground. Any interruption of the protective earth grounding may cause potential electric shock hazard that could result in personal injury.

Connect the power line and turn on the power switch on the front panel. The AC Source will begin a series of self tests. The LCD on the front panel will be on and displaying the following.



In the mean time the AC Source executes memory, data and communication self tests. The display shows the Model Number and AC Source's Serial No. when executing the self test routines and each test item will show "OK" on the right if no error is found. It needs about 10 seconds for self test to finish the routines and then the software version will show on the display.

"ERROR CODE" will appear on the right if one of the test items is failed. See Section 8.2 *Self Test* for detail information.

When the self tests of memory, data and communication are done, the AC Source will conduct a power output self test. The output relay is OFF during the procedure to ensure the load connected to the output terminal won't be damaged. The AC Source sets the output to 300Vac for measurement and if the measured voltage exceeds  $300V \pm 100V$ , the power self test fails and the display shows "NG." The display shows as below if it OK and the screen changes to MAIN PAGE automatically.

---

 **WARNING**

1. Users can run self diagnosis during power on self test to see if there are any errors or NG (No Good) conditions, see section 8.2 for detail information.
  2. The AC Source needs about 20 seconds to finish the self test.
- 

## **2.7 Maintenance & Cleaning**

Remove all connected wires and cables on the instrument before cleaning. Use a brush to clean the dust. If there are stains on the chassis that cannot be removed by brush, wipe it with a volatile liquid. Do not use any corrosive liquid to avoid damaging the chassis. Use a damp cloth with soap and water or a soft detergent to clean the LCD front panel. Please send it back to the distributors or agents of QuadTech for internal cleaning. Do not open the chassis cover arbitrarily.

## **2.8 Common Environment Conditions**

1. In door use.
2. Altitude up to 2000m.
3. Temperature 0°C to 40°C.
4. Transient over voltage is impulse withstand CAT II.
5. Pollution degree 2.

## 3. Local Operation

### 3.1 Introduction






The AC Source can be configured to operate in local or remote mode. The remote mode operation is through a remote GPIB or RS-232C interface as described in Chapter 9. This section describes the operation in local mode using the keypad on the front panel for data entry and test. Local operation can be used directly when the AC Source is turned on.





### 3.2 Using Keyboard & RPG

The AC Source is equipped with a user friendly programmable interface containing a keypad and a RPG (Rotary Pulse Generator) on the front panel. The LCD on AC Source displays the operation menu.


Figure 3-1 shows the command tree. The following describes how to use both the keypad and the RPG to set the commands before explaining each menu. When the power-on procedure is completed (see 2.6), the display will show the MAIN PAGE (3\_Phase Mode/1\_Phase Mode) as below.

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	Po =	0.0		Waveform Viewer
	I =	0.000	PF =	0.000		
#2	V =	0.00	Po =	0.0		Limitation
	I =	0.000	PF =	0.000		
#3	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
	V <sub>12</sub> =	0.00	V <sub>21</sub> =	0.00		Measurement To Page2
	V <sub>23</sub> =	0.00	Po =	0.0		
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:28:14
1_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
						Measurement Setting
MEASUREMENT						
	V =	0.00	Po =	0.0		Waveform Viewer
	I =	0.000	PF =	0.000		
	Vac =	0.00	Vdc =	0.00		Limitation
	Iac =	0.000	I <sub>dc</sub> =	0.000		
	V <sub>pk</sub> =	0.00	V <sub>A</sub> =	0.0		
	I <sub>pk</sub> =	0.000	CF =	0.000		
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:28:37

Press , , ,  keys to move the cursor for item selection. Use numeric and decimal keys or RPG to set the values and press **ENTER** to confirm them. Users can use the indicators located at the bottom or lower right of the LCD to set the parameters or functions following the description at the bottom or lower right of the screen, or press  to return to MAIN PAGE.

In MAIN PAGE, users can press the indicators located at the bottom or lower right of the LCD to select the function list. Use , , ,  to move the cursor after entering each list. For digital setting, users can use the numeric and decimal keys or the RPG to set the value, then press **ENTER** for confirmation. For text setting, users can turn the RPG for selection and press **ENTER** for confirmation.

MAIN PAGE (Output Setting & Measurement)



CONFIGURATION





Figure 3-1

Save/Recall



Output Setting




Figure 3-2

### 3.3 MAIN PAGE (Output Setting & Measurement)

When the AC Source is turned on and finished the self test, the screen displays the MAIN PAGE (3\_Phase Mode/1\_Phase Mode). A line on the screen shows the output setting. The default output setting can be set by the Power ON Status (see 3.4.4) under the CONFIG function key. The MEASUREMENT on the screen shows the items measured by the AC Source and each of them has 12 types totaling three pages as shown below.

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	Po =	0.0		Waveform Viewer
	I =	0.000	PF =	0.000		Limitation
#2	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
#3	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		Measurement To Page2
	V12 =	0.00	V31 =	0.00		
	V23 =	0.00	Po =	0.0		
Recall	Recall	Recall	Recall	Recall	More	2008/10/13
CH1	CH2	CH3	CH4	CH5	1 of 2	10:30:14

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	Vac =	0.00	Iac =	0.000		Waveform Viewer
	Vdc =	0.00	Idc =	0.000		Limitation
#2	Vac =	0.00	Iac =	0.000		
	Vdc =	0.00	Idc =	0.000		
#3	Vac =	0.00	Iac =	0.000		
	Vdc =	0.00	Idc =	0.000		Measurement To Page2
Z	V12 =	0.00	V23 =	0.00		
	V31 =	0.00	VA =	0.0		
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:30:39

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	Vpk =	0.00	Ipk =	0.000		Waveform Viewer
	VA =	0.0	CF =	0.000		Limitation
#2	Vpk =	0.00	Ipk =	0.000		
	VA =	0.0	CF =	0.000		
#3	Vpk =	0.00	Ipk =	0.000		
	VA =	0.0	CF =	0.000		Measurement To Page1
Z						
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:30:41

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
						Measurement Setting
MEASUREMENT						
	V =	0.00	Po =	0.0		Waveform Viewer
	I =	0.000	PF =	0.000		Limitation
	Vac =	0.00	Vdc =	0.00		
	Iac =	0.000	Idc =	0.000		
	Vpk =	0.00	VA =	0.0		
	Ipk =	0.000	CF =	0.000		
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:31:08

On top of the screen, the range displayed 300V this is the Range status (see 3.3.1.2).

There are 3 ranges:

1. 150V Range
2. 300V Range
3. AUTO Range

The definition of output parameters:

Vac : AC output voltage in Volts.

F : Output frequency in Hertz.

Vdc : DC output voltage in Volts.

Press **OUT/QUIT** enables the AC Source outputs the voltage with the setting of Vac, F

and Vdc. Press it again the AC Source output is disabled.

**ⓘ NOTICE**

When Coupling = AC+DC the output is the sum of Vac and Vdc. However, the combination of peak voltage cannot exceed the limit of each range (range 150V: 212.1V and range 300V: 424.2V.) The output voltage will skip to 0V automatically and trigger protection if it exceeds the voltage limit (OVP).

Following lists the definition of measurement parameters:

- V : It is the voltage measurement in Volts. (True RMS measurement)
- F : It is the output frequency in Hertz.
- I : It is the current measurement in Amps. (True RMS measurement)
- P : It is the real power measurement in Volts.
- PF : It is Power Factor and the calculation formula = Real Power / (Vrms × Irms)
- CF : It is Crest Factor and the calculation formula = Ipeak/Irms
- Vdc : It is the DC voltage measurement in Volts.
- Idc : It is the DC current measurement in Amps.
- Ip : It is the peak current measurement in Amps. The Ipeak display is the Ip (+) or Ip(-) whichever is larger.
- Is : It is I surge that is only measured when output changes as defined in section 3.3.2.3.
- VA : It is the apparent power in Volt-Ampere and the calculation formula = Vrms×Irms.
- VAR : The calculation formula =  $\sqrt{VA^2 - P^2}$

**3.3.1 OUTPUT: More Setting**

Press OUTPUT: More Setting in the MAIN PAGE (3\_Phase Mode/1\_Phase Mode) (see section 3.3), a line of output functions will appear at the bottom of the screen as described below.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac = 0.0V	F = 60.0Hz			OUTPUT: More Setting
#2	Vac = 0.0V	F = 60.0Hz			
#3	Vac = 0.0V	F = 60.0Hz			Measurement Setting
MORE SETTING					
#1	Waveform = A SINE				Waveform Viewer
#2	Waveform = A SINE				
#3	Waveform = A SINE				Limitation
	SINE				
	ON Degree = 0.0	OFF Degree = IMMED			
	Vac S/R = 0.000V/ms	Vdc S/R = 0.000V/ms			
	F S/R = 0.000Hz/ms				
	Phase angle 1-2 = 120.0		Phase angle 1-3 = 240.0		
Coupling	Range	Threc			2008/10/13 18:31:56
AC	300V	Phase Setting			



1_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Vac = 0.0V F = 60.0Hz					OUTPUT: More Setting
					Measurement Setting
MORE SETTING					
Waveform = A SINE					Waveform Viewer
ON Degree = 0.0 OFF Degree = IMMED					Limitation
Vac S/R = 0.000V/ms					
Vdc S/R = 0.000V/ms					
F S/R = 0.000Hz/ms					
Coupling AC	Range 300V				2008/10/13 18:32:33

### 3.3.1.1 Coupling Output Mode (AC+DC, AC, DC)

There are three types of AC Source output: AC+DC, AC and DC. The coupling can be set to meet a variety of applications.

The setting procedure from AC to AC+DC is described as below:

1. Press Coupling at the bottom.
2. Turn the RPG to change the selection from AC to AC+DC and press **ENTER**.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac = 0.0V F = 60.0Hz				OUTPUT: More Setting
#2	Vac = 0.0V F = 60.0Hz				
#3	Vac = 0.0V F = 60.0Hz				Measurement Setting
MORE SETTING					
#1	Waveform = A SINE				Waveform Viewer
#2	Waveform = A SINE				
#3	Waveform = A SINE				Limitation
ON Degree = 0.0      OFF Degree = IMMED					
Vac S/R = 0.000V/ms      Vdc S/R = 0.000V/ms					
F S/R = 0.000Hz/ms					
Phase angle 1-2 = 120.0      Phase angle 1-3 = 240.0					
Coupling AC	Range 300V	Three Phase Setting			2008/10/13 18:32:10

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac = 0.0V F = 60.0Hz				OUTPUT: More Setting
#2	Vac = 0.0V F = 60.0Hz				
#3	Vac = 0.0V F = 60.0Hz				Measurement Setting
MORE SETTING					
#1	Waveform = A SINE				Waveform Viewer
#2	Waveform = A SINE				
#3	Waveform = A SINE				Limitation
ON Degree = 0.0      OFF Degree = IMMED					
Vac S/R = 0.000V/ms      Vdc S/R = 0.000V/ms					
F S/R = 0.000Hz/ms					
Phase angle 1-2 = 120.0      Phase angle 1-3 = 240.0					
Coupling <b>AC+DC</b>	Range 300V	Three Phase Setting			2008/10/13 18:32:56


3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V		OUTPUT: More Setting
#2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V		
#3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V		
MORE SETTING					Measurement Setting
#1	Waveform = A	SINE			Waveform Viewer
#2	Waveform = A	SINE			Limitation
#3	Waveform = A	SINE			
ON Degree = 0.0		OFF Degree = IMMED			
Vac S/R = 0.000V/ms		Vdc S/R = 0.000V/ms			
F S/R = 0.000Hz/ms					
Phase angle 1-2 = 120.0		Phase angle 1-3 = 240.0			
Coupling AC+DC	Range 300V	Three Phase Setting			2008/10/13 10:34:10

**NOTICE**

Since the AC Source does not have as many capacitors as the common DC Power Supply has, some voltage fluctuations and transient load characters are not the same. This AC Source is able to provide positive and negative voltage without changing the output connector. The output capacitance cannot exceed 20uF as it may cause the device to be damaged due to unstable output.

Though the AC Source has AC/DC/AC+DC output mode, the features are still different from the common DC Power Supply when in pure DC mode as explained below.

1. The output voltage ripple is bigger because there is no output capacitor.
2. When the output current reaches the current limit set point, the output voltage will be cut off and in protection mode. It will not stay in constant current mode with a voltage drop like common DC sources.
3. It is necessary to connect the fixture as shown below if more than 20uF is to be used.



4. The output has DC bias that is smaller than 15mV@150V range (temperature coefficient is 2.5mV/°C typical) or smaller than 30mV@300V range (temperature

coefficient is 5mV/°C typical.)

### 3.3.1.2 Range

The AC Source has full scale voltage of output voltage in 150 V, 300 V and AUTO 3 selections. Users can set Range by the function of OUTPUT: More Setting. This parameter controls the power stage relay for parallel (range 150V) or series (range 300V) for more current or higher voltage. AUTO range indicates the output range will change between 150V and 300V automatically as need.

Set the output voltage range to 150V as instructed below.

1. Press Range at the bottom.
2. Turn the RPG to change “300V” to “150V” and press **ENTER**.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
02	Vac =	0.0V	F =	60.0Hz	
03	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					Measurement Setting
01	Waveform =	A			Waveform Viewer
		SINE			
02	Waveform =	A			Limitation
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three Phase Setting			2008/10/13 18:35:28
AC	300V				

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
02	Vac =	0.0V	F =	60.0Hz	
03	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					Measurement Setting
01	Waveform =	A			Waveform Viewer
		SINE			
02	Waveform =	A			Limitation
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three Phase Setting			2008/10/13 18:35:52
AC	300V				

3_Phase 150V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
02	Vac =	0.0V	F =	60.0Hz	
03	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					Measurement Setting
01	Waveform =	A			Waveform Viewer
		SINE			
02	Waveform =	A			Limitation
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three Phase Setting			2008/10/13 18:36:05
AC	150V				

**ⓘ NOTICE**

The output voltage will set to 0V before the range changes to eliminate the peak voltage, then set the output voltage. Please note that it may cause the UUT to be suspended and/or damaged when changing the range.

**3.3.1.3 Setting 3\_Phase Output**

Press 3\_Phase Setting to enter into the function as shown below.


**Edit:** All, Each.

Press Edit to set “Each” or “All” for 3\_Phase output voltage limit.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	Edit
#2	Vac =	0.0V	F =	60.0Hz	Each
#3	Vac =	0.0V	F =	60.0Hz	Sequence Positive
MORE SETTING					
#1	Waveform =	A			Three Phase Independ.
	SINE				
#2	Waveform =	A			
	SINE				
#3	Waveform =	A			Phase re-lock Disable
	SINE				
ON Degree =	0.0	OFF Degree =	IMMED		
Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms		
F S/R =	0.000Hz/ms				
Phase angle 1-2 =	120.0	Phase angle 1-3 =	240.0		
Coupling AC	Range 300V	Three Phase Setting			2008/10/13 18:38:36

**Sequence:** Positive, Negative.

For example, the phase difference degree of 3\_Phase in positive balance is 120 degrees as shown below.



Press Sequence to set the Positive/Negative sequence for AC Source’s 3\_Phase voltage output. The following lists the procedure to set the 3\_Phase output voltage sequence to Negative.

1. Press Sequence on the right.
2. Use RPG to select “Negative” and press **ENTER**.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	Edit
02	Vac =	0.0V	F =	60.0Hz	Each
03	Vac =	0.0V	F =	60.0Hz	Sequence
MORE SETTING					Positive
01	Waveform =	A	Three Phases		
		SINE	Independ.		
02	Waveform =	A			
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =			Phase angle 1-3 =		
120.0			240.0		
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:37:15
		Setting			

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	Edit
02	Vac =	0.0V	F =	60.0Hz	Each
03	Vac =	0.0V	F =	60.0Hz	Sequence
MORE SETTING					Negative
01	Waveform =	A	Three Phases		
		SINE	Independ.		
02	Waveform =	A			
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =			Phase angle 1-3 =		
120.0			240.0		
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:37:30
		Setting			

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	Edit
02	Vac =	0.0V	F =	60.0Hz	Each
03	Vac =	0.0V	F =	60.0Hz	Sequence
MORE SETTING					Negative
01	Waveform =	A	Three Phases		
		SINE	Independ.		
02	Waveform =	A			
		SINE			
03	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		1PMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =			Phase angle 1-3 =		
120.0			240.0		
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:37:42
		Setting			

**Three Phases:** Independ, Same Freq, Balance.

Press Three Phases to set the relationship among the AC Source 3\_Phase output voltage, which are Independ, Same Freq and Balance.

Following lists the procedure to set the same frequency for 3\_Phase voltage output.

1. Press Three Phases on the right.
2. Use RPG to select “Same freq” and press **ENTER**.

3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	Edit
#2	Vac =	0.0V	F =	60.0Hz	Each
#3	Vac =	0.0V	F =	60.0Hz	Sequence
MORE SETTING					
#1	Waveform =	A			Three Phases
		SINE			Independ.
#2	Waveform =	A			
		SINE			
#3	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		IMMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:28:21
		Setting			

3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	Edit
#2	Vac =	0.0V	F =	60.0Hz	Each
#3	Vac =	0.0V	F =	60.0Hz	Sequence
MORE SETTING					
#1	Waveform =	A			Three Phases
		SINE			Same Freq
#2	Waveform =	A			
		SINE			
#3	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		IMMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:28:33
		Setting			

3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	Edit
#2	Vac =	0.0V			Each
#3	Vac =	0.0V			Sequence
MORE SETTING					
#1	Waveform =	A			Three Phases
		SINE			Same freq
#2	Waveform =	A			
		SINE			
#3	Waveform =	A			
		SINE			
ON Degree =		0.0	OFF Degree =		IMMED
Vac S/R =		0.000V/ms	Vdc S/R =		0.000V/ms
F S/R =		0.000Hz/ms			
Phase angle 1-2 =		120.0	Phase angle 1-3 =		240.0
Coupling	Range	Three			2008/10/13
AC	300V	Phase			18:28:43
		Setting			

When 3\_Phase balance is in use, the user may set the output voltage to be Phase Volt or Line Volt. Below is the procedure for setting the 3\_Phase voltage output to 3\_Phase balance.

1. Press Three Phases on the right.
2. Use RPG to select "Balance" and press **ENTER**.
3. Press Voltage set on the right.
4. Use RPG to select "Line" and press **ENTER**.



3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac =	0.0V	F =	60.0Hz	Edit Each
02	Vac =	0.0V	F =	60.0Hz	
03	Vac =	0.0V	F =	60.0Hz	Sequence Negative
MORE SETTING					
01	Waveform =	A			Three Phase Balance
		SINE			
02	Waveform =	A			
		SINE			
03	Waveform =	A			
		SINE			
	ON Degree =	0.0	OFF Degree =	1PMED	Phase re-lock Disable
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms	
	F S/R =	0.000Hz/ms			
	Phase angle 1-2 =	120.0	Phase angle 1-3 =	240.0	
Coupling	Range	Three Phase Setting			2008/10/13 18:39:10
AC	300V				

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Balanced, Sequence:Negative, Voltage:Phase					Edit Each
Vac = 0.0V F = 60.0Hz					
					Sequence Negative
MORE SETTING					
01	Waveform =	A			Three Phase Balance
		SINE			
02	Waveform =	A			
		SINE			Voltage set Phase
03	Waveform =	A			
		SINE			
	ON Degree =	0.0	OFF Degree =	1PMED	
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms	
	F S/R =	0.000Hz/ms			
Coupling	Range	Three Phase Setting	Output Waveform Selection	Zo Program Disable	2008/10/13 18:39:31
AC	300V				

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Balanced, Sequence:Negative, Voltage:Phase					Edit Each
Vac = 0.0V F = 60.0Hz					
					Sequence Negative
MORE SETTING					
01	Waveform =	A			Three Phase Balance
		SINE			
02	Waveform =	A			
		SINE			Voltage set Line
03	Waveform =	A			
		SINE			
	ON Degree =	0.0	OFF Degree =	1PMED	
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms	
	F S/R =	0.000Hz/ms			
Coupling	Range	Three Phase Setting			2008/10/13 18:39:43
AC	300V				

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Balanced, Sequence:Negative, Voltage:Line					Edit Each
Vac = 0.0V F = 60.0Hz					
					Sequence Negative
MORE SETTING					
01	Waveform =	A			Three Phase Balance
		SINE			
02	Waveform =	A			
		SINE			Voltage set Line
03	Waveform =	A			
		SINE			
	ON Degree =	0.0	OFF Degree =	1PMED	
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms	
	F S/R =	0.000Hz/ms			
Coupling	Range	Three Phase Setting			2008/10/13 18:40:03
AC	300V				

Phase re-lock: Enable, Disable.

Phase re-lock is used to lock the phase again. Since the output voltage and frequency are set separately when the AC Source is in 3\_Phase mode, users can set the 3\_Phase for different frequency output. Assuming the 3\_Phase output frequencies are varied and users set them to the same when the phase re-lock function is disabled, the phase difference of the 3\_Phase output does not return to default (each phase difference is 120°) as Figure 3-3 shows. The phase difference of 3\_Phase output will return to default (each phase difference is 120°) as Figure 3-4 shows when the phase re-lock function is enabled.

Press Phase re-lock on the right to enable or disable the function.

3 Phase		300V	LOCAL	QUIT
OUTPUT SETTING				
#1	Vac =	0.0V	F =	60.0Hz
#2	Vac =	0.0V	F =	60.0Hz
#3	Vac =	0.0V	F =	60.0Hz
MORE SETTING				
#1	Waveform =	A		
		SINE		
#2	Waveform =	A		
		SINE		
#3	Waveform =	A		
		SINE		
	ON Degree =	0.0	OFF Degree =	IMMED
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms
	F S/R =	0.000Hz/ms		
	Phase angle 1-2 =	120.0	Phase angle 1-3 =	240.0
Coupling	Range	Three Phase Setting		
AC	300V			2008/10/13 10:40:40




Figure 3-3 Phase Re-lock Disabled






Figure 3-4 Phase Re-lock Enabled

### 3.3.1.4 Output Degree

The AC Source can control the degree of the waveform during output or when stopping the output. In MAIN PAGE (3\_Phase Mode/1\_Phase Mode) (see 3.3), press OUTPUT: More Setting on the right to set ON Degree and OFF Degree.

Following lists the procedure for setting the output phase degree to ON Degree = 90 and OFF Degree=180 in 1\_Phase/3\_Phase Mode.

1. Press OUTPUT : More Setting on the right.
2. Move the cursor to “ON Degree= ” command position.
3. Press **[9]**, **[0]**, and **[ENTER]** to change the value to "90.0."
4. The cursor moves to “OFF Degree= ” command position automatically.
5. Press **[1]**, **[8]**, **[0]**, and **[ENTER]** to change the value to "180.0."

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz	Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					
#1	Waveform = A				Waveform Viewer
	SINE				
#2	Waveform = A				Limitation
	SINE				
#3	Waveform = A				
	SINE				
	ON Degree =	90.0	OFF Degree =	180.0	
	Vac S/R =	0.000V/ms	Vdc S/R =	0.000V/ms	
	F S/R =	0.000Hz/ms			
	Phase angle 1-2 =	120.0	Phase angle 1-3 =	240.0	
Coupling	Range	Three Phase			2008/10/13 18:44:37
AC	300V	Setting			
1_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
MORE SETTING					
	Waveform = A				Waveform Viewer
	SINE				
	ON Degree =	90.0			Limitation
	OFF Degree =	180.0			
	Vac S/R =	0.000V/ms			
	Vdc S/R =	0.000V/ms			
	F S/R =	0.000Hz/ms			
Coupling	Range				2008/10/13 18:43:31
AC	300V				

**NOTICE**

If "OFF Degree=IMMED" when **[QUIT]** is pressed, the output voltage jumps off immediately. If a degree is already set, it will output voltage till it reaches the set degree. Input “OFF Degree= 360” will turn into “OFF Degree= IMMED.”

### 3.3.1.5 Slew Rate of Output Transient

The AC Source has the ability to set the slew rate of the voltage waveform. This is done through 3 commands in OUTPUT: More Setting, which are Vac S/R, F S/R and Vdc S/R which control the change speed of voltage waveform change.

- Vac S/R: It the slew rate of Vac output.
- F S/R: It is the slew rate of frequency output.
- Vdc S/R: It is the slew rate of Vdc output.

Change the output setting in MAIN PAGE when the AC Source is in OUT mode, the output voltage and frequency will change to follow the setting of Vac S/R, F S/R and Vdc S/R.

The procedure of setting Vac S/R =0.2, F S/R =0.1 and Vdc S/R =1 in 1\_Phase/3\_Phase Mode is described below.

1. Move the cursor to “Vac S/R =” command line.
2. Press **[0]**, **[.]**, **[2]** and **[ENTER]** to change the value to “0.2.”
3. The cursor moves to “F S/R =” command automatically, press **[0]**, **[.]**, **[1]** and **[ENTER]**.
4. The cursor moves to “Vdc S/R =” command automatically, press **[1]** and **[ENTER]**.


3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac = 0.0V F = 60.0Hz				OUTPUT: More Setting
#2	Vac = 0.0V F = 60.0Hz				Measurement Setting
#3	Vac = 0.0V F = 60.0Hz				Waveform Viewer
MORE SETTING					
#1	Waveform = A SINE				Limitation
#2	Waveform = A SINE				
#3	Waveform = A SINE				
ON Degree = 0.0		OFF Degree = IMMED			
Vac S/R = 0.200V/ms		Vdc S/R = 1.000V/ms			
F S/R = 0.100Hz/ms					
Phase angle 1-2 = 120.0		Phase angle 1-3 = 240.0			
Coupling AC	Range 300V	Threc Phase Setting			2008/10/13 18:45:20
1 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Vac = 0.0V F = 60.0Hz					OUTPUT: More Setting
					Measurement Setting
MORE SETTING					
Waveform = A SINE					Waveform Viewer
					Limitation
ON Degree = 0.0		OFF Degree = IMMED			
Vac S/R = 0.200V/ms		Vdc S/R = 1.000V/ms			
F S/R = 0.100Hz/ms					
Coupling AC	Range 300V				2008/10/13 18:45:47

**① NOTICE**

- 
1. When setting Vac S/R = 0, F S/R = 0, Vdc S/R = 0, the output transient outputs in the highest speed.
  2. Though the input range of Vac S/R, F S/R, Vdc S/R is quite large when using the software editor, the output voltage may not apply the slew rate properly due to the hardware restriction when the Vac S/R, F S/R and Vdc S/R are too large. The maximum of Vac S/R and Vdc S/R is 1200V/ms and the minimum is 0.001V/ms. The maximum of F S/R is 1600Hz/ms and the minimum is 0.001Hz/ms.
  3. When executing **OUT** on the AC Source the output will reach the final state as set. Once QUIT is executed, the output turns to 0V immediately. If users wish to output following the slew rate is already set, it is necessary to key in 0V and press **ENTER** instead of pressing **QUIT** directly.
- 

### 3.3.1.6 Output Degree of 3-phase Voltage Output

On the other hand, the AC Source is able to set the phase difference degree for 3\_Phase output voltage. For instance, the phase difference among the 3 phases is 120 degree for the output voltage with 3\_Phase balance positive sequence as the figure shown below.



Following lists the procedure for setting the output voltage to 3\_Phase balance with 120 degree phase difference among the 3 phases.

1. Move the cursor to “Phase angle 1-2 =” command line.
2. Press **1**, **2**, **0** and **ENTER**.
3. Move the cursor to “Phase angle 1-3 =” command line.
4. Press **2**, **4**, **0** and **ENTER**.

3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
#1	Vac =	0.0V	F =	60.0Hz	OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz	
#3	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					
#1	Waveform = A	SINE			Waveform Viewer
#2	Waveform = A	SINE			
#3	Waveform = A	SINE			
ON Degree = 0.0      OFF Degree = IMMED					Limitation
Vac S/R = 0.000V/ms		Vdc S/R = 0.000V/ms			
F S/R = 0.000Hz/ms					
Phase angle 1-2 = 120.0		Phase angle 1-3 = 240.0			
Coupling AC	Range 300V	Three Phase Setting			2008/10/13 10:46:38

**NOTICE**

Since the 3\_Phase voltage output of the AC Source is running independently, it is able to set the phase difference of 3\_Phase output to unbalance, such as Phase angle 1-2 = 100, Phase angle 1-3 = 200.

**3.3.1.7 Output Waveform Selection Enable (31120A/31180A only)**


The AC Source has two sets of unique waveforms, A and B. Each of them has sine, square, clipped sine waveforms and 30 sets of built-in waveforms along with 6 sets of user defined waveforms.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Waveform
#1	Vac =	0.0V	F =	60.0Hz	Edit Each
#2	Vac =	0.0V	F =	60.0Hz	
#3	Vac =	0.0V	F =	60.0Hz	
MORE SETTING					
#1	Waveform A =	SINE			View Waveform
	Waveform B =	SINE			
#2	Waveform A =	SINE			
	Waveform B =	SINE			
#3	Waveform A =	SINE			
	Waveform B =	SINE			
Coupling AC	Range 300V	Three Phase Setting	Output Waveform Selection	Zc Program Disable	2008/10/14 15:45:23

Follow the steps below to set the 3-phase waveform to A and to sine:

- 1 Press Edit on the right and use RPG to change the selection to All.
- 2 Move the cursor to WAVE A command line.
- 3 Turn the RPG to select "SINE" and press **ENTER**.

Users can press "View Waveform" on the right to view the set waveform.



Follow the steps below to set the A waveform of 3-phase to clipped sine with a total harmonic distortion of 35%.


- 1 Press Edit on the right and use RPG to change the selection to All.
- 2 Move the cursor to the WAVE A command line and select "CSIN".
- 3 The LCD screen to show MODE and PERCENT.
- 4 Turn the RPG to change MODE to "THD" and press **ENTER**.
- 5 Press **3**, **5** and **ENTER** to set the THD to be 35%.

Users can press "View Waveform" on the right to view the set waveform.

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Waveform
#1	Vac =	0.0V	F =	60.0Hz		Edit All
#2	Vac =	0.0V	F =	60.0Hz		Edit All
#3	Vac =	0.0V	F =	60.0Hz		
MORE SETTING						
#1	Waveform A =	SINE	Waveform B =	SINE		View Waveform
#2	Waveform A =	SINE	Waveform B =	SINE		
#3	Waveform A =	SINE	Waveform B =	SINE		
Coupling	Range	Three Phase Setting	Output Waveform Selection	Zo Program Disable		2008/10/14 15:45:58

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Waveform
#1	Vac =	0.0V	F =	60.0Hz		Edit All
#2	Vac =	0.0V	F =	60.0Hz		Edit All
#3	Vac =	0.0V	F =	60.0Hz		
MORE SETTING						
#1	Waveform A =	CSIN	Mode =THD	Percent = 35%		View Waveform
#2	Waveform A =	CSIN	Mode =THD	Percent = 35%		
#3	Waveform A =	CSIN	Mode =THD	Percent = 35%		
Coupling	Range	Three Phase Setting	Output Waveform Selection	Zo Program Disable		2008/10/14 15:47:31



**NOTICE**

- 1 Clipped sine waveform can be programmed via “Amplitude” or “Total Harmonic Distortion”. The amplitude range is from 0 to 100% (100%: without clipping) while the Total Harmonic Distortion range is from 0 to 43% (0%: without distortion.)
- 2 User defined waveform needs to be defined by and downloaded from the remote PC.
- 3 For detail DST waveform, please see *Appendix B Built-in DST Waveform*.

**" WARNING**

- 1 When using the user defined waveform, it may cause the AC Source to be damaged if the waveform frequency exceeds 1000Hz.
- 2 Due to the bandwidth restriction of AC Source, distortion may occur on the output especially when the user defined waveform contains high frequency.

**3.3.1.8 Zo Program Enable (31120A/31180A only)**

The output impedance of AC Source is very low; however users may need special output impedances in certain test conditions. The output impedance can be programmed within a certain range using the Zo Program under OUTPUT SETTING (3.3.1) in the AC Source.

3_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
01	Vac = 0.0V	F = 60.0Hz			OUTPUT: More Setting
02	Vac = 0.0V	F = 60.0Hz			
03	Vac = 0.0V	F = 60.0Hz			Measurement Setting
MORE SETTING					
01	Waveform = A SINE	Zo_R = 0.000 Zo_L = 0.00mH			Waveform Viewer
02	Waveform = A SINE	Zo_R = 0.000 Zo_L = 0.00mH			
03	Waveform = A SINE	Zo_R = 0.000 Zo_L = 0.00mH			Limitation
ON Degree = 0.0		OFF Degree = 100.0		Output Mode	
Vac S/R = 0.000V/ms		Vdc S/R = 0.000V/ms			
F S/R = 0.000Hz/ms					
Phase angle 1-2 = 120.0		Phase angle 1-3 = 240.0			
Coupling AC	Range 300V	Three Phase Setting	Output Waveform Selection	Zo Program Enable	2005/10/14 19:54:16





Follow the steps below to set the output impedance Zo Program = Enable, R = 1.0Ω, and L = 1.0mH:

- 1 Press Zo Program at the bottom.
- 2
- 3
- 4
- 5

Turn RPG to switch to “Enable” and press **ENTER**.  
 The cursor moves to “Zo R = ” command line automatically.  
 Press **1**, **.**, **0**, and **ENTER** to change Zo\_R to “1.0Ω.”  
 Press **1**, **.**, **0**, and **ENTER** to change Zo\_L to “1.0 mH.”

<b>3_Phase 300V LOCAL QUIT</b> OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz MORE SETTING #1 Waveform = A #2 Waveform = A #3 Waveform = A ON Degree = 0.0 OFF Degree = IMMED Vac S/R = 0.000V/ms Vdc S/R = 0.000V/ms F S/R = 0.000Hz/ms Phase angle 1-2 = 120.0 Phase angle 1-3 = 240.0 Coupling AC Range 300V Three Phase Setting Output Waveform Selection Zo Program Disable 2008/10/14 15:53:23		<b>3_Phase 300V LOCAL QUIT</b> OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz MORE SETTING #1 Waveform = A #2 Waveform = A #3 Waveform = A ON Degree = 0.0 OFF Degree = IMMED Vac S/R = 0.000V/ms Vdc S/R = 0.000V/ms F S/R = 0.000Hz/ms Phase angle 1-2 = 120.0 Phase angle 1-3 = 240.0 Coupling AC Range 300V Three Phase Setting Output Waveform Selection Zo Program <b>Enable</b> 2008/10/14 15:54:05	
<b>3_Phase 300V LOCAL QUIT</b> OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz MORE SETTING #1 Waveform = A Zo_R = 0.000 #2 Waveform = A Zo_L = 0.00mH #3 Waveform = A Zo_R = 0.000 ON Degree = 0.0 OFF Degree = IMMED Vac S/R = 0.000V/ms Vdc S/R = 0.000V/ms F S/R = 0.000Hz/ms Phase angle 1-2 = 120.0 Phase angle 1-3 = 240.0 Coupling AC Range 300V Three Phase Setting Output Waveform Selection Zo Program <b>Enable</b> 2008/10/14 15:54:16		<b>3_Phase 300V LOCAL QUIT</b> OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz MORE SETTING #1 Waveform = A Zo_R = 1.000 #2 Waveform = A Zo_L = 1.00mH #3 Waveform = A Zo_R = 0.000 ON Degree = 0.0 OFF Degree = IMMED Vac S/R = 0.000V/ms Vdc S/R = 0.000V/ms F S/R = 0.000Hz/ms Phase angle 1-2 = 120.0 Phase angle 1-3 = 240.0 Coupling AC Range 300V Three Phase Setting Output Waveform Selection Zo Program <b>Enable</b> 2008/10/14 15:55:04	

**NOTICE**

- 1 When Zo Program = Enable, the AC Source uses current feedback to reprogram the output waveform to meet the setting. However, the output impedance is the AC Source’s original reading if Zo Program = Disable.
- 2 The programmable output impedance function is invalid for DC outputs.
- 3 The programmable output impedance function is invalid for 1\_Phase Mode.

**" WARNING**

The maximum of Zo\_R and Zo\_L is 1.0Ω and 1.0 mH. However, if L is over 0.5 mH and the

output voltage is too low (<100Vac), it may cause the AC Source to be unstable, especially when the output current is too great. Users have to program the inductance to the desired level slowly. If there is incorrect high frequency/voltage output or noise, monitor the output voltage and the sound of the AC Source. Do not use output impedance program but external impedance circuit when unstable condition occurs.

### 3.3.2 Measurement Setting

Press Measurement Setting on the right in MAIN PAGE (3\_Phase Mode/1\_Phase Mode) to set the measurement as the figure shown below. There are 12 measurement items in the setting screen such as voltage, current, output power and etc. The setting is done by moving the cursor to each item and use the RPG to select the required test item and press **ENTER**.

Below is procedure to change the 3<sup>rd</sup> measurement item from Po to VA in 3\_Phase mode.

1. Press Measurement Setting on the right in MAIN PAGE (3\_Phase Mode).
2. Move the cursor to "Po."
3. Use the RPG to select "VA" and press **ENTER**.
4. Press **←** to return to MAIN PAGE.

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#3	Vac =	0.0V	F =	60.0Hz		Measurement Setting
MEASUREMENT SETTING						
#1	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Waveform Viewer
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Limitation
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times: 1	Isurge Delay: 10ms	Isurge Interval: 10ms	Edit Each		2008/10/13 18:47:36

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#3	Vac =	0.0V	F =	60.0Hz		Measurement Setting
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Waveform Viewer
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Limitation
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times: 1	Isurge Delay: 10ms	Isurge Interval: 10ms	Edit Each		2008/10/13 18:02:30

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#3	Vac =	0.0V	F =	60.0Hz		Measurement Setting
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Waveform Viewer
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
						Limitation
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times: 1	Isurge Delay: 10ms	Isurge Interval: 10ms	Edit Each		2008/10/13 18:03:44

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Main
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#3	Vac =	0.0V	F =	60.0Hz		Measurement Setting
MEASUREMENT						
#1	V	=	0.00	VA	=	0.0
	I	=	0.000	PF	=	0.000
						Waveform Viewer
#2	V	=	0.00	Po	=	0.0
	I	=	0.000	PF	=	0.000
						Limitation
#3	V	=	0.00	Po	=	0.0
	I	=	0.000	PF	=	0.000
Σ	V12	=	0.00	V31	=	0.00
	V23	=	0.00	Po	=	0.0
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 18:04:02

Below is the procedure to the 2<sup>nd</sup> measurement item from I to Iac in 1\_Phase mode.

1. Press Measurement Setting on the right in MAIN PAGE (1\_Phase Mode).
2. Move the cursor to "I."
3. Use the RPG to select "Iac" and press **ENTER**.
4. Press **←** to return to MAIN PAGE.

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING Vac = 0.0V F = 60.0Hz						Setting
						OUTPUT: More Setting
						Measurement Setting
MEASUREMENT SETTING						
V	Po	Vac	Vdc	Vpk	VA	Waveform Viewer
I	PF	Iac	Idc	Ipk	CF	Limitation
Current Range	Average Times 1	Isurge Start 10ms	Isurge Interval 10ms			2008/10/13 19:04:28

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING Vac = 0.0V F = 60.0Hz						Setting
						OUTPUT: More Setting
						Measurement Setting
MEASUREMENT SETTING						
V	Po	Vac	Vdc	Vpk	VA	Waveform Viewer
I	PF	Iac	Idc	Ipk	CF	Limitation
Current Range	Average Times 1	Isurge Start 10ms	Isurge Interval 10ms			2008/10/13 19:04:42

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING Vac = 0.0V F = 60.0Hz						Setting
						OUTPUT: More Setting
						Measurement Setting
MEASUREMENT SETTING						
V	Po	Vac	Vdc	Vpk	VA	Waveform Viewer
I	PF	Iac	Idc	Ipk	CF	Limitation
Current Range	Average Times 1	Isurge Start 10ms	Isurge Interval 10ms			2008/10/13 19:04:49

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING Vac = 0.0V F = 60.0Hz						Main
						OUTPUT: More Setting
						Measurement Setting
MEASUREMENT						
V	Po	Vac	Vdc	Vpk	VA	Waveform Viewer
I	PF	Iac	Idc	Ipk	CF	Limitation
V = 0.00	Po = 0.0	Vac = 0.00	Vdc = 0.00	Vpk = 0.00	VA = 0.0	
Iac = 0.000	PF = 0.000	Iac = 0.000	Idc = 0.000	Ipk = 0.00	CF = 0.000	
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 19:05:35

### 3.3.2.1 Current Range

Press Current Range at the bottom can set the current detection range. Setting appropriate current range will result in a more accurate current measurement. The current value of each range is the maximum value it can detect. If the output current is larger than the maximum current the range can detect, the screen will show I = OVRRange. The current detection ranges are listed below.

31180:

**Φ1 Range:**12A, 48A, 192A, Auto.

**Φ2 Range:**12A, 48A, 192A, Auto.

**Φ3 Range:**12A, 48A, 192A, Auto.

31120:

**Φ1 Range:** 8A, 32A, 128A, Auto.

**Φ2 Range:** 8A, 32A, 128A, Auto.

**Φ3 Range:** 8A, 32A, 128A, Auto.

The procedure for setting the current detection range of the 1<sup>st</sup> phase to 12A is described below:

1. Press Current Range at the bottom.
2. Press Φ1 Range on the right.
3. Turn the RPG to change to “12A” and press **ENTER**.

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		#1 Range
#2	Vac =	0.0V	F =	60.0Hz		192A
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each		2008/10/13 19:06:02

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		#1 Range
#2	Vac =	0.0V	F =	60.0Hz		12A
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each		2008/10/13 19:06:25

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		#1 Range
#2	Vac =	0.0V	F =	60.0Hz		12A
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each		2008/10/13 19:06:41

3_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		#1 Range
#2	Vac =	0.0V	F =	60.0Hz		12A
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT SETTING						
#1	V	VA	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#2	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
#3	V	Po	Vac	Vdc	Vpk	VA
	I	PF	Iac	Idc	Ipk	CF
Σ	V12	V31	V12	V31		
	V23	Po	V23	VA		
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each		2008/10/13 19:06:52

### 3.3.2.2 Average Times

Average Times is the sampling average of voltage/current RMS and voltage/current peak. The AC Source uses moving windows for sampling. When “4” is selected for Average Times it indicates it will be sampling 4 times in moving windows.

Press Average Times at the bottom to set the average times for sampling. When the measurement is fluctuated severely, higher sampling average times can be set to improve the measurement accuracy. The average times for sampling to be set are listed below.

**Average Times:** 1, 2, 4, 8, 16, 32.

The steps for setting the sampling average times to 1 are described below.

1. Press Average Times at the bottom.
2. Turn the RPG to switch to “1” and press **ENTER**.

3 Phase 300V LOCAL QUIT							
OUTPUT SETTING						Setting	
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT:	
#2	Vac =	0.0V	F =	60.0Hz		More Setting	
#3	Vac =	0.0V	F =	60.0Hz		Measurement Setting	
MEASUREMENT SETTING							
#1	V	VA	Vac	Vdc	Vpk	VA	Waveform Viewer
	I	PF	Iac	Idc	Ipk	CF	
#2	V	Po	Vac	Vdc	Vpk	VA	Limitation
	I	PF	Iac	Idc	Ipk	CF	
#3	V	Po	Vac	Vdc	Vpk	VA	
	I	PF	Iac	Idc	Ipk	CF	
	V <sub>12</sub>	V <sub>31</sub>	V <sub>12</sub>	V <sub>31</sub>			
	V <sub>23</sub>	Po	V <sub>23</sub>	VA			
	Current Range	Average Times	Isurge Delay 10ms	Isurge Interval 10ms	Edit Each		2008/10/13 10:07:48

### 3.3.2.3 Isurge Delay, Isurge Interval

The Isurge in Measurement Setting is the surge peak current output by the AC Source. Isurge measurement starts after Isurge Delay when the voltage output changes. The measurement time is set by Isurge Interval. These two functions can be set by Measurement Setting.

The procedure for setting Isurge Delay = 10 ms, Isurge Interval = 10 ms is described below.

1. Move the cursor to “Isurge Delay =” command line.
2. Press **1**, **0** and **ENTER** to change the value to “10.0.”
3. Move the cursor to “Isurge Interval =” command line.
4. Press **1**, **0** and **ENTER** to change the value “10.0.”

3 Phase 300V LOCAL QUIT												
OUTPUT SETTING										Setting		
#1	Vac =	0.0V	F =	60.0Hz								Setting
#2	Vac =	0.0V	F =	60.0Hz								More Setting
#3	Vac =	0.0V	F =	60.0Hz								Measurement Setting
MEASUREMENT SETTING										Setting		
#1	V	VA	Vac	Vdc	Vpk	VA						Waveform Viewer
	I	PF	Iac	Idc	Ipk	CF						
#2	V	Po	Vac	Vdc	Vpk	VA						Limitation
	I	PF	Iac	Idc	Ipk	CF						
#3	V	Po	Vac	Vdc	Vpk	VA						
	I	PF	Iac	Idc	Ipk	CF						
Σ	V12	V31	V12	V31								
	V23	Po	V23	VA								
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each								2008/10/13 19:08:25

3 Phase 300V LOCAL QUIT												
OUTPUT SETTING										Setting		
#1	Vac =	0.0V	F =	60.0Hz								Setting
#2	Vac =	0.0V	F =	60.0Hz								More Setting
#3	Vac =	0.0V	F =	60.0Hz								Measurement Setting
MEASUREMENT SETTING										Setting		
#1	V	VA	Vac	Vdc	Vpk	VA						Waveform Viewer
	I	PF	Iac	Idc	Ipk	CF						
#2	V	Po	Vac	Vdc	Vpk	VA						Limitation
	I	PF	Iac	Idc	Ipk	CF						
#3	V	Po	Vac	Vdc	Vpk	VA						
	I	PF	Iac	Idc	Ipk	CF						
Σ	V12	V31	V12	V31								
	V23	Po	V23	VA								
Current Range	Average Times	Isurge Delay	Isurge Interval	Edit Each								2008/10/13 19:08:48

### 3.3.3 Waveform Viewer

Waveform View can be used to see the real time output voltage/current waveform. There are a total of 3 CH available. Voltage, current and time can be adjusted by the Scale command. The figure below shows the Waveform View.

**Ch1:** Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I.

**Ch2:** Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I.

**Ch3:** Φ1V, Φ2V, Φ3V, Φ1I, Φ2I, Φ3I.

**V Scale:** 10, 20, 40, 80, 120V/div.


**I Scale:** 5, 10, 20, 40, 60A/div.

**Time Scale:** 0.2, 0.5, 1, 2, 5, 10, 50, 100, 200ms/div.

The procedure for setting CH1 =Φ1V, CH2 =Φ2V, CH3 =Φ3V, V Scale = 10 V/div, I Scale = 5A/div, Time Scale =2 ms/div in 1\_Phase/3\_Phase Mode is described as below.

1. Press CH1 at the bottom.
2. Turn the RPG to change to “Φ1V” and press **ENTER**.
3. Press CH2 at the bottom.
4. Turn the RPG to change to “Φ2V” and press **ENTER**.
5. Press CH3 at the bottom.
6. Turn the RPG to change to “Φ3V” and press **ENTER**.
7. Press V Scale at the bottom.
8. Turn the RPG to change to “10” and press **ENTER**.
9. Press I Scale at the bottom.
10. Turn the RPG to change to “5” and press **ENTER**.
11. Press Time Scale at the bottom.
12. Turn the RPG to change to “2” and press **ENTER**.





### 3.3.4 Limitation

The Limit of AC Source 1\_Phase/3\_Phase output mode is set separately. For instance, the Vac Limit setting will apply the settings of the 1\_Phase mode when changing it from the 3\_Phase mode without applying the Limit settings of any one phase.


#### 3.3.4.1 Vac Limit

Vac Limit sets the Vac value in MAIN PAGE (3\_Phase Mode/1\_Phase Mode). Press Limitation on the right in MAIN PAGE (3\_Phase Mode/1\_Phase Mode) to set the Vac Limit. This command protects the planned program instead of the hardware.

Press Edit at the bottom to set the limitation of the 3-phase voltage output for “Each” or “All.”

The procedure to set Vac Limit = 300V in 1\_Phase/3\_Phase Mode is described below.

1. Move the cursor to “Vac =” command line.
2. Press **[3]**, **[0]**, **[0]** and **[ENTER]** to change the value to “300.0.”



**ⓘ NOTICE**

The setting of Vac Limit is not restricted by range; however, the Vac in MAIN PAGE is restricted by the range. For example, assuming the range is 150V, though Vac Limit = 300V the maximum Vac setting is 150V.

### 3.3.4.2 Vdc Limit (+), Vdc Limit (-)

Vdc Limit (+) and Vdc Limit (-) restrict the Vdc setting in MAIN PAGE (3\_Phase Mode/1\_Phase Mode). These two items can be set in the Limitation function (see 3.3.4). The Vdc setting can exceed Vdc Limit (+) but cannot be under Vdc Limit (-).

The procedure for setting Vdc (+) = 424.2V, Vdc (-) = 0V in 1\_Phase/3\_Phase Mode is described below.

1. Move the cursor to “Vdc (+) = ” command line.
2. Press **[4]**, **[2]**, **[4]**, **[.]**, **[2]** and **[ENTER]** to change the value to “424.2.”
3. Move the cursor to “Vdc (-) = ” command line.
4. Press **[0]** and **[ENTER]** to change the value to “0.0.”

3_Phase 300V LOCAL QUIT				1 Phase 300V LOCAL QUIT			
OUTPUT SETTING				OUTPUT SETTING			
#1	Vac =	0.0V	F = 60.0Hz				
#2	Vac =	0.0V	F = 60.0Hz				
#3	Vac =	0.0V	F = 60.0Hz				
LIMITATION				LIMITATION			
#1	Vac =	300.0V	Vdc (+) = 424.2V				
	F =	1500.0Hz	Vdc (-) = 0.0V				
#2	Vac =	300.0V	Vdc (+) = 424.2V				
	F =	1500.0Hz	Vdc (-) = 0.0V				
#3	Vac =	300.0V	Vdc (+) = 424.2V				
	F =	1500.0Hz	Vdc (-) = 0.0V				
Edit Each		Set to Maximum		Set to Minimum		2008/11/20 10:02:18	
						2008/11/20 10:01:48	

**ⓘ NOTICE**

1. The setting of Vdc Limit is not restricted by range; however, the Vdc in MAIN PAGE is restricted by the range. For example, assuming the range is 150V, though Vdc Limit=424.2V the maximum Vdc setting is 212.1V.
2. It is better to restrict the Vdc value when the output contains it. It may cause damage if the output polarity is reversed especially the load polarity.

## 3.4 CONFIG Function Key

Press **[CONFIG]** in the **FUNCTION** keys shown below to enter into CONFIG function. (3\_Phase Mode/1\_Phase Mode).





Figure 3-5 FUNCTION Keys

3 Phase 300V LOCAL QUIT							1 Phase 300V LOCAL QUIT							
OUTPUT SETTING						Config	OUTPUT SETTING						Config	
#1	Vac = 0.0V	F = 60.0Hz					Interface	Vac = 0.0V F = 60.0Hz						Interface
#2	Vac = 0.0V	F = 60.0Hz					External Vref							External Vref
#3	Vac = 0.0V	F = 60.0Hz					Display	MEASUREMENT						Display
MEASUREMENT						PowerON Status	V = 0.00 VA = 0.0						PowerON Status	
#1	V = 0.00	VA = 0.0					Protection	Iac = 0.000 PF = 0.000						Protection
#2	I = 0.000	PF = 0.000					More 1 of 2	V = 0.00 Po = 0.0						More 1 of 2
#3	V = 0.00	Po = 0.0						Iac = 0.000 Vdc = 0.00						
							I = 0.000 PF = 0.000							
							Vpk = 0.00 VA = 0.0							
							Ipk = 0.000 CF = 0.000							
							V12 = 0.00 V31 = 0.00							
							V23 = 0.00 Po = 0.0							
GPIB Address 30						2008/10/13 19:14:39	GPIB Address 30						2008/10/13 19:15:07	
RS232 Parity None							RS232 Parity None							
RS232 Baudrate 115200							RS232 Baudrate 115200							
Remote Inhibit Disable							Remote Inhibit Disable							
EXT. ON/OFF Disable							EXT. ON/OFF Disable							
Ethernet Setting							Ethernet Setting							

### 3.4.1 Interface

#### 3.4.1.1 GPIB Address, RS-232C Parity/Baudrate

The AC Source also has remote operation mode that can be activated by the CONFIG function (3\_Phase Mode/1\_Phase Mode). It is necessary to set GPIB Address to 30 before conducting remote operation in 1\_Phase/3\_Phase Mode.

1. Press GPIB Address at the bottom.
2. Turn the RPG to change the Address and press **ENTER** to set Address 30.

3_Phase 300V LOCAL QUIT							1_Phase 300V LOCAL QUIT							
OUTPUT SETTING						Config	OUTPUT SETTING						Config	
#1	Vac = 0.0V	F = 60.0Hz					Interface	Vac = 0.0V F = 60.0Hz						Interface
#2	Vac = 0.0V	F = 60.0Hz					External Vref							External Vref
#3	Vac = 0.0V	F = 60.0Hz					Display	MEASUREMENT						Display
MEASUREMENT						PowerON Status	V = 0.00 VA = 0.0						PowerON Status	
#1	V = 0.00	VA = 0.0					Protection	Iac = 0.000 PF = 0.000						Protection
#2	I = 0.000	PF = 0.000					More 1 of 2	V = 0.00 Po = 0.0						More 1 of 2
#3	V = 0.00	Po = 0.0						Iac = 0.000 Vdc = 0.00						
							I = 0.000 PF = 0.000							
							Vpk = 0.00 VA = 0.0							
							Ipk = 0.000 CF = 0.000							
							V12 = 0.00 V31 = 0.00							
							V23 = 0.00 Po = 0.0							
GPIB Address 30						2008/10/13 19:16:15	GPIB Address 30						2008/10/13 19:15:39	
RS232 Parity None							RS232 Parity None							
RS232 Baudrate 115200							RS232 Baudrate 115200							
Remote Inhibit Disable							Remote Inhibit Disable							
EXT. ON/OFF Disable							EXT. ON/OFF Disable							
Ethernet Setting							Ethernet Setting							

**NOTICE**

The address range is from 1 to 30.

The AC Source uses the RS-232C bus to provide remote operation. Follow the steps below to set the communication protocol.

Set Parity=None and Baudrate =115200 in 1\_Phase/3\_Phase Mode as described below:

1. Press RS232 Parity at the bottom.
2. Turn the RPG to select None and press **ENTER**.
3. Press RS232 Baudrate at the bottom.
4. Turn the RPG to “115200” and press **ENTER**.

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Config
#1	Vac = 0.0V	F = 60.0Hz				Interface
#2	Vac = 0.0V	F = 60.0Hz				External Vref
#3	Vac = 0.0V	F = 60.0Hz				Display
MEASUREMENT						PowerON Status
#1	V = 0.00	VA = 0.0				Protection
#2	I = 0.000	PF = 0.000				More 1 of 2
#3	V = 0.00	Po = 0.0				GPB Address 30
	I = 0.000	PF = 0.000				RS232 Parity None
	V12 = 0.00	V31 = 0.00				RS232 Baudrate 115200
	V23 = 0.00	Po = 0.0				Remote Inhibit Disable
						EXT. ON/OFF Disable
						Ethernet Setting
						2008/10/13 19:17:27

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Config
#1	Vac = 0.0V	F = 60.0Hz				Interface
#2	Vac = 0.0V	F = 60.0Hz				External Vref
#3	Vac = 0.0V	F = 60.0Hz				Display
MEASUREMENT						PowerON Status
#1	V = 0.00	VA = 0.0				Protection
#2	I = 0.000	PF = 0.000				More 1 of 2
#3	V = 0.00	Po = 0.0				GPB Address 30
	I = 0.000	PF = 0.000				RS232 Parity None
	V12 = 0.00	V31 = 0.00				RS232 Baudrate 115200
	V23 = 0.00	Po = 0.0				Remote Inhibit Disable
						EXT. ON/OFF Disable
						Ethernet Setting
						2008/10/13 19:18:19

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Config
Vac = 0.0V F = 60.0Hz						Interface
						External Vref
MEASUREMENT						Display
V = 0.00 Po = 0.0						PowerON Status
Iac = 0.000 PF = 0.000						Protection
Vac = 0.00 Vdc = 0.00						More 1 of 2
Iac = 0.000 Idc = 0.000						GPB Address 30
Vpk = 0.00 VA = 0.0						RS232 Parity None
Ipk = 0.000 CF = 0.000						RS232 Baudrate 115200
						Remote Inhibit Disable
						EXT. ON/OFF Disable
						Ethernet Setting
						2008/10/13 19:18:45

1 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Config
Vac = 0.0V F = 60.0Hz						Interface
						External Vref
MEASUREMENT						Display
V = 0.00 Po = 0.0						PowerON Status
Iac = 0.000 PF = 0.000						Protection
Vac = 0.00 Vdc = 0.00						More 1 of 2
Iac = 0.000 Idc = 0.000						GPB Address 30
Vpk = 0.00 VA = 0.0						RS232 Parity None
Ipk = 0.000 CF = 0.000						RS232 Baudrate 115200
						Remote Inhibit Disable
						EXT. ON/OFF Disable
						Ethernet Setting
						2008/10/13 19:18:55

**NOTICE**

The baudrate selections are 9600/19200/38400/57600/115200 and the selections for parity are EVEN/ODD/NONE.

### 3.4.1.2 Remote Inhibit, EXT. ON/OFF

The output of AC Source can be inhibited by external control or manual trigger. The output signal of the remote inhibit (remote control) is received from the TTL terminal on the rear

panel (see Appendix A.) Remote Inhibit and EXT. ON/OFF are set by the CONFIG function (3\_Phase Mode/1\_Phase Mode). There are two remote inhibit output states: Enable and Disable.

**Remote Inhibit:** When the Remote Inhibit is enabled on the AC Source and the Remote Inhibit signal is LOW, the AC Source will disable the output. The AC Source holds the output disabled even when the Remote Inhibit signal turns to HIGH. In order to re-enable the output, the user must press **OUT/QUIT** to restart output.

**EXT. ON/OFF:** When the EXT. ON/OFF is enabled on the AC Source and the EXT. ON/OFF signal is LOW, the AC Source will disable the output. The AC Source will re-enable the output when the EXT. ON/OFF signal turns to HIGH.

The procedure for setting Remote Inhibit/EXT. ON/OFF to disable in 1\_Phase/3\_Phase Mode is described below.

1. Press Remote Inhibit/EXT. ON/OFF at the bottom.
2. Turn the RPG to change to “Disable” and press **ENTER**.

<b>3 Phase 300V LOCAL QUIT</b>							
OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz							Config Interface
MEASUREMENT #1 V = 0.00 VA = 0.0 I = 0.000 PF = 0.000 #2 V = 0.00 P <sub>o</sub> = 0.0 I = 0.000 PF = 0.000 #3 V = 0.00 P <sub>o</sub> = 0.0 I = 0.000 PF = 0.000 V <sub>12</sub> = 0.00 V <sub>31</sub> = 0.00 V <sub>23</sub> = 0.00 P <sub>o</sub> = 0.0							External Vref Display PowerON Status Protection More 1 of 2
GPIB Address 20	RS232 Parity None	RS232 Baudrate 115200	Remote Inhibit <b>Disable</b>	EXT. ON/OFF Disable	Ethernet Setting	2008/10/13 19:20:41	

<b>1_Phase 300V LOCAL QUIT</b>							
OUTPUT SETTING Vac = 0.0V F = 60.0Hz							Config Interface
MEASUREMENT V = 0.00 P <sub>o</sub> = 0.0 I <sub>ac</sub> = 0.000 PF = 0.000 Vac = 0.00 V <sub>dc</sub> = 0.00 I <sub>ac</sub> = 0.000 I <sub>dc</sub> = 0.000 V <sub>pk</sub> = 0.00 VA = 0.0 I <sub>pk</sub> = 0.000 CF = 0.000							External Vref Display PowerON Status Protection More 1 of 2
GPIB Address 20	RS232 Parity None	RS232 Baudrate 115200	Remote Inhibit <b>Disable</b>	EXT. ON/OFF Disable	Ethernet Setting	2008/10/13 19:19:54	

<b>3 Phase 300V LOCAL QUIT</b>							
OUTPUT SETTING #1 Vac = 0.0V F = 60.0Hz #2 Vac = 0.0V F = 60.0Hz #3 Vac = 0.0V F = 60.0Hz							Config Interface
MEASUREMENT #1 V = 0.00 VA = 0.0 I = 0.000 PF = 0.000 #2 V = 0.00 P <sub>o</sub> = 0.0 I = 0.000 PF = 0.000 #3 V = 0.00 P <sub>o</sub> = 0.0 I = 0.000 PF = 0.000 V <sub>12</sub> = 0.00 V <sub>31</sub> = 0.00 V <sub>23</sub> = 0.00 P <sub>o</sub> = 0.0							External Vref Display PowerON Status Protection More 1 of 2
GPIB Address 20	RS232 Parity None	RS232 Baudrate 115200	Remote Inhibit Disable	EXT. ON/OFF <b>Disable</b>	Ethernet Setting	2008/10/13 19:20:50	

<b>1_Phase 300V LOCAL QUIT</b>							
OUTPUT SETTING Vac = 0.0V F = 60.0Hz							Config Interface
MEASUREMENT V = 0.00 P <sub>o</sub> = 0.0 I <sub>ac</sub> = 0.000 PF = 0.000 Vac = 0.00 V <sub>dc</sub> = 0.00 I <sub>ac</sub> = 0.000 I <sub>dc</sub> = 0.000 V <sub>pk</sub> = 0.00 VA = 0.0 I <sub>pk</sub> = 0.000 CF = 0.000							External Vref Display PowerON Status Protection More 1 of 2
GPIB Address 20	RS232 Parity None	RS232 Baudrate 115200	Remote Inhibit Disable	EXT. ON/OFF <b>Disable</b>	Ethernet Setting	2008/10/13 19:20:22	

**ⓘ NOTICE**

The output of the Remote Inhibit (Remote Control) transmits the TTL signals via a special I/O connector. See Appendix A *TTL Signal Pin Assignments* for the detail info.

### 3.4.1.3 Ethernet Setting

The AC Source can be operated remotely through a network once the Ethernet Settings are complete.

**Network Setting:** Auto, Manual

The procedure for setting Network Settings manually in 1\_Phase/3\_Phase Mode is described below.

1. Press Ethernet setting at the bottom.
2. Move the cursor to "Network Setting."
3. Turn the RPG to change to Manual and press **ENTER**.
4. Set the IP Address, Net Mask and Gateway.

3 Phase 300V LOCAL QUIT							Config
OUTPUT SETTING							Set
#1	Vac =	0.0V	F =	60.0Hz			
#2	Vac =	0.0V	F =	60.0Hz			
#3	Vac =	0.0V	F =	60.0Hz			
NETWORK SETTING							
Network Setting: Auto							
IP Address : 255 . 255 . 255 . 255							
Net Mask : 255 . 255 . 255 . 255							
Gateway : 255 . 255 . 255 . 255							
LAN Status = SETTING.....							
OPiB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:21:20	
30	None	115200	Disable	Disable			

3 Phase 300V LOCAL QUIT							Config
OUTPUT SETTING							Set
#1	Vac =	0.0V	F =	60.0Hz			
#2	Vac =	0.0V	F =	60.0Hz			
#3	Vac =	0.0V	F =	60.0Hz			
NETWORK SETTING							
Network Setting: Manual							
IP Address : 255 . 255 . 255 . 255							
Net Mask : 255 . 255 . 255 . 255							
Gateway : 255 . 255 . 255 . 255							
LAN Status = SETTING.....							
OPiB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:21:59	
30	None	115200	Disable	Disable			

3 Phase 300V LOCAL QUIT							Config
OUTPUT SETTING							Set
#1	Vac =	0.0V	F =	60.0Hz			
#2	Vac =	0.0V	F =	60.0Hz			
#3	Vac =	0.0V	F =	60.0Hz			
NETWORK SETTING							
Network Setting: Manual							
IP Address : 192 . 168 . 0 . 1							
Net Mask : 255 . 255 . 255 . 0							
Gateway : 192 . 168 . 0 . 254							
LAN Status = SETTING.....							
OPiB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:22:09	
30	None	115200	Disable	Disable			

1 Phase 300V LOCAL QUIT							
OUTPUT SETTING							Config
Vac = 0.0V F = 60.0Hz							Set
NETWORK SETTING							
Network Setting: Auto							
IP Address : 255 . 255 . 255 . 255							
Net Mask : 255 . 255 . 255 . 255							
Gateway : 255 . 255 . 255 . 255							
LAN Status = SETTING.....							
GPB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:22:32	
30	None	115200	Disable	Disable			

1 Phase 300V LOCAL QUIT							
OUTPUT SETTING							Config
Vac = 0.0V F = 60.0Hz							Set
NETWORK SETTING							
Network Setting: Manual							
IP Address : 255 . 255 . 255 . 255							
Net Mask : 255 . 255 . 255 . 255							
Gateway : 255 . 255 . 255 . 255							
LAN Status = SETTING.....							
GPB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:22:44	
30	None	115200	Disable	Disable			

1 Phase 300V LOCAL QUIT							
OUTPUT SETTING							Config
Vac = 0.0V F = 60.0Hz							Set
NETWORK SETTING							
Network Setting: Manual							
IP Address : 192 . 168 . 0 . 1							
Net Mask : 255 . 255 . 255 . 0							
Gateway : 192 . 168 . 0 . 254							
LAN Status = SETTING.....							
GPB	RS232	RS232	Remote	EXT.	Ethernet	2008/10/13	
Address	Parity	Baudrate	Inhibit	ON/OFF	Setting	19:22:54	
30	None	115200	Disable	Disable			

### 3.4.2 External Vref

The AC Source has the capability of using an analog control signal (simulated) from an external device to set its output (optional card is required.) The External Vref terminal socket at the rear panel allows users to apply signals to the AC Source for output voltage setting. The External Vref and the Control Method can be set by the CONFIG function (3\_Phase Mode/1\_Phase Mode). External Vref has two coupled modes to indicate the output of AC Source: Amplifier and Level. When the user is using single phase Ext. Vref, the signal inputted by terminal pin Ext-V Φ2 is the main control signal. Refer to *Appendix A TTL Signal Pin Assignments* for detail information.

**Amplifier:** The output voltage (Vout) is the composition of the voltage set in MAIN PAGE and the supplemental programmed voltage inputted externally. The external V reference voltage range is from -10 V to 10V. When Vac=0 and Vdc=0 in MAIN PAGE, the following formula can be used to calculate Vout.

$$V_{out} (dc) = V_{ref} (dc) / 10 V_{dc} \times 424.2 V_{dc} \text{ (range 300V)}$$

$$V_{out} (dc) = V_{ref} (dc) / 10 V_{dc} \times 212.1 V_{dc} \text{ (range 150V)}$$

or

$$V_{out} (ac) = V_{ref} (ac) / 7.072 V_{ac} \times 300 V_{ac} \text{ (range 300V)}$$

$$V_{out} (ac) = V_{ref} (ac) / 7.072 V_{ac} \times 150 V_{ac} \text{ (range 150V)}$$

Ex. (1): Set Vout to 100Vdc:

1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is  $V = 2.357V_{dc}$ ,  $V_{out} = 100V_{dc}$ .
2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is  $V = 4.715V_{dc}$ ,  $V_{out} = 100V_{dc}$ .

Ex. (2): Set Vout to 100Vac:

1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is  $V = 2.357V_{ac}$ ,  $V_{out} = 100V_{ac}$ .
2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is  $V = 4.715V_{ac}$ ,  $V_{out} = 100V_{ac}$ .

**Level:** It is the linear proportional output of output voltage ( $V_{out}$  (ac)) RMS programmed by the DC V reference. The  $V_{reference}$  range is from -10V to 10V. The following formula can be used to calculate  $V_{out}$ :

$$V_{out} (ac) = | V_{ref} (dc) | / 10 V_{dc} \times 300V_{ac} \text{ (range 300V)}$$

$$V_{out} (ac) = | V_{ref} (dc) | / 10 V_{dc} \times 150V_{ac} \text{ (range 150V)}$$

Ex. (1): Set Vout to 100Vac:

1. When selecting range 300V in OUTPUT: More Setting function, the applied external output voltage is  $V = 3.333V_{dc}$  (or  $-3.333V_{dc}$ ),  $V_{out} = 100V_{ac}$ .
2. When selecting range 150V in OUTPUT: More Setting function, the applied external output voltage is  $V = 6.667V_{dc}$  (or  $-6.667V_{dc}$ ),  $V_{out} = 100V_{ac}$ .

The procedure for setting Ext. Vref Control = OFF, Control Method = Amplifier is described below.

1. Press Ext. Vref Control at the bottom.
2. Turn the RPG to change ON to OFF and press **ENTER**.
3. Press Control Method at the bottom.
4. Turn the RPG to select Amplifier and press **ENTER**.

3 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
MEASUREMENT				Display
#1	V = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000		
#2	V = 0.00	Po = 0.0	PowerON Status	
	I = 0.000	PF = 0.000		
#3	V = 0.00	Po = 0.0	Protection	
	I = 0.000	PF = 0.000		
Z	V12 = 0.00	V31 = 0.00	More 1 of 2	
	V23 = 0.00	Po = 0.0		
Ext.Vref Control	Control Method			2008/10/13 18:23:48
Off	Amplifier			

3 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
MEASUREMENT				Display
#1	V = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000		
#2	V = 0.00	Po = 0.0	PowerON Status	
	I = 0.000	PF = 0.000		
#3	V = 0.00	Po = 0.0	Protection	
	I = 0.000	PF = 0.000		
Z	V12 = 0.00	V31 = 0.00	More 1 of 2	
	V23 = 0.00	Po = 0.0		
Ext.Vref Control	Control Method			2008/10/13 18:23:58
Off	Amplifier			



3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Config
#1	V <sub>ac</sub> =	0.0V	F =	60.0Hz	Interface
#2	V <sub>ac</sub> =	0.0V	F =	60.0Hz	
#3	V <sub>ac</sub> =	0.0V	F =	60.0Hz	
MEASUREMENT					External Vref
#1	V =	0.00	VA =	0.0	Display
	I =	0.000	PF =	0.000	
#2	V =	0.00	P <sub>o</sub> =	0.0	PowerON Status
	I =	0.000	PF =	0.000	
#3	V =	0.00	P <sub>o</sub> =	0.0	Protection
	I =	0.000	PF =	0.000	
Z	V <sub>12</sub> =	0.00	V <sub>31</sub> =	0.00	More 1 of 2
	V <sub>23</sub> =	0.00	P <sub>o</sub> =	0.0	
Ext.Vref Control	Control Method				2008/10/13 10:23:17

**NOTICE**

When Ext. Vref Control =ON, Control Method =Level, the output voltage (Vout) can only be controlled by the level of the external DC programming voltage. It is unable to control the Vout amplitude from the front panel keys until Ext. Vref Control=OFF is set.

**WARNING**

- When Control Method = Amplifier and the Vref frequency exceeds 1000Hz, it could damage the AC Source. This formula should be followed exactly – when  $F > 1000\text{Hz}$  it has to be  $V_{\text{ref}} (\text{pk-pk, V}) \times F (\text{Vref, Hz}) < 10000 \text{ VHz}$ .
- The output may be distorted due to the bandwidth restriction of AC Source, especially when the external V reference has too many high frequency components.

### 3.4.3 Display

The brightness of the backlight and power-save mode settings of the LCD can be set in the CONFIG function. (3\_Phase Mode/1\_Phase Mode).

**Style:** Default.

**Backlight:** Low, Medium, High.

**Backlight OFF after:** Never, 1 min, 3 mins, 5 mins, 10 mins, 30 mins, 1 hour, 3 hours.

The procedure for setting Backlight = Medium, Backlight OFF after = Never in 1\_Phase/3\_Phase Mode is listed below.

- Press Backlight at the bottom.
- Turn the RPG to Medium and press **ENTER**.
- Press Backlight OFF after at the bottom.
- Turn the RPG to select Never and press **ENTER**.

3 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
MEASUREMENT				Display
#1	V = 0.00	VA = 0.0		PowerON Status
	I = 0.000	PF = 0.000		
#2	V = 0.00	Po = 0.0		Protection
	I = 0.000	PF = 0.000		
#3	V = 0.00	Po = 0.0		More 1 of 2
	I = 0.000	PF = 0.000		
	V12 = 0.00	V31 = 0.00		
	V23 = 0.00	Po = 0.0		
Style	Backlight	Backlight		2008/10/13 19:25:03
Default	Medium	OFF after	Never	

1 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
Vac = 0.0V F = 60.0Hz				
MEASUREMENT				Display
V = 0.00		Po = 0.0		PowerON Status
Iac = 0.000	PF = 0.000	Vdc = 0.00	Idc = 0.000	
Vpk = 0.00		VA = 0.0		Protection
Ipk = 0.000	CF = 0.000			
				More 1 of 2
Style	Backlight	Backlight		2008/10/13 19:24:39
Default	Medium	OFF after	Never	

### 3.4.4 Power-ON Status

Users can set the output state of AC Source during power on using the Power-ON Status in the CONFIG function (3\_Phase Mode/1\_Phase Mode). Once it is set, users should save the data before turning power off. With the output set to Off, it indicates the AC Source will not enable the output voltage after it is powered on. With it set to On, the AC Source will enable the output by default after powered on.

3_Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
POWER ON STATUS SETTING				Display
#1	Vac = 0.0V	F = 60.0Hz		PowerON Status
	Vdc = 0.0V			
#2	Vac = 0.0V	F = 60.0Hz		Protection
	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz		More 1 of 2
	Vdc = 0.0V			
Output	Edit			2008/10/13 19:25:31
Off	Each			

3 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
POWER ON STATUS SETTING				Display
#1	Vac = 0.0V	F = 60.0Hz		PowerON Status
	Vdc = 0.0V			
#2	Vac = 0.0V	F = 60.0Hz		Protection
	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz		More 1 of 2
	Vdc = 0.0V			
Output	Edit			2008/10/13 19:25:52
Off	On	Each		

3 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
#1	Vac = 0.0V	F = 60.0Hz		
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz	External Vref	
POWER ON STATUS SETTING				Display
#1	Vac = 0.0V	F = 60.0Hz		PowerON Status
	Vdc = 0.0V			
#2	Vac = 0.0V	F = 60.0Hz		Protection
	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz		More 1 of 2
	Vdc = 0.0V			
Output	Edit			2008/10/13 19:26:02
Off	Each			

1 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
Vac = 0.0V F = 60.0Hz				
POWER ON STATUS SETTING				Display
Vac = 0.0V		F = 60.0Hz		PowerON Status
Vdc = 0.0V				
				Protection
				More 1 of 2
Output				2008/10/13 19:26:39
Off				



### 3.4.5 Protection

The AC Source's Protection for 1\_Phase/3\_Phase output mode is set separately. For instance, the Protection will apply the settings of 1\_Phase when switching from 3\_Phase to 1\_Phase mode rather than the Protection settings of any phase under 3\_Phase Mode.

The Protection in the CONFIG function (3\_Phase Mode/1\_Phase Mode) is able to set the limit of the output RMS current (OCP), output power (OPP) and the Delay Time for triggering the current protection. The limit in this command is to protect the program instead of the hardware.

Following shows the procedure of setting the current limit = 48A (32A for 31120), power limit = 6000W (4000W for 31120), delay time = 3 sec. for 31180 in 3\_Phase Mode.

1. Move the cursor to "OCP =" command line.
2. Press **[4]**, **[8]** and **[ENTER]** to change the value to "48.0."
3. Move the cursor to "OPP =" command line.
4. Press **[6]**, **[0]**, **[0]**, **[0]**, **[ENTER]** to change the value to "6000.0."
5. Move the cursor to "Delay time =" command line.
6. Press **[3]**, **[ENTER]** to change the value to "3.0."

3_Phase 300V LOCAL QUIT			
OUTPUT SETTING			Config
#1	Vac = 0.0V	F = 60.0Hz	Interface
#2	Vac = 0.0V	F = 60.0Hz	External Vref
#3	Vac = 0.0V	F = 60.0Hz	External Vref
PROTECTION SETTING			Display
#1	OCP = 48.0A	OPP = 6000.0W	PowerON Status
#1	Delay time = 3.0sec		Protection
#2	OCP = 48.0A	OPP = 6000.0W	
#2	Delay time = 3.0sec		
#3	OCP = 48.0A	OPP = 6000.0W	
#3	Delay time = 3.0sec		
Edit Each		Set to Maximum	Set to Minimum
		2008/10/13	10:27:29

Following shows the procedure of setting the current limit = 144A (96A for 31120), power limit = 18000W (12000W for 31120), delay time = 3 sec. for 31180 in 1\_Phase Mode.

1. Move the cursor to "OCP =" command line.
2. Press **[1]**, **[4]**, **[4]** and **[ENTER]** to change the value to "144.0."
3. Move the cursor to "OPP =" command line.
4. Press **[1]**, **[8]**, **[0]**, **[0]**, **[0]**, **[ENTER]** to change the value to "18000.0."
5. The cursor moves to "Delay time =" command line automatically.
6. Press **[3]**, **[ENTER]** to change the value to "3.0."

1 Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Interface
Vac = 0.0V F = 60.0Hz				External Vref
PROTECTION SETTING				Display
OCP = 144.0A				PowerON Status
OPP = 18000.0W				Protection
Delay time = 3.0sec				More 1 of 2
			Get to Maximum	Get to Minimum
				2008/10/13 19:28:00

**NOTICE**

1. When “OCP = 0.0 A” it means the limit of output current equals to the specification limit.
2. The setting of the time delay is only valid when the current is within the specification. It does not work when the output exceeds the specification. The resolution is 0.1s.

**NOTICE**

The protection point varies by the measurement error, thus it may act before reaching the protection point set.

### 3.4.6 Others

Press MORE on the right in CONFIG function (3\_Phase Mode/1\_Phase Mode) to go to the second page and press Others on the right to set Output Relay, Buzzer and Date/Time.

**Output Relay:** Depend, Always ON.

**Buzzer:** on, off.

**Date/Time:** Year, Month, Day, Hour, Minute, Second.

3_Phase 300V LOCAL QUIT				Config
OUTPUT SETTING				Others
#1	Vac = 0.0V F = 60.0Hz			Calibration
#2	Vac = 0.0V F = 60.0Hz			
#3	Vac = 0.0V F = 60.0Hz			
MEASUREMENT				System Information
#1	V = 0.00	VA = 0.0		Factory Default
	I = 0.000	PF = 0.000		
#2	V = 0.00	Po = 0.0		Factory Default
	I = 0.000	PF = 0.000		
#3	V = 0.00	Po = 0.0		More 2 of 2
	I = 0.000	PF = 0.000		
	V12 = 0.00	V31 = 0.00		
	V23 = 0.00	Po = 0.0		
Output Relay	Buzzer	Date/Time		2008/10/13 19:28:34
Depend	On			

1_Phase 300V LOCAL QUIT				Config	
OUTPUT SETTING				Others	
Vac = 0.0V F = 60.0Hz				Calibration	
MEASUREMENT					System Information
V = 0.00	Po = 0.0				Factory Default
Iac = 0.000	PF = 0.000				
Vac = 0.00	Vdc = 0.00			More 2 of 2	
Iac = 0.000	Idc = 0.000				
Vpk = 0.00	VA = 0.0				
Ipk = 0.000	CF = 0.000				
Output Relay	Buzzer	Date/Time		2008/10/13 19:28:58	
Depend	On				

The output circuit on the AC Source has a relay to connect to the load. When the output relay is “Always ON,” it indicates the output relay is closed (connected) even if the AC Source output state is in QUIT mode. When the output relay is “Depend,” the output relay is

closed (connected) only when the output state is in OUT mode. If the output state is in QUIT mode, the output relay will be opened (disconnected.)

The procedure for setting the output relay to Always ON in 1\_Phase/3\_Phase Mode is described below.

1. Press Output Relay at the bottom.
2. Turn the RPG to set the output relay to Always ON and press **ENTER**. When the output relay is working, the AC Source will click once.

3_Phase 300V LOCAL QUIT				1_Phase 300V LOCAL QUIT			
OUTPUT SETTING				OUTPUT SETTING			
#1	Vac = 0.0V	F = 60.0Hz	Config	Vac = 0.0V F = 60.0Hz		Config	
#2	Vac = 0.0V	F = 60.0Hz	Others			Others	
#3	Vac = 0.0V	F = 60.0Hz	Calibration			Calibration	
MEASUREMENT				MEASUREMENT			
#1	V = 0.00	VA = 0.0	System Information	V = 0.00	Po = 0.0	System Information	
	I = 0.000	PF = 0.000	Factory Default	Iac = 0.000	PF = 0.000	Factory Default	
#2	V = 0.00	Po = 0.0		Vac = 0.00	Vdc = 0.00		
	I = 0.000	PF = 0.000		Iac = 0.000	Idc = 0.000		
#3	V = 0.00	Po = 0.0		Vpk = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000		Ipk = 0.000	CF = 0.000		
Z	V12 = 0.00	V31 = 0.00	More 2 of 2			More 2 of 2	
	V23 = 0.00	Po = 0.0					
Output Relay	Buzzer	Date/Time	2008/10/13 19:31:42	Output Relay	Buzzer	Date/Time	2008/10/13 19:29:20
Always ON	Off			Always ON	On		

**NOTICE**

Check if the AC Source has voltage output before powering it off. To ensure the safety of hardware, it is prohibited to power off the AC Source in Output state.

Next, the AC Source buzzer beeps when the panel keys are pressed or the RPG rotary is turned. If the user does not want the buzzer active, it may be turned off.

Following procedure describes the procedure for turning off the buzzer in 1\_Phase/3\_Phase Mode.

1. Press Buzzer at the bottom.
2. Turn the RPG to change ON to OFF and press **ENTER**.

3_Phase 300V LOCAL QUIT				1_Phase 300V LOCAL QUIT			
OUTPUT SETTING				OUTPUT SETTING			
#1	Vac = 0.0V	F = 60.0Hz	Config	Vac = 0.0V F = 60.0Hz		Config	
#2	Vac = 0.0V	F = 60.0Hz	Others			Others	
#3	Vac = 0.0V	F = 60.0Hz	Calibration			Calibration	
MEASUREMENT				MEASUREMENT			
#1	V = 0.00	VA = 0.0	System Information	V = 0.00	Po = 0.0	System Information	
	I = 0.000	PF = 0.000	Factory Default	Iac = 0.000	PF = 0.000	Factory Default	
#2	V = 0.00	Po = 0.0		Vac = 0.00	Vdc = 0.00		
	I = 0.000	PF = 0.000		Iac = 0.000	Idc = 0.000		
#3	V = 0.00	Po = 0.0		Vpk = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000		Ipk = 0.000	CF = 0.000		
Z	V12 = 0.00	V31 = 0.00	More 2 of 2			More 2 of 2	
	V23 = 0.00	Po = 0.0					
Output Relay	Buzzer	Date/Time	2008/10/13 19:31:07	Output Relay	Buzzer	Date/Time	2008/10/13 19:30:04
Always ON	Off			Always ON	Off		

At last, set the time and date of AC Source.

**Date/Time:** Year, Month, Day, Hour, Minute, Second.

Follow the procedure below to set the time and date in 1\_Phase/3\_Phase Mode.

1. Press Date/Time at the bottom.
2. Select the item (Year/Month/Day/Hour/Minute/Second) to be set and press the button on the right.
3. Use the RPG to change the selected item and press **ENTER**.

3_Phase 300V LOCAL QUIT				1_Phase 300V LOCAL QUIT			
OUTPUT SETTING				OUTPUT SETTING			
#1	Vac = 0.0V	F = 60.0Hz	Config	Vac = 0.0V	F = 60.0Hz	Config	Year 2008
#2	Vac = 0.0V	F = 60.0Hz	Year 2008			Month 10	Month 10
#3	Vac = 0.0V	F = 60.0Hz	Month 10			Day 13	Day 13
MEASUREMENT				MEASUREMENT			
#1	V = 0.00	VA = 0.0	Day 13	V = 0.00	PO = 0.0	Day 13	Day 13
	I = 0.000	PF = 0.000	Hour 19	Iac = 0.000	PF = 0.000	Hour 19	Hour 19
#2	V = 0.00	PO = 0.0	Hour 19	Vac = 0.00	Vdc = 0.00	Minute 32	Minute 32
	I = 0.000	PF = 0.000	Minute 32	Iac = 0.000	Idc = 0.000	Second 24	Second 24
#3	V = 0.00	PO = 0.0	Minute 32	Vpk = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000	Second 1	Ipk = 0.000	CF = 0.000		
±	V12 = 0.00	V31 = 0.00	Second 1				
	V23 = 0.00	PO = 0.0					
Output Relay Always ON	Buzzer Off	Date/Time	2008/10/13 19:32:08	Output Relay Always ON	Buzzer Off	Date/Time	2008/10/13 19:32:27

### 3.4.7 Calibration

For detail calibration procedure, please refer to the description in Chapter 4.


### 3.4.8 System Information

Press MORE on the right in the CONFIG function (3\_Phase Mode/1\_Phase Mode) to go to next page. Press System Information on the right to see the system information of the AC Source.

3_Phase 300V LOCAL QUIT			
UNIT DATA			
Model: 31180		Serial NO: 000001	
Display	Version: 00.30 BETA	Config	
Waveform	Version: 00.31 Oct 8 2008	Others	
Remote	Version: 00.31 Oct 8 2008	Calibration	
		System Information	
		Factory Default	
		More 2 of 2	
		2008/10/13 19:33:02	

### 3.4.9 Factory Default

Press MORE on the right in the CONFIG function (3\_Phase Mode/1\_Phase Mode) to go to next page. Press Factory Default on the right and Yes at the bottom to return to the factory default.



### 3.5 PHASE Function Key


Press **PHASE** function key in Figure 3-5 to go to the switch 3\_Phase Mode/1\_Phase Mode.

#### 3.5.1 3\_Phase Mode

The AC Source can be set to 3\_Phase AC power by pressing the **PHASE** function key to switch to 3\_Phase Mode when it is required.

The procedure for setting the AC Source to 3\_Phase mode is described below.

1. Press **PHASE** function key.
2. Press 3\_PHASE on the right.
3. Press Yes on the right to confirm the change.




### 3.5.2 1\_Phase Mode

When the 3\_Phase power of the AC Source is not enough to drive the load, the 3\_Phase output can be paralleled to one of the phases. Pressing the **PHASE** function key can change the AC Source setting from 3\_Phase to 1\_Phase.

The procedure for setting the AC Source to 1\_Phase mode is described below.

1. Press **PHASE** function key.
2. Press Single 1\_PHASE on the right.
3. Press Yes on the right to confirm the change.



#### ⓘ NOTICE

When switching between 1\_Phase and 3\_Phase mode, the set output value will be reset to zero to avoid damaging the Unit Under Test (UUT).

### 3.6 CURSOR Function Key

Press **CURSOR** function key in Figure 3-5 to set the value of a single digit.

The RPG can be used to set the digit of hundred, decade, figure and 1<sup>st</sup> place after the decimal point for voltage or frequency to save time in inputting the values.

The procedure for setting the 1<sup>st</sup> place after the decimal point for output voltage Vac in 1\_Phase/3\_Phase Mode is described below.

1. Move the cursor to “Vac =” command line.
2. Press **CURSOR** function key.
3. The cursor will shorten to one digit range.
4. Move the cursor to the 1<sup>st</sup> digit after decimal point and use the RPG to change the value.
5. Press **CURSOR** function key again to exit it.



3 Phase 300V LOCAL QUIT						Main
OUTPUT SETTING						OUTPUT: More Setting
#1	Vac = 000.0V	F = 60.0Hz				
#2	Vac = 0.0V	F = 60.0Hz				
#3	Vac = 0.0V	F = 60.0Hz				Measurement Setting
MEASUREMENT						Waveform Viewer
#1	V = 0.00	VA = 0.0				
	I = 0.000	PF = 0.000				Limitation
#2	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				Output Mode
#3	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				Measurement To Page2
Z	V12 = 0.00	V31 = 0.00				
	V23 = 0.00	Po = 0.0				
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 19:35:50

1 Phase 300V LOCAL QUIT						Main
OUTPUT SETTING						OUTPUT: More Setting
Vac = 000.0V F = 60.0Hz						
MEASUREMENT						Waveform Viewer
V = 0.00 Po = 0.0						
Iac = 0.000 PF = 0.000						Limitation
Vac = 0.00 Vdc = 0.00						
Iac = 0.000 Idc = 0.000						Output Mode
Vpk = 0.00 VA = 0.0						
Ipk = 0.000 CF = 0.000						
Recall CH1	Recall CH2	Recall CH3	Recall CH4	Recall CH5	More 1 of 2	2008/10/13 19:36:19

### 3.7 LOCK Function Key

Press **LOCK** function key in Figure 3-5 to lock the function.

Press this key to lock all functions on the panel and making all keys invalid. Press **LOCK** for 3 seconds to unlock it.

3 Phase 300V LOCAL QUIT						Main
OUTPUT SETTING						OUTPUT: More Setting
#1	Vac = 0.0V	F = 60.0Hz				
#2	Vac = 0.0V	F = 60.0Hz				
#3	Vac = 0.0V	F = 60.0Hz				Measurement Setting
MEASUREMENT						Waveform Viewer
#1	V = 0.00	VA = 0.0				
	I = 0.000	PF = 0.000				Limitation
#2	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				Output Mode
#3	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				Measurement To Page2
Z	V12 = 0.00	V31 = 0.00				
	V23 = 0.00	Po = 0.0				
Front key and Rotary are disabled Press <LOCK> for 3 seconds to enable them						2008/10/13 19:36:52

1 Phase 300V LOCAL QUIT						Main
OUTPUT SETTING						OUTPUT: More Setting
Vac = 0.0V F = 60.0Hz						
MEASUREMENT						Waveform Viewer
V = 0.00 Po = 0.0						
Iac = 0.000 PF = 0.000						Limitation
Vac = 0.00 Vdc = 0.00						
Iac = 0.000 Idc = 0.000						Output Mode
Vpk = 0.00 VA = 0.0						
Ipk = 0.000 CF = 0.000						
Front key and Rotary are disabled Press <LOCK> for 3 seconds to enable them						2008/10/13 19:36:33

### 3.8 OUTPUT Function Key

Please refer to 3.3.1 for the detail description of OUTPUT function key.

### 3.9 LOCAL/REMOTE Function Key

Press **LOCAL/REMOTE** function key in Figure 3-5 to switch to remote control.

When the AC Source is in REMOTE state and controlled by an external device, press this key to release the REMOTE state and return to LOCAL control.

3 Phase 300V REMOTE QUIT			
OUTPUT SETTING			Main
#1	Vac = 0.0V	F = 60.0Hz	
#2	Vac = 0.0V	F = 60.0Hz	
#3	Vac = 0.0V	F = 60.0Hz	
MEASUREMENT			
#1	V = 0.00	Po = 0.0	
	I = 0.000	PF = 0.000	
#2	V = 0.00	Po = 0.0	
	I = 0.000	PF = 0.000	
#3	V = 0.00	Po = 0.0	
	I = 0.000	PF = 0.000	
Z	V12 = 0.00	V31 = 0.00	
	V23 = 0.00	Po = 0.0	
			2008/10/13 18:28:11

### 3.10 SAVE/RECALL Function Key

The AC Source has two modes for users to save and recall the output setting or system information as described in section 3.10.1 and 3.10.2. Press **SAVE/RECALL** function key in Figure 3-5 to access the save and recall functions.

#### 3.10.1 Save/Recall Output Setting

The AC Source has 10 channels for users to save the frequently used Vac, F and Vdc for recall. For example, enter the setting and save it to CH1 memory in MAIN PAGE (3\_Phase Mode) (see 3.3.)

3 Phase 300V LOCAL QUIT				Save/Recall
OUTPUT SETTING				
#1	Vac = 0.0V	F = 60.0Hz		Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz		Save System Data
MEASUREMENT				
#1	V = 0.00	VA = 0.0		
	I = 0.000	PF = 0.000		Recall Output Setting
#2	V = 0.00	Po = 0.0		
	I = 0.000	PF = 0.000		Recall System Data
#3	V = 0.00	Po = 0.0		
	I = 0.000	PF = 0.000		
Z	V12 = 0.00	V31 = 0.00		
	V23 = 0.00	Po = 0.0		
				2008/10/13 18:37:34

3 Phase 300V LOCAL QUIT				Save/Recall
OUTPUT SETTING				
#1	Vac = 0.0V	F = 60.0Hz		Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz		
#3	Vac = 0.0V	F = 60.0Hz		Save System Data
CHANNEL DATA				
1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	Recall Output Setting
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	Recall System Data
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
4	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V	
Save to CH1	Save to CH2	Save to CH3	Save to CH4	More
				2008/10/13 18:38:20



3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Save/Recall
#1	Vac = 0.0V	F = 60.0Hz				Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz				Save System Data
#3	Vac = 0.0V	F = 60.0Hz				Save System Data
CHANNEL DATA						
Save output setting to CH 1						
						2008/10/13 19:38:34

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Save/Recall
#1	Vac = 0.0V	F = 60.0Hz				Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz				Save System Data
#3	Vac = 0.0V	F = 60.0Hz				Save System Data
CHANNEL DATA						
1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Recall Output Setting
2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Recall System Data
3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Recall System Data
4	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
						2008/10/13 19:39:15

**NOTICE**

- Only the save and recall settings are set in MAIN PAGE. Other parameters are ignored.
- In different output coupling modes (see 3.3.1.1) the missing settings will be adjusted to Vac=0V, F=60Hz, Vdc=0V automatically. For example, when executing save in DC output mode Vac=0V, F=60Hz, Vdc is the setting in MAIN PAGE.

### 3.10.2 Save/Recall System Data

The AC Source has 10 groups of memory for users to save and recall system data. System data contains all parameters in the function keys such as MAIN PAGE (see 3.3) and CONFIG (see 3.4). Press **SAVE/RECALL** in MAIN PAGE (3\_Phase Mode) (see 3.3) and press the LCD at the bottom to save the system data as shown below.

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Save/Recall
#1	Vac = 0.0V	F = 60.0Hz				Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz				Save System Data
#3	Vac = 0.0V	F = 60.0Hz				Save System Data
MEASUREMENT						
#1	V = 0.00	VA = 0.0				
	I = 0.000	PF = 0.000				
#2	V = 0.00	Po = 0.0				Recall Output Setting
	I = 0.000	PF = 0.000				
#3	V = 0.00	Po = 0.0				Recall System Data
	I = 0.000	PF = 0.000				
Z	V12 = 0.00	V31 = 0.00				
	V23 = 0.00	Po = 0.0				
						2008/10/13 19:37:34

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Save/Recall
#1	Vac = 0.0V	F = 60.0Hz				Save Output Setting
#2	Vac = 0.0V	F = 60.0Hz				Save System Data
#3	Vac = 0.0V	F = 60.0Hz				Save System Data
MEASUREMENT						
#1	V = 0.00	VA = 0.0				
	I = 0.000	PF = 0.000				
#2	V = 0.00	Po = 0.0				Recall Output Setting
	I = 0.000	PF = 0.000				
#3	V = 0.00	Po = 0.0				Recall System Data
	I = 0.000	PF = 0.000				
Z	V12 = 0.00	V31 = 0.00				
	V23 = 0.00	Po = 0.0				
						2008/10/13 19:40:21

3 Phase 300V LOCAL QUIT						3 Phase 300V LOCAL QUIT					
OUTPUT SETTING						OUTPUT SETTING					
#1	Vac =	0.0V	F =	60.0Hz	Save/Recall	#1	Vac =	0.0V	F =	60.0Hz	Save/Recall
#2	Vac =	0.0V	F =	60.0Hz	Save Output Setting	#2	Vac =	0.0V	F =	60.0Hz	Save Output Setting
#3	Vac =	0.0V	F =	60.0Hz	Save System Data	#3	Vac =	0.0V	F =	60.0Hz	Save System Data
CHANNEL DATA						MEASUREMENT					
Save system data to GROUP 1						#1	V =	0.00	VA =	0.0	Save/Recall
						#1	I =	0.000	PF =	0.000	Save/Recall
						#2	V =	0.00	Po =	0.0	Recall Output Setting
						#2	I =	0.000	PF =	0.000	Recall Output Setting
						#3	V =	0.00	Po =	0.0	Recall System Data
						#3	I =	0.000	PF =	0.000	Recall System Data
						V <sub>12</sub> =	0.00	V <sub>31</sub> =	0.00		
						V <sub>23</sub> =	0.00	Po =	0.0		
						Recall GROUP1	Recall GROUP2	Recall GROUP3	Recall GROUP4	Recall GROUP5	More
											2008/10/13 19:40:49
											2008/10/13 19:40:54

**NOTICE**

The AC Source has 11 groups of memory: GROUP 0, GROUP1~10. GROUP 0 will be reserved for the power-on default. The data saved in GROUP 0 will be recalled automatically and loaded when the AC Source powers on again. As for the data saved in GROUP 1~10 memory groups, they need to be called manually for loading.

### 3.11 Protection

The AC Source has both software and hardware protection. When protection occurs the AC Source will stop the output and disconnect the output relay. The display shows that the source is in protection mode. To return to normal output after the protection is triggered, please address any issues and press **ENTER** to release protection for normal operation.

The table below lists the software protection:

Protection	Description
OCP	It occurs when output current exceeds the limit or specification.
OPP	It occurs when output power exceeds specification.
OVP	It occurs when output voltage exceeds the limit of each range.
Remote - Inhibit	It executes remote inhibit.

The table below lists the hardware protection:

Protection	Description
FAN - FAIL	It occurs when the cooling fan is out of order.
INT - AD	It is the internal AD power stage protection indicating the output voltage is over or under the specification.
INT - DD	It is the internal DD power stage protection indicating the output voltage is over or under the specification.
INT - LINE	It occurs when the line input voltage is over or under specification.
SHORT	It is the short circuit protection.
OTP	It occurs when the AC Source's internal temperature is too high.

3 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Phase
#1	Vac =	0.0V	F =	60.0Hz	
#2	Vac =	0.0V	F =	60.0Hz	
#3	Vac =	0.0V	F =	60.0Hz	
PROTECTION					
INT_DD					
Warning!					
					2008/10/13 10:30:14

**ⓘ NOTICE**

The protection point varies by the measurement error, thus it may act before reaching the protection point set.



## 4. Calibration

### 4.1 Introduction

The AC Source has a simple procedure built in to calibrate the output and measure the accuracy without opening the chassis. Users simply need to follow the procedure step by step for operation. A voltage meter, current meter and an adequate load with a +5V DC power supply are required to perform the calibration. For the connections of these instruments please refer to Figure 4-1. There are 3 items required for calibration: output voltage, output current and external reference voltage. However, they don't need to be calibrated at the same time. Select one of them for calibration is needed.




Figure 4-1

---


#### ⓘ NOTICE

When in the ambient temperature 25°C, it needs to warm up for 20 minutes before calibration to allow the device internal to reach the normal operation temperature and ensure the calibration is correct.

---

## 4.2 Manual Calibration


Select “Calibration” in CONFIG function (3\_Phase Mode/1\_Phase Mode) to input the calibration procedure. Before any calibration items appear, users have to input a password to eliminate accidental input. The password is included in the manual to ensure users read this manual before executing the calibration procedure.




### ⓘ NOTICE

1. The password for calibration procedure is “3621,” press **ENTER** to confirm it.
2. Users should read the procedure clearly before calibrating the AC Source, or partial memory data could be lost due to incorrect operation.

Once the correct password is entered, the LCD shows that the calibration procedure can only be running in 3\_Phase mode and is prohibited in 1\_Phase mode. Press **ENTER** to continue the calibration procedure.



Next users can select the voltage, current and external reference voltage for calibration.




Voltage setting & Measure: This is the calibration for output voltage and measurement accuracy.

Current Measure: This is the calibration for current measurement accuracy.


External Vref.: This is the calibration of external Vref.

### 4.2.1 Output Voltage and Measurement Calibration

CALIBRATION CHOICE can be input after you enter the password, see section 4.2. Press Voltage setting & Measure at the bottom to calibrate the output voltage and measurement.



When in Voltage Setting & Measurement Calibration, the screen will ask the user if conducting the 150V Range Offset voltage calibration. Press **ENTER** to continue the offset voltage calibration and press **EXIT** to skip it to go into 150V Range Voltage Setting & Meas. calibration procedure.



For step A in 150V Range Offset voltage calibration procedure, users should use a Digital Voltage Meter (DVM) to measure the AC Source's output DC voltage with the unit of mV and key in the measured value to LCD. Keep monitoring the DVM readings and input/output of the DC voltage repeatedly until the DC output is lower than  $\pm 10$  mV.



**NOTICE**

1. The Vdc offset can be positive or negative. Connect the positive terminal of DVM to the AC Source's Line output and the negative terminal to the AC Source's Neutral output as shown in Figure 4-1.
2. The load must be off for all of the steps in ACCURACY CALI under Voltage setting & Measure.


Voltage Setting & Measurement:#1					
CALIBRATION					Calibration
150V Range					
A).Keyin the DVM measured Vdc,then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+-10mV>).					
B).Wait 2 seconds,then press <ENTER>.					
					2008/10/13
					19:50:54

Voltage Setting & Measurement:#1					
CALIBRATION					Calibration
150V Range					
A).Keyin the DVM measured Vdc,then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+-10mV>).					
B).Wait 2 seconds,then press <ENTER>.					
Vac = 0.00V Vdc = 0.00V					
					2008/10/13
					19:51:07

For step B in 150V Range Offset voltage calibration procedure, the display shows the difference between Vac and Vdc measured by the AC Source. It is generated by an internal component. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vac and Vdc calculated by the AC Source at present.

Voltage Setting & Measurement:#1					
CALIBRATION					Calibration
150V Range					
A).Keyin the DVM measured Vdc,then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+-10mV>).					
B).Wait 2 seconds,then press <ENTER>.					
Vac = 0.00V Vdc = 0.00V					
C).Calibration for 150V Range offset is completed,					
press <ENTER> to run 150V setting & meas.					
calibration.					
					2008/11/20
					19:06:49

For step C in 150V Range Offset voltage calibration procedure, the display shows the 150V range offset voltage calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 150V range voltage setting and measurement calibration procedure.




In step C, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.

---


**ⓘ NOTICE**

The AC Source calibration procedure can be executed separately; however, it is better to follow the calibration sequence step by step (step A, step B ...) or it may cause an output and measurement error.


---




Once the 150V Range Offset voltage calibration is done, the screen will ask the user if conducting the 150V Range Setting & Meas. calibration. Press **ENTER** to continue the Setting & Meas. calibration and press **EXIT** to skip it to go into 300V Range Offset voltage calibration procedure.




For step A in the 150V Range Setting & Meas. calibration procedure, the user should remove the load. Check if the output AC voltage measured by the DVM is about 15Vac. This is to confirm the connection is correct, and press **ENTER**.




For step B in the 150V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 120VAC. Input the correct value measured by the DVM and press **ENTER**.




For step C in the 150V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 150VAC. Input the correct value measured by the DVM and press **ENTER**.



For step D in 150V Range Setting & Meas. calibration procedure, the display shows the 150V Range Setting & Meas. calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 300V Range offset voltage calibration.



In step D, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.



Once the 150V Range Setting & Meas. calibration is done, the screen will ask the user if conducting the 300V Range Offset voltage calibration. Press **ENTER** to continue the Offset voltage calibration and press **EXIT** to skip it to go into 300V Range Setting & Meas.

calibration.

Voltage Setting & Measurement :#1					
CALIBRATION					Calibration
300V Range					
A).Keyin the DVM measured Vdc, then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+/-10mV>).					
					2008/10/13 19:52:41

For step A in the 300V range Offset voltage calibration procedure, users should use a Digital Voltage Meter (DVM) to measure the AC Source's output DC voltage with the unit of mV and key in the measured value to the LCD. Keep monitoring the DVM readings, and the input/output and the DC voltage repeatedly until the DC output is lower than  $\pm 10$  mV.


Voltage Setting & Measurement :#1					
CALIBRATION					Calibration
300V Range					
A).Keyin the DVM measured Vdc, then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+/-10mV>).					
B).Wait 2 seconds, then press <ENTER>.					
					2008/10/13 19:52:55

Voltage Setting & Measurement :#1					
CALIBRATION					Calibration
300V Range					
A).Keyin the DVM measured Vdc, then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+/-10mV>).					
B).Wait 2 seconds, then press <ENTER>.					
Vac = 0.00V Vdc = 0.00V					
					2008/10/13 19:53:07


For step B in the 300V range Offset voltage calibration procedure, the display shows the difference between Vac and Vdc measured by the AC Source. It is generated by an internal component. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vac and Vdc calculated by the AC Source at present.

Voltage Setting & Measurement :#1					
CALIBRATION					Calibration
300V Range					
A).Keyin the DVM measured Vdc, then press <ENTER>					
Vdc offset = 0.0mV					
(repeat this step until Vdc offset <+/-10mV>).					
B).Wait 2 seconds, then press <ENTER>.					
Vac = 0.04V Vdc = 0.02V					
C).Calibration for 300V Range offset is completed,					
press <ENTER> to run 300V setting & meas.					
calibration.					
					2008/11/20 19:11:57


For step C in 300V range Offset voltage calibration procedure, the display shows the 300V range offset voltage calibration has been done. Press **EXIT** to go into save screen as shown below, or press **ENTER** to continue for next 300V range voltage setting and measurement calibration procedure.




In step C, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.




Once the 300V Range Offset voltage calibration is done, the screen will ask the user if conducting the 300V Range Setting & Meas. calibration. Press **ENTER** to continue the Setting & Meas. calibration and press **EXIT** to skip it to go into the calibration main screen.




For step A in the 300V Range Setting & Meas. calibration procedure, the user should remove the load. Check if the output AC voltage measured by the DVM is about 30Vac. This is to confirm the connection is correct, and press **ENTER**.




For step B in the 300V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 240VAC. Input the correct value measured by the DVM and press **ENTER**.



For step C in the 300V Range Setting & Meas. calibration procedure, check if the DVM measured output voltage is about 300VAC. Input the correct value measured by the DVM and press **ENTER**.



For step D in 300V Range Setting & Meas. calibration procedure, the display shows the 300V Range Setting & Meas. calibration has been done. Press **EXIT** to go into screen as shown below, or press **ENTER** to continue voltage calibration for other phases.



In step D, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.




### **NOTICE**

1. Users can press **ENTER** at the last step to continue calibrating the 2<sup>nd</sup> and 3<sup>rd</sup> phase.
2. If **EXIT** is pressed without saving the result, the calibration result is kept till power-off.


## 4.2.2 Current Measurement Calibration

CALIBRATION CHOICE can be inputted after the password is entered, see section 4.2. Press Current Measure at the bottom to calibrate the current measurement.







For step A, of ACCURACY CALI in Current Measure the display shows the difference of Iac and Idc measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press **ENTER** the Iac = 0.00A and Idc = 0.00A.




For step B, users adjust the load to 2.5Ω for output and press **ENTER**, the AC Source will output 20Vac.




Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.




Press **ENTER** to continue the calibration procedure. The load will be disconnected at this time.




In step A, the display shows the difference of Iac and Idc measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press **ENTER** the Iac = 0.00A and Idc = 0.00A.




For step B, users adjust the load to 2.5Ω for output and press **ENTER**, the AC Source will output 75Vac.




Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.




Press **ENTER** to continue the calibration procedure. The load will be disconnected at this time.




In step A, the display shows the difference of  $I_{ac}$  and  $I_{dc}$  measured by the AC Source. It is generated by internal component. Wait for 2 seconds and press **ENTER** the  $I_{ac} = 0.00A$  and  $I_{dc} = 0.00A$ .




For step B, users adjust the load to  $2.5\Omega$  for output and press **ENTER**, the AC Source will output 120Vac.



Use Current Meter (or Power Analyzer) to measure the output current. Input the measured value and press **ENTER**.



Step C is the last step of ACCURACY CALI in Current Measure. Press **ENTER** to continue calibrating the 2<sup>nd</sup> and 3<sup>rd</sup> phase or press **EXIT** to leave this page. The display shows the following. Press Yes on the right to save the calibration results.




**ⓘ NOTICE**


1. The resistance of the external load has to be constant; therefore the load current and output voltage should be proportional or step B of CURRENT MEAS. ACCURACY will be meaningless. Only when the current complies with step C (output voltage is 125VAC) can this be used for calibration.
2. Protection is removed temporary when the calibration procedure is running. It may cause the AC Source to be damaged if the incorrect load is applied.

### 4.2.3 External Vref Calibration

CALIBRATION CHOICE can be inputted after the password is entered, see 4.2. Press External Vref at the bottom to conduct the external Vref calibration as shown below.




Step A: Short circuiting the pin 1 and pin 4 of the Ext. Vref input terminal and press **ENTER**.




Step B: After short circuited the external Vref input terminal, make the input 0V and the display will show the AC Source's measured Vdc. The offset voltage is generated by internal components. Wait for 2 seconds and press **ENTER**, the display will show the offset voltage Vdc calculated the AC Source at present.




Step C: Disconnect the pin 1 and pin 4 of the Ext. Vref input terminal, then input a DC voltage of 10Vdc between pin 1 and pin 4 and press **ENTER**.



Step D: Use a DVM to measure the voltage between pin 1 and pin 4 of Ext. Vref input terminal, then input a DC voltage and press **ENTER**.



Step E: It is the last step of External Vref CALI. Press **EXIT** to go into the save screen as shown below, or press **ENTER** to continue the voltage calibration of other phases.



In step E, press **EXIT** the display will show the save screen and press Yes on the right can save the calibrated result.



## 5. Transient Generator 31120A and 31180A only

### 5.1 Overview

The AC Source model 31120A and 31180A can, not only, program a stable sinusoidal output voltage and frequency, but also provides powerful features to simulate power line interrupts. Users can change the output using the Sequences in the LIST mode (see 5.2) or change the output to step-by-step in the STEP mode (see 5.4.) With these functions, the simulations of conditions such as cycle loss, transient peak and power attenuation are easy.

The AC Source models 31120A and 31180A are able to measure the related power parameters provided in the MAIN PAGE (see 3.3), it can also provide harmonic measurements up to 40 orders (see 5.7.) In addition, the AC Source allows the user to edit different harmonic components to synthesize the harmonic distortion waveform (see 5.5). It has the ability to program the inter-harmonic frequency and components, as well as, to sweep and overlap the static fundamental waveforms (see 5.6).

3 Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
#1	Vac =	0.0V	F =	60.0Hz		OUTPUT: More Setting
#2	Vac =	0.0V	F =	60.0Hz		Measurement Setting
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	Po =	0.0		Waveform Viewer
	I =	0.000	PF =	0.000		
#2	V =	0.00	Po =	0.0		Limitation
	I =	0.000	PF =	0.000		
#3	V =	0.00	Po =	0.0		Output Mode
	I =	0.000	PF =	0.000		
Σ	V12 =	0.00	V21 =	0.00		
	V23 =	0.00	Po =	0.0		
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:03:13

### 5.2 List Mode

Press Output Mode on the right on the MAIN PAGE (see 3.3) to go into the Output Mode command line. Press the List Mode at the bottom to go into the List Mode command line.

3 Phase		LIST MODE: STOP				QUIT
OUTPUT SETTING						
#1	Vac = 0.0V	F = 60.0Hz				List Mode
#2	Vac = 0.0V	F = 60.0Hz				Trigger
#3	Vac = 0.0V	F = 60.0Hz				Couple Individual
MEASUREMENT						
#1	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#2	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#3	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
	V12 = 0.00	V21 = 0.00				
	V23 = 0.00	Po = 0.0				Edit
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:03:39

Press Edit on the right to go to the setting page.

3 Phase		LIST MODE				QUIT
LIST MODE SETTING						
	Vac start = 0.0V	Vac end = 0.0V				List Mode
	F start = 60.0Hz	F end = 60.0Hz				Edit Each
#1	Vdc start = 0.0V	Vdc end = 0.0V				Trigger Auto
	Degree = 0.0°	Waveform = A				
	Time = 0.0ms					
	Vac start = 0.0V	Vac end = 0.0V				Base Time
	F start = 60.0Hz	F end = 60.0Hz				
#2	Vdc start = 0.0V	Vdc end = 0.0V				Count 1
	Degree = 0.0°	Waveform = A				
	Time = 0.0ms					
	Vac start = 0.0V	Vac end = 0.0V				Sequence 0
	F start = 60.0Hz	F end = 60.0Hz				
#3	Vdc start = 0.0V	Vdc end = 0.0V				Execution Page
	Degree = 0.0°	Waveform = A				
	Time = 0.0ms					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:04:07

The waveform programming in the List mode is a combination of Sequences. The output waveform starts from Sequence = 0 and one Sequence after another until the Time or Cycle = 0, stopping the action. The Sequences following will not be executed. Users can edit the output voltage sequence as needed.

**Trigger method:** Auto / Manual / Excite.

Auto: It finishes all counts when triggered.

Manual: It executes the sequence waveform once, same as Count = 1.

Excite: It is Remote-Excite, via the pin 13 of TTL terminal that is triggered by the external trigger signal. See *Appendix A TTL Signal Pin Assignments* for the detail pin assignment.

**Couple:** Individual /  $\Phi1+\Phi2+\Phi3$ .

Individual: The three phases are set separately.

$\Phi1+\Phi2+\Phi3$ : The setting of second/third phase is the same as the setting of the first phase, thus the user only needs to set the first phase.

**Base sequence unit:** Time / Cycle.

Time: The sequence unit is time.

Cycle: The sequence unit is cycle.

**Count:** The entire sequence execution times.

Count = 0: unlimited execution.

**Sequence:** Sequence number.

The sequence has to start from 0 with a maximum sequence number of 99. The phase difference of the second/third phase and the first phase of Sequence 0 is fixed to differ 120°. Therefore, the user cannot use the angle of the second/third phase in Sequence 0.

**Degree:** The phase angle when the sequence starts.

**Vac start, F start, Vdc start:** The initial waveform when the sequence starts.


**Vac end, F end, Vdc end:** The final waveform when the sequence ends.

**Waveform= A / B:** Select waveform (see 3.3.3.)

After setting the sequences, press Execution Page on the right to exit the List mode. The LCD will show LIST MODE : STOP on the top. STOP indicates the present trigger state. Users can press Trigger on the right to trigger the output. The LCD will show RUNNING to indicate that the List mode is under execution. At the same time, users can press Stop to cease the List waveform output. When the AC Source finishes all Sequences and Counts, the LCD will return to its initial state and display STOP. The AC Source will QUIT at the same time, as shown below.

3 Phase		LIST MODE : STOP				QUIT
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz		List Mode
#2	Vac =	0.0V	F =	60.0Hz		Trigger
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	P <sub>o</sub> =	0.0		
	I =	0.000	PF =	0.000		
#2	V =	0.00	P <sub>o</sub> =	0.0		
	I =	0.000	PF =	0.000		
#3	V =	0.00	P <sub>o</sub> =	0.0		
	I =	0.000	PF =	0.000		
Σ	V <sub>12</sub> =	0.00	V <sub>31</sub> =	0.00		Edit
	V <sub>23</sub> =	0.00	P <sub>o</sub> =	0.0		
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:04:48

3 Phase		LIST MODE : RUNNING OUT				
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz		Stop
#2	Vac =	0.0V	F =	60.0Hz		
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.04	P <sub>o</sub> =	-0.0		
	I =	0.001	PF =	-2.182		
#2	V =	0.06	P <sub>o</sub> =	0.0		
	I =	0.330	PF =	0.276		
#3	V =	0.08	P <sub>o</sub> =	0.0		
	I =	0.712	PF =	0.088		
Σ	V <sub>12</sub> =	0.53	V <sub>31</sub> =	0.52		
	V <sub>23</sub> =	0.53	P <sub>o</sub> =	0.0		
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:04:59

If the AC Source is under operation, pressing **OUT/QUIT** will stop the output and the waveform will be at zero volts. Press **OUT/QUIT** again and the AC Source only outputs the waveform set in the MAIN PAGE. Trigger must be pressed to re-trigger the source. When pressing  to exit LIST page, the programmed the LIST mode waveform will be closed.

Example of LIST Mode in 1\_Phase Mode:

**Trigger:** Auto , **Base:** Time , **Count:** 1

**LIST MODE SETTING:**

**Sequence 0:** Vac start = 20V, Vac end = 100V  
F start = 50Hz, F end = 50Hz Vdc start = 0V, Vdc end = 0V Degree = 90°, Time = 75ms Waveform = A

**Sequence 1:** Vac start = 20V, Vac end = 20V  
F start = 50Hz, F end = 50Hz Vdc start = 0V, Vdc end = 100V Degree = 0°, Time = 80ms Waveform = A

**Sequence 2:** Vac start = 20V, Vac end = 120V  
F start = 50Hz, F end = 500Hz Vdc start = 0V, Vdc end = 0V Degree = 0°, Time = 100ms Waveform = A

Following lists the setting pages of the LIST MODE.

1 Phase		LIST MODE			QUIT	
LIST MODE SETTING					Trigger	List Mode
Vac start =	0.0V			.Auto		
Vac end =	0.0V				Base Time	
F start =	60.0Hz				Count 1	
F end =	60.0Hz				Sequence 0	
Vdc start =	0.0V				Execution Page	
Vdc end =	0.0V					
Degree =	0.0°					
Waveform =	A					
Time =	0.0ms					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:06:33

1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	0.0V				
Vac end	=	0.0V				
F start	=	60.0Hz				
F end	=	60.0Hz				
Vdc start	=	0.0V				
Vdc end	=	0.0V				
Degree	=	0.0°				
Waveform	=	A				
Time	=	0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:06:48

1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	0.0V				
Vac end	=	0.0V				
F start	=	60.0Hz				
F end	=	60.0Hz				
Vdc start	=	0.0V				
Vdc end	=	0.0V				
Degree	=	0.0°				
Waveform	=	A				
Time	=	0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:06:59


1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	0.0V				
Vac end	=	0.0V				
F start	=	60.0Hz				
F end	=	60.0Hz				
Vdc start	=	0.0V				
Vdc end	=	0.0V				
Degree	=	0.0°				
Waveform	=	A				
Time	=	0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:07:40

1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	20.0V				
Vac end	=	100.0V				
F start	=	50.0Hz				
F end	=	50.0Hz				
Vdc start	=	0.0V				
Vdc end	=	0.0V				
Degree	=	90.0°				
Waveform	=	A				
Time	=	75.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:08:34

1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	20.0V				
Vac end	=	20.0V				
F start	=	50.0Hz				
F end	=	50.0Hz				
Vdc start	=	0.0V				
Vdc end	=	100.0V				
Degree	=	0.0°				
Waveform	=	A				
Time	=	80.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:09:03

1 Phase		LIST MODE				QUIT
LIST MODE SETTING						
Vac start	=	20.0V				List Mode
Vac end	=	120.0V				
F start	=	50.0Hz				Trigger Auto
F end	=	500.0Hz				
Vdc start	=	0.0V				Base Time
Vdc end	=	0.0V				
Degree	=	0.0°				Count 1
Waveform	=	A				Sequence 2
Time	=	100.0ms				Execution Page
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:09:48

The trigger waveform, when the settings are complete, is shown below:



### 5.3 Pulse Mode

Press Output Mode on the right of the MAIN PAGE (see 3.3) to go into the Output Mode command line. Press Pulse Mode at the bottom to go into the Pulse Mode command line.

3_Phase		PULSE MODE:STOP				QUIT
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz	Trigger	
#2	Vac =	0.0V	F =	60.0Hz		
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	Po =	0.0	Edit	
	I =	0.000	PF =	0.000		
#2	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000	Edit	
#3	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
Σ		V12 =	0.00	V21 =	0.00	Edit
		V23 =	0.00	Po =	0.0	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:10:30

3_Phase		PULSE MODE				QUIT
PULSE MODE SETTING						
Vac =		0.0V	Vdc =		0.0V	Edit Each
F =		60.0Hz	Duty cycle =		50%	
#1	Degree =	0.0°	Waveform =		A	Trigger Auto
Period =		0.0ms				
Vac =		0.0V	Vdc =		0.0V	Count 0
F =		60.0Hz	Duty cycle =		50%	
#2	Degree =	0.0°	Waveform =		A	Execution Page
Period =		0.0ms				
Vac =		0.0V	Vdc =		0.0V	Execution Page
F =		60.0Hz	Duty cycle =		50%	
#3	Degree =	0.0°	Waveform =		A	Execution Page
Period =		0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:10:52

PULSE mode allows users to program a special waveform and add it to the normal output settings in the MAIN PAGE. Waveform programming specifies the time ratio and the duty cycle of the pulse voltage.

**Trigger method:** Auto / Manual / Excite.

Auto: It finishes all counts when triggered.

Manual: It executes the sequence waveform once, same as Count = 1.

Excite: It is Remote-Excite via the pin 13 of TTL terminal that is triggered by the external trigger signal. See *Appendix A TTL Signal Pin Assignments* for the detail pin assignment.

**Count:** The count number of pulse.

**Vac, F, Vdc:** The Vac, F and DC output in pulse voltage.

**Duty cycle:** The pulse ratio during a duty cycle.

**Period:** The total length of the duty cycle.

**Waveform = A / B:** Select waveform (see 3.3.3.)

**Degree:** The output phase degree of pulse.


After setting the sequences, press the Execution Page on the right to exit the Pulse mode. The LCD will show PULSE MODE : STOP on the top. STOP indicates the present trigger state. Users can press Trigger on the right to trigger the output. The LCD will show RUNNING to indicate the Pulse mode is under execution. The user can



also press Stop to cease the Pulse waveform output. When the AC Source finishes all Sequences and Counts, the LCD will return to its initial state and display STOP. The AC Source will QUIT at the same time, as shown below.

3 Phase		PULSE MODE: STOP				QUIT
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz	Pulse Mode	
#2	Vac =	0.0V	F =	60.0Hz	Trigger	
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
#2	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
#3	V =	0.00	Po =	0.0		
	I =	0.000	PF =	0.000		
Σ	V12 =	0.00	V21 =	0.00		
	V23 =	0.00	Po =	0.0	Edit	
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:11:04

3 Phase		PULSE MODE: RUNNING OUT				
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz	Pulse Mode	
#2	Vac =	0.0V	F =	60.0Hz	Stop	
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.04	Po =	-0.0		
	I =	0.011	PF =	-0.744		
#2	V =	0.01	Po =	0.0		
	I =	0.322	PF =	0.813		
#3	V =	0.05	Po =	-0.0		
	I =	0.707	PF =	-0.050		
Σ	V12 =	0.53	V21 =	0.52		
	V23 =	0.53	Po =	-0.0		
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:11:24

If the AC Source is operating, pressing **OUT/QUIT** will stop the output and the waveform will be zero at volts. Press **OUT/QUIT** again, the AC Source will output the waveform set in the MAIN PAGE. Trigger must be pressed to re-trigger the source. When pressing  to exit the PULSE page, the pulse will be closed.

Example of PULSE Mode in 1\_Phase Mode:

**OUTPUT SETTING:** Vac = 50V, F = 50Hz

**PULSE MODE SETTING:**

Vac = 100V, Vdc = 0V

F = 50Hz, Duty cycle = 35%

Period = 100ms, Degree = 90°

Waveform = A

**Trigger:** Auto, **Count:** 0




The following lists the setting pages of the PULSE MODE.

1_Phase		PULSE MODE				QUIT
PULSE MODE SETTING						
Vac	=	0.0V	Pulse Mode			
Vdc	=	0.0V	Trigger Auto			
F	=	60.0Hz	Count 0			
Duty cycle	=	50%	Execution Page			
Degree	=	0.0°				
Waveform	=	A				
Period	=	0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:12:01

1_Phase		PULSE MODE				QUIT
PULSE MODE SETTING						
Vac	=	0.0V	Pulse Mode			
Vdc	=	0.0V	Trigger Auto			
F	=	60.0Hz	Count 0			
Duty cycle	=	50%	Execution Page			
Degree	=	0.0°				
Waveform	=	A				
Period	=	0.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:12:12

1_Phase		PULSE MODE				QUIT
PULSE MODE SETTING						
Vac	=	100.0V	Pulse Mode			
Vdc	=	0.0V	Trigger Auto			
F	=	50.0Hz	Count 0			
Duty cycle	=	35%	Execution Page			
Degree	=	90.0°				
Waveform	=	A				
Period	=	100.0ms				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:12:56

The trigger waveform, when the settings are complete, is shown below:.



## 5.4 Step Mode

Press Output Mode on the right on the MAIN PAGE (see 3.3) to go into the Output Mode command line. Press Step Mode at the bottom to go into the Step Mode command line.

3 Phase		STEP MODE: STOP				QUIT
OUTPUT SETTING						
#1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Step Mode
#2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Trigger
#3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
MEASUREMENT						
#1	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#2	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#3	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
Z	V12 = 0.00	V21 = 0.00				
	V23 = 0.00	Po = 0.0				Edit
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:13:48

3 Phase		STEP MODE				QUIT
STEP MODE SETTING						
	Vac = 0.0V	ΔVac = 0.0V				Step Mode
	F = 60.0Hz	ΔF = 0.0Hz				Edit Each
#1	Vdc = 0.0V	ΔVdc = 0.0V				Trigger
	Degree = 0.0°	Dwell = 0.0ms				Auto
	Count = 0	Waveform = A				
#2	Vac = 0.0V	ΔVac = 0.0V				
	F = 60.0Hz	ΔF = 0.0Hz				
	Vdc = 0.0V	ΔVdc = 0.0V				
	Degree = 0.0°	Dwell = 0.0ms				
	Count = 0	Waveform = A				
#3	Vac = 0.0V	ΔVac = 0.0V				
	F = 60.0Hz	ΔF = 0.0Hz				
	Vdc = 0.0V	ΔVdc = 0.0V				
	Degree = 0.0°	Dwell = 0.0ms				
	Count = 0	Waveform = A				Execution Page
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:14:13

STEP Mode provides a simple auto switch function to change the output voltage by stepping. Waveform programming sets the item with an initial voltage, specifies the dwell time and the change of each step as well as the step number. The output voltage will keep the last state after execution.

**Trigger method:** Auto / Manual.

Auto: It finishes all counts when triggered.

Manual: The output voltage changes a step every time it operates.

**Count:** The count number of each change.

**Dwell:** The time for each step.

**Vac, F, Vdc:** The Vac, F, DC initial value when STEP mode starts.

**$\Delta$ Vac,  $\Delta$ F,  $\Delta$ Vdc:** The difference value of each step. (It can be negative.)

**Waveform = A / B:** Select waveform (see 3.3.3. ) ◦

**Degree:** The output phase angle of each step.

Press Step Mode at the bottom to go the STEP page. The LCD shows the STEP MODE : STOP on the top. STOP indicates the present trigger state. Users can press Trigger to trigger the output. The LCD will show RUNNING to indicate Step mode is executing the output. Stop and Pause will show on the screen when the output is triggered. Stop ceases the waveform change of STEP, while Pause keeps the STEP waveform until the user presses TRIG\_CONTINUE. When the AC Source finishes all Counts, the LCD will show STOP and the AC Source will QUIT.

3 Phase		STEP MODE: STOP				QUIT
OUTPUT SETTING						Step Mode
#1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Trigger
#2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
MEASUREMENT						
#1	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#2	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
#3	V = 0.00	Po = 0.0				
	I = 0.000	PF = 0.000				
Σ	V <sub>12</sub> = 0.00	V <sub>21</sub> = 0.00				Edit
	V <sub>23</sub> = 0.00	Po = 0.0				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:14:33

3 Phase		STEP MODE: RUNNING OUT				
OUTPUT SETTING						Step Mode
#1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			Stop
#2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
MEASUREMENT						Pause
#1	V = 0.04	Po = -0.0				
	I = 0.012	PF = -0.228				
#2	V = 0.05	Po = 0.0				
	I = 0.321	PF = 0.061				
#3	V = 0.04	Po = -0.0				
	I = 0.699	PF = -0.281				
Σ	V <sub>12</sub> = 0.53	V <sub>21</sub> = 0.52				
	V <sub>23</sub> = 0.53	Po = -0.0				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:14:50

If the AC Source is outputting, pressing **OUT/QUIT** will stop the output and the waveform will be at zero volts. Press **OUT/QUIT** again and the AC Source will output the waveform set in the MAIN PAGE. Users must press Trigger again to re-trigger the output. If the AC Source is not outputting, the user can press **ENTER** to directly output the STEP waveform. When pressing **←** to exit the STEP page, the STEP waveform will stop execution. The LCD shows Trigger UP and Trigger DOWN when **Trigger = Manual**. The output waveform changes to next voltage if Trigger UP is selected; and the output waveform changes to previous voltage if Trigger DOWN is selected.

3 Phase		STEP MODE: RUNNING OUT				
OUTPUT SETTING						Step Mode
#1	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			STOP
#2	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
#3	Vac = 0.0V	F = 60.0Hz	Vdc = 0.0V			
MEASUREMENT						Trigger UP
#1	V = 0.37	Po = 0.0				Trigger DOWN
	I = 0.002	PF = 0.938				
#2	V = 0.03	Po = 0.0				
	I = 0.323	PF = 0.062				
#3	V = 0.07	Po = 0.0				
	I = 0.700	PF = 0.230				
Σ	V <sub>12</sub> = 6.79	V <sub>21</sub> = 6.83				
	V <sub>23</sub> = 0.56	Po = -0.0				
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:15:24

Example of STEP Mode in 1\_Phase Mode:

**Trigger:** Auto

**STEP MODE SETTING:** Vac = 40V, ΔVac = 10V F = 50Hz, ΔF = 50Hz Vdc = 0V, ΔVdc = 20V Degree = 90°, Dwell = 60ms Count = 3, Waveform = A


Following lists the setting pages of the STEP MODE.

1_Phase		STEP MODE			QUIT	
STEP MODE SETTING						
Vac	=	0.0V			Step Mode	
ΔVac	=	0.0V				
Vdc	=	0.0V			Trigger	
ΔVdc	=	0.0V			Auto	
F	=	60.0Hz				
ΔF	=	0.0Hz				
Degree	=	0.0°				
Count	=	0				
Waveform	=	A				
Dwell	=	0.0ms			Execution Page	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:19:59

1 Phase		STEP MODE				QUIT
STEP MODE SETTING						
Vac	=	40.0V				Step Mode
ΔVac	=	10.0V				
Vdc	=	0.0V				Trigger Auto
ΔVdc	=	20.0V				
F	=	50.0Hz				
ΔF	=	50.0Hz				
Degree	=	90.0°				
Count	=	3				
Waveform	=	A				
Dwell	=	60.0ms				Execution Page
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:16:00

1 Phase		STEP MODE:RUNNING				OUT
OUTPUT SETTING						
Vac	=	70.0V	F =	200.0Hz		Step Mode
Vdc	=	60.0V				Stop
MEASUREMENT						
V	=	0.03	Po	=	-0.0	
I	=	1.112	PF	=	-0.050	Pause
Vac	=	0.03	Vdc	=	0.00	
Iac	=	0.263	I <sub>dc</sub>	=	-1.081	
V <sub>pk</sub>	=	0.78	VA	=	0.0	
I <sub>pk</sub>	=	1.786	CF	=	1.606	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:20:11

The trigger waveform, when the settings are complete, is shown below:




## 5.5 Synthesis Waveform

Press Output Mode on the right in the MAIN PAGE (see 3.3) to enter into the Output Mode command line. Next press Synthesis at the bottom to go into the Synthesis command line. Pressing Edit on the right will enter the Synthesis editing window.

3_Phase			SYNTHESIS: STOP			QUIT		
SYNTHESIS WAVEFORM FUNDAMENTAL SETTING								
#1	V <sub>ac_fund</sub> =	0.0V	F <sub>fund</sub> =	60Hz	V <sub>dc</sub> =	0.0V	Synthesis	
#2	V <sub>ac_fund</sub> =	0.0V	F <sub>fund</sub> =	60Hz	V <sub>dc</sub> =	0.0V	Run	
#3	V <sub>ac_fund</sub> =	0.0V	F <sub>fund</sub> =	60Hz	V <sub>dc</sub> =	0.0V		
SYNTHESIS WAVEFORM MEASUREMENT								
#1	V =	0.00	P <sub>o</sub> =	0.0				
	I =	0.000	PF =	0.000				
#2	V =	0.00	P <sub>o</sub> =	0.0				
	I =	0.000	PF =	0.000				
#3	V =	0.00	P <sub>o</sub> =	0.0				
	I =	0.000	PF =	0.000				
#	V <sub>12</sub> =	0.00	V <sub>21</sub> =	0.00				
	V <sub>23</sub> =	0.00	P <sub>o</sub> =	0.0	Edit			
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:21:20		

3_Phase			SYNTHESIS			QUIT		
SYNTHESIS WAVEFORM FUNDAMENTAL SETTING								
V <sub>ac_fundamental</sub> = 0.0V			V <sub>dc</sub> = 0.0V			Synthesis		
F <sub>fundamental</sub> = 60Hz			Degree = 0.0°			Compose Value-1		
N	V	φ	N	V	φ	N	V	φ
2	0.00	0.0	15	0.00	0.0	28	0.00	0.0
3	0.00	0.0	16	0.00	0.0	29	0.00	0.0
4	0.00	0.0	17	0.00	0.0	30	0.00	0.0
5	0.00	0.0	18	0.00	0.0	31	0.00	0.0
6	0.00	0.0	19	0.00	0.0	32	0.00	0.0
7	0.00	0.0	20	0.00	0.0	33	0.00	0.0
8	0.00	0.0	21	0.00	0.0	34	0.00	0.0
9	0.00	0.0	22	0.00	0.0	35	0.00	0.0
10	0.00	0.0	23	0.00	0.0	36	0.00	0.0
11	0.00	0.0	24	0.00	0.0	37	0.00	0.0
12	0.00	0.0	25	0.00	0.0	38	0.00	0.0
13	0.00	0.0	26	0.00	0.0	39	0.00	0.0
14	0.00	0.0	27	0.00	0.0	40	0.00	0.0
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:21:44		

31120A and 31180A Series AC Source provides a Synthesis function for users to synthesize waveform. The harmonic components range up to 40th order, with the fundamental frequency limited to 50Hz or 60Hz. Users can easily program the size and phase of each order on the LCD. The following is an example figure of the synthesis waveform.



**Compose = Value-1 / Value-2 / Value-3 / Percent-1 / Percent-2 / Percent-3:** The data form of each harmonic order.

**Value:** The absolute value.

**Percent:** The percentage of the fundamental frequency voltage.

Users can program six types of synthesis waveform to execution or save.

**Vac fundamental:** The fundamental frequency voltage, the maximum is limited by RANGE (see 3.3.1.2.)

**F fundamental = 50 / 60Hz:** The fundamental frequency.

**Vdc:** The DC voltage component.

**Degree:** The start angle of the output waveform.

Following is the example of using Synthesis Mode in 1\_Phase Mode:

1 Phase 300V LOCAL QUIT						Setting
OUTPUT SETTING					Vac = 0.0V F = 60.0Hz	
						OUTPUT: More Setting
MEASUREMENT						Measurement Setting
V = 0.00	Po = 0.0					Waveform Viewer
I = 0.000	PF = 0.000					
Vac = 0.00	Vdc = 0.00					Limitation
Iac = 0.000	Idc = 0.000					
Vpk = 0.00	VA = 0.0					Output Mode
Ipk = 0.000	CF = 0.000					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:22:21

Press Output Mode on the right in the MAIN PAGE to select any Mode for application.



1_Phase		SYNTHESIS: STOP				QUIT
SYNTHESIS WAVEFORM FUNDAMENTAL SETTING						Synthesis
Vac_fund = 0.0V						Run
F_fund = 60Hz Vdc = 0.0V						
SYNTHESIS WAVEFORM MEASUREMENT						
V = 0.00		Po = 0.0				
I = 0.000		PF = 0.000				
Vac = 0.00		Vdc = 0.00				
Iac = 0.000		Idc = 0.000				
Vpk = 0.00		VA = 0.0				
Ipk = 0.000		CF = 0.000				
						Edit
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:22:43


Next, press Synthesis at the bottom to go to Synthesis Mode.

1_Phase		SYNTHESIS				QUIT
SYNTHESIS WAVEFORM FUNDAMENTAL SETTING						Synthesis
Vac fundamental = 100.0V Vdc = 0.0V						Compose Percent-1
F fundamental = 60Hz Degree = 0.0°						
N	U	P	N	U	P	
2	0.00	0.0	15	0.00	0.0	
3	0.00	0.0	16	0.00	0.0	
4	0.00	0.0	17	0.00	0.0	
5	0.00	0.0	18	0.00	0.0	
6	0.00	0.0	19	0.00	0.0	
7	20.00	0.0	20	0.00	0.0	
8	0.00	0.0	21	0.00	0.0	
9	0.00	0.0	22	0.00	0.0	
10	0.00	0.0	23	0.00	0.0	
11	0.00	0.0	24	0.00	0.0	
12	0.00	0.0	25	0.00	0.0	
13	0.00	0.0	26	0.00	0.0	
14	0.00	0.0	27	0.00	0.0	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:24:12


Press Edit on the right to go to editing screen. Use the arrow keys to move the cursor to the appropriate column. Use the numeric keys to key-in the setting, and then press **ENTER**. The example uses the following settings:

**OUTPUT SETTING** : Vac = 100V , F = 60Hz


**Compose = Percent-1 Edit = Φ3 Vac fundamental = 100.0V F fundamental = 60Hz Vdc = 0.0V Degree = 0.0°**



Once the settings are edited, the user can press View Waveform on the right to view the edited output waveform. Press Return to go to the previous page.



Press Execution Page on the right to return to the Synthesis Mode page. Next, press Run on the right to output the waveform.



The figure above is the output voltage waveform of the AC Source, measured by an oscilloscope. It is the same as the user edited waveform.

**NOTICE**

In order to protect the power stage of AC Source for practical use, it is necessary to limit the synthesis value or the percentage of each order.

2 ≤ order ≤ 10, value ≤ 150V or percentage ≤ 100%.

11 ≤ order ≤ 20, value ≤ 120V or percentage ≤ 50%.

21 ≤ order ≤ 30, value ≤ 80V or percentage ≤ 30%.

31 ≤ order ≤ 40, value ≤ 45V or percentage ≤ 15%.



If the synthesis waveform exceeds the voltage limit, 424V for 300V range or 212V for 150V range, OUTPUT OVP will occur.

## 5.6 Inter-harmonics Waveform

Press Output Mode on the right in the MAIN PAGE (see 3.3) to enter into the Output Mode command line. Next, press Inter-harmonics at the bottom to go to the Inter-harmonics command line. Press Edit on the right to enter the Inter-harmonics editing window. Besides the fundamental voltage output of the AC Source Inter-harmonics function, another frequency of variable voltage component is added to test certain anti-interference. Following is the example figure of an inter-harmonic:

3 Phase INTERHARMONICS STOP QUIT						
OUTPUT SETTING						
#1	Vac =	0.0V	F =	60.0Hz	Interharmon Trigger	
#2	Vac =	0.0V	F =	60.0Hz		
#3	Vac =	0.0V	F =	60.0Hz		
MEASUREMENT						
#1	V =	0.00	P <sub>o</sub> =	0.0	Edit	
	I =	0.000	PF =	0.000		
#2	V =	0.00	P <sub>o</sub> =	0.0		
	I =	0.000	PF =	0.000		
#3	V =	0.00	P <sub>o</sub> =	0.0		
	I =	0.000	PF =	0.000		
	V <sub>12</sub> =	0.00	V <sub>21</sub> =	0.00		
	V <sub>23</sub> =	0.00	P <sub>o</sub> =	0.0		
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:28:27

3 Phase INTERHARMONICS QUIT							
INTERHARMONIC WAVEFORM SETTING							
	F start =	0.1Hz			Interharmon Edit Each		
	F end =	0.1Hz					
#1	Level =	0.0%					
	Time =	0.0Sec					
#2	F start =	0.1Hz					
	F end =	0.1Hz					
	Level =	0.0%			Execution Page		
	Time =	0.0Sec					
#3	F start =	0.1Hz					
	F end =	0.1Hz					
	Level =	0.0%					
	Time =	0.0Sec					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics		Harmonic Meas.	2008/10/13 20:28:30



**F start** : The start frequency of scanning wave. The range is 0.01Hz ~ 2400Hz.

**F end** : The end frequency of scanning wave. The range is 0.01Hz ~ 2400Hz

**Level** : The rms of scanning wave that is the percentage of fundamental voltage set in MAIN PAGE.

**Time** : The scanning time from F start to F end. The following is the example of using Inter-harmonics Mode in 1\_Phase Mode:

1_Phase 300V LOCAL QUIT						
OUTPUT SETTING						Setting
Vac = 0.0V F = 60.0Hz						OUTPUT: More Setting
MEASUREMENT						Measurement Setting
V = 0.00	Po = 0.0					Waveform Viewer
I = 0.000	PF = 0.000					Limitation
Vac = 0.00	Vdc = 0.00					
Iac = 0.000	Idc = 0.000					Output Mode
Vpk = 0.00	VA = 0.0					
Ipk = 0.000	CF = 0.000					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:27:05

Press Output Mode on the right in the MAIN PAGE to select any Mode for application.

1_Phase INTERHARMONICS:STOP QUIT						
OUTPUT SETTING						Interharmon
Vac = 0.0V F = 60.0Hz						Trigger
MEASUREMENT						
V = 0.00	Po = 0.0					
I = 0.000	PF = 0.000					
Vac = 0.00	Vdc = 0.00					
Iac = 0.000	Idc = 0.000					
Vpk = 0.00	VA = 0.0					
Ipk = 0.000	CF = 0.000					Edit
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:27:23

Next, press Inter-harmonics at the bottom to go to Inter-harmonics Mode.


1 Phase INTERHARMONICS QUIT						
INTERHARMONIC WAVEFORM SETTING						Interharmon
F start	=	500.0Hz				
F end	=	500.0Hz				
Level	=	20.0%				
Time	=	10.0Sec				
						Execution Page
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:27:55

Press Edit on the right to go to the editing screen. Use the arrow keys to move the cursor to the column to be set and use the numeric keys to key-in the setting, then press **ENTER**. The example uses the following settings:

**OUTPUT SETTING : Vac = 60.0V F = 60Hz F start = 500.0Hz F end = 500.0Hz Level = 20.0% Time = 10.0Sec**

1 Phase INTERHARMONICS: RUNNING OUT						
OUTPUT SETTING						Interharmon
Vac	=	60.0V	F	=	60.0Hz	Stop
						Pause
MEASUREMENT						
V	=	0.06	Po	=	0.0	
I	=	0.974	PF	=	0.146	
Vac	=	0.06	Vdc	=	-0.01	
Iac	=	0.268	Idc	=	-0.937	
Vpk	=	0.85	VA	=	0.1	
Ipk	=	1.591	CF	=	1.633	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:28:24

Press Execution Page on the right to return to the Inter-harmonics Mode page. Next, press Trigger on the right to output the waveform.



The above figure shows the output voltage waveform of the AC Source, measured by an oscilloscope. It is the same as the user edited waveform.

---

**NOTICE**

In order to protect the power stage of AC Source for practical use, it is necessary to limit the F start and F end related Level. If  $0.01\text{Hz} \leq F \text{ start or } F \text{ end} \leq 500\text{Hz}$ , Level  $\leq 30\%$ . If  $500\text{Hz} < F \text{ start or } F \text{ end} \leq 1000\text{Hz}$ , Level  $\leq 20\%$ . If  $1000\text{Hz} < F \text{ start or } F \text{ end} < 2400\text{Hz}$ , Level  $< 10\%$ .

---

## 5.7 Harmonic Waveform

Press Output Mode on the right in the MAIN PAGE (see 3.3) to enter into the Output Mode command line. Next press Harmonic Meas. at the bottom to go to the I Harmonic Meas. command line. Press Edit on the right to enter the Harmonic Meas. editing window.

3 Phase HARMONIC MEAS. : STOP						QUIT
HARMONIC MEASUREMENT SETTING						Harmonic
#1	THD = 0.0%	DC = 0.0V	Fundamental = 0.0V			Trigger
#2	THD = 0.0%	DC = 0.0V	Fundamental = 0.0V			
#3	THD = 0.0%	DC = 0.0V	Fundamental = 0.0V			
	N	V	N	V	N	V
	2	0.00	15	0.00	28	0.00
	3	0.00	16	0.00	29	0.00
	4	0.00	17	0.00	30	0.00
	5	0.00	18	0.00	31	0.00
	6	0.00	19	0.00	32	0.00
	7	0.00	20	0.00	33	0.00
	8	0.00	21	0.00	34	0.00
	9	0.00	22	0.00	35	0.00
	10	0.00	23	0.00	36	0.00
	11	0.00	24	0.00	37	0.00
	12	0.00	25	0.00	38	0.00
	13	0.00	26	0.00	39	0.00
	14	0.00	27	0.00	40	0.00
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:29:25

3 Phase HARMONIC MEAS. QUIT						
HARMONIC MEASUREMENT						Harmonic
	Source = <u>V</u>					Edit Each
#1	F fundamental = 60Hz					Parameter Value
#2	Source = V					Measurement Single
	F fundamental = 60Hz					
#3	Source = V					Execution Page
	F fundamental = 60Hz					
List Mode	Pulse Mode	Stop Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:29:48

This function can measure the Total Harmonic Distortion (THD) of the fundament frequency 50Hz or 60Hz, the DC current, and the fundamental frequency of output current or voltage. It can also measure 2 □ 40 orders of harmonic values.

**Source = V / I:** It measures the source signal output voltage or output current.

V: The output voltage.

I: The output current.

**F fundamental = 50 / 60 Hz:** The fundamental frequency of source signal. **Measurement = Single / Continue:** The way the measurement result displays on LCD.

Single: The display will keep the measured data when set. It takes about 3 seconds to get the results. Continue: The display updates the measured data when set. It takes about 10 seconds to get stable results.

**Parameter = Percent / Value:** The data form of each harmonic component.

Percent: The percentage of fundament frequency value.

Value: The absolute value.

Following is an example of using Harmonic Meas. Mode in 1\_Phase Mode:




1 Phase 300V LOCAL QUIT					
OUTPUT SETTING					Setting
Vac = 0.0V F = 60.0Hz					OUTPUT: More Setting
MORE SETTING					Measurement Setting
Waveform = A SINE					Waveform Viewer
ON Degree = 0.0					Limitation
OFF Degree = IMMED					Output Mode
Vac S/R = 0.000V/ms					
Vdc S/R = 0.000V/ms					
F S/R = 0.000Hz/ms					
Coupling AC	Range 300V		Output Waveform Selection	Zc Program Disable	2008/10/13 20:30:24


Press OUTPUT : To access Settings on the right in the MAIN PAGE for entry into the output selections page.

1_Phase 300V LOCAL QUIT					
OUTPUT SETTING					Waveform
Vac = 0.0V F = 60.0Hz					
MORE SETTING					
Waveform A = SINE					View Waveform
Waveform B = SINE					
Coupling AC	Range 300V		Output Waveform Selection	Zc Program Disable	2008/10/13 20:30:40


Next, press Output Waveform Selection at the bottom to go to the output waveform selection page.



Set the Waveform A of  $\Phi 3$  to DST04 waveform.



When the waveform setting is complete, press View Waveform on the right to view the output waveform, the ratio of each harmonic order and the output angle.



Press Return to go back to the MAIN PAGE and set the Vac of  $\Phi 3$  to 100.0V. Then, press **OUT/QUIT** to output waveform.

1_Phase 300V LOCAL OUT						
OUTPUT SETTING						Setting
Vac = 100.0V F = 60.0Hz						OUTPUT: More Setting
MEASUREMENT						Measurement Setting
V = 99.98	Po = 0.2					Waveform Viewer
I = 1.000	PF = 0.002					Limitation
Vac = 99.98	Vdc = -0.01					Output Mode
Iac = 0.280	Idc = -0.960					
Vpk = 139.94	VA = 100.0					
Ipk = 1.960	CF = 1.960					
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:32:19

Press Output Mode on the right in the MAIN PAGE to select any Mode.

1_Phase HARMONIC MEAS.: STOP OUT						
HARMONIC MEASUREMENT SETTING						Harmonic
THD = 0.0% DC = 0.0V						Trigger
Fundamental = 0.0V						
N	V	M	V	N	V	
2	0.00	15	0.00	28	0.00	
3	0.00	16	0.00	29	0.00	
4	0.00	17	0.00	30	0.00	
5	0.00	18	0.00	31	0.00	
6	0.00	19	0.00	32	0.00	
7	0.00	20	0.00	33	0.00	
8	0.00	21	0.00	34	0.00	
9	0.00	22	0.00	35	0.00	
10	0.00	23	0.00	36	0.00	
11	0.00	24	0.00	37	0.00	
12	0.00	25	0.00	38	0.00	
13	0.00	26	0.00	39	0.00	
14	0.00	27	0.00	40	0.00	Edit
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:32:41

Next, press Harmonic Meas. at the bottom to go to the Harmonic Meas. Mode.

1_Phase HARMONIC MEAS. OUT						
HARMONIC MEASUREMENT						Harmonic
Source = <u>V</u>						Parameter Percent
F fundamental = 60Hz						Measurement Continue
						Execution Page
List Mode	Pulse Mode	Step Mode	Synthesis	Inter- harmonics	Harmonic Meas.	2008/10/13 20:33:06

Press Edit on the right to go to the editing screen. Use the arrow keys to move the cursor to the column to be set. Use the numeric keys to enter the setting, then press **ENTER**. The example uses the following settings:


**Source = V F fundamental = 60 Hz Measurement = Continue Parameter = Percent**

1 Phase HARMONIC MEAS. : STOP						OUT
HARMONIC MEASUREMENT SETTING						Harmonic
THD = 0.0%		DC = 0.0V				Trigger
Fundamental = 0.0V						
N	Y	N	Y	N	Y	
2	0.00	15	0.00	28	0.00	
3	0.00	16	0.00	29	0.00	
4	0.00	17	0.00	30	0.00	
5	0.00	18	0.00	31	0.00	
6	0.00	19	0.00	32	0.00	
7	0.00	20	0.00	33	0.00	
8	0.00	21	0.00	34	0.00	
9	0.00	22	0.00	35	0.00	
10	0.00	23	0.00	36	0.00	
11	0.00	24	0.00	37	0.00	
12	0.00	25	0.00	38	0.00	
13	0.00	26	0.00	39	0.00	Edit
14	0.00	27	0.00	40	0.00	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:33:31

Press Execution Page on the right to return to the Harmonic Meas. Mode page. Next, press Trigger on the right to perform the output voltage harmonic measurement.

1 Phase HARMONIC MEAS. : RUNNING						OUT
HARMONIC MEASUREMENT SETTING						Harmonic
THD = 4.1%		DC = 0.0V				Stop
Fundamental = 99.9V						
N	Y	N	Y	N	Y	
2	0.04	15	0.11	28	0.02	
3	1.98	16	0.02	29	0.02	
4	0.02	17	0.03	30	0.02	
5	1.55	18	0.03	31	1.33	
6	0.00	19	0.05	32	0.02	
7	2.03	20	0.02	33	1.01	
8	0.00	21	0.04	34	0.03	
9	0.02	22	0.03	35	0.03	
10	0.01	23	1.64	36	0.01	
11	0.06	24	0.01	37	0.02	
12	0.03	25	0.97	38	0.02	
13	0.03	26	0.02	39	0.02	
14	0.03	27	0.04	40	0.03	
List Mode	Pulse Mode	Step Mode	Synthesis	Inter-harmonics	Harmonic Meas.	2008/10/13 20:33:50

After triggered, users can press DATA on the right to view the measurement of a phase.





The figure above is the output voltage waveform of the AC Source, measured by an oscilloscope. It is the same as the user edited waveform.

#### NOTICE

When users press Trigger to execute the current harmonic measurement, the AC Source will adjust the internal gain automatically by the measured data. This ensures that the AC Source can obtain more accurate data of each harmonic. Thus, it is better to wait for the load to be stable before executing the harmonic measurement. In addition, the load cannot be changed during measurement or the retrieved data may lose its accuracy or cause over-current protection.

## 6. Parallel Operation

### 6.1 Parallel Connection of AC Source

When two AC Sources or one AC Source with one Power Stage Unit are applied in parallel mode, an Input/Output Terminal Box for Parallel Connection (2 Units) (QTA615104) is used to connect the AC Source and Power Stage Unit (QTA615103) or another AC Source as shown in the figure below. Use the Input/Output Terminal Box for Parallel Connection (3 Units) (QTA615105) when connecting three devices in parallel.




Figure 6-1 Master/Slave Connecting Diagram

## 6.2 Parallel Connection

When the AC Source and the Power Stage Unit are applied in parallel mode, it requires the use of the System Bus and DVI communication cable to transmit parallel data. The following figure shows the parallel connecting diagram when connecting the AC Source and Power Stage Unit. If more AC Sources 31120, 31180, 31120A, 31180A or QTA615103 Power Stage Units are required for parallel connection, just follow the way shown below to connect them.

### NOTICE

When the parallel mode is in use, it is necessary to connect the System Bus and DVI cables correctly or it will cause the system connection error.




Figure 6-2 Parallel Connection of AC Source and Power Stage Unit

## 6.3 Setting Up

### 6.3.1 Setting the AC Source to Slave

To set an AC Source to Slave, press **CONFIG** in the **FUNCTION** keys to enter into the CONFIG function and select Master/Slave Function for parallel connection setting. The procedures are listed below.

- 1 Press Master/Slave Function.
- 2 Press Position at the bottom.
- 3 Turn the RPG to change the Position to Slave and press **ENTER** to set it to Slave.
- 4 If the AC Source to be set is located between two terminals, press Terminator and turn the RPG to change the Terminator to Enable and then press **ENTER** to set it.




**NOTICE**

At least one device needs to be set as Slave when applying the parallel connection.


3 Phase 300V LOCAL QUIT				3 Phase 300V LOCAL QUIT			
OUTPUT SETTING				OUTPUT SETTING			
#1	Vac = 0.0V	F = 60.0Hz	Config	#1	Vac = 0.0V	F = 60.0Hz	Config
#2	Vac = 0.0V	F = 60.0Hz	Others	#2	Vac = 0.0V	F = 60.0Hz	Others
#3	Vac = 0.0V	F = 60.0Hz	Calibration	#3	Vac = 0.0V	F = 60.0Hz	Calibration
MEASUREMENT				MEASUREMENT			
#1	V = 0.00	VA = 0.0	System Information	#1	V = 0.00	VA = 0.0	System Information
	I = 0.000	PF = 0.000			I = 0.000	PF = 0.000	
#2	V = 0.00	Po = 0.0	Factory Default	#2	V = 0.00	Po = 0.0	Factory Default
	I = 0.000	PF = 0.000			I = 0.000	PF = 0.000	
#3	V = 0.00	Po = 0.0	Master/Slave Function	#3	V = 0.00	Po = 0.0	Master/Slave Function
	I = 0.000	PF = 0.000			I = 0.000	PF = 0.000	
Σ	V12 = 0.00	V31 = 0.00	More 2 of 2	Σ	V12 = 0.00	V31 = 0.00	More 2 of 2
	V23 = 0.00	Po = 0.0			V23 = 0.00	Po = 0.0	
Position Master	Number of Slave 1	Terminator Disable	Function Disable	2008/10/13 19:28:34	Position Slave1	Terminator Disable	2008/10/13 19:28:34

### 6.3.2 Setting the Slave of Mixed AC Source and QTA615103


When the parallel connection is mixed with A615103 and AC Source as the Slave, the terminator of these two terminal devices must be enabled as shown in the figure below. The maximum AC Sources to be connected in parallel is N = 5. Please refer to the User’s Manual of latest version for any changes.



Example 1: if the system has a Slave AC Source and an QTA615103 parallelable power stage unit, the connection is shown in the figure below. Set the terminator of Master to “Enable” and the “Position” of Slave AC Source to “Slave1.” Also, set the Slave ID of QTA615103 to Slave2 with terminator enabled.



Example 2: if the system has a Slave AC Source and an QTA615103 parallelable power stage unit, the connection is shown in the figure below. Set the terminator of Master to “Enable” and the “Position” of the Slave AC Source to “Slave2.” Also, set the Slave ID of QTA615103 to Slave1 with terminator enabled.



### 6.3.3 Setting the AC Source to Master

Press **CONFIG** in the **FUNCTION** keys to enter into the CONFIG function and select Master/Slave Function for parallel connection setting. The procedures are listed below.

- 1 Press Master/Slave Function.
- 2 Press Position at the bottom.
- 3 Turn the RPG to change the Position to Master and press **ENTER** to set it to Master.
- 4 Press Number of Slave.
- 5 Turn the RPG to select the quantity of Slaves to connect in parallel and press Enter.
- 6 If the AC Source to be set is located between two terminals, press Terminator and turn the RPG to change the Terminator to Enable and press **ENTER** to set it.
- 7 Press Function bottom.
- 8 Turn the RPG to change the Function to Enable and press **ENTER** to set it.
- 9 Now, the device set to Master will retrain to the main menu, and the one set to Slave will show Slave on the screen.

3 Phase 300V LOCAL QUIT									
OUTPUT SETTING								Config	
#1	Vac =	0.0V	F =	60.0Hz			Others		
#2	Vac =	0.0V	F =	60.0Hz			Calibration		
#3	Vac =	0.0V	F =	60.0Hz			System Information		
MEASUREMENT								Factory Default	
#1	V =	0.00	VA =	0.0			Master/Slave Function		
	I =	0.000	PF =	0.000			More 2 of 2		
#2	V =	0.00	Po =	0.0					
	I =	0.000	PF =	0.000					
#3	V =	0.00	Po =	0.0					
	I =	0.000	PF =	0.000					
Σ	V12 =	0.00	V31 =	0.00					
	V23 =	0.00	Po =	0.0					
Position Master	Number of Slave 1	Terminator Disable			Function Disable	2008/10/13 19:28:34			

3 Phase 300V LOCAL QUIT									
OUTPUT SETTING								Config	
#1	Vac =	0.0V	F =	60.0Hz			Others		
#2	Vac =	0.0V	F =	60.0Hz			Calibration		
#3	Vac =	0.0V	F =	60.0Hz			System Information		
MEASUREMENT								Factory Default	
#1	V =	0.00	VA =	0.0			Master/Slave Function		
	I =	0.000	PF =	0.000			More 2 of 2		
#2	V =	0.00	Po =	0.0					
	I =	0.000	PF =	0.000					
#3	V =	0.00	Po =	0.0					
	I =	0.000	PF =	0.000					
Σ	V12 =	0.00	V31 =	0.00					
	V23 =	0.00	Po =	0.0					
Position Master	Number of Slave 1	Terminator Disable			Function Enable	2008/10/13 19:28:34			



**NOTICE**


At least one device needs to be set as the Slave when in parallel application, or it will show “System Connection Fail!” when setting the Master Enable. See the section below for the detail description of troubleshooting.

**6.4 Troubleshooting**


When multiple devices are conneted in parallel for use, each standalone device has to have a System bus and a DVI cable to transmit the signal. If not, the quantity of the Slave set for connection does not match the one in actual. If the connection is busy, or an error occurs during connection, follow the troubleshooting procedure to resolve the problem and redo the parallel connection.

**6.4.1 When the Connecting Cable Falls**

If “System Connection Fail!” occurs when initiating Master connection, check to see if the System Bus cable is connected firmly and that the Power Stage Unit or another AC Source is set to Slave. When confirmed, press Retry on Master to redo the connection.




If “SYSTEM SHUTDOWN” occurs during connection, power it off first and check if the DVI cable is connected firmly. If yes, reboot it and retry the connection.



## 6.4.2 Parallel Setting Error

If “System Connection Fail!” occurred when connecting to the Master, it could be a connection setting error. First, check if the Master connected amount (Number of slave) is the same as the actual slave amount. Next, check if the parallel slave position is duplicated. The position set for slave cannot be duplicated. When confirmed, press Retry on the Master to do the connection again.



## **7. Theory of Operation**

### **7.1 Overview**

The 31120/31180 AC source consists of several Printed Circuit Boards (PCB) and other components. Each of the PCBs has specific functions that are described in the following sections.

### **7.2 Description of Overall System**

Figure 7-1 is an overall system diagram that is composed of the following portions:

- **Input Stage I Board:**  
It converts the AC power to DC power with passive PFC function.
- **Isolation Converter G/GD Board:**  
The isolation DC/DC converter isolates the I board output with regulation function. It can also provide the inverter a stable input DC source.
- **Output Stage HB/HT/O/A board:**  
The above boards are composed of an inverter that draws power from G/GD board to provide 31120/31180 to output DC or AC power.
- **Auxiliary Power J/Z board:**  
The J board converts the mains to a 16-17V DC power for the ICs and fans of entire device use. The Z board is an isolation DC/DC converter that converts the J board output to  $\pm 12V$  and  $+5V$  power to drive the IC of various PCB and other components.
- **Fan Control Circuit R Board:**  
The R board detects the temperature of each power stage and adjusts the fan speed automatically to control the temperature of entire device. This circuit has Over-Temperature Protection (OTP) and FAN- LOCK protection.
- **Digital Signal Processor B board:**  
The B board contains DSP, FPGA and CPLD control elements that are responsible for the actions and measurements of 31120/31180's entire device.
- **Communication Interface E board:**  
The E board connects all of the 31120/31180 communication interfaces such as GPIB, RS-232, USB...and sends the signals back to B board to accomplish the remote control function.
- **Signal Transmission C Board:**  
The C board is responsible for transmitting the signals from B board and other PCBs.

- Key input KA/KC/KR/KS board:  
It is the front panel key controls for the above PCBs that send the inputted signals to B board.
- 1-phase Output Connecting Device L Board:  
When L board is in 1-phase output, short circuit L1~L3 3 outputs for user wiring.
- Input Wire Selection Switch ( $\Delta$ -Y wiring selection switch):  
Users can follow the actual power system to change the 31120/31180 internal input-connection that enables 31120/31180 to accept the input from  $\Delta$  or Y.




Figure 7-1 Overall System Diagram



## 8. Self Test and Troubleshooting

### 8.1 Overview

This chapter describes the procedures of self test and suggestions for troubleshooting when the AC Source is unable to operate normally. If the information provided here is unable to resolve the problem, please contact the local QuadTech distributor.

### 8.2 Self Test

The AC Source runs a series of self tests during power-on. First, it executes the memory, data and communication self tests for the items of DISPLAY, WAVEFORM and REMOTE. If any failure is detected on a certain item, an "error code" will show on the right of the item. The following table lists all of the error messages.

Error Code	Description	Remark
Bit 0	Memory error	0 – OK, 1 - ERROR
Bit 1	Waveform Generator error	0 – OK, 1 – ERROR
Bit 2	DATA error	0 – OK, 1 – ERROR
Bit 3	Communication error	0 – OK, 1 - ERROR
Bit 4	Output test result	0 – OK, 1 – ERROR
Bit 5	Reserved	
Bit 6	Reserved	
Bit 7	Reserved	

Example: If an error code shows " ERROR = 05 ", it is " 00000101" in binary. The bit 0 and bit 2 are "1". So "ERROR = 05" means memory error and DATA error occurs.

Error Message	Description	Resolution
Memory error	Memory tested fail.	Consult your dealer for further support
Waveform Generator error	Waveform generator tested fail.	Consult your dealer for further support.
DATA error	The data in Flash or EEPROM tested fail.	Consult your dealer for further support.
Communication error	Unable to send.	1. Power off the AC Source and wait for three seconds to power it on again. 2. Consult your dealer for further support.

After the self test of memory, data and communication, the AC Source executes the power output self test. In this procedure, the output relays are OFF to prevent the load connected to the output terminal from damage. An error message will appear on the panel if abnormal is encountered during self test.

## 8.3 Troubleshooting

The following table lists the operating problems and suggested corrective actions:

<b>Problem</b>	<b>Cause</b>	<b>Resolution</b>
Poor measurement of V, I.	Aged components result in deviation of characteristics.	Periodic calibration is required. Refer to Chapter 4 <i>Calibration</i> .
Output distortion	<ol style="list-style-type: none"> <li>1. The output voltage of AC Source is too low.</li> <li>2. The rectified load is too large during high frequency.</li> </ol>	<ol style="list-style-type: none"> <li>1. Program higher output voltage.</li> <li>2. Reduce the load or output frequency.</li> </ol>
Over-Temperature Protection (OTP)	<ol style="list-style-type: none"> <li>1. The ambient temperature is too high.</li> <li>2. The airway is obstructed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Operate the unit in 0 ~ 40°C.</li> <li>2. Unblock the airway.</li> </ol>
Over-Power Protection (OPP)	The output power exceeds specification.	Remove the output power or output voltage.
Over-Current Protection (OCP)	The output current exceeds specification or I LIMIT.	Remove the overload or expand the I LIMIT.
Output Short Protection (Short)	<ol style="list-style-type: none"> <li>1. The output is shorted.</li> <li>2. External current reversed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Remove the short state.</li> <li>2. Remove the load.</li> </ol>
Input error protection (INT_LINE)	The line input voltage of AC Source is too low or too high.	Measure the input voltage and regulate it if over specification.
AUX output error protection (INT_OFF)	The internal auxiliary power outputs abnormally.	If it is unable to reset the protection, consult the dealer for assistance.
INT_AD protection	<ol style="list-style-type: none"> <li>1. The cycle dropout for line input voltage.</li> <li>2. Instant over current during output.</li> <li>3. The AD power stage is damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the stability of input voltage.</li> <li>2. Remove the load.</li> <li>3. If it is unable to reset the protection, consult the dealer for assistance.</li> </ol>
INT_DD protection	<ol style="list-style-type: none"> <li>1. The cycle dropout for line input voltage.</li> <li>2. Instant over current during output.</li> <li>3. The DD power stage is damaged.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the stability of input voltage.</li> <li>2. Remove the load.</li> <li>3. If it is unable to reset the protection, consult the dealer for assistance.</li> </ol>
OUTPUT OVP protection	<ol style="list-style-type: none"> <li>1. Output voltage peak exceeds the range.</li> </ol>	<ol style="list-style-type: none"> <li>1. Connect the output to remote sense terminals.</li> <li>2. Check the settings of Vac and Vdc on MAIN PAGE.</li> </ol>
Cooling fan protection (FANFAIL)	<ol style="list-style-type: none"> <li>1. The fan stops operation due obstruction.</li> <li>2. The fan is not inserted.</li> </ol>	<ol style="list-style-type: none"> <li>1. Clear the fan.</li> <li>2. If it is unable to reset the protection, consult the dealer for assistance.</li> </ol>
Unable to control AC Source via GPIB	<ol style="list-style-type: none"> <li>1. The address of AC Source is incorrect.</li> <li>2. GPIB cable is loose at rear.</li> </ol>	<ol style="list-style-type: none"> <li>1. Update the address.</li> <li>2. Check the connection and tighten the screws.</li> </ol>

## 9. Remote Operation

### 9.1 Introduction

The AC Source is able to do remote control via USB, GPIB, RS-232 or Ethernet. The USB interface supports USB 2.0/USB 1.1. The GPIB interface is an 8-bit parallel data bus that is synchronized by the bus command from the host. RS-232C interface is a serial bus with less powerful functions; however, the user can do basic remote control via simple programs.

#### 9.1.1 USB Interface

- (1) Hardware Support: USB 2.0 and USB 1.1
- (2) Software Support: USBTMC class and USB488 subclass
- (3) OS Support: Windows 98/2000/XP/Vista
- (4) Installing Driver: 31120/31180 Series USB Interface supports USBTMC, so if the PC OS supports USBTMC (installed NI-VISA runtime version 3.00 or above) it is no need to install other drivers. The OS will search for the standard USBTMC driver installation program automatically.

If the PC OS does not support USBTMC, it is suggested to install the NI-VISA runtime version 3.00 or above first. When the installation of NI-VISA runtime is done, the USBTMC driver program is stored in OS. The PC can communicate with 31120/31180 Series via NI-VISA after using the USB cable to connect them.

Related Documents:

1. USB Test and Measurement Class (USBTMC) specification, Revision 1.0, <http://www.usb.org>
2. USB Test and Measurement Class USB488 subclass specification, Revision 1.0, <http://www.usb.org>

#### 9.1.2 GPIB Interface

The default of GPIB address is 30 and it can only be changed from the “CONFIG” function menu (see Figure 3-1.)

GPIB Capability	Description	Interface Function
Talker/Listener	Commands and response messages can be sent and received via the GPIB bus. Status information can be retrieved by serial query.	AH1, SH1, T6, L4
Service Request	The AC Source sets the SRQ to be true if there is a service request.	SR1
Remote/Local	When the AC Source is powered on in local mode,	RL1


	it can operate the front panel. In remote mode, all other keys are invalid except <b>LOCAL/REMOTE</b> . Press <b>LOCAL/REMOTE</b> can return to local mode.	
--	---	--

### 9.1.3 RS-232C Interface

The baud rate of the AC Source is set to **115200** with parity set to None. For the RS-232C parameters such as baudrate and parity can be set via “CONFIG” function menu (see section 3.4.) Only TxD and RxD signals are used for data transmission. The connector is a 9-pin D-subminiature male connector. The following table describes the pins and signals of RS-232C connector.

Pin No.	Input/Output	Description
1	---	No Connection
2	INPUT	RxD
3	OUTPUT	TxD
4	---	No Connection
5	GND	GND
6	---	No Connection
7	---	No Connection
8	---	No Connection
9	---	No Connection

Interconnection between the computer (compatible with IBM PC) and the AC Source is illustrated below:



### 9.1.4 Ethernet Interface

To remote program an AC Power Supply via a PC with Ethernet interface, it needs to confirm the IP address, Gateway address and Subnet mask in advance. See 3.4.1.3 for detail settings. To ensure reliable data transmission, TCP is used for data transmission and the communication port is 2101.

## 9.2 Introduction to Programming

All commands and response messages are transmitted in ASCII code. The response messages must be read completely before sending a new command; otherwise the remaining response messages will be lost and a query interrupt error will occur.

### 9.2.1 Conventions

Angle brackets	< >	Items in angle brackets are parameter abbreviations.
Vertical bar		Vertical bar separates alternative parameters.
Square brackets	[ ]	Items in square brackets are optional. For example, OOTP [ : STATE] means that : STATE may be omitted.
Braces	{ }	Braces indicate the parameters that may be repeated. The notation <A> {<, B>} means that parameter "A" must be entered while parameter "B" may be omitted or entered once or many times.

### 9.2.2 Numerical Data Formats

All data programmed to or returned from the AC Source are ASCII. The data can be numerical or character string.

Symbol	Description	Example
NR1	It is a digit with no decimal point. The decimal is assumed to be on the right of the least significant digit.	123, 0123
NR2	It is a digit with a decimal point.	12.3, .123
NR3	It is a digit with a decimal point and an exponent.	1.23E+2

### 9.2.3 Boolean Data Format

Boolean parameter <Boolean> applies ON|OFF format only.

### 9.2.4 Character Data Format

The character strings returned by query command may in either of the following forms:

<CRD>	Character Response Data: character string with maximum length of 12.
<SRD>	String Response Data: character string.

## **9.2.5 Basic Definition**

### **Command Tree Table:**

The commands of the AC Source are structured hierarchically, which is called tree system. Full path must be specified to obtain a particular command. This path is represented in the table by placing the highest node in the farthest left position of the hierarchy. Lower nodes in the hierarchy are indented in the position to the right under the parent node.

### **Program Header:**

Program header is the key word to identify the command according to the IEEE 488.2 syntax described in section 9.5. The AC Source accepts characters in both upper and lower cases without any distinction. Program header consists of two unique types, the common command header and the instrument-controlled header.

### **Common Command and Query Header:**

The syntax of common commands and query headers are described in IEEE 488.2. They are used along with the IEEE 488.2 defined common commands and queries. The commands with leading "\*" are common commands.

### **Instrument-Controlled Header:**

Instrument-controlled header can be applied to all instrument commands. Each header has a long form and a short form. The AC Source only accepts the exact short and long forms. A special notation is used to distinguish the short form header from the long one of the same in this section. The short form of header is shown by upper case characters while the rest of the headers are shown in lower case.

### **Program Header Separator (:):**

If a command has more than one header, a colon must be used to separate them (FETC: CURR?, VOLT:DC 10). At least one space is required to separate the data and program header.

### **Program Message:**

The program message consists of many elements including zero sequence or message components that are separated by the separator (semicolon.)

### **Program Message Component:**

A program component is a single command, programming data or query.

Example: `FREQ?, OUTPut ON.`

### **Program Message Component Separator ( ; )::**

The separator (semicolon ;) separates the program message components from another in a program message.

Example: `VOLT:AC 110 ; FREQ 120<PMT>`

### **Program Message Terminator (<PMT>):**

A program message terminator can end the program message. Three permitted

terminators are:

- (1) <END> : end or identify (EOI)
- (2) <NL> : new line which is a single ASCII encoded byte 0A (10 decimals).
- (3) <NL> <END> : new line with EOI.

### NOTICE

The response message is terminated by <NL> <END> for GPIB and <NL> for RS-232C.




Figure 9-1 Structure of Command Message

## 9.3 Traversal of the Command Tree

Multiple program message units can be sent in one program message. The first command usually refers to the root node. Subsequent commands refer to the tree level same as the previous command in a program message. When the colon is ahead of the program message component it changes the header path to root level.

Example:

OUTPut : PROTection : CLear                      All colons are header separators.  
 OUTPut : PROTection : CLear ; VOLT : AC 100      Only the third colon is a specified  
 root.

## 9.4 Execution Order

The AC Source executes program messages by the order received. Problems may occur if the sequence is not followed.

For example, assuming the current output voltage range is LOW, the output voltage range desired for new state is HIGH with amplified 220 Volt. If the commands

```
VOLTage : AC            220<PMT>
VOLTage : RANGE       HIGH<PMT>
```

are sent out, the error of out of range will appear.

## 9.5 Commands of AC Source

This section talks about the syntax and parameters of all commands for the AC Source. The examples of each command can be used in common.

Syntax Form	Syntax definition is in long format header; however, only short format header appears in the examples.
Parameter	Most commands require a parameter.
Return Parameter	All queries return a parameter.
Model	If a command is merely applied to specific models, these models will be listed in the Model only entry. If there is no Model only entry, the command will be applied to all models.

### 9.5.1 Common Command Dictionary

The common commands begin with a “ \* ” and consist of three letters and/or one “ ? ” (query). Common commands and queries are listed alphabetically. The command commands and queries are listed in alphabetic order.

*CLS	Clear status This command clears the following registers (1) Questionable Status Event (2) Status Byte (3) Error Queue
*ESE<n>	Standard event status enabled This command programs the Standard Event register bits. If one or more enabled events of Standard Event registers are set, the ESB of Status Byte Register is set as well.

Bit Configuration of Standard Event Status Enabled Register

Bit Position	7	6	5	4	3	2	1	0
Bit Name	PON	---	CME	EXE	DDE	QYE	---	OPC
	CME = Command Error				DDE = Device-dependent error			
	EXE = Execution Error				OPC = Operation Completed			
	PON = Power On				QYE = Query Error			

*ESE?	Return standard event status enabled
*ESR?	The query reads the Standard Event readings of Event register and clears it. The bits of configuration are the same as Standard Event Status Enabled Register.
*IDN?	Return the AC Source identification string. Return Parameter QuadTech, Inc. 31180, 150926A1 QuadTech, Inc : Company name 31180 : Model name



123456 : Serial number  
 1.00 : Firmware version

- \*RCL<n> Restore the values of specified group that stored in memory previously.  
 Parameter 1 - 3
- \*SAV<n> Save the values to a specified group in memory.  
 Parameter 1 - 3
- \* RST It resets the AC Source to the initial states. It's better to wait for 3 seconds to send the next command.
- \*SRE It sets conditions of Service Request Enabled Register. If one or more of the enabled events of the Status Byte Register is set, the MSS and RQS of Status Byte Register are set too.
- \*SRE? This query returns the Service Request Enabled Register.
- \*STB? This query returns the Status Byte Register.

Bit Configuration of Status Byte Register

Bit Position	7	6	5	4	3	2	1	0
Condition	--	MSS RQS	ESB	MAV	QUES	--	--	--

ESB = Event Status Byte Summary  
 QUS = Questionable Status Summary  
 RQS = Request for Service  
 MSS = Master Status Summary  
 MAV = Message Available

- \* TST? It queries the self-test result of the AC Source.

## 9.5.2 Instrument Command Dictionary

The commands are listed in alphabetical order. Commands followed by question marks (?) are in query forms. When a command has both command and query forms, it is noted in the description of query syntax.

### 9.5.2.1 SYSTEM Sub-System

#### SYSTEM

**:ERRor?**  
**:VERSion?**  
**:LOCal**  
**:REMote**  
**:DATE**  
**:TIME**

#### SYSTEM:ERRor?

Description : This command queries the error string of the command parser.  
Query Syntax : SYSTEM:ERRor?  
Parameter : None  
Return Parameter : Error string response: No Error  
Data Format Error  
Data Range Error  
Too Many Errors  
Execution Error

#### SYSTEM:VERSion?

Description : This query requests the AC Source to identify itself.  
Query Syntax : SYSTEM:VERSion?  
Parameter : None  
Return Parameter : Current version (XX.XX)

#### SYSTEM:LOCal

Description : This command can only be used under the control of RS-232C.  
If SYST : LOC is programmed, the AC source will be set in the LOCAL state, and the front panel will work.  
Query Syntax : None  
Parameter : None  
Return Parameter : None

#### SYSTEM:REMote

Description : This command can only be used under the control of RS-232C.  
If SYST : REM is programmed, the AC source will be set in the REMOTE state, and the front panel will be disabled except the "<PAGE/EXIT> key."  
Query Syntax : None  
Parameter : None  
Return Parameter : None

#### SYSTEM:DATE

Description : This command sets the date of the AC Source real time clock.  
Query Syntax : SYSTEM:DATE?  
Parameter : <year>,<month>,<day>  
Return Parameter : 2008,01,01

**SYSTem:TIME**

Description : This command sets the time (24H) of the AC Source real time clock.

Query Syntax : **SYSTem:TIME?**

Parameter : <hour>,<minute>,<second>

Return Parameter : 20,30,01

**9.5.2.2 INSTRUMENT Sub-System****INSTRument**

**:EDIT**  
**:Couple**  
**:NSElect**  
**:SElect**  
**:PHASe**

**INSTRument:EDIT**

Description : It is very convenient to use a programmed command to set all phases at the same time for an AC Source that equipped with multiple phases. If INST:EDIT ALL has been programmed, it will be sent to all phases. INST:EDIT EACH command disables EDIT ALL command.

Query Syntax : INSTRument:EDIT?

Parameter : EACH | ALL

Return Parameter : None

**INSTRument : COUPle**

Description : It is easy to use a command to program all phases in an AC Source with multiple phases. If INST: COUP ALL is programmed, the command will be sent to all phases. INST: COUP NONE command will cancel COUP ALL command.

Query Syntax : INSTRument : COUPle?

Parameter : NONE | ALL

Return Parameter : None

**INSTRument : NSElect**

Description : This command sets individual output for subsequent commands or queries in the multi-phase model. If INST: COUP NONE has been programmed, the phase selection command will send to a specific output phase set by INSTRument: NSElect. If INST: COUP ALL has been programmed, all remote operation commands will send to all output phases. This command only affects the set voltage and queries the measurement data. For instance, if “INST: COUP ALL”, “INST : NSEL 2” and “Meas : VOLT?” are programmed, the AC Source will return  $\Phi$  2 measurement voltage. INST: NSEL follows the number to select phase.

Query Syntax : INSTRument : NSElect?

Parameter : 1 | 2 | 3  
 Return Parameter : 1 | 2 | 3

**INSTrument : SElect**

Description : This command sets individual output for subsequent commands or queries in the multi-phase model. If INST: COUP NONE has been programmed, the phase selection command will send to a specific output phase set by INSTrument: SElect. If INST: COUP ALL has been programmed, all remote operation commands will send to all output phases. This command only affects the set voltage and queries the measurement data. For instance, if “INST: COUP ALL”, “INST: SEL OUTPUT2” and “Meas: VOLT?” are programmed, the AC Source will return  $\Phi$  2 measurement voltage. INST: SElect follows the number to select phase.

Query Syntax : None  
 Parameter : OUTPUT1 | OUTPUT2 | OUTPUT3  
 Return Parameter : None

**INSTrument : PHASe**

Description : It switches between single phase and three-phase mode.  
 Query Syntax : INSTrument : PHASe?  
 Parameter : THREE | SINGLE  
 Return Parameter : THREE | SINGLE

**9.5.2.3 FETCH & MEASURE Sub-System**

**FETCh | MEASure**

[ : SCALAr]  
 : CURRent  
     : AC? It queries the rms current of AC component.  
     : DC? It queries the DC current level.  
     : ACDC? It queries the current (AC+DC) rms.  
     : AMPLitude : MAXimum? It queries the peak current.  
     : CRESfactor? It queries the current crest factor.  
     : INRush? It queries the inrush current.  
 : FREQuency? It queries the frequency.  
 : POWer  
     : AC  
         [: REAL]? It queries the real power.  
         : APParent? It queries the apparent power.  
         : REACTive? It queries the reactive power.  
         : PFACTor? It queries the power factor.  
         : TOTal? It queries the total power.  
         : TOTal : APParent? It queries the total apparent power.

:VOLTage

component.	: AC?	It queries the rms voltage of AC
	: DC?	It queries the DC voltage.
	: ACDC?	It queries the rms voltage
	: AMPLitude : MAXimum?	It queries the peak voltage.
	:LINE	
1 and	:V12?	It queries the voltage difference of phase 2.
2 and	:V23?	It queries the voltage difference of phase 3.
3 and	:V31?	It queries the voltage difference of phase 1.

This command enables users to get measurement data from the AC Source via MEASure and FETCh. MEASure triggers the acquisition to get new data before returning data, while FETCh returns the previously acquired data from measurement buffer.

**FETCh [ : SCALar] : CURRent : AC?**

**MEASure [ : SCALar] : CURRent : AC?**

Description : These queries return the rms current of AC component that is output from the output terminal.  
 Query Syntax : FETCh : CURRent : AC?, MEASure : CURRent : AC?  
 Return Parameter : <NR2>

**FETCh [ : SCALar] : CURRent : DC?**

**MEASure [ : SCALar] : CURRent : DC?**

Description : These queries return the DC current that is output from the output terminal.  
 Query Syntax : FETCh : CURRent : DC?, MEASure : CURRent : DC?  
 Return Parameter : <NR2>

**FETCh [ : SCALar] : CURRent : ACDC?**

**MEASure [ : SCALar] : CURRent : ACDC?**

Description : These queries return the rms current that is output from the output terminal.  
 Query Syntax : FETCh : CURRent : ACDC?, MEASure : CURRent : ACDC?  
 Return Parameter : <NR2>

**FETCh [ : SCALar] : CURRent : AMPLitude : MAXimum?**

**MEASure [ : SCALar] : CURRent : AMPLitude : MAXimum?**

Description : These queries return the absolute value of peak current.  
 Query Syntax : FETCh : CURRent : AMPLitude : MAXimum?,  
 MEASure : CURRent : AMPLitude : MAXimum?  
 Return Parameter : <NR2>

**FETCh [ : SCALAr] : CURRent : CREStfactor?**

**MEASure [ : SCALAr] : CURRent : CREStfactor?**

Description : These queries return the output current crest factor. It is the ratio of peak output current to rms output current.

Query Syntax : FETCh : CURRent : CREStfactor?  
MEASure : CURRent : CREStfactor?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : CURRent : INRush?**

**MEASure [ : SCALAr] : CURRent : INRush?**

Description : These queries return the inrush current that is output from the output terminal.

Query Syntax : FETCh:CURRent: INRush?, MEASure: CURRent : INRush?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : FREQuency?**

**MEASure [ : SCALAr] : FREQuency?**

Description : These queries return the output frequency in Hertz.

Query Syntax : FETCh : FREQuency?  
MEASure : FREQuency?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : POWer : AC [ : REAL] ?**

**MEASure [ : SCALAr] : POWer : AC [ : REAL] ?**

Description : These queries return the real power that is output from the output terminals in watt.

Query Syntax : FETCh : POWer : AC?  
MEASure : POWer : AC?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : POWer : AC : APParent?**

**MEASure [ : SCALAr] : POWer : AC : APParent?**

Description : These queries return the apparent power that is output from the output terminals in volt-ampere.

Query Syntax : FETCh : POWer : AC : APParent?  
MEASure : POWer : AC : APParent?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : POWer : AC : REACTive?**

**MEASure [ : SCALAr] : POWer : AC : REACTive?**

Description : These queries return the reactive power that is output from the output terminals in volt-ampere. Reactive power is calculated by the following formula:

$$VAR = \sqrt{APPARENTPOWER^2 - REALPOWER^2}$$

Query Syntax : FETCh : POWer : AC : REACTive?  
MEASure : POWer : AC : REACTive?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : POWER : AC : PFACTOR?****MEASure [ : SCALAr] : POWER : AC : PFACTOR?**

Description : These queries return the power factor that is output from the output terminals. Power factor is computed by:  
 $PF = TRUE\ POWER / APPARENT\ POWER$

Query Syntax : FETCh : POWER : AC : PFACTOR?  
 MEASure : POWER : AC : PFACTOR?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : POWER : AC : TOTAL ?****MEASure [ : SCALAr] : POWER : AC : TOTAL ?**

Description : These queries return the total of real power that is output from 3\_Phase output terminal in watt.

Query Syntax : FETCh : POWER : AC : TOTAL?  
 MEASure : POWER : AC : TOTAL?

Return Parameter : <NR2>

**FETCh [:SCALAr]:POWER:AC:TOTAL:APPARENT?****MEASure [:SCALAr]:POWER:AC:TOTAL:APPARENT?**

Description : These queries return the total apparent power that is output from 3\_Phase output terminal in volt-ampere.

Query Syntax : FETCh:POWER:AC:TOTAL:APPARENT?  
 MEASure:POWER:AC:TOTAL:APPARENT?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : VOLTage : AC?****MEASure [ : SCALAr] : VOLTage : AC?**

Description : These queries return the rms of AC component that is output from the output terminal.

Query Syntax : FETCh [ : SCALAr] : VOLTage : AC?  
 MEASure [ : SCALAr] : VOLTage : AC?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : VOLTage : DC?****MEASure [ : SCALAr] : VOLTage : DC?**

Description : These queries return the DC composite voltage that is output from the output terminal.

Query Syntax : FETCh [ : SCALAr] : VOLTage : DC?  
 MEASure [ : SCALAr] : VOLTage : DC?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : VOLTage : ACDC?****MEASure [ : SCALAr] : VOLTage : ACDC?**

Description : These queries return the rms that is output from the output terminal.

Query Syntax : FETCh [ : SCALAr] : VOLTage : ACDC?  
 MEASure [ : SCALAr] : VOLTage : ACDC?

Return Parameter : <NR2>

**FETCh [ : SCALAr] : VOLTage: AMPLitude : MAXimum?**

**MEASure [ : SCALAr] : VOLTage : AMPLitude : MAXimum?**

Description : These queries return the absolute value of peak voltage.  
Query Syntax : FETCh : **VOLTage**: AMPLitude : MAXimum?,  
MEASure : **VOLTage** : AMPLitude : MAXimum?  
Return Parameter : <NR2>

**FETCh [ : SCALAr] : LINE : V12?**

**MEASure [ : SCALAr] : LINE : V12?**

Description : These queries return the line voltage between phase 1 and 2.  
Query Syntax : FETCh [ : SCALAr] : LINE : V12?  
MEASure [ : SCALAr] : LINE : V12?  
Return Parameter : <NR2>

**FETCh [ : SCALAr] : LINE : V23?**

**MEASure [ : SCALAr] : LINE : V23?**

Description : These queries return the line voltage between phase 2 and 3.  
Query Syntax : FETCh [ : SCALAr] : LINE : V23?  
MEASure [ : SCALAr] : LINE : V23?  
Return Parameter : <NR2>

**FETCh [ : SCALAr] : LINE : V31?**

**MEASure [ : SCALAr] : LINE : V31?**

Description : These queries return the line voltage between phase 3 and 1.  
Query Syntax : FETCh [ : SCALAr] : LINE : V31?  
MEASure [ : SCALAr] : LINE : V31?  
Return Parameter : <NR2>

## 9.5.2.4 OUTPUT Sub-System

### OUTPut

[ : STATe]  
: RELay  
: SLEW  
: VOLTage  
: AC  
: DC  
: FREQency  
: COUPLing  
: PROTection  
: CLear

### OUTPut [ : STATe]

Description : This command enables or disables the output of the AC Source. Disabled output is to set the output voltage amplitude to 0 Volt.



Query Syntax : OUTPut [: STATe]?  
 Parameter : OFF | ON  
 Return Parameter : OFF | ON

**OUTPut : RELay**

Description : This command sets output relay on or off.  
 Query Syntax : OUTPut : RELay?  
 Parameter : OFF | ON, ON sets the output relay of the AC Source on (close), OFF sets the output relay of the AC source off (open).  
 Return Parameter : OFF | ON

**OUTPut : SLEW : VOLTage : AC**

Description : This command sets the slew rate of the AC output voltage.  
 Query Syntax : OUTPut : SLEW : VOLTage : AC?  
 Parameter : <NR2>, valid range is 0.000V/ms ~ 1200.000V/ms.  
 Return Parameter : <NR2>

**OUTPut : SLEW : VOLTage : DC**

Description : This command sets the slew rate of the DC composite voltage.  
 Query Syntax : OUTPut : SLEW : VOLTage : DC?  
 Parameter : <NR2>, valid range is 0.000V/ms ~ 1200.000V/ms.  
 Return Parameter : <NR2>

**OUTPut : SLEW : FREQuency**

Description : This command sets the slew rate of the output frequency.  
 Query Syntax : OUTPut : SLEW : FREQuency?  
 Parameter : <NR2>, valid range is 0.000 Hz/ms ~ 1600.000Hz/ms  
 Return Parameter : <NR2>

**OUTPut : COUPling**

Description : This command selects the coupling of the output signals.  
 Query Syntax : OUTPut : COUPling?  
 Parameter : AC | DC | ACDC  
 Return Parameter : AC | DC | ACDC

**OUTPut : PROTection : CLear**

Description : This command clears the latch that disables the output when over current (OCP), over-temperature (OTP), over-power (OPP) or remote inhibit (RI) is detected. All conditions that generate the faults must be resolved before the latch is cleared.  
 Query Syntax : None  
 Parameter : None  
 Return Parameter : None

**9.5.2.5 SOURCE Sub-System**

[SOURce :]  
 CURRent

```

: LIMit
: DELay
: INRush
  : START
  : INTerval
: RANGE
FREQuency
  [: {CW | IMMEDIATE}]
  : LIMit
VOLTage
  [: LEVel][: IMMEDIATE][:AMPLitude]
  : AC
  : DC
  : LIMit
  : AC
  : DC
  : PLUS
  : MINus
  : RANGE
POWER
  : PROTECTION

```

**[SOURCE :] CURRENT : LIMit**

Description : This command sets the rms current limit of the AC Source for protection.

Query Syntax : [SOURCE :] CURRENT : LIMit?

Parameter : <NR2>, valid range is 0.00 ~ maximum current spec. of the specific model (unit: A.)

Return Parameter : <NR2>

**[SOURCE :] CURRENT : DELay**

Description : This command sets the time delayed for triggering over current protection.

Query Syntax : [SOURCE :] CURRENT : DELay?

Parameter : <NR2>, valid range is 0.0 ~ 5.0 (unit: 0.1 second.)

Return Parameter : <NR2>

**[SOURCE :] CURRENT : INRush : START**

Description : This command sets the time to start the inrush current measurement.

Query Syntax : [SOURCE :] CURRENT : INRush : START?

Parameter : <NR2>, valid range is 0 ~ 9999 (unit: ms.)

Return Parameter : <NR2>

**[SOURCE :] CURRENT : INRush : INTerval**

Description : This command sets the measuring interval for inrush current measurement.

Query Syntax : [SOURCE :] CURRENT : INRush : INTerval?

Parameter : <NR2>, valid range is 0 ~ 9999 (unit: ms.)

Return Parameter : <NR2>

**[SOURce:]CURRent:RANGe**

Description : This command sets the current measurement range for output

Query Syntax : [SOURce:]CURRent:RANGe?

Parameter :

Para. / Model	1	2	3	AUTO
31180	12A	48A	192A	Auto
31120	8A	32A	128A	Auto

Return Parameter : 1 | 2 | 3 | Auto

**[SOURCE :] FREQUENCY [: {CW | IMMEDIATE}]**

Description : This command sets the output waveform frequency for the AC Source in Hz.

Query Syntax : [SOURCE :] FREQUENCY [: {CW | IMMEDIATE}]?

Parameter : <NR2>, valid range is 15.00 ~ 1500.0 (unit: Hz.)

Return Parameter : <NR2>

**[SOURCE :] FREQUENCY : LIMIT**

Description : This command sets the output frequency limit for the AC Source.

Query Syntax : [SOURCE :] FREQUENCY : LIMIT?

Parameter : <NR2>, valid range is 15.00 ~ 1500.00 (unit: Hz)

Return Parameter : <NR2>

**[SOURCE :] POWER:PROTECTION**

Description : This command sets the OPP (Over Power Protection) for AC Source.

Query Syntax : [SOURCE :] POWER:PROTECTION?

Parameter : <NR2>, valid range is 0.0 ~ maximum power of specific model (unit: W.)

Return Parameter : <NR2>

**[SOURCE :] VOLTAGE [: LEVEL][: IMMEDIATE][: AMPLITUDE] : AC**

Description : This command sets the AC composite output voltage in Volts.

Query Syntax : [SOURCE :] VOLTAGE [: LEVEL][: IMMEDIATE][: AMPLITUDE] : AC?

Parameter : <NR2>, valid range is 0.0 ~ 150.0 (low range), 0.0 ~ 300.0 (high range.)

Return Parameter : <NR2>

**[SOURCE :] VOLTAGE [: LEVEL][: IMMEDIATE][: AMPLITUDE] : DC**

Description : This command sets the DC composite output voltage in Volts.

Query Syntax : [SOURCE :] VOLTAGE [: LEVEL][: IMMEDIATE][: AMPLITUDE] : DC?

Parameter : <NR2>, valid range is -212.1 ~ 212.1 (low range), -424.2 ~ 424.2 (high range.)

Return Parameter : <NR2>

**[SOURCE :] VOLTAGE : LIMIT : AC**

Description : This command sets the Vac LIMIT to restrict the value of Vac.

Query Syntax : [SOURce :] VOLTage : LIMit : AC?  
Parameter : <NR2>, valid range is 0.0 ~ 300.0 (unit: V.)  
Return Parameter : <NR2>

**[SOURce :] VOLTage : LIMit : DC : PLUS**

Description : This command sets the Vdc Limit(+).  
Query Syntax : [SOURce :] VOLTage : LIMit : DC : PLUS?  
Parameter : <NR2>, valid range is -424.2 ~ 424.2 (unit: V)  
PS: The lower limit cannot exceed Vdc Limit(-).  
Return Parameter : <NR2>

**[SOURce :] VOLTage : LIMit : DC : MINus**

Description : This command sets the Vdc Limit(-).  
Query Syntax : [SOURce :] VOLTage : LIMit : DC : MINus?  
Parameter : <NR2>, valid range is -424.2 ~ -424.2 (unit: V)  
PS: The upper limit cannot exceed Vdc Limit(+).  
Return Parameter : <NR2>

**[SOURce :] VOLTage : RANGE**

Description : This command sets the output voltage range to LOW (150 V)  
or HIGH (300 V) or AUTO 3 selections.  
Query Syntax : [SOURce :] VOLTage : RANGE?  
Parameter : LOW | HIGH  
Return Parameter : LOW | HIGH

### 9.5.2.6 CONFIGURE Sub-System

**[SOURCE :]**  
CONFigure  
: INHibit  
: EXTernal  
: COUPling  
: EXTON

#### **[SOURCE :] CONFigure : INHibit**

Description : This command sets the Remote Inhibit function.  
Query Syntax : [SOURCE :] CONFigure : INHibit?  
Parameter : DISABLE | ENABLE  
Return Parameter : DISABLE | ENABLE

#### **[SOURCE :] CONFigure : EXTernal**

Description : This command sets if enabling the External-V Reference function.  
Query Syntax : [SOURCE :] CONFigure : EXTernal?  
Parameter : OFF | ON  
Return Parameter : OFF | ON

#### **[SOURCE :] CONFigure : COUPling?**

Description : This command sets the External-V Reference to be AC\_AMPLIFIER or DC\_LEVEL to control the AC Source output.  
Query Syntax : [SOURCE :] CONFigure : COUPling?  
Parameter : AC | DC  
Return Parameter : AC | DC

#### **[SOURCE :] CONFigure : EXTON**

Description : This command sets the External ON/OFF control.  
Query Syntax : [SOURCE :] CONFigure : EXTON?  
Parameter : DISABLE | ENABLE  
Return Parameter : DISABLE | ENABLE

### 9.5.2.7 PHASE Sub-System

**[SOURCE:]**  
PHASe  
:ON  
:OFF  
:P12  
:P13  
:SEQuence  
:THREE  
:RELOCK

**[SOURCE:] PHASe: ON**

Description : This command sets the transition angle when the waveform shifts. The default is ON meaning 0 degree.  
Query Syntax : [SOURCE :] PHASe : ON?  
Parameter : <NR2>, valid range is 0.0 ~ 359.9.  
Return Parameter : <NR2>

**[SOURCE:] PHASe: OFF**

Description : This command sets the transition angle when the waveform ends.  
Query Syntax : [SOURCE :] PHASe : OFF?  
Parameter : <NR2>, valid range is 0.0 ~ 360.0, 360.0: means IMMED.  
Return Parameter : <NR2>

**[SOURCE:]PHASe:P12**

Description : This command sets the phase difference of  $\Phi 1$  and  $\Phi 2$ .  
Query Syntax : [SOURCE :]PHASe:P12?  
Parameter : <NR2>, valid range is 0.0 ~ 359.9.  
Return Parameter : <NR2>

**[SOURCE:]PHASe:P13**

Description : This command sets the phase difference of  $\Phi 1$  and  $\Phi 3$ .  
Query Syntax : [SOURCE :]PHASe:P13?  
Parameter : <NR2>, valid range is 0.0 ~ 359.9.  
Return Parameter : <NR2>

**[SOURCE:]PHASe:SEQuence**

Description : This command sets the phase sequence in 3\_Phase mode.  
Query Syntax : [SOURCE :]PHASe:SEQuence?  
Parameter : POS | NEG  
Return Parameter : POSITIVE | NEGATIVE

**[SOURCE:]PHASe:RELOCK**

Description : This command sets the relock function in 3\_Phase mode.  
Query Syntax : [SOURCE :]PHASe:RELOCK?  
Parameter : ENABLE | DISABLE  
Return Parameter : ENABLE | DISABLE

**[SOURCE:]PHASe:THREE**

Description : This command set the operation mode in 3\_Phase mode.  
Query Syntax : [SOURCE :]PHASe:THREE?  
Parameter : INDEPEND | SAMEFREQ | BALANCE  
Return Parameter : INDEPEND | SAMEFREQ | BALANCE

## 9.5.2.8 STATUS Sub-system

### STATus

: OPERation  
[: EVENT]?  
: ENABle  
: QUEStionable  
: CONDition  
[: EVENT]?  
: ENABle  
: NTRansition  
: PTRansition

#### STATus : OPERation [: EVENT]?

Description : This command queries the Operation Status register.  
Query Syntax : STATus : OPERation [: EVENT]?  
Parameter : None  
Return Parameter : Always 0.

#### STATus : OPERation : ENABle

Description : This command sets the Operation Status Enable register. The register is the shield when specific bit is enabled from Operation Status register.  
Query Syntax : STATus : OPERation : ENABle?  
Parameter : <NR1>, valid range is 0 ~ 255.  
Return Parameter : Always 0.

#### STATus : QUEStionable : CONDition?

Description : This query command returns the value of Questionable Condition register. It is a read only register that saves the questionable condition of AC Source in real time.  
Query Syntax : STATus : QUEStionable : CONDition?  
Parameter : NONE  
Return Parameter : <NR1>, valid range is 0 ~ 511.

#### STATus : QUEStionable [: EVENT] ?

Description : This query command returns the value of Questionable Event register. It is a read only register that saves all items that passed Questionable NTR and/or PTR filter. If the QUES bit in Service Request Enabled register has been set and Questionable Event register > 0, the QUES of Status Byte register will be set too.  
Query Syntax : STATus : QUEStionable [: EVENT]?  
Parameter : NONE  
Return Parameter : <NR1>, valid range is 0 ~ 511.

#### STATus : QUEStionable : ENABle

Description : The command sets or reads the value of Questionable Enable register. The register is the shield when specific bit is enabled



to set the QUES bit of Status Byte register from Operation Status register.  
 Query Syntax : STATus : QUESTionable : ENABle?  
 Parameter : <NR1>, valid range is 0 ~ 511.  
 Return Parameter : <NR1>

**STATus : QUESTionable : NTRansition**

Description : These commands set or read the value of register.  
 The operation of these registers is the same as polarity filter of Questionable Enable and Questionable Event registers that lead the following actions:

- \* When a bit of the Questionable NTR register is set to 1, a 1-to-0 transition of the corresponding bit in the Questionable Condition register will make that bit in the Questionable Event register to be set.
- \* When a bit of the Questionable PTR register is set to 1, a 0-to-1 transition of the corresponding bit in the Questionable Condition register will make that bit in the Questionable Event register to be set.
- \* If the two same bits in both NTR and PTR registers are set to 0, none transition of that bit in the Questionable Condition register can set the corresponding bit in the Questionable Event register.

Bit Configuration of Questionable Status Register

Bit Position	15-9	8	7	6	5	4	3	2	1	0
Condition	---	OVP	INP	OCP	FAN	SHT	OTP	OPP	INT-DD	INT-AD

OVP : Output voltage protection  
 INP : Line input protection.  
 OCP : Over current protection.  
 FAN : Fan failure.  
 SHT : Output short protection.  
 OTP : Over temperature protection.  
 OPP : Over power protection.  
 INT-DD : Inner DD power stage protection  
 INT-AD : Inner AD power stage protection

Query Syntax : STATus : QUESTionable : NTRansition?  
 Parameter : <NR1>, valid range is 0 ~ 511.  
 Return Parameter : <NR1>

**STATus : QUESTionable : PTRansition**

Description : These commands set or read the values of Questionable PTR register. Please refer to the description of previous command.  
 Query Syntax : STATus : QUESTionable : PTRansition?  
 Parameter : <NR1>, valid range is 0 ~ 511.

Return Parameter : <NR1>

### 9.5.2.9 TRACE Sub-system

**TRACe**

: RMS

**TRACe**

Description : This command sets the user-defined waveform data. It needs 1024 data points to create a period of waveform. Users have to normalize the data and make the maximum point equal to 32767 or the minimum point equal to -32767.

Syntax : **TRACe** <waveform\_name>, <amplitude>, {<amplitude>} Parameter : <waveform\_name>:US<n>, n=1~6, <amplitude>:<NR1>, the valid range is -32767 ~ 32767. Example : **TRACe** US1 100 200 ...32767... 500 800 <= 1024 points This command requires about 5 seconds for execution.

**TRACe : RMS**

Description : This command sets the rms value of user's waveform. Users need to calculate the root mean square value for 1024 data points. Syntax :

**TRACe : RMS** <waveform\_name>, <rms> Parameter : <waveform\_name>:US<n>, n=1~6, <rms>:<NR1>, the valid range is 0 ~ 32767.

Example : **TRACe : RMS** US1 27000

### 9.5.2.10 LIST Sub-system

[**SOURce**

:]

**LIST**

: COUPling

:TRIG

: POINts?

: COUNT

: DWELl

: SHAPE

: BASE

: VOLTage

: AC

: START

```

: END
: DC
: START
: END
: START
: END
:
FREQ          : START
uency        : END
              : DEGREE
OUTPut
              : MODE
    
```

**TRIG**  
**TRIG : STATE?**

**[SOURCE:]LIST : COUPLing**

Description : This command sets the function of list mode.  
 Query Syntax : [SOURCE:] LIST : Coupling?  
 Parameter : ALL | NONE  
 Return Parameter : ALL | NONE

**[SOURCE:]LIST : TRIG**

Description : This command sets the trigger type of list mode.  
 Query Syntax : [SOURCE:] LIST : TRIG?  
 Parameter : AUTO | MANUAL|EXCITE  
 Return Parameter : AUTO | MANUAL|EXCITE

**[SOURCE:] LIST : POINTs?**

Description : This command returns the valid order number of list mode.  
 Query Syntax : [SOURCE:] LIST : POINTs?  
 Parameter : None  
 Return Parameter : <NR1>, the valid range is 0 ~ 100.

**[SOURCE :] LIST : COUNT**

Description : This command sets the number of times the list executed before completion. Query Syntax : [SOURCE :] LIST : COUNT?  
 Parameter : <NR1>, the valid range is 0 ~ 65535.  
 Return Parameter : <NR1>

**[SOURCE :] LIST : DWELI**

Description : This command sets the sequence of dwell time list points.

Query Syntax : [SOURCE:] LIST : DWELI?

Parameter : <NR2>, ..., <NR2>, the valid range is 0 ~ 99999999.9 (unit: ms.)

Return Parameter : <NR2>, ..., <NR2>

**[SOURCE :] LIST : SHAPe**

Description : This command sets the sequence of waveform buffer list points.

Query Syntax : [SOURCE:] LIST : SHAPe?

Parameter : A|B, ..., A|B

Return Parameter : A|B, ..., A|B

**[SOURCE :] LIST : BASE**

Description : This command sets the time base of list.

Query Syntax : [SOURCE:] LIST : BASE?

Parameter : TIME | CYCLE

Return Parameter : TIME | CYCLE

**[SOURCE :] LIST : VOLTage : AC : START**

Description : This command sets the sequence of AC start voltage list points.

Query Syntax : [SOURCE:] LIST : VOLTage : AC : START?

Parameter : <NR2>, ..., <NR2>, the valid range is 0.0 ~ 150.0 (low range), 0.0 ~

300.0 (high range.)

Return Parameter : <NR1>, ..., <NR2>

**[SOURCE :] LIST : VOLTage : AC : END**

Description : This command sets the sequence of AC end voltage list points.

Query Syntax : [SOURCE:] LIST : VOLTage : AC : END?

Parameter : <NR2>, ..., <NR2>, the valid range is 0.0 ~ 150.0 (low range), 0.0 ~

300.0 (high range.)

Return Parameter : <NR2>, ..., <NR2>

**[SOURCE :] LIST : VOLTage : DC : START**

Description : This command sets the sequence of DC start voltage list points.

Query Syntax : [SOURCE:] LIST : VOLTage : DC : START?

Parameter : <NR2>, ..., <NR2>, the valid range is -212.1 ~ 212.1 (low range),

-424.2 ~ 414.2 (high range.)

Return Parameter : <NR1>

**[SOURCE :] LIST : VOLTage : DC : END**

Description : This command sets the sequence of DC end voltage list points.  
Query Syntax : [SOURce:] LIST : VOLTage : DC : START?  
Parameter : <NR2>, ..., <NR2>, the valid range is -212.2 ~ 212.1 (low range),

-424.2 ~ 414.2 (high range.)

Return Parameter : <NR2>, ..., <NR2>

#### [SOURce :] LIST : FREQuency : START

Description : This command sets the sequence of start frequency list points.  
Query Syntax : [SOURce:] LIST : FREQuency : START?  
Parameter : <NR2>, ..., <NR2>, the valid range is 15.00 ~ 1000.00 (unit: Hz.)  
Return Parameter : <NR2>, ..., <NR2>

#### [SOURce :] LIST : FREQuency : END

Description : This command sets the sequence of end frequency list points.  
Query Syntax : [SOURce:] LIST : FREQuency : END?  
Parameter : <NR2>, ..., <NR2>, the valid range is 15.0 ~ 1500.0 (unit: Hz.)  
Return Parameter : <NR2>, ..., <NR2>

#### [SOURce :] LIST : DEGRee

Description : This command sets the sequence of phase angle list points.  
Query Syntax : [SOURce:] LIST : DEGRee?  
Parameter : <NR2>, ..., <NR2>, the valid range is 0.0 ~ 359.9.  
Return Parameter : <NR2>, ..., <NR2>

#### OUTPut : MODE

Description : This command sets the operation mode.  
Query Syntax : OUTPut : MODE?  
Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR  
Return Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

#### TRIG

Description : This command sets LIST mode in OFF, ON execution state after setting **OUTPut : MODE LIST**. If users wish to change the parameters, it's necessary to set **TRIG OFF** then **OUTPut : MODE FIXED**. Then, set **OUTPut : MODE LIST** again to get ready to set **TRIG ON**.

Query Syntax : TRIG : STATE?  
Parameter : OFF | ON  
Return Parameter : OFF | RUNNING

### 9.5.2.11 PULSE Sub-system

#### [SOURCE :] PULSe

: VOLTage  
: AC  
: DC  
  
: FREQuency  
: SHAPe  
: SPHase  
: COUNT  
: DCYCLe  
: PERiod  
: TRIG

#### OUTPut

: MODE

#### TRIG

#### TRIG : STATE?

#### [SOURCE :] PULSe : VOLTage : AC

Description : This command sets AC voltage for the duty cycle of PULSE mode.  
Query Syntax : [SOURCE :] PULSE : VOLTage : AC?  
Parameter : <NR2>, the valid range is 0.0 ~ 150.0 (low range), 0.0 ~ 300.0 (high range.)  
Return Parameter : <NR2>

#### [SOURCE :] PULSe : VOLTage : DC

Description : This command sets the DC voltage for the duty cycle of PULSE mode. Query Syntax : [SOURCE :] PULSE : VOLTage : DC?  
Parameter : <NR2>, the valid range is -212.1 ~ 212.1 (low range), -424.2 ~ 424.2 (high range.)  
Return Parameter : <NR2>

#### [SOURCE :] PULSe : FREQuency

Description : This command sets the frequency for the duty cycle of PULSE mode.  
Query Syntax : [SOURCE :] PULSE : FREQuency?

Parameter : <NR2>, the valid range is 15.0 ~ 1500.0 (unit: Hz.)

Return Parameter : <NR2>

**[SOURCE :] PULSe : SHAPe**

Description : This command selects the waveform buffer for PULSE mode.

Query Syntax : [SOURCE :] PULSE : SHAPe?

Parameter : A | B

Return Parameter : A | B

**[SOURCE :] PULSe : SPHase**

Description : This command sets the start phase angle of duty cycle for PULSE mode.

Query Syntax : [SOURCE :] PULSE : SPHase?

Parameter : <NR2>, the valid range is 0.0 ~ 359.9.

Return Parameter : <NR2>

**[SOURCE :] PULSe : COUNT**

Description : This command sets the number of times the pulse executed before completion.

Query Syntax : [SOURCE :] PULSE : COUNT?

Parameter : <NR2>, the valid range is 0 ~ 65535.

Return Parameter : <NR2>

**[SOURCE :] PULSe : DCYCLe**

Description : This command sets the duty cycle of PULSE mode.

Query Syntax : [SOURCE :] PULSE : DCYCLe?

Parameter : <NR2>, the valid range is 0 % ~ 100 %.

Return Parameter : <NR2>

**[SOURCE :] PULSe : PERiod**

Description : This command sets the period of the PULSE mode.

Query Syntax : [SOURCE :] PULSE : PERiod?

Parameter : <NR2>, the valid range is 0 ~ 99999999.9 (unit: ms.)

Return Parameter : <NR2>

**[SOURCE:]PULSe : TRIG**

Description : This command sets the TRIG type of PULSE mode.

Query Syntax : [SOURCE:] PULSe : TRIG?

Parameter : AUTO | MANUAL|EXCITE

Return Parameter: AUTO | MANUAL|EXCITE

**OUTPut : MODE**

Description : This command sets the operation mode.

Query Syntax : **OUTPut** : **MODE**?  
Parameter : **FIXED** | **LIST** | **PULSE** | **STEP** | **SYNTH** | **INTERHAR**  
Return Parameter : **FIXED** | **LIST** | **PULSE** | **STEP** | **SYNTH** | **INTERHAR**

## **TRIG**

Description : This command sets **PULSE** mode in **OFF** execution state after setting **OUTPut : MODE PULSE**. If users want to change the parameters, it's necessary to set **TRIG OFF** then **OUTPut : MODE FIXED**. Then, set **OUTPut : MODE PULSE** again to get ready to set **TRIG ON**.

Query Syntax : **TRIG** : **STATE**?  
Parameter : **OFF** | **ON**  
Return Parameter : **OFF** | **RUNNING**

### **9.5.2.12 STEP Sub-system**

**[SOURCE :] STEP**

: **VOLTage**  
: **AC**  
: **DC**

: **FREQuency**  
: **SHAPE**  
: **SPHase**  
: **DVOLTage**

: **AC**  
: **DC**  
: **DFREquency**

: **DWELI**  
: **COUNT**  
: **TRIG**

**OUTPut**  
: **MODE**

**TRIG**  
**TRIG : STATE?**



**[SOURCE :] STEP : VOLTage : AC**

Description : This command sets the initial AC voltage of STEP mode.

Query Syntax : [SOURCE :] STEP : VOLTage : AC?

Parameter : <NR2>, the valid range is 0.0 ~ 150.0 (low range), 0.0 ~ 300.0 (high range.)

Return Parameter : <NR2>

**[SOURCE :] STEP : VOLTage : DC**

Description : This command sets the initial DC voltage of STEP mode.

Query Syntax : [SOURCE :] STEP : VOLTage : DC?

Parameter : <NR2>, the valid range is -212.1 ~ 212.1 (low range), -424.2 ~ 414.2 (high range.)

Return Parameter : <NR2>

**[SOURCE :] STEP : FREQuency**

Description : This command sets the initial frequency of STEP mode.

Query Syntax : [SOURCE :] STEP : FREQuency?

Parameter : <NR2>, the valid range is 15.0 ~ 1500.0 (unit: Hz.)

Return Parameter : <NR2>

**[SOURCE :] STEP : SHAPe**

Description : This command selects the waveform buffer of STEP mode.

Query Syntax : [SOURCE :] STEP : SHAPe?

Parameter : A | B

Return Parameter : A | B

**[SOURCE :] STEP : SPHase**

Description : This command sets the start phase angle of STEP mode.

Query Syntax : [SOURCE :] STEP : SPHase?

Parameter : <NR2>, the valid range is 0.0 ~ 359.9.

Return Parameter : <NR2>

**[SOURCE :] STEP : DVOLTage : AC**

Description : This command sets the AC voltage change in each step.

Query Syntax : [SOURCE :] STEP : DVOLTage : AC?

Parameter : <NR2>, the valid range is -150.0 ~ 150.0 (low range), -300.0 ~ 300.0 (high range.)

Return Parameter : <NR2>

**[SOURCE :] STEP : DVOLTage : DC**

Description : This command sets the DC voltage change in each step.  
Query Syntax : [SOURce :] STEP : DVOLtage : DC?  
Parameter : <NR2>, the valid range is -212.2 ~ 212.1 (low range), -424.2 ~ 424.2

(high range.)

Return Parameter : <NR2>

#### **[SOURce :] STEP : DFRequency**

Description : This command sets the frequency change in each step.  
Query Syntax : [SOURce :] STEP : DFRequency?  
Parameter : <NR2>, the valid range is -1500.00 ~ 1500.0 (unit: Hz.)  
Return Parameter : <NR2>

#### **[SOURce :] STEP : DWELl**

Description : This command sets the dwell time in each step.  
Query Syntax : [SOURce :] STEP : DWELl?  
Parameter : <NR2>, the valid range is 0 ~ 99999999.9 (unit: ms.)  
Return Parameter : <NR2>

#### **[SOURce :] STEP : COUNT**

Description : This command sets the number of times the step executed before completion.  
Query Syntax : [SOURce :] STEP : COUNT?  
Parameter : <NR2>, the valid range is 0 ~ 65535.  
Return Parameter : <NR2>

#### **[SOURce:] STEP : TRIG**

Description : This command sets the TRIP type of STEP mode.  
Query Syntax : [SOURce:] STEP : TRIG?  
Parameter : AUTO | MANUAL  
Return Parameter : AUTO | MANUAL

#### **OUTPut : MODE**

Description : This command sets the operation mode.  
Query Syntax : OUTPut : MODE?  
Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR  
Return Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

#### **TRIG**

Description : This command sets STEP mode in OFF, ON execution state after setting **OUTPut : MODE STEP**. If users want to change the parameters, it's necessary to set **TRIG OFF** then **OUTPut : MODE FIXED**. Then, set **OUTPut : MODE STEP** again to

get ready to set **TRIG ON**.  
Query Syntax : TRIG : STATE?  
Parameter : OFF | ON  
Return Parameter : OFF | RUNNING

### 9.5.2.13 SYNTHESIS Sub-system

**[SOURCE :]**

**SYNThe  
sis**

: COMPose  
: AMPLitude  
: PHASe  
: FUNDamental  
: DC  
: FREQuency  
: SPHase

**OUTPut**

: MODE

**TRIG**

**TRIG : STATE?**

**[SOURCE :] SYNThesis : COMPose**

Description : This command sets the data format of each harmonic order. VALUE: absolute value, PERCENT: basic computer percentage. Users can program 6 waveforms for execution.

Query Syntax : [SOURCE :] SYNThesis :  
COMPose?

Parameter : VALUE1 | VALUE2 |  
VALUE3 |

PERCENT1 | PERCENT2 | PERCENT3

Return Parameter : VALUE1 | VALUE2 |  
VALUE3 |

PERCENT1 | PERCENT2 | PERCENT3

**[SOURCE :] SYNThesis : AMPLitude**

Description : This command sets the amplitude of each harmonic order.  
The maximum order is 40.

Query Syntax : [SOURCE :] SYNThesis : AMPLitude?

Parameter : <NR2>, ..., <NR2>

Valid range:

Order	Value	Percentage
2 ~ 10	0 ~ 150.0	0 ~ 100.00
11 ~ 20	0 ~ 120.0	0 ~ 50.00
21 ~ 30	0 ~ 80.0	0 ~ 30.00
31 ~ 40	0 ~ 45.0	0 ~ 15.00

Return Parameter : <NR2>, ..., <NR2>

**[SOURCE :] SYNThesis : PHASe**

Description : This command sets the phase angle of each harmonic order.

Query Syntax : [SOURCE :] SYNThesis : PHASe?

Parameter : <NR2>, ..., <NR2>, the valid range: 0.0 ~ 359.9

Return Parameter : <NR2>, ..., <NR2>

**[SOURCE :] SYNThesis : FUNDamental**

Description : This command sets the fundamental AC voltage in SYNTHESIS mode. Query Syntax : [SOURCE :] SYNThesis :

FUNDamental? Parameter : <NR2>, the valid range: 0.0 ~ 150.0 (low range), 0.0 ~ 300.0 (high

range)

Return Parameter : <NR2>

**[SOURCE :] SYNThesis : DC**

Description : This command sets the DC voltage to add the voltage waveform in SYNTHESIS mode. Query Syntax : [SOURCE :] SYNThesis :

DC? Parameter : <NR2>, the valid range: -212.1 ~ 212.1 (low range), -424.2 ~ 424.2

(high range)

Return Parameter : <NR2>

**[SOURCE :] SYNThesis : FREQuency**

Description : This command sets the fundamental frequency in SYNTHESIS mode.

Query Syntax : [SOURCE :] SYNThesis : FREQuency?

Parameter : 50 | 60

Return Parameter : 50 | 60

**[SOURCE :] SYNThesis : SPHase**

Description : This command sets the start phase angle in SYNTHESIS mode.

Query Syntax : [SOURCE :] SYNThesis : SPHase?

Parameter : <NR2>, the valid range: 0.0 ~ 359.9

Return Parameter : <NR2>

**OUTPut : MODE**

Description : This command sets the operation mode. User should quit output before setting **OUTPut : MODE SYNTH**.

Query Syntax : OUTPut : MODE?

Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

Return Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

**TRIG**

Description : This command sets SYNTHESIS mode in OFF, ON execution state after setting **OUTPut : MODE SYNTH**. If users want to change the parameters, it's necessary to set **TRIG OFF** then **OUTPut : MODE FIXED**. Then, set **OUTPut : MODE SYNTH** again to get ready to set **TRIG ON**.

Query Syntax : TRIG : STATE?

Parameter : OFF | ON

Return Parameter : OFF | RUNNING

**9.5.2.14 INTERHARMONICS Sub-system**

[SOURce :]

**INTERHARmonic  
s**

: FREQuency  
: STARt  
: END

: LEVel  
: DWELl

**OUTPut**

: MODE

**TRIG**

**TRIG : STATE?**

**FETCh | MEASure**

: INTERHARmonics

: FREQuency? It queries the sweeping frequency.

**[SOURce :] INTERHARmonics : FREQuency : START**

Description : This command sets the start frequency of sweep wave for INTERHARMONICS mode.

Query Syntax : [SOURce :] INTERharmonics : FREQuency : START?

Parameter : <NR2>, the valid range is 0.01 ~ 2400.0 (unit: Hz.)

Return Parameter : <NR2>

**[SOURce :] INTERHARmonics: FREQuency : END**

Description : This command sets the end frequency of sweep wave for INTERHARMONICS mode.

Query Syntax : [SOURce :] INTERharmonics : FREQuency : END?

Parameter : <NR2>, the valid range is 0.01 ~ 2400.00 (unit: Hz.)

Return Parameter : <NR2>

**[SOURce :] INTERHARmonics: LEVel**

Description : This command sets the rms. range of sweep wave in percentage level. Query Syntax : [SOURce :] INTERharmonics : LEVel?

Parameter : <NR2>, the valid range is 0% ~ 30% in 0.01 Hz ~ 500 Hz

0% ~ 20% in 500.01 Hz ~ 1000 Hz 0% ~ 10% in

1000.01 Hz ~ 2400 Hz Return Parameter : <NR2>

**[SOURce :] INTERHARmonics: DWELl**

Description : This command sets the dwell time of sweep wave.

Query Syntax : [SOURce :] INTERharmonics : DWELl?

Parameter : <NR2>, the valid range is 0.00 ~ 99999.99 (unit: sec.)

Return Parameter : <NR2>

**OUTPut : MODE**

Description : This command sets the operation mode.

Query Syntax : OUTPut : MODE?

Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

Return Parameter : FIXED | LIST | PULSE | STEP | SYNTH | INTERHAR

**TRIG**

Description : This command sets INTERHARMONICS mode in OFF, ON, PAUSE or CONTINUE execution state after setting **OUTPut : MODE INTERHAR**. If users wish to change the Parameter, it has to set **TRIG OFF** and **OUTPut : MODE FIXED**, next **OUTPut : MODE INTERHAR** in order to set **TRIG ON**.

Query Syntax : TRIG : STATE?

Parameter : OFF | ON | PAUSE | CONTINUE

Return Parameter : OFF | RUNNING | PAUSE

**FETCh [:SCALAr] : INTERHARmonics:  
FREQuency? MEASure [:SCALAr] :**

**INTERHARmonics: FREQuency?**

Description : These query commands return the sweep frequency stacked on base voltage.

Query Syntax : FETCh :  
INTERHARMonics :  
FREQuency? MEASure :  
INTERHARMonics :  
FREQuency? Return  
Parameter : <NR2>

**9.5.2.15 Harmonic Sense Sub-system**

[SOURce :]

CON

Figur

e

: HARMonic  
: SOURce  
: TIMES  
: PARAmeter  
: FREQuency

**SENSe**

: HARMonic

**FETCh | MEASure**

[ : SCALar]





: HARMonic : THD? It returns the % of total harmonic distortion. :  
 FUNDamental? It returns the fundamental frequency. : ARRy? It returns  
 the array of all harmonic orders.

**[SOURce :] CONFigure : HARMonic : SOURce**

Description : This command sets the measured  
 power source in harmonic  
 analysis mode. Query  
 Syntax : [SOURce :]  
 CONFigure : HARMonic :  
 SOURce?

Parameter : VOLT | CURR

Return Parameter : VOLT | CURR

**[SOURce :] CONFigure : HARMonic : TIMES**

Description : This command sets the way the measurement result of harmonic analysis  
 displayed on LCD. SINGLE: It keeps the measured data on the  
 display when set. CONTINUE: It updates the measured data on the  
 display when set.

Query Syntax : [SOURce :] CONFigure : HARMonic : TIMES?

Parameter : SINGLE | CONTINUE

Return Parameter : SINGLE | CONTINUE

**[SOURce :] CONFigure : HARMonic : PARAMeter**

Description : This command sets the data format for each harmonic order.

Query Syntax : [SOURce :] CONFigure : HARMonic : PARAMeter?

Parameter : VALUE | PERCENT

Return Parameter : VALUE | PERCENT

**[SOURce :] CONFigure : HARMonic : FREQuency**

Description : This command sets the fundamental frequency of original waveform.

Query Syntax : [SOURce :] CONFigure : HARMonic : FREQuency?

Parameter : 50 | 60

Return Parameter : 50 | 60

**SENSe : HARMonic**

Description : This command sets the harmonic measurement on/off. It has to execute  
 “ON” before every new search or measurement. Only 3 seconds  
 are required for the result. The parameter has to set to “OFF” if  
 users wish to measure other data.

Query Syntax : SENSe : HARMonic?

Parameter : ON | OFF

Return Parameter : ON | OFF

**FETCh [:SCALar] : HARMonic : THD?**

**MEASure [:SCALar] : HARMonic : THD?**

Description : This query command returns the % of total harmonic distortion. Query Syntax : FETCh : HARMonic : THD? MEASure : HARMonic : THD? Return Parameter : <NR2>

**FETCh [:SCALar] : HARMonic : FUNDamental?**

**MEASure [:SCALar] : HARMonic : FUNDamental?**

Description : This query command returns the fundamental frequency output current or voltage. Query Syntax : FETCh : HARMonic : FUNDamental? MEASure : HARMonic : FUNDamental? Return Parameter : <NR2>

**FETCh [:SCALar] : HARMonic : ARRay?**

**MEASure [:SCALar] : HARMonic : ARRay?**

Description : This query command returns the array of all harmonic orders. Query Syntax : FETCh : HARMonic : ARRay? MEASure : HARMonic : ARRay? Return Parameter : <NR2>

## 9.6 Command Summary

### *Common Commands*

* CLS	Clear status
* ESE<n>	Enable standard event status
* ESE?	Return enabled standard event status
* IDN?	Return the AC Source ID
* RCL<n>	Recall the AC Source file
* RST	Reset the AC Source to initial states
* SAV<n>	Save the AC Source status
* SRE	Set request enable register
* STB?	Return status byte
* TST?	Return the self-test result of AC Source

### *Instrument Commands*

**SYSTem**

: ERRor?  
: VERSion?  
: LOCal  
: REMote

: DATE  
: TIME

**INSTrument**

: EDIT  
: Couple  
: NSElect  
: SElect  
: PHASe

**FETCh | MEASure**

[ : SCALAr]  
: CURRent  
  : AC?  
  : DC?  
  : ACDC?  
  : AMPLitude:MAXimum?  
  : CRESfactor?  
  : INRush?  
: FREQuency?  
: POWer  
  : AC  
    [: REAL]?  
    : APParent?  
    : REACtive?  
    : PFACtor?  
    : TOTal?  
    : TOTal:APParent?  
: VOLTage  
  : AC?  
  : DC?  
  : ACDC?  
  : AMPLitude:MAXimum?  
: LINE  
  : V12?  
  : V23?  
  : V31?

**OUTPut**

[ : STATe]  
: RELay  
: SLEW  
  : VOLTage  
    : AC  
    : DC  
  : FREQuency  
: COUPling  
: PROTection  
  : CLear

**[SOURCE :]**

CURRent  
: LIMit  
: DELay  
: INRush  
: STARt  
: INTerval  
:RANGe  
FREQency  
[: {CW | IMMEDIATE}]  
: LIMit  
VOLTage  
[: LEVel][: IMMEDIATE][:AMPLitude]  
: AC  
: DC  
: LIMit  
: AC  
: DC  
: PLUS  
: MINus  
: RANGe  
  
POWER  
: PROTection

**[SOURCE :]**

PHASe  
: ON  
: OFF

**[SOURCE :]**

CONFigure  
: INHibit

**STATus**

: OPERation  
[: EVENT]?  
: ENABle  
: QUEStionable  
: CONDition  
[: EVENT]?  
: ENABle  
: NTRansition  
: PTRansition


## Appendix A TTL Signal Pin Assignments

Green terminal with female connector:

Pin No.	Signal	Description
1	Ext-V $\Phi$ 1	$\Phi$ 1 External-V Reference signal input (-10V~10V)
2	Ext-V $\Phi$ 2	$\Phi$ 2 External-V Reference signal input (-10V~10V) It is the input pin of external voltage signal when applied in single phase.
3	Ext-V $\Phi$ 3	$\Phi$ 3 External-V Reference signal input (-10V~10V)
4	AGND	External-V Reference signal grounding
5	+12V	12V voltage output (providing current 1A)
6	Reserved	
7	DGND	Digital signal grounding
8	DGND	Digital signal grounding
9	AC-ON	This pin turns to HIGH when the AC Source outputs voltage and turns to LOW when quits output.
10	/FAULT-OUT	The voltage level of this pin is HIGH when the AC Source is in normal mode, it will turn to LOW when the AC Source is in protection mode.
11	/Ext-ONOFF	When EXT-ONOFF is enabled and the voltage level of this pin turns to LOW, the AC Source output will be open and it will close on the contrary.
12	/Remote-Inhibit	When the voltage level of this pin turns to LOW, it can inhibit the AC Source output or trigger mode.
13	/Remote-Excite	When this pin receives a negative edge signal (from High to Low), it can trigger the transient output of AC Source.
14	/Transient	When the output of AC Source changes, this pin will send out a low level 1us or remain at high level.
15	Reserved	
16	Reserved	
17	Reserved	
18	Reserved	




Waveform A = DST03



N	%	D
3	2.00	0
5	1.40	0
7	2.00	0
23	1.40	0
31	1.00	0

DST03


Waveform A = DST04



N	%	D
3	2.50	0
5	1.90	0
7	2.50	0
23	1.90	0
25	1.10	0
31	1.50	0
33	1.10	0

DST04

Waveform A = DST05



N	%	D
3	1.10	0
5	2.80	0
7	1.40	0
9	2.30	0
11	1.50	0

DST05


Waveform A = DST06



N	%	D
3	1.65	0
5	4.20	0
7	3.45	0
15	1.05	0
19	3.00	0

DST06

Waveform A = DST07




N	%	D
3	2.20	0
5	5.60	0
7	2.80	0
9	4.60	0
11	3.00	0
15	1.40	0
21	1.00	0



DST07


Waveform A = DST08



N	%	D
3	4.90	0
5	1.60	0
7	2.70	0
11	1.40	0
15	2.00	0
17	1.10	0

DST08


Waveform A = DST09



N	%	D	N	%	D
3	7.35	0	23	1.20	0
5	2.40	0	25	1.05	0
7	4.05	0			
11	2.10	0			
13	1.05	0			
15	3.00	0			
17	1.65	0			
19	1.05	0			
21	1.05	0			

DST09


Waveform A = DST10



N	%	D	N	%	D
3	9.80	0	21	1.40	0
5	3.20	0	23	1.60	0
7	5.40	0	25	1.40	0
9	1.20	0			
11	2.80	0			
13	1.40	0			
15	4.00	0			
17	2.20	0			
19	1.40	0			

DST10


Waveform A = DST11



N	%	D
3	17.75	0

DST11


Waveform A = DST12



N	%	D
3	21.25	0

DST12

Waveform A = DST13



N	%	D
3	24.50	0

DST13


Waveform A = DST14



<b>N</b>	<b>%</b>	<b>D</b>
2	2.30	0
5	9.80	0
7	15.80	0
8	2.50	0

DST14


Waveform A = DST15



<b>N</b>	<b>%</b>	<b>D</b>
2	1.15	0
5	4.90	0
7	7.90	0
8	1.25	0

DST15


Waveform A = DST16



N	%	D
5	2.45	0
7	3.95	0

DST16


Waveform A = DST17



N	%	D	N	%	D
3	11.11	180	21	0.23	0
5	4.00	0	23	0.19	180
7	2.04	180	25	0.16	0
9	1.23	0	27	0.14	180
11	0.83	180			
13	0.59	0			
15	0.44	180			
17	0.35	0			
19	0.28	180			

DST17


Waveform A = DST18



<b>N</b>	<b>%</b>	<b>D</b>
3	7.17	0
5	3.42	180
9	0.80	0

DST18


Waveform A = DST19



<b>N</b>	<b>%</b>	<b>D</b>
3	8.07	0
5	3.55	180
9	0.96	0
13	0.92	180

DST19


Waveform A = DST20



N	%	D
3	9.38	0
5	3.44	180
9	1.12	0
13	0.50	180

DST20


Waveform A = DST21



N	%	D
3	2.06	180
5	1.77	0
7	1.62	180
9	1.23	0
11	0.91	180
13	0.54	0
23	0.51	0
25	0.53	180

DST21

Waveform A = DST22



N	%	D	N	%	D
3	3.08	180	27	0.69	0
5	2.72	0	29	0.56	180
7	2.43	180			
9	1.97	0			
11	1.41	180			
13	0.86	0			
21	0.62	180			
23	0.73	0			
25	0.77	180			

DST22

Waveform A = DST23



N	%	D	N	%	D
3	4.28	180	23	0.97	0
5	3.77	0	25	1.04	180
7	3.27	180	29	0.75	180
9	2.57	0			
11	1.93	180			
13	1.22	0			
15	0.55	180			
19	0.46	0			
21	0.83	180			

DST23



Waveform A = DST24



N	%	D	N	%	D
3	5.74	180	23	1.28	0
5	5.11	0	25	1.35	180
7	4.44	180	27	1.22	0
9	3.52	0	29	0.98	180
11	2.63	180			
13	1.65	0			
15	0.80	180			
19	0.61	0			
21	1.07	180			

DST24


Waveform A = DST25



N	%	D	N	%	D
3	7.35	180	23	1.64	0
5	6.60	0	25	1.73	180
7	5.74	180	27	1.56	0
9	4.57	0	29	1.24	180
11	3.41	180			
13	2.16	0			
15	1.04	180			
19	0.74	0			
21	1.35	180			

DST25


Waveform A = DST26



<u>N</u>	<u>%</u>	<u>D</u>	<u>N</u>	<u>%</u>	<u>D</u>
5	3.41	0	35	2.34	0
7	2.55	0	37	2.21	0
11	9.22	0			
13	7.68	0			
17	0.90	0			
19	0.90	0			
23	3.88	0			
25	3.56	0			
31	0.50	0			

DST26


Waveform A = DST27



<u>N</u>	<u>%</u>	<u>D</u>
21	1.24	0
23	4.91	0
25	2.21	0

DST27


Waveform A = DST28



N	%	D	N	%	D
3	33.39	0	21	4.52	0
5	20.01	0	23	4.00	0
7	13.76	0	25	3.49	0
9	10.70	0	27	2.91	0
11	8.39	0	29	2.45	0
13	7.06	0	31	1.94	0
15	5.85	0	33	1.95	0
17	4.86	0	35	1.91	0
19	4.86	0	37	1.89	0
			39	1.83	0

DST28


Waveform A = DST29



N	%	D	N	%	D
3	33.39	0	21	4.48	0
5	20.01	0	23	3.93	0
7	13.75	0	25	0.89	0
9	10.70	0	27	0.92	0
11	8.37	0	29	0.94	0
13	7.05	0	31	0.94	0
15	5.84	0	33	0.94	0
17	4.84	0	35	0.93	0
19	4.83	0	37	0.92	0
			39	0.91	0

DST29

Waveform A = DST30



<b>N</b>	<b>%</b>	<b>D</b>
3	33.39	0
5	20.01	0
7	13.75	0
9	10.70	0
11	8.33	0
13	6.99	0
15	5.26	0

DST30

