




880 SERIES

Video Test Generators
& Analyzer

Quick Start Guide



Contents

Model 880 Series Test Generators *Quick Start Guide*


Introduction	3
Video Interface	3
Computer Interface	5
Front Panel Interface	6
Status Indicators	6
Menu Selection Keys	7
Selecting menu items	7
Item selection examples	7
Using the Settings and Options keys	8
Generator Operational Modes	10
Booting up the generator	10
Basic mode	10
Browse mode	11
Video Display Testing Procedures	14
Making physical connections	14
Selecting the device type and interface	16
Selecting video formats	17
Selecting images	19
Web Interface	22
Establishing a Network Environment	22
Working with the Virtual Front Panel	27
Copying files from a PC to a generator	30
Copying files from a generator to a PC	31

Introduction

This Quick Start Guide describes the basic features, functions and operating procedures for the 881 and 882 Quantum Data video test instruments for testing analog and digital video display devices. The 881 provides features for testing video displays in production environments. The 882 is its complement. It provides extended features to test video displays for development environments and quality assurance applications.

Video Interface


This section describes the generator's video interface. The video interface for 881 and 882C is shown below and the table describes each connector.



Interface	Description
1	SDI/HD-SDI connector outputs a serial digital signal per SMPTE 259M and SMPTE 292M standards.
2	CVBS connector outputs an analog composite video baseband signal in accordance with SMPTE 170M standard.
3	S-VIDEO connector outputs an S-Video split luminance (Y) and chrominance (C) analog video signal.
4	SPECIAL connector provides multiple outputs, including: <ul style="list-style-type: none"> - digital composite sync - line sync - frame sync - movable scope trigger (probe) pulse - pixel clock signal
5	VGA OUT connector outputs analog component video or analog RGB signal.
6, 7	HDMI OUT (1/2) connectors output full single link HDMI video, as well as DVI and modern HDMI-compatible digital video signals.
8, 9	HDMI IN (1/2) connectors for input of full single link HDMI video, as well as DVI and modern HDMI-compatible digital video signals.
10	SPDIF-AV connector inputs audio from an external source.

Introduction

The video interface for 882D is shown below and the table describes each connector.




Interface	Description
1	SDI/HD-SDI connector outputs a serial digital signal per SMPTE 259M and SMPTE 292M standards.
2	CVBS connector outputs an analog composite video baseband signal in accordance with SMPTE 170M standard.
3	S-VIDEO connector outputs an S-Video split luminance (Y) and chrominance (C) analog video signal.
4	SPECIAL connector provides multiple outputs, including: <ul style="list-style-type: none"> - digital composite sync - line sync - frame sync - movable scope trigger (probe) pulse - pixel clock signal
5	VGA OUT connector outputs analog component video or analog RGB signal.
6, 7	HDMI OUT (1/2) connectors output full single link HDMI video, as well as DVI and modern HDMI-compatible digital video signals.
8, 9	HDMI IN (1/2) connectors for input of full single link HDMI video, as well as DVI and modern HDMI-compatible digital video signals.
10	SPDIF-AV connector inputs audio from an external source.

Computer Interface

Computer Interface

This section describes the generator's computer interface. The computer interface is shown below and the table describes each connector.




Interface	Description
1	SERIAL connector provides RS-232C serial data communication interface for the generator.
2	DEBUG connector is for Quantum Data use only.
3	ETHERNET connector is used to connect the generator with a TCP/IP network, for remote administration and control, and for sharing resources from a file server.
4	GPIB connector provides IEEE-488 GPIB interface to the generator (882 only; not provided on the 881 generator).

Front Panel Interface


Front Panel Interface

This section describes the front panel interface for operating the generator. The front panel keys are shown below.



Status Indicators


Status indicators provide feedback about the operational status of the generator. The graphic below shows the location of the status indicators.



Selecting Menu Items


Menu Selection Keys

You can access the generator's menus using the menu selection keys depicted below.



Selecting menu items


When you press a menu selection key, a menu appears on the generator's display. Each menu item corresponds to a key located adjacent to the item. These keys are called "soft keys because their functions change depending on the items that appear on the generator's display. For example, for the menu shown below, the soft key at the upper left corresponds to the System item on the generator's display.



Item selection examples

The following examples show the different types of menu items.

Settings and Options Keys



Using the Settings and Options keys

The **Options** key enables you to view or set basic options for the selected item. For items with multiple pages of options, press the **Options** key again to view additional pages. Typically, options are attributes that are either enabled or disabled. For example, the screen below shows the options for a format. On this screen, the asterisk (*) next to DSS means that DSS is selected, the + next to SyncOnG means that this option is enabled, and the - signs next to Pedestal, SyncOnR, and SyncOnB mean that these options are disabled. If you press the soft key adjacent to SyncOnR, the - will change to a +, indicating the option is now enabled.

ACS	SyncOnR-
DCS	SyncOnG+
*DSS	SyncOnB-
-Pedestal	

The **Settings** key enables you to view or set a parameter to a value. For example, the screen below shows the settings for the video signal of a format. To change the value of the XVSI, AVSI, or DVSI setting, press the soft keys next to the arrows on the bottom row of the generator's display until the blinking cursor is on the value you want to change. Increment the value up or down by pressing the + and - keys.

Video Signal	->	
Interface	->	
XVSI	AVSI	DVSI
<- 1	3	0 ->

Generator File System

The generator has a file system that can be stored on multiple media (storage devices or locations). The 880 series generator file system is comprised of two main directories (folders): 1) System and 2) Library. The System folder contains the realtime operating system and firmware file (vxWorks) and the gateway. The Library folder contains the following resource files:

File Type	Description
Fonts	Object files used to define the font types.
Formats	XML files for configuring the source list of formats.
FormatLib	XML files for configuring the source list of formats.
Images	C++ object files, executables, bitmaps and XML files for rendering images.
Sequences	XML files with instructions for test sequences.
Users	XML files for user configuration profiles.
Web	HTML files for the internal web server.

Generator Operational Modes

The generator has two operational modes: 1) Basic mode and 2) Browse mode. The generator boots up in the Basic mode which is the main operating mode you will be using. Both modes are described below along with instructions for booting up the generator.

Booting up the generator

When the generator is powered up it presents a screen enabling you to select the boot device. Selecting a boot device means that you can specify which medium (storage location) the generator loads its operating system and firmware from. If you do not press a key within five seconds the currently specified boot location is used and boot up proceeds. This feature enables you to control where the generator boots from in instances where the default location is either inaccessible or known to have a suspect application file. Follow the procedure below to boot the generator:

To boot the generator:

1. Apply power to the generator. The following display appears.

If you are sure you want to boot from the current storage location you can let the system boot automatically.

```
Quantum Data
windriver
vxworks System Boot
Press any key for setup
```

2. To boot from an alternative device, press any key within five seconds. The following display appears. The following screen appears on the generator's display:

```
!BootDev  !Passwd
!HostName !Flags
!FileName !Other
!InetAddr !TrgtName
```

3. Choose the **!BootDev** item by pressing the adjacent soft key.

```
Network Boot
*Internal Flash
PCMCIA Boot
```

Basic mode


The Basic mode is the main operating mode of the generator. Typically, you will use the Basic mode when testing displays and sources. In Basic mode you can select formats and images, create and run test sequences, view and edit object properties, and so on.

Browse Mode

In the Basic mode you make selections in the front panel with the item selection keys and the soft keys.

Browse mode


Browse mode is for advanced users who want to load objects from different media and program the generator function keys. When in Browse mode, the selection keys shown below are active.



The procedure below describes how to place the generator in Browse mode:

To place the generator in Browse mode:

1. Press and hold the **Tools** key. The message **Hold to enter Browse Mode** appears on the generator's display. Continue holding the Tools key until the Browser status indicator lights. The following menu appears:




In Browse mode, you can view and use objects (resource files such as formats, images and sequences) located in the generator's flash memory, a network file server, the generator's PC card, or the generator's cache memory.

Medium	Description
Flashmem	Non-volatile memory in generator.
NetPlace	File server connected with generator.
PCCard	Compact Flash card in generator.
Cache	Volatile memory in generator. This source contains objects that have been used (loaded into cache) since the generator was started.

Operational Modes

2. Choose the media type that you wish to browse through.

A list of folders on that medium appears on the generator's display as shown below.



3. Choose the folder you want to open by pressing the adjacent soft key. The contents of the folder appears on the generator's display.
4. Continue selecting folders to open until you locate the item you need. To use an item, press the adjacent soft key.

Setting the generator's path


You can configure the generator to access resource files from any media storage location. When you are in Basic mode the generator's **Source** list, **Content** list of Sequence list display items in the folder that the format, image or sequence path parameters are pointing to. However, the path parameter for formats, images and sequences can be changed either through the command line or through the front panel using the Browse mode which is shown below.

Changing the path parameter enables you to configure the generator to access format, image, and sequence files stored on the media location that you specify. For example you can set the format path to the PC card so that when you press the **Source** key in Basic mode you get a list of formats in the PC card's Format folder. You may wish to set the image path to the PC server so that when you press the **Content** key in the Basic mode you access a list of images from the server's Image folder. You can set the format, image or sequence path to any of the media storage locations (i.e. flash memory, PC card, or on a file server).

Note: You can also set the generator's path using the command line interface. For instructions refer to the User's Guide.

To set the generator's path using the front panel:

1. Place the generator in Browse mode by holding down the **Tools** key until the media menu appears on the generator's display as shown below.




2. Choose the desired medium by pressing the adjacent soft key. The folders on the selected medium (for example flash memory) appear on the generator's display as shown below.

Operational Modes



3. Press the soft key adjacent to the Library folder. The contents of the selected folder appears on the generator's display as shown in the example below.



4. Press the soft key adjacent to the folder you want to use. For example, to set the format path, press the soft key adjacent to the Formats folder. The contents of the Formats folder appears on the generator's display.
5. Select a format by pressing the adjacent soft key.

The format path is now set to the selected folder on the selected medium. In this example, when you go back in to Basic mode and you press the **Source** key you will get a list of formats in the Flashmem's Format folder.

Programming the generator's function keys

The generator is equipped with four function keys (F1 through F4) that can be programmed as short-cuts to folders. The procedure below describes how to program the function keys.

To program a function key as a folder short cut:


1. Browse to the folder to which you want to create a short cut.
2. Hold down a function key (F1, F2, F3, or F4) to assign the key to the folder.

Switching from Browse mode to Basic mode

You can switch back to the Basic mode when you are finished browsing for files.

To switch from Browse mode to Basic mode:

1. Press and hold the **Tools** key. The message **Hold to enter Basic Mode** appears on the generator's display. Continue holding the **Tools** key until the Browser status indicator turns off and the Tools menu appears.



Video Display Testing Procedures

This section provides an overview of the video testing process, which involves connecting the generator to the display under test, selecting the interface and format appropriate for the display, and then selecting images to exercise the display to ensure proper functioning.

Making physical connections

Use the following table for the 882C/881 as a guide for connecting the generator to the display under test. First identify the Signal type and determine the Port (Interface). Then select the cable.

Display type		Signal type	Port (Interface)	Cable
Information Technology (IT)	Computer - VESA (DMT,CVT)	Analog Component RGB	VGA OUT	VGA to VGA
	Computer - VESA (DDWG)	Digital Component RGB (DVI)	HDMI OUT	HDMI to DVI
Consumer Equipment (CE)	SDTV - ITU-470-6 baseband	Analog Composite CVBS	CVBS	BNC to RCA 75 Ohms
	SDTV - ITU-470-6 baseband	Analog Composite S-VIDEO	S-VIDEO	S-Video (miniDin)
	SDTV -CEA-861C	Analog Component YPbPr	VGA OUT	VGA to RCA (optional - avail from QDI)
	HDTV -CEA-861C	Digital Component DVI RGB	HDMI OUT	HDMI to DVI
	HDTV -CEA-861C	Digital component HDMI RGB and YCbCr	HDMI OUT	HDMI to HDMI
Professional AV	SDI (SMPTE-259M) and HD-SDI (SMPTE-292M-C)	Digital component YCbCr	SDI/HD-SDI	BNC Coax

Video Display Testing Procedures

Use the following table for the 882D as a guide for connecting the generator to the display under test. First identify the Signal type and determine the Port (Interface). Then select the cable.

Video Display Testing Procedures

Selecting the device type and interface

After making the physical connections, you are ready to select the device type and interface. If you are testing video displays, you will select Display as the device type using the front panel keys.


You can select the interface using either the front panel keys or the command line interface. The interface you specify will depend on the video display type you are testing. It will be one of the following:

Interface	Description
VGA	For testing analog VESA displays and component consumer electronic displays.
CVBS	For testing composite analog consumer electronic displays.
S-Video	For testing composite (separate luma and chroma) analog consumer electronic displays.
HDMI-D	For testing DVI displays through the HDMI interface.
Low DVI	For testing single and dual link DVI displays.
HDMI-H	For testing HDMI consumer electronic displays.
SD/HD-SDI	For testing SDI and HD-SDI professional AV displays.

Once you have selected the display and the interface you can change the parameters specifying the physical size of the display if your application calls for that. You can also gate off the interface output temporarily if necessary. Use the procedures below.

To define the display size:


1. After selecting the interface, press the **Settings** key. The following information appears on the generator's display.



2. Navigate to the other parameters for physical size (VSIZ and USIZ) to set the display size for your test application.

To gate off the interface:

1. After selecting the interface, press the **Options** key. The following information appears on the generator's display.



2. Enable or disable the interface output by pressing the adjacent soft key.

Selecting Video Formats

Selecting video formats

When you have selected the interface you next need to specify the format. A format defines a set of video, timing, and sync parameters for a specific device or standard. This section explains how to configure the generator to output video formats that are supported by the device being tested.


Note: For more information about formats, see the 881/882 User's Guide.

Selecting formats automatically

When testing EDID-compatible displays, the generator can automatically update the Source list to include only formats supported by the display under test.

To update the Source list automatically:

1. Connect the generator to the display you want to test.
2. Press the **Sink** key.
3. Press the **Options** key. The following information appears on the generator's display.



```
-Read EDID      CDF
+HP Bypass
```


4. Choose the **Read EDID** item by pressing the adjacent soft key. A + appears next to Read EDID, indicating it is enabled.

The generator loads the Source list with formats supported by the connected display (hot-plug formats read via EDID structure of attached display).

Note: To disable hot plug formats press the soft key adjacent to Read EDID. A - next to Read EDID indicates it is disabled.

To bypass hot plug formats:

1. Connect the generator to the display you want to test.
2. Press the **Sink** key.
3. Press the **Options** key. The following information appears on the generator's display.



```
-Read EDID      CDF
+HP Bypass
```

Selecting Video Formats

4. Choose the **HP Bypass** item by pressing the adjacent soft key. A + appears next to Read EDID, indicating it is enabled.
5. Disable hot plug (enable hot plug bypass) by pressing the adjacent soft key until a '-' (minus sign) is displayed indicating disabled.

Selecting formats manually

When testing a display that is not EDID-compliant, you must manually choose formats that are supported by the display. Note that once you select an interface the source list of formats will be filtered to only those that are suitable for a particular video interface. For example if you select CVBS as the interface the source list of formats will not include the VESA formats.

The generator has a library of standard formats. For a description of how the library is organized, see the 881/882 User's Guide.

Once you have selected a format you can modify the format options and settings if necessary. For instructions on this refer to the User's Guide.

To select a format:

1. Identify the type of display (composite television, component standard definition television, component high definition television, computer equipment, or other specialty display).

Check the specifications of your display for supported formats.

2. Press the **Source** key to access the list of formats. A list of formats appear on the generator's display as shown below. To see all of the formats, press the + and - keys.

*DMT0660	DMT0672
DMT0675	DMT0685
DMT0785H	DMT0856
DMT0860	DMT0872

The list of formats that appears when you press the **Source** key may be a filtered or abbreviated list. Formats not suitable for the selected interface type will not appear by default on the Source list.

The list of formats that appear when you press the **Source** key will be the formats in the Format folder of the media storage location that you have set the format path parameter to using either the Browse mode or command line (FMTP parameter).

3. Choose a format by pressing the adjacent soft key.

Selecting Images

Selecting images

Once you have determined the format or formats appropriate for testing the display, you will apply a series of images suitable for evaluating the display. Of primary importance is determining what type of display you are testing (for example, CRT or digital flat panel display). You must also determine if you are testing composite TV and use images appropriate for these formats and video types.

Each image in the generator's library is intended to test one or more attributes of a particular display type and video type.

Displaying images

Use the following procedures to view primary images. Once you have selected an image you can modify the image options if necessary.

To select an image:

1. Identify the type of display (CRT or FPD) and the images that are used for testing this type of display (see the table below).
2. Press the **Content** key. A list of images appears on the generator's display as shown below. Press the + and - keys to see all of the images.

Acer1	Acer2
Acer3	Acer4
Acer5	Acer6
Acer7	Acer8

The list of images that appear when you press the **Content** key will be the images in the Image folder of the media storage location that you have set the image path parameter to using the Browse mode or the command line (IMGP parameter).

3. Choose an image by pressing the adjacent soft key.

The table below provides a summary of analog CRT display characteristics and the images used to evaluate them. For details on the images and display attributes, see Appendix B, "Image Reference" of the User's Guide.

Displaying Images

Display type	Display characteristic	Image
Analog CRT	Geometry (pin and barrel, linearity)	Static images: Hatch (TVHatch, Hatch16,20) CirclesL, Geom_1 - Geom-5, SMPTE133.
	Focus	Focus and Text images.
	Photometry (chrominance, levels)	Flat, Ramp, ColorBar, SMPTEBar, TVBar.
	Luminance	SMPTE133 Grays(5,9,11,16,32,64).
	Gamma correction	SMPTE133 (checkbox).
	Resolution	BurstTCE, Burst(TV formats only), Grill(11,15,22,33,44).
	Pulse (CE SDTV)	PulseBar.
	Centering	Outline(0,1,2,3).
	Voltage Regulation	Regulate.
	Electromagnetic Interference	EMITest(1,2,3,4,5).

The table below provides a summary of digital FPD display characteristics and the images used to evaluate them. For details on the images and display attributes, see Appendix B, "Image Reference" of the User's Guide.

Display type	Display characteristic	Images
Digital Flat Panel (fixed pixel displays)	Pixel anomalies (stuck pixels, miss sampling)	Flat, Raster, Ramp, Focus Text.
	Photometry (chrominance, levels)	Flat, Flatgray, Ramp, ColorBar, SMPTEBar, SMPTE133.
	Luminance	SMPTE133(grayscale), Grays(5,9,11,16,32,64).
	Resolution	BurstTCE, Grill(11,15,22,33,44).
	Centering	Outline(0,1,2,3).
	Persistence	Animated images: Persist, Cubes, SlideX.

Displaying Image Versions

Displaying image versions

Many images have secondary or alternate versions and some images have many versions. Use the procedures below to view the alternate and multiple image versions.

To view alternate image versions in the Content list:

1. Select an image by pressing the **Contents** key.
2. Enable and view image versions as follows:

Press the **Options** key. The following menu will appear on the generator's display for images with a single secondary image:

```
-Alternate          Red+
-NoGamma           Green+
-Noise             Blue+
```

3. Choose the **Alternate** item by pressing the adjacent soft key until a + appears next to the item.

```
+Alternate          Red+
-NoGamma           Green+
-Noise             Blue+
```

4. Toggle back and forth between the images using the adjacent soft key.

To view multiple image versions in the Content list:

1. Select an image by pressing the **Contents** key.
2. Enable and view image versions as follows:

Press the **Options** key. The following menu appears on the generator's display:

```
-More              Red+
-NoGamma           Green+
-Noise             Blue+
```

3. Choose the **More** item by pressing the adjacent soft key until a + and Rendition appears next to the item.

```
+More Rendition: 000 Red+
-NoGamma           Green+
-Noise             Blue+
```

4. Press the + and - keys to advance through the image versions. Each version shows the format parameters for a different format in the **Source** list.

Web Interface

The generator has a built-in Web server that enables you to interact with the generator using a PC and an Ethernet connection. The Web interface includes the following functions:


- Virtual Front Panel for operating the generator remotely.
- Generator FTP Browser for copying files between media within the generator, between generators, and between a generator and a PC.
- Format Editor for creating formats and modifying and viewing format parameters. For more information about the Format Editor, Refer to the User's Guide for instructions on using the Format Editor.
- CMD Terminal for operating the generator using the command line interface.
- Calibration reports (Currently not available)

This section describes how to operate the Virtual Front Panel and the Generator FTP Browser.

Establishing a Network Environment

To utilize the Web interface features you have to create a network environment for your generators. You must physically connect the generators to the network, and then configure their IP addresses and the IP address of the file server (which must be different). Procedures for these tasks are described in this section.


In a typical networked environment, you will connect the generators to the corporate, IP-based Ethernet LAN. In this scenario, you connect a standard Ethernet patch cable between the Ethernet port on the generator and a LAN access jack or to a local hub. The file server is also connected to the LAN in the same manner.



Establishing a Network Environment

Another type of network scenario is to directly connect a single generator to a file server. For a direct connection, you must use a crossover Ethernet cable and connect it from the Ethernet port on the file server to the generator Ethernet port as shown below.

Note: If you are using a PC that is connected to a network that automatically assigns an IP address, and you will be disconnecting from that network to connect to the crossover cable and generator, you must manually enter an IP address into the PC so it can communicate with the generator. The network portions of the IP addresses of the generator and the PC must match; the host portions must be different.




When the network connection on the generator is active, the **Network** LED lights on the front panel.

Setting the generator's IP address


Each generator on the network must have a unique IP address if you want to control the generator over a network, or want the generator to share resources located on a file server. Typically, your site's LAN administrator will provide you with IP addresses for each generator. Depending on how your site's LAN is configured, your LAN administrator may also provide you with a subnet mask.

To set the IP address of the generator:

1. Press the **Tools** key. The Tools menu appears on the generator's display as shown below.



2. Choose the **System** item by pressing the adjacent soft key. The System menu appears on the generator's display as shown below.



3. Choose the **Network** item by pressing the adjacent soft key. The generator's IP address and subnet mask appear on the generator's display as shown below.

Setting the Generator's IP Address

```
IP Address
206.135.215.168
Subnet Mask
000.000.000.000
```

4. Press the **Settings** key. The Network Connection screen appears on the generator's display as shown below.

```
Network Connection
Set TCP/IP →
IP Address →
← 206.135.215.168
```

Note: If the IP Address configuration option is not visible, press the soft key adjacent to the arrow symbol by SubnetMask until IP Address appears.

5. Change the IP address as follows:
 - a. Position the blinking cursor on the address digit you want to change. To do this, press the soft key adjacent to the arrow by the address to move the cursor left or right until it appears on the digit you want to change.
 - b. Adjust the value of the digit up or down by pressing the + or - keys. Repeat for each IP address digit you want to change.
6. If necessary, change the subnet mask as follows:
 - a. If the SubnetMask configuration option is not visible, press the soft key adjacent to the arrow symbol by IP Address until SubnetMask appears.
 - b. Position the blinking cursor on the subnet mask digit you want to change. To do this, press the soft key adjacent to the arrow by the subnet mask to move the cursor left or right until it appears on the digit you want to change.
 - c. Adjust the value of the digit up or down by pressing the + or - keys. Repeat for each subnet mask digit you want to change.

```
Network Connection
Set TCP/IP →
← SubnetMask
← 000.000.000.000
```

7. To save the changes, press the **Enter (Options)** key. The following choices appear on the generator's display:

```
Apply Settings?
Back
Yes No
```

Setting the Server's IP Address

To save the changes, choose the **Yes** item by pressing the adjacent soft key.

To exit without saving the changes, choose the **No** item.

To return to the Network Connection screen without saving the changes, choose the **Back** item.


8. Reboot the generator to enable the IP address change.

Setting the server's IP address in the generator


You must enter the IP address of the file server in each generator so the generator can communicate with the file server. In addition, you can also enter a name (called the Server Name) for the file server.

To specify the IP address and host name of the file server:


1. Press the **Tools** key. The Tools menu appears on the generator's display as shown below.




2. Choose the **System** item by pressing the adjacent soft key. The System menu appears on the generator's display as shown below.



3. Choose the **Server** item by pressing the adjacent soft key. The host name and IP address appear on the generator's display.



4. Press the **Settings** key. The Network Server (Server IP address) screen appears on the generator's display as shown below.



If the Server Address (IP address) configuration option is not visible, press the soft key adjacent to the arrow symbol by Server Name until Server Address (IP address) appears.

Setting the Server's IP Address

5. Change the Server address as follows:
 - a. Position the blinking cursor on the address digit you want to change. To do this, press the soft key adjacent to the arrow by the address to move the cursor left or right until it appears on the digit you want to change.
 - b. Adjust the value of the digit up or down by pressing the + or - keys. Repeat for each address digit you want to change.
6. (Optional) Change the Server name as follows:
 - a. If the Server Name configuration option is not visible, press the soft key adjacent to the arrow symbol by Server IP Address until Server Name appears.
 - b. Position the blinking cursor on the character you want to change. To do this, press the soft key adjacent to the arrow by the name to move the cursor left or right until it appears on the character you want to change.
 - c. Select the desired character by pressing the + or - keys to scroll through upper-case letters, lowercase letters, and numbers. Repeat for each character you want to change.

```
Server IP Address
206.135.215.218
Server Name
Host01
```

7. To save the changes, press the **Enter (Options)** key. The following choices appear on the generator's display:

```
Apply Settings?
Back
Yes           No
```

To save the changes, choose the **Yes** item by pressing the adjacent soft key.

To exit without saving the changes, choose the **No** item.

To return to the Network Server screen without saving the changes, choose the **Back** item.

Virtual Front Panel

Working with the Virtual Front Panel


The Virtual Front Panel enables you to perform remotely the same tasks as you would with the generator's front panel. To use the Virtual Front Panel, you must have a PC connected to a generator either through an Ethernet LAN or locally through an Ethernet crossover cable connected between the Ethernet ports on the generator and the PC. These configurations are described in more detail in the User's Guide. You must also have the Java Runtime Environment (JRE) 1.4.2 or later installed on your PC. You can download the JRE from <http://java.sun.com/j2se/1.4.2/download.html>.

To use the Virtual Front Panel, you must know the IP address of the generator and configure it with an IP address that is compatible with the IP address of your PC.


The following procedures describe how to access the Virtual Front Panel using a Web browser.

To determine the IP address of the generator:

1. Press the **Tools** key. The Tools menu appears on the generator's display as shown.



2. Choose the **System** item by pressing the adjacent soft key. The System menu appears on the generator's display as shown below.




Virtual Front Panel

To use the Virtual Front Panel:

1. Open a Web browser (such as Internet Explorer) and type the generator's IP address in the address entry field.


The generator home page appears in the browser.



You can add the page to your list of favorite pages in your Web browser to avoid retyping the IP address each time you want to access the page.

Virtual Front Panel

2. Click the **Virtual Front Panel** link. The Virtual Front Panel appears.



3. Use your mouse to click the virtual keys, which function the same as if you pressed the physical keys on the generator.

FTP Browser


If you create objects on a PC, such as images or formats, you can use the Generator FTP Browser to copy these objects to a generator. You can also use the Generator FTP Browser to copy objects between media in a generator and to copy objects from one generator to another.

Copying files from a PC to a generator

You can copy files from the PC to the generator when you are upgrading the generators with new system or library files.

To copy files from a PC to a generator:

1. Open a Web browser (such as Internet Explorer) and type the generator's IP address in the address entry field.
The generator home page appears in the browser.
2. Choose the **FTP Browser** menu item. The Generator FTP Browser appears. The Instrument Files area shows the files stored on the generator. The Host Files area shows the files stored on the PC.



Copying Files with the Generator FTP Browser

3. In the **Host Files** area, locate and select the file or folder you want to copy.
4. In the **Instrument Files** area, locate the destination folder for the file as follows:
In the **Look in** box, click the down arrow and select the storage medium where you want to copy the file. Select **tffs0** for the generator's flash memory or **card0** for the generator's PC card.
In the list of files, open the destination folder.
5. In the **Host Files** area, click **Download**. The **Transfer Files** dialog box appears.
Verify that the source file or folder and the destination folder are correct, and then click **OK**.
The **Copying Files** dialog box appears showing the status of the operation. When the status is 100%, click **Done**.


Copying files from a generator to a PC

You can copy files from a generator back to your PC. This is useful if you need to save custom formats or images saved only in a generator's local memory.

To copy files from a generator to a PC:

1. Choose the **FTP Browser** menu item. The Generator FTP Browser appears. The Instrument Files area shows the files stored on the generator. The Host Files area shows the files stored on the PC.

Copying Files from the Generator to a PC



3. In the **Instrument Files** area, locate and select the file or folder you want to copy as follows.
4. In the **Look in** box, click the down arrow and select the medium where the file is located. Select **tffs0** for the generator's flash memory or **card0** for the generator's PC card.
5. In the list of files, select the file or folder you want to copy.
6. In the **Host Files** area, open the destination folder where you want to copy the files.
7. In the **Instrument Files** area, click **Upload**. The **Transfer Files** dialog box appears.

Verify that the source file or folder and the destination folder are correct, and then click **OK**.

The **Copying Files** dialog box appears showing the status of the operation. When the status is 100%, click **Done**.

881 and 882

The following hardware configurations are covered:

- GPIB Communications Port
- Ethernet Communications Port
- Serial Communications Port
- NTSC/PAL TV Outputs (CVBS and S-Video)
- VGA Analog Video Outputs
- Dual link DVI Digital Video Outputs
- Single Link HDMI/DVI Digital Video Outputs
- SDI/HD-SDI Output (Serial Digital Interface/High Definition) (optional interface)
- HDMI/DVI Analyzer

Information based on the following generator firmware versions:

881/882C (A) 882D Version 2.4

**Entire contents
Copyright ©2006
by Quantum Data, Inc.
All rights reserved.**

The information contained in this document is provided for use by our customers and may not be incorporated into other products or publications without the expressed written consent of Quantum Data. Information furnished by Quantum Data is believed to be accurate and reliable. However, no responsibility is assumed by Quantum Data for its use.

Quantum Data reserves the right to make changes at any time and without notice to its products to improve performance, reliability, manufacturing methods, and (or) marketability.

"Model 802 Series Quick Start Guide"
Part # **68-00203 Rev. C**
(20 - June- 2006)



**Quantum Data, Inc.
2111 Big Timber Rd.
Elgin, IL 60123-1100
U.S.A.**

Internet Connections

World Wide Web Site:
<http://www.quantumdata.com>

Sales E-mail:
sales@quantumdata.com

Customer Service E-mail:
service@quantumdata.com

Technical Support E-mail:
support@quantumdata.com

The information contained in this document is provided for use by our customers and may not be incorporated into other products or publications without the expressed written consent of Quantum Data. Information furnished by Quantum Data is believed to be accurate and reliable. However, no responsibility is assumed by Quantum Data for its use.

Quantum Data reserves the right to make changes at any time and without notice to its products to improve performance, reliability, manufacturing methods, and (or) marketability.

Entire contents Copyright ©2006 by Quantum Data, Inc.
All rights reserved.

881, 882 and 882D

The following hardware configurations are covered:

- GPIB Communications Port
- Ethernet Communications Port
- Serial Communications Port
- NTSC/PAL TV Outputs (CVBS and S-Video)
- VGA Analog Video Outputs
- Single Link HDMI/DVI Digital Video Outputs
- SDI/HD-SDI Output (Serial Digital Interface/High Definition) (optional interface)
- HDMI/DVI Analyzer

Information based on the following generator firmware versions:
881/882/882D: Version 2.4

To learn more about Quantum Data products, visit us at www.quantumdata.com



2111 Big Timber Road, Elgin, IL 60123-1100
Phone: (847)888-0450 • Fax: (847)888-2802
sales@quantumdata.com
www.quantumdata.com

68-00203

