

1260 VXI SWITCHING CARD

1260-132 HIGH VOLTAGE PLUG-IN

PUBLICATION NO. 980824-132

RACAL INSTRUMENTS

Racal Instruments, Inc.

4 Goodyear St., Irvine, CA 92618-2002
Tel: (800) RACAL-ATE, (800) 722-2528, (949) 859-8999; FAX: (949) 859-7139

Racal Instruments, Ltd.

480 Bath Road, Slough, Berkshire, SL1 6BE, United Kingdom
Tel: +44 (0) 1628 604455; FAX: +44 (0) 1628 662017

Racal Systems Electronique S.A.

18 Avenue Dutartre, 78150 LeChesnay, France
Tel: +33 (1) 3923 2222; FAX: +33 (1) 3923 2225

Racal Systems Elettronica s.r.l.

Strada 2-Palazzo C4, 20090 Milanofiori Assago, Milan, Italy
Tel: +39 (0)2 5750 1796; FAX +39 (0)2 5750 1828

Racal Elektronik System GmbH.

Technologiepark Bergisch Gladbach, Friedrich-Ebert-Strasse, D-51429 Bergisch Gladbach, Germany
Tel.: +49 2204 8442 00; FAX: +49 2204 8442 19

Racal Instruments, Ltd.

Unit 5, 25F., Mega Trade Center, No 1, Mei Wan Road, Tsuen Wan, Hong Kong, PRC
Tel: +852 2405 5500, FAX: +852 2416 4335

<http://www.racalstruments.com>



PUBLICATION DATE: Aug., 30, 2002

Copyright 2002 by Racal Instruments, Inc. Printed in the United States of America. All rights reserved.
This book or parts thereof may not be reproduced in any form without written permission of the publisher.

THANK YOU FOR PURCHASING THIS RACAL INSTRUMENTS PRODUCT.

For this product, or any other Racal Instruments product that incorporates software drivers, you may access our web site to verify and/or download the latest driver versions. The web address for driver downloads is:

<http://www.racalinstruments.com/downloads>

You will be asked to register one time only to gain access to the driver and product manual downloads sections. At registration a cookie will be placed on your computer if you choose to accept it. This is done to facilitate your use of these sections on future visits. You may refuse to accept the cookie and still have complete access to the software driver database but will have to re-register every time you visit. This cookie is for ease of use only and no information is gathered for, sold, or reported to, any third party organization.

If you have any questions about software driver downloads or our privacy policy, please contact us at info@racalinstruments.com.

WARRANTY STATEMENT

All Racal Instruments, Inc. products are designed and manufactured to exacting standards and in full conformance to Racal's ISO 9001 procedures.

This warranty does not apply to defects resulting from any modification(s) of any product or part without Racal's express written consent, or misuse of any product or part. The warranty also does not apply to fuses, software, non-rechargeable batteries, damage from battery leakage, or problems arising from normal wear, such as mechanical relay life, or failure to follow instructions.

This warranty is in lieu of all other warranties, expressed or implied, including any implied warranty of merchantability or fitness for a particular use. The remedies provided herein are buyer's sole and exclusive remedies.

For the specific terms of your standard warranty, or optional extended warranty or service agreement, contact your Racal customer service advisor. Please have the following information available to facilitate service.

1. Product serial number
2. Product model number
3. Your company and contact information

You may contact your customer service advisor by:

E-Mail: Helpdesk@racalinstruments.com

| | | |
|------------|--------------------|-------------|
| Telephone: | +1 800 722 3262 | (USA) |
| | +44(0) 8706 080134 | (UK) |
| | +852 2405 5500 | (Hong Kong) |
| Fax: | +1 949 859 7309 | (USA) |
| | +44(0) 1628 662017 | (UK) |
| | +852 2416 4335 | (Hong Kong) |

RETURN of PRODUCT

Authorization is required from Racal Instruments before you send us your product for service or calibration. Call your nearest Racal Instruments support facility. A list is located on the last page of this manual. If you are unsure where to call, contact Racal Instruments, Inc. Customer Support Department in Irvine, California, USA at 1-800-722-3262 or 1-949-859-8999 or via fax at 1-949-859-7139. We can be reached at: helpdesk@racalinstruments.com.

PROPRIETARY NOTICE

This document and the technical data herein disclosed, are proprietary to Racal Instruments, and shall not, without express written permission of Racal Instruments, be used, in whole or in part to solicit quotations from a competitive source or used for manufacture by anyone other than Racal Instruments. The information herein has been developed at private expense, and may only be used for operation and maintenance reference purposes or for purposes of engineering evaluation and incorporation into technical specifications and other documents which specify procurement of products from Racal Instruments.

DISCLAIMER

Buyer acknowledges and agrees that it is responsible for the operation of the goods purchased and should ensure that they are used properly and in accordance with this handbook and any other instructions provided by Seller. RII products are not specifically designed, manufactured or intended to be used as parts, assemblies or components in planning, construction, maintenance or operation of a nuclear facility, or in life support or safety critical applications in which the failure of the RII product could create a situation where personal injury or death could occur. Should Buyer purchase RII product for such unintended application, Buyer shall indemnify and hold RII, its officers, employees, subsidiaries, affiliates and distributors harmless against all claims arising out of a claim for personal injury or death associated with such unintended use.

FOR YOUR SAFETY

Before undertaking any troubleshooting, maintenance or exploratory procedure, read carefully the **WARNINGS** and **CAUTION** notices.

This equipment contains voltage hazardous to human life and safety, and is capable of inflicting personal injury.

If this instrument is to be powered from the AC line (mains) through an autotransformer, ensure the common connector is connected to the neutral (earth pole) of the power supply.

Before operating the unit, ensure the conductor (green wire) is connected to the ground (earth) conductor of the power outlet. Do not use a two-conductor extension cord or a three-prong/two-prong adapter. This will defeat the protective feature of the third conductor in the power cord.

Maintenance and calibration procedures sometimes call for operation of the unit with power applied and protective covers removed. Read the procedures and heed warnings to avoid “live” circuit points.

Before operating this instrument:

1. Ensure the instrument is configured to operate on the voltage at the power source. See Installation Section.
2. Ensure the proper fuse is in place for the power source to operate.
3. Ensure all other devices connected to or in proximity to this instrument are properly grounded or connected to the protective third-wire earth ground.

If the instrument:

- fails to operate satisfactorily
- shows visible damage
- has been stored under unfavorable conditions
- has sustained stress

Do not operate until performance is checked by qualified personnel.

Racal Instruments

EC Declaration of Conformity

We

Racal Instruments Inc.
4 Goodyear Street
Irvine, CA 92718

declare under sole responsibility that the

1260-132, 1x23 Two Wire HV Multiplexer Module, P/N 407822

They conform to the following Product Specifications:

Safety: EN61010-1:1993+A2:1995

EMC: EN61326:1997+A1:1998

Supplementary Information:

The above specifications are met when the product is installed in a Racal Instruments certified mainframe with faceplates installed over all unused slots, as applicable

The product herewith complies with the requirements of the Low Voltage Directive 73/23/EEC and the EMC Directive 89/336/EEC (modified by 93/68/EEC).

Irvine, CA, August 5, 2002


Engineering Director

Table of Contents

| | |
|--|-----|
| Chapter 1 | 1-1 |
| Introduction..... | 1-1 |
| SPECIFICATIONS | 1-1 |
| Specifications | 1-2 |
| Power Dissipation | 1-3 |
| About MTBF..... | 1-4 |
| Ordering Information | 1-5 |
| Chapter 2 | 2-1 |
| INSTALLATION INSTRUCTIONS | 2-1 |
| Unpacking and Inspection | 2-1 |
| Reshipment Instructions | 2-2 |
| Installation..... | 2-2 |
| Module Configurations..... | 2-3 |
| Front Panel Connectors | 2-3 |
| Mating Connectors..... | 2-6 |
| Chapter 3 | 3-1 |
| MODULE OPERATION | 3-1 |
| Setting the Module Address | 3-1 |
| 1256 Operation..... | 3-1 |
| VXI Operating Modes..... | 3-1 |
| Operating In VXI Message-Based Mode | 3-3 |
| Channel Descriptors For The 1260-132..... | 3-3 |
| Power Up Relay Default State..... | 3-4 |
| Reply To The MOD:LIST? Command..... | 3-5 |
| Operating in VXI Register-Based Mode | 3-5 |
| 1260-132 Example Code..... | 3-8 |
| Chapter 4 | 4-1 |
| OPTIONAL ASSEMBLIES | 4-1 |
| Chapter 5 | 5-1 |
| PRODUCT SUPPORT | 5-1 |

Product Support..... 5-1
Reshipment Instructions 5-1
Support Offices 5-2
Repair and Calibration Request Form..... 5-23

List of Figures

| | |
|---|-----|
| Figure 2-1, Front-Panel Connector Pin Numbering..... | 2-3 |
| Table 2-1, 1260-132 Front-Panel Connections | 2-4 |
| Figure 2-2 Relay Diagram..... | 2-5 |
| Figure 2-3, Block Diagram | 2-6 |
| Figure 3-1, Message-Based Mode of Operation..... | 3-2 |
| Figure 3-2, Register-Based Mode of Operation..... | 3-2 |
| Table 3-1, Control Register Channel Assignments | 3-6 |

List of Tables

| | |
|---|-----|
| Table 2-1, 1260-132 Front-Panel Connections | 2-4 |
| Table 3-1, Control Register Channel Assignments | 3-6 |


This page was left intentionally blank.

Chapter 1

Introduction

The 1260-132 is a plug-in switch module developed for the Racal Instruments 1260-100 Adapt-a-Switch Carrier and the 1256 Switch Controller. The 1260-132 includes the following features:

- Standard plug-in design, providing for ease of replacement.
- Data-Driven embedded descriptor, allowing immediate use with any Option-01T or 1256 switch controller, regardless of firmware revision level.
- 1x23 Isolated Two Wire High-Voltage Multiplexer.



SPECIFICATIONS

Specifications

| | | |
|---------------------------|--|-------------------------------------|
| Maximum Switching Voltage | | |
| AC | | 1000 VAC pk-pk |
| DC | | 1000 VDC |
| Switching Current | | |
| AC | | 2.0 AACrms |
| DC | | 2.0 A |
| Switching Power | | |
| AC | | 60 VA |
| DC | | 60 W |
| Minimum Breakdown | | ≥ 1.5 KV |
| Initial Path resistance | | $\leq .5$ Ω |
| Insulation resistance | | $\geq 10^9$ Ω |
| Thermal EMF | | ≤ 40 μ V |
| Bandwidth (-3dB) | | ≥ 5 MHz |
| Insertion Loss | | |
| 1 MHz | | ≤ 0.2 dB |
| 5 MHz | | < 0.5 dB |
| Isolation | | |
| 1 MHz | | ≥ 60 dB |
| 10 MHz | | ≥ 30 dB |
| Capacitance | | |
| Channel-Ground | | ≤ 150 pF |
| Open-Channel | | ≤ 10 pF |
| Relay Settling Time | | ≤ 2 ms |
| Shock | | 30g, 11 ms, $\frac{1}{2}$ sine wave |

| | |
|--------------------|--|
| Vibration | 0.013 in. P _k -P _k , 5-55 Hz |
| Bench Handling | 4 in., 45° |
| Cooling | See 1260-100 or 1256 cooling data |
| Temperature | |
| Operating | 0°C to +55°C |
| Non-operating | -40°C to +75°C |
| Relative Humidity | 85% ± 5% non-condensing at ≤ 35°C |
| Altitude | |
| Operating | 10,000 feet |
| Non-operating | 15,000 feet |
| Power Requirements | |
| +5 VDC | ≤ 1.5 amps max |
| Weight | 14.75 oz. (0.42 kg) |
| MTBF | ≥ 300,000 hours (MIL-HDBK-217E) |
| Dimensions | 4.5"H X 0.75"W X 9.5"D |

Power Dissipation

While the cooling of the Adapt-a-Switch carrier is dependent upon the chassis into which it is installed, the carrier can normally dissipate approximately 100 W. Care must be taken, then, in the selection and loading of the plug-in modules used in the carrier. It is not possible to fully load the carrier, energize every relay, and run full power through every set of contacts, all at the same time. In practice this situation would never occur.

To properly evaluate the power dissipation of the plug-in modules, examine the path resistance, the current passing through the relay contacts, the ambient temperature, and the number of relays closed at any one time.

For example, if a 1260-132 module typically has two relays closed, passing a current of 2.0A, then:

$$\text{Total power dissipation} = [(\text{current})^2 * (\text{path resistance}) * 2] + (\text{quiescent power})$$

By substituting the actual values:

$$\text{Total power dissipation} = [(2.0 \text{ A})^2 * (0.5 \Omega) * 2] + (8.0 \text{ W}) = 12 \text{ W at } 55^\circ\text{C}$$

This is acceptable power dissipation for an individual plug-in module. If five additional modules are likewise loaded, then the overall carrier dissipation is approximately 70 W, which is well within the cooling available in any commercial VXIbus chassis or the 1256 Switching System. In practice, rarely are more than two relays energized simultaneously, and rarely is full rated current run through every path. In addition, the actual contact resistance is typically one-half to one-fourth the specified maximum, and temperatures are normally not at the rated maximum. The power dissipated by each plug-in should be no more than 15 W if all six slots are used simultaneously. Consult the Power Dissipation Section of any other 1260 Adapt-a-Switch card manuals for additional information.

Most users of a signal-type switch, such as the 1260-132, switch no more than a few hundred milliamperes and are able to energize all relays simultaneously, should they so desire.

Additionally, if fewer plug-in modules are used, more power may be dissipated by the remaining cards. By using a chassis with high cooling capacity, such as the Racal Instruments 1261B, almost any configuration may be realized.

About MTBF

The 1260-132 MTBF is >300,000 hours, calculated in accordance with MIL-HDBK-217E. Relays are included in this calculation but be aware that relay life is strongly dependent upon operating conditions. Factors affecting relay life expectancy are:

1. Switched voltage
2. Switched current
3. Switched power
4. Maximum switching capacity
5. Maximum rated carrying current
6. Load type (resistive, inductive, capacitive)
7. Switching repetition rate
8. Ambient temperature

The most important factor is the maximum switching capacity, which is an interrelationship of maximum switching power, maximum switching voltage and maximum switching current. When a relay operates at a lower percentage of its maximum switching capacity, its life expectancy is longer. The maximum

switching capacity specification is based on a resistive load, and must be further de-rated for inductive and capacitive loads.

For more details about the above life expectancy factors, refer to the data sheet for the switch plug-in module.

The relays used on the 1260-132 plug-in are Racal P/N 310303. The manufacturer's specifications for this relay are:

| | |
|-----------------|---|
| Life Expectancy | |
| Mechanical | 100,000,000 operations |
| Electrical | 1,000,000 operations at full rated load (resistive) |

For additional relay specifications, refer to the relay manufacturer's data sheet.

Ordering Information


Listed below are part numbers for the 1260-132 switch module and available mating connector accessories. Each 1260-132 uses a single 48 pin mating connector.

| ITEM | DESCRIPTION | PART # |
|----------------------|--|------------|
| 1260-132 | 1x23 Two Wire HV Mux Module | 407822 |
| Mating Connector Kit | 48 Pin Connector Housing / Strain Relief | 407664-001 |
| Spare Connector Pins | Crimp Connector Pins | 602258-900 |
| Additional Manual | 1260-132 Users Manual | 980824-132 |

This page was left intentionally left blank.

INSTALLATION INSTRUCTIONS

Unpacking and Inspection



1. Before unpacking the switching module, check the exterior of the shipping carton for any signs of damage. All irregularities should be noted on the shipping bill and reported.

CAUTION

ESD sensitive devices, open the instrument at an ESD safe work station.

WARNING

The 1260-132 card is a high-voltage switch card. This card if improperly used could expose the user to potentially lethal voltages. Make absolutely sure, that all external high-voltage sources are off and locked-out prior to inserting, removing, or servicing this card in the chassis. The card retention screws should be tightened to the chassis and all chassis grounds should be verified with a ohmmeter prior to the first use. Failure to observe these precautions could result in either death or serious injury.

WARNING

Extreme care must be exercised when high-voltage / high-current power sources are used. Make sure that adequate external fault protection exists between these sources and the 1260-132. Failure to observe this precaution could result in fire or serious damage to both the 1260-132 and chassis.

WARNING

The 1260-132 module should be periodically inspected for dust accumulation and removed as necessary to prevent internal arcing within the module.

CAUTION

With reactive loads the 1260-132 module should be switched with the high-voltage removed to eliminate the possibility of contact welding.

2. Remove the instrument from its carton, preserving the factory packaging as much as possible.
3. Inspect the switching module for any defects or damage. Immediately notify the carrier if any damage is apparent.
4. Have a qualified person check the instrument for safety before use.

Reshipment Instructions

1. Use the original packing material when returning the switching module to Racal Instruments for servicing. The original shipping carton and the instrument's plastic foam will provide the necessary support for safe reshipment.
2. If the original packing material is unavailable, wrap the switching module in an ESD Shielding bag and use plastic spray foam to surround and protect the instrument.
3. Reship in either the original or a new shipping carton.

Installation

Installation of the 1260-132 Switching Module into a 1260-100 Carrier assembly is described in the Installation section of the 1260-100 Adapt-a-Switch Carrier Manual and the 1256 Switch System Manual.

Module Configurations

The 1260-132 is a 1 x 23, two wire, high voltage reed switch multiplexer module. The 1260-132 uses an isolation relay to disconnect the 1x23 multiplexer when cascading multiple 1260-132 modules to build larger multiplexers. This additional relay reduces the capacitance and increases the insulation resistance for large multiplexer configurations.

Front Panel Connectors

The 1260-132 has a 48-pin front-panel connector, labeled J200. It is a 48-pin, DIN style. See **Figure 2-1** for pin numbering. **Table 2-1** shows the mapping of channel numbers to connector pins. Information about available mating connectors is provided immediately after **Table 2-1**. See **Figure 2-2** for a detail of the actual relay diagram. See **Figure 2-3** for a block diagram of the 1260-132.




Figure 2-1, Front-Panel Connector Pin Numbering

Table 2-1, 1260-132 Front-Panel Connections

| CHANNEL | HI | LO | RELAY |
|---------|----------|----------|-------|
| 00 | J200-E32 | J200-E30 | K1 |
| 01 | J200-A28 | J200-C28 | K2 |
| 02 | J200-A30 | J200-C30 | K3 |
| 03 | J200-A32 | J200-C32 | K4 |
| 04 | J200-E28 | J200-E26 | K5 |
| 05 | J200-E24 | J200-E22 | K6 |
| 06 | J200-A24 | J200-C24 | K7 |
| 07 | J200-A26 | J200-C26 | K8 |
| 08 | J200-E20 | J200-E18 | K9 |
| 09 | J200-A18 | J200-C18 | K10 |
| 10 | J200-A20 | J200-C20 | K11 |
| 11 | J200-A22 | J200-C22 | K12 |
| 12 | J200-E16 | J200-E14 | K13 |
| 13 | J200-A12 | J200-C12 | K14 |
| 14 | J200-A14 | J200-C14 | K15 |
| 15 | J200-A16 | J200-C16 | K16 |
| 16 | J200-E12 | J200-E10 | K17 |
| 17 | J200-E8 | J200-E6 | K18 |
| 18 | J200-A8 | J200-C8 | K19 |
| 19 | J200-A10 | J200-C10 | K20 |
| 20 | J200-E4 | J200-E2 | K21 |
| 21 | J200-A2 | J200-C2 | K22 |
| 22 | J200-A4 | J200-C4 | K23 |
| 23 | J200-A6 | J200-C6 | K24 |





Figure 2-2 Relay Diagram

Figure 2-3, Block Diagram



Mating Connectors

Mating connector accessories are available:

160-Pin Connector Kit with backshell and pins,
P/N 407664-001

The 48-Pin Connector Kit consists of a connector housing and 60 crimp pins. After wire attachment, the pin is inserted into the housing and will snap into place, providing positive retention.

The suggested hand tool for the crimp pins is Racal Instruments P/N 990898. The corresponding pin removal tool is Racal Instruments P/N 990899.

This page was left intentionally blank.

Chapter 3

MODULE OPERATION

Setting the Module Address

Both the Racal Instruments Option-01T and 1256 switch controllers identify each Adapt-a-Switch plug-in by a *module address* that is unique to that module.

For setting the module address of the 1260-132 refer to one of the following manuals.

- 1260-100 Adapt-a-Switch Manual – Publication No. 980824-100 (“Module Address Switch” section in Chapter 2)
- 1256 User Manual – Publication No. 980855 (“Numbering of Plug-In Slots” section in Chapter 2)

1256 Operation

For a detailed description of the use of the 1260-132 when it is being used in a 1256 Switch Controller, refer to the 1256 User Manual (P/N 980855).

VXI Operating Modes

The 1260-132 may be operated either in *message-based* mode or in *register-based* mode when used with an Adapt-a-switch Carrier in a VXI chassis.

In the *message-based* mode, the 1260-01T switch controller interprets commands sent by the slot 0 controller, and determines the appropriate data to send to the control registers of the 1260-132 module.

A conceptual view of the message-based mode of operation is shown in **Figure 3-1** below.




Figure 3-1, Message-Based Mode of Operation

In the *register-based* mode, the user writes directly to the control registers on the 1260-132 module. The 1260-01T command module does not monitor these operations, and does not keep track of the relay states on the 1260-132 module in this mode.

A conceptual view of the register-based mode is shown in **Figure 3-2** below.




Figure 3-2, Register-Based Mode of Operation

Since the 1260-01T switch controller does not keep track of relay states during the register-based mode, it is advisable to use **either** the message-based or the register-based mode, and continue to use the same mode throughout the application program.

In general, the message-based mode of operation is easier to use with utility software such as the National Instruments VXI Interactive Control (VIC) program. The message-based mode allows the user to send ASCII text commands to the 1260-01T and to read replies from the 1260-01T. In addition, some features, such as the SCAN list, are available only in the message-based mode of operation.

The register-based mode provides faster control of relay channels. In this mode, relay operations are processed in less than 9 microseconds, not counting relay settling time or software overhead inherent in I/O libraries such as VISA. To determine the relay settling time, refer to Relay Settling Time in the Specifications section.

Consult the 1260-01T User's Manual for a comparison of the message-based and register-based modes of operation.

Operating In VXI Message-Based Mode

Channel Descriptors For The 1260-132

The standard 1260-01T commands are used to operate the 1260-132 module. These commands are described in the 1260-01T User's Manual.

Each 1260-01T relay command uses a *channel descriptor* to select the channel(s) of interest. The syntax for a channel descriptor is the same for all 1260 series modules. In general, the following syntax is used to select a single channel:

```
(@ <module address> ( <channel> ) )
```

Where:

- <module address> is the address of the 1260-132 module. This is a number in the range from 1 through 12, inclusive.
- <channel range> is a list of channels to operate. Each channel is a two-digit number. Thus, the valid channel numbers are:

0 through 23

When listing multiple channels, separate the channels with a comma (.). To select a contiguous range of channels, specify the first and last channels, and separate them by a colon (:)

The following examples illustrate the use of the channel descriptors for the 1260-132, with a module address of 8.

| | |
|---------------------|--|
| OPEN (@8(5)) | Open channel 5. |
| OPEN (@8(10)) | Open channel 10. |
| CLOSE (@8(0,9)) | Close channel 9 on the 1260-132. (Note that Channel 0 is used as the common output and must be closed to complete the path) |
| CLOSE (@8(0,23)) | Close channel 23 on the 1260-132. |
| OPEN (@8(0:23)) | Open channels 0 through 23 (all channels) on the 1260-132. |
| CLOSE (@8(0,10:22)) | Close channels 0, 10, through 22 on the 1260-132. |

Power Up Relay Default State

Normally, the default state for all relays for the 1260-132 is to be open on power up. The 1260-01T controller or the 1256 will set this state by default. This may or may not be what the user desires.

In the event that the user would like to change the state of the relays after power up it can be accomplished by doing the following:

- 1) Close each of channels on the 1260-132 that you would like to configure as closed for the power up state. For example, if the module address = 3:

CLOSE (@3(0,1))

- 3) Repeat step #2 for EACH 1260-132 in the system
- 4) Execute the "**SAV 0" command to save the present states of all relays into non-vol.

After this, whenever the Option -01T or 1256 is powered on, the specified relays will be closed (until specifically commanded to be open).

Reply To The MOD:LIST? Command

The 1260-01T returns a reply to the MOD:LIST? command. This reply is unique for each different 1260 series switch module. The syntax for the reply is:

<module address> : <module-specific identification string>

The <module-specific identification string> for the 1260-132 are:

1260-132 HIGH POWER REED FORM A MUX

So, for a 1260-132 whose <module address> is set to 8, the reply to this query would be:

8 : 1260-132 HIGH POWER REED FORM A MUX

Operating in VXI Register-Based Mode

In register-based mode, the 1260-132 is operated by directly writing and reading control registers on the 1260-132 module. The first control register on the module operates channels 0 through 7. The second control register operates channels 8 through 15. The third control register operates channels 16 through 23, etc. When a control register is written to, all channels controlled by that register are operated simultaneously.

The control registers are located in the VXIbus A24 Address Space. The A24 address for a control register depends on:

1. The A24 Address Offset assigned to the 1260-01T module by the Resource Manager program. The Resource Manager program is provided by the VXIbus slot-0 controller vendor. The A24 Address Offset is placed into the "Offset Register" of the 1260-01T by the Resource Manager.
2. The <module address> of the 1260-132 module. This is a value in the range from 1 and 12 inclusive.
3. The 1260-132 control register to be written to or read from. Each control register on the 1260-132 has a unique address.

The base A24 address for the 1260-132 module may be calculated by:

(A24 Offset of the 1260-01T) + (1024 x Module Address of 1260-132).

The A24 address offset is usually expressed in hexadecimal. A typical value of 204000₁₆ is used in the examples that follow.

A 1260-132 with a module address of 7 would have the base A24 address computed as follows:

$$\text{Base A24 Address of 1260-132} = 204000_{16} + (400_{16} \times 7_{10}) = 205C00_{16}$$

The control registers for Adapt-a-Switch plug-ins and conventional 1260-Series modules are always on odd-numbered A24 addresses. The three control registers for the 1260-132 reside at the first three odd-numbered A24 addresses for the module:

$$(\text{Base A24 Address of 1260-132}) + 1 = \text{Control Register 0}$$

$$(\text{Base A24 Address of 1260-132}) + 3 = \text{Control Register 1}$$

$$(\text{Base A24 Address of 1260-132}) + 5 = \text{Control Register 2}$$

So, for our example, the three control registers are located at:

205C01 Control Register 0, controls channels 0 through 7.

205C03 Control Register 1, controls channels 8 through 15.

205C05 Control Register 2, controls channels 16 through 23.

Table 3-1 shows the channel assignments for each control register.

Table 3-1, Control Register Channel Assignments

| Control Register | Channels | | | | | | | |
|------------------|-------------|-------|-------|-------|-------|-------|-------|-------------|
| | Bit 7 (MSB) | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 (LSB) |
| 0 | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| 1 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |
| 2 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 |

Setting a control bit to 1 closes the corresponding channels and clearing the bit to zero opens the channels. Thus, if you write the value 1000 0101 binary = 133 decimal = 85 hexadecimal to Control Register 0, channels 0, 2, and 7, will close, while channels 1,3,4,5, and 6, will be open.

The present control register value may be read back by reading an 8-bit value from the control register address. **The value is inverted from the control register** . In other words, the eight-bit value read back is the one's complement of the value written.

If you want to change the state of a single relay without affecting the present state of the other relays controlled by the control register, you must:

1. Read the control register.
2. Invert the bits (perform a one's complement on the register data).
3. Perform a bit-wise AND operation, leaving all but the specific control register bit for the relay to change.
4. **To open:** No operation required. **To close:** OR in the bits for the relays to close.
5. Write the modified value back to the control register.

For example, to close channel 14:

1. Read Control Register 1 (this register controls channels 8 through 15, with channel 8 represented by the LSB).
2. Invert the bits in the value read in step 1.
3. AND with 1011 1111 binary (the zero is in the position corresponding to channel 14).
4. OR with 0100 0000 binary.
5. Write the value to Control Register 1.

The VISA I/O library may be used to control the module. The VISA function `viOut8()` is used to write a single 8-bit byte to a control register, while `viIn8()` is used to read a single 8-bit byte from the control register. The following code example shows the use of `viOut8()` to update the 1260-132 module.

1260-132 Example Code

```
#include <visa.h>

/* This example shows a 1260-01T at logical address 16 and a VXI/MXI */
/* interface */
#define RI1260_01_DESC      "VXI::16"

/* For a GPIB-VXI interface, and a logical address of 77 */
/* the descriptor would be: "GPIB-VXI::77" */

/* this example shows a 1260-132 with module address 7 */
#define MOD_ADDR_132 7

void example_operate_1260_132(void)
{
    ViUInt8 creg_val;
    ViBusAddress creg0_addr;
    ViBusAddress creg1_addr;
    ViBusAddress creg2_addr;
    ViSession hdl1260; /* VISA handle to the 1260-01T */
    ViSession hdlRM; /* VISA handle to the resource manager */
*/
    ViStatus error; /* VISA error code */

    /* open the resource manager */
    /* this must be done once in application program */
    error = viOpenDefaultRM(&hdlRM);

    if (error < 0) {
        /* error handling code goes here */
    }

    /* get a handle for the 1260-01T */
    error = viOpen(hdlRM, RI1260_01_DESC, VI_NULL,VI_NULL, &hdl1260);
    if (error < 0) {
        /* error handling code goes here */
    }
}
```



```
/* form the offset for control register 0 */
/* note that the base A24 Address for the 1260-01T */
/* is already accounted for by VISA calls viIn8() and */
/* viOut8() */

/* module address shifted 10 places = module address x 1024 */
creg0_addr = (MOD_ADDR_132 << 10) + 1;
creg1_addr = creg0_addr + 2;
creg2_addr = creg1_addr + 2;

/* close channel 14 without affecting the state of */
/* channels 8, 9, 10, 11, 12, 13, and 15 */
error = viIn8 (hdl1260, VI_A24_SPACE, creg1_addr, &creg_val);
if (error < 0) {
    /* error handling code goes here */
}

/* invert the bits to get the present control register value */
creg_val = ~creg_val;

/* AND to leave every channel except 14 unchanged */
creg_val &= ~ (0x40);

/* OR in the bit to close channel 14 */
creg_val |= 0x40;

/* write the updated control register value */
error = viOut8 (hdl1260, VI_A24_SPACE, creg1_addr, creg_val);
if (error < 0) {
    /* error handling code goes here */
}

/* open channel 16 without affecting channels 17 through 23 */
error = viIn8 (hdl1260, VI_A24_SPACE, creg2_addr, &creg_val);
if (error < 0) {
    /* error handling code goes here */
}

/* invert the bits to get the present control register value */
creg_val = ~creg_val;

/* AND to leave every channel except 16 unchanged */
/* leave bit 0 clear to open channel 16 */
creg_val &= ~ (0x01);

/* write the updated control register value */
```

```
error = viOut8 (hdl1260, VI_A24_SPACE, creg2_addr, creg_val);
if (error < 0) {
    /* error handling code goes here */
}

/* close the VISA session */
error = viClose( hdl1260 );
if (error < 0) {
    /* error handling code goes here */
}
}
```


Chapter 4

OPTIONAL ASSEMBLIES

407664-001 Mating Connector Kit.....4-2

Publication 980851 Rev A
 Assembly Procedure
 Racal Instruments Assembly 407664-001

Publication Date 22 June 1999



INSTRUCTIONS

1. AFFIX LABEL (ITEM 7) TO BRACKET (ITEM 1) APPROX WHERE SHOWN.
2. CRIMP TERMINAL (ITEM 3) TO WIRE (NOT SUPPLIED).
3. PASS CRIMPED WIRES THROUGH INSULATOR ASSEMBLY (ITEM 6).
4. INSERT CRIMPED TERMINALS INTO CONNECTOR BODY (ITEM 2).
5. ATTACH INSULATOR ASSEMBLY (ITEM 6) TO STRAIN RELIEF BRACKET (ITEM 1) AND CONNECTOR BODY (ITEM 2) WITH SCREWS AND WASHERS (ITEMS 4&5). GASKET MUST SEAT SNUGLY AND EVENLY AGAINST CONNECTOR BODY.

| ITEM NO. | QTY. | PART NO. | DESCRIPTION |
|----------|------|------------|------------------------|
| 1 | 1 | 456673 | BRACKET, STRAIN RELIEF |
| 2 | 1 | 602258-116 | CONNECTOR, 160 PIN |
| 3 | 1 | 602258-900 | TERMINAL, CRIMP |
| 4 | 2 | 617127 | WASHER, #4 SPLIT LOCK |
| 5 | 2 | 616304 | SCREW, M2.5X10MM |
| 6 | 1 | 407714 | INSULATOR ASSEMBLY |
| 7 | 2 | 921592 | WARNING LABEL, SHOCK |

Chapter 5

PRODUCT SUPPORT

Product Support

Racal Instruments has a complete Service and Parts Department. If you need technical assistance or should it be necessary to return your product for repair or calibration, call 1-800-722-3262. If parts are required to repair the product at your facility, call 1-949-859-8999 and ask for the Parts Department.

When sending your instrument in for repair, complete the form in the back of this manual.

For worldwide support and the office closes to your facility, refer to the Support Offices section on the following page.

Reshipment Instructions

Use the original packing material when returning the 1260-132 to Racal Instruments for calibration or servicing. The original shipping crate and associated packaging material will provide the necessary protection for safe reshipment.

If the original packing material is unavailable, contact Racal Instruments Customer Service for information.

Support Offices

Racal Instruments, Inc.

4 Goodyear St., Irvine, CA 92618-2002
Tel: (800) 722-3262, FAX: (949) 859-7309

Racal Instruments, Ltd.

480 Bath Road, Slough, Berkshire, SL1 6BE, United Kingdom
Tel: +44 (0) 8706 080134; FAX: +44 (0) 1753 791290

Racal Systems Electronique S.A.

18 Avenue Dutartre, 78150 LeChesnay, France
Tel: +33 (1) 3923 2222; FAX: +33 (1) 3923 2225

Racal Systems Elettronica s.r.l.

Strada 2-Palazzo C4, 20090 Milanofiori Assago, Milan, Italy
Tel: +39 (02) 5750 1796; FAX +39 (02) 5750 1828

Racal Elektronik System GmbH.

Frankenforster Strasse 21, 51427 Bergisch Gladbach, Germany
Tel:+49 2204 92220; FAX: +49 2204 21491

Racal Instruments, Ltd.

Unit 5, 25F., Mega Trade Center, No 1, Mei Wan Road, Tsuen
Wan, Hong Kong, PRC

Tel: +852 2405 5500, FAX: +852 2416 4335

REPAIR AND CALIBRATION REQUEST FORM

To allow us to better understand your repair requests, we suggest you use the following outline when calling and include a copy with your instrument to be sent to the Racal Repair Facility.

Model _____ Serial No. _____ Date _____

Company Name _____ Purchase Order # _____

Billing Address _____
City _____

State/Province _____ Zip/Postal Code _____ Country _____

Shipping Address _____
City _____

State/Province _____ Zip/Postal Code _____ Country _____

Technical Contact _____ Phone Number () _____

Purchasing Contact _____ Phone Number () _____

1. Describe, in detail, the problem and symptoms you are having. Please include all set up details, such as input/output levels, frequencies, waveform details, etc. _____

2. If problem is occurring when unit is in remote, please list the program strings used and the controller type. _____

3. Please give any additional information you feel would be beneficial in facilitating a faster repair time (i.e., modifications, etc.) _____

4. Is calibration data required? Yes No (please circle one)

Call before shipping Ship instruments to nearest support office
Note: We do not accept listed on back.
"collect" shipments.