
R197.132.Z90

Series: SMB CARLOCK



**Issue:** 0334 A



\_

R197.132.Z90

Series: SMB CARLOCK

#### **PACKAGING**

Standard	Unit	Other
100	'W' option	Contact us

## **SPECIFICATION**

**QS9000** 

## **ELECTRICAL CHARACTERISTICS**

Impedance  $\Omega$ 

Frequency GHz VSWR + **0.000** x F(GHz) Maxi

Insertion loss  $\sqrt{F(GHz)}$  dB Maxi RF leakage - ( - F(GHz)) dB Maxi

Voltage rating Veff Maxi Dielectric withstanding voltage Veff mini Insulation resistance  $M\Omega$  mini

## **ENVIRONMENTAL**

Operating temperature -40/+110 ° C

Hermetic seal Atm.cm3/s

Panel leakage

## **OTHERS CHARACTERISTICS**

**HOUSING FOR COAX:** 

R114.242.325,R114.246.325,R114.249.325

Assembly instruction Page 3 & 4

Others:

## MECHANICAL CHARACTERISTICS

Center contact retention

Axial force – Mating end N mini
Axial force – Opposite end N mini
Torque N.cm mini

Recommended torque

Mating N.cm Panel nut N.cm

Mating life 100 Cycles mini

Weight **1.217** g

1.217 g

**Issue:** 0334 A




R197.132.Z90

Series: SMB CARLOCK

## RECOMMENDED MOUNTING PROCEDURE




• Push the coax until it stops at the bottom of the housing





• Push the secondary lock in final position to secure the coax inside the housing (until it click on)



**Issue:** 0334 A




R197.132.Z90

Series: SMB CARLOCK

# RECOMMENDED DISASSEMBLING PROCEDURE




- insert a screw driver into the slot of the CPA devise as shown on the picture.
- Tip up the screw driver as shown on the picture to lift up the CPA devise until it click on.





- insert a screw driver between the elastic finger and the CPA devise as shown on the picture.
- Tip up the screw driver as shown on the picture to lift up the elastic finger and when it is done pull on the cable assembly to remove the coax from the housing.



**Issue:** 0334 A

