


R197.135.\_80


Series: SMB **CARLOCK** 

To obtain the complete P/N please fill in the blank "\_" with the coding letter









Housing to be used with: -R299.197.000 -R299.197.010

All dimensions are in mm.

COMPONENTS	MATERIALS	PLATING	(μm)
		UL CLASSIFICATION	COLOR
HOUSING	PA6.6 GF15 (POLYAMIDE)	UL 94 V-2	See Page2

### **PACKAGING**

Standard	Unit	Other
500	'W' option	Contact us

## MECHANICAL CHARACTERISTICS

#### **ENVIRONMENTAL**

Mating life 100 Cycles mini Operating temperature **-40/+110** ° C

Weight **1,6500** g

**Issue:** 0745 A


In the effort to improve our products, we reserve the right to make changes judged to be

necessary.



R197.135.\_80

Series : **SMB CARLOCK** 



-To obtain the complete P/N please fill in the blank  $"\_"$  with the coding letter

**Issue:** 0745 A

In the effort to improve our products, we reserve the right to make changes judged to be necessary.




R197.135.\_80

Series : **SMB CARLOCK** 

# RECOMMENDED MOUNTING PROCEDURE




• Pre-insertion of the coax into the housing




Orientation of the slot


• Orientation of the tab of the coax with the slot of the housing.






• Push the connector into the housing until it clip on.







**Issue:** 0745 A

In the effort to improve our products, we reserve the right to make changes judged to be




R197.135.\_80


Series: SMB **CARLOCK** 

## RECOMMENDED DISASSEMBLING PROCEDURE



- To unlock the coax from the housing, rotate the coax until the tab is not in front of the elastic finger of the housing.
- insert a screw driver between the elastic finger and the slot of the housing as shown on the picture.
- Tip down the screw driver as shown on the picture to lift up the elastic finger until you have enough room.








- Hold on the elastic finger up and rotate the coax until the tab is in front of the elastic finger of the housing. (you can use the crimping of the jacket as a reference).
- pull on the cable assembly to remove the coax from the housing.







**Issue:** 0745 A

In the effort to improve our products, we reserve the right to make changes judged to be

