

# R&S®FSW-K40

## Phase Noise Measurements

### User Manual



1173.9286.02 – 14

This manual applies to the following R&S®FSW models with firmware version 2.40 and higher:

- R&S®FSW8 (1312.8000K08)
- R&S®FSW13 (1312.8000K13)
- R&S®FSW26 (1312.8000K26)
- R&S®FSW43 (1312.8000K43)
- R&S®FSW50 (1312.8000K50)
- R&S®FSW67 (1312.8000K67)
- R&S®FSW85 (1312.8000K85)

The following firmware options are described:

- R&S FSW-K40 (1313.1397.02)

© 2016 Rohde & Schwarz GmbH & Co. KG  
Mühldorfstr. 15, 81671 München, Germany  
Phone: +49 89 41 29 - 0  
Fax: +49 89 41 29 12 164  
Email: [info@rohde-schwarz.com](mailto:info@rohde-schwarz.com)  
Internet: [www.rohde-schwarz.com](http://www.rohde-schwarz.com)

Subject to change – Data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

The following abbreviations are used throughout this manual: R&S®FSW is abbreviated as R&S FSW.

# Contents

<b>1</b>	<b>Preface</b> .....	<b>5</b>
1.1	About this Manual.....	5
1.2	Documentation Overview.....	6
1.3	Conventions Used in the Documentation.....	7
<b>2</b>	<b>Welcome to the Phase Noise Measurement Application</b> .....	<b>9</b>
2.1	Starting the Application.....	9
2.2	Understanding the Display Information.....	10
<b>3</b>	<b>Measurements and Result Displays</b> .....	<b>14</b>
<b>4</b>	<b>Measurement Basics</b> .....	<b>22</b>
4.1	Spurs and Spur Removal.....	22
4.2	Residual Effects.....	23
4.3	Measurement Range.....	24
4.4	Sweep Modes.....	25
4.5	Trace Averaging.....	25
4.6	Frequency Determination.....	27
4.7	Level Determination.....	30
4.8	Signal Attenuation.....	30
4.9	Using Limit Lines.....	31
4.10	Analyzing Several Traces - Trace Mode.....	33
4.11	Using Markers.....	35
<b>5</b>	<b>Configuration</b> .....	<b>36</b>
5.1	Configuration Overview.....	36
5.2	Default Settings for Phase Noise Measurements.....	37
5.3	Configuring the Frontend.....	38
5.4	Controlling the Measurement.....	40
5.5	Configuring the Measurement Range.....	43
5.6	Performing Measurements.....	46
5.7	Configuring In- and Outputs.....	48
5.8	Automatic Measurement Configuration.....	49
<b>6</b>	<b>Analysis</b> .....	<b>51</b>

6.1	Configuring Graphical Result Displays.....	51
6.2	Configure Numerical Result Displays.....	56
6.3	Using Limit Lines.....	58
6.4	Using Markers.....	65
7	<b>How to Configure Phase Noise Measurements.....</b>	<b>68</b>
7.1	Performing a Basic Phase Noise Measurement.....	68
7.2	Customizing the Measurement Range.....	68
8	<b>Remote Control Commands for Phase Noise Measurements.....</b>	<b>70</b>
8.1	Common Suffixes.....	70
8.2	Introduction.....	71
8.3	Controlling the Phase Noise Measurement Channel.....	76
8.4	Performing Measurements.....	80
8.5	Configuring the Result Display.....	85
8.6	Configuring the Frontend.....	92
8.7	Controlling the Measurement.....	95
8.8	Configuring the Measurement Range.....	99
8.9	Using Limit Lines.....	106
8.10	Graphical Display of Phase Noise Results.....	117
8.11	Configure Numerical Result Displays.....	127
8.12	Using Markers.....	140
8.13	Configuring In- and Outputs.....	146
8.14	Automatic Measurement Configuration.....	147
8.15	Using the Status Register.....	148
8.16	Remote Control Example Scripts.....	154
	<b>List of Remote Commands (Phase Noise).....</b>	<b>160</b>
	<b>Index.....</b>	<b>165</b>

# 1 Preface

## 1.1 About this Manual

This User Manual provides all the information **specific to the application**. All general instrument functions and settings common to all applications and operating modes are described in the main R&S FSW User Manual.

The main focus in this manual is on the measurement results and the tasks required to obtain them. The following topics are included:

- **Welcome to the Phase Noise Application**  
Introduction to and getting familiar with the application
- **Typical applications**  
Example measurement scenarios in which the application is frequently used.
- **Measurements and Result Displays**  
Details on supported measurements and their result types
- **Phase Noise Measurement Basics**  
Background information on basic terms and principles in the context of the measurement
- **Phase Noise Measurement Configuration + Analysis**  
A concise description of all functions and settings available to configure measurements and analyze results with their corresponding remote control command
- **How to Perform Measurements with the Phase Noise Application**  
The basic procedure to perform each measurement and step-by-step instructions for more complex tasks or alternative methods
- **Measurement Examples**  
Detailed measurement examples to guide you through typical measurement scenarios and allow you to try out the application immediately
- **Optimizing and Troubleshooting the Measurement**  
Hints and tips on how to handle errors and optimize the test setup
- **Remote Commands for Phase Noise Measurements**  
Remote commands required to configure and perform phase noise measurements in a remote environment, sorted by tasks  
(Commands required to set up the environment or to perform common tasks on the instrument are provided in the main R&S FSW User Manual)  
Programming examples demonstrate the use of many commands and can usually be executed directly for test purposes
- **Annex**  
Reference material
- **List of remote commands**  
Alphabetical list of all remote commands described in the manual
- **Index**

## 1.2 Documentation Overview

The user documentation for the R&S FSW consists of the following parts:

- "Getting Started" printed manual
- Online Help system on the instrument
- User manuals and online manual for base unit and options provided on the product page
- Service manual provided on the internet for registered users
- Instrument security procedures provided on the product page
- Release notes provided on the product page
- Data sheet and brochures provided on the product page
- Application notes provided on the Rohde & Schwarz website



You find the user documentation on the R&S FSW product page mainly at:

<http://www.rohde-schwarz.com/product/FSW> > "Downloads" > "Manuals"

Additional download paths are stated directly in the following abstracts of the documentation types.

---

### Getting Started

Introduces the R&S FSW and describes how to set up and start working with the product. Includes basic operations, typical measurement examples, and general information, e.g. safety instructions, etc.

### Online Help

Offers quick, context-sensitive access to the information needed for operation and programming. It contains the description for the base unit and the software options. The Online Help is embedded in the instrument's firmware; it is available using the ? icon on the toolbar of the R&S FSW.

### User Manuals and Online Manual

Separate manuals are provided for the base unit and the software options:

- **Base unit manual**  
Contains the description of the graphical user interface, an introduction to remote control, the description of all SCPI remote control commands, programming examples, and information on maintenance, instrument interfaces and error messages. Includes the contents of the **Getting Started** manual.
- **Software option manuals**  
Describe the specific functions of the option. Basic information on operating the R&S FSW is not included.

The **online manual** provides the contents of the user manuals for the base unit and all software options for immediate display on the internet.

**Service Manual**

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists.

The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS).

**Instrument Security Procedures**

Deals with security issues when working with the R&S FSW in secure areas.

**Data Sheet and Brochures**

The data sheet contains the technical specifications of the R&S FSW. Brochures provide an overview of the instrument and deal with the specific characteristics, see:

<http://www.rohde-schwarz.com/product/FSW> > "Downloads" > "Brochures and Data Sheets"

**Release Notes**

Describes the firmware installation, new and modified features and fixed issues according to the current firmware version. You find the latest version at:

<http://www.rohde-schwarz.com/product/FSW> > "Firmware"

**Application Notes, Application Cards, White Papers, etc.**

These documents deal with special applications or background information on particular topics, see:

<http://www.rohde-schwarz.com/> > "Downloads" > "Applications".

## 1.3 Conventions Used in the Documentation

### 1.3.1 Typographical Conventions

The following text markers are used throughout this documentation:

Convention	Description
"Graphical user interface elements"	All names of graphical user interface elements on the screen, such as dialog boxes, menus, options, buttons, and softkeys are enclosed by quotation marks.
KEYS	Key names are written in capital letters.
File names, commands, program code	File names, commands, coding samples and screen output are distinguished by their font.
<i>Input</i>	Input to be entered by the user is displayed in italics.

Convention	Description
Links	Links that you can click are displayed in blue font.
"References"	References to other parts of the documentation are enclosed by quotation marks.

### 1.3.2 Conventions for Procedure Descriptions

When describing how to operate the instrument, several alternative methods may be available to perform the same task. In this case, the procedure using the touchscreen is described. Any elements that can be activated by touching can also be clicked using an additionally connected mouse. The alternative procedure using the keys on the instrument or the on-screen keyboard is only described if it deviates from the standard operating procedures.

The term "select" may refer to any of the described methods, i.e. using a finger on the touchscreen, a mouse pointer in the display, or a key on the instrument or on a keyboard.

### 1.3.3 Notes on Screenshots

When describing the functions of the product, we use sample screenshots. These screenshots are meant to illustrate as much as possible of the provided functions and possible interdependencies between parameters.

The screenshots usually show a fully equipped product, that is: with all options installed. Thus, some functions shown in the screenshots may not be available in your particular product configuration.



## 2 Welcome to the Phase Noise Measurement Application

The R&S FSW-K40 is a firmware application that adds functionality to measure the phase noise characteristics of a device under test with the R&S FSW signal analyzer.

This user manual contains a description of the functionality that the application provides, including remote control operation.

Functions that are not discussed in this manual are the same as in the Spectrum application and are described in the R&S FSW User Manual. The latest versions of the manuals are available for download at the product homepage.

<http://www2.rohde-schwarz.com/product/FSW.html>.

### Installation

Find detailed installing instructions in the Getting Started or the release notes of the R&S FSW.


- [Starting the Application](#)..... 9
- [Understanding the Display Information](#)..... 10

### 2.1 Starting the Application

The phase noise measurement application adds a new type of measurement to the R&S FSW.

#### To activate the the Phase Noise application

1. Select the MODE key.  
A dialog box opens that contains all operating modes and applications currently available on your R&S FSW.
2. Select the "Phase Noise" item.



The R&S FSW opens a new measurement channel for the Phase Noise application.


All settings specific to phase noise measurements are in their default state.

#### Multiple Measurement Channels and Sequencer Function

When you enter an application, a new measurement channel is created which determines the measurement settings for that application. The same application can be activated with different measurement settings by creating several channels for the same application.

The number of channels that can be configured at the same time depends on the available memory on the instrument.


Only one measurement can be performed at any time, namely the one in the currently active channel. However, in order to perform the configured measurements consecutively, a Sequencer function is provided.

If activated, the measurements configured in the currently active channels are performed one after the other in the order of the tabs. The currently active measurement is indicated by a  symbol in the tab label. The result displays of the individual channels are updated in the tabs (as well as the "MultiView") as the measurements are performed. Sequential operation itself is independent of the currently *displayed* tab.

For details on the Sequencer function see the R&S FSW User Manual.

## 2.2 Understanding the Display Information

The following figure shows the display as it looks for phase noise measurements. All different information areas are labeled. They are explained in more detail in the following sections.



**Figure 2-1: Screen layout of the phase noise measurement application**

- 1 = Toolbar
- 2 = Channel bar
- 3 = Diagram header
- 4 = Result display
- 5 = Softkey bar
- 6 = Measurement status
- 7 = Status bar

For a description of the elements not described below, please refer to the Getting Started of the R&S FSW.

## Measurement status

The application shows the progress of the measurement in a series of green bars at the bottom of the diagram area. For each half decade in the measurement, the application adds a bar that spans the frequency range of the corresponding half decade.

The bar has several features.

- The numbers within the green bar show the progress of the measurement(s) in the half decade the application currently works on.  
The first number is the current, the second number the total count of measurements for that half decade. The last number is the time the measurement requires.
- A double-click on the bar opens an input field to define the number of averages for that half decade.
- A right-click on the bar opens a context menu.



The context menu provides easy access to various parameters (resolution bandwidth, sweep mode etc.) that define the measurement characteristics for a half decade. The values in parentheses are the currently selected values. For more information on the available parameters see "[Half Decades Configuration Table](#)" on page 46.

## Channel bar information

The channel bar contains information about the current measurement setup, progress and results.


Phase Noise			
Frequency	3.90000025 GHz	Meas Level	9.63 dBm
Ref Level & Att	10.20 dBm, Att 11.00 dB	Initial Delta	0.10 dB
Meas Range	3 kHz to 100 MHz	Drift	-0.02 dB
		Meas Frequency	3.90000025 GHz
		Initial Delta	-24.22 Hz / -0.01 ppm
		Drift	-498.28 mHz / 0 ppm

Figure 2-2: Channel bar of the phase noise application

<b>Frequency</b>	Frequency the R&S FSW has been tuned to. The frontend frequency is the expected frequency of the carrier. When frequency tracking or verification is on, the application might adjust the frontend frequency.
<b>Ref Level &amp; Att</b>	Reference level (first value) and attenuation (second value) of the R&S FSW. When level tracking or verification is on, the application might adjust the frontend level.
<b>Measurement</b>	Complete phase noise measurement range. For more information see <a href="#">Chapter 4.3, "Measurement Range"</a> , on page 24.
<b>Measured Level</b>	DUT level that has been actually measured. The measured level might differ from the frontend level, e.g. if you are using level verification.
<b>Initial Delta</b>	Difference between the nominal level and the first level that has been measured.


<b>Drift</b>	<p>Difference between the 1st level that has been measured and the level that has been measured last.</p> <p>In continuous sweep mode, the drift is the difference between the 1st level that has been measured in the 1st sweep and the level that has been measured last.</p>
<b>Measured Frequency</b>	<p>DUT frequency that has been actually measured.</p> <p>The measured frequency might differ from the frontend frequency, e.g. if you are using level verification.</p>
<b>Initial Delta</b>	<p>Difference between the nominal frequency and the first frequency that has been measured.</p>
<b>Drift</b>	<p>Difference between the 1st frequency that has been measured and the frequency that has been measured last.</p> <p>In continuous sweep mode, the drift is the difference between the 1st frequency that has been measured in the 1st sweep and the frequency that has been measured last.</p>
<b>SGL [###]</b>	<p>Sweep mode (single or continuous). If you use trace averaging, it also shows the current measurement number out of the total number of measurements.</p>

The following two figures show the relations between the frequency and level errors.



**Figure 2-3: Frequency errors**

$f_{front}$  = initial frequency set on the frontend  
 $f_{meas_x}$  = actual frequency that has been measured



**Figure 2-4: Level errors**

$P_{front}$  = reference level if tracking = off  
 $P_{front}$  = initial reference level if tracking = on  
 $P_{meas_1}$  = becomes reference level after first sweep if tracking = on  
 $P_{meas_2}$  = becomes reference level after second sweep if tracking = on  
 $P_{meas_3}$  = becomes reference level after third sweep if tracking = on

**Window title bar information**

For each diagram, the header provides the following information:



**Figure 2-5: Window title bar information of the phase noise application**

- 1 = Window number
- 2 = Window type
- 3 = Trace color and number
- 4 = Trace mode
- 5 = Smoothing state and degree

### Status bar information

Global instrument settings, the instrument status and any irregularities are indicated in the status bar beneath the diagram. Furthermore, the progress of the current operation is displayed in the status bar.

## 3 Measurements and Result Displays

### Access:

The Phase Noise application measures the phase noise of a single sideband of a carrier.

It features several result displays. Result displays are different representations of the measurement results. They may be diagrams that show the results in a graphic way or tables that show the results in a numeric way.

In the default state of the application, only the graphical display of phase noise results is active.

Phase Noise Diagram.....	14
Residual Noise.....	15
Spot Noise.....	16
Spur List.....	17
Sweep Result List.....	18
Spectrum Monitor.....	19
Frequency Drift.....	20
Frequency and Level Stability.....	21
Reference Measurement.....	21

### Phase Noise Diagram

The phase noise diagram shows the power level of the phase noise over a variable frequency offset from the carrier frequency.

#### Measurement range

The unit of both axes in the diagram is fix. The x-axis always shows the offset frequencies in relation to the carrier frequency on a logarithmic scale in Hz. It always has a logarithmic scale to make sure of a equal representation of offsets near and far away from the carrier. The range of offsets that the x-axis shows is variable and depends on the measurement range you have defined and the scope of the x-axis that you have set.

For more information on the measurement range see [Chapter 4.3, "Measurement Range"](#), on page 24.

If the measurement range you have set is necessary, but you need a better resolution of the results, you can limit the displayed result by changing the x-axis scope. The scope works like a zoom to get a better view of the trace at various points. It does not start a new measurement or alter the current measurements results in any way.

The y-axis always shows the phase noise power level contained in a 1 Hz bandwidth in relation to the level of the carrier. The unit for this information is dBc/Hz and is also fix.

#### Y-axis scale

The scale of the y-axis is variable. Usually it is best to use the automatic scaling that the application provides, because it makes sure that the whole trace is always visible. You can, however, also customize the range, the minimum and the maximum values on the y-axis by changing the y-axis scale.

The measurement results are displayed as traces in the diagram area. Up to six active traces at any time are possible. Each of those may have a different setup and thus show different aspects of the measurement results.

In the default state, the application shows two traces. A yellow one and a blue one. Both result from the same measurement data, but have been evaluated differently. On the first trace, smoothing has been applied, the second one shows the raw data.

For more information on trace smoothing see [Chapter 4.5, "Trace Averaging"](#), on page 25.




Figure 3-1: Overview of the phase noise result display

The figure above shows a phase noise curve with typical characteristics. Frequency offsets near the carrier usually have higher phase noise levels than those further away from the carrier. The curve has a falling slope until the thermal noise of the DUT has been reached. From this point on, it is more or less a straight horizontal line.

Remote command:

[TRACe \[ : DATA \] ?](#) on page 126

### Residual Noise

The residual noise display summarizes the residual noise results in a table.

For more information on the residual noise results see [Chapter 4.2, "Residual Effects"](#), on page 23.

The table consists of up to four rows with each row representing a different integration interval. Each row basically contains the same information with the exception that the first row always shows the results for the first trace and the other rows with custom integration ranges the results for any one trace.

2 Residual Noise							
Trace	Start Offset	Stop Offset	Int PHN	PM	FM	Jitter	
T1	1.00 kHz	10.00 kHz	-50.15 dBc	251.81 m° / 4...	7.72 Hz	134.52 fs	
T1	10.00 kHz	100.00 kHz	-63.80 dBc	52.32 m° / 91...	55.32 Hz	27.95 fs	
T1	100.00 kHz	200.68 kHz	-64.34 dBc	49.17 m° / 85...	129.94 Hz	26.26 fs	

The residual noise information is made up out of several values.

<b>Type</b>	Shows the number of the trace that is integrated (T[x]).
<b>Start / Stop Offset</b>	Shows the start and stop offset of the integration interval.
<b>Int. PHN</b>	Shows the Integrated Phase Noise. The integral is calculated over the frequency range defined by the Start and Stop Offset values.
<b>PM</b>	Shows the Residual PM result in degrees and rad.
<b>FM</b>	Shows the Residual FM results in Hz.
<b>Jitter</b>	Shows the Jitter in seconds.

For more information on residual noise see [Chapter 4.2, "Residual Effects"](#), on page 23.

Remote command:

Querying Residual PM:

`FETCh:PNOise<t>:RPM?` on page 131

Querying Residual FM:

`FETCh:PNOise<t>:RFM?` on page 130

Querying Jitter:

`FETCh:PNOise<t>:RMS?` on page 130

Querying Integrated Phase Noise

Querying user ranges:

`FETCh:PNOise<t>:USER<range>:RFM?` on page 131

`FETCh:PNOise<t>:USER<range>:RMS?` on page 131

`FETCh:PNOise<t>:USER<range>:RPM?` on page 132

### Spot Noise

Spot noise is the phase noise at a particular frequency offset (or spot) that is part of the measurement range. It is thus like a fixed marker.

The unit of spot noise results is dBc/Hz. The application shows the results in a table.

2 Spot Noise		
Type	Offset Frequency [T1]	Phase Noise [T1]
User 1	<b>1.00 kHz</b>	<b>-115.33 dBc/Hz</b>
User 2	<b>10.00 kHz</b>	<b>-124.42 dBc/Hz</b>
User 3	<b>100.00 kHz</b>	<b>-122.67 dBc/Hz</b>
User 4	<b>1.00 MHz</b>	<b>-132.82 dBc/Hz</b>
User 5	<b>10.00 MHz</b>	<b>---</b>

The table consists of a variable number of 10<sup>x</sup> frequencies (depending on the measurement range), and a maximum of five user frequencies, with each row containing the spot noise information for a particular frequency offset.

The spot noise information is made up out of several variables.



<b>Type</b>	Shows where the spot noise offset frequency comes from. By default, the application evaluates the spot noise for the first offset frequency of a decade only (10 <sup>x</sup> Hz, beginning at 1 kHz). However, you can add up to five customized offsets frequencies that you want to know the phase noise for. If you want to use more custom offsets, you can add another spot noise table. The "User" label indicates a custom offset frequency.
<b>Offset Frequency</b>	Shows the offset frequency the spot noise is evaluated for. You may add any offset that is part of the measurement range. The number in brackets (T<x>) indicates the trace the result refers to.
<b>Phase Noise</b>	Shows the phase noise for the corresponding offset frequency. The number in brackets (T<x>) indicates the trace the result refers to.

Note that the spot noise results are calculated for a particular trace only. You can select the trace by tapping on the trace LED in the header of the result display.

1 Phase Noise ● 1 Clrw Lin Smth 1% ○ 2 Clrw

Remote command:

Querying spot noise results on 10<sup>x</sup> offset frequencies:

[CALCulate<n>:SNOise:DECades:X?](#) on page 133

[CALCulate<n>:SNOise:DECades:Y?](#) on page 133

Querying custom spot noise results:

[CALCulate<n>:SNOise<m>:Y?](#) on page 135

Trace selection: [DISPlay\[:WINDow<n>\]:TRACe<t>:SElect](#) on page 135

### Spur List

Spurs are peak levels at one or more offset frequencies and are caused mostly by interfering signals. The application shows the location of all detected spurs in a table.

4 Spur List			
No	Offset Frequency	Power	Jitter
1	1.70 kHz	-50.20 dBc	133.82 fs
2	3.40 kHz	-80.59 dBc	4.04 fs
3	5.10 kHz	-82.42 dBc	3.28 fs
Total	Discrete Jitter		133.92 fs
	Random Jitter		12.62 fs

The table consists of a variable number of rows. For each detected spur, the table shows several results.

<b>Number</b>	Shows the spur number. Spurs are sorted by their frequency, beginning with the spur with the lowest frequency.
<b>Offset Frequency</b>	Shows the position (offset frequency) of the spur.

<b>Power</b>	Shows the power level of the spur in dBc.
<b>Jitter</b>	Shows the jitter value of the spur in s. In addition to the jitter for each spur, the result display also shows the <b>Discrete Jitter</b> and the <b>Random Jitter</b> at the end of the table. <ul style="list-style-type: none"> <li>The Discrete Jitter is the RMS value of all individual jitter values.</li> <li>The Random Jitter is the difference of the overall jitter (as shown in the <a href="#">Residual Noise</a> result display) and the Discrete Jitter. The result is an RMS value: <math>\text{RandomJitter}^2 = \text{Jitter}^2 - \text{DiscreteJitter}^2</math></li> </ul>

For more information see [Chapter 4.1, "Spurs and Spur Removal"](#), on page 22.

Remote command:

[FETCh:PNOise:SPURs?](#) on page 136

[FETCh:PNOise:SPURs:DISCReTe?](#) on page 136

[FETCh:PNOise:SPURs:RANDOm?](#) on page 136

### Sweep Result List

The sweep result list summarizes the results of the phase noise measurement.

3 Sweep Result List						
Start	Stop	Sampling Rate	AVG	Freq Drift	Level Drift	Max Freq Drift
300.00 Hz	1.00 kHz	2.50 kHz	134	3.32 Hz	0.08 dB	35.94 mHz
1.00 kHz	3.00 kHz	7.50 kHz	1000	3.33 Hz	0.08 dB	82.92 mHz
3.00 kHz	10.00 kHz	25.00 kHz	1000	3.33 Hz	0.08 dB	219.37 mHz
10.00 kHz	30.00 kHz	75.00 kHz	1000	3.32 Hz	0.08 dB	553.48 mHz
30.00 kHz	100.00 kHz	250.00 kHz	1000	3.33 Hz	0.08 dB	2.17 Hz
100.00 kHz	300.00 kHz	750.00 kHz	1000	3.33 Hz	0.08 dB	11.45 Hz
300.00 kHz	1.00 MHz	2.50 MHz	1000	3.33 Hz	0.08 dB	105.11 Hz

The table consists of several rows with each row representing a half decade. The number of rows depends on the number of half decades analyzed during the measurement.

The sweep results are made up out of several values.

- Results in a red font indicate that the frequency drift is so large that the frequency has drifted into the range of a higher half decade. The result is therefore invalid.
- Results in a green font indicate the half decade that is currently measured.

<b>Start / Stop</b>	Shows the start and stop offset of the half decade.
<b>Sampling Rate</b>	Shows the sample rate used in the corresponding half decade.
<b>AVG</b>	Shows the number of measurements performed in the half decade to calculate the average (final) result.
<b>Freq Drift</b>	Shows the difference to the initial (nominal) frequency that was measured in the half decade.  If you perform more than one measurement (averages) in the half decade, the value is updated for each single measurement. The last value that has been measured in the half decade will remain in the table.

<b>Max Drift</b>	Shows the highest difference to the initial (nominal) frequency that was measured in the half decade.
<b>Level Drift</b>	Shows the difference to the initial (nominal) level that was measured in the half decade.  If you perform more than one measurement (averages) in the half decade, the value is updated for each single measurement. The last value that has been measured in the half decade will remain in the table.

Remote command:

Start offset: `FETCh:PNOise:SWEep:START?` on page 139

Stop offset: `FETCh:PNOise:SWEep:STOP?` on page 139

Sample rate: `FETCh:PNOise:SWEep:SRATe?` on page 139

Averages: `FETCh:PNOise:SWEep:AVG?` on page 137

Frequency drift: `FETCh:PNOise:SWEep:FDRift?` on page 138

Max drift: `FETCh:PNOise:SWEep:MDRift?` on page 138

Level drift: `FETCh:PNOise:SWEep:LDRift?` on page 138

### Spectrum Monitor


The spectrum monitor shows the spectrum for the half decade that is currently measured.

#### Span

The span on the x-axis is defined by the start and stop frequency of the half decade that is currently measured.

#### Y-axis scale

The scale of the y-axis is automatically determined according to the signal characteristics.



In I/Q mode, the result display contains two traces.

- The yellow trace ("raw trace") represents the live signal with the actual center frequency currently measured.

- The blue trace ("track trace") equalizes frequency drifting signals and thus shows a stable version of the signal with the intended center frequency.

If necessary, you can turn the traces on and off. For more information see ["Spectrum Monitor: Raw Trace / Trk Trace \(On Off\)"](#) on page 56.

The green vertical lines indicate the phase noise offset to be measured on in relation to the displayed center frequency. The position of the two green line depends on the half decade that is currently measured and the sample rate you have selected.

Remote command:

[TRACe \[ : DATA \] ?](#) on page 126

### Frequency Drift

The frequency drift shows the instantaneous frequency over time for the half decade that is currently measured.


### Time span

The displayed time span on the x-axis is defined by the time it takes to perform a measurement in the half decade that is currently measured. If the measurement time for a particular half decade is very long (several seconds), the application probably updates the result display several times. In that case, the application splits the measurement into several "sub-measurements".

### Y-axis scale

The scale of the y-axis is automatically determined according to the sample rate. For a better resolution, the trace is offset by the first measured frequency value. Thus, the trace always starts at 0 Hz. The initial correction value is displayed in the diagram as a numeric result.

To get a better resolution of the time axis, use the zoom function.





If necessary, you can turn the trace on and off. For more information see ["Frequency Drift: Trace 1 \(On Off\)"](#) on page 56.

### Frequency and Level Stability

The stability results show the current level and frequency drift characteristics of the carrier signal compared to the initial frequency and level. In addition to the numerical results, the result display also contains a graphical representation of the drift characteristics.

The result display contains the following results.

- **Carrier Stability**  
Difference between the 1st frequency that has been measured and the frequency that has been measured last.
- **Δ to Ref Level**  
Difference between the 1st level that has been measured and the level that has been measured last.

2 Frequency & Level Stability				
Type		Indicator		Value
Carrier Stability	-3.75 kHz		3.75 kHz	130.00 mHz
Δ to Ref Level				-0.57 dB

The results correspond to the Level Drift and Frequency Drift results displayed in the channel bar. For more information see "[Channel bar information](#)" on page 11

Note that the results are only valid for I/Q FFT measurements (see "[Global Sweep Mode](#)" on page 45).

### Reference Measurement

The reference measurement measures the inherent noise figure (DANL) of the R&S FSW.

To determine the inherent noise, the application performs a measurement without the signal at the input. The resulting trace shows the inherent noise of the R&S FSW only. When you subtract that inherent noise from the phase noise of the measurement with trace mathematics, you get a trace that shows the phase noise of the DUT only.

Remote command:

`CONFigure:REFMeas ONCE` on page 81

## 4 Measurement Basics

The measurement basics contain background information on the terminology and principles of phase noise measurements.

Phase noise measurements in general determine the single sideband phase noise characteristics of a device under test (DUT).

• <a href="#">Spurs and Spur Removal</a> .....	22
• <a href="#">Residual Effects</a> .....	23
• <a href="#">Measurement Range</a> .....	24
• <a href="#">Sweep Modes</a> .....	25
• <a href="#">Trace Averaging</a> .....	25
• <a href="#">Frequency Determination</a> .....	27
• <a href="#">Level Determination</a> .....	30
• <a href="#">Signal Attenuation</a> .....	30
• <a href="#">Using Limit Lines</a> .....	31
• <a href="#">Analyzing Several Traces - Trace Mode</a> .....	33
• <a href="#">Using Markers</a> .....	35

### 4.1 Spurs and Spur Removal

Most phase noise results contain spurs. Spurs are peak levels at one or more offset frequencies and are caused mostly by interfering signals. For some applications you may want to specifically indentify the location of spurs. However, for some applications, spurs do not matter in evaluating the results and you may want to remove them from the trace in order to get a "smooth" phase noise trace.

#### Spur removal

The application allows you to (visually) remove spurs from the trace. Spur removal is based on an algorithm that detects and completely removes the spurs from the trace and fills the gaps with data that has been determined mathematically.

The spur removal functionality separates the actual spur power from the underlying phase noise and displays the latter in a two-stage process. The first stage of spur detection is based on an eigenvalue decomposition during the signal processing.

#### Spur threshold

During the second stage, the application uses statistical methods to remove a spur. A spur is detected, if the level of the signal is above a certain threshold. The spur threshold is relative to an imaginary median trace that the application calculates.

If parts of the signal are identified as spurs, the application removes all signal parts above that level and substitutes them with the median trace.




Figure 4-1: Spur detection and removal principle

## 4.2 Residual Effects

Residual noise effects are modulation products that originate directly from the phase noise. It is possible to deduce them mathematically from the phase noise of a DUT.

The application calculates three residual noise effects. All calculations are based on an integration of the phase noise over a particular offset frequency range.

### Residual PM

The residual phase modulation is the contribution of the phase noise to the output of a PM demodulator. It is evaluated over the frequency range you have defined.

$$\text{Residual PM} = \sqrt{2 \cdot \int_{f_{\text{start}}}^{f_{\text{stop}}} L(f_m) df_m} \text{ [rad]}$$

with  $L(f)$  = single sideband phase noise [dBc/Hz]

### Residual FM

The residual frequency modulation is the contribution of the phase noise to the output of an FM demodulator. It is evaluated over the frequency range you have defined.

$$\text{Residual FM} = \sqrt{2 \cdot \int_{f_{\text{start}}}^{f_{\text{stop}}} f_m^2 L(f_m) df_m} \text{ [Hz]}$$

with  $L(f_m)$  = single sideband phase noise [dBc/Hz]

$f_m$  = frequency [Hz]

### Jitter

The jitter is the RMS temporal fluctuation of a carrier with the given phase noise evaluated over a given frequency range of interest.

$$\text{Jitter[s]} = \frac{\text{Residual PM [rad]}}{2\pi \cdot f_0}$$

with  $f_0$  = Carrier frequency





Figure 4-2: Residual noise based on an integration between 10 kHz and 100 kHz offset

## 4.3 Measurement Range

Noise measurements determine the noise characteristics of a DUT over a particular measurement range. This **measurement range** is defined by two offset frequencies. The **frequency offsets** themselves are relative to the nominal frequency of the DUT.

The measurement range again is divided into several (logarithmic) decades, or, for configuration purposes, into **half decades**.





**Figure 4-3: Measurement range and half decades**

This breakdown into several half decades is made to speed up measurements. You can configure each half decade separately in the "Half Decade Configuration Table". For quick, standardized measurements, the application provides several predefined sweep types or allows you to configure each half decade manually, but globally.

The main issue in this context is the **resolution bandwidth (RBW)** and its effect on the measurement time. In general, it is best to use a resolution bandwidth as small as possible for the most accurate measurement results. However, accuracy comes at the price of measurement speed.

To avoid very long measurement times, the application provides only a certain range of RBW that are available for each half decade.

## 4.4 Sweep Modes

Sweep modes define the data processing method.

### Swept

The application performs a sweep of the frequency spectrum.

### I/Q FFT

The application evaluates the I/Q data that has been collected and calculates the trace based on that data.

## 4.5 Trace Averaging

The application provides several modes of trace averaging that you can use separately or in any combination.

The order in which averaging is performed is as follows. For more details for each averaging mode see below.

1. Half decade averaging.

The application measures each half decade a particular number of times before measuring the next one.

2. Cross-correlation

The application performs a certain number of cross-correlation operations in each half decade.

3. Sweep Count.

The application measures the complete measurement range a particular number of times.

It again includes half decade averaging as defined.

After the measurement over the sweep count is finished, the application displays the averaged results.

4. Trace smoothing.

Calculates the moving average for the current trace.

#### 4.5.1 Half Decade Averaging

Define the number of measurements that the application performs for each half decade before it displays the averaged results and measures the next half decade.

In combination with the RBW, this is the main factor that has an effect on the measurement time. Typically you will use a small number of averages for small RBWs because small RBWs already provide accurate results and a high number of averages for high RBWs to get more balanced results.

#### 4.5.2 Sweep Count


The sweep count defines the number of sweeps that the application performs during a complete measurements.

A sweep in this context is the measurement over the complete measurement range once. A complete measurement, however, can consist of more than one sweep. In that case the application measures until the number of sweeps that have been defined are done. The measurement configuration stays the same all the time.

In combination with the Average trace mode and half decade averaging, the sweep count averages the trace even more.

#### 4.5.3 Trace Smoothing

(Software-based) **smoothing** is a way to visually remove anomalies in the trace that may distort the results. The smoothing process is based on a moving average over the complete measurement range. The number of samples included in the averaging process (the *aperture* size) is variable and is a percentage of all samples that the trace consists of.



**Figure 4-4: Sample size included in trace smoothing**

The application smoothes the trace only after the measurement has been finished and the data has been analyzed and written to a trace. Thus, smoothing is really just an enhancement of the trace display, not of the data itself. This also means that smoothing is always applied after any other trace averagings have been done, as these happen during the measurement itself.

You can turn trace smoothing on and off for all traces individually and compare, for example, the raw and the smooth trace.

Linear smoothing is based on the following algorithm:

$$y'(s) = \frac{1}{n} \left( \sum_{x=s-\frac{n-1}{2}}^{x=s+\frac{n-1}{2}} y(x) \right)$$

**Equation 4-1: Linear trace smoothing**

Logarithmic smoothing is based on the following algorithm:

$$y'(s) = 10 \cdot \log_{10} \left( \frac{1}{n} \left( \sum_{x=s-\frac{n-1}{2}}^{x=s+\frac{n-1}{2}} 10^{\left( \frac{y(x)}{10} \right)} \right) \right)$$

**Equation 4-2: Logarithmic trace smoothing**

$y(s)$  = logarithmic phase noise level

## 4.6 Frequency Determination

### Nominal frequency

The nominal frequency is the output or center frequency of the DUT. To get correct and valid measurement results, the application needs to know the real frequency of the DUT.



### Unverified signals

The R&S FSW tries to start the measurement as soon as you enter the phase noise application. If it cannot verify a signal, it will try to start the measurement over and over. To stop the repeated (and probably unsuccessful) signal verification, stop the measurement on the first verification failure.

The available (nominal) frequency range depends on the hardware you are using. For more information see the datasheet of the R&S FSW.

If you are not sure about the nominal frequency, define a tolerance range to verify the frequency. For measurements on unstable or drifting DUTs, use the frequency tracking functionality.

### Frequency verification

When you are using frequency verification, the application initiates a measurement that verifies that the frequency of the DUT is within a certain range of the nominal frequency. This measurement takes place before the actual phase noise measurement. Its purpose is to find strong signals within a frequency tolerance range and, if successful, to adjust the nominal frequency and lock onto that new frequency. The frequency tolerance is variable. You can define it in absolute or relative terms.




Figure 4-5: Frequency and level tolerance

You can define both absolute and relative tolerances. In that case, the application uses the higher tolerance to determine the frequency.

If there is no signal within the tolerance range, the application aborts the phase noise measurement.

In the numerical results, the application always shows the frequency the measurement was actually performed on. If the measured frequency is not the same as the nominal frequency, the numerical results also show the deviation from the nominal frequency.

### Frequency tracking

When you are using the frequency tracking, the application tracks drifting frequencies of unstable DUTs. It internally adjusts and keeps a lock on the nominal frequency of the DUT.




Figure 4-6: Frequency and level tracking

### Tracking bandwidth

The tracking bandwidth defines the bandwidth within which the application tracks the frequency.

Normally, the application adjusts the sample rate to the half decade it is currently measuring. For half decades that are near the carrier, the sample rate is small. Half decades far from the carrier use a higher sample rate. However, in case of drifting signals, this method may result in data loss because the default bandwidth for a half decade might be too small for the actual drift in the frequency. In that case, you can define the tracking bandwidth which increases the sample rate if necessary and thus increases the chance to capture the signal.




Figure 4-7: Frequency tracking with tracking bandwidth turned off (left) and a tracking bandwidth of 100 Hz (right)

## 4.7 Level Determination

### Nominal level

The nominal level in other terms is the reference level of the R&S FSW. This is the level that the analyzer expects at the RF input.

The available level range depends on the hardware. For more information see the datasheet of the R&S FSW.

Make sure to define a level that is as close to the level of the DUT to get the best dynamic range for the measurement. At the same time make sure that the signal level is not higher than the reference level to avoid an overload of the A/D converter and thus deteriorating measurement results.

If you are not sure about the power level of the DUT, but would still like to use the best dynamic range and get results that are as accurate as possible, you can verify or track the level.

### Level verification

When you are using the level verification, the application initiates a measurement that determines the level of the DUT. If the level of the DUT is within a certain tolerance range, it will adjust the nominal level to that of the DUT. Else, it will abort the phase noise measurement.

Define a level tolerance in relation to the current nominal level. The tolerance range works for DUT levels that are above or below the current nominal level.

### Level tracking

For tests on DUTs whose level varies, use level tracking. If active, the application keeps track of the DUTs level during the phase noise measurement and adjusts the nominal level accordingly.

For a graphical representation of level verification and level tracking see the figures in [Chapter 4.6, "Frequency Determination"](#), on page 27.

## 4.8 Signal Attenuation

Attenuation of the signal may become necessary if you have to reduce the power of the signal that you have applied. Power reduction is necessary, for example, to prevent an overload of the input mixer. An overload of the input mixer may lead to incorrect measurement results or damage to the hardware if the signal power is too strong.

In the default state, the application automatically determines the attenuation according to the reference level. If necessary, you can also define the attenuation manually.

When you attenuate the signal, the application adjusts graphical and numerical results accordingly.

Because the reference level and attenuation are interdependent, changing the attenuation manually may also adjust the reference level.

### RF attenuation

RF attenuation is always available. It is a combination of mechanical and IF attenuation.

The mechanical attenuator is located directly after the RF input of the R&S FSW. Its step size is 5 dB. IF attenuation is applied after the signal has been down-converted. Its step size is 1 dB.

Thus, the step size for RF attenuation as a whole is 1 dB. Mechanical attenuation is used whenever possible (attenuation levels that are divisible by 5). IF attenuation handles the 1 dB steps only.

### Example:

If you set an attenuation level of 18 dB, 15 dB are mechanical attenuation and 3 dB are IF attenuation.

If you set an attenuation level of 6 dB, 5 dB are mechanical attenuation and 1 dB is IF attenuation.

### Electronic attenuation

Electronic attenuation is available with R&S FSW-B25. You can use it in addition to mechanical attenuation. The step size of electronic attenuation is 1 dB with attenuation levels not divisible by 5 again handled by the IF attenuator. Compared to RF attenuation, you can define the amount of mechanical and electronic attenuation freely.

## 4.9 Using Limit Lines

Limit lines provide an easy way to verify if measurement results are within the limits you need them to be. As soon as you turn a limit line on, the application will indicate if the phase noise a trace displays is in line with the limits or if it violates the limits.

The application provides two kinds of limit lines. 'Normal' limit lines as you know them from the Spectrum application and special thermal limit lines for easy verification of thermal noise results.

### Phase noise limit lines

Phase noise limit lines have been designed specifically for phase noise measurements. Their shape is based on the thermal noise floor of the DUT and the typical run of the phase noise curve.

The typical slope of the phase noise curve depends on the offset from the DUT frequency. In the white noise range (the noise floor), far away from the carrier, the slope is more or less 0 dB per frequency decade. In the colored noise segment, the slope is greater than 0 dB. The slope, however, is not constant in that segment, but again is typical for various carrier offset segments (or ranges).

The application supports the definition of up to five ranges, each with a different slope. The ranges themselves are defined by corner frequencies. Corner frequencies are those frequencies that mark the boundaries of typical curve slopes. If you use all five ranges, the result would be a limit line with six segments.

All segments have a slope of 10 dB per decade ( $f^{-1}$ ) by default.

In most cases, these special limit lines will suffice for phase noise measurements as they represent the typical shape of a phase noise curve.




Figure 4-8: Typical looks of a special limit line

### Normal limit lines

Normal limit lines on the other hand may have any shape and may consist of up to 200 data points. You can turn on up to 8 normal limit lines at the same time. Each of those limit line can test one or several traces.

If you want to use them for phase noise measurements however, a limit line must be scaled in the unit dBc/Hz and must be defined on a logarithmic scale on the horizontal axis.






Figure 4-9: Possible looks of a normal limit line

## 4.10 Analyzing Several Traces - Trace Mode

If several sweeps are performed one after the other, or continuous sweeps are performed, the trace mode determines how the data for subsequent traces is processed. After each sweep, the trace mode determines whether:

- the data is frozen (View)
- the data is hidden (Blank)
- the data is replaced by new values (Clear Write)
- the data is replaced selectively (Max Hold, Min Hold, Average)




Each time the trace mode is changed, the selected trace memory is cleared.

The R&S FSW provides the following trace modes:

Table 4-1: Overview of available trace modes

Trace Mode	Description
Blank	Hides the selected trace.
Clear Write	Overwrite mode: the trace is overwritten by each sweep. This is the default setting.
Max Hold	The maximum value is determined over several sweeps and displayed. The R&S FSW saves the sweep result in the trace memory only if the new value is greater than the previous one.
Min Hold	The minimum value is determined from several measurements and displayed. The R&S FSW saves the sweep result in the trace memory only if the new value is lower than the previous one.
Average	The average is formed over several sweeps. The sweep count determines the number of averaging procedures.
View	The current contents of the trace memory are frozen and displayed.



If a trace is frozen ("View" mode), the instrument settings, apart from level range and reference level, can be changed without impact on the displayed trace. The fact that the displayed trace no longer matches the current instrument setting is indicated by the  icon on the tab label.

If the level range or reference level is changed, the R&S FSW automatically adapts the trace data to the changed display range. This allows an amplitude zoom to be made after the measurement in order to show details of the trace.

### Trace averaging algorithm

In "Average" trace mode, the sweep count determines how many traces are averaged. The more traces are averaged, the smoother the trace is likely to become.

The algorithm for averaging traces depends on the sweep mode and sweep count.

- sweep count = 0 (default)  
In continuous sweep mode, a continuous average is calculated for 10 sweeps, according to the following formula:

$$Trace = \frac{9 * Trace_{old} + MeasValue}{10}$$

Figure 4-10: Equation 1

Due to the weighting between the current trace and the average trace, past values have practically no influence on the displayed trace after about ten sweeps. With this setting, signal noise is effectively reduced without need for restarting the averaging process after a change of the signal.

- sweep count = 1  
The currently measured trace is displayed and stored in the trace memory. No averaging is performed.
- sweep count > 1  
For both "Single Sweep" mode and "Continuous Sweep" mode, averaging takes place over the selected number of sweeps. In this case the displayed trace is determined during averaging according to the following formula:

$$Trace_n = \frac{1}{n} \cdot \left[ \sum_{i=1}^{n-1} (T_i) + MeasValue_n \right]$$

Figure 4-11: Equation 2

where n is the number of the current sweep (n = 2 ... Sweep Count).

No averaging is carried out for the first sweep but the measured value is stored in the trace memory. With increasing n, the displayed trace is increasingly smoothed since there are more individual sweeps for averaging.

After the selected number of sweeps the average trace is saved in the trace memory. Until this number of sweeps is reached, a preliminary average is displayed.

When the averaging length defined by the "Sweep Count" is attained, averaging is continued in continuous sweep mode or for "Continue Single Sweep" according to the following formula:

$$Trace = \frac{(N - 1) * Trace_{old} + MeasValue}{N}$$

where N is the sweep count

## 4.11 Using Markers

Markers are used to mark points on traces, to read out measurement results and to select a display section quickly. The application provides 4 markers.

By default, the application positions the marker on the lowest level of the trace. You can change a marker position in several ways.

- Enter a particular offset frequency in the input field that opens when you activate a marker.
- Move the marker around with the rotary knob or the cursor keys.
- Drag the marker around using the touchscreen.

### 4.11.1 Marker Types

All markers can be used either as normal markers or delta markers. A normal marker indicates the absolute signal value at the defined position in the diagram. A delta marker indicates the value of the marker relative to the specified reference marker (by default marker 1).

In addition, special functions can be assigned to the individual markers. The availability of special marker functions depends on whether the measurement is performed in the frequency or time domain.

### 4.11.2 Activating Markers

Only active markers are displayed in the diagram and in the marker table. Active markers are indicated by a highlighted softkey.

By default, marker 1 is active and positioned on the maximum value (peak) of trace 1 as a normal marker. If several traces are displayed, the marker is set to the maximum value of the trace which has the lowest number and is not frozen (View mode). The next marker to be activated is set to the frequency of the next lower level (next peak) as a delta marker; its value is indicated as an offset to marker 1.

A marker can only be activated when at least one trace in the corresponding window is visible. If a trace is switched off, the corresponding markers and marker functions are also deactivated. If the trace is switched on again, the markers along with coupled functions are restored to their original positions, provided the markers have not been used on another trace.

# 5 Configuration

**Access:** MODE > "Phase Noise"

When you activate a measurement channel in the Phase Noise application, a measurement for the input signal is started automatically with the default configuration. The "Phase Noise" menu is displayed and provides access to the most important configuration functions.



## Automatic refresh of preview and visualization in dialog boxes after configuration changes


The R&S FSW supports you in finding the correct measurement settings quickly and easily - after each change in settings in dialog boxes, the preview and visualization areas are updated immediately and automatically to reflect the changes. Thus, you can see if the setting is appropriate or not before accepting the changes.

- [Configuration Overview](#).....36
- [Default Settings for Phase Noise Measurements](#)..... 37
- [Configuring the Frontend](#)..... 38
- [Controlling the Measurement](#).....40
- [Configuring the Measurement Range](#)..... 43
- [Performing Measurements](#).....46
- [Configuring In- and Outputs](#).....48
- [Automatic Measurement Configuration](#).....49

## 5.1 Configuration Overview



Throughout the measurement channel configuration, an overview of the most important currently defined settings is provided in the "Overview". The "Overview" is displayed when you select the "Overview" icon, which is available at the bottom of all softkey menus.



In addition to the main measurement settings, the "Overview" provides quick access to the main settings dialog boxes. The individual configuration steps are displayed in the order of the data flow. Thus, you can easily configure an entire measurement channel from input over processing to output and analysis by stepping through the dialog boxes as indicated in the "Overview".

In particular, the "Overview" provides quick access to the following configuration dialog boxes (listed in the recommended order of processing):

1. Frontend  
See [Chapter 5.3, "Configuring the Frontend"](#), on page 38.
2. Measurement Control  
See [Chapter 5.4, "Controlling the Measurement"](#), on page 40.
3. Phase Noise Measurement  
See [Chapter 5.5, "Configuring the Measurement Range"](#), on page 43.
4. Limit Analysis  
See [Chapter 6.3, "Using Limit Lines"](#), on page 58.
5. Graphical Results  
See [Chapter 6.1, "Configuring Graphical Result Displays"](#), on page 51.
6. Numerical Results  
See [Chapter 6.2, "Configure Numerical Result Displays"](#), on page 56.

#### To configure settings

- ▶ Select any button in the "Overview" to open the corresponding dialog box. Select a setting in the channel bar (at the top of the measurement channel tab) to change a specific setting.

#### Preset Channel

Select the "Preset Channel" button in the lower lefthand corner of the "Overview" to restore all measurement settings **in the current channel** to their default values.

Note that the PRESET key restores the entire instrument to its default values and thus closes **all measurement channels** on the R&S FSW (except for the default Spectrum application channel)!

Remote command:

`SYSTem:PRESet:CHANnel[:EXECute]` on page 79

## 5.2 Default Settings for Phase Noise Measurements

When you enter the phase noise application for the first time, a set of parameters is passed on from the currently active application:

- nominal or center frequency
- nominal or reference level

- input coupling

After initial setup, the parameters for the measurement channel are stored upon exiting and restored upon re-entering the channel. Thus, you can switch between applications quickly and easily.

Apart from these settings, the following default settings are activated directly after a measurement channel has been set to the Phase Noise application, or after a channel preset:


**Table 5-1: Default settings for phase noise measurement channels**

Parameter	Value
Attenuation	Auto (0 dB)
Verify frequency & level	On
Frequency & level tracking	Off
Measurement range	1 kHz ... 1 MHz
Sweep type	Normal
X axis scaling	Measurement range
Y axis scaling	20 dBc/Hz ... 120 dBc/Hz
Smoothing	1%
Smoothing type	Linear

## 5.3 Configuring the Frontend

**Access:** "Overview" > "Input / Frontend"

The "Frontend" tab of the "Measurement Settings" dialog box contains all functions necessary to configure the frontend of the RF measurement hardware.



Functions to configure the RF input described elsewhere:

- [Chapter 5.7.1, "Input Source Configuration"](#), on page 48

Nominal Frequency.....	39
Nominal Level.....	39
Mechanical Attenuator / Value.....	39
Coupling.....	39
Preamplifier.....	39

### Nominal Frequency

Defines the nominal frequency of the measurement.

For more information see [Chapter 4.6, "Frequency Determination"](#), on page 27.

Remote command:

`[SENSe:] FREQuency:CENTer` on page 92

### Nominal Level

Defines the nominal level of the R&S FSW.

For more information see [Chapter 4.7, "Level Determination"](#), on page 30

Remote command:

`[SENSe:] POWer:RLEVel` on page 93

### Mechanical Attenuator / Value

Turns mechanical attenuation on and off.

If on, you can define an attenuation level in 5 dB steps.

For more information see [Chapter 4.8, "Signal Attenuation"](#), on page 30.

Remote command:

Turning manual attenuation on and off:

`INPut:ATTenuation:AUTO` on page 94

Defining an attenuation level:

`INPut:ATTenuation` on page 93

### Coupling

Selects the coupling method at the RF input.

AC coupling blocks any DC voltage from the input signal. DC coupling lets DC voltage through.

For more information refer to the data sheet.

Remote command:

`INPut:COUPling` on page 94

### Preamplifier

If the (optional) Preamplifier hardware is installed, a preamplifier can be activated for the RF input signal.

You can use a preamplifier to analyze signals from DUTs with low output power.

For R&S FSW26 or higher models, the input signal is amplified by 30 dB if the preamplifier is activated.

For R&S FSW8 or 13 models, the following settings are available:

"Off"                      Deactivates the preamplifier.

"15 dB"                    The RF input signal is amplified by about 15 dB.

"30 dB" The RF input signal is amplified by about 30 dB.

Remote command:


`INPut:GAIN:STATe` on page 94

`INPut:GAIN[:VALue]` on page 95

## 5.4 Controlling the Measurement

**Access:** "Overview" > "Measurement Control"

The "Control" tab of the "Measurement Settings" dialog box contains all functions necessary to control the sequence of the phase noise measurement.



Verify Frequency.....	40
Verify Level.....	41
On Verify Failed.....	41
Frequency Tracking.....	41
Level Tracking.....	41
AM Rejection.....	42
Max Freq Drift.....	42
Digital PLL.....	42
Decimation.....	42
Online I/Q.....	42

### Verify Frequency

Turns frequency verification on and off.

If frequency verification is on, the R&S FSW initiates the phase noise measurement only if the frequency of the DUT is within a certain frequency tolerance range. The tolerance range is either a percentage range of the nominal frequency or an absolute deviation from the nominal frequency.

If you define both an absolute and relative tolerance, the application uses the higher tolerance level.

For more information see [Chapter 4.6, "Frequency Determination"](#), on page 27.

Remote command:

Verify frequency:

`[SENSe:]FREQuency:VERify[:STATe]` on page 96

Relative tolerance:

`[SENSe:]FREQuency:VERify:TOLerance:RELative` on page 96



Absolute tolerance:

[\[SENSe:\] FREQuency:VERify:TOLerance:ABSolute](#) on page 96

### Verify Level

Turns level verification on and off.

If level verification is on, the R&S FSW initiates the phase noise measurement only if the level of the DUT is within a certain level tolerance range. The tolerance range is a level range relative to the nominal level.

For more information see [Chapter 4.7, "Level Determination"](#), on page 30.

Remote command:

Verify level:

[\[SENSe:\] POWer:RLEVel:VERify\[:STATe\]](#) on page 98

Level tolerance:

[\[SENSe:\] POWer:RLEVel:VERify:TOLerance](#) on page 98

### On Verify Failed

Selects the way the application reacts if signal verification fails.

Takes effect on both frequency and level verification.

"Restart"            Restarts the measurement if verification has failed.

"Stop"                Stops the measurement if verification has failed.

"Run Auto All"      Starts an automatic frequency and level detection routine if verification has failed. After the new frequency and level have been set, the measurement restarts. For more information see [Chapter 5.8, "Automatic Measurement Configuration"](#), on page 49.

Remote command:

[\[SENSe:\] SWEep:SVFailed](#) on page 99

### Frequency Tracking

Turns frequency tracking on and off.

If on, the application tracks the frequency of the DUT during the phase noise measurement and adjusts the nominal frequency accordingly. The application adjusts the frequency after each half decade measurement.

For more information see [Chapter 4.6, "Frequency Determination"](#), on page 27.

Remote command:

[\[SENSe:\] FREQuency:TRACk](#) on page 95

### Level Tracking

Turns level tracking on and off.

If on, the R&S FSW tracks the level of the DUT during phase noise measurements and adjusts the nominal level accordingly. The application adjusts the level after each half decade measurement.

For more information see [Chapter 4.7, "Level Determination"](#), on page 30.

Remote command:

[\[SENSe:\] POWer:TRACk](#) on page 98

**AM Rejection**

Turns the suppression of AM noise on and off.

If on, the application suppresses the AM noise that the signal contains in order to display phase noise as pure as possible.

AM rejection is available for the I/Q sweep mode.

Remote command:

[\[SENSe:\] REJect:AM](#) on page 99

**Max Freq Drift**

Defines the minimum bandwidth or sample rate used in the signal processing to increase the probability of capture drifting signals.

The tracking bandwidth is valid for all half decades measured in I/Q mode.

Remote command:

[\[SENSe:\] IQ:TBW](#) on page 98

**Digital PLL**

Turns an additional frequency correction based on the I/Q data on and off.

If on, the application is able to track frequency changes during the I/Q data capture that would otherwise fall into the half decade measurement bandwidth (see [Max Freq Drift](#)).

The digital PLL works for all half decades measured in I/Q mode.

Remote command:

[\[SENSe:\] IQ:DPLL](#) on page 97

**Decimation**

Turns decimation on and off.

When you turn on decimation, the samples that have already been used for a given half decade are resampled in lower half decades. Reusing these samples results in lower measurement times in the lower half decades, because less samples have to be recorded there.

To get valid results for lower offset frequencies, make sure to use an appropriate sample rate.

This feature is especially useful when you are measuring half decades with very low offset frequencies.

Using decimation is available for the "I/Q FFT" sweep mode.

Remote command:

[\[SENSe:\] IQ:DECimation](#) on page 97

**Online I/Q**

Turns the online measurement mode for I/Q measurements on and off.

When you turn the online measurement mode on, the application records smaller amounts of data at a time. It is thus able to process that data faster, because it does not have to wait until the I/Q capture buffer is full, before processing the data.. The result is that the measurement results are updated faster.

This mode is useful to measure the phase noise at small offset frequencies, because the small bandwidths required to measure these offset frequencies usually lead to long measurement times (and especially when you apply averaging).

In the Half Decade Configuration Table, half decades that are measured in online mode are highlighted in a darker shade of green (compared to the shade of green that is used to highlight the half decades that are taken into account in the measurement).

10 kHz	30 kHz	300 Hz	10	I/Q FFT	Blackman-Harris	< 0.1 s
30 kHz	100 kHz	1 kHz	10	I/Q FFT	Blackman-Harris	< 0.1 s

Light green = normal I/Q mode  
 Dark green = online I/Q mode

The online measurement mode is available under the following conditions:

- Only half decades with a frequency offset smaller than 30 kHz can be measured in online mode.
- The half decades that you want to measure in online mode have to be set to "I/Q FFT" sweep mode.
- Decimation has to be turned on.
- Sweep Forward has to be turned off.


Remote command:

[SENSe:] IQ:ONLine on page 97

## 5.5 Configuring the Measurement Range

**Access:** "Overview" > "Phase Noise Meas"

The "Phase Noise" tab of the "Measurement Settings" dialog box contains all funtions necessary to configure the measurement range for phase noise measurements, including individual range settings.



Range Start / Stop.....	44
Sweep Forward.....	44
Presets.....	44
Global RBW.....	44
Global Average Count.....	45
Multiplier.....	45
Global Sweep Mode.....	45
Global I/Q Window.....	45
Half Decades Configuration Table.....	46

**Range Start / Stop**

Defines the frequency offsets that make up the measurement range.

Note that the maximum offset you can select depends on the hardware you are using.

If a "Preamplifier" on page 39 is used, make sure the entire frequency range is covered by the preamplifier.

Remote command:

Measurement Range Start

[SENSe:] FREQuency: START on page 101

Measurement Range Stop

[SENSe:] FREQuency: STOP on page 101

**Sweep Forward**

Selects the sweep direction. Forward and reverse sweep direction are available.

Forward sweep direction performs a measurement that begins at the smallest frequency offset you have defined. The measurement ends after the largest offset has been reached.

Reverse sweep direction performs a measurement that begins at the largest frequency offset you have defined. The measurement ends after the smallest offset has been reached. The reverse sweep is the default sweep direction because the application is able to lock on a drifting carrier frequency in that case.

Remote command:

[SENSe:] SWEep: FORWard on page 105

**Presets**

Selects predefined measurement settings for each individual half decade that are used for the measurement.

If the measurement settings differ from one of the preset states, the application displays a symbol (🚩) at the label.

"Fast"	Fast measurements perform one measurement in each half decade. No averaging takes place.
"Normal"	Normal measurements use averaging for some half decades, but with respect to measurement speed.
"Average"	Average measurements use averaging for all half decades. However, you have to put up with slower measurement speed.
"Manual"	Manual configuration of the measurement range.

Remote command:

[SENSe:] SWEep: MODE on page 106

**Global RBW**

Defines the resolution bandwidth for all half decades globally.

The resulting RBW is a percentage of the start frequency of the corresponding half decade.

If the resulting RBW is not available, the application rounds to the next available bandwidth.

You can also change the global bandwidth with the "RBW Global" softkey in the "Bandwidth" menu.

Remote command:

`[SENSe:]LIST:BWIDth[:RESolution]:RATio` on page 100

### Global Average Count

Defines the number of measurements that the application uses to calculate averaged results in each half decade.

The range is 1 to 10000.

Remote command:

`[SENSe:]LIST:SWEep:COUNT` on page 104

### Multiplier

Turns a multiplier that changes the average count in each half decade on and off.

If on, you can define a value that multiplies the number of averages currently defined for each half decade by that value.

When you turn it off, the original averages are restored and used again.

### Example:

You have three half decades:

- 1st half decade average count: 1
- 2nd half decade average count: 3
- 3rd half decade average count: 5

If you turn the multiplier on and define a value of 5, the average count changes as follows:

- 1st half decade average count: 5
- 2nd half decade average count: 15
- 3rd half decade average count: 25

Remote command:

`[SENSe:]LIST:SWEep:COUNT:MULTiplier` on page 105

`[SENSe:]LIST:SWEep:COUNT:MULTiplier:STATe` on page 105

### Global Sweep Mode

Selects the analysis mode for all half decades. The sweep mode defines the way the application processes the data.

For more information see [Chapter 4.4, "Sweep Modes"](#), on page 25.

"Normal"            Uses spectrum analyzer data for the data analysis.

"I/Q / FFT"        Uses I/Q data for the data analysis.

Remote command:

`[SENSe:]LIST:BWIDth:RESolution:TYPE` on page 102

### Global I/Q Window

Selects the window function for all half decades.

The window function is available for I/Q analysis.

"Blackman Harris" Blackman Harris window.

"Chebychev" Chebychev window.

"Gaussian" Gaussian window.

"Rectangular" Rectangular window.

Remote command:

[\[SENSe\]:LIST:IQWindow:TYPE](#) on page 102

### Half Decades Configuration Table

Contains all functionality to configure the phase noise measurement range.

"Start" Shows the offset frequency that the half decade starts with.

"Stop" Shows the offset frequency that the half decade stops with.  
**Tip:** Note that double-clicking on one of the start or stop offset values is an easy way to adjust the measurement range.

"RBW" Selects resolution bandwidth for the half decade.  
 To avoid invalid measurements and long measurement times, the availability of RBW for each half decade is limited.

"Sweep Mode" Selects the measurement mode. The measurement mode is the way the application analyzes the data.

- Swept
- I/Q / FFT

For more information see [Chapter 4.4, "Sweep Modes"](#), on page 25.

"AVG" Defines the number of averagings that the application performs before the results for a half decade are displayed.

"Window" Selects the window type for a half decade.  
 Window functions are available for I/Q measurements.

"Meas Time" Shows an estimation of how long the measurement of a half decade lasts.

Remote command:

RBW:

[\[SENSe:\]LIST:RANGe<range>:BWIDth\[:RESolution\]](#) on page 103

Sweep Mode

[\[SENSe:\]LIST:RANGe<range>:FILTer:TYPE](#) on page 103

Averages:

[\[SENSe:\]LIST:RANGe<range>:SWEep:COUNT](#) on page 104

Window:

[\[SENSe:\]LIST:RANGe<range>:IQWindow:TYPE](#) on page 103

## 5.6 Performing Measurements

**Access:** SWEEP

The "Sweep" menu contains all functionality necessary to control and perform phase noise measurements.

Functions to configure the sweep described elsewhere:

- "Multiplier" on page 45
- "Global Average Count" on page 45

Continuous Sweep/RUN CONT.....	47
Single Sweep/ RUN SINGLE.....	47
Continue Single Sweep.....	47
Sweep / Average Count.....	47
Finish Half Decade.....	48

### Continuous Sweep/RUN CONT

After triggering, starts the sweep and repeats it continuously until stopped. This is the default setting.

While the measurement is running, the "Continuous Sweep" softkey and the RUN CONT key are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again. The results are not deleted until a new measurement is started.

**Note:** Sequencer. Furthermore, the RUN CONT key controls the Sequencer, not individual sweeps. RUN CONT starts the Sequencer in continuous mode. For details on the Sequencer, see the R&S FSW User Manual.

Remote command:

`INITiate<n>:CONTinuous` on page 81

### Single Sweep/ RUN SINGLE

While the measurement is running, the "Single Sweep" softkey and the RUN SINGLE key are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again.

**Note:** Sequencer. Furthermore, the RUN SINGLE key controls the Sequencer, not individual sweeps. RUN SINGLE starts the Sequencer in single mode.

If the Sequencer is off, only the evaluation for the currently displayed measurement channel is updated.

Remote command:

`INITiate<n>[:IMMediate]` on page 82

### Continue Single Sweep

After triggering, repeats the number of sweeps set in "Sweep Count", without deleting the trace of the last measurement.

While the measurement is running, the "Continue Single Sweep" softkey and the RUN SINGLE key are highlighted. The running measurement can be aborted by selecting the highlighted softkey or key again.

Remote command:

`INITiate<n>:CONMeas` on page 81

### Sweep / Average Count

Defines the number of sweeps to be performed in the single sweep mode. Values from 0 to 200000 are allowed. If the values 0 or 1 are set, one sweep is performed.

The sweep count is applied to all the traces in all diagrams.

If the trace modes "Average", "Max Hold" or "Min Hold" are set, this value also determines the number of averaging or maximum search procedures.

In continuous sweep mode, if sweep count = 0 (default), averaging is performed over 10 sweeps. For sweep count = 1, no averaging, maxhold or minhold operations are performed.

Remote command:

[SENSe:] SWEEp:COUNT on page 84

#### Finish Half Decade

Aborts the measurement in the current half decade and continues measuring the subsequent half decade.

Averaged results displayed for a half decade finished prematurely are based on the number of measurements already done.

Remote command:

[SENSe:] SWEEp:FHDecade on page 84

## 5.7 Configuring In- and Outputs

The "In- / Output" menu contains all functionality necessary to control and perform phase noise measurements.

For more information on configuring the input mixer see the manual of the R&S FSW.

- [Input Source Configuration](#)..... 48
- [External Mixer Configuration](#).....49

### 5.7.1 Input Source Configuration

**Access:** "Overview" > "Input / Frontend" > "Input Source Config"

The "Radio Frequency" dialog box contains functionality to configure the input source.

Note that the "Radio Frequency (On Off)" button is unavailable in the R&S FSW-K40

- [Coupling](#)..... 48
- [Input Connector](#)..... 48

#### Coupling

Selects the coupling method at the RF input.

AC coupling blocks any DC voltage from the input signal. DC coupling lets DC voltage through.

For more information refer to the data sheet.

Remote command:

INPut:COUPling on page 94

#### Input Connector

Selects the input source.



The Phase Noise application supports the following input sources:

- RF Input
- Analog Baseband Input
  - The "Baseband Input I" requires option R&S FSW-B71.

Remote command:

[INPut:CONNector](#) on page 146

## 5.7.2 External Mixer Configuration

The "External Mixer" dialog box contains functionality to configure an external mixer (R&S FSW-B21).

Please refer to the User Manual of the R&S FSW for a detailed description on how to configure the external mixer.

## 5.8 Automatic Measurement Configuration

**Access:** AUTO SET

The "Auto Set" menu contains all functionality necessary to determine measurement parameters automatically.

<a href="#">Adjusting all Determinable Settings Automatically (Auto All)</a> .....	49
<a href="#">Adjusting the Center Frequency Automatically (Auto Freq)</a> .....	49
<a href="#">Setting the Reference Level Automatically (Auto Level)</a> .....	50

### **Adjusting all Determinable Settings Automatically (Auto All)**

Activates all automatic adjustment functions for the current measurement settings.

This includes:

- [Auto Frequency](#)
- [Auto Level](#)

Remote command:

[\[SENSe:\]ADJust:ALL](#) on page 147

### **Adjusting the Center Frequency Automatically (Auto Freq)**

The R&S FSW adjusts the center frequency automatically.

The optimum center frequency is the frequency with the highest S/N ratio in the frequency span. As this function uses the signal counter, it is intended for use with sinusoidal signals.

Remote command:

[\[SENSe:\]ADJust:FREQuency](#) on page 147

**Setting the Reference Level Automatically (Auto Level)**

Automatically determines a reference level which ensures that no overload occurs at the R&S FSW for the current input data. At the same time, the internal attenuators and the preamplifier (for analog baseband input: the full scale level) are adjusted so the signal-to-noise ratio is optimized, while signal compression and clipping are minimized.

To determine the required reference level, a level measurement is performed on the R&S FSW.

If necessary, you can optimize the reference level further. Decrease the attenuation level manually to the lowest possible value before an overload occurs, then decrease the reference level in the same way.

Remote command:

`[SENSe:]ADJust:LEVel` on page 147

# 6 Analysis


The application provides various means and methods to analyze and evaluate measurement results.

- [Configuring Graphical Result Displays](#).....51
- [Configure Numerical Result Displays](#).....56
- [Using Limit Lines](#).....58
- [Using Markers](#).....65

## 6.1 Configuring Graphical Result Displays

**Access:** "Overview" > "Graphical Results"

The "Graphical" tab of the "Results" dialog box and the "Trace" menu contain all functions necessary to set up and configure the graphical phase noise result displays.



- [Scaling the Diagram](#).....51
- [Configuring Traces](#).....53

### 6.1.1 Scaling the Diagram

- [X-Axis Scope](#).....51
- [X-Axis Start / Stop](#).....52
- [Half Decade](#).....52
- [Y Axis Scaling](#).....52
- [Top / Range / Bottom](#).....52
- [Auto Scale Once](#).....53

#### X-Axis Scope

Selects the way the application scales the horizontal axis.

- "Half Decade" The horizontal axis shows one half decade that you can select.
- "Manual" The horizontal axis shows a detail of the measurement range that you can define freely.
- "Meas Range" The horizontal axis shows the complete measurement range.

Remote command:

[DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:SCOPE](#) on page 121

### X-Axis Start / Stop

Defines the start and stop frequency of the horizontal axis.

Note that the displayed frequency range is a detail of the measurement range. Regardless of the displayed frequency range, the application still performs all measurement over the measurement range you have defined.

The range depends on the measurement range. and possible increments correspond to the half decades.

Available for a manual "X Axis Scope".

Remote command:

X-axis start:

[DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:START](#) on page 121

X-axis stop:

[DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:STOP](#) on page 121

### Half Decade

Selects the half decade that is displayed.

Available if you have selected the half decade "X Axis Scope".

Remote command:

[DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:HDECade](#) on page 120

### Y Axis Scaling

Selects the type of scaling for the vertical axis.

"Auto" Automatically scales the vertical axis.

"Top & Bottom" Allows you to set the values at the top and bottom of the vertical axis.

"Top & Range" Allows to set the value at the top of the vertical axis and its range.

"Bottom & Range" Allows you to set the value at the bottom of the vertical axis and its range.

Remote command:

Automatic scaling:

[DISPlay\[:WINDow\]:TRACe:Y\[:SCALe\]:AUTO](#) on page 122

Manual scaling:

[DISPlay\[:WINDow\]:TRACe:Y\[:SCALe\]:MANual](#) on page 122

### Top / Range / Bottom

Define the top and bottom values or the range of the vertical axis.

Top defines the top values of the vertical axis. The unit is dBm/Hz.

Bottom defines the bottom value of the vertical axis. The unit is dBm/Hz.

Range defines the range of the vertical axis. The unit is dB.

The availability of the three fields depends on the type of manual "Y Axis Scaling" you have selected.

Remote command:

Top:

`DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel` on page 123

Range:

`DISPlay[:WINDow]:TRACe:Y[:SCALe]` on page 122

Bottom:

`DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel:LOWer` on page 123

### Auto Scale Once

Automatically scales the vertical axis for ideal viewing.

## 6.1.2 Configuring Traces

Trace Offset.....	53
Trace Smoothing.....	53
Smoothing Type.....	53
Trace Config.....	54
L Traces.....	54
L Quick Config.....	54
L Trace Export.....	55
L Copy Trace.....	55
L Trace Math.....	56
Spur Removal / Spur Threshold.....	56
Frequency Drift: Trace 1 (On Off).....	56
Spectrum Monitor: Raw Trace / Trk Trace (On Off).....	56

### Trace Offset

Defines a trace offset in dB.

The trace offset moves the trace vertically by the level you have defined.

The range is from -200 dB to 200 dB.

Remote command:

`DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel:OFFSet` on page 124

### Trace Smoothing

Defines the magnitude (or aperture) of trace smoothing in percent.

The range is from 1% to 20%. The aperture takes effect on all traces that you smooth.

For more information see [Chapter 4.5.3, "Trace Smoothing"](#), on page 26.

Remote command:

`DISPlay[:WINDow]:TRACe<t>:SMOothing:APERture` on page 119

### Smoothing Type

Selects the method that the application uses to smooth the trace.

For more information see [Chapter 4.5.3, "Trace Smoothing"](#), on page 26.

"Linear"            Converts the data to linear values before smoothing the trace.

"Logarithmic"    Smooths the (original) logarithmic data.

"Median"            Smooths the trace based on the median value of the sample.

Remote command:

`DISPlay[:WINDow]:TRACe<t>:SMOothing:TYPE` on page 119

### Trace Config

Opens a dialog box to configure traces.

The application supports up to 6 traces with a different setup. In the diagram each trace has a different color.

The diagram header of the measurement window contains the trace information, including a color map, trace mode and smoothing percentage.

Note that trace configuration is also possible in the "Trace" softkey menu available via the TRACE key.

### Traces ← Trace Config

The "Traces" tab contains functionality to configure a trace.

"Trace Selection"	The "Trace 1" to "Trace 6" buttons select a trace. If a trace is selected, it is highlighted orange. Note that you cannot select a trace if its trace mode is "Blank".
"Trace Mode"	Selects the trace mode for the corresponding trace. For more information see <a href="#">Chapter 4.10, "Analyzing Several Traces - Trace Mode"</a> , on page 33.
"Smoothing"	Turns trace smoothing for the corresponding trace on and off. For each trace, the application allows you to select the smoothing type and percentage. For more information see <a href="#">Chapter 4.5.3, "Trace Smoothing"</a> , on page 26 (→ "Graphical" tab).
"Spur Removal"	Turns spur removal on a particular trace on and off. You can define a threshold above which a spur is detected with the <a href="#">Threshold</a> parameter. For more information see <a href="#">Chapter 4.1, "Spurs and Spur Removal"</a> , on page 22.

Remote command:

Trace mode: `DISPlay[:WINDow]:TRACe<t>:MODE` on page 118

Trace smoothing: `DISPlay[:WINDow]:TRACe<t>:SMOothing[:STATE]` on page 119

Spur removal: `DISPlay[:WINDow]:TRACe<t>:SPURs:SUPPpress` on page 120

### Quick Config ← Trace Config

Commonly required trace settings have been predefined and can be applied very quickly by selecting the appropriate button.

Preset All Traces	Resets all traces to their default mode. Trace 1 - 2 mode = Clear Write; Trace 3 - 6 mode = Blank Trace 1 smoothing = On, Trace 2 - 6 smoothing = Off
Set Trace Mode Max   Avg   Min	Trace 1 mode: Max Hold Trace 2 mode: Average Trace 3 mode: Min Hold
Set Trace Mode Max   ClrWrite   Min	Trace 1 mode: Max Hold Trace 2 mode: Clear Write Trace 3 mode: Min Hold

### Trace Export ← Trace Config

The "Trace Export" tab contains functionality to export trace data.

"Export all traces and all table results"	Turns the export of all measurement results (traces and numerical results) on and off. If on, selecting a particular trace to export in the "Trace to Export" dropdown menu is unavailable.
"Include Instrument Measurement Settings"	Includes or excludes the measurement configuration as shown in the channel bar from the export.
"Trace to Export"	Selects the trace that will be exported to a file.
"Decimal Separator"	Selects the decimal separator for floating-point numerals for the ASCII Trace export. Evaluation programs require different separators in different languages.
"Export Trace to ASCII File"	Opens a file selection dialog box and saves the selected trace in ASCII format to the specified file and directory.

Remote command:

Decimal separator:

[FORMat:DEXPort:DSEParator](#) on page 124

Export trace to ASCII file:

[MMEMory:STORe<n>:TRACe](#) on page 125

Selecting a trace:

[FORMat:DEXPort:TRACes](#) on page 124

Export the header:

[FORMat:DEXPort:HEADer](#) on page 124

### Copy Trace ← Trace Config

**Access:** "Overview" > "Analysis" > "Traces" > "Copy Trace"

Or: TRACE > "Copy Trace"

Copies trace data to another trace.

The first group of buttons (labeled "Trace 1" to "Trace 6") selects the source trace. The second group of buttons (labeled "Copy to Trace 1" to "Copy to Trace 6") selects the destination.

Remote command:

[TRACe<n>:COPY](#) on page 126

#### **Trace Math ← Trace Config**

The "Trace Math" tab contains functionality to control trace mathematics.

"State" Turns trace mathematics on and off.

"Expression" Selects the mathematical operation.

Remote command:

State:

[CALCulate<n>:MATH:STATE](#) on page 118

Expression:

[CALCulate<n>:MATH\[:EXpression\] \[:DEFine\]](#) on page 118

#### **Spur Removal / Spur Threshold**

Turns spur removal for all traces on and off and defines the threshold for spur removal.

For more information see [Chapter 4.1, "Spurs and Spur Removal"](#), on page 22.

Note that you can also remove spurs for individual traces in the "Trace Config" dialog box.

Remote command:

Turn spur suppression on and off:

[\[SENSe:\]SPURs:SUPPression](#) on page 125

Set the threshold:

[\[SENSe:\]SPURs:THReshold](#) on page 126

#### **Frequency Drift: Trace 1 (On Off)**

Turns the trace displayed in the Frequency Drift result display on and off.

#### **Spectrum Monitor: Raw Trace / Trk Trace (On Off)**

Turns the traces displayed in the Spectrum Monitor result display on and off.

The "Raw Trace (On Off)" softkey controls the yellow trace.

The "Trk Trace (On Off)" softkey controls the blue trace.

## **6.2 Configure Numerical Result Displays**

**Access:** "Overview" > "Numerical Results"

The "Numerical" tab of the "Results" dialog box contains all functions necessary to set up and configure the numerical phase noise result displays.





## 6.2.1 Configuring Residual Noise Measurements

<a href="#">Meas Range</a> .....	57
<a href="#">User Range</a> .....	57

### Meas Range

Turns the integration of the entire measurement range for residual noise calculations on and off.

The range defined here is applied to all traces.

"On"                    The application calculates the residual noise over the entire measurement range.

"Off"                    The application calculates the residual noise over a customized range.  
The input fields next to the "On/Off" control become available to define a customized integration range. The application shows two red lines ("EL1" and "EL2") in the graphical result display to indicate the custom range.

Remote command:

Turn customized range on and off:

[CALCulate<n>:EVALuation\[:STATe\]](#) on page 128

Define start point of custom range:

[CALCulate<n>:EVALuation:START](#) on page 127

Define end point of custom range:

[CALCulate<n>:EVALuation:STOP](#) on page 128

### User Range

Defines a custom range for residual noise calculations. You have to assign a user range to a particular trace.

In the default state, user ranges are inactive. "None" is selected in the dropdown menu. If you assign the user range to a trace by selecting one of the traces from the dropdown menu, the input fields next to the trace selection become active. In these fields, you can define a start and stop offset frequency.

Remote command:

Selecting a trace:

[CALCulate<n>:EVALuation:USER<range>:TRACe](#) on page 129

Define start frequency of user range:

[CALCulate<n>:EVALuation:USER<range>:START](#) on page 129

Define stop frequency of user range:

[CALCulate<n>:EVALuation:USER<range>:STOP](#) on page 129

## 6.2.2 Configuring Spot Noise Measurements

<a href="#">On All Decade Edges</a> .....	58
<a href="#">On User Defined Offsets / Offset Frequency</a> .....	58

### On All Decade Edges

Turns the calculation of spot noise on all 10<sup>x</sup> offset frequencies on and off.

Remote command:

Turn on and off spot noise calculation on 10<sup>x</sup> offset frequencies:

[CALCulate<n>:SNOise:DECades\[:STATe\]](#) on page 133

Querying spot noise results on 10<sup>x</sup> offset frequencies:

[CALCulate<n>:SNOise:DECades:X?](#) on page 133

[CALCulate<n>:SNOise:DECades:Y?](#) on page 133

### On User Defined Offsets / Offset Frequency

Turns custom spot noise frequencies on and off.

If on, the "Offset Frequency" input fields become available. You can measure the spot noise for up to five custom offset frequencies. If active, the application adds those spots to the spot noise table.

Remote command:

Turning spot noise marker on and off:

[CALCulate<n>:SNOise<m>:STATe](#) on page 134

[CALCulate<n>:SNOise:AOFF](#) on page 132

Positioning spot noise markers:

[CALCulate<n>:SNOise<m>:X](#) on page 134


Querying custom spot noise results:

[CALCulate<n>:SNOise<m>:Y?](#) on page 135

## 6.3 Using Limit Lines

**Access:** "Overview" > "Limit Analysis"

The "Limits" tab of the "Results" dialog box contains all functions necessary to set up and configure limit lines.



### 6.3.1 Using Phase Noise Limit Lines

Phase Noise Limit Line.....	59
Selected Traces.....	59
Noise Floor.....	59
Range x - Range y.....	59
Copy to User Limit Line.....	60

#### Phase Noise Limit Line

Selects the shape of the phase noise limit line.

For more information see [Chapter 4.9, "Using Limit Lines"](#), on page 31.

- "None"            No limit line.
- "Noise floor    Limit line defined by the noise floor and x corner frequencies and  
and x Ranges"   slopes. The application supports up to 5 ranges.

Remote command:  
`CALCulate:PNLimit:TYPE` on page 108

#### Selected Traces

Selects the trace(s) to assign a phase noise limit line to.

For more information see [Chapter 4.9, "Using Limit Lines"](#), on page 31.

Remote command:  
`CALCulate:PNLimit:TRACe` on page 108

#### Noise Floor

Defines the noise floor level in dBm/Hz of the DUT.

For more information see [Chapter 4.9, "Using Limit Lines"](#), on page 31.

Remote command:  
`CALCulate:PNLimit:NOISe` on page 107

#### Range x - Range y

Defines the corner frequencies and slope for a particular segment of phase noise limit lines.

The slope defines the slope of the limit line segment to the left of the corner frequency.

For more information see [Chapter 4.9, "Using Limit Lines"](#), on page 31.

Remote command:

Corner frequencies:

[CALCulate:PNLimit:FC5](#) on page 107

Slope:

[CALCulate:PNLimit:SLOPe<segment>](#) on page 109

**Copy to User Limit Line**

Creates a new user limit line from the data of a phase noise limit line.

The file is stored in the default folder for user limit lines. You can load and edit the limit line via the "Select Limit Line" dialog box. For more information see ["Select Limit Line"](#) on page 60.

Remote command:

[CALCulate:PNLimit:COPY<k>](#) on page 106

**6.3.2 Selecting Standard Limit Lines**

**Access:** "Overview" > "Limit Analysis" > "Line Config"

[Select Limit Line](#).....60

- L [Name](#)..... 61
- L [Unit](#).....61
- L [Compatible](#).....61
- L [Visible](#)..... 61
- L [Check Traces](#).....61
- L [Comment](#)..... 62
- L [View Filter](#)..... 62
- L [New / Edit / Copy To](#).....62
- L [Delete](#).....62
- L [Disable All Lines](#)..... 62

**Select Limit Line**

The "Select Limit Line" dialog box contains functionality to include standard limit lines in the measurement.

The dialog box consists of a table that shows all available limit lines and their characteristics and a few buttons to manage individual limit lines.

**Name ← Select Limit Line**

Shows the name of the limit line.

**Unit ← Select Limit Line**

Shows the unit of the limit line.

**Compatible ← Select Limit Line**

Shows if the limit line is compatible to the current measurement setup or not.

"Yes"                    You can use the limit line because it is compatible to the current measurement setup.

"No"                     You cannot use the limit line because it is compatible to the current measurement setup.

**Visible ← Select Limit Line**

Displays a limit line in the diagram area.

You can display up to eight limit lines at the same time.

Remote command:

Display a limit line:

Lower limit: [CALCulate<n>:LIMit<k>:LOWer:STATe](#) on page 112

Upper limit: [CALCulate<n>:LIMit<k>:UPPer:STATe](#) on page 113

Query all visible limit lines:

[CALCulate<n>:LIMit<k>:ACTive?](#) on page 109

**Check Traces ← Select Limit Line**

Turns the limit check for a particular trace on and off.

Remote command:

Assign a limit line to a particular trace:

[CALCulate<n>:LIMit<k>:TRACe](#) on page 112

Activate the limit check:

[CALCulate<n>:LIMit<k>:STATe](#) on page 112

Querying limit check results:

[CALCulate<n>:LIMit<k>:FAIL?](#) on page 111

**Comment ← Select Limit Line**

Shows the comment of the selected limit line. If the limit line has no comment, this field stays empty.

**View Filter ← Select Limit Line**

Turns filter for the list of limit lines on and off.

By default, the list includes all limit lines that are stored on the R&S FSW.

"Show Compatible" Filters the list of limit lines by compatibility.  
If on, the list includes only those limit lines that are compatible to the current measurement setup.

"Show Lines For PNoise" Filters the list of limit lines by compatibility to phase noise measurements.  
If on, the list includes only those limit lines that are compatible to phase noise measurements.

**New / Edit / Copy To ← Select Limit Line**

All three buttons open the "Edit Limit Line" dialog box to create or edit limit lines.

When you use the "New" button, the dialog box contains no data.

When you use the "Edit" button, the dialog box contains the data of the previously selected limit line.

When you use the "Copy To" button, the dialog box also contains a copy the data of the previously selected limit line.

Remote command:

New:

[CALCulate<n>:LIMit<k>:NAME](#) on page 111

Copy:

[CALCulate<n>:LIMit<k>:COPY](#) on page 110

**Delete ← Select Limit Line**

Deletes the selected limit line.

Remote command:

[CALCulate<n>:LIMit<k>:DELeTe](#) on page 110

**Disable All Lines ← Select Limit Line**

Turns all active limit lines off.

### 6.3.3 Creating and Editing Standard Limit Lines

**Access:** "Overview" > "Limit Analysis" > "Line Config" > "New" / "Edit" > "Copy To"


<a href="#">Edit Limit Line</a> .....	63
L <a href="#">Name</a> .....	63
L <a href="#">Comment</a> .....	63
L <a href="#">X-Axis</a> .....	63
L <a href="#">Y-Axis</a> .....	64
L <a href="#">Data Points</a> .....	64
L <a href="#">Insert Value</a> .....	64

- L Delete Value..... 64
- L Shift X..... 64
- L Shift Y..... 64
- L Save..... 64

**Edit Limit Line**

The "Edit Limit Line" dialog box contains functionality to describe the shape of a limit line.

Because limit lines have to meet certain conditions for phase noise measurements, the availability of parameters is limited.



**Name ← Edit Limit Line**

Defines the name of a limit line.

Remote command:

[CALCulate<n>:LIMit<k>:NAME](#) on page 111

**Comment ← Edit Limit Line**

Defines a comment for the limit line.

A comment is not mandatory.

Remote command:

[CALCulate<n>:LIMit<k>:COMMeNt](#) on page 114

**X-Axis ← Edit Limit Line**

Defines the characteristics of the horizontal axis.

The characteristics consist of the unit, the scaling and the type of values.

In the Phase Noise application, the unit for the horizontal axis is always Hz. The scaling can either be logarithmic or linear

- "Unit" In the Phase Noise application, the unit is always Hz.
- "Scaling" In the Phase Noise application, the scaling of the horizontal axis is always logarithmic.
- "Type of Values" The type of values can be absolute values or relative to the nominal frequency.

Remote command:

Type of values:

`CALCulate<n>:LIMit<k>:LOWer:MODE` on page 115

`CALCulate<n>:LIMit<k>:UPPer:MODE` on page 116

### Y-Axis ← Edit Limit Line

Defines the characteristics of the vertical axis.

The characteristics consist of the unit, the type of values and the usage of the line.

"Unit" In the Phase Noise application, the unit is always dBc/Hz.

"Type of Values" In the Phase Noise application, the type of values is always absolute.

"Line usage" Selects if the limit line is used as an upper or lower limit line.

### Data Points ← Edit Limit Line

The data points define the shape of the limit line. A limit line consists of at least 2 data points and a maximum of 200 data points.

A data point is defined by its position in horizontal ("Position" column) and vertical direction ("Value" column). The position of the data points have to be in ascending order.

Remote command:

Horizontal data (position):

`CALCulate<n>:LIMit<k>:CONTRol[:DATA]` on page 114

Vertical data (value):

Lower limit: `CALCulate<n>:LIMit<k>:LOWer[:DATA]` on page 115

Upper limit: `CALCulate<n>:LIMit<k>:UPPer[:DATA]` on page 116

### Insert Value ← Edit Limit Line

Insert a new limit line data point below the selected data point.

### Delete Value ← Edit Limit Line

Deletes the selected limit line data point.

### Shift X ← Edit Limit Line

Shifts each data point horizontally by a particular amount.

Remote command:

`CALCulate<n>:LIMit<k>:CONTRol:SHIFt` on page 114

### Shift Y ← Edit Limit Line

Shifts each data point vertically by a particular amount.

Remote command:

Lower limit: `CALCulate<n>:LIMit<k>:LOWer:SHIFt` on page 116

Upper limit: `CALCulate<n>:LIMit<k>:UPPer:SHIFt` on page 117

### Save ← Edit Limit Line

Saves the limit line or the changes you have made to a limit line.



## 6.4 Using Markers

**Access** (marker position): MKR > "Marker Config" > "Markers"

**Access** (marker settings): MKR > "Marker Config" > "Marker Settings"

The "Marker Configuration" dialog box and the "Marker" menu contain all functionality necessary to control markers.

The "Marker Configuration" dialog box consists of two tabs.

The "Markers" tab contains functionality to define characteristics for each marker.



The "Marker Settings" tab contains general marker functionality.



- Marker 1 ... Marker x..... 65
- Marker Type..... 66
- Reference Marker..... 66
- Assigning the Marker to a Trace..... 66
- Marker Zoom..... 66
- All Markers Off..... 66
- Marker Table Display..... 67
- Marker Info..... 67

### Marker 1 ... Marker x

Selects and turns the corresponding marker on and off.

Turning on a marker also opens an input field to define the horizontal position of the marker.

In the "Marker Configuration" dialog box, you can also define the horizontal position of each marker ("x-value").

By default, the first marker you turn on is a normal marker, all others are delta markers.

Remote command:

CALCulate<n>:MARKer<m>[:STATe] on page 140

CALCulate<n>:DELTAmarker<m>[:STATe] on page 143

**Marker Type**

Toggles the marker type.

The type for marker 1 is always "Normal", the type for delta marker 1 is always "Delta". These types cannot be changed.

**Note:** If normal marker 1 is the active marker, switching the "Mkr Type" activates an additional delta marker 1. For any other marker, switching the marker type does not activate an additional marker, it only switches the type of the selected marker.

"Normal"            A normal marker indicates the absolute value at the defined position in the diagram.

"Delta"            A delta marker defines the value of the marker relative to the specified reference marker (marker 1 by default).

Remote command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 140

[CALCulate<n>:DELTAmarker<m>\[:STATe\]](#) on page 143

**Reference Marker**

Defines a marker as the reference marker which is used to determine relative analysis results (delta marker values).

Remote command:

[CALCulate<n>:DELTAmarker<m>:MREF](#) on page 143

**Assigning the Marker to a Trace**

The "Trace" setting assigns the selected marker to an active trace. The trace determines which value the marker shows at the marker position. If the marker was previously assigned to a different trace, the marker remains on the previous frequency or time, but indicates the value of the new trace.

If a trace is turned off, the assigned markers and marker functions are also deactivated.

Remote command:

[CALCulate<n>:MARKer<m>:TRACe](#) on page 141

**Marker Zoom**

Turns the marker zoom on and off.

The marker zoom magnifies the diagram area around marker 1 by a certain factor.

Turning on the zoom also opens an input field to define the zoom factor.

Remote command:

Turning on the zoom:

[DISPlay\[:WINDow:\]ZOOM\[:STATe\]](#) on page 146

Defining the zoom factor:

[CALCulate:MARKer:FUNction:ZOOM](#) on page 146

**All Markers Off**

Deactivates all markers in one step.

Remote command:

[CALCulate<n>:MARKer<m>:AOFF](#) on page 140

**Marker Table Display**

Defines how the marker information is displayed.


"On"	Displays the marker information in a table in a separate area beneath the diagram.
"Off"	Displays the marker information within the diagram area. No separate marker table is displayed.
"Auto"	(Default) Up to two markers are displayed in the diagram area. If more markers are active, the marker table is displayed automatically.

Remote command:

`DISPlay:MTABLE` on page 145

**Marker Info**

Turns the marker information displayed in the diagram on and off.



Remote command:

`DISPlay:MINFo[:STAT]` on page 145

## 7 How to Configure Phase Noise Measurements

### 7.1 Performing a Basic Phase Noise Measurement

1. In the Spectrum application, define the center frequency of the DUT.
2. Enter the "Phase Noise" application.  
The R&S FSW-K40 starts the measurement with the default configuration. The default configuration defines most settings automatically.  
If you need any custom configuration, define them after entering the Phase Noise application.
3. Layout the display as required via the SmartGrid.
4. Open the "Overview" dialog box to configure the measurement.
5. Configure the frontend (frequency, level etc.) via the "Frontend" dialog box.
6. Define the measurement range via the "Phase Noise" dialog box.
7. Turn on frequency and level tracking via the "Control" dialog box.
8. Run a single sweep.
9. Turn on a marker and read out the results.
10. Read out the residual noise over the measurement range.
11. Customize a residual noise range and read out the results.
12. Freeze trace 1 and 2 (trace mode: View).
13. Turn on trace 3 and 4 (trace mode: Clear/Write).
14. Switch the measurement mode to "IQ FFT" in the "Phase Noise" dialog box.
15. Repeat the measurement.

### 7.2 Customizing the Measurement Range

The application provides several ways to customize. Each method features a different level of details you can define.

1. Open the "Phase Noise" configuration via the "Overview" dialog box or the "Meas Config" softkey menu.
2. Define the frequency offset range you'd like to measure in the corresponding fields.

3. Select the "Sweep Type".
  - a) Select sweep types "Fast", "Normal" or "Averaged" for automatic measurement configuration.

For a custom configuration, proceed to set up each measurement parameter separately.

4. Define the "RBW", number of "Averages", sweep "Mode" and "I/Q Window" function.
  - a) Define the parameters globally for all (half) decades covered by the measurement range.
  - b) Define the parameters for each individual (half) decade covered by the measurement range in the "Half Decade Configuration Table".

## 8 Remote Control Commands for Phase Noise Measurements

The following remote control commands are required to configure and perform phase noise measurements in a remote environment. The R&S FSW must already be set up for remote operation in a network as described in the base unit manual.



### Universal functionality

Note that basic tasks that are also performed in the base unit in the same way are not described here. For a description of such tasks, see the R&S FSW User Manual.

In particular, this includes:

- Managing Settings and Results, i.e. storing and loading settings and result data.
- Basic instrument configuration, e.g. checking the system configuration, customizing the screen layout, or configuring networks and remote operation.
- Using the common status registers (specific status registers for Pulse measurements are not used).

• <a href="#">Common Suffixes</a> .....	70
• <a href="#">Introduction</a> .....	71
• <a href="#">Controlling the Phase Noise Measurement Channel</a> .....	76
• <a href="#">Performing Measurements</a> .....	80
• <a href="#">Configuring the Result Display</a> .....	85
• <a href="#">Configuring the Frontend</a> .....	92
• <a href="#">Controlling the Measurement</a> .....	95
• <a href="#">Configuring the Measurement Range</a> .....	99
• <a href="#">Using Limit Lines</a> .....	106
• <a href="#">Graphical Display of Phase Noise Results</a> .....	117
• <a href="#">Configure Numerical Result Displays</a> .....	127
• <a href="#">Using Markers</a> .....	140
• <a href="#">Configuring In- and Outputs</a> .....	146
• <a href="#">Automatic Measurement Configuration</a> .....	147
• <a href="#">Using the Status Register</a> .....	148
• <a href="#">Remote Control Example Scripts</a> .....	154

### 8.1 Common Suffixes

In the R&S FSW Phase Noise Measurement application, the following common suffixes are used in remote commands:

**Table 8-1: Common suffixes used in remote commands in the R&S FSW Phase Noise Measurement application**

Suffix	Value range	Description
<m>	1 to 16	Marker
<n>	1 to 16	Window (in the currently selected measurement channel)
<t>	1 to 4	Trace
<k>	1 to 8	Limit line

## 8.2 Introduction

Commands are program messages that a controller (e.g. a PC) sends to the instrument or software. They operate its functions ('setting commands' or 'events') and request information ('query commands'). Some commands can only be used in one way, others work in two ways (setting and query). If not indicated otherwise, the commands can be used for settings and queries.

The syntax of a SCPI command consists of a header and, in most cases, one or more parameters. To use a command as a query, you have to append a question mark after the last header element, even if the command contains a parameter.

A header contains one or more keywords, separated by a colon. Header and parameters are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). If there is more than one parameter for a command, these are separated by a comma from one another.

Only the most important characteristics that you need to know when working with SCPI commands are described here. For a more complete description, refer to the User Manual of the R&S FSW.



### Remote command examples

Note that some remote command examples mentioned in this general introduction may not be supported by this particular application.

### 8.2.1 Conventions used in Descriptions

Note the following conventions used in the remote command descriptions:

- Command usage**  
 If not specified otherwise, commands can be used both for setting and for querying parameters.  
 If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- Parameter usage**  
 If not specified otherwise, a parameter can be used to set a value and it is the result of a query.  
 Parameters required only for setting are indicated as **Setting parameters**.

Parameters required only to refine a query are indicated as **Query parameters**. Parameters that are only returned as the result of a query are indicated as **Return values**.

- **Conformity**  
Commands that are taken from the SCPI standard are indicated as **SCPI confirmed**. All commands used by the R&S FSW follow the SCPI syntax rules.
- **Asynchronous commands**  
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an **Asynchronous command**.
- **Reset values (\*RST)**  
Default parameter values that are used directly after resetting the instrument (\*RST command) are indicated as **\*RST** values, if available.
- **Default unit**  
This is the unit used for numeric values if no other unit is provided with the parameter.
- **Manual operation**  
If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

### 8.2.2 Long and Short Form

The keywords have a long and a short form. You can use either the long or the short form, but no other abbreviations of the keywords.

The short form is emphasized in upper case letters. Note however, that this emphasis only serves the purpose to distinguish the short from the long form in the manual. For the instrument, the case does not matter.

**Example:**

`SENSe:FREQuency:CENTer` is the same as `SENS:FREQ:CENT`.

### 8.2.3 Numeric Suffixes

Some keywords have a numeric suffix if the command can be applied to multiple instances of an object. In that case, the suffix selects a particular instance (e.g. a measurement window).

Numeric suffixes are indicated by angular brackets (<n>) next to the keyword.

If you don't quote a suffix for keywords that support one, a 1 is assumed.

**Example:**

`DISPlay[:WINDow<1...4>]:ZOOM:STATe` enables the zoom in a particular measurement window, selected by the suffix at `WINDow`.

`DISPlay:WINDow4:ZOOM:STATe ON` refers to window 4.



## 8.2.4 Optional Keywords

Some keywords are optional and are only part of the syntax because of SCPI compliance. You can include them in the header or not.

Note that if an optional keyword has a numeric suffix and you need to use the suffix, you have to include the optional keyword. Otherwise, the suffix of the missing keyword is assumed to be the value 1.

Optional keywords are emphasized with square brackets.

### Example:

Without a numeric suffix in the optional keyword:

```
[SENSe:]FREQuency:CENTer is the same as FREQuency:CENTer
```

With a numeric suffix in the optional keyword:

```
DISPlay[:WINDow<1...4>]:ZOOM:STATe
```

DISPlay:ZOOM:STATe ON enables the zoom in window 1 (no suffix).

DISPlay:WINDow4:ZOOM:STATe ON enables the zoom in window 4.

## 8.2.5 Alternative Keywords

A vertical stroke indicates alternatives for a specific keyword. You can use both keywords to the same effect.

### Example:

```
[SENSe:]BANDwidth|BWIDth[:RESolution]
```

In the short form without optional keywords, BAND 1MHZ would have the same effect as BWID 1MHZ.

## 8.2.6 SCPI Parameters

Many commands feature one or more parameters.

If a command supports more than one parameter, these are separated by a comma.

### Example:

```
LAYout:ADD:WINDow Spectrum,LEFT,MTABLE
```

Parameters may have different forms of values.

- [Numeric Values](#).....74
- [Boolean](#).....74
- [Character Data](#).....75
- [Character Strings](#).....75
- [Block Data](#).....75

### 8.2.6.1 Numeric Values

Numeric values can be entered in any form, i.e. with sign, decimal point or exponent. In case of physical quantities, you can also add the unit. If the unit is missing, the command uses the basic unit.

**Example:**

with unit: `SENSe:FREQuency:CENTer 1GHZ`

without unit: `SENSe:FREQuency:CENTer 1E9` would also set a frequency of 1 GHz.

Values exceeding the resolution of the instrument are rounded up or down.

If the number you have entered is not supported (e.g. in case of discrete steps), the command returns an error.

Instead of a number, you can also set numeric values with a text parameter in special cases.

- **MIN/MAX**  
Defines the minimum or maximum numeric value that is supported.
- **DEF**  
Defines the default value.
- **UP/DOWN**  
Increases or decreases the numeric value by one step. The step size depends on the setting. In some cases you can customize the step size with a corresponding command.

#### Querying numeric values

When you query numeric values, the system returns a number. In case of physical quantities, it applies the basic unit (e.g. Hz in case of frequencies). The number of digits after the decimal point depends on the type of numeric value.

**Example:**

Setting: `SENSe:FREQuency:CENTer 1GHZ`

Query: `SENSe:FREQuency:CENTer?` would return `1E9`

In some cases, numeric values may be returned as text.

- **INF/NINF**  
Infinity or negative infinity. Represents the numeric values 9.9E37 or -9.9E37.
- **NAN**  
Not a number. Represents the numeric value 9.91E37. NAN is returned in case of errors.

### 8.2.6.2 Boolean

Boolean parameters represent two states. The "ON" state (logically true) is represented by "ON" or a numeric value 1. The "OFF" state (logically untrue) is represented by "OFF" or the numeric value 0.

### Querying boolean parameters

When you query boolean parameters, the system returns either the value 1 ("ON") or the value 0 ("OFF").

**Example:**

Setting: `DISPlay:WINDow:ZOOM:STATe ON`

Query: `DISPlay:WINDow:ZOOM:STATe?` would return 1

### 8.2.6.3 Character Data

Character data follows the syntactic rules of keywords. You can enter text using a short or a long form. For more information see [Chapter 8.2.2, "Long and Short Form"](#), on page 72.

### Querying text parameters

When you query text parameters, the system returns its short form.

**Example:**

Setting: `SENSe:BANDwidth:RESolution:TYPE NORMal`

Query: `SENSe:BANDwidth:RESolution:TYPE?` would return `NORM`

### 8.2.6.4 Character Strings

Strings are alphanumeric characters. They have to be in straight quotation marks. You can use a single quotation mark ( ' ) or a double quotation mark ( " ).

**Example:**

`INSTRument:DElete 'Spectrum'`

### 8.2.6.5 Block Data

Block data is a format which is suitable for the transmission of large amounts of data.

The ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes all end or other control signs are ignored until all bytes are transmitted. #0 specifies a data block of indefinite length. The use of the indefinite format requires an `NL^END` message to terminate the data block. This format is useful when the length of the transmission is not known or if speed or other considerations prevent segmentation of the data into blocks of definite length.

## 8.3 Controlling the Phase Noise Measurement Channel

The following commands are necessary to control the measurement channel.

<a href="#">INSTrument:CREate:DUPLicate</a> .....	76
<a href="#">INSTrument:CREate[:NEW]</a> .....	76
<a href="#">INSTrument:CREate:REPLace</a> .....	77
<a href="#">INSTrument:DELeTe</a> .....	77
<a href="#">INSTrument:LIST?</a> .....	77
<a href="#">INSTrument:REName</a> .....	79
<a href="#">INSTrument[:SELeCt]</a> .....	79
<a href="#">SYSTem:PRESet:CHANnel[:EXECute]</a> .....	79

---

### INSTrument:CREate:DUPLicate

This command duplicates the currently selected measurement channel, i.e. creates a new measurement channel of the same type and with the identical measurement settings. The name of the new channel is the same as the copied channel, extended by a consecutive number (e.g. "IQAnalyzer" -> "IQAnalyzer2").

The channel to be duplicated must be selected first using the `INST:SEL` command.

**Example:**

```
INST:SEL 'IQAnalyzer'
```

```
INST:CRE:DUPL
```

Duplicates the channel named 'IQAnalyzer' and creates a new measurement channel named 'IQAnalyzer2'.

**Usage:** Event

---

### INSTrument:CREate[:NEW] <ChannelType>, <ChannelName>

This command adds an additional measurement channel.

The number of measurement channels you can configure at the same time depends on available memory.

**Parameters:**

<ChannelType> Channel type of the new channel.  
For a list of available channel types see [INSTrument:LIST?](#) on page 77.

<ChannelName> String containing the name of the channel. The channel name is displayed as the tab label for the measurement channel.  
Note: If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel (see [INSTrument:LIST?](#) on page 77).

**Example:**

```
INST:CRE IQ, 'IQAnalyzer2'
```

Adds an additional I/Q Analyzer channel named "IQAnalyzer2".

---

**INSTRument:CREate:REPLace** <ChannelName1>,<ChannelType>,<ChannelName2>

This command replaces a measurement channel with another one.

**Setting parameters:**

- <ChannelName1> String containing the name of the measurement channel you want to replace.
- <ChannelType> Channel type of the new channel.  
For a list of available channel types see [INSTRument:LIST?](#) on page 77.
- <ChannelName2> String containing the name of the new channel.  
Note: If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel (see [INSTRument:LIST?](#) on page 77).

**Example:** `INST:CRE:REPL 'IQAnalyzer2',IQ,'IQAnalyzer'`  
Replaces the channel named 'IQAnalyzer2' by a new measurement channel of type 'IQ Analyzer' named 'IQAnalyzer'.

**Usage:** Setting only

---

**INSTRument:DELeTe** <ChannelName>

This command deletes a measurement channel.

If you delete the last measurement channel, the default "Spectrum" channel is activated.

**Parameters:**

- <ChannelName> String containing the name of the channel you want to delete.  
A measurement channel must exist in order to be able delete it.

**Example:** `INST:DEL 'IQAnalyzer4'`  
Deletes the channel with the name 'IQAnalyzer4'.

**Usage:** Event

---

**INSTRument:LIST?**

This command queries all active measurement channels. This is useful in order to obtain the names of the existing measurement channels, which are required in order to replace or delete the channels.

**Return values:**

- <ChannelType>,  
<ChannelName> For each channel, the command returns the channel type and channel name (see tables below).  
Tip: to change the channel name, use the [INSTRument:REName](#) command.

**Example:** `INST:LIST?`  
 Result for 3 measurement channels:  
 'ADEM', 'Analog Demod', 'IQ', 'IQ  
 Analyzer', 'IQ', 'IQ Analyzer2'

**Usage:** Query only

**Table 8-2: Available measurement channel types and default channel names in Signal and Spectrum Analyzer mode**

Application	<ChannelType> Parameter	Default Channel Name*)
Spectrum	SANALYZER	Spectrum
1xEV-DO BTS (R&S FSW-K84)	BDO	1xEV-DO BTS
1xEV-DO MS (R&S FSW-K85)	MDO	1xEV-DO MS
3GPP FDD BTS (R&S FSW-K72)	BWCD	3G FDD BTS
3GPP FDD UE (R&S FSW-K73)	MWCD	3G FDD UE
802.11ad (R&S FSW-K95)	WIGIG	802.11ad
Amplifier Measurements (R&S FSW-K18)	AMPLifier	Amplifier
Analog Demodulation (R&S FSW-K7)	ADEM	Analog Demod
Avionics (R&S FSW-K15)	AVIonics	Avionics
cdma2000 BTS (R&S FSW-K82)	BC2K	CDMA2000 BTS
cdma2000 MS (R&S FSW-K83)	MC2K	CDMA2000 MS
DOCSIS 3.1 (R&S FSW-K192/193)	DOCSis	DOCSIS 3.1
GSM (R&S FSW-K10)	GSM	GSM
I/Q Analyzer	IQ	IQ Analyzer
LTE (R&S FSW-K10x)	LTE	LTE
Multi-Carrier Group Delay (R&S FSW-K17)	MCGD	MC Group Delay
Noise (R&S FSW-K30)	NOISE	Noise
Phase Noise (R&S FSW-K40)	PNOISE	Phase Noise
Pulse (R&S FSW-K6)	PULSE	Pulse
Real-Time Spectrum (R&S FSW-B160R/- K160RE)	RTIM	Real-Time Spectrum
Spurious Measurements (R&S FSW-K50)	SPUR	Spurious
TD-SCDMA BTS (R&S FSW-K76)	BTDS	TD-SCDMA BTS
TD-SCDMA UE (R&S FSW-K77)	MTDS	TD-SCDMA UE
Transient Analysis (R&S FSW-K60)	TA	Transient Analysis
*) the default channel name is also listed in the table. If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel.		

Application	<ChannelType> Parameter	Default Channel Name*)
VSA (R&S FSW-K70)	DDEM	VSA
WLAN (R&S FSW-K91)	WLAN	WLAN
*) the default channel name is also listed in the table. If the specified name for a new channel already exists, the default name, extended by a sequential number, is used for the new channel.		

---

**INSTrument:REName** <ChannelName1>, <ChannelName2>

This command renames a measurement channel.

**Parameters:**

<ChannelName1> String containing the name of the channel you want to rename.

<ChannelName2> String containing the new channel name.  
Note that you cannot assign an existing channel name to a new channel; this will cause an error.

**Example:** `INST:REN 'IQAnalyzer2', 'IQAnalyzer3'`  
Renames the channel with the name 'IQAnalyzer2' to 'IQAnalyzer3'.

**Usage:** Setting only

---

**INSTrument[:SElect]** <Application>

Selects the measurement application (channel type) for the current channel.

See also [INSTrument:CREate\[:NEW\]](#) on page 76.

For a list of available channel types see [Table 8-2](#).

**Parameters:**

<Application> **PNOise**  
Phase noise measurements, R&S FSW-K40

---

**SYSTem:PRESet:CHANnel[:EXECute]**

This command restores the default instrument settings in the current channel.

Use `INST:SEL` to select the channel.

**Example:** `INST:SEL 'Spectrum2'`  
Selects the channel for "Spectrum2".  
`SYST:PRESet:CHAN:EXEC`  
Restores the factory default settings to the "Spectrum2" channel.

**Usage:** Event

**Manual operation:** See "[Preset Channel](#)" on page 37

## 8.4 Performing Measurements

The following commands are necessary to perform measurements.



You can also perform a sequence of measurements using the Sequencer (see "[Multiple Measurement Channels and Sequencer Function](#)" on page 9).

ABORt.....	80
CONFigure:REFMeas ONCE.....	81
INITiate<n>:CONMeas.....	81
INITiate<n>:CONTinuous.....	81
INITiate<n>[:IMMediate].....	82
INITiate<n>:SEQuencer:ABORt.....	82
INITiate<n>:SEQuencer:IMMediate.....	82
INITiate<n>:SEQuencer:MODE.....	83
[SENSe:]SWEep:COUNT.....	84
[SENSe:]SWEep:FHDecade.....	84
SYSTem:SEQuencer.....	85

### ABORt

This command aborts the measurement in the current measurement channel and resets the trigger system.

To prevent overlapping execution of the subsequent command before the measurement has been aborted successfully, use the \*OPC? or \*WAI command after ABOR and before the next command.

For details see the "Remote Basics" chapter in the R&S FSW User Manual.

#### Note on blocked remote control programs:

If a sequential command cannot be completed, for example because a triggered sweep never receives a trigger, the remote control program will never finish and the remote channel to the R&S FSW is blocked for further commands. In this case, you must interrupt processing on the remote channel first in order to abort the measurement.

To do so, send a "Device Clear" command from the control instrument to the R&S FSW on a parallel channel to clear all currently active remote channels. Depending on the used interface and protocol, send the following commands:

- **Visa:** viClear()
- **GPIB:** ibclr()
- **RSIB:** RSDLLibclr()

Now you can send the ABORt command on the remote channel performing the measurement.

#### Example:

```
ABOR; :INIT:IMM
```

Aborts the current measurement and immediately starts a new one.



**Example:**            `ABOR; *WAI`  
                           `INIT: IMM`  
 Aborts the current measurement and starts a new one once  
 abortion has been completed.

**Usage:**             Event  
                           SCPI confirmed

### **CONFigure:REFMeas ONCE**

This command initiates a reference measurement that determines the inherent phase noise of the R&S FSW.

**Parameters:**  
 ONCE

**Example:**            `CONF:REFM ONCE`  
 Initiates a reference measurement

**Manual operation:** See "[Reference Measurement](#)" on page 21

### **INITiate<n>:CONMeas**

This command restarts a (single) measurement that has been stopped (using `ABORT`) or finished in single sweep mode.

The measurement is restarted at the beginning, not where the previous measurement was stopped.

As opposed to `INITiate<n>[:IMMEDIATE]`, this command does not reset traces in maxhold, minhold or average mode. Therefore it can be used to continue measurements using maxhold or averaging functions.

**Suffix:**  
 <n>                    irrelevant

**Usage:**             Event

**Manual operation:** See "[Continue Single Sweep](#)" on page 47

### **INITiate<n>:CONTinuous <State>**

This command controls the sweep mode for an individual measurement channel.

Note that in single sweep mode, you can synchronize to the end of the measurement with `*OPC`, `*OPC?` or `*WAI`. In continuous sweep mode, synchronization to the end of the measurement is not possible. Thus, it is not recommended that you use continuous sweep mode in remote control, as results like trace data or markers are only valid after a single sweep end synchronization.

For details on synchronization see the "Remote Basics" chapter in the R&S FSW User Manual.

**Suffix:**

<n> irrelevant

**Parameters:**

<State> ON | OFF | 0 | 1  
**ON | 1**  
 Continuous sweep  
**OFF | 0**  
 Single sweep  
 \*RST: 1

**Example:**

```
INIT:CONT OFF
Switches the sweep mode to single sweep.
INIT:CONT ON
Switches the sweep mode to continuous sweep.
```

**Manual operation:** See "[Continuous Sweep/RUN CONT](#)" on page 47

**INITiate<n>[:IMMEDIATE]**

This command starts a (single) new measurement.

With sweep count or average count > 0, this means a restart of the corresponding number of measurements. With trace mode MAXHold, MINHold and AVERage, the previous results are reset on restarting the measurement.

You can synchronize to the end of the measurement with \*OPC, \*OPC? or \*WAI.

For details on synchronization see the "Remote Basics" chapter in the R&S FSW User Manual.

**Suffix:**

<n> irrelevant

**Usage:**

Event

**Manual operation:** See "[Single Sweep/ RUN SINGLE](#)" on page 47

**INITiate<n>:SEQuencer:ABORT**

This command stops the currently active sequence of measurements. The Sequencer itself is not deactivated, so you can start a new sequence immediately using [INITiate<n>:SEQuencer:IMMEDIATE](#) on page 82.

To deactivate the Sequencer use [SYSTEM:SEQuencer](#) on page 85.

**Suffix:**

<n> irrelevant

**Usage:**

Event

**INITiate<n>:SEQuencer:IMMEDIATE**

This command starts a new sequence of measurements by the Sequencer.

Its effect is similar to the `INITiate<n>[:IMMediate]` command used for a single measurement.

Before this command can be executed, the Sequencer must be activated (see `SYSTem:SEQuencer` on page 85).

**Suffix:**

<n> irrelevant

**Example:**

`SYST:SEQ ON`

Activates the Sequencer.

`INIT:SEQ:MODE SING`

Sets single sequence mode so each active measurement will be performed once.

`INIT:SEQ:IMM`

Starts the sequential measurements.

**Usage:**

Event

**INITiate<n>:SEQuencer:MODE <Mode>**

This command selects the way the R&S FSW application performs measurements sequentially.

Before this command can be executed, the Sequencer must be activated (see `SYSTem:SEQuencer` on page 85).

A detailed programming example is provided in the "Operating Modes" chapter in the R&S FSW User Manual.

**Note:** In order to synchronize to the end of a sequential measurement using `*OPC`, `*OPC?` or `*WAI` you must use `SINGLE` Sequence mode.

For details on synchronization see the "Remote Basics" chapter in the R&S FSW User Manual.

**Suffix:**

<n> irrelevant

**Parameters:**

<Mode>

**SINGLE**

Each measurement is performed once (regardless of the channel's sweep mode), considering each channels' sweep count, until all measurements in all active channels have been performed.

**CONTinuous**

The measurements in each active channel are performed one after the other, repeatedly (regardless of the channel's sweep mode), in the same order, until the Sequencer is stopped.

**CDEFined**

First, a single sequence is performed. Then, only those channels in continuous sweep mode (`INIT:CONT ON`) are repeated.

\*RST: CONTinuous

**Example:**

```

SYST:SEQ ON
Activates the Sequencer.
INIT:SEQ:MODE SING
Sets single sequence mode so each active measurement will be
performed once.
INIT:SEQ:IMM
Starts the sequential measurements.

```

### [SENSe:]SWEep:COUNT <SweepCount>

This command defines the number of sweeps that the application uses to average traces.

In case of continuous sweep mode, the application calculates the moving average over the average count.

In case of single sweep mode, the application stops the measurement and calculates the average after the average count has been reached.

**Suffix:**

<n> [Window](#)

**Parameters:**

<SweepCount> If you set a sweep count of 0 or 1, the R&S FSW performs one single sweep.

Range: 0 to 200000

\*RST: 200

**Example:**

```

SWE:COUN 64
Sets the number of sweeps to 64.
INIT:CONT OFF
Switches to single sweep mode.
INIT;*WAI
Starts a sweep and waits for its end.

```

**Usage:** SCPI confirmed

**Manual operation:** See "[Sweep / Average Count](#)" on page 47

### [SENSe:]SWEep:FHDecade

This command stops the measurement in the current half decade and continues measuring in the subsequent half decade.

**Example:**

```

SWE:FHD
Aborts the current measurement and continues in the next half
decade.

```

**Usage:** Event

**Manual operation:** See "[Finish Half Decade](#)" on page 48

**SYSTem:SEQuencer** <State>

This command turns the Sequencer on and off. The Sequencer must be active before any other Sequencer commands (`INIT:SEQ...`) are executed, otherwise an error will occur.

A detailed programming example is provided in the "Operating Modes" chapter in the R&S FSW User Manual.

**Parameters:**

&lt;State&gt;

ON | OFF | 0 | 1

**ON | 1**

The Sequencer is activated and a sequential measurement is started immediately.

**OFF | 0**

The Sequencer is deactivated. Any running sequential measurements are stopped. Further Sequencer commands (`INIT:SEQ...`) are not available.

\*RST: 0

**Example:**

SYST:SEQ ON

Activates the Sequencer.

INIT:SEQ:MODE SING

Sets single Sequencer mode so each active measurement will be performed once.

INIT:SEQ:IMM

Starts the sequential measurements.

SYST:SEQ OFF

## 8.5 Configuring the Result Display

The commands required to configure the screen display in a remote environment are described here.

- [General Window Commands](#)..... 85
- [Working with Windows in the Display](#)..... 86

### 8.5.1 General Window Commands

The following commands are required to configure general window layout, independent of the application.

[DISPlay:FORMat](#)..... 85

[DISPlay\[:WINDow<n>\]:SIZE](#)..... 86

**DISPlay:FORMat** <Format>

This command determines which tab is displayed.

**Parameters:**

&lt;Format&gt;

**SPLit**

Displays the MultiView tab with an overview of all active channels

**SINGle**

Displays the measurement channel that was previously focused.

\*RST: SING

**Example:**

DISP:FORM SPL

**DISPlay[:WINDow<n>]:SIZE <Size>**

This command maximizes the size of the selected result display window *temporarily*. To change the size of several windows on the screen permanently, use the `LAY:SPL` command (see `LAYout:SPLitter` on page 89).

**Suffix:**

&lt;n&gt;

Window

**Parameters:**

&lt;Size&gt;

**LARGe**

Maximizes the selected window to full screen. Other windows are still active in the background.

**SMALI**

Reduces the size of the selected window to its original size. If more than one measurement window was displayed originally, these are visible again.

\*RST: SMALI

**Example:**

DISP:WIND2:SIZE LARG

## 8.5.2 Working with Windows in the Display

The following commands are required to change the evaluation type and rearrange the screen layout for a measurement channel as you do using the SmartGrid in manual operation. Since the available evaluation types depend on the selected application, some parameters for the following commands also depend on the selected measurement channel.

<code>LAYout:ADD[:WINDow]?</code> .....	87
<code>LAYout:CATalog[:WINDow]?</code> .....	88
<code>LAYout:IDENtify[:WINDow]?</code> .....	88
<code>LAYout:REMove[:WINDow]</code> .....	88
<code>LAYout:REPLace[:WINDow]</code> .....	89
<code>LAYout:SPLitter</code> .....	89
<code>LAYout:WINDow&lt;n&gt;:ADD?</code> .....	91
<code>LAYout:WINDow&lt;n&gt;:IDENtify?</code> .....	91
<code>LAYout:WINDow&lt;n&gt;:REMove</code> .....	92
<code>LAYout:WINDow&lt;n&gt;:REPLace</code> .....	92

**LAYout:ADD[:WINDow]?** <WindowName>,<Direction>,<WindowType>

This command adds a window to the display in the active measurement channel.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

To replace an existing window, use the `LAYout:REPLace[:WINDow]` command.

**Parameters:**

<WindowName>	String containing the name of the existing window the new window is inserted next to. By default, the name of a window is the same as its index. To determine the name and index of all active windows, use the <code>LAYout:CATalog[:WINDow]?</code> query.
<Direction>	LEFT   RIGHT   ABOVE   BELOW Direction the new window is added relative to the existing window.
<WindowType>	text value Type of result display (evaluation method) you want to add. See the table below for available parameter values.

**Return values:**

<NewWindowName> When adding a new window, the command returns its name (by default the same as its number) as a result.

**Example:**

LAY:ADD? '1', LEFT, MTAB

Result:

'2'

Adds a new window named '2' with a marker table to the left of window 1.

**Usage:**

Query only

**Table 8-3: <WindowType> parameter values for Phase Noise application**

Parameter value	Window type
FDRift	Frequency drift
MTABle	Marker table
PNOise	Phase noise diagram
RNOise	Residual noise table
SNOise	Spot noise table
SPECtrum	Spectrum monitor
SPURs	Spur list
SRESults	Sweep result list
STABility	Frequency and level stability indicator

**LAYout:CATalog[:WINDow]?**

This command queries the name and index of all active windows in the active measurement channel from top left to bottom right. The result is a comma-separated list of values for each window, with the syntax:

<WindowName\_1>,<WindowIndex\_1>..<WindowName\_n>,<WindowIndex\_n>

**Return values:**

<WindowName>      string  
Name of the window.  
In the default state, the name of the window is its index.

<WindowIndex>    **numeric value**  
Index of the window.

**Example:**

LAY:CAT?

Result:

'2',2,'1',1

Two windows are displayed, named '2' (at the top or left), and '1' (at the bottom or right).

**Usage:**              Query only

**LAYout:IDENtify[:WINDow]? <WindowName>**

This command queries the **index** of a particular display window in the active measurement channel.

**Note:** to query the **name** of a particular window, use the `LAYout:WINDow<n>:IDENtify?` query.

**Query parameters:**

<WindowName>      String containing the name of a window.

**Return values:**

<WindowIndex>    Index number of the window.

**Example:**

LAY:WIND:IDEN? '2'

Queries the index of the result display named '2'.

Response:

2

**Usage:**              Query only

**LAYout:REMOve[:WINDow] <WindowName>**

This command removes a window from the display in the active measurement channel.

**Parameters:**

<WindowName>      String containing the name of the window.  
In the default state, the name of the window is its index.

**Example:**

LAY:REM '2'

Removes the result display in the window named '2'.



**Usage:** Event

---

**LAYout:REPLace[:WINDow]** <WindowName>,<WindowType>

This command replaces the window type (for example from "Diagram" to "Result Summary") of an already existing window in the active measurement channel while keeping its position, index and window name.

To add a new window, use the [LAYout:ADD\[:WINDow\]?](#) command.

**Parameters:**

<WindowName> String containing the name of the existing window. By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active measurement channel, use the [LAYout:CATalog\[:WINDow\]?](#) query.

<WindowType> Type of result display you want to use in the existing window. See [LAYout:ADD\[:WINDow\]?](#) on page 87 for a list of available window types.

**Example:** `LAY:REPL:WIND '1',MTAB`  
Replaces the result display in window 1 with a marker table.

---

**LAYout:SPLitter** <Index1>,<Index2>,<Position>

This command changes the position of a splitter and thus controls the size of the windows on each side of the splitter.

Compared to the [DISPlay\[:WINDow<n>\]:SIZE](#) on page 86 command, the `LAYout:SPLitter` changes the size of all windows to either side of the splitter permanently, it does not just maximize a single window temporarily.

Note that windows must have a certain minimum size. If the position you define conflicts with the minimum size of any of the affected windows, the command will not work, but does not return an error.




Figure 8-1: SmartGrid coordinates for remote control of the splitters

**Parameters:**

- <Index1> The index of one window the splitter controls.
- <Index2> The index of a window on the other side of the splitter.
- <Position> New vertical or horizontal position of the splitter as a fraction of the screen area (without channel and status bar and softkey menu).  
The point of origin ( $x = 0$ ,  $y = 0$ ) is in the lower left corner of the screen. The end point ( $x = 100$ ,  $y = 100$ ) is in the upper right corner of the screen. (See Figure 8-1.)  
The direction in which the splitter is moved depends on the screen layout. If the windows are positioned horizontally, the splitter also moves horizontally. If the windows are positioned vertically, the splitter also moves vertically.

Range: 0 to 100

**Example:**

LAY:SPL 1, 3, 50

Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Table') to the center (50%) of the screen, i.e. in the figure above, to the left.

**Example:**

LAY:SPL 1, 4, 70

Moves the splitter between window 1 ('Frequency Sweep') and 3 ('Marker Peak List') towards the top (70%) of the screen.

The following commands have the exact same effect, as any combination of windows above and below the splitter moves the splitter vertically.

LAY:SPL 3, 2, 70

LAY:SPL 4, 1, 70

LAY:SPL 2, 1, 70

**LAYout:WINDow<n>:ADD?** <Direction>,<WindowType>

This command adds a measurement window to the display. Note that with this command, the suffix <n> determines the existing window next to which the new window is added, as opposed to `LAYout:ADD[:WINDow]?`, for which the existing window is defined by a parameter.

To replace an existing window, use the `LAYout:WINDow<n>:REPLace` command.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

**Suffix:**

<n> [Window](#)

**Parameters:**

<Direction> LEFT | RIGHT | ABOVE | BELOW

<WindowType> Type of measurement window you want to add.  
See `LAYout:ADD[:WINDow]?` on page 87 for a list of available window types.

**Return values:**

<NewWindowName> When adding a new window, the command returns its name (by default the same as its number) as a result.

**Example:**

LAY:WIND1:ADD? LEFT,MTAB

Result:

'2'

Adds a new window named '2' with a marker table to the left of window 1.

**Usage:**

Query only

**LAYout:WINDow<n>:IDENTify?**

This command queries the **name** of a particular display window (indicated by the <n> suffix) in the active measurement channel.

**Note:** to query the **index** of a particular window, use the `LAYout:IDENTify[:WINDow]?` command.

**Suffix:**

<n> [Window](#)

**Return values:**

<WindowName> String containing the name of a window.  
In the default state, the name of the window is its index.

**Example:**

LAY:WIND2:IDEN?

Queries the name of the result display in window 2.

Response:

'2'

**Usage:**

Query only

**LAYout:WINDow<n>:REMOve**

This command removes the window specified by the suffix <n> from the display in the active measurement channel.

The result of this command is identical to the `LAYout:REMOve[:WINDow]` command.

**Suffix:**

<n> [Window](#)

**Example:**

`LAY:WIND2:REM`  
Removes the result display in window 2.

**Usage:**

Event

**LAYout:WINDow<n>:REPLace <WindowType>**

This command changes the window type of an existing window (specified by the suffix <n>) in the active measurement channel.

The result of this command is identical to the `LAYout:REPLace[:WINDow]` command.

To add a new window, use the `LAYout:WINDow<n>:ADD?` command.

**Suffix:**

<n> [Window](#)

**Parameters:**

<WindowType> Type of measurement window you want to replace another one with.  
See `LAYout:ADD[:WINDow]?` on page 87 for a list of available window types.

**Example:**

`LAY:WIND2:REPL MTAB`  
Replaces the result display in window 2 with a marker table.

## 8.6 Configuring the Frontend

The following commands are necessary to configure the frontend settings.

<code>[SENSe:]FREQUency:CENTer</code> .....	92
<code>[SENSe:]POWer:RLEVel</code> .....	93
<code>INPut:ATTenuation</code> .....	93
<code>INPut:ATTenuation:AUTO</code> .....	94
<code>INPut:COUPling</code> .....	94
<code>INPut:GAIN:STATe</code> .....	94
<code>INPut:GAIN[:VALue]</code> .....	95

**[SENSe:]FREQUency:CENTer <Frequency>**

This command defines the nominal frequency.

**Parameters:**

<Frequency>            Range:     0 to f<sub>max</sub>  
                               \*RST:     f<sub>max</sub>/2  
                               Default unit: Hz  
                               f<sub>max</sub> is specified in the data sheet. min span is 10 Hz

**Example:**

FREQ:CENT 100 MHz  
 Defines a nominal frequency of 100 MHz.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Nominal Frequency](#)" on page 39

**[SENSe:]POWer:RLEVel <Power>**

This command defines the nominal level.

**Parameters:**

<Power>                Numeric value in dBm.  
                               Range:     -200 to 200  
                               \*RST:     0

**Example:**

POW:RLEV -20  
 Defines a nominal level of -20 dBm.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Nominal Level](#)" on page 39

**INPut:ATTenuation <Attenuation>**

This command defines the total attenuation for RF input.

If you set the attenuation manually, it is no longer coupled to the reference level, but the reference level is coupled to the attenuation. Thus, if the current reference level is not compatible with an attenuation that has been set manually, the command also adjusts the reference level.

**Parameters:**

<Attenuation>        Range:     see data sheet  
                               Increment: 5 dB  
                               \*RST:     10 dB (AUTO is set to ON)

**Example:**

INP:ATT 30dB  
 Defines a 30 dB attenuation and decouples the attenuation from the reference level.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Mechanical Attenuator / Value](#)" on page 39

**INPut:ATTenuation:AUTO** <State>

This command couples or decouples the attenuation to the reference level. Thus, when the reference level is changed, the R&S FSW determines the signal level for optimal internal data processing and sets the required attenuation accordingly.

**Parameters:**

<State> ON | OFF | 0 | 1  
\*RST: 1

**Example:** INP:ATT:AUTO ON  
Couples the attenuation to the reference level.

**Usage:** SCPI confirmed

**Manual operation:** See "[Mechanical Attenuator / Value](#)" on page 39

**INPut:COUPling** <CouplingType>

This command selects the coupling type of the RF input.

**Parameters:**

<CouplingType> **AC**  
AC coupling  
**DC**  
DC coupling  
\*RST: AC

**Example:** INP:COUP DC

**Usage:** SCPI confirmed

**Manual operation:** See "[Coupling](#)" on page 39

**INPut:GAIN:STATe** <State>

This command turns the preamplifier on and off. It requires the optional preamplifier hardware.

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Example:** INP:GAIN:STAT ON  
Switches on 30 dB preamplification.

**Usage:** SCPI confirmed

**Manual operation:** See "[Preamplifier](#)" on page 39

**INPut:GAIN[:VALue] <Gain>**

This command selects the gain if the preamplifier is activated (`INP:GAIN:STAT ON`, see `INPut:GAIN:STATe` on page 94).

The command requires the additional preamplifier hardware option.

**Parameters:**

<Gain> 15 dB | 30 dB

The availability of gain levels depends on the model of the R&S FSW.

R&S FSW8/13: 15dB and 30 dB

R&S FSW26 or higher: 30 dB

All other values are rounded to the nearest of these two.

\*RST: OFF

**Example:**

```
INP:GAIN:STAT ON
INP:GAIN:VAL 30
```

Switches on 30 dB preamplification.

**Usage:** SCPI confirmed

**Manual operation:** See "Preamplifier" on page 39

## 8.7 Controlling the Measurement

The following commands are necessary to control the sequence of the phase noise measurement.

<code>[SENSe:]FREQuency:TRACk</code> .....	95
<code>[SENSe:]FREQuency:VERify:TOLerance:ABSolute</code> .....	96
<code>[SENSe:]FREQuency:VERify:TOLerance:RELative</code> .....	96
<code>[SENSe:]FREQuency:VERify[:STATe]</code> .....	96
<code>[SENSe:]IQ:DECimation</code> .....	97
<code>[SENSe:]IQ:DPLL</code> .....	97
<code>[SENSe:]IQ:ONLine</code> .....	97
<code>[SENSe:]IQ:TBW</code> .....	98
<code>[SENSe:]POWer:RLEVel:VERify:TOLerance</code> .....	98
<code>[SENSe:]POWer:RLEVel:VERify[:STATe]</code> .....	98
<code>[SENSe:]POWer:TRACk</code> .....	98
<code>[SENSe:]REJect:AM</code> .....	99
<code>[SENSe:]SWEep:SVFailed</code> .....	99

**[SENSe:]FREQuency:TRACk <State>**

This command turns frequency tracking on and off.

**Parameters:**

<State> ON | OFF

\*RST: ON

**Example:** `FREQ:TRAC OFF`  
Turns off frequency tracking.

**Manual operation:** See ["Frequency Tracking"](#) on page 41

**[SENSe:]FREQuency:VERify:TOLerance:ABSolute <Frequency>**

This command defines an absolute frequency tolerance for frequency verification.

If you define both an absolute and relative tolerance, the application uses the higher tolerance level.

**Parameters:**  
<Frequency> Numeric value in Hz.

\*RST: 1 kHz

**Example:** `FREQ:VER:TOL:ABS 100kHz`  
Defines a frequency tolerance range of 100 kHz.

**Manual operation:** See ["Verify Frequency"](#) on page 40

**[SENSe:]FREQuency:VERify:TOLerance:RELative <Percentage>**

This command defines a relative frequency tolerance for frequency verification.

If you define both an absolute and relative tolerance, the application uses the higher tolerance level.

**Parameters:**  
<Percentage> Numeric value in %, relative to the current nominal frequency.

Range: 1 to 100

\*RST: 10

Default unit: PCT

**Example:** `FREQ:VER:TOL:REL 12`  
Defines a frequency tolerance of 12% in relation to the nominal frequency.

**Usage:** SCPI confirmed

**Manual operation:** See ["Verify Frequency"](#) on page 40

**[SENSe:]FREQuency:VERify[:STATe] <State>**

This command turns frequency verification on and off.

**Parameters:**  
<State> ON | OFF

\*RST: ON

**Example:** `FREQ:VER ON`  
Turns on frequency verification.

**Usage:** SCPI confirmed



**Manual operation:** See ["Verify Frequency"](#) on page 40

#### [SENSe:]IQ:DECimation <State>

This command turns decimation of results on and off.

**Parameters:**

<State> ON | OFF  
\*RST: ON

**Example:** IQ:DEC ON  
Turns on decimation.

**Manual operation:** See ["Decimation"](#) on page 42

#### [SENSe:]IQ:DPLL <State>

This command turns the digital PLL on and off.

**Parameters:**

<State> ON | OFF

**Example:** IQ:DPLL ON  
Turns the digital PLL on.

**Manual operation:** See ["Digital PLL"](#) on page 42

#### [SENSe:]IQ:ONLine <State>

This command turns the I/Q online measurement mode on and off.

This mode is available for offset frequencies smaller than 30 kHz.

Note that you have to

- turn on decimation with [\[SENSe:\]IQ:DECimation](#)
- select the I/Q FFT mode for the affected half decades with [\[SENSe:\]BANDwidth|BWIDth\[:RESolution\]:TYPE](#)
- turn off forward sweep with [\[SENSe:\]SWEep:FORWARD](#)

**Parameters:**

<State> ON | OFF

**Example:** SWE:FORW OFF  
LIST:RANG9:FILT:TYPE IQFF  
LIST:RANG8:FILT:TYPE IQFF  
IQ:DEC ON  
IQ:ONL ON  
Configures a online measurement for the half decades between 3 kHz and 10 kHz and 10 kHz and 30 kHz.

**Manual operation:** See ["Online I/Q"](#) on page 42

---

**[SENSe:]IQ:TBW <Bandwidth>**

This command defines the maximum tracking bandwidth (sample rate) for all half decades.

**Parameters:**

<Bandwidth>            Range:        60 mHz to 65.28 MHz  
                               Increment: 10 mHz  
                               \*RST:        60 mHz

**Example:**

IQ:TBW 100HZ  
 Defines a tracking bandwidth of 100 Hz.

**Manual operation:** See "[Max Freq Drift](#)" on page 42

---

**[SENSe:]POWer:RLEVel:VERify:TOLerance <Level>**

This command defines a relative level tolerance for level verification

**Parameters:**

<Level>                Numeric value in dB, relative to the nominal level.  
                               \*RST:        10 dB

**Example:**

POW:RLEV:TOL 5  
 Defines a level tolerance of 5 dB.

**Usage:**                SCPI confirmed

**Manual operation:** See "[Verify Level](#)" on page 41

---

**[SENSe:]POWer:RLEVel:VERify[:STATe] <State>**

This command turns level verification on and off.

**Parameters:**

<State>                ON | OFF  
                               \*RST:        ON

**Example:**

POW:RLEV:VER ON  
 Turns on level verification.

**Usage:**                SCPI confirmed

**Manual operation:** See "[Verify Level](#)" on page 41

---

**[SENSe:]POWer:TRACk <State>**

This command turns level tracking on and off.

**Parameters:**

<State>                ON | OFF  
                               \*RST:        ON

**Example:** POW:TRAC ON  
Turns on level tracking.

**Usage:** SCPI confirmed

**Manual operation:** See "[Level Tracking](#)" on page 41

**[SENSe:]REJect:AM <State>**

This command turns the suppression of AM noise on and off.

**Parameters:**

<State> ON | OFF

**Example:** REJ:AM ON  
Turns AM noise suppression on.

**Manual operation:** See "[AM Rejection](#)" on page 42

**[SENSe:]SWEep:SVFailed <State>**

This command turns repeated tries to start the measurement if signal verification fails on and off.

**Parameters:**

<State> ON | OFF

If on, the application tries to verify the signal once and then aborts the measurement if verification has failed.

\*RST: OFF

**Example:** SWE:SVF ON  
Stops the measurement if signal verification has failed.

**Manual operation:** See "[On Verify Failed](#)" on page 41

## 8.8 Configuring the Measurement Range

The following commands are necessary to configure the phase noise measurement range.

**Table 8-4: <range> suffix assignment**

Suffix	Half Decade
1	1 Hz ... 3 Hz
2	3 Hz ... 10 Hz
3	10 Hz ... 30 Hz
4	30 Hz ... 100 Hz
5	100 Hz ... 300 Hz
6	300 Hz ... 1 kHz

Suffix	Half Decade
7	1 kHz ... 3 kHz
8	3 kHz ... 10 kHz
9	10 kHz ... 30 kHz
10	30 kHz ... 100 kHz
11	100 kHz ... 300 kHz
12	300 kHz ... 1 MHz
13	1 MHz ... 3 MHz
14	3 MHz ... 10 MHz
15	10 MHz ... 30 MHz
16	30 MHz ... 100 MHz
17	100 MHz ... 300 MHz
18	300 MHz ... 1 GHz
19	1 GHz ... 3 GHz
20	3 GHz ... 10 GHz

[SENSe:]LIST:BWIDth[:RESolution]:RATio.....	100
[SENSe:]BANDwidth BWIDth[:RESolution]:TYPE.....	101
[SENSe:]FREQuency:STARt.....	101
[SENSe:]FREQuency:STOP.....	101
[SENSe:]LIST:BWIDth:RESolution:TYPE.....	102
[SENSe:]LIST:IQWindow:TYPE.....	102
[SENSe:]LIST:RANGe<range>:BWIDth[:RESolution].....	103
[SENSe:]LIST:RANGe<range>:FILTer:TYPE.....	103
[SENSe:]LIST:RANGe<range>:IQWindow:TYPE.....	103
[SENSe:]LIST:RANGe<range>:SWEep:COUNT.....	104
[SENSe:]LIST:SWEep:COUNT.....	104
[SENSe:]LIST:SWEep:COUNT:MULTiplier.....	105
[SENSe:]LIST:SWEep:COUNT:MULTiplier:STATe.....	105
[SENSe:]SWEep:FORWard.....	105
[SENSe:]SWEep:MODE.....	106

---

### [SENSe:]LIST:BWIDth[:RESolution]:RATio <Ratio>

This command defines the resolution bandwidth over all half decades.

**Parameters:**

<Ratio>                    Numeric value in %.  
 The resulting RBW is the percentage of the start frequency of each half decade.  
 If the resulting RBW is not available, the application rounds to the next available bandwidth.  
 Range:            1 to 100  
 \*RST:            10

**Example:**

LIST:BWID:RAT 20  
 Defines a RBW of 20% of the start frequency of the corresponding half decade.

**Manual operation:** See "[Global RBW](#)" on page 44

**[SENSe:]BANDwidth|BWIDth[:RESolution]:TYPE <Mode>**

This command selects the sweep mode for a all half decades globally.

**Parameters:**

<Mode>                    **IQ**  
 Measurement based on I/Q data.  
**NORMAL**  
 Measurement based on spectrum analyzer data.  
**FFT**  
 Measurement based on spectrum analyzer data. Kept for compatibility to R&S FSV.  
 \*RST:            Depends on half decade

**Example:**

BAND:TYPE FFT  
 Selects FFT analysis for all half decades.

**[SENSe:]FREQuency:STARt <Frequency>**

This command defines the start frequency of the measurement range.

**Parameters:**

<Frequency>            Offset frequencies in half decade steps.  
 Range:            1 Hz to 3 GHz  
 \*RST:            1 kHz

**Example:**

FREQ:STAR 10kHz  
 Defines a start frequency of 10 kHz.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Range Start / Stop](#)" on page 44

**[SENSe:]FREQuency:STOP <Frequency>**

This command defines the stop frequency of the measurement range.

**Parameters:**

<Frequency> Offset frequencies in half decade steps.  
 Range: 3 Hz to 10 GHz  
 \*RST: 1 MHz

**Example:**

FREQ:STOP 10MHz  
 Defines a stop frequency of 10 MHz.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Range Start / Stop](#)" on page 44

**[SENSe:]LIST:BWIDth:RESolution:TYPE <Mode>**

This command selects the sweep mode for all half decades.

**Parameters:**

<Mode> **IQFFt**  
 Measurement based on I/Q data.  
**NORMal**  
 Measurement based on spectrum analyzer data.  
**FFT**  
 Measurement based on spectrum analyzer data. Kept for compatibility to R&S FSV.  
 \*RST: Depends on half decade

**Example:**

LIST:BWID:RES:TYPE IQFF  
 Selects I/Q analysis mode for all half decades.

**Manual operation:** See "[Global Sweep Mode](#)" on page 45

**[SENSe:]LIST:IQWindow:TYPE <WindowFunction>**

This command selects the window function for all half decades.

Window functions are available for I/Q sweep mode.

**Parameters:**

<WindowFunction> **REctangular**  
**GAUSsian**  
**CHEBychev**  
**BHARris**  
 \*RST: Depends on the half decade

**Example:**

LIST:IQW:TYPE REC  
 Selects a rectangular FFT window.

**Manual operation:** See "[Global I/Q Window](#)" on page 45

**[SENSe:]LIST:RANGe<range>:BWIDth[:RESolution] <RBW>**

This command defines the resolution bandwidth for a particular half decade.

**Suffix:**

<range>                    1...20  
 Selects the half decade.  
 For the suffix assignment see [Table 8-4](#).

**Parameters:**

<RBW>                    Numeric value in Hz.  
 Note that each half decade has a limited range of available bandwidths.  
 \*RST:                    Depends on the half decade  
 Default unit: Hz

**Example:**

LIST:RANG9:BWID 100Hz  
 Selects a RBW of 100 Hz for the half decade from 1 kHz to 3 kHz.

**Manual operation:** See "[Half Decades Configuration Table](#)" on page 46

**[SENSe:]LIST:RANGe<range>:FILTer:TYPE <Mode>**

This command selects the sweep mode for a particular half decade.

**Suffix:**

<range>                    1...20  
 Selects the half decade.  
 For the suffix assignment see [Table 8-4](#).

**Parameters:**

<Mode>                    **IQFFt**  
 Measurement based on I/Q data.  
**NORMAL**  
 Measurement based on spectrum analyzer data.  
**FFT**  
 Measurement based on spectrum analyzer data. Kept for compatibility to R&S FSV.  
 \*RST:                    Depends on half decade

**Example:**

LIST:RANG9:FILT:TYPE FFT  
 Selects FFT analysis for the ninth half decade.

**Manual operation:** See "[Half Decades Configuration Table](#)" on page 46

**[SENSe:]LIST:RANGe<range>:IQWindow:TYPE <WindowFunction>**

This command selects the window function for a particular half decade.

Window functions are available for I/Q sweep mode.

**Suffix:**

&lt;range&gt;

1...20

Selects the half decade.

For the suffix assignment see [Table 8-4](#).**Parameters:**

&lt;WindowFunction&gt;

**RECTangular****GAUSSian****CHEBychev****BHARRis**

\*RST: Depends on the half decade

**Example:**

LIST:RANG:IQW:TYPE BHAR

Selects the Blackman Harris window function for the first half decade.

**Manual operation:** See "[Half Decades Configuration Table](#)" on page 46**[SENSe:]LIST:RANGe<range>:SWEep:COUNT <Measurements>**

This command defines the number of measurements included in the averaging for a half decade.

**Suffix:**

&lt;range&gt;

1...20

Selects the half decade.

For the suffix assignment see [Table 8-4](#).**Parameters:**

&lt;Measurements&gt;

Range: 1 to 10000

\*RST: Depends on the half decade

**Example:**

LIST:RANG9:SWE:COUN 15

Includes 15 measurements in the averaging of the ninth half decade.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Half Decades Configuration Table](#)" on page 46**[SENSe:]LIST:SWEep:COUNT <Averages>**

This command defines the number of measurements to be included in the averaging for each and all half decades.

**Parameters:**

&lt;Averages&gt;

Range: 1 to 10000

\*RST: Depends on the half decade.

**Example:**

LIST:SWE:COUN 20

Defines 20 averages for all half decades.

**Manual operation:** See "[Global Average Count](#)" on page 45



**[SENSe:]LIST:SWEep:COUNT:MULTiplier <Multiplier>**

This command defines a multiplier that is applied to the average count in each half decade.

Before you can use the command you have to turn on the multiplier with `[SENSe:]LIST:SWEep:COUNT:MULTiplier:STATe`.

**Parameters:**

<Multiplier>            Numeric value.

**Example:**

```
LIST:SWE:COUN:MULT:STAT ON
```

```
LIST:SWE:COUN:MULT 5
```

Turns on the multiplier and multiplies the averages by 5.

**Manual operation:** See "Multiplier" on page 45

**[SENSe:]LIST:SWEep:COUNT:MULTiplier:STATe <State>**

This command turns a multiplier that is applied to the average count in each half decade on and off.

**Parameters:**

<State>                ON | OFF

\*RST:                OFF

**Example:**

See `[SENSe:]LIST:SWEep:COUNT:MULTiplier` on page 105.

**Manual operation:** See "Multiplier" on page 45

**[SENSe:]SWEep:FORWard <State>**

This command selects the measurement direction.

Specifies the sweep direction. When switched on the sweep direction is from the start frequency to the stop frequency. When switched off the sweep direction is reversed

**Parameters:**

<State>                **ON**

Measurements in forward direction.

The measurements starts at the smallest offset frequency.

**OFF**

Measurement in reverse direction.

The measurement starts at the highest offset frequency.

\*RST:                OFF

**Example:**

```
SWE:FORW ON
```

Selects forward measurements.

**Usage:**

SCPI confirmed

**Manual operation:** See "Sweep Forward" on page 44

---

**[SENSe:]SWEep:MODE** <Mode>

This command selects the type of measurement configuration.

**Parameters:**

<Mode>

**AVERage**

Selects a measurement configuration optimized for quality results.

**FAST**

Selects a measurement configuration optimized for speed.

**MANual**

Selects manual measurement configuration.

**NORMal**

Selects a balanced measurement configuration.

\*RST: NORMal

**Usage:** SCPI confirmed

**Manual operation:** See "Presets" on page 44

## 8.9 Using Limit Lines

The following commands are necessary to set up and configure limit lines.

- [Using Phase Noise Limit Lines](#)..... 106
- [Using Standard Limit Lines](#)..... 109
- [Creating and Editing Standard Limit Lines](#)..... 114

### 8.9.1 Using Phase Noise Limit Lines

<a href="#">CALCulate:PNLimit:COPY&lt;k&gt;</a> .....	106
<a href="#">CALCulate:PNLimit:FC1 &lt;Frequency&gt;</a> .....	107
<a href="#">CALCulate:PNLimit:FC2 &lt;Frequency&gt;</a> .....	107
<a href="#">CALCulate:PNLimit:FC3 &lt;Frequency&gt;</a> .....	107
<a href="#">CALCulate:PNLimit:FC4 &lt;Frequency&gt;</a> .....	107
<a href="#">CALCulate:PNLimit:FC5</a> .....	107
<a href="#">CALCulate:PNLimit:NOISe</a> .....	107
<a href="#">CALCulate:PNLimit:TRACe</a> .....	108
<a href="#">CALCulate:PNLimit:TYPE</a> .....	108
<a href="#">CALCulate:PNLimit:FAIL?</a> .....	108
<a href="#">CALCulate:PNLimit:SLOPe&lt;segment&gt;</a> .....	109

---

**CALCulate:PNLimit:COPY<k>**

Creates a new user limit line from the data of a phase noise limit line.

**Suffix:**

&lt;k&gt;

1...8

Number of the limit line the phase noise limit line is copied to. An existing limit line in that slot is overwritten.

**Example:**

CALC:PNL:COPY2

Copies the phase noise limit line to limit line 3.

**Usage:**

Event

**Manual operation:** See ["Copy to User Limit Line"](#) on page 60

**CALCulate:PNLimit:FC1** <Frequency>**CALCulate:PNLimit:FC2** <Frequency>**CALCulate:PNLimit:FC3** <Frequency>**CALCulate:PNLimit:FC4** <Frequency>**CALCulate:PNLimit:FC5** <Frequency>

This command defines the start frequency of a segment of a phase noise limit line.

CALCulate:PNLimit:FC1 is available for special phase noise limit lines with one segment or more.

CALCulate:PNLimit:FC2 is available for special phase noise limit lines with two segment or more.

CALCulate:PNLimit:FC3 is available for special phase noise limit lines with three segment or more.

CALCulate:PNLimit:FC4 is available for special phase noise limit lines with four segment or more.

CALCulate:PNLimit:FC5 is available for special phase noise limit lines with five segments.

**Parameters:**

&lt;Frequency&gt;

Offset frequency relative to the carrier frequency.

The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.

\*RST: 1 MHz

**Example:**

CALC:PNL:FC1 2MHZ

Defines a corner frequency at 2 MHz offset.

**Manual operation:** See ["Range x - Range y"](#) on page 59

**CALCulate:PNLimit:NOISe** <NoiseLevel>

This command defines the noise floor level of the DUT.

The noise floor level is necessary for the calculation of a phase noise limit line.

**Parameters:**

<NoiseLevel>           Range:     -200 to 200  
                               \*RST:       0  
                               Default unit: dBm/Hz

**Example:**

CALC:PNL:NOIS -150  
 Defines a noise floor level of 150 dBm/Hz.

**Manual operation:** See "[Noise Floor](#)" on page 59

**CALCulate:PNLimit:TRACe** <Trace>

This command selects the trace to assign a phase noise limit line to.

**Parameters:**

<Trace>                 Range:     1 to 6  
                               \*RST:       -

**Example:**

CALC:PNL:TRAC 1  
 Assigns the phase noise limit line to trace 1.

**Manual operation:** See "[Selected Traces](#)" on page 59

**CALCulate:PNLimit:TYPE** <Shape>

This command selects the shape of a phase noise limit line.

**Parameters:**

<Shape>                **FC1**  
                               Limit line defined by the noise floor and 1 corner frequency.

**FC2**  
                               Limit line defined by the noise floor and 2 corner frequencies.

**FC3**  
                               Limit line defined by the noise floor and 3 corner frequencies.

**FC4**  
                               Limit line defined by the noise floor and 4 corner frequencies.

**FC5**  
                               Limit line defined by the noise floor and 5 corner frequencies.

**NONE**  
                               No limit line.

                              \*RST:       NONE

**Example:**

CALC:PNL:TYPE FC2  
 Selects a limit line with 2 corner frequencies.

**Manual operation:** See "[Phase Noise Limit Line](#)" on page 59

**CALCulate:PNLimit:FAIL?**

This command queries the limit check results for phase noise limit lines.

**Return values:**

<LimitCheck>      **1**  
Limit check has passed.

**0**  
Limit check has failed.

**Example:**

CALC:PNL:FAIL?  
Queries the limit check result.

**Usage:**

Query only

**CALCulate:PNLimit:SLOPe<segment> <Slope>**

This command defines the slope for a phase noise limit line segment.

**Suffix:**

<segment>            1...5  
Selects the limit line segment.

**Parameters:**

<Slope>              Level distance from the left border of the limit line segment to the previous one.

\*RST:                10  
Default unit: dB

**Example:**

CALC:PNL:SLOP2 20  
Defines a slope of 20 dB for the second limit line segment.

**Manual operation:** See "Range x - Range y" on page 59

## 8.9.2 Using Standard Limit Lines

CALCulate<n>:LIMit<k>:ACTive?	109
CALCulate<n>:LIMit<k>:CLEar[IMMediate]	110
CALCulate<n>:LIMit<k>:COpy	110
CALCulate<n>:LIMit<k>:DELeTe	110
CALCulate<n>:LIMit<k>:FAIL?	111
CALCulate<n>:LIMit<k>:NAME	111
CALCulate<n>:LIMit<k>:LOWer:STATe	112
CALCulate<n>:LIMit<k>:STATe	112
CALCulate<n>:LIMit<k>:TRACe	112
CALCulate<n>:LIMit<k>:TRACe<t>:CHECK	113
CALCulate<n>:LIMit<k>:UPPer:STATe	113

**CALCulate<n>:LIMit<k>:ACTive?**

This command queries the names of *all* active limit lines.

**Suffix:**

<n>, <k>              irrelevant

**Return values:**

<LimitLines> String containing the names of all active limit lines in alphabetical order.

**Example:**

```
CALC:LIM:ACT?
```

Queries the names of all active limit lines.

**Usage:**

Query only

**Manual operation:** See "[Visible](#)" on page 61

**CALCulate<n>:LIMit<k>:CLEar[IMMediate]**

This command deletes the result of the current limit check.

The command works on *all* limit lines in *all* measurement windows at the same time.

**Suffix:**

<n>, <k> irrelevant

**Example:**

```
CALC:LIM:CLE
```

Deletes the result of the limit check.

**Usage:**

SCPI confirmed

**CALCulate<n>:LIMit<k>:COPY <Line>**

This command copies a limit line.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Parameters:**

<Line> **1 to 8**  
number of the new limit line

**<name>**

String containing the name of the limit line.

**Example:**

```
CALC:LIM1:COPY 2
```

Copies limit line 1 to line 2.

```
CALC:LIM1:COPY 'FM2'
```

Copies limit line 1 to a new line named FM2.

**Manual operation:** See "[New / Edit / Copy To](#)" on page 62

**CALCulate<n>:LIMit<k>:DELeTe**

This command deletes a limit line.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Usage:** Event

**Manual operation:** See "[Delete](#)" on page 62

### **CALCulate<n>:LIMit<k>:FAIL?**

This command queries the result of a limit check in the specified window.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single sweep mode.

See also [INITiate<n>:CONTInuous](#) on page 81.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Return values:**

<Result>           **0**  
                           PASS  
                           **1**  
                           FAIL

**Example:**

```
INIT; *WAI
Starts a new sweep and waits for its end.
CALC2:LIM3:FAIL?
Queries the result of the check for limit line 3 in window 2.
```

**Usage:** Query only  
 SCPI confirmed

**Manual operation:** See "[Check Traces](#)" on page 61

### **CALCulate<n>:LIMit<k>:NAME <Name>**

This command selects a limit line that already exists or defines a name for a new limit line.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Parameters:**

<Name>           String containing the limit line name.  
 \*RST:            REM1 to REM8 for lines 1 to 8

**Manual operation:** See "[New / Edit / Copy To](#)" on page 62  
 See "[Name](#)" on page 63

**CALCulate<n>:LIMit<k>:LOWer:STATe <State>**

This command turns a lower limit line on and off.

Before you can use the command, you have to select a limit line with [CALCulate<n>:LIMit<k>:NAME](#) on page 111.

**Suffix:**

<n> irrelevant

<k> [Limit line](#)

**Parameters:**

<State> ON | OFF

\*RST: OFF

**Usage:** SCPI confirmed

**Manual operation:** See "[Visible](#)" on page 61

**CALCulate<n>:LIMit<k>:STATe <State>**

This command turns the limit check for a specific limit line on and off.

To query the limit check result, use [CALCulate<n>:LIMit<k>:FAIL?](#).

Note that a new command exists to activate the limit check and define the trace to be checked in one step (see [CALCulate<n>:LIMit<k>:TRACe<t>:CHECK](#) on page 113).

**Suffix:**

<n> irrelevant

<k> [Limit line](#)

**Parameters:**

<State> ON | OFF

\*RST: OFF

**Example:** `CALC:LIM:STAT ON`  
Switches on the limit check for limit line 1.

**Usage:** SCPI confirmed

**Manual operation:** See "[Check Traces](#)" on page 61

**CALCulate<n>:LIMit<k>:TRACe <TraceNumber>**

This command links a limit line to one or more traces.

Note that this command is maintained for compatibility reasons only. Limit lines no longer need to be assigned to a trace explicitly. The trace to be checked can be defined directly (as a suffix) in the new command to activate the limit check (see [CALCulate<n>:LIMit<k>:TRACe<t>:CHECK](#) on page 113).



**Suffix:**<n> [Window](#)<k> [Limit line](#)**Example:**

```
CALC:LIM2:TRAC 3
```

Assigns limit line 2 to trace 3.

**Manual operation:** See "[Check Traces](#)" on page 61**CALCulate<n>:LIMit<k>:TRACe<t>:CHECK <State>**

This command turns the limit check for a specific trace on and off.

To query the limit check result, use [CALCulate<n>:LIMit<k>:FAIL?](#).

Note that this command replaces the two commands from previous signal and spectrum analyzers (which are still supported, however):

- [CALCulate<n>:LIMit<k>:TRACe](#) on page 112
- [CALCulate<n>:LIMit<k>:STATe](#) on page 112

**Suffix:**<n> [Window](#)<k> [Limit line](#)<t> [Trace](#)**Parameters:**

```
<State> ON | OFF
*RST: OFF
```

**Example:**

```
CALC:LIM3:TRAC2:CHEC ON
```

Switches on the limit check for limit line 3 on trace 2.

**CALCulate<n>:LIMit<k>:UPPer:STATe <State>**

This command turns an upper limit line on and off.

Before you can use the command, you have to select a limit line with [CALCulate<n>:LIMit<k>:NAME](#) on page 111.

**Suffix:**

&lt;n&gt; irrelevant

<k> [Limit line](#)**Parameters:**

```
<State> ON | OFF
*RST: OFF
```

**Usage:** SCPI confirmed**Manual operation:** See "[Visible](#)" on page 61

### 8.9.3 Creating and Editing Standard Limit Lines

CALCulate<n>:LIMit<k>:COMMeNt.....	114
CALCulate<n>:LIMit<k>:CONTRol[:DATA].....	114
CALCulate<n>:LIMit<k>:CONTRol:SHIFt.....	114
CALCulate<n>:LIMit<k>:LOWer[:DATA].....	115
CALCulate<n>:LIMit<k>:LOWer:MODE.....	115
CALCulate<n>:LIMit<k>:LOWer:SHIFt.....	116
CALCulate<n>:LIMit<k>:UPPeR:MODE.....	116
CALCulate<n>:LIMit<k>:UPPeR[:DATA].....	116
CALCulate<n>:LIMit<k>:UPPeR:SHIFt.....	117

---

#### CALCulate<n>:LIMit<k>:COMMeNt <Comment>

This command defines a comment for a limit line.

##### Suffix:

<n> irrelevant

<k> [Limit line](#)

##### Parameters:

<Comment> String containing the description of the limit line. The comment may have up to 40 characters.

**Manual operation:** See "[Comment](#)" on page 63

---

#### CALCulate<n>:LIMit<k>:CONTRol[:DATA] <LimitLinePoints>

This command defines the horizontal definition points of a limit line.

##### Suffix:

<n> irrelevant

<k> [Limit line](#)

##### Parameters:

<LimitLinePoints> Variable number of x-axis values.  
 Note that the number of horizontal values has to be the same as the number of vertical values set with [CALCulate<n>:LIMit<k>:LOWer\[:DATA\]](#) or [CALCulate<n>:LIMit<k>:UPPeR\[:DATA\]](#). If not, the R&S FSW either adds missing values or ignores surplus values.  
 The unit is Hz.

\*RST: -

**Usage:** SCPI confirmed

**Manual operation:** See "[Data Points](#)" on page 64

---

#### CALCulate<n>:LIMit<k>:CONTRol:SHIFt <Distance>

This command moves a complete limit line horizontally.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

**Suffix:**

<n> irrelevant

<k> [Limit line](#)

**Parameters:**

<Distance> Numeric value.  
The unit depends on the scale of the x-axis.

**Manual operation:** See "[Shift X](#)" on page 64

**CALCulate<n>:LIMit<k>:LOWer[:DATA] <LimitLinePoints>**

This command defines the vertical definition points of a lower limit line.

**Suffix:**

<n> irrelevant

<k> [Limit line](#)

**Parameters:**

<LimitLinePoints> Variable number of level values.  
Note that the number of vertical values has to be the same as the number of horizontal values set with [CALCulate<n>:LIMit<k>:CONTRol\[:DATA\]](#). If not, the R&S FSW either adds missing values or ignores surplus values.

\*RST: Limit line state is OFF

**Usage:** SCPI confirmed

**Manual operation:** See "[Data Points](#)" on page 64

**CALCulate<n>:LIMit<k>:LOWer:MODE <Mode>**

This command selects the vertical limit line scaling.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Parameters:**

<Mode> **ABSolute**  
Limit line is defined by absolute physical values.  
The unit is variable.

**RELative**  
Limit line is defined by relative values related to the reference level (dB).

\*RST: ABSolute

**Manual operation:** See "[X-Axis](#)" on page 63

**CALCulate<n>:LIMit<k>:LOWer:SHIFt <Distance>**

This command moves a complete lower limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Parameters:**

<Distance> Defines the distance that the limit line moves.

**Manual operation:** See "[Shift Y](#)" on page 64

**CALCulate<n>:LIMit<k>:UPPer:MODE <Mode>**

This command selects the vertical limit line scaling.

**Suffix:**

<n> [Window](#)

<k> [Limit line](#)

**Parameters:**

<Mode>

**ABSolute**

Limit line is defined by absolute physical values.  
The unit is variable.

**RELative**

Limit line is defined by relative values related to the reference level (dB).

\*RST: ABSolute

**Manual operation:** See "[X-Axis](#)" on page 63

**CALCulate<n>:LIMit<k>:UPPer[:DATA] <LimitLinePoints>**

This command defines the vertical definition points of an upper limit line.

**Suffix:**

<n> irrelevant

<k> [Limit line](#)

**Parameters:**

<LimitLinePoints>

Variable number of level values.

Note that the number of vertical values has to be the same as the number of horizontal values set with [CALCulate<n>:LIMit<k>:CONTRol\[:DATA\]](#). If not, the R&S FSW either adds missing values or ignores surplus values.

\*RST: Limit line state is OFF

**Usage:** SCPI confirmed

**Manual operation:** See "Data Points" on page 64

---

#### **CALCulate<n>:LIMit<k>:UPPer:SHIFt <Distance>**

This command moves a complete upper limit line vertically.

Compared to defining an offset, this command actually changes the limit line definition points by the value you define.

#### **Suffix:**

<n> irrelevant

<k> Limit line

#### **Parameters:**

<Distance> Defines the distance that the limit line moves.

**Usage:** Event

**Manual operation:** See "Shift Y" on page 64

## 8.10 Graphical Display of Phase Noise Results

The following commands are necessary to set up and configure the graphical phase noise result displays.

CALCulate<n>:MATH[:EXPrESSion][:DEFine].....	118
CALCulate<n>:MATH:STATE.....	118
DISPlay[:WINDow]:TRACe<t>:MODE.....	118
DISPlay[:WINDow]:TRACe<t>:SMOothing:APERture.....	119
DISPlay[:WINDow]:TRACe<t>:SMOothing[:STATE].....	119
DISPlay[:WINDow]:TRACe<t>:SMOothing:TYPE.....	119
DISPlay[:WINDow]:TRACe<t>:SPURs:SUPPResS.....	120
DISPlay[:WINDow]:TRACe:X[:SCALE]:HDECade.....	120
DISPlay[:WINDow]:TRACe:X[:SCALE]:SCOPE.....	121
DISPlay[:WINDow]:TRACe:X[:SCALE]:START.....	121
DISPlay[:WINDow]:TRACe:X[:SCALE]:STOP.....	121
DISPlay[:WINDow]:TRACe:Y[:SCALE].....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:AUTO.....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:MANual.....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel.....	123
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel:LOWer.....	123
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel:OFFSet.....	124
FORMat:DEXPort:DSEParator.....	124
FORMat:DEXPort:HEADer.....	124
FORMat:DEXPort:TRACes.....	124
MMEMory:STORe<n>:TRACe.....	125
[SENSe:]SPURs:SUPPResSion.....	125
[SENSe:]SPURs:THReshold.....	126
TRACe<n>:COPY.....	126
TRACe[:DATA]?.....	126

**CALCulate**<n>:**MATH**[:**EXPRession**][:**DEFine**] <Expression>

This command selects the mathematical expression for trace mathematics.

Before you can use the command, you have to turn trace mathematics on.

**Suffix:**

<n> [Window](#)

**Parameters:**

<Expression> **(TRACE1-TRACE2)**  
Subtracts trace 2 from trace 1.  
**(TRACE1-TRACE3)**  
Subtracts trace 3 from trace 1.  
**(TRACE1-TRACE4)**  
Subtracts trace 4 from trace 1.

**Example:**

```
CALC:MATH:STAT ON
Turns trace mathematics on.
CALC:MATH:EXPR:DEF (TRACE1-TRACE3)
Subtracts trace 3 from trace 1.
```

**Usage:** SCPI confirmed

**Manual operation:** See "[Trace Math](#)" on page 56

**CALCulate**<n>:**MATH**:**STATe** <State>

This command turns the trace mathematics on and off.

**Suffix:**

<n> [Window](#)

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Example:**

```
CALC:MATH:STAT ON
Turns on trace mathematics.
```

**Usage:** SCPI confirmed

**Manual operation:** See "[Trace Math](#)" on page 56

**DISPlay**[:**WINDow**]:**TRACe**<t>:**MODE** <Mode>

This command selects the trace mode.

**Suffix:**

<t> [Trace](#)

**Parameters:**

<Mode> WRITe | VIEW | AVERAge | MAXHold | MINHold | BLANK  
\*RST: Trace 1/2: WRITe, Trace 3-6: BLANK

**Example:**

```
INIT:CONT OFF
SWE:COUN 16
Turns on single sweep mode and defines a count of 16 measurements.
DISP:TRAC2:MODE AVER
Select average trace mode for trace 2.
INIT;*WAI
Performs the measurement (16 sweeps) with synchronization to the end.
```

**Manual operation:** See "[Traces](#)" on page 54

#### DISPlay[:WINDow]:TRACe<t>:SMOothing:APERture <Aperture>

This command defines the degree (aperture) of the trace smoothing.

A single aperture applies to all traces which require smoothing.

**Suffix:**

<t> [Trace](#)

**Parameters:**

<Aperture>           Range:     1 to 20  
                          \*RST:     0  
                          Default unit: PCT

**Example:**

```
DISP:TRAC:SMO:APER 5
Defines an aperture of 5%.
```

**Usage:**                SCPI confirmed

**Manual operation:** See "[Trace Smoothing](#)" on page 53

#### DISPlay[:WINDow]:TRACe<t>:SMOothing[:STATe] <State>

This command turns trace smoothing for a particular trace on and off.

**Suffix:**

<t> [Trace](#)

**Parameters:**

<State>                ON | OFF  
                          \*RST:     OFF

**Example:**

```
DISP:TRAC2:SMO ON
Turns on trace smoothing for trace 2.
```

**Usage:**                SCPI confirmed

**Manual operation:** See "[Traces](#)" on page 54

#### DISPlay[:WINDow]:TRACe<t>:SMOothing:TYPE <Type>

This command selects the trace smoothing method.

<b>Suffix:</b>	
<t>	Trace
<b>Parameters:</b>	
<Type>	<b>LINear</b> Linear smoothing.
	<b>LOGarithmic</b> Logarithmic smoothing.
	<b>MEDian</b> Median smoothing.
	*RST: LIN
<b>Example:</b>	DISP:TRAC2:SMO:TYPE LIN Selects linear smoothing for trace 2.
<b>Usage:</b>	SCPI confirmed
<b>Manual operation:</b>	See "Smoothing Type" on page 53

#### DISPlay[:WINDow]:TRACe<t>:SPURs:SUPPress <State>

This command turns spur suppression on individual traces on and off.

<b>Suffix:</b>	
<t>	Trace
<b>Parameters:</b>	
<State>	ON   OFF
	*RST: OFF
<b>Example:</b>	DISP:TRAC3:SPUR:SUPP ON Turns on spur suppression on trace 3.
<b>Manual operation:</b>	See "Traces" on page 54

#### DISPlay[:WINDow]:TRACe:X[:SCALE]:HDECade <HalfDecade>

This command selects the half decade to be displayed.

Before you can use the command you have to select the half decade scope for the x-axis with `DISPlay[:WINDow]:TRACe:X[:SCALE]:SCOPE`.

<b>Parameters:</b>	
<HalfDecade>	Start offset frequency of the half decade you want to display. Note that the half decade you want to display has to be part of the current measurement range.
	Range: 100 mHz...300 mHz to 3 GHz...10GHz
	*RST: Half decade display is off.
<b>Example:</b>	DISP:TRAC:X:HDEC 1KHZ Displays the half decade beginning with 1 kHz.
<b>Manual operation:</b>	See "Half Decade" on page 52



**DISPlay[:WINDow]:TRACe:X[:SCALe]:SCOPE** <Scope>

This command selects the way the application scales the horizontal axis.

**Parameters:**

&lt;Scope&gt;

**HDECade**

Shows a particular half decade only.

You can select a particular half decade with .

**MANual**

Shows a custom part of the measurement range.

You can select the start and stop offsets with .

**MRANGe**

Shows the complete measurement range.

\*RST: MRANGe

**Example:**

```
DISP:TRAC:X:SCOP MRAN
```

Shows the complete measurement range on the x-axis.

**Manual operation:** See "[X-Axis Scope](#)" on page 51

**DISPlay[:WINDow]:TRACe:X[:SCALe]:STARt** <StartFrequency>

This command selects the start frequency of the display range.

Before you can use the command you have to select a manual display range for the x-axis with [DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:SCOPE](#).

**Parameters:**

&lt;StartFrequency&gt;

Start offset frequency of a half decade.

Note that the start offset you want to display has to be part of the current measurement range.

Range: 100 mHz to 3 GHz

\*RST: Manual display range is OFF

**Example:**

```
DISP:TRAC:X:STAR 100HZ
```

Defines 100 Hz as the start of the display range.

**Manual operation:** See "[X-Axis Start / Stop](#)" on page 52

**DISPlay[:WINDow]:TRACe:X[:SCALe]:STOP** <StopFrequency>

This command selects the stop frequency of the display range.

Before you can use the command you have to select a manual display range for the x-axis with [DISPlay\[:WINDow\]:TRACe:X\[:SCALe\]:SCOPE](#).

**Parameters:**

&lt;StopFrequency&gt;

Stop offset frequency of a half decade.

Note that the stop offset you want to display has to be part of the current measurement range.

Range: 300 mHz to 10 GHz

\*RST: Manual display range is OFF

**Example:** `DISP:TRAC:X:STOP 3KHZ`  
 Defines 3 kHz as the end of the display range.

**Manual operation:** See "[X-Axis Start / Stop](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe] <Range>**

This command defines the display range.

Note that you have to select manual y-axis scaling before you can use the command.

**Parameters:**

<Range>            Range:     1 to 200  
                      \*RST:     100  
                      Default unit: dB

**Example:** `DISP:TRAC:Y 80`  
 Defines a display range over 80 dB.

**Manual operation:** See "[Top / Range / Bottom](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe]:AUTO <Mode>**

This command turns automatic scaling of the vertical axis on and off.

**Parameters:**

<Mode>            **ON**  
                      Automatic scaling is on.  
                      **OFF**  
                      Automatic scaling is off.  
                      **ONCE**  
                      Automatic scaling is performed once, then turned off again.  
                      \*RST:     ON

**Example:** `DISP:WIND2:TRAC:Y:SCAL:AUTO ONCE`  
 Scales the vertical axis once.

**Manual operation:** See "[Y Axis Scaling](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe]:MANual <Mode>**

This command selects the type of manual scaling of the vertical axis.

**Parameters:**

&lt;Mode&gt;

**BRANge**

Scaling based on the value at the bottom of the diagram and the axis range.

**OFF**

Turns manual scaling of the y-axis off.

**TBOTtom**

Scaling based on the values on the bottom and top of the diagram.

**TRANge**

Scaling based on the value at the top of the diagram and the axis range.

\*RST: ON

**Example:**

```
DISP:WIND2:TRAC:Y:SCAL:MAN TRAN
```

Scaling of the vertical axis based on the top and the range of the axis.

**Manual operation:** See "[Y Axis Scaling](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel <Reference>**

This command defines the reference value or upper border of the diagram area.

Note that you have to select manual y-axis scaling before you can use the command.

**Parameters:**

&lt;Reference&gt;

Range: -200 to 0

\*RST: -20

Default unit: dBc/Hz

**Example:**

```
DISP:TRAC:Y:RLEV -50
```

Defines a reference value of -50 dBc/Hz.

**Manual operation:** See "[Top / Range / Bottom](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel:LOWer <LowerReference>**

This command defines the reference value or upper border of the diagram area.

Note that you have to select manual y-axis scaling before you can use the command.

**Parameters:**

&lt;LowerReference&gt;

Range: -400 to 1

\*RST: -120

Default unit: dBc/Hz

**Example:**

```
DISP:TRAC:Y:RLEV:LOW -100
```

Sets the bottom of the diagram to .100 dBc/Hz.

**Manual operation:** See "[Top / Range / Bottom](#)" on page 52

**DISPlay[:WINDow]:TRACe:Y[:SCALe]:RLEVel:OFFSet <Offset>**

This command defines the trace offset.

**Parameters:**

<Offset>                    Range:        -200 to 200  
                               \*RST:        0dB  
                               Default unit: dB

**Example:**                DISP:TRAC:Y:RLEV:OFFS -10  
 Defines a trace offset of -10 dB.

**Manual operation:**    See "[Trace Offset](#)" on page 53

**FORMat:DEXPort:DSEParator <Separator>**

This command selects the decimal separator for data exported in ASCII format.

**Parameters:**

<Separator>                **COMMa**  
 Uses a comma as decimal separator, e.g. 4,05.  
                               **POINT**  
 Uses a point as decimal separator, e.g. 4.05.  
                               \*RST:        \*RST has no effect on the decimal separator.  
                               Default is POINT.

**Example:**                FORM:DEXP:DSEP POIN  
 Sets the decimal point as separator.

**Manual operation:**    See "[Trace Export](#)" on page 55

**FORMat:DEXPort:HEADer <State>**

If enabled, additional instrument and measurement settings are included in the header of the export file for result data. If disabled, only the pure result data from the selected traces and tables is exported.

**Parameters:**

<State>                    ON | OFF | 0 | 1  
                               \*RST:        1

**Usage:**                    SCPI confirmed

**Manual operation:**    See "[Trace Export](#)" on page 55

**FORMat:DEXPort:TRACes <Selection>**

This command selects the data to be included in a data export file (see [MMEMory:STORe<n>:TRACe](#) on page 125).

**Parameters:**

&lt;Selection&gt;

**SINGle**

Only a single trace is selected for export, namely the one specified by the `MMEMoRY:STORe<n>:TRACe` command.

**ALL**

Selects all active traces and result tables (e.g. Result Summary, marker peak list etc.) in the current application for export to an ASCII file.

The <trace> parameter for the `MMEMoRY:STORe<n>:TRACe` command is ignored.

\*RST: SINGle

**Usage:**

SCPI confirmed

**Manual operation:** See "[Trace Export](#)" on page 55

**MMEMoRY:STORe<n>:TRACe** <Trace>, <FileName>

This command exports trace data from the specified window to an ASCII file.

**Secure User Mode**

In secure user mode, settings that are stored on the instrument are stored to volatile memory, which is restricted to 256 MB. Thus, a "Memory full" error can occur although the hard disk indicates that storage space is still available.

To store data permanently, select an external storage location such as a USB memory device.

For details, see "Protecting Data Using the Secure User Mode" in the "Data Management" section of the R&S FSW User Manual.

**Suffix:**

&lt;n&gt;

[Window](#)**Parameters:**

&lt;Trace&gt;

Number of the trace to be stored

&lt;FileName&gt;

String containing the path and name of the target file.

**Example:**

```
MME:STOR1:TRAC 3, 'C:\TEST.ASC'
```

Stores trace 3 from window 1 in the file TEST.ASC.

**Usage:**

SCPI confirmed

**Manual operation:** See "[Trace Export](#)" on page 55

**[SENSe:]SPURs:SUPPReSSion** <State>

This command turns spur suppression on and off.

**Parameters:**

&lt;State&gt;

ON | OFF

\*RST: ON

**Example:** `SPUR:SUPP OFF`  
Turns spur suppression off.

**Manual operation:** See "[Spur Removal / Spur Threshold](#)" on page 56

**[SENSe:]SPURs:THReshold** <Threshold>

This command defines the level threshold for spur removal.

**Parameters:**  
<Threshold> Range: 0 to 50  
\*RST: 0  
Default unit: dB

**Example:** `SPUR:THR 10`  
Defines a spur threshold of 50 dB.

**Manual operation:** See "[Spur Removal / Spur Threshold](#)" on page 56

**TRACe<n>:COPY** <TraceNumber>, <TraceNumber>

This command copies data from one trace to another.

**Suffix:**  
<n> [Window](#)

**Parameters:**  
<TraceNumber>, **TRACE1 | TRACE2 | TRACE3 | TRACE4 | TRACE5 | TRACE6**  
<TraceNumber> The first parameter is the destination trace, the second parameter is the source.  
(Note the 'e' in the parameter is required!)

**Example:** `TRAC:COPY TRACE1,TRACE2`  
Copies the data from trace 2 to trace 1.

**Usage:** SCPI confirmed

**Manual operation:** See "[Copy Trace](#)" on page 55

**TRACe[:DATA]? <Trace>**

This command queries the results of the graphical result displays.

**Parameters:**  
<Trace> TRACE1 | TRACE2 | TRACE3 | TRACE4 | TRACE5 | TRACE6

**Return values:**

<Frequency>  
<Level>

**Phase noise:**

Coordinates of the phase noise trace as list of comma separated values, beginning at the nearest offset frequency.

<OffsetFrequency1>,<Level1>,<OffsetFrequency2>,<Level2>,...

**Spectrum monitor:**

Coordinates of the spectrum trace as a list of comma separated values, beginning at the left border of the display.

<Frequency1>,<Level1>,<Frequency2>,<Level2>,...

<Time>, <Frequency>**Frequency drift:**

Coordinates of the frequency drift trace as a list of comma separated values, beginning at the left border of the display.

<Time1>,<Frequency1>,<Time2>,<Frequency2>,...

**Example:**

TRAC? TRACE1

Queries the data of trace 1.

**Usage:**

Query only

**Manual operation:**

See "[Phase Noise Diagram](#)" on page 14

See "[Spectrum Monitor](#)" on page 19

## 8.11 Configure Numerical Result Displays

The following commands are necessary to configure the numerical phase noise result displays.

- [Configuring Residual Noise Measurements](#)..... 127
- [Reading Out Residual Noise Results](#)..... 130
- [Configuring Spot Noise Measurements](#)..... 132
- [Reading Out the Spur List](#)..... 135
- [Reading Out Measured Values](#)..... 136
- [Reading Out the Sweep Result List](#)..... 137

### 8.11.1 Configuring Residual Noise Measurements

<a href="#">CALCulate&lt;n&gt;:EVALuation:START</a> .....	127
<a href="#">CALCulate&lt;n&gt;:EVALuation[:STATe]</a> .....	128
<a href="#">CALCulate&lt;n&gt;:EVALuation:STOP</a> .....	128
<a href="#">CALCulate&lt;n&gt;:EVALuation:USER&lt;range&gt;:START</a> .....	129
<a href="#">CALCulate&lt;n&gt;:EVALuation:USER&lt;range&gt;:STOP</a> .....	129
<a href="#">CALCulate&lt;n&gt;:EVALuation:USER&lt;range&gt;:TRACe</a> .....	129

---

#### **CALCulate<n>:EVALuation:START** <OffsetFrequency>

This command defines the start point of the residual noise integration range.

Before you can use the command, you have to turn on the measurement range integration with [CALCulate<n>:EVALuation\[:STATe\]](#) on page 128.

**Suffix:**<n> [Window](#)**Parameters:**

&lt;OffsetFrequency&gt; The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.

\*RST: 1 kHz

**Example:**

CALC:EVAL:STAR 1 kHz

Defines an start point of 1 kHz for the residual noise range.

**Manual operation:** See "[Meas Range](#)" on page 57**CALCulate<n>:EVALuation[:STATe] <State>**

This command turn integration of the measurement range for residual noise calculation on and off.

**Suffix:**<n> [Window](#)**Parameters:**

&lt;State&gt;

**OFF**

Calculates the residual noise over the entire measurement range.

**ON**

Calculates the residual noise over a customized range.

\*RST: OFF

**Example:**

CALC:EVAL ON

Uses a customized offset range for residual noise calculation.

**Manual operation:** See "[Meas Range](#)" on page 57**CALCulate<n>:EVALuation:STOP <OffsetFrequency>**

This command defines the end point of the residual noise integration range.

Before you can use the command, you have to turn on the measurement range integration with [CALCulate<n>:EVALuation\[:STATe\]](#) on page 128.**Suffix:**<n> [Window](#)**Parameters:**

&lt;OffsetFrequency&gt; The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.

\*RST: 1 MHz

**Example:**

CALC:EVAL:STOP 1 MHz

Defines an end point of 1 MHz for the residual noise range.

**Manual operation:** See "[Meas Range](#)" on page 57



**CALCulate<n>:EVALuation:USER<range>:START <OffsetFrequency>**

This command defines the start point of a custom residual noise calculation range.

Before you can use the command, you have to assign the user range to a trace with [CALCulate<n>:EVALuation:USER<range>:TRACe](#) on page 129.

**Suffix:**

<n> [Window](#)

**Parameters:**

<OffsetFrequency> The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.

\*RST: 1 MHz

**Example:**

CALC:EVAL:USER2:STAR 1kHz

Defines a start point of 1 kHz for the second user range.

**Manual operation:** See "[User Range](#)" on page 57

**CALCulate<n>:EVALuation:USER<range>:STOP <OffsetFrequency>**

This command defines the end point of a custom residual noise calculation range.

Before you can use the command, you have to assign the user range to a trace with [CALCulate<n>:EVALuation:USER<range>:TRACe](#) on page 129.

**Suffix:**

<n> [Window](#)

**Parameters:**

<OffsetFrequency> The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.

\*RST: 1 MHz

**Example:**

CALC:EVAL:USER2:STOP 100kHz

Defines an end point of 100 kHz for the second user range.

**Manual operation:** See "[User Range](#)" on page 57

**CALCulate<n>:EVALuation:USER<range>:TRACe <Trace>**

This command selects the trace for a custom residual noise calculation range.

**Suffix:**

<n> [Window](#)

<range> 1...3  
Selects the user range.

**Parameters:**

<Trace> **NONE**  
Turns a user range off.

**TRACE1 ... TRACE6**  
Trace to assign the user range to.

**Example:** `CALC:EVAL:USER2:TRAC TRACE2`  
Assigns the second user range to trace 2.

**Manual operation:** See "[User Range](#)" on page 57

### 8.11.2 Reading Out Residual Noise Results

<a href="#">FETCh:PNOise:IPN?</a> .....	130
<a href="#">FETCh:PNOise&lt;t&gt;:RFM?</a> .....	130
<a href="#">FETCh:PNOise&lt;t&gt;:RMS?</a> .....	130
<a href="#">FETCh:PNOise&lt;t&gt;:RPM?</a> .....	131
<a href="#">FETCh:PNOise&lt;t&gt;:USER&lt;range&gt;:IPN?</a> .....	131
<a href="#">FETCh:PNOise&lt;t&gt;:USER&lt;range&gt;:RFM?</a> .....	131
<a href="#">FETCh:PNOise&lt;t&gt;:USER&lt;range&gt;:RMS?</a> .....	131
<a href="#">FETCh:PNOise&lt;t&gt;:USER&lt;range&gt;:RPM?</a> .....	132

---

#### FETCh:PNOise:IPN?

This command queries the Integrated Phase Noise for the first trace.

**Example:** `FETC:PNO2:IPN?`  
Queries the Integrated Phase Noise for the first trace in the diagram.

**Usage:** Query only

---

#### FETCh:PNOise<t>:RFM?

This command queries the residual FM for the first trace.

**Suffix:**  
<t> [Trace](#)

**Example:** `FETC:PNO2:RFM?`  
Queries the residual FM for the first trace in the diagram.

**Usage:** Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

---

#### FETCh:PNOise<t>:RMS?

This command queries the residual RMS jitter for the first trace.

**Suffix:**  
<t> [Trace](#)

**Example:** `FETC:PNO2:RMS?`  
Queries the RMS jitter for the first trace in the diagram.

**Usage:** Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

**FETCh:PNOise<t>:RPM?**

This command queries the residual PM for the first trace.

**Suffix:**

<t> [Trace](#)

**Example:**

FETC:PNO:RPM?

Queries the residual PM for the first trace of the diagram.

**Usage:**

Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

**FETCh:PNOise<t>:USER<range>:IPN?**

This command queries the Integrated Phase Noise for a particular user range.

The trace that is queried depends on [CALCulate<n>:EVALuation:USER<range>:TRACe](#).

**Suffix:**

<t> [Trace](#)

<range>

1...3

Selects the user range.

**Example:**

FETC:PNO:USER2:IPN?

Queries the Integrated Phase Noise for user range 2.

**Usage:**

Query only

**FETCh:PNOise<t>:USER<range>:RFM?**

This command queries the residual FM for a particular user range.

The trace that is queried depends on [CALCulate<n>:EVALuation:USER<range>:TRACe](#).

**Suffix:**

<t> [Trace](#)

<range>

1...3

Selects the user range.

**Example:**

FETC:PNO:USER2:RFM?

Queries the residual FM for user range 2.

**Usage:**

Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

**FETCh:PNOise<t>:USER<range>:RMS?**

This command queries the residual RMS jitter for a particular user range.

The trace that is queried depends on `CALCulate<n>:EVALuation:USER<range>:TRACe`.

**Suffix:**

<t> [Trace](#)

<range> 1...3  
Selects the user range.

**Example:**

`FETC:PNO:USER2:RMS?`  
Queries the RMS jitter for user range 2.

**Usage:**

Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

**FETCh:PNOise<t>:USER<range>:RPM?**

This command queries the residual PM for a particular user range.

The trace that is queried depends on `CALCulate<n>:EVALuation:USER<range>:TRACe`.

**Suffix:**

<t> [Trace](#)

<range> 1...3  
Selects the user range.

**Example:**

`FETC:PNO:USER2:RPM?`  
Queries the residual PM for user range 2.

**Usage:**

Query only

**Manual operation:** See "[Residual Noise](#)" on page 15

### 8.11.3 Configuring Spot Noise Measurements

<code>CALCulate&lt;n&gt;:SNOise:AOff</code> .....	132
<code>CALCulate&lt;n&gt;:SNOise:DECades[:STATe]</code> .....	133
<code>CALCulate&lt;n&gt;:SNOise:DECades:X?</code> .....	133
<code>CALCulate&lt;n&gt;:SNOise:DECades:Y?</code> .....	133
<code>CALCulate&lt;n&gt;:SNOise&lt;m&gt;:STATe</code> .....	134
<code>CALCulate&lt;n&gt;:SNOise&lt;m&gt;:X</code> .....	134
<code>CALCulate&lt;n&gt;:SNOise&lt;m&gt;:Y?</code> .....	135
<code>DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:SELect</code> .....	135

**CALCulate<n>:SNOise:AOff**

This command turns all spot noise markers off (custom and 10<sup>x</sup> markers).

**Suffix:**

<n> [Window](#)

- Example:** `CALC:SNO:AOFF`  
Turns all spot noise markers off.
- Usage:** Event
- Manual operation:** See ["On User Defined Offsets / Offset Frequency"](#) on page 58

#### **CALCulate<n>:SNOise:DECades[:STATe] <State>**

This command turns the spot noise calculation on every 10<sup>x</sup> offset frequency on and off.

**Suffix:**  
<n> [Window](#)

**Parameters:**  
<State> ON | OFF  
\*RST: ON

**Example:** `CALC:SNO:DEC ON`  
Turns the spot noise calculation for each decade start on.

**Manual operation:** See ["On All Decade Edges"](#) on page 58

#### **CALCulate<n>:SNOise:DECades:X?**

This command queries the horizontal position of the 10<sup>x</sup> offset frequency spot noise markers.

**Suffix:**  
<n> [Window](#)

**Return values:**  
<OffsetFrequency> List of offset frequencies, one for each 10<sup>x</sup> spot noise marker. The number of return values depends on the measurement range.  
Default unit: Hz

**Example:** `CALC:SNO:DEC:X?`  
Return values, e.g.:  
1000,10000,100000,1000000

**Usage:** Query only

**Manual operation:** See ["Spot Noise"](#) on page 16  
See ["On All Decade Edges"](#) on page 58

#### **CALCulate<n>:SNOise:DECades:Y?**

This command queries the vertical position of the 10<sup>x</sup> offset frequency spot noise markers.

**Suffix:**  
<n> [Window](#)

**Return values:**

&lt;Level&gt;

List of level values, one for each 10<sup>x</sup> spot noise marker. The number of return values depends on the measurement range.

Default unit: dBc/Hz

**Example:**

```
CALC:SNO:DEC:Y?
```

Return values, e.g.:

```
-152.560974121094, -136.443389892578,
-145.932891845703, -152.560974121094
```

**Usage:**

Query only

**Manual operation:**

See "[Spot Noise](#)" on page 16

See "[On All Decade Edges](#)" on page 58

**CALCulate<n>:SNOise<m>:STATe <State>**

This command turns a custom spot noise marker on and off.

**Suffix:**

<n> [Window](#)

<m> 1...5  
Selects the spot noise marker.

**Parameters:**

<State> ON | OFF

\*RST: All ON

**Example:**

```
CALC:SNO3:STATE ON
```

Turns spot noise marker 3 on.

**Manual operation:**

See "[On User Defined Offsets / Offset Frequency](#)" on page 58

**CALCulate<n>:SNOise<m>:X <OffsetFrequency>**

This command defines the horizontal position of a custom spot noise marker.

**Suffix:**

<n> [Window](#)

<m> 1...5  
Selects the spot noise marker.

**Parameters:**

<OffsetFrequency> The minimum offset is 1 Hz. The maximum offset depends on the hardware you are using.  
The default value varies for each of the five spot noise markers. For marker 1 it is 1 kHz, for marker 2 it is 10 kHz, for marker 3 it is 100 kHz, for marker 4 it is 1 MHz and for marker 5 it is 10 MHz

**Example:** `CALC:SNO3:X 2MHz`  
Positions the third custom spot noise marker to an offset frequency of 2 MHz.

**Manual operation:** See ["On User Defined Offsets / Offset Frequency"](#) on page 58

#### **CALCulate<n>:SNOise<m>:Y?**

This command queries the vertical position of a custom spot noise marker.

**Suffix:**

<n> [Window](#)  
<m> 1...5  
Selects the spot noise marker

**Return values:**

<Level> <numeric value>  
Phase noise level at the marker position.  
Default unit: dBc/Hz

**Example:** `CALC:SNO3:Y?`  
Queries the level of the third custom spot noise marker.

**Usage:** Query only

**Manual operation:** See ["Spot Noise"](#) on page 16  
See ["On User Defined Offsets / Offset Frequency"](#) on page 58

#### **DISPlay[:WINDow<n>]:TRACe<t>:SElect <Trace>**

This command selects the trace for which spot noise results are calculated.

A trace can only be selected if it has been turned on ("Trace Mode" ≠ Blank).

**Suffix:**

<n>, <t> irrelevant

**Parameters:**

<Trace> Number of the trace you want to select.  
Range: 1 to 6  
\*RST: 1

**Example:** `DISP:TRAC:SEL 2`  
Selects trace number 2.

**Manual operation:** See ["Spot Noise"](#) on page 16

### 8.11.4 Reading Out the Spur List

<a href="#">FETCh:PNOise:SPURs?</a> .....	136
<a href="#">FETCh:PNOise:SPURs:DISCcrete?</a> .....	136
<a href="#">FETCh:PNOise:SPURs:RANDom?</a> .....	136

**FETCH:PNOise:SPURs?**

This command queries the location and level of all spurs that have been detected.

**Return values:**

<Spurs> Returns two values (frequency and level) for each spur that has been detected.

**Example:**

FETCH:PNO:SPUR?  
would return, e.g.  
1999.232666,-0.639974,6494.312500,-0.760579,  
19992.324219,-0.639974

**Usage:** Query only

**Manual operation:** See "[Spur List](#)" on page 17

**FETCH:PNOise:SPURs:DISCReTe?**

This command queries the Discrete Jitter result.

**Return values:**

<Jitter> Default unit: s

**Example:**

FETCH:PNO:SPUR:DISC?  
would return, e.g.  
2.3e-08

**Usage:** Query only

**Manual operation:** See "[Spur List](#)" on page 17

**FETCH:PNOise:SPURs:RANDOm?**

This command queries the Random Jitter result.

**Return values:**

<Jitter> Default unit: s

**Example:**

FETCH:PNO:SPUR:RAND?  
would return, e.g.  
3.59e-09

**Usage:** Query only

**Manual operation:** See "[Spur List](#)" on page 17

**8.11.5 Reading Out Measured Values**

<a href="#">FETCH:PNOise:MEASured:FREQuency?</a> .....	137
<a href="#">FETCH:PNOise:MEASured:LEVel?</a> .....	137



**FETCh:PNOise:MEASured:FREQuency?**

This command queries the carrier frequency that has been actually measured.

The measured frequency is shown in the channel bar.

**Return values:**

<Frequency>            Frequency in Hz.

**Example:**

FETC:PNO:MEAS:FREQ?  
Queries the measured frequency.

**Usage:**

Query only

**FETCh:PNOise:MEASured:LEVel?**

This command queries the level of the DUT that has been actually measured.

The measured level is shown in the channel bar.

**Return values:**

<Level>                Level in dBm.

**Example:**

FETC:PNO:MEAS:LEV?  
Queries the measured level.

**Usage:**

Query only

**8.11.6 Reading Out the Sweep Result List**

FETCh:PNOise:SWEep:AVG?	137
FETCh:PNOise:SWEep:FDRift?	138
FETCh:PNOise:SWEep:LDRift?	138
FETCh:PNOise:SWEep:MDRift?	138
FETCh:PNOise:SWEep:SRATe?	139
FETCh:PNOise:SWEep:START?	139
FETCh:PNOise:SWEep:STOP?	139

**FETCh:PNOise:SWEep:AVG?**

This command queries the number of measurements that have been performed in each half decade.

**Return values:**

<Measurements>        Number of measurements as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.

**Example:**

FETC:PNO:SWE:AVG?  
would return, e.g.:  
10,10,10,10,10

**Usage:**

Query only

**Manual operation:** See ["Sweep Result List"](#) on page 18

---

**FETCh:PNOise:SWEep:FDRift?**

This command queries the frequency drift in each half decade.

**Return values:**

<Frequency> Frequency drift as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: Hz

**Example:**

```
FETC:PNO:SWE:FDR?  
would return, e.g.:  
-203.565049124882,-198.254803592339,  
-179.608235809952,-126.506989398971,  
-95.0386250484735
```

**Usage:** Query only

**Manual operation:** See ["Sweep Result List"](#) on page 18

---

**FETCh:PNOise:SWEep:LDRift?**

This command queries the level drift in each half decade.

**Return values:**

<Level> Level drift as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: dB

**Example:**

```
FETC:PNO:SWE:LDR?  
would return, e.g.:  
0.84823463324,6.55278904401,1.02393361087,  
2.10021296216,5.28119567376
```

**Usage:** Query only

**Manual operation:** See ["Sweep Result List"](#) on page 18

---

**FETCh:PNOise:SWEep:MDRift?**

This command queries the maximum frequency drift in each half decade.

**Return values:**

<Frequency> Frequency drift as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: Hz

**Example:** `FETCH:PNO:SWE:MDR?`  
would return, e.g.:  
2.17, 11.45, 105.11, 219.37, 553.48

**Usage:** Query only

**Manual operation:** See "[Sweep Result List](#)" on page 18

---

#### **FETCH:PNOise:SWEep:SRATe?**

This command queries the sampling rate used in each half decade.

**Return values:**  
<SamplingRate> Sampling rate as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: Hz

**Example:** `FETCH:PNO:SWE:SRAT?`  
would return, e.g.:  
25000, 75000, 250000, 750000, 2500000

**Usage:** Query only

**Manual operation:** See "[Sweep Result List](#)" on page 18

---

#### **FETCH:PNOise:SWEep:STARt?**

This command queries the start frequency offset of each half decade.

**Return values:**  
<Frequency> Frequency offset as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: Hz

**Example:** `FETCH:PNO:SWE:STAR?`  
would return, e.g.:  
1000, 3000, 10000, 30000, 100000

**Usage:** Query only

**Manual operation:** See "[Sweep Result List](#)" on page 18

---

#### **FETCH:PNOise:SWEep:STOP?**

This command queries the stop frequency offset of each half decade.

**Return values:**  
<Measurements> Frequency offset as displayed in the Sweep Result List.  
The command returns one value for each half decade as a comma separated list.  
Default unit: Hz

**Example:** FETC:PNO:SWE:STOP?  
would return, e.g.:  
3000,10000,30000,100000,300000

**Usage:** Query only

**Manual operation:** See "Sweep Result List" on page 18

## 8.12 Using Markers

The following commands are necessary to control markers.

- [Using Markers](#)..... 140
- [Using Delta Markers](#)..... 142
- [Configuring Markers](#)..... 145
- [Using the Marker Zoom](#)..... 146

### 8.12.1 Using Markers

<a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:AOFF</a> .....	140
<a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;[:STATe]</a> .....	140
<a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:TRACe</a> .....	141
<a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:X</a> .....	141
<a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:Y?</a> .....	142

---

#### **CALCulate<n>:MARKer<m>:AOFF**

This command turns all markers off.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Example:** CALC:MARK:AOFF  
Switches off all markers.

**Usage:** Event

**Manual operation:** See "All Markers Off" on page 66

---

#### **CALCulate<n>:MARKer<m>[:STATe] <State>**

This command turns markers on and off. If the corresponding marker number is currently active as a deltamarker, it is turned into a normal marker.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Example:**

CALC:MARK3 ON  
 Switches on marker 3.

**Manual operation:** See "[Marker 1 ... Marker x](#)" on page 65  
 See "[Marker Type](#)" on page 66

**CALCulate<n>:MARKer<m>:TRACe <Trace>**

This command selects the trace the marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<Trace> **1 to 6**  
 Trace number the marker is assigned to.

**Example:**

CALC:MARK3:TRAC 2  
 Assigns marker 3 to trace 2.

**Manual operation:** See "[Assigning the Marker to a Trace](#)" on page 66

**CALCulate<n>:MARKer<m>:X <Position>**

This command moves a marker to a particular coordinate on the x-axis.

If necessary, the command activates the marker.

If the marker has been used as a delta marker, the command turns it into a normal marker.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<Position> Numeric value that defines the marker position on the x-axis.  
 Default unit: Hz

**Example:**

CALC:MARK2:X 1.7MHz  
 Positions marker 2 to frequency 1.7 MHz.

**CALCulate<n>:MARKer<m>:Y?**

This command queries the position of a marker on the y-axis.

If necessary, the command activates the marker first.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single sweep mode.

See also [INITiate<n>:CONTinuous](#) on page 81.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Return values:**

<Level> Phase noise level of the marker.  
Default unit: dBc/Hz

**Example:**

```
INIT:CONT OFF
Switches to single measurement mode.
CALC:MARK2 ON
Switches marker 2.
INIT;*WAI
Starts a measurement and waits for the end.
CALC:MARK2:Y?
Outputs the measured value of marker 2.
```

**Usage:** Query only

**8.12.2 Using Delta Markers**

<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;:AOFF</a> .....	142
<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;:MREF</a> .....	143
<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;[:STATe]</a> .....	143
<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;:TRACe</a> .....	143
<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;:X</a> .....	144
<a href="#">CALCulate&lt;n&gt;:DELTamarker&lt;m&gt;:Y?</a> .....	144

**CALCulate<n>:DELTamarker<m>:AOFF**

This command turns *all* delta markers off.

**Suffix:**

<n> [Window](#)

<m> irrelevant

**Example:**

```
CALC:DELT:AOFF
Turns all delta markers off.
```

**Usage:** Event

**CALCulate<n>:DELTamarker<m>:MREF <Reference>**

This command selects a reference marker for a delta marker other than marker 1.

The reference may be another marker or the fixed reference.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<Reference> **1 to 16**

Selects markers 1 to 16 as the reference.

**FIXed**

Selects the fixed reference as the reference.

**Example:**

`CALC:DELT3:MREF 2`

Specifies that the values of delta marker 3 are relative to marker 2.

**Manual operation:** See ["Reference Marker"](#) on page 66

**CALCulate<n>:DELTamarker<m>[:STATe] <State>**

This command turns delta markers on and off.

If necessary, the command activates the delta marker first.

No suffix at DELTmarker turns on delta marker 1.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<State> ON | OFF

\*RST: OFF

**Example:**

`CALC:DELT2 ON`

Turns on delta marker 2.

**Manual operation:** See ["Marker 1 ... Marker x"](#) on page 65  
See ["Marker Type"](#) on page 66

**CALCulate<n>:DELTamarker<m>:TRACe <Trace>**

This command selects the trace a delta marker is positioned on.

Note that the corresponding trace must have a trace mode other than "Blank".

If necessary, the command activates the marker first.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<Trace> Trace number the marker is assigned to.

**Example:**

`CALC:DELT2:TRAC 2`  
Positions delta marker 2 on trace 2.

**CALCulate<n>:DELTamarker<m>:X <Position>**

This command moves a delta marker to a particular coordinate on the x-axis.

If necessary, the command activates the delta marker and positions a reference marker to the peak power.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Parameters:**

<Position> The position is relative to the reference marker.  
The unit is Hz (offset frequency).  
A query returns the absolute position of the delta marker.  
Range: The value range depends on the current measurement range.

**Example:**

`CALC:DELT:X?`  
Outputs the absolute frequency/time of delta marker 1.

**CALCulate<n>:DELTamarker<m>:Y?**

This command queries the relative position of a delta marker on the y-axis.

If necessary, the command activates the delta marker first.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single sweep mode.

See also [INITiate<n>:CONTinuous](#) on page 81.

**Suffix:**

<n> [Window](#)

<m> [Marker](#)

**Return values:**

<Level> Phase noise level.  
Default unit: dBc/Hz



**Example:**           INIT:CONT OFF  
                           Switches to single sweep mode.  
                           INIT;\*WAI  
                           Starts a sweep and waits for its end.  
                           CALC:DELT2 ON  
                           Switches on delta marker 2.  
                           CALC:DELT2:Y?  
                           Outputs measurement value of delta marker 2.

**Usage:**             Query only

### 8.12.3 Configuring Markers

DISPlay:MINFo[:STAT].....	145
DISPlay:MTABLE.....	145

---

#### DISPlay:MINFo[:STAT] <DisplayMode>

This command turns the marker information in all diagrams on and off.

**Parameters:**

<DisplayMode>       **ON**  
                           Displays the marker information in the diagrams.

**OFF**  
                           Hides the marker information in the diagrams.

                          \*RST:     ON

**Example:**           DISP:MINF OFF  
                           Hides the marker information.

**Manual operation:** See "[Marker Info](#)" on page 67

---

#### DISPlay:MTABLE <DisplayMode>

This command turns the marker table on and off.

**Parameters:**

<DisplayMode>       **ON**  
                           Turns the marker table on.

**OFF**  
                           Turns the marker table off.

**AUTO**  
                           Turns the marker table on if 3 or more markers are active.

                          \*RST:     AUTO

**Example:**           DISP:MTAB ON  
                           Activates the marker table.

**Manual operation:** See "[Marker Table Display](#)" on page 67

### 8.12.4 Using the Marker Zoom

CALCulate:MARKer:FUNcTion:ZOOM.....	146
DISPlay[:WINDow:]ZOOM[:STATe].....	146

---

#### CALCulate:MARKer:FUNcTion:ZOOM <ZoomFactor>

This command defines the factor or magnitude of the marker zoom.

**Parameters:**

<ZoomFactor>           Range:     1 to 20  
                          \*RST:     Zoom OFF

**Example:**            CALC:MARK:FUNC:ZOOM 12  
                          Zooms into the diagram with a factor of 10 around marker 1.

**Manual operation:** See "Marker Zoom" on page 66

---

#### DISPlay[:WINDow:]ZOOM[:STATe] <State>

This command turns the marker zoom for marker 1 on and off.

**Parameters:**

<State>                ON | OFF  
                          \*RST:     OFF

**Example:**            DISP:ZOOM ON  
                          Turns on the marker zoom.

**Manual operation:** See "Marker Zoom" on page 66

---

## 8.13 Configuring In- and Outputs

The following commands are necessary to configure the frontend settings.

INPut:CONNector.....	146
----------------------	-----

---

#### INPut:CONNector <ConnType>

Determines whether the RF input data is taken from the RF input connector or the optional Analog Baseband I connector. This command is only available if the Analog Baseband interface (R&S FSW-B71) is installed and active for input. It is not available for the R&S FSW67 or R&S FSW85.

**Parameters:**

<ConnType>            **RF**  
                          RF input connector  
                          **AIQI**  
                          Analog Baseband I connector  
                          \*RST:     RF

<b>Example:</b>	INP:CONN:AIQI Selects input from the analog baseband I connector.
<b>Usage:</b>	SCPI confirmed
<b>Manual operation:</b>	See <a href="#">"Input Connector"</a> on page 48

## 8.14 Automatic Measurement Configuration

The following commands are necessary to determine measurement parameters automatically.

<a href="#">[SENSe:]ADJust:ALL</a> .....	147
<a href="#">[SENSe:]ADJust:FREQuency</a> .....	147
<a href="#">[SENSe:]ADJust:LEVel</a> .....	147

---

### [SENSe:]ADJust:ALL

This command initiates a measurement to determine and set the ideal settings for the current task automatically (only once for the current measurement).

This includes:

- Center frequency
- Reference level

<b>Example:</b>	ADJ:ALL
<b>Usage:</b>	Event
<b>Manual operation:</b>	See <a href="#">"Adjusting all Determinable Settings Automatically (Auto All)"</a> on page 49

---

### [SENSe:]ADJust:FREQuency

This command sets the center frequency to the frequency with the highest signal level in the current frequency range.

<b>Example:</b>	ADJ:FREQ
<b>Usage:</b>	Event
<b>Manual operation:</b>	See <a href="#">"Adjusting the Center Frequency Automatically (Auto Freq)"</a> on page 49

---

### [SENSe:]ADJust:LEVel

This command initiates a single (internal) measurement that evaluates and sets the ideal reference level for the current input data and measurement settings. This ensures that the settings of the RF attenuation and the reference level are optimally adjusted to the signal level without overloading the R&S FSW or limiting the dynamic range by an S/N ratio that is too small.

<b>Example:</b>	ADJ:LEV
<b>Usage:</b>	Event
<b>Manual operation:</b>	See " <a href="#">Setting the Reference Level Automatically (Auto Level)</a> " on page 50

## 8.15 Using the Status Register

The status reporting system stores information about the current state of the R&S FSW. This includes, for example, information about errors during operation or information about limit checks. The R&S FSW stores this information in the status registers and in the error queue. You can query the status register and error queue via IEC bus.

The R&S FSW-K40 features several status registers that are specific to phase noise measurements. Here is a description of those, including the corresponding remote commands.

- [Status Registers for Phase Noise Measurements](#)..... 148

### 8.15.1 Status Registers for Phase Noise Measurements

The figure below shows the status registers of the phase noise application.




Figure 8-2: Status registers for phase noise measurements

The R&S FSW structures the information hierarchically, with the Status Byte register (STB) and the Service Request Enable mask register (SRE) being on the highest level. The STB gets its information from the standard Event Status Register (ESR) and the Event Status Enable mask register (ESE). The STB and ESR are both defined by IEEE 488.2. In addition to the ESR, the STB also gets information from the STATus:OPERation and STATus:QUESTIONable registers. These are the link to the lower levels of the status register and are defined by SCPI. They contain information about the state of the instrument.

For a more comprehensive description of the status registers not mentioned here and status register functionality in general see the manual of the base unit.

- [STATus:QUEStionable Register](#)..... 150
- [STATus:QUEStionable:POWer Register](#)..... 150
- [STATus:QUEStionable:LIMit Register](#)..... 151
- [STATus:QUEStionable:PNOise Register](#)..... 151
- [Status Register Remote Commands](#)..... 152

### 8.15.1.1 STATus:QUEStionable Register

The `STATus:QUEStionable` register contains information about indefinite states which may occur if the unit is operated without meeting the specifications.

Bit no	Meaning
0 to 2	Unavailable for phase noise measurements.
3	POWer This bit is set if a questionable power occurs.
5 to 7	Unavailable for phase noise measurements.
8	CALibration This bit is set if the R&S FSW is not calibrated.
9	LIMit This bit is set if a limit line is violated.
10-12	Unavailable for phase noise measurements.
13	PNOise This bit is set if the phase noise measurement is questionable.
14	Unavailable for phase noise measurements.
15	This bit is always 0.

### 8.15.1.2 STATus:QUEStionable:POWer Register

The `STATus:QUEStionable:POWer` register contains information about possible overload situations that may occur during operation of the R&S FSW.

Bit no	Meaning
0	OVERload This bit is set if an overload occurs at the RF input.
1	UNDerload This bit is set if an underload occurs at the RF input.
2	IF OVERload This bit is set if an overload occurs in the IF path.
3 to 14	Unavailable for phase noise measurements.
15	This bit is always 0.

### 8.15.1.3 STATus:QUEStionable:LIMit Register

The `STATus:QUEStionable:LIMit` register contains information about limit lines and the results of a limit checks.

The number of LIMit registers depends on the number of measurement windows available in any application.

Bit no	Meaning
0	LIMit 1 FAIL This bit is set if limit line 1 is violated.
1	LIMit 2 FAIL This bit is set if limit line 2 is violated.
2	LIMit 3 FAIL This bit is set if limit line 3 is violated.
3	LIMit 4 FAIL This bit is set if limit line 4 is violated.
4	LIMit 5 FAIL This bit is set if limit line 5 is violated.
5	LIMit 6 FAIL This bit is set if limit line 6 is violated.
6	LIMit 7 FAIL This bit is set if limit line 7 is violated.
7	LIMit 8 FAIL This bit is set if limit line 8 is violated.
8	Phase Noise LIMit FAIL This bit is set if a limit of the phase noise limit line is violated.
9 to 14	Unavailable for phase noise measurements.
15	This bit is always 0.

### 8.15.1.4 STATus:QUEStionable:PNOise Register

The `STATus:QUEStionable:PNOise` register contains information about the status of phase noise measurements.

Bit no	Meaning
0	No trace are active This bit is set if no trace is on.
1	SIGNal not found This bit is set if no valid signal could be found.
2	VERify This bit is set if signal verification has failed.

Bit no	Meaning
3 to 14	Unavailable for phase noise measurements.
15	This bit is always 0.

### 8.15.1.5 Status Register Remote Commands

STATus:OPERation[:EVENT]?.....	152
STATus:QUESTionable[:EVENT]?.....	152
STATus:QUESTionable:LIMit[:EVENT]?.....	152
STATus:QUESTionable:PNOise[:EVENT]?.....	152
STATus:QUESTionable:POWer[:EVENT]?.....	152
STATus:OPERation:CONDition?.....	153
STATus:QUESTionable:CONDition?.....	153
STATus:QUESTionable:LIMit:CONDition?.....	153
STATus:QUESTionable:PNOise:CONDition?.....	153
STATus:QUESTionable:POWer:CONDition?.....	153
STATus:OPERation:ENABle.....	153
STATus:QUESTionable:ENABle.....	153
STATus:QUESTionable:LIMit:ENABle.....	153
STATus:QUESTionable:PNOise:ENABle.....	153
STATus:QUESTionable:POWer:ENABle.....	153
STATus:OPERation:NTRansition.....	153
STATus:QUESTionable:NTRansition.....	153
STATus:QUESTionable:LIMit:NTRansition.....	153
STATus:QUESTionable:PNOise:NTRansition.....	153
STATus:QUESTionable:POWer:NTRansition.....	153
STATus:OPERation:PTRansition.....	154
STATus:QUESTionable:PTRansition.....	154
STATus:QUESTionable:LIMit:PTRansition.....	154
STATus:QUESTionable:PNOise:PTRansition.....	154
STATus:QUESTionable:POWer:PTRansition.....	154

---

**STATus:OPERation[:EVENT]?**

**STATus:QUESTionable[:EVENT]?**

**STATus:QUESTionable:LIMit[:EVENT]? <ChannelName>**

**STATus:QUESTionable:PNOise[:EVENT]? <ChannelName>**

**STATus:QUESTionable:POWer[:EVENT]? <ChannelName>**

These commands read out the EVENT section of the status register.

The commands at the same time delete the contents of the EVENT section.

**Query parameters:**

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

**Usage:** Query only



---

**STATus:OPERation:CONDition?**  
**STATus:QUESTionable:CONDition?**  
**STATus:QUESTionable:LIMit:CONDition?** <ChannelName>  
**STATus:QUESTionable:PNOise:CONDition?** <ChannelName>  
**STATus:QUESTionable:POWer:CONDition?** <ChannelName>

These commands read out the CONDition section of the status register.

The commands do not delete the contents of the EVENT section.

**Query parameters:**

<ChannelName> String containing the name of the channel.  
 The parameter is optional. If you omit it, the command works for the currently active channel.

**Usage:** Query only

---

**STATus:OPERation:ENABLE** <SumBit>,<ChannelName>  
**STATus:QUESTionable:ENABLE** <SumBit>,<ChannelName>  
**STATus:QUESTionable:LIMit:ENABLE** <SumBit>,<ChannelName>  
**STATus:QUESTionable:PNOise:ENABLE** <SumBit>,<ChannelName>  
**STATus:QUESTionable:POWer:ENABLE** <SumBit>,<ChannelName>

These commands control the ENABLE part of a register.

The ENABLE part allows true conditions in the EVENT part of the status register to be reported in the summary bit. If a bit is 1 in the enable register and its associated event bit transitions to true, a positive transition will occur in the summary bit reported to the next higher level.

**Parameters:**

<SumBit> Range: 0 to 65535  
 <ChannelName> String containing the name of the channel.  
 The parameter is optional. If you omit it, the command works for the currently active channel.

---

**STATus:OPERation:NTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:NTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:LIMit:NTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:PNOise:NTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:POWer:NTRansition** <SumBit>,<ChannelName>

These commands control the Negative TRansition part of a register.

Setting a bit causes a 1 to 0 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

**Parameters:**

<SumBit> Range: 0 to 65535

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

---

**STATus:OPERation:PTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:PTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:LIMit:PTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:PNOise:PTRansition** <SumBit>,<ChannelName>  
**STATus:QUESTionable:POWer:PTRansition** <SumBit>,<ChannelName>

These commands control the Positive TRansition part of a register.

Setting a bit causes a 0 to 1 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

**Parameters:**

<SumBit> Range: 0 to 65535  
 <ChannelName> String containing the name of the channel.  
 The parameter is optional. If you omit it, the command works for the currently active channel.

## 8.16 Remote Control Example Scripts

This chapter contains a few remote control example scripts for particular phase noise measurement and configuration tasks.

The first chapter contains a short sequence of commands to perform a complete phase noise measurement. The subsequent chapters contain sequences of remote commands to perform special tasks for phase noise measurements like customizing the half decade configuration table.

All examples are based on a measurement range from 100 Hz to 1 MHz.

### 8.16.1 Performing a Basic Phase Noise Measurement

```
//Enter Phase Noise application
INST:SEL PNO
//Perform a preset of the channel
SYST:PRES:CHAN
//Customizing the screen layout.
//Add residual noise window:
LAY:ADD? '1',BEL,RNO
//Add spot noise window:
LAY:ADD? '2',RIGH,SNO
//Configure single sweep measurement.
INIT:CONT OFF
//Define the measurement range.
```

```

FREQ:STAR 100HZ
FREQ:STOP 1MHZ
//Select the sweep type.
SWE:MODE AVER
//Turn on frequency tracking.
FREQ:TRAC ON
//Turn on level tracking.
POW:TRAC ON
//Start the measurement with synchronization.
INIT;*WAI
//Set a marker on trace 1 and query its position.
CALC:MARK ON
CALC:MARK:X 1MHZ
CALC:MARK:Y?
//Query the residual noise results of trace 2 over the measurement range.
CALC:EVAL ON
//Residual FM:
FETC:PNO2:RFM?
//Residual PM:
FETC:PNO2:RPM?
//Residual RMS jitter:
FETC:PNO2:RMS?
//Freeze trace 1 and trace 2.
DISP:TRAC:MODE VIEW
DISP:TRAC2:MODE VIEW
//Activate trace 3 and trace 4.
DISP:TRAC3:MODE WRIT
DISP:TRAC4:MODE WRIT
//Activate linear trace smoothing for trace 4.
DISP:TRAC4:SMO ON
DISP:TRAC4:SMO:TYPE LIN
DISP:TRAC:SMO:APER 1
//Select IQ sweep mode.
SWE:MODE MAN
LIST:BWID:RES:TYPE IQFF
//Repeat the measurement.
INIT;*WAI

```

## 8.16.2 Configuring the Measurement Range

### Performing a customized IQ FFT measurement over the whole measurement range

```

//Define the measurement range.
FREQ:STAR 100HZ
FREQ:STOP 1MHZ
//Define the measurement settings for all half decades in the measurement range.
SWE:MODE MAN

```

```
//Measurement bandwidth (in per cent of the decade frequency):
LIST:BWID:RAT 20
//Averages:
LIST:SWE:COUN 20
//Mode:
LIST:BWID:RES:TYPE IQFF
//Window function:
LIST:IQW:TYPE GAUS
```

### Customizing a half decade configuration table

```
//Define the measurement range.
FREQ:STAR 100HZ
FREQ:STOP 1MHZ
//Define the contents of the table manually.
SWE:MODE MAN
//Customize the range from 100 Hz to 300 Hz.
//Measurement bandwidth:
LIST:RANG5:BWID 1HZ
//Sweep type:
LIST:RANG5:FILT:TYPE IQFF
//Window function:
LIST:RANG5:IQW:TYPE CHEB
//Averages:
LIST:RANG5:SWE:COUN 5
//Customize the range from 300 Hz to 1 kHz.
//Averages:
LIST:RANG6:SWE:COUN 5
```

## 8.16.3 Scaling the Display

### Scaling the x-axis: displaying a half decade

```
//Select display of one half decade.
DISP:TRAC:X:SCOP HDEC
//Select the start frequency of the half decade.
DISP:TRAC:X:HDEC 1KHZ
//Display the full measurement range again.
DISP:TRAC:X:SCOP MRAN
```

### Scaling the x-axis: customizing the x-axis range

```
//Select manual x-axis scaling.
DISP:TRAC:X:SCOP MAN
//Define the start frequency of the display range.
DISP:TRAC:X:STAR 30KHZ
//Define the stop frequency of the display range.
DISP:TRAC:X:STOP 300KHZ
```

**Scaling the y-axis: scaling based on bottom value and range**

```
//Select manual y-axis scaling.
DISP:TRAC:Y:MAN BRAN
//Define the bottom value.
DISP:TRAC:Y:RLEV:LOW -160
//Define the range.
DISP:TRAC:Y 60
```

**Scaling the y-axis: scaling based on top value and range**

```
//Select manual y-axis scaling.
DISP:TRAC:Y:MAN TRAN
//Define the top value.
DISP:TRAC:Y:RLEV -100
//Define the range.
DISP:TRAC:Y 60
```

**Scaling the y-axis: scaling based on bottom and top value**

```
//Select manual y-axis scaling.
DISP:TRAC:Y:MAN TBOT
//Define the bottom value.
DISP:TRAC:Y:RLEV:LOW -160
//Define the top value.
DISP:TRAC:Y:RLEV -100
```

**8.16.4 Configuring Numerical Results****Defining a user range for residual noise results and query the results**

```
//Select the trace for integration.
CALC:EVAL:USER2:TRAC TRACE1
//Define the start and stop frequencies of the integration range.
CALC:EVAL:USER2:STAR 100KHZ
CALC:EVAL:USER2:STOP 1MHZ
//Query the results.
//Residual FM:
FETC:PNO:USER2:RFM?
//Residual PM:
FETC:PNO:USER2:RPM?
//Residual RMS jitter:
FETC:PNO:USER2:RMS?
```

**Working with spot noise results**

```
//Turn on spot noise markers on every decade edge.
CALC:SNO:DEC ON
//Turn on spot noise markers at two additional offset frequencies.
CALC:SNO1:STAT ON
```

```

CALC:SNO1:X 50KHZ
CALC:SNO2:STAT ON
CALC:SNO2:X 500KHZ
//Read out spot noise marker results.
//Read out the decade edges:
CALC:SNO:DEC:X?
//Read out the marker positions on the decade edges:
CALC:SNO:DEC:Y?
//Read out customized spot noise marker results:
//At 50 kHz:
CALC:SNO1:Y?
//At 500 kHz:
CALC:SNO2:Y?

```

### 8.16.5 Using Limit Lines

#### Programming a phase noise limit line with three segments

```

//Define the level of the DUT's noise floor.
CALC:PNL:NOIS -134
//Select the number of line segments.
CALC:PNL:TYPE FC3
//Define the characteristics of the line segments.
CALC:PNL:FC1 300KHZ
CALC:PNL:SLOP1 10
CALC:PNL:FC2 30KHZ
CALC:PNL:SLOP2 20
CALC:PNL:FC3 3KHZ
CALC:PNL:SLOP3 30
//Assign the limit line to trace 1 and 2.
CALC:PNL:TRAC 1,2
//Query limit check results.
CALC:PNL:FAIL?

```

#### Programming a standard limit line

```

//Select or create the limit line by name.
CALC:LIM:NAME 'Phase Noise'
//Comment on the limit line.
CALC:LIM:COMM 'Limit line to test phase noise measurement'
//Define the horizontal data points of the limit line.
CALC:LIM:CONT 100HZ,1kHZ
//Define the vertical data points of an (upper) limit line.
//The unit is fix for phase noise measurements.
CALC:LIM:UPP -160,-170
//Shift the limit line 5 dBc/Hz down.
CALC:LIM:UPP:SHIF -5
//Turn the limit line on.
CALC:LIM:UPP:STAT ON

```

```
//Select the trace to check.  
CALC:LIM:TRAC 3  
//Turn on the limit check.  
CALC:LIM:STAT ON  
//Query the limit check results.  
CALC:LIM:FAIL?
```

## 8.16.6 Using Markers

### Using spot noise markers

See ["Working with spot noise results"](#) on page 157.

### Using normal and delta markers

```
//Activate and position a normal marker (marker 1).  
CALC:MARK ON  
CALC:MARK:X 1MHZ  
//Position marker 1 on trace 2.  
CALC:MARK:TRAC 2  
//Query the position of marker 1.  
CALC:MARK:Y?  
//Activate and position a delta marker (delta marker 1).  
CALC:DELT ON  
CALC:DELT:X -900KHZ  
//Position the delta marker on trace 2.  
CALC:DELT:TRAC 2  
//Query the position of the delta marker.  
CALC:DELT:Y?  
//Turning all markers off  
CALC:MARK:AOFF  
CALC:DELT:AOFF
```

## List of Remote Commands (Phase Noise)

[SENSe:]ADJust:ALL.....	147
[SENSe:]ADJust:FREQuency.....	147
[SENSe:]ADJust:LEVel.....	147
[SENSe:]BANDwidth BWIDth[:RESolution]:TYPE.....	101
[SENSe:]FREQuency:CENTer.....	92
[SENSe:]FREQuency:STARt.....	101
[SENSe:]FREQuency:STOP.....	101
[SENSe:]FREQuency:TRACk.....	95
[SENSe:]FREQuency:VERify:TOLerance:ABSolute.....	96
[SENSe:]FREQuency:VERify:TOLerance:RELative.....	96
[SENSe:]FREQuency:VERify[:STATE].....	96
[SENSe:]IQ:DECimation.....	97
[SENSe:]IQ:DPLL.....	97
[SENSe:]IQ:ONLine.....	97
[SENSe:]IQ:TBW.....	98
[SENSe:]LIST:BWIDth:RESolution:TYPE.....	102
[SENSe:]LIST:BWIDth[:RESolution]:RATio.....	100
[SENSe:]LIST:RANGe<range>:BWIDth[:RESolution].....	103
[SENSe:]LIST:RANGe<range>:FILTer:TYPE.....	103
[SENSe:]LIST:RANGe<range>:IQWindow:TYPE.....	103
[SENSe:]LIST:RANGe<range>:SWEep:COUNT.....	104
[SENSe:]LIST:SWEep:COUNT.....	104
[SENSe:]LIST:SWEep:COUNT:MULTIplier.....	105
[SENSe:]LIST:SWEep:COUNT:MULTIplier:STATe.....	105
[SENSe:]POWer:RLEVel.....	93
[SENSe:]POWer:RLEVel:VERify:TOLerance.....	98
[SENSe:]POWer:RLEVel:VERify[:STATE].....	98
[SENSe:]POWer:TRACk.....	98
[SENSe:]REJect:AM.....	99
[SENSe:]SPURs:SUPPression.....	125
[SENSe:]SPURs:THReshold.....	126
[SENSe:]SWEep:COUNT.....	84
[SENSe:]SWEep:FHDecade.....	84
[SENSe:]SWEep:FORWard.....	105
[SENSe:]SWEep:MODE.....	106
[SENSe:]SWEep:SVFailed.....	99
[SENSe:]LIST:IQWindow:TYPE.....	102
ABORT.....	80
CALCulate:MARKer:FUNCTion:ZOOM.....	146
CALCulate:PNLimit:COpy<k>.....	106
CALCulate:PNLimit:FAIL?.....	108
CALCulate:PNLimit:FC1 <Frequency>.....	107
CALCulate:PNLimit:FC2 <Frequency>.....	107
CALCulate:PNLimit:FC3 <Frequency>.....	107
CALCulate:PNLimit:FC4 <Frequency>.....	107
CALCulate:PNLimit:FC5.....	107
CALCulate:PNLimit:NOISe.....	107



CALCulate:PNLimit:SLOPe<segment>.....	109
CALCulate:PNLimit:TRACe.....	108
CALCulate:PNLimit:TYPE.....	108
CALCulate<n>:DELTAmarker<m>:AOFF.....	142
CALCulate<n>:DELTAmarker<m>:MREF.....	143
CALCulate<n>:DELTAmarker<m>:TRACe.....	143
CALCulate<n>:DELTAmarker<m>:X.....	144
CALCulate<n>:DELTAmarker<m>:Y?.....	144
CALCulate<n>:DELTAmarker<m>[:STATe].....	143
CALCulate<n>:EVALuation:START.....	127
CALCulate<n>:EVALuation:STOP.....	128
CALCulate<n>:EVALuation:USER<range>:START.....	129
CALCulate<n>:EVALuation:USER<range>:STOP.....	129
CALCulate<n>:EVALuation:USER<range>:TRACe.....	129
CALCulate<n>:EVALuation[:STATe].....	128
CALCulate<n>:LIMit<k>:ACTive?.....	109
CALCulate<n>:LIMit<k>:CLear[:IMMediate].....	110
CALCulate<n>:LIMit<k>:COMMeNt.....	114
CALCulate<n>:LIMit<k>:CONTRol:SHIFt.....	114
CALCulate<n>:LIMit<k>:CONTRol[:DATA].....	114
CALCulate<n>:LIMit<k>:COpy.....	110
CALCulate<n>:LIMit<k>:DELeTe.....	110
CALCulate<n>:LIMit<k>:FAIL?.....	111
CALCulate<n>:LIMit<k>:LOWer:MODE.....	115
CALCulate<n>:LIMit<k>:LOWer:SHIFt.....	116
CALCulate<n>:LIMit<k>:LOWer:STATe.....	112
CALCulate<n>:LIMit<k>:LOWer[:DATA].....	115
CALCulate<n>:LIMit<k>:NAME.....	111
CALCulate<n>:LIMit<k>:STATe.....	112
CALCulate<n>:LIMit<k>:TRACe.....	112
CALCulate<n>:LIMit<k>:TRACe<t>:CHECK.....	113
CALCulate<n>:LIMit<k>:UPPer:MODE.....	116
CALCulate<n>:LIMit<k>:UPPer:SHIFt.....	117
CALCulate<n>:LIMit<k>:UPPer:STATe.....	113
CALCulate<n>:LIMit<k>:UPPer[:DATA].....	116
CALCulate<n>:MARKer<m>:AOFF.....	140
CALCulate<n>:MARKer<m>:TRACe.....	141
CALCulate<n>:MARKer<m>:X.....	141
CALCulate<n>:MARKer<m>:Y?.....	142
CALCulate<n>:MARKer<m>[:STATe].....	140
CALCulate<n>:MATH:STATe.....	118
CALCulate<n>:MATH[:EXPRession][:DEFine].....	118
CALCulate<n>:SNOise:AOFF.....	132
CALCulate<n>:SNOise:DECades:X?.....	133
CALCulate<n>:SNOise:DECades:Y?.....	133
CALCulate<n>:SNOise:DECades[:STATe].....	133
CALCulate<n>:SNOise<m>:STATe.....	134
CALCulate<n>:SNOise<m>:X.....	134
CALCulate<n>:SNOise<m>:Y?.....	135
CONFIgure:REFMeas ONCE.....	81

DISPlay:FORMat.....	85
DISPlay:MINFo[:STAT].....	145
DISPlay:MTABLE.....	145
DISPlay[:WINDow:]ZOOM[:STATe].....	146
DISPlay[:WINDow]:TRACe:X[:SCALE]:HDECade.....	120
DISPlay[:WINDow]:TRACe:X[:SCALE]:SCOPE.....	121
DISPlay[:WINDow]:TRACe:X[:SCALE]:START.....	121
DISPlay[:WINDow]:TRACe:X[:SCALE]:STOP.....	121
DISPlay[:WINDow]:TRACe:Y[:SCALE].....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:AUTO.....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:MANual.....	122
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel.....	123
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel:LOWer.....	123
DISPlay[:WINDow]:TRACe:Y[:SCALE]:RLEVel:OFFSet.....	124
DISPlay[:WINDow]:TRACe<t>:MODE.....	118
DISPlay[:WINDow]:TRACe<t>:SMOothing:APERture.....	119
DISPlay[:WINDow]:TRACe<t>:SMOothing:TYPE.....	119
DISPlay[:WINDow]:TRACe<t>:SMOothing[:STATe].....	119
DISPlay[:WINDow]:TRACe<t>:SPURs:SUPPress.....	120
DISPlay[:WINDow<n>]:SIZE.....	86
DISPlay[:WINDow<n>]:TRACe<t>:SELEct.....	135
FETCh:PNOise:IPN?.....	130
FETCh:PNOise:MEASured:FREQuency?.....	137
FETCh:PNOise:MEASured:LEVel?.....	137
FETCh:PNOise:SPURs:DISCReTe?.....	136
FETCh:PNOise:SPURs:RANDom?.....	136
FETCh:PNOise:SPURs?.....	136
FETCh:PNOise:SWEEp:AVG?.....	137
FETCh:PNOise:SWEEp:FDRift?.....	138
FETCh:PNOise:SWEEp:LDRift?.....	138
FETCh:PNOise:SWEEp:MDRift?.....	138
FETCh:PNOise:SWEEp:SRATe?.....	139
FETCh:PNOise:SWEEp:START?.....	139
FETCh:PNOise:SWEEp:STOP?.....	139
FETCh:PNOise<t>:RFM?.....	130
FETCh:PNOise<t>:RMS?.....	130
FETCh:PNOise<t>:RPM?.....	131
FETCh:PNOise<t>:USER<range>:IPN?.....	131
FETCh:PNOise<t>:USER<range>:RFM?.....	131
FETCh:PNOise<t>:USER<range>:RMS?.....	131
FETCh:PNOise<t>:USER<range>:RPM?.....	132
FORMat:DEXPort:DSEParator.....	124
FORMat:DEXPort:HEADer.....	124
FORMat:DEXPort:TRACes.....	124
INITiate<n>:CONMeas.....	81
INITiate<n>:CONTInuous.....	81
INITiate<n>:SEQuencer:ABORt.....	82
INITiate<n>:SEQuencer:IMMediate.....	82
INITiate<n>:SEQuencer:MODE.....	83
INITiate<n>[:IMMediate].....	82

INPut:ATTenuation.....	93
INPut:ATTenuation:AUTO.....	94
INPut:CONNector.....	146
INPut:COUPling.....	94
INPut:GAIN:STATe.....	94
INPut:GAIN[:VALue].....	95
INSTrument:CREate:DUPLicate.....	76
INSTrument:CREate:REPLace.....	77
INSTrument:CREate[:NEW].....	76
INSTrument:DELeTe.....	77
INSTrument:LIST?.....	77
INSTrument:REName.....	79
INSTrument[:SElect].....	79
LAYout:ADD[:WINDow]?.....	87
LAYout:CATalog[:WINDow]?.....	88
LAYout:IDENTify[:WINDow]?.....	88
LAYout:REMove[:WINDow].....	88
LAYout:REPLace[:WINDow].....	89
LAYout:SPLitter.....	89
LAYout:WINDow<n>:ADD?.....	91
LAYout:WINDow<n>:IDENTify?.....	91
LAYout:WINDow<n>:REMove.....	92
LAYout:WINDow<n>:REPLace.....	92
MMEMory:STORe<n>:TRACe.....	125
STATus:OPERation:CONDition?.....	153
STATus:OPERation:ENABLE.....	153
STATus:OPERation:NTRansition.....	153
STATus:OPERation:PTRansition.....	154
STATus:OPERation[:EVENT]?.....	152
STATus:QUESTionable:CONDition?.....	153
STATus:QUESTionable:ENABLE.....	153
STATus:QUESTionable:LIMit:CONDition?.....	153
STATus:QUESTionable:LIMit:ENABLE.....	153
STATus:QUESTionable:LIMit:NTRansition.....	153
STATus:QUESTionable:LIMit:PTRansition.....	154
STATus:QUESTionable:LIMit[:EVENT]?.....	152
STATus:QUESTionable:NTRansition.....	153
STATus:QUESTionable:PNOise:CONDition?.....	153
STATus:QUESTionable:PNOise:ENABLE.....	153
STATus:QUESTionable:PNOise:NTRansition.....	153
STATus:QUESTionable:PNOise:PTRansition.....	154
STATus:QUESTionable:PNOise[:EVENT]?.....	152
STATus:QUESTionable:POWER:CONDition?.....	153
STATus:QUESTionable:POWER:ENABLE.....	153
STATus:QUESTionable:POWER:NTRansition.....	153
STATus:QUESTionable:POWER:PTRansition.....	154
STATus:QUESTionable:POWER[:EVENT]?.....	152
STATus:QUESTionable:PTRansition.....	154
STATus:QUESTionable[:EVENT]?.....	152
SYSTem:PRESet:CHANnel[:EXECute].....	79

SYSTem:SEQuencer.....	85
TRACe[:DATA]?.....	126
TRACe<n>:COPY.....	126

# Index

## A

Abort measurement (remote control) .....	80
Aborting	
Sweep .....	47
Application cards .....	7
Application notes .....	7
Attenuation	
Mechanical .....	39
Mechanical (remote control) .....	92
Auto all .....	49
Auto frequency .....	49
Auto level	
Reference level .....	50
Softkey .....	50
Automatic	
Frequency detection (remote control) .....	147
Level detection (remote control) .....	147
Parameter detection (remote control) .....	147
Automatic scaling .....	53
Automatic scaling (remote control) .....	117
Average count .....	47
Averaging .....	45, 46
Averaging (remote control) .....	99

## B

Brochures .....	7
-----------------	---

## C

Center frequency	
Automatic configuration .....	49
Closing	
Channels (remote) .....	77
Windows (remote) .....	88, 92
Continue single sweep	
Softkey .....	47
Continuous sweep	
Softkey .....	47
Conventions	
SCPI commands .....	71
Copy trace (remote control) .....	117
Copying	
Measurement channel (remote) .....	76
Traces .....	55
Coupling .....	39, 48
Input (remote) .....	94
Coupling (remote control) .....	92

## D

Data format	
Remote .....	124
Data sheet .....	7
Delta markers .....	66
Defining .....	66
Delta markers (remote control) .....	140
Duplicating	
Measurement channel (remote) .....	76

## E

Evaluation methods	
Remote .....	87

## F

FFT window .....	45
FFT window (remote control) .....	99
Format	
Data (remote) .....	124
Frequency	
Nominal .....	39
Nominal (remote control) .....	92
Frequency tolerance .....	40
Frequency tolerance (remote control) .....	95
Frequency tracking .....	41
Frequency tracking (remote control) .....	95
Frequency verification .....	40
Frequency verification (remote control) .....	95

## H

Half decades configuration table .....	46
Hardware settings	
Displayed .....	11

## I

Initiate measurement (remote control) .....	80
Input	
Connector (remote) .....	146
Coupling (remote) .....	94
Installation .....	9

## J

Jitter (remote control) .....	127
-------------------------------	-----

## K

Keys	
RUN CONT .....	47
RUN SINGLE .....	47

## L

Level	
nominal .....	39
Nominal (remote control) .....	92
Level tolerance .....	41
Level tolerance (remote control) .....	95
Level tracking .....	41
Level tracking (remote control) .....	95
Level verification .....	41
Level verification (remote control) .....	95
Limit lines	
Noise floor (remote control) .....	106
Phase noise (remote control) .....	106
Standard (remote control) .....	109
Limit lines (remote control) .....	106

**M**

Marker to Trace .....	66
Marker zoom (remote control) .....	146
Markers .....	35
Assigned trace .....	66
Deactivating .....	66
Delta markers .....	66
Table .....	67
Type .....	66
Markers (remote control) .....	142
Maximizing .....	
Windows (remote) .....	86
Measurement .....	
Reference .....	81
Measurement channel .....	
Creating (remote) .....	76, 77
Deleting (remote) .....	77
Duplicating (remote) .....	76
Querying (remote) .....	77
Renaming (remote) .....	79
Replacing (remote) .....	77
Measurement range .....	44
Measurement range (remote control) .....	99
Measurement time .....	46
Mechanical attenuation .....	39
Mechanical attenuation (remote control) .....	92
Multiple .....	
Measurement channels .....	9

**N**

Nominal frequency .....	39
Nominal frequency (remote control) .....	92
Nominal level .....	39
Nominal level (remote control) .....	92

**O**

Offset frequency .....	
Start .....	44
Start (remote control) .....	99
Stop .....	44
Stop (remote control) .....	99
Online help .....	6
Options .....	
Preamplifier .....	39
Overview .....	
Configuration .....	36

**P**

Preamplifier .....	
Setting .....	39
Softkey .....	39
Presetting .....	
Channels .....	37

**R**

Range Start/Stop .....	44
Range Start/Stop (remote control) .....	99
RBW .....	44, 46
RBW (remote control) .....	99
Reference level .....	
Auto level .....	50
Reference marker .....	66

Reference measurement .....	81
Release notes .....	7
Remote commands .....	
Basics on syntax .....	71
Boolean values .....	74
Capitalization .....	72
Character data .....	75
Data blocks .....	75
Numeric values .....	74
Optional keywords .....	73
Parameters .....	73
Strings .....	75
Suffixes .....	72
Residual FM (remote control) .....	127
Residual noise .....	
Integration range .....	57
Integration Range .....	57
Integration Range (remote control) .....	127
Residual noise (remote control) .....	127
Residual PM (remote control) .....	127
Resolution bandwidth .....	44, 46
Resolution bandwidth (remote control) .....	99
Restoring .....	
Channel settings .....	37
Results .....	
Data format (remote) .....	124
RF input .....	
Connector (remote) .....	146
RUN CONT .....	
Key .....	47
RUN SINGLE .....	
Key .....	47

**S**

Scaling .....	
X-axis .....	51
X-axis (remote control) .....	117
Y-axis .....	52
Y-axis (remote control) .....	117
Scope .....	
X-axis .....	51
X-axis (remote control) .....	117
Sequencer .....	9
Aborting (remote) .....	82
Activating (remote) .....	82
Mode (remote) .....	83
Remote .....	81
Single sweep .....	
Softkey .....	47
Smoothing .....	
Traces .....	26
Smoothing type .....	53
Smoothing type (remote control) .....	117
Softkeys .....	
Auto All .....	49
Auto Freq .....	49
Auto Level .....	50
Continue Single Sweep .....	47
Continuous Sweep .....	47
Marker to Trace .....	66
Norm/Delta .....	66
Preamp .....	39
Single Sweep .....	47
Sweep count .....	47

Spot noise		
10_x Hz	58	
10_x Hz (remote control)	127	
user defined	58	
user defined (remote control)	127	
Spur removal	56	
Spur removal (remote control)	117	
Spur threshold	56	
Spur threshold (remote control)	117	
Stop On Verify Failed	41	
Suffixes		
Common	70	
Remote commands	72	
Sweep		
Aborting	47	
Count	47	
Sweep count (remote control)	80	
Sweep direction	44	
Sweep direction (remote control)	99	
Sweep mode	45, 46	
Sweep mode (remote control)	99	
Sweep type	44	
Sweep type (remote control)	99	
<b>T</b>		
Tolerance		
frequency	40	
frequency (remote control)	95	
level	41	
level (remote control)	95	
Trace configuration	54	
Trace configuration (remote control)	117	
Trace copy (remote control)	117	
Trace export	55	
Trace export (remote control)	117	
Trace math	56	
Trace math (remote control)	117	
Trace offset	53	
Trace offset (remote control)	117	
Trace smoothing	26, 53	
Trace smoothing (remote control)	117	
Traces		
Copying	55	
Copying (remote control)	126	
Tracking		
frequency	41	
frequency (remote control)	95	
level	41	
level (remote control)	95	
<b>V</b>		
Verify frequency	40	
Verify frequency (remote control)	95	
Verify level	41	
Verify level (remote control)	95	
<b>W</b>		
White papers	7	
Window function	45	
Window function (remote control)	99	
Window title bar information	12	
Windows		
Adding (remote)	87	
Closing (remote)	88, 92	
Layout (remote)	89	
Maximizing (remote)	86	
Querying (remote)	88	
Replacing (remote)	89	
Splitting (remote)	86	
Types (remote)	87	
<b>X</b>		
X-axis		
Half decade	52	
Half decade (remote control)	117	
scope	51	
scope (remote control)	117	
Start	52	
Start (remote control)	117	
Stop	52	
Stop (remote control)	117	
<b>Y</b>		
Y-axis		
Scaling	52	
Scaling (remote control)	117	
Scaling automatic (remote control)	117	
Y-axis scaling		
Automatic	53	