

# R&S® VSE-K72

## 3GPP FDD Measurements

### Application

### User Manual



1176.8968.02 – 01

This manual applies to the R&S®VSE base software (1320.7500.02) version 1.13 and higher.  
The following firmware options are described:

- R&S VSE-K72 (1320.7580.02)

The software contained in this product makes use of several valuable open source software packages. For information, see the "Open Source Acknowledgment" on the user documentation CD-ROM (included in delivery).

Rohde & Schwarz would like to thank the open source community for their valuable contribution to embedded computing.

© 2015 Rohde & Schwarz GmbH & Co. KG

Mühlhofstr. 15, 81671 München, Germany

Phone: +49 89 41 29 - 0

Fax: +49 89 41 29 12 164

Email: [info@rohde-schwarz.com](mailto:info@rohde-schwarz.com)

Internet: [www.rohde-schwarz.com](http://www.rohde-schwarz.com)

Subject to change – Data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

The following abbreviations are used throughout this manual: R&S®VSE is abbreviated as R&S VSE. "R&S VSE-K72" is abbreviated as R&S VSE-K72.

# Contents

|          |   |            |
|----------|---|------------|
| <b>1</b> | <b>Preface</b> .....  | <b>5</b>   |
| 1.1      | About this Manual.....  | 5          |
| 1.2      | Typographical Conventions.....                                    | 6          |
| <b>2</b> | <b>Welcome to the 3GPP FDD Applications</b> .....                 | <b>7</b>   |
| 2.1      | Starting the 3GPP FDD Application.....                            | 7          |
| 2.2      | Understanding the Display Information.....                        | 8          |
| <b>3</b> | <b>Measurements and Result Display</b> .....                      | <b>11</b>  |
| 3.1      | Code Domain Analysis.....   | 11         |
| 3.2      | Time Alignment Error Measurements.....                            | 30         |
| <b>4</b> | <b>Measurement Basics</b> .....                                   | <b>32</b>  |
| 4.1      | Channel Detection.....  | 35         |
| 4.2      | BTS Channel Types.....  | 35         |
| 4.3      | UE Channel Types.....   | 39         |
| 4.4      | 3GPP FDD BTS Test Models.....                                     | 40         |
| 4.5      | Setup for Base Station Tests.....                                 | 41         |
| 4.6      | 3GPP FDD UE Test Models.....                                      | 42         |
| 4.7      | Setup for User Equipment Tests.....                               | 43         |
| 4.8      | Time Alignment Error Measurements.....                            | 44         |
| <b>5</b> | <b>Configuration</b> .....  | <b>46</b>  |
| 5.1      | Code Domain Analysis.....   | 46         |
| 5.2      | Time Alignment Error Measurements.....                            | 83         |
| <b>6</b> | <b>Analysis</b> .....   | <b>85</b>  |
| 6.1      | Evaluation Range.....   | 85         |
| 6.2      | Code Domain Analysis Settings (BTS Measurements).....             | 87         |
| 6.3      | Code Domain Analysis Settings (UE Measurements).....              | 89         |
| 6.4      | Traces.....   | 90         |
| 6.5      | Markers.....  | 91         |
| <b>7</b> | <b>How to Perform Measurements in 3GPP FDD Applications</b> ..... | <b>97</b>  |
| <b>8</b> | <b>Measurement Examples</b> .....                                 | <b>100</b> |

|       |   |     |
|-------|---|-----|
| 8.1   | Measurement 1: Measuring the Relative Code Domain Power.....                    | 100 |
| 8.2   | Measurement 2: Triggered Measurement of Relative Code Domain Power.....         | 104 |
| 8.3   | Measurement 3: Measuring the Composite EVM.....                                 | 106 |
| 8.4   | Measurement 4: Determining the Peak Code Domain Error.....                      | 108 |
| 9     | Optimizing and Troubleshooting the Measurement.....                             | 111 |
| 9.1   | Error Messages.....   | 111 |
| 10    | Remote Commands for 3GPP FDD Measurements.....                                  | 112 |
| 10.1  | Introduction.....   | 112 |
| 10.2  | Common Suffixes.....  | 117 |
| 10.3  | Activating 3GPP FDD Measurements.....   | 118 |
| 10.4  | Selecting a Measurement.....  | 118 |
| 10.5  | Restoring the Default Configuration (Preset).....                               | 119 |
| 10.6  | Configuring Code Domain Analysis and Time Alignment Error Measurements<br>..... | 119 |
| 10.7  | Configuring the Result Display.....   | 166 |
| 10.8  | Retrieving Results.....   | 177 |
| 10.9  | Analysis.....   | 195 |
| 10.10 | Querying the Status Registers.....  | 206 |
| 10.11 | Commands for Compatibility.....   | 209 |
| 10.12 | Programming Examples (R&S VSE-K72).....   | 212 |
| A     | Reference.....  | 218 |
| A.1   | Menu Reference.....   | 218 |
| A.2   | Reference of Toolbar Functions.....   | 222 |
|       | List of Remote Commands (3GPP FDD).....   | 227 |
|       | Index.....  | 231 |

# 1 Preface

## 1.1 About this Manual

This R&S VSE 3GPP FDD User Manual provides all the information **specific to the application**. All general software functions and settings common to all applications and operating modes are described in the R&S VSE Base Software User Manual.

The main focus in this manual is on the measurement results and the tasks required to obtain them. The following topics are included:

- **Welcome to the R&S VSE 3GPP FDD Measurements application**  
Introduction to and getting familiar with the application
- **Measurements and Result Displays**  
Details on supported measurements and their result types
- **Measurement Basics**  
Background information on basic terms and principles in the context of the measurement
- **Configuration + Analysis**  
A concise description of all functions and settings available to configure measurements and analyze results with their corresponding remote control command
- **How to Perform Measurements in the R&S VSE 3GPP FDD Measurements application**  
The basic procedure to perform each measurement and step-by-step instructions for more complex tasks or alternative methods
- **Measurement Examples**  
Detailed measurement examples to guide you through typical measurement scenarios and allow you to try out the application immediately
- **Optimizing and Troubleshooting the Measurement**  
Hints and tips on how to handle errors and optimize the measurement configuration
- **Remote Commands for 3GPP FDD Measurements**  
Remote commands required to configure and perform 3GPP FDD measurements in a remote environment, sorted by tasks  
(Commands required to set up the environment or to perform common tasks in the software are provided in the R&S VSE Base Software User Manual)  
Programming examples demonstrate the use of many commands and can usually be executed directly for test purposes
- **List of remote commands**  
Alphabetical list of all remote commands described in the manual
- **Index**

## 1.2 Typographical Conventions

The following text markers are used throughout this documentation:

| Convention                            | Description  |
|---------------------------------------|--|
| "Graphical user interface elements"   | All names of graphical user interface elements on the screen, such as dialog boxes, menus, options, buttons, and softkeys are enclosed by quotation marks. |
| KEYS                                  | Key names are written in capital letters.  |
| File names, commands,<br>program code | File names, commands, coding samples and screen output are distinguished by their font.  |
| <i>Input</i>                          | Input to be entered by the user is displayed in italics.   |
| <a href="#">Links</a>                 | Links that you can click are displayed in blue font.   |
| "References"                          | References to other parts of the documentation are enclosed by quotation marks.  |

## 2 Welcome to the 3GPP FDD Applications

The R&S VSE 3GPP FDD Measurements application applications add functionality to the R&S VSE to perform code domain analysis or power measurements according to the 3GPP standard (FDD mode). The application firmware is in line with the 3GPP standard (Third Generation Partnership Project) with Release 5. Signals that meet the conditions for channel configuration of test models 1 to 4 according to the 3GPP standard, e.g. W-CDMA signals using FDD, can be measured with the 3GPP FDD BTS application.

R&S VSE-K72 performs **Base Transceiver Station (BTS)** measurements (for downlink signals), as well as **User Equipment (UE)** measurements (for uplink signals).

In particular, the R&S VSE 3GPP FDD Measurements application features:

- Code domain analysis, providing results like code domain power, EVM, peak code domain error etc.
- Time alignment error determination


This user manual contains a description of the functionality that the application provides, including remote control operation.

Functions that are not discussed in this manual are the same as in the I/Q Analyzer application and are described in the R&S VSE Base Software User Manual. The latest version is available for download at the product homepage (<http://www2.rohde-schwarz.com/product/VSE.html>).

### 2.1 Starting the 3GPP FDD Application


The 3GPP FDD measurements require a special application on the R&S VSE. It is activated by creating a new measurement channel in 3GPP FDD mode.

#### To activate the 3GPP FDD application

1.  Channel

Select the "Add Channel" function in the Sequence tool window.

A dialog box opens that contains all operating modes and applications currently available in your R&S VSE.



2. Select the 3GPP FDD BTS or 3GPP FDD UE item.




The R&S VSE opens a new measurement channel for the 3GPP FDD application.

## 2.2 Understanding the Display Information

The following figure shows a measurement diagram during a 3GPP FDD BTS measurement. All different information areas are labeled. They are explained in more detail in the following sections.

(The basic screen elements are identical for 3GPP FDD UE measurements)





- 1 = Color coding for windows of same channel
- 2 = Channel bar with measurement settings
- 3 = Window title bar with diagram-specific (trace) information
- 4 = Diagram area
- 5 = Diagram footer with diagram-specific information, depending on result display

**Channel bar information**


In 3GPP FDD applications, when performing Code Domain Analysis, the R&S VSE screen display shows the following settings:

**Table 2-1: Hardware settings displayed in the channel bar in 3GPP FDD applications for Code Domain Analysis**

|                               |  |
|-------------------------------|--|
| <b>Ref Level</b>              | Reference level  |
| <b>Att</b>                    | Mechanical and electronic RF attenuation   |
| <b>Freq</b>                   | Center frequency for the RF signal   |
| <b>Channel</b>                | Channel number (code number and spreading factor)  |
| <b>CPICH Slot / Slot (UE)</b> | Slot of the (CPICH) channel  |
| <b>Power</b>                  | Power result mode: <ul style="list-style-type: none"> <li>• Absolute</li> <li>• Relative to CPICH (BTS application only)</li> <li>• Relative to total power</li> </ul> |
| <b>SymbRate</b>               | Symbol rate of the current channel   |
| <b>Capture</b>                | <b>(UE application only):</b> basis for analysis (slot or frame)   |

### Window title bar information

For each diagram, the header provides the following information:



**Fig. 2-1: Window title bar information in 3GPP applications**

- 0 = Color coding for windows of same channel
- 1 = Edit result display function
- 2 = Channel name
- 3 = Window number
- 4 = Window type
- 5 = Trace color, trace number, trace mode
- 6 = Dock/undock window function
- 7 = Close window function

### Diagram area

The diagram area displays the results according to the selected result displays (see [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14).

### Diagram footer information

For most graphical evaluations the diagram footer (beneath the diagram) contains scaling information for the x-axis, where applicable:

- Start channel/chip/frame/slot
- Channel/chip/frame/slot per division
- Stop channel/chip/frame/slot

For the **Bitstream** evaluation, the diagram footer indicates:

- Channel format (type and modulation type (HS-PDSCH only))
- Number of data bits
- Number of TPC bits
- Number of TFCI bits
- Number of pilot bits

(The bit numbers are indicated in the order they occur.)

### Status bar information


The software status, errors and warnings and any irregularities in the software are indicated in the status bar at the bottom of the R&S VSE window.

## 3 Measurements and Result Display

The 3GPP FDD applications provide several different measurements for signals according to the 3GPP FDD standard. The main and default measurement is Code Domain Analysis. Furthermore, a Time Alignment Error measurement is provided.

### Result display windows

For each measurement, a separate measurement channel is activated. Each measurement channel can provide multiple result displays, which are displayed in individual windows. The measurement windows can be rearranged and configured in the R&S VSE to meet your requirements. All windows that belong to the same measurement (including the channel bar) are indicated by a colored line at the top of the window title bar.

- ▶ To add further result displays for the 3GPP FDD channel, select the  "Add Window" icon from the toolbar, or select the "Window > New Window" menu item.

For details on working with channels and windows see the "Operating Basics" chapter in the R&S VSE Base Software User Manual.

### Evaluation range

You can restrict evaluation to a specific channel, frame or slot, depending on the evaluation method. See [chapter 6.1, "Evaluation Range"](#), on page 85.

- [Code Domain Analysis](#)..... 11
- [Time Alignment Error Measurements](#)..... 30

## 3.1 Code Domain Analysis

The Code Domain Analysis measurement provides various evaluation methods and result diagrams.

The code domain power measurements are performed as specified by the 3GPP standards. A signal section of approximately 20 ms is recorded for analysis and then searched through to find the start of a 3GPP FDD frame. If a frame start is found in the signal, the code domain power analysis is performed for a complete frame starting from slot 0. The different evaluations are calculated from the captured I/Q data set. Therefore it is not necessary to start a new measurement in order to change the evaluation.

The 3GPP FDD applications provide the peak code domain error measurement and composite EVM specified by the 3GPP standard, as well as the code domain power measurement of assigned and unassigned codes. The power can be displayed either for all channels in one slot, or for one channel in all slots. The composite constellation diagram of the entire signal can also be displayed. In addition, the symbols demodulated in a slot, their power, and the determined bits or the symbol EVM can be displayed for an active channel.

The power of a code channel is always measured in relation to its symbol rate within the code domain. It can be displayed either as absolute values or relative to the total signal or the CPICH channel. By default, the power relative to the CPICH channel is displayed. The total power may vary depending on the slot, since the power can be controlled on a per-slot-basis. The power in the CPICH channel, on the other hand, is constant in all slots.

For all measurements performed in a slot of a selected channel (bits, symbols, symbol power, EVM), the actual slot spacing of the channel is taken as a basis, rather than the CPICH slots. The time reference for the start of a slot is the CPICH slot. If code channels contain a timing offset, the start of a specific slot of the channel differs from the start of the reference channel (CPICH). Thus, the power-per-channel display may not be correct. If channels with a timing offset contain a power control circuit, the channel-power-versus-time display may provide better results.

The composite EVM, peak code domain error and composite constellation measurements are always referenced to the total signal.

**Remote command:**

CONF:WCDP:MEAS WCDP, see [CONFigure:WCDPower\[:BTS\]:MEASurement](#) on page 118

### 3.1.1 Code Domain Parameters

Two different types of measurement results are determined and displayed in the Result Summary: global results and channel results (for the selected channel).



The number of the CPICH slot at which the measurement is performed is indicated globally for the measurement in the channel bar.

The spreading code of the selected channel is indicated with the channel number in the channel bar and above the channel-specific results in the Result Summary.

In the Channel Table, the analysis results for all active channels are displayed.

**Table 3-1: General code domain power results for a specific frame and slot**

| Parameter           | Description   |
|---------------------|---|
| Total Power:        | The total signal power (average power of total evaluated slot).   |
| Carrier Freq Error: | The frequency error relative to the center frequency of the analyzer. The absolute frequency error is the sum of the analyzer and DUT frequency error. The specified value is averaged for one (CPICH) slot. See also the note on " <a href="#">Carrier Frequency Error</a> " on page 13. |
| Chip Rate Error:    | The chip rate error in the frame to analyze in ppm. As a result of a high chip rate error, symbol errors arise and the CDP measurement is possibly not synchronized to the 3GPP FDD BTS signal. The result is valid even if synchronization of the analyzer and signal failed.            |

| Parameter            | Description  |
|----------------------|--|
| Trigger to Frame:    | The time difference between the beginning of the recorded signal section to the start of the analyzed frame. In case of triggered data collection, this difference is identical with the time difference of frame trigger (+ trigger offset) – frame start. If synchronization of the analyzer and input signal fails, the value of "Trigger to Frame" is not significant. |
| IQ Offset:           | DC offset of the signal in the selected slot in %  |
| IQ Imbalance:        | I/Q imbalance of signals in the selected slot in %   |
| Avg Power Inact Chan | Average power of the inactive channels   |
| Composite EVM:       | The composite EVM is the difference between the test signal and the ideal reference signal in the selected slot in %.<br>See also " <a href="#">Composite EVM</a> " on page 19   |
| Pk CDE (15 ksp/s):   | The Peak Code Domain Error projects the difference between the test signal and the ideal reference signal onto the selected spreading factor in the selected slot (see " <a href="#">Peak Code Domain Error</a> " on page 23). The spreading factor onto which projection is performed can be derived from the symbol rate indicated in brackets.                          |
| RHO                  | Quality parameter RHO for each slot.   |
| No of Active Chan:   | The number of active channels detected in the signal in the selected slot. Both the detected data channels and the control channels are considered active channels.  |
| Avg. RCDE            | Average Relative Code Domain Error over all channels detected with 64 QAM (UE: 4PAM) modulation in the selected frame.   |



### Carrier Frequency Error

The maximum frequency error that can be compensated is specified in [table 3-2](#) as a function of the synchronization mode. Transmitter and receiver should be synchronized as far as possible.

**Table 3-2: Maximum frequency error that can be compensated**

| SYNC mode | ANTENNA DIV | Max. Freq. Offset |
|-----------|-------------|-------------------|
| CPICH     | X           | 5.0 kHz           |
| SCH       | OFF         | 1.6 kHz           |
| SCH       | ANT 1       | 330 Hz            |
| SCH       | ANT 2       | 330 Hz            |

**Table 3-3: Channel-specific code domain power results**

|                  |   |
|------------------|---|
| Symbol Rate:     | Symbol rate at which the channel is transmitted   |
| Channel Slot No: | <b>(BTS measurements only):</b><br>Channel slot number; determined by combining the value of the selected CPICH and the channel's timing offset |
| Channel Mapping  | <b>(UE measurements only):</b><br>Branch onto which the channel is mapped (I or Q, specified by the standard)                                   |
| Chan Power Abs:  | Channel power, absolute   |

|                   |   |
|-------------------|---|
| Chan Power Rel:   | Channel power, relative (referenced to CPICH or total signal power)   |
| Timing Offset:    | Offset between the start of the first slot in the channel and the start of the analyzed 3GPP FDD BTS frame  |
| RCDE              | Relative Code Domain Error for the complete frame of the selected channel   |
| Symbol EVM:       | Peak and average of the results of the error vector magnitude evaluation  |
| No of Pilot Bits: | Number of pilot bits of the selected channel  |
| Modulation Type:  | BTS measurements:<br>Modulation type of an HSDPA channel. High speed physical data channels can be modulated with QPSK, 16 QAM or 64 QAM modulation.<br>UE measurements: the modulation type of the selected channel. Valid entries are: <ul style="list-style-type: none"> <li>• BPSK I for channels on I-branch</li> <li>• BPSK Q for channels on Q-branch</li> <li>• NONE for inactive channels</li> </ul> |

### 3.1.2 Evaluation Methods for Code Domain Analysis

The captured I/Q data can be evaluated using various different methods without having to start a new measurement.

The selected evaluation also affects the results of the trace data query (see [chapter 10.8.2, "Measurement Results for TRACe<n>\[:DATA\]? TRACE<n>"](#), on page 181).

|                                  |    |
|----------------------------------|----|
| Bitstream.....                   | 15 |
| Channel Table.....               | 15 |
| └ Table Configuration.....       | 16 |
| Code Domain Power.....           | 17 |
| Code Domain Error Power.....     | 18 |
| Composite Constellation.....     | 18 |
| Composite EVM.....               | 19 |
| EVM vs Chip.....                 | 20 |
| Frequency Error vs Slot.....     | 21 |
| Mag Error vs Chip.....           | 22 |
| Marker Table.....                | 22 |
| Peak Code Domain Error.....      | 23 |
| Phase Discontinuity vs Slot..... | 24 |
| Phase Error vs Chip.....         | 24 |
| Power vs Slot.....               | 26 |
| Power vs Symbol.....             | 26 |
| Result Summary.....              | 27 |
| Symbol Constellation.....        | 27 |
| Symbol EVM.....                  | 28 |
| Symbol Magnitude Error.....      | 29 |
| Symbol Phase Error.....          | 29 |

### Bitstream

The Bitstream evaluation displays the demodulated bits of a selected channel for a given slot. Depending on the symbol rate the number of symbols within a slot can vary from 12 (min) to 384 (max). For QPSK modulation a symbol consists of 2 bits (I and Q). For BPSK modulation a symbol consists of 1 bit (only I used).

|     | 0  | 2  | 4  | 6  | 8  | 10 | 12 | 14 | 16 |
|-----|----|----|----|----|----|----|----|----|----|
| 0   | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 | 00 |
| 18  | 00 |    |    |    |    |    |    |    |    |
| 36  |    |    |    |    |    |    |    |    |    |
| 54  |    |    |    |    |    |    |    |    |    |
| 72  |    |    |    |    |    |    |    |    |    |
| 90  |    |    |    |    |    |    |    |    |    |
| 108 |    |    |    |    |    |    |    |    |    |
| 126 |    |    |    |    |    |    |    |    |    |
| 144 |    |    |    |    |    |    |    |    |    |

CPICH    20xD1    0xTPC    0xTFCI    0xD2    0xPil

Fig. 3-1: Bitstream display for 3GPP FDD BTS measurements

**TIP:** Select a specific symbol using a marker for the display. Enter the symbol number as the x-value. The marker is moved to the selected symbol, which is highlighted by a blue circle.

The diagram footer indicates:

- Channel format (type and modulation type (HS-PDSCH only))
- Number of data bits (D1 / D2)
- Number of TPC bits (TPC)
- Number of TFCI bits (TFCI)
- Number of pilot bits (Pil)

Remote command:

LAY:ADD? '1', RIGH, BITS, see LAYout:ADD[:WINDow]? on page 171  
[TRACe<n>\[:DATA\]? ABITstream](#)

### Channel Table

The Channel Table evaluation displays the detected channels and the results of the code domain power measurement. The channel table can contain a maximum of 512 entries.

In BTS measurements, this corresponds to the 512 codes that can be assigned within the class of spreading factor 512.

In UE measurements, this corresponds to the 256 codes that can be assigned within the class of spreading factor 256, with both I and Q branches.

The first entries of the table indicate the channels that must be available in the signal to be analyzed and any other control channels (see [chapter 4.2, "BTS Channel Types"](#), on page 35 and [chapter 4.3, "UE Channel Types"](#), on page 39).

The lower part of the table indicates the data channels that are contained in the signal.

If the type of a channel can be fully recognized, based on pilot sequences or modulation type, the type is indicated in the table. In BTS measurements, all other channels are of type CHAN.

The channels are in descending order according to symbol rates and, within a symbol rate, in ascending order according to the channel numbers. Therefore, the unassigned codes are always displayed at the end of the table.

| Chan Type | Ch.SF  | PwrAbs [dBm] | PwrRel [dB] | State | Mod Type | SymRate [ksps] | Toffs [Chips] | TFCI | PilotL [Bits] |
|-----------|--------|--------------|-------------|-------|----------|----------------|---------------|------|---------------|
| CPICH     | 0.256  | -38.37       | 0.00        | ON    | QPSK     | 15             | 0.00          | OFF  | 0             |
| PSCH      |        | -41.36       | -2.99       | ON    | NONE     | 0              | 0.00          | OFF  | 0             |
| SSCH      |        | -41.35       | -2.98       | ON    | NONE     | 0              | 0.00          | OFF  | 0             |
| PCCPCH    | 1.256  | -38.37       | 0.00        | ON    | QPSK     | 15             | 0.00          | OFF  | 0             |
| SCCPCH    | 3.256  | -46.37       | -8.00       | ON    | QPSK     | 15             | 0.00          | OFF  | 0             |
| PICH      | 16.256 | -46.38       | -8.00       | ON    | QPSK     | 15             | 30720.0       | OFF  | 0             |
| DPCH      | 2.128  | -44.37       | -5.99       | ON    | QPSK     | 30             | 22016.0       | OFF  | 8             |
| DPCH      | 4.128  | -45.37       | -7.00       | ON    | QPSK     | 30             | 23296.0       | OFF  | 8             |
| DPCH      | 7.128  | -47.36       | -8.99       | ON    | QPSK     | 30             | 21248.0       | OFF  | 8             |
| DPCH      | 9.128  | -46.38       | -8.00       | ON    | QPSK     | 30             | 1792.00       | OFF  | 8             |
| DPCH      | 11.128 | -44.37       | -5.99       | ON    | QPSK     | 30             | 34304.0       | OFF  | 8             |
| DPCH      | 12.128 | -48.38       | -10.01      | ON    | QPSK     | 30             | 8192.00       | OFF  | 8             |
| DPCH      | 13.128 | -49.39       | -11.01      | ON    | QPSK     | 30             | 6400.00       | OFF  | 8             |

Fig. 3-2: Channel Table display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, CTABLE, see LAYout:ADD[:WINDOW]? on page 171

TRACe<n>[:DATA]? CTABLE


TRACe<n>[:DATA]? PWCDp

TRACe<n>[:DATA]? CWCDp

### Table Configuration ← Channel Table

You can configure which parameters are displayed in the Channel Table by clicking (not double-clicking!) a column header.

A "Table Configuration" dialog box is displayed in which you can select the columns to be displayed.



By default, only active channels are displayed. In order to display all channels, including the inactive ones, enable the "Show Inactive Channels" option.

The following parameters of the detected channels are determined by the CDP measurement and can be displayed in the Channel Table evaluation. (For details see [chapter 3.1.1, "Code Domain Parameters"](#), on page 12.)



Table 3-4: Code domain power results in the channel table

| Label                       | Description  |
|-----------------------------|--|
| Chan Type                   | Type of channel (active channels only)   |
| Ch. SF                      | Number of channel spreading code (0 to [spreading factor-1])   |
| Symbol Rate [ksps]          | Symbol rate at which the channel is transmitted<br>In BTS measurements: always   |
| State                       | Active: channel is active and all pilot symbols are correct<br>Inactive: channel is not active<br>Pilotf: channel is active, but pilot symbols incomplete or missing |
| TFCI                        | <b>(BTS measurements only):</b><br>Data channel uses TFCI symbols  |
| Mapping                     | <b>(UE measurements only):</b><br>Branch the channel is mapped to (I or Q)   |
| PilotL [Bits]               | Number of pilot bits in the channel<br>(UE measurements: only for control channel DPCCH)   |
| Pwr Abs [dBm]/Pwr Rel [dBm] | Absolute and relative channel power (referred to the CPICH or the total power of the signal)   |
| T Offs [Chips]              | <b>(BTS measurements only):</b><br>Timing offset   |

### Code Domain Power




Fig. 3-3: Code Domain Power Display for 3GPP FDD BTS measurements

The Code Domain Power evaluation shows the power of all possible code channels in the selected channel slot. The x-axis shows the possible code channels from 0 to the highest spreading factor. Due to the circumstance that the power is regulated from slot to slot, the result power may differ between different slots. Detected channels are displayed yellow. The selected code channel is highlighted red. The codes where no channel could be detected are displayed green.

**Note:** Effects of missing or incomplete pilot symbols. In "Autosearch" channel detection mode, the application expects specific pilot symbols for DPCH channels. If these

symbols are missing or incomplete, the channel power in the Code Domain Power evaluation is displayed green at the points of the diagram the channel should appear due to its spreading code, and a message ("INCORRECT PILOT") is displayed in the status bar. In this case, check the pilot symbols for those channels using the Power vs Slot or the Bitstream evaluations.

Optionally, all QPSK-modulated channels can also be recognized without pilot symbols (see "HSDPA/UPA" on page 49).

Remote command:

LAY:ADD? '1',RIGH, CDPower, see [LAYout:ADD\[:WINDow\]?](#) on page 171

CALC:MARK:FUNC:WCDP:RES? CDP, see [CALCulate<n>:MARKer<m>:FUNction:WCDPower\[:BTS\]:RESult?](#) on page 177

CALC:MARK:FUNC:WCDP:MS:RES? CDP, see [CALCulate<n>:MARKer<m>:FUNction:WCDPower:MS:RESult?](#) on page 179


[TRACe<n>\[:DATA\]? CTABLE](#)

[TRACe<n>\[:DATA\]? PWCDp](#)

[TRACe<n>\[:DATA\]? CWCDp](#)

### Code Domain Error Power

Code Domain Error Power is the difference in power between the measured and the ideal signal. The unit is dB. There are no other units for the y-axis.



*Fig. 3-4: Code Domain Error Power Display for 3GPP FDD BTS measurements*

Remote command:

LAY:ADD? '1',RIGH, CDEPower, see [LAYout:ADD\[:WINDow\]?](#) on page 171

[TRACe<n>\[:DATA\]? TRACE<1...4>](#)

### Composite Constellation

The Composite Constellation evaluation analyzes the entire signal for one single slot. If a large number of channels is to be analyzed, the results are superimposed. In that case the benefit of this evaluation is limited (senseless).

In Composite Constellation evaluation the constellation points of the 1536 chips are displayed for the specified slot. This data is determined inside the DSP even before the channel search. Thus, it is not possible to assign constellation points to channels. The constellation points are displayed normalized with respect to the total power.




Fig. 3-5: Composite Constellation display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, CCONst, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Composite EVM

The Composite EVM evaluation displays the root mean square composite EVM (modulation accuracy) according to the 3GPP specification. The square root is determined of the mean squared errors between the real and imaginary components of the received signal and an ideal reference signal (EVM referenced to the total signal). The error is averaged over all channels for individual slots. The Composite EVM evaluation covers the entire signal during the entire observation time.

$$EVM_{RMS} = \sqrt{\frac{\sum_{n=0}^N |s_n - x_n|^2}{\sum_{n=0}^{N-1} |x_n|^2}} * 100\% \quad | \quad N = 2560$$

where:

|             |   |
|-------------|---|
| $EVM_{RMS}$ | root mean square of the vector error of the composite signal              |
| $s_n$       | complex chip value of received signal                                     |
| $x_n$       | complex chip value of reference signal                                    |
| $n$         | index number for mean power calculation of received and reference signal. |
| $N$         | number of chips at each CPICH slot  |




Fig. 3-6: Composite EVM display for 3GPP FDD BTS measurements

The measurement result consists of one composite EVM measurement value per slot. In this case, the measurement interval is the slot spacing of the CPICH (timing offset of 0 chips referenced to the beginning of the frame). Only the channels recognized as active are used to generate the ideal reference signal. If an assigned channel is not recognized as active since pilot symbols are missing or incomplete, the difference between the measurement and reference signal and the composite EVM is very high.

Remote command:

LAY:ADD? '1',RIGH, CEVM, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### EVM vs Chip

EVM vs Chip activates the Error Vector Magnitude (EVM) versus chip display. The EVM is displayed for all chips of the selected slot.

**Note:** In UE measurements, if the measurement interval "Halfslot" is selected for evaluation, 30 slots are displayed instead of the usual 15 (see "Measurement Interval" on page 89).

The EVM is calculated by the root of the square difference of received signal and reference signal. The reference signal is estimated from the channel configuration of all active channels. The EVM is related to the square root of the mean power of reference signal and given in percent.

$$EVM_k = \sqrt{\frac{|s_k - x_k|^2}{\frac{1}{N} \sum_{n=0}^{N-1} |x_n|^2}} \cdot 100\% \quad | N = 2560 \quad | k \in [0 \dots (N-1)]$$

where:

|         |   |
|---------|---|
| $EVM_k$ | vector error of the chip EVM of chip number k |
| $s_k$   | complex chip value of received signal         |
| $x_k$   | complex chip value of reference signal        |

|   |   |
|---|---|
| k | index number of the evaluated chip                          |
| N | number of chips at each CPICH slot                          |
| n | index number for mean power calculation of reference signal |




Fig. 3-7: EVM vs Chip display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, EVMChip, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

**Frequency Error vs Slot**

For each value to be displayed, the difference between the frequency error of the corresponding slot to the frequency error of the first (zero) slot is calculated (based on CPICH slots). This helps eliminate a static frequency offset of the whole signal to achieve a better display of the actual time-dependant frequency diagram.




Fig. 3-8: Frequency Error vs Slot display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, FESLot, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? ATRACE

### Mag Error vs Chip

The Magnitude Error versus chip display shows the magnitude error for all chips of the selected slot.

**Note:** In UE measurements, if the measurement interval "Halfslot" is selected for evaluation, 30 slots are displayed instead of the usual 15 (see "Measurement Interval" on page 89).

The magnitude error is calculated as the difference of the magnitude of the received signal to the magnitude of the reference signal. The reference signal is estimated from the channel configuration of all active channels. The magnitude error is related to the square root of the mean power of reference signal and given in percent.

$$MAG_k = \frac{|s_k| - |x_k|}{\sqrt{\frac{1}{N} \sum_{n=0}^{N-1} |x_n|^2}} \cdot 100\% \quad | N = 2560 \quad | k \in [0 \dots (N-1)]$$

where:

|                  |   |
|------------------|---|
| MAG <sub>k</sub> | magnitude error of chip number k                            |
| s <sub>k</sub>   | complex chip value of received signal                       |
| x <sub>k</sub>   | complex chip value of reference signal                      |
| k                | index number of the evaluated chip                          |
| N                | number of chips at each CPICH slot                          |
| n                | index number for mean power calculation of reference signal |




Fig. 3-9: Magnitude Error vs Chip display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1', RIGH, MEChip, see LAYout:ADD[:WINDow]? on page 171  
[TRACe<n>\[:DATA\]? TRACE<1...4>](#)

### Marker Table

Displays a table with the current marker values for the active markers.

This table may be displayed automatically if configured accordingly (see "Marker Table Display" on page 94).

| Wnd | Type | Ref | X-Value | Y-Value  |
|-----|------|-----|---------|----------|
| 1   | M1   |     | 0.256   | 0.00 dB  |
| 1   | D2   | M1  | 415.512 | -1.94 dB |
| 1   | D3   | M1  | 489.512 | -1.95 dB |
| 1   | D4   | M1  | 266.512 | -2.00 dB |

Remote command:

LAY:ADD? '1', RIGH, MTAB, see LAYout:ADD[:WINDow]? on page 171

Results:

CALCulate<n>:MARKer<m>:X on page 197

CALCulate<n>:MARKer<m>:Y? on page 197

### Peak Code Domain Error

In line with the 3GPP specifications, the error between the measurement signal and the ideal reference signal for a given slot and for all codes is projected onto the various spreading factors. The result consists of the peak code domain error value per slot. The measurement interval is the slot spacing of the CPICH (timing offset of 0 chips referenced to the beginning of the frame). Only the channels recognized as active are used to generate the ideal reference signal for the peak code domain error. If an assigned channel is not recognized as active since pilot symbols are missing or incomplete, the difference between the measurement and reference signal is very high. This display is a bar diagram over slots. The unit is dB. The Peak Code Domain Error evaluation covers the entire signal and the entire observation time.




Fig. 3-10: Peak Code Domain Error display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1', RIGH, PCDError, see LAYout:ADD[:WINDow]? on page 171

TRACe<n>[:DATA]? TRACE<1...4>

### Phase Discontinuity vs Slot

The Phase Discontinuity vs Slot is calculated according to 3GPP specifications. The phase calculated for each slot is interpolated to both ends of the slot using the frequency shift of that slot. The difference between the phase interpolated for the beginning of one slot and the end of the preceding slot is displayed as the phase discontinuity of that slot.




Fig. 3-11: Phase Discontinuity vs Slot display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, PDSLot, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Phase Error vs Chip

Phase Error vs Chip activates the phase error versus chip display. The phase error is displayed for all chips of the selected slot.

**Note:** In UE measurements, if the measurement interval "Halfslot" is selected for evaluation, 30 slots are displayed instead of the usual 15 (see "Measurement Interval" on page 89).

The phase error is calculated by the difference of the phase of received signal and phase of reference signal. The reference signal is estimated from the channel configuration of all active channels. The phase error is given in degrees in a range of  $+180^\circ$  to  $-180^\circ$ .







Fig. 3-12: Calculating the magnitude, phase and vector error per chip

$$PHI_k = \varphi(s_k) - \varphi(x_k) \quad | \quad N = 2560 \quad | \quad k \in [0 \dots (N-1)]$$

where:

|                  |  |
|------------------|--|
| PHI <sub>k</sub> | phase error of chip number k           |
| s <sub>k</sub>   | complex chip value of received signal  |
| x <sub>k</sub>   | complex chip value of reference signal |
| k                | index number of the evaluated chip     |
| N                | number of chips at each CPICH slot     |
| φ(x)             | phase calculation of a complex value   |




Remote command:

LAY:ADD? '1',RIGH, PEChip, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Power vs Slot

The Power vs Slot evaluation displays the power of the selected channel for each slot. The power is displayed either absolute or relative to the total power of the signal or to the CPICH channel.



**Fig. 3-13: Power vs Slot Display for 3GPP FDD BTS measurements**

If a timing offset of the selected channel in relation to the CPICH channel occurs, the power is calculated and displayed per channel slot (as opposed to the Code Domain Power evaluation). However, for reference purposes, the grid in the Power vs Slot diagram indicates the CPICH slots. The first CPICH slot is always slot 0, the grid and labels of the grid lines do not change. Thus, the channel slots may be shifted in the diagram grid. The channel slot numbers are indicated within the power bars. The selected slot is highlighted in the diagram.

Remote command:

LAY:ADD? '1',RIGH, PSlot, see [LAYout:ADD\[:WINDow\]?](#) on page 171  
[TRACe<n>\[:DATA\]? TPVSlot](#)

### Power vs Symbol

The Power vs. Symbol evaluation shows the power over the symbol number for the selected channel and the selected slot. The power is not averaged here. The trace is drawn using a histogram line algorithm, i.e. only vertical and horizontal lines, no diagonal, linear Interpolation (polygon interpolation). Surfaces are NOT filled.




Fig. 3-14: Power vs Symbol display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, PSYMBOL, see LAYOUT:ADD[:WINDOW]? on page 171

TRACe<n>[:DATA]? TRACE<1...4>

### Result Summary

The Result Summary evaluation displays a list of measurement results on the screen. For details see [chapter 3.1.1, "Code Domain Parameters"](#), on page 12.

| 3G FDD BTS: 2 Result Summary                   |            |                    |             |
|--|------------|--------------------|-------------|
| <b>General Results (Frame 0, CPICH Slot 0)</b> |            |                    |             |
| Total Power                                    | -28.36 dBm | Carrier Freq Error | -0.00 Hz    |
| Chip Rate Error                                | -0.00 ppm  | Trigger to Frame   | 5.637434 ms |
| IQ Offset                                      | 0.03 %     | IQ Imbalance       | 0.02 %      |
| Avg Power Inact Chan                           | -59.73 dB  | Composite EVM      | 0.73 %      |
| Rho  | 0.999943   | Pk CDE(15 Ksps)    | -63.76 dB   |
| No of Active Channels                          | 68         | Avg RCDE(64QAM)    | ---         |
| <b>Channel Results (Ch 0.256)</b>              |            |                    |             |
| Symbol Rate                                    | 15 ksym/s  | Timing Offset      | 0 Chips     |
| No of Pilot Bits                               | 0          | Channel Slot No    | 0           |
| RCDE   | -57.03 dB  | Modulation Type    | QPSK        |
| Channel Power Abs                              | -38.37 dBm | Symbol EVM         | 0.21 % PK   |
| Channel Power Rel                              | 0.00 dB    | Symbol EVM         | 0.14 % rms  |

Fig. 3-15: Result Summary display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, RSUMmary, see LAYOUT:ADD[:WINDOW]? on page 171

TRACe<n>[:DATA]? TRACE<1...4>

CALCulate<n>:MARKer<m>:FUNCTION:WCDPower[:BTS]:RESult? on page 177

### Symbol Constellation

The Symbol Constellation evaluation shows all modulated signals of the selected channel and the selected slot. QPSK constellation points are located on the diagonals (not x and y-axis) of the constellation diagram. BPSK constellation points are always on the x-axis.




Fig. 3-16: Symbol Constellation display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, SCONst, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Symbol EVM

The Symbol EVM evaluation shows the error between the measured signal and the ideal reference signal in percent for the selected channel and the selected slot. A trace over all symbols of a slot is drawn. The number of symbols is in the range from 12 (min) to 384 (max). It depends on the symbol rate of the channel.




Fig. 3-17: Symbol EVM display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, SEVM, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Symbol Magnitude Error

The Symbol Magnitude Error is calculated analogous to symbol EVM. The result is one symbol magnitude error value for each symbol of the slot of a special channel. Positive values of symbol magnitude error indicate a symbol magnitude that is larger than the expected ideal value; negative symbol magnitude errors indicate a symbol magnitude that is less than the ideal one. The symbol magnitude error is the difference between the magnitude of the received symbol and that of the reference symbol, related to the magnitude of the reference symbol.




Fig. 3-18: Symbol Magnitude Error display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, SMERror, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

### Symbol Phase Error

The Symbol Phase Error is calculated analogous to symbol EVM. The result is one symbol phase error value for each symbol of the slot of a special channel. Positive values of symbol phase error indicate a symbol phase that is larger than the expected ideal value; negative symbol phase errors indicate a symbol phase that is less than the ideal one.




Fig. 3-19: Symbol Phase Error display for 3GPP FDD BTS measurements

Remote command:

LAY:ADD? '1',RIGH, SPERror, see LAYout:ADD[:WINDow]? on page 171  
 TRACe<n>[:DATA]? TRACE<1...4>

## 3.2 Time Alignment Error Measurements

Time Alignment Error Measurements are a special type of Code Domain Analysis used to determine the time offset between the signals of both antennas of a base station.

They are only available in 3GPP FDD BTS measurements.

The result is displayed numerically on the screen, a graphical result is not available.



### Synchronization errors

A synchronization check is performed for both antennas which must have the result "Sync OK" to ensure a proper TAE result. Synchronization problems are indicated by the messages "No antenna 1 sync", "No antenna 2 sync" and "No sync".


For more information see [chapter 4.8, "Time Alignment Error Measurements"](#), on page 44.

### Evaluation Methods

For Time Alignment Error measurements, the following evaluation methods are available:

### Result List

Indicates the time delay (in chips) of the signal at antenna 2 relative to the signal at antenna 1.



**Fig. 3-20: Time Alignment Error display for 1 base station**

Remote command:

`CONF:WCDP:MEAS TAER`, see `CONFigure:WCDPower[:BTS]:MEASurement`  
on page 118

`CALCulate<n>:MARKer<m>:FUNction:TAError:RESult?` on page 177

## 4 Measurement Basics

Some background knowledge on basic terms and principles used in 3GPP FDD tests and measurements is provided here for a better understanding of the required configuration settings.

### Basic principle

The basic principle of 3GPP FDD (frequency division duplex) is that the communication between a base station and several mobile stations is performed in the same frequency band and in the same time slots. The separation of the data for the different mobile stations is achieved by using CDMA (Code Division Multiple Access). In this technique, channels are distinguished by using different orthogonal codes.

### Scrambling codes

Each base station uses a unique scrambling code. The mobile station can only demodulate the base station signal if it knows which scrambling code was used by the base station.

Thus, in order to demodulate the data in the 3GPP FDD applications, you must either specify the scrambling code explicitly, or the application can perform an automatic search to detect the scrambling code itself.

### Channels, codes and symbol rate

In signals according to the 3GPP FDD standard, the data is transmitted in channels. These channels are based on orthogonal codes and can have different data rates. The data rate depends on the used modulation type and the spreading factor of the channel.

### Spreading factors

**Spreading factors** determine whether the transmitted data is sent in short or long sequences. The spreading factor is re-assigned dynamically in certain time intervals according to the current demand of users and data to be transmitted. The higher the spreading factor, the lower the data rate; the lower the spreading factor, the higher the data rate.

The smallest available spreading factor is 4, the largest is 512. So we can say that the code domain consists of 512 basic codes. A channel with a lower spreading factor consists of several combined codes. That means a channel can be described by its number and its spreading factor.

The following table shows the relationship between the code class, the spreading factor, the number of codes per channel, and the symbol rate.



**Table 4-1: Relationship between code class, spreading factor, codes per channel and symbol rate for 3GPP FDD signals**

| Code class | Spreading factor | No. codes / channel | Symbol rate |
|------------|------------------|---------------------|-------------|
| 2          | 4                | 128                 | 960 ksps    |
| 3          | 8                | 64                  | 480 ksps    |
| 4          | 16               | 32                  | 240 ksps    |
| 5          | 32               | 16                  | 120 ksps    |
| 6          | 64               | 8                   | 60 ksps     |
| 7          | 128              | 4                   | 30 ksps     |
| 8          | 256              | 2                   | 15 ksps     |
| 9          | 512              | 1                   | 7.5 ksps    |



In the measurement settings and results, the spreading factor is often represented by the corresponding symbol rate (in kilo symbols per second, ksps). The power of a channel is always measured in relation to its symbol rate (or spreading factor).

In the 3GPP FDD applications, the channel number consists of the used spreading factor and the channel's sequential number in the code domain, assuming the code domain is divided into equal divisions:

<sequence number>.<spreading factor>

#### **Example:**

For a channel number of 5.32, for example, imagine a code domain of 512 codes with a scale of 16 codes per division. Each division represents a possible channel with spreading factor 32. Since channel numbering starts at 0, channel number 5 is the sixth division on the scale.

#### **Selected codes and channels**

In the result displays that refer to channels, the currently selected channel is highlighted in the diagram. You select a channel by entering a channel number and spreading factor in the "Evaluation Range" settings. In the example above, if you select the channel number 5.32, the sixth division on the scale with 16 codes per division is highlighted.

For the display in the 3GPP FDD applications, the scale for code-based diagrams contains 512 divisions, one for each code. The selected channel in the example (5.32) would thus correspond to codes 80-96. (The division starts at  $5 \cdot 16 = 80$  and is 16 codes wide.)

If no spreading factor is given for the channel number, the default factor 512 is assumed. Channel number 5 would thus refer to the sixth division on the scale, which is the sixth code in the code domain. If the code belongs to a detected channel, the entire channel is highlighted.

If the selected channel is not active, only the first code belonging to the corresponding division is highlighted. In the example, for the inactive channel number 5.32, the first code in the sixth division on the scale with 16 codes per division is highlighted. That corresponds to code number 80 with the scale based on 512 divisions.

### Special channels - PCCPCH, SCH, CPICH, DPCH

In order to control the data transmission between the sender and the receiver, specific symbol must be included in the transmitted data, for example the scrambling code of the sender or the used spreading factor, as well as synchronization data for different channels. This data is included in special data channels defined by the 3GPP standard which use fixed codes in the code domain. Thus, they can be detected easily by the receiver.

The **Primary Common Control Physical Channel** (PCCPCH) must always be contained in the signal. As the name implies, it is responsible for common control of the channels during transmission.

The **Synchronization Channel** (SCH) is a time reference and responsible for synchronizing the individual channels.

Another important channel is the **Common Pilot Channel** (CPICH), which continuously transmits the sender's scrambling code. This channel is used to identify the sender, but also as a reference in 3GPP FDD signal measurements.

The user data is contained in the **Dedicated Physical Channel** (DPCH).

More details on channel types are provided in [chapter 4.2, "BTS Channel Types"](#), on page 35.

### Chips, frames and slots

The user data is spread across the available bandwidth using the spreading factor before transmission. The spreaded bits are referred to as "chips".

A time span of 10 ms is also known as a "frame". A frame is a basic time unit in the transmission process. Each frame is divided into 15 time "slots". Various channel parameters are put in relation to frames or the individual slots in the 3GPP standard, as well as some measurement results for 3GPP FDD signals. A slot contains 2560 chips.

### Channel slots versus CPICH slots

The time slots of the individual channels may not be absolutely synchronous. A time offset may occur, so that the slots in a data channel are slightly shifted in relation to the CPICH slots, for example. In the 3GPP FDD BTS application, the CPICH slot number is provided as a reference with the measurement settings in the channel bar. In the Result Summary, the actual slot number of the evaluated channel is indicated as the "Channel Slot No".

### Pilot symbols

Some slots contain a fixed sequence of symbols, referred to as "pilot symbols". These pilot symbols allow the receiver to identify a particular channel, if the unique pilot symbols can be detected in the input signal.

### Power control

While the spreading factors are adjusted for each frame, i.e. every 10 ms, the power levels for transmission must be adapted to the current requirements (such as interference) much more dynamically. Thus, power control bits are transmitted in each slot, allowing for much higher change rates. As the CPICH channel continuously transmits the same data, the power level need not be adapted. Thus, the power control bits can lead to a timing offset between the CPICH slots and other channel slots.

## 4.1 Channel Detection

The 3GPP FDD applications provide two basic methods of detecting active channels:

- **Automatic search using pilot sequences**

The application performs an automatic search for active (DPCH) channels throughout the entire code domain. The search is based on the presence of known symbol sequences (pilot symbols) in the despread symbols of a channel. A data channel is considered to be active if the pilot symbols as specified by the 3GPP FDD standard are found at the end of each slot. In this mode, channels without or with incomplete pilot symbols are therefore not recognized as being active.

An exception to this rule is seen in the special channels PICH and SCCPCH, which can be recognized as active in the automatic search mode although they do not contain pilot symbols. Optionally, all QPSK-modulated channels can also be recognized without pilot symbols (see "[HSDPA/UPA](#)" on page 49).

In addition, the channel must exceed a minimum power in order to be considered active (see "[Inactive Channel Threshold \(BTS measurements only\)](#)" on page 72).

**In UE measurements**, a channel is considered to be active if a minimum signal/noise ratio is maintained within the channel.

- **Comparison with predefined channel tables**

The input signal is compared to a predefined channel table. All channels that are included in the predefined channel table are considered to be active.

## 4.2 BTS Channel Types

The 3GPP FDD standard defines various BTS channel types. Some channels are mandatory and must be contained in the signal, as they have control or synchronization functions. Thus, these channels always occupy a specific channel number and use a specific symbol rate by which they can be identified.

### Control and synchronization channels

The 3GPP FDD BTS application expects the following control and synchronization channels for the Code Domain Power measurements:

Table 4-2: Common 3GPP FDD BTS control channels and their usage

| Channel type  | Description   |
|---------------|---|
| <b>PSCH</b>   | <p><b>Primary Synchronization Channel</b></p> <p>The Primary Synchronization Channel is used to synchronize the signal in the case of SCH synchronization. It is a non-orthogonal channel. Only the power of this channel is determined.</p>  |
| <b>SSCH</b>   | <p><b>Secondary Synchronization Channel</b></p> <p>The Secondary Synchronization Channel is a non-orthogonal channel. Only the power of this channel is determined.</p>   |
| <b>PCCPCH</b> | <p><b>Primary Common Control Physical Channel</b></p> <p>The Primary Common Control Physical Channel is also used to synchronize the signal in the case of SCH synchronization. It is expected at code class 8 and code number 1.</p>   |
| <b>SCCPCH</b> | <p><b>Secondary Common Control Physical Channel</b></p> <p>The Secondary Common Control Physical Channel is a QPSK-modulated channel without any pilot symbols. In the 3GPP test models, this channel can be found in code class 8 and code number 3. However, the code class and code number need not be fixed and can vary. For this reason, the following rules are used to indicate the SCCPCH.</p> <ul style="list-style-type: none"> <li>• Only one QPSK-modulated channel without pilot symbols is detected and displayed as the SCCPCH. Any further QPSK-modulated channels without pilot symbols are not detected as active channels.</li> <li>• If the signal contains more than one channel without pilot symbols, the channel that is received in the highest code class and with the lowest code number is displayed as the SCCPCH. It is expected that only one channel of this type is included in the received signal. According to this assumption, this channel is probably the SCCPCH.</li> <li>• If the application is configured to recognize all QPSK-modulated channels without pilot symbols (see "<a href="#">HSDPA/UPA</a>" on page 49), and one of these channels is received at code class 8 and code number 3, it is displayed as the SCCPCH.</li> </ul> |
| <b>CPICH</b>  | <p><b>Common Pilot Channel</b></p> <p>The Common Pilot Channel is used to synchronize the signal in the case of CPICH synchronization. It is expected at code class 8 and code number 0.</p> <p>If it is not contained in the signal configuration, the firmware application must be configured to synchronize to the SCH channel (see "<a href="#">Synchronization Type</a>" on page 70).</p>  |

Other channels are optional and contain the user data to be transmitted. A data channel is any channel that does not have a predefined channel number and symbol rate. The following channel types can be detected by the 3GPP FDD BTS application.

Table 4-3: Common 3GPP FDD BTS data channels and their usage

| Channel type        | Description   |
|---------------------|---|
| <b>PICH</b>         | <p><b>Paging Indication Channel</b></p> <p>The Paging Indication Channel is expected at code class 8 and code number 16.</p> <p>The lower part of the table indicates the data channels contained in the signal. A data channel is any channel that does not have a predefined channel number and symbol rate. There are different types of data channels, which are indicated in the column "Chan Type".</p>   |
| <b>DPCH</b>         | <p><b>Dedicated Physical Channel</b> of a standard frame</p> <p>The Dedicated Physical Channel is a data channel that contains pilot symbols. The displayed channel type is DPCH.</p>   |
| <b>CPRSD</b>        | <p>Dedicated Physical Channel (DPCH) in <b>compressed</b> mode</p> <p>Compressed mode channels usually do not transmit valid symbols in all slots. There are different lengths of the transmitting gap. One to fourteen slots can be switched off in each frame. In some cases outside the gap the symbol rate is increased by 2 to ensure a constant average symbol rate of this channel. In any case all of the transmitted slots contain a pilot sequence defined in the 3GPP specification. There are different types of compressed mode channels.</p> <p>To evaluate compressed mode channels, the associated measurement mode needs to be activated (see "<a href="#">Compressed Mode</a>" on page 50).</p>   |
| <b>CPR-TPC</b>      | DPCH in <b>compressed</b> mode where <b>TPC</b> symbols are sent in the first slot of the transmitting gap  |
| <b>CPR-SF/2</b>     | DPCH in <b>compressed</b> mode using half spreading factor ( <b>SF/2</b> ) to increase the symbol rate of the active slots by two   |
| <b>CPR-SF/2-TPC</b> | DPCH in <b>compressed</b> mode using half spreading factor ( <b>SF/2</b> ) to increase the symbol rate of the active slots by two, where <b>TPC</b> symbols are sent in the first slot of the transmitting gap  |
| <b>HS-PDSCH</b>     | <p>HSDPA: <b>High Speed Physical Downlink Shared Channel</b></p> <p>The High Speed Physical Downlink Shared Channel (HSDPA) does not contain any pilot symbols. It is a channel type that is expected in code classes lower than 7. The modulation type of these channels can vary depending on the selected slot.</p> <p><b>HSPDSCH-QPSK_</b>: QPSK-modulated slot of an HS PDSCH channel</p> <p><b>HSPDSCH-16QAM_</b>: 16QAM-modulated slot of an HS PDSCH channel</p> <p><b>HSPDSCH-NONE_</b>: slot without power of an HS PDSCH channel</p>   |
| <b>HS-SCCH</b>      | <p>HSDPA: <b>High Speed Shared Control Channel</b></p> <p>The High Speed Shared Control Channel (HSDPA) does not contain any pilot symbols. It is a channel type that is expected in code classes equal to or higher than 7. The modulation type should always be QPSK. The channel does not contain any pilot symbols.</p> <p>If the application is configured to recognize all QPSK-modulated channels without pilot symbols (see "<a href="#">HSDPA/UPA</a>" on page 49), the channels of HSDPA will be found among the data channels. If the type of a channel can be fully recognized, as for example with a DPCH (based on pilot sequences) or HS-PDSCH (based on modulation type), the type is entered in the field TYPE. All other channels without pilot symbols are of type CHAN. The channels are in descending order according to symbol rates and, within a symbol rate, in ascending order according to the channel numbers. Therefore, the unassigned codes are always to be found at the end of the table.</p> <p>If the modulation type for a channel can vary, the measured value of the modulation type will be appended to the type of the channel.</p> |

| Channel type | Description   |
|--------------|---|
| EHICH-ERGCH  | HSUPA:<br>Enhanced HARQ Hybrid Acknowledgement Indicator Channel<br>Enhanced Relative Grant Channel   |
| EAGCH        | Enhanced Absolute Grant Channel   |
| SCPICH       | Secondary Common Pilot Channel  |
| CHAN         | If the application is configured to recognize all QPSK-modulated channels without pilot symbols (see "HSDPA/UPA" on page 49), all QPSK-modulated channels without pilot symbols and a code class higher than or equal to 7 are marked with the channel type CHAN. |

### MIMO channel types

Optionally, single antenna MIMO measurement channels can also be detected. In this case, HS-PDSCH channels with exclusively QPSK or exclusively 16 QAM on both transport streams are automatically detected and demodulated. The corresponding channel types are denoted as "HS-MIMO-QPSK" and "HS-MIMO-16QAM".

The MIMO constellations resulting on a single antenna consist of three amplitudes per dimension (-1, 0, 1) in the case of QPSK x QPSK, and seven amplitudes per dimension (-3, -2, -1, 0, 1, 2, 3) in the case of 16 QAM x 16 QAM. The symbol decisions of these constellations can be retrieved via the bitstream output. The mapping between bits and constellation points is given by the following table.

**Table 4-4: Mapping between bits and constellation points for MIMO-QPSK**

| Constellation point (normalized) | Bit sequence |
|----------------------------------|--------------|
| 0,0                              | 0,1,0,1      |
| 1,0                              | 0,1,0,0      |
| -1,0                             | 0,1,1,1      |
| 0,1                              | 0,0,0,1      |
| 1,1                              | 0,0,0,0      |
| -1,1                             | 0,0,1,1      |
| 0,-1                             | 1,1,0,1      |
| 1,-1                             | 1,1,0,0      |
| -1,-1                            | 1,1,1,1      |

For MIMO-16QAM, the bit sequence is the same in both I and Q. Only one dimension is given here.

**Table 4-5: Mapping between bits and constellation points for MIMO-16QAM**

| Constellation point (normalized) | Bit sequence |
|----------------------------------|--------------|
| -3                               | 1,1,1        |
| -2                               | 1,1,0        |
| -1                               | 1,0,0        |

| Constellation point (normalized) | Bit sequence |
|----------------------------------|--------------|
| 0                                | 1,0,1        |
| 1                                | 0,0,1        |
| 2                                | 0,0,0        |
| 3                                | 0,1,0        |

### 4.3 UE Channel Types

The following channel types can be detected in 3GPP FDD uplink signals by the 3GPP FDD UE application.

#### Control channels

The 3GPP FDD UE application expects the following control channels for the Code Domain Power measurements:

*Table 4-6: Common 3GPP FDD UE control channels and their usage*

| Channel type | Description   |
|--------------|---|
| DPCCH        | The <b>D</b> edicated <b>P</b> hysical <b>C</b> ontrol <b>C</b> hannel is used to synchronize the signal. It carries pilot symbols and is expected in the Q branch at code class 8 with code number 0. This channel must be contained in every channel table.   |
| HSDPCCH      | The <b>H</b> igh <b>S</b> peed <b>D</b> edicated <b>P</b> hysical <b>C</b> ontrol <b>C</b> hannel (for HS-DCH) is used to carry control information (CQI/ACK/NACK) for downlink high speed data channels (HS-DCH). It is used in HSDPA signal setup. The symbol rate is fixed to 15ksps. The code allocation depends on the number of active DPCH. The HS-DPCCH can be switched on or off after the duration of 1/5 frame or 3 slots or 2ms. Power control is applicable too. |
| EDPCCH       | The <b>E</b> nhanced <b>D</b> edicated <b>P</b> hysical <b>C</b> ontrol <b>C</b> hannel is used to carry control information for uplink high speed data channels (EDPDCH). It is used in HSUPA signal setup. The symbol rate is fixed to 15ksps.  |

Other channels are optional and contain the user data to be transmitted. A data channel is any channel that does not have a predefined channel number and symbol rate.

The following channel types can be detected by the 3GPP FDD UE application:

*Table 4-7: Common 3GPP FDD UE data channels and their usage*

| Channel type | Description  |
|--------------|--|
| DPDCH        | The <b>D</b> edicated <b>P</b> hysical <b>D</b> ata <b>C</b> hannel is used to carry UPLINK data from the UE to the BS. The code allocation depends on the total required symbol rate.   |
| EDPDCH       | The <b>E</b> nhanced <b>D</b> edicated <b>P</b> hysical <b>D</b> ata <b>C</b> hannel is used to carry UPLINK data for high speed channels (EDPDCH). It is used in HSUPA signal setup. The symbol rate and code allocation depends on the number of DPDCH and HS-DPCCH. |



As specified in 3GPP, the channel table can contain up to 6 DPDCHs or up to 4 E-DPDCHs.

## 4.4 3GPP FDD BTS Test Models

For measurements on base-station signals in line with 3GPP, test models with different channel configurations are specified in the document "Base station conformance testing (FDD)" (3GPP TS 25.141 V5.7.0). An overview of the test models is provided here.

**Table 4-8: Test model 1**

| Channel type    | Number of channels | Power (%)  | Level (dB)    | Spreading code | Timing offset (x256Tchip) |
|-----------------|--------------------|------------|---------------|----------------|---------------------------|
| PCCPCH+SCH      | 1                  | 10         | -10           | 1              | 0                         |
| Primary CPICH   | 1                  | 10         | -10           | 0              | 0                         |
| PICH            | 1                  | 1.6        | -18           | 16             | 120                       |
| SCCPCH (SF=256) | 1                  | 1.6        | -18           | 3              | 0                         |
| DPCH (SF=128)   | 16/32/64           | 76.8 total | see TS 25.141 | see TS 25.141  | see TS 25.141             |

**Table 4-9: Test model 2**

| Channel type    | Number of channels | Power (%)      | Level (dB)      | Spreading code | Timing offset (x256Tchip) |
|-----------------|--------------------|----------------|-----------------|----------------|---------------------------|
| PCCPCH+SCH      | 1                  | 10             | -10             | 1              | 0                         |
| Primary CPICH   | 1                  | 10             | -10             | 0              | 0                         |
| PICH            | 1                  | 5              | -13             | 16             | 120                       |
| SCCPCH (SF=256) | 1                  | 5              | -13             | 3              | 0                         |
| DPCH (SF=128)   | 3                  | 2 x 10, 1 x 50 | 2 x -10, 1 x -3 | 24, 72, 120    | 1, 7, 2                   |

**Table 4-10: Test model 3**

| Channel type    | Number of channels | Power (%)<br>16/32 | Level (dB)<br>16/32 | Spreading code | Timing offset (x256Tchip) |
|-----------------|--------------------|--------------------|---------------------|----------------|---------------------------|
| PCCPCH+SCH      | 1                  | 12.6/7.9           | -9/-11              | 1              | 0                         |
| Primary CPICH   | 1                  | 12.6/7.9           | -9/-11              | 0              | 0                         |
| PICH            | 1                  | 5/1.6              | -13/-18             | 16             | 120                       |
| SCCPCH (SF=256) | 1                  | 5/1.6              | -13/-18             | 3              | 0                         |
| DPCH (SF=256)   | 16/32              | 63,7/80,4 total    | see TS 25.141       | see TS 25.141  | see TS 25.141             |



Table 4-11: Test model 4

| Channel type   | Number of channels | Power (%)<br>16/32 | Level (dB)<br>16/32 | Spreading code | Timing offset (×256Tchip) |
|----------------|--------------------|--------------------|---------------------|----------------|---------------------------|
| PCCPCH+SCH     | 1                  | 50 to 1.6          | -3 to -18           | 1              | 0                         |
| Primary CPICH* | 1                  | 10                 | -10                 | 0              | 0                         |

Table 4-12: Test model 5

| Channel type     | Number of channels | Power (%)            | Level (dB)    | Spreading code | Timing offset (×256Tchip) |
|------------------|--------------------|----------------------|---------------|----------------|---------------------------|
| PCCPCH+SCH       | 1                  | 7.9                  | -11           | 1              | 0                         |
| Primary CPICH    | 1                  | 7.9                  | -11           | 0              | 0                         |
| PICH             | 1                  | 1.3                  | -19           | 16             | 120                       |
| SCCPCH (SF=256)  | 1                  | 1.3                  | -19           | 3              | 0                         |
| DPCH (SF=256)    | 30/14/6            | 14/14.2/14.4 total   | see TS 25.141 | see TS 25.141  | see TS 25.141             |
| HS_SCCH          | 2                  | 4 total              | see TS 25.141 | see TS 25.141  | see TS 25.141             |
| HS_PDSCH (16QAM) | 8/4/2              | 63.6/63.4/63.2 total | see TS 25.141 | see TS 25.141  | see TS 25.141             |

## 4.5 Setup for Base Station Tests

This section describes how to set up the analyzer for 3GPP FDD BTS tests. As a prerequisite for starting the test, the instrument in use must be correctly set up and connected to the AC power supply as described in the instrument's Getting Started manual. Furthermore, the 3GPP FDD BTS application must be available.

### Standard Test Setup

- Connect the antenna output (or Tx output) of the BTS to the RF input of the analyzer via a power attenuator of suitable attenuation.  
The following values are recommended for the external attenuator to ensure that the RF input of the analyzer is protected and the sensitivity of the analyzer is not reduced too much.

| Max. power    | Recommended ext. attenuation |
|---------------|------------------------------|
| ≥55 to 60 dBm | 35 to 40 dB                  |
| ≥50 to 55 dBm | 30 to 35 dB                  |
| ≥45 to 50 dBm | 25 to 30 dB                  |
| ≥40 to 45 dBm | 20 to 25 dB                  |
| ≥35 to 40 dBm | 15 to 20 dB                  |

| Max. power    | Recommended ext. attenuation |
|---------------|------------------------------|
| ≥30 to 35 dBm | 10 to 15 dB                  |
| ≥25 to 30 dBm | 5 to 10 dB                   |
| ≥20 to 25 dBm | 0 to 5 dB                    |
| <20 dBm       | 0 dB                         |

- For signal measurements at the output of two-port networks, connect the reference frequency of the signal source to the rear reference input of the analyzer (EXT REF IN/OUT).
- To ensure that the error limits specified by the 3GPP standard are met, the analyzer should use an external reference frequency for frequency measurements on base stations. For instance, a rubidium frequency standard may be used as a reference source.
- If the base station is provided with a trigger output, connect this output to the trigger input of the analyzer.

### Presetting

Configure the R&S VSE as follows:

- Set the external attenuation (Reference level offset).
- Set the reference level.
- Set the center frequency.
- Set the trigger.
- Select the BTS standard and measurement.

## 4.6 3GPP FDD UE Test Models

The possible channel configurations for the mobile station signal are limited by 3GPP. Only two different configurations for data channels DPDCH are permissible according to the specification. In addition to these two channel configurations, the HS-DPCCH channel can be transmitted to operate the mobile station in HSDPA mode. Thus, the 3GPP FDD UE application checks for these channel configurations only during the automatic channel search. Therefore, channels whose parameters do not correspond to one of these configurations are not automatically detected as active channels.

The two possible channel configurations are summarized below:

**Table 4-13: Channel configuration 1: DPCCH and 1 DPDCH**

| Channel type | Number of channels | Symbol rate        | Spreading code(s)    | Mapping |
|--------------|--------------------|--------------------|----------------------|---------|
| DPCCH        | 1                  | 15 ksps            | 0                    | Q       |
| DPDCH        | 1                  | 15 ksps – 960 ksps | [spreading-factor/4] | I       |

**Table 4-14: Channel configuration 2: DPCCH and up to 6 DPDCH**

| Channel type | Number of channels | Symbol rate | Spreading code(s) | Mapping |
|--------------|--------------------|-------------|-------------------|---------|
| DPCCH        | 1                  | 15 ksps     | 0                 | Q       |
| DPDCH        | 1                  | 960 ksps    | 1                 | I       |
| DPDCH        | 1                  | 960 ksps    | 1                 | Q       |
| DPDCH        | 1                  | 960 ksps    | 3                 | I       |
| DPDCH        | 1                  | 960 ksps    | 3                 | Q       |
| DPDCH        | 1                  | 960 ksps    | 2                 | I       |
| DPDCH        | 1                  | 960 ksps    | 2                 | Q       |

**Table 4-15: Channel configuration 3: DPCCH, up to 6 DPDCH and 1 HS-DPCCH** The channel configuration is as above in table 4-2. On HS-DPCCH is added to each channel table.

| Number of DPDCH | Symbol rate all DPDCH | Symbol rate HS-DPCCH | Spreading code HS-DPCCH | Mapping (HS-DPCCH) |
|-----------------|-----------------------|----------------------|-------------------------|--------------------|
| 1               | 15 – 960 ksps         | 15 ksps              | 64                      | Q                  |
| 2               | 1920 ksps             | 15 ksps              | 1                       | I                  |
| 3               | 2880 ksps             | 15 ksps              | 32                      | Q                  |
| 4               | 3840 ksps             | 15 ksps              | 1                       | I                  |
| 5               | 4800 ksps             | 15 ksps              | 32                      | Q                  |
| 6               | 5760 ksps             | 15 ksps              | 1                       | I                  |

**Table 4-16: Channelization code of HS-DPCCH**

| Nmax-dpdch (as defined in subclause 4.2.1) | Channelization code $C_{ch}$ |
|--|------------------------------|
| 1  | $C_{ch,256,64}$              |
| 2,4,6                                      | $C_{ch,256,1}$               |
| 3,5  | $C_{ch,256,32}$              |

## 4.7 Setup for User Equipment Tests

This section describes how to set up the R&S VSE for 3GPP FDD UE user equipment tests. As a prerequisite for starting the test, the instrument in use must be correctly set up and connected to the AC power supply as described in the analyzer's Getting Started manual. Furthermore, the 3GPP FDD UE application must be installed.

### Standard Test Setup

- Connect antenna output (or Tx output) of UE to RF input of the analyzer via a power attenuator of suitable attenuation.

The following values are recommended for the external attenuator to ensure that the RF input of the analyzer is protected and the sensitivity of the analyzer is not reduced too much.

| Max. power                | Recommended ext. attenuation |
|---------------------------|------------------------------|
| <sup>3</sup> 55 to 60 dBm | 35 to 40 dB                  |
| <sup>3</sup> 50 to 55 dBm | 30 to 35 dB                  |
| <sup>3</sup> 45 to 50 dBm | 25 to 30 dB                  |
| <sup>3</sup> 40 to 45 dBm | 20 to 25 dB                  |
| <sup>3</sup> 35 to 40 dBm | 15 to 20 dB                  |
| <sup>3</sup> 30 to 35 dBm | 10 to 15 dB                  |
| <sup>3</sup> 25 to 30 dBm | 5 to 10 dB                   |
| <sup>3</sup> 20 to 25 dBm | 0 to 5 dB                    |
| <20 dBm                   | 0 dB                         |

- For signal measurements at the output of two-port networks, connect the reference frequency of the signal source to the external reference input connector of the analyzer (REF INPUT).
- To ensure that the error limits specified by the 3GPP standard are met, the analyzer should use an external reference frequency for frequency measurements on user equipment. For instance, a rubidium frequency standard may be used as a reference source.
- If the user equipment is provided with a trigger output, connect this output to one of the TRIGGER INPUT connectors of the analyzer.

### Presetting

Configure the R&S VSE as follows:

- Set the external attenuation (Reference level offset).
- Set the reference level.
- Set the center frequency.
- Set the trigger.
- Select the UE standard and measurement.

## 4.8 Time Alignment Error Measurements

Time Alignment Error Measurements are a special type of Code Domain Analysis used to determine the time offset between the signals of both antennas of a base station.

- [Measurement Setup for Two Antennas in a Base Station](#)..... 45

### 4.8.1 Measurement Setup for Two Antennas in a Base Station

The antenna signals of the two BTS transmitter branches are fed to the analyzer via a combiner. Each antenna must provide a common pilot channel, i.e. P-CPICH for antenna 1 and P-CPICH or S-CPICH for antenna 2. The [Time Alignment Error Measurement setup for one base station using an R&S FSW](#) shows the measurement setup.




Fig. 4-1: Time Alignment Error Measurement setup for one base station using an R&S FSW

#### Synchronization check


A synchronization check is performed for both antennas which must have the result "Sync OK" to ensure a proper TAE result. Synchronization problems are indicated by the messages "No antenna 1 sync", "No antenna 2 sync" and "No sync". Errors can also be read remotely via bits 1 and 2 of the `Sync` status register (see [chapter 10.10, "Querying the Status Registers"](#), on page 206).

## 5 Configuration

The 3GPP FDD applications provide several different measurements for signals according to the 3GPP FDD application. The main and default measurement is Code Domain Analysis. Furthermore, a Time Alignment Error measurement is provided. In addition to the code domain power measurements specified by the 3GPP standard, the 3GPP FDD options offer measurements with predefined settings in the frequency domain, e.g. RF power measurements.



### Multiple access paths to functionality

The easiest way to configure a measurement channel is via the "Overview" dialog box, which is displayed when you select the  "Overview" icon from the main toolbar or the "Meas Setup" > "Overview" menu item.

Alternatively, you can access the individual dialog boxes from the corresponding menu items, or via tools in the toolbars, if available.

In this documentation, only the most convenient method of accessing the dialog boxes is indicated - usually via the "Overview". For an overview of all available menu items and toolbar icons see [chapter A, "Reference"](#), on page 218.

### Selecting the measurement type

When you activate an 3GPP FDD application, Code Domain Analysis of the input signal is started automatically. However, the 3GPP FDD applications also provide other measurement types.

- ▶ To select a different measurement type, do one of the following:
  - In the "Overview", select the "Select Measurement" button. Select the required measurement.
  - From the "Meas Setup" menu, select "Select Measurement". Select the required measurement.
- [Code Domain Analysis](#).....46
- [Time Alignment Error Measurements](#)..... 83

## 5.1 Code Domain Analysis

3GPP FDD measurements require a special application on the R&S VSE.



**General R&S VSE functions**

The application-independent functions for general tasks on the R&S VSE are also available for 3GPP FDD measurements and are described in the R&S VSE Base Software User Manual. In particular, this comprises the following functionality:

- Controlling Instruments and Capturing I/Q Data
- Data Management
- General Software Preferences and Information


- [Configuration Overview](#).....47
- [Signal Description](#).....48
- [Data Input and Output Settings](#).....53
- [Frontend Settings](#).....59
- [Trigger Settings](#).....65
- [Signal Capture \(Data Acquisition\)](#).....68
- [Synchronization \(BTS Measurements Only\)](#).....70
- [Channel Detection](#).....71
- [Automatic Settings](#).....80
- [Zoom Functions](#).....82

**5.1.1 Configuration Overview**



**Access:** "Meas Setup" > "Overview"

Throughout the measurement configuration, an overview of the most important currently defined settings is provided in the "Overview".



**Fig. 5-1: Configuration "Overview" for CDA measurements**

In addition to the main measurement settings, the "Overview" provides quick access to the main settings dialog boxes. Thus, you can easily configure an entire measurement channel from input over processing to evaluation by stepping through the dialog boxes as indicated in the "Overview".



The available settings and functions in the "Overview" vary depending on the currently selected measurement.

For Time Alignment Error Measurements see [chapter 5.2.1, "Configuration Overview"](#), on page 83.

### To configure settings

- ▶ Select any button in the "Overview" to open the corresponding dialog box. Select a setting in the channel bar (at the top of the measurement channel tab) to change a specific setting.

|  |    |
|--|----|
| <a href="#">Preset Channel</a> .....     | 48 |
| <a href="#">Select Measurement</a> ..... | 48 |
| <a href="#">Specifics for</a> .....      | 48 |

#### Preset Channel

Select the "Preset Channel" button in the lower lefthand corner of the "Overview" to restore all measurement settings **in the current channel** to their default values.

Remote command:

`SYSTem:PRESet:CHANnel[:EXECute]` on page 119

#### Select Measurement

Selects a different measurement to be performed.

See [chapter 3, "Measurements and Result Display"](#), on page 11.

#### Specifics for

The measurement channel may contain several windows for different results. Thus, the settings indicated in the "Overview" and configured in the dialog boxes vary depending on the selected window.

Select an active window from the "Specifics for" selection list that is displayed in the "Overview" and in all window-specific configuration dialog boxes.

The "Overview" and dialog boxes are updated to indicate the settings for the selected window.

## 5.1.2 Signal Description

**Access:** "Overview" > "Signal Description"

**or:** "Meas Setup" > "Signal Description"

The signal description provides information on the expected input signal.




- [BTS Signal Description](#)..... 49
- [BTS Scrambling Code](#).....50
- [UE Signal Description \(UE Measurements\)](#)..... 52

### 5.1.2.1 BTS Signal Description

**Access:** "Overview" > "Signal Description"

or: "Meas Setup" > "Signal Description"

The settings available to describe the input signal in BTS measurements are described here.



- [HSDPA/UPA](#)..... 49
- [Compressed Mode](#).....50
- [MIMO](#)..... 50
- [Antenna Diversity](#)..... 50
- [Antenna Number](#)..... 50

#### HSDPA/UPA

If enabled, the application detects all QPSK-modulated channels without pilot symbols (HSDPA channels) and displays them in the channel table. If the type of a channel can be fully recognized, as for example with a HS-PDSCH (based on modulation type), the type is indicated in the table. All other channels without pilot symbols are of type "CHAN".

Remote command:

[SENSe:]CDPower:HSDPamode on page 120

**Compressed Mode**

If compressed mode is switched on, some slots of a channel are suppressed. To keep the overall data rate, the slots just before or just behind a compressed gap can be sent with half spreading factor (SF/2). This mode must be enabled to detect compressed mode channels (see [chapter 4.2, "BTS Channel Types"](#), on page 35).

Remote command:

[\[SENSe:\]CDPower:PCONtrol](#) on page 122

**MIMO**

Activates or deactivates single antenna MIMO measurement mode.

If activated, HS-PDSCH channels with exclusively QPSK or exclusively 16 QAM on both transport streams are automatically detected and demodulated. The corresponding channel types are denoted as "HS-MIMO-QPSK" and "HS-MIMO-16QAM", respectively.

For details see ["MIMO channel types"](#) on page 38.

Remote command:

[\[SENSe:\]CDPower:MIMO](#) on page 122

**Antenna Diversity**

This option switches the antenna diversity mode on and off.

Remote command:

[\[SENSe:\]CDPower:ANTenna](#) on page 120

**Antenna Number**

This option switches between diversity antennas 1 and 2. Depending on the selected setting, the 3GPP FDD application synchronizes to the CPICH of antenna 1 or antenna 2.

Remote command:


[\[SENSe:\]CDPower:ANTenna](#) on page 120

**5.1.2.2 BTS Scrambling Code**

**Access:** "Overview" > "Signal Description" > "Scrambling Code" tab

**or:** "Meas Setup" > "Signal Description" > "Scrambling Code" tab

The scrambling code identifies the base station transmitting the signal. You can either define the used scrambling code manually, or perform a search on the input signal to detect a list of possible scrambling codes automatically.



Scrambling Code.....51  
 Format Hex/Dec..... 51  
 Scrambling Codes..... 51  
 Autosearch for Scrambling Code..... 51  
 Export.....52

**Scrambling Code**

Defines the scrambling code. The scrambling codes are used to distinguish between different base stations. Each base station has its own scrambling code.

Remote command:

[SENSe:]CDPower:LCODE:DVALue on page 123

**Format Hex/Dec**

Switch the display format of the scrambling codes between hexadecimal and decimal.

Remote command:

[SENSe:]CDPower:LCODE:DVALue on page 123  
 [SENSe:]CDPower:LCODE[:VALue] on page 123

**Scrambling Codes**

This table includes all found scrambling codes from the last autosearch sequence. In the first column each detected scrambling code can be selected for export.

Remote command:

[SENSe:]CDPower:LCODE:SEARCh:LIST? on page 121

**Autosearch for Scrambling Code**

Starts a search on the measured signal for all scrambling codes. The scrambling code that leads to the highest signal power is chosen as the new scrambling code.

Searching requires that the correct center frequency and level are set. The scrambling code search can automatically determine the primary scrambling code number. The secondary scrambling code number is expected as 0. Alternative scrambling codes can not be detected. Therefore the range for detection is 0x0000 – 0x1FF0h, where the last digit is always 0.

Remote command:

[SENSe:]CDPower:LCODE:SEARCh[:IMMediate]? on page 121


**Export**

Writes the detected scrambling codes together with their powers into a text file in the R&S user directory (C:\R\_S\Instr\User\ScrCodes.txt)

**5.1.2.3 UE Signal Description (UE Measurements)**

**Access:** "Overview" > "Signal Description" > "Signal Description"

The settings available to describe the input signal in UE measurements are described here.



Scrambling Code.....52  
 Format.....53  
 Type.....53  
 HSDPA/UPA.....53  
 QPSK Modulation Only.....53

**Scrambling Code**

Defines the scrambling code used to transmit the signal in the specified format.

The scrambling code identifies the user equipment transmitting the signal. If an incorrect scrambling code is defined, a CDP measurement of the signal is not possible.

Remote command:

[SENSe:]CDPower:LCODE[:VALue] on page 123

**Format**

Switches the display format of the scrambling codes between hexadecimal and decimal.

Remote command:

SENS:CDP:LCOD:DVAL <numeric value> (see [SENSe:]CDPower:LCODE:DVALue on page 123)

**Type**

Defines whether the entered scrambling code is to be handled as a long or short scrambling code.

Remote command:

[SENSe:]CDPower:LCODE:TYPE on page 124

**HSDPA/UPA**

If enabled, the application detects all QPSK-modulated channels without pilot symbols (HSDPA channels) and displays them in the channel table. If the type of a channel can be fully recognized, as for example with a HS-PDSCH (based on modulation type), the type is indicated in the table. All other channels without pilot symbols are of type "CHAN".

Remote command:

[SENSe:]CDPower:HSDPamode on page 120

**QPSK Modulation Only**

If enabled, it is assumed that the signal uses QPSK modulation only. Thus, a special QPSK-based synchronization can be performed and the measurement therefore runs with optimized speed.

Do not enable this mode for signals that do not use QPSK modulation.

Remote command:

[SENSe:]CDPower:QPSK on page 124

**5.1.3 Data Input and Output Settings**

**Access:** "Overview" > "Input/Frontend"

**or:** "Input & Output"

The R&S VSE can analyze signals from different input sources and provide various types of output (such as noise or trigger signals).

- [Input Source Settings](#).....53
- [Output Settings](#)..... 57

**5.1.3.1 Input Source Settings**

**Access:** "Overview" > "Input/Frontend" > "Input Source"

**or:** "Input & Output" > "Input Source"

The R&S VSE can control the input sources of the connected instruments.


- [Radio Frequency Input](#).....54
- [I/Q File Input](#).....56

**Radio Frequency Input**

**Access:** "Overview" > "Input/Frontend" > "Input Source" > "Radio Frequency"

**or:** "Input & Output" > "Input Source" > "IQ File"

The default input source for the instrument in use is "Radio Frequency". Depending on the instrument in use, different input parameters are available.



*Fig. 5-2: RF input source settings for an R&S FSW*

[Input Type](#)..... 54

[Instrument](#)..... 54

[Input Coupling](#)..... 54

[Impedance](#)..... 55

[High-Pass Filter 1...3 GHz](#)..... 55

[YIG-Preselector](#)..... 55

[Preselector State](#)..... 55

[Preselector Mode](#)..... 56

[10 dB Minimum Attenuation](#)..... 56

[Input Selection](#)..... 56

**Input Type**

Selects an instrument or a file as the type of input provided to the channel.

Remote command:

[INSTRument:BLOCK:CHANnel\[:SETTings\]:SOURce](#) on page 128

[INPut:SElect](#) on page 127

**Instrument**

Specifies a configured instrument to be used for input.

**Input Coupling**

The RF input of the instrument in use can be coupled by alternating current (AC) or direct current (DC).

AC coupling blocks any DC voltage from the input signal. This is the default setting to prevent damage to the instrument. Very low frequencies in the input signal may be distorted.

However, some specifications require DC coupling. In this case, you must protect the instrument from damaging DC input voltages manually. For details, refer to the data sheet.

Remote command:

`INPut:COUPling` on page 125

### Impedance

For some measurements, the reference impedance for the measured levels of the instrument in use can be set to 50  $\Omega$  or 75  $\Omega$ .

75  $\Omega$  should be selected if the 50  $\Omega$  input impedance is transformed to a higher impedance using a 75  $\Omega$  adapter of the RAZ type (= 25  $\Omega$  in series to the input impedance of the instrument). The correction value in this case is 1.76 dB = 10 log (75 $\Omega$ /50 $\Omega$ ).

Remote command:

`INPut:IMPedance` on page 126

### High-Pass Filter 1...3 GHz

Activates an additional internal high-pass filter for RF input signals from 1 GHz to 3 GHz. This filter is used to remove the harmonics of the analyzer in order to measure the harmonics for a DUT, for example.

This function may require an additional hardware option on the instrument in use.

Remote command:

`INPut:FILTer:HPASs[:STATe]` on page 126

### YIG-Preselector

Activates or deactivates the YIG-preselector, if available on the instrument in use.

An internal YIG-preselector at the input of the instrument in use ensures that image frequencies are rejected. However, this is only possible for a restricted bandwidth. In order to use the maximum bandwidth for signal analysis you can deactivate the YIG-preselector at the input of the instrument in use, which may lead to image-frequency display.

Remote command:

`INPut:FILTer:YIG[:STATe]` on page 126

### Preselector State

Turns the preselector on and off.

When you turn the preselector on, you can configure the characteristics of the preselector and add the preamplifier into the signal path.

When you turn the preselector off, the signal bypasses the preselector and the preamplifier, and is fed into the input mixer directly.

Remote command:

`INPut:PRESelection[:STATe]` on page 127

**Preselector Mode**

Selects the preselection filters to be applied to the measurement.

|               |  |
|---------------|--|
| "Auto"        | Performs a measurement by automatically applying all available bandpass filters.<br>Available with the optional preamplifier.  |
| "Auto Wide"   | Performs a measurement by automatically applying the wideband filters consecutively: <ul style="list-style-type: none"> <li>• Lowpass 40 MHz</li> <li>• Bandpass 30 MHz to 2250 MHz</li> <li>• Bandpass 2 GHz to 8 GHz</li> <li>• Bandpass 8 GHz to 26.5 GHz</li> </ul> Available with the optional preselector.   |
| "Auto Narrow" | Performs a measurement by automatically applying the most suitable narrowband preselection filters, depending on the bandwidth you have selected.<br>For measurement frequencies up to 30 MHz, the instrument in use uses combinations of lowpass and highpass filters. For higher frequencies, the instrument in use uses bandpass filters.<br>Available with the optional preselector. |
| "Manual"      | Performs a measurement with the filter settings you have defined manually.   |

Remote command:

[INPut:PRESelection:SET](#) on page 127

**10 dB Minimum Attenuation**

Turns the availability of attenuation levels of less than 10 dB on and off.

When you turn the feature on, the attenuation level is always at least 10 dB to protect the input mixer and avoid accidental setting of 0 dB, especially if you measure DUTs with high RFI voltage.

When you turn it off, you can also select attenuation levels of less than 10 dB.

The setting applies to a manual selection of the attenuation as well as the automatic selection of the attenuation.

Remote command:

[INPut:ATTenuation:PROTection\[:STATe\]](#) on page 125

**Input Selection**

Selects the RF input you would like to use for a measurement.

Note that you can not use both RF inputs simultaneously.

Remote command:

Global: [INPut:TYPE](#) on page 127

**I/Q File Input**

**Access:** "Overview" > "Input/Frontend" > "Input Source" > "IQ File"


or: "Input & Output" > "Input Source" > "IQ File"



Alternatively to "live" data input from a connected instrument, measurement data to be analyzed by the R&S VSE software can also be provided "offline" by a stored data file. This allows you to perform a measurement on any instrument, store the results to a file, and analyze the stored data partially or as a whole at any time using the R&S VSE software.



The "Input Source" settings defined in the "Input" dialog box are identical to those configured for a specific channel in the "Measurement Group Setup" window.



[Input Type](#)..... 57  
[Input File](#)..... 57

**Input Type**

Selects an instrument or a file as the type of input provided to the channel.

Remote command:

[INSTrument:BLOCK:CHANnel\[:SETTings\]:SOURce](#) on page 128

[INPut:SElect](#) on page 127

**Input File**

Specifies the I/Q data file to be used for input.

Select "Select File" to open the "Load I/Q File" dialog box.

**5.1.3.2 Output Settings**


**Access:** "Overview" > "Input/ Frontend" > "Output"

**or:** "Input & Output" > "Output"

The R&S VSE can control the output provided by the instrument in use to special connectors for other devices.

Which output settings and connectors are available depends on the instrument in use.

For details on the output connectors refer to the instrument's Getting Started manual.



Noise Source.....58

Trigger 2/3.....58

    L Output Type.....58

        L Level.....59

        L Pulse Length.....59

        L Send Trigger.....59

**Noise Source**

Switches the supply voltage for an external noise source on the instrument in use on or off, if available.

External noise sources are useful when you are measuring power levels that fall below the noise floor of the instrument in use itself, for example when measuring the noise level of a DUT.

Remote command:

[DIAGnostic:SERvice:NSource](#) on page 128

**Trigger 2/3**

Defines the usage of variable trigger input/output connectors on the instrument in use. Which output settings are available depends on the type of instrument in use. For details see the instrument's documentation.

"Input"           The signal at the connector is used as an external trigger source by the instrument in use. Trigger input parameters are available in the "Trigger" dialog box.

"Output"           The instrument in use sends a trigger signal to the output connector to be used by connected devices. Further trigger parameters are available for the connector.

Remote command:

[OUTPut:TRIGger<port>:LEVel](#) on page 140

[OUTPut:TRIGger<port>:DIRection](#) on page 140

**Output Type ← Trigger 2/3**

Type of signal to be sent to the output

"Device Trig-   (Default) Sends a trigger when the instrument in use triggers.  
gered"

- "Trigger Armed" Sends a (high level) trigger when the instrument in use is in "Ready for trigger" state.  
This state is indicated by a status bit in the `STATUS:OPERation` register (bit 5), as well as by a low level signal at the AUX port (pin 9) of the instrument in use, if available.
- "User Defined" Sends a trigger when user selects "Send Trigger" button.  
In this case, further parameters are available for the output signal.

Remote command:

`OUTPut:TRIGger<port>:OTYPe` on page 140

#### **Level ← Output Type ← Trigger 2/3**

Defines whether a constant high (1) or low (0) signal is sent to the output connector.

Remote command:

`OUTPut:TRIGger<port>:LEVel` on page 140

#### **Pulse Length ← Output Type ← Trigger 2/3**

Defines the length of the pulse sent as a trigger to the output connector.

Remote command:

`OUTPut:TRIGger<port>:PULSe:LENGth` on page 141

#### **Send Trigger ← Output Type ← Trigger 2/3**

Sends a user-defined trigger to the output connector immediately. Note that the trigger pulse level is always opposite to the constant signal level defined by the output "Level" setting, e.g. for "Level = High", a constant high signal is output to the connector until the "Send Trigger" button is selected. Then, a low pulse is sent.

Which pulse level will be sent is indicated by a graphic on the button.

Remote command:

`OUTPut:TRIGger<port>:PULSe:IMMediate` on page 141

## 5.1.4 Frontend Settings

**Access:** "Overview" > "Input/Frontend"

Frequency, amplitude and y-axis scaling settings represent the "frontend" of the measurement setup.

- [Amplitude Settings](#)..... 59
- [Y-Axis Scaling](#)..... 62
- [Frequency Settings](#)..... 63


### 5.1.4.1 Amplitude Settings

**Access:** "Overview" > "Input/Frontend" > "Amplitude"

or: "Input & Output" > "Amplitude"

Amplitude settings determine how the instrument in use must process or display the expected input power levels.

Which amplitude settings are available depends on the instrument in use.



Reference Level..... 60

- └ Shifting the Display (Offset)..... 60
- └ Unit..... 61
- └ Setting the Reference Level Automatically (Auto Level)..... 61

RF Attenuation..... 61

- └ Attenuation Mode / Value..... 61

Using Electronic Attenuation..... 61

Input Settings..... 62

- └ Preamplicifier..... 62

**Reference Level**

Defines the expected maximum reference level. Signal levels above this value may not be measured correctly, which is indicated by the "IF OVLD" status display ("OVLD" for analog baseband or digital baseband input).

The reference level is also used to scale power diagrams; the reference level is then used as the maximum on the y-axis.

Since the hardware of the instrument in use is adapted according to this value, it is recommended that you set the reference level close above the expected maximum signal level to ensure an optimum measurement (no compression, good signal-to-noise ratio).

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALE]:RLEVEL` on page 132

**Shifting the Display (Offset) ← Reference Level**

Defines an arithmetic level offset. This offset is added to the measured level. In some result displays, the scaling of the y-axis is changed accordingly.

Define an offset if the signal is attenuated or amplified before it is fed into the R&S VSE so the application shows correct power results. All displayed power level results will be shifted by this value.

The setting range is  $\pm 200$  dB in 0.01 dB steps.

Note, however, that the *internal* reference level (used to adjust the hardware settings to the expected signal optimally) ignores any "Reference Level Offset". Thus, it is important to keep in mind the actual power level the R&S VSE must handle, and not to rely on the displayed reference level (internal reference level = displayed reference level - offset).

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet` on page 132

#### **Unit ← Reference Level**

For CDA measurements the unit should not be changed, as this would lead to useless results.

#### **Setting the Reference Level Automatically (Auto Level) ← Reference Level**

The instrument in use automatically determines the optimal reference level for the current input data. At the same time, the internal attenuators and the preamplifier are adjusted so the signal-to-noise ratio is optimized, while signal compression, clipping and overload conditions are minimized. This function is not available on all supported instruments.

Remote command:

`[SENSe:]ADJust:LEVel` on page 161

#### **RF Attenuation**

Defines the attenuation applied to the RF input of the R&S VSE.

#### **Attenuation Mode / Value ← RF Attenuation**

The RF attenuation can be set automatically as a function of the selected reference level (Auto mode). This ensures that no overload occurs at the RF INPUT connector for the current reference level. It is the default setting.

In "Manual" mode, you can set the RF attenuation in 1 dB steps (down to 0 dB). Other entries are rounded to the next integer value. The range is specified in the data sheet. If the defined reference level cannot be set for the defined RF attenuation, the reference level is adjusted accordingly and the warning "Limit reached" is displayed.

**NOTICE!** Risk of hardware damage due to high power levels. When decreasing the attenuation manually, ensure that the power level does not exceed the maximum level allowed at the RF input, as an overload may lead to hardware damage.

Remote command:

`INPut:ATTenuation` on page 133

`INPut:ATTenuation:AUTO` on page 134

#### **Using Electronic Attenuation**

If the (optional) Electronic Attenuation hardware is installed on the instrument in use, you can also activate an electronic attenuator.

In "Auto" mode, the settings are defined automatically; in "Manual" mode, you can define the mechanical and electronic attenuation separately.

**Note:** Note that restrictions may apply concerning which frequencies electronic attenuation is available for, depending on which instrument is connected to the R&S VSE software. Check your instrument documentation for details.

In "Auto" mode, RF attenuation is provided by the electronic attenuator as much as possible to reduce the amount of mechanical switching required. Mechanical attenuation may provide a better signal-to-noise ratio, however.

When you switch off electronic attenuation, the RF attenuation is automatically set to the same mode (auto/manual) as the electronic attenuation was set to. Thus, the RF attenuation may be set to automatic mode, and the full attenuation is provided by the mechanical attenuator, if possible.

If the defined reference level cannot be set for the given attenuation, the reference level is adjusted accordingly and the warning "Limit reached" is displayed in the status bar.

Remote command:

[INPut:EATT:STATe](#) on page 135

[INPut:EATT:AUTO](#) on page 134

[INPut:EATT](#) on page 134

### Input Settings

Some input settings affect the measured amplitude of the signal, as well.

The parameters "Input Coupling" and "Impedance" are identical to those in the "Input" settings.

See ["Radio Frequency Input"](#) on page 54.

### Preamplifier ← Input Settings

If the (optional) Preamplifier hardware is installed on the instrument in use, a preamplifier can be activated for the RF input signal.

You can use a preamplifier to analyze signals from DUTs with low input power.

Depending on the connected instrument, different settings are available. See the instrument's documentation for details.

Remote command:

[INPut:GAIN:STATe](#) on page 132


[INPut:GAIN\[:VALue\]](#) on page 133

#### 5.1.4.2 Y-Axis Scaling

**Access:** "Overview" > "Input/Frontend" > "Scale"

**or:** "Input & Output" > "Scale"

The vertical axis scaling is configurable. In Code Domain Analysis, the y-axis usually displays the measured power levels.



Y-Maximum, Y-Minimum..... 63  
 Auto Scale Once..... 63  
 Restore Scale (Window)..... 63

**Y-Maximum, Y-Minimum**

Defines the amplitude range to be displayed on the y-axis of the evaluation diagrams.

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MAXimum` on page 131

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MINimum` on page 131

**Auto Scale Once**

Automatically determines the optimal range and reference level position to be displayed for the current measurement settings.

The display is only set once; it is not adapted further if the measurement settings are changed again.

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO ONCE` on page 131


**Restore Scale (Window)**

Restores the default scale settings in the currently selected window.

**5.1.4.3 Frequency Settings**

**Access:** "Overview" > "Input/Frontend" > "Frequency"

**or:** "Input & Output" > "Frequency"



Center frequency.....64  
 Center Frequency Stepsize.....64  
 Frequency Offset.....65

**Center frequency**

Defines the center frequency of the signal in Hertz.

$$0 \text{ Hz} \leq f_{\text{center}} \leq f_{\text{max}}$$

$f_{\text{max}}$  and  $\text{span}_{\text{min}}$  depend on the instrument and are specified in the data sheet.

**Note:** For file input you can shift the center frequency of the current measurement compared to the stored measurement data. The maximum shift depends on the channel's current analysis bandwidth.

$$CF_{\text{shift}_{\text{max}}} = CF_{\text{file}} \pm \frac{ABW_{\text{file}} - ABW_{\text{channel}}}{2}$$

If the file does not provide the center frequency, it is assumed to be 0 Hz.

Remote command:

[SENSe:] FREQuency:CENTer on page 129

**Center Frequency Stepsize**

Defines the step size by which the center frequency is increased or decreased using the arrow keys.

When you use the mouse wheel, the center frequency changes in steps of only 1/10 of the "Center Frequency Stepsize".

The step size can be coupled to another value or it can be manually set to a fixed value.

This setting is available for frequency and time domain measurements.

- "X \* Span"      Sets the step size for the center frequency to a defined factor of the span. The "X-Factor" defines the percentage of the span. Values between 1 and 100 % in steps of 1 % are allowed. The default setting is 10 %.
- "= Center"      Sets the step size to the value of the center frequency. The used value is indicated in the "Value" field.



"Manual" Defines a fixed step size for the center frequency. Enter the step size in the "Value" field.

Remote command:

[SENSe:] FREQuency:CENTer:STEP on page 129

### Frequency Offset

Shifts the displayed frequency range along the x-axis by the defined offset.

This parameter has no effect on the instrument's hardware, or on the captured data or on data processing. It is simply a manipulation of the final results in which absolute frequency values are displayed. Thus, the x-axis of a spectrum display is shifted by a constant offset if it shows absolute frequencies, but not if it shows frequencies relative to the signal's center frequency.

A frequency offset can be used to correct the display of a signal that is slightly distorted by the measurement setup, for example.

The allowed values range from -100 GHz to 100 GHz. The default setting is 0 Hz.

Remote command:


[SENSe:] FREQuency:OFFSet on page 130

## 5.1.5 Trigger Settings


**Access:** "Overview" > "Signal Capture" > "Trigger Source"

or: INPUT & OUTPUT > "Trigger"

Trigger settings determine when the input signal is measured.



External triggers from one of the TRIGGER INPUT/OUTPUT connectors on the R&S VSE are configured in a separate tab of the dialog box.



|                            |    |
|----------------------------|----|
| Trigger Settings.....      | 66 |
| L Trigger Source.....      | 66 |
| L Free Run.....            | 66 |
| L External Trigger<X>..... | 66 |
| L Trigger Level.....       | 66 |
| L Trigger Offset.....      | 66 |
| L Slope.....               | 67 |
| Trigger 2/3.....           | 67 |
| L Output Type.....         | 67 |
| L Level.....               | 67 |
| L Pulse Length.....        | 68 |
| L Send Trigger.....        | 68 |

### Trigger Settings

The trigger settings define the beginning of a measurement.

#### Trigger Source ← Trigger Settings

Defines the trigger source. If a trigger source other than "Free Run" is set, "TRG" is displayed in the channel bar and the trigger source is indicated.

Remote command:

`TRIGger [:SEquence] :SOURce` on page 138

#### Free Run ← Trigger Source ← Trigger Settings

No trigger source is considered. Data acquisition is started manually or automatically and continues until stopped explicitly.

Remote command:

`TRIG:SOUR IMM`, see `TRIGger [:SEquence] :SOURce` on page 138

#### External Trigger<X> ← Trigger Source ← Trigger Settings

Data acquisition starts when the signal fed into the specified input connector or input channel of the instrument in use meets or exceeds the specified trigger level.

(See "Trigger Level" on page 66).

**Note:** Which input and output connectors are available depends on the connected instrument. For details see the "Instrument Tour" chapter in the instrument's Getting Started manual.

Remote command:

`TRIG:SOUR EXT`, `TRIG:SOUR EXT2`, `TRIG:SOUR EXT3`, `TRIG:SOUR EXT4`

See `TRIGger [:SEquence] :SOURce` on page 138

#### Trigger Level ← Trigger Settings

Defines the trigger level for the specified trigger source.

For details on supported trigger levels, see the data sheet.

Remote command:

`TRIGger [:SEquence] :LEVel [:EXTernal<port>]` on page 137

#### Trigger Offset ← Trigger Settings

Defines the time offset between the trigger event and the start of the measurement.

|             |  |
|-------------|--|
| offset > 0: | Start of the measurement is delayed      |
| offset < 0: | Measurement starts earlier (pre-trigger) |

(If supported by the instrument in use.)

Remote command:

[TRIGger\[:SEquence\]:HOLDoff\[:TIME\]](#) on page 136

### Slope ← Trigger Settings

For all trigger sources except time you can define whether triggering occurs when the signal rises to the trigger level or falls down to it.

Remote command:

[TRIGger\[:SEquence\]:SLOPe](#) on page 138

### Trigger 2/3

Defines the usage of variable trigger input/output connectors on the instrument in use. Which output settings are available depends on the type of instrument in use. For details see the instrument's documentation.

"Input"            The signal at the connector is used as an external trigger source by the instrument in use. Trigger input parameters are available in the "Trigger" dialog box.

"Output"           The instrument in use sends a trigger signal to the output connector to be used by connected devices. Further trigger parameters are available for the connector.

Remote command:

[OUTPut:TRIGger<port>:LEVel](#) on page 140

[OUTPut:TRIGger<port>:DIRection](#) on page 140

### Output Type ← Trigger 2/3

Type of signal to be sent to the output

"Device Trig-  
gered"            (Default) Sends a trigger when the instrument in use triggers.

"Trigger  
Armed"            Sends a (high level) trigger when the instrument in use is in "Ready for trigger" state.  
This state is indicated by a status bit in the `STATUS:OPERation` register (bit 5), as well as by a low level signal at the AUX port (pin 9) of the instrument in use, if available.

"User Defined"   Sends a trigger when user selects "Send Trigger" button.  
In this case, further parameters are available for the output signal.

Remote command:

[OUTPut:TRIGger<port>:OTYPe](#) on page 140

### Level ← Output Type ← Trigger 2/3

Defines whether a constant high (1) or low (0) signal is sent to the output connector.

Remote command:

[OUTPut:TRIGger<port>:LEVel](#) on page 140

**Pulse Length ← Output Type ← Trigger 2/3**

Defines the length of the pulse sent as a trigger to the output connector.

Remote command:

`OUTPut:TRIGger<port>:PULSe:LENGth` on page 141

**Send Trigger ← Output Type ← Trigger 2/3**

Sends a user-defined trigger to the output connector immediately. Note that the trigger pulse level is always opposite to the constant signal level defined by the output "Level" setting, e.g. for "Level = High", a constant high signal is output to the connector until the "Send Trigger" button is selected. Then, a low pulse is sent.

Which pulse level will be sent is indicated by a graphic on the button.

Remote command:


`OUTPut:TRIGger<port>:PULSe:IMMediate` on page 141

**5.1.6 Signal Capture (Data Acquisition)**

**Access:** "Overview" > "Signal Capture"

**or:** "Meas Setup" > "Capture"

How much and how data is captured from the input signal are defined in the "Signal Capture" settings.



Sample Rate..... 69

Invert Q..... 69

RRC Filter State..... 69

Capture Mode..... 69

Capture Length (Frames)..... 69

Frame To Analyze..... 69

Capture Time..... 69

Capture / Average Count..... 69

**Sample Rate**

The sample rate is always 16 MHz (indicated for reference only).

**Invert Q**

Inverts the sign of the signal's Q-branch. The default setting is OFF.

Remote command:

[\[SENSe:\]CDPower:QINVert](#) on page 143

**RRC Filter State**

Selects if a root raised cosine (RRC) receiver filter is used or not. This feature is useful if the RRC filter is implemented in the device under test (DUT).

|       |   |
|-------|---|
| "ON"  | If an unfiltered signal is received (normal case), the RRC filter should be used to get a correct signal demodulation. (Default settings)                 |
| "OFF" | If a filtered signal is received, the RRC filter should not be used to get a correct signal demodulation. This is the case if the DUT filters the signal. |

Remote command:

[\[SENSe:\]CDPower:FILTer\[:STATe\]](#) on page 142

**Capture Mode**

Captures a single slot or one complete frame.

Remote command:

[\[SENSe:\]CDPower:BASE](#) on page 142

**Capture Length (Frames)**

Defines the capture length (amount of frames to record).

Remote command:

[\[SENSe:\]CDPower:IQLength](#) on page 142

**Frame To Analyze**

Defines the frame to be analyzed and displayed.

Remote command:

[\[SENSe:\]CDPower:FRAMe\[:VALue\]](#) on page 161

**Capture Time**

This setting is read-only.

It indicates the capture time determined by the capture length and sample rate.

**Capture / Average Count**

Defines the number of captures to be performed in the single capture mode. Values from 0 to 32767 are allowed. If the values 0 or 1 are set, one capture is performed.

The "Capture / Average Count" is available from the "Meas Setup" menu.

The "Capture / Average Count" is applied to all the traces in all diagrams.

If the trace modes "Average", "Max Hold" or "Min Hold" are set, this value also determines the number of averaging or maximum search procedures.

In continuous capture mode, if "Capture / Average Count" = 0 (default), averaging is performed over 10 captures. For "Capture / Average Count" =1, no averaging, maxhold or minhold operations are performed.

Remote command:

[SENSe:] SWEp:COUNT on page 143


[SENSe:] AVERage<n>:COUNT on page 143

### 5.1.7 Synchronization (BTS Measurements Only)

**Access:** "Overview" > "Synchronization" > "Antenna1"/"Antenna2"

**or:** "Meas Setup" > "Sync"

For BTS tests, the individual channels in the input signal need to be synchronized to detect timing offsets in the slot spacings. These settings are described here.



|                              |    |
|------------------------------|----|
| Synchronization Type.....    | 70 |
| Antenna1 / Antenna2.....     | 71 |
| L CPICH Mode.....            | 71 |
| L S-CPICH Code Nr.....       | 71 |
| S-CPICH Antenna Pattern..... | 71 |

#### Synchronization Type

Defines whether the signal is synchronized to the CPICH or the synchronization channel (SCH).

- "CPICH"           The 3GPP FDD application assumes that the CPICH control channel is present in the signal and attempts to synchronize to this channel. If the signal does not contain CPICH, synchronization fails.
- "SCH"             The 3GPP FDD application synchronizes to the signal without assuming the presence of a CPICH. This setting is required for measurements on test model 4 without CPICH. While this setting can also be used with other channel configurations, it should be noted that the probability of synchronization failure increases with the number of data channels.

Remote command:

[SENSe:] CDPower:STYPe on page 145

**Antenna1 / Antenna2**

Synchronization is configured for each diversity antenna individually, on separate tabs. The 3GPP FDD standard defines two different CPICH patterns for diversity antenna 1 and antenna 2. The CPICH pattern used for synchronization can be defined depending on the antenna (standard configuration), or fixed to either pattern, independently of the antenna (user-defined configuration).

Remote command:

[\[SENSe:\]CDPower:ANTenna](#) on page 120

**CPICH Mode ← Antenna1 / Antenna2**

Defines whether the common pilot channel (CPICH) is defined by its default position or a user-defined position.

"P-CPICH" Standard configuration (CPICH is always on channel 0)

"S-CPICH" User-defined configuration. Enter the CPICH code number in the [S-CPICH Code Nr](#) field.

Remote command:

[\[SENSe:\]CDPower:UCPich:ANT<antenna>\[:STATe\]](#) on page 145

**S-CPICH Code Nr ← Antenna1 / Antenna2**

If a user-defined CPICH definition is to be used, enter the code of the CPICH based on the spreading factor 256. Possible values are 0 to 255.

Remote command:

[\[SENSe:\]CDPower:UCPich:ANT<antenna>:CODE](#) on page 144

**S-CPICH Antenna Pattern**

Defines the pattern used for evaluation.

Remote command:

[\[SENSe:\]CDPower:UCPich:ANT<antenna>:PATTern](#) on page 144

**5.1.8 Channel Detection**

**Access:** "Overview" > "Channel Detection"

**or:** "Meas Setup" > "Channel Detection"


The channel detection settings determine which channels are found in the input signal.

- [General Channel Detection Settings](#).....71
- [Channel Table Management](#).....73
- [Channel Table Settings and Functions](#).....74
- [Channel Details \(BTS Measurements\)](#).....76
- [Channel Details \(UE Measurements\)](#).....78

**5.1.8.1 General Channel Detection Settings**

**Access:** "Overview" > "Channel Detection"

**or:** "Meas Setup" > "Channel Detection"



Inactive Channel Threshold (BTS measurements only).....72  
 Using Predefined Channel Tables..... 72  
 Comparing the Measurement Signal with the Predefined Channel Table..... 73  
 Timing Offset Reference..... 73

**Inactive Channel Threshold (BTS measurements only)**

Defines the minimum power that a single channel must have compared to the total signal in order to be recognized as an active channel.

Remote command:

[SENSe:]CDPower:ICTReshold on page 149

**Using Predefined Channel Tables**

Defines the channel search mode.

"Predefined"      Compares the input signal to the predefined channel table selected in the "Predefined Tables" list



"Auto" Detects channels automatically using pilot sequences

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE\[:STATe\]](#) on page 149

UE measurements:

[CONFigure:WCDPower:MS:CTABLE\[:STATe\]](#) on page 151

### Comparing the Measurement Signal with the Predefined Channel Table

If enabled, the 3GPP FDD application compares the measured signal to the predefined channel tables. In the result summary, only the differences to the predefined table settings are displayed.

Remote command:

[CONFigure:WCDPower\[:BTS\]:CTABLE:COMPare](#) on page 147

### Timing Offset Reference

Defines the reference for the timing offset of the displayed measured signal.

"Relative to CPICH" The measured timing offset is shown in relation to the CPICH.

"Relative to Predefined Table" If the predefined table contains timing offsets, the delta between the defined and measured offsets are displayed in the evaluations.

Remote command:

[CONFigure:WCDPower\[:BTS\]:CTABLE:TOFFset](#) on page 148

## 5.1.8.2 Channel Table Management

**Access:** "Overview" > "Channel Detection"

|  |    |
|--|----|
| <a href="#">Predefined Tables</a> .....        | 73 |
| <a href="#">Selecting a Table</a> .....        | 74 |
| <a href="#">Creating a New Table</a> .....     | 74 |
| <a href="#">Editing a Table</a> .....          | 74 |
| <a href="#">Copying a Table</a> .....          | 74 |
| <a href="#">Deleting a Table</a> .....         | 74 |
| <a href="#">Restoring Default Tables</a> ..... | 74 |

### Predefined Tables

The list shows all available channel tables and marks the currently used table with a checkmark. The currently *focussed* table is highlighted blue.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:CATalog?](#) on page 149

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:CATalog?](#) on page 152

**Selecting a Table**

Selects the channel table currently focussed in the "Predefined Tables" list and compares it to the measured signal to detect channels.

Remote command:

BTS measurements:

`CONFigure:WCDPower[:BTS]:CTABLE:SElect` on page 151

UE measurements:

`CONFigure:WCDPower:MS:CTABLE:SElect` on page 153

**Creating a New Table**

Creates a new channel table. See [chapter 5.1.8.4, "Channel Details \(BTS Measurements\)"](#), on page 76.

For step-by-step instructions on creating a new channel table, see ["To define or edit a channel table"](#) on page 98.

**Editing a Table**

You can edit existing channel table definitions. The details of the selected channel are displayed in the "Channel Table" dialog box. See [chapter 5.1.8.4, "Channel Details \(BTS Measurements\)"](#), on page 76.

**Copying a Table**

Copies an existing channel table definition. The details of the selected channel are displayed in the "Channel Table" dialog box. See [chapter 5.1.8.4, "Channel Details \(BTS Measurements\)"](#), on page 76.

Remote command:

BTS measurements:

`CONFigure:WCDPower[:BTS]:CTABLE:COpy` on page 150

UE measurements:

`CONFigure:WCDPower:MS:CTABLE:COpy` on page 152

**Deleting a Table**

Deletes the currently selected channel table after a message is confirmed.

Remote command:

BTS measurements:

`CONFigure:WCDPower[:BTS]:CTABLE:DElete` on page 151

UE measurements:

`CONFigure:WCDPower:MS:CTABLE:DElete` on page 152

**Restoring Default Tables**

Restores the predefined channel tables delivered with the software.

**5.1.8.3 Channel Table Settings and Functions**

**Access:** "Overview" > "Channel Detection" > "New"/"Copy"/"Edit"

**or:** "Meas Setup" > "Channel Detection" > "New"/"Copy"/"Edit"

Some general settings and functions are available when configuring a predefined channel table.

|  |    |
|--|----|
| Name.....  | 75 |
| Comment.....   | 75 |
| Adding a Channel.....  | 75 |
| Deleting a Channel.....  | 75 |
| Creating a New Channel Table from the Measured Signal (Measure Table)..... | 75 |
| Sorting the Table.....   | 75 |
| Cancelling Configuration.....  | 75 |
| Saving the Table.....  | 76 |

### Name

Name of the channel table that will be displayed in the "Predefined Channel Tables" list.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:NAME](#) on page 153

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154

### Comment

Optional description of the channel table.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:COMMENT](#) on page 154

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:COMMENT](#) on page 154

### Adding a Channel

Inserts a new row in the channel table to define another channel.

### Deleting a Channel

Deletes the currently selected channel from the table.

### Creating a New Channel Table from the Measured Signal (Measure Table)

Creates a completely new channel table according to the current measurement data.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:MEASurement](#) on page 118

UE measurements:

[CONFigure:WCDPower:MS:MEASurement](#) on page 118

### Sorting the Table

Sorts the channel table entries.

### Cancelling Configuration

Closes the "Channel Table" dialog box without saving the changes.


**Saving the Table**

Saves the changes to the table and closes the "Channel Table" dialog box.

**5.1.8.4 Channel Details (BTS Measurements)**

**Access:** "Overview" > "Channel Detection" > "New"/"Copy"/"Edit"

or: "Meas Setup" > "Channel Detection" > "New"/"Copy"/"Edit"



Channel Type.....76  
 Symbol Rate.....77  
 Channel Number (Ch. SF).....77  
 Use TFCI.....77  
 Timing Offset.....77  
 Pilot Bits.....77  
 CDP Relative.....77  
 Status.....78  
 Conflict.....78

**Channel Type**

Type of channel. For a list of possible channel types see [chapter 4.2, "BTS Channel Types"](#), on page 35.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTable:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTable:DATA](#) on page 156

**Symbol Rate**

Symbol rate at which the channel is transmitted.

**Channel Number (Ch. SF)**

Number of channel spreading code (0 to [spreading factor-1])

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**Use TFCI**

Indicates whether the slot format and data rate are determined by the Transport Format Combination Indicator(TFCI).

Remote command:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

**Timing Offset**

Defines a timing offset in relation to the CPICH channel. During evaluation, the detected timing offset can be compared to this setting; only the delta is displayed (see "[Timing Offset Reference](#)" on page 73).

Remote command:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

**Pilot Bits**

Number of pilot bits of the channel (only valid for the control channel DPCCH)

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**CDP Relative**

Code domain power (relative to the total power of the signal)

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**Status**

Indicates the channel status. Codes that are not assigned are marked as inactive channels.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTable:DATA](#) on page 156


**Conflict**

Indicates a code domain conflict between channel definitions (e.g. overlapping channels).

**5.1.8.5 Channel Details (UE Measurements)**

**Access:** "Overview" > "Channel Detection" > "New"/"Copy"/"Edit"

or: "Meas Setup" > "Channel Detection" > "New"/"Copy"/"Edit"



Channel Type.....79

Symbol Rate.....79

Channel Number (Ch. SF).....79

Mapping.....79

Pilot Bits.....79

CDP Relative.....79

Status.....79

**Channel Type**

Type of channel. For a list of possible channel types see [chapter 4.2, "BTS Channel Types"](#), on page 35.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**Symbol Rate**

Symbol rate at which the channel is transmitted.

**Channel Number (Ch. SF)**

Number of channel spreading code (0 to [spreading factor-1])

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**Mapping**

Branch onto which the channel is mapped (I or Q). The setting is not editable, since the standard specifies the channel assignment for each channel.

**Pilot Bits**

Number of pilot bits of the channel (only valid for the control channel DPCCH)

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**CDP Relative**

Code domain power (relative to the total power of the signal)

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

**Status**

Indicates the channel status. Codes that are not assigned are marked as inactive channels.

Remote command:

BTS measurements:

[CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155

UE measurements:

[CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156

## 5.1.9 Automatic Settings

**Access:** "Auto Set" toolbar

Some settings can be adjusted by the R&S VSE automatically according to the current measurement settings. In order to do so, a measurement is performed. The duration of this measurement can be defined automatically or manually.

|   |    |
|---|----|
| Adjusting all Determinable Settings Automatically (Auto All)..... | 80 |
| Setting the Reference Level Automatically (Auto Level).....       | 80 |
| Autosearch for Scrambling Code.....                               | 80 |
| Auto Scale Window.....  | 81 |
| Auto Scale All.....   | 81 |
| Auto Settings Configuration.....                                  | 81 |
| L Automatic Measurement Time Mode and Value.....                  | 81 |
| L Upper Level Hysteresis.....                                     | 81 |
| L Lower Level Hysteresis.....                                     | 82 |

### Adjusting all Determinable Settings Automatically (Auto All)

Activates all automatic adjustment functions for the current measurement settings.

This includes:

- "Setting the Reference Level Automatically (Auto Level)" on page 61
- "Autosearch for Scrambling Code" on page 51
- "Auto Scale All" on page 81

Remote command:

[SENSe:]ADJust:ALL on page 159

### Setting the Reference Level Automatically (Auto Level)

The instrument in use automatically determines the optimal reference level for the current input data. At the same time, the internal attenuators and the preamplifier are adjusted so the signal-to-noise ratio is optimized, while signal compression, clipping and overload conditions are minimized. This function is not available on all supported instruments.

Remote command:

[SENSe:]ADJust:LEVel on page 161

### Autosearch for Scrambling Code

Starts a search on the measured signal for all scrambling codes. The scrambling code that leads to the highest signal power is chosen as the new scrambling code.

Searching requires that the correct center frequency and level are set. The scrambling code search can automatically determine the primary scrambling code number. The secondary scrambling code number is expected as 0. Alternative scrambling codes can not be detected. Therefore the range for detection is 0x0000 – 0x1FF0h, where the last digit is always 0.

Remote command:

[SENSe:]CDPower:LCODE:SEARch[:IMMediate]? on page 121



**Auto Scale Window**


Automatically determines the optimal range and reference level position to be displayed for the *current* measurement settings in the currently selected window. No new measurement is performed.

**Auto Scale All**

Automatically determines the optimal range and reference level position to be displayed for the *current* measurement settings in all displayed diagrams. No new measurement is performed.

**Auto Settings Configuration**

For some automatic settings, additional parameters can be configured. The "Auto Set Config" dialog box is available when you select the icon from the "Auto Set" toolbar.

**Automatic Measurement Time Mode and Value ← Auto Settings Configuration**

To determine the optimal reference level automatically, a level measurement is performed on the instrument in use. You can define whether the duration of this measurement is determined automatically or manually.

To define the duration manually, enter a value in seconds.

Remote command:

[\[SENSe:\]ADJust:CONFigure:DURation:MODE](#) on page 160

[\[SENSe:\]ADJust:CONFigure:DURation](#) on page 159

**Upper Level Hysteresis ← Auto Settings Configuration**

When the reference level is adjusted automatically using the [Auto Level](#) function, the internal attenuators and the preamplifier (if available) of the instrument in use are also adjusted. In order to avoid frequent adaptation due to small changes in the input signal, you can define a hysteresis. This setting defines a lower threshold the signal must fall below (compared to the last measurement) before the reference level is adapted automatically.

Remote command:

[\[SENSe:\]ADJust:CONFigure:HYSTeresis:UPPer](#) on page 160

**Lower Level Hysteresis ← Auto Settings Configuration**

When the reference level is adjusted automatically using the [Auto Level](#) function, the internal attenuators and the preamplifier (if available) of the instrument in use are also adjusted. In order to avoid frequent adaptation due to small changes in the input signal, you can define a hysteresis. This setting defines a lower threshold the signal must fall below (compared to the last measurement) before the reference level is adapted automatically.

Remote command:

[\[SENSe:\]ADJust:CONFigure:HYSTeresis:LOWer](#) on page 160

**5.1.10 Zoom Functions**

**Access:** "Zoom" icons in toolbar

|  |    |
|--|----|
| <a href="#">Single Zoom</a> .....  | 82 |
| <a href="#">Multiple Zoom</a> .....  | 82 |
| <a href="#">Restore Original Display</a> .....   | 82 |
|  <a href="#">Deactivating Zoom (Selection mode)</a> ..... | 83 |

**Single Zoom**

A single zoom replaces the current diagram by a new diagram which displays an enlarged extract of the trace. This function can be used repetitively until the required details are visible.

Remote command:

[DISPlay\[:WINDow<n>\]:ZOOM:STATe](#) on page 205

[DISPlay\[:WINDow<n>\]:ZOOM:AREA](#) on page 205

**Multiple Zoom**

In multiple zoom mode, you can enlarge several different areas of the trace simultaneously. An overview window indicates the zoom areas in the original trace, while the zoomed trace areas are displayed in individual windows. The zoom area that corresponds to the individual zoom display is indicated in the lower right corner, between the scrollbars.

Remote command:

[DISPlay\[:WINDow<n>\]:ZOOM:MULTiple<zoom>:STATe](#) on page 206

[DISPlay\[:WINDow<n>\]:ZOOM:MULTiple<zoom>:AREA](#) on page 205

**Restore Original Display**

Restores the original display, that is, the originally calculated displays for the entire capture buffer, and closes all zoom windows.

Remote command:

single zoom:

`DISPlay[:WINDow<n>]:ZOOM:STATe` on page 205

multiple zoom:

`DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:STATe` on page 206 (for each multiple zoom window)

#### **Deactivating Zoom (Selection mode)**

Deactivates any zoom mode.

Selecting a point in the display no longer invokes a zoom, but selects an object.

Remote command:

single zoom:

`DISPlay[:WINDow<n>]:ZOOM:STATe` on page 205

multiple zoom:

`DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:STATe` on page 206 (for each multiple zoom window)

## 5.2 Time Alignment Error Measurements


**Access:** "Overview" > "Select Measurement" >

### 5.2.1 Configuration Overview



**Access:** "Meas Setup" > "Overview"

For Time Alignment Error measurements, the "Overview" provides quick access to the following configuration dialog boxes (listed in the recommended order of processing):



1. "Select Measurement"  
See [chapter 3, "Measurements and Result Display"](#), on page 11
2. "Scrambling Code"  
See [chapter 5.1.2.2, "BTS Scrambling Code"](#), on page 50
3. "Input/ Frontend"  
See [chapter 5.1.3, "Data Input and Output Settings"](#), on page 53
4. (Optionally:) "Trigger"  
[chapter 5.1.5, "Trigger Settings"](#), on page 65
5. "Signal Capture"  
See [chapter 5.1.6, "Signal Capture \(Data Acquisition\)"](#), on page 68
6. "Synchronization"  
See [chapter 5.1.7, "Synchronization \(BTS Measurements Only\)"](#), on page 70
7. "Analysis"  
See [chapter 6, "Analysis"](#), on page 85
8. "Display Configuration"  
See [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14 and ["Evaluation Methods"](#) on page 30

All settings required for Time Alignment Error measurements are identical to those described for Code Domain Analysis (see [chapter 5.1, "Code Domain Analysis"](#), on page 46).

## 6 Analysis

**Access:** "Overview" > "Analysis"

General result analysis settings concerning the evaluation range, trace, markers, etc. can be configured

The remote commands required to perform these tasks are described in [chapter 10.9, "Analysis"](#), on page 195.


- [Evaluation Range](#).....85
- [Code Domain Analysis Settings \(BTS Measurements\)](#).....87
- [Code Domain Analysis Settings \(UE Measurements\)](#).....89
- [Traces](#).....90
- [Markers](#).....91

### 6.1 Evaluation Range

**Access:** "Overview" > "Analysis" > "Evaluation Range"

or: "Meas Setup" > "Evaluation Range"

The evaluation range defines which channel, slot or frame is evaluated in the result display.



- [Channel](#).....85
- [Slot](#).....86
- [Frame To Analyze](#).....86
- [Branch \(UE measurements only\)](#).....86
  - ↳ [Details](#).....86
  - ↳ [Selecting a Different Branch for a Window](#).....87

#### Channel

Selects a channel for the following evaluations:

- [Code Domain Power](#)
- [Power vs Slot](#)
- [Symbol Constellation](#)
- [Symbol EVM](#)

Enter a channel number and spreading factor, separated by a decimal point.

The specified channel is selected and marked in red, if active. If no spreading factor is specified, the code on the basis of the spreading factor 512 is marked. For unused channels, the code resulting from the conversion is marked.

**Example:** Enter 5.128

Channel 5 is marked at spreading factor 128 (30 ksps) if the channel is active, otherwise code 20 at spreading factor 512.

Remote command:

`[SENSe:]CDPower:CODE` on page 161

### Slot

Selects the slot for evaluation. This affects the following evaluations (see also [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14):

- Code Domain Power
- Peak Code Domain Error
- Result Summary
- Composite Constellation
- Code Domain Error Power
- Channel Table
- Power vs Symbol
- Symbol Const
- Symbol EVM
- Bitstream

Remote command:

`[SENSe:]CDPower:SLOT` on page 162

### Frame To Analyze

Defines the frame to be analyzed and displayed.

Remote command:

`[SENSe:]CDPower:FRAME[:VALue]` on page 161

### Branch (UE measurements only)


Switches between the evaluation of the I and the Q branch in UE measurements.

Remote command:

`CALCulate<n>:CDPower:Mapping` on page 162

### Details ← Branch (UE measurements only)

By default, the same branch is used for all evaluations. However, you can select a different branch for individual windows. These settings are only available in the detailed dialog box, which is displayed when you select the "Details" button in the "Evaluation Range" dialog box.



To hide the detailed dialog box for individual windows, select the "Hide" button.

#### Selecting a Different Branch for a Window ← Branch (UE measurements only)

By default, the same (common) branch is used by all windows, namely the one specified by the [Branch \(UE measurements only\)](#) setting.

In order to evaluate a different branch for an individual window, toggle the "Use Common Branch" setting to "No". Select the window from the list of active windows under "Specifics for", then select the "Branch".

Remote command:


[CALCulate<n>:CDPower:Mapping](#) on page 162

## 6.2 Code Domain Analysis Settings (BTS Measurements)

**Access:** "Overview" > "Analysis" > "Code Domain Settings"

**or:** "Meas Setup" > "Code Domain Settings"

Some evaluations provide further settings for the results. The settings for BTS measurements are described here.



Compensate IQ Offset..... 88  
 Code Power Display.....88  
 Show Difference to Previous Slot.....88  
 Constellation Parameter B..... 89

**Compensate IQ Offset**

If enabled, the I/Q offset is eliminated from the measured signal. This is useful to deduct a DC offset to the baseband caused by the DUT, thus improving the EVM. Note, however, that for EVM measurements according to standard, compensation must be disabled.

Remote command:

[SENSe:]CDPower:NORMalize on page 163

**Code Power Display**

For Code Domain Power evaluation:

Defines whether the absolute power or the power relative to the chosen reference is displayed.

"TOT" Relative to the total signal power

"CPICH" Relative to the power of the CPICH

Remote command:

[SENSe:]CDPower:PDISplay on page 164

[SENSe:]CDPower:PREFference on page 164

**Show Difference to Previous Slot**

For Power vs. Slot evaluation:

If enabled, the slot power difference between the current slot and the previous slot is displayed in the "Power vs. Slot" evaluation.

Remote command:

[SENSe:]CDPower:PDIFf on page 164



**Constellation Parameter B**

For Bitstream evaluation:

Defines the constellation parameter B. According to 3GPP specification, the mapping of 16QAM symbols to an assigned bitstream depends on the constellation parameter B. This parameter can be adjusted to decide which bit mapping should be used for bitstream evaluation.

Remote command:


[SENSe:]CDPower:CPB on page 163

**6.3 Code Domain Analysis Settings (UE Measurements)**

**Access:** "Overview" > "Analysis" > "Code Domain Settings"

**or:** "Meas Setup" > "Code Domain Settings"

Some evaluations provide further settings for the results. The settings for UE measurements are described here.



|                           |    |
|---------------------------|----|
| Measurement Interval..... | 89 |
| Compensate IQ Offset..... | 90 |
| Eliminate Tail Chips..... | 90 |
| Code Power Display.....   | 90 |

**Measurement Interval**

Switches between the analysis of a half slot or a full slot.

Both measurement intervals are influenced by the settings of [Eliminate Tail Chips](#): If "Eliminate Tail Chips" is set to "On", 96 chips at both ends of the measurement interval are not taken into account for analysis.

- "Slot"                    The length of each analysis interval is 2560 chips, corresponding to one time slot of the 3GPP signal. The time reference for the start of slot 0 is the start of a 3GPP radio frame.
- "Halfslot"              The length of each analysis interval is reduced to 1280 chips, corresponding to half of one time slot of the 3GPP signal.

Remote command:

[SENSe:]CDPower:HSLot on page 166

**Compensate IQ Offset**

If enabled, the I/Q offset is eliminated from the measured signal. This is useful to deduct a DC offset to the baseband caused by the DUT, thus improving the EVM. Note, however, that for EVM measurements according to standard, compensation must be disabled.

Remote command:

[\[SENSe:\]CDPower:NORMalize](#) on page 163

**Eliminate Tail Chips**

Selects the length of the measurement interval for calculation of error vector magnitude (EVM) in accordance with 3GPP specification Release 5.

- |       |   |
|-------|---|
| "On"  | Changes of power are expected. Therefore an EVM measurement interval of one slot minus 25 µs at each end of the burst (3904 chips) is considered. |
| "Off" | Changes of power are not expected. Therefore an EVM measurement interval of one slot (4096 chips) is considered. (Default settings)               |

Remote command:

[\[SENSe:\]CDPower:ETChips](#) on page 165

**Code Power Display**

For "Code Domain Power" evaluation:

Defines whether the absolute power or the power relative to the total signal is displayed.

- |            |                                    |
|------------|------------------------------------|
| "Absolute" | Absolute power levels              |
| "Relative" | Relative to the total signal power |

Remote command:


[\[SENSe:\]CDPower:PDISplay](#) on page 164

## 6.4 Traces

**Access:** "Overview" > "Analysis" > "Trace"

**or:** "Trace" > "Trace"

The trace settings determine how the measured data is analyzed and displayed on the screen.



In CDA evaluations, only one trace can be active in each diagram at any time.



### Window-specific configuration

The settings in this dialog box are specific to the selected window. To configure the settings for a different window, select the window outside the displayed dialog box, or select the window from the "Specifics for" selection list in the dialog box.

#### Trace Mode

Defines the update mode for subsequent traces.

|               |   |
|---------------|---|
| "Clear Write" | Overwrite mode: the trace is overwritten by each measurement. This is the default setting.  |
| "Max Hold"    | The maximum value is determined over several measurements and displayed. The R&S VSE saves each trace point in the trace memory only if the new value is greater than the previous one. |
| "Min Hold"    | The minimum value is determined from several measurements and displayed. The R&S VSE saves each trace point in the trace memory only if the new value is lower than the previous one.   |
| "Average"     | The average is formed over several measurements.  |
| "View"        | The current contents of the trace memory are frozen and displayed.  |
| "Blank"       | Removes the selected trace from the display.  |

Remote command:

`DISPlay[:WINDow<n>]:TRACe<t>:MODE` on page 195

## 6.5 Markers

**Access:** "Overview" > "Analysis" > "Marker"

**or:** "Marker"

Markers help you analyze your measurement results by determining particular values in the diagram. Thus you can extract numeric values from a graphical display.



### Markers in Code Domain Analysis measurements

In Code Domain Analysis measurements, the markers are set to individual symbols, codes, slots or channels, depending on the result display. Thus you can use the markers to identify individual codes, for example.


- [Individual Marker Settings](#).....92
- [General Marker Settings](#)..... 94
- [Marker Search Settings](#).....94
- [Marker Positioning Functions](#).....95

### 6.5.1 Individual Marker Settings

**Access:** "Overview" > "Analysis" > "Marker" > "Markers"

**or:** "Marker" > "Marker"

In CDA evaluations, up to 4 markers can be activated in each diagram at any time.



- ▼ Place New Marker..... 92
- ML Marker 1/ Delta 1/ Delta 2/.../Delta 4..... 92
- Selected Marker..... 93
- Marker State..... 93
- X-value..... 93
- Marker Type..... 93
- All Markers Off..... 94

#### ▼ Place New Marker

Activates the next currently unused marker and sets it to the peak value of the current trace in the current window.

#### ML Marker 1/ Delta 1/ Delta 2/.../Delta 4

When you select the arrow on the marker selection list in the toolbar, or select a marker from the "Marker > Select Marker" menu, the marker is activated and an edit dialog box is displayed to enter the marker position ("X-value").

To deactivate a marker, select the marker name in the marker selection list in the toolbar (not the arrow) to display the "Select Marker" dialog box. Change the "State" to "Off".

Marker 1 is always the default reference marker for relative measurements. If activated, markers 2 to 4 are delta markers that refer to marker 1. These markers can be converted into markers with absolute value display using the "Marker Type" function.

Several markers can be configured very easily using the "Marker" dialog box, see [chapter 6.5, "Markers"](#), on page 91.

Remote command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 197

[CALCulate<n>:MARKer<m>:X](#) on page 197

[CALCulate<n>:MARKer<m>:Y?](#) on page 197

[CALCulate<n>:DELTamarker<m>\[:STATe\]](#) on page 198

[CALCulate<n>:DELTamarker<m>:X](#) on page 198

[CALCulate<n>:DELTamarker<m>:X:RELative?](#) on page 199

[CALCulate<n>:DELTamarker<m>:Y?](#) on page 199

### Selected Marker

Marker name. The marker which is currently selected for editing is highlighted orange.

Remote command:

Marker selected via suffix <m> in remote commands.

### Marker State

Activates or deactivates the marker in the diagram.

Remote command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 197

[CALCulate<n>:DELTamarker<m>\[:STATe\]](#) on page 198

### X-value

Defines the position of the marker on the x-axis (channel, slot, symbol, depending on evaluation).

Remote command:

[CALCulate<n>:DELTamarker<m>:X](#) on page 198

[CALCulate<n>:MARKer<m>:X](#) on page 197

### Marker Type



Toggles the marker type.

The type for marker 1 is always "Normal", the type for delta marker 1 is always "Delta". These types cannot be changed.

**Note:** If normal marker 1 is the active marker, switching the "Mkr Type" activates an additional delta marker 1. For any other marker, switching the marker type does not activate an additional marker, it only switches the type of the selected marker.

"Normal"            A normal marker indicates the absolute value at the defined position in the diagram.

"Delta"            A delta marker defines the value of the marker relative to the specified reference marker (marker 1 by default).

Remote command:

[CALCulate<n>:MARKer<m>\[:STATe\]](#) on page 197

[CALCulate<n>:DELTamarker<m>\[:STATe\]](#) on page 198

**All Markers Off**

Deactivates all markers in one step.


Remote command:

[CALCulate<n>:MARKer<m>:AOFF](#) on page 196

**6.5.2 General Marker Settings**

**Access:** "Overview" > "Analysis" > "Marker" > "Marker Settings"

**or:** "Marker" > "Marker" > "Marker Settings" tab

**Marker Table Display**

Defines how the marker information is displayed.

- "On" Displays the marker information in a table in a separate area beneath the diagram.
- "Off" Displays the marker information within the diagram area.
- "Auto" (Default) Up to two markers are displayed in the diagram area. If more markers are active, the marker table is displayed automatically.

Remote command:


[DISPlay:MTABLE](#) on page 200

**6.5.3 Marker Search Settings**

**Access:** "Overview" > "Analysis" > "Marker" > "Search"

**Access:** "Marker" > "Search"

Several functions are available to set the marker to a specific position very quickly and easily. In order to determine the required marker position, searches may be performed. The search results can be influenced by special settings.



[Search Mode for Next Peak](#)..... 95

**Search Mode for Next Peak**

Selects the search mode for the next peak search.

- "Left"                 Determines the next maximum/minimum to the left of the current peak.
- "Absolute"            Determines the next maximum/minimum to either side of the current peak.
- "Right"                Determines the next maximum/minimum to the right of the current peak.

Remote command:

[chapter 10.9.2.3, "Positioning the Marker"](#), on page 200

**6.5.4 Marker Positioning Functions**

**Access:** "Marker" toolbar

The following functions set the currently selected marker to the result of a peak search.



**Markers in Code Domain Analysis measurements**

In Code Domain Analysis measurements, the markers are set to individual symbols, codes, slots or channels, depending on the result display. Thus you can use the markers to identify individual codes, for example.

[Search Next Peak](#)..... 95

[Search Next Minimum](#)..... 96

[Peak Search](#)..... 96

[Search Minimum](#)..... 96

[Marker To CPICH](#)..... 96

[Marker To PCCPCH](#)..... 96

**Search Next Peak**

Sets the selected marker/delta marker to the next (lower) maximum of the assigned trace. If no marker is active, marker 1 is activated.



Remote command:

`CALCulate<n>:MARKer<m>:MAXimum:NEXT` on page 201  
`CALCulate<n>:MARKer<m>:MAXimum:RIGHT` on page 201  
`CALCulate<n>:MARKer<m>:MAXimum:LEFT` on page 201  
`CALCulate<n>:DELTamarker<m>:MAXimum:NEXT` on page 203  
`CALCulate<n>:DELTamarker<m>:MAXimum:RIGHT` on page 203  
`CALCulate<n>:DELTamarker<m>:MAXimum:LEFT` on page 203

### Search Next Minimum

Sets the selected marker/delta marker to the next (higher) minimum of the selected trace. If no marker is active, marker 1 is activated.



Remote command:

`CALCulate<n>:MARKer<m>:MINimum:NEXT` on page 202  
`CALCulate<n>:MARKer<m>:MINimum:LEFT` on page 202  
`CALCulate<n>:MARKer<m>:MINimum:RIGHT` on page 202  
`CALCulate<n>:DELTamarker<m>:MINimum:NEXT` on page 204  
`CALCulate<n>:DELTamarker<m>:MINimum:LEFT` on page 204  
`CALCulate<n>:DELTamarker<m>:MINimum:RIGHT` on page 204

### Peak Search



Sets the selected marker/delta marker to the maximum of the trace. If no marker is active, marker 1 is activated.

Remote command:

`CALCulate<n>:MARKer<m>:MAXimum[:PEAK]` on page 201  
`CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK]` on page 203

### Search Minimum



Sets the selected marker/delta marker to the minimum of the trace. If no marker is active, marker 1 is activated.

Remote command:

`CALCulate<n>:MARKer<m>:MINimum[:PEAK]` on page 202  
`CALCulate<n>:DELTamarker<m>:MINimum[:PEAK]` on page 204

### Marker To CPICH

Sets the marker to the CPICH channel.

Remote command:

`CALCulate<n>:MARKer<m>:FUNCTION:CPICH` on page 200

### Marker To PCCPCH

Sets the marker to the PCCPCH channel.

Remote command:




`CALCulate<n>:MARKer<m>:FUNCTION:PCCPch` on page 201



## 7 How to Perform Measurements in 3GPP FDD Applications

The following step-by-step instructions demonstrate how to perform measurements with the 3GPP FDD applications.

### To perform Code Domain Analysis

1. Open a new channel or replace an existing one and select the "3GPP FDD" application.
2. Select the "Meas Setup > Overview" menu item to display the "Overview" for a 3GPP FDD measurement.
3. Select the "Signal Description" button and configure the expected input signal and used scrambling code.
4. Select the "Input/Frontend" button and then the "Frequency" tab to define the input signal's center frequency.
5. Optionally, select the "Trigger" button and define a trigger for data acquisition, for example an external trigger to start capturing data only when a useful signal is transmitted.
6. Select the "Signal Capture" button and define the acquisition parameters for the input signal.
7. If necessary, select the "Synchronization" button and change the channel synchronization settings.
8. Select the "Channel Detection" button and define how the individual channels are detected within the input signal. If necessary, define a channel table as described in ["To define or edit a channel table"](#) on page 98.
9. Select the  "Add Window" icon from the toolbar to add further result displays for the 3GPP FDD channel.
10. Select "Meas Setup > Overview" to display the "Overview".
11. Select the "Analysis" button in the "Overview" to configure how the data is evaluated in the individual result displays.
  - Select the channel, slot or frame to be evaluated.
  - Configure specific settings for the selected evaluation method(s).
  - Optionally, configure the trace to display the average over a series of sweeps.
  - Configure markers and delta markers to determine deviations and offsets within the results, e.g. when comparing errors or peaks.
12. In the "Control" toolbar, or in the "Sequence" tool window, select  "Single" capture mode, then select the  "Capture" function to stop the continuous measurement mode and start a defined number of measurements.

### To define or edit a channel table

Channel tables contain a list of channels to be detected and their specific parameters. You can create user-defined and edit pre-defined channel tables.

1. From the "Meas Setup" menu, select "Channel Detection".
2. To define a new channel table, select the "New" button next to the "Predefined Tables" list.  
To edit an existing channel table:
  - a) Select the existing channel table in the "Predefined Tables" list.
  - b) Select the "Edit" button next to the "Predefined Tables" list.
3. In the "Channel Table" dialog box, define a name and, optionally, a comment that describes the channel table. The comment is displayed when you set the focus on the table in the "Predefined Tables" list.
4. Define the channels to be detected using one of the following methods:  
Select the "Measure Table" button to create a table that consists of the channels detected in the currently measured signal.  
Or:
  - a) Select the "Add Channel" button to insert a row for a new channel below the currently selected row in the channel table.
  - b) Define the channel specifications required for detection:
    - Symbol rate
    - Channel number
    - Whether TFCI is used
    - Timing offset, if applicable
    - Number of pilot bits (for DPCCH only)
    - The channel's code domain power (relative to the total signal power)
5. Select the "Save Table" button to store the channel table.  
The table is stored and the dialog box is closed. The new channel table is included in the "Predefined Tables" list in the "Channel Detection" dialog box.
6. To activate the use of the new channel table:
  - a) Select the table in the "Predefined Tables" list.
  - b) Select the "Select" button.  
A checkmark is displayed next to the selected table.
  - c) Toggle the "Use Predefined Channel Table" setting to "Predefined".
  - d) Toggle the "Compare Meas Signal with Predefined Table" setting to "On".
  - e) Start a new measurement.

### To determine the Time Alignment Error

1. Open a new channel or replace an existing one and select the "3GPP FDD" application.
2. From the "Meas Setup" menu, select "Synchronization". Configure the location of the S-CPICH for antenna 2 and select the "Antenna Pattern".

3. Select the Time Alignment Error measurement:
  - a) From the "Meas Setup" menu, select "Select Measurement".
  - b) In the "Select Measurement" dialog box, select the "Time Alignment Error" button.

The Time Alignment Error is calculated and displayed immediately.

## 8 Measurement Examples

Some practical examples for basic 3GPP°FDD Base station tests are provided here. They describe how operating and measurement errors can be avoided using correct presets. The measurements are performed with R&S VSE equipped with option R&S VSE-K72.

It is assumed an instrument is connected and configured for input to the R&S VSE software.

(See the R&S VSE Base Software User Manual).

Key settings are shown as examples to avoid measurement errors. Following the correct setting, the effect of an incorrect setting is shown.

The measurements are performed using the following instruments and accessories:

- The R&S VSE with option R&S VSE-K72: 3GPP FDD measurements
- An R&S FSW Signal and Spectrum Analyzer
- The Vector Signal Generator R&S SMW200A with option R&S SMW-K42: digital standard 3GPP FDD (requires options R&S SMW-B10, R&S SMW-B13 and R&S SMW-B103)
- 1 coaxial cable, 50Ω, approx. 1 m, N connector
- 1 coaxial cable, 50Ω, approx. 1 m, BNC connector

The following measurements are described:

- [Measurement 1: Measuring the Relative Code Domain Power](#)..... 100
- [Measurement 2: Triggered Measurement of Relative Code Domain Power](#)..... 104
- [Measurement 3: Measuring the Composite EVM](#)..... 106
- [Measurement 4: Determining the Peak Code Domain Error](#)..... 108

### 8.1 Measurement 1: Measuring the Relative Code Domain Power

A code domain power measurement on one of the channel configurations is shown in the following. Basic parameters of CDP analysis are changed to demonstrate the effects of values that are not adapted to the input signal.

#### Test setup

1. Connect the RF A output of the R&S SMW200A to the RF input of the R&S FSW (coaxial cable with N connectors).
2. Connect the reference input (REF INPUT) on the rear panel of the R&S FSW to the reference output (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).

## Measurement 1: Measuring the Relative Code Domain Power

**Settings on the R&S SMW200A**

1. PRESET
2. "Freq. A" = *2.1175 GHz*
3. "Level"= *0 dBm*
4. "Baseband A > CDMA Standards > 3GPP FDD"
5. "General" tab: "Link Direction > DOWN/FORWARD"
6. "Basestations" tab: "Test Setups/Models > Test\_Model\_1\_16\_channels"
7. "Basestations" tab: "Select Basestation > BS 1 > ON"
8. "General" tab: "3GPP FDD > STATE > ON"
9. "RF A": "On"

**Settings in the R&S VSE**

1. "File > Preset > All"
2. "Measurement Group Setup": "Replace Channel > 3GPP FDD BTS"
3. "Input and Output > Amplitude": "Reference level"= *10 dBm*
4. "Input and Output > Frequency": "Center frequency" = *2.1175 GHz*
5. "Input and Output > Scale": "Auto Scale Once"

**Result**

Window 1 shows the Code Domain Power of the signal.

Window 2 shows the Result Summary, i.e. the numeric results of the CDP measurement.

## Measurement 1: Measuring the Relative Code Domain Power




Fig. 8-1: Measurement Example 1: Measuring the Relative Code Domain Power

### 8.1.1 Synchronizing the Reference Frequencies

The synchronization of the reference oscillators both of the DUT and the R&S FSW strongly reduces the measured frequency error.

#### Test setup

- ▶ Connect the reference input (REF INPUT (1...20 MHz)) on the rear panel of the R&S FSW to the reference output (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).

#### Settings on the R&S SMW200A

The settings on the R&S SMW200A remain the same.

#### Settings in the R&S VSE

In addition to the settings of the basic test, activate the use of an external reference:

- ▶ "Instruments > Info & Settings > Reference": "Reference Frequency Input = External Reference 10 MHz"

The displayed carrier frequency error should be < 10 Hz.

## Measurement 1: Measuring the Relative Code Domain Power

### 8.1.2 Behaviour with Deviating Center Frequency

In the following, the behaviour of the DUT and the R&S FSW with an incorrect center frequency setting is shown.

1. Tune the center frequency of the signal generator in 0.5 kHz steps.
2. Watch the measurement results in the R&S VSE:
  - Up to 5 kHz, a frequency error causes no apparent difference in measurement accuracy of the code domain power measurement.
  - Above a frequency error of 5 kHz, the probability of an impaired synchronization increases. With continuous measurements, at times all channels are displayed in blue with almost the same level.
  - Above a frequency error of approx. 7 kHz, a CDP measurement cannot be performed. The R&S VSE displays all possible codes in blue with a similar level.




Fig. 8-2: Measurement Example 1: Measuring the Relative Code Domain Power with Incorrect Center Frequency

3. Reset the frequency to 2.1175 GHz both on the R&S SMW200A and in the R&S VSE software.

### 8.1.3 Behaviour with Incorrect Scrambling Code

A valid CDP measurement can be carried out only if the scrambling code set in the R&S VSE is identical to that of the transmitted signal.

#### Settings on the R&S SMW200A

- "Basestationss" tab > BS 1 > "Common" tab: "Scrambling Code (hex)" = 0000


## Measurement 2: Triggered Measurement of Relative Code Domain Power

**Settings in the R&S VSE**

- "Meas Setup > Scrambling Code" = 0001

**Result**

The CDP display shows all possible codes with approximately the same level.



*Fig. 8-3: Measurement Example 1: Measuring the Relative Code Domain Power with Incorrect Scrambling Code*

## 8.2 Measurement 2: Triggered Measurement of Relative Code Domain Power

If the code domain power measurement is performed without external triggering, a section of approximately 20 ms of the test signal is recorded at an arbitrary moment to detect the start of a 3GPP FDD BTS frame in this section. Depending on the position of the frame start, the required computing time can be quite long. Applying an external (frame) trigger can reduce the computing time.

**Test setup**

1. Connect the RF A output of the R&S SMW200A to the input of the R&S FSW.
2. Connect the reference input (REF INPUT) on the rear panel of the R&S FSW to the reference input (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).
3. Connect the external trigger input of the R&S FSW (TRIGGER INPUT) to the external trigger output USER 1 of the R&S SMW200A.

**Settings on the R&S SMW200A**

1. PRESET
2. "Freq. A" = 2.1175 GHz
3. "Level" = 0 dBm



## Measurement 2: Triggered Measurement of Relative Code Domain Power

4. "Baseband A > CDMA Standards > 3GPP FDD"
5. "General" tab: "Link Direction > DOWN/FORWARD"
6. "Basestations" tab: "Test Setups/Models > Test\_Model\_1\_16\_channels"
7. "Basestations" tab: "Select Basestation > BS 1 > ON"
8. "General" tab: "3GPP FDD > STATE > ON"
9. "RF A": "On"

**Settings in the R&S VSE**

1. "File > Preset > All"
2. "Measurement Group Setup": "Replace Channel > 3GPP FDD BTS"
3. "Input and Output > Amplitude": "Reference level"= *10 dBm*
4. "Input and Output > Frequency": "Center frequency" = *2.1175 GHz*
5. "Meas Setup > Scrambling Code" = *0000*
6. "Input and Output > Trigger": "Trigger Source: External Trigger 1"
7. "Input and Output > Scale": "Auto Scale Once"

**Results**

The following is displayed:

- Window 1: Code Domain Power of signal
- Window 2: Result Summary, including the "Trigger to Frame", i.e. offset between trigger event and start of 3GPP FDD BTS frame

## Measurement 3: Measuring the Composite EVM



Fig. 8-4: Measurement Example 2: Triggered Measurement of Relative Code Domain Power



The repetition rate of the measurement increases considerably compared to the repetition rate of a measurement without an external trigger.

### Trigger Offset

A delay of the trigger event referenced to the start of the 3GPP FDD BTS frame can be compensated by modifying the trigger offset.

- ▶ Setting in the R&S VSE:  
"Input and Output > Trigger""Trigger Offset" = 100  $\mu$ s

The "Trigger to Frame" parameter in the Result Summary (Window 2) changes:  
"Trigger to Frame" = -100  $\mu$ s

## 8.3 Measurement 3: Measuring the Composite EVM

The 3GPP specification defines the composite EVM measurement as the average square deviation of the total signal.

An ideal reference signal is generated from the demodulated data. The test signal and the reference signal are compared with each other. The square deviation yields the composite EVM.



**Test setup**

1. Connect the RF A output of the R&S SMW200A to the input of the R&S FSW.
2. Connect the reference input (REF INPUT) on the rear panel of the R&S FSW to the reference input (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).
3. Connect the external trigger input of the R&S FSW (TRIGGER INPUT) to the external trigger output USER 1 of the R&S SMW200A.

**Settings on the R&S SMW200A**

1. PRESET
2. "Freq. A" = 2.1175 GHz
3. "Level" = 0 dBm
4. "Baseband A > CDMA Standards > 3GPP FDD"
5. "General" tab: "Link Direction > DOWN/FORWARD"
6. "Basestations" tab: "Test Setups/Models > Test\_Model\_1\_16\_channels"
7. "Basestations" tab: "Select Basestation > BS 1 > ON"
8. "General" tab: "3GPP FDD > STATE > ON"
9. "RF A": "On"

**Settings in the R&S VSE**

1. "File > Preset > All"
2. "Measurement Group Setup": "Replace Channel > 3GPP FDD BTS"
3. "Input and Output > Amplitude": "Reference level" = 10 dBm
4. "Input and Output > Frequency": "Center frequency" = 2.1175 GHz
5. "Meas Setup > Scrambling Code" = 0000
6. "Input and Output > Trigger": "Trigger Source: External Trigger 1"
7. Replace the Result Summary display by a Composite EVM display:
  - a) Select the  "Delete" icon from the Result Summary window title bar.
  - b) Select the  "Add Window" icon from the toolbar.
  - c) Select the "Composite EVM" result display.
8. "Input and Output > Scale": "Auto Scale Once"

**Results**

The following is displayed:

- Window 1: Code Domain Power of signal
- Window 2: Composite EVM (EVM for total signal)

## Measurement 4: Determining the Peak Code Domain Error




Fig. 8-5: Measurement Example 3: Measuring the Composite EVM

## 8.4 Measurement 4: Determining the Peak Code Domain Error

The peak code domain error measurement is defined in the 3GPP specification for FDD signals.

An ideal reference signal is generated from the demodulated data. The test signal and the reference signal are compared with each other. The difference of the two signals is projected onto the classes of the different spreading factors. The peak code domain error measurement is obtained by summing up the symbols of each difference signal slot and searching for the maximum error code.

### Test setup

1. Connect the RF A output of the R&S SMW200A to the input of the R&S FSW.
2. Connect the reference input (REF INPUT) on the rear panel of the R&S FSW to the reference input (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).
3. Connect the external trigger input of the R&S FSW (TRIGGER INPUT) to the external trigger output USER 1 of the R&S SMW200A.


### Settings on the R&S SMW200A

1. PRESET

## Measurement 4: Determining the Peak Code Domain Error

2. "Freq. A" = 2.1175 GHz
3. "Level" = 0 dBm
4. "Baseband A > CDMA Standards > 3GPP FDD"
5. "General" tab: "Link Direction > DOWN/FORWARD"
6. "Basestations" tab: "Test Setups/Models > Test\_Model\_1\_16\_channels"
7. "Basestations" tab: "Select Basestation > BS 1 > ON"
8. "General" tab: "3GPP FDD > STATE > ON"
9. "RF A": "On"

**Settings in the R&S VSE**

1. "File > Preset > All"
2. "Measurement Group Setup": "Replace Channel > 3GPP FDD BTS"
3. "Input and Output > Amplitude": "Reference level" = 0 dBm
4. "Input and Output > Frequency": "Center frequency" = 2.1175 GHz
5. "Meas Setup > Scrambling Code" = 0000
6. "Input and Output > Trigger": "Trigger Source: External Trigger 1"
7. Replace the Composite EVM display by a Peak Code Domain Error display:
  - a) Select the  "Change window" icon from the Composite EVM window title bar.
  - b) Select the "Peak Code Domain Error" result display.
8. "Input and Output > Scale": "Auto Scale Once"

**Results**

The following is displayed:

- Window 1: Code Domain Power of signal
- Window 2: Peak Code Domain Error (projection of error onto the class with spreading factor 256)

Measurement 4: Determining the Peak Code Domain Error




Fig. 8-6: Measurement Example 4: Determining the Peak Code Domain Error

## 9 Optimizing and Troubleshooting the Measurement

If the results do not meet your expectations, try the following methods to optimize the measurement:

### Synchronization fails:

- Check the frequency.
- Check the reference level.
- Check the scrambling code.
- When using an external trigger, check whether an external trigger is being sent to the instrument in use.

### 9.1 Error Messages

Error messages are entered in the error/event queue of the status reporting system in the remote control mode and can be queried with the command `SYSTem:ERRor?`.

A short explanation of the device-specific error messages for the 3GPP FDD applications is given below.

| Status bar message      | Description  |
|-------------------------|--|
| Sync not found          | This message is displayed if synchronization is not possible.<br>Possible causes are that frequency, level, scrambling code, Invert Q values are set incorrectly, or the input signal is invalid.  |
| Sync OK                 | This message is displayed if synchronization is possible.  |
| Incorrect pilot symbols | This message is displayed if one or more of the received pilot symbols are not equal to the specified pilot symbols of the 3GPP standard.<br>Possible causes are: <ul style="list-style-type: none"> <li>• Incorrectly sent pilot symbols in the received frame.</li> <li>• Low signal to noise ratio (SNR) of the W-CDMA signal.</li> <li>• One or more code channels have a significantly lower power level compared to the total power. The incorrect pilots are detected in these channels because of low channel SNR.</li> <li>• One or more channels are sent with high power ramping. In slots with low relative power to total power, the pilot symbols might be detected incorrectly (check the signal quality by using the symbol constellation display</li> </ul> |

# 10 Remote Commands for 3GPP FDD Measurements

The following commands are required to perform measurements in R&S VSE 3GPP FDD Measurements applications in a remote environment.

It is assumed that the R&S VSE has already been set up for remote control in a network as described in the R&S VSE Base Software User Manual.

## General R&S VSE Remote Commands

The application-independent remote commands for general tasks on the R&S VSE are also available for 3GPP FDD measurements and are described in the R&S VSE User Manual. In particular, this comprises the following functionality:

- Controlling instruments and capturing data
- Managing Settings and Results
- Setting Up the Instrument
- Using the Status Register

## Channel-specific commands

Apart from a few general commands on the R&S VSE, most commands refer to the currently active channel. Thus, always remember to activate a 3GPP FDD channel before starting a remote program for a 3GPP FDD measurement.

After a short introduction, the tasks specific to the 3GPP FDD application are described here:

|  |     |
|--|-----|
| • <a href="#">Introduction</a> .....   | 112 |
| • <a href="#">Common Suffixes</a> .....  | 117 |
| • <a href="#">Activating 3GPP FDD Measurements</a> .....                                       | 118 |
| • <a href="#">Selecting a Measurement</a> .....  | 118 |
| • <a href="#">Restoring the Default Configuration (Preset)</a> .....                           | 119 |
| • <a href="#">Configuring Code Domain Analysis and Time Alignment Error Measurements</a> ..... | 119 |
| • <a href="#">Configuring the Result Display</a> .....   | 166 |
| • <a href="#">Retrieving Results</a> .....   | 177 |
| • <a href="#">Analysis</a> .....   | 195 |
| • <a href="#">Querying the Status Registers</a> .....  | 206 |
| • <a href="#">Commands for Compatibility</a> .....   | 209 |
| • <a href="#">Programming Examples (R&amp;S VSE-K72)</a> .....                                 | 212 |

## 10.1 Introduction

Commands are program messages that a controller (e.g. a PC) sends to the instrument or software. They operate its functions ('setting commands' or 'events') and request information ('query commands'). Some commands can only be used in one



way, others work in two ways (setting and query). If not indicated otherwise, the commands can be used for settings and queries.

The syntax of a SCPI command consists of a header and, in most cases, one or more parameters. To use a command as a query, you have to append a question mark after the last header element, even if the command contains a parameter.

A header contains one or more keywords, separated by a colon. Header and parameters are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). If there is more than one parameter for a command, these are separated by a comma from one another.

Only the most important characteristics that you need to know when working with SCPI commands are described here. For a more complete description, refer to the User Manual of the R&S VSE.



### Remote command examples

Note that some remote command examples mentioned in this general introduction may not be supported by this particular application.

## 10.1.1 Conventions used in Descriptions

Note the following conventions used in the remote command descriptions:

- **Command usage**  
If not specified otherwise, commands can be used both for setting and for querying parameters.  
If a command can be used for setting or querying only, or if it initiates an event, the usage is stated explicitly.
- **Parameter usage**  
If not specified otherwise, a parameter can be used to set a value and it is the result of a query.  
Parameters required only for setting are indicated as **Setting parameters**.  
Parameters required only to refine a query are indicated as **Query parameters**.  
Parameters that are only returned as the result of a query are indicated as **Return values**.
- **Conformity**  
Commands that are taken from the SCPI standard are indicated as **SCPI confirmed**. All commands used by the R&S VSE follow the SCPI syntax rules.
- **Asynchronous commands**  
A command which does not automatically finish executing before the next command starts executing (overlapping command) is indicated as an **Asynchronous command**.
- **Reset values (\*RST)**  
Default parameter values that are used directly after resetting the instrument (\*RST command) are indicated as **\*RST** values, if available.
- **Default unit**  
This is the unit used for numeric values if no other unit is provided with the parameter.

- **Manual operation**

If the result of a remote command can also be achieved in manual operation, a link to the description is inserted.

### 10.1.2 Long and Short Form

The keywords have a long and a short form. You can use either the long or the short form, but no other abbreviations of the keywords.

The short form is emphasized in upper case letters. Note however, that this emphasis only serves the purpose to distinguish the short from the long form in the manual. For the instrument, the case does not matter.

**Example:**

`SENSe:FREQuency:CENTer` is the same as `SENS:FREQ:CENT`.

### 10.1.3 Numeric Suffixes

Some keywords have a numeric suffix if the command can be applied to multiple instances of an object. In that case, the suffix selects a particular instance (e.g. a measurement window).

Numeric suffixes are indicated by angular brackets (<n>) next to the keyword.

If you don't quote a suffix for keywords that support one, a 1 is assumed.

**Example:**

`DISPlay[:WINDow<1...4>]:ZOOM:STATe` enables the zoom in a particular measurement window, selected by the suffix at `WINDow`.

`DISPlay:WINDow4:ZOOM:STATe ON` refers to window 4.

### 10.1.4 Optional Keywords

Some keywords are optional and are only part of the syntax because of SCPI compliance. You can include them in the header or not.

Note that if an optional keyword has a numeric suffix and you need to use the suffix, you have to include the optional keyword. Otherwise, the suffix of the missing keyword is assumed to be the value 1.

Optional keywords are emphasized with square brackets.

**Example:**

Without a numeric suffix in the optional keyword:

```
[SENSe:]FREQuency:CENTer is the same as FREQuency:CENTer
```

With a numeric suffix in the optional keyword:

```
DISPlay[:WINDow<1...4>]:ZOOM:STATe
```

DISPlay:ZOOM:STATe ON enables the zoom in window 1 (no suffix).

DISPlay:WINDow4:ZOOM:STATe ON enables the zoom in window 4.

### 10.1.5 Alternative Keywords

A vertical stroke indicates alternatives for a specific keyword. You can use both keywords to the same effect.

**Example:**

```
[SENSe:]BANDwidth|BWIDth[:RESolution]
```

In the short form without optional keywords, BAND 1MHZ would have the same effect as BWID 1MHZ.

### 10.1.6 SCPI Parameters

Many commands feature one or more parameters.

If a command supports more than one parameter, these are separated by a comma.

**Example:**

```
LAYout:ADD:WINDow Spectrum,LEFT,MTABLE
```

Parameters may have different forms of values.

- [Numeric Values](#)..... 115
- [Boolean](#)..... 116
- [Character Data](#)..... 117
- [Character Strings](#)..... 117
- [Block Data](#)..... 117

#### 10.1.6.1 Numeric Values

Numeric values can be entered in any form, i.e. with sign, decimal point or exponent. In case of physical quantities, you can also add the unit. If the unit is missing, the command uses the basic unit.

**Example:**

with unit: SENSe:FREQuency:CENTer 1GHZ

without unit: SENSe:FREQuency:CENTer 1E9 would also set a frequency of 1 GHz.

Values exceeding the resolution of the instrument are rounded up or down.

If the number you have entered is not supported (e.g. in case of discrete steps), the command returns an error.

Instead of a number, you can also set numeric values with a text parameter in special cases.

- **MIN/MAX**  
Defines the minimum or maximum numeric value that is supported.
- **DEF**  
Defines the default value.
- **UP/DOWN**  
Increases or decreases the numeric value by one step. The step size depends on the setting. In some cases you can customize the step size with a corresponding command.

### Querying numeric values

When you query numeric values, the system returns a number. In case of physical quantities, it applies the basic unit (e.g. Hz in case of frequencies). The number of digits after the decimal point depends on the type of numeric value.

#### Example:

Setting: `SENSe:FREQuency:CENTer 1GHZ`

Query: `SENSe:FREQuency:CENTer?` would return `1E9`

In some cases, numeric values may be returned as text.

- **INF/NINF**  
Infinity or negative infinity. Represents the numeric values `9.9E37` or `-9.9E37`.
- **NAN**  
Not a number. Represents the numeric value `9.91E37`. NAN is returned in case of errors.

### 10.1.6.2 Boolean

Boolean parameters represent two states. The "ON" state (logically true) is represented by "ON" or a numeric value 1. The "OFF" state (logically untrue) is represented by "OFF" or the numeric value 0.

#### Querying boolean parameters

When you query boolean parameters, the system returns either the value 1 ("ON") or the value 0 ("OFF").

#### Example:

Setting: `DISPlay:WINDow:ZOOM:STATe ON`

Query: `DISPlay:WINDow:ZOOM:STATe?` would return `1`

### 10.1.6.3 Character Data

Character data follows the syntactic rules of keywords. You can enter text using a short or a long form. For more information see [chapter 10.1.2, "Long and Short Form"](#), on page 114.

#### Querying text parameters

When you query text parameters, the system returns its short form.

#### Example:

Setting: `SENSe:BANDwidth:RESolution:TYPE NORMal`

Query: `SENSe:BANDwidth:RESolution:TYPE?` would return `NORM`

### 10.1.6.4 Character Strings

Strings are alphanumeric characters. They have to be in straight quotation marks. You can use a single quotation mark ( ' ) or a double quotation mark ( " ).

#### Example:

`INSTRument:DELeTe 'Spectrum'`

### 10.1.6.5 Block Data

Block data is a format which is suitable for the transmission of large amounts of data.

The ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes all end or other control signs are ignored until all bytes are transmitted. #0 specifies a data block of indefinite length. The use of the indefinite format requires a `NL^END` message to terminate the data block. This format is useful when the length of the transmission is not known or if speed or other considerations prevent segmentation of the data into blocks of definite length.

## 10.2 Common Suffixes

In 3GPP FDD applications, the following common suffixes are used in remote commands:

| Suffix | Value range | Description |
|--------|-------------|-------------|
| <n>    | 1..x        | Window      |
| <t>    | 1           | Trace       |
| <m>    | 1..4        | Marker      |

## 10.3 Activating 3GPP FDD Measurements

3GPP FDD measurements require a special application in the R&S VSE. The common commands for configuring and controlling measurement channels, as well as blocks and sequences, are also used in the R&S VSE 3GPP FDD Measurements application.

They are described in the R&S VSE Base Software User Manual.

## 10.4 Selecting a Measurement

The following commands are required to define the measurement type in a remote environment. For details on available measurements see [chapter 3, "Measurements and Result Display"](#), on page 11.

|   |     |
|---|-----|
| <a href="#">CONFigure:WCDPower[:BTS]:MEASurement.....</a> | 118 |
| <a href="#">CONFigure:WCDPower:MS:MEASurement.....</a>    | 118 |

---

### CONFigure:WCDPower[:BTS]:MEASurement <Type>

This command selects the type of 3GPP FDD BTS base station tests.

#### Parameters:

|        |   |
|--------|---|
| <Type> | <b>WCDPower</b><br>Code domain power measurement. This selection has the same effect as command <code>INSTRUMENT:SELECT BWCD</code> |
|        | <b>TAError</b><br>Time Alignment Error measurement  |
|        | *RST:       WCDPower  |

**Example:**       CONF:WCDP:MEAS TAE

**Mode:**           BTS application only

**Manual operation:** See "[Result List](#)" on page 30  
See "[Creating a New Channel Table from the Measured Signal \(Measure Table\)](#)" on page 75

---

### CONFigure:WCDPower:MS:MEASurement <Type>

This command selects the 3GPP FDD UE user equipment tests.

#### Parameters:

|        |   |
|--------|---|
| <Type> | <b>WCDPower</b><br>Code domain power measurement. This selection has the same effect as command <code>INSTRUMENT:SELECT MWCD</code> |
|        | *RST:       WCDPower  |

**Example:**       CONF:WCDP:MS:MEAS TAE

**Mode:**           UE application only

**Manual operation:** See "Creating a New Channel Table from the Measured Signal (Measure Table)" on page 75

## 10.5 Restoring the Default Configuration (Preset)

[SYSTem:PRESet:CHANnel\[:EXECute\]](#)..... 119

### **SYSTem:PRESet:CHANnel[:EXECute]**

This command restores the default software settings in the current channel.

Use `INST:SEL` to select the channel.

**Example:**

```
INST 'Spectrum2'
```

Selects the channel for "Spectrum2".

```
SYST:PRESet:CHAN:EXEC
```

Restores the factory default settings to the "Spectrum2" channel.

**Usage:** Event

**Manual operation:** See "Preset Channel" on page 48

## 10.6 Configuring Code Domain Analysis and Time Alignment Error Measurements

The following commands are required to configure Code Domain Analysis and Time Alignment Error measurements.

- [Signal Description](#)..... 119
- [Configuring the Data Input and Output](#)..... 125
- [Frontend Configuration](#)..... 128
- [Configuring Triggered Measurements](#)..... 135
- [Signal Capturing](#)..... 141
- [Synchronization](#)..... 144
- [Channel Detection](#)..... 146
- [Automatic Settings](#)..... 158
- [Evaluation Range](#)..... 161
- [Code Domain Analysis Settings \(BTS Measurements\)](#)..... 163
- [Code Domain Analysis Settings \(UE Measurements\)](#)..... 165

### 10.6.1 Signal Description

The signal description provides information on the expected input signal.

- [BTS Signal Description](#)..... 120
- [BTS Scrambling Code](#)..... 123
- [UE Signal Description](#)..... 124

### 10.6.1.1 BTS Signal Description

The following commands describe the input signal in BTS measurements.

|   |     |
|---|-----|
| [SENSe:]CDPower:ANTenna.....              | 120 |
| [SENSe:]CDPower:HSDPamode.....            | 120 |
| [SENSe:]CDPower:LCODE:SEARch[:IMMediate]? | 121 |
| [SENSe:]CDPower:LCODE:SEARch:LIST?        | 121 |
| [SENSe:]CDPower:MIMO.....                 | 122 |
| [SENSe:]CDPower:PCONtrol.....             | 122 |

---

#### [SENSe:]CDPower:ANTenna <Mode>

This command activates or deactivates the antenna diversity mode and selects the antenna to be used.

##### Parameters:

<Mode>                    OFF | 1 | 2  
 \*RST:                    OFF

**Example:**                CDP:ANT 1

**Mode:**                    BTS application only

**Manual operation:**    See "Antenna Diversity" on page 50  
                               See "Antenna Number" on page 50  
                               See "Antenna1 / Antenna2" on page 71

---

#### [SENSe:]CDPower:HSDPamode <State>

This command defines whether the HS-DPCCH channel is searched or not.

##### Parameters:

<State>                    ON | OFF | 0 | 1  
**ON | 1**  
 The high speed channels can be detected. A detection of the modulation type (QPSK /16QAM) is done instead of a detection of pilot symbols.  
**OFF | 0**  
 The high speed channel can not be detected. A detection of pilot symbols is done instead a detection of the modulation type (QPSK /16QAM)  
 \*RST:                    1

**Example:**                SENS:CDP:HSDP OFF

**Manual operation:**    See "HSDPA/UPA" on page 49



**[SENSe:]CDPower:LCODE:SEARch[:IMMediate]?**

This command automatically searches for the scrambling codes that lead to the highest signal power. The code with the highest power is stored as the new scrambling code for further measurements.

Searching requires that the correct center frequency and level are set. The scrambling code search can automatically determine the primary scrambling code number. The secondary scrambling code number is expected as 0. Alternative scrambling codes can not be detected. Therefore the range for detection is 0x0000 – 0x1FF0h, where the last digit is always 0.

If the search is successful (PASS), a code was found and can be queried using [\[SENSe:\]CDPower:LCODE:SEARch:LIST?](#).

**Parameters:**

<Status>                   **PASSed**  
Scrambling code(s) found.

**FAILed**  
No scrambling code found.

**Example:**

`SENS:CDP:LCOD:SEAR?`  
Searches the scrambling code that leads to the highest signal power and returns the status of the search.

**Usage:**                   Query only

**Mode:**                    BTS application only

**Manual operation:**    See "[Autosearch for Scrambling Code](#)" on page 51

**[SENSe:]CDPower:LCODE:SEARch:LIST?**

This command returns the automatic search sequence (see [\[SENSe:\]CDPower:LCODE:SEARch\[:IMMediate\]?](#) on page 121) as a comma-separated list of results for each detected scrambling code.

**Return values:**

<Code1>                    Scrambling code in decimal format.  
Range:            16 \* n, with n = 0...511

<Code2>                    Scrambling code in hexadecimal format.  
Range:            0x0000h – 0x1FF0h, where the last digit is always 0

<CPICHPower>            Highest power value for the corresponding scrambling code.

**Example:**

`SENS:CDP:LCOD:SEAR:LIST?`  
Result:  
16,0×10,-18.04,32,0×20,-22.87,48,0×30,-27.62,  
64,0×40,-29.46  
(Explanation in table below)

**Usage:**                   Query only

**Mode:**                    BTS application only

**Manual operation:** See "Scrambling Codes" on page 51

*Table 10-1: Description of query results in example:*

| Code (dec) | Code(hex) | CPICH power (dBm) |
|------------|-----------|-------------------|
| 16         | 0x10      | -18.04            |
| 32         | 0x20      | -22.87            |
| 48         | 0x30      | -27.62            |
| 64         | 0x40      | -29.46            |

---

#### [SENSe:]CDPower:MIMO <State>

Activates or deactivates single antenna MIMO measurement mode.

Channels that have modulation type MIMO-QPSK or MIMO-16QAM are only recognized as active channels if this setting is ON.

For details see "MIMO" on page 50.

#### Parameters:

<State> ON | OFF  
\*RST: OFF

**Example:** SENS:CDP:MIMO ON

**Mode:** BTS application only

**Manual operation:** See "MIMO" on page 50

---

#### [SENSe:]CDPower:PCONTrol <Position>

This command determines the power control measurement position. An enhanced channel search is used to consider the properties of compressed mode channels.

#### Parameters:

<Position> SLOT | PILot  
**SLOT**  
The slot power is averaged from the beginning of the slot to the end of the slot.  
**PILot**  
The slot power is averaged from the beginning of the pilot symbols of the previous slot to the beginning of the pilot symbols of the current slot.  
\*RST: PILot

- Example:**            `SENS:CDP:PCON SLOT`  
Switch to power averaging from slot start to the end of the slot. An enhanced channel search is used to consider the properties of compressed mode channels.
- `SENS:CDP:PCON P1L`  
Switch to power averaging from the pilot symbols of the previous slot number to the start of the pilots of the displayed slot number.  
The channel search only considers standard channels.
- Mode:**                BTS application only
- Manual operation:** See "[Compressed Mode](#)" on page 50

### 10.6.1.2 BTS Scrambling Code

The scrambling code identifies the base station transmitting the signal in BTS measurements.

|   |     |
|---|-----|
| <a href="#">[SENSe:]CDPower:LCODE:DVALue</a> .....  | 123 |
| <a href="#">[SENSe:]CDPower:LCODE[:VALue]</a> ..... | 123 |

---

#### **[SENSe:]CDPower:LCODE:DVALue** <ScramblingCode>

This command defines the scrambling code in decimal format.

**Parameters:**

<ScramblingCode>    <numeric value>  
                          \*RST:        0

**Example:**            `SENS:CDP:LCOD:DVAL 3`  
Defines the scrambling code in decimal format.

**Manual operation:** See "[Scrambling Code](#)" on page 51  
                          See "[Format Hex/Dec](#)" on page 51  
                          See "[Format](#)" on page 53

---

#### **[SENSe:]CDPower:LCODE[:VALue]** <ScramblingCode>

This command defines the scrambling code in hexadecimal format.

**Parameters:**

<ScramblingCode>    Range:        #H0 to #H1fff  
                          \*RST:        #H0

**Example:**            `SENS:CDP:LCOD #H2`  
Defines the scrambling code in hexadecimal format.

**Manual operation:** See "[Format Hex/Dec](#)" on page 51  
                          See "[Scrambling Code](#)" on page 52

### 10.6.1.3 UE Signal Description

The following commands describe the input signal in UE measurements.

Useful commands for describing UE signals described elsewhere:

- [\[SENSe:\]CDPower:LCODE\[:VALue\]](#) on page 123
- [\[SENSe:\]CDPower:HSDPamode](#) on page 120

**Remote commands exclusive to describing UE signals:**

|  |     |
|--|-----|
| <a href="#">[SENSe:]CDPower:LCODE:TYPE</a> ..... | 124 |
| <a href="#">[SENSe:]CDPower:QPSK</a> .....       | 124 |
| <a href="#">[SENSe:]CDPower:SFACTOR</a> .....    | 124 |

---

#### **[SENSe:]CDPower:LCODE:TYPE <Type>**

This command switches between long and short scrambling code.

**Parameters:**

<Type> LONG | SHORT  
\*RST: LONG

**Example:** CDP:LCOD:TYPE SHOR

**Mode:** UE application only

**Manual operation:** See "[Type](#)" on page 53

---

#### **[SENSe:]CDPower:QPSK <State>**

If enabled, it is assumed that the signal uses QPSK modulation only. Thus, no synchronization is required and the measurement can be performed with optimized settings and speed.

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Mode:** BTS application only

**Manual operation:** See "[QPSK Modulation Only](#)" on page 53

---

#### **[SENSe:]CDPower:SFACTOR <SpreadingFactor>**

This command defines the spreading factor. The spreading factor is only significant for Peak Code Domain Error evaluation.

**Parameters:**

<SpreadingFactor> 4 | 8 | 16 | 32 | 64 | 128 | 256 | 512  
\*RST: 512

**Example:** SENS:CDP:SFACTOR 16

## 10.6.2 Configuring the Data Input and Output

- [RF Input](#)..... 125
- [Configuring the Outputs](#)..... 128

### 10.6.2.1 RF Input

|  |     |
|--|-----|
| <a href="#">INPut:ATTenuation:PROTection[:STATe]</a> .....       | 125 |
| <a href="#">INPut:COUPling</a> .....                             | 125 |
| <a href="#">INPut:FILTer:HPASS[:STATe]</a> .....                 | 126 |
| <a href="#">INPut:FILTer:YIG[:STATe]</a> .....                   | 126 |
| <a href="#">INPut:IMPedance</a> .....                            | 126 |
| <a href="#">INPut:PRESelection:SET</a> .....                     | 127 |
| <a href="#">INPut:PRESelection[:STATe]</a> .....                 | 127 |
| <a href="#">INPut:SELEct</a> .....                               | 127 |
| <a href="#">INPut:TYPE</a> .....                                 | 127 |
| <a href="#">INSTrument:BLOCK:CHANnel[:SETTings]:SOURce</a> ..... | 128 |

---

#### **INPut:ATTenuation:PROTection[:STATe]** <State>

This command turns the availability of attenuation levels of 10 dB or less on and off.

##### Parameters:

<State>                    ON | OFF  
 \*RST:                    OFF

**Example:**                INP:ATT:PROT ON

**Manual operation:**    See "[10 dB Minimum Attenuation](#)" on page 56

---

#### **INPut:COUPling** <CouplingType>

This command selects the coupling type of the RF input.

##### Parameters:

<CouplingType>        **AC**  
                              AC coupling  
                              **DC**  
                              DC coupling  
 \*RST:                    AC

**Example:**                INP:COUP DC

**Usage:**                    SCPI confirmed

**Manual operation:**    See "[Input Coupling](#)" on page 54

**INPut:FILTer:HPASs[:STATe]** <State>

Activates an additional internal high-pass filter for RF input signals from 1 GHz to 3 GHz. This filter is used to remove the harmonics of the instrument in use in order to measure the harmonics for a DUT, for example.

This function requires an additional high-pass filter hardware option.

(Note: for RF input signals outside the specified range, the high-pass filter has no effect. For signals with a frequency of approximately 4 GHz upwards, the harmonics are suppressed sufficiently by the YIG filter.)

**Parameters:**

<State>                    ON | OFF  
\*RST:                    OFF

**Example:**                INP:FILT:HPAS ON  
Turns on the filter.

**Usage:**                    SCPI confirmed

**Manual operation:**    See "[High-Pass Filter 1...3 GHz](#)" on page 55

**INPut:FILTer:YIG[:STATe]** <State>

This command turns the YIG-preselector on and off.

Note the special conditions and restrictions for the YIG filter described in "[YIG-Preselector](#)" on page 55.

**Example:**                INP:FILT:YIG OFF  
Deactivates the YIG-preselector.

**Manual operation:**    See "[YIG-Preselector](#)" on page 55

**INPut:IMPedance** <Impedance>

This command selects the nominal input impedance of the RF input. In some applications, only 50 Ω are supported.

75 Ω should be selected if the 50 Ω input impedance is transformed to a higher impedance using a matching pad of the RAZ type (= 25 Ω in series to the input impedance of the instrument). The power loss correction value in this case is 1.76 dB = 10 log (75Ω/50Ω).

**Parameters:**

<Impedance>              50 | 75  
\*RST:                    50 Ω

**Example:**                INP:IMP 75

**Usage:**                    SCPI confirmed

**Manual operation:**    See "[Impedance](#)" on page 55

---

**INPut:PRESelection:SET** <Mode>

This command selects the preselector mode.

The command is available with the optional preselector.

**Parameters:**

&lt;Mode&gt;

**NARRow**

Performs a measurement by automatically applying all available combinations of low and high pass filters consecutively. These combinations all have a narrow bandwidth.

**WIDE**

Performs a measurement by automatically applying all available bandpass filters consecutively. The bandpass filters have a wide bandwidth.

**Manual operation:** See "[Preselector Mode](#)" on page 56

---

**INPut:PRESelection[:STATe]** <State>

This command turns the preselector on and off.

**Manual operation:** See "[Preselector State](#)" on page 55

---

**INPut:SElect** <Source>

This command selects the signal source for measurements, i.e. it defines which connector is used to input data to the R&S VSE.

**Parameters:**

&lt;Source&gt;

**RF**

Radio Frequency ("RF INPUT" connector)

**FIQ**

I/Q data file

\*RST: RF

**Manual operation:** See "[Input Type](#)" on page 54

---

**INPut:TYPE** <Input>

The command selects the signal source.

**Parameters:**

&lt;Input&gt;

**INPUT1**

Selects RF input 1.

**INPUT2**

Selects RF input 2.

\*RST: INPUT1

**Example:**

```
INP:TYPE INPUT1
```

Selects RF input 1.

**Manual operation:** See ["Input Selection"](#) on page 56

**INSTRument:BLOCK:CHANnel[:SETTings]:SOURce <Type>**

Selects an instrument or a file as the source of input provided to the channel.

**Parameters:**

- <Type> FILE | DEVIce | NONE
- FILE**  
A loaded file is used for input.
- DEVIce**  
A configured device provides input for the measurement
- NONE**  
No input source defined.

**Manual operation:** See ["Input Type"](#) on page 54

**10.6.2.2 Configuring the Outputs**



Configuring trigger input/output is described in [chapter 10.6.4.2, "Configuring the Trigger Output"](#), on page 139.

DIAGnostic:SERVice:NSource..... 128

**DIAGnostic:SERVice:NSource <State>**

This command turns the 28 V supply of the BNC connector labeled NOISE SOURCE CONTROL on the instrument in use on and off.

**Parameters:**

- <State> ON | OFF
- \*RST: OFF

**Example:** DIAG:SERV:NSO ON

**Manual operation:** See ["Noise Source"](#) on page 58

**10.6.3 Frontend Configuration**

The following commands configure frequency, amplitude and y-axis scaling settings, which represent the "frontend" of the measurement setup.

- [Frequency](#)..... 129
- [Amplitude Settings](#)..... 130
- [Configuring the Attenuation](#)..... 133



### 10.6.3.1 Frequency

|   |     |
|---|-----|
| [SENSe:]FREQUENCY:CENTer.....           | 129 |
| [SENSe:]FREQUENCY:CENTer:STEP.....      | 129 |
| [SENSe:]FREQUENCY:CENTer:STEP:AUTO..... | 130 |
| [SENSe:]FREQUENCY:OFFSet.....           | 130 |

---

#### [SENSe:]FREQUENCY:CENTer <Frequency>

This command defines the center frequency.

##### Parameters:

<Frequency>            The allowed range and  $f_{\max}$  is specified in the data sheet.

##### UP

Increases the center frequency by the step defined using the  
[SENSe:]FREQUENCY:CENTer:STEP command.

##### DOWN

Decreases the center frequency by the step defined using the  
[SENSe:]FREQUENCY:CENTer:STEP command.

\*RST:             $f_{\max}/2$

Default unit: Hz

##### Example:

```
FREQ:CENT 100 MHz
FREQ:CENT:STEP 10 MHz
FREQ:CENT UP
Sets the center frequency to 110 MHz.
```

**Usage:**            SCPI confirmed

**Manual operation:** See "[Center frequency](#)" on page 64

---

#### [SENSe:]FREQUENCY:CENTer:STEP <StepSize>

This command defines the center frequency step size.

You can increase or decrease the center frequency quickly in fixed steps using the  
SENS:FREQ UP AND SENS:FREQ DOWN commands, see [SENSe:]FREQUENCY:  
CENTer on page 129.

##### Parameters:

<StepSize>             $f_{\max}$  is specified in the data sheet.

Range:            1 to  $f_{\max}$

\*RST:            0.1 x span

Default unit: Hz

##### Example:

```
FREQ:CENT 100 MHz
FREQ:CENT:STEP 10 MHz
FREQ:CENT UP
Sets the center frequency to 110 MHz.
```

**Manual operation:** See "[Center Frequency Stepsize](#)" on page 64

**[SENSe:]FREQuency:CENTer:STEP:AUTO <State>**

This command couples or decouples the center frequency step size to the span.

In time domain (zero span) measurements, the center frequency is coupled to the RBW.

**Parameters:**

<State> ON | OFF | 0 | 1  
\*RST: 1

**Example:**

FREQ:CENT:STEP:AUTO ON  
Activates the coupling of the step size to the span.

**[SENSe:]FREQuency:OFFSet <Offset>**

This command defines a frequency offset.

If this value is not 0 Hz, the application assumes that the input signal was frequency shifted outside the application. All results of type "frequency" will be corrected for this shift numerically by the application.

See also "[Frequency Offset](#)" on page 65.

**Parameters:**

<Offset> Range: -100 GHz to 100 GHz  
\*RST: 0 Hz

**Example:**

FREQ:OFFS 1GHZ

**Usage:**

SCPI confirmed

**Manual operation:** See "[Frequency Offset](#)" on page 65

**10.6.3.2 Amplitude Settings**

The following commands are required to configure the amplitude settings in a remote environment.

Useful commands for amplitude settings described elsewhere:

- [INPut:COUPling](#) on page 125
- [INPut:IMPedance](#) on page 126
- [\[SENSe:\]ADJust:LEVel](#) on page 161

**Remote commands exclusive to amplitude settings:**

|  |     |
|--|-----|
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:Y[:SCALe]:AUTO ONCE</a> ..... | 131 |
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:Y[:SCALe]:MAXimum</a> .....   | 131 |
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:Y[:SCALe]:MINimum</a> .....   | 131 |
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:Y[:SCALe]:PDIVision</a> ..... | 132 |
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:TRACe&lt;t&gt;:Y[:SCALe]:RLEVel</a> .....    | 132 |

|   |     |
|---|-----|
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet..... | 132 |
| INPut:GAIN:STATe.....                                     | 132 |
| INPut:GAIN[:VALue].....                                   | 133 |

---

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO ONCE

Automatic scaling of the y-axis is performed once, then switched off again (for all traces, <t> is irrelevant).

**Usage:** SCPI confirmed

**Manual operation:** See "[Auto Scale Once](#)" on page 63

---

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MAXimum <Value>

This command defines the maximum value of the y-axis for all traces in the selected result display.

The suffix <t> is irrelevant.

**Parameters:**

<Value>                      <numeric value>  
 \*RST:                      depends on the result display  
 The unit and range depend on the result display.

**Example:**                      DISP:TRAC:Y:MIN -60  
   DISP:TRAC:Y:MAX 0  
 Defines the y-axis with a minimum value of -60 and maximum value of 0.

**Manual operation:** See "[Y-Maximum, Y-Minimum](#)" on page 63

---

#### DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MINimum <Value>

This command defines the minimum value of the y-axis for all traces in the selected result display.

The suffix <t> is irrelevant.

**Parameters:**

<Value>                      <numeric value>  
 \*RST:                      depends on the result display  
 The unit and range depend on the result display.

**Example:**                      DISP:TRAC:Y:MIN -60  
   DISP:TRAC:Y:MAX 0  
 Defines the y-axis with a minimum value of -60 and maximum value of 0.

**Manual operation:** See "[Y-Maximum, Y-Minimum](#)" on page 63

**DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:PDIVision <Value>**

This remote command determines the grid spacing on the Y-axis for all diagrams, where possible.

The suffix <t> is irrelevant.

**Parameters:**

<Value>                    numeric value WITHOUT UNIT (unit according to the result display)  
 Defines the range per division (total range = 10\*<Value>)  
 \*RST:                    depends on the result display

**Example:**

DISP:TRAC:Y:PDIV 10  
 Sets the grid spacing to 10 units (e.g. dB) per division  
 (For example 10 dB in the Code Domain Power result display.)

**DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel <ReferenceLevel>**

This command defines the reference level (for all traces, <t> is irrelevant).

With a reference level offset ≠ 0, the value range of the reference level is modified by the offset.

**Parameters:**

<ReferenceLevel>        The unit is variable.  
 Range:                    see datasheet  
 \*RST:                    0 dBm

**Example:**

DISP:TRAC:Y:RLEV -60dBm

**Usage:**                    SCPI confirmed

**Manual operation:**    See "[Reference Level](#)" on page 60

**DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLEVel:OFFSet <Offset>**

This command defines a reference level offset (for all traces, <t> is irrelevant).

**Parameters:**

<Offset>                    Range:                    -200 dB to 200 dB  
 \*RST:                    0dB

**Example:**

DISP:TRAC:Y:RLEV:OFFS -10dB

**Manual operation:**    See "[Shifting the Display \(Offset\)](#)" on page 60

**INPut:GAIN:STATe <State>**

This command turns the preamplifier on the instrument in use on and off. It requires the additional preamplifier hardware option on the connected instrument.

Depending on the instrument in use, the preamplification is defined by `INPut:GAIN[:VALue]`.

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Example:**

INP:GAIN:STAT ON  
 Switches on 30 dB preamplification.

**Usage:**

SCPI confirmed

**Manual operation:** See "Preamplifier" on page 62

**INPut:GAIN[:VALue] <Gain>**

This command selects the gain level if the preamplifier is activated (INP:GAIN:STAT ON, see INPut:GAIN:STATe on page 132).

The command requires the additional preamplifier hardware option.

**Parameters:**

<Gain> 15 dB | 30 dB  
 The availability of gain levels depends on the model of the instrument in use.  
 \*RST: OFF

**Example:**

INP:GAIN:VAL 30  
 Switches on 30 dB preamplification.

**Usage:**

SCPI confirmed

**Manual operation:** See "Preamplifier" on page 62

**10.6.3.3 Configuring the Attenuation**

|                             |     |
|-----------------------------|-----|
| INPut:ATTenuation.....      | 133 |
| INPut:ATTenuation:AUTO..... | 134 |
| INPut:EATT.....             | 134 |
| INPut:EATT:AUTO.....        | 134 |
| INPut:EATT:STATe.....       | 135 |

**INPut:ATTenuation <Attenuation>**

This command defines the total attenuation for RF input.

If you set the attenuation manually, it is no longer coupled to the reference level, but the reference level is coupled to the attenuation. Thus, if the current reference level is not compatible with an attenuation that has been set manually, the command also adjusts the reference level.

**Parameters:**

<Attenuation> Range: see data sheet  
 Increment: 5 dB  
 \*RST: 10 dB (AUTO is set to ON)

- Example:** `INP:ATT 30dB`  
 Defines a 30 dB attenuation and decouples the attenuation from the reference level.
- Usage:** SCPI confirmed
- Manual operation:** See "[Attenuation Mode / Value](#)" on page 61

**INPut:ATTenuation:AUTO** <State>

This command couples or decouples the attenuation to the reference level. Thus, when the reference level is changed, the R&S VSE determines the signal level for optimal internal data processing and sets the required attenuation accordingly.

**Parameters:**

<State> ON | OFF | 0 | 1  
 \*RST: 1

- Example:** `INP:ATT:AUTO ON`  
 Couples the attenuation to the reference level.

- Usage:** SCPI confirmed
- Manual operation:** See "[Attenuation Mode / Value](#)" on page 61

**INPut:EATT** <Attenuation>

This command defines an electronic attenuation manually. Automatic mode must be switched off (`INP:EATT:AUTO OFF`, see `INPut:EATT:AUTO` on page 134).

If the current reference level is not compatible with an attenuation that has been set manually, the command also adjusts the reference level.

This command requires the electronic attenuation hardware option.

**Parameters:**

<Attenuation> attenuation in dB  
 Range: see data sheet  
 Increment: 1 dB  
 \*RST: 0 dB (OFF)

- Example:** `INP:EATT:AUTO OFF`  
`INP:EATT 10 dB`

- Manual operation:** See "[Using Electronic Attenuation](#)" on page 61

**INPut:EATT:AUTO** <State>

This command turns automatic selection of the electronic attenuation on and off.

If on, electronic attenuation reduces the mechanical attenuation whenever possible.

This command requires the electronic attenuation hardware option.

**Parameters:**

<State> ON | OFF | 0 | 1  
 \*RST: 1

**Example:**

INP:EATT:AUTO OFF

**Manual operation:** See ["Using Electronic Attenuation"](#) on page 61

**INPut:EATT:STATe <State>**

This command turns the electronic attenuator on and off.

This command requires the electronic attenuation hardware option.

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Example:**

INP:EATT:STAT ON

Switches the electronic attenuator into the signal path.

**Manual operation:** See ["Using Electronic Attenuation"](#) on page 61

## 10.6.4 Configuring Triggered Measurements

The following commands are required to configure a triggered measurement in a remote environment.

The tasks for manual operation are described in [chapter 5.1.5, "Trigger Settings"](#), on page 65

Note that the availability of trigger settings depends on the instrument in use.



The \*OPC command should be used after commands that retrieve data so that subsequent commands to change the selected trigger source are held off until after the sweep is completed and the data has been returned.

- [Configuring the Triggering Conditions](#).....135
- [Configuring the Trigger Output](#).....139

### 10.6.4.1 Configuring the Triggering Conditions

The following commands are required to configure a triggered measurement.

Note that the availability of trigger sources depends on the instrument in use.

|   |     |
|---|-----|
| <a href="#">TRIGger[:SEQuence]:DTIME</a> .....                        | 136 |
| <a href="#">TRIGger[:SEQuence]:HOLDoff[:TIME]</a> .....               | 136 |
| <a href="#">TRIGger[:SEQuence]:IFPower:HOLDoff</a> .....              | 136 |
| <a href="#">TRIGger[:SEQuence]:IFPower:HYSteresis</a> .....           | 136 |
| <a href="#">TRIGger[:SEQuence]:LEVel[:EXTernal&lt;port&gt;]</a> ..... | 137 |
| <a href="#">TRIGger[:SEQuence]:LEVel:IFPower</a> .....                | 137 |

|  |     |
|--|-----|
| TRIGger[:SEQuence]:LEVel:IQPower.....  | 137 |
| TRIGger[:SEQuence]:LEVel:RFPower.....  | 138 |
| TRIGger[:SEQuence]:SLOPe.....          | 138 |
| TRIGger[:SEQuence]:SOURce.....         | 138 |
| TRIGger[:SEQuence]:TIME:RINTerval..... | 139 |

---

#### TRIGger[:SEQuence]:DTIME <DropoutTime>

Defines the time the input signal must stay below the trigger level before a trigger is detected again.

##### Parameters:

<DropoutTime> Dropout time of the trigger.  
 Range: 0 s to 10.0 s  
 \*RST: 0 s

---

#### TRIGger[:SEQuence]:HOLDoff[:TIME] <Offset>

Defines the time offset between the trigger event and the start of the measurement.

##### Parameters:

<Offset> \*RST: 0 s

**Example:** TRIG:HOLD 500us

**Manual operation:** See "[Trigger Offset](#)" on page 66

---

#### TRIGger[:SEQuence]:IFPower:HOLDoff <Period>

This command defines the holding time before the next trigger event.

Note that this command can be used for **any trigger source**, not just IF Power (despite the legacy keyword).

##### Parameters:

<Period> Range: 0 s to 10 s  
 \*RST: 0 s

**Example:** TRIG:SOUR EXT  
 Sets an external trigger source.  
 TRIG:IFP:HOLD 200 ns  
 Sets the holding time to 200 ns.

---

#### TRIGger[:SEQuence]:IFPower:HYSTeresis <Hysteresis>

This command defines the trigger hysteresis, which is only available for "IF Power" trigger sources.

##### Parameters:

<Hysteresis> Range: 3 dB to 50 dB  
 \*RST: 3 dB



**Example:**           TRIG:SOUR IFP  
Sets the IF power trigger source.  
TRIG:IFP:HYST 10DB  
Sets the hysteresis limit value.

#### TRIGger[:SEQUence]:LEVel[:EXTernal<port>] <TriggerLevel>

This command defines the level the external signal must exceed to cause a trigger event.

**Suffix:**  
<port>               Selects the trigger port.  
1 = trigger port 1 (TRIGGER INPUT connector on front panel)  
2 = trigger port 2 (TRIGGER INPUT/OUTPUT connector on front panel)  
3 = trigger port 3 (TRIGGER3 INPUT/OUTPUT connector on rear panel)

**Parameters:**  
<TriggerLevel>     Range:     0.5 V to 3.5 V  
                      \*RST:     1.4 V

**Example:**           TRIG:LEV 2V

**Manual operation:** See "[Trigger Level](#)" on page 66

#### TRIGger[:SEQUence]:LEVel:IFPower <TriggerLevel>

This command defines the power level at the third intermediate frequency that must be exceeded to cause a trigger event. Note that any RF attenuation or preamplification is considered when the trigger level is analyzed. If defined, a reference level offset is also considered.

**Parameters:**  
<TriggerLevel>     For details on available trigger levels and trigger bandwidths see the data sheet.  
                      \*RST:     -10 dBm

**Example:**           TRIG:LEV:IFP -30DBM

#### TRIGger[:SEQUence]:LEVel:IQPower <TriggerLevel>

This command defines the magnitude the I/Q data must exceed to cause a trigger event. Note that any RF attenuation or preamplification is considered when the trigger level is analyzed.

**Parameters:**  
<TriggerLevel>     Range:     -130 dBm to 30 dBm  
                      \*RST:     -20 dBm

**Example:**           TRIG:LEV:IQP -30DBM

---

**TRIGger[:SEQuence]:LEVel:RFPower <TriggerLevel>**

This command defines the power level the RF input must exceed to cause a trigger event. Note that any RF attenuation or preamplification is considered when the trigger level is analyzed. If defined, a reference level offset is also considered.

The input signal must be between 500 MHz and 8 GHz.

**Parameters:**

<TriggerLevel> For details on available trigger levels and trigger bandwidths see the data sheet.

\*RST: -20 dBm

**Example:** TRIG:LEV:RFP -30dBm

---

**TRIGger[:SEQuence]:SLOPe <Type>****Parameters:**

<Type> POSitive | NEGative

**POSitive**

Triggers when the signal rises to the trigger level (rising edge).

**NEGative**

Triggers when the signal drops to the trigger level (falling edge).

\*RST: POSitive

**Example:** TRIG:SLOP NEG

**Manual operation:** See "[Slope](#)" on page 67

---

**TRIGger[:SEQuence]:SOURce <Source>**

This command selects the trigger source.

Note that the availability of trigger sources depends on the instrument in use.

**Note on external triggers:**

If a measurement is configured to wait for an external trigger signal in a remote control program, remote control is blocked until the trigger is received and the program can continue. Make sure this situation is avoided in your remote control programs.

**Parameters:**

&lt;Source&gt;

**IMMediate**

Free Run

**EXT | EXT2 | EXT3 | EXT4**

Trigger signal from the corresponding TRIGGER INPUT/OUTPUT connector on the instrument in use, or the oscilloscope's corresponding input channel.

For details on the connectors see the instrument's Getting Started manual.

**RFPower**

First intermediate frequency

(Frequency and time domain measurements only.)

**IFPower**

Second intermediate frequency

(For frequency and time domain measurements only.)

**MAGNitude**

For (offline) input from a file, rather than an instrument. Triggers on a specified signal level.

\*RST: IMMediate

**Example:**

TRIG:SOUR EXT

Selects the external trigger input as source of the trigger signal

**Manual operation:**See "[Trigger Source](#)" on page 66See "[Free Run](#)" on page 66See "[External Trigger<X>](#)" on page 66**TRIGger[:SEquence]:TIME:RINTerval <Interval>**

This command defines the repetition interval for the time trigger.

**Parameters:**

&lt;Interval&gt;

2.0 ms to 5000

Range: 2 ms to 5000 s

\*RST: 1.0 s

**Example:**

TRIG:SOUR TIME

Selects the time trigger input for triggering.

TRIG:TIME:RINT 50

The measurement starts every 50 s.

**10.6.4.2 Configuring the Trigger Output**

The following commands are required to send the trigger signal to one of the variable TRIGGER INPUT/OUTPUT connectors on the instrument in use.

|   |     |
|---|-----|
| OUTPut:TRIGger<port>:DIRection.....       | 140 |
| OUTPut:TRIGger<port>:LEVel.....           | 140 |
| OUTPut:TRIGger<port>:OTYPe.....           | 140 |
| OUTPut:TRIGger<port>:PULSe:IMMediate..... | 141 |
| OUTPut:TRIGger<port>:PULSe:LENGth.....    | 141 |

---

### OUTPut:TRIGger<port>:DIRection <Direction>

This command selects the trigger direction for trigger ports that serve as an input as well as an output.

#### Suffix:

<port>

#### Parameters:

<Direction>

#### INPut

Port works as an input.

#### OUTPut

Port works as an output.

\*RST: INPut

**Manual operation:** See "Trigger 2/3" on page 58

---

### OUTPut:TRIGger<port>:LEVel <Level>

This command defines the level of the signal generated at the trigger output.

This command works only if you have selected a user defined output with `OUTPut:TRIGger<port>:OTYPe`.

#### Suffix:

<port>

Selects the trigger port to which the output is sent.

#### Parameters:

<Level>

#### HIGH

TTL signal.

#### LOW

0 V

\*RST: LOW

**Manual operation:** See "Trigger 2/3" on page 58  
See "Level" on page 59

---

### OUTPut:TRIGger<port>:OTYPe <OutputType>

This command selects the type of signal generated at the trigger output.

#### Suffix:

<port>

Selects the trigger port to which the output is sent.

**Parameters:**

|              |   |
|--------------|---|
| <OutputType> | <b>DEvice</b><br>Sends a trigger signal when the R&S VSE has triggered internally.  |
|              | <b>TARMed</b><br>Sends a trigger signal when the trigger is armed and ready for an external trigger event.                          |
|              | <b>UDEFineD</b><br>Sends a user defined trigger signal. For more information see <a href="#">OUTPut:TRIGger&lt;port&gt;:LEVel</a> . |
|              | *RST: DEvice  |

**Manual operation:** See "[Output Type](#)" on page 58

**OUTPut:TRIGger<port>:PULSe:IMMediate**

This command generates a pulse at the trigger output.

**Suffix:**

<port> Selects the trigger port to which the output is sent.

**Usage:** Event

**Manual operation:** See "[Send Trigger](#)" on page 59

**OUTPut:TRIGger<port>:PULSe:LENGth <Length>**

This command defines the length of the pulse generated at the trigger output.

**Suffix:**

<port> Selects the trigger port to which the output is sent.

**Parameters:**

<Length> Pulse length in seconds.

**Manual operation:** See "[Pulse Length](#)" on page 59

## 10.6.5 Signal Capturing

The following commands are required to configure how much and how data is captured from the input signal.

Useful commands for configuring data acquisition described elsewhere:

- [\[SENSe:\]CDPower:FRAMe\[:VALue\]](#) on page 161

**Remote commands exclusive to signal capturing:**

|  |     |
|--|-----|
| <a href="#">[SENSe:]CDPower:BASE</a> .....           | 142 |
| <a href="#">[SENSe:]CDPower:FILTer[:STATe]</a> ..... | 142 |
| <a href="#">[SENSe:]CDPower:IQLength</a> .....       | 142 |
| <a href="#">[SENSe:]CDPower:QINVert</a> .....        | 143 |

|                               |     |
|-------------------------------|-----|
| [SENSe:]CDPower:SBANd.....    | 143 |
| [SENSe:]AVERage<n>:COUNT..... | 143 |
| [SENSe:]SWEep:COUNT.....      | 143 |

---

### [SENSe:]CDPower:BASE <BaseValue>

This command defines the base of the CDP analysis.

#### Parameters:

<BaseValue>            SLOT | FRAME

**SLOT**  
Only one slot of the signal is analyzed.

**FRAME**  
The complete 3GPP frame is analyzed.

\*RST:            FRAME

**Example:**            CDP:BASE SLOT

**Manual operation:** See "[Capture Mode](#)" on page 69

---

### [SENSe:]CDPower:FILTer[:STATE] <State>

This command selects if a root raised cosine (RRC) receiver filter is used or not. This feature is useful if the RRC filter is implemented in the device under test (DUT).

#### Parameters:

<State>            ON | 1  
If an unfiltered signal is received (normal case), the RRC filter should be used to get a correct signal demodulation.

**OFF | 0**  
If a filtered signal is received, the RRC filter should not be used to get a correct signal demodulation. This is the case if the DUT filters the signal.

\*RST:            1

**Example:**            SENS:CDP:FILT:STAT OFF

**Manual operation:** See "[RRC Filter State](#)" on page 69

---

### [SENSe:]CDPower:IQLength <CaptureLength>

This command specifies the number of frames that are captured by one sweep.

#### Parameters:

<CaptureLength>    Range:    1 to 100  
\*RST:            1

**Example:**            SENS:CDP:IQLength 3

**Manual operation:** See "[Capture Length \(Frames\)](#)" on page 69

**[SENSe:]CDPower:QINVert <State>**

This command inverts the Q-branch of the signal.

**Parameters:**

ON | OFF                    \*RST:        OFF

**Example:**

CDP:QINV ON  
Activates inversion of Q-branch

**Manual operation:** See "[Invert Q](#)" on page 69

**[SENSe:]CDPower:SBAND <NORMAL | INVers>**

This command is used to swap the left and right sideband.

**Parameters:**

<NORMAL | INVers>        \*RST:        NORM

**Example:**

CDP:SBAN INV  
Switches the right and left sideband.

**[SENSe:]AVERAge<n>:COUNT <AverageCount>****[SENSe:]SWEep:COUNT <SweepCount>**

This command defines the number of measurements that the application uses to average traces.

In case of continuous measurement mode, the application calculates the moving average over the average count.

In case of single measurement mode, the application stops the measurement and calculates the average after the average count has been reached.

**Parameters:**

<SweepCount>            When you set a capture count of 0 or 1, the R&S VSE performs one single measurement in single measurement mode. In continuous measurement mode, if the capture count is set to 0, a moving average over 10 measurements is performed.

Range:        0 to 200000

\*RST:        0

**Example:**

SWE:COUN 64  
Sets the number of measurements to 64.  
INIT:CONT OFF  
Switches to single measurement mode.  
INIT;\*WAI  
Starts a measurement and waits for its end.

**Usage:**                SCPI confirmed

**Manual operation:** See "[Capture / Average Count](#)" on page 69

## 10.6.6 Synchronization

For BTS tests, the individual channels in the input signal need to be synchronized to detect timing offsets in the slot spacings. These commands are described here. they are only available in the 3GPP FDD BTS application

Useful commands for synchronization described elsewhere:

- [\[SENSe:\]CDPower:ANTenna](#) on page 120

### Remote commands exclusive to synchronization:

|   |     |
|---|-----|
| <a href="#">[SENSe:]CDPower:UCPich:ANT&lt;antenna&gt;:CODE</a> .....    | 144 |
| <a href="#">[SENSe:]CDPower:UCPich:ANT&lt;antenna&gt;:PATTERN</a> ..... | 144 |
| <a href="#">[SENSe:]CDPower:UCPich:ANT&lt;antenna&gt;[:STATE]</a> ..... | 145 |
| <a href="#">[SENSe:]CDPower:STYPe</a> .....                             | 145 |

---

### **[SENSe:]CDPower:UCPich:ANT<antenna>:CODE** <CodeNumber>

This command sets the code number of the user defined CPICH used for signal analysis.

**Note:** this command is equivalent to the command [\[SENSe:\]CDPower:UCPich:CODE](#) on page 211 for antenna 1.

#### Suffix:

<antenna>            1 | 2  
                          Antenna to be configured

#### Parameters:

<CodeNumber>        Range:     0 to 225  
                          \*RST:     0

**Example:**            SENS:CDP:UCP:ANT2:CODE 10

**Mode:**                BTS application only

**Manual operation:** See "[S-CPICH Code Nr](#)" on page 71

---

### **[SENSe:]CDPower:UCPich:ANT<antenna>:PATTERN** <Pattern>

This command defines which pattern is used for signal analysis for the user-defined CPICH (see [\[SENSe:\]CDPower:UCPich:ANT<antenna>\[:STATE\]](#) on page 145).

**Note:** this command is equivalent to the command [\[SENSe:\]CDPower:UCPich:PATTERN](#) on page 211 for antenna 1.

#### Suffix:

<antenna>            1 | 2  
                          Antenna to be configured



**Parameters:**

<Pattern> 1 | 2  
**1**  
 fixed usage of "Pattern 1" according to standard  
**2**  
 fixed usage of "Pattern 2" according to standard  
 \*RST: 2

**Example:** SENS:CDP:UCP:ANT2:PATT 1

**Mode:** BTS application only

**Manual operation:** See "[S-CPICH Antenna Pattern](#)" on page 71

**[SENSe:]CDPower:UCPich:ANT<antenna>[:STATe] <State>**

Defines whether the common pilot channel (CPICH) is defined by a user-defined position instead of its default position.

**Note:** this command is equivalent to the command [\[SENSe:\]CDPower:UCPich\[:STATe\]](#) on page 212 for antenna 1.

**Suffix:**

<antenna> 1 | 2  
 Antenna to be configured

**Parameters:**

<State> **0**  
 Standard configuration (CPICH is always on channel 0)  
**1**  
 User-defined configuration, position defined using [\[SENSe:\]CDPower:UCPich:ANT<antenna>:CODE](#) on page 144.  
 \*RST: 0

**Example:** SENS:CDP:CPIC:ANT2:STAT 1

**Mode:** BTS application only

**Manual operation:** See "[CPICH Mode](#)" on page 71

**[SENSe:]CDPower:STYPe <Type>**

This command selects the type of synchronization.

**Parameters:**

&lt;Type&gt; CPICH | SCHannel

**CPICH**

Synchronization is carried out to CPICH. For this type of synchronization, the CPICH must be available in the input signal.

**SCHannel**

Synchronization is carried out without CPICH. This type of synchronization is required for test model 4 without CPICH.

\*RST: CPICH

**Example:**

SENS:CDP:STYP SCH

**Mode:**

BTS application only

**Manual operation:** See "[Synchronization Type](#)" on page 70

## 10.6.7 Channel Detection

The channel detection settings determine which channels are found in the input signal. The commands for working with channel tables are described here.

When the channel type is required as a parameter by a remote command or provided as a result for a remote query, the following abbreviations and assignments to a numeric value are used:

*Table 10-2: BTS channel types and their assignment to a numeric parameter value*

| Param. | Channel type | Description   |
|--------|--------------|---|
| 0      | DPCH         | Dedicated <b>Physical Channel</b> of a standard frame   |
| 1      | PICH         | <b>Paging Indication Channel</b>  |
| 2      | CPICH        | <b>Common Pilot Channel</b>   |
| 3      | PSCH         | <b>Primary Synchronization Channel</b>  |
| 4      | SSCH         | <b>Secondary Synchronization Channel</b>  |
| 5      | PCCPCH       | <b>Primary Common Control Physical Channel</b>  |
| 6      | SCCPCH       | <b>Secondary Common Control Physical Channel</b>  |
| 7      | HS_SCCH      | HSDPA: <b>High Speed Shared Control Channel</b>   |
| 8      | HS_PDSCH     | HSDPA: <b>High Speed Physical Downlink Shared Channel</b>   |
| 9      | CHAN         | Channel without any pilot symbols (QPSK modulated)  |
| 10     | CPRSD        | Dedicated Physical Channel in <b>compressed</b> mode  |
| 11     | CPR-TPC      | Dedicated Physical Channel in <b>compressed</b> mode<br><b>TPC</b> symbols are sent in the first slot of the gap. |
| 12     | CPR-SF/2     | Dedicated Physical Channel in <b>compressed</b> mode using half spreading factor ( <b>SF/2</b> ).                 |

| Param. | Channel type | Description  |
|--------|--------------|--|
| 13     | CPR-SF/2-TPC | Dedicated Physical Channel in <b>compressed</b> mode using half spreading factor ( <b>SF/2</b> ).<br><b>TPC</b> symbols are sent in the first slot of the gap. |
| 14     | EHICH-ERGCH  | HSUPA: <b>Enhanced HARQ Hybrid Acknowledgement Indicator Channel</b><br>HSUPA: <b>Enhanced Relative Grant Channel</b>  |
| 15     | EAGCH        | E-AGCH: <b>Enhanced Absolute Grant Channel</b>   |
| 16     | SCPICH       | <b>Secondary Common Pilot Channel</b>  |

**Table 10-3: UE channel types and their assignment to a numeric parameter value**

| Param. | Channel type | Description                                   |
|--------|--------------|---|
| 0      | DPDCH        | Dedicated Physical Data Channel               |
| 1      | DPCCH        | Dedicated Physical Control Channel            |
| 2      | HS-DPCCH     | High-Speed Dedicated Physical Control Channel |
| 3      | E-DPCCH      | Enhanced Dedicated Physical Control Channel   |
| 4      | E_DPDCH      | Enhanced Dedicated Physical Data Channel      |

- [General Channel Detection](#)..... 147
- [Managing Channel Tables](#)..... 149
- [Configuring Channel Tables](#)..... 153
- [Configuring Channel Details \(BTS Measurements\)](#)..... 155
- [Configuring Channel Details \(UE Measurements\)](#)..... 156

### 10.6.7.1 General Channel Detection

The following commands configure how channels are detected in general.

Useful commands for general channel detection described elsewhere:

- [CONFigure:WCDPower\[:BTS\]:CTABLE\[:STATe\]](#) on page 149
- [CONFigure:WCDPower\[:BTS\]:CTABLE:SElect](#) on page 151

**Remote commands exclusive to general channel detection:**

|   |     |
|---|-----|
| <a href="#">CONFigure:WCDPower[:BTS]:CTABLE:COMPare</a> ..... | 147 |
| <a href="#">CONFigure:WCDPower[:BTS]:CTABLE:TOFFset</a> ..... | 148 |
| <a href="#">[SENSe:]CDPower:ICTReshold</a> .....              | 149 |

---

#### **CONFigure:WCDPower[:BTS]:CTABLE:COMPare <State>**

This command switches between normal predefined mode and predefined channel table compare mode.

In the compare mode a predefined channel table model can be compared with the measurement in respect to power, pilot length and timing offset of the active channels.

Comparison is a submode of predefined channel table measurement. It only influences the measurement if the "Channel Search Mode" is set to *Predefined* (see [CONFigure:WCDPower\[:BTS\]:CTABLE\[:STATE\]](#) on page 149). If the compare mode is selected, the power values, pilot lengths and timing offsets are measured and are compared with the values from the predefined channel table. The "Timing Offset" setting is disabled in this case. The differences between the measured and the predefined values are visualized in the corresponding columns of the "CHANNEL TABLE" evaluation (see ["Channel Table"](#) on page 15). The following columns are displayed in the channel table:

- **PilotL** is the subtraction of PilotLengthMeasured - PilotLengthPredefined
- **PwrRel** is the subtraction of PowerRelMeasured - PowerRelPredefined
- **T Offs** is the subtraction of TimingOffsetMeasured - TimingOffsetPredefined

For non-active channels dashes are shown.

**Parameters:**

<State> ON | OFF  
**ON**  
 predefined channel table compare mode  
**OFF**  
 normal predefined mode  
 \*RST: OFF

**Example:** CONF:WCDP:CTAB:COMP ON

**Mode:** BTS application only

**Manual operation:** See ["Comparing the Measurement Signal with the Predefined Channel Table"](#) on page 73

**CONFigure:WCDPower[:BTS]:CTABLE:TOFFset <Mode>**

This command specifies whether the timing offset and pilot length are measured or if the values are taken from the predefined table.

**Parameters:**

<Mode> PRED | MEAS  
**PRED**  
 The timing offset and pilot length values from the predefined table are used.  
**MEAS**  
 The timing offset and the pilot length are measured by the application. The channel configuration is specified via the predefined channel table.

**Example:** CONF:WCDP:CTAB:TOFF MEAS

**Mode:** BTS application only

**Manual operation:** See ["Timing Offset Reference"](#) on page 73



**Return values:**

|             |   |
|-------------|---|
| <TotalSize> | Sum of file sizes of all channel table files (in bytes) |
| <FreeMem>   | Available memory left on hard disk (in bytes)           |
| <FileName>  | File name of individual channel table file              |
| <FileSize>  | File size of individual channel table file (in bytes)   |

**Example:**

```
CONF:WCDP:CTAB:CAT?
```

Sample result (description see table below):

```
52853,2634403840,3GB_1_16.XML,
3469,3GB_1_32.XML,5853,3GB_1_64.XML,
10712,3GB_2.XML,1428,3GB_3_16.XML,
3430,3GB_3_32.XML,5868,3GB_4.XML,
678,3GB_5_2.XML,2554,3GB_5_4.XML,
4101,3GB_5_8.XML,7202,3GB_6.XML,
7209,MYTABLE.XML,349
```

**Usage:** Query only

**Mode:** BTS application only

**Manual operation:** See "Predefined Tables" on page 73

*Table 10-4: Description of query results in example:*

| Value        | Description  |
|--------------|--|
| 52853        | Total size of all channel table files: 52583 bytes |
| 2634403840   | Free memory on hard disk: 2.6 Gbytes               |
| 3GB_1_16.XML | Channel table 1: 3GB_1_16.XML                      |
| 3469         | File size for channel table 1: 3469 bytes          |
| 3GB_1_32.XML | Channel table 2: 3GB_1_32.XML                      |
| 5853         | File size for channel table 2: 5853 bytes          |
| 3GB_1_64.XML | Channel table 3: 3GB_1_64.XML                      |
| 10712        | File size for channel table 3: 10712 bytes         |
| ...          | Channel table x: ...                               |

---

**CONFigure:WCDPower[:BTS]:CTABLE:COPY <FileName>**

This command copies one channel table onto another one. The channel table to be copied is selected with command `CONFigure:WCDPower[:BTS]:CTABLE:NAME` on page 153.

The name of the channel table may contain a maximum of 8 characters.

**Parameters:**

<FileName> name of the new channel table

**Example:** `CONF:WCDP:CTAB:NAME 'NEW_TAB'`  
 Defines the channel table name to be copied.  
`CONF:WCDP:CTAB:COPY 'CTAB_2'`  
 Copies channel table 'NEW\_TAB' to 'CTAB\_2'.

**Usage:** Event

**Mode:** BTS application only

**Manual operation:** See ["Copying a Table"](#) on page 74

---

#### CONFigure:WCDPower[:BTS]:CTABLE:DELEte

This command deletes the selected channel table. The channel table to be deleted is selected with the command `CONFigure:WCDPower[:BTS]:CTABLE:NAME` on page 153.

**Example:** `CONF:WCDP:CTAB:NAME 'NEW_TAB'`  
 Defines the channel table name to be deleted.  
`CONF:WCDP:CTAB:DEL`  
 Deletes the table.

**Mode:** BTS application only

**Manual operation:** See ["Deleting a Table"](#) on page 74

---

#### CONFigure:WCDPower[:BTS]:CTABLE:SELEct <FileName>

This command selects a predefined channel table file for comparison during channel detection. Before using this command, the "RECENT" channel table must be switched on first with the command `CONFigure:WCDPower[:BTS]:CTABLE[:STATE]` on page 149.

**Parameters:**  
 <FileName> \*RST: RECENT

**Example:** `CONF:WCDP:CTAB ON`  
 Switches the channel table on.  
`CONF:WCDP:CTAB:SEL 'CTAB_1'`  
 Selects the predefined channel table 'CTAB\_1'.

**Mode:** BTS application only

**Manual operation:** See ["Selecting a Table"](#) on page 74

---

#### CONFigure:WCDPower:MS:CTABLE[:STATE] <State>

This command switches the channel table on or off. When switched on, the measured channel table is stored under the name "RECENT" and is selected for use. After the "RECENT" channel table is switched on, another channel table can be selected with the command `CONFigure:WCDPower:MS:CTABLE:SELEct` on page 153.

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Example:** CONF:WCDP:CTAB ON

**Mode:** UE application only

**Manual operation:** See ["Using Predefined Channel Tables"](#) on page 72

**CONFigure:WCDPower:MS:CTABLE:CATalog?**

This command reads out the names of all channel tables stored in the software. The first two result values are global values for all channel tables, the subsequent values are listed for each individual table.

**Return values:**

<TotalSize> Sum of file sizes of all channel table files (in bytes)  
 <FreeMem> Available memory left on hard disk (in bytes)  
 <FileName> File name of individual channel table file  
 <FileSize> File size of individual channel table file (in bytes)

**Usage:** Query only

**Mode:** UE application only

**Manual operation:** See ["Predefined Tables"](#) on page 73

**CONFigure:WCDPower:MS:CTABLE:COPY <FileName>**

This command copies one channel table onto another one. The channel table to be copied is selected with command [CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154.

The name of the channel table may contain a maximum of 8 characters.

**Parameters:**

<FileName> Name of the new channel table

**Example:** CONF:WCDP:MS:CTAB:NAME 'NEW\_TAB'  
 Defines the channel table name to be copied.  
 CONF:WCDP:MS:CTAB:COPY 'CTAB\_2'  
 Copies channel table 'NEW\_TAB' to 'CTAB\_2'.

**Mode:** UE application only

**Manual operation:** See ["Copying a Table"](#) on page 74

**CONFigure:WCDPower:MS:CTABLE:DELeTe**

This command deletes the selected channel table. The channel table to be deleted is selected with the command [CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154.



**Example:** `CONF:WCDP:MS:CTAB:NAME 'NEW_TAB'`  
 Defines the channel table name to be deleted.  
`CONF:WCDP:MS:CTAB:DEL`

**Mode:** UE application only

**Manual operation:** See "Deleting a Table" on page 74

#### **CONFigure:WCDPower:MS:CTABLE:SElect <FileName>**

This command selects a predefined channel table file for comparison during channel detection. Before using this command, the "RECENT" channel table must be switched on first with the command `CONFigure:WCDPower:MS:CTABLE[:STATE]` on page 151.

**Parameters:**  
 <FileName> \*RST: RECENT

**Example:** `CONF:WCDP:MS:CTAB1 ON`  
 Switches the channel table on.  
`CONF:WCDP:CTAB:MS:SEL 'CTAB_1'`  
 Selects the predefined channel table 'CTAB\_1'.

**Mode:** UE application only

**Manual operation:** See "Selecting a Table" on page 74

### 10.6.7.3 Configuring Channel Tables

Some general settings and functions are available when configuring a predefined channel table.

#### **Remote commands exclusive to configuring channel tables:**

|  |     |
|--|-----|
| <code>CONFigure:WCDPower[:BTS]:CTABLE:NAME</code> .....    | 153 |
| <code>CONFigure:WCDPower[:BTS]:CTABLE:COMMeNT</code> ..... | 154 |
| <code>CONFigure:WCDPower:MS:CTABLE:NAME</code> .....       | 154 |
| <code>CONFigure:WCDPower:MS:CTABLE:COMMeNT</code> .....    | 154 |

#### **CONFigure:WCDPower[:BTS]:CTABLE:NAME <Name>**

This command creates a new channel table file or selects an existing channel table in order to copy or delete it.

**Parameters:**  
 <Name> <file name>  
 \*RST: RECENT

**Example:** `CONF:WCDP:CTAB:NAME 'NEW_TAB'`

**Mode:** BTS application only

**Manual operation:** See "Name" on page 75

**CONFigure:WCDPower[:BTS]:CTABLE:COMMENT** <Comment>

This command defines a comment for the selected channel table:

Prior to this command, the name of the channel table has to be defined with command [CONFigure:WCDPower\[:BTS\]:CTABLE:NAME](#) on page 153. The values of the table are defined with command [CONFigure:WCDPower\[:BTS\]:CTABLE:DATA](#) on page 155.

**Parameters:**

<Comment>

**Example:**

```
CONF:WCDP:CTAB:NAME 'NEW_TAB'
Defines the channel table name.
CONF:WCDP:CTAB:COMM 'Comment for table 1'
Defines a comment for the table.
CONF:WCDP:CTAB:DATA
8,0,0,0,0,0,1,0.00,8,1,0,0,0,0,1,0.00,7,1,0,
256,8,0,1,0.00
Defines the table values.
```

**Mode:** BTS application only

**Manual operation:** See "[Comment](#)" on page 75

**CONFigure:WCDPower:MS:CTABLE:NAME** <FileName>

This command creates a new channel table file or selects an existing channel table in order to copy or delete it.

**Parameters:**

<FileName> <file name>  
\*RST: RECENT

**Example:**

```
CONF:WCDP:CTAB:NAME 'NEW_TAB'
```

**Mode:** UE application only

**Manual operation:** See "[Name](#)" on page 75

**CONFigure:WCDPower:MS:CTABLE:COMMENT** <Comment>

This command defines a comment for the selected channel table:

Prior to this command, the name of the channel table has to be defined with command [CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154. The values of the table are defined with command [CONFigure:WCDPower:MS:CTABLE:DATA](#) on page 156.

**Parameters:**

<Comment>

**Example:**            `CONF:WCDP:MS:CTAB:NAME 'NEW_TAB'`  
                          Defines the channel table name.  
                          `CONF:WCDP:MS:CTAB:COMM 'Comment for table 1'`  
                          Defines a comment for the table.

**Mode:**                UE application only

**Manual operation:** See "Comment" on page 75

#### 10.6.7.4 Configuring Channel Details (BTS Measurements)

The following commands are used to configure individual channels in a predefined channel table in BTS measurements.

`CONFigure:WCDPower[:BTS]:CTABLE:DATA`..... 155

---

**CONFigure:WCDPower[:BTS]:CTABLE:DATA** <CodeClass>, <CodeNumber>, <UseTFCl>, <TimingOffset>, <PilotLength>, <ChannelType>, <Status>, <CDP>

This command defines or queries the values of the selected channel table. Each line of the table consists of 8 values.

Channels PICH, CPICH and PCCPCH may only be defined once. If channel CPICH or PCCPCH is missing in the command, it is automatically added at the end of the table.

Prior to this command, the name of the channel table has to be defined with the command `CONFigure:WCDPower[:BTS]:CTABLE:NAME` on page 153.

**Parameters:**

|                |  |
|----------------|--|
| <CodeClass>    | Range: 2 to 9  |
| <CodeNumber>   | Range: 0 to 511  |
| <UseTFCl>      | 0   1<br><b>0</b><br>not used<br><b>1</b><br>used  |
| <TimingOffset> | Step width: 256; for code class 9: 512<br>Range: 0 to 38400  |
| <PilotLength>  | code class 9: 4<br>code class 8: 2,4, 8<br>code class 7: 4, 8<br>code class 5/6: 8<br>code class 2/3/4: 16 |
| <ChannelType>  | For the assignment of channel types to parameters see <a href="#">table 10-2</a> .                         |

|                          |  |
|--------------------------|--|
| <Status>                 | <b>0</b><br>not active<br><b>1</b><br>active   |
| <CDP>                    | for queries: CDP relative to total signal power; for settings: CDP absolute or relative  |
| <b>Example:</b>          | <pre>CONF:WCDP:CTAB:NAME 'NEW_TAB'</pre> <p>Defines the channel table name.</p> <pre>CONF:WCDP:CTAB:DATA 8,0,0,0,0,0,1,0.00,8,1,0,0,0,0,1,0.00,7,1,0, 256,8,0,1,0.00</pre>   |
| <b>Mode:</b>             | BTS application only   |
| <b>Manual operation:</b> | <p>See "Channel Type" on page 76</p> <p>See "Channel Number (Ch. SF)" on page 77</p> <p>See "Use TFCI" on page 77</p> <p>See "Timing Offset" on page 77</p> <p>See "Pilot Bits" on page 77</p> <p>See "CDP Relative" on page 77</p> <p>See "Status" on page 78</p> |

#### 10.6.7.5 Configuring Channel Details (UE Measurements)

The following commands are used to configure individual channels in a predefined channel table in UE measurements.

|   |     |
|---|-----|
| <a href="#">CONFigure:WCDPower:MS:CTABLE:DATA</a> .....         | 156 |
| <a href="#">CONFigure:WCDPower:MS:CTABLE:DATA:HSDPcch</a> ..... | 157 |
| <a href="#">CONFigure:WCDPower:MS:CTABLE:EDATa</a> .....        | 157 |
| <a href="#">CONFigure:WCDPower:MS:CTABLE:EDATa:EDPCc</a> .....  | 158 |

#### **CONFigure:WCDPower:MS:CTABLE:DATA**

<CodeClass>,<NoActChan>,<PilotLength>

This command defines the values of the selected channel table.

The Channel DPCCH may only be defined once. If channel DPCCH is missing in the command data, it is automatically added at the end of the table. Prior to this command, the name of the channel table has to be defined with the command [CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154.

#### **Setting parameters:**

|               |  |
|---------------|--|
| <CodeClass>   | Code class of channel 1. I-mapped<br>Range: 2 to 9 |
| <NoActChan>   | Number of active channels<br>Range: 1 to 7         |
| <PilotLength> | pilot length of channel DPCCH                      |

**Return values:**

|               |   |
|---------------|---|
| <CodeClass>   | Code class of channel 1. I-mapped<br>Range: 2 to 9      |
| <NoActChan>   | Number of active channels<br>Range: 1 to 7              |
| <PilotLength> | pilot length of channel DPCCH                           |
| <CDP1>        | Measured relative code domain power values of channel 1 |
| <CDP2>        | Measured relative code domain power values of channel 2 |
| <CDP3>        | Measured relative code domain power values of channel 3 |
| <CDP4>        | Measured relative code domain power values of channel 4 |
| <CDP5>        | Measured relative code domain power values of channel 5 |
| <CDP6>        | Measured relative code domain power values of channel 6 |

**Example:**

```
CONF:WCDP:MS:CTAB:DATA 8,0,0,5,1,0.00,
4,1,1,0,1,0.00, 4,1,0,0,1,0.00
```

The following channels are defined: DPCCH and two data channels with 960 ksp.

**Mode:** UE application only

**Manual operation:** See "Channel Type" on page 76  
 See "Channel Number (Ch. SF)" on page 77  
 See "Pilot Bits" on page 77  
 See "CDP Relative" on page 77  
 See "Status" on page 78

**CONFigure:WCDPower:MS:CTABLE:DATA:HSDPcch <State>**

This command activates or deactivates the HS-DPCCH entry in a predefined channel table.

**Parameters:**

<State> \*RST: ON

**Example:** CONF:WCDP:MS:CTAB:DATA:HSDP ON

**Mode:** UE application only

**CONFigure:WCDPower:MS:CTABLE:EDATa <CodeClass>, <NoActChan>**

This command defines the values for an E-DPCCH channel in the selected channel table. The channel table must be selected using the command [CONFigure:WCDPower:MS:CTABLE:NAME](#) on page 154.

**Setting parameters:**

<CodeClass> Code class of channel  
 Range: 2 to 9

|                       |   |
|-----------------------|---|
| <NoActChan>           | Number of active channels<br>Range: 0 to 4              |
| <b>Return values:</b> |   |
| <CodeClass>           | Code class of channel<br>Range: 2 to 9                  |
| <NoActChan>           | Number of active channels<br>Range: 0 to 4              |
| <ECDP1>               | Measured relative code domain power values of channel 1 |
| <ECDP2>               | Measured relative code domain power values of channel 2 |
| <ECDP3>               | Measured relative code domain power values of channel 3 |
| <ECDP4>               | Measured relative code domain power values of channel 4 |
| <b>Example:</b>       | CONF:WCDP:MS:CTAB:EDAT 8,3                              |
| <b>Mode:</b>          | UE application only                                     |

---

#### CONFigure:WCDPower:MS:CTABle:EDATa:EDPCc <State>

This command activates or deactivates the E-DPCCH entry in a predefined channel table.

**Parameters:**

<State> \*RST: OFF

**Example:** CONF:WCDP:MS:CTAB:EDAT:EDPC ON

**Mode:** UE application only

## 10.6.8 Automatic Settings

Useful commands for adjusting settings automatically described elsewhere:

- [DISPlay\[:WINDow<n>\]:TRACe<t>:Y\[:SCALE\]:AUTO ONCE](#) on page 131
- [\[SENSe:\]CDPower:LCODE:SEARch\[:IMMediate\]?](#) on page 121

#### Remote commands exclusive to adjusting settings automatically:

|   |     |
|---|-----|
| <a href="#">CONFigure:WCDPower[:BTS]:AScale[:STATe]</a> .....   | 159 |
| <a href="#">CONFigure:WCDPower[:BTS]:MCARrier:STATe</a> .....   | 159 |
| <a href="#">[SENSe:]ADJust:ALL</a> .....                        | 159 |
| <a href="#">[SENSe:]ADJust:CONFigure:DURation</a> .....         | 159 |
| <a href="#">[SENSe:]ADJust:CONFigure:DURation:MODE</a> .....    | 160 |
| <a href="#">[SENSe:]ADJust:CONFigure:HYSTeresis:LOWer</a> ..... | 160 |
| <a href="#">[SENSe:]ADJust:CONFigure:HYSTeresis:UPPer</a> ..... | 160 |
| <a href="#">[SENSe:]ADJust:LEVel</a> .....                      | 161 |

**CONFigure:WCDPower[:BTS]:AScale[:STATe] <State>**

Activate this command if multiple carriers are used. In this case, the autoscaling function automatically changes the level settings if the center frequency is changed to another carrier.

**Parameters:**

<State> ON | OFF  
\*RST: ON

**Example:** CONF:WCDP:ASC:STAT ON

**Mode:** BTS application only

**CONFigure:WCDPower[:BTS]:MCARrier:STATe <State>**

Activate this command if multiple carriers are used. In this case, the adjust reference level procedure ensures that the settings of RF attenuation and reference level are optimally adjusted for measuring a multicarrier signal.

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Example:** CONF:WCDP:MCAR:STAT ON

**Mode:** BTS application only

**[SENSe:]ADJust:ALL**

This command initiates a measurement to determine and set the ideal settings for the current task automatically (only once for the current measurement).

This includes:

- Reference level
- Scrambling code
- Scaling

**Example:** ADJ:ALL

**Usage:** Event

**Manual operation:** See ["Adjusting all Determinable Settings Automatically \(Auto All\)"](#) on page 80

**[SENSe:]ADJust:CONFigure:DURation <Duration>**

In order to determine the ideal reference level, the R&S VSE performs a measurement on the current input data. This command defines the length of the measurement if `[SENSe:]ADJust:CONFigure:DURation:MODE` is set to `MANual`.

**Parameters:**

<Duration>                    Numeric value in seconds  
 Range:            0.001 to 16000.0  
 \*RST:            0.001  
 Default unit: s

**Example:**

ADJ:CONF:DUR:MODE MAN  
 Selects manual definition of the measurement length.  
 ADJ:CONF:LEV:DUR 5ms  
 Length of the measurement is 5 ms.

**Manual operation:** See "[Automatic Measurement Time Mode and Value](#)" on page 81

**[SENSe:]ADJust:CONFigure:DURation:MODE <Mode>**

In order to determine the ideal reference level, the R&S VSE performs a measurement on the current input data. This command selects the way the R&S VSE determines the length of the measurement .

**Parameters:**

<Mode>                    **AUTO**  
 The R&S VSE determines the measurement length automatically according to the current input data.  
**MANual**  
 The R&S VSE uses the measurement length defined by [\[SENSe:\]ADJust:CONFigure:DURation](#) on page 159.  
 \*RST:            AUTO

**Manual operation:** See "[Automatic Measurement Time Mode and Value](#)" on page 81

**[SENSe:]ADJust:CONFigure:HYSTeresis:LOWer <Threshold>****Parameters:**

<Threshold>                    Range:            0 dB to 200 dB  
 \*RST:            +1 dB  
 Default unit: dB

**Example:**

SENS:ADJ:CONF:HYST:LOW 2  
 For an input signal level of currently 20 dBm, the reference level will only be adjusted when the signal level falls below 18 dBm.

**Manual operation:** See "[Lower Level Hysteresis](#)" on page 82

**[SENSe:]ADJust:CONFigure:HYSTeresis:UPPer <Threshold>****Parameters:**

<Threshold>                    Range:            0 dB to 200 dB  
 \*RST:            +1 dB  
 Default unit: dB



**Example:** `SENS:ADJ:CONF:HYST:UPP 2`

**Example:** For an input signal level of currently 20 dBm, the reference level will only be adjusted when the signal level rises above 22 dBm.

**Manual operation:** See "[Upper Level Hysteresis](#)" on page 81

#### **[SENSe:]ADJust:LEVel**

This command initiates a single (internal) measurement that evaluates and sets the ideal reference level for the current input data and measurement settings. This ensures that the settings of the RF attenuation and the reference level are optimally adjusted to the signal level without overloading the R&S VSE or limiting the dynamic range by an S/N ratio that is too small.

**Example:** `ADJ:LEV`

**Usage:** Event

**Manual operation:** See "[Setting the Reference Level Automatically \(Auto Level\)](#)" on page 61

### 10.6.9 Evaluation Range

The evaluation range defines which data is evaluated in the result display.

|  |     |
|--|-----|
| <a href="#">[SENSe:]CDPower:CODE</a> .....               | 161 |
| <a href="#">[SENSe:]CDPower:FRAME[:VALue]</a> .....      | 161 |
| <a href="#">[SENSe:]CDPower:SLOT</a> .....               | 162 |
| <a href="#">[SENSe:]CDPower:MAPPING</a> .....            | 162 |
| <a href="#">CALCulate&lt;n&gt;:CDPower:Mapping</a> ..... | 162 |

#### **[SENSe:]CDPower:CODE <CodeNumber>**

This command sets the code number. The code number refers to code class 9 (spreading factor 512).

**Parameters:**

<CodeNumber>      <numeric value>  
                          \*RST:      0

**Example:** `SENS:CDP:CODE 30`

**Manual operation:** See "[Channel](#)" on page 85

#### **[SENSe:]CDPower:FRAME[:VALue] <Frame>**

This command defines the frame to be analyzed within the captured data.

**Parameters:**

<Frame> <numeric value>  
 Range: [0 ... CAPTURE\_LENGTH – 1]  
 \*RST: 1

**Example:** CDP:FRAM:VAL 1

**Manual operation:** See "[Frame To Analyze](#)" on page 69

**[SENSe:]CDPower:SLOT <SlotNumber>**

This command selects the (CPICH) slot number to be evaluated.

**Parameters:**

<SlotNumber> <numeric value>  
 \*RST: 0

**Example:** SENS:CDP:SLOT 3

**Manual operation:** See "[Slot](#)" on page 86

**[SENSe:]CDPower:MAPPING <SignalBranch>**

This command switches between I and Q branches of the signal for all evaluations (if not specified otherwise using [CALCulate<n>:CDPower:Mapping](#) on page 162).

**Parameters:**

<SignalBranch> I | Q  
 \*RST: Q

**Example:** CDP:MAPP Q

**Mode:** UE application only

**CALCulate<n>:CDPower:Mapping <SignalBranch>**

This command adjusts the mapping for the evaluations Code Domain Power and Code Domain Error Power in a specific window.

**Parameters:**

<SignalBranch> I | Q | AUTO  
**I**  
 The I-branch of the signal will be used for evaluation  
**Q**  
 The Q-branch of the signal will be used for evaluation  
**AUTO**  
 The branch selected by the [\[SENSe:\]CDPower:MAPPING](#) command will be used for evaluation.  
 \*RST: AUTO

**Example:** CALC:CDP:MAPPING AUTO

|                          |  |
|--------------------------|--|
| <b>Mode:</b>             | UE application only  |
| <b>Manual operation:</b> | See <a href="#">"Branch (UE measurements only)"</a> on page 86<br>See <a href="#">"Selecting a Different Branch for a Window"</a> on page 87 |

### 10.6.10 Code Domain Analysis Settings (BTS Measurements)

Some evaluations provide further settings for the results. The commands for BTS measurements are described here.

|   |     |
|---|-----|
| <a href="#">CALCulate:MARKer&lt;m&gt;:FUNCTION:ZOOM</a> ..... | 163 |
| <a href="#">[SENSe:]CDPower:CPB</a> .....                     | 163 |
| <a href="#">[SENSe:]CDPower:NORMALize</a> .....               | 163 |
| <a href="#">[SENSe:]CDPower:PDISplay</a> .....                | 164 |
| <a href="#">[SENSe:]CDPower:PDIFf</a> .....                   | 164 |
| <a href="#">[SENSe:]CDPower:PREFerece</a> .....               | 164 |

---

#### **CALCulate:MARKer<m>:FUNCTION:ZOOM <State>**

If marker zoom is activated, the number of channels displayed on the screen in the code domain power and code domain error power result diagram is reduced to 64.

The currently selected marker defines the center of the displayed range.

#### **Parameters:**

<State>                    ON | OFF  
\*RST:                    OFF

**Example:**                    CALC:MARK:FUNC:ZOOM ON

---

#### **[SENSe:]CDPower:CPB <Value>**

This command selects the constellation parameter B. According to 3GPP specification, the mapping of 16QAM symbols to an assigned bit pattern depends on the constellation parameter B.

#### **Parameters:**

<Value>                    <numeric value>  
\*RST:                    0

**Example:**                    SENS:CDP:CDP 1

**Manual operation:**    See ["Constellation Parameter B"](#) on page 89

---

#### **[SENSe:]CDPower:NORMALize <State>**

If enabled, the I/Q offset is eliminated from the measured signal. This is useful to deduct a DC offset to the baseband caused by the DUT, thus improving the EVM. Note, however, that for EVM measurements according to standard, compensation must be disabled.

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Example:**

SENS:CDP:NORM ON  
 Activates the elimination of the I/Q offset.

**Manual operation:** See ["Compensate IQ Offset"](#) on page 88

**[SENSe:]CDPower:PDISplay <Mode>**

This command switches between showing the absolute or relative power.

This parameter only affects the Code Domain Power evaluation.

**Parameters:**

<Mode> ABS | REL  
**ABSolute**  
 Absolute power levels  
**RELative**  
 Power levels relative to total signal power or (BTS application only) CPICH channel power (see [\[SENSe:\]CDPower:PREference](#) on page 164)  
 \*RST: ABS

**Example:**

SENS:CDP:PDIS ABS

**Manual operation:** See ["Code Power Display"](#) on page 88  
 See ["Code Power Display"](#) on page 90

**[SENSe:]CDPower:PDIFf <State>**

This command defines which slot power difference is displayed in the Power vs Slot evaluation.

**Parameters:**

<State> ON | OFF  
**ON**  
 The slot power difference to the previous slot is displayed.  
**OFF**  
 The current slot power of each slot is displayed.  
 \*RST: OFF

**Example:**

SENS:CDP:PDIF ON

**Mode:** BTS application only

**Manual operation:** See ["Show Difference to Previous Slot"](#) on page 88

**[SENSe:]CDPower:PREference <Mode>**

This command defines the reference for the relative CDP measurement values.

**Parameters:**

<Mode>                   TOTAl | CPICh  
**TOTAl**  
 Total signal power  
**CPICh**  
 CPICH channel power  
 \*RST:           TOTAl

**Example:**               SENS:CDP:PREF CPIC

**Mode:**                   BTS application only

**Manual operation:**   See "Code Power Display" on page 88

### 10.6.11 Code Domain Analysis Settings (UE Measurements)

Some evaluations provide further settings for the results. The commands for UE measurements are described here.

Useful commands for Code Domain Analysis described elsewhere:

- [CALCulate:MARKer<m>:FUNction:ZOOM](#) on page 163
- [\[SENSe:\]CDPower:NORMALize](#) on page 163
- [\[SENSe:\]CDPower:PDISplay](#) on page 164

#### Remote commands exclusive to Code Domain Analysis in UE Measurements:

[\[SENSe:\]CDPower:ETCHips](#)..... 165  
[\[SENSe:\]CDPower:HSLot](#)..... 166

---

#### **[SENSe:]CDPower:ETCHips <State>**

This command selects length of the measurement interval for calculation of error vector magnitude (EVM). In accordance with 3GPP specification Release 5, the EVM measurement interval is one slot (4096 chips) minus 25  $\mu$ s (3904 chips) at each end of the burst if power changes are expected. If no power changes are expected, the evaluation length is one slot (4096 chips).

**Parameters:**

<State>                   **ON**  
 Changes of power are expected. Therefore an EVM measurement interval of one slot minus 25  $\mu$ s (3904 chips) is considered.  
**OFF**  
 Changes of power are not expected. Therefore an EVM measurement interval of one slot (4096 chips) is considered  
 \*RST:           OFF

**Example:**               SENS:CDP:ETCH ON

**Manual operation:**   See "Eliminate Tail Chips" on page 90

**[SENSe:]CDPower:HSLot** <State>

This command switches between the analysis of half slots and full slots.

**Parameters:**

<State>                    ON | OFF  
                               **ON**  
                               30 (half) slots are evaluated  
                               **OFF**  
                               15 (full) slots are evaluated  
                               \*RST:        OFF

**Example:**                SENS:CDP:HSL ON

**Mode:**                    UE application only

**Manual operation:**    See "[Measurement Interval](#)" on page 89

## 10.7 Configuring the Result Display

The commands required to configure the screen display in a remote environment are described here.

- [Global Layout Commands](#).....166
- [Working with Windows in the Display](#)..... 170
- [General Window Commands](#)..... 176

### 10.7.1 Global Layout Commands

The following commands are required to change the evaluation type and rearrange the screen layout across measurement channels as you do in manual operation.



For compatibility with other Rohde & Schwarz Signal and Spectrum Analyzers, the layout commands described in [chapter 10.7.2, "Working with Windows in the Display"](#), on page 170 are also supported. Note, however, that the commands described there only allow you to configure the layout within the *active* measurement channel.

|  |     |
|--|-----|
| <a href="#">LAYout:GLOBal:ADD[:WINDow]?</a> .....      | 166 |
| <a href="#">LAYout:GLOBal:CATalog[:WINDow]?</a> .....  | 168 |
| <a href="#">LAYout:GLOBal:IDENtify[:WINDow]?</a> ..... | 169 |
| <a href="#">LAYout:GLOBal:REMOve[:WINDow]</a> .....    | 169 |
| <a href="#">LAYout:GLOBal:REPLace[:WINDow]</a> .....   | 170 |

**LAYout:GLOBal:ADD[:WINDow]?**

<ExChanName>,<ExWinName>,<Direction>,<NewChanName>,<NewWinType>

This command adds a window to the display next to an existing window. The new window may belong to a different channel than the existing window.

To replace an existing window, use the `LAYout:GLOBal:REPLace[:WINDow]` command.

**Parameters:**

|                                  |  |
|----------------------------------|--|
| <code>&lt;ExChanName&gt;</code>  | string<br>Name of an existing channel  |
| <code>&lt;ExWinName&gt;</code>   | string<br>Name of the existing window within the <code>&lt;ExChanName&gt;</code> channel the new window is inserted next to.<br>By default, the name of a window is the same as its index. To determine the name and index of all active windows use the <code>LAYout:GLOBal:IDENTify[:WINDow]? query</code> . |
| <code>&lt;Direction&gt;</code>   | LEFT   RIGHT   ABOVE   BELOW   TAB<br>Direction the new window is added relative to the existing window.<br><b>TAB</b><br>The new window is added as a new tab in the specified existing window.   |
| <code>&lt;NewChanName&gt;</code> | string<br>Name of the channel for which a new window is to be added.   |
| <code>&lt;NewWinType&gt;</code>  | string<br>Type of result display (evaluation method) you want to add. See the table below for available parameter values.  |

**Return values:**

|                                    |   |
|------------------------------------|---|
| <code>&lt;NewWindowName&gt;</code> | When adding a new window, the command returns its name (by default the same as its number) as a result. |
|------------------------------------|---|

**Example:**

```
LAYout:GLOBal:ADD:WINDow? 'IQ Analyzer', '1', RIGHT, 'IQ Analyzer2', 'FREQ'
```

Adds a new window named 'Spectrum' with a Spectrum display to the right of window 1 in the channel 'IQ Analyzer'.

**Usage:**

Query only

*Table 10-5: <WindowType> parameter values for 3GPP FDD application*

| Parameter value | Window type             |
|-----------------|-------------------------|
| BITStream       | Bitstream               |
| CCONst          | Composite Constellation |
| CDPower         | Code Domain Power       |
| CDEPower        | Code Domain Error Power |
| CEVM            | Composite EVM           |
| CTABLE          | Channel Table           |
| EVMChip         | EVM vs Chip             |
| FESLot          | Frequency Error vs Slot |

| Parameter value | Window type                 |
|-----------------|-----------------------------|
| MECHip          | Magnitude Error vs Chip     |
| MTABle          | Marker table                |
| PCDError        | Peak Code Domain Error      |
| PDSLot          | Phase Discontinuity vs Slot |
| PECHip          | Phase Error vs Chip         |
| PSLot           | Power vs Slot               |
| PSYMBOL         | Power vs Symbol             |
| RSUMmary        | Result Summary              |
| SCONst          | Symbol Constellation        |
| SEVM            | Symbol EVM                  |
| SMERror         | Symbol Magnitude Error      |
| SPERror         | Symbol Phase Error          |

#### LAYout:GLOBal:CATalog[:WINDow]?

This command queries the name and index of all active windows from top left to bottom right for each active channel. The result is a comma-separated list of values for each window, with the syntax:

```
<ChannelName_1>: <WindowName_1>,<WindowIndex_1>..<WindowName_n>,<WindowIndex_n>
```

..

```
<ChannelName_m>: <WindowName_1>,<WindowIndex_1>..<WindowName_n>,<WindowIndex_n>
```

#### Return values:

|               |  |
|---------------|--|
| <ChannelName> | String containing the name of the channel. The channel name is displayed as the tab label for the measurement channel. |
| <WindowName>  | string<br>Name of the window.<br>In the default state, the name of the window is its index.                            |
| <WindowIndex> | <b>numeric value</b><br>Index of the window.   |



**Example:** LAY:GLOB:CAT?  
**Result:**  
 IQ Analyzer: '1',1,'2',2  
 Analog Demod: '1',1,'4',4  
 For the I/Q Analyzer channel, two windows are displayed, named '2' (at the top or left), and '1' (at the bottom or right).  
 For the Analog Demodulation channel, two windows are displayed, named '1' (at the top or left), and '4' (at the bottom or right).

**Usage:** Query only

**LAYout:GLOBal:IDENtify[:WINDow]? <ChannelName>,<WindowName>**

This command queries the **index** of a particular display window in the specified channel.

**Note:** to query the **name** of a particular window, use the `LAYout:WINDow<n>:IDENtify?` query.

**Parameters:**

<ChannelName> String containing the name of the channel. The channel name is displayed as the tab label for the measurement channel.

**Query parameters:**

<WindowName> String containing the name of a window.

**Return values:**

<WindowIndex> Index number of the window.

**Example:** LAYout:GLOBal:ADD:WINDow? IQ,'1',RIGHT,  
 'Spectrum',FREQ  
 Adds a new window named 'Spectrum' with a Spectrum display to the right of window 1.

**Example:** LAYout:GLOBal:IDENtify? 'IQ Analyzer',  
 'Spectrum'  
**Result:**  
 2  
 Window index is: 2.

**Usage:** Query only

**LAYout:GLOBal:REMOve[:WINDow] <ChannelName>,<WindowName>**

This command removes a window from the display.

**Parameters:**

<ChannelName> String containing the name of the channel.

<WindowName> String containing the name of the window.

**Usage:** Event

**LAYout:GLOBal:REPLace[:WINDow]**

<ExChannelName>,<WindowName>,<NewChannelName>,<WindowType>

This command replaces the window type (for example from "Diagram" to "Result Summary") of an already existing window while keeping its position, index and window name.

To add a new window, use the `LAYout:GLOBal:ADD[:WINDow]?` command.

**Parameters:**

- <ExChannelName> String containing the name of the channel in which a window is to be replaced. The channel name is displayed as the tab label for the measurement channel.
- <WindowName> String containing the name of the existing window. To determine the name and index of all active windows, use the `LAYout:GLOBal:CATalog[:WINDow]?` query.
- <NewChannelName> String containing the name of the channel for which a new window will be created.
- <WindowType> Type of result display you want to use in the existing window. Note that the window type must be valid for the specified channel (<NewChannelName>). See `LAYout:ADD[:WINDow]?` on page 171 for a list of available window types.

**Example:**

```
LAY:GLOB:REPL:WIND 'IQ Analyzer','1',
'AnalogDemod',MTAB
```

Replaces the I/Q Analyzer result display in window 1 by a marker table for the AnalogDemod channel.

**10.7.2 Working with Windows in the Display**

The following commands are required to change the evaluation type and rearrange the screen layout for a measurement channel as you do using the SmartGrid in manual operation. Since the available evaluation types depend on the selected application, some parameters for the following commands also depend on the selected measurement channel.

Note that the suffix <n> always refers to the window *in the currently selected measurement channel*.

To configure the layout of windows across measurement channels, use the [chapter 10.7.1, "Global Layout Commands"](#), on page 166.

|  |     |
|--|-----|
| <code>LAYout:ADD[:WINDow]?</code> .....        | 171 |
| <code>LAYout:CATalog[:WINDow]?</code> .....    | 173 |
| <code>LAYout:IDENTify[:WINDow]?</code> .....   | 173 |
| <code>LAYout:REMove[:WINDow]</code> .....      | 174 |
| <code>LAYout:REPLace[:WINDow]</code> .....     | 174 |
| <code>LAYout:WINDow&lt;n&gt;:ADD?</code> ..... | 174 |

|  |     |
|--|-----|
| <a href="#">LAYout:WINDow&lt;n&gt;:IDENtify?</a> ..... | 175 |
| <a href="#">LAYout:WINDow&lt;n&gt;:REMOve</a> .....    | 175 |
| <a href="#">LAYout:WINDow&lt;n&gt;:REPLace</a> .....   | 176 |

---

**LAYout:ADD[:WINDow]? <WindowName>,<Direction>,<WindowType>**

This command adds a window to the display in the active measurement channel.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

To replace an existing window, use the [LAYout:REPLace\[:WINDow\]](#) command.

**Parameters:**

|                           |   |
|---------------------------|---|
| <b>&lt;WindowName&gt;</b> | String containing the name of the existing window the new window is inserted next to.<br>By default, the name of a window is the same as its index. To determine the name and index of all active windows, use the <a href="#">LAYout:CATalog[:WINDow]?</a> query.  |
| <b>&lt;Direction&gt;</b>  | LEFT   RIGHT   ABOVE   BELOW<br>Direction the new window is added relative to the existing window.  |
| <b>&lt;WindowType&gt;</b> | text value<br>Type of result display (evaluation method) you want to add. See the table below for available parameter values.<br>Note that the window type must be valid for the active measurement channel. To create a window for a different measurement channel use the <a href="#">LAYout:GLOBal:REPLace[:WINDow]</a> command. |

**Return values:**

|                              |   |
|------------------------------|---|
| <b>&lt;NewWindowName&gt;</b> | When adding a new window, the command returns its name (by default the same as its number) as a result. |
|------------------------------|---|

**Example:** `LAY:ADD? '1',BEL,'XPOW:CDP:ABSolute'`  
Adds a Code Domain Power display below window 1.

**Usage:** Query only

- Manual operation:**
- See "Bitstream" on page 15
  - See "Channel Table" on page 15
  - See "Code Domain Power" on page 17
  - See "Code Domain Error Power" on page 18
  - See "Composite Constellation" on page 18
  - See "Composite EVM" on page 19
  - See "EVM vs Chip" on page 20
  - See "Frequency Error vs Slot" on page 21
  - See "Mag Error vs Chip" on page 22
  - See "Marker Table" on page 22
  - See "Peak Code Domain Error" on page 23
  - See "Phase Discontinuity vs Slot" on page 24
  - See "Phase Error vs Chip" on page 24
  - See "Power vs Slot" on page 26
  - See "Power vs Symbol" on page 26
  - See "Result Summary" on page 27
  - See "Symbol Constellation" on page 27
  - See "Symbol EVM" on page 28
  - See "Symbol Magnitude Error" on page 29
  - See "Symbol Phase Error" on page 29

**Table 10-6:** <WindowType> parameter values for 3GPP FDD application

| Parameter value | Window type                 |
|-----------------|-----------------------------|
| BITStream       | Bitstream                   |
| CCONst          | Composite Constellation     |
| CDPower         | Code Domain Power           |
| CDEPower        | Code Domain Error Power     |
| CEVM            | Composite EVM               |
| CTABLE          | Channel Table               |
| EVMChip         | EVM vs Chip                 |
| FESLot          | Frequency Error vs Slot     |
| MECHip          | Magnitude Error vs Chip     |
| MTABLE          | Marker table                |
| PCDerror        | Peak Code Domain Error      |
| PDSLot          | Phase Discontinuity vs Slot |
| PECHip          | Phase Error vs Chip         |
| PSLot           | Power vs Slot               |
| PSYMBOL         | Power vs Symbol             |
| RSUMmary        | Result Summary              |
| SCONst          | Symbol Constellation        |
| SEVM            | Symbol EVM                  |

| Parameter value | Window type            |
|-----------------|------------------------|
| SMERror         | Symbol Magnitude Error |
| SPERror         | Symbol Phase Error     |

### LAYout:CATalog[:WINDow]?

This command queries the name and index of all active windows in the active measurement channel from top left to bottom right. The result is a comma-separated list of values for each window, with the syntax:

<WindowName\_1>,<WindowIndex\_1>..<WindowName\_n>,<WindowIndex\_n>

To query the name and index of all windows in all measurement channels use the [LAYout:GLOBal:CATalog\[:WINDow\]?](#) command.

#### Return values:

<WindowName>      string  
Name of the window.  
In the default state, the name of the window is its index.

<WindowIndex>    **numeric value**  
Index of the window.

#### Example:

LAY:CAT?

Result:

'2',2,'1',1

Two windows are displayed, named '2' (at the top or left), and '1' (at the bottom or right).

**Usage:**            Query only

### LAYout:IDENtify[:WINDow]? <WindowName>

This command queries the **index** of a particular display window in the active measurement channel.

**Note:** to query the **name** of a particular window, use the [LAYout:WINDow<n>:IDENtify?](#) query.

To query the index of a window in a different measurement channel use the [LAYout:GLOBal:IDENtify\[:WINDow\]?](#) command.

#### Query parameters:

<WindowName>      String containing the name of a window.

#### Return values:

<WindowIndex>    Index number of the window.

#### Example:

LAY:WIND:IDEN? '2'

Queries the index of the result display named '2'.

Response:

2

**Usage:** Query only

---

**LAYout:REMOve[:WINDow] <WindowName>**

This command removes a window from the display in the active measurement channel.

To remove a window for a different measurement channel use the `LAYout:GLOBal:REMOve[:WINDow]` command.

**Parameters:**

<WindowName> String containing the name of the window.  
In the default state, the name of the window is its index.

**Example:** `LAY:REM '2'`  
Removes the result display in the window named '2'.

**Usage:** Event

---

**LAYout:REPLace[:WINDow] <WindowName>,<WindowType>**

This command replaces the window type (for example from "Diagram" to "Result Summary") of an already existing window in the active measurement channel while keeping its position, index and window name.

To add a new window, use the `LAYout:ADD[:WINDow]?` command.

**Parameters:**

<WindowName> String containing the name of the existing window.  
By default, the name of a window is the same as its index. To determine the name and index of all active windows in the active measurement channel, use the `LAYout:CATalog[:WINDow]?` query.

<WindowType> Type of result display you want to use in the existing window.  
See `LAYout:ADD[:WINDow]?` on page 171 for a list of available window types.  
Note that the window type must be valid for the active measurement channel. To create a window for a different measurement channel use the `LAYout:GLOBal:REPLace[:WINDow]` command.

**Example:** `LAY:REPL:WIND '1',MTAB`  
Replaces the result display in window 1 with a marker table.

---

**LAYout:WINDow<n>:ADD? <Direction>,<WindowType>**

This command adds a measurement window to the display. Note that with this command, the suffix <n> determines the existing window next to which the new window is added, as opposed to `LAYout:ADD[:WINDow]?`, for which the existing window is defined by a parameter.

To replace an existing window, use the `LAYout:WINDow<n>:REPLace` command.

This command is always used as a query so that you immediately obtain the name of the new window as a result.

**Parameters:**

<Direction> LEFT | RIGHT | ABOVE | BELOW

<WindowType> Type of measurement window you want to add.  
See [LAYout:ADD\[:WINDow\]?](#) on page 171 for a list of available window types.  
Note that the window type must be valid for the active measurement channel. To create a window for a different measurement channel use the [LAYout:GLOBal:ADD\[:WINDow\]?](#) command.

**Return values:**

<NewWindowName> When adding a new window, the command returns its name (by default the same as its number) as a result.

**Example:**

```
LAY:WIND1:ADD? LEFT,MTAB
```

Result:

```
'2'
```

Adds a new window named '2' with a marker table to the left of window 1.

**Usage:**

Query only

**LAYout:WINDow<n>:IDENTify?**

This command queries the **name** of a particular display window (indicated by the <n> suffix) in the active measurement channel.

**Note:** to query the **index** of a particular window, use the [LAYout:IDENTify\[:WINDow\]?](#) command.

**Return values:**

<WindowName> String containing the name of a window.  
In the default state, the name of the window is its index.

**Example:**

```
LAY:WIND2:IDEN?
```

Queries the name of the result display in window 2.

Response:

```
'2'
```

**Usage:**

Query only

**LAYout:WINDow<n>:REMOve**

This command removes the window specified by the suffix <n> from the display in the active measurement channel.

The result of this command is identical to the [LAYout:REMOve\[:WINDow\]](#) command.

To remove a window in a different measurement channel use the [LAYout:GLOBal:REMOve\[:WINDow\]](#) command.

**Example:**           LAY:WIND2:REM  
Removes the result display in window 2.

**Usage:**            Event

#### LAYout:WINDow<n>:REPLace <WindowType>

This command changes the window type of an existing window (specified by the suffix <n>) in the active measurement channel.

The result of this command is identical to the `LAYout:REPLace[:WINDow]` command.

To add a new window, use the `LAYout:WINDow<n>:ADD?` command.

#### Parameters:

<WindowType>       Type of measurement window you want to replace another one with.  
See `LAYout:ADD[:WINDow]?` on page 171 for a list of available window types.  
Note that the window type must be valid for the active measurement channel. To create a window for a different measurement channel use the `LAYout:GLOBal:REPLace[:WINDow]` command.

**Example:**           LAY:WIND2:REPL MTAB  
Replaces the result display in window 2 with a marker table.

### 10.7.3 General Window Commands

The following commands are required to work with windows, independently of the application.

Note that the suffix <n> always refers to the window *in the currently selected measurement channel*.

`DISPlay[:WINDow<n>]:SElect`..... 176

#### DISPlay[:WINDow<n>]:SElect

This command sets the focus on the selected result display window.

This window is then the active window.

**Example:**           DISP:WIND1:SEL  
Sets the window 1 active.

**Usage:**            Setting only



## 10.8 Retrieving Results

The following commands are required to retrieve the results from a 3GPP FDD measurement in a remote environment.

When the channel type is required as a parameter by a remote command or provided as a result for a remote query, abbreviations or assignments to a numeric value are used as described in [table 10-2](#).

### Specific commands:

- [Retrieving Calculated Measurement Results](#)..... 177
- [Measurement Results for TRACe<n>\[:DATA\]? TRACE<n>](#)..... 181
- [Retrieving Trace Results](#)..... 187

### 10.8.1 Retrieving Calculated Measurement Results

The following commands describe how to retrieve the calculated results from the CDA and Time Alignment Error measurements.

|  |     |
|--|-----|
| <a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:FUNction:TAERror:RESult?</a> .....        | 177 |
| <a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:FUNction:WCDPower[:BTS]:RESult?</a> ..... | 177 |
| <a href="#">CALCulate&lt;n&gt;:MARKer&lt;m&gt;:FUNction:WCDPower:MS:RESult?</a> .....    | 179 |

---

#### **CALCulate<n>:MARKer<m>:FUNction:TAERror:RESult? <ResultType>**

This command queries the result of a time alignment measurement (see [chapter 3.2](#), "Time Alignment Error Measurements", on page 30).

#### Query parameters:

|              |   |
|--------------|---|
| <ResultType> | <b>TAERror</b><br>Returns the time offset between the two antenna signals in chips. |
|--------------|---|

**Example:**                    `CALC:MARK:FUNC:TAER:RES? TAER`

**Usage:**                     Query only

**Mode:**                     BTS application only

**Manual operation:**    See "[Result List](#)" on page 30

---

#### **CALCulate<n>:MARKer<m>:FUNction:WCDPower[:BTS]:RESult? <Measurement>**

This command queries the measured and calculated results of the 3GPP FDD BTS code domain power measurement.

**Query parameters:**

|                    |  |
|--------------------|--|
| <Measurement>      | The parameter specifies the required evaluation method.                          |
| <b>ACHannels</b>   | Number of active channels  |
| <b>ARCDerror</b>   | relative code domain error averaged over all channels with modulation type 64QAM |
| <b>CDPabsolute</b> | code domain power absolute   |
| <b>CDPRelative</b> | code domain power relative   |
| <b>CERRor</b>      | chip rate error  |
| <b>CHANnel</b>     | channel number   |
| <b>CSLot</b>       | channel slot number  |
| <b>EVMPeak</b>     | error vector magnitude peak  |
| <b>EVMRms</b>      | error vector magnitude RMS   |
| <b>FERRor</b>      | frequency error in Hz  |
| <b>IOFFset</b>     | imaginary part of the I/Q offset   |
| <b>IQIMbalance</b> | I/Q imbalance  |
| <b>IQOFFset</b>    | I/Q offset   |
| <b>MACCuracy</b>   | composite EVM  |
| <b>MPIC</b>        | average power of inactive channels   |
| <b>MTYPE</b>       | modulation type:<br>2 – QPSK<br>4 – 16 QAM<br>5 – 64 QAM<br>15 – NONE            |
| <b>PCDerror</b>    | peak code domain error   |
| <b>PSYMBOL</b>     | number of pilot bits   |
| <b>PTOTAL</b>      |  |

total power

**QOFFset**

real part of the I/Q offset

**RCDerror**

relative code domain error

**RHO**

rho value for every slot

**SRATe**

symbol rate

**TFRame**

trigger to frame

**TOFFset**

timing offset

|                          |   |
|--------------------------|---|
| <b>Example:</b>          | <code>CALC:MARK:FUNC:WCDP:RES? PTOT</code>  |
| <b>Usage:</b>            | Query only  |
| <b>Mode:</b>             | BTS application only  |
| <b>Manual operation:</b> | See " <a href="#">Code Domain Power</a> " on page 17<br>See " <a href="#">Result Summary</a> " on page 27 |

---

**CALCulate<n>:MARKer<m>:FUNCTion:WCDPower:MS:RESult? <Measurement>**

This command queries the measured and calculated results of the 3GPP FDD UE code domain power measurement.

**Query parameters:**

|                    |  |
|--------------------|--|
| <Measurement>      | The parameter specifies the required evaluation method.                          |
| <b>ACHannels</b>   | Number of active channels  |
| <b>CDPabsolute</b> | code domain power absolute   |
| <b>CDPRelative</b> | code domain power relative   |
| <b>CERRor</b>      | chip rate error  |
| <b>CHANnel</b>     | channel number   |
| <b>CMApping</b>    | Channel branch   |
| <b>CSLot</b>       | channel slot number  |
| <b>EVMPeak</b>     | error vector magnitude peak  |
| <b>EVMRms</b>      | error vector magnitude RMS   |
| <b>FERRor</b>      | frequency error in Hz  |
| <b>IQIMbalance</b> | I/Q imbalance  |
| <b>IQOffset</b>    | I/Q offset   |
| <b>MACCuracy</b>   | composite EVM  |
| <b>MPIC</b>        | average power of the inactive codes for the selected slot                        |
| <b>MTYPe</b>       | modulation type:<br>BPSK-I: 0<br>BPSK-Q: 1<br>4PAM-I: 6<br>4PAM-Q: 7<br>NONE: 15 |
| <b>PCDerror</b>    | peak code domain error   |
| <b>PSYMBOL</b>     | Number of pilot bits   |
| <b>PTOTAL</b>      | total power  |
| <b>RHO</b>         |  |

rho value for every slot

**SRATe**

symbol rate

**TFRame**

trigger to frame

**TOFFset**

timing offset

|                          |                                    |
|--------------------------|------------------------------------|
| <b>Example:</b>          | CALC:MARK:FUNC:WCDP:MS:RES? PTOT   |
| <b>Usage:</b>            | Query only                         |
| <b>Mode:</b>             | UE application only                |
| <b>Manual operation:</b> | See "Code Domain Power" on page 17 |

## 10.8.2 Measurement Results for TRACe<n>[:DATA]? TRACE<n>

The evaluation method selected by the LAY:ADD:WIND command also affects the results of the trace data query (TRACe<n>[:DATA]? TRACE<n>, see TRACe<n>[:DATA]? on page 188).

Details on the returned trace data depending on the evaluation method are provided here.

For details on the graphical results of these evaluation methods, see chapter 3, "Measurements and Result Display", on page 11.

|                                    |     |
|------------------------------------|-----|
| • Code Domain Power.....           | 182 |
| • Channel Table.....               | 182 |
| • Code Domain Error Power.....     | 182 |
| • Power vs Slot.....               | 183 |
| • Result Summary.....              | 183 |
| • Composite EVM (RMS).....         | 183 |
| • Peak Code Domain Error.....      | 184 |
| • Composite Constellation.....     | 184 |
| • Power vs Symbol.....             | 184 |
| • Symbol Constellation.....        | 184 |
| • Symbol EVM.....                  | 185 |
| • Bitstream.....                   | 185 |
| • Frequency Error vs Slot.....     | 186 |
| • Phase Discontinuity vs Slot..... | 186 |
| • EVM vs Chip.....                 | 186 |
| • Mag Error vs Chip.....           | 187 |
| • Phase Error vs Chip.....         | 187 |
| • Symbol Magnitude Error.....      | 187 |
| • Symbol Phase Error.....          | 187 |

### 10.8.2.1 Code Domain Power

When the trace data for this evaluation is queried, 5 values are transmitted for each channel:

- the code class
- the channel number
- the absolute level
- the relative level
- the timing offset

For details on these parameters see [TRACe<n>\[:DATA\]?](#) on page 188.

### 10.8.2.2 Channel Table

When the trace data for this evaluation is queried, 5 values are transmitted for each channel:

- the class
- the channel number
- the absolute level
- the relative level
- the timing offset

For details on these parameters see [TRACe<n>\[:DATA\]?](#) on page 188.

#### Example:

The following example shows the results of a query for three channels with the following configuration:

| Channel | Spreading factor | Channel number | Timing offset |
|---------|------------------|----------------|---------------|
| 1st     | 512              | 7              | 0             |
| 2nd     | 4                | 1              | 256 chips     |
| 3rd     | 128              | 255            | 2560 chips    |

This yields the following result:

9, 7, -40, -20, 0, 2, 1, -40, -20, 256, 7, 255, -40, -20, 2560

The channel order is the same as in the CDP diagram, i.e. it depends on their position in the code domain of spreading factor 512.

### 10.8.2.3 Code Domain Error Power

When the trace data for this evaluation is queried, 4 values are transmitted for each channel with code class 9:

|             |  |
|-------------|--|
| code class  | Highest code class of a downlink signal, always set to 9 (CC9) |
| code number | Code number of the evaluated CC9 channel [0...511]             |

|              |   |
|--------------|---|
| CDEP         | Code domain error power value of the CC9 channel in [dB]  |
| channel flag | Indicates whether the CC9 channel belongs to an assigned code channel:<br>0b00-0d0: CC9 is inactive.<br>0b01-0d1: CC9 channel belongs to an active code channel.<br>0b11-0d3: CC9 channel belongs to an active code channel; sent pilot symbols are incorrect |

The channels are sorted by code number.

#### 10.8.2.4 Power vs Slot

When the trace data for this evaluation is queried, 16 pairs of slots (slot number of CPICH) and level values are transferred:

<slot number>, <level value in dB> (for 16 slots)

#### 10.8.2.5 Result Summary

When the trace data for this evaluation is queried, the results of the result summary are output in the following order:

<composite EVM [%]>,  
 <peak CDE [dB]>,  
 < carr freq error [Hz]>,  
 <chip rate error [ppm]>,  
 <total power [dB]>,  
 <trg to frame [μs]>,  
 <EVM peak channel [%]>,  
 <EVM mean channel [%]>,  
 <code class>,  
 <channel number>,  
 <power abs. channel [dB]>,  
 <power rel. channel [dB], referenced to CPICH or total power>,  
 <timing offset [chips]>,  
 <I/Q offset [%]>,  
 <I/Q imbalance [%]>

#### 10.8.2.6 Composite EVM (RMS)

When the trace data for this evaluation is queried, 15 pairs of slots (slot number of CPICH) and level values are transferred:

<slot number>, <level value in %> (for 15 slots)

#### 10.8.2.7 Peak Code Domain Error

When the trace data for this evaluation is queried, 15 pairs of slots (slot number of CPICH) and level values are transferred:

<slot number>, <level value in dB> (for 15 slots)

#### 10.8.2.8 Composite Constellation

When the trace data for this evaluation is queried, the real and the imaginary branches of the chip constellation at the selected slot are transferred:

<Re1>, <Im1>, <Re2>, <Im2>, ....., <Re2560>, <Im2560>

The values are normalized to the square root of the average power at the selected slot.

#### 10.8.2.9 Power vs Symbol

When the trace data for this evaluation is queried, the power of each symbol at the selected slot is transferred. The values indicate the difference to the reference power in dB. The number of the symbols depends on the spreading factor of the selected channel:

$\text{NOFSymbols} = 10 * 2^{(8 - \text{CodeClass})}$

#### 10.8.2.10 Symbol Constellation

When the trace data for this evaluation is queried, the real and the imaginary branches are transferred:

<Re<sub>0</sub>>, <Im<sub>0</sub>>, <Re<sub>1</sub>>, <Im<sub>1</sub>>, ....., <Re<sub>n</sub>>, <Im<sub>n</sub>>

The number of level values depends on the spreading factor:

| Spreading factor | Number of level values |
|------------------|------------------------|
| 512              | 5                      |
| 256              | 10                     |
| 128              | 20                     |
| 64               | 40                     |
| 32               | 80                     |
| 16               | 160                    |
| 8                | 320                    |
| 4                | 640                    |



### 10.8.2.11 Symbol EVM

When the trace data for this evaluation is queried, the real and the imaginary branches are transferred:

$\langle \text{Re}_0 \rangle$ ,  $\langle \text{Im}_0 \rangle$ ,  $\langle \text{Re}_1 \rangle$ ,  $\langle \text{Im}_1 \rangle$ , ...,  $\langle \text{Re}_n \rangle$ ,  $\langle \text{Im}_n \rangle$

The number of level values depends on the spreading factor:

| Spreading factor | Number of level values |
|------------------|------------------------|
| 512              | 5                      |
| 256              | 10                     |
| 128              | 20                     |
| 64               | 40                     |
| 32               | 80                     |
| 16               | 160                    |
| 8                | 320                    |
| 4                | 640                    |

### 10.8.2.12 Bitstream

When the trace data for this evaluation is queried, the bit stream of one slot is transferred. Each symbol contains two consecutive bits in the case of a QPSK modulated slot and 4 consecutive bits in the case of a 16QAM modulated slot. One value is transferred per bit (range 0, 1). The number of symbols is not constant and may vary for each sweep. Individual symbols in the bit stream may be invalid depending on the channel type and the bit rate (symbols without power). The assigned invalid bits are marked by one of the digits "6", "7" or "9".

The values and number of the bits are as follows (without HS-DPCCH channels, see [SENSe:]CDPower:HSDPamode on page 120) :

**Table 10-7: Bit values and numbers without HS-DPCCH channels**

|                   |   |
|-------------------|---|
| Unit              | []  |
| Value range       | {0, 1, 6, 9}<br>0 - Low state of a transmitted bit<br>1 - High state of a transmitted bit<br>6 - Bit of a symbol of a suppressed slot of a DPCH in Compressed Mode (DPCH-CPRSD)<br>9 - Bit of a suppressed symbol of a DPCH (e.g. TFCI off) |
| Bits per slot     | $N_{\text{BitPerSymb}} = 2$   |
| Number of symbols | $N_{\text{Symb}} = 10 * 2^{(\text{8-Code Class})}$  |
| Number of bits    | $N_{\text{Bit}} = N_{\text{Symb}} * N_{\text{BitPerSymb}}$  |
| Format            | Bit <sub>00</sub> , Bit <sub>01</sub> , Bit <sub>10</sub> , Bit <sub>11</sub> , Bit <sub>20</sub> , Bit <sub>21</sub> , ..., Bit <sub>N<sub>Symb</sub>0</sub> , Bit <sub>N<sub>Symb</sub>1</sub>  |

The values and number of the bits including HS-DPCCH channels (see [SENSe: ]CDPower:HSDPamode on page 120) are as follows:

**Table 10-8: Bit values and numbers including HS-DPCCH channels**

|                   |   |
|-------------------|---|
| Unit              | []  |
| Value range       | {0, 1, 6, 7, 8, 9}<br>0 - Low state of a transmitted bit<br>1 - High state of a transmitted bit<br>6 - Bit of a symbol of a suppressed slot of a DPCH in Compressed Mode (DPCH-CPRSD)<br>7 - Bit of a switched-off symbol of an HS-PDSCH channel<br>8 - Fill value for unused bits of a lower order modulation symbol in a frame containing higher order modulation<br>9 - Bit of a suppressed symbol of a DPCH (e.g. TFCI off)   |
| Bits per symbol   | $N_{\text{BitPerSymb}} = \{2, 4, 6\}$   |
| Symbols per slot  | $N_{\text{Symb_Slot}} = 10 \cdot 2^{(8-\text{Code Class})}$   |
| Symbols per frame | $N_{\text{Symb_Frame}} = 15 \cdot N_{\text{Symb_Slot}} = 150 \cdot 2^{(8-\text{Code Class})}$   |
| Number of bits    | $N_{\text{Bit}} = N_{\text{Symb_Frame}} \cdot N_{\text{BitPerSymb\_MAX}}$   |
| Format (16QAM)    | Bit <sub>00</sub> , Bit <sub>01</sub> , Bit <sub>02</sub> , Bit <sub>03</sub> , Bit <sub>10</sub> , Bit <sub>11</sub> , Bit <sub>12</sub> , Bit <sub>13</sub> , ..., ..., ,<br>Bit <sub>N<sub>Symb_Frame</sub> 0</sub> , Bit <sub>N<sub>Symb_Frame</sub> 1</sub> , Bit <sub>N<sub>Symb_Frame</sub> 2</sub> ,<br>Bit <sub>N<sub>Symb_Frame</sub> 3</sub>   |
| Format (64QAM)    | Bit <sub>00</sub> , Bit <sub>01</sub> , Bit <sub>02</sub> , Bit <sub>03</sub> , Bit <sub>04</sub> , Bit <sub>05</sub> , Bit <sub>10</sub> , Bit <sub>11</sub> , Bit <sub>12</sub> , Bit <sub>13</sub> , Bit <sub>14</sub> , Bit <sub>15</sub> , ..., ,<br>Bit <sub>N<sub>Symb_Frame</sub> 0</sub> , Bit <sub>N<sub>Symb_Frame</sub> 1</sub> , Bit <sub>N<sub>Symb_Frame</sub> 2</sub> , Bit <sub>N<sub>Symb_Frame</sub> 3</sub> , Bit <sub>N<sub>Symb_Frame</sub> 4</sub> , Bit <sub>N<sub>Symb_Frame</sub> 5</sub> |

### 10.8.2.13 Frequency Error vs Slot

When the trace data for this evaluation is queried, 15 pairs of slot (slot number of CPICH) and values are transferred:

<slot number>, <value in Hz>

### 10.8.2.14 Phase Discontinuity vs Slot

When the trace data for this evaluation is queried, 15 pairs of slot (slot number of CPICH) and values are transferred:

<slot number>, <value in deg>

### 10.8.2.15 EVM vs Chip

When the trace data for this evaluation is queried, a list of vector error values of all chips at the selected slot is returned (=2560 values). The values are calculated as the square root of the square difference between the received signal and the reference sig-

nal for each chip, normalized to the square root of the average power at the selected slot.

#### 10.8.2.16 Mag Error vs Chip

When the trace data for this evaluation is queried, a list of magnitude error values of all chips at the selected slot is returned (=2560 values). The values are calculated as the magnitude difference between the received signal and the reference signal for each chip in %, and are normalized to the square root of the average power at the selected slot.

#### 10.8.2.17 Phase Error vs Chip

When the trace data for this evaluation is queried, a list of phase error values of all chips in the selected slot is returned (=2560 values). The values are calculated as the phase difference between the received signal and the reference signal for each chip in degrees, and are normalized to the square root of the average power at the selected slot.

#### 10.8.2.18 Symbol Magnitude Error

When the trace data for this evaluation is queried, the magnitude error in % of each symbol at the selected slot is transferred. The number of the symbols depends on the spreading factor of the selected channel:

$$\text{NOFSymbols} = 10 * 2^{(8 - \text{CodeClass})}$$

#### 10.8.2.19 Symbol Phase Error

When the trace data for this evaluation is queried, the phase error in degrees of each symbol at the selected slot is transferred. The number of the symbols depends on the spreading factor of the selected channel:

$$\text{NOFSymbols} = 10 * 2^{(8 - \text{CodeClass})}$$

### 10.8.3 Retrieving Trace Results

The following commands describe how to retrieve the trace data from the CDA and Time Alignment Error measurements. Note that for these measurements, only 1 trace per window can be configured.

- `FORMat [ :DATA ]`
- `TRACe<n> [ :DATA ] ?` on page 188
- `TRACe<n>[:DATA]? TRACE1`
- `TRACe<n>[:DATA]? ABITstream`
- `TRACe<n>[:DATA]? ATRace1`
- `TRACe<n>[:DATA]? CTABLE`

- TRACe<n>[:DATA]? CWCDp
- TRACe<n>[:DATA]? FINa1
- TRACe<n>[:DATA]? PWCDp
- TRACe<n>[:DATA]? TPVSlot

---

**FORMat[:DATA] <Format>**

This command selects the data format that is used for transmission of trace data from the R&S VSE to the controlling computer.

Note that the command has no effect for data that you send to the R&S VSE. The R&S VSE automatically recognizes the data it receives, regardless of the format.

**Parameters:**

&lt;Format&gt;

**AScii**

AScii format, separated by commas.

This format is almost always suitable, regardless of the actual data format. However, the data is not as compact as other formats may be.

**REAL,32**

32-bit IEEE 754 floating-point numbers in the "definite length block format".

For I/Q data, 8 bytes per sample are returned for this format setting.

\*RST:        ASCII

**Example:**

```
FORM REAL,32
```

**Usage:**

SCPI confirmed

---

**TRACe<n>[:DATA]? <MeasMode>**

This command queries the trace data from the measurement. Depending on the selected measurement mode, the results vary. For a detailed description of the results, see the individual commands.

**Query parameters:**

&lt;MeasMode&gt;

ATRACE1 | ABITstream1 | CTABLE | CEVM | CWCDp |  
FINAL1 | LIST | PWCDp | TPVSlot | TRACE1

The data type defines which type of trace data is read.

**Example:**

```
TRAC:DATA? ATRACE
```

**Usage:**

Query only

---

**TRACe<n>[:DATA]? TRACE1**

This command returns the trace data. Depending on the evaluation, the trace data format varies.

The channels are output in a comma-separated list in ascending order sorted by code number, i.e. in the same sequence they are displayed on screen.

For details see [chapter 10.8.2, "Measurement Results for TRACe<n>\[:DATA\]? TRACE<n>"](#), on page 181.

**Return values:**

|                |  |
|----------------|--|
| <CodeClass>    | <b>2 ... 9</b><br>Code class of the channel  |
| <ChannelNo>    | <b>0 ... 511</b><br>Code number of the channel   |
| <AbsLevel>     | <b>dBm</b><br>Absolute level of the code channel at the selected channel slot.   |
| <RelLevel>     | <b>%</b><br>Relative level of the code channel at the selected channel slot referenced to CPICH or total power.  |
| <TimingOffset> | <b>0 ... 38400 [chips]</b><br>Timing offset of the code channel to the CPICH frame start. The value is measured in chips. The step width is 256 chips in the case of code class 2 to 8, and 512 chips in the case of code class 9. |

**Example:**

```
TRAC2:DATA? TRACE1
```

Returns the trace data from trace 1 in window 2.

**Usage:**

Query only

**Manual operation:**

See ["Code Domain Error Power"](#) on page 18  
 See ["Composite Constellation"](#) on page 18  
 See ["Composite EVM"](#) on page 19  
 See ["EVM vs Chip"](#) on page 20  
 See ["Mag Error vs Chip"](#) on page 22  
 See ["Peak Code Domain Error"](#) on page 23  
 See ["Phase Discontinuity vs Slot"](#) on page 24  
 See ["Phase Error vs Chip"](#) on page 24  
 See ["Power vs Symbol"](#) on page 26  
 See ["Result Summary"](#) on page 27  
 See ["Symbol Constellation"](#) on page 27  
 See ["Symbol EVM"](#) on page 28  
 See ["Symbol Magnitude Error"](#) on page 29  
 See ["Symbol Phase Error"](#) on page 29

**TRACe<n>[:DATA]? ABITstream**

This command returns the bit streams of all 15 slots one after the other. The output format may be REAL, UINT or ASCII. The number of bits of a 16QAM-modulated channel is twice that of a QPSK-modulated channel, the number of bits of a 64QAM-modulated channel is three times that of a QPSK-modulated channel.

This query is only available if the evaluation for the corresponding window is set to "Bit-stream" using the `LAY:ADD:WIND "XTIM:CDP:BSTream"` command (see [LAYout:ADD\[:WINDOW\]?](#) on page 171).

The output format is identical to that of the `TRAC:DATA? TRAC` command for an activated Bitstream evaluation (see [chapter 10.8.2, "Measurement Results for TRACe<n>\[:DATA\]? TRACE<n>"](#), on page 181). The only difference is the number of symbols which are evaluated. The `ABITstream` parameter evaluates all symbols of one entire frame (vs. only one slot for `TRAC:DATA? TRAC`).

The values 7 and 8 are only used in case of a varying modulation type of an HS-PDSCH channel. In this case the number of bits per symbol (`NBitPerSymb`) varies, as well. However, the length of the transmitted bit vector (`NBit`) depends only on the maximum number of bits per symbol in that frame. Thus, if the modulation type changes throughout the frame this will not influence the number of bits being transmitted (see examples below).

**Example:**

```
LAY:REPL 2, "XTIM:CDP:BSTream"
Sets the evaluation for window 2 to bit stream.
TRAC2:DATA? ABITstream
Returns the bit streams of all 15 slots in window 2, one after the other.
```

**Usage:** Query only

**Manual operation:** See ["Bitstream"](#) on page 15

#### Examples for bits 7 and 8 for changing modulation types

##### Example 1:

Some slots of the frame are 64QAM modulated, other are 16QAM and QPSK modulated and some are switched OFF (NONE). If one or more slots of the frame are 64QAM modulated, six bits per symbol are transmitted and if the highest modulation order is 16QAM, four bits per symbol are transmitted. In any slot of the frame with lower order modulation, the first two or four of the four or six bits are marked by the number 8 and the last bits represent the transmitted symbol. If no power is transmitted in a slot, four or six entries per symbol of value 7 are transmitted.

##### Example 2:

Some slots of the frame are QPSK modulated and some are switched OFF. If one or more slots of the frame are QPSK modulated and no slot is 16QAM modulated, 2 bits per symbol are transmitted. If no power is transmitted in a slot, 2 entries per symbol of value 7 are transmitted.

##### Example 3:

Some slots of a DPCH are suppressed because of compressed mode transmission. The bits of the suppressed slots are marked by the digit '6'. In this case, always 2 bits per symbol are transmitted.

---

#### TRACe<n>[:DATA]? ATRace1

This command returns a list of absolute Frequency Error vs Slot values for all 16 slots (based on CPICH slots). In contrast to the `TRACE1` parameter return value, absolute values are returned.

**Return values:**

|              |  |
|--------------|--|
| <SlotNumber> | Slot number                                  |
| <FreqError>  | Absolute frequency error<br>Default unit: Hz |

**Example:**

```
TRAC2:DATA? ATR
```

Returns a list of absolute frequency errors for all slots in window 2.

**Usage:**

Query only

**Mode:**

BTS application only

**Manual operation:**

See ["Frequency Error vs Slot"](#) on page 21

**TRACe<n>[:DATA]? CTABle**

This command returns the pilot length and the channel state (active, inactive) in addition to the values returned for `TRACE<t>`.

This command is only available for Code Domain Power or Channel Table evaluations (see [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14).

**Return values:**

|                |  |
|----------------|--|
| <CodeClass>    | <b>2 ... 9</b><br>Code class of the channel  |
| <ChannelNo>    | <b>0 ... 511</b><br>Code number of the channel   |
| <AbsLevel>     | <b>dBm</b><br>Absolute level of the code channel at the selected channel slot.   |
| <RelLevel>     | <b>%</b><br>Relative level of the code channel at the selected channel slot referenced to CPICH or total power.  |
| <TimingOffset> | <b>0 ... 38400 [chips]</b><br>Timing offset of the code channel to the CPICH frame start. The value is measured in chips. The step width is 256 chips in the case of code class 2 to 8, and 512 chips in the case of code class 9. |
| <PilotLength>  | The length of the pilot symbols. According to the 3GPP standard, the pilot length range depends on the code class.<br>Range: 0,2,4,8,16<br>Default unit: symbols   |
| <ActiveFlag>   | 0   1<br>Flag to indicate whether a channel is active (1) or not (0)   |

**Example:**

```
TRAC:DATA? CTABle
```

Returns a list of channel information, including the pilot length and channel state.

|                          |  |
|--------------------------|--|
| <b>Usage:</b>            | Query only   |
| <b>Manual operation:</b> | See " <a href="#">Channel Table</a> " on page 15<br>See " <a href="#">Code Domain Power</a> " on page 17 |

---

### TRACe<n>[:DATA]? CWCDp

This command returns additional results to the values returned for TRACE<t>.

The result is a comma-separated list with 10 values for each channel; the channels are output in ascending order sorted by code number, i.e. in the same sequence they are displayed on screen.

This command is only available for Code Domain Power or Channel Table evaluations (see [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14).

#### Return values:

|                |  |
|----------------|--|
| <CodeClass>    | <b>2 ... 9</b><br>Code class of the channel  |
| <ChannelNo>    | <b>0 ... 511</b><br>Code number of the channel   |
| <AbsLevel>     | <b>dBm</b><br>Absolute level of the code channel at the selected channel slot.   |
| <RelLevel>     | <b>%</b><br>Relative level of the code channel at the selected channel slot referenced to CPICH or total power.  |
| <TimingOffset> | <b>0 ... 38400 [chips]</b><br>Timing offset of the code channel to the CPICH frame start. The value is measured in chips. The step width is 256 chips in the case of code class 2 to 8, and 512 chips in the case of code class 9. |
| <PilotLength>  | The length of the pilot symbols. According to the 3GPP standard, the pilot length range depends on the code class.<br>Range: 0,2,4,8,16<br>Default unit: symbols   |
| <ActiveFlag>   | 0   1<br>Flag to indicate whether a channel is active (1) or not (0)   |
| <ChannelType>  | Channel type. For details see <a href="#">table 10-2</a> .<br>Range: 0 ... 16  |



|                          |  |
|--------------------------|--|
| <ModType>                | Modulation type of the code channel at the selected channel slot<br><b>2</b><br>QPSK<br><b>4</b><br>16 QAM<br><b>15</b><br>NONE<br>There is no power in the selected channel slot (slot is switched OFF).<br>Range: 2,4,15 |
| <Reserved>               | for future use   |
| <b>Example:</b>          | TRAC:DATA? CWCDp<br>Returns a list of channel information for each channel in ascending order.   |
| <b>Usage:</b>            | Query only   |
| <b>Manual operation:</b> | See "Channel Table" on page 15<br>See "Code Domain Power" on page 17   |

---

**TRACe<n>[:DATA]? FINa11**

This command returns the peak list. For each peak the following results are given:

**Return values:**

|              |   |
|--------------|---|
| <Freq>       | Peak frequency  |
| <Level>      | Peak level  |
| <DeltaLevel> | Delta between current peak level and next higher peak level |

**Example:** TRAC2:DATA? FINa11  
Returns a list of peak values.

**Usage:** Query only

**Mode:** BTS application only

---

**TRACe<n>[:DATA]? PWCDp**

This command returns the pilot length in addition to the values returned for "TRACE<t>".

This command is only available for Code Domain Power or Channel Table evaluations (see [chapter 3.1.2, "Evaluation Methods for Code Domain Analysis"](#), on page 14).

**Return values:**

|             |  |
|-------------|--|
| <CodeClass> | <b>2 ... 9</b><br>Code class of the channel    |
| <ChannelNo> | <b>0 ... 511</b><br>Code number of the channel |

|                          |  |
|--------------------------|--|
| <AbsLevel>               | <b>dBm</b><br>Absolute level of the code channel at the selected channel slot.   |
| <RelLevel>               | <b>%</b><br>Relative level of the code channel at the selected channel slot referenced to CPICH or total power.  |
| <TimingOffset>           | <b>0 ... 38400 [chips]</b><br>Timing offset of the code channel to the CPICH frame start. The value is measured in chips. The step width is 256 chips in the case of code class 2 to 8, and 512 chips in the case of code class 9. |
| <PilotLength>            | 0,2,4,8,16<br>The length of the pilot symbols. According to the 3GPP standard, the pilot length range depends on the code class.<br>Default unit: symbols  |
| <b>Example:</b>          | <code>TRAC:DATA? PWCDp</code><br>Returns a list of channel information, including the pilot length.  |
| <b>Usage:</b>            | Query only   |
| <b>Mode:</b>             | BTS application only   |
| <b>Manual operation:</b> | See " <a href="#">Channel Table</a> " on page 15<br>See " <a href="#">Code Domain Power</a> " on page 17   |

---

#### TRACe<n>[:DATA]? TPVSlot

This command returns a comma-separated list of absolute Power vs Slot results for all 16 slots. In contrast to the `TRACE<t>` parameter result, absolute values are returned.

**Return values:**

|              |                                    |
|--------------|------------------------------------|
| <SlotNumber> | <b>0...15</b><br>CPICH slot number |
| <Level>      | <b>dBm</b><br>Slot level value     |

**Example:** `CALC2:FEED 'XTIM:CDP:PVSlot:ABSolute'`  
Sets the evaluation for window 2 to POWER VS SLOT.  
`TRAC2:DATA? TPVSlot`  
Returns a list of absolute frequency errors for all slots in window 2.

**Usage:** Query only

**Manual operation:** See "[Power vs Slot](#)" on page 26

## 10.9 Analysis

The following commands define general result analysis settings concerning the traces and markers.

- [Traces](#)..... 195
- [Markers](#)..... 196
- [Zooming into the Display](#).....204

### 10.9.1 Traces

The trace settings determine how the measured data is analyzed and displayed on the screen. In 3GPP FDD applications, only one trace per window can be configured for Code Domain Analysis.

- [DISPlay\[:WINDow<n>\]:TRACe<t>:MODE](#)..... 195
- [DISPlay\[:WINDow<n>\]:TRACe<t>\[:STATe\]](#)..... 196

---

#### **DISPlay[:WINDow<n>]:TRACe<t>:MODE <Mode>**

This command selects the trace mode.

##### **Parameters:**

<Mode>

##### **WRITe**

Overwrite mode: the trace is overwritten by each sweep. This is the default setting.

##### **AVERage**

The average is formed over several sweeps. The "Sweep/Average Count" determines the number of averaging procedures.

##### **MAXHold**

The maximum value is determined over several sweeps and displayed. The R&S VSE saves the sweep result in the trace memory only if the new value is greater than the previous one.

##### **MINHold**

The minimum value is determined from several measurements and displayed. The R&S VSE saves the sweep result in the trace memory only if the new value is lower than the previous one.

##### **VIEW**

The current contents of the trace memory are frozen and displayed.

##### **BLANK**

Hides the selected trace.

\*RST: Trace 1: WRITe, Trace 2-6: BLANK

**Example:**

```
INIT:CONT OFF
Switching to single sweep mode.
SWE:COUN 16
Sets the number of measurements to 16.
DISP:TRAC3:MODE WRIT
Selects clear/write mode for trace 3.
INIT;*WAI
Starts the measurement and waits for the end of the measurement.
```

**Manual operation:** See "Trace Mode" on page 91

---

### DISPlay[:WINDow<n>]:TRACe<t>[:STATe] <State>

This command turns a trace on and off.

The measurement continues in the background.

**Parameters:**

<State> ON | OFF | 0 | 1  
 \*RST: 1 for TRACe1, 0 for TRACe 2 to 6

**Example:** DISP:TRAC3 ON

**Usage:** SCPI confirmed

## 10.9.2 Markers

Markers help you analyze your measurement results by determining particular values in the diagram. In 3GPP FDD applications, only 4 markers per window can be configured for Code Domain Analysis.

- [Individual Marker Settings](#)..... 196
- [General Marker Settings](#)..... 200
- [Positioning the Marker](#)..... 200

### 10.9.2.1 Individual Marker Settings

|  |     |
|--|-----|
| CALCulate<n>:MARKer<m>:AOFF.....             | 196 |
| CALCulate<n>:MARKer<m>[:STATe].....          | 197 |
| CALCulate<n>:MARKer<m>:X.....                | 197 |
| CALCulate<n>:MARKer<m>:Y?.....               | 197 |
| CALCulate<n>:DELTAmarker<m>[:STATe].....     | 198 |
| CALCulate<n>:DELTAmarker<m>:AOFF.....        | 198 |
| CALCulate<n>:DELTAmarker<m>:X.....           | 198 |
| CALCulate<n>:DELTAmarker<m>:X:RELative?..... | 199 |
| CALCulate<n>:DELTAmarker<m>:Y?.....          | 199 |

---

### CALCulate<n>:MARKer<m>:AOFF

This command turns all markers off.

- Example:** `CALC:MARK:AOFF`  
Switches off all markers.
- Usage:** Event
- Manual operation:** See "[All Markers Off](#)" on page 94

#### **CALCulate<n>:MARKer<m>[:STATe] <State>**

This command turns markers on and off. If the corresponding marker number is currently active as a deltamarker, it is turned into a normal marker.

##### **Parameters:**

<State> ON | OFF  
\*RST: OFF

- Example:** `CALC:MARK3 ON`  
Switches on marker 3.

- Manual operation:** See "[MI Marker 1/ Delta 1/ Delta 2/.../Delta 4](#)" on page 92  
See "[Marker State](#)" on page 93  
See "[Marker Type](#)" on page 93

#### **CALCulate<n>:MARKer<m>:X <Position>**

This command moves a marker to a particular coordinate on the x-axis.

If necessary, the command activates the marker.

If the marker has been used as a delta marker, the command turns it into a normal marker.

##### **Parameters:**

<Position> Numeric value that defines the marker position on the x-axis. The unit is either Hz (frequency domain) or s (time domain) or dB (statistics).  
Range: The range depends on the current x-axis range.

- Example:** `CALC:MARK2:X 1.7MHz`  
Positions marker 2 to frequency 1.7 MHz.

- Manual operation:** See "[Marker Table](#)" on page 22  
See "[MI Marker 1/ Delta 1/ Delta 2/.../Delta 4](#)" on page 92  
See "[X-value](#)" on page 93

#### **CALCulate<n>:MARKer<m>:Y?**

This command queries the position of a marker on the y-axis.

If necessary, the command activates the marker first.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single measurement mode.

**Return values:**

<Result> Result at the marker position.

**Example:**

```
INIT:CONT OFF
Switches to single measurement mode.
CALC:MARK2 ON
Switches marker 2.
INIT;*WAI
Starts a measurement and waits for the end.
CALC:MARK2:Y?
Outputs the measured value of marker 2.
```

**Usage:**

Query only

**Manual operation:**

See "[Marker Table](#)" on page 22

See "[MI](#) Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92

**CALCulate<n>:DELTamarker<m>[:STATE] <State>**

This command turns delta markers on and off.

If necessary, the command activates the delta marker first.

No suffix at DELTmarker turns on delta marker 1.

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Example:**

```
CALC:DELT2 ON
Turns on delta marker 2.
```

**Manual operation:**

See "[MI](#) Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92

See "[Marker State](#)" on page 93

See "[Marker Type](#)" on page 93

**CALCulate<n>:DELTamarker<m>:AOFF**

This command turns *all* delta markers off.

(<m> is irrelevant)

**Example:**

```
CALC:DELT:AOFF
Turns all delta markers off.
```

**Usage:**

Event

**CALCulate<n>:DELTamarker<m>:X <Position>**

This command moves a delta marker to a particular coordinate on the x-axis.

If necessary, the command activates the delta marker and positions a reference marker to the peak power.

**Parameters:**

<Position> Numeric value that defines the marker position on the x-axis.  
 Range: The value range and unit depend on the measurement and scale of the x-axis.

**Example:**

CALC:DELT:X?  
 Outputs the absolute x-value of delta marker 1.

**Manual operation:**

See " Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92  
 See "X-value" on page 93

**CALCulate<n>:DELTamarker<m>:X:RELative?**

This command queries the relative position of a delta marker on the x-axis.

If necessary, the command activates the delta marker first.

**Return values:**

<Position> Position of the delta marker in relation to the reference marker.

**Example:**

CALC:DELT3:X:REL?  
 Outputs the frequency of delta marker 3 relative to marker 1 or relative to the reference position.

**Usage:**

Query only

**Manual operation:**

See " Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92

**CALCulate<n>:DELTamarker<m>:Y?**

This command queries the relative position of a delta marker on the y-axis.

If necessary, the command activates the delta marker first.

To get a valid result, you have to perform a complete measurement with synchronization to the end of the measurement before reading out the result. This is only possible for single measurement mode.

The unit depends on the application of the command.

**Return values:**

<Position> Position of the delta marker in relation to the reference marker.

**Example:**

INIT:CONT OFF  
 Switches to single sweep mode.  
 INIT;\*WAI  
 Starts a sweep and waits for its end.  
 CALC:DELT2 ON  
 Switches on delta marker 2.  
 CALC:DELT2:Y?  
 Outputs measurement value of delta marker 2.

**Usage:**

Query only

**Manual operation:**

See " Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92

### 10.9.2.2 General Marker Settings

|                     |     |
|---------------------|-----|
| DISPlay:MTABLE..... | 200 |
|---------------------|-----|

---

#### DISPlay:MTABLE <DisplayMode>

This command turns the marker table on and off.

#### Parameters:

|               |             |  |
|---------------|-------------|--|
| <DisplayMode> | <b>ON</b>   | Turns the marker table on.                                 |
|               | <b>OFF</b>  | Turns the marker table off.                                |
|               | <b>AUTO</b> | Turns the marker table on if 3 or more markers are active. |
| *RST:         | AUTO        |  |

**Example:**           DISP:MTAB ON  
Activates the marker table.

**Manual operation:** See "Marker Table Display" on page 94

### 10.9.2.3 Positioning the Marker

This chapter contains remote commands necessary to position the marker on a trace.

- Positioning Normal Markers ..... 200
- Positioning Delta Markers..... 202

#### Positioning Normal Markers

The following commands position markers on the trace.

|   |     |
|---|-----|
| CALCulate<n>:MARKer<m>:FUNCTion:CPICH.....  | 200 |
| CALCulate<n>:MARKer<m>:FUNCTion:PCCPch..... | 201 |
| CALCulate<n>:MARKer<m>:MAXimum:LEFT.....    | 201 |
| CALCulate<n>:MARKer<m>:MAXimum:NEXT.....    | 201 |
| CALCulate<n>:MARKer<m>:MAXimum[:PEAK].....  | 201 |
| CALCulate<n>:MARKer<m>:MAXimum:RIGHT.....   | 201 |
| CALCulate<n>:MARKer<m>:MINimum:LEFT.....    | 202 |
| CALCulate<n>:MARKer<m>:MINimum:NEXT.....    | 202 |
| CALCulate<n>:MARKer<m>:MINimum[:PEAK].....  | 202 |
| CALCulate<n>:MARKer<m>:MINimum:RIGHT.....   | 202 |

---

#### CALCulate<n>:MARKer<m>:FUNCTion:CPICH

This command sets the marker to channel 0.

This command is only available in Code Domain Power and Code Domain Error Power evaluations.

**Example:**           CALC:MARK:FUNC:CPIC



**Manual operation:** See ["Marker To CPICH"](#) on page 96

---

#### **CALCulate<n>:MARKer<m>:FUNCtion:PCCPch**

This command sets the marker to the position of the PCCPCH.

This command is only available in code domain power and code domain error power evaluations.

**Example:** `CALC:MARK:FUNC:PCCP`

**Manual operation:** See ["Marker To PCCPCH"](#) on page 96

---

#### **CALCulate<n>:MARKer<m>:MAXimum:LEFT**

This command moves a marker to the next lower peak.

The search includes only measurement values to the left of the current marker position.

**Usage:** Event

**Manual operation:** See ["Search Next Peak"](#) on page 95

---

#### **CALCulate<n>:MARKer<m>:MAXimum:NEXT**

This command moves a marker to the next lower peak.

**Usage:** Event

**Manual operation:** See ["Search Next Peak"](#) on page 95

---

#### **CALCulate<n>:MARKer<m>:MAXimum[:PEAK]**

This command moves a marker to the highest level.

If the marker is not yet active, the command first activates the marker.

**Usage:** Event

**Manual operation:** See ["Peak Search"](#) on page 96

---

#### **CALCulate<n>:MARKer<m>:MAXimum:RIGHT**

This command moves a marker to the next lower peak.

The search includes only measurement values to the right of the current marker position.

**Usage:** Event

**Manual operation:** See ["Search Next Peak"](#) on page 95

**CALCulate<n>:MARKer<m>:MINimum:LEFT**

This command moves a marker to the next minimum value.

The search includes only measurement values to the right of the current marker position.

**Usage:** Event

**Manual operation:** See "[Search Next Minimum](#)" on page 96

**CALCulate<n>:MARKer<m>:MINimum:NEXT**

This command moves a marker to the next minimum value.

**Usage:** Event

**Manual operation:** See "[Search Next Minimum](#)" on page 96

**CALCulate<n>:MARKer<m>:MINimum[:PEAK]**

This command moves a marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

**Usage:** Event

**Manual operation:** See "[Search Minimum](#)" on page 96

**CALCulate<n>:MARKer<m>:MINimum:RIGHT**

This command moves a marker to the next minimum value.

The search includes only measurement values to the right of the current marker position.

**Usage:** Event

**Manual operation:** See "[Search Next Minimum](#)" on page 96

**Positioning Delta Markers**

The following commands position delta markers on the trace.

|   |     |
|---|-----|
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:FUNCTION:CPICH</a> .....  | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:FUNCTION:PCCPch</a> ..... | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MAXimum:LEFT</a> .....    | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MAXimum:NEXT</a> .....    | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MAXimum[:PEAK]</a> .....  | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MAXimum:RIGHT</a> .....   | 203 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MINimum:LEFT</a> .....    | 204 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MINimum:NEXT</a> .....    | 204 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MINimum[:PEAK]</a> .....  | 204 |
| <a href="#">CALCulate&lt;n&gt;:DELTAmarker&lt;m&gt;:MINimum:RIGHT</a> .....   | 204 |

---

**CALCulate<n>:DELTamarker<m>:FUNCTion:CPICH**

This command sets the delta marker to channel 0.

This command is only available in Code Domain Power and Code Domain Error Power evaluations.

**Example:**                    `CALC:DELT2:FUNC:CPIC`

---

**CALCulate<n>:DELTamarker<m>:FUNCTion:PCCPch**

This command sets the delta marker to the position of the PCCPCH.

This command is only available in code domain power and code domain error power evaluations.

**Example:**                    `CALC:DELT2:FUNC:PCCP`

---

**CALCulate<n>:DELTamarker<m>:MAXimum:LEFT**

This command moves a delta marker to the next higher value.

The search includes only measurement values to the left of the current marker position.

**Usage:**                    Event

**Manual operation:**    See "[Search Next Peak](#)" on page 95

---

**CALCulate<n>:DELTamarker<m>:MAXimum:NEXT**

This command moves a marker to the next higher value.

**Usage:**                    Event

**Manual operation:**    See "[Search Next Peak](#)" on page 95

---

**CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK]**

This command moves a delta marker to the highest level.

If the marker is not yet active, the command first activates the marker.

**Usage:**                    Event

**Manual operation:**    See "[Peak Search](#)" on page 96

---

**CALCulate<n>:DELTamarker<m>:MAXimum:RIGHT**

This command moves a delta marker to the next higher value.

The search includes only measurement values to the right of the current marker position.

**Usage:**                    Event

**Manual operation:** See ["Search Next Peak"](#) on page 95

---

#### **CALCulate<n>:DELTamarker<m>:MINimum:LEFT**

This command moves a delta marker to the next higher minimum value.

The search includes only measurement values to the right of the current marker position.

**Usage:** Event

**Manual operation:** See ["Search Next Minimum"](#) on page 96

---

#### **CALCulate<n>:DELTamarker<m>:MINimum:NEXT**

This command moves a marker to the next higher minimum value.

**Usage:** Event

**Manual operation:** See ["Search Next Minimum"](#) on page 96

---

#### **CALCulate<n>:DELTamarker<m>:MINimum[:PEAK]**

This command moves a delta marker to the minimum level.

If the marker is not yet active, the command first activates the marker.

**Usage:** Event

**Manual operation:** See ["Search Minimum"](#) on page 96

---

#### **CALCulate<n>:DELTamarker<m>:MINimum:RIGHT**

This command moves a delta marker to the next higher minimum value.

The search includes only measurement values to the right of the current marker position.

**Usage:** Event

**Manual operation:** See ["Search Next Minimum"](#) on page 96

## 10.9.3 Zooming into the Display


### 10.9.3.1 Using the Single Zoom

|  |     |
|--|-----|
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:ZOOM:AREA</a> .....  | 205 |
| <a href="#">DISPlay[:WINDow&lt;n&gt;]:ZOOM:STATe</a> ..... | 205 |

**DISPlay[:WINDow<n>]:ZOOM:AREA <x1>,<y1>,<x2>,<y2>**

This command defines the zoom area.

To define a zoom area, you first have to turn the zoom on.



- 1 = origin of coordinate system (x1 = 0, y1 = 0)
- 2 = end point of system (x2 = 100, y2 = 100)
- 3 = zoom area (e.g. x1 = 60, y1 = 30, x2 = 80, y2 = 75)

**Parameters:**

<x1>,<y1>,  
<x2>,<y2>

Diagram coordinates in % of the complete diagram that define the zoom area.  
The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system.  
Range: 0 to 100  
Default unit: PCT

**Manual operation:** See "Single Zoom" on page 82

**DISPlay[:WINDow<n>]:ZOOM:STATe <State>**

This command turns the zoom on and off.

**Parameters:**

<State> ON | OFF  
\*RST: OFF

**Example:**

DISP:ZOOM ON  
Activates the zoom mode.

**Manual operation:** See "Single Zoom" on page 82  
See "Restore Original Display" on page 82  
See "Deactivating Zoom (Selection mode)" on page 83


**10.9.3.2 Using the Multiple Zoom**

DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:AREA.....205  
DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:STATe..... 206

**DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:AREA <x1>,<y1>,<x2>,<y2>**

This command defines the zoom area for a multiple zoom.

To define a zoom area, you first have to turn the zoom on.



- 1 = origin of coordinate system (x1 = 0, y1 = 0)  
 2 = end point of system (x2 = 100, y2 = 100)  
 3 = zoom area (e.g. x1 = 60, y1 = 30, x2 = 80, y2 = 75)

**Suffix:**

<zoom> 1...4  
 Selects the zoom window.

**Parameters:**

<x1>, <y1>, <x2>, <y2>  
 Diagram coordinates in % of the complete diagram that define the zoom area.  
 The lower left corner is the origin of coordinate system. The upper right corner is the end point of the system.  
 Range: 0 to 100  
 Default unit: PCT

**Manual operation:** See ["Multiple Zoom"](#) on page 82

**DISPlay[:WINDow<n>]:ZOOM:MULTiple<zoom>:STATe <State>**

This command turns the multiple zoom on and off.

**Suffix:**

<zoom> 1...4  
 Selects the zoom window.  
 If you turn off one of the zoom windows, all subsequent zoom windows move up one position.

**Parameters:**

<State> ON | OFF  
 \*RST: OFF

**Manual operation:** See ["Multiple Zoom"](#) on page 82  
 See ["Restore Original Display"](#) on page 82  
 See ["Deactivating Zoom \(Selection mode\)"](#) on page 83

## 10.10 Querying the Status Registers

The following commands are required for the status reporting system specific to the 3GPP FDD applications. In addition, the 3GPP FDD applications also use the standard status registers of the R&S VSE (depending on the measurement type).

For details on the common R&S VSE status registers refer to the description of remote control basics in the R&S VSE User Manual.



\*RST does not influence the status registers.

The `STATUS:QUESTIONABLE:SYNC` register contains application-specific information about synchronization errors or errors during pilot symbol detection.

**Table 10-9: Status error bits in `STATUS:QUESTIONABLE:SYNC` register for 3GPP FDD applications**

| Bit     | Definition  |
|---------|---|
| 0       | Not used.   |
| 1       | <p>Frame Sync failed</p> <p>This bit is set when synchronization is not possible within the application.</p> <p>Possible reasons:</p> <ul style="list-style-type: none"> <li>• Incorrectly set frequency</li> <li>• Incorrectly set level</li> <li>• Incorrectly set scrambling code</li> <li>• Incorrectly set values for Q-INVERT or SIDE BAND INVERT</li> <li>• Invalid signal at input</li> <li>• Antenna 1 synchronization is not possible (Time Alignment Error measurements, 3GPP FDD BTS only)</li> </ul>   |
| 2       | <p>For Time Alignment Error measurements (3GPP FDD BTS only): bit is set if antenna 2 synchronization is not possible;</p> <p>Otherwise: not used.</p>  |
| 3 to 4  | Not used.   |
| 5       | <p>Incorrect Pilot Symbol</p> <p>This bit is set when one or more of the received pilot symbols are not equal to the specified pilot symbols of the 3GPP standard.</p> <p>Possible reasons:</p> <ul style="list-style-type: none"> <li>• Incorrectly sent pilot symbols in the received frame.</li> <li>• Low signal to noise ratio (SNR) of the W-CDMA signal.</li> <li>• One or more code channels has a significantly lower power level compared to the total power. The incorrect pilots are detected in these channels because of low channel SNR.</li> <li>• One or more channels are sent with high power ramping. In slots with low relative power to total power, the pilot symbols might be detected incorrectly (check the signal quality by using the symbol constellation display).</li> </ul> |
| 6 to 14 | Not used.   |
| 15      | This bit is always 0.   |

|  |     |
|--|-----|
| <code>STATUS:QUESTIONABLE:SYNC[:EVENT]?.....</code>    | 208 |
| <code>STATUS:QUESTIONABLE:SYNC:CONDition?.....</code>  | 208 |
| <code>STATUS:QUESTIONABLE:SYNC:ENABLE.....</code>      | 208 |
| <code>STATUS:QUESTIONABLE:SYNC:NTRansition.....</code> | 208 |
| <code>STATUS:QUESTIONABLE:SYNC:PTRansition.....</code> | 209 |

---

**STATus:QUESTionable:SYNC[:EVENT]? <ChannelName>**

This command reads out the EVENT section of the status register.

The command also deletes the contents of the EVENT section.

**Query parameters:**

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

**Usage:** Query only

---

**STATus:QUESTionable:SYNC:CONDition? <ChannelName>**

This command reads out the CONDition section of the status register.

The command does not delete the contents of the EVENT section.

**Query parameters:**

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

**Usage:** Query only

---

**STATus:QUESTionable:SYNC:ENABle <BitDefinition>, <ChannelName>**

This command controls the ENABle part of a register.

The ENABle part allows true conditions in the EVENT part of the status register to be reported in the summary bit. If a bit is 1 in the enable register and its associated event bit transitions to true, a positive transition will occur in the summary bit reported to the next higher level.

**Parameters:**

<BitDefinition> Range: 0 to 65535

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

---

**STATus:QUESTionable:SYNC:NTRansition <BitDefinition>, <ChannelName>**

This command controls the Negative TRansition part of a register.

Setting a bit causes a 1 to 0 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

**Parameters:**

<BitDefinition> Range: 0 to 65535



<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

---

### **STATus:QUESTionable:SYNC:PTRansition** <BitDefinition>,<ChannelName>

These commands control the Positive TRansition part of a register.

Setting a bit causes a 0 to 1 transition in the corresponding bit of the associated register. The transition also writes a 1 into the associated bit of the corresponding EVENT register.

#### **Parameters:**

<BitDefinition> Range: 0 to 65535

<ChannelName> String containing the name of the channel.  
The parameter is optional. If you omit it, the command works for the currently active channel.

## 10.11 Commands for Compatibility

The following commands are provided for compatibility to other signal analyzers only. For new remote control programs use the specified alternative commands.

|                                     |     |
|-------------------------------------|-----|
| CALCulate<n>:FEED.....              | 209 |
| [SENSe:]CDPower:LEVel:ADJust.....   | 210 |
| [SENSe:]CDPower:PRESet .....        | 211 |
| [SENSe:]CDPower:UCPich:CODE.....    | 211 |
| [SENSe:]CDPower:UCPich:PATtern..... | 211 |
| [SENSe:]CDPower:UCPich[:STATe]..... | 212 |

---

### **CALCulate<n>:FEED** <Evaluation>

This command selects the evaluation method of the measured data that is to be displayed in the specified window.

Note that this command is maintained for compatibility reasons only. Use the LAYout commands for new remote control programs (see [chapter 10.7.2, "Working with Windows in the Display"](#), on page 170).

#### **Parameters:**

<Evaluation> Type of evaluation you want to display.  
See the table below for available parameter values.

#### **Example:**

```
INST:SEL BWCD
Activates 3GPP FDD BTS mode.
CALC:FEED CDP
Selects the display of the code domain power.
```

Table 10-10: &lt;Evaluation&gt; parameter values for 3GPP FDD applications

| String Parameter  | Enum Parameter | Evaluation                              |
|---|----------------|---|
| 'XTIM:CDP:BSTream'  | BITStream      | Bitstream                               |
| 'XTIM:CDP:COMP:CONStellation'                                       | CCONst         | Composite Constellation                 |
| 'XPOW:CDEPower'   | CDEPower       | Code Domain Error Power                 |
| 'XPOW:CDP'<br>'XPOW:CDP:ABSolute'                                   | CDPower        | Code Domain Power (absolute scaling)    |
| 'XPOW:CDP:RATio'  | CDPower        | Code Domain Power (relative scaling) *) |
| 'XTIM:CDP:MACCuracy'  | CEVM           | Composite EVM                           |
| 'XTIM:CDP:ERR:CTABLE'   | CTABLE         | Channel Table                           |
| 'XTIMe:CDP:CHIP:EVM'  | EVMChip        | EVM vs Chip                             |
| 'XTIM:CDP:FVSLot'   | FESLot         | Frequency Error vs Slot                 |
| 'XTIMe:CDP:CHIP:MAGNI-tude'   | MEChip         | Magnitude Error vs Chip                 |
| 'XTIM:CDP:ERR:PCDomain'   | PCDerror       | Peak Code Domain Error                  |
| 'XTIM:CDPower:PSVSlot'  | PDSLot         | Phase Discontinuity vs Slot             |
| 'XTIMe:CDPower:CHIP:PHASe'  | PEChip         | Phase Error vs Chip                     |
| 'XTIM:CDP:PVSLot'<br>'XTIM:CDP:PVSLot:ABSolute'                     | PSLot          | Power vs Slot (absolute scaling)        |
| 'XTIM:CDP:PVSLot:RATio'   | PSLot          | Power vs Slot (relative scaling)*)      |
| 'XTIM:CDP:PVSYmbol'   | PSYMBOL        | Power vs Symbol                         |
| 'XTIM:CDP:ERR:SUMMary'  | RSUMmary       | Result Summary                          |
| 'XPOW:CDP:RATio'  | SCONst         | Symbol Constellation                    |
| 'XTIM:CDP:SYMB:EVM'   | SEVM           | Symbol EVM                              |
| 'XTIMe:CDPower:SYM-Bol:EVM:MAGNI-tude'                              | SMERror        | Symbol Magnitude Error                  |
| 'XTIMe:CDPower:SYM-Bol:EVM:PHASe'                                   | SPERror        | Symbol Phase Error                      |
| *) Use [SENS:]CDP:PDIS ABS   REL subsequently to change the scaling |                |   |

**[SENSe:]CDPower:LEVel:ADJust**

This command adjusts the reference level to the measured channel power. This ensures that the settings of the RF attenuation and the reference level are optimally adjusted to the signal level without overloading the R&S VSE or limiting the dynamic range by an S/N ratio that is too small.

Note that this command is retained for compatibility reasons only. For new R&S VSE programs use [\[SENSe:\]ADJust:LEVel](#) on page 161.

---

### **[SENSe:]CDPower:PRESet**

This command resets the 3GPP FDD channel to its predefined settings. Any RF measurement is aborted and the measurement type is reset to Code Domain Analysis.

Note that this command is retained for compatibility reasons only. For new R&S VSE programs use [SYSTEM:PRESet:CHANnel\[:EXECute\]](#) on page 119.

**Usage:** Event

---

### **[SENSe:]CDPower:UCPich:CODE <CodeNumber>**

This command sets the code number of the user defined CPICH used for signal analysis.

This command only applies to antenna 1.

Note that this command is maintained for compatibility reasons only. Use [\[SENSe:\]CDPower:UCPich:ANT<antenna>:CODE](#) on page 144 for new remote control programs.

**Parameters:**

<CodeNumber> Range: 0 to 225  
\*RST: 0

**Example:** SENS:CDP:UCP:CODE 10

**Mode:** BTS application only

---

### **[SENSe:]CDPower:UCPich:PATtern <Pattern>**

This command defines which pattern is used for signal analysis for the user-defined CPICH (see [\[SENSe:\]CDPower:UCPich\[:STATe\]](#) on page 212).

This command only applies to antenna 1.

Note that this command is maintained for compatibility reasons only. Use [\[SENSe:\]CDPower:UCPich:ANT<antenna>\[:STATe\]](#) on page 145 for new remote control programs.

**Parameters:**

<Pattern> 1  
fixed usage of "Pattern 1" according to standard  
2  
fixed usage of "Pattern 2" according to standard  
\*RST: 2

**Example:** SENS:CDP:UCP:PATT 1

**Mode:** BTS application only

**[SENSe:]CDPower:UCPich[:STATe] <State>**

Defines whether the common pilot channel (CPICH) is defined by a user-defined position instead of its default position.

If enabled, the user-defined position must be defined using `[SENSe:]CDPower:UCPich:CODE` on page 211.

This command only applies to antenna 1.

Note that this command is maintained for compatibility reasons only. Use `[SENSe:]CDPower:UCPich:ANT<antenna>:CODE` on page 144 for new remote control programs.

**Parameters:**

<State>                    ON | OFF  
                              \*RST:        OFF

**Example:**                SENS:CDP:UCP ON

**Mode:**                    BTS application only

## 10.12 Programming Examples (R&S VSE-K72)

The following programming examples are based on the measurement examples described in [chapter 8, "Measurement Examples"](#), on page 100 for manual operation.

The measurements are performed using the following devices and accessories:

- The R&S VSE with option R&S VSE-K72: 3GPP FDD measurements
- An R&S FSW Signal and Spectrum Analyzer
- A Vector Signal Generator R&S SMW200A with option R&S SMW-K42: digital standard 3GPP FDD (requires options R&S SMW-B10, R&S SMW-B13 and R&S SMW-B103)
- 1 coaxial cable, 50Ω, approx. 1 m, N connector
- 1 coaxial cable, 50Ω, approx. 1 m, BNC connector



### Prerequisites in the R&S VSE software

It is assumed an R&S FSW named 'MyFSW' is connected and configured for input to the R&S VSE software.

(See the R&S VSE Base Software User Manual).

Only the commands required to control the R&S VSE-K72 application and the analyzer are provided, not the signal generator.

### Test setup

1. Connect the RF A output of the R&S SMW200A to the input of the R&S VSE.

2. Connect the reference input (REF INPUT) on the rear panel of the R&S VSE to the reference input (REF OUT) on the rear panel of the R&S SMW200A (coaxial cable with BNC connectors).
3. Connect the external trigger input of the R&S VSE (TRIGGER INPUT) to the external trigger output of the R&S SMW200A (TRIGOUT1 of PAR DATA).

### Settings on the R&S SMW200A

| Setting                  | value                    |
|--------------------------|--------------------------|
| Preset                   |                          |
| Frequency                | 2.1175 GHz               |
| Level                    | 0 dBm                    |
| Digital standard         | 3GPP FDD                 |
| Link direction           | DOWN/FORWARD             |
| Test model               | Test_Model_1_16_channels |
| Base station             | BS 1                     |
| Digital standard - State | ON                       |
| Scrambling code          | 0000                     |

The following measurements are described:

- [Measurement 1: Measuring the Relative Code Domain Power](#)..... 213
- [Measurement 2: Triggered Measurement of Relative Code Domain Power](#)..... 215
- [Measurement 3: Measuring the Composite EVM](#)..... 215
- [Measurement 4: Determining the Peak Code Domain Error](#).....216

## 10.12.1 Measurement 1: Measuring the Relative Code Domain Power

```
*RST
//Reset the instrument
INST:CRE:REPL 'IQ Analyzer',BWCD,'BTSMeasurement'
//Replace the default channel by a 3GPP FDD BTS channel named "BTSMeasurement"
DISP:TRAC:Y:SCAL:RLEV 10
//Set the reference level to 10 dBm
FREQ:CENT 2.1175 GHz
//Set the center Frequency to 2.1175 GHz
DISP:TRAC:Y:SCAL:AUTO ONCE
//Optimize the scaling of the y-axis for the current measurement
INIT:CONT OFF
//Stops continuous sweep
SWE:COUN 100
//Set the number of sweeps to be performed to 100
INIT;*WAI
//Start a new measurement with 100 sweeps and wait for the end
```

```

CALC:MARK:FUNC:WCDP:BTS:RES? CDP
//Retrieve the relative code domain power
//Result: 0 [dB]
TRAC:DATA? TRACE1
//Retrieve the trace data of the code domain power measurement
//Result: +8.000000000,+0.000000000,-4.319848537,-3.011176586,+0.000000000,
//+2.000000000,+1.000000000,-4.318360806,-3.009688854,+1.000000000,
//+8.000000000,+0.000000000,-7.348078156E+001,-7.217211151E+001,+1.000000000,
// [...]

-----Synchronizing the Reference Frequencies-----

//Select the external Frequency from the REF INPUT 1..20 MHZ connector as a reference
DEV:EXTR:SOUR 'MyFSW',E10

//Query the carrier Frequency error
//Result: 0.1 [Hz]

-----Behaviour with Incorrect Scrambling Code-----

CDP:LCOD:DVAL 0001
//Change the scrambling code on the analyzer to 0001 (default is 0000)
TRAC:DATA? TRACE1
//Retrieve the trace data of the code domain power measurement
//Result: 1.000000000,+8.000000000,+7.700000000E+001,-2.991873932E+001,-2.861357307E+001,
//+0.000000000,+8.000000000,+7.800000000E+001,-2.892916107E+001,-2.762399483E+001,
//+1.000000000,+8.000000000,+7.800000000E+001,-2.856664085E+001,-2.726147461E+001,
// [...]
    
```

**Table 10-11: Trace results for Relative Code Domain Power measurement (correct scrambling code)**

| Code class   | Channel no.  | Abs. power level [dBm] | Rel. power level [%] | Timing offset [chips] |
|--------------|--------------|------------------------|----------------------|-----------------------|
| +8.000000000 | +0.000000000 | -4.319848537           | -3.011176586         | +0.000000000          |
| +2.000000000 | +1.000000000 | -4.318360806           | -3.009688854         | +1.000000000          |
| +8.000000000 | +0.000000000 | -7.348078156E+001      | -7.217211151E+001    | +1.000000000          |
| ...          | ...          |                        |                      |                       |

**Table 10-12: Trace results for Relative Code Domain Power measurement (incorrect scrambling code)**

| Code class   | Channel no.  | Abs. power level [dBm] | Rel. power level [%] | Timing offset [chips] |
|--------------|--------------|------------------------|----------------------|-----------------------|
| 1.000000000  | +8.000000000 | +7.700000000E+001      | -2.991873932E+001    | -2.861357307E+001     |
| +0.000000000 | +8.000000000 | +7.800000000E+001      | -2.892916107E+001    | -2.762399483E+001     |

| Code class   | Channel no.  | Abs. power level [dBm] | Rel. power level [%] | Timing offset [chips] |
|--------------|--------------|------------------------|----------------------|-----------------------|
| +1.000000000 | +8.000000000 | +7.800000000E+001      | -2.856664085E+001    | -2.726147461E+001     |
| ...          | ...          |                        |                      |                       |

### 10.12.2 Measurement 2: Triggered Measurement of Relative Code Domain Power

```

*RST
//Reset the instrument
INST:CRE:REPL 'IQ Analyzer',BWCD,'BTSMeasurement'
//Replace the default channel by a 3GPP FDD BTS channel named "BTSMeasurement"
DISP:TRAC:Y:SCAL:RLEV 10
//Set the reference level to 10 dBm
FREQ:CENT 2.1175 GHz
//Set the center Frequency to 2.1175 GHz
CDP:LCOD:DVAL 0000
//Change the scrambling code on the analyzer to 0000
TRIG:SOUR EXT
//Set the trigger source to the external trigger
//(TRIGGER INPUT connector)
DISP:TRAC:Y:SCAL:AUTO ONCE
//Optimize the scaling of the y-axis for the current measurement
INIT:CONT OFF
//Stops continuous sweep
SWE:COUN 100
//Set the number of sweeps to be performed to 100
INIT;*WAI
//Start a new measurement with 100 sweeps and wait for the end
CALC:MARK:FUNC:WCDP:BTS:RES? TFR
//Retrieve the trigger to frame (the offset between trigger event and
// start of first captured frame)
//Result: 0.00599987013 [ms]

----- Compensating a delay of the trigger event to the first captured frame -----

TRIG:HOLD 100 us
//Change the trigger offset to 100 us (=trigger to frame value)
CALC:MARK:FUNC:WCDP:BTS:RES? TFR
//Retrieve the trigger to frame value
//Result: 0.00599987013 [ms]

```

### 10.12.3 Measurement 3: Measuring the Composite EVM

```

*RST
//Reset the instrument

```

```

INST:CRE:REPL 'IQ Analyzer',BWCD,'BTSMeasurement'
//Replace the default channel by a 3GPP FDD BTS channel named "BTSMeasurement"
DISP:TRAC:Y:SCAL:RLEV 10
//Set the reference level to 10 dBm
FREQ:CENT 2.1175 GHz
//Set the center Frequency to 2.1175 GHz
TRIG:SOUR EXT
//Set the trigger source to the external trigger
//(TRIGGER INPUT connector)
LAY:REPL '2','XTIM:CDP:MACC'
//Replace the second measurement window (Result Summary) by Composite EVM evaluation
DISP:WIND2:TRAC:Y:SCAL:AUTO ONCE
//Optimize the scaling of the y-axis for the Composite EVM measurement
INIT:CONT OFF
//Stops continuous sweep
SWE:COUN 100
//Set the number of sweeps to be performed to 100
INIT;*WAI
//Start a new measurement with 100 sweeps and wait for the end
TRAC2:DATA? TRACE1
//Retrieve the trace data of the composite EVM measurement
//Result: +0.000000000,+5.876136422E-001,
//+1.000000000,+5.916179419E-001,
//+2.000000000,+5.949081182E-001,
//[...]

```

**Table 10-13: Trace results for Composite EVM measurement**

| (CPICH) Slot number | EVM               |
|---------------------|-------------------|
| 0                   | +5.876136422E-001 |
| 1                   | +5.916179419E-001 |
| 2                   | +5.949081182E-001 |
| ...                 | ...               |

#### 10.12.4 Measurement 4: Determining the Peak Code Domain Error

```

*RST
//Reset the instrument
INST:CRE:REPL 'IQ Analyzer',BWCD,'BTSMeasurement'
//Replace the default channel by a 3GPP FDD BTS channel named "BTSMeasurement"
DISP:TRAC:Y:SCAL:RLEV 10
//Set the reference level to 10 dBm
FREQ:CENT 2.1175 GHz
//Set the center Frequency to 2.1175 GHz
TRIG:SOUR EXT
//Set the trigger source to the external trigger
//(TRIGGER INPUT connector)
LAY:REPL '2','XTIM:CDP:ERR:PCD'

```



```

//Replace the second measurement window (Result Summary) by the
//Peak Code Domain Error evaluation
DISP:WIND2:TRAC:Y:SCAL:AUTO ONCE
//Optimize the scaling of the y-axis for the Composite EVM measurement
INIT:CONT OFF
//Stops continuous sweep
SWE:COUN 100
//Set the number of sweeps to be performed to 100
INIT;*WAI
//Start a new measurement with 100 sweeps and wait for the end
TRAC2:DATA? TRACE1
//Retrieve the trace data of the Peak Code Domain Error measurement
//Result: +0.000000000,-6.730751038E+001,
//+1.000000000,-6.687619019E+001,
//+2.000000000,-6.728615570E+001,
// [...]

```

**Table 10-14: Trace results for Peak Code Domain Error measurement**

| Slot number | Peak Error        |
|-------------|-------------------|
| 0           | -6.730751038E+001 |
| 1           | -6.687619019E+001 |
| 2           | -6.728615570E+001 |
| ...         | ...               |

# A Reference

- [Menu Reference](#).....218
- [Reference of Toolbar Functions](#).....222

## A.1 Menu Reference

Most functions in the R&S VSE are available from the menus.

- [Common R&S VSE Menus](#).....218
- [3GP FDD Measurements Menus](#).....220

### A.1.1 Common R&S VSE Menus



The following menus provide **basic functions for all applications**:

- [File Menu](#).....218
- [Window Menu](#).....219
- [Help Menu](#).....220

#### A.1.1.1 File Menu

The "File" menu includes all functionality directly related to any file operations, printing or setting up general parameters.

For a description of these functions see the "Data Management" chapter in the R&S VSE User Manual.


| Menu item                     | Corresponding icon in toolbar   | Description  |
|-------------------------------|---|--|
| Save                          |  | Saves the current software configuration to a file                   |
| Recall                        |  | Recalls a saved software configuration from a file                   |
| Save IQ Recording             | -   | Saves the recorded I/Q data from a measurement channel to a file     |
| Recall IQ Recording           | -   | Loads the recorded I/Q data from a file                              |
| Measurement Group >           | -   | Configures measurement channels and groups                           |
| > New Group                   | -   | Inserts a new group in the measurement sequence                      |
| > New Measurement Channel     | -   | Inserts a new channel in the selected group                          |
| > Replace Measurement Channel | -   | Replaces the currently selected channel by the selected application. |

| Menu item                            | Corresponding icon in toolbar | Description  |
|--------------------------------------|-------------------------------|--|
| > Delete Current Measurement Channel | -                             | Deletes the currently selected channel.  |
| > Measurement Group Setup            | -                             | Displays the "Measurement Group Setup" tool window.  |
| Instruments >                        | -                             | Configures instruments to be used for input to the R&S VSE software  |
| > New                                | -                             | Creates a new instrument configuration   |
| > Search                             | -                             | Searches for connected instruments in the network  |
| > Delete All                         | -                             | Deletes all current instrument configurations  |
| > Setup                              | -                             | Hides or displays the "Instrument" tool window   |
| Preset >                             | -                             | Restores stored settings   |
| > All                                | -                             | Restores the default software configuration globally for the entire software   |
| > All & Delete Instruments           | -                             | Restores the default software configuration globally for the entire software and deletes all instrument configurations |
| > Selected Channel                   | -                             | Restores the default software configuration for an individual channel  |
| > Reset VSE Layout                   | -                             | Restores the default layout of windows, toolbars etc. in the R&S VSE software  |
| Preferences >                        | -                             | Configures global software settings  |
| > General                            | -                             |  |
| > Displayed Items                    | -                             | Hides or shows individual screen elements  |
| > Theme & Color                      | -                             | Configures the style of individual screen elements   |
| > Network & Remote                   | -                             | Configures the network settings and remote access to or from other devices   |
| > Recording                          | -                             | Configures general recording parameters  |
| Print                                | -                             | Opens "Print" dialog to print selected measurement results   |
| Exit                                 | -                             | Closes the R&S VSE software  |

### A.1.1.2 Window Menu


The "Window" menu allows you to hide or show individual windows.

| Menu item           | Corresponding icon in toolbar | Description  |
|---------------------|-------------------------------|--|
| Player...           | -                             | Displays the "Player" tool window to recall I/Q data recordings  |
| Instrument Setup... | -                             | Displays the "Instruments" window to configure input instruments |

| Menu item                        | Corresponding icon in toolbar   | Description   |
|----------------------------------|---|---|
| Measurement Group Setup...       | -   | Displays the "Measurement Group Setup" window to configure a measurement sequence             |
| New Window >                     |  | Inserts a new result display window for the selected measurement channel                      |
| Channel Infos >                  | -   | Displays the channel bar with global channel information for the selected measurement channel |
| Active Windows >                 | -   | Selects a result display as the active window; the corresponding channel is also activated    |
| Configure Selected Result Window | -   | Displays the "Window Configuration" dialog box to configure result-specific settings          |

### A.1.1.3 Help Menu

The "Help" menu provides access to help, support and licensing functions.

| Menu item      | Corresponding icon in toolbar   | Description   |
|----------------|---|---|
| Help           |  | Opens the Online help window  |
| License        | -   | Licensing, version and options information  |
| Support        | -   | Support functions   |
| Register VSE   | -   | Attempts to create an email with the default mail program (if available) to the Rohde & Schwarz support address for registration. |
| Online Support | -   | Opens the default web browser and attempts to establish an Internet connection to the Rohde & Schwarz product site.               |
| About          | -   | Software version information  |

## A.1.2 3GP FDD Measurements Menus

The following menus are only available if a 3GP FDD measurement channel is selected.

- [Input & Output Menu](#).....221
- [Meas Setup Menu](#).....221
- [Trace Menu](#).....221
- [Marker Menu](#).....222
- [Limits Menu](#).....222

### A.1.2.1 Input & Output Menu

The "Input & Output" menu provides functions to configure the input source, frontend parameters and output settings for the measurement.

This menu is application-specific.

**Table 1-1: "Input & Output" menu items for 3GP FDD Measurements**

| Menu item    | Description   |
|--------------|---|
| Amplitude    | <a href="#">chapter 5.1.4.1, "Amplitude Settings"</a> , on page 59    |
| Scale        | <a href="#">chapter 5.1.4.2, "Y-Axis Scaling"</a> , on page 62        |
| Frequency    | <a href="#">chapter 5.1.4.3, "Frequency Settings"</a> , on page 63    |
| Trigger      | <a href="#">chapter 5.1.5, "Trigger Settings"</a> , on page 65        |
| Input Source | <a href="#">chapter 5.1.3.1, "Input Source Settings"</a> , on page 53 |
| Output       | <a href="#">chapter 5.1.3.2, "Output Settings"</a> , on page 57       |

### A.1.2.2 Meas Setup Menu

The "Meas Setup" menu provides access to most measurement-specific settings, as well as bandwidth, sweep and auto configuration settings, and the configuration "Overview" window.

This menu is application-specific.

**Table 1-2: "Meas Setup" menu items for 3GP FDD Measurements**

| Menu item            | Description  |
|----------------------|--|
| Select Measurement   | <a href="#">chapter 3, "Measurements and Result Display"</a> , on page 11                    |
| Capture              | <a href="#">"Capture / Average Count"</a> on page 69   |
| Signal Description   | <a href="#">chapter 5.1.2, "Signal Description"</a> , on page 48                             |
| Scrambling Code      | <a href="#">chapter 5.1.2.2, "BTS Scrambling Code"</a> , on page 50                          |
| Signal Capture       | <a href="#">chapter 5.1.6, "Signal Capture (Data Acquisition)"</a> , on page 68              |
| Sync                 | <a href="#">chapter 5.1.7, "Synchronization (BTS Measurements Only)"</a> , on page 70        |
| Channel Detection    | <a href="#">chapter 5.1.8, "Channel Detection"</a> , on page 71                              |
| Code Domain Settings | <a href="#">chapter 6.2, "Code Domain Analysis Settings (BTS Measurements)"</a> , on page 87 |
| Evaluation Range     | <a href="#">chapter 6.1, "Evaluation Range"</a> , on page 85                                 |
| Overview             | <a href="#">chapter 5.1.1, "Configuration Overview"</a> , on page 47                         |

### A.1.2.3 Trace Menu

The "Trace" menu provides access to trace-specific functions.

See [chapter 6.4, "Traces"](#), on page 90

This menu is application-specific.

**Table 1-3: "Trace" menu items for 3GP FDD Measurements**





| Menu item  | Description   |
|--|---|
| Clear Write<br>Max Hold<br>Min Hold<br>Average<br>View | Defines the trace mode, see <a href="#">"Trace Mode"</a> on page 91                                 |
| Trace ...  | Opens the "Traces" configuration dialog box, see <a href="#">chapter 6.4, "Traces"</a> , on page 90 |

#### A.1.2.4 Marker Menu

The "Marker" menu provides access to marker-specific functions.

This menu is application-specific.

**Table 1-4: "Marker" menu items for 3GP FDD Measurements**

| Menu item         | Corresponding icon in toolbar   | Description  |
|-------------------|---|--|
| Select marker <x> |  | "  Marker 1/ Delta 1/ Delta 2/.../Delta 4" on page 92 |
| All Markers Off   |  | <a href="#">"All Markers Off"</a> on page 94   |
| CPICH             | -   | <a href="#">"Marker To CPICH"</a> on page 96   |
| PCCPCH            | -   | <a href="#">"Marker To PCCPCH"</a> on page 96  |
| Marker...         |  | <a href="#">chapter 6.5.1, "Individual Marker Settings"</a> , on page 92   |
| Search            | -   | <a href="#">chapter 6.5.3, "Marker Search Settings"</a> , on page 94   |

#### A.1.2.5 Limits Menu

The "Limits" menu does not contain any functions for 3GP FDD measurements.

## A.2 Reference of Toolbar Functions

Common functions can be performed via the icons in the toolbars.



Individual toolbars can be hidden or displayed.

### Hiding and displaying a toolbar

1. Right-click any toolbar or the menu bar.  
A context menu with a list of all available toolbars is displayed.
2. Select the toolbar you want to hide or display.  
A checkmark indicates that the toolbar is currently displayed.  
The toolbar is toggled on or off.

Note that some icons are only available for specific applications. Those functions are described in the individual application's User Manual.








### General toolbars

The following functions are generally available for all applications:

#### "Main" toolbar

For a description of these functions see the R&S VSE Base Software User Manual.




*Table 1-5: Functions in the "Main" toolbar*





| Icon  | Description  |
|---|--|
|  | Overview: Displays the configuration overview for the current measurement channel    |
|  | Save: Saves the current software configuration to a file                             |
|  | Recall: Recalls a saved software configuration from a file                           |
|  | Save I/Q recording: Stores the recorded I/Q data to a file                           |
|  | Recall I/Q recording: Loads recorded I/Q data from a file                            |
|  | Print immediately: prints the current display (screenshot) as configured             |
|  | Add Window: Inserts a new result display window for the selected measurement channel |

#### "Control" toolbar

For a description of these functions see the R&S VSE Base Software User Manual.

*Table 1-6: Functions in the "Control" toolbar*



| Icon  | Description                                      |
|---|--|
|  | Selects the currently active channel             |
|  | Capture: performs the selected measurement       |
|  | Pause: temporarily stops the current measurement |

| Icon  | Description  |
|---|--|
|  | Continuous: toggles to continuous measurement mode for next capture  |
|  | Single: toggles to single measurement mode for next capture  |
|  | Record: performs the selected measurement and records the captured data and results  |
|  | Refresh: Repeats the evaluation of the data currently in the capture buffer without capturing new data (VSA application only). |

### "Help" toolbar

For a description of these functions see the R&S VSE Base Software User Manual.

**Table 1-7: Functions in the "Help" toolbar**

| Icon  | Description   |
|---|---|
|  | Help (+ Select): allows you to select an object for which context-specific help is displayed (not available in standard Windows dialog boxes or measurement result windows) |
|  | Help: displays context-sensitive help topic for currently selected element  |





### Application-specific toolbars

The following toolbars are application-specific; not all functions shown here may be available in each application:



#### "Zoom" toolbar

For a description of these functions see the R&S VSE Base Software User Manual.

**Table 1-8: Functions in the "Zoom" toolbar**

| Icon   | Description  |
|--|--|
|         | Normal mouse mode: the cursor can be used to select (and move) markers in a zoomed display         |
|         | Zoom mode: displays a dotted rectangle in the diagram that can be expanded to define the zoom area |
|         | Multiple zoom mode: multiple zoom areas can be defined for the same diagram                        |
| <br>1:1 | Zoom off: displays the diagram in its original size  |

**Table 1-9: Functions in the "Marker" toolbar**

| Icon  | Description      |
|---|------------------|
|  | Place new marker |
|  | Select marker    |





| Icon | Description  |
|------|--|
|      | Marker type "normal"   |
|      | Marker type "delta"  |
|      | Global peak  |
|      | Absolute peak<br>(Currently only for GSM application)              |
|      | Next peak to the left  |
|      | Next peak to the right   |
|      | Next peak up (for spectrograms only: search in more recent frames) |
|      | Next peak down (for spectrograms only: search in previous frames)  |
|      | Global minimum   |
|      | Next minimum left  |
|      | Next minimum right   |
|      | Next min up (for spectrograms only: search in more recent frames)  |
|      | Next min down (for spectrograms only: search in previous frames)   |
|      | Set marker value to center frequency                               |
|      | Set reference level to marker value                                |
|      | All markers off  |
|      | Marker search configuration  |
|      | Marker configuration   |

Table 1-10: Functions in the "AutoSet" toolbar

| Icon | Description                                     |
|------|---|
|      | Auto level                                      |
|      | Auto frequency                                  |
|      | Auto trigger (R&S VSE GSM application only)     |
|      | Auto frame (R&S VSE GSM application only)       |
|      | Auto search (R&S VSE 3GPP FDD application only) |

## Reference of Toolbar Functions

| Icon  | Description   |
|---|---|
|   | Auto scale (R&S VSE 3GPP FDD + Pulse applications only)     |
|   | Auto scale all (R&S VSE 3GPP FDD + Pulse applications only) |
|  | Auto all  |
|  | Configure auto settings                                     |

## List of Remote Commands (3GPP FDD)

|  |     |
|--|-----|
| [SENSe:]ADJust:ALL.....                          | 159 |
| [SENSe:]ADJust:CONFigure:DURation.....           | 159 |
| [SENSe:]ADJust:CONFigure:DURation:MODE.....      | 160 |
| [SENSe:]ADJust:CONFigure:HYSTeresis:LOWer.....   | 160 |
| [SENSe:]ADJust:CONFigure:HYSTeresis:UPPer.....   | 160 |
| [SENSe:]ADJust:LEVel.....                        | 161 |
| [SENSe:]AVERAge<n>:COUnT.....                    | 143 |
| [SENSe:]CDPower:ANTenna.....                     | 120 |
| [SENSe:]CDPower:BASE.....                        | 142 |
| [SENSe:]CDPower:CODE.....                        | 161 |
| [SENSe:]CDPower:CPB.....                         | 163 |
| [SENSe:]CDPower:ETChips.....                     | 165 |
| [SENSe:]CDPower:FiLTer[:STATe].....              | 142 |
| [SENSe:]CDPower:FRAMe[:VALue].....               | 161 |
| [SENSe:]CDPower:HSDPamode.....                   | 120 |
| [SENSe:]CDPower:HSLot.....                       | 166 |
| [SENSe:]CDPower:ICTReshold.....                  | 149 |
| [SENSe:]CDPower:IQLength.....                    | 142 |
| [SENSe:]CDPower:LCODE:DVALue.....                | 123 |
| [SENSe:]CDPower:LCODE:SEARch:LIST?.....          | 121 |
| [SENSe:]CDPower:LCODE:SEARch[:IMMEdiate]?.....   | 121 |
| [SENSe:]CDPower:LCODE:TYPE.....                  | 124 |
| [SENSe:]CDPower:LCODE[:VALue].....               | 123 |
| [SENSe:]CDPower:LEVel:ADJust.....                | 210 |
| [SENSe:]CDPower:MAPPing.....                     | 162 |
| [SENSe:]CDPower:MIMO.....                        | 122 |
| [SENSe:]CDPower:NORMAlize.....                   | 163 |
| [SENSe:]CDPower:PCONTrol.....                    | 122 |
| [SENSe:]CDPower:PDIFf.....                       | 164 |
| [SENSe:]CDPower:PDISplay.....                    | 164 |
| [SENSe:]CDPower:PREFERENCE.....                  | 164 |
| [SENSe:]CDPower:PRESet.....                      | 211 |
| [SENSe:]CDPower:QINVert.....                     | 143 |
| [SENSe:]CDPower:QPSK.....                        | 124 |
| [SENSe:]CDPower:SBANd.....                       | 143 |
| [SENSe:]CDPower:SFACTor.....                     | 124 |
| [SENSe:]CDPower:SLOT.....                        | 162 |
| [SENSe:]CDPower:STYPe.....                       | 145 |
| [SENSe:]CDPower:UCPich:ANT<antenna>:CODE.....    | 144 |
| [SENSe:]CDPower:UCPich:ANT<antenna>:PATTern..... | 144 |
| [SENSe:]CDPower:UCPich:ANT<antenna>[:STATe]..... | 145 |
| [SENSe:]CDPower:UCPich:CODE.....                 | 211 |
| [SENSe:]CDPower:UCPich:PATTern.....              | 211 |
| [SENSe:]CDPower:UCPich[:STATe].....              | 212 |
| [SENSe:]FREQUency:CENTer.....                    | 129 |
| [SENSe:]FREQUency:CENTer:STEP.....               | 129 |
| [SENSe:]FREQUency:CENTer:STEP:AUTO.....          | 130 |

|   |     |
|---|-----|
| [SENSe:]FREQuency:OFFSet.....                               | 130 |
| [SENSe:]SWEep:COUNT.....                                    | 143 |
| CALCulate:MARKer<m>:FUNction:ZOOM.....                      | 163 |
| CALCulate<n>:CDPower:Mapping.....                           | 162 |
| CALCulate<n>:DELTamarker<m>:AOFF.....                       | 198 |
| CALCulate<n>:DELTamarker<m>:FUNction:CPICH.....             | 203 |
| CALCulate<n>:DELTamarker<m>:FUNction:PCCPch.....            | 203 |
| CALCulate<n>:DELTamarker<m>:MAXimum:LEFT.....               | 203 |
| CALCulate<n>:DELTamarker<m>:MAXimum:NEXT.....               | 203 |
| CALCulate<n>:DELTamarker<m>:MAXimum:RIGHT.....              | 203 |
| CALCulate<n>:DELTamarker<m>:MAXimum[:PEAK].....             | 203 |
| CALCulate<n>:DELTamarker<m>:MINimum:LEFT.....               | 204 |
| CALCulate<n>:DELTamarker<m>:MINimum:NEXT.....               | 204 |
| CALCulate<n>:DELTamarker<m>:MINimum:RIGHT.....              | 204 |
| CALCulate<n>:DELTamarker<m>:MINimum[:PEAK].....             | 204 |
| CALCulate<n>:DELTamarker<m>:X.....                          | 198 |
| CALCulate<n>:DELTamarker<m>:X:RELative?.....                | 199 |
| CALCulate<n>:DELTamarker<m>:Y?.....                         | 199 |
| CALCulate<n>:DELTamarker<m>[:STATe].....                    | 198 |
| CALCulate<n>:FEED.....                                      | 209 |
| CALCulate<n>:MARKer<m>:AOFF.....                            | 196 |
| CALCulate<n>:MARKer<m>:FUNction:CPICH.....                  | 200 |
| CALCulate<n>:MARKer<m>:FUNction:PCCPch.....                 | 201 |
| CALCulate<n>:MARKer<m>:FUNction:TAERror:RESult?.....        | 177 |
| CALCulate<n>:MARKer<m>:FUNction:WCDPower:MS:RESult?.....    | 179 |
| CALCulate<n>:MARKer<m>:FUNction:WCDPower[:BTS]:RESult?..... | 177 |
| CALCulate<n>:MARKer<m>:MAXimum:LEFT.....                    | 201 |
| CALCulate<n>:MARKer<m>:MAXimum:NEXT.....                    | 201 |
| CALCulate<n>:MARKer<m>:MAXimum:RIGHT.....                   | 201 |
| CALCulate<n>:MARKer<m>:MAXimum[:PEAK].....                  | 201 |
| CALCulate<n>:MARKer<m>:MINimum:LEFT.....                    | 202 |
| CALCulate<n>:MARKer<m>:MINimum:NEXT.....                    | 202 |
| CALCulate<n>:MARKer<m>:MINimum:RIGHT.....                   | 202 |
| CALCulate<n>:MARKer<m>:MINimum[:PEAK].....                  | 202 |
| CALCulate<n>:MARKer<m>:X.....                               | 197 |
| CALCulate<n>:MARKer<m>:Y?.....                              | 197 |
| CALCulate<n>:MARKer<m>[:STATe].....                         | 197 |
| CONFigure:WCDPower:MS:CTABLE:CATalog?.....                  | 152 |
| CONFigure:WCDPower:MS:CTABLE:COMMENT.....                   | 154 |
| CONFigure:WCDPower:MS:CTABLE:COPY.....                      | 152 |
| CONFigure:WCDPower:MS:CTABLE:DATA.....                      | 156 |
| CONFigure:WCDPower:MS:CTABLE:DATA:HSDPcch.....              | 157 |
| CONFigure:WCDPower:MS:CTABLE:DELeTe.....                    | 152 |
| CONFigure:WCDPower:MS:CTABLE:EDATa.....                     | 157 |
| CONFigure:WCDPower:MS:CTABLE:EDATa:EDPCc.....               | 158 |
| CONFigure:WCDPower:MS:CTABLE:NAME.....                      | 154 |
| CONFigure:WCDPower:MS:CTABLE:SELeCt.....                    | 153 |
| CONFigure:WCDPower:MS:CTABLE[:STATe].....                   | 151 |
| CONFigure:WCDPower:MS:MEASurement.....                      | 118 |
| CONFigure:WCDPower[:BTS]:ASCale[:STATe].....                | 159 |

|  |     |
|--|-----|
| CONFigure:WCDPower[:BTS]:CTABLE:CATalog?             | 149 |
| CONFigure:WCDPower[:BTS]:CTABLE:COMMeNt              | 154 |
| CONFigure:WCDPower[:BTS]:CTABLE:COMParE              | 147 |
| CONFigure:WCDPower[:BTS]:CTABLE:COpy                 | 150 |
| CONFigure:WCDPower[:BTS]:CTABLE:DATA                 | 155 |
| CONFigure:WCDPower[:BTS]:CTABLE:DELeTe               | 151 |
| CONFigure:WCDPower[:BTS]:CTABLE:NAME                 | 153 |
| CONFigure:WCDPower[:BTS]:CTABLE:SELeCt               | 151 |
| CONFigure:WCDPower[:BTS]:CTABLE:TOFFset              | 148 |
| CONFigure:WCDPower[:BTS]:CTABLE[:STATe]              | 149 |
| CONFigure:WCDPower[:BTS]:MCARrier:STATe              | 159 |
| CONFigure:WCDPower[:BTS]:MEASurement                 | 118 |
| DIAGnostic:SERVice:NSource                           | 128 |
| DISPlay:MTABLE                                       | 200 |
| DISPlay[:WINDow<n>]:SELeCt                           | 176 |
| DISPlay[:WINDow<n>]:TRACe<t>:MODE                    | 195 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:AUTO ONCE     | 131 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MAXimum       | 131 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:MINimum       | 131 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:PDIVision     | 132 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLeVeL        | 132 |
| DISPlay[:WINDow<n>]:TRACe<t>:Y[:SCALe]:RLeVeL:OFFSet | 132 |
| DISPlay[:WINDow<n>]:TRACe<t>[:STATe]                 | 196 |
| DISPlay[:WINDow<n>]:ZOOM:AREA                        | 205 |
| DISPlay[:WINDow<n>]:ZOOM:MuLTiple<zoom>:AREA         | 205 |
| DISPlay[:WINDow<n>]:ZOOM:MuLTiple<zoom>:STATe        | 206 |
| DISPlay[:WINDow<n>]:ZOOM:STATe                       | 205 |
| FORMAt[:DATA]  | 188 |
| INPut:ATTenuation                                    | 133 |
| INPut:ATTenuation:AUTO                               | 134 |
| INPut:ATTenuation:PROTection[:STATe]                 | 125 |
| INPut:COUPLing                                       | 125 |
| INPut:EATT   | 134 |
| INPut:EATT:AUTO                                      | 134 |
| INPut:EATT:STATe                                     | 135 |
| INPut:FILTer:HPASs[:STATe]                           | 126 |
| INPut:FILTer:YIG[:STATe]                             | 126 |
| INPut:GAIN:STATe                                     | 132 |
| INPut:GAIN[:VALue]                                   | 133 |
| INPut:IMPedance                                      | 126 |
| INPut:PRESelection:SET                               | 127 |
| INPut:PRESelection[:STATe]                           | 127 |
| INPut:SELeCt   | 127 |
| INPut:TYPE   | 127 |
| INSTRument:BLock:CHANnel[:SETTings]:SOURce           | 128 |
| LAYout:ADD[:WINDow]?                                 | 171 |
| LAYout:CATalog[:WINDow]?                             | 173 |
| LAYout:GLOBal:ADD[:WINDow]?                          | 166 |
| LAYout:GLOBal:CATalog[:WINDow]?                      | 168 |
| LAYout:GLOBal:IDENtify[:WINDow]?                     | 169 |

|  |     |
|--|-----|
| LAYout:GLOBal:REMOve[:WINDow].....             | 169 |
| LAYout:GLOBal:REPLace[:WINDow].....            | 170 |
| LAYout:IDENtify[:WINDow]?.....                 | 173 |
| LAYout:REMOve[:WINDow].....                    | 174 |
| LAYout:REPLace[:WINDow].....                   | 174 |
| LAYout:WINDow<n>:ADD?.....                     | 174 |
| LAYout:WINDow<n>:IDENtify?.....                | 175 |
| LAYout:WINDow<n>:REMOve.....                   | 175 |
| LAYout:WINDow<n>:REPLace.....                  | 176 |
| OUTPut:TRIGger<port>:DIRection.....            | 140 |
| OUTPut:TRIGger<port>:LEVel.....                | 140 |
| OUTPut:TRIGger<port>:OTYPe.....                | 140 |
| OUTPut:TRIGger<port>:PULSe:IMMediate.....      | 141 |
| OUTPut:TRIGger<port>:PULSe:LENGth.....         | 141 |
| STATus:QUEStionable:SYNC:CONDition?.....       | 208 |
| STATus:QUEStionable:SYNC:ENABle.....           | 208 |
| STATus:QUEStionable:SYNC:NTRansition.....      | 208 |
| STATus:QUEStionable:SYNC:PTRansition.....      | 209 |
| STATus:QUEStionable:SYNC[:EVENT]?.....         | 208 |
| SYSTem:PRESet:CHANnel[:EXECute].....           | 119 |
| TRACe<n>[:DATA]?.....                          | 188 |
| TRACe<n>[:DATA]?.....                          | 188 |
| TRACe<n>[:DATA]?.....                          | 189 |
| TRACe<n>[:DATA]?.....                          | 190 |
| TRACe<n>[:DATA]?.....                          | 191 |
| TRACe<n>[:DATA]?.....                          | 192 |
| TRACe<n>[:DATA]?.....                          | 193 |
| TRACe<n>[:DATA]?.....                          | 193 |
| TRACe<n>[:DATA]?.....                          | 194 |
| TRIGger[:SEQuence]:DTIME.....                  | 136 |
| TRIGger[:SEQuence]:HOLDoff[:TIME].....         | 136 |
| TRIGger[:SEQuence]:IFPower:HOLDoff.....        | 136 |
| TRIGger[:SEQuence]:IFPower:HYSteresis.....     | 136 |
| TRIGger[:SEQuence]:LEVel:IFPower.....          | 137 |
| TRIGger[:SEQuence]:LEVel:IQPower.....          | 137 |
| TRIGger[:SEQuence]:LEVel:RFPower.....          | 138 |
| TRIGger[:SEQuence]:LEVel[:EXTernal<port>]..... | 137 |
| TRIGger[:SEQuence]:SLOPe.....                  | 138 |
| TRIGger[:SEQuence]:SOURce.....                 | 138 |
| TRIGger[:SEQuence]:TIME:RINTerval.....         | 139 |

# Index

## Symbols

|                            |     |
|----------------------------|-----|
| 3GPP FDD                   |     |
| Basics .....               | 32  |
| Measurement examples ..... | 100 |
| Measurements .....         | 11  |
| Programming examples ..... | 212 |
| Remote control .....       | 112 |

## A

|                                      |        |
|--------------------------------------|--------|
| AC/DC coupling .....                 | 54     |
| Activating                           |        |
| 3GPP FDD measurements (remote) ..... | 118    |
| Amplitude                            |        |
| Configuration .....                  | 59     |
| Configuration (remote) .....         | 130    |
| Settings .....                       | 59     |
| Analysis                             |        |
| BTS Code Domain Settings .....       | 87, 89 |
| Mode .....                           | 69     |
| Remote control .....                 | 195    |
| Settings .....                       | 85     |
| Antenna                              |        |
| Diversity .....                      | 50     |
| Number .....                         | 50     |
| Synchronization .....                | 71     |
| Attenuation .....                    | 61     |
| Auto .....                           | 61     |
| Configuration (remote) .....         | 133    |
| Displayed .....                      | 9      |
| Electronic .....                     | 61     |
| Manual .....                         | 61     |
| Option .....                         | 61     |
| Auto all .....                       | 80     |
| Auto level                           |        |
| Hysteresis .....                     | 81, 82 |
| Reference level .....                | 61, 80 |
| Auto scaling .....                   | 63     |
| Auto scrambling code                 |        |
| Softkey .....                        | 51, 80 |
| Auto settings .....                  | 80     |
| Meastime mode .....                  | 81     |
| Remote control .....                 | 158    |
| Autosearch                           |        |
| Channel detection .....              | 35     |
| Scrambling code .....                | 51, 80 |
| Average count .....                  | 69     |
| Avg Power Inact Chan .....           | 12     |
| Avg. RCDE .....                      | 12     |

## B

|                          |        |
|--------------------------|--------|
| Base station             |        |
| see BTS .....            | 7      |
| Base transceiver station |        |
| see BTS .....            | 7      |
| Bitstream                |        |
| Evaluation .....         | 15     |
| Parameter .....          | 89     |
| Trace results .....      | 185    |
| Branch                   |        |
| Evaluation range .....   | 86, 87 |

|           |   |
|-----------|---|
| BTS ..... | 7 |
|-----------|---|

## C

|  |          |
|--|----------|
| Capture Length .....                       | 69       |
| Carrier frequency error .....              | 12       |
| Relationship to synchronization mode ..... | 13       |
| CDA .....                                  | 11       |
| Analysis settings (BTS) .....              | 87       |
| Analysis settings (UE) .....               | 89       |
| Channel results .....                      | 13       |
| Configuring .....                          | 46       |
| Configuring (remote) .....                 | 119      |
| Evaluation settings BTS (remote) .....     | 163      |
| Evaluation settings UE (remote) .....      | 165      |
| Parameters .....                           | 12       |
| Performing .....                           | 97       |
| Results .....                              | 12       |
| CDEP .....                                 | 12       |
| Evaluation .....                           | 18       |
| Trace results .....                        | 182      |
| CDP  |          |
| Channel parameter .....                    | 37       |
| Channel table .....                        | 77, 79   |
| Evaluation .....                           | 17       |
| Measurement example .....                  | 100      |
| Programming example .....                  | 213      |
| Trace results .....                        | 182      |
| Center frequency .....                     | 64       |
| Measurement example .....                  | 103      |
| Step size .....                            | 64       |
| Ch. SF .....                               | 17       |
| Channel detection                          |          |
| Autosearch .....                           | 35       |
| Configuring .....                          | 71       |
| Methods .....                              | 35       |
| Predefined tables .....                    | 35       |
| Remote control .....                       | 146, 147 |
| Search mode .....                          | 72       |
| Softkey .....                              | 71       |
| Channel number .....                       | 77, 79   |
| Channel power .....                        | 13       |
| Channel table                              |          |
| Configuration .....                        | 16       |
| Channel tables                             |          |
| Comparison .....                           | 35, 73   |
| Configuring .....                          | 98       |
| Configuring (remote) .....                 | 153      |
| Configuring channels (remote) .....        | 155, 156 |
| Copying .....                              | 74       |
| Creating .....                             | 74       |
| Creating from input .....                  | 75       |
| Deleting .....                             | 74       |
| Details (BTS) .....                        | 76       |
| Details (UE) .....                         | 78       |
| Editing .....                              | 74       |
| Evaluation .....                           | 15       |
| Managing .....                             | 73       |
| Managing (remote) .....                    | 149      |
| Predefined .....                           | 73       |
| Restoring .....                            | 74       |
| Selecting .....                            | 74       |
| Settings .....                             | 74       |

- Sorting ..... 75
- Trace results ..... 182
- Channel types ..... 37
  - BTS ..... 35
  - Compressed ..... 37
  - Configuring in table ..... 76, 79
  - Control ..... 35, 39
  - CPICH ..... 34, 36
  - CPRSD ..... 37
  - DPCCH ..... 39
  - DPCH ..... 34, 37
  - DPDCH ..... 39
  - EDPCCH ..... 39
  - EDPDCH ..... 39
  - HSDPCCH ..... 39
  - MIMO ..... 38
  - Parameter values (remote) ..... 146, 147
  - PCCPCH ..... 34, 36
  - PICH ..... 37
  - PSCH ..... 36
  - SCCPCH ..... 36
  - SCH ..... 34, 36
  - Special ..... 34
  - SSCH ..... 36
  - Synchronization ..... 35
  - UE ..... 39
- Channels ..... 32
  - Active ..... 72, 78, 79
  - Bandwidth ..... 32
  - Displayed ..... 9
  - Evaluation range ..... 85
  - Inactive, showing ..... 16
  - Mapping ..... 13
  - No of Active ..... 12
  - Number ..... 32
  - Status ..... 78, 79
- Chip rate error ..... 12
- Chips ..... 34
- Closing
  - Windows (remote) ..... 169, 174, 175
- Code class
  - Relationship to spreading factor ..... 33
  - Relationship to symbol rate ..... 33
- Code domain ..... 32
- Code Domain Analysis
  - see CDA ..... 11
- Code domain error power
  - see CDEP ..... 12
- Code Domain Power
  - see CDP ..... 17
- Code domain settings
  - Softkey ..... 87, 89
- Code number
  - see Channel number ..... 32
- Code Power Display ..... 88, 90
- Codes ..... 32
  - Number per channel ..... 33
- Composite Constellation
  - Evaluation ..... 18
  - Trace results ..... 184
- Composite EVM ..... 12
  - Evaluation ..... 19
  - Measurement example ..... 106
  - Programming example ..... 215
  - Trace results ..... 183
- Compressed Mode ..... 50
- Conflict
  - Channel table ..... 78
- Constellation
  - Parameter B ..... 89
- Constellation points
  - Mapping in MIMO channels ..... 38
- Conventions
  - SCPI commands ..... 113
- Coupling
  - Input (remote) ..... 125
- CPICH ..... 36
  - Mode ..... 71
  - Power reference ..... 88
  - Slot, displayed ..... 9
  - Softkey ..... 96
- CPRSD ..... 37
- D**
- Data acquisition
  - see Signal capturing ..... 68
- Data format
  - Remote ..... 188
- DC offset
  - see IQ offset ..... 88, 90
- Delta markers
  - Defining ..... 93
- Diagram footer information ..... 10
- Diagrams
  - Footer information ..... 10
- DPCH ..... 37
- E**
- Electronic input attenuation ..... 61
- Eliminating
  - IQ offset ..... 88, 90, 163
  - Tail chips ..... 90
- Errors
  - IF OVLD ..... 60
- Evaluation methods
  - Remote ..... 166, 171
- Evaluation range
  - Branch ..... 86, 87
  - Channel ..... 85
  - Remote control ..... 161
  - Settings ..... 85
  - Slot ..... 86
  - Softkey ..... 85
- Evaluations
  - Bitstream ..... 89
  - CDA ..... 14
  - TAE ..... 30
- EVM
  - Symbol ..... 13
- EVM vs Chip
  - Evaluation ..... 20
  - Trace results ..... 186
- Exporting
  - Scrambling codes ..... 52
- External trigger ..... 66
  - Level (remote) ..... 137



- F**
- Filters
    - High-pass (remote) ..... 126
    - High-pass (RF input) ..... 55
    - YIG (remote) ..... 126
  - Format
    - Data (remote) ..... 188
    - Scrambling codes (BTS) ..... 51
    - Scrambling codes (UE) ..... 53
  - Frames ..... 34
    - Capture mode ..... 69
    - Evaluation range ..... 69, 86
    - Number to capture ..... 69
    - Selected ..... 69, 86
  - Free Run
    - Trigger ..... 66
  - Frequency
    - Configuration ..... 63
    - Configuration (remote) ..... 129
    - Offset ..... 65
  - Frequency Error vs Slot
    - Evaluation ..... 21
    - Trace results ..... 186
  - Frontend
    - Configuration ..... 59
    - Configuration (remote) ..... 128
  - Full slot
    - Evaluation ..... 89
- H**
- Half slot
    - Evaluation ..... 89
  - Hardware settings
    - CDA, Displayed ..... 9
  - High-pass filter
    - Remote ..... 126
    - RF input ..... 55
  - HS-DPA/UPA ..... 49, 53
  - HS-PDSCH ..... 37
  - HS-SSCH ..... 37
  - Hysteresis
    - Lower (Auto level) ..... 82
    - Upper (Auto level) ..... 81
- I**
- I/Q imbalance ..... 12
  - I/Q offset ..... 12
  - I/Q Power
    - Trigger level (remote) ..... 137
  - IF Power
    - Trigger level (remote) ..... 137
  - Impedance
    - Remote ..... 126
    - Setting ..... 55
  - Inactive Channel Threshold ..... 72
  - Input ..... 56
    - Coupling ..... 54
    - Coupling (remote) ..... 125
    - Settings ..... 62
  - Input sources
    - Channels ..... 54, 57
    - Instrument ..... 54
    - Radio frequency (RF) ..... 54
- Instruments
- Input source ..... 54
- Invert Q ..... 69
- IQ offset
  - Eliminating ..... 88, 90, 163
- K**
- Keys
  - MKR -> ..... 95
- L**
- Lower Level Hysteresis ..... 82
- M**
- Mag Error vs Chip
    - Evaluation ..... 22
    - Trace results ..... 187
  - Mapping
    - Channel ..... 13
    - Channel table ..... 79
    - I/Q branches ..... 79
  - Marker table
    - Configuring ..... 94
    - Evaluation method ..... 22
  - Markers
    - Configuration (remote) ..... 196, 200
    - Configuring ..... 92
    - Configuring (softkey) ..... 91
    - Deactivating ..... 94
    - Delta markers ..... 93
    - Minimum ..... 96
    - Minimum (remote control) ..... 200
    - Next minimum ..... 96
    - Next minimum (remote control) ..... 200
    - Next peak ..... 95
    - Next peak (remote control) ..... 200
    - Peak ..... 96
    - Peak (remote control) ..... 200
    - Positioning ..... 95
    - Querying position (remote) ..... 197
    - Search settings ..... 94
    - Setting to CPICH ..... 96
    - Setting to PCCPCH ..... 96
    - Settings (remote) ..... 196
    - State ..... 93
    - Table ..... 94
    - Table (evaluation method) ..... 22
    - Type ..... 93
  - Maximum
    - Y-axis ..... 63
  - Measurement channels
    - Input source ..... 54, 57
  - Measurement examples
    - 3GPP FDD ..... 100
    - Composite EVM ..... 106
    - Incorrect center frequency ..... 103
    - Incorrect scrambling code ..... 103
    - PCDE ..... 108
    - Reference frequency ..... 102
    - Relative code domain power ..... 100
    - Triggered CDP ..... 104
  - Measurement time
    - Auto settings ..... 81

|                                       |                |  |
|---------------------------------------|----------------|--|
| Measurement types                     |                |  |
| CDA .....                             | 11             |  |
| TAE .....                             | 30             |  |
| Measurements                          |                |  |
| Interval .....                        | 89             |  |
| Selecting .....                       | 48             |  |
| Selecting (remote) .....              | 118            |  |
| MIMO                                  |                |  |
| Channel types .....                   | 38             |  |
| Mapping to constellation points ..... | 38             |  |
| Measurement mode .....                | 50             |  |
| Remote control .....                  | 122            |  |
| Minimum .....                         | 96             |  |
| Marker positioning .....              | 96             |  |
| Next .....                            | 96             |  |
| Y-axis .....                          | 63             |  |
| Minimum attenuation .....             | 56             |  |
| MKR ->                                |                |  |
| Key .....                             | 95             |  |
| Mobile station                        |                |  |
| see UE (user equipment) .....         | 7              |  |
| Modulation type .....                 | 13             |  |
| Multiple zoom .....                   | 82             |  |
| <b>N</b>                              |                |  |
| Next Minimum .....                    | 96             |  |
| Marker positioning .....              | 96             |  |
| Next Peak .....                       | 95             |  |
| Marker positioning .....              | 95             |  |
| Noise                                 |                |  |
| Source .....                          | 58             |  |
| <b>O</b>                              |                |  |
| Offset                                |                |  |
| Frequency .....                       | 65             |  |
| Reference level .....                 | 60             |  |
| Timing .....                          | 12, 13, 73, 77 |  |
| Options                               |                |  |
| Electronic attenuation .....          | 61             |  |
| High-pass filter .....                | 55, 126        |  |
| Preamplifier .....                    | 62             |  |
| Output                                |                |  |
| Configuration .....                   | 57             |  |
| Configuration (remote) .....          | 128            |  |
| Noise source .....                    | 58             |  |
| Settings .....                        | 57             |  |
| Trigger .....                         | 58, 67         |  |
| Overview                              |                |  |
| Configuration 3GPP FDD .....          | 47             |  |
| <b>P</b>                              |                |  |
| P-CPICH                               |                |  |
| Synchronization mode .....            | 71             |  |
| PCCPCH .....                          | 36             |  |
| Softkey .....                         | 96             |  |
| PCDE                                  |                |  |
| Evaluation .....                      | 23             |  |
| Measurement example .....             | 108            |  |
| Programming example .....             | 216            |  |
| Trace results .....                   | 184            |  |
| Peak Code Domain Error                |                |  |
| see PCDE .....                        | 23             |  |
| Peak search                           |                |  |
| Mode .....                            | 95             |  |
| Peaks                                 |                |  |
| Marker positioning .....              | 96             |  |
| Next .....                            | 95             |  |
| Performing                            |                |  |
| 3G FDD measurement .....              | 97             |  |
| Phase Discontinuity vs Slot           |                |  |
| Evaluation .....                      | 24             |  |
| Trace results .....                   | 186            |  |
| Phase Error vs Chip                   |                |  |
| Evaluation .....                      | 24             |  |
| Trace results .....                   | 187            |  |
| PICH .....                            | 37             |  |
| Pilot bits .....                      | 34, 35         |  |
| Channel table .....                   | 77, 79         |  |
| Number of .....                       | 13             |  |
| PilotL .....                          | 17             |  |
| PK CDE .....                          | 12             |  |
| Power                                 |                |  |
| Channels .....                        | 13             |  |
| Control .....                         | 35             |  |
| Difference to previous slot .....     | 88             |  |
| Displayed .....                       | 9              |  |
| Inactive channels .....               | 12             |  |
| Reference .....                       | 88, 90         |  |
| Power vs Slot                         |                |  |
| Evaluation .....                      | 26             |  |
| Trace results .....                   | 183            |  |
| Power vs Symbol                       |                |  |
| Evaluation .....                      | 26             |  |
| Trace results .....                   | 184            |  |
| Preamplifier                          |                |  |
| Setting .....                         | 62             |  |
| Predefined tables                     |                |  |
| Channel detection .....               | 35             |  |
| Preselector .....                     | 55             |  |
| Presetting                            |                |  |
| Channels .....                        | 48, 211        |  |
| Pretrigger .....                      | 67             |  |
| Programming examples                  |                |  |
| 3GPP FDD .....                        | 212            |  |
| Composite EVM .....                   | 215            |  |
| Incorrect scrambling code .....       | 213            |  |
| PCDE .....                            | 216            |  |
| Reference Frequency .....             | 213            |  |
| Relative code domain power .....      | 213            |  |
| Triggered CDP .....                   | 215            |  |
| PSCH .....                            | 36             |  |
| Pwr Abs/Pwr Rel .....                 | 17             |  |
| <b>R</b>                              |                |  |
| Range                                 |                |  |
| Scaling .....                         | 63             |  |
| RCDE .....                            | 13             |  |
| Average .....                         | 12             |  |
| Reference frequency                   |                |  |
| Measurement example .....             | 102            |  |
| Reference Frequency                   |                |  |
| Programming example .....             | 213            |  |
| Reference level .....                 | 60             |  |
| Auto level .....                      | 61, 80         |  |
| Displayed .....                       | 9              |  |
| Offset .....                          | 60             |  |
| Unit .....                            | 60             |  |
| Value .....                           | 60             |  |
| Reference power .....                 | 88             |  |

- Remote commands
  - Basics on syntax ..... 112
  - Boolean values ..... 116
  - Capitalization ..... 114
  - Character data ..... 117
  - Data blocks ..... 117
  - Numeric values ..... 115
  - Obsolete ..... 209
  - Optional keywords ..... 114
  - Parameters ..... 115
  - Strings ..... 117
  - Suffixes ..... 114
- Restoring
  - Channel settings ..... 48, 211
- Result Display ..... 8
- Result displays
  - Marker table ..... 22
- Result list
  - Evaluation ..... 30
- Result summary
  - Channel results ..... 13
  - Evaluation ..... 27
  - General results ..... 12
  - Trace results ..... 183
- Results ..... 11
  - Calculated (remote) ..... 177
  - Data format (remote) ..... 188
  - Evaluating ..... 85
  - Retrieving (remote) ..... 177
  - Trace (remote) ..... 187
  - Trace data query (remote) ..... 181
- Retrieving
  - Calculated results (remote) ..... 177
  - Results (remote) ..... 177
  - Trace results (remote) ..... 187
- RF attenuation
  - Auto ..... 61
  - Manual ..... 61
- RF input ..... 54, 56
  - Remote ..... 125, 127
- RF Power
  - Trigger level (remote) ..... 138
- RHO ..... 12
- RRC Filter ..... 69, 142
- S**
- S-CPICH
  - Antenna pattern ..... 71
  - Code number ..... 71
  - Synchronization mode ..... 71
- Sample rate ..... 69
  - Configuring in channel table ..... 77, 79
- Scaling
  - Amplitude range, automatically ..... 63
  - Configuration, softkey ..... 62
  - Y-axis ..... 63
- SCCPCH ..... 36
- Scrambling code ..... 32
  - Autosearch ..... 51, 80
  - BTS ..... 50, 51
  - BTS (remote) ..... 123
  - Measurement example ..... 103
  - Programming example ..... 213
  - Softkey ..... 50
  - UE ..... 52
- Screen layout ..... 8
- Select meas
  - Softkey ..... 46
- Settings
  - Overview ..... 47
- Show inactive channels ..... 16
- Signal capturing
  - Remote control ..... 141
  - Softkey ..... 68
- Signal description
  - BTS (remote) ..... 120
  - BTS Configuration ..... 49
  - Configuration ..... 48
  - Remote control ..... 119
  - Softkey ..... 48
  - UE (remote) ..... 124
  - UE Configuration ..... 52
- Signal source
  - Remote ..... 127
- Single zoom ..... 82
- Slope
  - Trigger ..... 67, 138
- Slots ..... 34
  - Capture mode ..... 69
  - Channel ..... 34
  - CPICH ..... 34
  - Evaluation ..... 89
  - Evaluation range ..... 86
  - Number ..... 13
  - Power difference ..... 88
- Softkeys
  - Auto Scrambling Code ..... 51, 80
  - Channel Detection ..... 71
  - Code Domain Settings ..... 87, 89
  - CPICH ..... 96
  - Evaluation Range ..... 85
  - Marker Config ..... 91
  - PCCPCH ..... 96
  - Scale Config ..... 62
  - Scrambling Code ..... 50
  - Select Meas ..... 46
  - Signal Capture ..... 68
  - Signal Description ..... 48
  - Sweep count ..... 69
  - Synchronization ..... 70
  - Trace Config ..... 90
  - Trigger/Gate Config ..... 65
- Specifics for
  - Configuration ..... 48
- Spreading factor ..... 32
  - Relationship to code class ..... 33
  - Relationship to symbol rate ..... 33
- SSCH ..... 36
- Status
  - Channels ..... 78, 79
  - Display ..... 17
- Status registers
  - 3GPP FDD ..... 206
  - Contents ..... 206
  - Querying ..... 206
- Suffixes
  - Common ..... 117
  - Remote commands ..... 114
- Sweep
  - Count ..... 69
- Symbol Constellation
  - Evaluation ..... 27
  - Trace results ..... 184

- Symbol EVM ..... 13
  - Evaluation ..... 28
  - Trace results ..... 185
- Symbol Magnitude Error
  - Evaluation ..... 29
  - Trace results ..... 187
- Symbol Phase Error
  - Evaluation ..... 29
  - Trace results ..... 187
- Symbol rate ..... 17, 32
  - Displayed ..... 9
  - Relationship to code class ..... 33
  - Relationship to spreading factor ..... 33
- Synchronization
  - Check (TAE) ..... 45
  - Configuring ..... 70
  - Remote control ..... 144
  - Softkey ..... 70
  - Type ..... 70
- T**
- T Offs ..... 17
- TAE
  - Configuration (remote) ..... 119
  - Configuring ..... 83
  - Determining ..... 98
  - Measurement ..... 30
  - Results (remote control) ..... 177
- Tail chips
  - Eliminating ..... 90
- Test models
  - BTS ..... 40
  - UE ..... 42
- Test setup
  - BTS ..... 41
  - UE ..... 43
- TFCI ..... 17
  - Channel detection ..... 77
- Time Alignment Error
  - see TAE ..... 30
- Timing offset ..... 12, 13
  - Configuring ..... 77
  - Reference ..... 73
- Toolbars
  - AutoSet ..... 225
  - Control ..... 223
  - Functions ..... 222
  - Help ..... 224
  - Main ..... 223
  - Marker ..... 224
  - Overview ..... 222
  - Zoom ..... 224
- Traces
  - Configuration (remote) ..... 195
  - Configuration (softkey) ..... 90
  - Mode ..... 91
  - Mode (remote) ..... 195
  - Results (remote) ..... 187
- Trigger
  - Configuration (remote) ..... 135
  - External (remote) ..... 138
  - Measurement example ..... 104
  - Offset ..... 66
  - Output ..... 58, 67
  - Programming example ..... 215
  - Slope ..... 67, 138
    - to frame ..... 12
  - Trigger level ..... 66
    - External trigger (remote) ..... 137
    - I/Q Power (remote) ..... 137
    - IF Power (remote) ..... 137
    - RF Power (remote) ..... 138
  - Trigger source ..... 66
    - External ..... 66
    - Free Run ..... 66
  - Trigger/Gate
    - Configuration (Softkey) ..... 65
  - Type
    - Scrambling codes (UE) ..... 53
- U**
- UE (User equipment) ..... 7
- Units
  - Reference level ..... 60
- Upper Level Hysteresis ..... 81
- Use TFCI
  - Channel table ..... 77
- W**
- W-CDMA ..... 7
- Window title bar information ..... 10
- Windows
  - Adding (remote) ..... 166, 171
  - Closing (remote) ..... 169, 174, 175
  - Configuring ..... 48
  - Querying (remote) ..... 168, 169, 173
  - Replacing (remote) ..... 170, 174
  - Types (remote) ..... 166, 171
- X**
- X-value
  - Marker ..... 93
- Y**
- Y-maximum, Y-minimum
  - Scaling ..... 63
- YIG-preselector
  - Activating/Deactivating ..... 55
  - Activating/Deactivating (remote) ..... 126
- Z**
- Zooming
  - Activating (remote) ..... 205
  - Area (Multiple mode, remote) ..... 205
  - Area (remote) ..... 205
  - Deactivating ..... 83
  - Multiple mode ..... 82
  - Multiple mode (remote) ..... 205, 206
  - Remote ..... 204
  - Restoring original display ..... 82
  - Single mode ..... 82
  - Single mode (remote) ..... 204