



DVMD & Stream Explorer™ DVMD-B1

## Remote Usage of STREAM EXPLORER™ via Ethernet Network

In frequent cases, it appears that the MPEG2 decoder is not located in the control/monitoring room. The present application note describes how to operate a remote control of up to four DVMDs over an ethernet link.



## Contents

1	Overview .....	2
2	Principle of Operation.....	2
3	Hardware and Software Requirements.....	2
4	Connections.....	3
5	Installing the Driver / Setting the Parameter .....	4
6	Starting the Software.....	5
7	Trouble-shooting.....	5
8	Ordering information .....	6

## 1 Overview

This application note aims at providing the necessary understanding to configure and to control remotely the DVMD over an Ethernet link. The system includes a special device (COM-Server) to interface the network world upon which is connected a PC and the serial communication ports of the DVMD(s).

## 2 Principle of Operation

This all turns around the configuration of communication ports. After having configured the COM-Server driver (see below) and entered the corresponding serial port in the Stream Explorer, just use the duo DVMD-Stream Explorer as usual. The COM-Server makes it all transparent.

## 3 Hardware and Software Requirements

### Hardware Requirements

This application involves the following devices and cables



- PC + Ethernet card  
with Stream Explorer™ software already installed

- COM-Server Display-Version 1/4 ports #58004

or

- COM-Server Kompakt 1 ports #58201 :



(1 Port)



(4 Ports)

## Remote usage of Stream Explorer<sup>®</sup>

---

- **Driver for COM-Server** to be downloaded from Internet (see below)

- **2 Ethernet cables** for  
PC to Network  
Network to COM-Server : twisted pair or coaxial both possible on COM-Server

- **RS232 Cable** for  
COM-Server to DVMD


### Software Requirements


- Stream Explorer<sup>™</sup> DVMD-B1  
- Driver for COM-Server

## 4 Connections

PC to network: twisted pair  
COM-Server to network: coax or twisted pair  
DVMD to COM-Server: serial

Case of COM server with 4 ports shown:





## 5 Installing the Driver / Setting the Parameter

Now, the COM-Server must be informed about communication protocols of its both sides, i.e. serial protocols and Ethernet parameters.

*Installation of the COM-Server driver (RS232/Ethernet converter):*

The following procedures and parameters suit well to the application :

Download the driver from the WuT internet site, corresponding to the OS of the computer Windows 3.11, Windows 95 or Windows NT.

Download sites from W&T homepage: [www.wut.de](http://www.wut.de)

**Dienste** → **Download Service** for Win95 or Win98 driver

**Neuigkeiten** → **Umlenkung lokaler COMs ins Netzwerk...** for Windows NT driver

De-compact the received .EXE file in the directory of your choice.

Launch then the SETUP.EXE program.

Configure the COM-Server driver.

The settings of the converter must be fixed in the *System* window (icon *COM-Umlenkung*). Specify the IP address (refer to your network administrator) of the converter as well as the correspondence between the port number of the converter (A to D) and the communication port seen by the DVMD (COM1 to COM9).

When launching the Stream Explorer, the available serial ports are recognised and the communication can take place automatically if the parameters match :

*Parameters settings*

**COM-Server: menus**  
SET TCP/IP

## Remote usage of Stream Explorer<sup>®</sup>

---

Box IP Number : 89.10.24.86 (factory default setting)

### COM

Port A: 115,2 kBaud, 8 bits data, 1 bit stop, parity none, handshake hardware. (to match with the DVMD side)

### DVMD

These are the settings appearing on the monitor screen. Menu MAIN-SETUP-RS232

BAUD	115200
PARITY	NONE
PACE	RTS/CTS

## 6 Starting the Software

The system, after the installation of the COM-Server driver, is seen as a direct serial link between the PC and the DVMD. That is to say that the driver provided along with the COM-Server makes the Ethernet link (and its protocol) totally transparent to the PC.



## 7 Troubleshooting

### Problems that might occur and solutions

First of all check all settings correspondences (IP address, Port numbers, Cables, Parameters)

DIAGNOSIS	SOLUTION
Error on COM-Server at beginning (red LED)	Press OK button on front to cancel
Stream Explorer does not communicate with the DVMD straight away at the beginning	Press <i>Retry</i> in Stream Explorer
DVMD Status displays <i>No Decoder</i>	De-connect and reconnect (use of "offline" icon (mains plug) within the toolbar of Stream Explorer)

## 8 Ordering information

<b>MPEG2 MEASUREMENT DECODER</b>		
DVMD	Rohde & Schwarz	2068.8597.02
<b>STREAM EXPLORER™</b>		
DVMD-B1	Rohde & Schwarz	2068.9406.02
<b>COM-SERVER DISPLAY VERSION</b>		
COM-server 4 ports	Wiesemann & Theis GmbH	58004
<b>COM-SERVER KOMPAKT</b>		
COM-Server 1 port	Wiesemann & Theis GmbH	58201

Technical details on :

<http://www.wiesemann.de/58001.html>

Ordering :

Telephone: +49 202/2680-110

Fax: +49 202/2680-265

Wiesemann & Theis GmbH, Wittener Straße 312, D-42279 Wuppertal, Germany



**ROHDE & SCHWARZ**

ROHDE & SCHWARZ GmbH & Co. KG · Mühl Dorfstraße 15 · D-81671 München  
P.O.B 80 14 69 · D-81614 München · Telephone +49 89 4129 -0 · Fax +49 89 4129 - 3777 · Internet: <http://www.rsd.de>