

Operating Manual



Signal Source Analyzer

R&S® FSUP8
1166.3505.08

R&S® FSUP26
1166.3505.26

R&S® FSUP50
1166.3505.50

Printed in Germany



Dear Customer,

throughout this manual, the Signal Source Analyzer R&S®FSUP is abbreviated as R&S FSUP.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG

Trade names are trademarks of the owners.

Tabbed Divider Overview

Safety Instructions are provided on the CD-ROM

Tabbed Divider

Documentation Overview

Chapter 1: [Putting into Operation](#)

Chapter 2: [Getting Started](#)

Chapter 3: [Manual Operation](#)

Chapter 4: [Instrument Functions](#)

Chapter 5: [Remote Control – Basics](#)

Chapter 6: [Remote Control – Description of Commands](#)

Chapter 7: [Remote Control – Programming Examples](#)

Chapter 8: [Maintenance and Instrument Interfaces](#)

Chapter 9: [Error Messages](#)

Index

Documentation Overview

The documentation of the R&S FSUP consists of base unit manuals and option manuals. All manuals are provided in PDF format on the CD-ROM delivered with the instrument. Each software option available for the instrument is described in a separate software manual.

The base unit documentation comprises the following manuals:

- [R&S FSUP Quick Start Guide](#)
- [R&S FSUP Operating Manual](#)
- [R&S FSUP Service Manual](#)

Apart from the base unit, these manuals describe the following models and options of the R&S FSUP Signal Source Analyzer. Options that are not listed are described in separate manuals. These manuals are provided on an extra CD-ROM. For an overview of all options available for the R&S FSUP visit the R&S FSUP Signal Source Analyzer Internet site.

Base unit models:

- R&S FSUP8 (20 Hz to 8 GHz)
- R&S FSUP26 (20 Hz to 26.5 GHz)
- R&S FSUP50 (20 Hz to 50 GHz)

Options described in the base unit manuals:

- R&S FSU-B4 (OCXO - reference oscillator)
- R&S FSP-B10 (external generator control)
- R&S FSU-B21 (external mixer)
- R&S FSU-B23 (RF preamplifier)
- R&S FSU-B25 (electronic attenuator)
- R&S FSP-B28 (trigger port)
- R&S FSUP-B60 (low phase noise board - 10 MHz to 8 GHz, for Cross Correlation measurements)

R&S FSUP Quick Start Guide

This manual is delivered with the instrument in printed form and in PDF format on the CD-ROM. It provides the information needed to set up and start working with the instrument. Basic operations and basic measurements are described. Also a brief introduction to remote control is given. More detailed descriptions are provided in the Operating Manual. The Quick Start Guide includes general information (e.g. Safety Instructions) and the following chapters:

Chapter 1	Front and Rear Panel
Chapter 2	Preparing for Use
Chapter 3	Firmware-Update and Installation of Firmware Options
Chapter 4	Basic Operation
Chapter 5	Basic Measurement Examples
Chapter 6	LAN Interface
Chapter 7	Brief Introduction to Remote Control
Appendix A	Printer Interface
Appendix B	External Generator Control

R&S FSUP Operating Manual

This manual is a supplement to the Quick Start Guide and is available in PDF format on the CD-ROM delivered with the instrument. To retain the familiar structure that applies to all operating manuals of Rohde&Schwarz Test & Measurement instruments, the chapters 1 and 3 exist, but only in form of references to the corresponding Quick Start Guide chapters.

The operating manual is subdivided into the following chapters:

Chapter 1	Putting into Operation see Quick Start Guide chapters 1 and 2
Chapter 2	Getting Started gives an introduction to advanced measurement tasks of the R&S FSUP which are explained step by step.
Chapter 3	Manual Operation see Quick Start Guide chapter 4
Chapter 4	Instrument Functions forms a reference for manual operation of the R&S FSUP and contains a detailed description of all instrument functions and their application.
Chapter 5	Remote Control - Basics describes the basics for programming the R&S FSUP, command processing and the status reporting system.
Chapter 6	Remote Control - Description of Commands lists all the remote-control commands defined for the instrument.
Chapter 7	Remote Control - Programming Examples contains program examples for a number of typical applications of the R&S FSUP.
Chapter 8	Maintenance and Instrument Interfaces describes preventive maintenance and the characteristics of the instrument's interfaces.
Chapter 9	Error Messages gives a list of error messages that the R&S FSUP may generate.
Index	contains an index for the chapters 1 to 9 of the operating manual.

R&S FSUP Service Manual

This manual is available in PDF format on the CD-ROM delivered with the instrument. It informs on how to check compliance with rated specifications, on instrument function, repair, troubleshooting and fault elimination. It contains all information required for repairing the R&S FSUP by the replacement of modules. The manual includes the following chapters:

Chapter 1	Performance Test
Chapter 2	Adjustment
Chapter 3	Repair
Chapter 4	Software Update / Installing Options
Chapter 5	Documents



Before putting the product into operation for the first time, make sure to read the following



Safety Instructions

All plants and locations of the Rohde & Schwarz group of companies make every effort to keep the safety standard of our products up to date and to offer our customers the highest possible degree of safety. Our products and the auxiliary equipment required for them are designed and tested in accordance with the relevant safety standards. Compliance with these standards is continuously monitored by our quality assurance system. The product described here has been designed and tested in accordance with the EC Certificate of Conformity and has left the manufacturer's plant in a condition fully complying with safety standards. To maintain this condition and to ensure safe operation, observe all instructions and warnings provided in this manual. If you have any questions regarding these safety instructions, the Rohde & Schwarz group of companies will be happy to answer them.

Furthermore, it is your responsibility to use the product in an appropriate manner. This product is designed for use solely in industrial and laboratory environments or in the field and must not be used in any way that may cause personal injury or property damage. You are responsible if the product is used for an intention other than its designated purpose or in disregard of the manufacturer's instructions. The manufacturer shall assume no responsibility for such use of the product.

The product is used for its designated purpose if it is used in accordance with its product documentation and within its performance limits (see data sheet, documentation, the following safety instructions). Using the product requires technical skills and a basic knowledge of English. It is therefore essential that the product be used exclusively by skilled and specialized staff or thoroughly trained personnel with the required skills. If personal safety gear is required for using Rohde & Schwarz products, this will be indicated at the appropriate place in the product documentation.

Symbols and safety labels

Observe product documentation	Weight indication for units >18 kg	Danger of electric shock	Warning! Hot surface	PE terminal	Ground	Ground terminal	Attention! Electrostatic sensitive devices

Supply voltage ON/OFF	Standby indication	Direct current (DC)	Alternating current (AC)	Direct/alternating current (DC/AC)	Device fully protected by double/reinforced insulation

Safety Instructions

Observing the safety instructions will help prevent personal injury or damage of any kind caused by dangerous situations. Therefore, carefully read through and adhere to the following safety instructions before putting the product into operation. It is also absolutely essential to observe the additional safety instructions on personal safety that appear in relevant parts of the product documentation. In these safety instructions, the word "product" refers to all merchandise sold and distributed by the Rohde & Schwarz group of companies, including instruments, systems and all accessories.

Tags and their meaning

DANGER	This tag indicates a definite hazard carrying a high risk of death or serious injury if not avoided.
WARNING	This tag indicates a possible hazard carrying a medium risk of death or (serious) injury if not avoided.
CAUTION	This tag indicates a hazard carrying a low risk of minor or moderate injury if not avoided.
ATTENTION	This tag indicates the possibility of incorrect use that can cause damage to the product.
NOTE	This tag indicates a situation where the user should pay special attention to operating the product but which does not lead to damage.

These tags are in accordance with the standard definition for civil applications in the European Economic Area. Definitions that deviate from the standard definition may also exist in other economic areas or military applications. It is therefore essential to make sure that the tags described here are always used only in connection with the related product documentation and the related product. The use of tags in connection with unrelated products or documentation can result in misinterpretation and thus contribute to personal injury or material damage.

Basic safety instructions

1. The product may be operated only under the operating conditions and in the positions specified by the manufacturer. Its ventilation must not be obstructed during operation. Unless otherwise specified, the following requirements apply to Rohde & Schwarz products:
prescribed operating position is always with the housing floor facing down, IP protection 2X, pollution severity 2, overvoltage category 2, use only in enclosed spaces, max. operation altitude 2000 m above sea level, max. transport altitude 4500 m above sea level.
Unless specified otherwise in the data sheet, a tolerance of $\pm 10\%$ shall apply to the nominal voltage and of $\pm 5\%$ to the nominal frequency.
2. Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed. The product may be opened only by authorized, specially trained personnel. Prior to performing any work on the product or opening the product, the product must be disconnected from the supply network. Any adjustments, replacements of parts, maintenance or repair must be carried out only by technical personnel authorized by Rohde & Schwarz. Only original parts may be used for replacing parts relevant to safety (e.g. power switches, power transformers, fuses). A safety test must always be performed after parts relevant to safety have been replaced (visual inspection, PE conductor test, insulation resistance measurement, leakage current measurement, functional test).
3. As with all industrially manufactured goods, the use of substances that induce an allergic reaction (allergens, e.g. nickel) such as aluminum cannot be generally excluded. If you develop an allergic reaction (such as a skin rash, frequent sneezing, red eyes or respiratory difficulties), consult a physician immediately to determine the cause.

Safety Instructions

4. If products/components are mechanically and/or thermally processed in a manner that goes beyond their intended use, hazardous substances (heavy-metal dust such as lead, beryllium, nickel) may be released. For this reason, the product may only be disassembled, e.g. for disposal purposes, by specially trained personnel. Improper disassembly may be hazardous to your health. National waste disposal regulations must be observed.
5. If handling the product yields hazardous substances or fuels that must be disposed of in a special way, e.g. coolants or engine oils that must be replenished regularly, the safety instructions of the manufacturer of the hazardous substances or fuels and the applicable regional waste disposal regulations must be observed. Also observe the relevant safety instructions in the product documentation.
6. Depending on the function, certain products such as RF radio equipment can produce an elevated level of electromagnetic radiation. Considering that unborn life requires increased protection, pregnant women should be protected by appropriate measures. Persons with pacemakers may also be endangered by electromagnetic radiation. The employer/operator is required to assess workplaces where there is a special risk of exposure to radiation and, if necessary, take measures to avert the danger.
7. Operating the products requires special training and intense concentration. Make certain that persons who use the products are physically, mentally and emotionally fit enough to handle operating the products; otherwise injuries or material damage may occur. It is the responsibility of the employer to select suitable personnel for operating the products.
8. Prior to switching on the product, it must be ensured that the nominal voltage setting on the product matches the nominal voltage of the AC supply network. If a different voltage is to be set, the power fuse of the product may have to be changed accordingly.
9. In the case of products of safety class I with movable power cord and connector, operation is permitted only on sockets with earthing contact and protective earth connection.
10. Intentionally breaking the protective earth connection either in the feed line or in the product itself is not permitted. Doing so can result in the danger of an electric shock from the product. If extension cords or connector strips are implemented, they must be checked on a regular basis to ensure that they are safe to use.
11. If the product has no power switch for disconnection from the AC supply, the plug of the connecting cable is regarded as the disconnecting device. In such cases, it must be ensured that the power plug is easily reachable and accessible at all times (corresponding to the length of connecting cable, approx. 2 m). Functional or electronic switches are not suitable for providing disconnection from the AC supply. If products without power switches are integrated in racks or systems, a disconnecting device must be provided at the system level.
12. Never use the product if the power cable is damaged. Check the power cable on a regular basis to ensure that it is in proper operating condition. By taking appropriate safety measures and carefully laying the power cable, ensure that the cable cannot be damaged and that no one can be hurt by e.g. tripping over the cable or suffering an electric shock.
13. The product may be operated only from TN/TT supply networks fused with max. 16 A (higher fuse only after consulting with the Rohde & Schwarz group of companies).
14. Do not insert the plug into sockets that are dusty or dirty. Insert the plug firmly and all the way into the socket. Otherwise, this can result in sparks, fire and/or injuries.
15. Do not overload any sockets, extension cords or connector strips; doing so can cause fire or electric shocks.
16. For measurements in circuits with voltages $V_{\text{rms}} > 30 \text{ V}$, suitable measures (e.g. appropriate measuring equipment, fusing, current limiting, electrical separation, insulation) should be taken to avoid any hazards.
17. Ensure that the connections with information technology equipment comply with IEC 950/EN 60950.
18. Unless expressly permitted, never remove the cover or any part of the housing while the product is in operation. Doing so will expose circuits and components and can lead to injuries, fire or damage to the product.

Safety Instructions

19. If a product is to be permanently installed, the connection between the PE terminal on site and the product's PE conductor must be made first before any other connection is made. The product may be installed and connected only by a license electrician.
20. For permanently installed equipment without built-in fuses, circuit breakers or similar protective devices, the supply circuit must be fused in such a way that suitable protection is provided for users and products.
21. Do not insert any objects into the openings in the housing that are not designed for this purpose. Never pour any liquids onto or into the housing. This can cause short circuits inside the product and/or electric shocks, fire or injuries.
22. Use suitable overvoltage protection to ensure that no overvoltage (such as that caused by a thunderstorm) can reach the product. Otherwise the operating personnel will be endangered by electric shocks.
23. Rohde & Schwarz products are not protected against penetration of water, unless otherwise specified (see also safety instruction 1.). If this is not taken into account, there exists the danger of electric shock for the user or damage to the product, which can also lead to personal injury.
24. Never use the product under conditions in which condensation has formed or can form in or on the product, e.g. if the product was moved from a cold to a warm environment.
25. Do not close any slots or openings on the product, since they are necessary for ventilation and prevent the product from overheating. Do not place the product on soft surfaces such as sofas or rugs or inside a closed housing, unless this is well ventilated.
26. Do not place the product on heat-generating devices such as radiators or fan heaters. The temperature of the environment must not exceed the maximum temperature specified in the data sheet.
27. Batteries and storage batteries must not be exposed to high temperatures or fire. Keep batteries and storage batteries away from children. Do not short-circuit batteries and storage batteries.
If batteries or storage batteries are improperly replaced, this can cause an explosion (warning: lithium cells). Replace the battery or storage battery only with the matching Rohde & Schwarz type (see spare parts list). Batteries and storage batteries must be recycled and kept separate from residual waste. Batteries and storage batteries that contain lead, mercury or cadmium are hazardous waste. Observe the national regulations regarding waste disposal and recycling.
28. Please be aware that in the event of a fire, toxic substances (gases, liquids etc.) that may be hazardous to your health may escape from the product.
29. The product can be very heavy. Be careful when moving it to avoid back or other physical injuries.
30. Do not place the product on surfaces, vehicles, cabinets or tables that for reasons of weight or stability are unsuitable for this purpose. Always follow the manufacturer's installation instructions when installing the product and fastening it to objects or structures (e.g. walls and shelves).
31. Handles on the products are designed exclusively for personnel to hold or carry the product. It is therefore not permissible to use handles for fastening the product to or on means of transport such as cranes, fork lifts, wagons, etc. The user is responsible for securely fastening the products to or on the means of transport and for observing the safety regulations of the manufacturer of the means of transport. Noncompliance can result in personal injury or material damage.
32. If you use the product in a vehicle, it is the sole responsibility of the driver to drive the vehicle safely. Adequately secure the product in the vehicle to prevent injuries or other damage in the event of an accident. Never use the product in a moving vehicle if doing so could distract the driver of the vehicle. The driver is always responsible for the safety of the vehicle. The manufacturer assumes no responsibility for accidents or collisions.
33. If a laser product (e.g. a CD/DVD drive) is integrated in a Rohde & Schwarz product, do not use any other settings or functions than those described in the product documentation. Otherwise this may be hazardous to your health, since the laser beam can cause irreversible damage to your eyes. Never try to take such products apart, and never look into the laser beam.



Por favor lea imprescindiblemente antes de la primera puesta en funcionamiento las siguientes



Informaciones de seguridad

El principio del grupo de empresas Rohde & Schwarz consiste en tener nuestros productos siempre al día con los standards de seguridad y de ofrecer a nuestros clientes el máximo grado de seguridad. Nuestros productos y todos los equipos adicionales son siempre fabricados y examinados según las normas de seguridad vigentes. Nuestra sección de gestión de la seguridad de calidad controla constantemente que sean cumplidas estas normas. El presente producto ha sido fabricado y examinado según el comprobante de conformidad adjunto según las normas de la CE y ha salido de nuestra planta en estado impecable según los standards técnicos de seguridad. Para poder preservar este estado y garantizar un funcionamiento libre de peligros, el usuario deberá atenerse a todas las informaciones, informaciones de seguridad y notas de alerta. El grupo de empresas Rohde & Schwarz está siempre a su disposición en caso de que tengan preguntas referentes a estas informaciones de seguridad.

Además queda en la responsabilidad del usuario utilizar el producto en la forma debida. Este producto solamente fue elaborado para ser utilizado en la industria y el laboratorio o para fines de campo y de ninguna manera deberá ser utilizado de modo que alguna persona/cosa pueda ser dañada. El uso del producto fuera de sus fines definidos o despreciando las informaciones de seguridad del fabricante queda en la responsabilidad del usuario. El fabricante no se hace en ninguna forma responsable de consecuencias a causa del mal uso del producto.

Se parte del uso correcto del producto para los fines definidos si el producto es utilizado dentro de las instrucciones de la correspondiente documentación de producto y dentro del margen de rendimiento definido (ver hoja de datos, documentación, informaciones de seguridad que siguen). El uso del producto hace necesarios conocimientos profundos y conocimientos parciales del idioma inglés. Por eso se deberá tener en cuenta de exclusivamente autorizar para el uso del producto a personas peritas o debidamente minuciosamente instruidas con los conocimientos citados. Si fuera necesaria indumentaria de seguridad para el uso de productos de R&S, encontrará la información debida en la documentación del producto en el capítulo correspondiente.

Símbolos y definiciones de seguridad

Ver documentación de producto	Informaciones para maquinaria con un peso de > 18kg	Peligro de golpe de corriente	¡Advertencia! Superficie caliente	Conexión a conductor protector	Conexión a tierra	Conexión a masa conductora	¡Cuidado! Elementos de construcción con peligro de carga electrostática

potencia EN MARCHA/PARADA	Indicación Stand-by	Corriente continua DC	Corriente alterna AC	Corriente continua/alterna DC/AC	El aparato está protegido en su totalidad por un aislamiento de doble refuerzo

Informaciones de seguridad

Tener en cuenta las informaciones de seguridad sirve para tratar de evitar daños y peligros de toda clase. Es necesario de que se lean las siguientes informaciones de seguridad concienzudamente y se tengan en cuenta debidamente antes de la puesta en funcionamiento del producto. También deberán ser tenidas en cuenta las informaciones para la protección de personas que encontrarán en el capítulo correspondiente de la documentación de producto y que también son obligatorias de seguir. En las informaciones de seguridad actuales hemos juntado todos los objetos vendidos por el grupo de empresas Rohde & Schwarz bajo la denominación de „producto“, entre ellos también aparatos, instalaciones así como toda clase de accesorios.

Palabras de señal y su significado

PELIGRO	Identifica un peligro directo con riesgo elevado de provocar muerte o lesiones de gravedad si no se toman las medidas oportunas.
ADVERTENCIA	Identifica un posible peligro con riesgo medio de provocar muerte o lesiones (de gravedad) si no se toman las medidas oportunas.
ATENCIÓN	Identifica un peligro con riesgo reducido de provocar lesiones de gravedad media o leve si no se toman las medidas oportunas.
CUIDADO	Indica la posibilidad de utilizar mal el producto y a consecuencia dañarlo.
INFORMACIÓN	Indica una situación en la que deberían seguirse las instrucciones en el uso del producto, pero que no consecuentemente deben de llevar a un daño del mismo.

Las palabras de señal corresponden a la definición habitual para aplicaciones civiles en el área económica europea. Pueden existir definiciones diferentes a esta definición en otras áreas económicas o en aplicaciones militares. Por eso se deberá tener en cuenta que las palabras de señal aquí descritas sean utilizadas siempre solamente en combinación con la correspondiente documentación de producto y solamente en combinación con el producto correspondiente. La utilización de las palabras de señal en combinación con productos o documentaciones que no les correspondan puede llevar a malinterpretaciones y tener por consecuencia daños en personas u objetos.

Informaciones de seguridad elementales

1. El producto solamente debe ser utilizado según lo indicado por el fabricante referente a la situación y posición de funcionamiento sin que se obstruya la ventilación. Si no se convino de otra manera, es para los productos R&S válido lo que sigue: como posición de funcionamiento se define principalmente la posición con el suelo de la caja para abajo, modo de protección IP 2X, grado de suciedad 2, categoría de sobrecarga eléctrica 2, utilizar solamente en estancias interiores, utilización hasta 2000 m sobre el nivel del mar, transporte hasta 4.500 m sobre el nivel del mar. A menos que se especifique otra cosa en la hoja de datos, se aplicará una tolerancia de $\pm 10\%$ sobre el voltaje nominal y de $\pm 5\%$ sobre la frecuencia nominal.
2. En todos los trabajos deberán ser tenidas en cuenta las normas locales de seguridad de trabajo y de prevención de accidentes. El producto solamente debe de ser abierto por personal perito autorizado. Antes de efectuar trabajos en el producto o abrirlo deberá este ser desconectado de la corriente. El ajuste, el cambio de partes, la manutención y la reparación deberán ser solamente efectuadas por electricistas autorizados por R&S. Si se reponen partes con importancia para los aspectos de seguridad (por ejemplo el enchufe, los transformadores o los fusibles), solamente podrán ser sustituidos por partes originales. Después de cada recambio de partes elementales para la seguridad deberá ser efectuado un control de seguridad (control a primera vista, control de conductor protector, medición de resistencia de aislamiento, medición de medición de la corriente conductora, control de funcionamiento).

Informaciones de seguridad

3. Como en todo producto de fabricación industrial no puede ser excluido en general de que se produzcan al usarlo elementos que puedan generar alergias, los llamados elementos alergénicos (por ejemplo el níquel). Si se produjeran en el trato con productos R&S reacciones alérgicas, como por ejemplo urticaria, estornudos frecuentes, irritación de la conjuntiva o dificultades al respirar, se deberá consultar inmediatamente a un médico para averiguar los motivos de estas reacciones.
4. Si productos / elementos de construcción son tratados fuera del funcionamiento definido de forma mecánica o térmica, pueden generarse elementos peligrosos (polvos de sustancia de metales pesados como por ejemplo plomo, berilio, níquel). La partición elemental del producto, como por ejemplo sucede en el tratamiento de materias residuales, debe de ser efectuada solamente por personal especializado para estos tratamientos. La partición elemental efectuada inadecuadamente puede generar daños para la salud. Se deben tener en cuenta las directivas nacionales referentes al tratamiento de materias residuales.
5. En el caso de que se produjeran agentes de peligro o combustibles en la aplicación del producto que debieran de ser transferidos a un tratamiento de materias residuales, como por ejemplo agentes refrigerantes que deben ser repuestos en periodos definidos, o aceites para motores, deberán ser tenidas en cuenta las prescripciones de seguridad del fabricante de estos agentes de peligro o combustibles y las regulaciones regionales para el tratamiento de materias residuales. Cuiden también de tener en cuenta en caso dado las prescripciones de seguridad especiales en la descripción del producto.
6. Ciertos productos, como por ejemplo las instalaciones de radiación HF, pueden a causa de su función natural, emitir una radiación electromagnética aumentada. En vista a la protección de la vida en desarrollo deberían ser protegidas personas embarazadas debidamente. También las personas con un bypass pueden correr peligro a causa de la radiación electromagnética. El empresario/usuario está comprometido a valorar y señalar áreas de trabajo en las que se corra un riesgo aumentado de exposición a radiaciones para evitar riesgos.
7. La utilización de los productos requiere instrucciones especiales y una alta concentración en el manejo. Debe de ponerse por seguro de que las personas que manejen los productos estén a la altura de los requerimientos necesarios referente a sus aptitudes físicas, psíquicas y emocionales, ya que de otra manera no se pueden excluir lesiones o daños de objetos. El empresario lleva la responsabilidad de seleccionar el personal usuario apto para el manejo de los productos.
8. Antes de la puesta en marcha del producto se deberá tener por seguro de que la tensión preseleccionada en el producto equivalga a la del la red de distribución. Si es necesario cambiar la preselección de la tensión también se deberán en caso dabo cambiar los fusibles correspondientes del producto.
9. Productos de la clase de seguridad I con alimentación móvil y enchufe individual de producto solamente deberán ser conectados para el funcionamiento a tomas de corriente de contacto de seguridad y con conductor protector conectado.
10. Queda prohibida toda clase de interrupción intencionada del conductor protector, tanto en la toma de corriente como en el mismo producto. Puede tener como consecuencia el peligro de golpe de corriente por el producto. Si se utilizaran cables o enchufes de extensión se deberá poner al seguro, que es controlado su estado técnico de seguridad.
11. Si el producto no está equipado con un interruptor para desconectarlo de la red, se deberá considerar el enchufe del cable de distribución como interruptor. En estos casos deberá asegurar de que el enchufe sea de fácil acceso y nabejo (según la medida del cable de distribución, aproximadamente 2 m). Los interruptores de función o electrónicos no son aptos para el corte de la red eléctrica. Si los productos sin interruptor están integrados en construcciones o instalaciones, se deberá instalar el interruptor al nivel de la instalación.

Informaciones de seguridad

12. No utilice nunca el producto si está dañado el cable eléctrico. Compruebe regularmente el correcto estado de los cables de conexión a red. Asegure a través de las medidas de protección y de instalación adecuadas de que el cable de eléctrico no pueda ser dañado o de que nadie pueda ser dañado por él, por ejemplo al tropezar o por un golpe de corriente.
13. Solamente está permitido el funcionamiento en redes de distribución TN/TT aseguradas con fusibles de como máximo 16 A (utilización de fusibles de mayor amperaje sólo previa consulta con el grupo de empresas Rohde & Schwarz).
14. Nunca conecte el enchufe en tomas de corriente sucias o llenas de polvo. Introduzca el enchufe por completo y fuertemente en la toma de corriente. Si no tiene en consideración estas indicaciones se arriesga a que se originen chispas, fuego y/o heridas.
15. No sobrecargue las tomas de corriente, los cables de extensión o los enchufes de extensión ya que esto pudiera causar fuego o golpes de corriente.
16. En las mediciones en circuitos de corriente con una tensión de entrada de $U_{\text{eff}} > 30 \text{ V}$ se deberá tomar las precauciones debidas para impedir cualquier peligro (por ejemplo medios de medición adecuados, seguros, limitación de tensión, corte protector, aislamiento etc.).
17. En caso de conexión con aparatos de la técnica informática se deberá tener en cuenta que estos cumplan los requisitos de la EC950/EN60950.
18. A menos que esté permitido expresamente, no retire nunca la tapa ni componentes de la carcasa mientras el producto esté en servicio. Esto pone a descubierto los cables y componentes eléctricos y puede causar heridas, fuego o daños en el producto.
19. Si un producto es instalado fijamente en un lugar, se deberá primero conectar el conductor protector fijo con el conductor protector del aparato antes de hacer cualquier otra conexión. La instalación y la conexión deberán ser efectuadas por un electricista especializado.
20. En caso de que los productos que son instalados fijamente en un lugar sean sin protector implementado, autointerruptor o similares objetos de protección, el circuito de suministro de corriente deberá estar protegido de manera que usuarios y productos estén suficientemente protegidos.
21. Por favor, no introduzca ningún objeto que no esté destinado a ello en los orificios de la caja del aparato. No vierta nunca ninguna clase de líquidos sobre o en la caja. Esto puede producir corto circuitos en el producto y/o puede causar golpes de corriente, fuego o heridas.
22. Asegúrese con la protección adecuada de que no pueda originarse en el producto una sobrecarga por ejemplo a causa de una tormenta. Si no se verá el personal que lo utilice expuesto al peligro de un golpe de corriente.
23. Los productos R&S no están protegidos contra el agua si no es que exista otra indicación, ver también punto 1. Si no se tiene en cuenta esto se arriesga el peligro de golpe de corriente para el usuario o de daños en el producto lo cual también puede llevar al peligro de personas.
24. No utilice el producto bajo condiciones en las que pueda producirse y se hayan producido líquidos de condensación en o dentro del producto como por ejemplo cuando se desplaza el producto de un lugar frío a un lugar caliente.
25. Por favor no cierre ninguna ranura u orificio del producto, ya que estas son necesarias para la ventilación e impiden que el producto se caliente demasiado. No pongan el producto encima de materiales blandos como por ejemplo sofás o alfombras o dentro de una caja cerrada, si esta no está suficientemente ventilada.
26. No ponga el producto sobre aparatos que produzcan calor, como por ejemplo radiadores o calentadores. La temperatura ambiental no debe superar la temperatura máxima especificada en la hoja de datos.

Informaciones de seguridad

27. Baterías y acumuladores no deben de ser expuestos a temperaturas altas o al fuego. Guardar baterías y acumuladores fuera del alcance de los niños. No cortocircuitar baterías ni acumuladores. Si las baterías o los acumuladores no son cambiados con la debida atención existirá peligro de explosión (atención células de Litio). Cambiar las baterías o los acumuladores solamente por los del tipo R&S correspondiente (ver lista de piezas de recambio). Las baterías y acumuladores deben reutilizarse y no deben acceder a los vertederos. Las baterías y acumuladores que contienen plomo, mercurio o cadmio deben tratarse como residuos especiales. Respete en esta relación las normas nacionales de evacuación y reciclaje.
28. Por favor tengan en cuenta que en caso de un incendio pueden desprenderse del producto agentes venenosos (gases, líquidos etc.) que pueden generar daños a la salud.
29. El producto puede poseer un peso elevado. Muévelo con cuidado para evitar lesiones en la espalda u otras partes corporales.
30. No sitúe el producto encima de superficies, vehículos, estantes o mesas, que por sus características de peso o de estabilidad no sean aptas para él. Siga siempre las instrucciones de instalación del fabricante cuando instale y asegure el producto en objetos o estructuras (por ejemplo paredes y estantes).
31. Las asas instaladas en los productos sirven solamente de ayuda para el manejo que solamente está previsto para personas. Por eso no está permitido utilizar las asas para la sujeción en o sobre medios de transporte como por ejemplo grúas, carretillas elevadoras de horquilla, carros etc. El usuario es responsable de que los productos sean sujetados de forma segura a los medios de transporte y de que las prescripciones de seguridad del fabricante de los medios de transporte sean tenidas en cuenta. En caso de que no se tengan en cuenta pueden causarse daños en personas y objetos.
32. Si llega a utilizar el producto dentro de un vehículo, queda en la responsabilidad absoluta del conductor que conducir el vehículo de manera segura. Asegure el producto dentro del vehículo debidamente para evitar en caso de un accidente las lesiones u otra clase de daños. No utilice nunca el producto dentro de un vehículo en movimiento si esto pudiera distraer al conductor. Siempre queda en la responsabilidad absoluta del conductor la seguridad del vehículo. El fabricante no asumirá ninguna clase de responsabilidad por accidentes o colisiones.
33. Dado el caso de que esté integrado un producto de laser en un producto R&S (por ejemplo CD/DVD-ROM) no utilice otras instalaciones o funciones que las descritas en la documentación de producto. De otra manera pondrá en peligro su salud, ya que el rayo laser puede dañar irreversiblemente sus ojos. Nunca trate de descomponer estos productos. Nunca mire dentro del rayo laser.

Certified Quality System

DIN EN ISO 9001 : 2000
DIN EN 9100 : 2003
DIN EN ISO 14001 : 2004

DQS REG. NO 001954 QM UM

QUALITÄTSZERTIFIKAT

Sehr geehrter Kunde,

Sie haben sich für den Kauf eines Rohde & Schwarz-Produktes entschieden. Hiermit erhalten Sie ein nach modernsten Fertigungsmethoden hergestelltes Produkt. Es wurde nach den Regeln unseres Managementsystems entwickelt, gefertigt und geprüft.

Das Rohde & Schwarz Managementsystem ist zertifiziert nach:

DIN EN ISO 9001:2000
DIN EN 9100:2003
DIN EN ISO 14001:2004

CERTIFICATE OF QUALITY

Dear Customer,

you have decided to buy a Rohde & Schwarz product. You are thus assured of receiving a product that is manufactured using the most modern methods available. This product was developed, manufactured and tested in compliance with our quality management system standards.

The Rohde & Schwarz quality management system is certified according to:

DIN EN ISO 9001:2000
DIN EN 9100:2003
DIN EN ISO 14001:2004

CERTIFICAT DE QUALITÉ

Cher Client,

vous avez choisi d'acheter un produit Rohde & Schwarz. Vous disposez donc d'un produit fabriqué d'après les méthodes les plus avancées. Le développement, la fabrication et les tests respectent nos normes de gestion qualité.

Le système de gestion qualité de Rohde & Schwarz a été homologué conformément aux normes:

DIN EN ISO 9001:2000
DIN EN 9100:2003
DIN EN ISO 14001:2004



ROHDE & SCHWARZ



Certificate No.: 2006-25

This is to certify that:

Equipment type	Stock No.	Designation
FSUP8	1166.3505.08	Signal Source Analyzer
FSUP26	1166.3505.26	
FSUP50	1166.3505.50	
FSUP-B18	1145.0242.07	Removable Hard Disk
FSUP-B19	1145.0394.07	Second Hard Disk
FSUP-B60	1169.5544.02	Low Phase Noise Board

complies with the provisions of the Directive of the Council of the European Union on the approximation of the laws of the Member States

- relating to electrical equipment for use within defined voltage limits (73/23/EEC revised by 93/68/EEC)
- relating to electromagnetic compatibility (89/336/EEC revised by 91/263/EEC, 92/31/EEC, 93/68/EEC)

Conformity is proven by compliance with the following standards:

EN 61010-1 : 2001
EN 55011 : 1998 + A1 : 1999 + A2 : 2002, Class B
EN 61326 : 1997 + A1 : 1998 + A2 : 2001 + A3 : 2003

For the assessment of electromagnetic compatibility, the limits of radio interference for Class B equipment as well as the immunity to interference for operation in industry have been used as a basis.

Affixing the EC conformity mark as from 2006

ROHDE & SCHWARZ GmbH & Co. KG
Mühldorfstr. 15, D-81671 München

Munich, 2006-11-23

Central Quality Management MF-QZ / Radde

Customer Support

Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz equipment, contact one of our Customer Support Centers. A team of highly qualified engineers provides telephone support and will work with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz equipment.

Up-to-date information and upgrades

To keep your Rohde & Schwarz equipment always up-to-date, please subscribe to our electronic newsletter at

<http://www.rohde-schwarz.com/www/response.nsf/newsletterpreselection>

or request the desired information and upgrades via email from your Customer Support Center (addresses see below).

Feedback

We want to know if we are meeting your support needs. If you have any comments please email us and let us know CustomerSupport.Feedback@rohde-schwarz.com.

USA & Canada

Monday to Friday (except US public holidays)

8:00 AM – 8:00 PM Eastern Standard Time (EST)

Tel. from USA 888-test-rsa (888-837-8772) (opt 2)

From outside USA +1 410 910 7800 (opt 2)

Fax +1 410 910 7801

E-mail Customer.Support@rsa.rohde-schwarz.com

East Asia

Monday to Friday (except Singaporean public holidays)

8:30 AM – 6:00 PM Singapore Time (SGT)

Tel. +65 6 513 0488

Fax +65 6 846 1090

E-mail Customersupport.asia@rohde-schwarz.com

Rest of the World

Monday to Friday (except German public holidays)

08:00 – 17:00 Central European Time (CET)

Tel. from Europe +49 (0) 180 512 42 42

From outside Europe +49 89 4129 13776

Fax +49 (0) 89 41 29 637 78

E-mail CustomerSupport@rohde-schwarz.com



Address List

Headquarters, Plants and Subsidiaries

Headquarters

ROHDE & SCHWARZ GmbH & Co. KG
Mühlendorfstraße 15 · D-81671 München
P.O.Box 80 14 69 · D-81614 München

Phone +49 (89) 41 29-0
Fax +49 (89) 41 29-121 64
info.rs@rohde-schwarz.com

Plants

ROHDE & SCHWARZ Messgerätebau GmbH
Riedbachstraße 58 · D-87700 Memmingen
P.O.Box 16 52 · D-87686 Memmingen

Phone +49 (83 31) 1 08-0
+49 (83 31) 1 08-1124
info.rsmb@rohde-schwarz.com

ROHDE & SCHWARZ GmbH & Co. KG
Werk Teisnach
Kaikenrieder Straße 27 · D-94244 Teisnach
P.O.Box 11 49 · D-94240 Teisnach

Phone +49 (99 23) 8 50-0
Fax +49 (99 23) 8 50-174
info.rsdt@rohde-schwarz.com

ROHDE & SCHWARZ závod
Vimperk, s.r.o.
Location Spidrova 49
CZ-38501 Vimperk

Phone +420 (388) 45 21 09
Fax +420 (388) 45 21 13

ROHDE & SCHWARZ GmbH & Co. KG
Dienstleistungszentrum Köln
Graf-Zeppelin-Straße 18 · D-51147 Köln
P.O.Box 98 02 60 · D-51130 Köln

Phone +49 (22 03) 49-0
Fax +49 (22 03) 49 51-229
info.rsdc@rohde-schwarz.com
service.rsdc@rohde-schwarz.com

Subsidiaries

R&S BICK Mobilfunk GmbH
Fritz-Hahne-Str. 7 · D-31848 Bad Münder
P.O.Box 20 02 · D-31844 Bad Münder

Phone +49 (50 42) 9 98-0
Fax +49 (50 42) 9 98-105
info.bick@rohde-schwarz.com

ROHDE & SCHWARZ FTK GmbH
Wendenschloßstraße 168, Haus 28
D-12557 Berlin

Phone +49 (30) 658 91-122
Fax +49 (30) 655 50-221
info.ftk@rohde-schwarz.com

ROHDE & SCHWARZ SIT GmbH
Am Studio 3
D-12489 Berlin

Phone +49 (30) 658 84-0
Fax +49 (30) 658 84-183
info.sit@rohde-schwarz.com

R&S Systems GmbH
Graf-Zeppelin-Straße 18
D-51147 Köln

Phone +49 (22 03) 49-5 23 25
Fax +49 (22 03) 49-5 23 36
info.rssys@rohde-schwarz.com

GEDIS GmbH
Sophienblatt 100
D-24114 Kiel

Phone +49 (431) 600 51-0
Fax +49 (431) 600 51-11
sales@gedis-online.de

HAMEG Instruments GmbH
Industriestraße 6
D-63533 Mainhausen

Phone +49 (61 82) 800-0
Fax +49 (61 82) 800-100
info@hameg.de

Locations Worldwide

Please refer to our homepage: www.rohde-schwarz.com

- ◆ Sales Locations
- ◆ Service Locations
- ◆ National Websites

1 Putting into Operation

For details refer to the Quick Start Guide chapters 1, "Front and Rear Panel", and 2, "Preparing for Use".

2 Getting Started

Introduction	2.3
Characteristic Curve Measurement Results	2.4
Pushing	2.5
Pulling	2.8
DC Characteristic	2.9
Phase Noise Measurements (Phase Noise Analyzer)	2.11
Configuring the Center Frequency and the Level	2.13
Configuring the Settings	2.13
Available PLL Test Setups	2.15
Basic Configurations	2.16
Using an External Reference Oscillator	2.17
Double DUT Measurement	2.18
External Down-Conversion	2.19
Troubleshooting	2.20
Ground Loops	2.20
Measuring the Spectra of Complex Signals	2.21
Intermodulation Measurements	2.21
Measurement Example – Measuring the R&S FSUP's Intrinsic Intermodulation Distance	2.23
Measuring Signals in the Vicinity of Noise	2.28
Measurement Example – Measuring the Level of the Internal Reference Generator at Low S/N Ratios	2.31
Noise Measurements	2.36
Measuring Noise Power Density	2.36
Measurement Example – Measuring the Intrinsic Noise Power Density of the R&S FSUP at 1 GHz and Calculating the R&S FSUP's Noise Figure	2.36
Measurement of Noise Power within a Transmission Channel	2.39
Measurement Example – Measuring the Intrinsic Noise of the R&S FSUP at 1 GHz in a 1.23 MHz Channel Bandwidth with the Channel Power Function	2.39
Measuring Phase Noise	2.44
Measurement Example – Measuring the Phase Noise of a Signal Generator at a Carrier Offset of 10 kHz	2.44
Measurements on Modulated Signals	2.46
Measurements on AM Signals	2.46
Measurement Example 1 – Displaying the AF of an AM Signal in the Time Domain	2.46
Measurement Example 2 – Measuring the Modulation Depth of an AM Carrier in the Frequency Domain	2.48

Measurements on FM Signals	2.50
Measurement Example – Displaying the AF of an FM Carrier	2.50
Measuring Channel Power and Adjacent Channel Power	2.53
Measurement Example 1 – ACPR Measurement on an IS95 CDMA Signal	2.54
Measurement Example 2 – Measuring the Adjacent Channel Power of an IS136 TDMA Signal	2.59
Measurement Example 3 – Measuring the Modulation Spectrum in Burst Mode with the Gated Sweep Function	2.62
Measurement Example 4 – Measuring the Transient Spectrum in Burst Mode with the Fast ACP function	2.65
Measurement Example 5 – Measuring the Adjacent Channel Power of a W-CDMA Uplink Signal	2.67
Amplitude Distribution Measurements	2.71
Measurement Example – Measuring the APD and CCDF of White Noise Generated by the R&S FSUP	2.71

Introduction

This chapter explains how to operate the R&S FSUP using typical measurements as examples. Additional background information on the settings is given.

All of the following examples are based on the standard settings of the R&S FSUP. These are set with the *PRESET* key. A complete list of the standard settings can be found in chapter [“Instrument Functions”](#), section [“R&S FSUP Initial Configuration – PRESET Key”](#) on page 4.5.

Phase noise measurements

- [“Characteristic Curve Measurement Results”](#) on page 2.4
- [“Phase Noise Measurements \(Phase Noise Analyzer\)”](#) on page 2.11
- [“Available PLL Test Setups”](#) on page 2.15
- [“Troubleshooting”](#) on page 2.20

Signal Source Analyzer measurements

- [“Measuring the Spectra of Complex Signals”](#) on page 2.21
- [“Measuring Signals in the Vicinity of Noise”](#) on page 2.28
- [“Noise Measurements”](#) on page 2.36
- [“Measurements on Modulated Signals”](#) on page 2.46

Examples of more basic character are described in the Quick Start Guide, chapter 5.

An introduction to phase noise measurements and the measurement prerequisites (DC settings, test setup) are also provided in this chapter of the Quick Start Guide.

Characteristic Curve Measurement Results

A characteristic measurement example is given in the Quick Start Guide, chapter 5. There, also the VCO (voltage controlled oscillator) measurement results are explained. In this section, the following measurement results are described:

- [“Pushing ” on page 2.5](#)
- [“Pulling” on page 2.8](#)
- [“DC Characteristic” on page 2.9](#)

Pushing

Tuning measurement can be combined with variation of the supply voltage of the DUT (for details on the procedure see section “[Procedure](#)” on page 2.5). Three consecutive measurements are performed using DC voltage steps:

1. DC is set to its nominal value.
2. DC is set to a value above the nominal value.
3. DC is set to a value below the nominal value.

The selection of the *VCO TUNING CHAR* measurement result enables the Pushing measurement of the DUT’s characteristic vs. tuning voltage. The measurement identifies the impact of a DC supply voltage change on the characteristic curve. For this purpose, three consecutive characteristic measurements with variation in DC supply voltage are performed and displayed in one trace.



Note

Because all available traces are used for display of three voltage steps, no dual display (i.e. tuning characteristic and tuning sensitivity) is available.

Prerequisites

- Default test setup is selected (for details see Quick Start Guide, chapter 5).
- RF output, DC and tuning voltage inputs of the DUT are connected to the instrument.
- DC voltages are properly set (for details see Quick Start Guide, chapter 5).
- DC power is switched on.

Procedure

1. Select the operating mode.

- Press the *SSA HOME* hotkey.
- Press the *VCO MEAS* softkey.

2. Activate pushing.

- Set the *VCO PUSHING* softkey to *ON* by pressing it.

3. Select one of the following measurement results.

- Press the *VCO TUNING CHAR* softkey.
- Press the *VCO SENSITIVITY* softkey.
- Press the *VCO RF PWR CHAR* softkey.

4. In the Measurement Settings dialog box, set the number of measurement points for the DC voltage sweep.

For details refer to section “[DC Characteristic](#)”, step 3, or chapter 4, section “[VCO Measurements](#)” on page 4.42.

5. In the DC SETTINGS dialog box (SSA HOME-SETTINGS-DC SETTINGS), set the voltage step for the Pushing measurement.

- Press the *SETTINGS* hotkey.
- Press the *DC SETTINGS* softkey.
- Focus the ΔV_{cc1} *Pushing* field, enter a numeric value (e.g. 100) and press *ENTER*.
(For details on the *DC SETTINGS* dialog box refer to the Quick Start Guide, chapter 5.)

6. Press the RUN hotkey.

R&S FSUP Signal Source Analyzer						
Settings			Results			
Tuning	Voltage		Level @ Udc	ΔL @ Udc -100 mV		ΔL @ Udc +100 mV
Vmin	2.00	V	6.50 dBm	-0.11	dB	0.10 dB
Vcurrent	8.00	V	7.65 dBm	0.04	dB	0.17 dB
Vmax	20.00	V	6.05 dBm	-0.14	dB	0.09 dB




Fig. 2-1 Pushing measurement, impact of a DC supply voltage change on the VCO's characteristic (absolute scaling)

7. Change to relative scaling.

- Press the *SSA HOME* hotkey.
- Press the *VCO MEAS* softkey.
- Press the *NEXT* key.
- Press the *PUSH/PULL REL/ABS* softkey.
The measurement result is displayed in relative scaling.

R&S FSUP Signal Source Analyzer						
Settings			Results			
Tuning	Voltage		Level @ Udc	ΔL @ Udc -100 mV		ΔL @ Udc +100 mV
Vmin	2.00	V	6.50 dBm	-0.12	dB	0.12 dB
Vcurrent	8.00	V	8.00 dBm	-0.12	dB	0.05 dB
Vmax	20.00	V	6.05 dBm	-0.12	dB	0.11 dB




Fig. 2-2 Pushing measurement, impact of a DC supply voltage change on the VCO's characteristic (relative scaling)



Tip

If the DUT has large blocking capacitors, the Vcc settling time must be adapted correspondingly in order to enable proper voltage stabilization before a measurement.

Pulling

The Pulling measurement identifies the impact of a load change on the characteristic curve. Three consecutive characteristic measurements with a variation in load are performed and displayed in one trace. The load variation is controlled via the R&S FSUP-B28 option. For hardware details as switching signal states and pin assignment refer to the Quick Start Guide, chapter 1. For general details on the R&S FSUP-B28 option refer to section [“Trigger Port – Option R&S FSP-B28” on page 4.343](#).

In principle, the Pulling measurement is very similar to the Pushing measurement. Instead of identifying the impact of a DC supply voltage change on the characteristic curve, the impact of a load change is measured. Accordingly, the Pulling measurement result resembles the Pushing measurement result shown in [Fig. 2-1](#). The Pulling measurement result can also be displayed in relative and absolute scaling ([Fig. 2-2](#)).

DC Characteristic

In this measurement example, the DUT's characteristic vs. supply voltage is determined. The measurement is similar to the Pushing measurement, but in difference to the Pushing measurement, a fixed tuning voltage is used. The measurement demonstrates the impact of a DC supply voltage sweep (within the permitted limits) on the VCO's center frequency and level.

Prerequisites

For details refer to section [“Prerequisites” on page 2.5](#).

Procedure

1. Select the operating mode.

- Press the SSA HOME hotkey.
- Press the VCO MEAS softkey.

2. Select the measurement result.

- Press the VCO DC CHAR softkey.

3. In the Measurement Settings dialog box, set the number of measurement points for the DC voltage sweep.

- Press the SETTINGS hotkey.
- Press the MEAS SETTINGS softkey.

The *Measurement Settings* dialog box is displayed.

For details refer to chapter 4, section [“VCO Measurements” on page 4.42](#).

4. If you want to change general settings, open the General Settings dialog box.

- Press the SETTINGS hotkey.
- Press the GENERAL SETTINGS softkey.

The *General Settings* dialog box is displayed.

For details refer to chapter 4, section [“VCO Measurements” on page 4.28](#).

5. In the DC SETTINGS dialog box, define the range of the DC voltage sweep.

- Press the SETTINGS hotkey.
- Press the DC SETTINGS softkey.

For details on the DC SETTINGS dialog box refer to the Quick Start Guide, chapter 5, or chapter 4, section [“VCO Measurements” on page 4.28](#).

6. Press the RUN hotkey.




Fig. 2-3 VCO's DC characteristic



Tip

If the DUT has large blocking capacitors, the Vcc settling time must be adapted correspondingly in order to enable proper voltage stabilization before a measurement.

Phase Noise Measurements (Phase Noise Analyzer)

The spectrum analyzer measurement method is applied very commonly. By using a spectrum analyzer in sweep mode, the frequency offset range (up to 1 GHz) is much wider than a PLL measurement can achieve. On the other hand, the measurement speed is limited and the instrument's inherent noise floor close to the carrier is limited by the measurement signal level that the instrument has to handle. The instrument does not control the DUT in a loop so that measurements close to the carrier may be affected by the DUT's low frequency fluctuations.

The instrument switches into the default measurement mode regardless of the prior selected test setup. That means that the R&S FSUP expects the DUT's RF signal has to be connected to the RF input directly.

**Note**

Sweep spectrum measurements are made for RBWs larger than 3 kHz.

The spur search and remove functionality is not available in the spectrum analyzer measurement.

Prerequisites

- Unless otherwise noted, the measurement settings are identical to the basic PLL mode.
- DC power is switched on.
- DC voltages are properly set and are applied to the DUT (if required by the specific test setup).
- Default test setup is selected, and the DUT is connected to the instrument.

Procedure**1. Set the PLL measurement mode.**

- Press the *SSA HOME* hotkey.
- Press the *NOISE MEAS* hotkey.
- Press the *PH NOISE ANALYZER* softkey.

2. Enter the DUT's center frequency.

- Press the *FREQ* hardkey.
- Enter a numeric value, press the appropriate unit key and then *ENTER*.

3. Enter the DUT's level.

- Focus the *Level* field using the arrow keys.
- Enter a numeric value, press the appropriate unit key and then *ENTER*.

4. Perform a pre-measurement.

- Press the *PREMEAS* hotkey.

5. Open the Measurement Settings dialog box.

- Press the *SETTINGS* hotkey.
- Press the *MEAS SETTINGS* softkey.

6. Change start offset frequency.

- Press the *SPAN START* softkey.
- Select an entry from the list (e.g. 100 Hz)

7. Change stop offset frequency.

- Press the *SPAN STOP* softkey.
- Select an entry from the list (e.g. 30 MHz)

8. Start the phase noise measurement.

- Press the *RUN* hotkey.

After the R&S FSUP has finished the measurement, the numeric results (residual noise calculation and spot noise values) are updated.



Fig. 2-4 Phase noise measurement (spectrum analyzer)

Configuring the Center Frequency and the Level

The easiest way to determine the DUT's center frequency and level is to perform a pre-measurement. After finishing the pre-measurement, the instrument updates its center frequency and level setting automatically and displays the current values on the top left of the measurement screen.

Procedure

- Perform a pre-measurement by pressing the *PREMEAS* hotkey.

The center frequency and level setting are displayed on the top left of the measurement screen.




Fig. 2-5 Center frequency and level display



Tip

Alternatively, you can enter the DUT's center frequency and level manually in order to force the instrument to measure at the selected frequency. For a detailed description refer to section "[Phase Noise Measurements \(Phase Noise Analyzer\)](#)" on page 2.11, step 2 and 3.

Configuring the Settings

For the phase noise measurements, the following dialog boxes are available for settings:

- *Measurement Settings* dialog box
- *General Settings* dialog box

For further details refer also to chapter 4, section "[SETTINGS Hotkey Menu](#)" on page 4.17.

Procedure

1. Open the *Measurement Settings* dialog box.

- Press the *SETTINGS* hotkey.
- Press the *MEAS SETTINGS* softkey.

The *Measurement Settings* dialog box is displayed. The procedure is identical to the operation in PLL mode, detailed described in the Quick Start Guide, chapter 5. Further details on the parameters are given in chapter 4, section "[Noise Measurements](#)" on page 4.37.

2. Change start offset frequency.

- Press the *SPAN START* softkey.
- Select an entry from the list (e.g. 1 kHz).

3. Change stop offset frequency.

- Press the *SPAN STOP* softkey.
- Select an entry from the list (e.g. 30 MHz).

4. Open the General Settings dialog box.

- Press the *SETTINGS* hotkey.
- Press the *GENERAL SETTINGS* softkey.

The *General Settings* dialog box is displayed. For details refer to chapter 4, section “[Noise Measurements](#)” on page 4.19.

5. Restrict the range of the residual calculation. By default, the residual noise calculation is coupled to the meas settings.

- Press the *RESIDUAL CALC* softkey.
- Press *ENTER* to deactivate the *Use Meas Settings* option.
- Set the focus on *Eval From*, enter a numeric value (e.g. 3 kHz), and press *ENTER*.
- Set the focus on *To*, enter a numeric value (e.g. 300 kHz), and press *ENTER*.

The calculation range is updated immediately and the numeric values on top of the screen are updated.

Available PLL Test Setups

This chapter describes the available test setups for PLL measurements:

- [“Basic Configurations” on page 2.16](#)
- [“Using an External Reference Oscillator” on page 2.17](#)
- [“Double DUT Measurement” on page 2.18](#)
- [“External Down-Conversion” on page 2.19](#)

For information on how to display the selected test setup and change it, refer to the Quick Start Guide, chapter 5.

Basic Configurations




Fig. 2-6 Configuration suitable for DUTs with (very) good phase noise performance (internal generator is controlled)





Fig. 2-7 Configuration suitable for DUTs with poorer phase noise performance (external DUT is controlled)


Using an External Reference Oscillator

The internal generator can be replaced by an external generator if the external generator offers a better phase-noise performance.




Double DUT Measurement

This configuration is often used for low noise Xtal oscillators. Two identical oscillators are measured against each other. Since the phase noise of both is not correlated, a 3 dB correction factor is applied to the displayed phase noise values.



Note

The 3 dB correction factor is applied by the instrument automatically.





External Down-Conversion

This configuration is suitable for measuring objects exceeding the upper frequency range of the instrument.



Note

Be aware of the external generator's inherent phase noise. It may affect the measurement and may define the measurement floor.



Troubleshooting

This chapter provides help for difficult measurement tasks. The following topics are included:

- “Ground Loops ” on page 2.20

Ground Loops

Hum and noise picked up by ground loops may impact the phase noise measurement seriously. Ground loops are created when the ground leg of a signal travels, via the coax cable (when supplying the DUT with DC and tuning voltage) or other wiring and equipment back to its source. The loop picks up mains hum, interference from a switched power supply, power supply of a fluorescent lamp, noise of a CRT monitor or noise from any other source. Noise is introduced when the unwanted interference source causes a current in the loop and is added to the signals.

The impact grows with a rising tuning sensitivity of the DUT. As a corrective for the ground loop effects a toroidal core (supplied complementary with the instrument) can be used. Even some turns of the tuning voltage cable or the RF input cable damp the ground loop inducted noise and improve the measurement significantly.




Fig. 2-8 Ground loop configurations

The following ground loop configurations are possible as shown in Fig. 2-8:

- $V_{supply} \leftrightarrow RF \text{ input}$
- $V_{tune} \leftrightarrow RF \text{ Input}$
- $V_{supply} \leftrightarrow V_{tune}$ (not shown in diagram)

Measuring the Spectra of Complex Signals

Intermodulation Measurements

If several signals are applied to a DUT with non-linear characteristics, unwanted mixing products are generated – mostly by active components such as amplifiers or mixers. The products created by 3rd order intermodulation are particularly troublesome as they have frequencies close to the useful signals and, compared with other products, are closest in level to the useful signals. The fundamental wave of one signal is mixed with the 2nd harmonic of the other signal.

$$f_{s1} = 2 \times f_{u1} - f_{u2} \quad (1)$$

$$f_{s2} = 2 \times f_{u2} - f_{u1} \quad (2)$$

where f_{s1} and f_{s2} are the frequencies of the intermodulation products and f_{u1} and f_{u2} the frequencies of the useful signals.

The following diagram shows the position of the intermodulation products in the frequency domain.




Fig. 2-9 3rd order intermodulation products

Example

$$f_{u1} = 100 \text{ MHz}, f_{u2} = 100.03 \text{ MHz}$$

$$f_{s1} = 2 \times f_{u1} - f_{u2} = 2 \times 100 \text{ MHz} - 100.03 \text{ MHz} = 99.97 \text{ MHz}$$

$$f_{s2} = 2 \times f_{u2} - f_{u1} = 2 \times 100.03 \text{ MHz} - 100 \text{ MHz} = 100.06 \text{ MHz}$$

The level of the intermodulation products depends on the level of the useful signals. If the level of the two useful signals is increased by 1 dB, the level of the intermodulation products is increased by 3 dB. The intermodulation distance d_3 is, therefore, reduced by 2 dB. Fig. 2-10 shows how the levels of the useful signals and the 3rd order intermodulation products are related.




Fig. 2-10 Level of the 3rd order intermodulation products as a function of the level of the useful signals

The behavior of the signals can be explained using an amplifier as an example. The change in the level of the useful signals at the output of the amplifier is proportional to the level change at the input of the amplifier as long as the amplifier is operating in linear range. If the level at the amplifier input is changed by 1 dB, there is a 1 dB level change at the amplifier output. At a certain input level, the amplifier enters saturation. The level at the amplifier output does not increase with increasing input level.

The level of the 3rd order intermodulation products increases 3 times faster than the level of the useful signals. The 3rd order intercept is the virtual level at which the level of the useful signals and the level of the spurious products are identical, i.e. the intersection of the two straight lines. This level cannot be measured directly as the amplifier goes into saturation or is damaged before this level is reached.

The 3rd order intercept can be calculated from the known slopes of the lines, the intermodulation distance d_2 and the level of the useful signals.

$$TOI = a_{D3} / 2 + P_n \tag{3}$$

with TOI (Third Order Intercept) being the 3rd order intercept in dBm and P_n the level of a carrier in dBm.


With an intermodulation distance of 60 dB and an input level, P_w , of -20 dBm, the following 3rd order intercept is obtained:

$$TOI = 60 \text{ dBm} / 2 + (-20 \text{ dBm}) = 10 \text{ dBm}.$$

Measurement Example – Measuring the R&S FSUP’s Intrinsic Intermodulation Distance

To measure the intrinsic intermodulation distance, use the test setup shown in the figure below.

Test setup



Signal generator settings (e.g. R&S SMIQ)

	Level	Frequency
Signal generator 1	-10 dBm	999.9 MHz
Signal generator 2	-10 dBm	1000.1 MHz

Measurement using the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set center frequency to 1 GHz and the frequency span to 1 MHz.

- Press the *FREQ* key and enter 1 GHz.
- Press the *SPAN* key and enter 1 MHz.

3. Set the reference level to -10 dBm and RF attenuation to 0 dB.

- Press the *AMPT* key and enter -10 dBm.
- Press the *RF ATTEN MANUAL* softkey and enter 0 dB.
By reducing the RF attenuation to 0 dB, the level to the R&S FSUP input mixer is increased. Therefore, 3rd order intermodulation products are displayed.

4. Set the resolution bandwidth to 5 kHz.

- Press the *BW* key.
- Press the *RES BW MANUAL* softkey and enter 5 kHz.
By reducing the bandwidth, the noise is further reduced and the intermodulation products can be clearly seen.

5. Measuring intermodulation by means of the 3rd order intercept measurement function.

- Press the *MEAS* key.
- Press the *TOI* softkey.

The R&S FSUP activates four markers for measuring the intermodulation distance. Two markers are positioned on the useful signals and two on the intermodulation products. The 3rd order intercept is calculated from the level difference between the useful signals and the intermodulation products. It is then displayed on the screen:




Fig. 2-11 Result of intrinsic intermodulation measurement on the R&S FSUP. The 3rd order intercept (TOI) is displayed at the top right corner of the grid

The level of a Signal Source Analyzer’s intrinsic intermodulation products depends on the RF level of the useful signals at the input mixer. When the RF attenuation is added, the mixer level is reduced and the intermodulation distance is increased. With an additional RF attenuation of 10 dB, the levels of the intermodulation products are reduced by 20 dB. The noise level is, however, increased by 10 dB.

6. Increasing RF attenuation to 10 dB to reduce intermodulation products.

- Press the *AMPT* key.
- Press the *RF ATTEN MANUAL* softkey and enter *10 dB*.

The R&S FSUP’s intrinsic intermodulation products disappear below the noise floor.




Fig. 2-12 If the RF attenuation is increased, the R&S FSUP's intrinsic intermodulation products disappear below the noise floor.

Calculation method

The method used by the R&S FSUP to calculate the intercept point takes the average useful signal level P_U in dBm and calculates the intermodulation d_3 in dB as a function of the average value of the levels of the two intermodulation products. The third order intercept (TOI) is then calculated as follows:

$$\text{TOI/dBm} = \frac{1}{2} d_3 + P_U$$

Intermodulation- free dynamic range

The **Intermodulation – free dynamic range**, i.e. the level range in which no internal intermodulation products are generated if two-tone signals are measured, is determined by the 3rd order intercept point, the phase noise and the thermal noise of the R&S FSUP. At high signal levels, the range is determined by intermodulation products. At low signal levels, intermodulation products disappear below the noise floor, i.e. the noise floor and the phase noise of the R&S FSUP determine the range. The noise floor and the phase noise depend on the resolution bandwidth that has been selected. At the smallest resolution bandwidth, the noise floor and phase noise are at a minimum and so the maximum range is obtained. However, a large increase in sweep time is required for small resolution bandwidths. It is, therefore, best to select the largest resolution bandwidth possible to obtain the range that is required. Since phase noise decreases as the carrier-offset increases, its influence decreases with increasing frequency offset from the useful signals.

The following diagrams illustrate the intermodulation-free dynamic range as a function of the selected bandwidth and of the level at the input mixer (= signal level – set RF attenuation) at different useful signal offsets.




Fig. 2-13 Intermodulation-free range of the R&S FSUP as a function of level at the input mixer and the set resolution bandwidth (useful signal offset = 1 MHz, DANL = -157 dBm /Hz, TOI = 25 dBm; typical values at 2 GHz)

The optimum mixer level, i.e. the level at which the intermodulation distance is at its maximum, depends on the bandwidth. At a resolution bandwidth of 10 Hz, it is approx. -42 dBm and at 10 kHz increases to approx. -32 dBm.

Phase noise has a considerable influence on the intermodulation-free range at carrier offsets between 10 and 100 kHz (Fig. 2-14). At greater bandwidths, the influence of the phase noise is greater than it would be with small bandwidths. The optimum mixer level at the bandwidths under consideration becomes almost independent of bandwidth and is approx. -40 dBm.




Fig. 2-14 Intermodulation-free dynamic range of the R&S FSUP as a function of level at the input mixer and of the selected resolution bandwidth (useful signal offset = 10 to 100 kHz, DANL = -157 dBm /Hz, TOI = 25 dBm; typical values at 2 GHz).

**Tip**

If the intermodulation products of a DUT with a very high dynamic range are to be measured and the resolution bandwidth to be used is therefore very small, it is best to measure the levels of the useful signals and those of the intermodulation products separately using a small span. The measurement time will be reduced—in particular if the offset of the useful signals is large. To find signals reliably when frequency span is small, it is best to synchronize the signal sources and the R&S FSUP.

Measuring Signals in the Vicinity of Noise

The minimum signal level a Signal Source Analyzer can measure is limited by its intrinsic noise. Small signals can be swamped by noise and therefore cannot be measured. For signals that are just above the intrinsic noise, the accuracy of the level measurement is influenced by the intrinsic noise of the R&S FSUP.

The displayed noise level of a Signal Source Analyzer depends on its noise figure, the selected RF attenuation, the selected reference level, the selected resolution and video bandwidth and the detector. The effect of the different parameters is explained in the following.

Impact of the RF attenuation setting

The sensitivity of a Signal Source Analyzer is directly influenced by the selected RF attenuation. The highest sensitivity is obtained at a RF attenuation of 0 dB. The R&S FSUP's RF attenuation can be set in 5 dB steps up to 70 dB. Each additional 5 dB step reduces the R&S FSUP's sensitivity by 5 dB, i.e. the displayed noise is increased by 5 dB.

Impact of the reference level setting

If the reference level is changed, the R&S FSUP changes the gain on the last IF so that the voltage at the logarithmic amplifier and the A/D converter is always the same for signal levels corresponding to the reference level. This ensures that the dynamic range of the log amp or the A/D converter is fully utilized. Therefore, the total gain of the signal path is low at high reference levels and the noise figure of the IF amplifier makes a substantial contribution to the total noise figure of the R&S FSUP. The figure below shows the change in the displayed noise depending on the set reference level at 10 kHz and 300 kHz resolution bandwidth. With digital bandwidths (≤ 100 kHz) the noise increases sharply at high reference levels because of the dynamic range of the A/D converter.




Fig. 2-15 Change in displayed noise as a function of the selected reference level at bandwidths of 10 kHz and 300 kHz (-30 dBm reference level)

Impact of the resolution bandwidth

The sensitivity of a Signal Source Analyzer also directly depends on the selected bandwidth. The highest sensitivity is obtained at the smallest bandwidth (for the R&S FSUP: 10 Hz, for FFT filtering: 1 Hz). If the bandwidth is increased, the reduction in sensitivity is proportional to the change in bandwidth. The R&S FSUP has bandwidth settings in 2, 3, 5, 10 sequence. Increasing the bandwidth by a factor of 3 increases the displayed noise by approx. 5 dB (4.77 dB precisely). If the bandwidth is increased by a factor of 10, the displayed noise increases by a factor of 10, i.e. 10 dB. Because of the way the resolution filters are designed, the sensitivity of Signal Source Analyzers often depends on the selected resolution bandwidth. In data sheets, the displayed average noise level is often indicated for the smallest available bandwidth. The extra sensitivity obtained if the bandwidth is reduced may therefore deviate from the values indicated above. The following table illustrates typical deviations from the noise figure for a resolution bandwidth of 10 kHz which is used as a reference value (= 0 dB).




Fig. 2-16 Change in R&S FSUP noise figure at various bandwidths. The reference bandwidth is 10 kHz

Impact of the video bandwidth

The displayed noise of a Signal Source Analyzer is also influenced by the selected video bandwidth. If the video bandwidth is considerably smaller than the resolution bandwidth, noise spikes are suppressed, i.e. the trace becomes much smoother. The level of a sinewave signal is not influenced by the video bandwidth. A sinewave signal can therefore be freed from noise by using a video bandwidth that is small compared with the resolution bandwidth, and thus be measured more accurately.

Impact of the detector

Noise is evaluated differently by the different detectors. The noise display is therefore influenced by the choice of detector. Sinewave signals are weighted in the same way by all detectors, i.e. the level display for a sinewave RF signal does not depend on the selected detector, provided that the signal-to-noise ratio is high enough. The measurement accuracy for signals in the vicinity of R&S FSUP intrinsic noise is also influenced by the detector which has been selected. The R&S FSUP has the following detectors:

- Maximum peak detector

If the max. peak detector is selected, the largest noise display is obtained, since the R&S FSUP displays the highest value of the IF envelope in the frequency range assigned to a pixel at each pixel in the trace. With longer sweep times, the trace indicates higher noise levels since the probability of obtaining a high noise amplitude increases with the dwell time on a pixel. For short sweep times, the display approaches that of the sample detector since the dwell time on a pixel is only sufficient to obtain an instantaneous value.

- Minimum peak detector

The min. peak detector indicates the minimum voltage of the IF envelope in the frequency range assigned to a pixel at each pixel in the trace. The noise is strongly suppressed by the minimum peak detector since the lowest noise amplitude that occurs is displayed for each test point. If the signal-to-noise ratio is low, the minimum of the noise overlaying the signal is displayed too low.

At longer sweep times, the trace shows smaller noise levels since the probability of obtaining a low noise amplitude increases with the dwell time on a pixel. For short sweep times, the display approaches that of the sample detector since the dwell time on a pixel is only sufficient to obtain an instantaneous value.

- Autopoint detector

The Autopoint detector displays the maximum and minimum peak value at the same time. Both values are measured and their levels are displayed on the screen joint by a vertical line.

- Sample detector

The sample detector samples the logarithm of the IF envelope for each pixel of the trace only once and displays the resulting value. If the frequency span of the R&S FSUP is considerably higher than the resolution bandwidth ($\text{span/RBW} > 500$), there is no guarantee that useful signals will be detected. They are lost due to undersampling. This does not happen with noise because in this case it is not the instantaneous amplitude that is relevant but only the probability distribution.

- RMS detector

For each pixel of the trace, the RMS detector outputs the RMS value of the IF envelope for the frequency range assigned to each test point. It therefore measures noise power. The display for small signals is, however, the sum of signal power and noise power. For short sweep times, i.e. if only one uncorrelated sample value contributes to the RMS value measurement, the RMS detector is equivalent to the sample detector. If the sweep time is longer, more and more uncorrelated RMS values contribute to the RMS value measurement. The trace is, therefore, smoothed. The level of sinewave signals is only displayed correctly if the selected resolution bandwidth (RBW) is at least as wide as the frequency range which corresponds to a pixel in the trace. At a resolution bandwidth of 1 MHz, this means that the maximum frequency display range is 625 MHz.

- Average detector

For each pixel of the trace, the average detector outputs the average value of the linear IF envelope for the frequency range assigned to each test point. It therefore measures the linear average noise. The level of sinewave signals is only displayed correctly if the selected resolution bandwidth (RBW) is at least as wide as the frequency range which corresponds to a pixel in the trace. At a resolution bandwidth of 1 MHz, this means the maximum frequency display range is 625 MHz.

- Quasipeak detector

The quasipeak detector is a peak detector for EMI measurements with defined charge and discharge times. These times are defined in CISPR 16, the standard for equipment used to measure EMI emissions.

Measurement Example – Measuring the Level of the Internal Reference Generator at Low S/N Ratios

The example shows the different factors influencing the S/N ratio.

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Switch on the internal reference generator

- Press the *SETUP* key.
- Press the softkeys *SERVICE - INPUT CAL*.
The internal 128 MHz reference generator is on.
The R&S FSUP's RF input is off.

3. Set the center frequency to 128 MHz and the frequency span to 100 MHz.

- Press the *FREQ* key and enter 128 MHz.
- Press the *SPAN* key and enter 100 MHz.

4. Set the RF attenuation to 60 dB to attenuate the input signal or to increase the intrinsic noise.

- Press the *AMPT* key.
- Press the *RF ATTEN MANUAL* softkey and enter 60 dB.
The RF attenuation indicator is marked with an asterisk (*Att 60 dB) to show that it is no longer coupled to the reference level. The high input attenuation reduces the reference signal which can no longer be detected in noise.




Fig. 2-17 Sinewave signal with low S/N ratio. The signal is measured with the autopeak detector and is completely swamped by the intrinsic noise of the R&S FSUP.

5. To suppress noise spikes the trace can be averaged.

- Press the *TRACE* key.
- Press the *AVERAGE* softkey.
 The traces of consecutive sweeps are averaged. To perform averaging, the R&S FSUP automatically switches on the sample detector. The RF signal, therefore, can be more clearly distinguished from noise.




Fig. 2-18 RF sinewave signal with low S/N ratio if the trace is averaged.

6. Instead of trace averaging, a video filter that is narrower than the resolution bandwidth can be selected.

- Press the *CLEAR/WRITE* softkey in the trace menu.
- Press the *BW* key.

Press the *VIDEO BW MANUAL* softkey and enter *10 kHz*.
The RF signal can be more clearly distinguished from noise.




Fig. 2-19 RF sinewave signal with low S/N ratio if a smaller video bandwidth is selected.

7. By reducing the resolution bandwidth by a factor of 10, the noise is reduced by 10 dB.

- Press the *RES BW MANUAL* softkey and enter 300 kHz.
 The displayed noise is reduced by approx. 10 dB. The signal, therefore, emerges from noise by about 10 dB. Compared to the previous setting, the video bandwidth has remained the same, i.e. it has increased relative to the smaller resolution bandwidth. The averaging effect is, therefore, reduced by the video bandwidth. The trace will be noisier.




Fig. 2-20 Reference signal at a smaller resolution bandwidth

Noise Measurements

Noise measurements play an important role in spectrum analysis. Noise e.g. affects the sensitivity of radio communication systems and their components.

Noise power is specified either as the total power in the transmission channel or as the power referred to a bandwidth of 1 Hz. The sources of noise are, for example, amplifier noise or noise generated by oscillators used for the frequency conversion of useful signals in receivers or transmitters. The noise at the output of an amplifier is determined by its noise figure and gain.

The noise of an oscillator is determined by phase noise near the oscillator frequency and by thermal noise of the active elements far from the oscillator frequency. Phase noise can mask weak signals near the oscillator frequency and make them impossible to detect.

Measuring Noise Power Density

To measure noise power referred to a bandwidth of 1 Hz at a certain frequency, the R&S FSUP has an easy-to-use marker function. This marker function calculates the noise power density from the measured marker level.

Measurement Example – Measuring the Intrinsic Noise Power Density of the R&S FSUP at 1 GHz and Calculating the R&S FSUP's Noise Figure

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 1 GHz and the span to 1 MHz.

- Press the *FREQ* key and enter 1 GHz.
- Press the *SPAN* key and enter 1 MHz.

3. Switch on the marker and set the marker frequency to 1 GHz.

- Press the *MKR* key and enter 1 GHz.

4. Switch on the noise marker function.

- Press the *MEAS* key.
- Press the *NOISE MARKER* softkey.
The R&S FSUP displays the noise power at 1 GHz in dBm (1Hz).

Since noise is random, a sufficiently long measurement time has to be selected to obtain stable measurement results. This can be achieved by averaging the trace or by selecting a very small video bandwidth relative to the resolution bandwidth.

5. The measurement result is stabilized by averaging the trace

- Press the *TRACE* key.
- Press the *AVERAGE* softkey.
The R&S FSUP performs sliding averaging over 10 traces from consecutive sweeps. The measurement result becomes more stable.

Conversion to other reference bandwidths

The result of the noise measurement can be referred to other bandwidths by simple conversion. This is done by adding $10 \cdot \log(\text{BW})$ to the measurement result, BW being the new reference bandwidth.

Example

A noise power of -150 dBm (1 Hz) is to be referred to a bandwidth of 1 kHz.

$$P_{[1\text{kHz}]} = -150 + 10 \cdot \log(1000) = -150 + 30 = -120 \text{ dBm}(1 \text{ kHz})$$

Calculation method

The following method is used to calculate the noise power:

If the noise marker is switched on, the R&S FSUP automatically activates the sample detector. The video bandwidth is set to 1/10 of the selected resolution bandwidth (RBW).

To calculate the noise, the R&S FSUP takes an average over 17 adjacent pixels (the pixel on which the marker is positioned and 8 pixels to the left, 8 pixels to the right of the marker). The measurement result is stabilized by video filtering and averaging over 17 pixels.

Since both video filtering and averaging over 17 trace points is performed in the log display mode, the result would be 2.51 dB too low (difference between logarithmic noise average and noise power). The R&S FSUP, therefore, corrects the noise figure by 2.51 dB.

To standardize the measurement result to a bandwidth of 1 Hz, the result is also corrected by $-10 \cdot \log(\text{RBW}_{\text{noise}})$, with $\text{RBW}_{\text{noise}}$ being the power bandwidth of the selected resolution filter (RBW).

Detector selection

The noise power density is measured in the default setting with the sample detector and using averaging. Other detectors that can be used to perform a measurement giving true results are the average detector or the RMS detector. If the average detector is used, the linear video voltage is averaged and displayed as a pixel. If the RMS detector is used, the squared video voltage is averaged and displayed as a pixel. The averaging time depends on the selected sweep time ($=\text{SWT}/625$). An increase in the sweep time gives a longer averaging time per pixel and thus stabilizes the measurement result. The R&S FSUP automatically corrects the measurement result of the noise marker display depending on the selected detector (+1.05 dB for the average detector, 0 dB for the RMS detector). It is assumed that the video bandwidth is set to at least three times the resolution bandwidth. While the average or RMS detector is being switched on, the R&S FSUP sets the video bandwidth to a suitable value.

The Pos Peak, Neg Peak, Auto Peak and Quasipeak detectors are not suitable for measuring noise power density.

Determining the noise figure

The noise figure of amplifiers or of the R&S FSUP alone can be obtained from the noise power display. Based on the known thermal noise power of a 50Ω resistor at room temperature (-174 dBm (1Hz)) and the measured noise power P_{noise} the noise figure (NF) is obtained as follows:

$$\text{NF} = P_{\text{noise}} + 174 - g,$$

where g = gain of DUT in dB

Example:

The measured internal noise power of the R&S FSUP at an attenuation of 0 dB is found to be -155 dBm/1 Hz. The noise figure of the R&S FSUP is obtained as follows

$$\text{NF} = -155 + 174 = 17 \text{ dB}$$



Note

If noise power is measured at the output of an amplifier, for example, the sum of the internal noise power and the noise power at the output of the DUT is measured. The noise power of the DUT can be obtained by subtracting the internal noise power from the total power (subtraction of linear noise powers). By means of the following diagram, the noise level of the DUT can be estimated from the level difference between the total and the internal noise level.




Fig. 2-21 Correction factor for measured noise power as a function of the ratio of total power to the intrinsic noise power of the R&S FSUP.

Measurement of Noise Power within a Transmission Channel

Noise in any bandwidth can be measured with the channel power measurement functions. Thus the noise power in a communication channel can be determined, for example. If the noise spectrum within the channel bandwidth is flat, the noise marker from [“Measuring Noise Power Density” on page 2.36](#) can be used to determine the noise power in the channel by considering the channel bandwidth. If, however, phase noise and noise that normally increases towards the carrier is dominant in the channel to be measured, or if there are discrete spurious signals in the channel, the channel power measurement method must be used to obtain correct measurement results.

Measurement Example – Measuring the Intrinsic Noise of the R&S FSUP at 1 GHz in a 1.23 MHz Channel Bandwidth with the Channel Power Function

Test setup

The RF input of the R&S FSUP remains open-circuited or is terminated with 50 Ω .

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 1 GHz and the span to 2 MHz.

- Press the *FREQ* key and enter 1 GHz.
- Press the *SPAN* key and enter 2 MHz.

3. To obtain maximum sensitivity, set RF attenuation on the R&S FSUP to 0 dB.

- Press the *AMPT* key.
- Press the *RF ATTEN MANUAL* softkey and enter 0 dB.

4. Switch on and configure the channel power measurement.

- Press the *MEAS* key.
- Press the *CHAN PWR ACP* softkey.
The R&S FSUP activates the channel or adjacent channel power measurement according to the currently set configuration.
- Press the *CP/ACP CONFIG* \downarrow softkey.
The R&S FSUP enters the submenu for configuring the channel.
- Press the *CHANNEL BANDWIDTH* softkey and enter 1.23 MHz.
The R&S FSUP displays the 1.23 MHz channel as two vertical lines which are symmetrical to the center frequency.
- Press the *PREV* key.
The R&S FSUP returns to the main menu for channel and adjacent channel power measurement.

- Press the *ADJUST SETTINGS* softkey.
The settings for the frequency span, the bandwidth (RBW and VBW) and the detector are automatically set to the optimum values required for the measurement.




Fig. 2-22 Measurement of the R&S FSUP's intrinsic noise power in a 1.23 MHz channel bandwidth.

5. Stabilizing the measurement result by increasing the sweep time

- Press the *SWEEP TIME* softkey and enter 1 s.
By increasing the sweep time to 1 s, the trace becomes much smoother thanks to the RMS detector and the channel power measurement display is much more stable.

6. Referring the measured channel power to a bandwidth of 1 Hz

- Press the *CHAN PWR / Hz* softkey.
The channel power is referred to a bandwidth of 1 Hz. The measurement is corrected by $-10 \cdot \log(\text{ChanBW})$, with ChanBW being the channel bandwidth that was selected.

Method of calculating the channel power

When measuring the channel power, the R&S FSUP integrates the linear power which corresponds to the levels of the pixels within the selected channel. The R&S FSUP uses a resolution bandwidth which is far smaller than the channel bandwidth. When sweeping over the channel, the channel filter is formed by the passband characteristics of the resolution bandwidth (see Fig. 2-23).




Fig. 2-23 Approximating the channel filter by sweeping with a small resolution bandwidth

The following steps are performed:

- The linear power of all the trace pixels within the channel is calculated.

$$P_i = 10^{(L_i/10)}$$
 where
 P_i = power of the trace pixel i
 L_i = displayed level of trace point i
- The powers of all trace pixels within the channel are summed up and the sum is divided by the number of trace pixels in the channel.
- The result is multiplied by the quotient of the selected channel bandwidth and the noise bandwidth of the resolution filter (RBW).

Since the power calculation is performed by integrating the trace within the channel bandwidth, this method is also called the IBW method (Integration **B**andwidth method).

Bandwidth selection (RBW)

For channel power measurements, the resolution bandwidth (RBW) must be small compared to the channel bandwidth, so that the channel bandwidth can be defined precisely. If the resolution bandwidth which has been selected is too wide, this may have a negative effect on the selectivity of the simulated channel filter and result in the power in the adjacent channel being added to the power in the transmit channel. A resolution bandwidth equal to 1% to 3% of the channel bandwidth should, therefore, be selected. If the resolution bandwidth is too small, the required sweep time becomes too long and the measurement time increases considerably.

Detector selection

Since the power of the trace is measured within the channel bandwidth, only the sample detector and RMS detector can be used. These detectors provide measured values that make it possible to calculate the real power. The peak detectors (Pos Peak, Neg Peak and Auto Peak) are not suitable for noise power measurements as no correlation can be established between the peak value of the video voltage and power.

With the **sample detector**, a value (sample) of the IF envelope voltage is displayed at each trace pixel. Since the frequency spans are very large compared with the resolution bandwidth ($\text{span}/\text{RBW} > 500$), sinewave signals present in the noise might be lost, i.e. they are not displayed. This is not important for pure noise signals, however, since a single sample in itself is not important - it is the probability distribution of all measured values that counts. The number of samples for power calculation is limited to the number of trace pixels (625 for the R&S FSUP).

**Note**

To increase the repeatability of measurements, averaging is often carried out over several traces (*AVERAGE* softkey in the *TRACE* menu). This gives spurious results for channel power measurements (max. -2.51 dB for ideal averaging). Trace averaging should, therefore, be avoided.

With the **RMS detector**, the whole IF envelope is used to calculate the power for each trace pixel. The IF envelope is digitized using a sampling frequency which is at least five times the resolution bandwidth which has been selected. Based on the sample values, the power is calculated for each trace pixel using the following formula:

$$P_{\text{RMS}} = \sqrt{\frac{1}{N} \times \sum_{i=1}^N s_i^2}$$

s_i = linear digitized video voltage at the output of the A/D converter

N = number of A/D converter values per pixel of the trace

P_{RMS} = power represented by a trace pixel

When the power has been calculated, the power units are converted into decibels and the value is displayed as a trace pixel.

The number of A/D converter values, N , used to calculate the power, is defined by the sweep time. The time per trace pixel for power measurements is directly proportional to the selected sweep time. The RMS detector uses far more samples for power measurement than the sample detector, especially if the sweep time is increased. The measurement uncertainty can be reduced considerably. In the default setting, the R&S FSUP therefore uses the RMS detector to measure the channel power.

For both detectors (sample and RMS), the video bandwidth (VBW) must at least be three times the resolution bandwidth, so that the peak values of the video voltage are not cut off by the video filter. At smaller video bandwidths, the video signal is averaged and the power readout will be too small.

Sweep time selection

If the sample detector is used, it is best to select the smallest sweep time possible for a given span and resolution bandwidth. The minimum time is obtained if the setting is coupled. This means that the time per measurement is minimal. Extending the measurement time does not have any advantages as the number of samples for calculating the power is defined by the number of trace pixels in the channel.

When using the RMS detector, the repeatability of the measurement results can be influenced by the selection of sweep times. Repeatability is increased at longer sweep times.

Repeatability can be estimated from the following diagram:




Fig. 2-24 Repeatability of channel power measurements as a function of the number of samples used for power calculation

The curves in Fig. 2-24 indicate the repeatability obtained with a probability of 95% and 99% depending on the number of samples used.

The repeatability with 600 samples is ± 0.5 dB. This means that – if the sample detector and a channel bandwidth over the whole diagram (channel bandwidth = span) is used – the measured value lies within ± 0.5 dB of the true value with a probability of 99%.

If the RMS detector is used, the number of samples can be estimated as follows:

Since only uncorrelated samples contribute to the RMS value, the number of samples can be calculated from the sweep time and the resolution bandwidth.

Samples can be assumed to be uncorrelated if sampling is performed at intervals of $1/\text{RBW}$. The number of uncorrelated samples (N_{decorr}) is calculated as follows:

$$N_{\text{decorr}} = \text{SWT} \times \text{RBW}$$

The number of uncorrelated samples per trace pixel is obtained by dividing N_{decorr} by 625 (= pixels per trace).

Example


At a resolution bandwidth of 30 kHz and a sweep time of 100 ms, 3000 uncorrelated samples are obtained. If the channel bandwidth is equal to the frequency display range, i.e. all trace pixels are used for the channel power measurement, a repeatability of 0.2 dB with a confidence level of 99% is the estimate that can be derived from Fig. 2-24.

Measuring Phase Noise

The R&S FSUP has an easy-to-use marker function for phase noise measurements. This marker function indicates the phase noise of an RF oscillator at any carrier in dBc in a bandwidth of 1 Hz.

Measurement Example – Measuring the Phase Noise of a Signal Generator at a Carrier Offset of 10 kHz

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 100 MHz
Level: 0 dBm

Measurement using R&S FSUP

1. Set the R&S FSUP to the analyzer mode

- Press the *SPECTRUM* key.
R&S FSUP is in the analyzer mode.

2. Set the center frequency to 100 MHz and the span to 50 kHz

- Press the *FREQ* key and enter 100 MHz.
- Press the *SPAN* key and enter 50 kHz.

3. Set the R&S FSUP's reference level to 0 dBm (=signal generator level)

- Press the *AMPT* key and enter 0 dBm.

4. Enable phase noise measurement

- Press the *MKR FCTN* key.
- Press the *PHASE NOISE* ↓ softkey.

The R&S FSUP activates phase noise measurement. Marker 1 (=main marker) and marker 2 (=delta marker) are positioned on the signal maximum. The position of the marker is the reference (level and frequency) for the phase noise measurement. A horizontal line represents the level of the reference point and a vertical line the frequency of the reference point. Data entry for the delta marker is activated so that the frequency offset at which the phase noise is to be measured can be entered directly.

5. 10 kHz frequency offset for determining phase noise.

- Enter 10 kHz.
The R&S FSUP displays the phase noise at a frequency offset of 10 kHz. The magnitude of the phase noise in dBc/Hz is displayed in the delta marker output field at the top right of the screen (delta 2 [T1 PHN]).

6. Stabilize the measurement result by activating trace averaging.

- Press the TRACE key.
- Press the AVERAGE softkey.




Fig. 2-25 Measuring phase noise with the phase-noise marker function

The frequency offset can be varied by moving the marker with the rotary knob or by entering a new frequency offset as a number.

Measurements on Modulated Signals


If RF signals are used to transmit information, an RF carrier is modulated. Analog modulation methods such as amplitude modulation, frequency modulation and phase modulation have a long history and digital modulation methods are now used for modern systems. Measuring the power and the spectrum of modulated signals is an important task to assure transmission quality and to ensure the integrity of other radio services. This task can be performed easily with a Signal Source Analyzer. Modern Signal Source Analyzers also provide the test routines that are essential to simplify complex measurements.

Measurements on AM Signals

The R&S FSUP detects the RF input signal and displays the magnitudes of its components as a spectrum. AM modulated signals are also demodulated by this process. The AF voltage can be displayed in the time domain if the modulation sidebands are within the resolution bandwidth. In the frequency domain, the AM sidebands can be resolved with a small bandwidth and can be measured separately. This means that the modulation depth of a carrier modulated with a sinewave signal can be measured. Since the dynamic range of a Signal Source Analyzer is very wide, even extremely small modulation depths can be measured accurately. The R&S FSUP has a test routine which measures the modulation depth in %.

Measurement Example 1 – Displaying the AF of an AM Signal in the Time Domain

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 100 MHz
Level: 0 dBm
Modulation: 50 % AM, 1 kHz AF

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 100 MHz and the span to 0 kHz

- Press the *FREQ* key and enter *100 MHz*.
- Press the *SPAN* key and enter *0 Hz*.

3. Set the reference level to +6 dBm and the display range to linear

- Press the *AMPT* key and enter 6 dBm.
- Press the *RANGE LINEAR* softkey.

4. Use the video trigger to trigger on the AF signal in order to obtain a stationary display

- Press the *TRIG* key.
- Press the *VIDEO* softkey.
The video trigger level is set to 50% if the instrument is switched on for the first time. The trigger level is displayed as a horizontal line across the graph. The R&S FSUP displays the 1 kHz AF signal stably in the time domain.




Fig. 2-26 Measuring the AF signal from a 1 kHz AM carrier


The AM/FM demodulator in the R&S FSUP can be used to output the AF by means of a loudspeaker.

5. Switch on the internal AM demodulator

- Press the *MKR FCTN* key.
- Press the *MKR DEMOD* softkey.
The R&S FSUP switches the AM demodulator on automatically.
- Turn up volume control.
A 1 kHz tone is output by the loudspeaker.

Measurement Example 2 – Measuring the Modulation Depth of an AM Carrier in the Frequency Domain

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 100 MHz
Level: -30 dBm
Modulation: 50 % AM, 1 kHz AF

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 100 MHz and the span to 0 kHz

- Press the *FREQ* key and enter 100 MHz.
- Press the *SPAN* key and enter 5 kHz.

3. Activate the marker function for AM depth measurement

- Press the *MEAS* key.
- Press the *MODULATION DEPTH* softkey.
The R&S FSUP automatically positions a marker on the carrier signal in the middle of the graph and one delta marker on each of the lower and upper AM sidebands. The R&S FSUP calculates the AM modulation depth from the ratios of the delta marker levels to the main marker level and outputs the numerical value in the marker info field




Fig. 2-27 Measurement of AM modulation depth. The modulation depth is indicated by MDEPTH = 49.345 %. The frequency of the AF signal is indicated by the delta markers


Measurements on FM Signals

Since Signal Source Analyzers only display the magnitude of signals by means of the envelope detector, the modulation of FM signals cannot be directly measured as is the case with AM signals. With FM signals, the voltage at the output of the envelope detector is constant as long as the frequency deviation of the signal is within the flat part of the passband characteristic of the resolution filter which has been selected. Amplitude variations can only occur if the current frequency lies on the falling edge of the filter characteristic. This effect can be used to demodulate FM signals. The center frequency of the R&S FSUP is set in a way that the nominal frequency of the test signal is on the filter edge (below or above the center frequency). The resolution bandwidth and the frequency offset are selected in a way that the current frequency is on the linear part of the filter slope. The frequency variation of the FM signal is then transformed into an amplitude variation which can be displayed in the time domain.

The R&S FSUP's analog 5th order filters with frequencies from 200 kHz to 3 MHz have a good filter-slope linearity, if the frequency of the R&S FSUP is set to 1.2 times the filter bandwidth below or above the frequency of the transmit signal. The useful range for FM demodulation is then almost equal to the resolution bandwidth.

Measurement Example – Displaying the AF of an FM Carrier

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 100 MHz
Level: -30 dBm
Modulation: FM 0 kHz deviation (i.e., FM = off), 1 kHz AF

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 99.64 MHz and the span to 300 kHz.

- Press the *FREQ* key and enter 99.64 MHz.
- Press the *SPAN* key and enter 300 kHz.

3. Set a resolution bandwidth of 300 kHz.

- Press the *BW* key.
- Press the *RES BW MANUAL* softkey and enter 300 kHz.

4. Set a display range of 20 dB and shift the filter characteristics to the middle of the display.

- Press the *AMPT* key.
- Press the *RANGE LOG MANUAL* softkey and enter 20 dB.
- Press the *NEXT* key.
- Set the *GRID* softkey to *REL*.
- Press the *PREV* softkey.
- Using the rotary knob, shift the reference level so that the filter edge intersects the -10 dB level line at the center frequency.

The slope of the 300 kHz filter is displayed. This corresponds to the demodulator characteristics for FM signals with a slope of approx. 5 dB/100 kHz.




Fig. 2-28 Filter edge of a 300 kHz filter used as an FM-discriminator characteristic

5. Set an FM deviation of 100 kHz and an AF of 1 kHz on the signal generator

6. Set a frequency deviation of 0 Hz on the R&S FSUP

- Press the *SPAN* key.
 - Press the *ZERO SPAN*.
- The demodulated FM signal is displayed. The signal moves across the screen.

7. Creating a stable display by video triggering

- Press the TRIG key.
 - Press the VIDEO softkey.
- A stationary display is obtained for the FM AF signal

Result: (-10 ±5) dB; this means that a deviation of 100 kHz is obtained if the demodulator characteristic slope is 5 dB/100 kHz




Fig. 2-29 Demodulated FM signal

Measuring Channel Power and Adjacent Channel Power

Measuring channel power and adjacent channel power is one of the most important tasks in the field of digital transmission for a Signal Source Analyzer with the necessary test routines. While, theoretically, channel power could be measured at highest accuracy with a power meter, its low selectivity means that it is not suitable for measuring adjacent channel power as an absolute value or relative to the transmit channel power. The power in the adjacent channels can only be measured with a selective power meter.

A Signal Source Analyzer cannot be classified as a true power meter, because it displays the IF envelope voltage. However, it is calibrated such as to correctly display the power of a pure sinewave signal irrespective of the selected detector. This calibration is not valid for non-sinusoidal signals. Assuming that the digitally modulated signal has a Gaussian amplitude distribution, the signal power within the selected resolution bandwidth can be obtained using correction factors. These correction factors are normally used by the R&S FSUP's internal power measurement routines in order to determine the signal power from IF envelope measurements. These factors are valid if and only if the assumption of a Gaussian amplitude distribution is correct.

Apart from this common method, the R&S FSUP also has a true power detector, i.e. an RMS detector. It correctly displays the power of the test signal within the selected resolution bandwidth irrespective of the amplitude distribution, without additional correction factors being required. With an absolute measurement uncertainty of < 0.3 dB and a relative measurement uncertainty of < 0.1 dB (each with a confidence level of 95%), the R&S FSUP comes close to being a true power meter.

There are two possible methods for measuring channel and adjacent channel power with a Signal Source Analyzer:

The IBW method (**I**ntegration **B**andwidth **M**ethod) in which the R&S FSUP measures with a resolution bandwidth that is less than the channel bandwidth and integrates the level values of the trace versus the channel bandwidth. This method is described in section [“Noise Measurements” on page 2.36](#)


Measurement using a channel filter.

In this case, the R&S FSUP makes measurements in the time domain using an IF filter that corresponds to the channel bandwidth. The power is measured at the output of the IF filter. Until now, this method has not been used for Signal Source Analyzers, because channel filters were not available and the resolution bandwidths, optimized for the sweep, did not have a sufficient selectivity. The method was reserved for special receivers optimized for a particular transmission method.

The R&S FSUP has test routines for simple channel and adjacent channel power measurements. These routines give quick results without any complex or tedious setting procedures.

Measurement Example 1 – ACPR Measurement on an IS95 CDMA Signal

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 850 MHz
Level: 0 dBm
Modulation: CDMA IS 95

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 850 MHz and frequency deviation to 4 MHz.

- Press the *FREQ* key and enter 850 MHz.

3. Set the reference level to +10 dBm.

- Press the *AMPT* key and enter 10 dBm.

4. Configuring the adjacent channel power for the CDMA IS95 reverse link.

- Press the *MEAS* key.
- Press the *CHAN PWR ACP* ↓ softkey.
- Press the *CP/ACP STANDARD* softkey.

From the list of standards, select *CDMA IS95A REV* using the rotary knob or the cursor down key below the rotary knob and press *ENTER*.

The R&S FSUP sets the channel configuration according to the IS95 standard for mobile stations with 2 adjacent channels above and below the transmit channel. The spectrum is displayed in the upper part of the screen, the numeric values of the results and the channel configuration in the lower part of the screen. The various channels are represented by vertical lines on the graph.

The frequency span, resolution bandwidth, video bandwidth and detector are selected automatically to give correct results. To obtain stable results - especially in the adjacent channels (30 kHz bandwidth) which are narrow in comparison with the transmission channel bandwidth (1.23 MHz) - the RMS detector is used.

5. Set the optimal reference level and RF attenuation for the applied signal level.

- Press the *ADJUST REF LVL* softkey.

The R&S FSUP sets the optimal RF attenuation and the reference level based on the transmission channel power to obtain the maximum dynamic range. The following figure shows the result of the measurement.




Fig. 2-30 Adjacent channel power measurement on a CDMA IS95 signal

The repeatability of the results, especially in the narrow adjacent channels, strongly depends on the measurement time since the dwell time within the 10 kHz channels is only a fraction of the complete sweep time. A longer sweep time may increase the probability that the measured value converges to the true value of the adjacent channel power, but this increases measurement time.

To avoid long measurement times, the R&S FSUP measures the adjacent channel power in the time domain (FAST ACP). In the FAST ACP mode, the R&S FSUP measures the power of each channel at the defined channel bandwidth, while being tuned to the center frequency of the channel in question. The digital implementation of the resolution bandwidths makes it possible to select a filter characteristics that is precisely tailored to the signal. In case of CDMA IS95, the power in the useful channel is measured with a bandwidth of 1.23 MHz and that of the adjacent channels with a bandwidth of 30 kHz. Therefore the R&S FSUP jumps from one channel to the other and measures the power at a bandwidth of 1.23 MHz or 30 kHz using the RMS detector. The measurement time per channel is set with the sweep time. It is equal to the selected measurement time divided by the selected number of channels. The five channels from the above example and the sweep time of 100 ms give a measurement time per channel of 20 ms.

Compared to the measurement time per channel given by the span (= 5.1 MHz) and sweep time (= 100 ms, equal to 0.600 ms per 30 kHz channel) used in the example, this is a far longer dwell time on the adjacent channels (factor of 12). In terms of the number of uncorrelated samples this means $20000/33 \mu\text{s} = 606$ samples per channel measurement compared to $600/33 \mu\text{s} = 12.5$ samples per channel measurement.

Repeatability with a confidence level of 95% is increased from ± 1.4 dB to ± 0.38 dB as shown in Fig. 2-24. For the same repeatability, the sweep time would have to be set to 1.2 s with the integration method. The following figure shows the standard deviation of the results as a function of the sweep time.




Fig. 2-31 Repeatability of adjacent channel power measurement on IS95-standard signals if the integration bandwidth method is used

6. Switch to Fast ACP to increase the repeatability of results.

- Press the *CP/ACP CONFIG* ↓ softkey.
- Set the *FAST ACP* softkey to *ON*.
- Press the *ADJUST REF LVL* softkey.

The R&S FSUP measures the power of each channel in the time domain. The trace represents power as a function of time for each measured channel (see Fig. 2-32). The numerical results from consecutive measurements are much more stable.




Fig. 2-32 Measuring the channel power and adjacent channel power ratio for IS95 signals in the time domain (Fast ACP)

The following figure shows the repeatability of power measurements in the transmit channel and of relative power measurements in the adjacent channels as a function of sweep time. The standard deviation of measurement results is calculated from 100 consecutive measurements as shown in Fig. 2-31. Take scaling into account if comparing power values.




Fig. 2-33 Repeatability of adjacent channel power measurements on IS95 signals in the Fast ACP mode



Note on adjacent channel power measurements on IS95 base-station signals

When measuring the adjacent channel power of IS95 base-station signals, the frequency spacing of the adjacent channel to the nominal transmit channel is specified as ± 750 kHz. The adjacent channels are, therefore, so close to the transmit channel that the power of the transmit signal leaks across and is also measured in the adjacent channel if the usual method using the 30 kHz resolution bandwidth is applied. The reason is the low selectivity of the 30 kHz resolution filter. The resolution bandwidth, therefore, must be reduced considerably, e.g. to 3 kHz to avoid this. This causes very long measurement times (factor of 100 between a 30 kHz and 3 kHz resolution bandwidth).

This effect is avoided with the time domain method which uses steep IF filters. The 30 kHz channel filter implemented in the R&S FSUP has a very high selectivity so that even with a ± 750 kHz spacing to the transmit channel the power of the useful modulation spectrum is not measured.

The following figure shows the passband characteristics of the 30 kHz channel filter in the R&S FSUP.





Fig. 2-34 Frequency response of the 30 kHz channel filter for measuring the power in the IS 95 adjacent channel

Measurement Example 2 – Measuring the Adjacent Channel Power of an IS136 TDMA Signal

Test setup



Note

As the modulation spectrum of the IS136 signal leaks into the adjacent channel, it makes a contribution to the power in the adjacent channel. Exact tuning of the R&S FSUP to the transmit frequency is therefore critical. If tuning is not precise, the adjacent channel power ratios in the lower and upper adjacent channels become asymmetrical. The R&S FSUP's frequency and the generator frequency are therefore synchronized.

Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 850 MHz
 Level: -20 dBm
 Modulation: IS136/NADC

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set up the R&S FSUP for synchronization to an external reference frequency.

- Press the *SETUP* key.
- Set the *REFERENCE* softkey to *EXT*.

3. Set the center frequency to 850 MHz.

- Press the *FREQ* key and enter *850 MHz*.

4. Configure adjacent channel power measurement for IS136 signals.

- Press the *MEAS* key.
- Press the *CHAN PWR ACP* ↓ softkey.

- Press the *CP/ACP STANDARD* softkey.
- Select *NADC IS136* from the list of standards and press *ENTER*.
The R&S FSUP performs the power measurement in 5 channels (in the useful channel and in the two upper and two lower adjacent channels).

5. Setting the optimum reference level and RF attenuation for the measurement

- Press the *ADJUST REF LEVEL* softkey.
The R&S FSUP sets the optimum RF attenuation and the optimum reference level on the basis of the measured channel power.



Fig. 2-35 Measuring the relative adjacent channel power of an NADC signal in each of the two adjacent channels below and above the transmit channel.

To increase repeatability – especially in the adjacent channels – the R&S FSUP's Fast ACP routine is recommended.

6. Switching on the Fast ACP routine.

- Press the *CP/ACP CONFIG* ↓ softkey
- Set the *FAST ACP* softkey to *ON*.
- Press the *ADJUST REF LEVEL* softkey.
The R&S FSUP makes consecutive measurements on the 5 channels in the zero span mode using the receive filter specified in IS 136 to define the resolution bandwidth. The power in each channel is displayed on the graph as a function of time.




Fig. 2-36 Measuring adjacent channel power in time domain (Fast ACP)

As the resolution bandwidth is much wider than the one used for the integration method, the results are much more stable when compared at the same sweep time.

Repeatability can be influenced by the selected sweep time. The results become much more stable if long sweep times are selected. Since the amplitude distribution is different in different channels (part of the modulation spectrum falls within the first adjacent channel), the repeatability depends on the spacing of the measured channel from the transmit channel.

Fig. 2-37 shows the standard deviation of results in the different channels as a function of the selected sweep time. The standard deviation for the various sweep times was recorded using a signal generator as a source. With real DUTs the amplitude distributions in adjacent channels may be different so that the standard deviation could differ from that shown in Fig. 2-33. Standard deviation of the results of Fast ACP measurement as a function of selected sweep time evaluated from 100 measurements per sweep time. To evaluate the correct measuring time for time-critical measurements at a given standard deviation, the standard deviation of the ACP values at the output of the real DUT must be determined.





Fig. 2-37 Standard deviation of the results of Fast ACP measurement as a function of selected sweep time evaluated from 100 measurements per sweep time

Measurement Example 3 – Measuring the Modulation Spectrum in Burst Mode with the Gated Sweep Function

Since transmission systems compliant to IS136 use a TDMA method, the adjacent channel power must also be measured in burst mode. An IS136 TDMA frame is divided into 6 time slots. Two of these slots are assigned to a subscriber. This means that the ratio of transmit time to off-time for IS136 mobile phones is only 1:3 (e.g. time slots 1 and 4)

The R&S FSUP supports the measurement of the adjacent channel power in the TDMA mode with the Gated Sweep function.

Test setup with the R&S Signal Generator SMIQ



The R&S SMIQ has to be equipped with options R&S SMIQ-B10 or R&S SMIQ-B20 (modulation coder) and R&S SMIQ-B11 (data generator).

Option R&S SMIQ-Z5 is required to trigger the R&S FSUP. This option is connected to the R&S SMIQ's parallel output port. The BNC output Trigger 1 of the R&S SMIQ-Z5 provides a TTL trigger signal on the rising edge of the IS136 burst, which is used to start the R&S FSUP sweep in the Gated Sweep mode.

**Note**

The R&S FSUP's IF power trigger is not suitable for IS136. It triggers on every level edge of the input signal. Since the modulation of the IS136 signal causes level dips even during the transmit burst, there is no way of ensuring that the R&S FSUP is only triggered on the burst edge.

Settings on signal generator R&S SMIQ

Switch the signal generator to the IS136 burst mode (time slots 1 and 4 are switched on, the other time slots are switched off).

The R&S SMIQ is set as follows to generate the signal:

1. Press the *PRESET* key.
2. Press the *FREQ* key and enter 850 MHz.
3. Press the *LEVEL* key and enter -20 dBm.
4. Press the *RETURN* key.
5. Select *DIGITAL STANDARD* using the rotary knob and press the *SELECT* key.
6. Select *NADC* using the rotary knob and press the *SELECT* key.
7. Press the *SELECT* key.
8. Select *ON* using the rotary knob and press the *SELECT* key.
9. Press the *RETURN* key.
10. Keep turning the rotary knob until *SAVE/RECALL FRAME* appears in the list and select the menu item *SAVE/RECALL FRAME* using the *SELECT* key.
11. The cursor is set to *GET PREDEFINED FRAME*.
12. Press the *SELECT* key.
13. Select *UP1TCH* using the rotary knob and press the *SELECT* key.

In the following operating sequence for the R&S FSUP, it is assumed that steps 1 to 6 of "[Measurement Example 2 – Measuring the Adjacent Channel Power of an IS136 TDMA Signal](#)" on page 2.59 have already been performed.

Configuring the Gated Sweep function on the R&S FSUP

- > Press the *TRIG* key.
- > Press the *GATED TRIGGER* softkey.
- > Press the *EXTERN* softkey.
- > Press the *GATE SETTINGS* ↓ softkey.
The R&S FSUP switches to time domain measurement so that the setting of the Gated Sweep parameters can be checked visually.
- > Press the *SWEEPTIME* softkey and enter *10 ms*.
Exactly one TDMA burst will be displayed.

- > Press the *GATE DELAY* softkey and enter 2 ms or set the Gate Delay using the rotary knob so that the burst is reliably detected.
- > Press the *GATE LENGTH* softkey and enter 5 ms or set the vertical line for the gate length using the rotary knob so that the burst is reliably detected.




Fig. 2-38 Setting the parameters Gate Delay and Gate Length in time domain. The time interval required to measure the spectrum is indicated by two vertical lines.

- > Press the *PREV* key.
The R&S FSUP now performs the ACP measurement only during the switch-on phase of the TDMA burst. The measurement is stopped during the switch-off phase.



Note

The selected sweep time is the net sweep time, i.e. the time during which the R&S FSUP is actually measuring. The complete frame of an IS136 signal takes 40 ms. In the above example, measurement only takes place for 2x5 ms within a frame. The R&S FSUP is therefore only measuring for 25 % of the frame duration. The total measuring time is therefore four times that for the CW mode.

Measurement Example 4 – Measuring the Transient Spectrum in Burst Mode with the Fast ACP function

In addition to the modulation spectrum or adjacent channel power from the modulation of the RF carrier, the spectrum or adjacent channel power generated by burst edges is also to be measured in TDMA systems. The spectrum is a pulse spectrum and must be measured with the peak detector. With the usual IBW method, only the power of the continuously modulated signal can be measured properly. Even if the modulation spectrum is transmitted in the TDMA mode, the measurement of the modulation spectrum will work because the burst edges are blanked out for the measurement by means of the Gated Sweep function. The R&S FSUP performs measurements only if the modulation spectrum is continuous when the burst is on.

However, the IBW method fails for the spectrum created by the burst edges. As the measurement is carried out with resolution bandwidths that are very small compared to the signal bandwidth, a spurious amplitude distribution is obtained in the defined measurement channel because of the resolution bandwidth. The small resolution bandwidth cannot settle to the peak amplitudes of the test signal. This problem is avoided in the R&S FSUP by performing time domain measurements with the root raised cosine filter specified in the IS136 standard.

If the peak detector is used instead of the default RMS detector (which is selected when the standard is selected), the true adjacent channel power generated by the burst edges can also be measured.

Test setup

The test setup for this example and the settings for R&S SMIQ are identical to those described in [“Measurement Example 3 – Measuring the Modulation Spectrum in Burst Mode with the Gated Sweep Function”](#) on page 2.62.

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Synchronize the R&S FSUP to an external reference frequency.

- Press the *SETUP* key.
- Set the *REFERENCE* softkey to *EXT*.

3. Set the center frequency to 850 MHz

- Press the *FREQ* key and enter *850 MHz*.

4. Configure the adjacent channel power measurement for IS136 signals in Fast ACP mode.

- Press the *MEAS* key.
- Press the *CHAN PWR ACP* ↓ softkey.
- Press the *CP/ACP STANDARD* softkey.
- Select *NADC IS136* from the list of standards and press *ENTER*.
- Press the *CP/ACP CONFIG* ↓ softkey.
- Set the *FAST ACP* softkey to *ON*.
The R&S FSUP performs the power measurement in 5 channels (in the useful channel and in the two upper and lower adjacent channels).

5. Set the optimum reference level and RF attenuation for the measurement.

- Press the *ADJUST REF LEVEL* softkey.
The R&S FSUP sets the optimum RF attenuation and the optimum reference level on the basis of the measured channel power.

6. Select the peak detector and increase the sweep time to 10 s.

- Press the *TRACE* key.
- Press the *DETECTOR* softkey.
- Press the *DETECTOR MAX PEAK* softkey.
- Press the *SWEEP* key.
- Press the *SWEEP TIME* softkey and enter 10 s.
The R&S FSUP measures the adjacent channel power generated by the burst edges and the modulation.




Fig. 2-39 Adjacent channel power due to modulation spectrum and transient spectrum


**Note**

The peak power display depends on the selected sweep time. The longer the sweep time, the higher the probability of measuring the highest peak amplitude of the signal.

With shorter sweep times, level dips can be seen in the time domain traces. These level dips come from the burst characteristic of the signal. The numerical results, however, indicate the peak amplitudes during the measurement in the corresponding channel.

Measurement Example 5 – Measuring the Adjacent Channel Power of a W-CDMA Uplink Signal

Test setup



Settings on the signal generator (e.g. R&S SMIQ)

Frequency: 1950 MHz
Level: 4 dBm
Modulation: 3 GPP W-CDMA Reverse Link

Measurement with the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Set the center frequency to 1950 MHz.

- Press the *FREQ* key and enter *1950 MHz*.

3. Switch on the ACP measurement for W-CDMA.

- Press the *MEAS* key.
- Press the *CHAN PWR ACP* ↓ softkey.
- Press the *CP/ACP STANDARD* softkey.

- From the list of standards, select *W-CDMA 3GPP REV* using the rotary knob or the cursor down key below the rotary knob and press *ENTER*.
The R&S FSUP sets the channel configuration to the 3GPP W-CDMA standard for mobiles with two adjacent channels above and below the transmit channel. The frequency span, the resolution and video bandwidth and the detector are automatically set to the correct values. The spectrum is displayed in the upper part of the screen and the channel power, the level ratios of the adjacent channel powers and the channel configuration in the lower part of the screen. The individual channels are displayed as vertical lines on the graph.

4. Set the optimum reference level and the RF attenuation for the applied signal level.

- Press the *ADJUST REF LEVEL* softkey.
The R&S FSUP sets the optimum RF attenuation and the reference level for the power in the transmission channel to obtain the maximum dynamic range. The following figure shows the result of the measurement:




Fig. 2-40 Measuring the relative adjacent channel power on a W-CDMA uplink signal

5. Measuring adjacent channel power with the Fast ACP method.

- Press the *CP/ACP CONFIG* softkey.
- Set *FAST ACP* softkey to *ON*.

- Press the *ADJUST REF LVL* softkey.

The R&S FSUP measures the power of the individual channels in the time domain. A root raised cosine filter with the parameters $\alpha = 0.22$ and chip rate 3.84 Mcps (= receive filter for 3GPP W-CDMA) is used as the channel filter.




Fig. 2-41 Measuring the adjacent channel power of a W-CDMA signal with the Fast ACP method



Note

With W-CDMA, the R&S FSUP's dynamic range for adjacent channel measurements is limited by the 14-bit A/D converter. The greatest dynamic range is, therefore, obtained with the IBW method.

Optimum Level Setting for ACP Measurements on W-CDMA Signals

The dynamic range for ACP measurements is limited by the thermal noise floor, the phase noise and the intermodulation (spectral regrowth) of the R&S FSUP. The power values produced by the R&S FSUP due to these factors accumulate linearly. They depend on the applied level at the input mixer. The three factors are shown in the figure below for the adjacent channel (5 MHz carrier offset)




Fig. 2-42 The R&S FSUP's dynamic range for adjacent channel power measurements on W-CDMA uplink signals is a function of the mixer level.

The level of the W-CDMA signal at the input mixer is shown on the horizontal axis, i.e. the measured signal level minus the selected RF attenuation. The individual components which contribute to the power in the adjacent channel and the resulting relative level (total ACPR) in the adjacent channel are displayed on the vertical axis. The optimum mixer level is -10 dBm. The relative adjacent channel power (ACPR) at an optimum mixer level is $-77,5$ dBc. Since, at a given signal level, the mixer level is set in 5 dB steps with the 5 dB RF attenuator, the optimum 5 dB range is shown in the figure: it spreads from -13 dBm to -8 dBm. The obtainable dynamic range in this range is 76 dB.

To set the attenuation parameter manually, the following method is recommended:

- Set the RF attenuation so that the mixer level (= measured channel power – RF attenuation) is between -13 dBm and -8 dBm.
- Set the reference level to the largest possible value where no overload (IFOVLD) is indicated.

This method is automated with the R&S FSUP's ADJUST REF LEVEL function. Especially in remote control mode, e.g. in production environments, it is best to correctly set the attenuation parameters prior to the measurement, as the time required for automatic setting can be saved.



Note

To measure the R&S FSUP's intrinsic dynamic range for W-CDMA adjacent channel power measurements, a filter which suppresses the adjacent channel power is required at the output of the transmitter. A SAW filter with a bandwidth of 4 MHz, for example, can be used.

Amplitude Distribution Measurements

If modulation types that do not have a constant envelope in the time domain are used, the transmitter has to handle peak amplitudes that are greater than the average power. This includes all modulation types that involve amplitude modulation - QPSK for example. CDMA transmission modes in particular may have power peaks that are large compared to the average power.

For signals of this kind, the transmitter must provide large reserves for the peak power to prevent signal compression and thus an increase of the bit error rate at the receiver.

The peak power, or the crest factor of a signal is therefore an important transmitter design criterion. The crest factor is defined as the peak power / mean power ratio or, logarithmically, as the peak level minus the average level of the signal.

To reduce power consumption and cut costs, transmitters are not designed for the largest power that could ever occur, but for a power that has a specified probability of being exceeded (e.g. 0.01%).

To measure the amplitude distribution, the R&S FSUP has simple measurement functions to determine both the APD = **A**mplitude **P**robability **D**istribution and CCDF = **C**omplementary **C**umulative **D**istribution Function.



Note

In the literature, APD is also used for the probability of amplitude violation. This is the complimentary function to the APD function of R&S FSUP. The term PDF (=Probability Density Function) which is frequently used in the literature corresponds to the APD function of R&S FSUP.

In the APD display mode, the probability of occurrence of a certain level is plotted against the level.

In the CCDF display mode, the probability that the mean signal power will be exceeded is shown in percent.

Measurement Example – Measuring the APD and CCDF of White Noise Generated by the R&S FSUP

1. Set the R&S FSUP to the analyzer mode.

- Press the *SPECTRUM* key.
The R&S FSUP is in the analyzer mode.

2. Configure the R&S FSUP for APD measurement

- Press the *AMPT* key and enter *-60 dBm*.
The R&S FSUP's intrinsic noise is displayed at the top of the screen.
- Press the *MEAS* key.
- Press the *SIGNAL STATISTIC* ↓ softkey.

- Set the APD softkey to ON.

The R&S FSUP sets the frequency span to 0 Hz and measures the amplitude probability distribution (APD). The number of uncorrelated level measurements used for the measurement is 100000. The mean power and the peak power are displayed in dBm. The crest factor (peak power – mean power) is output as well (see Fig. 2-43).




Fig. 2-43 Amplitude probability distribution of white noise

3. Switch to the CCDF display mode.

- Set the CCDF softkey to ON

The APD measurement is switched off and the CCDF display mode is switched on.




Fig. 2-44 The CCDF of white noise

The CCDF trace indicates the probability that a level will exceed the mean power. The level above the mean power is plotted along the x-axis of the graph. The origin of the axis corresponds to the mean power level. The probability that a level will be exceeded is plotted along the y-axis.

4. Bandwidth selection

If the amplitude distribution is measured, the resolution bandwidth must be set in a way that the complete spectrum of the signal to be measured falls within the bandwidth. This is the only way of ensuring that all the amplitudes will pass through the IF filter without being distorted. If the selected resolution bandwidth is too small for a digitally modulated signal, the amplitude distribution at the output of the IF filter becomes a Gaussian distribution according to the central limit theorem and so corresponds to a white noise signal. The true amplitude distribution of the signal therefore cannot be determined.

A video bandwidth which is large in comparison to the resolution bandwidth ($\geq 3 \times \text{RBW}$) must be selected. This ensures that the amplitude peaks of the signal are not smoothed by the lowpass effect of the video filter. The video bandwidth is set automatically during statistics measurements.

Since the video bandwidth of the R&S FSUP is limited to 10 MHz, lowpass filtering occurs during measurements with a resolution bandwidth of 10 MHz. Additional band-limiting occurs at a resolution bandwidth of 10 MHz due to the lowpass filtering at the output of the log amplifier. The latter limits the video signal to a bandwidth of 8 MHz in order to obtain sufficient suppression of the 20.4 MHz IF. The level range of the signal amplitudes, e.g. during APD white-noise measurements, is smaller. For broadband-modulated signals such as W-CDMA signals, the effect depends on the bandwidth occupied by the signal. At a signal bandwidth of 4 MHz, the amplitude distribution can be measured correctly with the effective video bandwidth.

5. Selecting the number of samples

For statistics measurements with the R&S FSUP, the number of samples N_{Samples} is entered for statistical evaluation instead of the sweep time. Since only statistically independent samples contribute to statistics, the measurement or sweep time is calculated automatically. It is indicated on the R&S FSUP display. The samples are statistically independent if the time difference is at least $1/\text{RBW}$. The sweep time SWT is, therefore, expressed as follows:

$$\text{SWT} = N_{\text{Samples}} / \text{RBW}$$

3 Manual Operation

For details refer to the Quick Start Guide, chapter 4, "Basic Operation".

4 Instrument Functions

Introduction	4.4
R&S FSUP Initial Configuration – PRESET Key	4.5
Mode Selection – Hotkey Bar	4.8
Return to Manual Operation– LOCAL Menu	4.10
Phase Noise Mode	4.11
Menus Overview	4.11
QUICKSET Hotkey Menu	4.12
SETTINGS Hotkey Menu	4.17
Sweep Settings – SWEEP Key	4.58
Selection and Setting of Traces – TRACE Key	4.59
Marker Functions – MKR Key	4.64
Assigning Markers to Traces – MKR-> Key	4.66
Selection of the Measurement Function – MEAS Key	4.69
Setup of Limit Lines – LINES Key	4.76
Instrument Setup and Interface Configuration - SETUP Key	4.80
Analyzer Mode	4.82
QUICKSET Hotkey Menu	4.83
Frequency and Span Selection – FREQ Key	4.85
Setting the Frequency Span – SPAN Key	4.90
Level Display Setting and RF Input Configuration – AMPT Key	4.92
Electronic Attenuator	4.96
Setting the Bandwidths and Sweep Time – BW Key	4.97
Filter Types	4.103
List of Available Channel Filters	4.104
Sweep Settings – SWEEP Key	4.107
Triggering the Sweep – TRIG Key	4.110
Selection and Setting of Traces – TRACE Key	4.118
Selection of Trace Functions	4.118
Selection of Detector	4.127
Mathematical Functions for Traces	4.131
Recording the Correction Data – CAL Key	4.132
Markers and Delta Markers – MKR Key	4.134
Frequency Measurement with the Frequency Counter	4.137

Marker Functions – MKR FCTN Key	4.141
Activating the Markers	4.142
Measurement of Noise Density	4.142
Phase Noise Measurement	4.144
Measurement of the Filter or Signal Bandwidth	4.146
Measurement of a Peak List	4.147
Selecting the Trace	4.149
Change of Settings via Markers – MKR-> Key	4.150
Power Measurements – MEAS Key	4.157
Power Measurement in Time Domain	4.158
Channel and Adjacent-Channel Power Measurements	4.164
Setting the Channel Configuration	4.173
Measurement of Signal Amplitude Statistics	4.187
Measurement of Carrier/Noise Ratio C/N and C/No	4.193
Measurement of the AM Modulation Depth	4.195
Measurement of the Third Order Intercept (TOI)	4.196
Harmonic Measurement	4.199
Measuring Spurious Emissions	4.201
Basic Settings	4.208
Setup of Limit Lines and Display Lines – LINES Key	4.208
Selection of Limit Lines	4.209
Entry and Editing of Limit Lines	4.213
Display Lines	4.218
Configuration of Screen Display – DISP Key	4.221
Instrument Setup and Interface Configuration – SETUP Key	4.227
External Reference	4.229
External Noise Source	4.230
RF Preamplifier	4.230
Transducer	4.231
Programming the Interface Configuration and Time Setup	4.236
System Information	4.250
Service Menu	4.252
Firmware Update	4.255
Saving and Recalling Data Sets – FILE Key	4.257
Overview	4.257
Operating Concept of File Managers	4.262
Measurement Documentation – HCOPY Key	4.268
Selecting Printer Colors	4.271
External Generator Control – Option R&S FSP-B10	4.275
External Generator Settings	4.277
Transmission Measurement	4.278
Calibration of Transmission Measurement	4.278
Normalization	4.280

Reflection Measurement	4.284
Calibration of Reflection Measurement	4.284
Calibration Mechanism	4.285
Frequency-Converting Measurements	4.287
Configuration of an External Generator	4.288
List of Generator Types Supported by the R&S FSUP	4.292
LAN Interface	4.297
NOVELL Networks	4.297
MICROSOFT Network	4.297
Remote Data Transfer with TCP/IP Services	4.298
RSIB Protocol	4.299
Remote Control via RSIB Protocol	4.299
Windows Environment	4.299
UNIX Environment	4.300
RSIB Interface Functions	4.301
Overview of Interface Functions	4.301
Variables ibsta, iberr, ibcntl	4.301
Description of Interface Functions	4.303
Programming via the RSIB Protocol	4.311
Visual Basic	4.311
Visual Basic for Applications (Winword and Excel)	4.314
C / C++	4.315
LO/IF ports for external mixers - Option R&S FSU-B21	4.318
Connecting an External Mixer	4.318
Manual Operation	4.319
Conversion Loss Tables	4.324
Editing a Table	4.327
Signal Identification	4.331
Remarks Concerning Signal Identification with AUTO ID	4.332
Introductory Example of Operation	4.338
Trigger Port – Option R&S FSP-B28	4.343
Cross Correlation Measurement - Option R&S FSUP-B60	4.345

Introduction

All functions of the R&S FSUP and their application are explained in detail in this chapter. The sequence of the described menu groups depends on the procedure selected for the configuration and start of a measurement:

1. Resetting the instrument
 - [“R&S FSUP Initial Configuration – PRESET Key” on page 4.5](#)
2. Setting the mode
 - [“Mode Selection – Hotkey Bar” on page 4.8](#)
 - [“Return to Manual Operation– LOCAL Menu” on page 4.10](#)
3. Setting the measurement parameters in phase noise mode
 - [“Phase Noise Mode” on page 4.11](#)
4. Setting the measurement parameters in analyzer mode
 - [“Analyzer Mode” on page 4.82](#)
5. Basic functions for general settings, printout and data management
 - [“Setup of Limit Lines and Display Lines – LINES Key” on page 4.208](#)
 - [“Configuration of Screen Display – DISP Key” on page 4.221](#)
 - [“Instrument Setup and Interface Configuration – SETUP Key” on page 4.227](#)
 - [“Saving and Recalling Data Sets – FILE Key” on page 4.257](#)
 - [“Measurement Documentation – HCOPY Key” on page 4.268](#)
6. Additional and optional functions
 - [“External Generator Control – Option R&S FSP-B10” on page 4.275](#)
 - [“LAN Interface” on page 4.297](#)
 - [“LO/IF ports for external mixers - Option R&S FSU-B21” on page 4.318](#)
 - [“Trigger Port – Option R&S FSP-B28” on page 4.343](#)
 - [“Cross Correlation Measurement - Option R&S FSUP-B60” on page 4.345](#)

The operating concept is described in the Quick Start Guide, chapter 4, “Basic Operation”.

The remote commands (if any) are indicated for each softkey. A detailed description of the associated remote commands is given in chapter [“Remote Control – Description of Commands”](#).

R&S FSUP Initial Configuration – PRESET Key

PRESET

Using the *PRESET* key, the R&S FSUP can be set to a predefined initial state.



Notes

The settings are selected in a way that the RF input is always protected against overload, provided that the applied signal levels are in the allowed range for the instrument.

The initial instrument state set by the *PRESET* key can be adapted to arbitrary applications using the STARTUP RECALL function. With this function the STARTUP RECALL data set is loaded upon pressing the *PRESET* key. For further information refer to section “[Saving and Recalling Data Sets – FILE Key](#)” on page 4.257.

The initial state of the R&S FSUP depends on the selected preset mode. For details on the preset mode refer to section “[Instrument Setup and Interface Configuration – SETUP Key](#)”, “[PRESET SSA](#)” and “[PRESET ANALYZER](#)” on page 4.255.



Note

When performing a preset, the R&S FSUP keeps the following settings unchanged:

- port settings (e.g. supply voltages)
- test setup selection

Only in a cold start these settings are adapted to the initial configuration.

Pressing the *PRESET* key causes the R&S FSUP to enter its initial state according to [Table 4-1](#) or [Table 4-2](#).

Table 4-1 Initial State of R&S FSUP in phase noise preset mode

Parameter	Settings
Mode	Phase Noise (SSA)
Configuration	Internal generator, internal phase detector, internal generator controlled
Center frequency	determined by pre-measurement
Start offset frequency	1 kHz
Stop offset frequency	1 MHz
RF attenuation	auto
Preamplifier	auto
Reference level	determined by pre-measurement
Level unit	dBc/Hz
Sweep	cont
DC voltages	off
Trigger	free run
Trace 1	smoothed 1%
Trace 2	clr write
Trace 3	blank
Trace math	off

Table 4-2 Initial State of R&S FSUP in analyzer preset mode

Parameter	Settings
Mode	Spectrum
Center frequency	4 GHz / 13.25 GHz / 25 GHz (FSUP-8/-26/-50)
Center frequency step size	0.1 * center frequency
Span	8 GHz / 26.5 GHz / 50 GHz (FSUP-8/-26/-50)
RF attenuation	auto (5 dB)
Reference level	-20 dBm
Level range	100 dB log
Level unit	dBm
Sweep time	auto
Resolution bandwidth	auto (3 MHz)
Video bandwidth	auto (10 MHz)
FFT filters	off
Span / RBW	50
RBW / VBW	0.33
Sweep	cont
Trigger	free run
Trace 1	clr write
Trace 2/3	blank
Detector	auto peak
Trace math	off
Frequency offset	0 Hz
Reference level offset	0 dB
Reference level position	100 %
Grid	abs
Cal correction	on
Noise source	off
Input	RF
Display	Full screen, active screen A
External Generator 1/2 (only with option R&S FSP-B10)	off

Mode Selection – Hotkey Bar

For fast mode selection and quick access to softkey menus, the R&S FSUP has keys located under the measurement screen, the so-called hotkeys. These hotkeys are displayed depending on the selected mode and the options installed on the instrument. The hotkeys of the installed options are only available in analyzer mode.

In this section, only the hotkeys provided by the basic model are described. For information on the other hotkeys refer to the corresponding option descriptions.



Fig. 4-1 Hotkey bar in the phase noise mode (default setting)



Fig. 4-2 Hotkey bar in the analyzer mode

SPECTRUM

The *SPECTRUM* hotkey sets R&S FSUP to analyzer mode. For details on the softkey menus refer to section [“Analyzer Mode” on page 4.82](#).

Remote command: `INST:SEL SAN`

SSA

The *SSA* hotkey sets the R&S FSUP to phase noise mode (default mode). For details on the softkey menus refer to section [“Phase Noise Mode” on page 4.11](#).

Remote command: `INST:SEL PNO`
`INST:NSEL 20`

DC POWER

The *DC POWER* hotkey switches the DC power on or off for all selected ports. For further details refer to section [“SWITCHING SEQUENCE” on page 4.50](#).

Remote command: `SOUR:VOLT ON`

QUICKSET

The *QUICKSET* hotkey opens a softkey menu that offers fast access to important phase noise measurement settings. The appearance of this softkey menu depends on the selected measurement mode.

- Phase noise mode: For a description of the *QUICKSET* hotkey menu refer to section [“QUICKSET Hotkey Menu” on page 4.12](#).
- Analyzer mode: For a description of the *QUICKSET* hotkey menu refer to section [“QUICKSET Hotkey Menu” on page 4.83](#).

RUN

The *RUN* hotkey is only available in phase noise mode. It starts the next measurement sweep or stops the measurement.

Remote command: `INIT`

PREMEAS

The *PREMEAS* hotkey is only available in phase noise mode for Noise measurements. It starts a pre-measurement and displays the determined parameter in the *VCO & LOOP SETTINGS* dialog box. For further details refer to section “[VCO LOOP SETTINGS](#)” on [page 4.51](#) and the Quick Start Guide, chapter 5.

Remote command: `VCO:PREM ONCE`

SETTINGS

The *SETTINGS* hotkey is only available in phase noise mode. It opens the settings softkey menu. A detailed description of this menu is provided in section “[SETTINGS Hotkey Menu](#)” on [page 4.17](#).

MORE

The *MORE* hotkey switches to side hotkey bar(s) and back to the main hotkey bar. In the side hotkey bar(s), the hotkeys for the options are located. For further information refer to the descriptions of the corresponding options.

**SCREEN A /
SCREEN B**

With the *SCREEN A / SCREEN B* hotkey two different settings can be selected on the R&S FSUP in the FULL SCREEN display mode.

In the SPLIT SCREEN display mode the key switches between active diagram A and B.

The key designation indicates the diagram which has been activated by means of the key.

The currently active window is marked by **A** or **B** on the right of the diagram.

Remote command: `DISP:WIND<1|2>:SEL A`

Return to Manual Operation– LOCAL Menu

LOCAL

The *LOCAL* menu is displayed on switching the instrument to remote control mode.

At the same time, the hotkey bar is blanked out and all keys are disabled except the *PRESET* key. The diagram, traces and display fields are then blanked out (they can be activated using the [SYSTEM:DISPlay:UPDate](#) remote control command).

The menu contains only one softkey, the *LOCAL* key. The *LOCAL* key switches the instrument from remote to manual operation, with the assumption that the remote controller has not previously set the LOCAL LOCKOUT function.

A change in the control mode consists of:

- **Enabling the Front Panel Keys**

Returning to manual operation enables all inactive keys and turns on the hotkey bar. The softkey menu which is displayed is the main menu of the current mode.

- **Inserting the measurement diagrams**

The blanked diagrams, traces and display fields are inserted.

- **Generating the message OPERATION COMPLETE**

If, at the time of pressing the *LOCAL* softkey, the synchronization mechanism via *OPC, *OPC? or *WAI is active, the currently running measurement procedure is aborted and synchronization is achieved by setting the corresponding bits in the registers of the status reporting system.

- **Setting Bit 6 (User Request) of the Event Status Register**

With a corresponding configuration of the status reporting system, this bit immediately causes the generation of a service request (SRQ) which is used to inform the control software that the user wishes to return to front-panel control. This information can be used, e.g., to interrupt the control program so that the user can make necessary manual corrections to instrument settings. This bit is set each time the *LOCAL* softkey is pressed.



Note

If the LOCAL LOCKOUT function is active in the remote control mode, the front-panel *PRESET* key is also disabled. The LOCAL LOCKOUT state is left as soon as the process controller de-activates the REN line or the GPIB cable is disconnected from the instrument.

Phase Noise Mode

The phase noise mode is activated by pressing the SSA hotkey (see also section [“Mode Selection – Hotkey Bar” on page 4.8](#))

SSA

The SSA hotkey selects the phase noise mode. This mode is the default mode of the R&S FSUP.

If pressed, the SSA hotkey changes to *SSA HOME* and the softkey menu for phase noise measurements is displayed. A detailed description of this menu is provided in section [“Selection of the Measurement Function – MEAS Key” on page 4.69](#).

Remote command: INST:SEL PNO
 INST:NSEL 20

Menus Overview

The following sections provide a detailed description of all measurements, settings and results in phase noise mode.

- [“QUICKSET Hotkey Menu” on page 4.12](#)
- [“SETTINGS Hotkey Menu” on page 4.17](#)
- [“Sweep Settings – SWEEP Key” on page 4.58](#)
- [“Selection and Setting of Traces – TRACE Key” on page 4.59](#)
- [“Marker Functions – MKR Key” on page 4.64](#)
- [“Assigning Markers to Traces – MKR-> Key” on page 4.66](#)
- [“Selection of the Measurement Function – MEAS Key” on page 4.69](#)
- [“Setup of Limit Lines – LINES Key” on page 4.76](#)
- [“Instrument Setup and Interface Configuration - SETUP Key” on page 4.80](#)

The *MKR FCTN* and the *DISP* keys are not available in phase noise mode. The *FREQ*, *SPAN*, *AMPT*, *BW*, and *TRIG* keys do not open a separate softkey menu, but open the *General Settings* or *Measurement Settings* dialog box and focus on a specific field (details are given with the corresponding settings description).

Apart from the *LINES* and *SETUP* softkey menus that differ from the corresponding menus in analyzer mode, basic functions are described in section [“Basic Settings” on page 4.208](#).

In the status bar, information about the valid settings for the selected parameter is displayed. Any parameters that are not available for editing have a grey background. This usually occurs if the prerequisites are not met.

QUICKSET Hotkey Menu

QUICKSET

The *QUICKSET* hotkey offers fast access to important phase noise measurement settings. The *QUICKSET* hotkey is available both in the analyzer mode (*SPECTRUM* hotkey) and the phase noise mode (*SSA* hotkey). The description provided in this section only applies to the phase noise mode. For details of the menu in analyzer mode refer to section “[QUICKSET Hotkey Menu](#)” on page 4.83.

In phase noise mode, the appearance of the *QUICKSET* menu depends on the selected measurement (via the *SSA* hotkey or *MEAS* key).

Table 4-3 Softkeys in the *QUICKSET* menu for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements

TUNE DUT1
SUPPLY DUT1
SCOPE
SPOT LIST
SPUR LIST
HIGHLIGHT SPURS
SUPPRESS SPURS
AUTOSCALE Y-AXIS
Side menu
LNA GAIN
LNA GAIN AUTO
LOOP BW
LOOP BW AUTO
TRACKING
USE HARMONIC
AFC

Table 4-4 Softkeys in the *QUICKSET* menu for Phase Noise Analyzer measurements

SUPPLY DUT1
TUNE DUT1
TRACK LEVEL ON/OFF
TRACK FREQ ON/OFF
AUTOSCALE Y-AXIS
Side menu
COPY TRACE

Table 4-5 Softkeys in the *QUICKSET* menu for VCO measurements

SUPPLY DUT1
TUNE DUT1
PUSH DUT
SETTLE TIME
MEAS TIME
AUTOSCALE Y-AXIS

Table 4-6 Softkeys in the *QUICKSET* menu for Transient measurements

SUPPLY DUT1
TUNE DUT1
AUTOSCALE Y-AXIS

TUNE DUT1

The *TUNE DUT1* softkey opens an edit dialog box to enter the tuning voltage for DC Port 1. This entry corresponds to the *Vtune1 Voltage* field in the *Set* column, *DC SETTINGS* dialog box. For further details see section “*Vtune1 Voltage / Vtune2 Voltage*” on page 4.49.

SUPPLY DUT1

The *SUPPLY DUT1* softkey opens an edit dialog box to enter the supply voltage for DC Port 1. This entry corresponds to the *Vcc1 Voltage* field in the *Set* column, *DC SETTINGS* dialog box. For further details see section “*Vcc1 Voltage / Vcc2 Voltage*” on page 4.48.

PUSH DUT

The *PUSH DUT* softkey opens an edit dialog box to enter the voltage steps for DC Port 1 in a pushing measurement. This entry corresponds to the ΔV_{cc1} *Pushing* field in the *DC SETTINGS* dialog box. For further details see section “*DVcc1 Pushing*” on page 4.48 or chapter 2, section “*Pushing*” on page 2.5).

This softkey is only available for VCO measurements.

SETTLE TIME

The *SETTLE TIME* softkey opens an edit dialog box to enter the settle time for Tuning Port 1. This entry corresponds to the *Settle Time Vtune* field in the *Measurement Settings (VCO)* dialog box. For further details see section “*Settle Time Vtune*” on page 4.43.

This softkey is only available for VCO measurements.

MEAS TIME

The *MEAS TIME* softkey opens an edit dialog box to enter the sweep time. This entry corresponds to the *Meas Time* field in the *Measurement Settings (VCO)* dialog box. For further details see section “*Meas Time*” on page 4.43.

This softkey is only available for VCO measurements.

SCOPE

The *SCOPE* softkey activates the display of the *Phase Detector* scope in the right corner above the measured curve. It shows the phase detector voltage vs. time. For further details refer to the Quick Start Guide, chapter 5.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

Remote command: `DISP:TRAC:SCOP OFF`

- SPOT LIST** The *SPOT LIST* softkey activates the display of the *Spot Noise* list in the right corner above the measured curve. It shows the calculated results of the spot noise frequency points. The spot noise frequency points are defined in the *General Settings* dialog box, under *Spot Noise Settings* (for details refer to [“SPOT NOISE” on page 4.27](#)).
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.
- Remote command: CALC : SNO : Y?
- SPUR LIST** The *SPUR LIST* softkey activates the display of the *Spur List* in the right corner above the measured curve. For further details see section [“LIST SPURS” on page 4.56](#).
- This softkey is only available for Phase Noise PLL and Cross Correlation PLL measurements.
- HIGHLIGHT SPURS** The *HIGHLIGHT SPURS* softkey activates or deactivates the display of bars to mark the position and magnitude of the detected spurs. For further details see section [“HIGHLIGHT SPURS” on page 4.56](#).
- This softkey is only available for Phase Noise PLL and Cross Correlation PLL measurements.
- SUPPRESS SPURS** The *SUPPRESS SPURS* softkey displays the measured curve with all spurs removed. For further details see section [“SUPPRESS ALL” on page 4.55](#).
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.
- AUTOSCALE Y-AXIS** The *AUTOSCALE Y-AXIS* softkey recalculates the y-axis scaling from the results to give the best fit for the data. This entry corresponds to the *Autoscale Once* field in the *General Settings* dialog box. For further details see section [“Autoscale Once” on page 4.24](#).
- TRACK LEVEL ON/OFF** The *TRACK LEVEL ON/OFF* softkey activates or deactivates the tracking and adjusting of the level during the measurement. For further details see section [“Track Level” on page 4.22](#).
- This softkey is only available for Phase Noise Analyzer measurements.
- TRACK FREQ ON/OFF** The *TRACK FREQ ON/OFF* softkey activates or deactivates the tracking and adjusting of the center frequency during the measurement. For further details see section [“Track Frequency” on page 4.22](#).
- This softkey is only available for Phase Noise Analyzer measurements.
- COPY TRACE** The *COPY TRACE* softkey opens a dialog box to select a trace memory via a numeric entry, value range 1 to 8. For further details see section [“COPY TRACE” on page 4.63](#).
- This softkey is only available for Phase Noise Analyzer measurements.

LNA GAIN

The *LNA GAIN* softkey opens an edit dialog box to enter the amplifier setting of the low noise amplifier in dB. In most cases, the automatic setting (*LNA GAIN AUTO* softkey) is suitable, but crystal oscillators (low noise DUTs) may require a manual setting of 30 dB.

**Note**

Changing the LNA gain when a measurement is running causes the following:

- The current measurement is stopped.
 - A new measurement is started.
-

Remote command: `INP:LNA:GAIN 20`

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

LNA GAIN AUTO

The *LNA GAIN AUTO* softkey activates or deactivates the automatic setting of the low noise amplifier (LNA). If activated, the low noise amplifier setting is changed automatically when the sensitivity needs to be improved.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

Remote command: `INP:LNA:GAIN:AUTO ON`

LOOP BW

The *LOOP BW* softkey opens an edit dialog box to enter the loop bandwidth. This entry corresponds to the *PLL Loop BW* field in the *VCO LOOP SETTINGS* dialog box. For further details see section “*PLL Loop BW*” on page 4.54.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

LOOP BW AUTO

The *LOOP BW AUTO* softkey calculates the loop bandwidth automatically.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

Remote command: `VCO:LOOP:BWID:AUTO ON`

TRACKING

The *TRACKING* softkey opens an edit dialog box to enter the tracking parameter for internally tuned measurements.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

Remote command: `VCO:TRAC 1000`

USE HARMONIC

The *USE HARMONIC* softkey activates or deactivates the automatic determination of the best harmonic in the pre-measurement. This entry corresponds to the *Used Harmonic* field in the [VCO LOOP SETTINGS](#) dialog box. For further details see section [“Used Harmonic” on page 4.54](#).

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

AFC

The *AFC* softkey activates or deactivates the automatic frequency control settings. For further details see section [“AFC ON” on page 4.23](#).

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Spot Noise Tuning measurements.

SETTINGS Hotkey Menu

SETTINGS

The *SETTINGS* hotkey opens the *SETTINGS* menu..

TEST SETUP
GENERAL SETTINGS
MEAS SETTINGS
DC SETTINGS
VCO LOOP SETTINGS
SPURS SETTINGS
PRESET SETTINGS

TEST SETUP

The *TEST SETUP* softkey opens the softkey menu to select and display the test setup.

SELECT CONFIG
SHOW CONFIG
DEFAULT CONFIG

SELECT CONFIG

The *SELECT CONFIG* softkey opens the *MEASUREMENT CONFIGURATION* dialog box.

MEASUREMENT CONFIGURATION					
	PLL MODE / int	Generator	Phase Detector	Control	Recom. Freq Range
<input checked="" type="checkbox"/>	1 (default)	Internal	Internal	Internal Generator	10 MHz ... 40 GHz
<input type="checkbox"/>	2	Internal	Internal	DUT	10 MHz ... 40 GHz
<input type="checkbox"/>	3 (XCORR)	Internal	Internal	Internal Generator	10 MHz ... 8 GHz
	PLL MODE / ext	Generator	Phase Detector	Control	Recom. Freq Range
<input type="checkbox"/>	1	External	Internal	DUT	10 MHz ... 8 GHz
<input type="checkbox"/>	2	External	Internal	External Generator	10 MHz ... 8 GHz
	PLL MODE / 2 DUTs	Generator	Phase Detector	Control	Recom. Freq Range
<input type="checkbox"/>	1	DUT2	Internal	DUT1	10 MHz ... 8 GHz
	DOWNCONVERTER	Generator	Phase Detector	Control	Recom. Freq Range
<input type="checkbox"/>	1 (option ext mixer)	Internal	Internal	Internal Generator	> 26 GHz
<input type="checkbox"/>	2 (ext downconv)	Internal	Internal	Internal Generator	> 40 GHz

Fig. 4-3 MEASUREMENT CONFIGURATION dialog box

In the *MEASUREMENT CONFIGURATION* dialog box, select the physical test setup and connections. For further information refer also to the Quick Start Guide, chapter 5.

**Note**

Changing the test setup when a measurement is running stops the measurement. Press the *RUN* hotkey to start a new measurement.

Remote command: `CONF:TSET INT2`

- SHOW CONFIG** The *SHOW CONFIG* softkey displays the selected PLL test setup. For information on available test setups refer to chapter 2, section [“Available PLL Test Setups”](#) on page 2.15.
- DEFAULT CONFIG** The *DEFAULT CONFIG* softkey selects the default test setup and displays the corresponding test setup diagram.

GENERAL SETTINGS

The *GENERAL SETTINGS* softkey opens the *General Settings* dialog box to modify all settings related to the overall measurement. This comprises the signal characteristics, display settings, trace settings, residual calculation settings, and spot noise settings.

The appearance of the *General Settings* dialog box depends on the selected measurement. For a detailed description refer to the following sections:

- “Noise Measurements” on page 4.19
- “VCO Measurements” on page 4.28
- “Transient Measurements” on page 4.33

Noise Measurements

Fig. 4-4 shows the *General Settings (Noise)* dialog box for Noise measurements.




Fig. 4-4 General Settings (Noise) dialog box (Noise measurement)

Table 4-7 Softkeys and elements in the *General Settings (Noise)* dialog box

Softkey/Pane	Field/List/Option
SIGNAL SETTINGS	Frequency
	Frequency Multiplier
	Level
	Sweep Forward
	Verify Freq & Level
AFC SETTINGS	Track Frequency
	Track Level
	Frequency Tolerance
	Level Tolerance (+/-)
	AFC ON
	AFC Target Frequency
	AFC Tolerance (+/-)
	AFC Max Iterations
DISPLAY SETTINGS	X Axis Start
	X Axis Stop
	Autoscale Once
	Y Axis Top
	Y Axis Range
TRACE SETTINGS	Trace Offset
	Smoothing
	Smoothing Type
RESIDUAL CALC	Use Meas Settings
	Eval From
	To
Level Settings	Preamplifier & Atten Auto
	Preamplifier On
	Attenuation
SPOT NOISE	Enable
	Offset Freq1/2/3/4/5

SIGNAL SETTINGS The *SIGNAL SETTINGS* softkey sets the focus on the *Frequency* field. Under *Signal Settings*, the general settings concerning the level and frequency of the signal to be measured are grouped.

Frequency

Specifies the center frequency of the signal to be measured. This field is also focused using the *FREQ* key.

This parameter applies only to Phase Noise Analyzer measurements.

Remote command: FREQ:CENT 100MHz

Frequency Multiplier

Specifies a multiplier that is applied to all entered and displayed frequencies. By using this multiplier, the R&S FSUP corrects the measured frequencies to take an external multiplier into account.

If a multiplier is applied, the *Signal Frequency* parameter displayed below the title bar is marked with a white asterisk.

Remote command: FREQ:MULT 4

Level

Specifies the expected level of the RF input signal.

This parameter applies only to Phase Noise Analyzer measurements.

Remote command: POW:RLEV 1

Sweep Forward

Determines the sweep direction for the current measurement.

If activated, the measurement is performed from the start frequency to the stop frequency (sweep direction forward).

If deactivated, the measurement is performed from the stop frequency to the start frequency (sweep direction reverse).

This parameter applies only to Phase Noise Analyzer measurements, for Phase Noise PLL measurements the sweep direction is always from stop frequency to start frequency.

Remote command: SWE:FORW ON

Verify Freq & Level

Activates or deactivates the frequency and level verification before a measurement. The frequency and level verification helps to determine the carrier frequency if it is not known precisely.

If activated, the *Frequency Tolerance* and *Level Tolerance* parameters become enabled. A search for the carrier of greatest magnitude across the range specified by the *Frequency Tolerance* is performed. Carrier frequency and level are measured. If the level is within the range specified by the *Level Tolerance*, the measured level overrides the specified level. Otherwise the measurement is aborted.

This parameter applies only to Phase Noise Analyzer measurements.

Remote command: FREQ:VER OFF
POW:RLEV:VER OFF

AFC SETTINGS The *AFC SETTINGS* softkey sets the focus on the *AFC ON* option. Under *AFC Settings*, the track settings and the automatic frequency control (AFC) settings are grouped. The automatic frequency control settings only apply to tuning port 1.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

**Note**

Changing the tracking settings when a measurement is running causes the following:

- The current measurement is stopped.
- A new measurement is started.

Track Frequency

If activated, the center frequency is tracked and adjusted during the measurement.

This option is only available if the *Verify Frequency & Level* option is activated and only applies to Phase Noise Analyzer measurements.

Remote command: `FREQ:TRAC ON`

Track Level

If activated, the level is tracked and adjusted during the measurement.

This option is only available if the *Verify Frequency & Level* option is activated and only applies to Phase Noise Analyzer measurements.

Remote command: `POW:TRAC ON`

Frequency Tolerance

Verifies the input signal frequency. The process depends on the defined sweep direction.

If the sweep direction is forward, the *Frequency Tolerance (abs)* parameter specifies the range around the signal frequency within the carrier is known to be (in Hz). A frequency and level check is performed once, at the beginning of the measurement.

If the sweep direction is reverse, the *Frequency Tolerance (rel)* parameter specifies the ratio of the subspan start frequency (in %). A frequency and level check is performed before each sub-sweep.

This parameter applies only to Phase Noise Analyzer measurements.

Remote command: `FREQ:VER:TOL 20HZ`

Level Tolerance (+/-)

Specifies a power tolerance for the signal verification.

The input signal may vary by the maximum and minimum deviation from the specified level setting (*Level* field) to pass the verification, i.e. measured level between (Level+Level_Tolerance) and (Level-Level_Tolerance) is accepted.

This parameter applies only to Phase Noise Analyzer measurements.

Remote command: POW:RLEV:VER:TOL 5DB

AFC ON

Activates or deactivates the automatic frequency control. If activated, the R&S FSUP tries to set the target frequency by tuning the DUT in compliance with the specified AFC settings.

This parameter applies only to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: SOUR:VOLT:CONT1:AFC ON

AFC Target Frequency

Specifies the target frequency for automatic frequency control.

This parameter applies only to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: SOUR:VOLT:CONT1:AFC:TARG 200MHZ

AFC Tolerance (+/-)

Specifies the tolerance on the target frequency for automatic frequency control, e.g. the maximum value by which the target frequency may be undercut or exceeded.

This parameter applies only to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: SOUR:VOLT:CONT1:AFC:TOL 2KHZ

AFC Max Iterations

Specifies the maximum number of iterations for automatic frequency control.

The R&S FSUP tries to tune the DUT in compliance with the specified AFC settings until the target frequency range is set or the maximum number of iterations is reached.

This parameter applies only to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: SOUR:VOLT:CONT1:AFC:ITER 20

DISPLAY SETTINGS The *DISPLAY SETTINGS* softkey sets the focus on the *X Axis Start* field. Under *Display Settings*, the general settings concerning the range and scaling are grouped.

X Axis Start

Specifies the minimum frequency for the x-axis. Only the listed values can be set.

If this parameter is changed, the *Start Offset* parameter in the *Measurement Settings (Noise)* dialog box is updated accordingly (see “[SPAN START](#)” on [page 4.39](#)) and vice versa.

Remote command: FREQ:STAR 3MHz

X Axis Stop

Specifies the maximum frequency for the x-axis. Only the listed values can be set.

If this parameter is changed, the *Stop Offset* parameter in the *Measurement Settings (Noise)* dialog box is updated accordingly (see “[SPAN STOP](#)” on [page 4.39](#)) and vice versa.

Remote command: FREQ:STOP 100MHz

Autoscale Once

If activated, the y-axis scaling is calculated from results of the first sweep. The autoscaling is performed only once, the results of the subsequent sweeps have no effect.

If the *Autoscale Once* option is activated, the *Y Axis Top* and *Y Axis Range* parameters are disabled. If the *Autoscale Once* option is deactivated, the *Y Axis Top* and *Y Axis Range* parameters are editable.

This field is also focused using the *AMPT* key.

Remote command: DISP:TRAC:Y:AUTO ON

Y Axis Top

Specifies the reference level (maximum level) for the trace results.

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: DISP:TRAC:Y:RLEV -60

Y Axis Range

Specifies the display range of the y-axis (level axis).

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: DISP:TRAC:Y 110dB

TRACE SETTINGS The *TRACE SETTINGS* softkey sets the focus on the *Trace Offset* field. Under *Trace Settings*, the general settings concerning the offset and smoothing are grouped.

Trace Offset

Specifies the arithmetical reference level offset which is added to the y-axis labeling.

Remote command: `DISP:TRAC:Y:RLEV:OFFS -10dB`

Smoothing

Specifies the aperture of the window (as percentage of the display width) to be used when trace smoothing is performed. The larger the *Smoothing* parameter the greater the effect of smoothing.

For more details regarding smoothing and the algorithm used see section “SMOOTHING” on page 4.61.

Remote command: `DISP:TRAC:SMO:APER 10`

Smoothing Type

Specifies whether linear, logarithmic or median smoothing is to be performed.

Remote command: `DISP:TRAC1:SMO:TYPE LOG`

RESIDUAL CALC The *RESIDUAL CALC* softkey sets the focus on the *Use Meas Settings* option. If the settings under *Residual Calculations* are changed, the *Residual Noise* list below the title bar is updated accordingly.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Use Meas Settings

Specifies the range for the residual calculations.

If activated, the *Eval From* and *To* parameters are disabled and the residual calculations are performed across the complete range of the measurement results.

If deactivated, the *Eval From* and *To* parameters are editable to specify the range over which the residual calculations are to be performed.

This parameter applies only to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: `CALC:EVAL ON`

Eval From

Specifies the start of the measurement range for the residual calculations.

The minimum value is equal to the value of the *X Axis Start* setting. The maximum value is equal to the value of the *X Axis Stop* setting and cannot be higher than the *To* setting.

If the *X Axis Start* or *X Axis Stop* settings are modified, this parameter is automatically adjusted to ensure that it lies within the measurement range.

This field is only available if the *Use Meas Settings* option is activated and only applies to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: CALC:EVAL:STAR 2KHZ

To

Specifies the end of the measurement range for the residual calculations.

The minimum value is equal to the value of the *X Axis Start* setting. The maximum value is equal to the value of the *X Axis Stop* setting and cannot be lower than the *Eval From* setting.

If the *X Axis Start* or *X Axis Stop* settings are modified, this parameter is automatically adjusted to ensure that it lies within the measurement range.

This field is only available if the *Use Meas Settings* option is activated and only applies to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: CALC:EVAL:STOP 1MHZ

Level Settings Under *Level Settings*, the level settings are grouped.

Preamplifier & Atten Auto

If activated, the R&S FSUP automatically calculates the settings for the preamplifier and RF attenuator.

This option is only available with the RF preamplifier (B23) or electronic attenuator (B25) option and only applies to Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: INP:GAIN:AUTO ON

Preamplifier On

Activates or deactivates the preamplifier.

This option is only available if the *Preamplifier & Atten Auto* option is deactivated and with the RF preamplifier (B23) or electronic attenuator (B25) option.

Remote command: INP:GAIN:STAT ON

Attenuation

Specifies the attenuator setting.

This option is only available if the *Preamplifier & Atten Auto* option is deactivated.

Remote command: INP:ATT 40DB

SPOT NOISE The *SPOT NOISE* softkey sets the focus on the *Enable* option. Under *Spot Noise Settings*, discrete frequency points can be specified to obtain and display the phase noise result from a measurement sweep. The spot noise results are updated during a sweep.

Enable

The *Enable* option activates or deactivates the spot noise calculations.

Remote command: CALC:SNO1:STATE ON
 CALC:SNO:AOFF

Offset Freq1/2/3/4/5

The *Offset Freq* parameters specify the frequency points at which the spot noise calculations are performed. If an offset frequency outside the measurement frequency range is specified, no results are displayed for this offset frequency.

These parameters are only editable if the *Enable* option is activated.

Remote command: CALC:SNO2:X 2MHz

VCO Measurements

The appearance of the *General Settings* dialog box depends on the selected VCO measurement:

- *General Settings (VCO Tuning)* dialog box (see Table 4-8)
for the [VCO TUNING CHAR](#), [VCO TUNING SENSITIVITY](#), [VCO RF PWR CHAR](#), [VCO SUMMARY](#) measurements
- *General Settings (VCO Harmonic)* dialog box (see Table 4-9)
for the [HARMONIC PWR](#) measurement
- *General Settings (VCO DC)* dialog box (see Table 4-10)
for the [VCO DC CHAR](#) measurement

Fig. 4-5 shows the *General Settings (VCO Tuning)* dialog box as an example.

General Settings (VCO Tuning)		
Carrier Search		
Autosearch	<input checked="" type="checkbox"/>	
Start	1.00	Hz
Stop	40.00	GHz
Level Settings		
Preamplifier & Atten Auto	<input checked="" type="checkbox"/>	
Preamplifier On	<input type="checkbox"/>	
Attenuation	5	dB
Y-Axis Settings		
Autoscale Once	<input checked="" type="checkbox"/>	
Frequency		
Top	100.00	Hz
Range	100.00	Hz
Trace Offset	0.00	Hz
Level		
Top	-20.00	dBm
Range	10.00	dB
Frequency Per Volt		
Top	1.00	MHz/V
Range	2.00	MHz/V

Fig. 4-5 *General Settings (VCO Tuning)* dialog box (example)

Table 4-8 Softkeys and elements in the *General Settings (VCO Tuning)* dialog box

Pane	Field/Option
Carrier Search	Autosearch
	Start
	Stop
Level Settings	Preamplifier & Atten Auto
	Preamplifier On
	Attenuation
Y-Axis Settings	Autoscale Once
Frequency	Top
	Range
	Trace Offset
Level	Top
	Range
Frequency Per Volt	Top
	Range

Table 4-9 Softkeys and elements in the *General Settings (VCO Harmonic)* dialog box

Pane	Field/Option
Carrier Search	Autosearch
	Start
	Stop
Level Settings	Preamplifier & Atten Auto
	Preamplifier On
	Attenuation
Trace Settings	Trace 1
	Trace 2
	Trace 3
	Trace 4
Y-Axis	Autoscale Once
	Top
	Range

Table 4-10 Softkeys and elements in the *General Settings (VCO DC)* dialog box

Pane	Field/Option
Carrier Search	Autosearch
	Start
	Stop
Level Settings	Preamplifier & Atten Auto
	Preamplifier On
	Attenuation
Y-Axis	Autoscale Once
Frequency	Top
	Range
	Trace Offset
Level	Top
	Range

Carrier Search Typically the instrument uses its whole frequency range in order to detect the strongest spectrum line. For special purposes it may be useful to restrict the search range, e.g. if a spurious frequency is stronger than the desired frequency.

Autosearch

If activated, a pre-measurement is performed before a measurement (when pressing the *RUN* key). As part of the pre-measurement sequence, the VCO tuning range, VCO slope, VCO drift, center frequency, and level are calculated.

If deactivated, the search range can be set manually to restrict the search range.

This field is also focused using the *FREQ* key.

Remote command: `VCO:CSE:AUTO ON`

Start

Specifies the start frequency.

Remote command: `VCO:CSE:STAR 1GHZ`

Stop

Specifies the stop frequency.

Remote command: `VCO:CSE:STOP 30GHZ`

Level Settings	<p><i>Preamplifier & Atten Auto</i></p> <p>see “Preamplifier & Atten Auto” on page 4.26</p> <p><i>Preamplifier On</i></p> <p>see “Preamplifier On” on page 4.26</p> <p><i>Attenuation</i></p> <p>see “Attenuation” on page 4.26</p>
Trace Settings	<p><i>Trace 1</i></p> <p><i>Trace 2</i></p> <p><i>Trace 3</i></p> <p><i>Trace 4</i></p> <p>Specifies the harmonics to be measured individually for each trace.</p> <p>These parameters are only available for HARMONIC PWR measurements.</p> <p>Remote command: <code>CONF:VCO:TRAC1:HARM 1</code></p>
Y-Axis Settings	<p><i>Autoscale Once</i></p> <p>see “Autoscale Once” on page 4.24</p> <p>Remote command: <code>DISP:TRAC:Y:VCO:AUTO ON</code></p>
Frequency	<p>Under <i>Frequency</i>, the y-axis scaling for VCO TUNING CHAR and VCO DC CHAR measurements is defined.</p> <p><i>Top</i></p> <p>Specifies the upper value of the y-axis in Hz.</p> <p>This field is only available if the <i>Autoscale Once</i> option is deactivated.</p> <p>Remote command: <code>DISP:TRAC:Y:VCO:TOP 20GHZ</code></p> <p><i>Range</i></p> <p>Specifies the display range of the y-axis (level axis) in Hz.</p> <p>This field is only available if the <i>Autoscale Once</i> option is deactivated.</p> <p>Remote command: <code>DISP:TRAC:Y:VCO:RANG 10GHZ</code></p> <p><i>Trace Offset</i></p> <p>Specifies the frequency offset of the y-axis in Hz.</p> <p>Remote command: <code>DISP:TRAC:Y:VCO:OFFS 3MHZ</code></p>

Level Under *Top*, the y-axis scaling for **VCO RF PWR CHAR** and **HARMONIC PWR** measurements is defined.

Top

Specifies the upper value of the y-axis in dBm.

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: `DISP:TRAC:Y:VCO:TOP -30dBm`

Range

Specifies the display range of the y-axis (level axis) in dB.

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: `DISP:TRAC:Y:VCO:RANG 20dB`

Frequency Per Volt Under *Frequency Per Volt*, the y-axis scaling for **VCO TUNING SENSITIVITY** measurements is defined.

Top

Specifies the upper value of the y-axis in Hz/V.

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: `DISP:TRAC:Y:VCO:TOP 10MHZ/V`

Range

Specifies the display range of the y-axis (level axis) in Hz/V.

This field is only available if the *Autoscale Once* option is deactivated.

Remote command: `DISP:TRAC:Y:VCO:RANG 5MHZ/V`

Transient Measurements

Fig. 4-6 shows the *General Settings (Transient)* dialog box for Transient measurements.

General Settings (Transient)		
Signal Settings		
Frequency	20.00	GHz
Level	-20.00	dBm
Level Settings		
Preamplifier & Atten Auto	<input checked="" type="checkbox"/>	
Preamplifier On	<input type="checkbox"/>	
Attenuation	5	dB
Y-Axis Settings		
Autoscale Once	<input checked="" type="checkbox"/>	
Frequency		
Top	250.00	kHz
Range	500.00	kHz
Trace Offset	0.00	Hz
Phase		
Units	Radians	
Top	10.00	rad
Range	20.00	rad
Trace Offset	0.00	rad
Amplitude		
Top	100.00	%
Range	200.00	%
Trace Offset	0.00	%
Level		
Top	-20.00	dBm
Range	10.00	dB
Trace Offset	0.00	dB

Fig. 4-6 *General Settings (Transient)* dialog box (Transient measurement)

Table 4-11 Softkeys and elements in the *General Settings (Transient)* dialog box

Pane	Field/Option
Signal Settings	Frequency
	Level
Level Settings	Preamplifier & Atten Auto
	Preamplifier On
	Attenuation
Y-Axis Settings	Autoscale Once
Frequency	Top
	Range
	Trace Offset
Phase	Units
	Top
	Range
	Trace Offset
Amplitude	Top
	Range
	Trace Offset
Level	Top
	Range
	Trace Offset

Signal Settings



Note

The setting of center frequency and level is mandatory for Transient measurements.

Frequency

see “Frequency” on page 4.21

Level

see “Level” on page 4.21

Level Settings	<p><i>Preamplifier & Atten Auto</i> see “Preamplifier & Atten Auto” on page 4.26</p> <p><i>Preamplifier On</i> see “Preamplifier On” on page 4.26</p> <p><i>Attenuation</i> see “Attenuation” on page 4.26</p>
Y-Axis Settings	<p><i>Autoscale Once</i> see “Autoscale Once” on page 4.24</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:AUTO ON</code></p>
Frequency	<p>Under <i>Frequency</i>, the y-axis scaling for TRANSIENT FREQ measurements is defined.</p> <p><i>Top</i> see “Top” on page 4.31</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:TOP 1GHZ</code></p> <p><i>Range</i> see “Range” on page 4.31</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:RANG 1GHZ</code></p> <p><i>Trace Offset</i> see “Trace Offset” on page 4.31</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:OFFS 3MHZ</code></p>
Phase	<p>Under <i>Phase</i>, the y-axis scaling for TRANSIENT PHASE measurements is defined.</p> <p><i>Units</i> Specifies the unit for the phase settings.</p> <p><i>Top</i> Specifies the upper value of the y-axis in rad. This field is only available if the <i>Autoscale Once</i> option is deactivated.</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:TOP 20RAD</code></p> <p><i>Range</i> Specifies the display range of the y-axis (level axis) in rad. This field is only available if the <i>Autoscale Once</i> option is deactivated.</p> <p>Remote command: <code>DISP:TRAC:Y:TRAN:RANG 100RAD</code></p>

- Trace Offset*
Specifies the frequency offset of the y-axis in rad.
Remote command: `DISP:TRAC:Y:TRAN:OFFS 5RAD`
- Amplitude Under *Amplitude*, the y-axis scaling for **TRANSIENT AMPT** measurements is defined.
- Top*
Specifies the upper value of the y-axis in %.
This field is only available if the *Autoscale Once* option is deactivated.
Remote command: `DISP:TRAC:Y:TRAN:TOP 10PCT`
- Range*
Specifies the display range of the y-axis (level axis) in %.
This field is only available if the *Autoscale Once* option is deactivated.
Remote command: `DISP:TRAC:Y:TRAN:RANG 20PCT`
- Trace Offset*
Specifies the frequency offset of the y-axis in %.
Remote command: `DISP:TRAC:Y:TRAN:OFFS 50PCT`
- Level Under *Level*, the y-axis scaling for **TRANSIENT PWR** measurements is defined.
- Top*
see [“Top” on page 4.32](#)
Remote command: `DISP:TRAC:Y:TRAN:TOP -30DBM`
- Range*
see [“Range” on page 4.32](#)
Remote command: `DISP:TRAC:Y:TRAN:RANG 50DB`
- Trace Offset*
Specifies the frequency offset of the y-axis in dB.
Remote command: `DISP:TRAC:Y:TRAN:OFFS 100DB`

MEAS SETTINGS

The *MEAS SETTINGS* softkey opens the *Measurement Settings* dialog box.

In the *Measurement Settings* dialog box, the settings associated with measurement sweep are specified.

The appearance of the *Measurement Settings* dialog box depends on the selected measurement. For a detailed description refer to the following sections:

- “Noise Measurements” on page 4.37
- “VCO Measurements” on page 4.42
- “Transient Measurements” on page 4.44

Noise Measurements

Fig. 4-7 shows the *Measurement Settings (Spot Noise Vs Tuning)* dialog box as an example for Noise measurements.




Fig. 4-7 *Measurement Settings (Spot Noise Vs Tuning)* dialog box (example)

Table 4-12 Softkeys and elements in the *Measurement Settings* dialog box for Noise measurements

Softkey/Pane	Softkey/Field/List
SWEEP MODE	
FFT Window	
Span Settings	SPAN START
	SPAN STOP
Carrier Frequency Offset	SUBSPAN RBW
TUNING SETTINGS	
Preset Settings	RBW%
	AVERAGE / XCORR
	USE FFT ON/OFF
	XCORR OPT ON/OFF

SWEEP MODE The *SWEEP MODE* softkey opens the *Sweep Mode* list to select the sweep mode. The *Sweep Mode* list is also opened using the *BW* key.

After changing the sweep mode, the default settings of the sweep mode are loaded and the *Carrier Frequency Offset* table is updated accordingly. For each sub-band, the sweep mode provides specific values for RBW, Average and FFT settings. Possible values for the sweep mode are:

- *FAST*

Optimized for measurement speed only. The *Avg* column is set to 1 (not averaged) for all sub-bands. The measurement runs very fast.

The default settings cannot be change, the *Carrier Frequency Offset* table is not editable.

Remote command: `SWE:MODE FAST`

- *NORMAL*

Balanced setting of measurement speed and resolution bandwidth. The measurement runs slower than in *FAST* sweep mode, but the sub-bands are averaged.

The default settings cannot be change, the *Carrier Frequency Offset* table is not editable.

Remote command: `SWE:MODE NORM`

- *AVERAGED*

Good resolution bandwidth regardless of measurement speed. The measurement runs very slow with high average in each sub-band for more accurate results.

The default settings cannot be change, the *Carrier Frequency Offset* table is not editable.

Remote command: `SWE:MODE AVER`

	<ul style="list-style-type: none"> • <i>MANUAL</i> <p>The settings can be changed. The <i>RBW</i>, <i>Avg</i> and <i>FFT</i> columns are editable.</p> <p>Remote command: SWE:MODE MAN</p>
FFT Window	<p>Specifies the type of FFT window.</p> <p>This field is only available for Noise PLL measurements. For Phase Noise Analyzer measurements the FFT window is always <i>FLATTOP</i>.</p> <p>Remote command: SWE:FFTW GAUS</p>
Span Settings	<p>Under <i>Span Settings</i>, the start and stop frequency of the measurement are defined. In the <i>Carrier Frequency Offset</i> table, the selected span is highlighted accordingly.</p>
SPAN START	<p>The <i>SPAN START</i> softkey opens the <i>Start Offset</i> list to define the start carrier-offset frequency. The <i>Start Offset</i> list is also opened using the <i>SPAN</i> key.</p> <p>If the start frequency is changed, the <i>X-Axis Start</i> parameter in the <i>General Settings (Noise)</i> dialog box is updated accordingly (see “X Axis Start” on page 4.24) and vice versa.</p> <p>Remote command: FREQ:STAR 3MHz</p>
SPAN STOP	<p>The <i>SPAN STOP</i> softkey opens the <i>Stop Offset</i> list to define the stop carrier-offset frequency.</p> <p>If the stop frequency is changed, the <i>X-Axis Stop</i> parameter in the <i>General Settings (Noise)</i> dialog box is updated accordingly (see “X Axis Stop” on page 4.24) and vice versa.</p> <p>Remote command: FREQ:STOP 30MHz</p>
Carrier Frequency Offset	<p>The <i>Carrier Frequency Offset</i> table shows the specific settings for each sub-band.</p> <ul style="list-style-type: none"> • <i>From</i> <p>Displays the start frequency of each sub-band. The values are not editable.</p> <ul style="list-style-type: none"> • <i>To</i> <p>Displays the stop frequency of each sub-band. The values are not editable.</p> <ul style="list-style-type: none"> • <i>RBW</i> <p>Lists the resolution filter bandwidth used for each sub-band. Only in <i>MANUAL</i> sweep mode changes are possible.</p> <p>To change a sub-band value, use the <i>SUBSPAN RBW</i> softkey. For general changes over all sub-bands, use the <i>RBW%</i> softkey.</p>

- *Avg / XCorr*

Lists the number of sweeps or, in the Cross Correlation PLL measurements (R&S FSUP-B60), the number of correlations to average over / to use for each sub-band. Only in *MANUAL* sweep mode changes are possible.

To change a sub-band value, focus the corresponding field and enter the value. For general changes over all sub-bands, use the *AVERAGE / XCORR* softkey.

Remote command: LIST:RANG1:SWE:COUN 5 (sub-band value)

- *FFT*

Specifies the filter usage for each sub-band: FFT resolution filter or conventional filter.

Changes are only possible for Noise Analyzer measurements in *MANUAL* sweep mode. The FFT filter is only available for RBW values between 1 Hz and 10 kHz. To change a sub-band setting, focus the corresponding option and press *ENTER*. For general changes over all sub-bands, use the *USE FFT ON/OFF* softkey.

Remote command: LIST:RANG6:FILT:TYPE FFT
(sub-band value)

- *Meas Time*

Displays the estimated measurement time for each sub-band. This time is for the measurement only and does not include processing time. The values are not editable.

At the bottom of the *Carrier Frequency Offset* table, the overall measurement time for the selected span is displayed.

Remote command: SWE:TIME?

SUBSPAN RBW The *SUBSPAN RBW* softkey sets the focus on the first row of the selected span to specify the resolution bandwidth (RBW) for this sub-band in steps of 1/3/10. This softkey is only available in *MANUAL* sweep mode.

Remote command: LIST:RANG5:BWID 30

TUNING SETTINGS The *TUNING SETTINGS* softkey sets the focus on the *Meas Points* field. This softkey is only available for Spot Noise Tuning measurements.

Meas Points

Specifies the number of measurement points.

This parameter only applies to Spot Noise Tuning measurements.

Remote command: VCO:TUN:POIN 20

Settle Vdc

Specifies the settling time for *DC Port 1*.

This parameter only applies to Spot Noise Tuning measurements.

Remote command: VCO:POW:DEL 10MS

	<p><i>Settle Vtune</i></p> <p>Specifies the settling time for <i>Tuning Port 1</i>.</p> <p>This parameter only applies to Spot Noise Tuning measurements.</p> <p>Remote command: VCO:CONT:DEL 5MS</p>
Preset Settings	<p>Provides a method to configure a parameter in the <i>Carrier Frequency Offset</i> table for all sub-bands at once. Only in <i>MANUAL</i> sweep mode the <i>Preset Settings</i> group is available.</p>
RBW%	<p>The <i>RBW%</i> softkey sets the focus on the <i>RBW</i> field to specify a percentage. In the <i>Carrier Frequency Offset</i> table, every RBW value is calculated accordingly as proportion of its sub-band start frequency. The result is rounded to the nearest 1/3/10 steps.</p> <p>This softkey is only available in <i>MANUAL</i> sweep mode.</p> <p>Remote command: LIST:BWID:RAT 1</p>
AVERAGE / XCORR	<p>The softkey name and function depends on the selected measurement and configuration.</p> <p>In the Cross Correlation PLL measurement (R&S FSUP-B60), the <i>XCORR</i> softkey sets the focus on the <i>XCORR</i> field to specify the number of correlations. In the <i>Carrier Frequency Offset</i> table, all <i>XCORR</i> values are set to the specified value.</p> <p>In all Noise measurements except Cross Correlation PLL, the <i>AVERAGE</i> softkey sets the focus on the <i>Average</i> field to specify the number of sweeps. In the <i>Carrier Frequency Offset</i> table, all <i>Avg</i> values are set to the specified value.</p> <p>This softkey is only available in <i>MANUAL</i> sweep mode.</p> <p>Remote command: LIST:SWE:COUN 10</p>
USE FFT ON/OFF	<p>The <i>USE FFT ON OFF</i> softkey activates or deactivates the <i>FFT</i> options for all sub-bands that meet the following prerequisites:</p> <ul style="list-style-type: none"> • FFT filters are available (for details see “FFT” on page 4.40) • the sub-band lies within the specified span range <p>This softkey is only available for Noise Analyzer measurements in <i>MANUAL</i> sweep mode.</p> <p>Remote command: LIST:BWID:TYPE FFT</p>
XCORR OPT ON/OFF	<p>The <i>XCORR OPT ON/OFF</i> softkey activates or deactivates the <i>Optimize XCORR #</i> option. If deactivated, the number of correlations is specified by the <i>XCORR</i> values in the <i>Carrier Frequency Offset</i> table. If activated, the <i>XCORR</i> values in the <i>Carrier Frequency Offset</i> table are only maximum values and the cross correlation is only pursued as long as the measurement results are improved. Depending on the phase noise of the DUT, the measurement time is thus optimized.</p> <p>This softkey is only available for the Cross Correlation PLL measurement (R&S FSUP-B60).</p> <p>Remote command: SWE:XOPT ON</p>

VCO Measurements

Fig. 4-8 shows the *Measurement Settings (VCO)* dialog box.




Fig. 4-8 *Measurement Settings (VCO)* dialog box

Table 4-13 Softkeys and elements in the *Measurement Settings (VCO)* dialog box

Pane	Field/Option
Frequency Counter	Coupled
	Resolution
Meas Points	Tuning Meas
	Pushing Meas
Meas Time	Meas Time
	Settle Time Vdc
	Settle Time Vtune

Frequency Counter *Coupled*

Activates or deactivates the automatic setting of the frequency counter resolution and with it the measurement accuracy. If activated, the frequency counter resolution is determined automatically depending on the tuning range of the DUT.

Remote command: `VCO:FCO:COUP OFF`

Resolution

Specifies the frequency counter resolution.

This field is only available if the *Coupled* option is deactivated.

Remote command: `VCO:FCO:RES 10HZ`

Meas Points *Tuning Meas*

Specifies the number of measurement points for VCO Tuning Characteristics measurements.

Remote command: `VCO:TUN:POIN 20`

Pushing Meas

Specifies the number of measurement points for VCO DC Characteristics measurements.

Remote command: VCO:PUSH:POIN 20

**Note**

A large number of measurement points results in a high trace resolution, but also in a long measurement time. E.g. a value of 10 points would be a compromise between trace resolution and measurement time.

Meas Time

Defines the time for measuring the frequency and the level of a single measurement point and therefore specifies the sweep time.

This value is also accessible via the *QUICKSET* hotkey (see [“MEAS TIME” on page 4.13](#)).

Remote command: VCO:SWE:TIME 50MS

Settle Time Vdc

Specifies the settling time for *DC Port 1*.

Remote command: VCO:POW:DEL 10MS

Settle Time Vtune

Specifies the settling time for *Tuning Port 1*.

This value is also accessible via the *QUICKSET* hotkey (see [“SETTLE TIME” on page 4.13](#)).

Remote command: VCO:CONT:DEL 5MS

Transient Measurements

Fig. 4-9 shows the *Measurement Settings (Transient)* dialog box.




Fig. 4-9 *Measurement Settings (Transient)* dialog box

Table 4-14 Softkeys and elements in the *Measurement Settings (Transient)* dialog box

Pane	Field/List
Bandwidth Settings	Demod BW
	Low Pass
	Meas Time
Trigger Settings	Trigger Mode
	Trigger Offset
	Trigger Level

Bandwidth Settings *Demod BW*

Specifies the demodulation bandwidth. This field is also focused using the *SPAN* or *BW* key.

Remote command: `BAND:DEM 15MHZ`

Low Pass

Specifies the relative lowpass filter.

Remote command: `FILT:LPAS:FREQ:REL 10`

Meas Time

Specifies the measurement time of the FM demodulator.

Remote command: `SWE:TIME?`

Trigger Settings *Trigger Mode*

Specifies the type of trigger. This field is also focused using the *TRIG* key.

- *Free Run*

No triggering is performed.

Remote command: `TRIG:MODE IMM`

- *External*

The next measurement is triggered by the signal at the external trigger input, e.g. a gated trigger.

Remote command: TRIG:MODE EXT

- *Power*

Triggering of the measurement via signals that are outside the measurement channel.

Remote command: TRIG:MODE POW

Trigger Offset

Specifies the trigger delay. The *Trigger Offset* settings is only available if the *Trigger Mode* is set to *External* or *Power*.

Remote command: TRIG:HOLD 500us

Trigger Level

Specifies the input signal level at which the measurement will be triggered to start. The *Trigger Level* settings is only available if the *Trigger Mode* is set to *Power*.

Remote command: TRIG:LEV:POW 10DBM

DC SETTINGS

The *DC SETTINGS* softkey opens the *DC SETTINGS* dialog box.

DC SETTINGS

File: ** Default **

DC Port 1
 Enable Port:

	Min	Set	Max	Meas	
Vcc1 Voltage	3	3.3	3.5	3.3	V
Icc1 Current			50	0	mA
ΔVcc1 Pushing	100				mV

Tuning Port 1
 Enable Port:

	Min	Set	Max	Meas	
Vtune1 Voltage	0	1.5	3	1.6	V
Itune1 Current			10	0	mA

DC Port 2
 Enable Port:

	Min	Set	Max	Meas	
Vcc2 Voltage	4.75	5	5.25	0	V
Icc2 Current			50	1	mA

Tuning Port 2
 Enable Port:

	Min	Set	Max	Meas	
Vtune2 Voltage	0.5	2.5	5	0.1	V
Itune2 Current			10	0	mA

AUX Port
 Enable Port:

	Min	Set	Max	Meas	
Vaux Voltage		-5		-0.1	V
Iaux Current			-50	-3	mA

DC Switching Sequence
 Enable:

ON	OFF	Order	Voltage	Delay
↓	↑	1	Vcc1 / (Port1)	10 ms
		2	Vtune1 / (Port1)	10 ms
		3	Vaux / (AUX Port)	10 ms
		4	Vcc2 / (Port2)	10 ms
		5	Vtune2 / (Port2)	10 ms

Min: -9.50 V Max: 28 V Press enter to edit the group.

SPECTRUM SSA HOME DC POWER QUICKSET RUN PREMEAS SETTINGS

DC PORT1
TUNING PORT1
DC PORT2
TUNING PORT2
AUX PORT
SWITCHING SEQUENCE
PRESET SETTINGS
SAVE SETTINGS

Fig. 4-10 *DC SETTINGS* dialog box

In the *DC SETTINGS* dialog box, the supply voltages and tuning voltages of two independent DC ports are set (*DC Port 1* and *DC Port 2*). In addition, a negative DC voltage is available (*AUX Port*). For further details see also the Quick Start Guide, chapter 5.



Note

Setting DC voltages and currents properly is the most important step during the configuration in order not to damage the measuring object (DUT) by applying too much voltage or current!

Therefore it is recommended to connect the device under test (DUT) to the instrument after the DC settings have been made and verified.

Table 4-15 Softkeys and elements in the DC SETTINGS dialog box

Softkey/Pane	Field/Option
File	
DC PORT1 / DC PORT2	Enable Port
	Vcc1 Voltage / Vcc2 Voltage
	Icc1 Current / Icc2 Current
	Δ Vcc1 Pushing
TUNING PORT1 / TUNING PORT 2	Enable Port
	Vtune1 Voltage / Vtune2 Voltage
	Itune1 Current / Itune2 Current
AUX PORT	Enable Port
	Vaux Voltage
	Iaux Current
SWITCHING SEQUENCE	Enable
PRESET SETTINGS	
SAVE SETTINGS	

File Specifies the DC settings file for the following:

- Recalling previously saved DC settings using the **PRESET SETTINGS** softkey. The **** Default **** list entry selects the default settings.
- Saving a new set of DC settings using the **SAVE SETTINGS** softkey.



Note

For a port, the measured value is only displayed in the *Meas* column, if the following prerequisites are met:

- The DC power is switched on.
- The port is activated.

The background color of the measured results indicates whether the value is within the specified range (green) or outside the range (red).

If the DC power or the port is switched off, the measured values are displayed with a gray background.

DC PORT1 / DC PORT2 The *DC PORT1 / DC PORT2* softkeys select the port and set the focus on the *Enable Port* option.

Enable Port

Activates or deactivates the selected DC port.

This softkey is only available if the *DC Switching Sequence* is deactivated.

Remote command: SOUR:VOLT:POW1:LEV OFF

Vcc1 Voltage / Vcc2 Voltage

Specifies the supply voltage for the selected DC port:

- In the *Set* column, enter the operating point voltage.
- In the *Min* and *Max* columns, enter the minimum and maximum voltages.
- In the *Meas* column, the currently measured value is displayed.



Note

Changing the supply voltage when a measurement is running causes the following:

- The current measurement is stopped.
- A new measurement is started.

This value is also accessible via the *QUICKSET* hotkey (see [“QUICKSET” on page 4.12](#)).

Remote command: SOUR:VOLT:POW1:LEV:AMPL 5.2V
SOUR:VOLT:POW1:LEV:LIM:HIGH 6V
SOUR:VOLT:POW1:LEV:LIM:LOW 4V
SOUR:VOLT:SEQ:RES?

Icc1 Current / Icc2 Current

Specifies the supply current from the selected DC port:

- In the *Max* column, enter the maximum current.
- In the *Meas* column, the currently measured value is displayed.

Remote command: SOUR:CURR:POW1:LIM:HIGH 20MA
SOUR:CURR:SEQ:RES?

ΔVcc1 Pushing

In a Pushing measurement (*VCO PUSHING ON/OFF* softkey), specifies the supply voltage variation of *DC Port 1*. The supply voltage for the three consecutive characteristic measurements (displayed in one trace) is calculated as follows:

- V_{cc1} (*Vcc1 Voltage* value in *Set* column)
- $V_{cc1} - \Delta V_{cc1}$ Pushing
- $V_{cc1} + \Delta V_{cc1}$ Pushing

This value is also accessible via the *QUICKSET* hotkey (see [“PUSH DUT” on page 4.13](#)).

Remote command: `SOUR:VOLT:POW1:PUSH 200MV`

TUNING PORT1 / TUNING PORT 2 The *TUNING PORT1* / *TUNING PORT2* softkeys select the port and set the focus on the *Enable Port* option.

Enable Port

Activates or deactivates the selected tuning port.

This softkey is only available if the *DC Switching Sequence* is deactivated.

Remote command: `SOUR:VOLT:CONT1:LEV OFF`

Vtune1 Voltage / Vtune2 Voltage

Specifies the tuning voltage for the selected tuning port:

- In the *Set* column, enter the tuning voltage.
- In the *Min* and *Max* columns, enter the minimum and maximum voltages.
- In the *Meas* column, the currently measured value is displayed.



Note

Changing the tuning voltage when a measurement is running causes the following:

- The current measurement is stopped.
 - A new measurement is started.
-

This value is also accessible via the *QUICKSET* hotkey (see [“QUICKSET” on page 4.12](#)).

Remote command: `SOUR:VOLT:CONT1:LEV:AMPL 2V`
`SOUR:VOLT:CONT1:LEV:LIM:HIGH 4V`
`SOUR:VOLT:CONT1:LEV:LIM:LOW 1V`
`SOUR:VOLT:SEQ:RES?`

- *Itune1 Current / Itune2 Current*

Specifies the tuning current from the selected tuning port:

- In the *Max* column, enter the maximum current.
- In the *Meas* column, the currently measured value is displayed.

Remote command: `SOUR:CURR:CONT1:LIM:HIGH 20MA`
`SOUR:CURR:SEQ:RES?`

- AUX PORT** The *AUX PORT* softkey sets the focus on the *Enable Port* option.
- Enable Port*
- Activates or deactivates the Aux port.
- This softkey is only available if the *DC Switching Sequence* is deactivated.
- Remote command: SOUR:VOLT:AUX:LEV ON
- Vaux Voltage*
- Specifies the negative DC voltage for the Aux port:
- In the *Set* column, enter the required voltage.
 - In the *Meas* column, the currently measured value is displayed.
- Remote command: SOUR:VOLT:AUX:LEV:AMPL -1V
SOUR:VOLT:SEQ:RES?
- Iaux Current*
- Specifies the auxiliary current from the Aux port:
- In the *Max* column, enter the maximum current.
 - In the *Meas* column, the currently measured value is displayed.
- Remote command: SOUR:CURR:AUX:LIM:HIGH -20MA
SOUR:CURR:SEQ:RES?
- SWITCHING SEQUENCE** The *SWITCHING SEQUENCE* softkey sets the focus on the *Enable* option. Under *DC Switching Sequence*, a voltage power-up / power-down sequence for the ports is set. Typically this is only required if a DUT needs a negative DC voltage to be applied before switching on the positive voltages.
- Enable*
- If activated, the switching sequence is used. When the *DC POWER* hotkey is switched on, all activated ports are switched on in the order of *ON* column. When the *DC POWER* hotkey is switched off, all ports are switched off in the order of the *OFF* column. After each port the specified delay is applied before switching on/off the next port. All *Enable Port* options are deactivated.
- If deactivated, all ports are switched on or off simultaneously.
- To change the switching sequence, focus the *Order* column of the port and enter a number for the port position.
- Remote command: SOUR:VOLT:SEQ ON
SOUR:VOLT:SEQ:LIST VCC1,1,VCC2,1,
VTUNE1,1,VTUNE2,1,VAUX,1
- PRESET SETTINGS** The *PRESET SETTINGS* softkey sets all parameters to the values defined in the settings file specified via the [File](#) list.
- This softkey is not available, if all parameters have the alleged value.
- SAVE SETTINGS** The *SAVE SETTINGS* softkey opens the alphanumeric editor to enter the name of the file into which the DC settings are saved. The name of the file is added to the [File](#) list entries.

VCO LOOP SETTINGS

The *VCO LOOP SETTINGS* softkey opens the *VCO & LOOP SETTINGS* dialog box.

VCO & LOOP SETTINGS			
DUT Premeasurement			
	Current	Auto	
DUT Center Frequency	1.000000 GHz	<input checked="" type="checkbox"/>	
DUT Level	-0.21 dBm		
DUT Drift	0.00 Hz/s		
DUT Tuning Range	...		
DUT Slope(=K_VCO)	...		
Phase Detector			
	Current	Auto	
Phase Detector Slope (=K_PD)	705.58 mV/rad	<input checked="" type="checkbox"/>	565.31 mV/rad
Phase Detector Level	6.97 dBm		5.05 dBm
Phase Detector DC Offset	-2.54 mV		-6.82 mV
Beat Note Frequency	996.09 kHz		996.09 kHz
Used Harmonic	1	<input type="checkbox"/>	
Loop Settings			
	Current		
Generator's Slope (=K_GEN)	1.92 kHz/V		2.40 kHz/V
PLL Loop BW	3.00 kHz		

Measurement Complete

SPECTRUM SSA HOME DC POWER QUICKSET RUN PREMEAS SETTINGS

Fig. 4-11 *VCO & LOOP SETTINGS* dialog box

The *VCO & LOOP SETTINGS* dialog box contains parameters for Noise measurements. The following parameters are evaluated in the pre-measurement:

- center frequency, level, drift (under *DUT Premeasurement*)
- parameters under *Phase Detector* (Phase Noise PLL and Cross Correlation PLL measurements only)

For parameters with green background, manual input is also possible.

Table 4-16 Softkeys and elements in the VCO & LOOP SETTINGS dialog box

Softkey/Pane	Field/Option
DUT SETTINGS	DUT Center Frequency
	DUT Level
	DUT Drift
	DUT Tuning Range
	DUT Slope(= K_VCO)
	Auto
PHASE DETECTOR	Phase Detector Slope (= K_PD)
	Phase Detector Level
	Phase Detector DC Offset
	Beat Note Frequency
	Auto
	Used Harmonic
LOOP SETTINGS	Generator's Slope (= K_GEN)
	PLL Loop BW
PRESET SETTINGS	

DUT SETTINGS The *DUT SETTINGS* softkey sets the focus on the *DUT Center Frequency* field. Under *DUT Premeasurement*, the characteristic data of the DUT is displayed. The characteristic data of the DUT is measured in the pre-measurement but manual input is also possible.

DUT Center Frequency

Specifies the center frequency of the DUT.

Remote command: FREQ:CENT 100MHz
 VCO:PREM ON

DUT Level

Specifies the level of the DUT.

Remote command: POW:RLEV 1

DUT Drift

Specifies the drift of the DUT with the fixed tuning voltage.

Remote command: VCO:DRIF 300HZ/S

DUT Tuning Range

Specifies the minimum and maximum frequencies as a result of the tuning voltage variation.

This field is only available for test setups with controlled DUT (for details refer to [“SELECT CONFIG” on page 4.17](#)).

Remote command: `VCO:TRAN 10MHZ`

DUT Slope(= K_VCO)

Specifies the sensitivity of the DUT due to the small tuning voltage variations (deviation of the tuning curve).

This field is only available for test setups with controlled DUT (for details refer to [“SELECT CONFIG” on page 4.17](#)).

Remote command: `VCO:SLOP 5MHZ/V`

Auto

If the *Auto* option is activated, the center frequency, level, and drift (under *DUT Premeasurement*) are determined in the pre-measurement sequence. The result is displayed in this field.

If the *Auto* option is deactivated, none of the parameters under *DUT Premeasurement* are measured in the pre-measurement sequence.

PHASE DETECTOR

The *PHASE DETECTOR* softkey sets the focus on the *Phase Detector Slope (= K_PD)* field. Under *Phase Detector*, the corresponding settings are displayed or configured for Phase Noise PLL and Cross Correlation PLL measurements.

For details on the phase detector displays of Cross Correlation PLL measurements (R&S FSUP-B60), refer to section [“Cross Correlation Measurement - Option R&S FSUP-B60” on page 4.345](#).

Phase Detector Slope (= K_PD)

Specifies the phase detector slope.

Remote command: `VCO:PDET:SLOP 1V/RAD`
`VCO:PDET:PREM OFF`

Phase Detector Level

Specifies the phase detector level.

Remote command: `VCO:PDET:LEV 10DBM`

Phase Detector DC Offset

Specifies the phase detector DC offset.

Remote command: `VCO:PDET:OFFS 0.5V`

Beat Note Frequency

Displays the frequency measured at zero crossing of the beat note. This parameter is determined in the pre-measurement and cannot be changed.

Auto

If the *Auto* option is activated, the phase detector parameters are determined in the pre-measurement sequence. The result is displayed in this field.

If the *Auto* option is deactivated, none of the phase detector parameters are measured in the pre-measurement sequence.

Used Harmonic

Specifies the harmonic of the signal.

If the *Auto* option is deactivated, this field specifies the harmonic of the signal to be measured.

If the *Auto* option is activated, the pre-measurement determines the best harmonic to be used. The automatic detection of the best harmonic is only available for configurations that use the internal generator.

Remote command: VCO:PDET:HARM:STAT OFF
 VCO:PDET:HARM 2

LOOP SETTINGS The *LOOP SETTINGS* softkey sets the focus on the *Generator's Slope* (= *K_GEN*) field. Under *Loop Settings*, the corresponding settings are displayed or configured for Phase Noise PLL and Cross Correlation PLL measurements.

Generator's Slope (= *K_GEN*)

Specifies the measured tuning slope of the internal or external generator (depending on the selected configuration). The *PLL Loop BW* is calculated accordingly.

This field is only available for test setups without controlled DUT (for details refer to ["SELECT CONFIG" on page 4.17](#)).

Remote command: VCO:LOOP:SLOP 5MHZ/V

PLL Loop BW

Specifies the bandwidth for the phase locked loop. The start of the result range is indicated by a vertical line labelled as *Loop BW*, or by a value labelled as *Loop BW*, if the loop bandwidth lies outside the display range. The *Generator's Slope* is calculated accordingly.

**Note**

Changing the loop bandwidth when a measurement is running causes the following:

- The current measurement is stopped.
 - A new measurement is started.
-

Remote command: VCO:LOOP:BWID 20KHZ

PRESET SETTINGS The *PRESET SETTINGS* softkey sets all parameters to their default values.

SPURS SETTINGS

The *SPURS SETTINGS* softkey opens the *SPURS SETTINGS* menu to configure the spurs display. This menu is only available for Phase Noise PLL, Cross Correlation PLL (R&S FSUP-B60) and Spot Noise Tuning measurements.

SHOW ALL
SUPPRESS ALL
SHOW SELECTED
SUPPRESS SELECTED
SELECT SPURS
SPUR THRESHOLD
LIST SPURS
HIGHLIGHT SPURS
ASCII FILE EXPORT

For further details see also the Quick Start Guide, chapter 5.

**Note**

Spurs are included in the peak search. With the peak search functions (*PEAK*, *NEXT PEAK*, *NEXT PEAK RIGHT*, *NEXT PEAK LEFT* softkeys in the MKR-> menu), the marker is also positioned on maximum spurs.

SHOW ALL The *SHOW ALL* softkey displays the measured curve with all spurs. To configure the display style of spurs, use the *HIGHLIGHT SPURS* softkey.

Remote command: SPUR:SUPP NONE

SUPPRESS ALL The *SUPPRESS ALL* softkey displays the measured curve with all spurs removed.

Remote command: SPUR:SUPP ALL

SHOW SELECTED The *SHOW SELECTED* softkey displays the measured curve with the selected spurs only. The spurs are selected via the *SELECT SPURS* softkey. To configure the display style of spurs, use the *HIGHLIGHT SPURS* softkey.

Remote command: SPUR:SUPP UNS

SUPPRESS SELECTED The *SUPPRESS SELECTED* softkey displays the measured curve with the selected spurs removed. The spurs are selected via the *SELECT SPURS* softkey. To configure the display style of spurs, use the *HIGHLIGHT SPURS* softkey.

Remote command: SPUR:SUPP SEL

SELECT SPURS The *SELECT SPURS* softkey opens the *HARMONIC SPURS* dialog box to configure the spur display for the *SHOW SELECTED* and *SUPPRESS SELECTED* softkeys.

HARMONIC SPURS		
Fundamental	50 Hz	<input type="checkbox"/>
Max Order	5	
Fundamental	50 Hz	<input type="checkbox"/>
Max Order	5	

To define known or expected spurious frequencies to be displayed or suppressed, in the *Fundamental* field, enter the fundamental frequency for the spur group. In the *Max Order* field, enter the maximum order for the spur group. If the spur group is enabled (*Enable* option), the corresponding group data is used for the spur display configuration. If the spur group is disabled, the corresponding group data takes no effect.

Remote command: SPUR:SET:ENAB ON
 SPUR:SET:FUND 100KHZ
 SPUR:SET:COUNT 10

SPUR THRESHOLD The *SPUR THRESHOLD* softkey opens an edit dialog box to enter a threshold value. Only spurs above this threshold are displayed (in dBc/Hz).

Remote command: SPUR:THR 10

LIST SPURS The *LIST SPURS* softkey activates or deactivates the display of the *Spur List* (in the right corner above the measured curve). After the sweep is completed, a spur list is generated and updated after every measurement.

This softkey is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Remote command: FETC:PNO:SPUR?

HIGHLIGHT SPURS The *HIGHLIGHT SPURS* softkey configures how the spurs are displayed. If activated, the position and magnitude of the detected spurs is indicated by bars. While the measured curve is displayed in dBc/Hz, the spur level is displayed in dBc. Additionally, on the right side the y-axis is displayed in dBc, in the spur matching color. Only in this display mode, the limit lines defined for spurs are active.

If deactivated, the spurs are displayed as part of the measured curve according to their *FFT Window* form. The limit lines defined for spurs are inactive.

This softkey is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Remote command: SPUR:HIGH:STAT ON

ASCII FILE EXPORT The *ASCII FILE EXPORT* softkey stores the spurs list in a file with ASCII format. Enter a file name that includes the path and the drive name. The indication of the path complies with DOS conventions.

Remote command: MMEM:STOR:SPUR 'A:\TEST.DAT'

PRESET SETTINGS see [“PRESET SETTINGS” on page 4.50](#)

Sweep Settings – SWEEP Key

The *SWEEP* key serves for configuring the sweep mode and opens the *SWEEP* softkey menu. This section describes the functionality in phase noise mode. For a description of the *SWEEP* softkey menu in analyzer mode, refer to section “Sweep Settings – SWEEP Key” on page 4.107.

SWEEP

CONTINUOUS SWEEP
SINGLE SWEEP
SWEEP COUNT
SGL SWEEP DISP OFF

CONTINUOUS SWEEP

The *CONTINUOUS SWEEP* softkey activates the continuous sweep mode. The next measurement sweep activated (using the *RUN* hotkey) will run in continuous mode.

Remote command: INIT:CONT ON

SINGLE SWEEP

The *SINGLE SWEEP* softkey activates the single sweep mode. The next measurement sweep activated (using the *RUN* hotkey) will run in single sweep mode.

If the *SINGLE SWEEP* softkey is pressed while a continuous measurement is running, the measurement is aborted at the end of the current sweep.

Remote command: INIT:CONT OFF

SWEEP COUNT

The *SWEEP COUNT* softkey activates the entry of the number of sweeps used for averaging.

In the continuous sweep mode, averaging is performed until the set number of sweeps is attained and is continued as running averaging.

The default setting is 0. The number of sweeps used for averaging is applied to all active traces.

Remote command: SWE:COUN 64

SGL SWEEP DISP OFF

The *SGL SWEEP DISP OFF* softkey deactivates the display while a single sweep is being performed. Once the sweep has been completed the display is reactivated.

Remote command: INIT:DISP OFF

Selection and Setting of Traces – TRACE Key

The *TRACE* key opens the *TRACE* softkey menu. This section describes the functionality in phase noise mode. For general information and a description of the *TRACE* softkey menu in analyzer mode, refer to section [“Selection and Setting of Traces – TRACE Key” on page 4.118](#).

TRACE

SELECT TRACE	
CLEAR/WRITE	
MAX HOLD	
AVERAGE	
VIEW	
BLANK	
SWEEP COUNT	
SMOOTHING	
TRACE MATH ↓	T1-T3->T1
	T2-T3->T2
	TRACE MATH OFF
Side menu	
MIN HOLD	
ASCII FILE EXPORT	
DECIM SEP	
COPY TRACE	

The availability of the softkeys in the *TRACE* menu depends on the following:

- Selected measurement
- Trace functions

Active and passive traces differ in their trace functions. Active traces offer all trace modes that are available for the selected measurement. Passive traces only offer different view options ([VIEW](#), [BLANK](#), [SMOOTHING](#)), but no marker or evaluation functions.

In total, 8 traces are available. The allocation of traces (active or passive) depends on the selected measurement.

For general information on traces refer also to [“Selection and Setting of Traces – TRACE Key” on page 4.118](#).



Note

If you change the trace mode while a measurement is running, the measurement is aborted and restarted.

- SELECT TRACE** The *SELECT TRACE* softkey opens a dialog box to select a trace memory via a numeric entry, value range 1 to 8.
- Remote command: -- (selected via numeric suffix of TRACe)
- CLEAR/WRITE** The *CLEAR/WRITE* softkey activates the overwrite mode for the collected measured values for the active trace, i.e. the trace is overwritten by each sweep.
- Remote command: DISP:TRAC:MODE WRIT
- MAX HOLD** The *MAX HOLD* softkey activates the max hold function. The R&S FSUP saves the sweep result in the trace memory only if the new value is greater than the previous one.
- Pressing the *MAX HOLD* softkey again clears the trace memory and restarts the max hold function.
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL, Phase Noise Analyzer and Transient measurements.
- Remote command: DISP:TRAC:MODE MAXH
- AVERAGE** The *AVERAGE* softkey activates the trace averaging function for the active trace.
- In single sweep mode, the averaging is performed over the requested number of sweeps.
- For details on the methods for calculating the average refer to ["Description of averaging" on page 4.120](#).
- Remote command: DISP:TRAC:MODE AVER
- VIEW** The *VIEW* softkey freezes the current contents of the active trace memory and displays it. If a trace is frozen, the instrument settings can be changed without the displayed trace being modified. In contrast, the R&S FSUP automatically adapts the measured data to the display range if the display settings are changed.
- Remote command: DISP:TRAC:MODE VIEW
- BLANK** The *BLANK* softkey activates the blanking of the active trace.
- Remote command: DISP:TRAC OFF

SWEEP COUNT

The *SWEEP COUNT* softkey activates the entry of the number of sweeps used for averaging.

The default setting is 0. The number of sweeps used for averaging is the same for all active traces in the selected diagram.

**Note**

The setting of the sweep count in the *TRACE* menu is equivalent to the setting in the *SWEEP* menu.

Remote command: `SWE:COUN 64`

SMOOTHING

If the *SMOOTHING* softkey is activated, the trace on the screen is smoothed by the smoothing percentage and type defined via the [“TRACE SETTINGS” on page 4.25](#). Changing the setting of this softkey has an immediate effect on the displayed active trace. Each trace can be smoothed or not smoothed individually.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: `DISP:TRAC1:SMO OFF`

Description of Smoothing

The three available smoothing types use the following smoothing algorithms:

- Linear smoothing

$$y'(s) = 10 \cdot \log_{10} \left(\frac{1}{n} \sum_{x=s-\frac{n-1}{2}}^{x=s+\frac{n-1}{2}} 10^{\left(\frac{y(x)}{10}\right)} \right)$$

- Logarithmic smoothing

$$y'(s) = \frac{1}{n} \sum_{x=s-\frac{n-1}{2}}^{x=s+\frac{n-1}{2}} y(x)$$

- Median smoothing

$$y'(s) = 10 \cdot \log_{10} \left(\text{median} \left(10^{\left(\frac{y\left(s - \frac{(n-1)}{2}\right)}{10} \right)}, \dots, 10^{\left(\frac{y\left(s + \frac{(n-1)}{2}\right)}{10} \right)} \right) \right)$$

Where:

- s = the trace sample number
- y(s) = the phase noise at sample s
- x = the sample offset from s
- n = the width of the sliding window

If x exceeds the boundary samples, the boundary sample is used.

Example for linear smoothing

If the trace has samples numbering 0 to 500 then with $n = 5$ and $s = 0$ the average is calculated as follows:

$$y'(0) = 10 \cdot \log_{10} \left(\frac{1}{5} \left(3 \cdot 10^{\left(\frac{v(0)}{10} \right)} + 10^{\left(\frac{v(1)}{10} \right)} + 10^{\left(\frac{v(2)}{10} \right)} \right) \right)$$

If both trace averaging and smoothing are specified, the trace smoothing is applied first, and averaging is performed on the smoothed trace.

If smoothing is applied to a trace, the original (not smoothed) trace is still held in memory. This makes it possible to toggle between a smoothed and not smoothed trace without the need to run a new measurement sweep.

TRACE MATH

The *TRACE MATH* softkey opens a submenu to calculate the difference between traces.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

- T1-T3->T1 The *T1-T3* softkey subtracts the corresponding traces. The result displayed is displayed in trace 1. To indicate that the trace has been obtained by subtraction, the difference "1 - 3" is indicated as trace information.

This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.

Remote command: `CALC1:MATH (TRACE1-TRACE3)`

- T2-T3->T2** The *T2-T3* softkey subtracts the corresponding traces. The result displayed is displayed in trace 2. To indicate that the trace has been obtained by subtraction, the difference "2 - 3" is indicated as trace information.
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.
- Remote command: `CALC1:MATH (TRACE2-TRACE3)`
- TRACE MATH OFF** The *TRACE MATH OFF* softkey switches the math function off.
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.
- Remote command: `CALC1:MATH:STAT OFF`
- MIN HOLD** The *MIN HOLD* softkey activates the minimum hold function. The R&S FSUP saves for each sweep the smallest of the previously stored/currently measured values in the trace memory. In this way, the minimum value of a signal can be determined over several sweeps.
- Pressing the *MIN HOLD* softkey again clears the trace memory and restarts the minimum hold function.
- This softkey is only available for Phase Noise PLL, Cross Correlation PLL and Phase Noise Analyzer measurements.
- Remote command: `DISP:TRAC:MODE MINH`
- ASCII FILE EXPORT** The *ASCII FILE EXPORT* softkey stores the active trace in ASCII format on a floppy disk. For further details refer to "[ASCII FILE EXPORT](#)" on page 4.124.
- DECIM SEP** The *DECIM SEP* softkey selects the decimal separator between '.' (decimal point) and ',' (comma) with floating-point numerals for the [ASCII FILE EXPORT](#) function.
- With the selection of the decimal separator different language versions of evaluation programs (e.g. Microsoft Excel) can be supported.
- Remote command: `FORM:DEXP:DSEP POIN`
- COPY TRACE** The *COPY TRACE* softkey opens a dialog box to select a trace memory via a numeric entry, value range 1 to 8. The R&S FSUP copies the screen contents of the selected trace ([SELECT TRACE](#) softkey) into the selected trace memory.
- Upon copying, the contents of the trace memory is overwritten. The new contents is displayed in mode of the trace it was copied from.
- Remote command: `TRAC:COPY TRACE3,TRACE1`

Marker Functions – MKR Key

This section describes the functionality in phase noise mode. For a description of the *MKR* softkey menu in analyzer mode, refer to section [“Markers and Delta Markers – MKR Key” on page 4.134](#).

The markers are provided for marking points on traces, reading out measurement results and for quickly selecting a display section. All markers can be used either as markers or delta markers.

The *MKR* key opens the *MKR* softkey menu. The softkeys of the *MKR* menu are only available if measurement results are existent.

MKR

MARKER 1 / MARKER 2 / MARKER 3 / MARKER 4
MARKER NORM DELTA
MARKER ZOOM
ALL MARKER OFF
Side menu
MKR->TRACE
LINK MKR1 AND DELTA1

MARKER 1 / MARKER 2 / MARKER 3 / MARKER 4

The *MARKER 1/2/3/4* softkey opens an edit dialog box for the corresponding marker (1 to 4) to adjust the marker position. As soon as the entry is confirmed, the marker position in the trace is updated, along with the results displayed for the marker.

The *MARKER 3* softkey is not available for VCO DC Characteristics and VCO Summary measurements.

The *MARKER 4* softkey is not available for VCO measurements.

For further details refer to [“Working with Markers” on page 4.65](#).

Remote command: `CALC1:MARK3 ON`
 `CALC1:MARK2:X <value>`
 `CALC1:MARK:Y?`

MARKER NORM DELTA

The *MARKER NORM DELTA* softkey toggles the currently active marker between normal and delta marker mode.

This softkey is not available for VCO measurements except the Harmonic Power measurement. For VCO Harmonic Power measurements, a delta marker reads out the relative level of the harmonic (in dBc) compared to the fundamental.

For further details refer to [“Working with Markers” on page 4.65](#).

Remote command: `CALC1:DELT ON`
 `CALC1:DELT2:X <value>`
 `CALC1:DELT:Y?`

- MARKER ZOOM** The *MARKER ZOOM* softkey opens an edit dialog box to enter a value in order to zoom the trace around marker 1.
- This softkey is not available for Spot Noise Tuning, VCO and Transient measurements.
- Remote command: `CALC1:MARK1:FUNC:ZOOM 10`
- ALL MARKER OFF** The *ALL MARKER OFF* softkey switches off all markers and delta markers. It also switches off all functions and displays associated with the markers/delta markers.
- Remote command: `CALC1:MARK:AOFF`
`CALC1:DELT:AOFF`
- MKR->TRACE** The *MKR->TRACE* softkey opens an edit dialog box to select the trace for the active marker. The active marker is placed on the selected trace.
- Remote command: `CALC1:MARK3:TRAC 2`
`CALC1:DELT:TRAC 1`
- LINK MKR1 AND DELTA1** The *LINK MKR1 AND DELTA1* softkey activates or deactivates the linking of delta marker 1 to marker 1. If linked and marker 1 is moved on the x-axis, delta marker 1 will follow it maintaining a relative offset of zero. The linking is off by default.
- This softkey is not available for VCO measurements.
- Remote command: `CALC1:DELT1:LINK ON`

Working with Markers

To adjust the marker position, change the marker mode between normal and delta and switch the marker display on and off, do the following:

- *MARKER <n>* softkey has a grey background (marker is not displayed)
 - Press the *MARKER 1/2/3/4* softkey, to open the corresponding dialog box and switch on the marker.
The associated marker becomes the currently active marker and you can move it.
 - To change the state of this marker, press the *MARKER NORM DELTA* softkey.
Markers can be configured either as normal or delta markers. Normal markers show an absolute marker position, delta markers show a marker position result relative to the normal marker 1. Because delta marker results are relative to marker 1, switching off marker 1 also causes all delta markers to be switched off.
- *MARKER <n>* softkey has a red background (dialog box is displayed)
 - To switch off the marker, press the *MARKER 1/2/3/4* softkey.
- *MARKER <n>* softkey has a green background (marker is displayed)
 - To display the corresponding dialog box, press the *MARKER 1/2/3/4* softkey.

Assigning Markers to Traces – MKR-> Key

Pressing the *MKR->* key displays the corresponding softkey menu. This menu is not available for Spot Noise Tuning and VCO measurements. For the other measurements, the softkeys of the *MKR->* menu are only available if measurement results are existent.

This section describes the functionality in phase noise mode. For a description of the *MKR->* softkey menu in analyzer mode, refer to section [“Change of Settings via Markers – MKR-> Key” on page 4.150](#).

MKR->

SELECT MARKER
PEAK
REF LEVEL = MKR LVL
NEXT PEAK
NEXT PEAK RIGHT
NEXT PEAK LEFT
MKR->TRACE
Side menu
MIN
NEXT MIN
NEXT MIN RIGHT
NEXT MIN LEFT
PEAK EXCURSION

SELECT MARKER

The *SELECT MARKER* softkey opens the *Select Marker* dialog box to select a marker (1 to 4). The entry 0 selects delta marker 1. As soon as a marker has been selected, the corresponding *MARKER 1/2/3/4* dialog box is displayed to adjust the position of the selected marker.

Remote command: `CALC1:MARK1 ON`
 `CALC1:MARK2:X <value>`
 `CALC1:MARK1:Y`

PEAK

The *PEAK* softkey sets the active marker/delta marker to the peak of the trace. Spurs are included in the peak search. If no marker is active when *MKR->* menu is called, marker 1 is automatically switched on and the peak search is performed.

Remote command: `CALC1:MARK2:MAX`
 `CALC1:DELT3:MAX`
 `CALC:MARK:X:SPUR?`
 `CALC:DELT:X:SPUR?`

REF LEVEL = MKR LVL

The *REF LEVEL = MKR LVL* softkey sets the reference level to the current marker level.

This softkey is only available for Transient Power measurements.

Remote command: `CALC1:MARK2:FUNC:REF`

NEXT PEAK

The *NEXT PEAK* softkey sets the active marker/delta marker to the next lower maximum of the selected trace. Maxima are identified according to the peak excursion value (*PEAK EXCURSION* softkey). Spurs are included in the peak search.

Remote command: `CALC1:MARK2:MAX:NEXT`
 `CALC1:DELT2:MAX:NEXT`
 `CALC:MARK:X:SPUR?`
 `CALC:DELT:X:SPUR?`

NEXT PEAK RIGHT

The *NEXT PEAK RIGHT* softkey sets the active marker/delta marker to the next lower maximum right of the current marker position on the selected trace. Maxima are identified according to the peak excursion value (*PEAK EXCURSION* softkey). Spurs are included in the peak search.

Remote command: `CALC1:MARK2:MAX:RIGH`
 `CALC1:DELT:MAX:RIGH`
 `CALC:MARK:X:SPUR?`
 `CALC:DELT:X:SPUR?`

NEXT PEAK LEFT

The *NEXT PEAK LEFT* softkey sets the active marker/delta marker to the next lower maximum left of the current marker position the selected trace. Maxima are identified according to the peak excursion value (*PEAK EXCURSION* softkey). Spurs are included in the peak search.

Remote command: `CALC1:MARK2:MAX:LEFT`
 `CALC1:DELT:MAX:LEFT`
 `CALC:MARK:X:SPUR?`
 `CALC:DELT:X:SPUR?`

MKR->TRACE

The *MKR->TRACE* softkey opens the *Marker To Trace* dialog box to assign the currently active marker to a trace. To select the currently active marker, use the *SELECT MARKER* softkey.

Remote command: `CALC1:MARK:TRAC 2`
 `CALC1:DELT3:TRAC 3`

MIN

The *MIN* softkey sets the active marker/delta marker to the minimum of the selected trace.

Remote command: `CALC1:MARK2:MIN`
 `CALC1:DELT3:MIN`

NEXT MIN

The *NEXT MIN* softkey sets the active marker/delta marker to the next higher minimum of the selected trace.

Remote command: `CALC1:MARK2:MIN:NEXT`
 `CALC1:DELT2:MIN:NEXT`

Selection of the Measurement Function – MEAS Key

Pressing the *MEAS* key or the *SSA* hotkey displays the *MEAS* softkey menu. The settings for the measurements are adjusted via the *SETTINGS* hotkey (see section “[SETTINGS Hotkey Menu](#)” on page 4.17). The *QUICKSET* hotkey (“[QUICKSET Hotkey Menu](#)” on page 4.12) provides a fast access to important settings.

For a detailed description of all measurements functions in analyzer mode refer to section “[Analyzer Mode](#)” on page 4.82.

MEAS

NOISE MEAS ↓	PH NOISE PLL
	PH NOISE ANALYZER
	SPOT NOISE VS TUNING
	REF MEAS
VCO MEAS ↓	VCO TUNING CHAR
	VCO TUNING SENSITIVITY
	VCO RF PWR CHAR
	VCO PUSHING ON/OFF
	VCO PULLING ON/OFF
	HARMONIC PWR
	VCO DC CHAR
	VCO SUMMARY
	X-AXIS VOLT/FREQ
	Side menu
	PUSH/PULL REL/ABS
TRANSIENT MEAS ↓	TRANSIENT FREQ
	TRANSIENT PHASE
	TRANSIENT AMPT
	TRANSIENT PWR
	DEMOD BW
	MEAS TIME
	RANGE

NOISE MEAS

The *NOISE MEAS* softkey opens the softkey menu for Noise measurements. For details refer also to chapter 2 and to the Quick Start Guide, chapter 5.

Settings are described in sections “[Noise Measurements](#)” on page 4.19 (general settings), “[Noise Measurements](#)” on page 4.37 (measurement settings).

Remote command: TRAC:DATA?
 residual noise results:
 FETC:PNO:RFM?
 FETC:PNO:RPM?
 FETC:PNO:RMS?

PH NOISE PLL

The *PH NOISE PLL* softkey activates one of the phase noise measurement, depending on the selected test setup:

- Phase Noise PLL (all test setups except *PLL MODE / int 3*)

The abbreviation PLL stands for phase locked loop. For further details refer to the Quick Start Guide, chapter 5.

Remote command: CONF:PNO:MEAS PLL

- Cross Correlation PLL (*PLL MODE / int 3*)

This measurement is only available if the R&S FSUP-B60 option is installed. For details refer to section “[Cross Correlation Measurement - Option R&S FSUP-B60](#)” on page 4.345.

Remote command: CONF:PNO:MEAS CCOR

PH NOISE ANALYZER

The *PH NOISE ANALYZER* softkey activates the Phase Noise Analyzer measurement. For further details refer to chapter 2, section “[Phase Noise Measurements \(Phase Noise Analyzer\)](#)” on page 2.11.


Remote command: CONF:PNO:MEAS SPEC

SPOT NOISE VS TUNING

The *SPOT NOISE VS TUNING* softkey activates a phase noise measurement of the following procedure. During a succession of n measurements, the tuning voltage is altered. 5 frequency points - defined in the [GENERAL SETTINGS](#) dialog box, *Offset Freq1/2/3/4/5* field -are evaluated. The measurement result shows the developing of these frequency points as 5 curves with different spot noise offsets (see [Fig. 4-12](#)).

Remote command: CONF:PNO:MEAS SNT

R&S FSUP Signal Source Analyzer						
Settings		Results			Spot Noise [Vtune 1.8 V] w/o spurs	
Signal Frequency:	128.001952 MHz	Tuning	Voltage	Frequency	1.000 kHz	-109.30 dBc/Hz
Signal Level:	3.28 dBm	Vmin	0.00 V	128.003 MHz	10.000 kHz	-135.44 dBc/Hz
Spot Noise Tuning	Harmonic 1	Vcurrent	1.02 V	128.002 MHz	100.000 kHz	-151.81 dBc/Hz
Internal Ref Tuned	Internal Phase Det	Vmax	1.80 V	128.002 MHz	1.000 MHz	-160.47 dBc/Hz



Date: 3.JUL.2007 16:00:08

Fig. 4-12 Spot Noise Tuning measurement

REF MEAS The *REF MEAS* softkey starts a reference measurement for Phase Noise Analyzer measurements. This softkey is only available if the *PH NOISE ANALYZER* softkey is switched on.

Remote command: CONF:REFM ONCE

VCO MEAS	<p>The <i>VCO MEAS</i> softkey opens the softkey menu for Characteristic Curve measurements (VCO for voltage controlled oscillator). For details refer also to chapter 2, section “Characteristic Curve Measurement Results” on page 2.4, and the Quick Start Guide, chapter 5.</p> <p>Settings are described in sections “VCO Measurements” on page 4.28 (general settings), “VCO Measurements” on page 4.42 (measurement settings).</p> <p>Remote command: TRAC:DATA?</p>
VCO TUNING CHAR	<p>The <i>VCO TUNING CHAR</i> softkey activates the VCO Tuning Characteristic measurement (f_{DUT} vs. U_{Tune}). For details refer to the Quick Start Guide, chapter 5.</p> <p>Remote command: CONF:VCO:MEAS TCH FETC:VCO:TCH:FREQ? FETC:VCO:PUSH:FDEV? FETC:VCO:PULL:FDEV? (R&S FSUP-B28)</p>
VCO TUNING SENSITIVITY	<p>The <i>VCO TUNING SENSITIVITY</i> softkey activates the VCO Tuning Sensitivity measurement. The tuning sensitivity is determined by computing the differential quotient $\Delta f_{DUT}/\Delta U_{TUNE}$ of two neighbored measurement points. For details refer to the Quick Start Guide, chapter 5.</p> <p>Remote command: CONF:VCO:MEAS TSEN FETC:VCO:TCH:SENS? FETC:VCO:PUSH:SENS? FETC:VCO:PULL:SENS? (R&S FSUP-B28)</p>
VCO RF PWR CHAR	<p>The <i>VCO RF PWR CHAR</i> softkey activates the VCO RF Power measurement (P_{DUT} vs. U_{Tune}). For details refer to the Quick Start Guide, chapter 5.</p> <p>Remote command: CONF:VCO:MEAS RFP FETC:VCO:TCH:POW? FETC:VCO:PUSH:PDEV? FETC:VCO:PULL:PDEV? (R&S FSUP-B28)</p>
VCO PUSHING ON/OFF	<p>The <i>VCO PUSHING ON/OFF</i> softkey activates or deactivates a Pushing measurement. The measurement identifies the impact of a DC supply voltage change on the characteristic curve. Three consecutive characteristic measurements with variation in DC supply voltage are performed and displayed in one trace.</p> <p>The DC supply voltage variation is defined in the <i>DC SETTINGS</i> dialog box, <i>ΔV_{cc1} Pushing</i> field. The resolution is varied using the PUSH/PULL REL/ABS softkey. For further details see also section “Pushing” on page 2.5.</p> <p>This softkey is not available for the Harmonic Power and VCO DC Characteristic measurements. If this softkey is switched on, the VCO PULLING ON/OFF softkey is automatically switched off.</p> <p>Remote command: CONF:VCO:PUSH ON</p>

VCO PULLING ON/
OFF The *VCO PULLING ON/OFF* softkey activates or deactivates a Pulling measurement. The measurement identifies the impact of a load change on the characteristic curve. Three consecutive characteristic measurements with a variation in load are performed and displayed in one trace. The load variation is controlled via the R&S FSUP-B28 option (for details refer to the Quick Start Guide, chapter 1). Therefore this softkey only takes effect with the R&S FSUP-B28 option installed.

For further details see also section [“Pulling” on page 2.8](#). Details on the R&S FSUP-B28 option are given in section [“Trigger Port – Option R&S FSP-B28” on page 4.343](#).

The resolution is varied using the *PUSH/PULL REL/ABS* softkey.

This softkey is not available for the Harmonic Power and VCO DC Characteristic measurements. If this softkey is switched on, the *VCO PUSHING ON/OFF* softkey is automatically switched off.

Remote command: `CONF:VCO:PULL ON`

HARMONIC PWR The *HARMONIC PWR* softkey activates the Harmonic Power measurement (DUT’s harmonic frequencies vs. tuning voltage). For details refer to the Quick Start Guide, chapter 5.

Remote command: `CONF:VCO:MEAS HPOW`
 `FETC:VCO:HCH1:FREQ?`
 `FETC:VCO:HCH2:POW:ABS?`
 `FETC:VCO:HCH2:POW:REL?`
 `FETC:VCO:HCH3:SENS?`

VCO DC CHAR The *VCO DC CHAR* softkey activates the VCO DC Characteristic measurement (DUT’s characteristic vs supply voltage). The measurement shows the impact of a DC supply voltage sweep on the VCO’s center frequency and level. For further details see also section [“DC Characteristic” on page 2.9](#).

Remote command: `CONF:VCO:MEAS DCCH`
 `FETC:VCO:DCH:FREQ?`
 `FETC:VCO:DCH:POW?`

VCO SUMMARY The *VCO SUMMARY* softkey activates a measurement that summarizes the VCO characteristic results. For details refer to the Quick Start Guide, chapter 5.

Remote command: CONF:VCO:MEAS SUMM
 SOUR:VOLT:SEQ:RES?
 SOUR:CURR:SEQ:RES?
 SOUR:POW:SEQ:RES?
 SOUR:VOLT:CONT1:LEV:LIM:LOW?
 SOUR:VOLT:CONT1:LEV:AMPL
 SOUR:VOLT:CONT1:LEV:LIM:HIGH
 FETC:VCO:TCH:FREQ?
 FETC:VCO:TCH:POW?
 FETC:VCO:TCH:SENS?
 SOUR:VOLT:POW1:PUSH
 FETC:VCO:PUSH:FDEV?
 FETC:VCO:PUSH:PDEV?
 FETC:VCO:PUSH:SENS?
 FETC:VCO:PULL:PDEV? (R&S FSUP-B28)
 FETC:VCO:PULL:FDEV? (R&S FSUP-B28)
 FETC:VCO:PULL:SENS? (R&S FSUP-B28)

X-AXIS VOLT/FREQ The *X-AXIS VOLT/FREQ* softkey sets the x-axis scaling to Volt or Hz per division.

This softkey is not available for the VCO DC Characteristic or VCO Summary measurements or if the *VCO PUSHING ON/OFF* or *VCO PULLING ON/OFF* softkey is switched on.

Remote command: DISP:TRAC:X:UNIT VOLT

PUSH/PULL REL/ABS The *PUSH/PULL REL/ABS* softkey sets the relative or absolute display of the Pushing/Pulling measurement.

- REL

The relative setting increases the resolution to distinguish the three curves individually, if are too close together.

The basic curve (DC set to nominal value) is used as a reference and is displayed as a straight line. The two other curves are displayed relative to the basic curve. The scaling is adapted accordingly.

- ABS

The three curves are displayed with normal scaling.

This softkey is only available if the *VCO PUSHING ON/OFF* or *VCO PULLING ON/OFF* softkey is switched on. For further details see also section “Pushing ” on page 2.5.

Remote command: CONF:VCO:PUSH:SCAL ABS
 CONF:VCO:PULL:SCAL ABS (R&S FSUP-B28)

TRANSIENT MEAS	<p>The <i>TRANSIENT MEAS</i> softkey opens the softkey menu for Transient measurements. Transient measurements are used for observing power-on and settling processes of oscillators and frequency synthesizers. For details refer also to the Quick Start Guide, chapter 5.</p> <p>Settings are described in sections “Transient Measurements” on page 4.33 (general settings), “Transient Measurements” on page 4.44 (measurement settings).</p> <p>Remote command: TRAC:DATA? CALC:MARK:FUNC:ADEM:CARR?</p>
TRANSIENT FREQ	<p>The <i>TRANSIENT FREQ</i> softkey activates the Transient Frequency measurement.</p> <p>Remote command: CONF:TRAN:MEAS FREQ CALC:MARK:FUNC:ADEM:FM? PPE CALC:MARK:FUNC:ADEM:FERR?</p>
TRANSIENT PHASE	<p>The <i>TRANSIENT PHASE</i> softkey activates the Transient Phase measurement.</p> <p>Remote command: CONF:TRAN:MEAS PHAS CALC:MARK:FUNC:ADEM:PM? PPE CALC:MARK:FUNC:ADEM:FERR?</p>
TRANSIENT AMPT	<p>The <i>TRANSIENT AMPT</i> softkey activates the Transient Amplitude measurement.</p> <p>Remote command: CONF:TRAN:MEAS AMPL CALC:MARK:FUNC:ADEM:AM? PPE</p>
TRANSIENT PWR	<p>The <i>TRANSIENT PWR</i> softkey activates the Transient Power measurement.</p> <p>Remote command: CONF:TRAN:MEAS POW</p>
DEMODO BW	<p>The <i>DEMODO BW</i> softkey opens an edit dialog box for data entry. This entry corresponds to the <i>Demod BW</i> field in the <i>Measurement Settings (Transient)</i> dialog box. For further details refer to “Demod BW” on page 4.44.</p>
MEAS TIME	<p>The <i>MEAS TIME</i> softkey opens an edit dialog box for data entry. This entry corresponds to the <i>Meas Time</i> field in the <i>Measurement Settings (Transient)</i> dialog box. For further details refer to “Meas Time” on page 4.44.</p>
RANGE	<p>The <i>RANGE</i> softkey opens the <i>General Settings (Transient)</i> dialog box with focus on the <i>Autoscale Once</i> field. For further details refer to “Y-Axis Settings” on page 4.35.</p>

Setup of Limit Lines – LINES Key

This section describes the functionality in phase noise mode. For a description of the *LINES* softkey menu in analyzer mode, refer to section “[Setup of Limit Lines and Display Lines – LINES Key](#)” on page 4.208.

LINES

The *LINES* key opens the *Limit Line* selection dialog box and the *LINES* softkey menu.




Fig. 4-13 *Limit Line* selection dialog box

The *Limit Line* selection dialog box displays limit line information in two lists. In the lower list, all existing limit lines are listed with status, compatibility and comment.

- status (*Check* column)
Specifies whether the limit line is enabled and disabled.
To enable or disable a limit line, proceed according to the step-by-step instruction “[Enabling or Disabling Limit Lines](#)” on page 4.79.
- compatibility of the limit line to the current measurement settings (*Comp.* column)

Remote command: `CALC:LIM3:COMP?`

In the upper list, additional information on the selected limit line is displayed. To change this information or view/edit the defined limit line values, press the *EDIT* softkey (see Fig. 4-14). For step-by-step instructions refer to “[Editing or Creating Limit Lines](#)” on page 4.77.

Using the *LINES* softkey menu, you can add new limit lines, edit existing limit lines, and delete limit lines.

NEW
EDIT
DELETE

NEW

The *NEW* softkey opens the *Limit Line* data dialog box (see Fig. 4-14) and the corresponding submenu to define a new limit line. For further details refer to section “[Editing or Creating Limit Lines](#)” on page 4.77.

EDIT The *EDIT* softkey opens the *Limit Line* data dialog box (see Fig. 4-14) and the corresponding submenu to edit the selected limit line. For further details refer to section “Editing or Creating Limit Lines” on page 4.77.

DELETE The *DELETE* softkey deletes the limit line selected in the *Limit Line* selection dialog box (see Fig. 4-13).

Remote command: `CALC:LIM1:DEL`

Editing or Creating Limit Lines

Pressing the *NEW* or *EDIT* softkey opens the *Limit Line* data dialog box.




Fig. 4-14 *Limit Line* data dialog box

To edit or create limit lines, the following softkey menu is provided:

NAME
VALUE
INSERT
DELETE
SAVE

NAME The *NAME* softkey sets the focus on the *Name* field to enter a unique name using the alphanumeric editor. The name can contain any combination of numbers, letters and characters. If the name is not unique, the line cannot be saved and an error message is displayed.

Remote command: `CALC:LIM1:NAME 'FM1'`

Domain Specifies the domain: frequency or time. If you change the domain, the table with the limit line values is updated accordingly.

Units	<p>Specifies the limit line unit. The unit defines usage of a limit line:</p> <ul style="list-style-type: none"> • dBc for spur limit lines <p>These limit lines are only active if the spurs are displayed in bar form (HIGHLIGHT SPURS softkey is activated).</p> <ul style="list-style-type: none"> • dBc/Hz for Noise measurement limit lines • other units for the available measurements in phase noise mode <p>Remote command: <code>CALC:LIM4:UNIT DBCHZ</code></p>
Limit	<p>Specifies the limit line type: upper or lower.</p>
X Scaling/Y Scaling	<p>Displays the scaling of the x- and y-axis.</p>
Trace No.	<p>Specifies the trace to which the limit line is to be applied. Each limit may only be applied to one trace at a time. Each trace may have multiple limit lines applied to it.</p> <p>Remote command: <code>CALC:LIM2:TRAC 3</code></p>
Comment	<p>Gives a textual description of the limit line. The comment can contain any combination of numbers, letters and characters.</p> <p>Remote command: <code>CALC:LIM5:COMM 'Upper limit for spectrum'</code></p>
VALUE	<p>The <i>VALUE</i> softkey sets the focus on the <i>Frequency</i> column to specify the limit line values.</p> <p>Remote command: <code>CALC:LIM2:CONT 1MHz,30MHz,100MHz,300MHz,1GHz</code> <code>CALC:LIM2:LOW -30,-40,-10,-40,-30</code> <code>CALC:LIM2:UPP -10,0,0,-10,-5</code> <code>CALC:LIM2:CONT:SHIF 50KHZ</code> <code>CALC:LIM3:LOW:SHIF 20DBM</code> <code>CALC:LIM3:UPP:SHIF 20DBM</code> <code>CALC:LIM2:CONT:DOM FREQ</code> <code>CALC:LIM4:UNIT DBCHZ</code></p>
Frequency/Time Limits/<unit>	<p>The table lists the limit values for specific frequency values. The table can contain up to 100 frequency/limit value pairs. The order of frequency values must be in ascending order.</p> <p>Navigate through the table in all four directions using the cursor keys. An editable parameter in the table is highlighted. To insert or delete rows, press the INSERT or DELETE softkey. To save a limit line, press the SAVE softkey.</p>
INSERT	<p>The <i>INSERT</i> softkey inserts a new row in the <i>Frequency Limits/Bc/Hz</i> table directly above the row currently selected. The focus is set on the new row ready for entry.</p> <p>If the maximum number of entries in the <i>Frequency Limits/Bc/Hz</i> table has been reached, the <i>INSERT</i> softkey is disabled.</p>

DELETE The *DELETE* softkey deletes the currently selected row in the *Frequency | Limits/Bc/Hz* table. No confirmation is required for this action. The cursor is moved to the next row.

SAVE The *SAVE* softkey saves the new limit line or the changes of a limit line. If the data contain entries that are not allowed, an error message is displayed and saving is aborted.

To discard the changes, press the *ESC* key. A message box is displayed to define whether the limit line data should be stored or not. Select *No* and press *ENTER* to confirm the action.

Enabling or Disabling Limit Lines

1. In the *Limit Line* selection dialog box (see [Fig. 4-13](#)), focus the required limit line.

The selected limit line is highlighted.

2. Press the *ENTER* key to change the state of the limit line from enabled to disabled and vice versa.

If a limit line is enabled, a tick symbol is shown in the *Check* field. The limit line is displayed in the relevant results graph, and limit checking is performed.

If a limit line is disabled, it is not displayed in the relevant results graph, and no limit checking for this line is performed.

Remote command:

```
CALC:LIM:STAT ON
CALC:LIM4:LOW:STAT ON
CALC:LIM4:UPP:STAT ON
CALC:LIM3:FAIL?
CALC:LIM:CLE
CALC:LIM1:COPY 2
```



Note

Only one limit line of each type can be active at a given time.

Instrument Setup and Interface Configuration - SETUP Key

In phase noise mode (SSA hotkey), the setup menu (*SETUP* key) offers less functionality than in analyzer mode (*SPECTRUM* hotkey), as shown in [Table 4-17](#).



Note

If you miss a softkey when performing a task, check which mode is active (the corresponding hotkey is highlighted). If necessary, change to the analyzer mode by pressing the *SPECTRUM* hotkey. For a detailed description of the *SETUP* softkey menu in analyzer mode, refer to section “Instrument Setup and Interface Configuration – SETUP Key” on page 4.227.

SETUP

Table 4-17 Softkeys in the *SETUP* menu

REFERENCE INT/EXT	
NOISE SRC ON/OFF	
GENERAL SETUP	GPIB ADDRESS
	CONFIGURE NETWORK
	NETWORK LOGIN
SERVICE	INPUT RF
	INPUT CAL
	SELFTEST
	SELFTEST RESULTS
	PAGE UP
	PAGE DOWN
	Side menu
	CAL GEN 128 MHZ
	CAL GEN COMB
Side menu	
FIRMWARE UPDATE	
PRESET SSA	
PRESET ANALYZER	
IF SHIFT	

REFERENCE INT/ EXT

For details refer to “REFERENCE INT / EXT” on page 4.229.

NOISE SRC ON/OFF	For details refer to “NOISE SRC ON/OFF” on page 4.230.
GENERAL SETUP	The GENERAL SETUP softkey opens a submenu for remote control and network settings.
GPIB ADDRESS	For details refer to “GPIB ADDRESS” on page 4.237.
CONFIGURE NETWORK	For details refer to “CONFIGURE NETWORK” on page 4.244.
NETWORK LOGIN	For details refer to “NETWORK LOGIN” on page 4.245.
SERVICE	The SERVICE softkey opens a submenu for maintenance and/or trouble shooting.
INPUT RF	For details refer to “INPUT RF” on page 4.252.
INPUT CAL	For details refer to “INPUT CAL” on page 4.252.
SELFTTEST	For details refer to “SELFTTEST” on page 4.254.
SELFTEST RESULTS	For details refer to “SELFTEST RESULTS” on page 4.254.
PAGE UP	For details refer to “PAGE UP / PAGE DOWN” on page 4.254.
PAGE DOWN	For details refer to “PAGE UP / PAGE DOWN” on page 4.254.
CAL GEN 128 MHZ	For details refer to “CAL GEN 128 MHZ” on page 4.253.
CAL GEN COMB	For details refer to “CAL GEN COMB PULSE” on page 4.253.
FIRMWARE UPDATE	For details refer to “FIRMWARE UPDATE” on page 4.255.
PRESET SSA	For details refer to “PRESET SSA” on page 4.255.
PRESET ANALYZER	For details refer to “PRESET ANALYZER” on page 4.255.
IF SHIFT	For details on this softkey and its submenu refer to “IF SHIFT” on page 4.256.

Analyzer Mode

The analyzer mode is activated by pressing the *SPECTRUM* hotkey (see also section [“Mode Selection – Hotkey Bar”](#) on page 4.8)

SPECTRUM

The *SPECTRUM* hotkey selects the mode for spectrum analysis, the so-called analyzer mode.

Do not mistake the *analyzer mode* for the *Phase Noise Analyzer* which is a measurement provided in phase noise mode. For details on the phase noise mode refer to [“Phase Noise Mode”](#) on page 4.11.

The functions provided correspond to those of a conventional spectrum analyzer. The R&S FSUP measures the frequency spectrum of the test signal over the selected frequency range with the selected resolution and sweep time, or, for a fixed frequency, displays the waveform of the video signal.



Note

If two displays (screen A and screen B) are opened after switch-on of signal analysis, the analyzer mode is only set for the display activated for entry (marked at the top right corner of diagram). For the other display, the previous settings remain valid.

Data acquisition and display of measured values is sequential: first in the upper and then in the lower display.

QUICKSET Hotkey Menu

The *QUICKSET* hotkey is available both in the analyzer mode (*SPECTRUM* hotkey) and the phase noise mode (*SSA* hotkey). The description provided in this section only applies to the analyzer mode. For details of the menu in phase noise mode refer to section “[QUICKSET Hotkey Menu](#)” on page 4.12.

In analyzer mode, the *QUICKSET* hotkey offers access to the DC settings.

QUICKSET

Table 4-18 Softkeys in the *QUICKSET* menu (analyzer mode)

DC PORT 1/2	
SUPPLY DUT	
TUNE DUT	
AUX DUT	
SUPPLY ENABLE	
TUNE ENABLE	
AUX ENABLE	
PORT LIMITS ↓	SUPPLY U MAX
	SUPPLY U MIN
	SUPPLY I MAX
	TUNE U MAX
	TUNE U MIN
	TUNE I MAX
	AUX I MAX
SWITCHING SEQUENCE	
Side menu	
SERVICE SETTINGS ↓	

DC PORT 1/2

For details refer to “[DC PORT1 / DC PORT2](#)” on page 4.48.

SUPPLY DUT

For details refer to “[Vcc1 Voltage / Vcc2 Voltage](#)” on page 4.48.

TUNE DUT

For details refer to “[TUNE DUT1](#)” on page 4.13.

AUX DUT

Specifies the auxiliary current from the Aux port. For details refer to “[AUX PORT](#)” on page 4.50.

SUPPLY ENABLE

This softkey activates or deactivates the DC port 1. For details refer to “[DC PORT1 / DC PORT2](#)” on page 4.48.

TUNE ENABLE

This softkey activates or deactivates the tuning port 1. For details refer to “[TUNING PORT1 / TUNING PORT 2](#)” on page 4.49.

AUX ENABLE	This softkey activates or deactivates the aux port. For details refer to “AUX PORT” on page 4.50.
PORT LIMITS	This softkey opens a submenu to edit the port limits.
SUPPLY U MAX	This softkey sets the maximum supply voltage. For details refer to “DC PORT1 / DC PORT2” on page 4.48.
SUPPLY U MIN	This softkey sets the minimum supply voltage. For details refer to “DC PORT1 / DC PORT2” on page 4.48.
SUPPLY I MAX	This softkey sets the maximum supply current. For details refer to “DC PORT1 / DC PORT2” on page 4.48.
TUNE U MAX	This softkey sets the maximum tuning voltage. For details refer to “TUNING PORT1 / TUNING PORT 2” on page 4.49.
TUNE U MIN	This softkey sets the minimum tuning voltage. For details refer to “TUNING PORT1 / TUNING PORT 2” on page 4.49.
TUNE I MAX	This softkey sets the maximum tuning current. For details refer to “TUNING PORT1 / TUNING PORT 2” on page 4.49.
AUX I MAX	This softkey sets the maximum aux current. For details refer to “AUX PORT” on page 4.50.
SWITCHING SEQUENCE	This softkey activates or deactivates the switching sequence. For details refer to “SWITCHING SEQUENCE” on page 4.50.
SERVICE SETTINGS	This softkey is only available for the service. For further details refer to section “SERVICE” on page 4.252.
Remote command:	FETC:EXT:LOWP:FREQ? CONF:EXT:LOWP ONCE

Frequency and Span Selection – *FREQ* Key

The *FREQ* key is used to specify the frequency axis of the active display window. The frequency axis can be defined either by the start and stop frequency or by the center frequency and the span (*SPAN* key). With two windows (*SPLIT SCREEN*) displayed at the same time, the input data always refer to the window selected in the *SYSTEM - DISPLAY* menu.

The softkeys in the *CF STEPSIZE* menu depend on the selected domain: frequency domain or time domain.

FREQ

CENTER	
CF STEPSIZE ↓	0.1 * SPAN / 0.1 * RBW
	0.5 * SPAN / 0.5 * RBW
	X * SPAN / X * RBW
	= CENTER
	= MARKER
	MANUAL
START	
STOP	
FREQUENCY OFFSET	
SIGNAL TRACK ↓	TRACK ON/OFF
	TRACK BW
	TRACK THRESHOLD
	SELECT TRACE
EXTERNAL MIXER (option B21)	

CENTER

The *CENTER* softkey opens the window for manually entering the center frequency.

The allowed range of values for the center frequency is:

- for the frequency domain (span >0):

$$\text{minspan} / 2 \leq f_{\text{center}} \leq f_{\text{max}} - \text{minspan} / 2$$
- and for the time domain (span = 0):

$$0 \text{ Hz} \leq f_{\text{center}} \leq f_{\text{max}}$$

f_{center} center frequency

minspan smallest selectable span > 0 Hz (10 Hz)

f_{max} max. frequency

Remote command: `FREQ:CENT 100MHz`

CF STEPSIZE

The *CF STEPSIZE* softkey opens a submenu for setting the step size of the center frequency. The step size can be coupled to the span (frequency domain) or the resolution bandwidth (time domain) or it can be manually set to a fixed value. The softkeys are mutually exclusive selection keys.

The softkeys are presented according to the selected domain (frequency or time).

Softkeys in frequency domain:

0.1 * SPAN The *0.1 * SPAN* softkey sets the step size for the center frequency entry to 10% of the span.

Remote command: `FREQ:CENT:STEP:LINK SPAN`
 `FREQ:CENT:STEP:LINK:FACT 10PCT`

0.5 * SPAN The *0.5 * SPAN* softkey sets the step size for the center frequency entry to 50% of the span.

Remote command: `FREQ:CENT:STEP:LINK SPAN`
 `FREQ:CENT:STEP:LINK:FACT 50PCT`

X * SPAN The *X * SPAN* softkey allows the factor defining the center frequency step size to be entered as % of the span.

Remote command: `FREQ:CENT:STEP:LINK SPAN`
 `FREQ:CENT:STEP:LINK:FACT 20PCT`

= CENTER The *= CENTER* softkey sets the step size coupling to *MANUAL* and the step size to the value of the center frequency. This function is especially useful during measurements of the signal harmonic content because by entering the center frequency each stroke of the *STEP* key selects the center frequency of another harmonic.

Remote command: `--`

= MARKER The *= MARKER* softkey sets the step size coupling to *MANUAL* and the step size to the value of the marker. This function is especially useful during measurements of the signal harmonic content at the marker position because by entering the center frequency each stroke of the *STEP* key selects the center frequency of another harmonic.

Remote command: `--`

MANUAL The *MANUAL* softkey activates the window for entering a fixed step size.

Remote command: `FREQ:CENT:STEP 120MHZ`

Softkeys in time domain:

0.1 * RBW The *0.1 * RBW* softkey sets the step size for the center frequency entry to 10% of the resolution bandwidth.

*AUTO 0.1 * RBW* corresponds to the default setting.

Remote command: FREQ:CENT:STEP:LINK RBW
FREQ:CENT:STEP:LINK:FACT 10PCT

0.5 * RBW The *0.5 * RBW* softkey sets the step size for the center frequency entry to 50% of the resolution bandwidth.

Remote command: FREQ:CENT:STEP:LINK RBW
FREQ:CENT:STEP:LINK:FACT 50PCT

X * RBW The *X * RBW* softkey allows the factor defining the center frequency step size to be entered as % of the resolution bandwidth.

Values between 1 and 100% in steps of 1% are allowed. The default setting is 10%.

Remote command: FREQ:CENT:STEP:LINK RBW
FREQ:CENT:STEP:LINK:FACT 20PCT

= CENTER The *= CENTER* softkey sets the step size coupling to *MANUAL* and the step size to the value of the center frequency. This function is especially useful during measurements of the signal harmonic content because by entering the center frequency each stroke of the *STEP* key selects the center frequency of another harmonic.

Remote command: --

= MARKER The *= MARKER* softkey sets the step size coupling to *MANUAL* and the step size to the value of the marker. This function is especially useful during measurements of the signal harmonic content at the marker position because by entering the center frequency each stroke of the *STEP* key selects the center frequency of another harmonic.

Remote command: --

MANUAL The *MANUAL* softkey activates the window for entering a fixed step size.

Remote command: FREQ:CENT:STEP 120MHz

START The *START* softkey activates the window for manually entering the start frequency.

The allowed range of values for the start frequency is:

$$0 \text{ Hz} \leq f_{\text{start}} \leq f_{\text{max}} - \text{minspan}$$

f_{start} start frequency

minspan smallest selectable span (10 Hz)

f_{max} max. frequency

Remote command: FREQ:STAR 20MHz

STOP	<p>The <i>STOP</i> softkey activates the window for entering the stop frequency.</p> <p>The allowed range of values for the stop frequency is:</p> $\text{minspan} \leq f_{\text{stop}} \leq f_{\text{max}}$ <p>f_{stop} stop frequency minspan smallest selectable span (10 Hz) f_{max} max. frequency</p> <p>Remote command: <code>FREQ:STOP 2000MHz</code></p>
FREQUENCY OFFSET	<p>The <i>FREQUENCY OFFSET</i> softkey activates the window for entering an arithmetical frequency offset which is added to the frequency axis labelling. The allowed range of values for the offset is -100 GHz to 100 GHz. The default setting is 0 Hz.</p> <p>Remote command: <code>FREQ:OFFS 10 MHz</code></p>
SIGNAL TRACK	<p>The <i>SIGNAL TRACK</i> softkey switches on the tracking of a signal near the center frequency. The signal is tracked as long it is in the search bandwidth around the center frequency defined with <i>TRACK BW</i> and above the level threshold defined with <i>TRACK THRESHOLD</i>.</p> <p>For that purpose, the maximum signal is searched (<i>PEAK SEARCH</i>) on the screen and the center frequency set to this signal (<i>MARKER ->CENTER</i>) after each frequency sweep within the search bandwidth.</p> <p>If the signal falls below the level threshold or jumps out of the search bandwidth around the center frequency, the center frequency is not varied until a signal is in the search bandwidth above the level threshold. This can be achieved by manually modifying the center frequency, for example.</p> <p>On switching on, the softkey is highlighted and the search bandwidth and the threshold value are marked on the diagram by two vertical lines and one horizontal line. All these lines are provided with the designation TRK.</p> <p>At the same time a submenu is opened in which the search bandwidth, the threshold value and the trace can be modified for the maximum search.</p> <p>The softkey is only available in the frequency domain (span >0).</p> <p>Remote command: <code>CALC:MARK:FUNC:STR OFF</code></p>
TRACK ON/OFF	<p>The <i>TRACK ON/OFF</i> softkey switches on and off signal tracking.</p> <p>Remote command: <code>CALC:MARK:FUNC:STR OFF</code></p>
TRACK BW	<p>The <i>TRACK BW</i> softkey defines the search bandwidth for signal tracking. The frequency range is symmetrical with respect to the center frequency.</p> <p>Remote command: <code>CALC:MARK:FUNC:STR:BAND 10KHZ</code></p>
TRACK THRESHOLD	<p>The <i>TRACK THRESHOLD</i> softkey defines the threshold value for signal detection. The value is always entered as an absolute level value.</p> <p>Remote command: <code>CALC:MARK:FUNC:STR:THR -70DBM</code></p>

SELECT TRACE The *SELECT TRACE* softkey selects the trace on which signal tracking is to be performed.

Remote command: CALC:MARK:FUNC:STR:TRAC 1

Setting the Frequency Span – SPAN Key

The *SPAN* key opens a menu which offers various options for setting the span.

The entry of the span (*SPAN MANUAL* softkey) is automatically active for span > 0 Hz.

For span = 0 Hz the entry for sweep time (*SWEPTIME MANUAL*) is automatically active.

With two windows (*SPLIT SCREEN*) displayed at the same time, the input data always refer to the window selected with the *SCREEN A/B* hotkey.

SPAN

SPAN MANUAL
SWEPTIME MANUAL
FULL SPAN
ZERO SPAN
LAST SPAN
FREQ AXIS LIN/LOG

SPAN MANUAL

The *SPAN MANUAL* softkey activates the window for manually entering the frequency span. The center frequency is kept constant.

Allowed range of span values:

- for the time domain (span = 0): 0 Hz
- and for the frequency domain (span >0): $\text{minspan} \leq f_{\text{span}} \leq f_{\text{max}}$

f_{span} frequency span

minspan smallest selectable span (10 Hz)

f_{max} max. frequency

Remote command: `FREQ:SPAN 2GHz`

SWEPTIME MANUAL

The *SWEPTIME MANUAL* softkey activates the window for entering the sweep time manually with Span = 0 Hz. The softkey is not available for Span > 0 Hz.

Remote command: `SWE:TIME 10s`

FULL SPAN

The *FULL SPAN* softkey sets the span to the full frequency range of R&S FSUP.

Remote command: `FREQ:SPAN:FULL`

ZERO SPAN

The *ZERO SPAN* softkey sets the span to 0 Hz. The x-axis becomes the time axis with the grid lines corresponding to 1/10 of the current sweep time (SWT).

Remote command: `FREQ:SPAN 0Hz`

LAST SPAN

After changing the span setting the *LAST SPAN* softkey activates the previous setting. With this function a fast change between overview measurement (*FULL SPAN*) and detailed measurement (manually set center frequency and span) is possible.

**Note**

Only values > 0 Hz are restored, i.e. a transition between time and frequency domain is not possible.

Remote command: --

**FREQ AXIS LIN/
LOG**

The *FREQ AXIS LIN/LOG* softkey switches between linear and logarithmic scaling of the frequency axis. Switch over is only possible if the stop/start frequency ratio is ≥ 10 .

The default state is LIN.

The logarithmic frequency axis is only available in analyzer mode and it is not available in zero span mode, in external mixer mode, with frequency offset or if the ratio stop frequency / start frequency is below 1.4.

Remote command: `DISP:WIND<1|2>:TRAC:X:SPAC LIN`

Level Display Setting and RF Input Configuration – AMPT Key

The *AMPT* key is used to set the reference level, the maximum level and the display range of the active window as well as the input impedance and the input attenuation of the RF input.

The *AMPT* key opens a menu for setting the reference level and the input attenuation of the active window. The data entry for the reference level (*REF LEVEL* softkey) is opened automatically.

Further settings regarding level display and attenuation can be made in this menu.

AMPT

REF LEVEL	
RANGE LOG 100 dB	
RANGE LOG MANUAL	
RANGE LINEAR ↓	RANGE LINEAR %
	RANGE LINEAR dB
UNIT ↓	dBm
	dBmV
	dB μ V
	dB μ A
	dB μ W
	VOLT
	AMPERE
	WATT
RF INPUT AC/DC	
RF ATTEN MANUAL	
RF ATTEN AUTO	
MIXER ↓	MIXER LVL AUTO
	MIXER LVL MANUAL
Side menu	
REF LEVEL POSITION	
REF LEVEL OFFSET	
GRID ABS/REL	
EL ATTEN AUTO (option B25)	
EL ATTEN MANUAL (option B25)	
EL ATTEN OFF (option B25)	
RF INPUT 50 Ohm / 75 Ohm	

REF LEVEL The *REF LEVEL* softkey allows the reference level to be input in the currently active unit (dBm, dB μ V, etc.)

Remote command: `DISP:WIND:TRAC:Y:RLEV -60dBm`

RANGE LOG 100 dB The *RANGE LOG 100 dB* softkey sets the level display range to 100 dB.

Remote command: `DISP:WIND:TRAC:Y:SPAC LOG`
`DISP:WIND:TRAC:Y 100DB`

RANGE LOG MANUAL The *RANGE LOG MANUAL* softkey activates the manual entry of the level display range. Display ranges from 1 to 200 dB are allowed in 10 dB steps. Inputs which are not allowed are rounded to the next valid value.

The default setting is 100 dB.

Remote command: `DISP:WIND:TRAC:Y:SPAC LOG`
`DISP:WIND:TRAC:Y 120DB`

RANGE LINEAR The *RANGE LINEAR* softkey selects linear scaling for the level display range of the R&S FSUPr. In addition, it opens a submenu for selecting % or dB for the scaling.

When linear scaling is selected, the % scaling is first activated (see also *RANGE LINEAR dB* softkey).

Remote command: `DISP:WIND:TRAC:Y:SPAC LIN`

RANGE LINEAR % The *RANGE LINEAR %* softkey selects linear scaling in % for the level display range, i.e. the horizontal lines are labelled in %. The grid is divided in decadic steps. Markers are displayed in the selected unit; delta markers are displayed in % referenced to the voltage value at the position of marker 1.

Remote command: `DISP:WIND:TRAC:Y:SPAC LIN`

RANGE LINEAR dB The *RANGE LINEAR dB* softkey selects linear scaling in dB for the level display range, i.e. the horizontal lines are labelled in dB.

Markers are displayed in the selected unit; delta markers are displayed in dB referenced to the power value at the position of marker 1.

Remote command: `DISP:WIND:TRAC:Y:SPAC LDB`

UNIT

dBm
dBmV
dB μ V
dB μ A
dB μ W
VOLT
AMPERE
WATT

The *UNIT* softkey opens a submenu allowing to select the unit for the level axis.

The default setting is dBm.

In general, the R&S FSUP measures the signal voltage at the RF input. The level display is calibrated in rms values of an unmodulated sinewave signal. In the default state, the level is displayed at a power of 1 mW (= dBm). Via the known input resistance of 50 Ω or 75 Ω , conversion to other units is possible. The units dBm, dBmV, dB μ V, dB μ A, dBpW, V, A and W are directly convertible.

Remote command: `CALC:UNIT:POW DBM`

RF INPUT AC/DC

The *RF INPUT AC/DC* softkey toggles the RF input of the R&S FSUP between AC and DC coupling.



Note

The softkey is only available for models 3, 8 and 26.

Remote command: `INP:COUP AC`

RF ATTEN MANUAL

The *RF ATTEN MANUAL* softkey allows the attenuation to be entered irrespective of the reference level.

The attenuation can be set in 5 dB steps between 0 and 75 dB.

Other entries will be rounded to the next lower integer value.

If the defined reference level cannot be set for the given RF attenuation, the reference level will be adjusted accordingly and the warning "Limit reached" will be output.



Note

The 0 dB value can be entered only via the numeric keypad in order to protect the input mixer against overload.

Remote command: `INP:ATT 40 DB`

RF ATTEN AUTO

The *RF ATTEN AUTO* softkey sets the RF attenuation automatically as a function of the selected reference level.

This ensures that the optimum RF attenuation desired by the user is always used.

RF ATTEN AUTO is the default setting.

Remote command: `INP:ATT:AUTO ON`

MIXER	<p>The <i>MIXER</i> softkey opens a submenu for defining the maximum mixer level attainable for the selected reference level.</p>
MIXER LVL AUTO	<p>The <i>MIXER LVL AUTO</i> softkey activates the automatic calculation of the mixer level dependent on the selected reference level and the selected RF attenuation.</p> <p>Remote command: INP:MIX:AUTO ON</p>
MIXER LVL MANUAL	<p>The <i>MIXER LVL MANUAL</i> softkey allows the maximum mixer level attainable at the reference level to be entered.</p> <p>The available range is 0 to -100 dBm in 10 dB steps.</p> <p>Remote command: INP:MIX -25DBM</p>
REF LEVEL POSITION	<p>The <i>REF LEVEL POSITION</i> softkey allows the reference level position to be entered.</p> <p>The setting range is from -200 to +200%, 0% corresponding to the lower and 100% to the upper limit of the diagram.</p> <p>Remote command: DISP:WIND:TRAC:RPOS 100PCT</p>
REF LEVEL OFFSET	<p>The <i>REF LEVEL OFFSET</i> softkey allows the arithmetic level offset to be entered. This offset is added to the measured level irrespective of the selected unit. The scaling of the y-axis is changed accordingly.</p> <p>The setting range is ± 200 dB in 0.1 dB steps.</p> <p>Remote command: DISP:WIND:TRAC:RLEV:OFFS -10dB</p>
GRID ABS/REL	<p>The <i>GRID ABS/REL</i> softkey switches between absolute and relative scaling of the level axis.</p> <p>GRID ABS is the default setting.</p> <p>ABS The labelling of the level lines refers to the absolute value of the reference level.</p> <p>REL The upper line of the grid is always at 0 dB. The scaling is in dB whereas the reference level is always in the set unit (dBm, dBmV,...).</p> <p>For setting <i>RANGE LINEAR</i> (linear scaling, labelling of axes in %) the softkey is not displayed since the unit % itself implies a relative scale.</p> <p>Remote command: DISP:WIND:TRAC:Y:MODE ABS</p>

**RF INPUT 50 Ohm /
75 Ohm**

The *RF INPUT 50 Ω / 75 Ω* softkey switches the input impedance of the instrument between 50 Ω (= default setting) and 75 Ω.

The setting 75 Ω should be used if the input impedance (50 Ω) is transformed to 75 Ω using the corresponding adapter unit of type RAZ (= 25 Ω in series to the input impedance of the R&S FSUP). The correction value used for the adoption is 1.76 dB = 10 log (75Ω / 50Ω).

All levels specified in this operating manual refer to the default setting of the instrument (50 Ω).

Remote command: INP:IMP 50OHM

Electronic Attenuator

Besides the mechanical attenuator at the RF input, the R&S FSUP also offers an electronic attenuation setting (option ELECTRONIC ATTENUATOR B25). The attenuation range is 0 to 30 dB, with the default attenuation being preset by the mechanical attenuator.

EL ATTEN MANUAL

The *EL ATTEN MANUAL* softkey switches the electronic attenuator on and allows the attenuation of the electronic attenuator to be set.

The attenuation can be varied in 5 dB steps from 0 to 30 dB. Other entries are rounded to the next lower integer value.

If the defined reference level cannot be set for the given RF attenuation, the reference level will be adjusted accordingly and the warning "Limit reached" will be output.

Remote command: INP:EATT:AUTO OFF
 INP:EATT 10 DB

This function is only available with option ELECTRONIC ATTENUATOR B25.

EL ATTEN AUTO

The *EL ATTEN AUTO* softkey switches the electronic attenuator on and automatically sets its attenuation to 0 dB.

The allowed setting range of the reference level ranges from the current reference level on switching on the electronic attenuator to over 30 dB. If a reference level is set outside the allowed 30-dB range, setting is performed by means of the mechanical attenuator. From this new reference level to over 30 dB the setting is again performed with the electronic attenuator.

Remote command: INP:EATT:AUTO ON

This function is only available with option ELECTRONIC ATTENUATOR B25.

EL ATTEN OFF

The *EL ATTEN OFF* softkey switches the electronic attenuator off.

Remote command: INP:EATT:STAT OFF

This function is only available with option ELECTRONIC ATTENUATOR B25.

Setting the Bandwidths and Sweep Time – BW Key

The *BW* key calls a menu for setting the resolution bandwidth (*RBW*), video bandwidth (*VBW*) and sweep time (*SWT*) for the frequency sweep. The parameters may be coupled dependent on the span (stop minus start frequency) or freely set by the user. When working with a split screen display, the settings always refer to the active window.

The R&S FSUP offers resolution bandwidths from 10 Hz to 20 MHz in 1, 2, 3, 5, 10 steps and additionally 50 MHz as maximum bandwidth.

Resolution bandwidths up to 100 kHz are realized using digital bandpasses with Gaussian characteristics. As far as the attenuation characteristic is concerned they behave like analog filters but have a much higher measurement speed than comparable analog filters. This is due to the fact that the transient response can be compensated as a result of an accurately defined filter behavior.

Bandwidths above 100 kHz are realized using decoupled 5-circuit LC filters.

As an alternative to the analog filters, FFT filters are available for the bandwidths between 1 Hz and 30 kHz. When working with bandwidths up to 30 kHz, the FFT algorithm offers considerably higher measurement speeds with all the other settings remaining the same. The reason is that with analog filters the sweep time required for a particular span is proportional to $(\text{Span}/\text{RBW}^2)$. When using the FFT algorithm, however, the sweep time is proportional to (Span/RBW) .

The video bandwidths are available in 1, 2, 3, 5, 10 steps between 1 Hz and 10 MHz (to 30 MHz for resolution bandwidth > 10 MHz). They can be set in accordance with the resolution bandwidth.

The video filters serve for smoothing the displayed trace. Video bandwidths that are small compared to the resolution bandwidth average out noise peaks and pulsed signals, so that only the signal average is displayed. If pulsed signals are to be measured, it is recommended to use a video bandwidth that is large compared to the resolution bandwidth ($\text{VBW} \geq 10 \times \text{RBW}$) for the amplitudes of pulses to be measured correctly.



Note

For analog and digital filters, the R&S FSUP has overload reserves of different magnitude above the reference level. Due to the LO breakthrough the overload display OVLD responds with digital filters with $\text{RBW} < 100 \text{ kHz}$, as soon as the start frequency is selected $< 6 \times$ resolution bandwidth, for $\text{RBW} = 100 \text{ kHz}$, as soon as the start frequency is below 3 MHz.

BW

RES BW MANUAL	
VIDEO BW MANUAL	
SWEEPTIME MANUAL	
RES BW AUTO	
VIDEO BW AUTO	
SWEEPTIME AUTO	
COUPLING RATIO ↓	RBW/VBW SINE [1/3]
	RBW/VBW PULSE [0.1]
	RBW/VBW NOISE [10]
	RBW/VBW MANUAL
	SPAN/RBW AUTO [50]
	SPAN/RBW MANUAL
DEFAULT COUPLING	
FILTER TYPE	
Side menu	
MAIN PLL BANDWIDTH	
FFT FILTER MODE	
VBW MODE LIN/LOG	

The *BW* key opens a menu for setting the resolution bandwidth, the video bandwidth, the sweep time and their couplings.

The ...*BW AUTO* softkeys are used to couple the functions. The coupling ratios are selected by means of the *COUPLING RATIO* softkey.

The ...*BW MANUAL* softkeys allow a parameter to be entered. This parameter is not coupled to the other parameters.

**Note**

With the ...*BW AUTO* softkeys the resolution bandwidth, the video bandwidth and the sweep time can be entered separately for the frequency domain (span > 0 Hz) and the time domain (span = 0 Hz).

But with ...*BW MANUAL* softkeys the selected values apply to both the frequency and time domain.

RES BW MANUAL

The *RES BW MANUAL* softkey activates the manual data entry for the resolution bandwidth.

The resolution bandwidth can be selected in 1/2/3/5/10 steps in the range between 10 Hz and 20 MHz. Additionally a maximum bandwidth of 50 MHz is available. The nominal resolution bandwidth is the 3 dB bandwidth.

When FFT filters are used, the lower limit of the bandwidth is 1 Hz. FFT filters may be used with bandwidths up to 30 kHz.

For numeric inputs, the values are always rounded to the nearest possible bandwidth. For rotary knob or UP/DOWN key inputs, the bandwidth is adjusted in steps either upwards or downwards.

For filter type CHANNEL or RRC, the bandwidth is selected from the list of available channel filters given in section “Filter Types” on page 4.103.

For data entry, the cursor keys  and  scroll through this list.

The manual input mode of the resolution bandwidth is indicated by a green asterisk (*) on the display.

Remote command: `BAND:AUTO OFF;`
 `BAND 1MHz`

VIDEO BW MANUAL

The *VIDEO BW MANUAL* softkey activates the manual data entry for the video bandwidth.

The video bandwidth can be selected in 1/2/3/5/10 steps in the range between 1 Hz and 10 MHz.

For numeric inputs, the values are always rounded to the nearest possible allowed bandwidth. For rotary knob or UP/DOWN key inputs, the bandwidth is adjusted in steps either downwards or upwards.

The manual input mode of the video bandwidth is indicated by a green asterisk (*) on the display.

Remote command: `BAND:VID:AUTO OFF;`
 `BAND:VID 10 kHz`

SWEEPTIME MANUAL

The *SWEEPTIME MANUAL* softkey activates the manual data entry for the sweep time. At the same time, the coupling of the sweep time is cancelled. Other couplings (*VIDEO BW*, *RES BW*) remain effective.

In the frequency domain (span > 0 Hz) and for resolution bandwidths above 1 kHz, the allowed sweep times for spans > 3.2 kHz range from 2.5 ms through to 16000 s. With spans below 3.2 kHz, the maximum allowed sweep time is reduced to 5 s * span/Hz.

If FFT filters are used, the sweep time is fixed by the span and the bandwidth and therefore cannot be set.

In time domain (span = 0 Hz), the range of sweep times is 1 μs to 16000 s is selectable in steps of max. 5% of the sweep time. For numeric inputs, rounding is made to the nearest possible sweep time. For rotary knob or UP/DOWN key inputs, the sweep time is adjusted in steps either downwards or upwards.

The manual input mode of the sweep time is indicated by a green asterisk (*) on the display. If the selected sweep time is too short for the selected bandwidth and span, level measurement errors will occur. This happens because the available settling time for the resolution or video filters is too short. In this case, the R&S FSUP outputs *UNCAL* on the display and marks the indicated sweep time with a red asterisk (*).

Remote command: SWE:TIME:AUTO OFF;
 SWE:TIME 10s

RES BW AUTO

The *RES BW AUTO* softkey couples the resolution bandwidth to the selected span. Changing the span causes automatic adjustment of the resolution bandwidth.

Automatic coupling of resolution bandwidth to span is always recommended when a favorable setting of the resolution bandwidth in relation to the selected span is desired for the measurement under request.

The coupling ratio is set in the *COUPLING RATIO* submenu.

The *RES BW AUTO* softkey is only available in the frequency domain (span > 0 Hz). The softkey is deactive in the time domain.

Remote command: BAND:AUTO ON

VIDEO BW AUTO

The *VIDEO BW AUTO* softkey couples the video bandwidth to the resolution bandwidth. If the resolution bandwidth is changed, the video bandwidth is automatically adjusted.

The coupling of the video bandwidth is always recommended when the minimum sweep time is required for a selected resolution bandwidth. Narrower video bandwidths require longer sweep times due to the longer settling time. Wider bandwidths reduce the signal/noise ratio.

The coupling ratio is set in the *COUPLING RATIO* submenu.

The coupling of the video bandwidth to the resolution filter is also permitted for the time domain display (span = 0).

Remote command: BAND:VID:AUTO ON

SWEEPTIME AUTO

The *SWEEPTIME AUTO* softkey couples the sweep time to the span, video bandwidth (VBW) and resolution bandwidth (RBW). The sweep time is automatically adjusted on any change in span, resolution bandwidth or video bandwidth.

The softkey is only available in the frequency domain (span >0 Hz). It is blanked in the time domain.

The R&S FSUP always selects the shortest sweep time possible without falsifying the signal. The maximum level error compared to using a longer sweep time is < 0.1 dB. If additional bandwidth and level errors are to be avoided, the sweep time is to be set to three times the time offered in coupled mode.

Remote command: SWE:TIME:AUTO ON

COUPLING RATIO

The *COUPLING RATIO* softkey opens a submenu for selection of the coupling ratios.

RBW/VBW SINE [1/3]
RBW/VBW PULSE [0.1]
RBW/VBW NOISE [10]
RBW/VBW MANUAL
SPAN/RBW AUTO [50]
SPAN/RBW MANUAL

When the default setting is active, i.e. the *COUPLING RATIO* softkey is deactivated (not highlighted), the ratio span/resolution bandwidth (SPAN/RBW) is 50 (this corresponds to SPAN / RBW AUTO [50]) and the ratio resolution bandwidth/video bandwidth (RBW/VBW) is 0.33 (this corresponds to RBW / VBW SINE [1/3]).

If the ratio RBW/VBW or SPAN/RBW is different from the default setting, the *COUPLING RATIO* softkey is highlighted.

The softkeys *RBW/VBW...* are selection keys. Only one softkey can be enabled at any one time. The softkeys are only effective for the *VBW AUTO* selection in the main menu.

The softkeys *SPAN/RBW...* are also selection keys. They are only effective for the *RBW AUTO* selection in the main menu.

RBW/VBW SINE [1/3]

The *RBW/VBW SINE [1/3]* softkey sets the following coupling ratio:

video bandwidth = 3 × resolution bandwidth.

This is the default setting for the coupling ratio resolution bandwidth/video bandwidth.

This is the coupling ratio recommended if sinusoidal signals are to be measured.

Remote command: `BAND:VID:RAT 3`

This setting is only effective for the *VBW AUTO* selection in the main menu.

**RBW/VBW
PULSE [0.1]**

The *RBW/VBW PULSE [0.1]* softkey sets the following coupling ratio:

video bandwidth = 10 × resolution bandwidth or

video bandwidth = 10 MHz (= max. VBW).

This coupling ratio is recommended whenever the amplitudes of pulsed signals are to be measured correctly. The IF filter is exclusively responsible for pulse shaping. No additional evaluation is performed by the video filter.


Remote command: `BAND:VID:RAT 10`

This setting is only effective for the *VBW AUTO* selection in the main menu.

RBW/VBW NOISE [10]	<p>The <i>RBW/VBW NOISE [10]</i> softkey sets the following coupling ratio: video bandwidth = resolution bandwidth/10</p> <p>At this coupling ratio, noise and pulsed signals are suppressed in the video domain. For noise signals, the average value is displayed.</p> <p>Remote command: <code>BAND:VID:RAT 0.1</code></p> <p>This setting is only effective for the <i>VBW AUTO</i> selection in the main menu.</p>
RBW/VBW MANUAL	<p>The <i>RBW/VBW MANUAL</i> softkey activates the manual input of the coupling ratio.</p> <p>The resolution bandwidth/video bandwidth ratio can be set in the range 0.001 to 1000.</p> <p>Remote command: <code>BAND:VID:RAT 10</code></p> <p>This setting is only effective for the <i>VBW AUTO</i> selection in the main menu.</p>
SPAN/RBW AUTO [50]	<p>The <i>SPAN/RBW AUTO [50]</i> softkey sets the following coupling ratio: resolution bandwidth = span/50</p> <p>This coupling ratio is the default setting of the R&S FSUP</p> <p>Remote command: <code>BAND:RAT 0.02</code></p> <p>This setting is only effective for the <i>RBW AUTO</i> selection in the main menu.</p>
SPAN/RBW MANUAL	<p>The <i>SPAN/RBW MANUAL</i> softkey activates the manual input of the coupling ratio.</p> <p>The span / resolution bandwidth ratio can be set in the range 1 to 10000.</p> <p>Remote command: <code>BAND:RAT 0.1</code></p> <p>This setting is only effective for the <i>RBW AUTO</i> selection in the main menu.</p>
DEFAULT COUPLING	<p>The <i>DEFAULT COUPLING</i> softkey sets all coupled functions to the default state (<i>AUTO</i>). In addition, the ratio <i>RBW/VBW</i> is set to <i>SINE [1/3]</i> and the ratio <i>SPAN/RBW</i> to 50 in the <i>COUPLING RATIO</i> submenu (default setting, <i>COUPLING RATIO</i> softkey not highlighted).</p> <p>Remote command: <code>BAND:AUTO ON</code> <code>BAND:VID:AUTO ON</code> <code>SWE:TIME:AUTO ON</code></p>

FILTER TYPE

The *FILTER TYPE* softkey opens the selection list for different filter types. In the range up to 30 kHz digital band filters with Gaussian characteristic and filtering with FFT algorithm can be selected.

**Filter Types**

- **NORMAL (3dB):** The resolution bandwidths are implemented by Gaussian filters with the set 3 dB bandwidth and correspond approximately to the noise bandwidth. For bandwidths up to 100 kHz, digital bandpass filters are used.
- **5-pole:** The resolution bandwidths are implemented by 5 pole filter (Gaussian filter approximation) with the set 3 dB bandwidth. For bandwidths up to 100 kHz, digital bandpass filters are used. Due to reduced group delay time, this filter type is usefully for gated sweep measurements.
- **FFT:** An FFT is performed. For that purpose, the filtered IF signal is digitized and then transformed into the spectral domain via FFT. The transformation range depends on the selected filter bandwidths and can be set between 4 kHz to 50 kHz. If the span is larger than the transformation range, several transformations are performed and the results are appended to each other in the spectral domain.

If the span is smaller than the transformation range, the measurement results are interpolated when the number of measurement points provided by the FFT is smaller than the number of display points in x-direction (625). A flattop window serves as a window in the time domain so that high amplitude precision with good selection is achieved.

Sweep time	Defined by the selected bandwidth and span (reason: FFT filtering is a block transformation). It cannot be changed (softkey deactivated).
Detector	Sample detector and peak detector are available. Peak detector is active when AUTO SELECT is selected.
Video bandwidth	Not defined in case of FFT; therefore cannot be set (softkeys deactivated).

Compared to bandpasses, FFT filters lead to significantly reduced sweep times. For a span of 50 kHz and a bandwidth of 100 Hz, for instance, the sweep time is reduced from 5 s to 40 ms. FFT filters are particularly suitable for stationary signals (sinusoidal signals or signals that are continuously modulated in time). For burst signals (TDMA) or pulsed signals, normal filters are preferable.

**Note**

As soon as the FFT filters are active ($RBW \leq 30$ kHz) the sweep time display field (SWT) is replaced by the acquisition time (AQT) display field.

FFT is a block transformation so the result depends on the time relation between the data set to be transformed and the burst or pulsed signal. A gated sweep measurement for TDMA signals is therefore not provided if FFT filters are used.

Additionally, a number of especially steep-edged channel filters are available for power measurement.

- CHANNEL = general, steep-edged channel filters
- RRC = filters with root-raised cosine characteristic (RRC = Root Raised Cosine)

When selecting these filter types, the automatic coupling of the resolution bandwidth to the span is not available. The filters are selected via the *RES BW* softkey.

A list of all available channel filters with their associated applications can be found at the end of this section.

Remote command: SENS:BAND:RES:TYPE NORM | FFT | CFIL
 | RRC | P5

List of Available Channel Filters

The channel filters included in the following table can be activated via the *FILTER TYPE* softkey and are then available as resolution filters (softkey *RES BW*)

**Note**

For filters of type RRC (Root Raised Cosine), the filter bandwidth indicated describes the sampling rate of the filter.

For all other filters (CFILter) the filter bandwidth is the 3 dB bandwidth.

Filter Bandwidth	Filter Type	Application
100 Hz 200 Hz 300 Hz 500 Hz	CFILter CFILter CFILter CFILter	A0
1 kHz 3 kHz 3.4 kHz 4 kHz 8.5 kHz	CFILter CFILter CFILter CFILter CFILter	DAB, Satellite ETS300 113 (12.5 kHz channels)
10 kHz 12.5 kHz 14 kHz 16 kHz 18 kHz, $\alpha=0.35$ 21 kHz 24.3 kHz, $\alpha=0.35$ 30 kHz	CFILter CFILter CFILter CFILter RRC CFILter RRC CFILter	CDMAone ETS300 113 (20 kHz channels) ETS300 113 (25 kHz channels) TETRA PDC IS 136 CDPD, CDMAone
100 kHz 150 kHz 192 kHz 300 kHz 500 kHz	CFILter CFILter CFILter CFILter CFILter	FM Radio J.83 (8-VSB DVB, USA)
1.0 MHz 1.2288 MHz 1.5 MHz	CFILter CFILter CFILter	CDMAone CDMAone DAB

MAIN PLL BANDWIDTH

The *MAIN PLL BANDWIDTH* softkey defines the bandwidth of the main PLL of the synthesizer of the R&S FSUP and thus influences the phase noise of the R&S FSUP. Three bandwidth settings are possible (High / Medium / Low); if AUTO is selected, the bandwidth is set automatically (default).

Remote command: `BAND:PLL AUTO`

FFT FILTER MODE

The softkey *FFT FILTER MODE* allows to specify between the following three options for FFT filters:

WIDE: The FFT filters with the greater partial span (this is the span which is covered with one FFT analysis) are used always.

AUTO: The firmware decides whether to use wide or narrow filters to achieve the best performance of the measurement.

NARROW: The FFT filters with the smaller partial span are used, this allows measurements near a carrier with reduced reference level, because of a more narrow analog prefilter.

Remote command: `SENS:BWID:FFT WIDE | AUTO | NARR`

**VBW MODE LIN/
LOG**

The *VBW MODE LIN/LOG* softkey determines the position of the video filter in the signal path for resolution bandwidths ≤ 100 kHz:

- If LINear is selected, the video filter will be in front of the logarithmic amplifier (default).
- If LOGarithmic is selected, the video filter will be behind the logarithmic amplifier.

The essential difference between the two operating modes relates to the settling in case of falling signal edges:

With LINear, the falling signal edge will be "flatter" than with LOGarithmic.

This is due to the conversion from linear power to logarithmic level units: a reduction of the linear power by 50% reduces the logarithmic signal level by only 3 dB.

Remote command: `BAND:VID:TYPE LIN`

Sweep Settings – SWEEP Key

The SWEEP key serves for configuring the sweep mode and opens the *SWEEP* softkey menu. In split-screen mode, the entries made are valid for the active window only.

The *CONTINUOUS SWEEP*, *SINGLE SWEEP* and *SGL SWEEP DISP OFF* softkeys are mutually exclusive selection keys.

SWEEP

CONTINUOUS SWEEP
SINGLE SWEEP
CONTINUE SGL SWEEP
SWEEPTIME MANUAL
SWEEPTIME AUTO
SWEEP COUNT
SWEEP POINTS
SGL SWEEP DISP OFF

CONTINUOUS SWEEP

The *CONTINUOUS SWEEP* softkey activates the continuous sweep mode, which means that the sweep takes place continuously according to the trigger mode set.

When working in the split-screen mode and with different settings in the two windows, screen A is swept first, followed by screen B. When the softkey is pressed, the sweep is restarted.

CONTINUOUS SWEEP is the default setting of R&S FSUP.

Remote command: INIT:CONT ON

SINGLE SWEEP

The *SINGLE SWEEP* softkey starts n sweeps after triggering. The number of sweeps is determined by the *SWEEP COUNT* softkey.

When working in the split-screen mode, the frequency ranges of the two windows are swept one after the other.

If a trace is swept using *TRACE AVERAGE* or *MAXHOLD*, the value set via the *SWEEP COUNT* softkey determines the number of sweeps. If 0 has been entered, one sweep is performed.

Remote command: INIT:CONT OFF

CONTINUE SGL SWEEP

The *CONTINUE SGL SWEEP* softkey repeats the number of sweeps set under *SWEEP COUNT*, however without first deleting the trace.

This is particularly of interest when using the functions *TRACE AVERAGE* and *MAXHOLD*, if previously recorded measurement results are to be taken into consideration for averaging / maximum search.

If *SGL SWEEP DISP OFF* is active, the screen is switched off also during repeated sweeps.

Remote command: `INIT:CONM`

SWEEPTIME MANUAL

The *SWEEPTIME MANUAL* softkey activates the window for entering the sweep time manually (see also *BW* menu).

Remote command: `SWE:TIME 10s`

SWEEPTIME AUTO

The *SWEEPTIME AUTO* softkey activates the automatic selection of the sweep time as a function of the bandwidth of the resolution and video filters (see also *BW* menu).

Remote command: `SWE:TIME:AUTO ON`

SWEEP COUNT

The *SWEEP COUNT* softkey activates the window for the entry of the number of sweeps to be performed by R&S FSUP after a single sweep has been started. If Trace Average, Max Hold or Min Hold is activated, this also determines the number of averaging or maximum search procedures.

Example

```
[TRACE1: MAX HOLD]
[SWEEP: SWEEP COUNT: {10} ENTER]
[SINGLE SWEEP]
```

R&S FSUP performs the Max Hold function over 10 sweeps.

The permissible range for the sweep count is 0 to 32767. For sweep count = 0 or 1, one sweep is performed. For trace averaging in the continuous-sweep mode, R&S FSUP performs running averaging over 10 sweeps if sweep count = 0; if sweep count = 1, no averaging is performed.

The sweep count is valid for all the traces in a diagram.

**Note**

The number of sweeps set in the *TRACE* menu is the same as that in the *SWEEP* menu.

If *SINGLE SWEEP* is selected, the measurement stops after the selected number of sweeps has been performed.

Remote command: `SWE:COUN 64`

SWEEP POINTS

The *SWEEP POINTS* softkey selects the number of measurement samples acquired during a sweep.

The following numbers of points per sweep are available: 155, 313, 625 (default), 1251, 2501, 5001, 10001, 20001, 40001

**Note**

The autopeak detector will be disabled while the number of points per sweep is \neq 625.

Remote command: SWE:POIN 625

**SGL SWEEP
DISP OFF**

The *SGL SWEEP DISP OFF* softkey deactivates the display while a single sweep is being performed. Once the sweep has been completed, the trace is shown.

Remote command: INIT:DISP OFF;:INIT

Triggering the Sweep – TRIG Key

The *TRIG* key opens a menu for selection of the various trigger sources, trigger polarity and external gate function. The active trigger mode is indicated by highlighting the corresponding softkey.

For video trigger, a trigger threshold can be entered, which is represented in the diagram as a horizontal line.

To indicate that a trigger mode other than *FREE RUN* has been set, the enhancement label **TRG** is displayed on the screen. If two windows are displayed, TRG appears next to the appropriate window.

TRIG

FREE RUN	
VIDEO	
EXTERN	
IF POWER	
TRIGGER OFFSET	
POLARITY POS/NEG	
GATED TRIGGER	
GATE SETTINGS ↓	GATE MODE LEVEL/EDGE
	POLARITY POS/NEG
	GATE DELAY
	GATE LENGTH
	SWEEPTIME
Side menu	
DELAY COMP ON/OFF	

FREE RUN

The *FREE RUN* softkey activates the free-run sweep mode, i.e. start of a sweep is not triggered. Once a measurement is completed, another is started immediately.

FREE RUN is the default setting of R&S FSUP.

Remote command: TRIG:SOUR IMM

VIDEO

The *VIDEO* softkey activates triggering through the displayed voltage.

For the video triggering mode, a horizontal trigger line is shown in the diagram. It may be used to set the trigger threshold between 0% and 100% of the overall diagram height.

Remote command: TRIG:SOUR VID
 TRIG:LEV:VID 50 PCT

EXTERN

The *EXTERN* softkey activates triggering via a TTL signal at the input connector *EXT TRIGGER/GATE* on the rear panel.

The external trigger level can be adjusted in the range from 0.5 V to 3.5 V. The default value is 1.4 V.

Remote command: TRIG:SOUR EXT <numeric_value>
 SWE:EGAT:SOUR EXT
 TRIG:SEQ:LEV:EXT

IF POWER

The *IF POWER* softkey activates triggering of the measurement via signals which are outside the measurement channel.

$$\text{MixerLevel}_{\min} + \text{RFAtt} - \text{PreampGain} \leq \text{InputSignal} \leq \text{MixerLevel}_{\max} + \text{RFAtt} - \text{PreampGain}$$

Thus, the measurement of spurious emissions, e.g. for pulsed carriers, is possible even when the carrier lies outside the selected frequency span.

Remote command: TRIG:SOUR IFP
 SWE:EGAT:SOUR IFP

TRIGGER OFFSET

The *TRIGGER OFFSET* softkey activates the window for entering the time offset between the trigger signal and the start of the sweep.

Triggering is delayed by the entered time with respect to the trigger signal (time entered > 0) or is started earlier (time entered < 0). The time may be entered in multiples of 125 ns in the range -100 s to 100 s (default 0 s).

**Note**

A negative offset (pretrigger) can be set in the time domain only (SPAN = 0 Hz) provided GATED TRIGGER is not active in that domain.

The maximum allowed range and the maximum resolution of the pretrigger is limited by the set sweep time:

max. range = - 499/500 × sweep time
 max. resolution = sweep time/500.

Pretriggering is not possible when the rms or the average detector is activated

As a common input signal is used for both trigger and gate when selecting *EXTERN* and *IF POWER*, changes to the gate delay will affect the trigger delay (*TRIGGER OFFSET*) as well.

Remote command: TRIG:HOLD 10US

**POLARITY POS/
NEG**

The *POLARITY POS/NEG* softkey selects the polarity of the trigger source.

The sweep starts after a positive or negative edge of the trigger signal. The selected setting is highlighted.

The selection is valid for all trigger modes with the exception of *FREE RUN*; in the gate mode, it also applies to the gate polarity.

The default setting is *POLARITY POS*.

Remote command: TRIG:SLOP POS

By using a gate in sweep mode and stopping the measurement while the gate signal is inactive, the spectrum for pulsed RF carriers can be displayed without the superposition of frequency components generated during switching. Similarly, the spectrum can also be examined for an inactive carrier. The sweep can be controlled by an external gate or by the internal power trigger.




Fig. 4-15 Pulsed signal GATE OFF




Fig. 4-16 TDMA signal with GATE ON

The gated-sweep mode is activated by the *GATED TRIGGER* softkey. The setting of the mode takes place in the *GATE SETTINGS* submenu.

GATED TRIGGER

The *GATED TRIGGER* softkey switches the sweep mode with gate on and off. When gate is switched on, a gate signal applied to the rear panel connector *EXT TRIGGER/GATE* or the internal IF power detector controls the sweep of the R&S FSUP. This selection is made via the *EXTERN* and *IF POWER* softkeys for trigger and gate.

The length of the gate signal defines when the sweep is to be interrupted. Here a differentiation is made between edge-triggered and level-triggered modes: in case of edge triggering the gate length can be set via the *GATE LENGTH* softkey, while in case of level triggering the gate length depends on the length of the gate signal.




Fig. 4-17 Timing diagram for GATE, GATE DELAY and GATE LENGTH

This softkey requires the *EXTERN* or *IF POWER* trigger mode. If a different mode is active, *IF POWER* is automatically selected.

Gated-sweep operation is also possible in the time domain. This enables - e.g. in burst signals - level variations of individual slots to be displayed versus time.

To indicate that a gate is used for the sweep, the enhancement label **GAT** is displayed on the screen. This label appears to the right of the window for which the gate is configured.

Remote command: SWE:EGAT ON
 SWE:EGAT:SOUR IFP
 or:
 SWE:EGAT:SOUR EXT

GATE SETTINGS

GATE MODE LEVEL/EDGE
POLARITY POS/NEG
GATE DELAY
GATE LENGTH
SWEEPTIME

The *GATE SETTINGS* softkey calls a submenu for making all the settings required for gated-sweep operation.

At the same time, a transition is made to the time domain (span = 0) and the time parameters *GATE DELAY* and *GATE LENGTH* are represented as vertical lines. This allows the required gate time parameters to be set easily.

For highly accurate setting of gate delay and gate length, the x-axis can be altered using the *SWEEPTIME* softkey in a way that the signal range concerned (e.g. one full burst) is displayed.

Then the sampling time and duration can be set by *GATE DELAY* and *GATE LENGTH* in a way that the desired portion of the signal is shown.

When quitting the submenu, the program will return to the frequency domain provided it was active before. The original span is restored so the desired measurement can now be performed with the accurately set gate.

Remote command: --

GATE MODE LEVEL/EDGE The *GATE MODE LEVEL/EDGE* softkey selects the trigger mode. Gated sweep is possible in the level-triggered as well as in the edge-triggered mode.

If level triggering is selected, the *GATE LENGTH* softkey becomes inactive and cannot be operated.

Remote command: SWE:EGAT:TYPE EDGE

POLARITY POS/NEG The *POLARITY POS/NEG* softkey controls the polarity of the *EXT TRIGGER/GATE* control line.

In case of level triggering the sweep is stopped by *POLARITY POS* and a logic '0' signal; the signal '1' will restart the sweep after the *GATE DELAY* time has elapsed.

In case of edge triggering the sweep is continued on a '0' to '1' transition for the duration of *GATE LENGTH* after a delay (*GATE DELAY*) has elapsed.

Changing the polarity automatically implies a transition of the trigger-edge polarity (*POLARITY* softkey in the higher menu).

Remote command: SWE:EGAT:POL POS

GATE DELAY The *GATE DELAY* softkey activates the window for setting the delay time between the gate signal and the continuation of the sweep.

This may be useful for taking into account a delay between the gate signal and the stabilization of an RF carrier for example.

As gate delay, values between 125 ns and 100 s may be set. The position of the delay on the time axis in relation to the sweep is indicated by the line labelled **GD**.

As there is a common input signal for trigger and gate if *EXTERN* or *IF POWER* is selected, changes to the gate delay will affect the trigger delay (*TRIGGER OFFSET*) as well.

Remote command: SWE:EGAT:HOLD 1US

GATE LENGTH The *GATE LENGTH* softkey activates the window for setting the sweep duration of R&S FSUP in the edge-triggered mode.

Values between 125 ns and 100 s may be set for the gate length. The length of the gate in relation to the sweep is indicated by the line labelled **GL**.

This softkey is only available if *GATE MODE EDGE* (edge triggering) has been selected.

Remote command: SWE:EGAT:LENG 100US

SWEEPTIME The *SWEEPTIME* softkey enables the user to change the time axis to obtain a higher resolution for positioning gate delay and gate length.

When this is to be done, the sweep time temporarily changes; the original value is restored when the menu is quit.

Remote command: --

Measurement example

The modulation spectrum of a GSM 900 signal is to be measured using the gated-sweep function. The signal is generated by a Signal Generator whose RF output is directly connected to the RF input of R&S FSUP.

Settings on the Signal Generator:

FREQ: 802 MHz
 Level: 0 dBm: Return
 Digital Mod: Select: GMSK: Select
 Source: Select: PRBS: Select: Return
 Level Attenuation: Select: 60 dB: Return

The Signal Generator supplies a GMSK-modulated TDMA signal (GSM).

Settings on R&S FSUP:

Conventions:

[KEY] Menu called by this key. All information between the brackets refers to this menu.

{Number} Numeric value to be entered for the parameter on hand.

SOFTKEY Softkey to be used for making a selection or entering a value.

[PRESET]

[FREQ: *CENTER {802} MHz]*

[SPAN *{3.6} MHz]*

[AMPT: *REF LEVEL {0} dBm: RF ATTEN MANUAL: {10} dB]*

[BW: *RES BW MANUAL: {30} kHz]*

[TRACE: *TRACE 1 DETECTOR: RMS]*

[SWEEP: *SWEEPTIME MANUAL: {50} ms]*

[TRIG: *EXTERN*

GATED TRIGGER;

GATE SETTINGS: GATE MODE EDGE; POLARITY POS

SWEEPTIME MANUAL {1} ms: GATE DELAY {300} μ s:

GATE LENGTH: {250} μ s]

The following figure shows the screen display for setting gate parameters. The vertical lines for gate delay (GD) and gate length (GL) can be adjusted to the burst signal by entering numeric values or by means of the rotary knob.




Fig. 4-18 Setting GATE DELAY and GATE LENGTH in time domain by means of lines GD and GL

On quitting the *GATE SETTINGS* menu, R&S FSUP returns to the previous screen.

**DELAY COMP ON/
OFF**

The *DELAY COMP ON/OFF* softkey enables the filter group delay compensation for the external trigger. If a bursted signal is analyzed in zero span and the delay compensation is on, a change of the RBW will not change the rising slope of the signal.

Default is *OFF*.

Remote command: TRIG:HOLD:ADJ:AUTO ON|OFF

Selection and Setting of Traces – TRACE Key

The R&S FSUP is capable of displaying up to three different traces at a time in a diagram. A trace consists of a maximum of 625 pixels on the horizontal axis (frequency or time). If more measured values than pixels are available, several measured values are combined in one pixel.

The traces are selected using the *SELECT TRACE* softkey in the menu of the *TRACE* key.

The traces can individually be activated for a measurement or frozen after completion of a measurement. Traces that are not activated are blanked.

The display mode can be selected for each trace. Traces can be overwritten in each measurement (*CLEAR/WRITE* mode), averaged over several measurements (*AVERAGE* mode), or a maximum or minimum value can be determined from several measurements and displayed (*MAX HOLD* or *MIN HOLD*).

Individual detectors can be selected for the various traces. The autopeak detector displays maximum and minimum values connected by a vertical line. The max peak detector and min peak detector display the maximum and minimum value of the level within a pixel. The sample detector displays the instantaneous value of the level at a pixel. The rms detector displays the power (rms value) of the measured values within a pixel, the average detector the average value.

Selection of Trace Functions

The trace functions are subdivided as follows:

- Display mode of trace (*CLEAR/WRITE*, *VIEW* and *BLANK*)
- Evaluation of the trace as a whole (*AVERAGE*, *MAX HOLD* and *MIN HOLD*)
- Evaluation of individual pixels of a trace using detectors

The *TRACE* key opens a menu offering the setting options for the selected trace.

In this menu, the mode of representing the measured data in the frequency or time domain in the 625 pixels of the display is determined. Upon start of the measurement, each trace can be displayed either completely new or based on the previous results.

Traces can be displayed, blanked and copied. Traces can also be corrected with the aid of mathematical functions.

The measurement detector for the individual display modes can be selected directly by the user or set automatically by R&S FSUP.

The default setting is trace 1 in the overwrite mode (*CLEAR / WRITE*), the other traces 2 and 3 are switched off (*BLANK*).

The *CLEAR/WRITE*, *MAX HOLD*, *MIN HOLD*, *AVERAGE*, *VIEW* and *BLANK* softkeys are mutually exclusive selection keys.

TRACE

SELECT TRACE	
CLEAR/WRITE	
MAX HOLD	
AVERAGE	
VIEW	
BLANK	
SWEEP COUNT	
DETECTOR ↓	AUTO SELECT
	DETECTOR AUTO PEAK
	DETECTOR MAX PEAK
	DETECTOR MIN PEAK
	DETECTOR SAMPLE
	DETECTOR RMS
	DETECTOR AVERAGE
	DETECTOR QPK
TRACE MATH ↓	T1-T2->T1
	T1-T3->T1
	TRACE POSITION
	TRACE MATH OFF
Side menu	
MIN HOLD	
HOLD CONT ON/OFF	
AVG MODE LOG/LIN	
ASCII FILE EXPORT	
DECIM SEP	
COPY TRACE	

SELECT TRACE

The *SELECT TRACE* softkey activates the entry for the active trace (1, 2, 3).

Remote command: -- (selected via numeric suffix of: TRACe)

CLEAR/WRITE

The *CLEAR/WRITE* softkey activates the overwrite mode for the collected measured values, i.e. the trace is overwritten by each sweep.

In the *CLEAR/WRITE* display mode all the available detectors can be selected. In the default mode the autopeak detector (setting *AUTO*) is selected.

Each time the *CLEAR/WRITE* softkey is actuated, R&S FSUP clears the selected trace memory and starts the measurement anew.

Remote command: DISP:WIND:TRAC:MODE WRIT

MAX HOLD

The *MAX HOLD* softkey activates the max peak detector.

The R&S FSUP saves the sweep result in the trace memory only if the new value is greater than the previous one.

The detector is automatically set to *MAX PEAK*. The maximum value of a signal can thus be determined over several sweeps.

This is especially useful with modulated or impulsive signals. The signal spectrum is filled up upon each sweep until all signal components are detected in a kind of envelope.

Pressing the *MAX HOLD* softkey again clears the trace memory and restarts the max hold mode.

Remote command: `DISP:WIND:TRAC:MODE MAXH`

AVERAGE

The *AVERAGE* softkey activates the trace averaging function. The average is formed over several sweeps. Averaging can be performed with any of the detectors available. If the detector is automatically selected by R&S FSUP, the sample detector is used.

Depending on the setting of *AVG MODE LOG / LIN*, the logarithmic level values or the measured power/voltage values are averaged.

Averaging is restarted every time the *AVERAGE* softkey is pressed. The trace memory is always cleared.

Remote command: `DISP:WIND:TRAC:MODE AVER`

Description of averaging

Averaging is carried out over the pixels derived from the measurement samples. Several measured values may be combined in a pixel. This means that with linear level display the average is formed over linear amplitude values and with logarithmic level display over levels. For this reason the trace must be measured again when changing between *LIN* and *LOG* display mode. The settings *CONT/SINGLE SWEEP* and running averaging apply to the average display analogously.

There are two methods for calculating the average. For a sweep count = 0, a running average is calculated according to the following formula:

$$\text{TRACE} = \frac{9 \cdot \text{TRACE} + \text{MeasValue}}{10}$$

Due to the weighting between the new measured value and the trace average, past values have practically no influence on the displayed trace after about ten sweeps. With this setting, signal noise is effectively reduced without need for restarting the averaging process after a change of the signal.

If the sweep count is >1, averaging takes place over the selected number of sweeps. In this case the displayed trace is determined during averaging according to the following formula:

$$\text{Trace}_n = \frac{1}{n} \cdot \left[\sum_{i=1}^{n-1} (T_i) + \text{MeasValue}_n \right]$$

where n is the number of the current sweep ($n = 2 \dots \text{SWEEP COUNT}$). No averaging is carried out for the first sweep but the measured value is stored in the trace memory. With increasing n , the displayed trace is increasingly smoothed since there are more single sweeps for averaging.

After the selected number of sweeps the average trace is saved in the trace memory. Until this number of sweeps is reached, a preliminary average is displayed.

After completion of averaging, i.e. when the averaging length defined by *SWEEP COUNT* is attained, a running averaging is continued with *CONTINUOUS SWEEP* according to the following formula:

$$\text{Trace} = \frac{(N - 1) \cdot \text{Trace}_{\text{old}} + \text{MeasValue}}{N}$$

where

Trace = new trace

Trace_{old} = old trace

N = SWEEP COUNT

The display "Sweep N of N" does not change any more until a new start is triggered.

In the *SINGLE SWEEP* mode, the number of sweeps is triggered with *SWEEP START*. The sweeps are stopped when the selected number of sweeps is attained. The number of the current sweep and the total number of sweeps are shown on the display: "Sweep 3 of 200".

VIEW

The *VIEW* softkey freezes the current contents of the trace memory and displays it.

If a trace is frozen by *VIEW*, the instrument settings can be changed without the displayed trace being modified (exception: level display range and reference level, see below). The fact that the trace and the current instrument setting do not agree any more is indicated by an enhancement label "*" at the right edge of the grid.

If in the *VIEW* display mode the level display range (*RANGE*) or the reference level (*REF LEVEL*) are changed, R&S FSUP automatically adapts the measured data to the changed display range. This allows an amplitude zoom to be made after the measurement in order to show details of the trace.

Remote command: `DISP:WIND:TRAC:MODE VIEW`

BLANK

The *BLANK* softkey activates the blanking of the trace on the screen.

Remote command: `DISP:WIND:TRAC OFF`

SWEEP COUNT

The *SWEEP COUNT* softkey activates the entry of the number of sweeps used for averaging. The allowed range of values is 0 to 30000 and the following should be observed:

- Sweep Count = 0 means running averaging
- Sweep Count = 1 means no averaging being carried out
- Sweep Count > 1 means averaging over the selected number of sweeps; in the continuous sweep mode averaging is performed until the set number of sweeps is attained and is then continued as running averaging.

The default setting is running averaging (Sweep Count = 0). The number of sweeps used for averaging is the same for all active traces in the selected diagram.

**Note**

The setting of the sweep count in the *TRACE* menu is equivalent to the setting in the *SWEEP* menu.

Remote command: SWE:COUN 64

DETECTOR

See following section [“Selection of Detector” on page 4.127.](#)

TRACE MATH

See following section [“Mathematical Functions for Traces” on page 4.131.](#)

MIN HOLD

The *MIN HOLD* softkey activates the min peak detector. R&S FSUP saves for each sweep the smallest of the previously stored/currently measured values in the trace memory. The detector is automatically set to *MIN PEAK*. In this way, the minimum value of a signal can be determined over several sweeps.

This function is useful e.g. for making an unmodulated carrier in a composite signal visible. Noise, interference signals or modulated signals are suppressed by the min hold function whereas a CW signal is recognized by its constant level.

Pressing the *MIN HOLD* softkey again clears the trace memory and restarts the min hold function.

Remote command: DISP:WIND:TRAC:MODE MINH

**HOLD CONT
ON/OFF**

The *HOLD CONT ON/OFF* softkey defines whether the traces in min hold and max hold mode are reset after some specific parameter changes.

- OFF: The traces are reset after some definite parameter changes (default)
- ON: This mechanism is switched off.

In general, parameter changes require a restart of the measurement before results are evaluated (e.g. with markers). For those changes that are known to require a new measurement (e.g. modification of the span), the trace is automatically reset so that erroneous evaluations of previous results are avoided.

This mechanism can be switched off for those exceptional cases where the described behavior is unwelcome.

Remote command: `:DISP:WIND:TRAC:MODE:HCON ON|OFF`

AVG MODE LOG/ LIN

The *AVG MODE LOG/LIN* softkey selects logarithmic or linear averaging for the logarithmic level display mode.

At the same time the difference calculation is switched between linear and logarithmic in submenu *TRACE MATH*.


Remote command: `CALC:MATH:AVER:MODE LIN`

With logarithmic averaging, the dB values of the display voltage are averaged or subtracted from each other with trace mathematical functions. With linear averaging the level values in dB are converted into linear voltages or powers prior to averaging. Voltage or power values are averaged or offset against each other and reconverted into level values.

For stationary signals the two methods yield the same result.

Logarithmic averaging is recommended if sinewave signals are to be clearly visible against noise since with this type of averaging noise suppression is improved while the sinewave signals remain unchanged.

For noise or pseudo-noise signals the positive peak amplitudes are decreased in logarithmic averaging due the characteristic involved and the negative peak values are increased relative to the average value. If the distorted amplitude distribution is averaged, a value is obtained that is smaller than the actual average value. The difference is -2.5 dB.



This low average value is usually corrected in noise power measurements by a 2.5 dB factor. Therefore the R&S FSUP offers the selection of linear averaging. The trace data are delogarithmized prior to averaging, then averaged and logarithmized again for display on the screen. The average value is always correctly displayed irrespective of the signal characteristic.

ASCII FILE EXPORT The *ASCII FILE EXPORT* softkey stores the active trace in ASCII format on a floppy disk.

Remote command: FORM ASC;
 MMEM:STOR:TRAC 1, 'TRACE.DAT'

The file consists of the header containing important scaling parameters and a data section containing the trace data.

The data of the file header consist of three columns, each separated by a semicolon:

parameter name; numeric value; base unit

The data section starts with the key word " Trace <n> " (<n> = number of stored trace), followed by the measured data in one or several columns (depending on measurement) which are also separated by a semicolon.

This format can be read in from spreadsheet calculation programs, e.g. MS-Excel. It is necessary to define ';' as a separator.



Note

Different language versions of evaluation programs may require a different handling of the decimal point. It is therefore possible to select between separators '.' (decimal point) and ',' (comma) using the *DECIM SEP* softkey.

Example - file header

File contents	Description
Type; R&S FSUP<model>;	Instrument model
Version;1.00;	Firmware version
Date;01.Jul 2005;	Date of data set storage
Mode;Spectrum;	Instrument mode
Center Freq;55000;Hz	Center frequency
Freq Offset;0;Hz	Frequency offset
Span;90000;Hz	Frequency range (0 Hz with zero span and statistics measurements)
x-Axis;LIN;	Scaling of x-axis linear (LIN) or logarithmic (LOG)
Start;10000;Hz Stop;100000;Hz	Start/stop of the display range. Unit: Hz for span > 0, s for span = 0, dBm/dB for statistics measurements
Ref.Level;-30;dBm	Reference level
Level Offset;0;dB	Level offset
Ref Position;75;%	Position of reference level referred to diagram limits (0% = lower edge)
y-Axis;LOG;	Scaling of y-axis linear (LIN) or logarithmic (LOG)
Level Range;100;dB	Display range in y direction. Unit: dB with x-axis LOG, % with x-axis LIN
RF Att;20;dB	Input attenuation
RBW;100000;Hz	Resolution bandwidth
VBW;30000;Hz	Video bandwidth
SWT;0.005;s	Sweep time
Trace Mode;AVERAGE;	Display mode of trace: CLR/WRITE,AVERAGE,MAXHOLD,MINHOLD
Detector;SAMPLE;	Detector set: AUTOPEAK,MAXPEAK,MINPEAK,AVERAGE, RMS,SAMPLE
Sweep Count;20;	Number of sweeps set

Example - data section of the file

File contents	Description
Trace 1;;	Selected trace
x-Unit;Hz;	Unit of x values: Hz with span > 0; s with span = 0; dBm/dB with statistics measurements
y-Unit;dBm;	Unit of y values: dB*V/A/Ω depending on the selected unit with y axis LOG or % with y-axis LIN
Values; 625;	Number of measurement points
10000;-10.3;-15.7 10180;-11.5;-16.9 10360;-12.0;-17.4 ...;...;	Measured values: <x value>, <y1>, <y2> <y2> being available only with detector AUTOPEAK and containing in this case the smallest of the two measured values for a test point.

DECIM SEP

The *DECIM SEP* softkey selects the decimal separator between '.' (decimal point) and ',' (comma) with floating-point numerals for the [ASCII FILE EXPORT](#) function.

With the selection of the decimal separator different language versions of evaluation programs (e.g. Microsoft Excel) can be supported.

Remote command: FORM:DEXP:DSEP POIN

COPY TRACE

The *COPY TRACE* softkey copies the screen contents of the current trace into another trace memory. The desired memory is selected by entering the number 1, 2 or 3.

Upon copying, the contents of the selected memory is overwritten and the new contents displayed in view mode.

Remote command: TRAC:COPY TRACE1, TRACE2

Selection of Detector

The detectors of the R&S FSUP are implemented as pure digital devices. The following detectors are available:

- “Peak detectors (MAX PEAK and MIN PEAK)” on page 4.127
- “Auto peak detector” on page 4.127
- “Sample detector” on page 4.127
- “RMS detector” on page 4.128
- “Average detector” on page 4.128
- “Quasipeak detector” on page 4.128

The peak detectors compare the current level value with the maximum or minimum level from the previously sampled data. When the number of samples defined by the instrument setting is reached, the samples are combined in the displayed pixels. Each of the 625 pixels of the display thus represents 1/625 of the sweep range and contains all single measurements (frequency samples) in this subrange in compressed form. For each trace display mode an optimized detector is selected automatically. Since peak detectors and sample detector are connected in parallel, a single sweep is sufficient for collecting all detector values for 3 traces.

Peak detectors (*MAX PEAK* and *MIN PEAK*)

Peak detectors are implemented by digital comparators. They determine the largest of all positive (max peak) or the smallest of all negative (min peak) peak values of the levels measured at the individual frequencies which are displayed in one of the 625 pixels. This procedure is repeated for each pixel so that for wide frequency spans and despite the limited resolution of the display a large number of measurements can be taken into consideration for the display of the spectrum.

Auto peak detector

The *AUTOPEAK* detector combines the two peak detectors. The max peak detector and the min peak detector simultaneously determine the maximum and the minimum level within a displayed test point and display it as a single measured value. The maximum and minimum levels within a frequency point are connected by a vertical line.

Sample detector

The *SAMPLE* detector routes through the sampled data without any further evaluation and either displays them directly or, for reasons of speed in case of short sweep times, first writes them into a memory and processes them subsequently.

There is no data reduction, i.e. no summing up of measured values of neighboring frequencies or time samples. If during a frequency sweep more measured values are obtained than can be displayed, measured values will be lost. This means that discrete signals might be lost.

The sample detector therefore can only be recommended for a span-to-resolution bandwidth ratio of up to approx. 250 in order to ensure that no signal will be suppressed (example: span 1 MHz, -> min. bandwidth 5 kHz).

RMS detector

The RMS detector forms the rms value of the measured values within a pixel.

To this effect, R&S FSUP uses the linear voltage after envelope detection. The sampled linear values are squared, summed and the sum is divided by the number of samples (= root mean square). For logarithmic display the logarithm is formed from the square sum. For linear display the root mean square value is displayed. Each pixel thus corresponds to the power of the measured values summed up in the pixel.

The RMS detector supplies the power of the signal irrespective of the waveform (CW carrier, modulated carrier, white noise or impulsive signal). Correction factors as needed for other detectors for measuring the power of the different signal classes are not required.

Average detector

The average detector forms the average value of the measured values within a pixel.

To this effect, R&S FSUP uses the linear voltage after envelope detection. The sampled linear values are summed up and the sum is divided by the number of samples (= linear average value). For logarithmic display the logarithm is formed from the average value. For linear display the average value is displayed. Each pixel thus corresponds to the average of the measured values summed up in the pixel.

The average detector supplies the average value of the signal irrespective of the waveform (CW carrier, modulated carrier, white noise or impulsive signal).

Quasipeak detector

The quasipeak detector resembles the behavior of an analog voltmeter by evaluating the measured values in a pixel.

The quasipeak detector is especially designed for the requirements of EMC measurements and is used for evaluating pulse-shaped spurious.



Note

During a frequency sweep, R&S FSUP increments the 1st local oscillator in steps that are smaller than approximately 1/10 of the bandwidth. This is to ensure that the signal level is correctly measured. For narrow bandwidths and wide frequency spans a very large number of measured values is thus obtained. The number of frequency steps, however, always is a multiple of 625 (= number of pixels that can be displayed). With the sample detector selected, only every n^{th} value is displayed. The value of n depends on the number of measured values, i.e. on the frequency span, the resolution bandwidth and the measurement rate.

DETECTOR

AUTO SELECT
DETECTOR AUTO PEAK
DETECTOR MAX PEAK
DETECTOR MIN PEAK
DETECTOR SAMPLE
DETECTOR RMS
DETECTOR AVERAGE
DETECTOR QPK

The *DETECTOR* softkey opens a submenu for selecting the detector for the selected trace. The softkey is highlighted if the detector is not selected with *AUTO SELECT*.

The detector can be selected independently for each trace. The *AUTO SELECT* mode selects the optimum detector for each display mode of the trace (Clear/Write, Max Hold or Min Hold).

The softkeys for the detectors are mutually exclusive selection keys.

AUTO SELECT

The *AUTO SELECT* softkey (= default setting) selects the optimum detector for the set display mode of the trace (Clear/Write, Max Hold and Min Hold) and the selected filter mode (bandpass/FFT).

Trace display	Detector (bandpass)	Detector (FFT)
Clear/Write	Auto Peak	Max Peak
Average	Sample	Sample
Max Hold	Max Peak	Max Peak
Min Hold	Min Peak	Max Peak

The detector activated for the specific trace is identified in the respective trace display field as follows:

Detector	
Auto Peak	AP
Max Peak	PK
Min Peak	MI
Average	AV
RMS	RM
Sample	SA
Quasipeak	QP

Remote command: DET:AUTO ON

**DETECTOR
AUTO PEAK**

The *DETECTOR AUTOPEAK* softkey activates the autopeak detector.

Remote command: DET APE

DETECTOR MAX PEAK	<p>The <i>DETECTOR MAX PEAK</i> softkey activates the max peak detector. It is recommended for measurement of impulsive signals.</p> <p>Remote command: DET POS</p>
DETECTOR MIN PEAK	<p>The <i>DETECTOR MIN PEAK</i> softkey activates the min peak detector. Weak sinewave signals become clearly visible in noise using this detector. In case of a composite signal made up of sinewave and impulsive signals, the impulsive signals are suppressed.</p> <p>Remote command: DET NEG</p>
DETECTOR SAMPLE	<p>The <i>DETECTOR SAMPLE</i> softkey activates the sample detector.</p> <p>It is used for measuring uncorrelated signals such as noise. The power can be determined with the aid of fixed correction factors for evaluation and the logarithmic function.</p> <p>Remote command: DET SAMP</p>
DETECTOR RMS	<p>The <i>DETECTOR RMS</i> softkey activates the rms detector.</p> <p>The rms detector supplies the power of the signal independent of the waveform. For this effect the root mean square of all sampled level values is formed during the sweep of a pixel. The sweep time thus determines the number of averaged values and with increasing sweep time better averaging is obtained. The rms detector is thus an alternative for averaging over several sweeps (see TRACE AVERAGE).</p> <p>Since the video bandwidth must be at least 10 times the resolution bandwidth (RBW) to ensure that video filtering does not invalidate the rms values of the signal, this ratio is set automatically upon activating the detector.</p> <p>Remote command: DET RMS</p>
DETECTOR AVERAGE	<p>The <i>DETECTOR AVERAGE</i> softkey activates the average detector.</p> <p>In contrast to the rms detector, the average detector supplies the linear average of all sampled level values during the sweep of a pixel.</p> <p>The same relations as for the rms detector apply (see above).</p> <p>Remote command: DET AVER</p>
DETECTOR QPK	<p>The <i>DETECTOR QPK</i> softkey activates the quasipeak detector.</p> <p>This detector evaluates the sampled level values during the sweep of a pixel like an analog voltmeter.</p> <p>On switching the quasipeak detector on the video bandwidth is automatically set to 10*RBW so as to exclude the influence of the video filter on the signal evaluation.</p> <p>Remote command: DET QPE</p>

Mathematical Functions for Traces

TRACE MATH

The *TRACE MATH* softkey opens a submenu in which the difference between the selected trace to trace 1 is calculated. The softkey is highlighted if a math function is activated.

T1-T2->T1 / T1-T3->T1
TRACE POSITION
TRACE MATH OFF

T1-T2->T1 /
T1-T3->T1

The *T1-T2* and *T1-T3* softkeys subtract the corresponding traces. The result displayed is referred to the zero point defined by *TRACE POSITION*.

To indicate that the trace has been obtained by subtraction, the difference "1 - 2" or "1 - 3" is indicated on the trace info of trace 1 and in the *TRACE* main menu the *TRACE MATH* softkey is highlighted.

Remote command: `CALC:MATH (TRACE1-TRACE2)`
 `CALC:MATH (TRACE1-TRACE3)`

TRACE POSITION

The *TRACE POSITION* softkey activates the entry of the trace position for 0 difference. The position is stated in % of the diagram height.

The range of values extends from -100% to +200%

Remote command: `CALC:MATH:POS 50PCT`

TRACE MATH OFF

The *TRACE MATH OFF* softkey switches the math function off.

Remote command: `CALC:MATH:STAT OFF`

Recording the Correction Data – CAL Key

The R&S FSUP obtains its high measurement accuracy through its inbuilt self-alignment method.

The correction data and characteristics required for the alignment are determined by comparison of the results at different settings with the known characteristics of the high-precision calibration signal source of R&S FSUP at 128 MHz. The correction data are then available in the instrument as a file and can be displayed by means of the *CAL RESULTS* softkey.

For service purposes the use of correction data can be deactivated by means of the *CAL CORR ON/OFF* softkey. If the correction data recording is aborted, the last complete correction data set is restored.



Note

The term "Calibration" formerly used for the integrated self alignment was often mistaken for the "true" calibration of the instrument at the test set in production and in service. It is therefore no longer used although it appears in the abbreviated form in the name of keys ("CAL...").

The *CAL* key opens a menu with the available functions for recording, displaying and activating the data for self alignment.

CAL

CAL TOTAL
CAL ABORT
CAL CORR ON/OFF
CAL RESULTS
PAGE UP / PAGE DOWN

CAL TOTAL

The *CAL TOTAL* softkey starts the recording of correction data of the instrument.

If the correction data recording has failed or if the correction values are deactivated (*CAL CORR = OFF* softkey), *UNCAL* is displayed in the status field.

Remote command: *CAL?

CAL ABORT

The *CAL ABORT* softkey interrupts the recording of correction data and restores the last complete correction data set.

Remote command: CAL:ABOR

- CAL CORR ON/OFF** The *CAL CORR ON/OFF* softkey switches the calibration data on/off.
- ON: The status message depends upon the results of the total calibration.
 - OFF: The message *UNCAL* appears in the status line.

Remote command: *CAL:STAT ON*

- CAL RESULTS** The *CAL RESULTS* softkey calls the *CALIBRATION RESULTS* table, which shows the correction data found during calibration.

The *CALIBRATION RESULTS* table contains the following information:

- date and time of last record of correction values
- overall results of correction value record
- list of found correction values according to function/module

The results have the following meaning:

PASSED calibration successful without any restrictions

CHECK deviation of correction value larger than expected, correction could however be performed

FAILED deviations of correction value too large, no correction was possible. The found correction data are not valid.

ABORTED calibration aborted

Remote command: *CAL:RES?*

- PAGE UP / PAGE DOWN** The softkeys *PAGE UP* and *PAGE DOWN* scroll one page forward or backward in the *CALIBRATION RESULTS* table. They have no function when the table is closed.

Remote command: *--*

Markers and Delta Markers – MKR Key

The markers are used for marking points on traces, reading out measurement results and for quickly selecting a display section. R&S FSUP provides four markers per display window. All markers can be used either as markers or delta markers. The availability of marker functions depends on whether the measurement is performed in the frequency, time or level domain.

The marker that you can move is defined in the following as the **active marker**.




Fig. 4-19 Examples of marker display

Temporary markers are used in addition to the markers and delta markers to evaluate the measurement results. They disappear when the associated function is deactivated.

The measurement results of the active marker (also called **marker values**) are displayed in the marker field. The marker info field at the upper right of the display shows the marker location (here, frequency), the level and the currently selected trace [T1].

```
MARKER 1 [T1]
-27.5 dBm
123.4567 MHz
```

The **MKR** key calls a menu that contains all marker and delta marker standard functions. If no marker is active, **MARKER 1** will be enabled and a peak search on the trace carried out. Otherwise, the data entry for the marker activated last is opened.

MKR

MARKER 1/2/3/4 / MARKER NORM DELTA	
SIGNAL COUNT	
REFERENCE FIXED ↓	REF FXD ON/OFF
	REF POINT LEVEL
	REF POINT LVL OFFSET
	REF POINT FREQUENCY
	REF POINT TIME
	PEAK SEARCH
MARKER ZOOM	
ALL MARKER OFF	

Side menu	
MKR->TRACE	
LINK MKR1 AND DELTA1	
CNT RESOL ...	

MARKER 1/2/3/4 / MARKER NORM DELTA

The *MARKER 1/2/3/4* softkey selects the corresponding marker and activates it.

MARKER 1 is always the normal marker. After they have been switched on, *MARKERS 2 to 4* are delta markers that refer to *MARKER 1*. These markers can be converted into markers with absolute value display by means of the *MARKER NORM DELTA* softkey. When *MARKER 1* is the active marker, pressing the *MARKER NORM DELTA* softkey switches on an additional delta marker.

Pressing the *MARKER 1 to 4* softkey again switches off the selected marker.

Example

[PRESET] R&S FSUP is set to the default setting.

[MKR] On calling the menu, *MARKER 1* is switched on ('1' highlighted in the softkey) and positioned on the maximum value of the trace. It is a normal marker and the *MARKER NORMAL* softkey is highlighted.

[MARKER 2] *MARKER 2* is switched on ('2' highlighted in the softkey). It is automatically defined as a delta marker on switching on so the *DELTA* is highlighted on softkey *MARKER NORM DELTA*. The frequency and level of *MARKER 2* with reference to *MARKER 1* are output in the marker info field.

[MARKER NORM DELTA] The *MARKER NORM DELTA* softkey is highlighted. *MARKER 2* becomes a normal marker. The frequency and level of *MARKER 2* are output as absolute values in the marker info field.

[MARKER 2] *MARKER 2* is switched off. *MARKER 1* is the active marker for entry. The frequency and level of *MARKER 1* are output in the marker info field.

```
Remote command:  CALC:MARK ON
                  CALC:MARK:X <value>
                  CALC:MARK:Y?

                  CALC:DELT ON
                  CALC:DELT:MODE ABS|REL
                  CALC:DELT:X <value>
                  CALC:DELT:X:REL?
                  CALC:DELT:Y?
```

When several traces are being displayed, the marker is set to the maximum value (peak) of the active trace which has the lowest number (1 to 3). In case a marker is already located there, it will be set to the frequency of the next lowest level (next peak).

When the split-screen display mode is active, the marker will be placed in the active window. A marker can only be enabled when at least one trace in the corresponding window is visible.

If a trace is turned off, the corresponding markers and marker functions are also deactivated. If the trace is switched on again (*VIEW, CLR/WRITE;..*), the markers along with coupled functions will be restored to their original positions provided the markers have not been used on another trace.

MKR->TRACE

The *MKR->TRACE* softkey places the active marker on a new trace. The trace is selected via a data entry field. Only those traces can be selected which are visible on the screen in the same window.

The function of this softkey is identical to that of the *MKR->TRACE* softkey in the *MKR->* menu (see “*MKR->TRACE*” on page 4.153).

Example

Three traces are presented on the screen. The marker is always on trace 1 when switching on.

[*MKR ->TRACE*] "2"<ENTER> The marker jumps to trace 2 but remains on the previous frequency or time.

[*MKR ->TRACE*] "3"<ENTER> The marker jumps to trace 3. '

Remote command: *CALC:MARK1:TRAC 1*
 CALC:DELT:TRAC 1

LINK MKR1 AND DELTA1

With the softkey *LINK MKR1 AND DELTA1* the delta marker 1 can be linked to marker 1, so if the x-axis value of the marker 1 is changed the delta marker 1 will follow on the same x-position. The link is off by default.

Example for setup

- PRESET
- TRACE | MAX HOLD
- TRACE | SELECT TRACE | 2 | AVERAGE
- MKR (Switches marker1 on)
- MARKER NORM DELTA | DELTA (Delta Marker 1 ON)
- MKR-> | MKR->TRACE | 2
- LINK MKR1 AND DELTA1

Now select the Marker1 (by switching *MARKER1* from *DELTA* back to *NORM*) and when changing the x-axis value (by knob wheel or *UP/DOWN* keys) the delta marker1 will follow automatically.

The delta marker1 x-value can not be changed away from 0 as long as the link functionality is active.

Remote command: *CALC:DELT:LINK ON | OFF*

Frequency Measurement with the Frequency Counter

In order to accurately determine the frequency of a signal, R&S FSUP is equipped with a frequency counter which measures the frequency of the RF signal at the intermediate frequency. Using the measured IF, R&S FSUP calculates the frequency of the RF input signal by applying the known frequency conversion factors.

The frequency measurement error depends only upon the accuracy of the frequency standard used (external or internal reference). Although R&S FSUP always operates synchronously irrespective of the set span, the frequency counter delivers a more exact result than a measurement performed with a marker. This is due to the following:

- The marker measures only the position of the pixel on the trace and infers the frequency of the signal from this value. The trace, however, contains only a limited number of pixels. Depending upon the selected span, each pixel may contain many measurement values, which therefore limits the frequency resolution.
- The resolution with which the frequency can be measured is proportional to the measurement time. For this reason, the bandwidth is normally made as wide as possible and the sweep time as short as possible. This results in a loss of frequency resolution.

For the measurement with the frequency counter, the sweep is stopped at the reference marker, the frequency is counted with the desired resolution and then the sweep is allowed to continue.


SIGNAL COUNT

The *SIGNAL COUNT* softkey switches the frequency counter on/off.

The frequency is counted at the position of the reference marker (*MARKER 1*). The sweep stops at the reference marker until the frequency counter has delivered a result. The time required for a frequency measurement depends on the selected frequency resolution. The resolution is set in the side menu.

If no marker is enabled when the *SIGNAL COUNT* softkey is pressed, *MARKER 1* is switched on and set at the largest signal.

In addition, the *SIGNAL COUNT* function is displayed in the marker info field on the screen with [Tx CNT].



```

MARKER 1 [T1 CNT]
-27.5 dBm
23.4567891 MHz

```

Switching the *SIGNAL COUNT* function off is accomplished by pressing the softkey again.

Remote command: `CALC:MARK1:COUN ON;`
 `CALC:MARK:COUN:FREQ?`

The resolution of the frequency counter is set in the *NEXT* menu of the *MARKER* menu. R&S FSUP offers counter resolutions between 0.1 Hz and 10 kHz.

CNT RESOL ...

The *CNT RESOL ...* softkeys select the counter resolution. They are selection switches, i.e. only one of the can be active at any one time.

The marker stop time, i.e. the frequency measurement time, depends on the selected resolution.

Remote command: `CALC:MARK1:COUN:RES <value>`

Measurement example

The frequency of a CW signal is to be determined by means of the frequency counter with a resolution of 10 Hz.

[PRESET] R&S FSUP is set to the default setting.

[MARKER] *MARKER 1* is switched on and set to the maximum value of the displayed spectrum.

[SIGNAL COUNT] The frequency counter is switched on. R&S FSUP counts the frequency of the signal at the marker position with a resolution of 1 kHz. The counted frequency is indicated in the marker info field.

[NEXT] Changes to the submenu for setting the counter resolution.

[CNT RESOL 10 Hz] The frequency counter resolution is increased to 10 Hz.

REFERENCE FIXED

REF FXD ON/OFF
REF POINT LEVEL
REF POINT LVL OFFSET
REF POINT FREQUENCY
REF POINT TIME
PEAK SEARCH

The *REFERENCE FIXED* softkey defines the level and the frequency or time of *MARKER 1* as a reference for one or several delta markers. The measured values for one or several markers displayed in the marker info field are derived from this reference point instead of the current values of the reference marker (*MARKER 1*).

On actuating the softkey, reference fixed is switched on and thus, the level value and the frequency, time or x-level value of *MARKER 1* immediately become the reference point.

Additionally, the *REFERENCE FIXED* softkey opens the submenu where it is possible to determine manually a reference point with level and frequency, time or x-axis level, to define a level offset or deactivate the reference point.

The *REFERENCE FIXED* function is useful for the measurement of the harmonic suppression at small span (fundamental not represented).

REF FXD ON/OFF

The *REF FXD ON/OFF* softkey switches on or off the relative measurement to a fixed reference value (*REFERENCE POINT*) independent of the trace.

Remote command: `CALC:DELT2:FUNC:FIX ON`

REF POINT LEVEL The *REF POINT LEVEL* softkey enters a reference level independent of the reference marker level. All relative level values of the delta markers refer to this reference level.

Remote command: `CALC:DELT2:FUNC:FIX:RPO:Y -10dBm`

REF POINT LVL OFFSET The *REF POINT LVL OFFSET* softkey specifies a level offset relevant to the reference level. The relative level values of the delta markers refer to the reference point level plus the level offset.

The level offset is set to 0 dB on enabling the *REFERENCE FIXED* or *PHASE NOISE* function.

Remote command: `CALC:DELT2:FUNC:FIX:RPO:Y:OFFS 0dB`

REF POINT FREQUENCY With the *REF POINT FREQUENCY* softkey a reference frequency can be manually activated for the delta markers when the *REFERENCE FIXED* or *PHASE NOISE* function is used.

Remote command: `CALC:DELT2:FUNC:FIX:RPO:X 10.7MHz`

REF POINT TIME The *REF POINT TIME* softkey activates the entry box for the input of a reference time for the *REFERENCE FIXED* function in the time domain (span = 0 Hz).

Remote command: `CALC:DELT2:FUNC:FIX:RPO:X 5MS`

For phase noise measurement, input of reference time is not possible.

PEAK SEARCH The *PEAK SEARCH* softkey defines the maximum of the selected trace as reference level for all delta markers when using the *REFERENCE FIXED* function.

Remote command: `CALC:DELT2:FUNC:FIX:RPO:X -5DBM`

Measurement example

Small-span harmonics measurement to increase sensitivity

CW signal (e.g. 100 MHz, 0 dBm) with harmonics at the RF input of R&S FSUP.

[PRESET] R&S FSUP is set to the default setting.

[CENTER: 100 MHz] The center frequency of R&S FSUP is set to 100 MHz.

[SPAN: 1 MHz] The span is set to 1 MHz.

[AMPL: 3 dBm] The reference level is set to 3 dBm (3 dB above the expected RF level).

[MKR] *MARKER 1* is switched on ('1' highlighted in the softkey) and set to the signal peak.

[MARKER 2] *MARKER 2* is switched on and automatically defined as the delta marker (*DELTA* is highlighted on *MARKER NORM DELTA* softkey).

[REFERENCE FIXED] The frequency and level of *MARKER 1* are a reference for the delta marker.

[CENTER: 200 MHz] The center frequency is set to 200 MHz (= frequency of the 2nd harmonic). The reference level may have to be reduced to see the 2nd harmonic from the noise. This does not affect the reference level set with *REFERENCE FIXED*.

[MKR->: PEAK] The delta marker jumps to the 2nd harmonic of the signal. The level spacing of the harmonic to the fundamental is displayed in the marker info field.

MARKER ZOOM

The *MARKER ZOOM* softkey expands the area around MARKER 1. With the zoom function, more details of the spectrum can be seen. The desired display range can be defined in an entry window.

The following sweep is stopped at the position of the reference marker. The frequency of the signal is counted and the measured frequency becomes the new center frequency. The zoomed display range is then configured and the new settings are used by R&S FSUP for further measurements.

As long as switching to the new frequency display range has not yet taken place, pressing the softkey will abort the procedure.

If *MARKER 1* is not active when the softkey is pressed, it is automatically activated and set to the highest peak in the window.

If an instrument setting is changed after selection of *MARKER ZOOM*, the function is aborted.

The *MARKER ZOOM* softkey is only available in the frequency domain (span > 0).

Remote command: `CALC:MARK1:FUNC:ZOOM 1kHz`

ALL MARKER OFF

The *ALL MARKER OFF* softkey switches off all markers (reference and delta markers). It also switches off all functions and displays associated with the markers/delta markers.

Remote command: `CALC:MARK:AOFF`

Marker Functions – MKR FCTN Key

The *MKR FCTN* menu offers further measurements with the markers:

- Measurement of noise density (*NOISE MEAS* softkey)
- Measurement of phase noise (*PHASE NOISE* softkey)
- Measurement of filter or signal bandwidth (*N DB DOWN* softkey)

On calling the menu, the entry for the last active marker is activated (*SELECT MARKER* softkey); if no marker is activated, marker 1 is activated and a maximum search (*PEAK* softkey) is performed. The marker can be set to the desired trace by means of *MKR->TRACE* softkey.

MKR FCTN

SELECT MARKER	
PEAK	
NOISE MEAS	
PHASE NOISE ↓	PH NOISE ON/OFF
	REF POINT LEVEL
	REF POINT LVL OFFSET
	REF POINT FREQUENCY
	PEAK SEARCH
	AUTO PEAK SEARCH
N DB DOWN	
PEAK LIST ↓	NEW SEARCH
	SORT MODE FREQ/LEVEL
	PEAK EXCURSION
	LEFT LIMIT / RIGHT LIMIT
	THRESHOLD
	PEAK LIST OFF
MKR->TRACE	

Activating the Markers

SELECT MARKER

The *SELECT MARKER* softkey activates the numerical selection of the marker in the data entry field. Delta marker 1 is selected by input of '0'.

If the marker is switched off, then it is switched on and can be moved later on.

Remote command: `CALC:MARK1 ON;`
 `CALC:MARK1:X <value>;`
 `CALC:MARK1:Y?`

PEAK

The *PEAK* softkey sets the active marker/delta marker to the peak of the trace.

Remote command: `CALC:MARK1:MAX`
 `CALC:DELT1:MAX`

Measurement of Noise Density

NOISE MEAS

The *NOISE MEAS* softkey switches the noise measurement for the active marker on or off. The corresponding marker becomes the *NORMAL* marker.

During noise measurement, the noise power density is measured at the position of the marker. In the time domain mode, all points of the trace are used to determine the noise power density. When measurements are performed in the frequency domain, two points to the right and left of the marker are used for the measurement to obtain a stable result.

The noise power density is indicated in the marker field. With a logarithmic amplitude units (dBm, dBmV, dBm μ V, dB μ A) the noise power density is output in dBm/Hz i.e. as level in 1 Hz bandwidth with reference to 1 mW. With linear amplitude units (V, A, Ω) the noise voltage density is evaluated in μ V/ \sqrt Hz, the noise current density in μ A/ \sqrt Hz or the noise power density in μ W/Hz.

The following settings have to be made to ensure that the power density measurement yields correct values:

Detector: Sample or RMS
 Video bandwidth: $\leq 0.1 \times$ resolution bandwidth with sample detector
 (corresponds to RBW / VBW NOISE)
 $\geq 3 \times$ resolution bandwidth with RMS detector
 (corresponds to RBW / VBW SINE)

In the default setting, the R&S FSUP uses the sample detector for the noise function.

With the sample detector, the trace can additionally be set to AVERAGE to stabilize the measured values. With RMS detector used, trace averaging must not be used since in this case it produces too low noise levels which cannot be corrected. Instead, the sweep time can be increased to obtain stable measurement results.

The R&S FSUP uses the following correction factors to evaluate the noise density from the marker level:

- Since the noise power is indicated with reference to 1 Hz bandwidth, the bandwidth correction value is deducted from the marker level. It is $10 \times \lg(1 \text{ Hz}/BW_{\text{Noise}})$, where BW_{Noise} is the noise or power bandwidth of the set resolution filter (RBW).

- Sample detector

As a result of video filter averaging and trace averaging, 1.05 dB is added to the marker level. This is the difference between the average value and the RMS value of white noise.

With a logarithmic level axis, 1.45 dB is added additionally. Logarithmic averaging is thus fully taken into account which yields a value that is 1.45 dB lower than that of linear averaging.

- RMS detector

With the exception of bandwidth correction, no further corrections are required for the RMS detector since it already indicates the power with every point of the trace.

To allow a more stable noise display the adjacent (symmetric to the measurement frequency) points of the trace are averaged.

In time domain mode, the measured values are averaged versus time (after a sweep).

Remote command: `CALC:MARK:FUNC:NOIS ON;`
 `CALC:MARK:FUNC:NOIS:RES?`

Example: Measurement of inherent R&S FSUP noise

[PRESET] The R&S FSUP is set to default setting.

[MARKER] Marker 1 is switched on and set to the maximum value of the displayed spectrum. Set marker to desired frequency using the rotary knob.

[NOISE] The R&S FSUP switches the sample detector on and sets the video bandwidth to 300 kHz ($0.1 \times \text{RBW}$). The power density level of inherent noise is displayed in dBm/Hz in the marker info field.



Note

The R&S FSUP noise figure can be calculated from the measured power density level. It is calculated by subtracting the set RF attenuation (RF Att) from the displayed noise level. 174 is to be added to the result to obtain the R&S FSUP noise figure.

Phase Noise Measurement

PHASE NOISE

PH NOISE ON/OFF
REF POINT LEVEL
REF POINT LVL OFFSET
REF POINT FREQUENCY
PEAK SEARCH
AUTO PEAK SEARCH

The *PHASE NOISE* softkey switches the *PHASE NOISE* function on/off. Additionally, the softkey opens the submenu for manually setting the reference point. The phase noise measurement can be switched off in the submenu.

MARKER 1 (= reference marker) is used as a reference for the phase noise measurement. The frequency and level of the reference marker are used as fixed reference values, i.e. the *REFERENCE FIXED* function is activated. After switching on the phase noise measurement the reference level or the center frequency can thus be set in a way that the carrier is outside the displayed frequency range, or, for example, a notch filter is switched on to suppress the carrier.

A noise power density measurement is carried out with the delta marker or delta markers. This measurement corresponds to the *NOISE* function in the *MARKER* menu (*MKR*). The result of the phase noise measurement is the difference in level between the reference point and the noise power density.

The following possibilities can be selected on switching on *PHASE NOISE*:

No marker enabled:

[*MKR FCTN*] *MARKER 1* is enabled and set to peak.

[*PHASE NOISE*] *MARKER 1* becomes the reference marker, *MARKER 2* the delta marker; frequency = frequency of the reference marker. The delta marker is the active marker, i.e. it can be moved with the rotary knob or adjusted by entering numerals.

The *PHASE NOISE* function is switched on and the measured value is output.

Markers are enabled:

[*MKR FCTN*] The previous marker configuration remains unchanged.

[*PHASE NOISE*] *MARKER 1* becomes the reference marker. If other markers are enabled, they become delta markers and measure the phase noise at their respective positions.

If further markers are enabled during the phase noise measurement, they automatically become delta markers and measure the phase noise at their respective positions.

When the phase noise measurement is switched off, the marker configuration remains unchanged and the delta markers measure the relative level to the reference marker (*MARKER 1*).

The *PHASE NOISE* function measures the noise power at the delta markers referred to 1 Hz bandwidth. The sample detector is automatically used and the video bandwidth set to 0.1 times the resolution bandwidth (RBW). The two settings are taken into account in the correction values used for the noise power measurement.

To obtain stable results, two pixels on the right and the left of the respective delta marker position are taken for the measurement. The procedure for determining the noise power is identical to the method used for the noise power measurement (see *NOISE* softkey). The measured noise level referred to 1 Hz bandwidth is subtracted from the carrier level at the reference marker (*MARKER 1*). The measured values are displayed in the delta marker field in dBc/Hz (= spacing in dB of the noise power from the carrier level in 1 Hz bandwidth).

If several delta markers are enabled, only the value read by the active marker is shown in the marker field. If several delta markers are active, their measurement results are shown in the marker info field.

The reference value for the phase noise measurement can be defined with *REF POINT LEVEL*, *REF POINT FREQUENCY* and *REF POINT LVL OFFSET* to differ from that of the reference marker.

Remote command: --

PH NOISE ON/OFF The *PH NOISE ON/OFF* softkey switches on/off the phase noise measurement. Switching on is performed by means of the *PHASE NOISE* softkey and is only necessary when the phase noise measurement has been switched off in the submenu.

Remote command: `CALC:DELT1:FUNC:PNO ON`
 `CALC:DELT1:FUNC:PNO:RES?`

REF POINT LEVEL The *REF POINT LEVEL* softkey activates an entry box for the input of a reference level other than the reference marker level. The function is identical to that of the softkey with the same name in the *MARKER* menu (*MKR*).

Remote command: `CALC:DELT1:FUNC:FIX:RPO:Y -10dB`

**REF POINT LVL
OFFSET** The *REF POINT LVL OFFSET* softkey activates an entry box for the input of an additional level offset for the phase noise calculation.

This level offset is set to 0 dB on when the *REFERENCE FIXED* or *PHASE NOISE* function is enabled.

Remote command: `CALC:DELT:FUNC:FIX:RPO:Y:OFFS 10dB`

**REF POINT
FREQUENCY** The *REF POINT FREQUENCY* softkey activates an entry box for the manual input of a reference frequency for the *REFERENCE FIXED* or *PHASE NOISE* function.

Remote command: `CALC:DELT1:FUNC:FIX:RPO:X 10.7MHz`

PEAK SEARCH The PEAK SEARCH sets the reference point level for delta marker 2 in the selected measurement window to the peak of the selected trace.

Remote command: `CALC:DELT:FUNC:FIX:RPO:MAX`

AUTO PEAK SEARCH The AUTO PEAK SEARCH softkey activates an automatic peak search for the reference fixed marker 1 at the end of each particular sweep.

This function may be used for tracking of a drifting source during a phase noise measurement. The delta marker 2, which shows the phase noise measurement result, keeps the delta frequency value. Therefore the phase noise measurement leads to reliable results in a certain offset although the source is drifting. Only if the marker 2 is reaching the border of the span, the delta marker value is adjusted to lie within the span. In these cases, choose a larger span.

Remote command: `CALC:DELT:FUNC:PNO:AUTO ON | OFF`

Measurement example

The phase noise of a CW signal at 100 MHz with 0 dBm level is to be measured at 800 kHz from the carrier

[PRESET] The R&S FSUP is set to the default setting.
 [CENTER: 100 MHz] The center frequency is set to 100 MHz.
 [SPAN: 2 MHz] The span is set to 2 MHz.
 [AMPT: 0 dBm] The reference level is set to 0 dBm.
 [MKR FCTN] MARKER 1 is switched on and positioned at the maximum of the displayed trace.
 [PHASE NOISE: 800 kHz] The phase noise measurement is switched on. The delta marker is positioned on the main marker and the measured phase noise value is displayed in the marker info field. The sample detector is used and the video bandwidth is set to $3 \times \text{RBW}$. When the phase noise measurement function is enabled, the entry of the delta marker frequency is activated. It can be entered directly.

Measurement of the Filter or Signal Bandwidth

N DB DOWN

The *N DB DOWN* softkey activates the temporary markers T1 and T2 which are n dB below the active reference marker. Marker T1 is placed to the left and marker T2 at the right of the reference marker. The value n can be input in a window.

The default setting is 3 dB.

Span > 0: The frequency spacing of the two temporary markers is indicated in the marker info field.

Span = 0: The pulse width between the two temporary markers is indicated in the marker info field.

If, for example, it is not possible to form the frequency spacing for the n dB value because of the noise display, dashes are indicated instead of a measured value.

If a negative value is entered than the markers are placed n dB above the active reference marker. This is then a n dB up function which can be used for notch filter measurements:

Remote command: CALC:MARK1:FUNC:NDBD:STAT ON
 CALC:MARK1:FUNC:NDBD 3dB
 CALC:MARK1:FUNC:NDBD:RES?
 CALC:MARK1:FUNC:NDBD:FREQ? 'Span > 0
 CALC:MARK1:FUNC:NDBD:TIME? 'Span = 0

Measurement of a Peak List

PEAK LIST

NEW SEARCH
SORT MODE FREQ/LEVEL
PEAK EXCURSION
LEFT LIMIT / RIGHT LIMIT
THRESHOLD
PEAK LIST OFF

The *PEAK LIST* softkey allows the peak values of the trace to be determined and entered in a list with 50 entries max. The order of the entries is defined by the *SORT MODE*:

- **FREQ:** sorting in ascending order of frequency values (see screenshot); if span = 0, the entries are sorted in ascending order of time values
- **LEVEL:** sorting according to level

PEAK LIST		
#	FREQUENCY	POWER
1	794.871794871 MHz	-55.37 dBm
2	2.397435897 GHz	-74.70 dBm
3	4.012820512 GHz	-38.00 dBm
4	5.615384615 GHz	-26.04 dBm
5	6.435897435 GHz	-38.02 dBm
6	7.217948717 GHz	-55.39 dBm

The search range can be restricted by means of the *LEFT LIMIT*, *RIGHT LIMIT* and *THRESHOLD* softkeys. The definition of the peak values can be modified using the *PEAK EXCURSION* softkey. The *MKR->TRACE* softkey in the main menu is used to select the trace for searching peak values.

Opening the list performs a single search at the end of the sweep. The *NEW SEARCH* softkey triggers a new sweep, determines the peak values of the trace at the end of the sweep and enters them in the list.

Use the *PEAK LIST OFF* key to delete the list from the screen.

Remote command: INIT:CONT OFF;
CALC:MARK:TRAC 1;
CALC:MARK:FUNC:FPE:SORT X;
INIT;*WAI;
CALC:MARK:FUNC:FPE 10;
CALC:MARK:FUNC:FPE:COUN?;
CALC:MARK:FUNC:FPE:Y?;
CALC:MARK:FUNC:FPE:X?

NEW SEARCH The *NEW SEARCH* softkey starts a new peak search and enters the results in the peak list.

Remote command: INIT;*WAI;
CALC:MARK:FUNC:FPE 10;
CALC:MARK:FUNC:FPE:COUN?;
CALC:MARK:FUNC:FPE:Y?;
CALC:MARK:FUNC:FPE:X?

**SORT MODE FREQ/
LEVEL** The *SORT MODE FREQ/LEVEL* softkey defines the position of the peak values in the list:

- FREQ: sorting in ascending order of frequency values (time values if span = 0)
- LEVEL: sorting according to level

Remote command: CALC:MARK:FUNC:FPE:SORT X;

PEAK EXCURSION With level measurements, the *PEAK EXCURSION* softkey allows the minimum amount to be entered by which a signal must decrease or increase in order to be recognized as a maximum by the peak search function.

Values between 0 dB and 80 dB may be entered, the resolution being 0.1 dB

Remote command: CALC:MARK:PEXC 6dB

**LEFT LIMIT /
RIGHT LIMIT** The *LEFT LIMIT* and *RIGHT LIMIT* softkeys define the vertical lines F1/F2 in the frequency domain (span > 0) and T1/T2 in the time domain (span = 0) between which the search is carried out.

If only one line is active, the F1/T1 line is used as the lower limit; the upper limit is the stop frequency. If F2/T2 is also active, it defines the upper limit.

Remote command: CALC:MARK:X:SLIM:LEFT 1MHZ
CALC:MARK:X:SLIM:RIGH 10MHZ
CALC:MARK:X:SLIM ON

THRESHOLD The *THRESHOLD* softkey defines a horizontal threshold line which represents the lower limit of the peak search level range.

Remote command: CALC:THR -20dBm
CALC:THR ON

PEAK LIST OFF The *PEAK LIST OFF* softkey switches off the table with the search results.

Remote command: --

The threshold line (*MKR->SEARCH LIMITS:THRESHOLD*) performs a squelch function in the demodulator. If the threshold is set, the R&S FSUP LF demodulation is switched on only when the signal to be demodulated exceeds the set threshold.

Selecting the Trace

MKR->TRACE

The *MKR->TRACE* softkey sets the active marker to different traces. Only those traces can be selected which are visible on the screen in the same window.

The function of the softkey is identical to that of the softkey with the same name in the *MKR->* menu.

Example

Three traces are displayed on the screen. The marker is always on Trace 1 on switching on.

[*MKR ->TRACE*] "1"<ENTER> The marker jumps to Trace 2, but remains at the previous frequency or time.

[*MKR ->TRACE*] "3"<ENTER> The marker jumps to Trace 3.

Remote command: CALC:MARK:TRAC 2

Change of Settings via Markers – MKR-> Key

The *MKR->* menu offers functions through which instrument parameters can be changed with the aid of the currently active marker. The functions can be used on markers and delta markers.

On opening the menu, the entry for the last active marker is activated; if no marker was enabled, MARKER 1 is activated and a peak search is performed.

MKR->

SELECT MARKER	
PEAK	
CENTER = MKR FREQ	
REF LEVEL = MKR LVL	
NEXT PEAK	
NEXT PEAK RIGHT	
NEXT PEAK LEFT	
SEARCH LIMITS ↓	LEFT LIMIT / RIGHT LIMIT
	THRESHOLD
	SEARCH LIMIT OFF
MKR->TRACE	
Side menu	
MKR->CF STEPSIZE	
MIN	
NEXT MIN	
NEXT MIN RIGHT	
NEXT MIN LEFT	
EXCLUDE LO	
PEAK EXCURSION	
2. side menu	
AUTO MAX PEAK	
AUTO MIN PEAK	

SELECT MARKER

The *SELECT MARKER* softkey activates the numerical selection of the marker in the data entry field. Delta marker 1 is selected by input of '0'.

Remote command: CALC:MARK1 ON
 CALC:MARK1:X <value>
 CALC:MARK1:Y?

PEAK

The *PEAK* softkey sets the active marker/delta marker to the peak of the trace. If no marker is active when *MKR->* menu is called, *MARKER 1* is automatically switched on and the peak search is performed.

Remote command: `CALC:MARK:MAX`
 `CALC:DELT:MAX`

**CENTER =
MKR FREQ**

The *CENTER = MKR FREQ* softkey sets the center frequency to the current marker or delta marker frequency.

A signal can thus be set to the center of the frequency display range, for example, so that it can then be examined in detail with a smaller span.

The softkey is not available in the time domain (zero span).

Remote command: `CALC:MARK:FUNC:CENT`

Example

A spectrum is displayed with a large span after *PRESET*. A signal off the center is to be examined in detail:

[*PRESET*] R&S FSUP is set to the default setting.
 [*MKR->*] *MARKER 1* is switched on and automatically jumps to the largest signal of the trace.
 [*CENTER=MKR FREQ*] The center frequency is set to the marker frequency. The span is adapted in such a way that the minimum frequency (= 0 Hz) or the maximum frequency is not exceeded.
 [*SPAN*] The span can, for example, be reduced using the rotary knob.

**REF LEVEL =
MKR LVL**

The *REF LEVEL = MKR LVL* softkey sets the reference level to the current marker level.

Remote command: `CALC:MARK:FUNC:REF`

Example

A spectrum is displayed with a large span after *PRESET*. A signal off the center is to be examined in detail:

[*PRESET*] R&S FSUP is set to the default setting.
 [*MKR->*] *MARKER 1* is switched on and automatically jumps to the largest signal of the trace.
 [*CENTER=MKR FREQ*] The center frequency is set to the marker frequency. The span is adapted in such a way that the minimum frequency (= 0 Hz) or the maximum frequency is not exceeded.
 [*REF LEVEL = MKR LVL*] The reference level is set to the measured marker level.
 [*SPAN*] The span can, for example, be reduced using the rotary knob.

NEXT PEAK The *NEXT PEAK* softkey sets the active marker/delta marker to the next lower maximum of the selected trace.

Remote command: `CALC:MARK:MAX:NEXT`
 `CALC:DELT:MAX:NEXT`

NEXT PEAK RIGHT The *NEXT PEAK RIGHT* softkey sets the active marker/delta marker to the next lower maximum right of the current marker position on the selected trace.

Remote command: `CALC:MARK:MAX:RIGH`
 `CALC:DELT:MAX:RIGH`

NEXT PEAK LEFT The *NEXT PEAK LEFT* softkey sets the active marker/delta marker to the next lower maximum left of the current marker position the selected trace.

Remote command: `CALC:MARK:MAX:LEFT`
 `CALC:DELT:MAX:LEFT`

AUTO MAX PEAK

AUTO MIN PEAK The *AUTO MAX PEAK* / *AUTO MIN PEAK* softkeys add an automatic peak search action for marker 1 at the end of each particular sweep. This function may be used during adjustments of a device under test to keep track of the current peak marker position and level.

The current marker search limit settings (*LEFT LIMIT*, *RIGHT LIMIT*, *THRESHOLD*, *EXCLUDE LO*) are taken into account.

Remote command: `CALC:MARK:MAX:AUTO ON | OFF`
 `CALC:MARK:MIN:AUTO ON | OFF`

SEARCH LIMITS

LEFT LIMIT / RIGHT LIMIT
THRESHOLD
SEARCH LIMIT OFF

The *SEARCH LIMITS* softkey limits the search range for maximum or minimum search. The softkey switches to a submenu in which the search range limits can be set in the x and y direction.

LEFT LIMIT / RIGHT LIMIT

The *LEFT LIMIT* and *RIGHT LIMIT* softkeys define the two vertical lines F1 and F2 in the frequency domain (span > 0) and T1 / T2 in the time domain (span = 0). The search is performed between these lines in the frequency and time domain

If only *LEFT LIMIT* is enabled, line F1/T1 is the lower limit and the upper limit corresponds to the stop frequency. If *RIGHT LIMIT* is also enabled, it determines the upper limit.

Remote command: `CALC:MARK:X:SLIM:LEFT 1MHZ`
 `CALC:MARK:X:SLIM:RIGH 10MHZ`
 `CALC:MARK:X:SLIM ON`

THRESHOLD	<p>The <i>THRESHOLD</i> softkey defines the threshold line.</p> <p>The threshold line represents a limit for the level range of the max. search at the lower end and that of the min. search at the upper end.</p> <p>Remote command: <code>CALC:THR -20dBm</code> <code>CALC:THR ON</code></p>
SEARCH LIMIT OFF	<p>The <i>SEARCH LIMIT OFF</i> softkey disables all limits of the search range.</p> <p>Remote command: <code>CALC:MARK:X:SLIM OFF</code> <code>CALC:THR OFF</code></p>
MKR->TRACE	<p>The function of this softkey is identical to that of the <i>MKR->TRACE</i> softkey in the <i>MKR</i> menu (see “<i>MKR->TRACE</i>” on page 4.136).</p>
MKR->CF STEPSIZE	<p>The <i>MKR->CF STEPSIZE</i> softkey sets the step size for the center frequency variation to the current marker frequency, and also sets step size adaptation to <i>MANUAL</i>. <i>CF STEPSIZE</i> remains at this value until the center frequency entry mode in the <i>STEP</i> menu is switched from <i>MANUAL</i> to <i>AUTO</i> again.</p> <p>The <i>MKR->CF STEPSIZE</i> function is, above all, useful in the measurement of harmonics with large dynamic range (narrow bandwidth and narrow span).</p> <p>The softkey is not available in the time domain (span = 0 Hz).</p> <p>Remote command: <code>CALC:MARK:FUNC:CST</code></p> <p>Example</p> <p>The harmonics levels of a CW carrier are to be measured at 100 MHz.</p> <p>[PRESET] R&S FSUP is set to the default setting.</p> <p>[CENTER: 100 MHz] R&S FSUP sets the center frequency to 100 MHz. The span is set to 200 MHz.</p> <p>[SPAN: 1 MHz] The span is set to 100 MHz.</p> <p>[MKR->] MARKER 1 is switched on and set to the maximum value of the signal.</p> <p>[NEXT] R&S FSUP switches to the submenu.</p> <p>[MKR->CF STEPSIZE] The step size of the center frequency setting equals the marker frequency (100 MHz).</p> <p>[CENTER] The center frequency entry mode is activated.</p> <p>[Right key] The center frequency is set to 200 MHz. The first harmonic of the test signal is displayed.</p> <p>[MKR->: PEAK] The marker is set to the harmonic and the level of the latter is output in the marker info field.</p>
MIN	<p>The <i>MIN</i> softkey sets the active marker/delta marker to the minimum of the selected trace.</p> <p>Remote command: <code>CALC:MARK:MIN</code> <code>CALC:DELT:MIN</code></p>

- NEXT MIN** The *NEXT MIN* softkey sets the active marker/delta marker to the next higher minimum of the selected trace.
- Remote command: `CALC:MARK:MIN:NEXT`
 `CALC:DELT:MIN:NEXT`
- NEXT MIN RIGHT** The *NEXT MIN RIGHT* softkey sets the active marker/delta marker to the next higher minimum right of the current marker position on the selected trace.
- Remote command: `CALC:MARK:MIN:RIGH`
 `CALC:DELT:MIN:RIGH`
- NEXT MIN LEFT** The *NEXT MIN LEFT* softkey sets the active marker/delta marker to the next higher minimum left of the current marker position on the selected trace.
- Remote command: `CALC:MARK:MIN:LEFT`
 `CALC:DELT:MIN:LEFT`
- EXCLUDE LO** The *EXCLUDE LO* softkey limits the frequency range for the marker search functions or disables the limit.
- activated Because of the feed through of the first local oscillator to the first intermediate frequency at the input mixer, the LO is represented as a signal at 0 Hz. To avoid the marker jumping to the LO at 0 Hz with the peak function when setting the display range, this frequency is excluded. The minimum frequency to which the marker jumps, is $\geq 6 \times$ resolution bandwidth (RBW).
- deactivated No restriction to the search range. The frequency 0 Hz is included in the marker search functions.
- Remote command: `CALC:MARK:LOEX ON`
- PEAK EXCURSION** The *PEAK EXCURSION* softkey enables – for level measurements – the entry of a minimum level value by which a signal must rise or fall so that it will be identified as a maximum or a minimum by the *NEXT PEAK* and *NEXT MIN* search functions.
- Valid entries are from 0 dB to 80 dB; the resolution is 0.1 dB.
- Remote command: `CALC:MARK:PEXC 10dB`
- The default setting for the peak excursion is 6 dB. This value is sufficient for the *NEXT PEAK* and *NEXT MIN* functions since, in this mode, the next lower maximum or next higher minimum will always be detected.
- If *NEXT PEAK LEFT* or *NEXT PEAK RIGHT* is selected, these functions search for the next relative maximum left or right of the current marker position irrespective of the current signal amplitude. *Relative maximum* is understood to mean a decrease of the signal amplitude by a defined value – i.e. the peak excursion – right and left of the amplitude peak.
- The 6 dB level change set as a default value may be attained already by the inherent noise of the instrument. In such a case, the R&S FSUP would identify noise peaks as maxima or minima. The value entered for the *PEAK EXCURSION* should therefore be higher than the difference between the highest and the lowest value measured for the displayed inherent noise.

The following example illustrates the effect of different settings of the *PEAK EXCURSION*.




Fig. 4-20 Examples of level measurement with different settings of *PEAK EXCURSION*

The following table lists the signals as indicated by marker numbers in the diagram above, as well as the minimum of the amplitude decrease to both sides of the signal:

signal #	min. amplitude decrease to both sides of the signal
1	30 dB
2	29.85 dB
3	7 dB
4	7 dB

With **40 dB peak excursion**, *NEXT PEAK*, *NEXT PEAK RIGHT* and *NEXT PEAK LEFT* will not find any signal, as the signal level does not decrease by more than 30 dB to either side of any signal.

Order of signals detected:

PEAK: signal 1
NEXT PEAK: signal 1 (no further signal detected)

or

PEAK: signal 1
NEXT PEAK LEFT: signal 1 (no further signal detected)
NEXT PEAK RIGHT: signal 1 (no further signal detected)

With **20 dB peak excursion**, *NEXT PEAK* and *NEXT PEAK RIGHT* will also detect signal 2, as the signal level decreases at least by 29.85 dB to either side of this signal, which is now greater than the peak excursion.

Order of signals detected:

PEAK: Signal 1
NEXT PEAK: Signal 2
NEXT PEAK: Signal 2 (no further signal detected)

or

PEAK: Signal 1
NEXT PEAK LEFT: Signal 1 (no further signal detected)
NEXT PEAK RIGHT: Signal 2
NEXT PEAK RIGHT: Signal 2 (no further signal detected)

With **6 dB peak excursion**, all signals will be detected with *NEXT PEAK* and *NEXT PEAK RIGHT / NEXT PEAK LEFT*.

Order of signals detected:

PEAK: Signal 1
NEXT PEAK: Signal 2
NEXT PEAK: Signal 3
NEXT PEAK: Signal 4

or

PEAK: Signal 1
NEXT PEAK LEFT: Signal 3
NEXT PEAK RIGHT: Signal 1
NEXT PEAK RIGHT: Signal 2
NEXT PEAK RIGHT: Signal 4

Power Measurements – MEAS Key

With its power measurement functions the R&S FSUP is able to measure all the necessary parameters with high accuracy in a wide dynamic range.

A modulated carrier is almost always used (except e.g. SSB-AM) for high-frequency transmission of information. Due to the information modulated upon the carrier, the latter covers a spectrum which is defined by the modulation, the transmission data rate and the signal filtering. Within a transmission band each carrier is assigned a channel taking into account these parameters. In order to ensure error-free transmission, each transmitter must be conforming to the specified parameters. These include among others:

- the output power,
- the occupied bandwidth, i.e. the bandwidth which must contain a defined percentage of the power and
- the power dissipation allowed in the adjacent channels.

Additionally the menu contains functions to determine the modulation depth of AM modulated signals and to measure the 3rd order intercept point.

The measurements and the corresponding settings are selected in the *MEAS* menu.

MEAS

TIME DOM POWER ↓
CHAN PWR ACP ↓
MULT CARR ACP ↓
OCCUPIED BANDWIDTH ↓
SIGNAL STATISTIC ↓
C/N / C/NO ↓
MODULATION DEPTH
SPURIOUS EMISSIONS ↓
SELECT MARKER
Side menu
TOI
HARMONIC DISTOR ↓

The *MEAS* key opens the menu to select and set the power measurement.

The following measurements can be selected:

- Power in the time domain (“[TIME DOM POWER](#)” on page 4.159)
- Channel power and adjacent-channel power in the frequency domain with a single carrier (“[CHAN PWR ACP](#)” on page 4.167)
- Channel power and adjacent-channel power in the frequency domain with several carriers (“[CHAN PWR ACP](#)” on page 4.167)
- Occupied bandwidth (“[OCCUPIED BANDWIDTH](#)” on page 4.184)
- Carrier-to-noise ratio (“[C/N / C/NO](#)” on page 4.194)

- Amplitude probability distribution (“[SIGNAL STATISTIC](#)” on page 4.189)
- Modulation depth (“[MODULATION DEPTH](#)” on page 4.195)
- Spurious emissions (“[SPURIOUS EMISSIONS](#)” on page 4.201)
- 3rd order intercept (“[TOI](#)” on page 4.198)
- Harmonic distortion (“[HARMONIC DISTOR](#)” on page 4.199)

The above measurements are carried out alternatively.

Power Measurement in Time Domain

With the aid of the power measurement function, the R&S FSUP determines the power of the signal in the time domain (SPAN = 0 Hz) by summing up the power at the individual pixels and dividing the result by the number of pixels. In this way it is possible to measure for example the power of TDMA signals during transmission or during the muting phase. Both the mean power and the rms power can be measured by means of the individual power values.

The result is displayed in the marker info field.

The measured values are updated after each sweep or averaged over a user-defined number of sweeps (*AVERAGE ON/OFF* and *NUMBER OF SWEEPS*) in order to determine e.g. the mean power over several bursts. For determination of the peak value (*MAX HOLD ON*) the maximum value from several sweeps is displayed.

Example

Marker info field for: *MEAN* selected, *AVERAGE ON* and *MAX HOLD ON*:

MEAN HOLD	-2.33 dBm
MEAN AV	-2.39 dBm

If both the on and off phase of a burst signal are displayed, the measurement range can be limited to the transmission or to the muting phase with the aid of vertical lines. The ratio between signal and noise power of a TDMA signal for instance can be measured by using a measurement as a reference value and after that varying the measurement range.

Upon switching on power measurement the sample detector is activated (*TRACE - DETECTOR - SAMPLE*).

TIME DOM POWER

POWER ON/OFF
PEAK
RMS
MEAN
STANDARD DEVIATION
LIMIT ON/OFF
START LIMIT
STOP LIMIT
Side menu
SET REFERENCE
POWER ABS/REL
MAX HOLD ON/OFF
AVERAGE ON/OFF
NUMBER OF SWEEPS

The *TIME DOM POWER* softkey activates the power measurement in the time domain and opens a submenu for configuration of the power measurement.

The submenu allows selection of the type of power measurement (rms or mean power), the settings for max hold and averaging as well as the definition of limits.

The power evaluation range can be limited by input of limit values.

**Note**

This softkey is only available in time domain (span = 0).

POWER ON/OFF

The *POWER ON/OFF* softkey switches the power measurement on and off. When entering the submenu it is *ON* since the power measurement is already switched on with the *TIME DOM POWER* softkey in the main menu.

**Note**

The measurement is performed on the trace on which marker 1 is placed. To evaluate another trace, marker 1 should be set on another trace using the *SELECT TRACE* softkey in *MARKER* menu (*MKR*).

Remote command: CALC:MARK:FUNC:SUMM:PPE ON
 CALC:MARK:FUNC:SUMM:PPE:RES?
 CALC:MARK:FUNC:SUMM:RMS ON
 CALC:MARK:FUNC:SUMM:RMS:RES?
 CALC:MARK:FUNC:SUMM:MEAN ON
 CALC:MARK:FUNC:SUMM:MEAN:RES?
 CALC:MARK:FUNC:SUMM:SDEV ON
 CALC:MARK:FUNC:SUMM:SDEV:RES?

PEAK The *PEAK* softkey switches on the calculation of the peak value from the points of the displayed trace or a segment thereof.

For the maximum peak, the largest peak value obtained since the activation of *MAX HOLD ON* is displayed.

With *AVERAGE ON*, the peak values of a trace are averaged over several sweeps and displayed.

The number of sweeps over which the average or the maximum value is calculated is set with the *NUMBER OF SWEEPS* softkey.

Remote command: CALC:MARK:FUNC:SUMM:PPE ON
 CALC:MARK:FUNC:SUMM:PPE:RES?

RMS The *RMS* softkey switches on the calculation of the rms value from the points of the displayed trace or a segment of it.

For the maximum peak, the largest rms value obtained since the activation of *MAX HOLD ON* is displayed.

With *AVERAGE ON*, the rms values of a trace are averaged over several sweeps and displayed.

The number of sweeps over which the average or the maximum value is calculated is set with the *NUMBER OF SWEEPS* softkey.

Remote command: CALC:MARK:FUNC:SUMM:RMS ON
 CALC:MARK:FUNC:SUMM:RMS:RES?

MEAN The *MEAN* softkey switches on the calculation of the mean value from the points of the displayed trace or a segment of it. The linear mean value of the equivalent voltages is calculated.

This can be used for instance to measure the mean power during a GSM burst.

For the maximum peak, the largest mean value obtained since the activation of *MAX HOLD ON* is displayed.

With *AVERAGE ON*, the mean values of a trace are averaged over several sweeps and displayed.

The number of sweeps over which the average or the maximum value is calculated is set with the *NUMBER OF SWEEPS* softkey.

Remote command: CALC:MARK:FUNC:SUMM:MEAN ON
 CALC:MARK:FUNC:SUMM:MEAN:RES?

STANDARD DEVIATION	<p>The <i>STANDARD DEVIATION</i> softkey switches on the calculation of the standard deviation of trace points from the mean value and outputs them as measured value. The measurement of the mean power is automatically switched on at the same time.</p> <p>For the maximum peak, the largest standard deviation obtained since the activation of <i>MAX HOLD ON</i> is displayed.</p> <p>With <i>AVERAGE ON</i>, the standard deviations of a trace are averaged over several sweeps and displayed.</p> <p>The number of sweeps over which the average or the maximum value is calculated is set with the <i>NUMBER OF SWEEPS</i> softkey.</p> <p>Remote command: <code>CALC:MARK:FUNC:SUMM:SDEV ON</code> <code>CALC:MARK:FUNC:SUMM:SDEV:RES?</code></p>
LIMIT ON/OFF	<p>The <i>LIMIT ON/OFF</i> softkey selects the limited (<i>ON</i>) or non-limited (<i>OFF</i>) evaluation range.</p> <p>The evaluation range is defined by the <i>START LIMIT</i> and <i>STOP LIMIT</i> softkeys. If <i>LIMIT = ON</i>, signals are only searched between the two lines.</p> <p>If only one limit line is switched on, time line 1 is the lower limit and the upper limit corresponds to the end of sweep. If time line 2 is also switched on, it defines the upper limit.</p> <p>If no limit line is switched on, the evaluation range is not limited.</p> <p>The default setting is <i>LIMIT = OFF</i>.</p> <p>Remote command: <code>CALC:MARK:X:SLIM OFF</code></p>
START LIMIT	<p>The <i>START LIMIT</i> softkey activates the entry of the lower limit of the evaluation range.</p> <p>Remote command: <code>CALC:MARK:X:SLIM:LEFT <value></code></p>
STOP LIMIT	<p>The <i>STOP LIMIT</i> softkey activates the entry of the upper limit of the evaluation range.</p> <p>Remote command: <code>CALC:MARK:X:SLIM:RIGH <value></code></p>
SET REFERENCE	<p>The <i>SET REFERENCE</i> softkey sets the power values currently measured as reference values for the calculation of the mean value (<i>MEAN</i>) and the rms value (<i>RMS</i>). The reference values are used to perform relative measurements.</p> <p>If the calculation of the mean value (<i>MEAN</i>) and rms value (<i>RMS</i>) is not switched on, 0 dBm is used as a reference value.</p> <p>If the average value (<i>AVERAGE</i>) or maximum value (<i>MAX HOLD</i>) is calculated over several sweeps, the current value is the measured value summed up at the actual time.</p> <p>Remote command: <code>CALC:MARK:FUNC:SUMM:REF:AUTO ONCE</code></p>

POWER ABS/REL The *POWER ABS/REL* softkey selects the absolute power measurement (default setting) or relative power measurement. The reference value for the relative power is defined by *SET REFERENCE*.

The value 0 dBm is used if the reference value is not defined.

Remote command: `CALC:MARK:FUNC:SUMM:MODE ABS`

MAX HOLD ON/OFF The *MAX HOLD ON/OFF* softkey switches the display of the maximum peak obtained from measurements at successive sweeps on and off.

The displayed maximum peak is only updated at the end of a sweep if a higher value has occurred.

The maximum value can be reset by switching the *MAX HOLD ON / OFF* softkey off and on again.

Remote command: `CALC:MARK:FUNC:SUMM:PHOL ON`
`CALC:MARK:FUNC:SUMM:PPE:PHOL:RES?`
`CALC:MARK:FUNC:SUMM:RMS:PHOL:RES?`
`CALC:MARK:FUNC:SUMM:MEAN:PHOL:RES?`
`CALC:MARK:FUNC:SUMM:SDEV:PHOL:RES?`

AVERAGE ON/OFF The *AVERAGE ON/OFF* softkey switches averaging over successive sweep measurements on and off.

The measured values can be reset by switching the *AVERAGE ON / OFF* softkey off and on again.

Remote command: `CALC:MARK:FUNC:SUMM:AVER ON`
`CALC:MARK:FUNC:SUMM:PPE:AVER:RES?`
`CALC:MARK:FUNC:SUMM:RMS:AVER:RES?`
`CALC:MARK:FUNC:SUMM:MEAN:AVER:RES?`
`CALC:MARK:FUNC:SUMM:SDEV:AVER:RES?`

NUMBER OF SWEEPS The *NUMBER OF SWEEPS* softkey activates the entry of the number of sweeps for maximum or average value calculation.

SINGLE SWEEP mode The R&S FSUP performs sweeps until the selected number of sweeps is reached and stops then.

CONTINUOUS SWEEP mode Averaging is carried out until the selected number of sweeps is reached. After that, averaging is performed in continuous mode and is then continued as running averaging. Calculation of the maximum peak (*MAX HOLD*) is performed continuously irrespective of the selected number of sweeps.

The valid range values is 0 to 32767.

Depending on the specified number of sweeps, averaging is carried out according to the following rules:

<i>NUMBER OF SWEEPS</i> = 0	Continuous averaging is carried out over 10 measured values.
<i>NUMBER OF SWEEPS</i> = 1	No averaging is carried out.
<i>NUMBER OF SWEEPS</i> > 1	Averaging is carried out over the set number of measured values.



Note

This setting is equivalent to the setting of the sweep count in the *TRACE* menu.

Remote command: `SWE:COUN <value>`

Example

The mean power of a GSM burst with 0 dBm nominal power at 800 MHz is to be measured.

[PRESET]	Set the R&S FSUP to the default setting.
[FREQ: CENTER: 800 MHz]	Set the center frequency to 800 MHz.
[SPAN: ZERO SPAN]	Select time domain display (span = 0 Hz).
[AMPT: 0 dBm]	Set the reference level to 0 dBm.
[BW: RES BW MANUAL: 30 kHz]	Set the resolution bandwidth to 30 kHz in line with the requirements of the GSM standard.
[SWEEP: SWEPTIME MANUAL 600 µs]	Set the sweep time to 600 µs.
[TRIG: VIDEO: 50%]	Use the video signal as trigger source.
[MEAS]	Call the menu for the measurement functions.
[TIME DOM POWER]	Select power measurement in the time domain. The R&S FSUP calculates the mean power from the points of the whole trace. The submenu for configuration of the power measurement is opened. <i>MEAN</i> is already switched on.
[LIMITS ON]	Activate the limitation of the time domain of the power measurement.
[START LIMIT: 250 µs]	Set the start of the power measurement at 250 µs.
[STOP LIMIT: 500 µs]	Set the end of the power measurement at 500 µs.

**Note**

The GSM specifications require the power to be measured between 50% and 90% of the TDMA burst. The time limits set above approximately correspond to the required time domain.

Channel and Adjacent-Channel Power Measurements

For all channel and adjacent-channel power measurements a specified channel configuration is assumed which is for instance based on a specific radio communication system.

This configuration is defined by the nominal channel frequency (= center frequency of the R&S FSUP if only one carrier is active), the channel bandwidth, the channel spacing, the adjacent-channel bandwidth and the adjacent-channel spacing. The R&S FSUP is able to simultaneously measure the power in up to four transmission channels and up to three adjacent channels (10 channels: 4 transmission channels, 3 lower and 3 upper adjacent channels).

It offers two methods for channel and adjacent-channel power measurement:

- The integrated bandwidth method (IBW method), i.e. the integration of trace pixels within the bandwidth of the channel to be measured to the total power of the channel,
- The measurement in time domain (Fast ACP) by means of steep resolution filters simulating the channel.

The two measurements yield the same results. The measurement in time domain can be performed much faster since the complete signal is measured within a channel at the same time. With the IBW method, the channel is divided into subspectra. This is done by means of a bandwidth which is small compared to the channel bandwidth. These subspectra are then combined by integration of the trace pixels.

With the IBW method, the transmission channels or adjacent channels are marked by vertical lines at a distance of half the channel bandwidth to the left and to the right of the corresponding channel center frequency (see [Fig. 4-21](#)).

With the time-domain method, the power versus time is shown for each channel. The boundaries of the channels are marked by vertical lines (see [Fig. 4-22](#)).

For both methods, the results are listed in tables in the lower half of the screen.

The R&S FSUP offers predefined standard settings which can be selected from a table for the common mobile radio standards. Thus, channel configuration is performed automatically without the need to enter the corresponding parameters manually.

For some standards, the channel power and the adjacent-channel power are to be weighted by means of a root-raised cosine filter corresponding to a receive filter. This type of filtering is switched on automatically for both methods on selecting the standard (e.g. NADC, TETRA or 3GPP W-CDMA).




Fig. 4-21 Screen display of adjacent-channel power measurement using the IBW method




Fig. 4-22 Screen display of adjacent-channel power measurement using the time-domain method

Limit values for the adjacent-channel power can be defined for the measurement. If limit checking is switched on, a pass/fail information indicating that the power has been exceeded is displayed during the measurement in the table in the lower half of the screen.



Note

With the CP/ACP measurement switched on the functions SPLIT SCREEN and FULL SCREEN are inhibited.

The channel configuration is defined in the *MEAS - CHAN PWR ACP* or the *MEAS - MULT CARR ACP* menu.

CHAN PWR ACP

MULT CARR ACP

CP/ACP ON/OFF		
CP/ACP STANDARD		
CP/ACP CONFIG ↓	NO. OF ADJ CHAN	
	NO. OF TX CHAN	
	CHANNEL BANDWIDTH	
	CHANNEL SPACING	
	ACP REF SETTINGS	
	CP/ACP ABS/REL	
	CHAN PWR / HZ	
	POWER MODE ↓	CLEAR/WRITE
		MAX HOLD
	ADJUST SETTINGS	
	Side menu	
	ACP LIMIT CHECK	
	EDIT ACP LIMITS	
	SELECT TRACE	
SET CP REFERENCE		
SWEEP TIME		
NOISE CORR ON/OFF		
FAST ACP ON/OFF		
DIAGRAM FULL SIZE		
ADJUST REF LVL		

The *CHAN PWR ACP* and *MULT CARR ACP* softkeys activate channel or adjacent-channel power measurement either for a single carrier signal (*CHAN PWR ACP*) or for several carrier signals (*MULT CARR ACP*), depending on the current measurement configuration. In addition, they open a submenu for defining the parameters for channel power measurement. The softkey selected is shown in color to indicate that a channel or adjacent-channel power measurement is active.

**Note**

The softkeys are available only for measurements in the frequency domain (span > 0).

CP/ACP ON/OFF The *CP/ACP ON/OFF* softkey switches calculation of the channel power or adjacent-channel power on and off.

With default settings the measurement is performed by integrating the powers at the display points within the specified channels (IBW method).

The powers of the adjacent channels are measured either as absolute values or as relative values referenced to the power of a transmission channel. The default setting is relative-value measurement (see *CP/ACP ABS/REL* softkey).

When multi carrier ACP measurement is activated, the number of test points is increased to ensure that adjacent-channel powers are measured with adequate accuracy.

Remote command: `CALC:MARK:FUNC:POW:SEL CPOW|ACP|MCAC`
 `CALC:MARK:FUNC:POW:RES?`
 `CPOW|ACP|MCAC`
 `CALC:MARK:FUNC:POW OFF`

CP/ACP STANDARD The *CP/ACP STANDARD* softkey opens a table for the selection of the settings according to predefined standards. The test parameters for the channel and adjacent-channel measurements are set according to the mobile radio standard.

ACP STANDARD
✓NONE
NADC IS136
TETRA
PDC
PHS
CDPD
CDMA IS95A FWD
CDMA IS95A REV
CDMA IS95C Class 0 FWD
CDMA IS95C Class 0 REV
CDMA J-STD008 FWD
CDMA J-STD008 REV
CDMA IS95C Class 1 FWD
CDMA IS95C Class 1 REV
W-CDMA 4.096 FWD
W-CDMA 4.096 REV
W-CDMA 3GPP FWD
W-CDMA 3GPP REV
CDMA 2000 DS
CDMA 2000 MC1
CDMA 2000 MC3
TD-SCDMA
WLAN 802.11A
WLAN 802.11B
WIMAX
WIBRO

The standards available are listed in the table above.

**Note**

For the R&S FSUP, the channel spacing is defined as the distance between the center frequency of the adjacent channel and the center frequency of the transmission channel. The definition of the adjacent-channel spacing in standards IS95 B and C, IS97 B and C and IS98 B and C is different. These standards define the adjacent-channel spacing from the center of the transmission channel to the closest border of the adjacent channel. This definition is also used for the R&S FSUP when the following standard settings are selected:

CDMA IS95 Class 0 FWD

CDMA IS95 Class 0 REV

CDMA IS95 Class 1 FWD

CDMA IS95 Class 1 REV

The selection of the standard influences the following parameters:

- channel spacing and adjacent-channel spacing
- channel bandwidth, adjacent-channel bandwidth, and type of filtering
- resolution bandwidth
- video bandwidth
- detector
- # of adjacent channels

FAST ACP is not available if a WLAN standard or the WiMAX or WiBro standard is selected.

Trace mathematics and trace averaging are switched off.

The reference level is not influenced by the selection of a standard. To achieve an optimum dynamic range, the reference level has to be set in a way that places the signal maximum close to the reference level without forcing an overload message.

The default setting is *CP/ACP STANDARD NONE*.

Remote command: `CALC:MARK:FUNC:POW:PRES <standard>`

CP/ACP CONFIG See following section [“Setting the Channel Configuration” on page 4.173.](#)

- SET CP REFERENCE** With channel power measurement activated, the *SET CP REFERENCE* softkey defines the currently measured channel power as the reference value. The reference value is displayed in the *CH PWR REF* field; the default value is 0 dBm.
- The softkey is available only for multi carrier ACP measurements.
- In adjacent-channel power measurement with one or several carrier signals, the power is always referenced to a transmission channel, i.e. no value is displayed for *CH PWR REF*.
- Remote command: `POW:ACH:REF:AUTO ONCE`
- SWEEP TIME** The *SWEEP TIME* softkey activates the entry of the sweep time. With the RMS detector, a longer sweep time increases the stability of the measurement results.
- The function of the softkey is identical to the softkey *SWEEP TIME MANUAL* in the *BW* menu.
- Remote command: `SWE:TIM <value>`
- NOISE CORR ON/OFF** If the *NOISE CORR ON/OFF* softkey is activated, the results will be corrected by the instrument's inherent noise, which increases the dynamic range.
- When the function is switched on, a reference measurement of the instrument's inherent noise is carried out. The noise power measured is then subtracted from the power in the channel that is being examined.
- The inherent noise of the instrument depends on the selected center frequency, resolution bandwidth and level setting. Therefore, the correction function is disabled whenever one of these parameters is changed. A disable message is displayed on the screen.
- To enable the correction function in conjunction with the changed setting, press the softkey once more. A new reference measurement is carried out.
- Remote command: `SENS:POW:NCOR ON`
- FAST ACP ON/OFF** The *FAST ACP ON/OFF* softkey switches between the IBW method (*FAST ACP OFF*) and the time domain method (*FAST ACP ON*).
- With *FAST ACP ON* the power measurement is performed in the different channels in the time domain. The R&S FSUP sets the center frequency consecutively to the different channel center frequencies and measures the power with the selected measurement time (= sweep time/number of channels). The RBW filters suitable for the selected standard and frequency offset are automatically used (e.g. root raised cos with IS 136).
- A list of available filters is included in section “[Filter Types](#)” on page 4.103.
- The RMS detector is used for obtaining correct power measurement results. Therefore this requires no software correction factors.
- Measured values are output as a list. The powers of the transmission channels are output in dBm, the powers of the adjacent channels in dBm (*CP/ACP ABS*) or dB (*CP/ACP REL*).
- The sweep time is selected depending on the desired reproducibility of results. Reproducibility increases with sweep time since power measurement is then performed over a longer time period.

As a general approach, it can be assumed that approx. 500 non-correlated measured values are required for a reproducibility of 0.5 dB (99% of the measurements are within 0.5 dB of the true measured value). This holds true for white noise. The measured values are considered as non-correlated when their time interval corresponds to the reciprocal of the measured bandwidth.

With IS 136 the measurement bandwidth is approx. 25 kHz, i.e. measured values at an interval of 40 μ s are considered as non correlated. A measurement time of 20 ms is thus required per channel for 1000 measured values. This is the default sweep time which the R&S FSUP sets in coupled mode. Approx. 5000 measured values are required for a reproducibility of 0.1 dB (99%), i.e. the measurement time is to be increased to 200 ms.

Remote command: SENS:POW:HSP ON

DIAGRAM FULL SIZE The *DIAGRAM FULL SIZE* softkey switches the diagram to full screen size.

Remote command: DISP:WIND1:SIZE LARG|SMAL

ADJUST REF LVL The *ADJUST REF LVL* softkey adjusts the reference level of the R&S FSUP to the measured channel power. This ensures that the settings of the RF attenuation and the reference level are optimally adjusted to the signal level without overloading the R&S FSUP or limiting the dynamic range by a too small S/N ratio.

Since the measurement bandwidth for channel power measurements is significantly lower than the signal bandwidth, the signal path may be overloaded although the trace is still significantly below the reference level.

Remote command: SENS:POW:ACH:PRES:RLEV

For manual setting of the test parameters different from the settings made with *ADJUST SETTINGS* the following should be observed:

Frequency span

The frequency span must at least cover the channels to be measured plus a measurement margin of 10%.

For channel power measurement, the span is $1.1 \times$ channel bandwidth.



Note

If the frequency span is large in comparison with the channel bandwidth (or the adjacent-channel bandwidths) being examined, only a few points on the trace are available per channel. This reduces the accuracy of the waveform calculation for the channel filter used, which has a negative effect on the measurement accuracy.

We therefore strongly recommend that the formulas mentioned be taken into consideration when selecting the frequency span.

Resolution bandwidth (RBW)

To ensure both an acceptable measurement speed and the required selection (to suppress spectral components outside the channel to be measured, especially of the adjacent channels), the resolution bandwidth must not be selected too small or too large. As a general approach, the resolution bandwidth is to be set to values between 1% and 4% of the channel bandwidth.

A larger resolution bandwidth can be selected if the spectrum within the channel to be measured and around it has a flat characteristic. In the standard setting, e.g. for standard IS95A REV at an adjacent channel bandwidth of 30 kHz, a resolution bandwidth of 30 kHz is used. This yields correct results since the spectrum in the neighborhood of the adjacent channels normally has a constant level. For standard NADC/IS136 this is not possible for example, since the spectrum of the transmit signal penetrates into the adjacent channels and a too large resolution bandwidth causes a too low selection of the channel filter. The adjacent-channel power would thus be measured too high.

With the exception of the IS95 CDMA standards, the *ADJUST SETTINGS* softkey sets the resolution bandwidth (RBW) as a function of the channel bandwidth:

$RBW \leq 1/40$ of channel bandwidth.

The maximum possible resolution bandwidth (with respect to the requirement $RBW \leq 1/40$) resulting from the available RBW steps (1, 3) is selected.

Video bandwidth (VBW)

For a correct power measurement, the video signal must not be limited in bandwidth. A restricted bandwidth of the logarithmic video signal would cause signal averaging and thus result in a too low indication of the power (-2.51 dB at very low video bandwidths). The video bandwidth should therefore be selected at least three times the resolution bandwidth.

The *ADJUST SETTINGS* softkey sets the video bandwidth (VBW) as a function of the channel bandwidth as follows:

$VBW \geq 3 \times RBW$.

The smallest possible VBW with regard to the available step size will be selected.

Detector

The *ADJUST SETTINGS* softkey selects the RMS detector.

The RMS detector is selected since it correctly indicates the power irrespective of the characteristics of the signal to be measured. In principle, the sample detector would be possible as well. Due to the limited number of trace pixels used to calculate the power in the channel, the sample detector would yield less stable results. Averaging, which is often performed to stabilize the measurement results, leads to a too low level indication and should therefore be avoided. The reduction in the displayed power depends on the number of averages and the signal characteristics in the channel to be measured.

Setting the Channel Configuration

CP/ACP CONFIG

NO. OF ADJ CHAN	
NO. OF TX CHAN	
CHANNEL BANDWIDTH	
CHANNEL SPACING	
ACP REF SETTINGS	
CP/ACP ABS/REL	
CHAN PWR / HZ	
POWER MODE ↓	CLEAR/WRITE
	MAX HOLD
ADJUST SETTINGS	
Side menu	
ACP LIMIT CHECK	
EDIT ACP LIMITS	
SELECT TRACE	

The *CP/ACP CONFIG* softkey opens a submenu for configuration of the channel power and adjacent channel power measurement independently of the offered standards.

The channel configuration includes the number of channels to be measured, the channel bandwidths (*CHANNEL BANDWIDTH*), and the channel spacings (*CHANNEL SPACING*).

Limit values can additionally be specified for the adjacent-channel power (*ACP LIMIT CHECK* and *EDIT ACP LIMITS*) which are checked for compliance during the measurement.

NO. OF ADJ CHAN

The *NO. OF ADJ CHAN* softkey activates the entry of the number $\pm n$ of adjacent channels to be considered in the adjacent-channel power measurement.

Numbers from 0 to 12 can be entered.

The following measurements are performed depending on the number of the channels.

- 0 Only the channel powers are measured.
- 1 The channel powers and the power of the upper and lower adjacent channel are measured.
- 2 The channel powers, the power of the upper and lower adjacent channel and of the next higher and lower channel (alternate channel 1) are measured.
- 3 The channel power, the power of the upper and lower adjacent channel, the power of the next higher and lower channel (alternate channel 1) and of the next but one higher and lower adjacent channel (alternate channel 2) are measured.

With higher numbers the procedure is expanded accordingly.

Remote command: POW:ACH:ACP 1

This increased number of adjacent channels is realized for all the relevant settings like:

```

ACLR LIMIT CHECK :CALC:LIM:ACP:ACH:RES?
                  :CALC:LIM:ACP:ALT1..11:RES?

EDIT ACLR LIMITS :CALC:LIM:ACP:ACH:STAT ON
                  :CALC:LIM:ACP:ACH:ABS -10dBm,-10dBm
                  :CALC:LIM:ACP:ACH:ABS:STAT ON
                  :CALC:LIM:ACP:ALT1..11 0dB,0dB
                  :CALC:LIM:ACP:ALT1..11:STAT ON
                  :CALC:LIM:ACP:ALT1..11:ABS -10dBm,-10dBm
                  :CALC:LIM:ACP:ALT1..11:ABS:STAT ON

ADJ CHAN         :SENS:POW:ACH:BWID:ALT1..11 30kHz
BANDWIDTH

ADJ CHAN SPACING :SENS:POW:ACH:SPAC:ALT1..11 4MHz

```

NO. OF TX CHAN The *NO. OF TX CHAN* softkey enables the entry of the number of carrier signals to be considered in channel and adjacent-channel power measurements.

Numbers from 1 to 12 can be entered.

The softkey is available only for multi carrier ACP measurements.

Remote command: SENS:POW:ACH:TXCH:COUN 12

CHANNEL BANDWIDTH The *CHANNEL BANDWIDTH* softkey opens a table for defining the channel bandwidths for the transmission channels and the adjacent channels.

TX/ACP CHANNEL BW	
CHAN	BANDWIDTH
TX	14 kHz
ADJ	14 kHz
ALT1	14 kHz
ALT2	14 kHz
ALT3	14 kHz
ALT4	14 kHz
ALT5	14 kHz
ALT6	14 kHz
ALT7	14 kHz
ALT8	14 kHz
ALT9	14 kHz
ALT10	14 kHz
ALT11	14 kHz

The transmission-channel bandwidth is normally defined by the transmission standard. The correct bandwidth is set automatically for the selected standard (see *CP/ACP STANDARD* softkey).

With the IBW method (*FAST ACP OFF*), the channel bandwidth limits are marked by two vertical lines right and left of the channel center frequency. It can in this way be visually checked whether the entire power of the signal under test is within the selected channel bandwidth.

Measurements in the time domain (*FAST ACP ON*) are performed in the zero span mode. The channel limits are indicated by vertical lines. For measurements requiring channel bandwidths deviating from those defined in the selected standard the IBW method is to be used.

Refer to section “[Filter Types](#)” on page 4.103 for a list of available filters.

When measuring according to the IBW method (*FAST ACP OFF*) the bandwidths of the different adjacent channels are to be entered numerically. Since all adjacent channels often have the same bandwidth, the other channels Alt1 and Alt2 are set to the bandwidth of the adjacent channel on entering the adjacent-channel bandwidth (ADJ). Thus only one value needs to be entered in case of equal adjacent channel bandwidths. The same holds true for the ALT2 channels (alternate channels 2) when the bandwidth of the ALT1 channel (alternate channel 1) is entered.



Notes

The channel spacings can be set separately by overwriting the table from top to bottom.

The entry "TX" is only available for the multi carrier ACP measurement.

Remote command: SENS:POW:ACH:BWID:CHAN 14kHz
 SENS:POW:ACH:BWID:ACH 1kHz
 SENS:POW:ACH:BWID:ALT1 14kHz
 SENS:POW:ACH:BWID:ALT2 14kHz

CHANNEL SPACING The *CHANNEL SPACING* softkey opens a table for defining the channel spacings for the TX channels as well as for the adjacent channels.



Note

The entry "TX" is only available for the multi carrier ACP measurement.

TX channels

The spacing between every TX channels can be defined separately. Therefore a TX spacing 1-2 for the spacing between the first and the second carrier, a TX spacing 2-3 for the spacing between the second and the third carrier and so on can be defined. In order to allow a convenient setup for the system with equal TX channel spacing, the value of TX spacing 1-2 will be copied in all the spacing below after entry, the TX spacing 2-3 will be copied in all the spacing below after entry and so forth.

**Note**

For different spacings a setup from top to bottom is necessary

If the spacings are not equal the channel distribution according to the center frequency is as follows:

- Odd number of TX channels:
The middle TX channel is centered to center frequency.
- Even number of TX channels:
The two TX channels in the middle are used to calculate the frequency between those two channels. This frequency is aligned to the center frequency.

TX/ACP CHANNEL SPACING	
CHAN	SPACING
TX1-2	20 kHz
TX2-3	20 kHz
TX3-4	20 kHz
TX4-5	20 kHz
TX5-6	20 kHz
TX6-7	20 kHz
TX7-8	20 kHz
TX8-9	20 kHz
TX9-10	20 kHz
TX10-11	20 kHz
TX11-12	20 kHz
ADJ	20 kHz
ALT1	40 kHz
ALT2	60 kHz
ALT3	80 kHz
ALT4	100 kHz
ALT5	120 kHz
ALT6	140 kHz
ALT7	160 kHz
ALT8	180 kHz
ALT9	200 kHz
ALT10	220 kHz
ALT11	240 kHz

Adjacent channels

Since all the adjacent channels often have the same distance to each other, the entry of the adjacent-channel spacing (ADJ) causes channel spacing ALT1 to be set to twice and channel spacing ALT2 to three times the adjacent-channel spacing (and so on). Thus only one value needs to be entered in case of equal channel spacing. The same holds true for the ALT2 channels when the bandwidth of the ALT1 channel is entered.



Note


The channel spacings can be set separately by overwriting the table from top to bottom.

If the ACP or MCACP measurement is started all settings according to the standard including the channel bandwidths and channel spacings are set and can be adjusted afterwards.

Remote command: :SENS:POW:ACH:SPAC:CHAN 20kHz
 :SENS:POW:ACH:SPAC:ACH 20kHz
 :SENS:POW:ACH:SPAC:ALT1 40kHz
 :SENS:POW:ACH:SPAC:ALT2 60kHz

ACP REF SETTINGS

The *ACP REF SETTINGS* softkey opens a table for selecting the transmission channel to which the adjacent-channel relative power values should be referenced.



- TX CHANNEL 1 - 12** Selection of one of the channels.
- MIN POWER TX CHANNEL** The transmission channel with the lowest power is used as a reference channel.
- MAX POWER TX CHANNEL** The transmission channel with the highest power is used as a reference channel.
- LOWEST & HIGHEST CHANNEL** The outer left hand transmission channel is the reference channel for the lower adjacent channels, the outer right hand transmission channel that for the upper adjacent channels.

The softkey is available only for multi carrier ACP measurements.

Remote command: SENS:POW:ACH:REF:TXCH:MAN 1
 SENS:POW:ACH:REF:TXCH:AUTO MIN

CP/ACP ABS/REL The *CP/ACP ABS/REL* softkey (channel power absolute/relative) switches between absolute and relative power measurement in the channel.

CP/ACP ABS The absolute power in the transmission channel and in the adjacent channels is displayed in the unit of the y-axis, e.g. in dBm, dBmV.

CP/ACP REL For adjacent-channel power measurements (*NO. OF ADJ CHAN > 0*), the level of the adjacent channels is displayed relative to the level of the transmission channel in dBc.

For channel power measurements (*NO. OF ADJ CHAN = 0*) with a single carrier, the power of the transmission channel is displayed relative to the power of a reference channel defined by *SET CP REFERENCE*. This means:

1. Declare the power of the currently measured channel as the reference value, using the *SET CP REFERENCE* softkey.
2. Select the channel of interest by varying the channel frequency (R&S FSUP center frequency).

With linear scaling of the y-axis, the power of the new channel relative to the reference channel (CP/CP_{ref}) is displayed. With dB scaling, the logarithmic ratio $10\lg(CP/CP_{ref})$ is displayed.

The relative channel power measurement can thus also be used for universal adjacent-channel power measurements. Each channel can be measured individually.

Remote command: `SENS:POW:ACH:MODE ABS`

CHAN PWR / HZ The *CHAN PWR / HZ* softkey toggles between the measurement of the total channel power and the measurement of the channel power referenced to a 1-Hz bandwidth.

The conversion factor is $10 \cdot \lg \frac{1}{\text{Channel Bandwidth}}$

By means of this function it is possible e.g. to measure the signal/noise power density or use the additional functions *CP/ACP REL* and *SET CP REFERENCE* to obtain the signal to noise ratio.

Remote command: `CALC:MARK:FUNC:POW:RES:PHZ ON|OFF`

POWER MODE The *POWER MODE* softkey opens the submenu for selecting the power mode.

CLEAR/WRITE
MAX HOLD

CLEAR/WRITE In the *CLEAR/WRITE* mode the channel power and the adjacent channel powers are calculated directly from the current trace (default mode).

MAX HOLD In *MAX HOLD* mode the power values are still derived from the current trace, but they are compared with the previous power value using a maximum algorithm. The higher value is remained.

Remote command: `CALC:MARK:FUNC:POW:MODE WRIT|MAXH`

ADJUST SETTINGS The *ADJUST SETTINGS* softkey automatically optimizes the instrument settings for the selected power measurement (see below).

All instrument settings relevant for a power measurement within a specific frequency range (channel bandwidth) are optimized for the selected channel configuration (channel bandwidth, channel spacing):

- Frequency span:

The frequency span should cover at least all channels to be considered in a measurement.

For channel power measurements, the frequency span is set as follows:

$$(\text{No. of transmission channels} - 1) \times \text{transmission channel spacing} + 2 \times \text{transmission channel bandwidth} + \text{measurement margin}$$

For adjacent-channel power measurements, the frequency span is set as a function of the number of transmission channels, the transmission channel spacing, the adjacent-channel spacing, and the bandwidth of one of adjacent-channels ADJ, ALT1 or ALT2, whichever is furthest away from the transmission channels:

$$(\text{No. of transmission channels} - 1) \times \text{transmission channel spacing} + 2 \times (\text{adjacent-channel spacing} + \text{adjacent-channel bandwidth}) + \text{measurement margin}$$

The measurement margin is approx. 10% of the value obtained by adding the channel spacing and the channel bandwidth.

- Resolution bandwidth: $\text{RBW} \leq 1/40$ of channel bandwidth
- Video bandwidth: $\text{VBW} \geq 3 \times \text{RBW}$
- Detector: RMS detector

Trace math and trace averaging functions are switched off.

The reference level is not influenced by *ADJUST SETTINGS*. It can be separately adjusted with *ADJUST REF LVL*.

The adjustment is carried out only once; if necessary, the instrument settings can be changed later.

Remote command: `SENS:POW:ACH:PRES ACP|CPOW|MCAC|OBW`

ACP LIMIT CHECK The *ACP LIMIT CHECK* softkey switches the limit check for the ACP measurement on and off.

Remote command: `CALC:LIM:ACP ON`
 `CALC:LIM:ACP:ACH:RES?`
 `CALC:LIM:ACP:ALT:RES?`

EDIT ACP LIMITS The *EDIT ACP LIMITS* softkey opens a table for defining the limits for the ACP measurement.

The following rules apply for the limits:

- A separate limit can be defined for each adjacent channel. The limit applies to both the upper and the lower adjacent channel.
- A relative and/or absolute limit can be defined. The check of both limit values can be activated independently.
- The R&S FSUP checks adherence to the limits irrespective of whether the limits are absolute or relative or whether the measurement is carried out with absolute or relative levels. If both limits are active and if the higher of both limit values is exceeded, the measured value is marked accordingly.



Note

Measured values exceeding the limit are marked by a preceding asterisk.

Remote command: `CALC:LIM:ACP ON`
 `CALC:LIM:ACP:ACH 0dB,0dB`
 `CALC:LIM:ACP:ACH:STAT ON`
 `CALC:LIM:ACP:ACH:ABS -10dBm,-10dBm`
 `CALC:LIM:ACP:ACH:ABS:STAT ON`
 `CALC:LIM:ACP:ALT1 0dB,0dB`
 `CALC:LIM:ACP:ALT1:STAT ON`
 `CALC:LIM:ACP:ALT1:ABS -10dBm,-10dBm`
 `CALC:LIM:ACP:ALT1:ABS:STAT ON`
 `CALC:LIM:ACP:ALT2 0dB,0dB`
 `CALC:LIM:ACP:ALT2:STAT ON`
 `CALC:LIM:ACP:ALT2:ABS -10dBm,-10dBm`
 `CALC:LIM:ACP:ALT2:ABS:STAT ON`


SELECT TRACE The *SELECT TRACE* softkey selects the trace on which the CP/ACP measurement is to be performed. Only activated traces can be selected, i.e. traces not set to BLANK.

Remote command: `SENS:POW:TRAC 1`

Examples

Measurement of adjacent-channel power for a specific standard:

The adjacent-channel power is to be measured for a signal at 800 MHz with 0 dBm level in line with IS136.

[PRESET]	Set the R&S FSUP to the default setting.
[FREQ: CENTER: 800 MHz]	Set the center frequency to 800 MHz.
[AMPT: 0 dBm]	Set the reference level to 0 dBm.
[MEAS]	Call the menu for the measurement functions.
[CHAN PWR / ACP]	Select the channel and adjacent-channel power measurement function. The measurement is performed with the default settings or a previously defined setting. The submenu for setting the desired new configuration is opened.
[CP/ACP STANDARD: select IS136: ENTER]	Select the NADC (IS136) standard.
[CP/ACP CONFIG]	Call the submenu for configuration of the adjacent-channel power measurement.
[NO. OF ADJ CHAN: 2 ENTER]	Select two adjacent channels for the measurement, i.e. the adjacent channel and the alternate channel are measured.
[ADJUST SETTINGS]	Set the optimum span, resolution bandwidth (RBW), video bandwidth (VBW) and detector automatically for the measurement. The absolute channel power and the relative power of the adjacent channels are displayed on the screen.
	Change to the main menu for channel power measurement.
[ADJUST REF LVL]	Set the reference level equal to the channel power measured.

Measurement with user-specific channel configuration:

Measurement of the adjacent-channel power ratio (ACPR) of an IS95 CDMA signal at 800 MHz, level 0 dBm. Similar to example 1, the setting can be simplified by using *CP/ACP STANDARD*.

[PRESET]	Set the R&S FSUP to the default setting.
[FREQ: CENTER: 800 MHz]	Set the center frequency to 800 MHz.
[AMPT: 0 dBm]	Set the reference level to 0 dBm.
[MEAS]	Call the menu for the measurement functions.
[CHAN PWR / ACP]	Select the channel and adjacent-channel power measurement function. The measurement is carried out with the default settings or a previously defined setting. The submenu for setting the desired new configuration is opened.

[CP/ACP CONFIG] Call the submenu for defining the channel configuration.

[NO. OF ADJ CHAN: 2 ENTER] Select two adjacent channels for the measurement, i.e. the adjacent channel and the alternate channel are measured.

[CHANNEL BANDWIDTH: 1.23 MHz: 30 kHz] Set the channel bandwidth to 1.23 MHz in accordance with IS 95. Set the adjacent-channel bandwidth to 30 kHz.

TX/ACP CHANNEL BW	
CHAN	BANDWIDTH
TX	1.23 MHz
ADJ	30 kHz
ALT1	30 kHz
ALT2	30 kHz

Upon entry of 30 kHz for the adjacent channel the alternate channels are also set to 30 kHz.

[CHAN SPACING: 1.25 MHz: 885 kHz: - 1.98 MHz] 2.97 MHz] Open the list for entering the channel spacings.

TX/ACP CHAN SPACING	
CHAN	SPACING
TX	1.25 MHz
ADJ	885 kHz
ALT1	1.98 MHz
ALT2	2.97 MHz

Upon entry of 885 kHz for the adjacent channel the channels ALT1 and ALT2 are set to 1770 kHz and 2655 kHz. Upon entry of 1.98 MHz for the alternate channel 1 the alternate channel 2 is set to 2.97 MHz.


[ADJUST SETTINGS] Automatically set the optimum span (= 5 MHz), resolution bandwidth (RBW = 30 kHz), video bandwidth (VBW = 300 kHz) and detector (RMS) for the measurement. The absolute channel power and the relative power of the adjacent channels and alternate channels are displayed on the screen.

PREV

Go to the main menu for channel power measurement.

[ADJUST REF LVL] Set the reference level equal to the channel power measured.

Measurement of signal/noise power density (C/No) of an IS95 CDMA signal (frequency 800 MHz, level 0 dBm)

[PRESET]	Set the R&S FSUP to the default setting.
[FREQ: CENTER: 800 MHz]	Set the center frequency to 800 MHz.
[AMPT: 0 dBm]	Set the reference level to 0 dBm.
MEAS]	Call the menu for the measurement functions.
[CHAN PWR / ACP]	Select the channel and adjacent-channel power measurement. The measurement is performed with the default setting or a previously defined setting. The submenu for setting the desired new configuration is opened.
[CP/ACP CONFIG]	Call the submenu for defining the channel configuration.
[NO. OF ADJ CHAN: 0 ENTER]	Do not select an adjacent channel for the measurement, i.e. the measurement is carried out in one channel only.
[CHANNEL BANDWIDTH: 1.23 MHz]	Set the channel bandwidth to 1.23 MHz in line with IS95.
[ADJUST SETTINGS]	Set the optimum span (= 5 MHz), resolution bandwidth (RBW = 30 kHz), video bandwidth (VBW = 300 kHz) and detector (RMS) for the measurement automatically. The absolute channel power and the relative power of the adjacent channels and alternate channels are displayed on the screen.
	Go to the main menu for channel power measurement
[ADJUST REF LVL]	Set the reference level equal to the channel power measured.
[SET CP REFERENCE]	Set the measured channel power as a reference for the subsequent measurements.
[CP/ACP ABS / REL]	Select relative measurement related to the reference power set with <i>SET REFERENCE</i> (result 0 dB).
[CHAN PWR / HZ]	Select power measurement related to 1 Hz bandwidth (result -60.9 dB).
[FREQ: CENTER: 805 MHz]	Set the center frequency to 805 MHz. The R&S FSUP measures the channel power at 1.23 MHz bandwidth and outputs the result in dB relative to the reference power and 1 Hz bandwidth.

Measurement of Occupied Bandwidth

An important characteristics of a modulated signal is its occupied bandwidth. In a radio communications system for instance the occupied bandwidth must be limited to enable distortion-free transmission in adjacent channels. The occupied bandwidth is defined as the bandwidth containing a defined percentage of the total transmitted power. A percentage between 10% and 99.9% can be set on the R&S FSUP.

OCCUPIED BANDWIDTH

OCCUP BW ON/OFF
% POWER BANDWIDTH
CHANNEL BANDWIDTH
ADJUST REF LVL
ADJUST SETTINGS

The *OCCUPIED BANDWIDTH* softkey activates measurement of the occupied bandwidth according to the current configuration and opens the submenu for configuring the measurement. The softkey is available only in frequency domain (span > 0) and is highlighted when the measurement is switched on.

In the spectrum display mode, this measurement determines the bandwidth that contains a predefined percentage of the power of the displayed frequency range (*% POWER BANDWIDTH* softkey). The occupied bandwidth is output in the marker display field and marked on the trace by temporary markers.

**Note**

- The softkey is only available in the frequency domain (span > 0).
- The measurement is performed on the trace with marker 1. In order to evaluate another trace, marker 1 must be placed on another trace by means of *SELECT TRACE* in the *MARKER* menu

OCCUP BW ON/OFF

The *OCCUP BW ON/OFF* softkey switches measurement of the occupied bandwidth on or off.

Remote command: `CALC:MARK:FUNC:POW:SEL OBW`
 `CALC:MARK:FUNC:POW:RES? OBW`
 `CALC:MARK:FUNC:POW OFF`

% POWER BANDWIDTH

The *% POWER BANDWIDTH* softkey opens the entry of the percentage of power related to the total power in the displayed frequency range which defines the occupied bandwidth (percentage of total power).

The valid range of values is 10% to 99.9%.

Remote command: `SENS:POW:BWID 99PCT`

CHANNEL BANDWIDTH

The *CHANNEL BANDWIDTH* softkey opens an input window for defining the channel bandwidth for the transmission channel. For measurements in line with a specific transmission standard, the bandwidth specified by the standard for the transmission channel must be entered.

The default setting is 14 kHz.

The specified channel bandwidth is used for optimization of the test parameters of the R&S FSUP with *ADJUST SETTINGS*.

Remote command: `SENS:POW:ACH:BWID 14kHz`

ADJUST REF LVL The *ADJUST REF LVL* softkey adjusts the reference level of the R&S FSUP to the measured total power of the signal. The softkey is activated after the first sweep with the measurement of the occupied bandwidth has been completed and the total power of the signal is thus known.

Adjusting the reference level ensures that the signal path of the R&S FSUP will not be overloaded and the dynamic range not limited by too low a reference level.

Since the measurement bandwidth for channel power measurements is significantly lower than the signal bandwidth, the signal path may be overloaded although the trace is distinctly below the reference level. If the measured channel power is equal to the reference level, the signal path cannot be overloaded.

Remote command: `SENS:POW:ACH:PRES:RLEV`

ADJUST SETTINGS The *ADJUST SETTINGS* softkey optimizes the instrument settings for the measurement of the occupied bandwidth according to the specified channel bandwidth.

All instrument settings relevant for power measurement within a specific frequency range are optimized:

- frequency span: $3 \times$ channel bandwidth
- resolution bandwidth: $RBW \leq 1/40$ of channel bandwidth
- video bandwidth: $VBW \geq 3 \times RBW$
- detector: RMS

The reference level is not influenced by *ADJUST SETTINGS*. For an optimum dynamic range it should be selected in a way that the signal maximum is close to the reference level.

The adjustment is carried out only once; if necessary, the instrument settings may be changed later.

Remote command: `SENS:POW:PRES:OBW`

Measurement principle

For example, the bandwidth containing 99% of the signal power is to be determined. The routine first calculates the total power of all displayed points of the trace. In the next step, the points from the right edge of the trace are summed up until 0.5% of the total power is reached. Auxiliary marker 1 is positioned at the corresponding frequency. Then the R&S FSUP sums up the points from the left edge of the trace until 0.5% of the power is reached. Auxiliary marker 2 is positioned at this point. 99% of the power is now between the two markers. The distance between the two frequency markers is the occupied bandwidth which is displayed in the marker info field.

A prerequisite for correct measurement is that only the signal to be measured is visible on the screen of the R&S FSUP. An additional signal would invalidate the measurement.

To ensure correct power measurement especially for noise signals and to obtain the correct occupied bandwidth, the following settings should be selected:

RBW	<< occupied bandwidth (approx. 1/20 of occupied bandwidth, for voice communication type. 300 Hz or 1 kHz)
VBW	$\geq 3 \times$ RBW
Detector	RMS or sample
Span	≥ 2 to $3 \times$ occupied bandwidth

Some of the measurement specifications (e.g. PDC, RCR STD-27B) require measurement of the occupied bandwidth using a peak detector. The detector setting of the R&S FSUP has to be changed accordingly then.

Example

Measurement of occupied bandwidth of a PDC signal at 800 MHz, level 0 dBm

[PRESET]	Set the R&S FSUP to the default setting.
[FREQ: CENTER: 800 MHz]	Set the center frequency to 800 MHz.
[AMPT: 0 dBm]	Set the reference level to 0 dBm.
[MEAS]	Call the menu for the measurement functions.
[OCCUPIED BANDWIDTH]	Select measurement of the occupied bandwidth and open the submenu for configuring the measurement.
[% POWER BANDWIDTH: 99%]	Select 99% for the bandwidth to be measured.
[CHANNEL BANDWIDTH: 21 kHz]	Enter the channel bandwidth of 21 kHz specified by PDC.
[ADJUST SETTINGS]	Optimize the measurement parameters for the specified channel bandwidth. Allow for a complete frequency sweep so that the R&S FSUP can determine the total signal power.
[ADJUST REF LVL]	Adjust the reference level to the measured signal power.
[TRACE: DETECTOR: DETECTOR MAX PEAK]	PDC requires measurement of the occupied bandwidth using a peak detector. Therefore, switch on the peak detector instead of the RMS detector selected by <i>ADJUST SETTINGS</i> .

Measurement of Signal Amplitude Statistics

Digital modulated signals are similar to white noise within the transmit channel, but are different in their amplitude distribution. In order to transmit the modulated signal without distortion all amplitudes of the signal have to be transmitted linearly, e.g. from the output power amplifier. Most critical are the peak amplitude values, of course.

Degradation in transmit quality caused by a transmitter two port network is dependent on the amplitude of the peak values as well as on their probability.

The probability of amplitude values can be measured with the APD function (Amplitude Probability Distribution). During a selectable measurement time all occurring amplitude values are assigned to an amplitude range. The number of amplitude values in the specific ranges is counted and the result is displayed as a histogram. Each bar of the histogram represents the percentage of measured amplitudes within the specific amplitude range.




Fig. 4-23 Simplified block diagram for APD measurement




Fig. 4-24 Display of the amplitude probability distribution




Fig. 4-25 Display of the complementary cumulative distribution function (CCDF)


Alternate to the histogram display of the APD the Complementary Cumulative Distribution Function (CCDF) can be displayed. It shows the probability of an amplitude exceeding a specific value.

For the APD function the x-axis is scaled in absolute values in dBm, whereas for the CCDF function the x-axis is scaled relative to the MEAN POWER measured.

Definitions:

Crest factor = peak voltage to rms

CCDF = complementary cumulative distribution function



Note

During an active statistic measurement, the functions FULL SCREEN, SPLIT SCREEN and selection of the active diagram via the SCREEN A / SCREEN B hotkeys are disabled.

SIGNAL STATISTIC The *SIGNAL STATISTIC* softkey opens a submenu for measurement of signal statistics.

APD ON/OFF	
CCDF ON/OFF	
PERCENT MARKER	
RES BW	
NO OF SAMPLES	
SCALING ↓	X-AXIS REF LEVEL
	X-AXIS RANGE
	Y-UNIT %/ABS
	Y-AXIS MAX VALUE
	Y-AXIS MIN VALUE
	ADJUST SETTINGS
	DEFAULT SETTINGS
ADJUST SETTINGS	
CONT MEAS	
SINGLE MEAS	

In the submenu measurement of amplitude probability density (*APD*) and complementary cumulative distribution (*CCDF*) can be selected alternately. Only one of the signal statistic functions can be switched on at a time.

In default mode all statistic functions are switched off.

With a statistic function switched on the R&S FSUP is set into zero span mode automatically.

The R&S FSUP measures the statistics of the signal applied to the RF input with the resolution bandwidth set. In order not to influence the peak amplitudes the video bandwidth is automatically set to 10 times the resolution bandwidth. The sample detector is used for detecting the video voltage.

APD ON/OFF The *APD ON/OFF* softkey switches on or off the amplitude probability distribution function. When the APD function is switched on, the CCDF function is switched off automatically.

Remote command: `CALC:STAT:APD ON`

CCDF ON/OFF The *CCDF ON/OFF* softkey switches on or off the complementary cumulative distribution function. When the CCDF function is switched on, the APD function is switched off automatically.

Remote command: `CALC:STAT:CCDF ON`

PERCENT MARKER If the CCDF function is active, the *PERCENT MARKER* softkey allows to position marker 1 by entering a probability value. Thus, the power which is exceeded with a given probability can be determined very easily.

If marker 1 is in the switched-off state, it will be switched on automatically.

Remote command: `CALC:MARK:Y:PERC 0...100%`

RES BW The *RES BW* softkey sets the resolution bandwidth in the menu *STATISTIC FUNCTION* directly without switching to the corresponding menu (*BW*). The function of the softkey is identical to the softkey *RES BW MANUAL* in the *BW* menu.

For correct measurement of the signal statistics the resolution bandwidth has to be wider than the signal bandwidth in order to transmit the actual peaks of the signal amplitude correctly. Video bandwidth is set to 10 MHz automatically with a statistic function switched on.

Remote command: `BAND 3 MHz`

NO OF SAMPLES The *NO OF SAMPLES* softkey sets the number of power measurements taken into account for the statistics.

Please note that the overall measurement time is influenced by the number of samples selected as well as by the resolution bandwidth set up for the measurement as the resolution bandwidth directly influences the sampling rate.

Remote command: `CALC:STAT:NSAM <value>`

SCALING

The *SCALING* softkey opens a submenu that allows changing the scaling parameters for both the x- and the y-axis.

X-AXIS REF LEVEL
X-AXIS RANGE
Y-UNIT %/ABS
Y-AXIS MAX VALUE
Y-AXIS MIN VALUE
ADJUST SETTINGS
DEFAULT SETTINGS

X-AXIS REF LEVEL The *X-AXIS REF LEVEL* softkey changes the level settings of the instrument and sets the maximum power to be measured.

The function is identical to softkey *REF LEVEL* in *AMPT* menu.

For the *APD* function this value is mapped to the right diagram border. For the *CCDF* function there is no direct representation of this value on the diagram as the x-axis is scaled relatively to the *MEAN POWER* measured.

Remote command: `CALC:STAT:SCAL:X:RLEV <value>`

X-AXIS RANGE	<p>The <i>X-AXIS RANGE</i> softkey changes the level range to be covered by the statistics measurement selected.</p> <p>The function is identical to softkey <i>RANGE LOG MANUAL</i> in <i>AMPT</i> menu.</p> <p>Remote command: <code>CALC:STAT:SCAL:X:RANG <value></code></p>
Y-UNIT %/ABS	<p>The softkey <i>Y-UNIT %/ABS</i> defines the scaling type on the y-axis. The default case are the absolute probability. This can be changed to percent values. The softkeys <i>Y-AXIS MIN</i> and <i>Y-AXIS MAX</i> are using values based on the <i>Y-UNIT</i> setting.</p> <p>Remote command: <code>CALC:STAT:SCAL:Y:UNIT PCT ABS</code></p> <p>The 0.01%, 0.1%, 1% and 10% value from the CCDF measurement are shown in the bottom screen half. Those values can also queried via remote:</p> <p>Remote command: <code>CALC:STAT:CCDF:X? P0_01 P0_1 P1 P10</code></p>
Y-AXIS MAX VALUE	<p>The <i>Y-AXIS MAX VALUE</i> softkey defines the upper limit of the displayed probability range.</p> <p>Values on the y-axis are normalized which means that the maximum value is 1.0. As the y-axis scaling has a logarithmic axis the distance between max and min value must be at least one decade.</p> <p>Remote command: <code>CALC:STAT:SCAL:Y:UPP <value></code></p>
Y-AXIS MIN VALUE	<p>The <i>Y-AXIS MIN VALUE</i> softkey defines the lower limit of the displayed probability range.</p> <p>As the y-axis scaling has a logarithmic axis the distance between max and min value must be at least one decade. Valid values are in the range $0 < \text{value} < 1$.</p> <p>Remote command: <code>CALC:STAT:SCAL:Y:LOW <value></code></p>
ADJUST SETTINGS	<p>The <i>ADJUST SETTINGS</i> softkey optimizes the level settings of the R&S FSUP according to the measured peak power in order to gain maximum sensitivity of the instrument.</p> <p>The level range is adjusted according to the measured difference between peak and minimum power for APD measurement and peak and mean power for CCDF measurement in order to obtain maximum power resolution.</p> <p>Additionally the probability scale is adapted to the selected number of samples.</p> <p>Remote command: <code>CALC:STAT:SCAL:AUTO ONCE</code></p>

DEFAULT SETTINGS The *DEFAULT SETTINGS* softkey resets the x- and y-axis scalings to their PRESET values.

- x-axis ref level: -20 dBm
- x-axis range APD: 100 dB
- x-axis range CCDF: 20 dB
- y-axis upper limit: 1.0
- y-axis lower limit: 1E-6

Remote command: `CALC:STAT:PRES`

ADJUST SETTINGS see [“ADJUST SETTINGS” on page 4.191](#)

CONT MEAS The *CONT MEAS* softkey starts collecting a new sequence of sample data and calculating the APD or CCDF curve depending on the selected measurement. The next measurement is started automatically as soon as the indicated number of samples has been reached.

Remote command: `INIT:CONT ON;`
 `INIT:IMM`

SINGLE MEAS The *SINGLE MEAS* softkey starts collecting a new sequence of sample data and calculating the APD or CCDF curve depending on the selected measurement. At the beginning of the measurement previously obtained measurement results are discarded.

Remote command: `INIT:CONT OFF;`
 `INIT:IMM`

Hint for usage of the marker functions with measurement of signal statistics

With the signal statistic measurement level always is displayed on x-axis. Y-axis always is a normalized value between 0 and 1. In contrary to use of marker in frequency or time domain marker is input in level values and the output is in percentage values.

Example

Measurement of CCDF of a IS95 BTS signal, level 0 dBm, frequency 800 MHz

- | | |
|--------------------------------|--|
| [PRESET] | Switch on preset settings. |
| [FREQ: CENTER: 800 MHz] | Set center frequency to 800 MHz. |
| [AMPT: 10 dBm] | Set reference level to 10 dBm. |
| [BW: 3 MHz] | Set resolution bandwidth to 3 MHz (resolution bandwidth shall be wider then signal bandwidth (1.25 MHz) in order to have the complete signal within the resolution bandwidth). |
| [MEAS] | Call the menu for measurement functions. |
| [SIGNAL STATISTIC] | Call the menu for signal statistics measurement. |

[CCDF ON /OFF]	Switch on measurement of the complementary cumulative distribution function. The R&S FSUP switches to zero span mode. The power of the signal and the CCDF is calculated for the number of samples selected. With the CCDF function sample detector and video bandwidth are set automatically.
[NO OF SAMPLES: 10000]	Set the number of measurement samples to 10000.
[SINGLE MEAS]	Start the measurement sequence. At the end the resulting trace will display the CCDF for the measured 10000 samples.

Measurement of Carrier/Noise Ratio C/N and C/No

Using the carrier/noise measurement function, the R&S FSUP determines the C/N ratio which can also be shown normalized to a 1 Hz bandwidth (function C/No).

To determine the noise power, a channel at the set center frequency is examined. The bandwidth of the channel is fixed by means of the *CHANNEL BANDWIDTH* function.

The largest signal in the frequency span is the carrier. It is searched when the function is activated and is marked by means of the *REFERENCE FIXED* marker. The noise power of the channel is subtracted from the signal level obtained (C/N), and in the case of a C/No measurement it is referred to a 1 Hz bandwidth.

There are two methods for measuring the carrier/noise ratio:

1. The carrier is outside the channel examined:

In this case, it is sufficient to switch on the desired measurement function and to set the channel bandwidth. The carrier/noise ratio is displayed on the screen.

2. The carrier is inside the channel examined:

In this case, the measurement must be performed in two steps. First, the reference measurement is performed with the carrier being active. This is done by switching on either the C/N or the C/No measurement and waiting for the end of the next measurement run. Then, the carrier is switched off so that only the noise of the test setup is active in the channel. The carrier/noise ratio is displayed after the subsequent measurement has been completed.

The *ADJUST SETTINGS* function facilitates the selection of the frequency span appropriate for the channel bandwidth: it automatically sets the *SPAN* to approx. $4 \times$ channel bandwidth.

The RMS detector is enabled when the power measurement is switched on (*TRACE-DETECTOR-RMS*).

**C/N /
C/NO**

The *C/N C/NO* softkey opens the submenu for configuring the carrier/noise ratio measurement.

C/N / C/NO
CHANNEL BANDWIDTH
ADJUST SETTINGS

The user can choose between measurement without (C/N) and measurement with reference to the bandwidth (C/No). In addition, it is possible to select the bandwidth of the channel and to adapt the span.



Note

The measurements are only available in the frequency domain (span >0).

**C/N /
C/NO**

The *C/N* and *C/NO* softkeys enable and disable the measurement of the carrier/noise ratio, the *C/No* measurement also being referred to a 1 Hz bandwidth.

The maximum value of the current trace is determined when the function is activated and is marked by means of the *REFERENCE FIXED* marker.



Note

The measurement is performed on the trace where *MARKER 1* is located. To measure another trace, *MARKER 1* has to be shifted to the trace in question using the *SELECT TRACE* softkey in the *MARKER* menu.

If no marker is active, *MARKER 1* is activated when the function is switched on.

Remote command:

```
CALC:MARK:FUNC:POW:SEL CN
CALC:MARK:FUNC:POW:RES? CN
CALC:MARK:FUNC:POW:SEL CN0
CALC:MARK:FUNC:POW:RES? CN0
CALC:MARK:FUNC:POW OFF
```

**CHANNEL
BANDWIDTH**

The *CHANNEL BANDWIDTH* softkey opens a window for selecting the measurement channel bandwidth.

The default setting is 14 kHz.

The specified channel bandwidth allows the optimal setting of the measurement parameters of the R&S FSUP using *ADJUST SETTINGS*.

Remote command:

```
SENS:POW:ACH:BWID 14kHz
```


ADJUST SETTINGS The *ADJUST SETTINGS* softkey adapts the span to the channel bandwidth selected.

For the carrier/noise ratio measurement, the span is set to:

$4 \times \text{channel bandwidth} + \text{measurement margin}$

The adjustment is performed once; if necessary, the setting can be changed later on.

Remote command: `SENS:POW:ACH:PRES CN | CN0`

Measurement of the AM Modulation Depth

MODULATION DEPTH

The *MODULATION DEPTH* softkey switches on the measurement of the AM modulation depth. An AM-modulated carrier is required on the screen for ensuring correct operation.

The level value of *MARKER 1* is taken as the carrier level. When this function is activated, *MARKER 2* and *MARKER 3* are automatically set symmetrically to the carrier on the adjacent peak values of the trace as delta markers and *MARKER 2* is activated for the entry.

When the position of *MARKER 2* (delta) is changed, *MARKER 3* (delta) is moved symmetrically with respect to the reference marker (*MARKER 1*).

If the data entry is activated for *MARKER 3* (*MARKER 1 2 3 4* softkey), the latter can be moved for fine adjustment irrespective of *MARKER 2*.

The R&S FSUP calculates the power at the marker positions from the measured levels. The AM modulation depth is calculated from the ratio between the power values at the reference marker and at the delta markers. When the powers of the two AM side bands are unequal, the mean value of the two power values is used for AM modulation depth calculation.

Measurement example

The AM modulation depth of a carrier modulated with 1 kHz is to be measured at 100 MHz.

[PRESET] The R&S FSUP is set to the default setting.
 [CENTER: 100 MHz] The center frequency is set to 100 MHz.
 [SPAN: 5 kHz] The span is set to 5 kHz.
 [AMPT: 0 dBm] The reference level is set to 0 dBm.
 [MKR FCTN] MARKER 1 is switched on and positioned at the maximum of the displayed trace.

[MODULATION DEPTH: 1 kHz] The measurement of the AM modulation depth is switched on. MARKERS 2 and 3 (delta markers) are set to the adjacent peak values of the trace and are activated for the frequency entry.

The AM modulation depth is output in % in the marker info field.

When 1 kHz is entered, MARKER 2 can be exactly positioned on 1 kHz and MARKER 3 at -1 kHz from the reference marker.

Remote command: `CALC:MARK:FUNC:MDEP ON;`
`CALC:MARK:FUNC:MDEP:RES?`

Measurement of the Third Order Intercept (TOI)

If several signals are applied to a transmission two port device with nonlinear characteristic, intermodulation products appear at its output by the sums and differences of the signals. The nonlinear characteristic produces harmonics of the useful signals which intermodulate at the characteristic. The intermodulation products of lower order have a special effect since their level is largest and they are near the useful signals. The intermodulation product of third order causes the highest interference. It is the intermodulation product generated from one of the useful signals and the 2nd harmonic of the second useful signal in case of two-tone modulation.

The frequencies of the intermodulation products are above and below the useful signals. [Fig. 4-26 Intermodulation products PU1 and PU2](#) shows intermodulation products P_{I1} and P_{I2} generated by the two useful signals P_{U1} and P_{U2} .




Fig. 4-26 Intermodulation products P_{U1} and P_{U2}

The intermodulation product at f_{I2} is generated by mixing the 2nd harmonic of useful signal P_{U2} and signal P_{U1} , the intermodulation product at f_{I1} by mixing the 2nd harmonic of useful signal P_{U1} and signal P_{U2} .

$$f_{I1} = 2 \times f_{U1} - f_{U2} \tag{1}$$

$$f_{I2} = 2 \times f_{U2} - f_{U1} \tag{2}$$

The level of the intermodulation products depends on the level of the useful signals. If the two useful signals are increased by 1 dB, the level of the intermodulation products increases by 3 dB, which means that spacing a_{D3} between intermodulation signals and useful signals is reduced by 2 dB. This is illustrated in Fig. 4-27 Dependence of intermodulation level on useful signal level.




Fig. 4-27 Dependence of intermodulation level on useful signal level

The useful signals at the two port output increase proportionally with the input level as long as the two port is in the linear range. A level change of 1 dB at the input causes a level change of 1 dB at the output. Beyond a certain input level, the two port goes into compression and the output level stops increasing. The intermodulation products of the third order increase three times as much as the useful signals. The intercept point is the fictitious level where the two lines intersect. It cannot be measured directly since the useful level is previously limited by the maximum two port output power.

It can be calculated from the known line slopes and the measured spacing a_{D3} at a given level according to the following formula.

$$IP3 = \frac{a_{D3}}{2} + P_N \quad (3)$$

The 3rd order intercept point (TOI), for example, is calculated for an intermodulation of 60 dB and an input level P_U of -20 dBm according to the following formula:

$$IP3 = \frac{60}{2} + (-20\text{dBm}) = 10\text{dBm} \quad (4)$$

TOI

The *TOI* softkey enables the measurement of the 3rd order intercept point.

A two-tone signal with equal carrier levels is expected at the R&S FSUP input. MARKER 1 and MARKER 2 (both normal markers) are set to the maximum of the two signals. MARKER 3 and MARKER 4 (both delta markers) are placed on the intermodulation products. When the function is enabled, the frequency entry is activated for the delta markers. They can be set manually.

The R&S FSUP calculates the third order intercept from the level spacing between normal markers and delta markers and outputs it in the marker info field.

Remote command: `CALC:MARK:FUNC:TOI ON;`
 `CALC:MARK:FUNC:TOI:RES?`

Example

A two-tone signal with frequencies of 100 MHz and 101 MHz is applied to the RF input of the R&S FSUP. The level of the two signals is -10 dBm.

[PRESET]	The R&S FSUP is set to the default setting.
[CENTER: 100.5 MHz]	The center frequency is set to 100.5 MHz.
[SPAN: 3 MHz]	The span is set to 3 MHz.
[AMPT: -10 dBm]	The reference level is set to -10 dBm.
[MKR FCTN]	MARKER 1 is switched on and set to the signal peak.
[TOI]	The R&S FSUP sets the 4 markers to the useful signals and the intermodulation products and calculates the third order intercept. The result is output in the marker info field.

SELECT MARKER

The *SELECT MARKER* softkey activates the selection of a marker for functions *MODULATION DEPTH* and *TOI*. Thus, the markers can be fine-adjusted for these functions.

The markers are numerically selected in a data entry field. Delta marker 1 is selected by entering '0'.

If the marker is in the switch-off state, it will be switched on and can thus be shifted.

Remote command: `CALC:MARK1 ON;`
 `CALC:MARK1:X <value>;`
 `CALC:MARK1:Y?`

Harmonic Measurement**HARMONIC
DISTOR**

HARMONIC ON/OFF
NO. OF HARMONICS
HARMONIC SWEETIME
HARMONIC RBW AUTO
ADJUST SETTINGS

The *HARMONIC DISTOR* softkey opens this submenu.

In the upper screen the zero span sweeps on all harmonics are shown, separated by a grid line. This allows a very good overview about the measurement. In the lower screen the mean RMS results are displayed in numerical values and the THD values can be seen in the marker info field.

The resolution bandwidth will be automatically adjusted: $RBW_n = RBW_1 * n$, if that RBW is not available the next higher value is used.

HARMONIC ON/OFF

The *HARMONIC ON/OFF* softkey activates the harmonic distortion measurement. With this measurement it is possible to measure easily the harmonics e.g. from a VCO. In addition the THD (total harmonic distortion) is calculated in % and dB.

There are 2 possible modes within the harmonic measurement. When entering the harmonic measurement from a frequency sweep (span > 0 Hz) an automatic search for the first harmonic is carried out within that given frequency range. Also a level adjust will be carried out. Is the zero span mode active before entering the harmonic measurement, the center frequency is unchanged.

Remote command: `:CALC:MARKer:FUNC:HARM:STAT ON | OFF`

NO. OF HARMONICS

With the softkey *NO. OF HARMONICS* the number of harmonics which shall be measured can be adjusted. The range is from 1 to 26.

Remote command: `:CALC:MARK:FUNC:HARM:NHAR <numerical value>`

HARMONIC SWEEPTIME	The <i>HARMONIC SWEEPTIME</i> softkey allows to set the value how long the zero span measurement on each harmonic frequency shall take place. This is an alias softkey to the normal sweep time of the zero span, therefore the same parser command is to be used.
HARMONIC RBW AUTO	The softkey <i>HARMONIC RBW AUTO</i> disables the resolution bandwidth. Remote command: :CALC:MARK:FUNC:HARM:BAND:AUTO ON OFF
ADJUST SETTINGS	The <i>ADJUST SETTINGS</i> softkey activated he frequency search in the frequency range from before starting the harmonic measurement (if harmonic measurement was started from frequency sweep) and the level adjust. Remote command: :CALC:MARK:FUNC:HARM:PRES

Measuring Spurious Emissions

All real amplifiers also generate unwanted RF products outside the assigned frequency band. These spurious emissions are usually measured across a wide frequency range, for example from 9 kHz to 12.75 GHz (ETSI). The analyzer settings are specified for each frequency range.

SPURIOUS EMISSIONS

SPURIOUS ON/OFF	
SWEEP LIST ↓	EDIT SWEEP LIST
	INS BEFORE RANGE
	INS AFTER RANGE
	DELETE RANGE
	NEXT RANGES
	PREVIOUS RANGES
	ADJUST AXIS
	START MEAS
	STOP MEAS
LIST EVALUATION	
PAGE UP / PAGE DOWN	
START MEAS	
STOP MEAS	
Side menu	
PEAK SEARCH	
PEAKS PER RANGE	
MARGIN	
VIEW PEAK LIST ↓	SORT BY FREQUENCY
	SORT BY DELTA LIM
	ASCII FILE EXPORT
	DECIM SEP
	PAGE UP / PAGE DOWN

In the Spurious Emissions measurement mode, the R&S FSUP performs measurements in predefined frequency ranges with settings that can be specified individually for each of these ranges.

For this purpose, the SWEEP TABLE settings or the current device settings are used. Up to 20 subranges can be defined (they need not directly follow one another) across which the R&S FSUP sweeps in subsequent order. However, the measurement ranges must not overlap. The measurement parameters can be selected independently from each other in every subrange (*SWEEP LIST* menu, *EDIT SWEEP LIST*).

Limit lines are defined and displayed irrespective of the sweep ranges, i.e. they are not part of the sweep ranges. The unit of the limit lines is restricted to dB or dBm.

The frequency range where measurements are actually performed is set by the start and stop frequency parameters of the R&S FSUP; these parameters are independent of the sweep ranges. It is thus possible to define sweep ranges for a measurement task that can be stored and reloaded and to quickly and easily set the frequency range to be actually measured by means of two parameters; complex editing in the sweep table is not necessary.

**Note**

When a limit line is defined in steps, the weaker limit is used at the frequency point with the straight vertical section.

SPURIOUS ON/OFF The *SPURIOUS ON/OFF* softkey switches the spurious emissions measurement on or off according to the current configuration.

Remote command: `SWEEP:MODE LIST` switches the spurious list on
 `SWEEP:MODE AUTO` switches the spurious list off

SWEEP LIST The *SWEEP LIST* softkey opens a submenu where predefined sweep ranges can be edited, or new ranges generated or deleted. A table listing the current sweep ranges is displayed.

Remote command: --

EDIT SWEEP LIST The *EDIT SWEEP LIST* softkey opens the table for editing the sweep ranges.

SWEEP LIST					
	RANGE 1	RANGE 2	RANGE 3	RANGE 4	RANGE 5
Range Start	9 kHz	50 MHz	500 MHz		
Range Stop	50 MHz	500 MHz	1 GHz		
Filter Type	NORMAL	CHANNEL	RRC		
RBW	10 kHz	100 kHz	3 MHz		
VBW	30 kHz	300 kHz	10 MHz		
Sweep time mode	AUTO	MANUAL	AUTO		
Sweep time	10 ms	10 ms	100 ms		
Detector	Peak	RMS	Peak		
REF-Level	-20 dBm	-20 dBm	-20 dBm		
RF-Att. mode	AUTO	MANUAL	AUTO		
RF-Attenuator	10 dB	10 dB	5 dB		
PRE-AMP	OFF	OFF	OFF		
Sweep Points	625	625	625		
Stop after sweep	ON	OFF	OFF		
Transd. factor	LOWFREQ	MIDFREQ	MIDFREQ		

In the *SWEEP LIST* table, the individual sweep ranges are set.

Range Start:	Start frequency of the range
Range Stop:	Stop frequency of the range
Filter Type:	Filter type: NORMAL, CHANNEL, RRC
RBW:	Resolution filter bandwidth
VBW:	Video filter bandwidth; not applicable for CHANNEL and RRC filters
Sweep Time Mode:	AUTO / MANUAL
Sweep Time:	Sweep time; if <i>AUTO</i> is indicated for the sweep time mode, the automatically calculated sweep time is displayed. If the cell is edited, the associated sweep time mode is automatically set to MANUAL.
Detector:	Specifies the range detector: Sample, Average, Max Peak, RMS, Min Peak and Auto Peak
REF-Level	Reference level in dBm The upper edge of the displayed screen area is the value of the maximum reference level, corrected by the associated transducer factor.
RF-Attenuator-Mode	AUTO / MANUAL
RF-Attenuator	Number; as with Sweep Time
PRE-AMP	ON / OFF; preamplifier selection (options B23, B25, if available)
Sweep Points	Number of sweep points per range (sweep segment). The number of sweep points must not exceed 100001 .
Stop after Sweep	ON / OFF; if <i>ON</i> , the sweep is stopped after the range and continued only if confirmed by you via a message box (bit 10 of the “STATUS:OPERation Register” on page 5.25).
Transd. factor	NONE or factor (enter via selection list)

Remote command: SENS:LIST:RANG<1...20>:...

INS BEFORE RANGE The *INS BEFORE RANGE* softkey inserts a range in front of the marked line.

Remote command: --

INS AFTER RANGE The *INS AFTER RANGE* softkey inserts a range following the marked line.

Remote command: --

DELETE RANGE The *DELETE RANGE* softkey deletes the current range. All higher ranges are set back by one.

Remote command: LIST:RANGe<1...20>:DELeTe

NEXT RANGES The *NEXT RANGES* softkey activates the displays of the next higher subranges, i.e. 6 to 10, 11 to 15 or 16 to 20.

Remote command: --

PREVIOUS RANGES The *PREVIOUS RANGES* softkey activates the displays of the next lower subranges, i.e. 1 to 5, 6 to 10 or 11 to 15.

Remote command: --

ADJUST AXIS The *ADJUST AXIS* softkey automatically adjusts the frequency axis of measurement diagram so that the start frequency matches the start frequency of the first sweep range, and the stop frequency of the last sweep range.

Remote command: --
 (via FREQuency:StARt <num_value> /
 FREQuency:StOP <num_value>)

START MEAS Using the *START MEAS* softkey, you can start the measurement while the submenu is simultaneously exited.

When the measurement is started, the R&S FSUP sets up the measurement diagram in the selected measurement window and starts the measurement in the selected mode.

With *SINGLE*, a single frequency sweep occurs; afterwards the R&S FSUP remains on the stop frequency.

With *CONTINUOUS*, the measurement continues until it is stopped.

You can stop the measurement with *STOP SWEEP*.

If a *STOP AFTER SWEEP* point has been defined in the range, the sweep stops automatically at the end of the respective range to allow you to change the external circuitry, for example. This is indicated in a message box:

SWEEP Range# reached CONTINUE/BREAK

If *CONTINUE* is selected, the sweep is continued in the next range. If *BREAK* is selected, the sweep is stopped.

Remote command: INIT:SPUR starts the measurement
 INIT:CONM starts the measurement after a
 BREAK has been reached
 ABORT stops the measurement after a range has
 been reached

STOP MEAS The *STOP MEAS* softkey stops the measurement. The measurement data can be analyzed.

Remote command: ABORT

LIST EVALUATION The *LIST EVALUATION* softkey activates or deactivates the spurious emission measurement LIST EVALUATION. The peak search evaluation is automatically done during measurement and the results are displayed in a table in the lower part of the screen.

Following results are listed:

- frequency range
- frequency of the absolute peak power in this range in dBm
- level delta to the limit with margin in dB
- limit check state (by color change and an asterisk at the end of the line if failed)

If *LIST EVALUATION* is switched on, the functions *PEAKS PER RANGE*, *MARGIN*, *PEAK SEARCH* and *VIEW PEAK LIST* are not available.

Remote command: `CALC1:PEAK:AUTO ON | OFF`

STOP MEAS See “STOP MEAS” on page 4.204.

START MEAS See “START MEAS” on page 4.204.

PEAK SEARCH The *PEAK SEARCH* softkey starts the process of determining the list of the subrange maximums from the existing sweep results. This procedure can be repeated as often as desired, e.g. to experiment with the various threshold settings.

It is activated only after a measurement has been performed with *START MEAS*.

Remote command: `CALC:PEAK`

PEAKS PER RANGE The *PEAKS PER RANGE* softkey activates entry of the number of peaks per range that are stored in the list. The value range extends from 1 to 50. Once the selected number of peaks has been reached, the peak search is stopped in the current range and continued in the next range. The default value is 25.

Remote command: `CALC:PEAK:SUBR 1...50`

MARGIN The *MARGIN* softkey activates entry of the margin, i.e. the acceptance threshold for determining the peak list. The limit line is shifted by this value when the maximums are determined. The value range extends from -200 dB to 200 dB. The default value is 6 dB.

Remote command: `CALC:PEAK:MARG -200dB...200dB`

VIEW PEAK LIST The *VIEW PEAK LIST* softkey opens the submenu for viewing the peak list. It is activated for display only after a *PEAK SEARCH* has been performed with *PEAK SEARCH*.

VIEW PEAK LIST			
TRACE / Detector	FREQUENCY	LEVEL dBm	DELTA LIMIT dB
1 RMS	80.0000 MHz	-36.02	-5.02
1 RMS	80.0001 MHz	-30.07	+0.24
1 RMS	85.1234 MHz	-30.02	-0.02
1 AVERAGE	130.234 MHz	-29.12	-5.12

If no limit check is active, a delta limit of +200dB is listed.

Remote command: TRACe? SPURious

SORT BY FREQUENCY The *SORT BY FREQUENCY* softkey sorts the table according to the entries in the *FREQUENCY* column in descending order.

Remote command: --

SORT BY DELTA LIM The *SORT BY DELTA LIM* softkey sorts the table according to the entries in the *DELTA LIM* column (default) in descending order. If no limit line has been specified, an offset of 200 dB is assumed for all peaks.

Remote command: --

ASCII FILE EXPORT The *ASCII FILE EXPORT* softkey stores the peak list in ASCII format to a file on a diskette.

The file has a header containing important parameters for scaling, several data sections containing the sweep settings per range and a data section containing the peak list.

The header data is made up of three columns, separated by ';':

parameter name; numeric value; base unit

Table 4-1 Example: ASCII export table - file header

File contents	Explanation
Type;R&S FSUP;	Model
Version;3.90;	Firmware version
Date;02.Aug 2006;	Storage date of data set
Mode;ANALYZER; SPURIOUS;	Operating mode of the device
Start;9000.000000;Hz Stop;8000000000.000000;Hz	Start/stop of the span Unit: Hz
x-Axis;LIN;	Linear (LIN) or logarithmic (LOG) (future feature) scaling of the x-axis
Sweep Count;1;	Selected number of sweeps

The data section for the measurement values starts with the key word "TRACE <n>:", where <n> includes the number of the used trace. Next comes the peak list with several columns also separated by ';':

Table 4-2 Example: ASCII export table - file data section

File contents	Explanation
TRACE 1:	Selected trace
Trace Mode;CLR/WRITE;	Display mode of trace: CLR/WRITE,AVERAGE,MAX HOLD,MIN HOLD, VIEW, BLANK
x-Unit;Hz;	Unit of x values:
y-Unit;dBm;	Unit of y values:
Margin;6.000000:s	Peak List margin
Values;8;	Number of measurement points
1;1548807257.5999999000;- 65.602280;-5.602280 1;1587207214.4000001000;- 65.327530;-5.327530 1;2112006624.0000000000;- 4.388008;55.611992	Measurement values: <Trace>;<x value>; <y value>;<delta limit>

Spreadsheet programs such as MS Excel can read this format. Use ';' as the delimiter for the table cells.



Note

Different language versions of evaluation programs may require different handling of the decimal point. Using the *DECIM SEP* softkey, you can thus choose between the delimiters '.' (decimal point) and ',' (comma).

Remote command: `M MEM:STOR:SPUR, 'F:\TEST.ASC'`

DECIM SEP In the case of floating-point numbers, use the *DECIM SEP* softkey to select between '.' (decimal point) and ',' (comma) as the decimal delimiter for the ASCII FILE EXPORT function.

By selecting the decimal delimiter, various language versions of evaluation programs (e.g. MS Excel) are supported.

Remote command: `FORM:DEXP:DSEP POIN`

PAGE UP / PAGE DOWN Using *PAGE UP* and *PAGE DOWN*, you can scroll forward and backward through the peak list pages.

They are active only as long as a peak list is displayed.

Basic Settings

In this section, the general settings, printout, and instrument settings are described in detail.

Setup of Limit Lines and Display Lines – LINES Key

In phase noise mode, the limit line handling differs from the handling described here. For further information refer to section “[Setup of Limit Lines – LINES Key](#)” on page 4.76.

Limit lines are used to define amplitude curves or spectral distribution boundaries on the display screen which are not to be exceeded. They indicate, for example, the upper limits for interference radiation or spurious waves which are allowed from a unit under test (UUT). For transmission of information in TDMA (e.g. GSM), the amplitude of the bursts in a timeslot must adhere to a curve which must fall within a specified tolerance band. The lower and upper limits may each be specified by a limit line. Then, the amplitude curve can be controlled either visually or automatically for any violations of the upper or lower limits (GO/NOGO test).

The instrument supports limit lines with a maximum of 50 data points. 8 of the limit lines stored in the instrument can be used simultaneously and activated in the split-screen mode either in Screen A, Screen B or in the two windows. The number of limit lines stored in the instrument is only limited by the capacity of the flash disk used.

For each limit line, the following characteristics must be defined:

- The name of the limit line. The limit line data are stored under this name and can be examined in the table *LIMIT LINES*.
- The domain in which the limit line is to be used. Here, a distinction is made between the time domain (span = 0 Hz) and the frequency domain (span > 0 Hz).
- The reference of the interpolation points to the x-axis. The limit line may be specified either for absolute frequencies or times or for frequencies which are related to the set center frequency and times related to the time on the left edge of the diagram.
- The reference of the interpolation points to the y-axis. The limit line can be selected either for absolute levels or voltages or referred to the set maximum level (Ref Lvl). The position on the display depends on the *REF LEVEL POSITION*.
- With relative reference values for the y-axis, it is possible to enter an absolute threshold (THRESHOLD) which lowers the relative limit values (see below).
- The type of limit line (upper or lower limit). With this information and the active limit checking function (Table *LIMIT LINES*, *LIMIT CHECK ON*), the R&S FSUP checks for compliance with each limit.
- The limit line units to be used. The units of the limit line must be compatible with the level axis in the active measurement window.

- The measurement curve (trace) to which the limit line is assigned. For the R&S FSUP, this defines the curve to which the limit is to be applied when several traces are simultaneously displayed.
- For each limit line, a margin can be defined which serves as a threshold for automatic evaluation.
- In addition, commentary can be written for each limit line, e.g. a description of the application.


Display lines are exclusively used to optically mark relevant frequencies or points in time (span = 0) as well as constant level values. It is not possible to check automatically whether the marked level values have been underranged or exceeded.

Selection of Limit Lines

LINES

The *LINES* key opens the menu for fixing the limit lines and the display lines.

SELECT LIMIT LINE	
EDIT LIMIT LINE / NEW LIMIT LINE ↓	NAME
	VALUES
	INSERT VALUE
	DELETE VALUE
	SHIFT X LIMIT LINE
	SHIFT Y LIMIT LINE
	SAVE LIMIT LINE
COPY LIMIT LINE	
DELETE LIMIT LINE	
X OFFSET	
Y OFFSET	
DISPLAY LINES ↓	DISPLAY LINE 1/ DISPLAY LINE 2
	FREQUENCY LINE 1/ FREQUENCY LINE 2
	TIME LINE 1 / TIME LINE 2



The *SELECTED LIMIT LINE* display field provides information concerning the characteristics of the marked limit lines.

In the *LIMIT LINES* table, the limit lines compatible to the settings of the active screen can be enabled.

New limit lines can be specified and edited in the *NEW LIMIT LINE* and *EDIT LIMIT LINE* submenus, respectively.

The horizontal and vertical lines of the *DISPLAY LINES* submenu mark individual levels or frequencies (span > 0) or times (span = 0) in the diagram.

The *SELECTED LIMIT LINE* table provides information about the characteristics of the marked limit line:

- Name* name
- Domain* frequency or time
- Unit* vertical scale
- X-Axis* interpolation
- Limit* upper/lower limit
- X-Scaling* absolute or relative frequencies/times
- Y-Scaling* absolute or relative Y units
- Threshold* absolute limit with relative Y units
- Comment* commentary

The characteristics of the limit line are set in the *EDIT LIMIT LINE (=NEW LIMIT LINE)* submenu.

SELECT LIMIT LINE The *SELECT LIMIT LINE* softkey activates the *LIMIT LINES* table and the selection bar jumps to the uppermost name in the table.

The following information is offered in the columns of the table:

<i>Name</i>	Enable the limit line.
<i>Compatible</i>	Indicates if the limit line is compatible with the measurement window of the given trace.
<i>Limit Check</i>	Activate automatic violation check for upper/lower limits.
<i>Trace</i>	Select the measurement curve to which the limit is assigned.
<i>Margin</i>	Define margin.

Name and Compatible - Enabling limit lines

A maximum of 8 limit lines can be enabled at any one time. In split screen mode, they may be assigned to screen A, screen B or to both screens. A check mark at the left edge of a cell indicates that this limit line is enabled.

A limit line can only be enabled when it has a check mark in the *Compatible* column, i.e. only when the horizontal display (time or frequency) and vertical scales are *identical* to those of the display in the measurement window.

Lines with the unit dB are compatible to all dB(..) settings of the y-axis.

If the scale of the y-axis or the domain (frequency or time axis) are changed, all non-compatible limit lines are automatically switched off in order to avoid misinterpretation. The limit lines must be enabled anew when the original display is re-displayed.

Remote command: `CALC:LIM3:NAME "GSM1"`
 `CALC:LIM3:UPP:STAT ON`
 `CALC:LIM4:LOW:STAT ON`

Limit Check - Activate automatic limit violation check

When *LIMIT CHECK ON* is activated, a GO/NOGO test is performed in the active screen. In the center of the diagram, a display window appears which indicates the results of the limit check test:

LIMIT CHECK: PASSED	No violations of active limits.
LIMIT CHECK: FAILED	One or more active limit lines were violated. The message contains the names of the limit lines which were violated or whose margins were not complied with.
LIMIT CHECK: MARGIN	The margin of at least one active limit lines was not complied with, however, no limit line was violated. The message contains the names of the limit lines whose margins were not complied with.

The following example shows two active limit lines:

```
LIMIT CHECK: FAILED
LINE VHF MASK: Failed
LINE UHF2MASK: Margin
```

A check for violations of limit lines takes place only if the limit line of the assigned measurement curve (trace) is enabled.

If *LIM CHECK* is set to *OFF* for all active limit lines, then the limit line check is not executed and the display window is activated.

Remote command: `CALC:LIM:STAT ON`
 `INIT;*WAI`
 `CALC:LIM:FAIL?`

Trace - Select the measurement curve to which the limit line is assigned.

The selection of the measurement curve (trace) takes place in an entry window. Allowed are the integer entries 1, 2 or 3. The default setting is trace 1. If the selected limit line is not compatible with the assigned measurement curve, then the limit line is disabled (display and limit check).

Remote command: `CALC:LIM:TRAC 1`

NEW LIMIT LINE See following section [“Entry and Editing of Limit Lines” on page 4.213.](#)

EDIT LIMIT LINE See following section [“Entry and Editing of Limit Lines” on page 4.213.](#)

COPY LIMIT LINE The *COPY LIMIT LINE* softkey copies the data file describing the marked limit line and saves it under a new name. In this way, a new limit line can be easily generated by parallel translation or editing of an existing limit line. The name can be arbitrarily chosen and input via an entry window (max. of 8 characters).

Remote command: `CALC:LIM3:COPY 2`
 or
 `CALC:LIM3:COPY "GSM2"`

DELETE LIMIT LINE The *DELETE LIMIT LINE* softkey erases the selected limit line. Before deletion, a message appears requesting confirmation.

Remote command: `CALC:LIM3:DEL`

X OFFSET The *X OFFSET* softkey horizontally shifts a limit line, which has been specified for relative frequencies or times (x-axis). The softkey opens an entry window, where the value for shifting may be entered numerically or via the rotary knob.




Note

This softkey does not have any effect on limit lines that represent absolute values for the x-axis.

Remote command: `CALC:LIM3:CONT:OFFS 10kHz`

Y OFFSET

The *Y OFFSET* softkey vertically shifts a limit line, which has relative values for the y-axis (levels or linear units such as volt). The softkey opens an entry window where the value for shifting may be entered numerically or via the rotary knob.

**Note**

This softkey does not have any effect on limit lines that represent absolute values for the y-axis.

Remote command: CALC:LIM3:LOW:OFFS 3dB
 CALC:LIM3:UPP:OFFS 3dB

Entry and Editing of Limit Lines

RBW 3 MHz

EDIT LIMIT LINE TABLE

Name:	LP1GHZ
Domain:	FREQUENCY
Unit:	dBm
x-Axis:	LIN
x-Scaling:	ABSOLUTE
y-Scaling:	ABSOLUTE
Limit:	UPPER
Margin:	40 dB
Threshold:	
Comment:	Lowpass at 1 GHz

Frequency	LIMIT/dBm
0.000 Hz	-10.0000
1.000 GHz	-10.0000
1.001 GHz	-70.0000
3.000 GHz	-70.0000

Press ENTER to edit field

-120 Start 0 Hz 200 MHz/ Stop 2 GHz

A limit line is characterized by

- its name
- the assignment of domain (frequency or time)
- the scaling in absolute or relative times or frequencies
- the vertical unit
- the interpolation

- the vertical scaling
- the vertical threshold (only with relative vertical scaling)
- the margin
- the definition of the limit line as either upper or lower limit.
- the data points for frequency/time and level.

At the time of entry, the R&S FSUP immediately checks that all limit lines are in accordance with certain guidelines. These guidelines must be observed if specified operation is to be guaranteed.

- The frequencies/times for each data point must be entered in ascending order, however, for any single frequency/time, two data points may be input (vertical segment of a limit line).

The data points are allocated in order of ascending frequency/time. Gaps are not allowed. If gaps are desired, two separate limit lines must be defined and then both enabled.

- The entered frequencies/times need not necessarily be selectable in R&S FSUP. A limit line may also exceed the specified frequency or time domains. The minimum frequency for a data point is -200 GHz, the maximum frequency is 200 GHz. For the time domain representation, negative times may also be entered. The valid range is -1000 s to +1000 s.
- The minimum/maximum value for a limit line is -200 dB to +200 dB for the logarithmic or 10^{-20} to 10^{+20} or -99.9% to + 999.9% for the linear amplitude scales.

**EDIT LIMIT LINE /
NEW LIMIT LINE**

NAME
VALUES
INSERT VALUE
DELETE VALUE
SHIFT X LIMIT LINE
SHIFT Y LIMIT LINE
SAVE LIMIT LINE

The *EDIT LIMIT LINE* and *NEW LIMIT LINE* softkeys both call the *EDIT LIMIT LINE* submenu used for editing limit lines. In the table heading, the characteristics of the limit line can be entered. The data points for frequency/time and level values are entered in the columns.

<i>Name</i>	Enter name.
<i>Domain</i>	Select domain.
<i>Unit</i>	Select units.
<i>X-Axis</i>	Select interpolation
<i>Limit</i>	Select upper and lower limit value.
<i>X-Scaling</i>	Entry of absolute or relative values for the x-axis
<i>Y-Scaling</i>	Entry of absolute or relative values for the y-axis
<i>Margin</i>	Entry of margin.

<i>Threshold</i>	Entry of vertical threshold (only with relative vertical scaling)
<i>Comment</i>	Enter comments.
<i>Time/Frequency</i>	Enter time/frequency for the data points.
<i>Limit/dBm</i>	Enter magnitudes for the data points.

**Note**

Domain, unit, X scaling and Y scaling cannot be modified as soon as reference values have been entered in the data section of the table.

NAME The *NAME* softkey enables the entry of characteristics in the table heading.

Name - Enter name

A maximum of 8 characters is permitted for each name. All names must be compatible with the MS DOS conventions for file names. The instrument stores all limit lines with the *.LIM* extension.

Remote command: `CALC:LIM3:NAME "GSM1"`

Domain - Select time or frequency domain

The default setting is frequency.

**Note**

A change in domain (frequency/time) is only permitted when the data point table is empty.

Remote command: `CALC:LIM3:CONT:DOM FREQ`

X-Axis - Select interpolation

Linear or logarithmic interpolation can be carried out between the frequency reference points of the table. The ENTER key toggles between LIN and LOG selection.

Remote command: `CALC:LIM3:CONT:SPAC LIN`
 `CALC:LIM3:UPP:SPAC LIN`
 `CALC:LIM3:LOW:SPAC LIN`

Scaling - selection of absolute or relative scaling

The limit line can either be scaled in absolute (frequency or time) or relative units. Any of the unit keys may be used to toggle between *ABSOLUTE* and *RELATIVE*, the cursor must be positioned in the *X Scaling* or the *Y Scaling* line.

<i>X-Scaling ABSOLUTE</i>	The frequencies or times are interpreted as absolute physical units.
<i>X-Scaling RELATIVE</i>	In the data point table, the frequencies are referred to the currently set center frequency. In time domain mode, the left boundary of the diagram constitutes the reference.
<i>Y-Scaling ABSOLUTE</i>	The limit values refer to absolute levels or voltages.
<i>Y-Scaling RELATIVE</i>	The limit values refer to the reference level (Ref Level) or, in case a reference line is set, to the reference line. Limit values with the unit dB are always relative values.

The *RELATIVE* scaling is always suitable, if masks for bursts are to be defined in the time domain, or if masks for modulated signals are required in the frequency domain.

An X offset with half the sweep time may be entered in order to shift the mask in the time domain into the center of screen.

Remote command: `CALC:LIM3:CONT:MODE ABS`
 `CALC:LIM3:UPP:MODE ABS`
 `CALC:LIM3:LOW:MODE ABS`

Unit - Select the vertical scale units for the limit line

The selection of units takes place in a selection box. The default setting is dBm.

Remote command: `CALC:LIM3:UNIT DBM`

Limit - Select upper/lower limit

A limit line can be defined as either an upper or lower limit.

Remote command: `--` (defined by key words `:UPPer` or `:LOWer`)


Margin - Setting a margin.

The margin is defined as the signal-level distance to the limit line. When the limit line is defined as an upper limit, the margin means that the level is below the limit line. When the limit line is defined as a lower limit, the margin means that the level is above the limit line. The default setting is 0 dB (i.e. no margin).

Remote command: `CALC:LIM3:UPP:MARG 10dB`
 `CALC:LIM3:LOW:MARG 10dB`

Threshold – Selection of the threshold value with relative Y scaling

With relative Y scaling, an absolute threshold value can be defined which lowers the relative limit values. The function is useful especially for mobile radio applications provided the limit values are defined in relation to the carrier power as long as they are above an absolute limit value.

Example:

The preset value is at -200 dBm. The field is displayed if the value RELATIVE is entered in the field Y-SCALING.

Remote command: `CALC:LIM3:UPP:THR -30 dBm`
or
`CALC:LIM3:LOW:THR -30 dBm`

Comment - Enter comments

Comments are arbitrary, however, they must be less than 41 characters long.

Remote command: `CALC:LIM3:COMM "Upper limit"`

VALUES The *VALUES* softkey activates the entry of the data points in the table columns *Time/Frequency* and *Limit/dB*. Which table columns appear depends upon the *Domain* selection in the table heading.

The desired frequency/time data points are entered in ascending order (two repeated frequencies/time values are permitted).

Remote command: `CALC:LIM3:CONT:DATA 1MHz,3MHz,30MHz`
`CALC:LIM3:UPP:DATA -10,0,0`
`CALC:LIM3:LOW:DATA -30,-40,-40`

INSERT VALUE The *INSERT VALUE* softkey creates an empty line above the current cursor position where a new data point may be entered. However, during the entry of new values, it is necessary to observe an ascending order for frequency/time.

Remote command: `--`

DELETE VALUE The *DELETE VALUE* softkey erases the data point (complete line) at the cursor position. All succeeding data points are shifted down accordingly.

Remote command: `--`

SHIFT X LIMIT LINE The *SHIFT X LIMIT LINE* softkey calls an entry window where the complete limit line may be shifted parallel in the horizontal direction.

The shift takes place according to the horizontal scale:

- in the frequency domain in Hz, kHz, MHz or GHz
- in the time domain in ns, μ s, ms or s

In this manner, a new limit line can be easily generated based upon an existing limit line which has been shifted horizontally and stored (*SAVE LIMIT LINE* softkey) under a new name (*NAME* softkey).

Remote command: `CALC:LIM3:CONT:SHIF 50KHz`

SHIFT Y LIMIT LINE The *SHIFT Y LIMIT LINE* softkey calls an entry window where the complete limit line may be shifted parallel in the vertical direction.

The shift takes place according to the vertical scale:

- for logarithmic units, relative, in dB
- for linear units, as a factor

In this manner, a new limit line can be easily generated based upon an existing limit line which has been shifted vertically and stored (*SAVE LIMIT LINE* softkey) under a new name (*NAME* softkey).

Remote command: `CALC:LIM3:CONT:UPP:SHIF 20dB`
 `CALC:LIM3:CONT:LOW:SHIF 20dB`

SAVE LIMIT LINE The *SAVE LIMIT LINE* softkey stores the currently edited limit line. The name can be entered in an input window (max. 8 characters)

Remote command: `--`

Display Lines

Display lines help to evaluate a trace – as do markers. The function of a display line is comparable to that of a ruler that can be shifted on the trace in order to mark absolute values.

The R&S FSUP provides two different types of display lines:

- two horizontal level lines for marking levels – Display Line 1/2,
- two vertical frequency or time lines for marking frequencies or points in time – Frequency/Time Line 1/2.

Each line is identified by one of the following abbreviations:

D1 Display Line 1
 D2 Display Line 2
 F1 Frequency Line 1
 F2 Frequency Line 2
 T1 Time Line 1
 T2 Time Line 2

The level lines are continuous horizontal lines across the entire width of a diagram and can be shifted in y direction.

The frequency or time lines are continuous vertical lines across the entire height of the diagram and can be shifted in x direction.

The *DISPLAY LINES* submenu for activating and setting the display lines appears different depending on the display mode set in the active measurement window (frequency or time domain).

If the spectrum is shown (span \neq 0) the *TIME LINE 1* and *TIME LINE 2* softkeys are disabled, whereas in the time domain (span = 0) the *FREQUENCY LINE 1* and *FREQUENCY LINE 2* softkeys are not available.

Working with display lines

The softkeys for setting and switching the display lines on/off work like triple switches:

Initial situation: The line is off (softkey with gray background)

1st press: The line is switched on (softkey with red background) and the data input function is activated. The position of the display line can be selected by means of the rotary knob, the step keys or a numerical entry in the appropriate field. The data input function is disabled if another function is activated. The line, however, remains switched on (softkey with green background).

2nd press: The line is switched off (softkey with gray background).

Initial situation: The line is on (softkey with green background)

1st press: The data input function is activated (softkey with red background). The position of the display line can be selected by means of the rotary knob, the step keys or a numerical entry in the appropriate field. The data input function is disabled if another function is activated. The line, however, remains switched on (softkey with green background).

2nd press: The line is switched off (softkey with gray background).

DISPLAY LINES

DISPLAY LINE 1/ DISPLAY LINE 2
FREQUENCY LINE 1/ FREQUENCY LINE 2
TIME LINE 1 / TIME LINE 2

DISPLAY LINE 1/
DISPLAY LINE 2

The *DISPLAY LINE 1/2* softkeys enable or disable the level lines and allow the user to enter the position of the lines.

The level lines mark the selected level in the measurement window.



Note

These softkeys are only available in the time domain (span = 0).

Remote command:

```
CALC:DLIN:STAT ON
CALC:DLIN -20dBm
```

FREQUENCY LINE 1 /
FREQUENCY LINE 2 The *FREQUENCY LINE 1/2* softkeys enable or disable the frequency lines 1/2 and allow the user to enter the position of the lines.

The frequency lines mark the selected frequencies in the measurement window.



Note

These softkeys are only available in the frequency domain (span > 0).

Remote command: CALC:FLIN:STAT ON
 CALC:FLIN 120MHz

TIME LINE 1 /
TIME LINE 2 The *TIME LINE 1/2* softkeys enable or disable the time lines 1/2 and allow the user to enter the position of the lines.

The time lines mark the selected times or define search ranges (see section [“Marker Functions – MKR FCTN Key”](#) on page 4.141).



Note

The two softkeys cannot be used in the frequency domain (span > 0).

Remote command: CALC:TLIN:STAT ON
 CALC:TLIN 10ms

Configuration of Screen Display – DISP Key

The *DISPLAY* menu allows the configuration of the diagram display on the screen and also the selection of the display elements and colors. The POWER SAVE mode is also configured in this menu for the display.

The test results are displayed on the screen of the R&S FSUP either in a full-screen window or in two overlapping windows. The two windows are called diagram A and diagram B.

In the default setting, the two windows are completely decoupled from each other, i.e. they behave like two separate instruments. This is very useful, for example with harmonics measurements or measurements on frequency-converting DUTs, since the input signal and the output signal lie in different frequency ranges.

However, specific settings of the two windows (reference level, center frequency) can be coupled, if required, so that with *CENTER B = MARKER A* for example, the shift of the marker in diagram A causes the frequency range (zoomed in some cases) to be shifted along diagram B.

New settings are performed in the diagram selected via *SCREEN A* or *SCREEN B* hotkey. If only one window is displayed, it is the diagram in which the measurements are performed; the diagram not displayed is not active for measurements.




Fig. 4-28 Typical split-screen display, settings are uncoupled

The *DISP* key opens the menu for configuring the screen display and selecting the active diagram in SPLIT SCREEN mode.

DISP

FULL SCREEN	
SPLIT SCREEN	
REF LEVEL COUPLED	
CENTER B = MARKER A / CENTER A = MARKER B	
CONFIG DISPLAY ↓	SCREEN TITLE
	TIME+DATE ON/OFF
	LOGO ON/OFF
	ANNOTATION ON/OFF
	DATA ENTRY OPAQUE
	DEFAULT COLORS 1/ DEFAULT COLORS 2
	DISPLAY PWR SAVE
	Side menu
	SELECT OBJECT
	BRIGHTNESS
	TINT
	SATURATION
	PREDEFINED COLORS

FULL SCREEN

The *FULL SCREEN* softkey selects the display of one diagram. This corresponds to the default setting of R&S FSUP.

In the *FULL SCREEN* mode, it is possible to switch between two different device settings by selecting the active window (screen A or screen B).

Switching between *SCREEN A* and *SCREEN B* is performed by means of the corresponding key in the hotkey bar (for details refer to “[Mode Selection – Hotkey Bar](#)” on page 4.8).

It should be noted that the measurements in the *FULL SCREEN* mode are performed only in the visible (active) window.

The active window is marked by **A** or **B** on the right of the diagram.

Remote command: DISP:FORM SING
 DISP:WIND<1 | 2>:SEL

SPLIT SCREEN

The *SPLIT SCREEN* softkey selects the display of two diagrams. The upper diagram is designated *SCREEN A*, the lower diagram *SCREEN B*.

Switching between *SCREEN A* and *SCREEN B* is performed via the corresponding key in the hotkey bar. The active window is marked by highlighting fields **A** and **B** on the right of the diagram.

Remote command: DISP:FORM SPL

**REF LEVEL
COUPLED**

The *REF LEVEL COUPLED* softkey switches the coupling of the reference level on and off. In addition to the reference level, the mixer level and input attenuation are coupled with one another.

For the level measurement, the same reference level and input attenuation must be set for the two diagrams.

Remote command: `INST:COUP RLEV`

**CENTER B =
MARKER A /
CENTER A =
MARKER B**

The *CENTER B = MARKER A* and *CENTER A = MARKER B* softkeys couple the center frequency in diagram B with the frequency of marker 1 in diagram A and the center frequency in diagram B with the frequency of marker 1 in diagram B. The two softkeys are mutually exclusive.

This coupling is useful, e.g. for viewing the signal at the marker position in diagram A with higher frequency resolution or in the time domain in diagram B.

If marker 1 is off, it is switched on and set to the maximum of the trace in the active diagram.

Remote command: `INST:COUP CF_B`
`INST:COUP CF_A`

CONFIG DISPLAY

SCREEN TITLE
TIME+DATE ON/OFF
LOGO ON/OFF
ANNOTATION ON/OFF
DATA ENTRY OPAQUE
DEFAULT COLORS 1/ DEFAULT COLORS 2
DISPLAY PWR SAVE
Side menu
SELECT OBJECT
BRIGHTNESS
TINT
SATURATION
PREDEFINED COLORS

The *CONFIG DISPLAY* softkey opens a submenu allowing additional display items to be added to the screen. In addition, the display power-save mode (*DISPLAY PWR SAVE* softkey) and the colors of the display elements can be set here.

SCREEN TITLE

The *SCREEN TITLE* softkey activates the entry of a title for the active diagram A or B. It switches on or off a title that is already input. The length of the title is limited to max. 20 characters.

Remote command: `DISP:WIND1:TEXT 'Noise Meas'`
`DISP:WIND1:TEXT:STATE ON`

TIME+DATE ON/OFF	<p>The <i>TIME+DATE ON/OFF</i> softkey switches on or off the display of date and time above the diagram.</p> <p>Remote command: <code>DISP:TIME OFF</code></p>
LOGO ON/OFF	<p>The <i>LOGO ON/OFF</i> softkey switches the Rohde & Schwarz company logo displayed in the upper left corner of the display screen on or off.</p> <p>Remote command: <code>DISP:LOGO ON</code></p>
ANNOTATION ON/ OFF	<p>The <i>ANNOTATION ON/OFF</i> softkey switches the displaying of frequency information on the screen on and off.</p> <ul style="list-style-type: none"> • ON: Frequency information is displayed. • OFF: Frequency information is not outputted to the display. This can be used for example to protect confidential data. <p>Remote command: <code>DISP:ANN:FREQ ON</code></p>
DATA ENTRY OPAQUE	<p>The <i>DATA ENTRY OPAQUE</i> softkey sets the data entry windows to opaque. This means that entry windows are underlaid with the background color for tables.</p> <p>Remote command: <code>--</code></p>
DEFAULT COLORS 1/ DEFAULT COLORS 2	<p>The <i>DEFAULT COLORS 1/2</i> softkeys restores the default settings for brightness, color tint and color saturation for all display screen elements.</p> <p>The color schemes have been selected to give optimum visibility of all picture elements at an angle of vision from above or below. <i>DEFAULT COLORS 1</i> is active in the default setting of the instrument.</p> <p>Remote command: <code>DISP:CMAP:DEF1</code> <code>DISP:CMAP:DEF2</code></p>
DISPLAY PWR SAVE	<p>The <i>DISPLAY PWR SAVE</i> softkey is used to switch on/off the power-save mode for the display and to enter the time for the power-save function to respond. After the elapse of this time the display is completely switched off, i.e. including backlighting.</p>

**Note**

This mode is recommended for saving the TFT display especially when the instrument is exclusively operated in remote control.

The power-save mode is configured as follows:

- The first keystroke activates the power-save mode and opens the editor for the response time. The response time is entered in minutes between 1 and 6 minutes and is confirmed by *ENTER*.
- The power-save mode is deactivated by pressing the key again.

On leaving the menu with the power-save mode in the activated state, the softkey is highlighted in color on returning to the menu and opens again the editor for the response time. Pressing again the key switches off the power-save mode.

Remote command: DISP:PSAV ON
 DISP:PSAV:HOLD 15

SELECT OBJECT The *SELECT OBJECT* softkey activates the *SELECT DISPLAY OBJECT* table, with which a graphics element can be selected. After selection, the brightness, tint and saturation of the selected element can be changed using the softkeys of the same name. The color changes by means of the *PREDEFINED COLORS* softkey can be seen immediately on the display screen.

SELECT DISPLAY OBJECT	
√	Background
	Grid
	Function field + status field + data entry text
	Function field LED on
	Function field LED warn
	Enhancement label text
	Status field background
	Trace 1
	Trace 2
	Trace 3
	Marker
	Lines
	Measurement status + limit check pass
	Limit check fail
	Table + softkey text
	Table + softkey background
	Table selected field text
	Table selected field background
	Table + data entry field opaq titlebar
	Data entry field opaq text
	Data entry field opaq background
	3D shade bright part
	3D shade dark part
	Softkey state on
	Softkey state data entry
	Logo

BRIGHTNESS The *BRIGHTNESS* softkey activates entry of the brightness of the selected graphics element.

Values between 0 and 100% can be entered.

Remote command: DISP:CMP3:HSL< hue>,<sat>,<lum>

TINT The *TINT* softkey activates the entry of the color tint of the selected element. The entered value is related to a continuous color spectrum ranging from red (0%) to blue (100%).

Remote command: DISP:CMP3:HSL <hue>,<sat>,<lum>

SATURATION The *SATURATION* softkey activates the entry of the color saturation for the selected element.

The range of inputs is from 0 to 100%.

Remote command: `DISP:CMAP3:HSL <hue>,<sat>,<lum>`

PREDEFINED COLORS The *PREDEFINED COLORS* softkey activates a table, with which the predefined colors for the display screen elements can be selected.

COLOR
√ BLACK
BLUE
BROWN
GREEN
CYAN
RED
MAGENTA
YELLOW
WHITE
GRAY
LIGHT GRAY
LIGHT BLUE
LIGHT GREEN
LIGHT CYAN
LIGHT RED
LIGHT MAGENTA

Remote command: `DISP:CMAP1 to 26:PDEF <color>`

Instrument Setup and Interface Configuration – SETUP Key

In phase noise mode (SSA hotkey), the setup menu (SETUP key) offers less functionality than in analyzer mode (SPECTRUM hotkey). If you miss a softkey when performing a task, check which mode is active (the corresponding hotkey is highlighted). If necessary, change to the analyzer mode by pressing the SPECTRUM hotkey.

The SETUP key opens the menu for configuration of the R&S FSUP:

SETUP

REFERENCE INT / EXT		
NOISE SRC ON/OFF		
PREAMP		
TRANSDUCER ↓	TRANSDUCER FACTOR	
	NEW FACTOR / EDIT TRD FACTOR ↓	TRD FACTOR NAME
		TRD FACTOR UNIT
		TRD FACTOR VALUES
		INSERT LINE
		DELETE LINE
		SAVE TRD FACTOR
	DELETE FACTOR	
	REFLVL ADJ AUTO MAN	
	PAGE UP	
	PAGE DOWN	
GENERAL SETUP ↓	GPIB ↓	GPIB ADDRESS
		ID STRING FACTORY
		ID STRING USER
		GPIB LANGUAGE
		IF GAIN NORM/PULS
		SWEEP REP ON/OFF
	COM INTERFACE	
	TIME+DATE	
	CONFIGURE NETWORK	
	NETWORK LOGIN	
	OPTIONS ↓	INSTALL OPTION
		REMOVE OPTION
	Side menu	
	SOFT FRONTPANEL	

	LXI ↓	DISPLAY ON/OFF
		LCI
SYSTEM INFO ↓	HARDWARE INFO	
	STATISTICS	
	SYSTEM MESSAGES	
	CLEAR ALL MESSAGES	
SERVICE ↓	INPUT RF	
	INPUT CAL	
	SELFTEST	
	SELFTEST RESULTS	
	ENTER PASSWORD	
	Side menu	
	CAL GEN 128 MHZ	
	CAL GEN COMB PULSE	
	CAL GEN COMB RECT	
	2. side menu	
	COMMAND TRACKING	
Side menu		
FIRMWARE UPDATE ↓	FIRMWARE UPDATE	
	RESTORE FIRMWARE	
	UPDATE PATH	
PRESET SSA		
PRESET ANALYZER		
POWER METER		
IF SHIFT ↓	IF SHIFT OFF	
	IF SHIFT A	
	IF SHIFT B	

The following settings can be modified here:

- The *REFERENCE INT/EXT* softkey determines the source of the reference. For details refer to section [“External Reference” on page 4.229](#).
- The *NOISE SRC ON/OFF* softkey switches on and off the voltage supply for an external noise source. For details refer to section [“External Noise Source” on page 4.230](#).
- The *PREAMP* softkey switches on the RF preamplifier gain. This softkey is only available with option EL. ATTENUATOR (B25). For details refer to section [“RF Preamplifier” on page 4.230](#).
- The *TRANSDUCER* softkey opens a submenu for entering the correction characteristics for transducers. For details refer to section [“TRANSDUCER” on page 4.231](#).

- The *GENERAL SETUP* softkey opens a submenu for all the general settings such as GPIB address, date and time as well as the configuration of the device interfaces. *FIRMWARE OPTIONS* can be installed under this menu item. For details refer to section “[GENERAL SETUP](#)” on page 4.237.
- The *SYSTEM INFO* softkey opens a submenu for displaying the hardware configuration of the instrument, the switching cycle statistics and system messages. For details refer to section “[SYSTEM INFO](#)” on page 4.250.
- The *SERVICE* softkey opens a submenu in which special device functions and system information can be selected for servicing. The password required for service functions can be entered in this submenu. For details refer to section “[SERVICE](#)” on page 4.252.
- The *SERVICE FUNCTIONS* softkey enables additional special settings for servicing and troubleshooting. It is available after entering the corresponding password under the *SERVICE* softkey.

External Reference

The R&S FSUP can use the internal reference source or an external reference source as frequency standard from which all internal oscillators are derived. A 10 MHz crystal oscillator is used as internal reference source. In the default setting (internal reference), this frequency is available as output signal at rear-panel connector REF OUT, e.g. to synchronize other instruments to the reference of the R&S FSUP.

In the setting *REFERENCE EXT*, the connector REF IN is used as input connector for an external frequency standard. In this case all internal oscillators of the R&S FSUP are synchronized to the external reference frequency.

REFERENCE INT / EXT

The *REFERENCE INT / EXT* softkey switches between the internal and external reference.

If the external reference is selected, also the frequency of the external reference is adjustable between 1 MHz and 20 MHz. The default value is 10 MHz.

With option R&S FSUP-B60 (Cross Correlation PLL measurements), the external reference frequency is restricted to 10 MHz and may not be changed.

These reference settings are not changed if a preset occurs to maintain the specific setup of a test system.



Note

If the reference signal is missing when switching to external reference, the *EXREF* message appears after a while to indicate that there is no synchronization.

When switching to internal reference ensure that the external reference signal is deactivated to avoid interactions with the internal reference signal.

Remote command: ROSC:SOUR INT
 ROSC:EXT:FREQ <numeric value>

External Noise Source

NOISE SRC ON/OFF The *NOISE SRC ON/OFF* softkey switches on or off the supply voltage for an external noise source which is connected to the *NOISE SOURCE* connector on the rear panel of the instrument.

Remote command: `DIAG:SERV:NSO ON`

RF Preamp

To improve the noise figure, a low-noise preamplifier with variable gain at the RF input can be switched into the signal path.

PREAMP The *PREAMP* softkey switches the preamplifier on and activates the entry of the preamplifier gain. The preamplifier is switched off by pressing the softkey again.

The only possible value with option el. attenuator is 20 dB.

Remote command: `INP:GAIN 0DB`



Note

The *PREAMP* softkey is only available with option EL. ATTENUATOR (B25).

Transducer

Activating Transducer Factors

The *TRANSDUCER* softkey opens a submenu enabling the user to activate or deactivate defined transducer factors, to generate new transducer factors or to edit existing ones. A table with the transducer factors defined is displayed.

As soon as a transducer is activated, the unit of the transducer is automatically used for all the level settings and outputs. The unit cannot be changed in the *AMPT* menu since the R&S FSUP and the transducer used are regarded as one measuring instrument. Only if the transducer has the unit dB, will the unit originally set on the R&S FSUP be maintained and can be changed.

If a transducer factor is active, the remark TDF appears in the enhancement labels column.

After all transducers have been switched off, the R&S FSUP returns to the unit that was used before a transducer was activated.

In the analyzer mode, an active transducer for a sweep is calculated once in advance for every point displayed and is added to the result of the level measurement during the sweep. If the sweep range changes, the correction values are calculated again. If several measured values are combined, only one value is taken into consideration.

If the active transducer factor is not defined for the entire sweep range, the values missing are replaced by zeroes.

TRANSDUCER

The *TRANSDUCER* softkey opens a submenu for editing existing transducer factor and sets or creating new transducer factor and sets.

TRANSDUCER FACTOR	
NEW FACTOR / EDIT TRD FACTOR ↓	TRD FACTOR NAME
	TRD FACTOR UNIT
	TRD FACTOR VALUES
	INSERT LINE
	DELETE LINE
	SAVE TRD FACTOR
DELETE FACTOR	
REFLVL ADJ AUTO MAN	
PAGE UP	
PAGE DOWN	

A table with the available factors is displayed, and the active transducer can be selected from this list.

TRANSDUCER FACTOR	
Name	Unit
<input checked="" type="checkbox"/> Cable_1	dB
HK116	dBuV/m
HL223	dBuV/m

The *TRANSDUCER FACTOR* table contains all the defined factors with name and unit. If the number of transducer factors defined exceeds the number of lines available in the table, the user has to scroll through the table.

Only one factor at a time can be activated. A check sign next to the name indicates that the transducer is active.

TRANSDUCER FACTOR The *TRANSDUCER FACTOR* softkey places the scrollbar on the position of the active transducer factor.


If a transducer factor is not active, the scrollbar is placed on the first line of the table.

Remote command: CORR:TRAN:SEL <name>
 CORR:TRAN ON | OFF

EDIT TRD FACTOR The *EDIT TRD FACTOR* softkey gives access to the submenu for editing and generating transducer factors. For details refer to section “[Entry and Editing of Transducer Factors](#)” on page 4.233.

NEW FACTOR The *NEW FACTOR* softkey gives access to the submenu for editing and generating transducer factors. For details refer to section “[Entry and Editing of Transducer Factors](#)” on page 4.233.

DELETE FACTOR The *DELETE FACTOR* softkey deletes the marked factor.
To prevent deletion by mistake, deletion has to be confirmed.



Remote command: CORR:TRAN DEL

REFLVL ADJ When a transducer factor is used, the trace is moved by a calculated shift. However, an upward shift reduces the dynamic range for the displayed values. With the softkey *REFLVL ADJ* an automatic reference level offset adaptation allows to restore the original dynamic range by also shifting the reference level by the maximum value of the transducer factor.

AUTO MAN

Remote command: CORR:TRAN:ADJ:RLEV ON | OFF

PAGE UP The *PAGE UP* softkey is used to scroll through large tables that cannot completely be displayed on the screen.

PAGE DOWN The *PAGE DOWN* softkey is used to scroll through large tables that cannot completely be displayed on the screen.

Entry and Editing of Transducer Factors

A transducer factor is characterized by the following:

- Reference values with frequency and factor (*Values*)
- Unit of the factor (*Unit*) and
- Name (*Name*) to distinguish the various factors.

During entry the R&S FSUP checks the transducer factor for compliance with specific rules that must be met to ensure correct operation.

- The frequencies for the reference values must always be entered in ascending order. Otherwise the entry will not be accepted and the following message is displayed.

Frequency Sequence!

- The frequencies entered may exceed the frequency range of the R&S FSUP since only the set frequency range is taken into account for measurements. The minimum frequency of a reference value is 0 Hz, the maximum frequency 200 GHz.
- The value range for the transducer factor is ± 200 dB. If the minimum or maximum value is exceeded, the R&S FSUP outputs the following message:

*Min Level -200 dB or
Max Level 200 dB.*

- Gain has to be entered as a negative value, and attenuation as a positive value.



Note

The softkeys in the *UNIT* submenu of the *AMPT* key cannot be operated if the transducer is on.

NEW FACTOR / EDIT TRD FACTOR

INSERT LINE
DELETE LINE
TRD FACTOR NAME
TRD FACTOR UNIT
TRD FACTOR VALUES
SAVE TRD FACTOR

The *NEW FACTOR* and *EDIT TRD FACTOR* softkeys give access to the submenu for editing and generating transducer factors.

EDIT TRANSDUCER FACTOR			
Name/Unit/Interpolation:	Cable	dB	LIN
Comment:			
FREQUENCY	TDF/dB..	FREQUENCY	TDF/dB..
1.0000000 MHz	1.000		
1.0000000 GHz	5.500		

Depending on the softkey selected, either the table with the data of the factor marked (*EDIT TRD FACTOR* softkey) or an empty table (*NEW FACTOR* softkey) is displayed. This table is empty except for the following entries:

Unit: dB

Interpolation: LIN for linear frequency scaling
LOG for logarithmic frequency scaling

The features of the factor are entered in the header of the table, and the frequency and the transducer factor are entered in the columns.

Name Entry of name
Unit Selection of unit
Interpolation Selection of interpolation
Comment Entry of comment
FREQUENCY Entry of frequency of reference values
TDF/dB Entry of transducer factor.

During editing, a transducer factor remains stored in the background until the factor edited is saved with the *SAVE TRD FACTOR* softkey or until the table is closed. A factor that was edited by mistake can be restored by leaving the entry function.

Comment - Entry of comment

Any comment with a maximum length of 50 characters can be entered.


Remote command: CORR:TRAN:COMM <string>

TRD FACTOR NAME The *TRD FACTOR NAME* softkey is used to enter the name of the transducer factor. The name may consist of a maximum of 8 characters that have to comply with the conventions for DOS file names. The instrument automatically adds the *.TDF* extension to all transducer factors that are saved.

If an existing name is changed, the factor stored under the previous name is maintained and is not automatically overwritten by the new version. The old factor can be deleted later on using the *DELETE* function. This makes it possible to copy factors.

Remote command: `CORR:TRAN:SEL <name>`

TRD FACTOR UNIT The *TRD FACTOR UNIT* softkey gives access to a box for selecting the unit of the transducer factor



The default setting is dB.

Remote command: `CORR:TRAN:UNIT <string>`

TRD FACTOR VALUES The *TRD FACTOR VALUES* softkey sets the scrollbar on the first reference value. The desired reference values for FREQUENCY and TDF/dB must be entered in ascending order of frequencies. After the frequency has been entered, the scrollbar automatically goes to the associated level value.

The table can be edited after entry of the first value using the *INSERT LINE* and *DELETE LINE* softkeys. To change individual values later on, the value has to be selected and a new one entered.

Remote command: `CORR:TRAN:DATA <freq>,<level>`

Interpolation - Selection of interpolation

Linear or logarithmic interpolation can be performed between the frequency reference values of the table. The *ENTER* key allows the user to select LIN or LOG (toggle function).

Remote command: `CORR:TRAN:SCAL LIN|LOG`

The following diagrams show the effect that interpolation has on the calculated trace:




Fig. 4-29 Linear frequency axis and linear interpolation




Fig. 4-30 Logarithmic frequency axis and interpolation

INSERT LINE The *INSERT LINE* softkey inserts an empty line above the marked reference value. When entering a new reference value in the line, the ascending order of frequencies must be taken into consideration, however.

DELETE LINE The *DELETE LINE* softkey deletes the marked reference value (complete line). The reference values that follow move one line up.

Remote command: --

SAVE TRD FACTOR The *SAVE TRD FACTOR* softkey saves the changed table in a file on the internal hard disk.

If there is already a transducer factor that has the same name, a confirmation query is output.

If the new factor is active, the new values become immediately valid.

Remote command: --
 (executed automatically after the definition of the
 reference values)

Programming the Interface Configuration and Time Setup

The *GENERAL SETUP* softkey opens a submenu in which the general instrument parameters can be set up. In addition to the configuration of the digital interfaces (*IECBUS*, *COM*), the date and time may be entered.

The current settings are displayed in tabular form on the display screen where they may be edited.

GENERAL SETUP

GPIB ↓	GPIB ADDRESS
	ID STRING FACTORY
	ID STRING USER
	GPIB LANGUAGE
	IF GAIN NORM/PULS
	SWEEP REP ON/OFF
COM INTERFACE	
TIME+DATE	
CONFIGURE NETWORK	
NETWORK LOGIN	
OPTIONS ↓	INSTALL OPTION
	REMOVE OPTION
Side menu	
SOFT FRONTPANEL	
LXI ↓	DISPLAY ON/OFF
	LCI

Selecting the GPIB Address

GPIB The *GPIB* softkey opens a submenu for setting the parameters of the remote-control interface.

Remote command: --

GPIB ADDRESS The *GPIB ADDRESS* softkey enables the entry of the GPIB address.

Valid addresses are 0 through 30. The default address is 20.

Remote command: SYST:COMM:GPIB:ADDR 20

ID STRING FACTORY The *ID STRING FACTORY* softkey selects the default response to the *IDN? query.

Remote command: --

ID STRING USER The *ID STRING USER* softkey opens an editor for entering a user-defined response to the *IDN? query.

Max. length of output string: 36 characters

Remote command: --

GPIB LANGUAGE The *GPIB LANGUAGE* softkey opens a list of selectable remote-control languages:

- SCPI
- 71100C
- 71200C
- 71209A
- 8560E
- 8561E
- 8562E
- 8563E
- 8564E
- 8565E
- 8566A
- 8566B
- 8568A
- 8568B
- 8591E
- 8594E



Notes

For 8566A/B, 8568A/B and 8594E, command sets A and B are available. Command sets A and B differ in the rules regarding the command structure.

Selecting a language different from "SCPI" will set the GPIB address to 18 if it was 20 before.

Start / stop frequency, reference level and # of sweep points will be adapted to the selected instrument model.

The HP model 8591E is compatible to HP model 8594E, the HP models 71100C, 71200C, and 71209A are compatible to HP models 8566A/B.

On switching between remote-control languages, the following settings or changes will be made:

SCPI:

- > The instrument will perform a PRESET.

8566A/B, 8568A/B, 8594E:

- > The instrument will perform a PRESET.
- > The following instrument settings will then be changed:

Model	# of Trace Points	Start Freq.	Stop Freq.	Ref Level	Input Coupling
8566A/B	1001	2 GHz	22 GHz	0 dBm	
8568A/B	1001	0 Hz	1.5 GHz	0 dBm	AC
8560E	601	0 Hz	2.9 GHz	0 dBm	AC
8561E	601	0 Hz	6.5 GHz	0 dBm	AC
8562E	601	0 Hz	13.2 GHz	0 dBm	AC
8563E	601	0 Hz	26.5 GHz	0 dBm	AC
8564E	601	0 Hz	40 GHz	0 dBm	AC
8565E	601	0 Hz	50 GHz	0 dBm	AC
8594E	401	0 Hz	3 GHz	0 dBm	AC



Notes regarding switch over to 8566A/B and 8568A/B on R&S FSUP

- Switch-hitter of the "# of Trace Points" will not take place until the instrument is switched to the REMOTE mode. For manual operation (selected with *LOCAL* softkey), the number of sweep points (trace points) will always be set to 1251.
- The stop frequency indicated in the table may be limited to the corresponding frequency of the R&S FSUP, if required.

Remote command:

```
SYST:LANG "SCPI" | "8560E" |
"8561E" | "8562E" | "8563E" |
"8564E" | "8565E" | "8566A" |
"8566B" | "8568A" | "8568B" |
"8591E" | "8594E" | "71100C" |
"71200C" | "71209A"
```

IF GAIN NORM/PULS The *IF GAIN NORM/PULS* softkey configures the internal IF gain settings in HP emulation mode due to the application needs. This setting is only taken into account for resolution bandwidth < 300 kHz.

NORM Optimized for high dynamic range,
overload limit is close to reference level.

PULS Optimized for pulsed signals,
overload limit up to 10 dB above reference level.

This softkey is only available, if a HP language is selected via the [GPIB LANGUAGE](#) softkey.

Remote command: SYST:IFG:MODE PULS

SWEEP REP ON/OFF The *SWEEP REP ON/OFF* softkey controls a repeated sweep of the E1 and MKPK HI HP model commands (for details on the commands refer to “[GPIB Commands of HP Models 856xE, 8566A/B, 8568A/B and 8594E](#)” on page 6.269). If the repeated sweep is OFF, the marker is set without sweeping before.



Note

In single sweep mode, switch off this softkey before you set the marker via the E1 and MKPK HI commands in order to avoid sweeping afresh.

This softkey is only available, if a HP language is selected via the [GPIB LANGUAGE](#) softkey.

Remote command: -

Serial Interface Configuration

COM INTERFACE The *COM INTERFACE* softkey activates the *COM INTERFACE* table for entry of the serial interface parameters.

The following parameters can be configured in the table:

<i>Baud rate</i>	data transmission rate
<i>Bits</i>	number of data bits
<i>Parity</i>	bit parity check
<i>Stop bits</i>	number of stop bits
<i>HW-Handshake</i>	hardware handshake protocol
<i>SW-Handshake</i>	software handshake protocol
<i>Owner</i>	assignment to the measuring instrument or computer

COM INTERFACE	
Baud	9600
Bits	8
Parity	NONE
Stopbits	2
HW-Handshake	NONE
SW-Handshake	NONE
Owner	INSTRUMENT

Baud – Data transmission rate

The R&S FSUP supports baud rates between 110 and 19200 baud. The default setting is 9600 baud.

BAUD RATE
19200
✓9600
4800
2400
1200
600
300
110

Remote command: SYST:COMM:SER:BAUD 9600

Bits – Number of data bits per word

For the transmission of text without special characters, 7 bits are adequate. For binary data as well as for text with special characters, 8 bits must be selected (default setting).

BITS
7
✓8

Remote command: SYST:COMM:SER:BITS 7

Parity – Bit parity check

NONE no parity check (default setting)
 EVEN even parity check
 ODD odd parity check

PARITY
✓NONE
EVEN
ODD

Remote command: SYST:COMM:SER:PAR NONE

Stop bits – Number of stop bits

Available are 1 and 2. The default setting is 1 stop bit.



Remote command: `SYST:COMM:SER:SBIT 1`

HW-Handshake – Hardware handshake protocol

The integrity of data transmission can be improved by the use of a hardware handshake mechanism, which effectively prevents uncontrolled transmission of data and the resulting loss of data bytes. For hardware handshake additional interface lines are used to transmit acknowledge signals with which the data transmission can be controlled and, if necessary, stopped until the receiver is ready to receive data again.

A prerequisite for using hardware handshaking is, however, that the interface lines (DTR and RTS) are connected on both transmitter and receiver. For a simple 3-wire connection, this is not the case and hardware handshake cannot be used here.

Default setting is *NONE*.



Remote command: `SYST:COMM:SER:CONT:DTR OFF`
`SYST:COMM:SER:CONT:RTS OFF`

SW-Handshake – Software handshake protocol

Besides the hardware handshake mechanism using interface lines, it is also possible to achieve the same effect by using a software handshake protocol. Here, control bytes are transmitted in addition to the normal data bytes. These control bytes can be used, as necessary, to stop data transmission until the receiver is ready to receive data again.

In contrast to hardware handshaking, software handshaking can be realized even for a simple 3-wire connection.

One limitation is, however, that software handshaking cannot be used for the transmission of binary data, since the control characters XON and XOFF require bit combinations that are also used for binary data transmission.

Default setting is *NONE*.



Remote command: `SYST:COMM:SER:PACE NONE`

Owner – Assignment of the interface

The serial interface can be assigned alternatively to the measuring instrument section or to the computer section.

If the interface is assigned to one section of the instrument, it is not available to the other section.

INSTRUMENT The interface is assigned to the measuring instrument section. Outputs to the interface from the computer section are not possible will get lost.


OS The interface is assigned to the computer section. It cannot be used by the measuring instrument section. This means that remote control of the instrument via the interface is not possible.



Remote command: --

Setting Date and Time

TIME+DATE The *TIME+DATE* softkey activates the entry of time and date for the internal real-time clock.



Time - Input of time

In the corresponding dialog box, the time is partitioned into two input fields so that hours and minutes can be entered independently.

Remote command: SYST:TIME 21,59

Date - Input of Date

In the corresponding dialog box, the date is partitioned into 3 input fields so that day, month and year can be input separately.

For the selection of the month, pressing a unit key opens a list of abbreviations wherein the desired month can be selected.



Remote command: SYST:DATE 1999,10,01


Configuration of Network Settings

The instrument can be connected to an Ethernet LAN (local area network) by means of the LAN Interface. This allows data transmission via the network and the use of network printers. The network card is able to handle both 10 MHz Ethernet IEEE 802.3 and 100 MHz Ethernet IEEE 802.3u.

For more details see the Quick Start Guide, chapter LAN Interface.

CONFIGURE
NETWORK

The *CONFIGURE NETWORK* softkey opens the dialog box with the network settings.



The softkey is used to modify an existing network configuration after the corresponding tabs are selected (see the Quick Start Guide, chapter LAN Interface).

**Notes**

- A PC keyboard with trackball (or mouse instead) is required for the installation/configuration of the network support.
-

Remote command: --

NETWORK LOGIN The *NETWORK LOGIN* softkey opens the dialog box with the auto login settings.

The screenshot shows a 'Network Login' dialog box. It has a title bar with the text 'Network Login'. Inside the dialog, there are two text input fields. The first is labeled 'Login Name:' and contains the text 'Instrument'. The second is labeled 'Password:' and contains the text 'instrument'. Below these fields is a checkbox labeled 'Auto Login' which is checked. At the bottom of the dialog are two buttons: 'OK' and 'Cancel'.

When a network is installed, the preset user name 'Instrument' and the password 'instrument' can be adapted to a new user (see the Quick Start Guide, chapter LAN Interface).

With the 'Auto Login' option active, an automatic registration is performed during booting with the specified user name and password. Otherwise the Windows XP login request is displayed during booting.

**Notes**

- A PC keyboard with trackball (or additional mouse instead) is required for the installation/configuration of the network support.
-

Remote command: --

Enabling Firmware Options

The *OPTIONS* softkey opens a submenu that allows license keys for firmware options to be entered. Previously installed options are displayed in a table that opens automatically.

Remote command: *OPT?

OPTIONS

INSTALL OPTION
REMOVE OPTION

INSTALL OPTION The *INSTALL OPTION* softkey opens the data entry for the license keycode of a firmware option.

On entry of a valid license key the message *OPTION KEY OK* is displayed in the status line and the firmware option appears in table *FIRMWARE OPTIONS*.

On entry of an invalid license key the message *OPTION KEY INVALID* is displayed in the status line.

Remote command: --


REMOVE OPTION The *REMOVE OPTION* softkey removes all firmware options from the instruments. Execution of this function must be confirmed in a message box in order to avoid removal of the firmware options by mistake.

Remote command: --

Emulation of the Instrument Front Panel

SOFT FRONTPANEL The *SOFT FRONTPANEL* softkey switches the display of the front panel keys on and off.

When the front-panel keys are displayed on the screen, the instrument can be controlled by clicking the respective button with the mouse. This is especially useful when the instrument in a different site is controlled via a remote-control program, such as, for instance, the remote desktop of Windows XP, and the screen contents are transferred to the controller via remote link (see the Quick Start Guide, chapter LAN Interface).



Display resolution

When the display of the front-panel keys is switched on, the screen resolution of the instrument changes to 1024x768 pixels. Only a section of the total screen is then displayed on the LC display, which will automatically be shifted on mouse moves.

In order to obtain a complete display of the user interface, an external monitor is to be plugged into the corresponding connector at the rear panel. Prior to performing the resolution change the user is prompted for confirmation whether the required monitor is connected.

Switching off the front-panel display restores the original screen resolution.

Key assignment

Button labels largely correspond to those of the front-panel keys. The rotation function of the rotary knob is assigned to the 'KNOB LEFT' and 'KNOB RIGHT' buttons, the press function (<ENTER>) to 'KNOB PRESS'.

The labels of the softkey buttons (F1 to F9) and of the hotkey buttons (C-F1 to C-F7) indicate that the keys can be operated directly by means of the corresponding function keys F1 to F9 or <CTRL>F1 to <CTRL>F7 of a PS/2 keyboard.

Remote command: SYST:DISP:FPAN ON


LXI Class C Functionality

The LXI menu offers functions for LXI Class C. This menu is only available, if the LXI package is installed and activated (see “LXI Installation” on page 4.248).

LXI

DISPLAY ON/OFF
LCI

DISPLAY ON/OFF The *DISPLAY ON/OFF* softkey shows or hides the *LXI Observer* dialog box.



LCI The *LCI* softkey executes the *LAN Configuration Initialize (LCI)*.

LXI Installation

The LXI Class C support package is pre-installed, if the analyzer is shipped with version 4.1x or newer. In the Windows Start menu, an *LXI* entry is displayed.



Note

The installation of the LXI Class C Support Package requires an external keyboard and/or a mouse.

To install the LXI Class C Support Package, do the following:

1. Download the installer file from the R&S download area.
2. Open the Windows Start menu (Windows key or *CTRL+ESC* key combination) and start the Windows Explorer.
3. Create the sub directory *D:\LXI*, if this directory does not exist.
4. Copy the installer file to this directory via LAN or USB stick.
5. Start the installation by double-clicking the MSI file.

LXI Activation

After the successful packet installation, the LXI support has to be activated:

1. Connect the analyzer to the LAN.
2. Select the Windows Start menu (Windows key or *CTRL+ESC* key combination).
3. Select *LXI*.
4. Select *LXI Config*.
An LXI configuration dialog will be opened.
5. Select the correct instrument (R&S FSUP).
6. Click *Rescan*.
The current IP address will be visible in the bottom line.
7. After successful rescan operation, click *Save*.

LXI Deactivation

1. To switch LXI off, use again the *LXI* entry in the Windows Start menu.
An LXI dialog box will be opened.
2. Click *LXI TURN OFF*.

System Information

The *SYSTEM INFO* softkey opens a submenu in which detailed information on module data, device statistics and system messages is displayed.

SYSTEM INFO

HARDWARE INFO
STATISTICS
SYSTEM MESSAGES
CLEAR ALL MESSAGES

Display of Module Data

HARDWARE INFO The *HARDWARE INFO* softkey opens a table in which the modules (INSTALLED COMPONENTS) installed in the instrument are listed together with the corresponding hardware revisions.

Table *HARDWARE INFO* consists of six columns:

SERIAL #	serial number
COMPONENT	name of module
ORDER #	order number
MODEL	model number of the module
REV	main modification index of the module
SUB REV	secondary modification index of the module

HARDWARE INFO						
COMPONENT	SERIAL #	ORDER #	MODEL	HWC	REV	SUB REV
WB-DETECTOR	000291/072	1130.3086	03	00	03	00
MW CONV UNIT	000291/072	1130.2396	02	00	03	44
CPU-Board	020204/330	1091.2520	00	00	03	02
MOTHERBOARD	100041/003	1130.1960	03	00	05	00
MW CONVERTER	000000	1130.2409	02	00	00	00
DIPLEXER	000000	1132.6501	02	00	00	00
YIG-FILTER	000000	1130.2744	02	00	00	00
FSU	123456/999	1129.9003	00	00	00	00
SYNTHESIZER	100375/002	1130.2096	02	00	05	03
RF-CONVERTER	100113/002	1130.1990	02	00	06	14
IF-FILTER	100302/002	1130.2296	03	05	04	07
RF_ATTEN_LB	100063/002	1137.0599	02	00	25	00
COAX-RELAYS	000000	1137.4788	02	00	00	00



Note

The screenshot lists the components of an R&S FSUP without options.

Display of Device Statistics

STATISTICS

The *STATISTICS* softkey opens the table *STATISTICS*. This table contains the model information, serial number, firmware version, and specifications version of the basic device. Additionally, the operating time of the instrument, the power-on cycles as well as attenuator switching cycles are displayed.

Remote command: --

Display of System Messages

SYSTEM MESSAGES

The *SYSTEM MESSAGES* softkey opens a submenu including a table in which the generated system messages are displayed in the order of their occurrence. The most recent messages are placed at the top of the list.

The following information is available:

- No Device-specific error code
- MESSAGE Brief description of the message
- COMPONENT On hardware messages:
 name of the affected module
- On software messages:
 if needed, the name of the affected software components
- DATE/TIME Date and time of the occurrence of the message

Messages that have occurred since the last call to the *SYSTEM MESSAGES* menu are marked with an asterisk '*'.

The *CLEAR ALL MESSAGES* softkey is activated and allows clearing of the error buffer.

If the number of error messages exceeds the capacity of the error buffer, the message appearing first is "Message buffer overflow".

SYSTEM MESSAGES			
NO	MESSAGE	COMP.	DATE/TIME
107	Reference is Unlocked	DCON	07.MAR.02; 14:03:19
110	Error 110 size of block too big. Block id 10616	CDS	07.MAR.02; 10:38:45
110	Checksum error RF attenuator Block id 10616	CDS	07.MAR.02; 10:38:45

Remote command: SYST:ERR?

CLEAR ALL MESSAGES

The *CLEAR ALL MESSAGES* softkey deletes all messages in the table. The softkey is only available when table *SYSTEM INFO* is active.

Remote command: SYST:ERR?

Service Menu

The service menu offers a variety of additional functions which are used for maintenance and/or trouble shooting.



ATTENTION

The service functions are not necessary for normal measurement operation. However, incorrect use can affect correct operation and/or data integrity of the R&S FSUP.

Therefore, many of the functions can only be used after entering a password. They are described in the instrument service manual.

SERVICE

INPUT RF
INPUT CAL
SELFTEST
SELFTEST RESULTS
ENTER PASSWORD
Side menu
CAL GEN 128 MHZ
CAL GEN COMB PULSE
CAL GEN COMB RECT
COMMAND TRACKING

The *SERVICE* softkey opens a submenu for selection of the service function.

The *INPUT RF* and *INPUT CAL* softkeys are mutually exclusive selection switches. Only one switch can be active at any one time.

General Service Functions

INPUT RF The *INPUT RF* softkey switches the input of the R&S FSUP to the input connector (normal position).

After *PRESET*, *RECALL* or R&S FSUP power on, the *INPUT RF* is always selected.

Remote command: `DIAG:SERV:INP RF`

INPUT CAL The *INPUT CAL* softkey switches the RF input of the R&S FSUP to the internal calibration source (128 MHz) and activates the data entry of the output level of the calibration source. Possible values are 0 dB and –30 dB.

Remote command: `DIAG:SERV:INP CAL;`
 `DIAG:SERV:INP:CSO 0 DBM`

- ENTER PASSWORD** The *ENTER PASSWORD* softkey allows the entry of a password.
- The R&S FSUP contains a variety of service functions which, if incorrectly used, can affect correct operation of the R&S FSUP. These functions are normally not accessible and are only usable after the entry of a password (see instrument service manual).
- Remote command: `SYST:PASS "Password"`
- CAL GEN 128 MHZ** The *CAL GEN 128 MHZ* softkey selects a sinusoidal signal at 128 MHz as output signal for the internal calibration source. The internal pulse generator will be switched off.
- CAL GEN 128 MHZ* is the default setting of the R&S FSUP.
- Remote command: `DIAG:SERV:INP CAL`
 `DIAG:SERV:INP:PULS OFF`
- CAL GEN COMB PULSE** This softkey switches the internal pulse generator on and allows the pulse frequency to be entered.
- Available pulse frequencies are 10 kHz, 62,5 kHz, 100 kHz, 500 kHz, 1 MHz, 128 MHz, and 640 MHz.
- Remote command: `DIAG:SERV:INP:PULS ON;`
 `DIAG:SERV:INP:PRAT <value>`
- CAL GEN COMB RECT** The *CAL GEN COMB RECT* softkey switches the internal pulse generator on and allows the pulse frequency to be entered.
- Available pulse frequencies are 5 kHz, 31.25 kHz, 50 kHz, 250 kHz, and 500 kHz.
- Remote command: `DIAG:SERV:INP:RECT ON`
 `DIAG:SERV:INP:RECT:PRAT`
- COMMAND TRACKING** The *COMMAND TRACKING* softkey activates or deactivates the SCPI error log function. All remote control commands received by the R&S FSUP are recorded in the following log file:
D:\R_S\instr\log\IEC_CMDS.LOG
- Logging the commands may be extremely useful for debug purposes, e.g. in order to find misspelled keywords in control programs.

**Note**

If this softkey is activated, the R&S FSUP becomes slower.

Remote command: -

Selftest

SELFTEST The *SELFTEST* softkey initiates the selftest of the instrument modules.

With this function the instrument is capable of identifying a defective module in case of failure.

During the selftest a message box appears in which the current test and its result is shown. The test sequence can be aborted by pressing ENTER ABORT. All modules are checked consecutively and the test result (selftest PASSED or FAILED) is output in the message box.

Remote command: *TST?

SELFTEST RESULTS The *SELFTEST RESULTS* softkey calls the *SELFTEST* table in which the results of the module test are displayed.

In case of failure a short description of the failed test, the defective module, the associated value range and the corresponding test results are indicated.

Remote command: DIAG:SERV:STE:RES?

**PAGE UP /
PAGE DOWN** The *PAGE UP* or *PAGE DOWN* softkey sets the *SELFTEST RESULTS* table to the next or previous page.

Remote command: --

Hardware Adjustment

Some of the R&S FSUP modules can be realigned. This realignment can become necessary after calibration due to temperature drift or aging of components (see service manual instrument).



ATTENTION

The realignment should be carried out by qualified personnel since the changes considerably influence the measurement accuracy of the instrument. This is the reason why the softkeys *REF FREQUENCY*, *CAL SIGNAL POWER* and *SAVE CHANGES* can only be accessed after entering a password.

Firmware Update

The installation of a new firmware version can be performed using the built-in diskette drive. The firmware update kit contains several diskettes.

The installation program is called in the *SETUP* menu.

FIRMWARE UPDATE

FIRMWARE UPDATE
RESTORE FIRMWARE
UPDATE PATH

The *FIRMWARE UPDATE* softkey opens the subdirectory for installing/deinstalling new firmware versions.

Remote command: --

FIRMWARE UPDATE

The *FIRMWARE UPDATE* softkey starts the installation program and leads the user through the remaining steps of the update

Remote command: --

The firmware update is started as follows:

- > Insert disk 1 into the floppy drive.
- > Call *SETUP* side menu via [SETUP][NEXT]
- > Open the subdirectory via [FIRMWARE UPDATE]
- > Start the update via [FIRMWARE UPDATE]

RESTORE FIRMWARE

The *RESTORE FIRMWARE* softkey restores the previous firmware version

Remote command: --

UPDATE PATH

The *UPDATE PATH* softkey is used to select the drive and directories under which the archive files for the firmware update are stored.

The firmware update can thus also be performed via network drives or USB memory sticks/USB-CD-ROM drives.

Remote command: "SYST:FIRM:UPD 'D:\USER\FWUPDATE'"

PRESET SSA

The *PRESET SSA* softkey sets the phase noise mode as preset mode. This is the default mode.

Pressing the *PRESET* key causes the R&S FSUP to load its initial state according to ["Initial State of R&S FSUP in phase noise preset mode" on page 4.6.](#)

Remote command: SYST:PRES:COMP OFF

PRESET ANALYZER

The *PRESET ANALYZER* softkey sets the analyzer mode as preset mode.

Pressing the *PRESET* key causes the R&S FSUP to load its initial state according to ["Initial State of R&S FSUP in analyzer preset mode" on page 4.7.](#)

Remote command: SYST:PRES:COMP SAN

POWER METER The *POWER METER* softkey opens a submenu for measurements with power sensors. For details refer to the Software Manual of the application firmware R&S FS-K9 on the options CD-ROM.

IF SHIFT The *IF SHIFT* softkey opens a submenu to activate or deactivate 1st IF shifting. Input signals at a frequency of half the 1st IF (in the frequency range of 2270 MHz to 2350 MHz) reduce the dynamic range of the analyzer. This problem only occurs for low RF attenuation values. It can be overcome by shifting the 1st IF.

**Note**

The 1st IF shifting is automatically done for ACP measurements if the center frequency (= signal frequency) is in the range of 2270 MHz to 2350 MHz. The *IF SHIFT* setting is therefore ignored for ACP measurements.

IF SHIFT OFF The *IF SHIFT OFF* softkey deactivates the 1st IF shifting.

Remote command: SWE:IF:SHIF OFF

IF SHIFT A The *IF SHIFT A* softkey is appropriate for input signals in the frequency range of 2270 MHz to 2310 MHz.

Remote command: SWE:IF:SHIF A

IF SHIFT B The *IF SHIFT B* softkey is appropriate for input signals in the frequency range of 2310 MHz to 2350 MHz.

Remote command: SWE:IF:SHIF B

Saving and Recalling Data Sets – FILE Key

Overview

The *FILE* key calls the following functions:

- Storage/loading functions for storing (*SAVE*) instrument settings such as instrument configurations (measurement/display settings, etc.) and measurement results from working memory to permanent storage media, or to load (*RECALL*) stored data into working memory.
- Functions for management of storage media (*FILE MANAGER*). Included are among others functions for listing files, formatting storage media, copying, and deleting/renaming files.

The R&S FSUP is capable of internally storing complete instrument settings with instrument configurations and measurement data in the form of data sets. The respective data are stored on the internal hard disk or, if selected, on a floppy. The hard disk and floppy disk drives have the following names:

floppy disk A:

hard disk D: (hard disk C: is reserved for instrument software)

FILE

SAVE		
RECALL		
EDIT PATH		
EDIT COMMENT		
ITEMS TO SAVE/RCL ↓	SELECT ITEMS	
	ENABLE ALL ITEMS	
	DISABLE ALL ITEMS	
	DEFAULT CONFIG	
DATA SET LIST		
DATA SET CLEAR		
STARTUP RECALL		
FILE MANAGER ↓	EDIT PATH	
	NEW FOLDER	
	COPY	
	RENAME	
	CUT	
	PASTE	
	DELETE	
	SORT MODE ↓	NAME
		DATE
		EXTENSION
		SIZE

	2 FILE LISTS	
	Side menu	
	FORMAT DISK	
Side menu		
ASCII FILE EXPORT		
DECIM SEP		
DATA SET CLEAR ALL		

For details on storing and loading instrument settings refer to the Quick Start Guide, chapter 5.

SAVE

The *SAVE* softkey opens the dialog window for entering the data set to be stored.

The *SAVE* table contains the entry fields for editing the data set.

Path Directory in which the data set is stored.

Files List of data sets already stored.

File Name Name of data set.

The name can be entered with or without drive name and directory; the drive name and directory, if available, will then appear in the PATH field. The extension of the data name is ignored.

Comment Comment regarding the data set.

Items Selection of settings to be stored.

Remote command: `MMEM:STOR:STAT 1,"a:\test02"`

RECALL

The *RECALL* softkey activates the dialog window to enter the data set to be loaded.

The *RECALL* table shows the current settings regarding the data set.

Path Directory in which the data set is stored.

Files List of stored data sets

File Name Name of data set.

The name can be entered with or without drive name and directory. The drive name and directory will then appear in the Path field. A potential extension of the file name is ignored.

Comment Comment regarding data set.


Items Selection of settings to be loaded.

Remote command: `MMEM:LOAD:STAT 1,"a:\test02"`

EDIT PATH

The *EDIT PATH* softkey activates the entry of a path name for the device configuration to be stored/to be loaded.

The desired directory is selected with the rotary knob or the *CURSOR UP / DOWN* key and is confirmed by pressing the rotary knob or the *ENTER* key.

Subdirectories are opened by the *CURSOR RIGHT*  key and closed with the *CURSOR LEFT*  key.

Remote command: --

EDIT COMMENT

The *EDIT COMMENT* softkey activates the entry of commentary concerning the current data set. The help line editor is opened with *CURSOR DOWN*.

A total of 60 characters are available for this purpose.

**Note**

For further information on how to enter the comment text via the front panel of the unit, see the Quick Start Guide, chapter "Basic Operation."

Remote command: `MMEM:COMM "Setup for FM measurement"`

**ITEMS TO SAVE/
RCL**

The *ITEMS TO SAVE/RCL* softkey opens a submenu for selecting the data subsets.

The *Save* dialog box offers the following selectable data subsets in the *Items* field.

Current Settings

These settings include:

- current configuration of general instrument parameters
- current measurement hardware settings
- active limit lines:

A data set may contain maximum 8 limit lines for each window. It always contain the activated limit lines and the de-activated limit lines used last, if any.

Consequently, the combination of the restored deactivated limit lines depends on the sequence of use with command `MMEM:LOAD`.

- the activated transducer factor
- user-defined color settings
- configuration for hardcopy output

	<i>All Limit Lines</i>	all limit lines
	<i>All Transducer</i>	all transducer factors
	<i>All Traces</i>	all traces which are not blanked
	<i>Source Cal Data</i>	correction data for tracking generator (only with options B10)
SELECT ITEMS	The <i>SELECT ITEMS</i> softkey moves the selection bar to the first line, left column of the <i>Items</i> field. An entry is selected. Position the entry focus to the corresponding partial data set using the cursor keys and then press the <i>ENTER</i> key in the desired line. The selection is cleared by pressing the key again.	
	Remote command:	MMEM:SEL:HWS ON (Current Settings) MMEM:SEL:LIN:ALL ON (All Limit Lines) MMEM:SEL:TRAC ON (All Traces)
ENABLE ALL ITEMS	The <i>ENABLE ALL ITEMS</i> softkey marks all partial data sets.	
	Remote command:	MMEM:SEL:ALL
DISABLE ALL ITEMS	The <i>DISABLE ALL ITEMS</i> softkey deselects all partial data sets.	
	Remote command:	MMEM:SEL:NONE
DEFAULT CONFIG	The <i>DEFAULT CONFIG</i> softkey establishes the default selection of the data subset to be saved and outputs <i>DEFAULT</i> in the <i>ITEMS</i> field of the <i>SAVE/RECALL DATA SET</i> table.	
	Remote command:	MMEM:SEL:DEF
DATA SET LIST	The <i>DATA SET LIST</i> softkey sets the entry focus to the list <i>Files</i> of all available data sets. In addition, the <i>DATA SET CLEAR</i> softkey is displayed.	
	The list <i>Files</i> lists all data sets which are stored in the selected directory.	
	The <i>Comment</i> and <i>Items</i> fields in the <i>DATA SET CONTENTS</i> column indicate the saved data subsets and the comment for the currently selected data set.	
	Remote command:	--
DATA SET CLEAR	The <i>DATA SET CLEAR</i> softkey deletes the selected data set	
	Remote command:	MMEM:CLE:STAT 1, "test03"
STARTUP RECALL	The <i>STARTUP RECALL</i> softkey activates the selection of a data set which is automatically loaded when the instrument is powered on and after <i>PRESET</i> . For this purpose the Dialog <i>Startup Recall</i> is opened (analogously to <i>DATA SET LIST</i>).	
	The field <i>Files</i> lists all data sets stored in the selected directory. The currently selected data set is checked.	
	In addition to the data sets stored by the user, the data set <i>FACTORY</i> , which specifies the settings of the instrument before it was last switched off (Standby), is always present (when unit is delivered).	

To select a data set, the entry focus is set to the corresponding entry by means of the rotary knob and the data set is activated by pressing the rotary knob or the *ENTER* key.


If a data set other than *FACTORY* is chosen, this data set will be loaded when the unit is switched on or after pressing the *PRESET* key. Any settings can be assigned to the *PRESET* key.

Remote command: MMEM:LOAD:AUTO 1,"D:
 \user\config\test02"

Operating Concept of File Managers

FILE MANAGER

The *FILE MANAGER* softkey opens a menu for managing storage media and files.




The designation and the letter of the current drive are displayed in the upper left corner of the File Manager dialog.

The table below shows the files of the current directory and potential subdirectories.

A file or a directory in the table is selected via cursor keys. The *ENTER* key is used to switch from one subdirectory to another. The softkeys *COPY*, *RENAME*, *CUT* and *DELETE* are only visible if the entry focus is set to a file and not to a directory.

The dots ".." open up the next higher directory.

EDIT PATH The *EDIT PATH* softkey activates the input of the directory which will be used in subsequent file operations.



Use *CURSOR UP / DOWN* to select a drive and confirm your selection with *ENTER*.

Open subdirectories by using *CURSOR RIGHT*, and use *CURSOR LEFT* to close them again.

When you have found the subdirectory you looked for, mark it with *ENTER*.


Remote command: MMEM:MSIS "a:"
 MMEM:CDIR "D:\user "

NEW FOLDER The *NEW FOLDER* softkey creates subdirectories.

The entry of an absolute path name (e.g. "\USER\MEAS") as well as the path relative to the current directory (e.g. "..\MEAS") is possible.

Remote command: MMEM:MDIR "D:\user\test"

COPY The *COPY* softkey opens the help line editor to enter the target directory for a copying process. The file is also copied into the clipboard and can be copied into a different directory at a later time by means of *PASTE*.



Files can also be copied to a different storage medium by indicating a certain drive letter (e.g. D:). The selected files or directories will be copied after terminating the entry with the ENTER key.

Remote command: `MMEM: COPY "D:\user\set.cfg", "a:"`

RENAME The *RENAME* softkey opens the help line editor to rename a file or a directory (analogously to the *COPY* softkey).

Remote command: `MMEM: MOVE "test02.cfg", "set2.cfg"`

CUT The *CUT* softkey shifts the selected file into the clipboard from where it can be copied into a different directory at a later time by means of *PASTE*.



Note

The file in the output directory will only be deleted if the *PASTE* softkey has been pressed.

Remote command: `--`

PASTE The *PASTE* softkey copies files from the clipboard to the current directory. The directory is changed by means of the cursor keys and subsequent pressing of *ENTER* or via the *EDIT PATH* softkey.

Remote command: `--`


DELETE The *DELETE* softkey deletes the selected file.
 A confirmation query is displayed to avoid unintentional deletion of files.

Remote command: MMEM:DEL "test01.hcp"
 MMEM:RDIR "D:\user\test"

SORT MODE

NAME
DATE
EXTENSION
SIZE

The *SORT MODE* softkey opens the submenu to select the sorting mode for the displayed files.



Directory names are located at the top of the list after the entry for the next higher directory level ("..").

Remote command: --

NAME The *NAME* softkey sorts the file list by name.

Remote command: --

DATE The *DATE* softkey sorts the file list by date.

Remote command: --

EXTENSION The *EXTENSION* softkey sorts the file list by file extension.

Remote command: --

SIZE The *SIZE* softkey sorts the file list by size

Remote command: --

2 FILE LISTS The *2 FILE LISTS* softkey opens a second window for the File Manager. The entry focus can be moved between the two windows by means of *SCREEN A* and *SCREEN B* hotkeys.

Files can thus very easily be copied and shifted from one directory to the other.



Note

The second file list can also be opened in the Full Screen mode via *SCREEN B* or *SCREEN A* hotkey.

Remote command: -

ASCII FILE EXPORT

The *ASCII FILE EXPORT* softkey stores the active trace in ASCII format to a disk.

Remote command: FORM ASC;
 MMEM:STOR:TRAC 1, 'TRACE.DAT'

The file consists of a header, which contains important scaling parameters, and a data section, which contains the trace data.

The file header data comes in three columns separated by semicolons (;).

It has the following contents:

parameter name; numerical value; default unit

The data section starts with the key word "Trace <n>", where <n> designates the number of the trace to be stored. This is followed by the measured data in columns separated by semicolons (;).

This format can be read by spreadsheet programs such as MS Excel. A semicolon (;) is to be defined as a separator between the cells of a table.



Note

Analysis programs may come in different language versions that require different notations of the decimal point. By means of the *DECIM SEP* softkey, a decimal point (.) or a comma (,) can be selected as decimal-point notation.

For a detailed description of the ASCII file format, refer to section "[Selection and Setting of Traces – TRACE Key](#)", "[ASCII FILE EXPORT](#)" on page 4.124 softkey.

DECIM SEP

By means of the *DECIM SEP* softkey, one can select between a decimal point (.) and a comma (,) as decimal-point notation for the ASCII FILE EXPORT function.

Due to the possibility of selecting between different decimal-point notations, different language versions of analysis programs (such as MS Excel) can be supported.

Remote command: FORM:DEXP:DSEP POIN

FORMAT DISK

The *FORMAT DISK* softkey formats disks located in drive A:.

To prevent accidental destruction of disk data, confirmation by the user is requested.

Remote command: MMEM:INIT "a:"

**DATA SET CLEAR
ALL**

The *DATA SET CLEAR ALL* softkey deletes all files containing device settings (data sets) in the selected directory.

Remote command: MMEMory:CLEar:ALL

Measurement Documentation – HCOPY Key

The *HCOPY* key opens the *HARDCOPY* menu for starting and configuring the printout.

The installation and configuration of printers is described in the Quick Start Guide, chapters 2, 6, and appendix A.

HCOPY

PRINT SCREEN		
PRINT TRACE		
PRINT TABLE		
DEVICE SETUP		
DEVICE 1 / 2		
COLORS ↓	COLOR ON/OFF	
	SCREEN COLORS	
	OPTIMIZED COLOR SET	
	USER DEFINED ↓	SELECT OBJECT
		BRIGHTNESS
		TINT
		SATURATION
		PREDEFINED COLORS
		SET TO DEFAULT
COMMENT		
Side menu		
INSTALL PRINTER		

Pressing one of the softkeys *PRINT SCREEN*, *PRINT TRACE* or *PRINT TABLE* in the *HCOPY* menu initiates the print job. The printer parameters defined in the *DEVICE SETTINGS* menu are used for setting up the printer configuration. All of the display items to be printed are written to the printer buffer. Since the printer runs in the background, the instrument may be operated immediately after pressing the *PRINT* softkey.

With *PRINT SCREEN* selected, all the diagrams with traces and status displays are printed as they occur on the screen. Softkeys, open tables and data entry fields are not printed.

The *PRINT TRACE* function allows individual traces to be printed. With *PRINT TABLE*, tables can be printed.

The *DEVICE 1 / 2* softkeys are used for selecting and configuring the output interface. For detailed information refer to “[DEVICE 1 / 2](#)” on page 4.270.

If the *Print to File* option in the *Hardcopy Setup* dialog box is selected, the printout is directed to a file. Upon pressing one of the *PRINT...* softkeys, the file name to which the output data is to be written is requested. An entry field is then opened for entering the file name. For detailed information refer to section “[DEVICE SETUP](#)” on page 4.270.

The *COLORS* submenu allows switch over between black-and-white and color printouts (default), provided that the printer connected can produce color printouts. In addition, the colors are set in this submenu. For detailed information refer to section [“Selecting Printer Colors” on page 4.271](#).

- **SCREEN** Output in screen colors.
- **OPTIMIZED (default)** Instead of light colors, dark colors are used for traces and markers: trace 1 blue, trace 1 black, trace 3 green, markers turquoise.
- **USER DEFINED** This option enables the user to change the colors at will. It provides the same setting functions as the *DISPLAY – CONFIG DISPLAY – NEXT* menu.



Notes

- With *SCREEN* and *OPTIMIZED* selected, the background will always be white and the grid black. With *USER DEFINED*, these colors can be selected, too.
 - Upon activation of the submenu, the color display is switched over to the selected printout colors. When the menu is quit, the original color setting is restored.
-

The *COMMENT SCREEN A / B* softkeys allow text to be added to the printout (date and time are inserted automatically).

Use the *INSTALL PRINTER* softkey to install additional printer drivers.

PRINT SCREEN

The *PRINT SCREEN* softkey starts the output of test results.

All the diagrams, traces, markers, marker lists, limit lines etc. are printed out as long as they are displayed on the screen. All the softkeys, tables and open data entry fields are not printed out. Moreover, comments, title, date, and time are output at the bottom margin of the printout.

Remote command: `HCOP:ITEM:ALL`
 `HCOP:IMM`

PRINT TRACE

The *PRINT TRACE* softkey starts the output of all curves visible on the display screen without auxiliary information. Specifically, no markers or display lines are printed.

Remote command: `HCOP:ITEM:WIND:TRAC:STAT ON`
 `HCOP:IMM`

PRINT TABLE

The *PRINT TABLE* softkey starts the output of all tables and info lists visible on the display screen without the measurement diagrams and other information lying behind.

Remote command: `HCOP:ITEM:WIND:TABL:STAT ON`
 `HCOP:IMM`

DEVICE SETUP

The *DEVICE SETUP* softkey opens the dialog where the file format and the printer can be selected. For details on selecting and configuring printers, and printing out the measurement results refer to the Quick Start Guide, chapter 2 and 5.

```
Remote command:      HCOP:DEV:LANG GDI;
                     SYST:COMM:PRIN:ENUM:FIRS?;
                     SYST:COMM:PRIN:ENUM:NEXT?;
                     SYST:COMM:PRIN:SEL <Printer>;
                     HCOP:PAGE:ORI PORT;
                     HCOP:DEST "SYST:COMM:PRIN";
                     HCOP:DEST "SYST:COMM:MMEM"
```

DEVICE 1 / 2

The R&S FSUP is able to manage two hardcopy settings independently of each other. They are selected via the *DEVICE 1 / 2* softkey, which displays also the associated setting if the *DEVICE SETUP* dialog is open. For details on selecting and configuring printers, and printing out the measurement results refer to the Quick Start Guide, chapter 2 and 5.

```
Remote command:      --
```

COLORS

The *COLORS* softkey gives access to the submenu where the colors for the printout can be selected (see section [“Selecting Printer Colors” on page 4.271](#)).

```
Remote command:      --
```

COMMENT

The *COMMENT* softkey opens an entry field in which a comment of two lines (60 characters per line) can be entered for screen A or B.

If the user enters more than 60 characters, the excess characters appear on the second line on the print-out. At any point, a manual line-feed can be forced by entering the @ character.

The comment is printed below the diagram area. The comment text appears on the hardcopy, but not on the display screen.

If a comment should not be printed, it must be cleared.

If the instrument is reset by a click on the PRESET key, all entered comments are cleared.

**Note**

The *COMMENT* softkey opens the auxiliary line editor where the desired letters can be entered in the text field by means of rotary knob and cursor keys.

After clicking the *COMMENT* softkey, the auxiliary line editor can be reached with the key. Pressing the rotary knob or the *ENTER* key inserts the selected characters in the text line.

After editing is completed, return to the text line with the key and confirm the comment text with *ENTER*.

If the entered comment should be aborted, quit the auxiliary line editor with *ESC*.



Note

Only after the auxiliary line editor has been closed with *ESC* can the softkeys and hardkeys be operated again.

A detailed description of the auxiliary line editor can be found in the Quick Start Guide, chapter “Basic Operation”.

Remote command: `HCOP:ITEM:WIND2:TEXT 'Comment'`

INSTALL PRINTER

A certain number of printer drivers is already installed on the R&S FSUP. The *INSTALL PRINTER* softkey opens the *Printers and Faxes* dialog where more printer drivers can be installed.



Note

For details refer to the Quick Start Guide, appendix “Printer Interface”.

Remote command: `--`

Selecting Printer Colors

COLORS

COLOR ON/OFF	
SCREEN COLORS	
OPTIMIZED COLOR SET	
USER DEFINED ↓	SELECT OBJECT
	BRIGHTNESS
	TINT
	SATURATION
	PREDEFINED COLORS
	SET TO DEFAULT

The *COLORS* softkey gives access to the submenu where the colors for the printout can be selected. To facilitate color selection, the selected color combination is displayed when the menu is entered. The previous colors are restored when the menu is exited.

For details on selecting and configuring printers, and printing out the measurement results refer to the Quick Start Guide, chapter 2 and 5.

Remote command: `--`

COLOR ON/OFF The *COLOR ON/OFF* softkey switches over from color output to black-and-white output. All color-highlighted areas are printed in white and all color lines in black. This improves the contrast on the printout. The default setting is *COLOR ON*.

Remote command: `HCOP:DEV:COL ON`

SCREEN COLORS The *SCREEN COLORS* softkey selects the current screen colors for the printout.

**Note**

The background is always printed in white and the grid in black.

Remote command: `HCOP:CMAP:DEF1`

OPTIMIZED COLOR SET The *OPTIMIZED COLOR SET* softkey selects an optimized color setting for the printout to improve the visibility of the colors on the hardcopy.

Trace 1 is blue, trace 2 black, trace 3 green, and the markers are turquoise.

The other colors correspond to the display colors of the *DISP – CONFIG DISPLAY – DEFAULT COLORS 1* softkey.

**Note**


The background is always printed in white and the grid in black.

Remote command: `HCOP:CMAP:DEF2`

USER DEFINED The *USER DEFINED* softkey opens a submenu for user-defined color selection (see submenu *USER DEFINED COLORS*).

Remote command: `HCOP:CMAP:DEF3`

SELECT OBJECT The *SELECT OBJECT* softkey allows picture elements to be selected to change their color setting. After selection, the *PREDEFINED COLORS*, *BRIGHTNESS*, *TINT* and *SATURATION* softkeys enable the user to change the colors or brightness, the hue and the color saturation of the element selected.



Remote command: --

BRIGHTNESS The *BRIGHTNESS* softkey serves for determining the brightness of the graphic element selected.

A value between 0 and 100% can be entered.

Remote command: HCOP:CMAP5:HSL <hue>,<sat>,<lum>

TINT The *TINT* softkey serves for determining the hue of the element selected. The percentage entered refers to a continuous color spectrum from red (0%) to blue (100%).


Remote command: HCOP:CMAP5:HSL <hue>,<sat>,<lum>

SATURATION The *SATURATION* softkey serves for determining the saturation of the element selected.

A value between 0 and 100% can be entered.

Remote command: HCOP:CMAP5:HSL <hue>,<sat>,<lum>

PREDEFINED COLORS The *PREDEFINED COLORS* softkey opens a list from which predefined colors for the displayed elements can be selected:



Remote command: HCOP:CMAP1 ... 26:PDEF <color>

SET TO DEFAULT The *SET TO DEFAULT* softkey reactivates the default color setting (= *OPTIMIZED COLOR SET*).

Remote command: --

Remote command:

External Generator Control – Option R&S FSP-B10

The external generator control option permits to operate a number of commercially available generators as tracking generator on the R&S FSUP. Thus, scalar network analysis with the R&S FSUP is also possible outside the frequency range of the internal tracking generator when the appropriate generators are used.

The R&S FSUP also permits to set a frequency offset for frequency-converting measurements when external generators are used. For harmonics measurements or frequency-converting measurements, it is also possible to enter a factor, by which the generator frequency is increased or reduced compared with the receive frequency of the R&S FSUP. Only make sure that the resulting generator frequencies do not exceed the allowed setting range of the generator.

The level range to be set also depends on the generator used.

The generator is controlled via the – optional – second GPIB interface of the R&S FSUP (= IEC2, supplied with the option) and, with some Rohde & Schwarz generators, additionally via the TTL synchronization interface included in the AUX interface of the R&S FSUP.



Note

The use of the TTL interface enables considerably higher measurement rates as pure GPIB control, because the frequency stepping of the R&S FSUP is directly coupled with the frequency stepping of the generator.

Therefore, the frequency sweep differs according to the capabilities of the generator used:

- In the case of generators without TTL interface, the generator frequency is first set for each frequency point via GPIB, then the setting procedure has to be completed before recording of measured values is possible.
- In the case of generators with TTL interface, a list of the frequencies to be set is entered into the generator before the beginning of the first sweep. Then the sweep is started and the next frequency point selected by means of the TTL handshake line TRIGGER. The recording of measured values is only enabled when the generator signals the end of the setting procedure via the BLANK signal. This method is considerably faster than pure GPIB control.

With the *SELECT GENERATOR* softkey, a list of the supported generators with the frequency and level range as well as the capabilities used is included.

The external generator can be used in all operating modes. Recording of test setup calibration values (*SOURCE CAL*) and normalization with the correction values (*NORMALIZE*) are only possible in the *NETWORK* mode.



Note

In order to enhance measurement accuracy a common reference frequency should be used for both the R&S FSUP and the generator. If no independent 10 MHz reference frequency is available, it is recommended to connect the reference output of the generator with the reference input of the R&S FSUP and to enable usage of the external Reference on the R&S FSUP via *SETUP – REFERENCE EXT.*

Like the internal tracking generator, the external generator is activated by means of the hotkey bar: *MORE* hotkey - *NETWORK* hotkey (for details refer to section [“Mode Selection – Hotkey Bar”](#) on page 4.8).

External Generator Settings

NETWORK

The *NETWORK* hotkey opens the menu for setting the functions of the external generator.

SOURCE POWER	
POWER OFFSET	
SOURCE CAL ↓	CAL TRANS
	CAL REFL SHORT
	CAL REFL OPEN
	NORMALIZE
	REF VALUE POSITION
	REF VALUE
	RECALL
	SAVE AS TRD FACTOR
FREQUENCY OFFSET	
EXT SOURCE ↓	EXT SRC ON / OFF
	SELECT GENERATOR
	FREQUENCY SWEEP
	GEN REF INT / EXT

SOURCE POWER

The *SOURCE POWER* softkey activates the entry of the generator output level. The value range depends on the selected generator. For detailed information see [“List of Generator Types Supported by the R&S FSUP” on page 4.292.](#)

If option is installed, the softkey will modify the output power of the generator currently in use.

The default output power is -20 dBm.

Remote command: `SOUR:EXT:POW -20dBm`

POWER OFFSET

The *POWER OFFSET* softkey activates the entry of a constant level offset of the generator. With this offset, attenuator pads or amplifiers connected to the output connector of the generator can be handled during the input and output of output levels.

The permissible setting range is -200 dB to +200 dB in steps of 0.1 dB. Positive offsets handle a subsequent amplifier and negative offsets an attenuator pad.

The default setting is 0 dB; offsets \neq 0 are marked by the activated enhancement label *LVL*.

Remote command: `SOUR:POW:OFFS -10dB`

Transmission Measurement

The transmission characteristic of a two-port network is measured. The external generator serves as a signal source. It is connected to the input connector of the DUT. The input of the R&S FSUP is fed from the output of the DUT.

A calibration can be carried out to compensate for the effects of the test setup (e.g. frequency response of connecting cables).

Calibration of Transmission Measurement

SOURCE CAL

CAL TRANS
CAL REFL SHORT
CAL REFL OPEN
NORMALIZE
REF VALUE POSITION
REF VALUE
RECALL
SAVE AS TRD FACTOR

The *SOURCE CAL* softkey opens a submenu comprising the calibration functions for the transmission and reflection measurement.

The calibration of the reflection measurement (*CAL REFL...*) and its functioning are described in separate sections.

To carry out a calibration for transmission measurements the whole test setup is through-connected (THRU).

CAL TRANS The *CAL TRANS* softkey triggers the calibration of the transmission measurement.

It starts a sweep that records a reference trace. This trace is then used to obtain the differences to the normalized values.





Fig. 4-31 Calibration curve for transmission measurement

During the calibration the following message is displayed:



After the calibration sweep the following message is displayed:



This message is cleared after approx. 3 seconds.

Remote command: CORR:METH TRAN

Normalization

NORMALIZE The *NORMALIZE* softkey switches normalization on or off. The softkey is only available if the memory contains a correction trace.

It is possible to shift the relative reference point within the grid using the *REF VALUE POSITION* softkey. Thus, the trace can be shifted from the top grid margin to the middle of the grid:




Fig. 4-32 Normalized display

In the *SPLIT SCREEN* setting, the normalization is switched on in the current window. Different normalizations can be active in the two windows.

Normalization is aborted when the *NETWORK* mode is quit.

Remote command: CORR ON

REF VALUE POSITION The *REF VALUE POSITION* softkey (reference position) marks a reference position in the active window on which the normalization (difference formation with a reference curve) is performed.

When pressed for the first time, the softkey switches on the reference line and activates the input of its position. The line can be shifted within the grid limits.

The reference line is switched off by pressing the softkey again.

The function of the reference line is explained in the section [“Calibration Mechanism”](#) on page 4.285.




Fig. 4-33 Normalized measurement, shifted with *REF VALUE POSITION 50%*

Remote command: `DISP:WIND:TRAC:Y:RPOS 10PCT`

REF VALUE The *REF VALUE* softkey activates the input of a level difference which is assigned to the reference line.

In the default setting, the reference line corresponds to a level difference of 0 dB. If e.g. a 10-dB attenuator pad is inserted between DUT and R&S FSUP input between recording of the calibration data and normalization, the trace will be shifted down by 10 dB. By entering a *REF VALUE* of -10 dB the reference line for difference formation can also be shifted down by 10 dB so that it will again coincide with the trace (see Fig. 4-34).




Fig. 4-34 Measurement with REF VALUE -10dB and REF VALUE POSITION 50%

After the reference line has been shifted by entering *REF VALUE* -10 dB, departures from the nominal value can be displayed with high resolution (e.g. 1 dB / Div.). The absolute measured values are still displayed, in the above example, 1 dB below nominal value (reference line) = 11 dB attenuation.




Fig. 4-35 Measurement of a 10-dB attenuator pad with 1dB/DIV

Remote command: `DISP:WIND:TRAC:Y:RVAL -10dB`

RECALL The *RECALL* softkey restores the instrument setting with which the calibration was carried out.

This can be useful if the device setting was changed after calibration (e.g. center frequency setting, frequency deviation, reference level, etc.).

The softkey is only available if:

- the *NETWORK* mode has been selected
- the memory contains a calibration data set.

Remote command: CORR:REC

SAVE AS TRD SAVE AS TRD FACTOR uses the normalized measurement data to generate a
FACTOR transducer factor with up to 625 points. The trace data are converted to a
 transducer with unit dB after the transducer name has been entered. The
 number of points is defined by SWEEP COUNT. The frequency points are
 allocated in equidistant steps between start and stop frequency. The generated
 transducer factor can be further adapted in the menu SETUP – TRANSDUCER.
SAVE AS TRD FACTOR is only available if normalization is switched on.

Remote command: CORR:TRAN:GEN <name>'

Reflection Measurement

Scalar reflection measurements can be carried out by means of a reflection-coefficient bridge.

Fig. 4-36 Test setup for reflection measurement

Calibration of Reflection Measurement

The calibration mechanism essentially corresponds to that of the transmission measurement.


CAL REFL OPEN The *CAL REFL OPEN* softkey starts the open-circuit calibration. During calibration the following message is displayed:



Remote command: CORR:METH REFL
 CORR:COLL OPEN

CAL REFL SHORT The *CAL REFL SHORT* softkey starts the short-circuit calibration. If both calibrations (open circuit, short circuit) are carried out, the calibration curve is formed by averaging the two measurements and stored in the memory. The order of measurements is optional.

After the calibration the following message is displayed:



The display is cleared after approx. 3 seconds.

Remote command: CORR:METH REFL
 CORR:COLL THR

Calibration Mechanism

Calibration means a calculation of the difference between the currently measured power and a reference curve, independent of the selected type of measurement (transmission/reflection). The hardware settings used for measuring the reference curve are included in the reference data set.

Even with normalization switched on, the device settings can be changed in a wide area without stopping the normalization. This reduces the necessity to carry out a new normalization to a minimum.

For this purpose, the reference data set (trace with 625 measured values) is stored as a table with 625 points (frequency/level).

Differences in level settings between the reference curve and the current device settings are taken into account automatically. If the span is reduced, a linear interpolation of the intermediate values is applied. If the span increases, the values at the left or right border of the reference data set are extrapolated to the current start or stop frequency, i.e. the reference data set is extended by constant values.

An enhancement label is used to mark the different levels of measurement accuracy. This enhancement label is displayed at the right diagram border when normalization is switched on and a deviation from the reference setting occurs. Three accuracy levels are defined:

Table 4-3 Measurement accuracy levels

Accuracy	Enhancement label	Reason/Limitation
High	NOR	No difference between reference setting and measurement
Medium	APX (approximation)	Change of the following settings: <ul style="list-style-type: none"> • coupling (RBW, VBW, SWT) • reference level, RF attenuation • start or stop frequency • output level of tracking generator • frequency offset of tracking generator • detector (max. peak, min. peak, sample, etc.) Change of frequency: <ul style="list-style-type: none"> • max. 625 points within the set sweep limits (corresponds to a doubling of the span)
-	Aborted normalization	<ul style="list-style-type: none"> • more than 500 extrapolated points within the current sweep limits (in case of span doubling)

**Note**

At a reference level (*REF LEVEL*) of -10 dBm and at a tracking generator output level of the same value the analyzer operates without overrange reserve, i.e. the analyzer is in danger of being overloaded if a signal is applied whose amplitude is higher than the reference line. In this case, either the message *OVL* for overload is displayed in the status line or the display range is exceeded (clipping of the trace at the upper diagram border = Overrange).

Overloading can be avoided as follows:

- Reducing the output level of the tracking generator (*SOURCE POWER*, *NETWORK* menu)
 - Increasing the reference level (*REF LEVEL*, *AMPT* menu)
-

Frequency-Converting Measurements

For frequency-converting measurements (e.g. on converters) the external generator is able to set a constant frequency offset between the output frequency of the generator and the receive frequency of the R&S FSUP and, in addition, the generator frequency as a multiple of the R&S FSUP.

Fig. 4-37 Test setup for frequency-converting measurements

FREQUENCY OFFSET

The *FREQUENCY OFFSET* softkey activates the input of the frequency offset between the output signal of the generator and the input frequency of the R&S FSUP. The value range depends on the selected generator.

The default setting is 0 Hz. Offsets \neq 0 Hz are marked with the enhancement label *FRQ*.

If a positive frequency offset is entered, the tracking generator generates an output signal above the receive frequency of the analyzer. In case of a negative frequency offset it generates a signal below the receive frequency of the analyzer. The output frequency of the generator is calculated as follows:

$$\text{Generator frequency} = \text{receive frequency} + \text{frequency offset}$$

Remote command: `SOUR:EXT:FREQ:OFFS 1GHZ`

Configuration of an External Generator

EXT SOURCE

EXT SRC ON / OFF
SELECT GENERATOR
FREQUENCY SWEEP
GEN REF INT / EXT

Ref -20 dBm Att 10 dB RBW 3 MHz
 VBW 10 MHz

SELECT GENERATOR								
SRC	TYPE	IFC	GPIB ADDR	MODE	F MIN	F MAX	P MIN	P MAX
1	SME03	TTL	28	REMOTE	5kHz	3GHz	-144dBm	16dBm
2	SHIQ03	GPIB	28	LOCAL	300kHz	3.3GHz	-140dBm	13dBm

FREQUENCY SWEEP						
SOURCE FREQ = REC FREQ * NUM/DEN + OFFSET						
SRC	STATE	POWER[dBm]	NUM	DEN	OFFSET	RESULT
1	<input checked="" type="checkbox"/>	-30dBm	1	1	0Hz	0Hz..3GHz *
2	<input type="checkbox"/>	-30dBm	1	1	0Hz	0Hz..3.2GHz

Start 0 Hz 320 MHz/ Stop 3.2 GHz

EXT SRC ON OFF
 SELECT GENERATOR
 FREQUENCY SWEEP
 GEN REF INT EXT
 SPECTRUM NETWORK SCREEN B

The *EXT SOURCE* softkey opens a submenu for configuration of the external generator.

The R&S FSUP is able to manage two generators, one of which can be active at the time.

EXT SRC ON / OFF The *EXT SRC ON / OFF* softkey switches the external generator on or off.

It can only be switched on successfully if the generator has been selected by means of *SELECT GENERATOR* and configured correctly by means of *FREQUENCY SWEEP*. If one of these conditions is not fulfilled, an error message will be output.



Notes

When switching on the external generator by means of *EXT SRC ON*, the R&S FSUP switches off the internal tracking generator and starts programming the generator settings via the GPIB interface IEC2.

Programming requires takeover of the remote control at this interface by the R&S FSUP. To avoid any access conflicts, ensure that no other controller is connected to the IEC2 interface or the external generator when selecting *EXT SRC ON*.

The maximum stop frequency is limited to the maximum generator frequency. This upper limit is automatically reduced by the set frequency offset of the generator and a set multiplication factor.

With the external generator switched on, the FFT filters (*FILTER TYPE FFT* in the menu *BW*) are not available.

If an error occurs on the GPIB when programming the external generator, the generator will automatically be switched off and the following error message will be output:



When the external generator is switched off using *EXT SRC OFF*, the GPIB control is handed over again at the IEC2 interface, i.e. a different controller will then take over the control of the signal generator.

Remote command: SOUR:EXT ON

SELECT GENERATOR The *SELECT GENERATOR* softkey opens a table for selection of the generator and definition of GPIB address and control interface.

The table permits configuration of two generators so that switching between two different configurations is easily possible.

SELECT GENERATOR								
SRC	TYPE	IFC	GPIB ADDR	MODE	F MIN	F MAX	P MIN	P MAX
1	SME03	TTL	28	REMOTE	5kHz	3GHz	-144dBm	16dBm
2	SMIQ03	GPIB	28	LOCAL	300kHz	3.3GHz	-140dBm	13dBm

The individual fields contain the following settings:

- *SRC*

Index of generator selected

- *TYPE*

The field opens the list with the available generators:

After completion of the selection, the remaining fields of the table are filled with the generator characteristics.

A list of generator types supported by the R&S FSUP is to be found in section [“List of Generator Types Supported by the R&S FSUP” on page 4.292.](#)

- *IFC*

This field selects the interface type of external generator 1 or 2. The following types are available:

- *GPIB*: GPIB only, suitable for all generators of other manufacturers and some Rohde & Schwarz instruments
- *TTL*: GPIB and TTL interface for synchronization, for most of the Rohde & Schwarz generators, see table above.

The two operating modes differ in the speed of the control: Whereas, with pure GPIB operation, each frequency to be set must be individually transferred to the generator, additional use of the TTL interface permits to program a total frequency list at once and subsequently perform the frequency stepping via TTL handshake, which is a big advantage in terms of speed.



Note

Generators equipped with the TTL interface can also be operated with GPIB only.

Only one of the two generators can be operated with TTL interface at a time. The other generator must be configured for GPIB.

- *GPIB ADDR*

GPIB address of the respective generator. Addresses from 0 to 30 are possible.

- *MODE*

Operating mode of generator. The generator activated using the *FREQUENCY SWEEP* softkey is automatically set to remote mode (REMOTE), the other to manual operation (LOCAL).

- *F MIN F MAX*

Frequency range of generator. Select the start and stop frequency of the R&S FSUP in a way that the specified range is not exceeded. If the start frequency lies below *F MIN*, the generator is only switched on when *F MIN* is reached. If the stop frequency lies above *F MAX*, it is limited to *F MAX* when the generator is switched on using the *EXT SRC ON/OFF* softkey.

- *P MIN P MAX*

Level range of generator. This field defines the allowed input range for the *POWER* column in the *FREQUENCY SWEEP* table.

Remote command: SYST:COMM:RDEV:GEN2:TYPE 'SMA01A'
 SYST:COMM:RDEV:GEN:LINK TTL
 SYST:COMM:GPIB:RDEV:GEN1:ADDR 28

List of Generator Types Supported by the R&S FSUP



Note

The R&S SMA and R&S SMU require the following firmware versions:

- R&S SMA: V2.10.x or higher
- R&S SMU: V1.10 or higher

Generator	Interface Type	Generator Min Freq	Generator Max Freq	Generator Min Power dBm	Generator Max Power dBm
SMA01A	TTL	9 kHz	3.0 GHz	-145	+30
SME02	TTL	5 kHz	1.5 GHz	-144	+16
SME03	TTL	5 kHz	3.0 GHz	-144	+16
SME06	TTL	5 kHz	6.0 GHz	-144	+16
SMG	GPIB	100 kHz	1.0 GHz	-137	+13
SMGL	GPIB	9 kHz	1.0 GHz	-118	+30
SMGU	GPIB	100 kHz	2.16 GHz	-140	+13
SMH	GPIB	100 kHz	2.0 GHz	-140	+13
SMHU	GPIB	100 kHz	4.32 GHz	-140	+13
SMIQ02B	TTL	300 kHz	2.2 GHz	-144	+13
SMIQ02E	GPIB	300 kHz	2.2 GHz	-144	+13
SMIQ03B	TTL	300 kHz	3.3 GHz	-144	+13
SMIQ03E	GPIB	300 kHz	3.3 GHz	-144	+13
SMIQ04B	TTL	300 kHz	4.4 GHz	-144	+10
SMIQ06B	TTL	300 kHz	6.4 GHz	-144	+10
SML01	GPIB	9 kHz	1.1 GHz	-140	+13
SML02	GPIB	9 kHz	2.2 GHz	-140	+13
SML03	GPIB	9 kHz	3.3 GHz	-140	+13
SMR20	TTL	1 GHz	20 GHz	-130 ²⁾	+11 ²⁾
SMR20B11 ¹⁾	TTL	10 MHz	20 GHz	-130 ²⁾	+13 ²⁾
SMR27	TTL	1 GHz	27 GHz	-130 ²⁾	+11 ²⁾
SMR27B11 ¹⁾	TTL	10 MHz	27 GHz	-130 ²⁾	+12 ²⁾
SMR30	TTL	1 GHz	30 GHz	-130 ²⁾	+11 ²⁾

Generator	Interface Type	Generator Min Freq	Generator Max Freq	Generator Min Power dBm	Generator Max Power dBm
SMR30B11 1)	TTL	10 MHz	30 GHz	-130 2)	+12 2)
SMR40	TTL	1 GHz	40 GHz	-130 2)	+9 2)
SMR40B11 1)	TTL	10 MHz	40 GHz	-130 2)	+12 2)
SMR50	TTL	1 GHz	50 GHz	-130 2)	+9 2)
SMR50B11 1)	TTL	10 MHz	50 GHz	-130 2)	+12 2)
SMR60	TTL	1 GHz	60 GHz	-130 2)	+9 2)
SMR60B11 1)	TTL	10 MHz	60 GHz	-130 2)	+12 2)
SMP02	TTL	10 MHz	20 GHz	-130 3)	+17 3)
SMP03	TTL	10 MHz	27 GHz	-130 3)	+13 3)
SMP04	TTL	10 MHz	40 GHz	-130 3)	+12 3)
SMP22	TTL	10 MHz	20 GHz	-130 3)	+20 3)
SMT02	GPIB	5.0 kHz	1.5 GHz	-144	+13
SMT03	GPIB	5.0 kHz	3.0 GHz	-144	+13
SMT06	GPIB	5.0 kHz	6.0 GHz	-144	+13
SMV03	GPIB	9 kHz	3.3 GHz	-140	+13
SMU200A	TTL	100 kHz	2.2 GHz	-145	+13
SMU02B31	TTL	100 kHz	2.2 GHz	-145	+19
SMU03 4)	TTL	100 kHz	3 GHz	-145	+13
SMU03B31	TTL	100 kHz	3 GHz	-145	+19
SMU04	TTL	100 kHz	4 GHz	-145	+13
SMU04B31	TTL	100 kHz	4 GHz	-145	+19
SMU06	TTL	100 kHz	6 GHz	-145	+13
SMU06B31	TTL	100 kHz	6 GHz	-145	+13
SMX	GPIB	100 kHz	1.0 GHz	-137	+13
SMY01	GPIB	9 kHz	1.04 GHz	-140	+13
SMY02	GPIB	9 kHz	2.08 GHz	-140	+13
HP8340A	GPIB	10 MHz	26.5 GHz	-110	10
HP8648	GPIB	9 kHz	4 GHz	-136	10
HP ESG-A Series 1000A, 2000A, 3000A, 4000A	GPIB	250 kHz	4 GHz	-136	20
HP ESG-D SERIES E4432B	GPIB	250 kHz	3 GHz	-136	+10

1) Requires the option SMR-B11 to be fitted.

- 2) Maximum/minimum power depends on presence of Option SMR-B15/-B17 and set frequency range. For more details see SMR data sheet.
- 3) Maximum/minimum power depends on presence of Option SMP-B15/-B17 and set frequency range. For more details see SMP data sheet.

FREQUENCY SWEEP The *FREQUENCY SWEEP* softkey opens a table for setting the generator level as well as the multiplier and the offset used to derive the generator frequency from the analyzer frequency.

This table also permits configuration of two generators so that switching between two different configurations is easily possible.

FREQUENCY SWEEP						
SOURCE FREQ = REC FREQ * NUM/DEN + OFFSET						
SRC	STATE	POWER[dBm]	NUM	DEN	OFFSET	RESULT
1	✓	-30dBm	1	1	0Hz	0Hz..3GHz *
2		-30dBm	1	1	0Hz	0Hz..3.2GHz


The individual fields contain the following settings:

- **SRC**
Index of selected generator
- **STATE**
Selects the active generator. Only one generator can be active at a time. The operating mode of the active generator is set to remote control in the *SELECT GENERATOR* table.
- **POWER**
Permits to enter the generator level within the limits P MIN to P MAX of the *SELECT GENERATOR* table.
- **NUM**
Numerator,
- **DEN**
Denominator,
- **OFFSET**
Offset, used to derive the generator frequency from the current frequency of the R&S FSUP according to the following formula:

$$F_{\text{Generator}} = \left| F_{\text{Analyzer}} \cdot \frac{\text{Numerator}}{\text{Denominator}} + F_{\text{Offset}} \right|$$

Note that the frequencies resulting from start and stop frequency of the R&S FSUP do not exceed the allowed generator range:

- If the start frequency lies below F MIN, the generator is only switched on when F MIN is reached.
- If the stop frequency lies above F MAX, the generator is switched off. When the generator is subsequently switched on using the *EXT SRC ON/OFF* softkey, the stop frequency is limited to F MAX.
- If the stop frequency lies below F MIN, the generator is switched off and the following error message output:



- In the time domain (Span = 0 Hz) the generator frequency is derived from the set receive frequency of the R&S FSUP using the calculation formula.

For the sake of clarity, the formula is also displayed in the table.

The offset setting can be used to sweep in the reverse direction. This can be achieved by setting a **negative** offset in the formula above:

Example for reverse sweep:

$$F_{\text{AnalyzerStart}} = 100 \text{ MHz}$$

$$F_{\text{AnalyzerStop}} = 200 \text{ MHz}$$

$$F_{\text{Offset}} = -300 \text{ MHz}$$

$$\text{Numerator} = \text{Denominator} = 1$$

$$\rightarrow F_{\text{GeneratorStart}} = 200 \text{ MHz}$$

$$\rightarrow F_{\text{GeneratorStop}} = 100 \text{ MHz}$$

If the offset is adjusted in a way that the sweep of the generator crosses the 0 Hz Frequency, it is indicated by the additional statement "via 0 Hz".

Example for reverse sweep via 0 Hz

$$F_{\text{AnalyzerStart}} = 100 \text{ MHz}$$

$$F_{\text{AnalyzerStop}} = 200 \text{ MHz}$$

$$F_{\text{Offset}} = -150 \text{ MHz}$$

$$\text{Numerator} = \text{Denominator} = 1$$

$$\rightarrow F_{\text{GeneratorStart}} = 50 \text{ MHz}$$

$$\rightarrow F_{\text{GeneratorStop}} = 50 \text{ MHz via } 0 \text{ Hz}$$

Remote command: : SOUR:EXT:FREQ:NUM 1
 : SOUR:EXT:FREQ:DEN 1
 : SOUR:EXT:FREQ:OFFS -300MHZ

• **RESULT**

The frequency range of the generator resulting from the calculation formula. An asterisk (*) after the upper limit indicates that the stop frequency of the R&S FSUP must be adapted when the generator is switched on in order not to exceed its maximum frequency. In the following illustration, this is true for the upper generator at a stop frequency of 3.2 GHz of the R&S FSUP, whereas the lower generator does not yet require an adaptation:

SOURCE	FREQ =	REC FREQ	* NUM/DEN	+ OFFSET	RESULT
	NUM	DEN	OFFSET		
1	1	1	0Hz		0Hz..3GHz *
1	1	1	0Hz		0Hz..3.2GHz

Remote command: SOUR:EXT:POW -30dBm
 SOUR:EXT:FREQ:NUM 4
 SOUR:EXT:FREQ:DEN 3
 SOUR:EXT:FREQ:OFFS 100MHZ

GEN REF INT / EXT The *GEN REF INT / EXT* softkey switches over the reference oscillator of the generator (switch over between internal and external reference source). Selection *EXT* allows connecting the external generator to an external reference frequency source. The internal reference source is selected as the default setting.

Remote command: SOUR:EXT1:ROSC INT

LAN Interface

The instrument can be connected to an Ethernet LAN (local area network) using the LAN interface connector on the rear panel. This makes it possible to transfer data over the network and to use network printers. In addition, the instrument can be remote-controlled via the network.

For details, refer to the Quick Start Guide, chapters "Preparing for Use" and "LAN Interface".

NOVELL Networks

The operating system NETWARE from NOVELL is a server-based system. Data cannot be exchanged between individual workstations; data transfer takes place between the PC and a server. This server provides memory space and the connection to network printers. On a server, data is organized in directories as under DOS and mapped to the workstation as virtual drives. A virtual drive behaves like an additional hard disk on the workstation, and the data can be edited accordingly. Network printers can also be addressed like normal printers.

There are two versions of the NOVELL network operating system: bindery-based (NETWARE 3) and NDS-based (more recent versions of NETWARE). With the older version (NETWARE 3), each server manages its resources on its own and is independent. A user must be managed on each server separately. In the case of NDS-based versions, all resources in the network are managed together in the NDS (NOVELL DIRECTORY SERVICE). The user must log into the network only once and is given access to the resources according to his/her access rights. The individual resources and users are managed as objects in a hierarchical tree (NDS TREE). The position of the object in the tree is referred to as "CONTEXT" with NETWARE and must be known for access to the resources.

MICROSOFT Network

In case of a MICROSOFT network, data can be exchanged both between workstations (peer to peer) and between workstations and servers. The latter can supply access to files and connection to the printers. On a server, data is organized in directories as under DOS and mapped to the workstation as virtual drives. A virtual drive behaves like an additional hard disk on the workstation, and the data can be edited accordingly. Network printers can also be addressed like normal printers. A connection is possible to DOS, WINDOWS FOR WORKGROUPS, WINDOWS95/98/ME, WINDOWS NT/XP.

Remote Data Transfer with TCP/IP Services

The protocol TCP/IP allows the transfer of files between different computer systems. This requires a program running on the two computers that controls this data transfer. It is not necessary that the same operating or file system is used by both computers. For example, a file transfer between DOS/WINDOWS and UNIX is possible. One of the two partners must be configured as Host and the other one as Client. However, they may change their roles. Usually, the system which is able to perform several processes at the same time will play the host role. The file transfer program usually used under TCP/IP is FTP (File Transfer Protocol). An FTP host is installed as standard on the majority of UNIX systems.

If the TCP/IP services are installed, a terminal connection is possible using *Start - Programs - Accessories - Telnet* or a data transfer via FTP by means of *Start - Run ftp - OK*. Thus all computer systems supporting these universal protocols can be addressed (UNIX, VMS, etc.).

For further information, refer to the corresponding XP literature.

File Transfer via FTP

The total scope of functions and commands is described in the FTP literature. The following table therefore only contains the major functions:

Setting up the connection

- > Click *Start* and then *Run* in the task bar.
- > The DOS command `FTP` starts the program.
- > The command `OPEN <xx.xx.xx.xx>` sets up the connection. (xx.xx.xx.xx = IP address e.g. 89.0.0.13)

Data transfer

- The command `PUT <file name>` transfers the data to the target system.
- The command `GET <file name>` transfers the data from the target system.
- The command `TYPE B` transfers the data in BINARY format; no conversion takes place.
- The command `TYPE A` transfers the data in ASCII format, converting control characters so that text files can also be read on the target system.

Examples

```
PUT C:\AUTOEXEC.BAT
```

sends the file `AUTOEXEC.BAT` to the target system.

```
LCD DATA
```

changes the current directory on the local machine to subdirectory `DATA`

```
CD SETTING
```

changes to the subdirectory `SETTING` on the target system

file name = file name e.g. `DATA.TXT`

Changing the directories

- The command `LCD <path>` changes the directory on the local machine as with DOS.
- The command `LDIR` shows the directory contents on the local machine.

These commands refer to the file system of the R&S FSUP. If the “L” is omitted ahead of the commands, they apply to the target system.

RSIB Protocol

The instrument is equipped with an RSIB protocol as standard, which allows the instrument to be controlled by means of Visual C++ and Visual Basic programs, but also by means of the Windows applications WinWord and Excel as well as National Instruments LabView, LabWindows/CVI and Agilent VEE. The control applications run on an external computer in the network.

A UNIX operating system can be installed on an external computer in addition to a Windows operating system. In this case, the control applications are created either in C or C++. The supported UNIX operating systems include:

- Sun Solaris 2.6 Sparc Station
- Sun Solaris 2.6 Intel Platform
- Red Hat Linux 6.2 x86 Processors

Remote Control via RSIB Protocol

Windows Environment

To access the measuring instruments via the RSIB protocol, the file `RSIB32.DLL` must be copied to the Windows `system32` directory or to the directory of the control applications. For 16-bit applications, the file `RSIB.DLL` must be additionally copied to the directories mentioned. The files `RSIB.DLL` and `RSIB32.DLL` are included on the instrument in directory `D:\R_S\Instr\RSIB`.

For the different programming languages, there are files available that contain the declarations of the DLL functions and the definition of the error codes.

Visual Basic (16 bit): '`RSIB.BAS`' (`D:\R_S\Instr\RSIB`)

Visual Basic (32 bit): '`RSIB32.BAS`' (`D:\R_S\Instr\RSIB`)

C:/C++: '`RSIB.H`' (`D:\R_S\Instr\RSIB`)

For C/C++: programs, import libraries are additionally available.

Import library for `RSIB.DLL`: `RSIB.LIB`' (`D:\R_S\Instr\RSIB`)

Import library for `RSIB32.DLL`: `RSIB32.LIB`' (`D:\R_S\Instr\RSIB`)

The control is performed using the Visual C++ or Visual Basic programs WinWord, Excel, LabView, LabWindows/CVI or Agilent VEE. Every application that can load a DLL is able to use the RSIB protocol. The programs use the IP address of the instrument or its *host name* to set up the connection.

Via VisualBasic:

```
ud = RSDLLibfind ("82.1.1.200", ibsta, iberr, ibcntl)
```

Return to manual operation is possible via the front panel (*LOCAL* key) or via the RSIB protocol:

Via RSIB:

```
ud = RSDLLibloc (ud, ibsta, iberr, ibcntl);
```

or

```
ud = RSDLLibonl (ud, 0, ibsta, iberr, ibcntl);
```

UNIX Environment

To access the measuring equipment via the RSIB interface, copy the `librsib.so.X.Y` file to a directory for which the control application has read rights. `X.Y` in the file name indicates the version number of the library, for example `1.0`.

The `librsib.so.X.Y` library is created as a *shared library*. The applications using the library need not consider its version. They simply link the library with the `lrsib` option. The following instructions have to be observed so that linking can be successfully performed and the library can be found during program execution:

File link:

- Use the operating system command `ln` to create a file with the link name `librsib.so` and pointing to `librsib.so.X.Y` in a directory for which the control application has read rights. Example:

```
$ ln -s /usr/lib/librsib.so.1.0 /usr/lib/librsib.so
```

Linker options for creating applications:

- `-lrsib`: import library
- `-Lxxx`: path information where the import library can be found. This is where the above file link has been created. Example: `-L/usr/lib`.

Additional linker options for creating applications (only under Solaris):

- `-Rxxx`: path information where the library is searched for during the program run: `-R/usr/lib`.

Run-time environment:

- Set environment variable `LD_RUN_PATH` to the directory in which the file link has been created. This is necessary only if `librsib.so` cannot be found in the default search path of the operating system and the `-R` linker option (only Solaris) was not specified.

For C/C++ programming, the declarations of the library functions and the definition of error codes are contained in:

```
C/C++:          'RSIB.H'          (D:\R_S\Instr\RSIB)
```

RSIB Interface Functions

This section lists all functions of the DLL "RSIB.DLL" or "RSIB32.DLL" or "librsib.so", which allow control applications to be produced.

Overview of Interface Functions

The library functions are adapted to the interface functions of National Instruments for GPIB programming. The functions supported by the libraries are listed in the following table.

Function	Description
RSDLLibfind()	Provides a handle for access to a device.
RSDLLibwrt()	Sends a zero-terminated string to a device.
RSDLLilwrt()	Sends a certain number of bytes to a device.
RSDLLibwrtf()	Sends the contents of a file to a device.
RSDLLibrd()	Reads data from a device into a string.
RSDLLird()	Reads a certain number of bytes from a device.
RSDLLibrdf()	Reads data from a device into a file.
RSDLLibtmo()	Sets time-out for RSIB functions.
RSDLLibsre()	Switches a device to the local or remote state.
RSDLLibloc()	Temporarily switches a device to the local state.
RSDLLibeot()	Enables/disables the END message for write operations.
RSDLLibrsp()	Performs a serial poll and provides the status byte.
RSDLLibonl()	Sets the device online/offline.
RSDLLTestSRQ()	Checks whether a device has generated an SRQ.
RSDLLWaitSrq()	Waits until a device generates an SRQ.
RSDLLSwapBytes	Swaps the byte sequence for binary numeric display (only required for non-Intel platforms).

Variables `ibsta`, `iberr`, `ibcntl`

As with the National Instrument interface, the successful execution of a command can be checked by means of the variables `ibsta`, `iberr` and `ibcntl`. For this purpose, all RSIB functions are assigned references to these three variables.

Status word - `ibsta`

The status word `ibsta` provides information on the status of the RSIB interface. The following bits are defined:

Bit designation	Bit	Hex code	Description
ERR	15	8000	Is set when an error has occurred on calling a function. If this bit is set, <code>iberr</code> contains an error code that specifies the error in greater detail.
TIMO	14	4000	Is set when a time-out has occurred on calling a function.
CMPL	8	0100	Is set if the response of the GPIB parser has been read out completely. If a parser response is read out with the function <code>RSDLLi1rd()</code> and the length of the buffer is insufficient for the answer, the bit will be cleared.

Error variable - `iberr`

If the ERR bit (8000h) is set in the status word, `iberr` contains an error code which allows the error to be specified in greater detail. Extra error codes are defined for the RSIB protocol, independent of the National Instruments interface.

Error	Error code	Description
IBERR_CONNECT	2	Setup of the connection to the measuring instrument has failed.
IBERR_NO_DEVICE	3	A function of the interface has been called with an illegal device handle.
IBERR_MEM	4	No empty memory available.
IBERR_TIMEOUT	5	Time-out has occurred.
IBERR_BUSY	6	The RSIB protocol is blocked by a function that is still running.
IBERR_FILE	7	Error when reading or writing to a file.
IBERR_SEMA	8	Error upon creating or assigning a semaphore (only under UNIX).

Count variable - `ibcnt1`

The variable `ibcnt1` is updated with the number of transferred bytes each time a read or write function is called.

RSDLLilwrt

This function sends `Cnt` bytes to a device with the handle `ud`.

VB format: Function `RSDLLilwrt (ByVal ud%, ByVal Wrt$, ByVal Cnt&, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short WINAPI RSDLLilwrt(short ud, char far *Wrt, unsigned long Cnt, short far *ibsta, short far *iberr, unsigned long far *ibcntl)`

C format (UNIX): `short RSDLLilwrt(short ud, char *Wrt, unsigned long Cnt, short *ibsta, short *iberr, unsigned long *ibcntl)`

Parameters:

<code>ud</code>	Device handle
<code>Wrt</code>	String sent to the GPIB parser.
<code>Cnt</code>	Number of bytes sent to the device.

Example: `RSDLLilwrt (ud, '.....', 100, ibsta, iberr, ibcntl)`

Like `RSDLLibwrt()` this function sends data to a device. The only difference is that binary data can be sent as well. The length of the data is not determined by a zero-terminated string, but by the indication of `Cnt` bytes. If the data is to be terminated with EOS (0Ah), the EOS byte must be appended to the string.

RSDLLibwrtf

This function sends the contents of a `file$` file to the device with the handle `ud`.

VB format: Function `RSDLLibwrtf (ByVal ud%, ByVal file$, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short WINAPI RSDLLibwrtf(short ud, char far *Wrt, short far *ibsta, short far *iberr, unsigned long far *ibcntl)`

C format (UNIX): `short RSDLLibwrtf(short ud, char *Wrt, short *ibsta, short *iberr, unsigned long *ibcntl)`

Parameters:

<code>ud</code>	Device handle
<code>file</code>	File whose contents is sent to the device.

Example: `RSDLLibwrtf(ud, "C:\db.sav", ibsta, iberr, ibcntl)`

This function allows setting and query commands to be sent to the measuring instruments. Whether the data is interpreted as a complete command can be set using the function `RSDLLibeot()`.

RSDLLibrd()

The function reads data from the device with the handle `ud` into the string `Rd`.

VB format: Function RSDLLibrd (ByVal ud%, ByVal Rd\$,
 ibsta%, iberr%, ibcntl&) As Integer

C format: short WINAPI RSDLLibrd(short ud, char far
 *Rd, short far *ibsta, short far *iberr,
 unsigned long far *ibcntl)

C format (UNIX): short RSDLLibrd(short ud, char *Rd, short
 *ibsta, short *iberr, unsigned long *ibcntl
)

Parameters: ud Device handle
 Rd String to which the read data is copied.

Example: RSDLLibrd (ud, Rd, ibsta, iberr, ibcntl)

This function fetches the responses of the GPIB parser to a query.

In the case of Visual Basic programming, a string of sufficient length must be generated beforehand. This can be done during the definition of the string or using the command `Space$()`.

Generation of a string of the length 100:

```
- Dim Rd as String * 100
- Dim Rd as String
  Rd = Space$(100)
```

RSDLLilrd

This function reads `Cnt` bytes from the device with the handle `ud`.

VB format: Function RSDLLilrd (ByVal ud%, ByVal Rd\$,
 ByVal Cnt&, ibsta%, iberr%, ibcntl&) As
 Integer

C format: short WINAPI RSDLLilrd(short ud, char far
 *Rd, unsigned long Cnt, short far *ibsta,
 short far *iberr, unsigned long far *ibcntl
)

C format (UNIX): short RSDLLilrd(short ud, char *Rd,
 unsigned long Cnt, short *ibsta, short
 *iberr, unsigned long *ibcntl)

Parameters: ud Device handle
 cnt Maximum number of bytes copied from
 the DLL into the target string `Rd`.

Example: RSDLLilrd (ud, RD, 100, ibsta, iberr,
 ibcntl)

Like the function `RSDLLibrd()`, this function reads data from a device. The only difference is that in this case the maximum number of bytes to be copied to the target string `Rd` can be indicated by means of `Cnt`. This function prevents writing beyond the end of the string.

RSDLLibrdf()

Reads data from the device with the handle `ud` into the file `file` .

VB format: Function `RSDLLibrdf (ByVal ud%, ByVal file$, ibsta%, iberr%, ibcntl&) As Integer`

C format: `short WINAPI RSDLLibrd(short ud, char far *file, short far *ibsta, short far *iberr, unsigned long far *ibcntl)`

C format (UNIX): `short RSDLLibrd(short ud, char *file, short *ibsta, short *iberr, unsigned long *ibcntl)`

Parameters: `ud` Device handle
`file` File to which the read data is written.

Example: `RSDLLibrdf (ud, "c:\db.sav", ibsta, iberr, ibcntl)`

The file name may as well include a drive or path specification.

RSDLLibtmo

This function defines the time-out for a device. The default value for the time-out is set to 5 seconds.

VB format: Function `RSDLLibtmo (ByVal ud%, ByVal tmo%, ibsta%, iberr%, ibcntl&) As Integer`

C format: `void WINAPI RSDLLibtmo(short ud, short tmo, short far *ibsta, short far *iberr, unsigned long far *ibcntl)`

C format (UNIX): `short RSDLLibtmo(short ud, short tmo, short *ibsta, short *iberr, unsigned long *ibcntl)`

Parameters: `ud` Device handle
`tmo` Time-out in seconds

Example: `RSDLLibtmo (ud, 10, ibsta, iberr, ibcntl)`

RSDLLibsre

This function sets the device to the 'LOCAL' or 'REMOTE' state.

VB format: Function RSDLLibsre (ByVal ud%, ByVal v%,
 ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLibsre(short ud, short v,
 short far *ibsta, short far *iberr, unsigned
 long far *ibcntl)

C format (UNIX): short RSDLLibsre(short ud, short v, short
 *ibsta, short *iberr, unsigned long
 *ibcntl)

Parameters: ud Device handle
 v State of device
 0 - local
 1 - remote

Example: RSDLLibsre (ud, 0, ibsta, iberr, ibcntl)

RSDLLibloc

This function temporarily switches the device to the 'LOCAL' state.

VB format: Function RSDLLibloc (ByVal ud%, ibsta%,
 iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLibloc(short ud, short far
 *ibsta, short far *iberr, unsigned long far
 *ibcntl)

C format (UNIX): short RSDLLibloc(short ud, short *ibsta,
 short *iberr, unsigned long *ibcntl)

Parameter: ud Device handle

Example: RSDLLibloc (ud, ibsta, iberr, ibcntl)

After switch over to LOCAL state, the instrument can be manually operated via the front panel. On the next access to the instrument by means of one of the functions of the library, the instrument is switched again to the REMOTE state.

RSDLLibeot

This function enables or disables the END message after write operations.

VB format: Function RSDLLibeot (ByVal ud%, ByVal v%,
ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLibsre(short ud, short v,
short far *ibsta, short far *iberr, unsigned
long far *ibcntl)

C format (UNIX): short RSDLLibsre(short ud, short v, short
*ibsta, short *iberr, unsigned long
*ibcntl)

Parameters: ud Device handle
v 0 - no END message 1 – send END
message

Example: RSDLLibeot (ud, 1, ibsta, iberr, ibcntl)

If the END message is disabled, the data of a command can be sent with several successive calls of write functions. The END message must be enabled again before sending the last data block.

RSDLLibrsp

This function performs a serial poll and provides the status byte of the device.

VB format: Function RSDLLibrsp(ByVal ud%, spr%,
ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLibrsp(short ud, char far*
spr, short far *ibsta, short far *iberr,
unsigned long far *ibcntl)

C format (UNIX): short RSDLLibrsp(short ud, char *spr,
short *ibsta, short *iberr, unsigned long
*ibcntl)

Parameters: ud Device handle
spr Pointer to status byte

Example: RSDLLibrsp(ud, spr, ibsta, iberr, ibcntl)

RSDLLibonl

This function switches the device to 'online' or 'offline' mode. When it is switched to 'offline' mode, the interface is released and the device handle becomes invalid. By calling RSDLLibfind again, the communication is set up again.

VB format: Function RSDLLibonl (ByVal ud%, ByVal v%,
 ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLibonl(short ud, short v,
 short far *ibsta, short far *iberr,
 unsigned long far *ibcntl)

C format: short RSDLLibonl(short ud, short v, short
 *ibsta, short *iberr, unsigned long
 *ibcntl)

Parameters: ud Device handle
 v Device state
 0 - local
 1 - remote

Example: RSDLLibonl(ud, 0, ibsta, iberr, ibcntl)

RSDLLTestSRQ

This function checks the status of the SRQ bit.

VB format: Function RSDLLTestSrq (ByVal ud%, Result%,
 ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLTestSrq(short ud, short
 far *result, short far *ibsta, short far
 *iberr, unsigned long far *ibcntl)

C format (UNIX): short RSDLLTestSrq(short ud, short
 *result, short *ibsta, short *iberr,
 unsigned long *ibcntl)

Parameters: ud Device handle
 result Reference to an integer value in which
 the library returns the status of the
 SRQ bit
 0 - no SRQ
 1 - SRQ active, device requests
 service

Example: RSDLLTestSrq (ud, result%, ibsta, iberr,
 ibcntl)

This function corresponds to the function RSDLLWaitSrq. The only difference is that RSDLLTestSRQ immediately returns the current status of the SRQ bit, whereas RSDLLWaitSrq waits for an SRQ to occur.

RSDLLWaitSrq

This function waits until the device triggers an SRQ with the handle `ud`.

VB format: Function RSDLLWaitSrq (ByVal ud%, Result%,
ibsta%, iberr%, ibcntl&) As Integer

C format: void WINAPI RSDLLWaitSrq(short ud, short
far *result, short far *ibsta, short far
*iberr, unsigned long far *ibcntl)

C format (UNIX): short RSDLLWaitSrq(short ud, short
*result, short *ibsta, short *iberr,
unsigned long *ibcntl)

Parameters:

<code>ud</code>	Device handle
<code>result</code>	Reference to an integer value in which the library returns the status of the SRQ bit 0 - No SRQ occurred during the time- out 1 - SRQ occurred during the time-out

Example: RSDLLWaitSrq(ud, result, ibsta, iberr,
ibcntl);

The function waits until one of the following two events occurs.

- The measuring instrument triggers an SRQ.
- No SRQ occurs during the time-out defined with `RSDLLibtmo()`.

RSDLLSwapBytes

This function changes the display of binary numbers on non-Intel platforms.

VB format: Not provided at present since it is
required only on non-Intel platforms.

C format: void WINAPI RSDLLSwapBytes(void far
*pArray, const long size, const long count)

C format (UNIX): void RSDLLSwapBytes(void *pArray, const
long size, const long count)

Parameters:

<code>pArray</code>	Array in which modifications are made
<code>size</code>	Size of a single element in <code>pArray</code>
<code>count</code>	Number of elements in <code>pArray</code>

Example: RSDLLSwapBytes(Buffer, sizeof(float),
ibcntl/sizeof(float))

This function swaps the display of various elements from *Big Endian* to *Little Endian* and vice versa. It is expected that a coherent storage area of elements of the same file type (`size` byte) is transferred to `pArray`. This function has no effect on Intel platforms.

Different types of processor architecture store data in different byte sequences. For example, Intel processors store data in the reverse order of Motorola processors. Comparison of byte sequences:

Byte sequence	Use in	Display in memory	Description
Big Endian	Motorola processors, network standard	Most significant byte at least significant address	The <i>most significant</i> byte is at the left end of the word.
Little Endian	Intel processors	Least significant byte at least significant address	The <i>most significant</i> byte is at the right end of the word.

Programming via the RSIB Protocol

Visual Basic

Programming tips

Access to the functions of the RSIB.DLL

To create Visual Basic control applications, the file RSIB.BAS must be added to a project for 16-bit Basic programs and the file RSIB32.BAS for 32-bit Basic programs (D:\R_S\INSTR\RSIB) so that the functions of the RSIB.DLL or RSIB32.DLL can be accessed.

Generating a response buffer

Prior to calling the functions `RSDLLibrd()` and `RSDLLilrd()`, a string of sufficient length must be generated. This is possible either by defining the string or using the command `Space$()`.

Generating a string of the length 100:

```
- Dim Response as String * 100
- Dim Response as String
  Response = Space$(100)
```

If a response is to be output as a string from the measuring instrument, the appended blanks can be removed using the Visual Basic Function `RTrim()`.


Example:

```
Response = Space$(100)
Call RSDLLibrd(ud, Response, ibsta, iberr, ibcntl)
Response = RTrim(Response)
' Output of Response
```

Reading out trace data in real format

Using the function declarations in the file RSIB.BAS or RSIB32.BAS the responses of the device can be assigned to one string only. If the data are to be read into an array with float values, the header and the useful data must be read out with separate function calls.

Example of a header



In order to enable the trace data to be directly read into a float array, a special function declaration must be created.

```

Declare Function RSDLLilrdTraceReal Lib "rsib32.dll" Alias
"RSDLLilrd" (ByVal ud%, Rd As Single, ByVal Cnt%, ibsta%,
iberr%, ibcntl%) As Integer
  
```

Example

```

Dim ibsta As Integer          ' Status variable
Dim iberr As Integer         ' Error variable
Dim ibcntl As Long          ' Count variable
Dim ud As Integer           ' Handle for measuring instrument
Dim Result As String        ' Buffer for simple results
Dim Digits As Byte          ' Number of digits of length indication
Dim TraceBytes As Long      ' Length of trace data in bytes
Dim TraceData(625) As Single ' Buffer for floating point Binary data

' Set up connection to instrument
ud = RSDLLibfind("89.10.38.97", ibsta, iberr, ibcntl)

' Query trace data in real format
Call RSDLLibwrt(ud, "FORM:DATA REAL,32", ibsta, iberr, ibcntl)
Call RSDLLibwrt(ud, "TRACE? TRACE1", ibsta, iberr, ibcntl)

' Read number of digits of length indication
Result = Space$(20)
Call RSDLLilrd(ud, Result, 2, ibsta, iberr, ibcntl)
Digits = Val(Mid$(Result, 2, 1))

' Read length indication
Result = Space$(20)
Call RSDLLilrd(ud, Result, Digits, ibsta, iberr, ibcntl)
TraceBytes = Val(Left$(Result, Digits)) 'and store
  
```

```
' Read out trace data
Call RSDLLilrdTraceReal(ud, TraceData(0), TraceBytes, ibsta, iberr,ibcntl)
```

Programming examples

In this example, the start frequency of the instrument is queried.

```
Dim ibsta As Integer      ' Status variable
Dim iberr As Integer      ' Error variable
Dim ibcntl As Long       ' Count variable
Dim ud As Integer        ' Handle for measuring instrument
Dim Response As String   ' Response string

' Set up connection to measuring instrument
ud = RSDLLibfind("89.10.38.97", ibsta, iberr, ibcntl)
If (ud < 0) Then
    ' Error treatment
End If

' Send query command
Call RSDLLibwrt(ud, "FREQ:START?", ibsta, iberr, ibcntl)

' Provide space for response
Response = Space$(100)

' Read response from measuring instrument
Call RSDLLibrd(ud, Response, ibsta, iberr, ibcntl)
```

In this example, a Save/Recall of the instrument setups is performed.

```
Dim ibsta As Integer      ' Status variable
Dim iberr As Integer      ' Error variable
Dim ibcntl As Long       ' Count variable
Dim ud As Integer        ' Handle for measuring instrument
Dim Cmd As String        ' Command string

' Set up connection to measuring instrument
ud = RSDLLibfind("89.10.38.97", ibsta, iberr, ibcntl)
If (ud < 0) Then
    ' Error treatment
End If

' Request instrument settings
Cmd = "SYST:SET?"
Call RSDLLibwrt(ud, Cmd, ibsta, iberr, ibcntl)

' Store instrument response in file
Call RSDLLibrdf(ud, "C:\db.sav", ibsta, iberr, ibcntl)
```

```

' Reset instrument
Call RSDLLibwrt(ud, "*RST", ibsta, iberr, ibcntl)

' and restore the previous settings
' to this end disable the END message
Call RSDLLibeot(ud, 0, ibsta, iberr, ibcntl)
' first send off command
Call RSDLLibwrt(ud, "SYST:SET ", ibsta, iberr, ibcntl)
' enable the END message again
Call RSDLLibeot(ud, 1, ibsta, iberr, ibcntl)
' and send the data
Call RSDLLibwrtf(ud, "C:\db.sav", ibsta, iberr, ibcntl)

```

Visual Basic for Applications (Winword and Excel)

Programming tips

The programming language Visual Basic for Applications (VBA) is supported as a macro language by various manufacturers. The programs Winword and Excel use this language for the versions Winword 97 or Excel 5.0 and higher.

For macros created with Visual Basic for Applications, the same tips are valid as for Visual Basic Applications.

Programming example

Using the macro `QueryMaxPeak`, a single sweep with subsequent query of the maximum peak is performed. The result is entered in a Winword or Excel document.

```

Sub QueryMaxPeak()

    Dim ibsta As Integer    ' Status variable
    Dim iberr As Integer    ' Error variable
    Dim ibcntl As Long     ' transferred characters
    Dim ud As Integer      ' Unit Descriptor (handle) for instrument
    Dim Response As String ' Response string

    ' Set up connection to measuring instrument
    ud = RSDLLibfind("89.10.38.97", ibsta, iberr, ibcntl)
    If (ud < 0) Then
        Call MsgBox("Device with address 89.10.38.97 could" & _
            "not be found", vbExclamation)
    End
End If

    ' Determine maximum peak in the range 1-2MHZ
    Call RSDLLibwrt(ud, "*RST", ibsta, iberr, ibcntl)
    Call RSDLLibwrt(ud, "INST:SEL SAN", ibsta, iberr, ibcntl)
    Call RSDLLibwrt(ud, "INIT:CONT OFF", ibsta, iberr, ibcntl)

```



```

Call RSDLLibwrt(ud, "FREQ:START 1MHZ", ibsta, iberr, ibcntl)
Call RSDLLibwrt(ud, "FREQ:STOP 2MHZ", ibsta, iberr, ibcntl)
Call RSDLLibwrt(ud, "INIT:IMM;*WAI", ibsta, iberr, ibcntl)
Call RSDLLibwrt(ud, "CALC:MARK:MAX;Y?", ibsta, iberr, ibcntl)
Response = Space$(100)
Call RSDLLibrd(ud, Response, ibsta, iberr, ibcntl)
Response = RTrim(Response) ' Cut off space

' Insert value in current document (Winword)
Selection.InsertBefore (Response)
Selection.Collapse (wdCollapseEnd)

' Terminate connection to measuring instrument
Call RSDLLibonl(ud, 0, ibsta, iberr, ibcntl)

```

End Sub

The entry of the peak value in the Winword document can be replaced as follows for Excel:

```

' Insert value in current document (Excel)
ActiveCell.FormulaR1C1 = Response

```

C / C++

Programming tips

Access to the functions of the RSIB32.DLL (Windows platforms)

The functions of the `RSIB32.DLL` are declared in the header file `RSIB.H`. The DLL functions can be linked to a C/C++ program in different ways.

- Enter one of the supplied import libraries (`RSIB.LIB` or `RSIB32.LIB`) into the linker options.
- Load the library using the function `LoadLibrary()` during runtime and determine the function pointers of the DLL functions using `GetProcAddress()`. Before the end of the program, the `RSIB.DLL` must be unloaded again using the function `FreeLibrary()`.

When import libraries are used, the DLL is automatically loaded immediately before the application is started. At the end of the program, the DLL is unloaded again unless it is still used by other applications.

Access to `libsib.so` functions (UNIX platforms)

The functions of `libsib.so` are declared in the header file `RSIB.H`. Uppercase/lowercase characters for file names are typically observed under UNIX. The library functions are linked to a C/C++ program by entering the `-libsib` linker option.

The *shared library* `libsib.so` is automatically loaded on starting the application. The accessibility (for example via standard path) of the library must be ensured. Refer to section [“UNIX Environment” on page 4.300](#).

Query of strings

If instrument responses are to be further processed as strings, a zero termination must be appended.

Example

```
char buffer[100];
...
RSDLLibrd( ud, buffer, &ibsta, &iberr, &ibcntl );
buffer[ibcntl] = 0;
```

Programming example

In the following C program example, a single sweep is started on the device with the IP address 89.10.38.97 and subsequently a marker is set to maximum level. Prior to the search for maximum, a synchronization to the end of the sweep is performed. For this purpose the command "*OPC" (Operation complete) is used to create a service request at the end of the sweep, for which the control program waits with the function RSDLLWaitSrq(). Then the maximum is determined ("CALC:MARK:MAX") and the level read out ("Y?").

```
#define MAX_RESP_LEN 100

short      ibsta, iberr;
unsigned long  ibcntl;
short      ud;
short      srq;
char      MaxPegel[MAX_RESP_LEN];
char      spr;

// Determine handle for instrument
ud = RSDLLibfind( "89.10.38.97", &ibsta, &iberr, &ibcntl );

// if instrument exists
if ( ud >= 0 )
{
    // Set timeout for RSDLLWaitSrq() to 10 seconds
    RSDLLibtmo( ud, 10, &ibsta, &iberr, &ibcntl );

    // Activate SRQ generation via event status register (ESR)
    // and enable ESB bit in SRE register
    RSDLLibwrt( ud, "*ESE 1;*SRE 32", &ibsta, &iberr, &ibcntl );

    // Set single sweep, trigger sweep and use "*OPC" to cause
    // the generation of a service request at the end of the sweep
    RSDLLibwrt( ud, "INIT:CONT off;INIT;*OPC", &ibsta, &iberr, &ibcntl );

    // Wait for SRQ (end of sweep)
    RSDLLWaitSrq( ud, &srq, &ibsta, &iberr, &ibcntl );
```

```
// Clear RQS/MSS bit
RSDLLibrsp( ud, &spr, &ibsta, &iberr, &ibcntl );

// if sweep is terminated
if (srq)
{
    // then set marker to first maximum and query the level
    RSDLLibwrt( ud, "CALC:MARK:MAX;Y?", &ibsta, &iberr, &ibcntl );
    RSDLLilrd( ud, MaxPegel, MAX_RESP_LEN, &ibsta, &iberr, &ibcntl );
    MaxPegel[ibcntl] = 0;
}
// End connection to instrument
RSDLLibonl (ud, 0, &ibsta, &iberr, &ibcntl ) ;
}
else
{
    ; // Error Instrument not found
}
}
```

LO/IF ports for external mixers - Option R&S FSU-B21

Connecting an External Mixer

To increase the frequency range, the FSUP 26/50 can be operated with external mixers.

Both two-port and three-port mixers can be used. Connect mixer as follows:



Note

Use the coaxial cable supplied to feed in the LO signal.

If no external mixers are connected to the R&S FSUP, cover the two front connectors 'LO OUT / IF IN' and 'IF IN' with the SMA caps supplied.

To activate the operation mode, press softkey *EXTERNAL MIXER* in the frequency menu.

Three-port mixer:

- > Connect the 'LO OUT / IF IN' output of the R&S FSUP to the LO port of the external mixer.
- > Connect the 'IF IN' input of the R&S FSUP to the IF port of the external mixer.
- > Feed the signal to be measured to the RF input of the external mixer.

Two-port mixer:

- > Connect the 'LO OUT / IF IN' output of the R&S FSUP to the LO/IF port of the external mixer. The nominal LO level is 15.5 dBm.

Because of the diplexer contained in the R&S FSUP the IF signal can be tapped from the line which is used to feed the LO signal to the mixer.

- > Feed the signal to be measured to the RF input of the external mixer.

Manual Operation

The *FREQ* hardkey opens the menu for selecting the frequency and the frequency range (details see “[Frequency and Span Selection – FREQ Key](#)” on page 4.85) extended by the following functions for external mixing:

FREQ

EXTERNAL MIXER ↓	EXT MIXER ON/OFF		
	SELECT BAND		
	CONV LOSS TABLE ↓	EDIT TABLE / NEW TABLE ↓	INSERT LINE
			DELETE LINE
			SAVE TABLE
			PAGE UP / PAGE DOWN
		LOAD TABLE ↓	PAGE UP / PAGE DOWN
		DELETE TABLE	
		COPY TABLE	
		PAGE UP / PAGE DOWN	
	ACCEPT BIAS		
	LO LEVEL		
	SIGNAL ID / AUTO ID / AUTO ID THRESHOLD		

Frequency range

The frequency of the input signal can be expressed as a function of the LO frequency and the selected harmonic of the 1st LO as follows:

$$f_{in} = n * f_{LO} + f_{IF}$$

where:

- f_{in} frequency of input signal
- n order of harmonic used for conversion
- f_{LO} frequency of 1st LO 7...15.5 GHz
- f_{IF} intermediate frequency 404.4 MHz



Note

The LO frequency range cannot be used to the full due to the signal identification functions (*SIGNAL ID* and *AUTO ID*, see section “[Signal Identification](#)” on page 4.331)

Full-screen level

The maximum reference level to be set is 0 dBm. If an IF signal with a level of -20 dBm is applied to the LO OUT / IF IN or IF IN input of the R&S FSUP, full screen level will be attained.

When digital filters are used (IF bandwidths = 100 kHz) the overload limit is typically approx. 3 dB above the set reference level. IF signals with higher levels cause the A/D converter to be overloaded (display 'IFOVL').

If an analog IF filter is used, the overload limit is determined by the IF amplifier. In this case, the 1 dB compression point is approximately 6 dB above the reference level. Overload display 'OVL' appears at higher levels.

In addition to the dynamic range of the R&S FSUP, the 1 dB compression point of the mixer has to be taken into account. The levels of the input signals should lie well below this value to avoid generation of harmonics of these signals in the mixer. These are converted by the LO signals harmonics of higher order and appear in the displayed spectrum.

EXTERNAL MIXER

The *EXTERNAL MIXER* softkey opens a submenu for setting the parameters of the external mixer. The softkey automatically switches on the external mixer.

EXT MIXER ON/OFF

External mixing is switched on or off by the *EXT MIXER ON/OFF* softkey.

Remote command: MIX ON

SELECT BAND

The *SELECT BAND* softkey opens a submenu for selecting the waveguide band and the harmonic to be used and for setting all necessary parameters. The configuration can be stored using the function *SAVE* of *FILE* menu.

Remote command: --

When the table *SELECT BAND* is open and you press *Enter* in a *BIAS* field the table is automatically closed. When the *BIAS* value is now changed the immediately effect on the measurement trace can be seen.

The table contains the following parameters for each band:

BAND - Designation of waveguide band

Remote command: MIX:HARM:BAND E

RANGE - Frequency range

The frequency range of the waveguide band or the frequency range which is covered by the selected harmonic is shown in this field.

Remote command: --

HARMONIC# - Order of harmonic

Order of harmonic used for conversion The order is selected automatically depending on the definition made in the *EVEN / ODD HARMONICS* column. The lowest order is selected that allows conversion of input signals in the whole band.

If due to LO frequency the conversion is not possible using one harmonic, the band is splitted. Frequency range and order of harmonic of the resulting parts are shown within the field.

Within the band *USER* the order of harmonic is defined by the user. The resulting frequency range will be automatically entered into the field *RANGE*. The order of harmonic can be between 2 and 64, the lowest usable frequency being 26,5 GHz.

Remote command: MIX:HARM 5

EVEN/ODD HARMONICS - Designation of harmonic to be used

Defines if only even, only odd, or even and odd harmonics can be used for conversion.

EVEN/ODD	
	EVEN
√	ODD
	EVEN&ODD

Depending on what has been selected within this field the order of harmonic to be used for conversion will change (shown in the field *HARMONIC#*).

Within the band *USER* this field is not editable.

Remote command: MIX:HARM:TYPE EODD

PORTS - Type of mixer

Defines if a two- or three-port mixer is used.

PORTS	
√	2
	3

Remote command: MIX:PORT 3

BIAS - Bias current

The bias current can range from -10 mA to 10 mA.

The current corresponds to the short-circuit current. The actual bias current is lower because of the forward voltage of the mixer diode(s).

If *CONV LOSS TABLE* is activated, changes of the bias current are temporary only, i.e. the bias current will not be changed within the file selected in *CONV LOSS TABLE*. To store the changes press *ACCEPT BIAS* softkey. (See section [“Bias Current” on page 4.323.](#))

Remote command: MIX:BIAS 7mA

AVG CONV LOSS - Average of conversion loss of the external mixer


Remote command: MIX:LOSS -12DB

CONV LOSS TABLE - Conversion loss depending on frequency

Alternatively to the average value stated under *AVG CONV LOSS*, conversion loss can be taken into account as a function of frequency. The *CONV LOSS TABLE* field gives the name (without extension) of a binary file stored on the hard disk. The file contains the following data of the associated mixer:

- type designation of mixer
- serial No. of mixer
- waveguide band
- frequency range
- order of harmonic
- number of ports (2 / 3)
- bias current
- conversion loss as a function of frequency

Within an edit box the tables suited for the band can be selected. Only those tables are allowed that cover the whole frequency range and correspond to the harmonic used.



After selection of a file the parameters *BIAS* for the *SELECT BAND* table are taken from that file. The selected mixer type must correspond to the file entry *PORTS*. It is not possible to modify these parameters during operation.

Only that part of the table is taken into account that contains reference values for frequencies that are covered by the selected order of harmonic. (See section [“Conversion Loss Tables” on page 4.324](#))

Remote command: MIX:LOSS:TABL mix_1_4

CONV LOSS TABL The *CONV LOSS TABLE* softkey opens a submenu for selecting and editing of conversion loss tables. (See section [“Conversion Loss Tables” on page 4.324](#))

Remote command: --

ACCEPT BIAS The *ACCEPT BIAS* softkey stores the bias setting selected in the table *SELECT BAND* in the file specified in the table.

The user is prompted to confirm the storage. The new setting will be stored only when confirmed with *YES*.

This softkey can only be used if *CONV LOSS TABLE* (conversion loss taken into account by means of frequency-dependent values) is active.

Remote command: --

LO LEVEL The softkey *LO LEVEL* changes the LO level of the external mixer LO port from 13.0 dBm to 17.0 dBm in 0.1 dB steps. Default value is 15.5 dB.

Remote command: [SENSe1:]MIXer:LOPower 16.0dBm

**SIGNAL ID /
AUTO ID /
AUTO ID
THRESHOLD** The *SIGNAL ID*, *AUTO ID* and *AUTO ID THRESHOLD* softkeys are used for signal identification.

Remote command: MIX:SIGN ON

See section [“Signal Identification” on page 4.331](#).

Bias Current

Single-diode mixers generally require a DC voltage which is applied via the LO line. This DC voltage is to be tuned to the minimum conversion loss versus frequency.

Such a DC voltage can be set via the *BIAS* function using the D/A converter of the R&S FSUP. The value to be entered is not the voltage but the short-circuit current.

The current is defined in the *SELECT BAND* table or set to the value of the Conversion Loss table.




Fig. 4-38 Bias circuit of the R&S FSUP

The voltage U_0 at the output of the operational amplifier can be set in the range -2.0 to $+2.0$ V. An open-circuit voltage V_{bias} of -0.5 to $+0.5$ V is obtained accordingly at the output of the voltage divider. A short-circuit current of $I_{short} = V_0 / 200 \Omega = -10$ mA to $+10$ mA is obtained for a short circuit at the output of the voltage divider. For using biasing it is not important to know exactly the current flowing through the diode since the conversion loss must be set to minimum with the frequency. It therefore makes no difference whether the setting is performed by an open-circuit voltage or by a short-circuit current.

A DC return path is ensured via the 66Ω resistor, which is an advantage in some mixers.

Conversion Loss Tables

Conversion loss tables allow the conversion loss of the mixer to be taken into account as a function of frequency.

CONV LOSS TABLE

EDIT TABLE / NEW TABLE ↓	INSERT LINE
	DELETE LINE
	SAVE TABLE
	PAGE UP / PAGE DOWN
LOAD TABLE ↓	PAGE UP / PAGE DOWN
DELETE TABLE	
COPY TABLE	
PAGE UP / PAGE DOWN	

The *CONV LOSS TABLE* softkey opens a submenu for selecting and editing of conversion loss tables. A list box containing all tables currently available opens by pressing the softkey.

Remote command: --

PREVIEW			
Name:	RS_Band_U_4	Mixer:	FS_Z60
Band:	U	S/N:	12345678
Harmonic#:	4	Ports:	2
Bias:	0.00 mA		
Comment:			
Freq. range:	40.000 GHz to 60.000 GHz		

TABLES	
Band_A_2	↑
Band_A_4	█
Band_Q_4	
RS_Band_U_4	
Band_W_8	
Press ENTER to edit table	
	↓

The *PREVIEW* window shows the information characterizing the marked file:


- Name* name of marked file
- Mixer* type of mixer
- Band* waveguide band
- S/N* serial No. of mixer
- Harmonic#* order of harmonic used for conversion
- Ports* type of mixer (two or three port mixer)
- Bias* bias current
- Comment* comment
- Freq range* frequency range

The *TABLES* table lists the files stored on the hard disk.

EDIT TABLE / NEW TABLE The *EDIT TABLE* or *NEW TABLE* softkey activates a submenu for editing or generating a file (see following section “[Editing a Table](#)” on page 4.327).

Remote command: CORR:CVL:SEL 'LOSS_T_4'

LOAD TABLE The *LOAD TABLE* softkey opens a submenu with a table *TABLES ON DISK* specifying all files stored on the inserted disk with mixer correction data (.ACL extension). The file selected is copied onto the hard disk.



Remote command: --

This function is needed, for example, for the initial loading of correction data of a new mixer from the supplied diskette to the hard disk of the R&S FSUP.

The correction data are stored in ASCII format.

Example

```
# Mixer Name
R&S FS-Z60
# Serial Number
832439/001
# Band
U
# Number of Harmonic
4
# Bias
0.0
# Ports
2
#Comment
R&S FS-Z60 (40..60 GHz) .
# Date
21.02.2003
# Calibration data
(40000000000, 17.49)
(40410000000, 17.5755102)
(40820000000, 17.56102041)
...
...
...
(58780000000, 19.86081633)
(59180000000, 20.08387755)
(59590000000, 19.91693878)
(60000000000, 19.95)
```

DELETE TABLE The *DELETE TABLE* softkey deletes the selected file from the hard disk of the R&S FSUP.

If the key is pressed, a window opens in which the user is prompted to confirm or abort deleting.

Remote command: CORR:CVL:CLE

COPY TABLE The *COPY TABLE* softkey copies the selected table. The table is stored under another name and can be edited later on.

Remote command: --

Editing a Table

EDIT TABLE /
NEW TABLE

INSERT LINE
DELETE LINE
SAVE TABLE
PAGE UP / PAGE DOWN

The *EDIT TABLE* or *NEW TABLE* softkey activates a submenu in which all entries of an existing table can be modified or in which a new table can be generated

Remote command: --

The table either contains data of the mixer selected or no data at all.

EDIT CONVERSION LOSS TABLE			
Name:	RS_Band_U_4	Mixer:	FS_Z60
Band:	U	S/N:	12345678
Harmonic#:	4	Ports:	2
Bias:	0.00 mA		
Comment:			
	FREQUENCY	CONV LOSS /dB	↑
	40.000 GHz	20.5	
	41.000 GHz	20.8	
	42.000 GHz	20.9	
	43.000 GHz	21.1	
	44.000 GHz	21.4	
	45.000 GHz	21.7	
	46.000 GHz	22.2	
	47.000 GHz	22.7	
	48.000 GHz	23.1	
	49.000 GHz	23.3	
	50.000 GHz	23.7	
	51.000 GHz	24.0	
	52.000 GHz	24.5	
	53.000 GHz	24.8	
	54.000 GHz	25.4	
	55.000 GHz	25.8	
	56.000 GHz	26.2	
	57.000 GHz	26.6	
	58.000 GHz	26.8	↓

Data and type designation of the mixer can be entered into the header of the table. The columns contain the frequencies and the corresponding conversion losses.

Name - File name

The name of the table is identical with the name of the file (without extension) in which the table is stored. The entry in this field is mandatory. The name may consist of a maximum of 10 characters and ends with the harmonic used, e.g. Mixer_2. The .ACL extension will automatically be appended at storing.

Remote command: CORR:CVL:SEL 'LOSS_T_4'

Mixer - Type designation of mixer

The information in the Mixer field shows the user at a glance to which mixer a file belongs. Entries in this field are optional.

Remote command: CORR:CVL:MIX 'FS_Z60'

Band - Designation of waveguide band

A waveguide band can be selected from a list. This field is mandatory.

Remote command: CORR:CVL:BAND E

S/N - Serial number

Serial number of the mixer. Entries in this field are optional.

Remote command: CORR:CVL:SNUM '123.4567'

Harmonic# - Order of harmonic

Order of harmonic used for conversion. For the conversion loss is valid for one harmonic only, entries in this field are mandatory.

Remote command: CORR:CVL:HARM 4

Ports - Two- or three-port mixer

A list is displayed from which the number of ports (two or three) of the mixer used can be selected. The entry in this field is mandatory.

Remote command: CORR:CVL:PORT 3

Bias - Bias setting

The bias current required for the mixer has to be entered in this field. The setting range is between -10 mA and +10 mA.

The entry in this field is mandatory.

**Note**

The current corresponds to the short-circuit current. The actual bias current is lower because of the forward voltage of the mixer diode(s).

Remote command: CORR:CVL:BIAS 7mA

See section [“Bias Current” on page 4.323](#).

Comment

The comment can be freely defined by the user. It may consist of a maximum of 60 characters. This field need not necessarily to be filled in.

Remote command: CORR:CVL:COMMENT 'MIXER FOR BAND U'


FREQUENCY/CONV LOSS - Conversion loss table

The reference values must be entered in order of increasing frequencies. A maximum of 50 reference values can be entered.

Correction values for frequencies between the reference values are obtained by interpolation. Linear interpolation is performed if the table contains only two values. If it contains more than two reference values, spline interpolation is carried out.

Outside the frequency range covered by the table the conversion loss is assumed to be the same (see illustration below) as that for the first and last reference value.

Remote command: CORR:CVL:DATA 1MHZ,-30DB,2MHZ,-40DB



INSERT LINE The *INSERT LINE* softkey inserts a blank line at the cursor position. Subsequent entries are shifted downwards by one line.

Remote command: --

DELETE LINE The *DELETE LINE* softkey deletes the marked line in the reference value table.

Remote command: --

SAVE TABLE The *SAVE TABLE* softkey stores the edited table on the hard disk under the name given in the field *NAME*. The *.ACL* extension is automatically appended to the file name.

Remote command: --

PAGE UP / PAGE DOWN The *PAGE UP / PAGE DOWN* softkeys allow to scroll through the selection list.

Remote command: --

With the *PREV* hardkey, an edited table can be accepted, checked for consistency with permissible values and stored on the hard disk under the specified table name.

The user has to confirm whether he wants to store the table (*YES*) or not (*NO*) or whether storage is to be aborted (*CANCEL*). After storage has been aborted, the table comes up again and the user can continue editing.

When the file is stored, an extension is added automatically.

If the name of the table to be stored is already used by another file, the user is asked if the old table is to be overwritten. If the user does not wish to overwrite the old file, he can further edit the new table, e.g. assign it a new name not used so far.

Upon exiting the *EDIT* menu, the table can be activated from the relevant selection list.

Signal Identification


In the *EXTERNAL MIXER* submenu (see section “[EXTERNAL MIXER](#)” on page 4.320), the *SIGNAL ID* and *AUTO ID* softkeys activate the functions for setting the signal identification.

Remote command: MIX:SIGN ON

SIGNAL ID

The *SIGNAL ID* softkey activates or deactivates visual signal identification.

Two sweeps are performed alternately. Trace 1 shows the test sweep, trace 2 shows the reference sweep. Trace 3 is not available.



The reference sweep is performed using a LO setting shifted downwards by $2 \cdot \text{IF} / \text{Harmonic\#}$. Input signals in the wanted sideband that are converted by means of the set harmonic are displayed in both traces at the same position on the frequency axis. Image signals and mixer products caused by other harmonics are displayed in both traces at different positions.

The user identifies the signals visually by comparing the two traces.

Since the LO frequency is displaced downwards in the reference sweep, the conversion loss of the mixer may differ from the test sweep.

Therefore the level should only be measured in the test sweep (trace 1).

Mathematical functions with traces and trace copy cannot be used in the *SIGNAL ID* menu.

AUTO ID

The *AUTO ID* softkey activates or deactivates automatic signal identification.

AUTO ID basically functions like *SIGNAL ID*. However, the test and reference sweeps are converted into a single trace by a comparison of maximum peak values of each sweep point. The result of this comparison is displayed in trace 3 if *SIGNAL ID* is active at the same time. If *SIGNAL ID* is not active, the result can be displayed in each of the traces 1 to 3. Unwanted mixer products are suppressed in this calculated trace.

As described for the function *SIGNAL ID*, real input signals are displayed at the same frequency in the test and reference sweeps, i.e. theoretically identical signal levels are expected in the two sweeps at the frequency of the real mixer product. If the level difference is lower than the tolerance set with *AUTO ID THRESHOLD*, the signal obtained in the test sweep is displayed.

If a signal occurs only in the test sweep or reference sweep, it is an unwanted mixer product. The level of this signal is compared to the noise floor in the other sweep. If the S/N ratio is sufficiently large, the tolerance limit for the maximum permissible level difference is exceeded. This means that the signal with the lower level, i.e. noise in this case, is displayed.

It should be noted that *AUTO ID* functions according to the fail-safe principle, i.e. unwanted mixer products may not be detected as such but signals which are in fact real input signals are not blanked out. See also [“Remarks Concerning Signal Identification with *AUTO ID*” on page 4.332](#).

**AUTO ID
THRESHOLD**

AUTO ID THRESHOLD allows the maximum permissible level difference to be fixed between test sweep and reference sweep during automatic comparison (function *AUTO ID*). The input range is between 0.1 dB and 100 dB.

Values of about 10 dB (i.e. default setting) generally yield satisfactory results.

See also [“Remarks Concerning Signal Identification with *AUTO ID*” on page 4.332](#).

**Remarks Concerning Signal Identification with
*AUTO ID*****Type of signal**

The automatic comparison of the test sweep and reference sweep with *AUTO ID* can only be usefully applied for signals with time-constant spectrum since the two sweeps are always required to determine the actual spectrum.

Tolerance for the comparison of test sweep and reference

Since the LO frequency is displaced downwards in the reference sweep, the conversion loss of the mixer may differ from that of the test sweep. The reasons for this are the LO output power of the R&S FSUP varying with the frequency and the non-ideal characteristics of the mixer. A certain tolerance should therefore be permitted for the comparison of the signal levels in the test sweep and reference sweep. The user can set this tolerance using the function *AUTO ID THRESHOLD*.

If the tolerance set is too tight the signal collected with the reference sweep may be displayed even for the identification of real signals.

Example

A signal with a frequency of 52.5 GHz is applied to the mixer input. Let the signal level be -30 dBm. The conversion loss of the mixer is 28 dB at this frequency in the test sweep and 35 dB in the reference sweep. The user has entered a tolerance of 5 dB and a conversion loss of 28 dB. Thus, the signal is recorded with the correct level of -30 dBm in the test sweep, a signal level of -37 dBm is obtained in the reference sweep. As the difference (7 dB) between the levels is >5 dB, the signal with the lower level is displayed, i.e. the signal of the reference sweep. Since the set conversion loss is adapted to the test sweep, the signal displayed on the R&S FSUP has a level of -37 dBm yielding incorrect level display.

The tolerance entered corresponds to the minimum S/N ratio which signals should have to ensure correct identification. If the S/N ratio of a mixer product is less than the tolerance, the decision criterion is fulfilled even if only the noise floor is recorded in the reference sweep at the frequency of this mixer product. Unwanted mixer products are therefore not detected as such by *AUTO ID*. They can only be identified by a visual comparison of the two traces using the function *SIGNAL ID*.

In order to avoid the visual identification of such unwanted mixer products it is useful to perform the measurement test in two steps:

In the first step the tolerance is set to the minimum value (0.1 dB). This enables unwanted mixer products with low S/N ratio to be detected and blanked out.

- [**FREQUENCY** : EXTERNAL MIXER : AUTO ID]

- [**FREQUENCY** : EXTERNAL MIXER : AUTO ID THRESHOLD : **0.1 dB**]

To determine the signal levels of real input signals the tolerance is to be set to the minimum value, e.g. 10 dB, in the second step.

- [**FREQUENCY** : EXTERNAL MIXER : AUTO ID THRESHOLD : **10 dB**]

The real input signals are then displayed with the correct level.

Mixer products with low S/N ratio

If the S/N ratio of a mixer product is less than the tolerance set with *AUTO ID THRESHOLD*, the level difference between the test sweep and reference sweep at the frequency of this mixer product is always within limits, even if the signal occurs in one of the sweeps only. Such mixer products cannot be identified by *AUTO ID*. It is therefore recommended to perform a visual comparison of the test sweep and reference sweep using the function *SIGNAL ID*.

An unwanted signal having a S/N ratio corresponding approximately to the tolerance set with *AUTO ID THRESHOLD* may not be blanked out permanently. Due to the fact that the noise display varies from one sweep to another, the S/N ratio changes and thus the level difference between the test sweep and reference sweep measured at a frequency too. As a result, the criterion for detecting unwanted signals is not fulfilled. To blank out unwanted signals permanently an almost constant noise indication is therefore required. This can be achieved by reducing the video bandwidth. Since the average noise indication lies well below the generated noise peak values, the minimum level diminishes. For identification using *AUTO ID* signals should have this minimum level.

Examining unwanted mixer products with small span

With large spans in which non-modulated sinewave signals are represented as single lines, unwanted mixer products are generally completely blanked out. If the user, however, examines closer the frequency range containing a blanked signal using a small span, e.g. an image-frequency response, the spectrum represented in Fig. 4-39 is obtained.




Fig. 4-39 Components of a mixer product blanked out with *AUTO ID*

There are components of a blanked signal the level difference of which is smaller than the tolerance predefined with *AUTO ID THRESHOLD* as compared with the noise floor. These components are therefore not blanked out. The tolerance chosen was 10 dB in this example which can be seen at the level difference between marker and delta marker (display 'Delta 2 [T1]').

Using *AUTO ID* with large spans

As already described, the comparison of maximum peak values of test and reference sweep is performed for each sweep point. A trace comprises yyy...10000 sweep values the number of which is reduced to build the 625 pixels. Each pixel contains the maximum value of the sweep points it consist of. Therefore a pixel can contain information of a number of frequency steps.

As already described, the comparison of maximum peak values of test and reference sweep is performed for each sweep point. A trace comprises yyy...10000 sweep values the number of which is reduced to build the 625 pixels. Each pixel contains the maximum value of the sweep points it consist of. Therefore a pixel can contain information of a number of frequency steps.

If unwanted mixer products represented at frequencies which slightly differ from each other occur in the test sweep and reference sweep, the two mixer products from the test sweep and the reference sweep are displayed by the same sweep point. They will not be detected as unwanted mixer products by *AUTO ID* and therefore not be blanked out. Illustration of this follows:




Fig. 4-40 Screen A: Unwanted mixer product not detected by *AUTO ID*
Screen B: Unwanted mixer product not detected by *AUTO ID* and examined with a small span using *SIGNAL ID*

An input signal consisting of a large number of spectral components is shown in Fig. 4-40, screen A. Unwanted mixer products are blanked out with *AUTO ID*. If a signal identified as real is examined at approx. 29.615 GHz (see marker in Fig. 4-40) with a reduced span using *SIGNAL ID* (see Fig. 4-40, screen B), it can be seen that the mixer products represented in the test sweep and reference sweep differ by approx. 16.5 MHz in their frequency. For the span of 13.4 GHz set in Fig. 4-40, screen A, a frequency range of 21,4 MHz is displayed by one sweep point (selection 625 sweep points).

Very small spans should therefore be selected to ensure correct signal identification by means of *AUTO ID*.

Display of mixer products at the same frequency

If the input signal consists of a very large number of spectral components, it will become more and more probable that two different unwanted mixer products will be displayed at the same frequency in the test sweep and reference sweep. Such a case is shown in Fig. 4-41.




Fig. 4-41 Different mixer products represented at the same frequency in the test sweep and reference sweep

The external mixer has been working using 2nd order harmonic. The signal recorded in the test sweep is displayed by trace 1. The IF filter of the R&S FSUP is represented at a 3 dB bandwidth of 20 kHz, the real IF bandwidth being 30 kHz. If, however, the 3 dB bandwidth (trace 2) of the signal recorded in the reference sweep is examined, it will be found to be larger exactly by a factor of 2. This shows that the two products were generated by mixing with LO harmonics of different orders

The signal recorded in the test sweep was generated by mixing with 3rd order harmonic. Since the frequency axis scaling is based on the 2nd order, the mixer product or the resulting diagram of the IF filter is compressed by a factor of 2/3.

The signal recorded in the reference sweep was generated by mixing with the fundamental of the LO signal. Since the frequency axis scaling is based on the 2nd order, the mixer product or the resulting diagram of the IF filter is expanded by a factor of 2.

Automatic identification with a large span is not possible since the two mixer products are displayed at the same frequency. The diagram shown in Fig. 4-42 is obtained when examining products with a narrow span using *AUTO ID*. The user can easily recognize unwanted mixer products from the clear diagram obtained using *AUTO ID* or *SIGNAL ID*.




Fig. 4-42 Signal as in Fig. 4-40, but with the use of *AUTO ID*

Introductory Example of Operation

The following example serves to explain the operation of external mixers as well as the required settings:

A sine wave signal with $f = 14.5$ GHz is applied to the input of a multiplier. The spectrum at the multiplier output is to be recorded in the range of 52 to 60 GHz using a 2-port mixer for the V band. The mixer used is a double-diode mixer.



Note

Conventions for setting the analyzer during measurement:

- [<KEY>] Press a key on the front panel, e.g. [**FREQUENCY**]
- [<SOFTKEY>] Press a softkey, e.g. [**EXTERNAL MIXER**]
- [<nn unit>] Enter a value and terminate by entering the unit, e.g. [**1 MHz**]

Successive entries are separated by [:], e.g. [**FREQUENCY: EXTERNAL MIXER : SELECT BAND**].

The example of operation is described in the following steps:

1. [Test setup](#)
2. [Activating the external mixing and selecting the mode](#)
3. [Default setting](#)
4. [Level correction](#)
5. [Frequency-dependent level correction](#)
6. [Level correction with average value](#)
7. [Taking into account the cable loss in the IF path](#)
8. [Functions for signal identification](#)

1. Test setup

- Connect the 'LO OUT / IF IN' output of the R&S FSUP to the LO/IF port of the external mixer.
- Connect the multiplier to the external mixer.
- Apply a sinewave signal with $f = 14.5$ GHz to the input of the multiplier.

2. Activating the external mixing and selecting the mode

- Activate the external mixing with [**FREQUENCY : EXTERNAL MIXER**]

3. Default setting

- Prior to the measurement select the required band (in this case the V band) with
[**FREQUENCY** : EXTERNAL MIXER : SELECT BAND]
- Select the V band using the cursor keys and ENTER

4. Level correction

The conversion loss of the mixer can be taken into account both as a function of frequency and with an average value. The frequency-dependent level correction is used in this example for obtaining a higher precision. First select a table valid for the selected band. As an alternative, level correction based on average value can be used (see [“Level correction with average value” on page 4.340](#)).

5. Frequency-dependent level correction

- Activate a selection list which contains all tables stored on the hard disk of the R&S FSUP with
[**FREQUENCY** : EXTERNAL MIXER : SELECT BAND]
- Select the *CONV LOSS TABLE* field by means of the cursor keys.
- If a file with correction data already exists for the mixer used, select a table valid with the cursor keys or the rotary knob and confirm with *ENTER*.

- If such a table is not yet available, create a new table with
[CONV LOSS TABLE : EDIT TABLE]

or copy from a disk to the hard disk of the R&S FSUP with
[CONV LOSS TABLE : LOAD TABLE]

(See section [“Conversion Loss Tables” on page 4.324](#))

and select the file created or loaded from a disk in the selection list as described before.

A selected file is marked by \surd and will be drawn into the table SELECT BAND.

No further settings are necessary since the selected file contains all required parameters.

- Quit the *SELECT BAND* menu using
[**ESC**] key

A span is automatically set which covers the whole V band (50 to 75 GHz).

- Set the frequency range to be examined using
[**FREQUENCY START** : 52 GHz]
and
[**FREQUENCY STOP** : 60 GHz]

- Reduce video bandwidth with
[**SWEEP COUPLING** : VIDEO BW MANUAL : **1 MHz**]

A correct signal identification using *AUTO ID* is thus possible (see also [“Remarks Concerning Signal Identification with AUTO ID” on page 4.332](#)).

The display shown in [Fig. 4-43](#) is obtained.




Fig. 4-43 Spectrum at the multiplier output recorded with an external mixer

6. Level correction with average value

If an average value is to be taken into account instead of the frequency-dependent level correction, enter the following parameters for the selected band in the *SELECT BAND* table:

- Enter the table with [**FREQUENCY** : EXTERNAL MIXER : SELECT BAND} dB]:
- Enter the average of the conversion loss into the field AVG CONV LOSS: {conversion loss} dB]
- Enter the type of mixer (in this example 2-port mixer) into the field PORTS.
- Enter the permissible harmonic (in this example even, since a double-diode mixer is used) into the field EVEN/ODD HARMONICS:

By pressing *ENTER* a list box will be opened to select the permissible harmonic.

The entered average value is taken into account for the spectrum display irrespective of the frequency. The precision that can be obtained depends on the frequency response of the mixer. With this type of level correction measurements can be easily performed at single frequencies.

7. Taking into account the cable loss in the IF path

On performing level correction, the conversion loss of the mixer and also the insertion loss a_0 of the cable used to tap off the IF signal are to be taken into account. This additional loss is frequency-dependent.

- Determine the insertion of the cable at the intermediate frequency $f_{IF} = 404.4$ MHz.
- For level correction with average value, add the cable insertion loss to the average conversion loss.
- For frequency-dependent level correction, increase every reference value by the insertion loss to the same extent.
- For this the cable loss can be entered via a transducer table.

Such a table should only contain two reference values (band start and end) for which a_0 is specified.

8. Functions for signal identification

The spectrum represented in [Fig. 4-43](#) contains the input signal and also a large number of unwanted mixer products. Two functions are provided by the R&S FSUP to identify real input signals. The implemented methods are described in section “[Signal Identification](#)” on [page 4.331](#). The *AUTO ID* function is used in this example.

- Activate the function *AUTO ID* with
[**FREQUENCY** : EXTERNAL MIXER : SIGNAL ID : AUTO ID] .

To obtain a display with the correct level when using *AUTO ID*, the tolerance limit taken as a basis for the use of AUTO ID is to be adapted to the mixer (see explanations on the *AUTO ID* function and “[Remarks Concerning Signal Identification with AUTO ID](#)” on [page 4.332](#)). The tolerance limit has been set to 5 dB in this example.

- Adapt the tolerance limit with
[**FREQUENCY** : EXTERNAL MIXER : SIGNAL ID : AUTO ID
THRESHOLD : {tolerance limit} dB] .

The trace shown in [Fig. 4-44](#) is obtained in which unwanted mixer products are blanked out.




Fig. 4-44 Output spectrum of the multiplier recorded with an external mixer and *AUTO ID*

Trigger Port – Option R&S FSP-B28

An essential performance criterion to be met by automatic test systems is to minimize the time overhead of the entire test relative to the net measurement time. A typical test comprises the following steps:

1. Setting of R&S FSUP (frequency, level, bandwidth, measurement time, trigger source)
2. Setting of device under test (DUT) and activation of its output signal
3. Start of measurement; R&S FSUP waits for trigger signal
4. Generation of trigger signal; test system waits for ready signal from R&S FSUP
5. Reading of measured data

After the start of a measurement, hardware settling times are allowed for the R&S FSUP before data acquisition is started. Trigger signals received by the R&S FSUP during the settling time will, therefore, be ignored.

This behavior is not critical in most cases, as long as the trigger signal is periodic and the test signal is stationary.




Fig. 4-45 Test with stationary test signal and periodic trigger signal

In the above case, the R&S FSUP will respond to the first trigger signal received after the settling time.

The situation is quite different, however, if data acquisition is to be started by a single trigger event. In such a case it is mandatory that settling times have elapsed before the trigger signal is sent. Otherwise, the trigger signal will not be identified as a request for data acquisition, and the subsequent query of measured data will result in a time-out on the controller:




Fig. 4-46 Test with single trigger pulse

A particularly difficult aspect of this problem is the variable settling times, which are unavoidable in practice. If there is no signal to indicate that the R&S FSUP is ready to collect measured data, the maximum settling time will have to be allowed for until the trigger signal is sent, thus ensuring reliable measurements. This results in considerable – and in many cases unacceptable – time overhead, depending on the instrument settings.

To minimize this overhead, the port supplies a signal that indicates the R&S FSUP's readiness to collect measured data. The signal is reset on detection of the next trigger signal. In this way, a handshake is established between the R&S FSUP and the DUT and between the R&S FSUP and the controller, which ensures reliable measurements and reduces the time overhead to the settling time actually needed by the R&S FSUP:




Fig. 4-47 Test with ready-for-trigger signal

Cross Correlation Measurement - Option R&S FSUP-B60

The standard instrument is equipped with a phase noise (PN) board. Instruments with the R&S FSUP-B60 option additionally provide a low phase noise (LPN) board for very low noise devices (10 MHz to 8 GHz) in order to decrease the inherent noise of the R&S FSUP.

The measurement selection is described in section “[Selection of the Measurement Function – MEAS Key](#)” on page 4.69. The hotkey and softkey menus are identical to that for the Phase Noise PLL measurement. For a basic measurement example and background information refer to the Quick Start Guide, chapter 5.

For further control of the option, the following additional functionality is provided.

PREMEAS

To display the LPN board settings, press the *PREMEAS* hotkey. In the *VCO & LOOP SETTINGS* dialog box, under *Phase Detector*, the LPN board settings are displayed with activated LPN board, marked in Fig. 4-48 with a red frame.




Fig. 4-48 LPN board settings in the *VCO & LOOP SETTINGS* dialog box

Phase Detector *Phase Detector Slope (= K_PD)*

Specifies the phase detector slope.

Remote command: VCO:PDET:LPN:SLOP?

Phase Detector Level

Specifies the phase detector level.

Remote command: VCO:PDET:LPN:LEV?

Phase Detector DC Offset

Specifies the phase detector DC offset.

Remote command: VCO:PDET:LPN:OFFS?

If the LPN board is switched on, the top area of the measurement window contains additional information on the LPN board:

- The messages *LOCKED* or *UNLOCKED* refer to the status of both boards. If one of the boards is not locked, the message *UNLOCKED* is displayed.
- The displayed *Phase Detector* curve is a result of the cross correlation calculation between the output signals of the PN and LPN board.

Setup Menu - *SETUP* Key

SELFTEST RESULTS

If the LPN board is switched on, during the selftest (*SETUP* key - *SERVICE* softkey - *SELFTEST* softkey) also the LPN board is tested. Accordingly, the test results are included in the results list under *Low-Phasenoise Selftest*.

SELFTEST RESULTS					
Low-Phasenoise Selftest					
test description	min	max	result	state	
TEMP BOARD	-5.00	75.00	33.00	PASSED	
-5V	-5.60	-4.40	-4.87	PASSED	
+5V	4.80	5.60	5.10	PASSED	
+7V	6.34	7.75	7.10	PASSED	
+12V	10.80	13.20	12.38	PASSED	
+28V	25.70	30.32	27.90	PASSED	
TUNE0CX0	0.40	4.60	2.65	PASSED	
TUNE128	1.01	23.01	11.35	PASSED	
TUNE595	2.01	6.50	4.72	PASSED	
TUNE610	6.99	15.00	10.45	PASSED	
TUNE620	15.00	22.01	17.03	PASSED	
LDOCX0	2.00	4.10	3.54	PASSED	
LD128	2.00	4.10	3.43	PASSED	
LD600	2.00	4.10	3.46	PASSED	
YIG CURRENT	0.60	1.80	1.61	PASSED	
TEMP128	35.00	75.00	63.40	PASSED	
REULEVEL	0.50	2.70	1.32	PASSED	

Fig. 4-49 LPN board test results in the *SELFTEST RESULTS* dialog box

For further information on the selftest in general, refer to “Selftest” on page 4.254.

CAL RESULTS If the LPN board is switched on, during calibration (CAL key) also the LPN board is calibrated. The calibration results are included in the results list under *low-phasenoise calibration*.

CALIBRATION RESULTS		
50000.00	51.19	47.15 59.40
phasenoise calibration		
ADC-Offset	Error[%]	
1994	0.00	PASSED
LNA 20dB [Hz]	Gain[dB]	Result
1000.00	24.76	PASSED
10000.00	23.79	PASSED
100000.00	23.66	PASSED
1000000.00	23.65	PASSED
3000000.00	23.69	PASSED
10000000.00	23.87	PASSED
15000000.00	23.67	PASSED
20000000.00	23.65	PASSED
30000000.00	23.75	PASSED
35000000.00	23.52	PASSED
LNA 30dB [Hz]	Gain[dB]	Result
1000.00	24.76	PASSED
10000.00	23.79	PASSED
100000.00	23.66	PASSED
1000000.00	23.65	PASSED
3000000.00	23.69	PASSED
10000000.00	23.87	PASSED
15000000.00	23.67	PASSED
20000000.00	23.65	PASSED
30000000.00	23.75	PASSED
35000000.00	23.52	PASSED
low-phasenoise calibration		
ADC-Offset	Error[%]	
1759	0.02	PASSED

Calibration Complete

SPECTRUM SSA HOME DC POWER QUICKSET RUN PREMEAS SETTINGS

CAL TOTAL CAL ABORT CAL CORR ON OFF CAL RESULTS PAGE UP PAGE DOWN

Fig. 4-50 LPN board calibration results in the CALIBRATION RESULTS dialog box

For further information on the calibration in general, refer to “Recording the Correction Data – CAL Key” on page 4.132.

5 Remote Control – Basics

Overview	5.3
Introduction	5.3
Getting Started	5.4
Starting Remote Control	5.4
Display Contents during Remote Control	5.5
Remote Control via GPIB	5.5
Setting the Device Address	5.5
Return to Manual Operation	5.6
Remote Control via RS-232-Interface	5.6
Setting the Transmission Parameters	5.6
Return to Manual Operation	5.7
Restrictions	5.7
Remote Control in a Network (LAN Interface)	5.8
Setting the Device Address	5.8
Return to Manual Operation	5.8
Messages	5.9
GPIB Interface Messages	5.9
Device Messages (Commands and Device Responses)	5.9
Structure and Syntax of the Device Messages	5.10
SCPI Introduction	5.10
Structure of a Command	5.10
Structure of a Command Line	5.13
Responses to Queries	5.14
Parameters	5.14
Overview of Syntax Elements	5.16
Instrument Model and Command Processing	5.17
Input Unit	5.17
Command Recognition	5.18
Instrument Data Base and Instrument Hardware	5.18
Status Reporting System	5.18
Output Unit	5.18
Command Sequence and Command Synchronization	5.19
Status Reporting System	5.20
Structure of an SCPI Status Register	5.20
Overview of the Status Registers	5.22

Description of the Status Registers	5.23
Status Byte (STB) and Service Request Enable Register (SRE)	5.23
IST Flag and Parallel Poll Enable Register (PPE)	5.24
Event-Status Register (ESR) and Event-Status-Enable Register (ESE)	5.24
STATus:OPERation Register	5.25
STATus:QUESTionable Register	5.25
STATus:QUESTionable:ACPLimit Register	5.26
STATus:QUESTionable:FREQuency Register	5.27
STATus:QUESTionable:LIMit<1 2> Register	5.28
STATus:QUESTionable:LMARgin<1 2> Register	5.29
STATus:QUESTionable:POWer Register	5.30
STATus:QUESTionable:LPNoise Register	5.30
STATus:QUESTionable:PNOise Register	5.31
STATus:QUESTionable:DCPNoise Register	5.32
Application of the Status Reporting Systems	5.32
Service Request, Making Use of the Hierarchy Structure	5.32
Serial Poll	5.33
Parallel Poll	5.33
Query by Means of Commands	5.33
Error Queue Query	5.34
Resetting Values of the Status Reporting System	5.34

Overview

This chapter contains the following:

- instructions on how to put the R&S FSUP into operation via remote control,
- a general introduction to remote control of programmable instruments. This includes the description of the command structure and syntax according to the SCPI standard, the description of command execution and of the status registers,
- diagrams and tables describing the status registers used in the R&S FSUP.

In chapter [“Remote Control – Description of Commands”](#), all remote control functions are described in detail. The subsystems are listed by alphabetical order according to SCPI.

Program examples for the R&S FSUP can be found in chapter [“Remote Control – Programming Examples”](#). The remote control interfaces and their interface functions are described in chapter [“Maintenance and Instrument Interfaces”](#).

Introduction

The instrument is equipped with an GPIB interface according to standard IEC 625.1/IEEE 488.2 and an RS-232 interface. The connectors are located at the rear of the instrument and permit to connect a controller for remote control.

In addition, the instrument can be remotely controlled in a local area network (LAN interface).

Also the VXI-11 channel is supported to remote control the instrument via LAN.

The instrument supports the SCPI version 1997.0 (Standard Commands for Programmable Instruments). The SCPI standard is based on standard IEEE 488.2 and aims at the standardization of device-specific commands, error handling and the status registers (see section [“SCPI Introduction”](#) on page 5.10).

The tutorial "Automatic Measurement Control – A tutorial on SCPI and IEEE 488.2" from John M. Pieper (R&S order number 0002.3536.00) offers detailed information on concepts and definitions of SCPI. For remote control in a network, refer to section [“Remote Control in a Network \(LAN Interface\)”](#) on page 5.8.

This section assumes basic knowledge of GPIB programming and operation of the controller. A description of the interface commands can be obtained from the relevant manuals.

The requirements of the SCPI standard placed on command syntax, error handling and configuration of the status registers are explained in detail in the following sections. Tables provide a fast overview of the bit assignment in the status registers. The tables are supplemented by a comprehensive description of the status registers.

The program examples for GPIB programming are all written in VISUAL BASIC.

Getting Started

The short and simple operating sequence given below permits fast putting into operation of the instrument and setting of its basic functions. As a prerequisite, the GPIB address, which is factory-set to 20, must not have been changed.

1. Connect instrument and controller using GPIB cable.
2. Write and start the following program on the controller:

```
CALL IBFIND("DEV1", analyzer%)
'Open port to the instrument

CALL IBPAD(analyzer%, 20)
'Inform controller about instrument address

CALL IBWRT(analyzer%, '*RST;*CLS')
'Reset instrument

CALL IBWRT(analyzer%, 'FREQ:CENT 100MHz')
'Set center frequency to 100 MHz

CALL IBWRT(analyzer%, 'FREQ:SPAN 10MHz')
'Set span to 10 MHz

CALL IBWRT(analyzer%, 'DISP:TRAC:Y:RLEV -10dBm')
'Set reference level to -10 dBm
```

The instrument now performs a sweep in the frequency range of 95 MHz to 105 MHz.

3. To return to manual operation, press the *LOCAL* key at the front panel.

Starting Remote Control

On power-on, the instrument is always in the manual operating state ("LOCAL" state) and can be operated via the front panel.

It is switched to remote control ("REMOTE" state)

GPIB	as soon as it receives an addressed command from a controller. if it is controlled in a network (RSIB interface), as soon as it receives a command from a controller.
RS-232	as soon as it receives the command "@REM" from a controller.

During remote control, operation via the front panel is disabled. The instrument remains in the remote state until it is reset to the manual state via the front panel or via remote control interfaces. Switching from manual operation to remote control and vice versa does not affect the remaining instrument settings.

Display Contents during Remote Control

During remote control, only the LOCAL softkey appears, with which it is possible to return to manual operation.

In addition, the display of diagrams and results can be blanked out with the command "SYSTEM:DISPlay:UPDate OFF" (default in remote control) to obtain optimum performance during remote control.

During program execution it is recommended to activate the display of results by means of "SYSTEM:DISPlay:UPDate ON" so that it is possible to follow the changes in the device settings and the recorded measurement curves on the screen.



Note

If the instrument is exclusively operated in remote control, it is recommended to switch on the power-save mode (*POWER SAVE*). In this mode, the required display is completely switched off after a preset time.

Remote Control via GPIB

Setting the Device Address

In order to operate the instrument via the GPIB, it must be addressed using the set GPIB address. The GPIB address of the instrument is factory-set to 20. It can be changed manually in the *SETUP - GENERAL SETUP* menu or via remote control. Addresses 0 to 30 are permissible.

Manually:

- Call *SETUP - GENERAL SETUP* menu
- Enter desired address in table *GPIB-ADDRESS*
- Terminate input using the *ENTER* key

Via GPIB:

```
CALL IBFIND("DEV1", analyzer%)
'Open port to the instrument
```

```
CALL IBPAD(analyzer%, 20)
'Inform controller about old address
```

```
CALL IBWRT(analyzer%, "SYST:COMM:GPIB:ADDR 18")
'Set instrument to new address
```

```
CALL IBPAD(analyzer%, 18)
'Inform controller about new address
```

Return to Manual Operation

Return to manual operation is possible via the front panel or remote control.

Manually:

➤ Press the *LOCAL* softkey or the *PRESET* key



Notes

- Before the transition, command processing must be completed as otherwise transition to GPIB is performed immediately.
 - The keys can be disabled by the universal command LLO (see chapter [“Maintenance and Instrument Interfaces”](#), section [“Interface Messages”](#) on page 8.5) in order to prevent unintentional transition. In this case, transition to manual operation is only possible via GPIB.
 - The keys can be enabled again by deactivating the REN line of the GPIB (see chapter [“Maintenance and Instrument Interfaces”](#), section [“Bus Lines”](#) on page 8.4).
-

Via GPIB:

...

```
CALL IBLOC(analyzer%)
'Set instrument to manual operation
```

...

Remote Control via RS-232-Interface

Setting the Transmission Parameters

To enable an error-free and correct data transmission, the parameters of the unit and the controller should have the same setting.

Parameters can be manually changed in menu *SETUP-GENERAL SETUP* in table *COM PORT* or via remote control using the command `SYSTem:COMMunicate:SERial:...`

The transmission parameters of the COM interface are factory-set to the following values:

baudrate = 9600, data bits = 8, stop bits = 1, parity = NONE and owner = INSTRUMENT.

For remote control, the interface should be allocated to the operating system (owner = OS) so that the control characters including @ can be recognized by the interface.

Manually:

Setting the COM interface

- > Call *SETUP-GENERAL SETUP* menu
- > Select desired baudrate, bits, stopbit, parity in table *COM PORT*.
- > Set owner to OS in table *COM PORT*.
- > Terminate input using the *ENTER* key.

Return to Manual Operation

Return to manual operation is possible via the front panel or via RS-232 interface.

Manually:

- > Press the *LOCAL* softkey or the *PRESET* key.

**Notes**

- Before the transition, command processing must be completed as otherwise transition to remote control is performed immediately
 - The keys can be enabled again by sending the control string "@LOC" via RS-232 (see chapter ["Maintenance and Instrument Interfaces"](#), section ["RS-232-C Interface \(COM\)"](#) on page 8.8).
-

Via RS-232:

...

```
v24puts(port, "@LOC");  
Set instrument to manual operation.
```

...

Restrictions

The following restrictions apply if the unit is remote-controlled via the RS-232-C interface:

No interface messages, only control strings (see interface description in chapter ["Maintenance and Instrument Interfaces"](#), section ["RS-232-C Interface \(COM\)"](#) on page 8.8).

Only the Common Commands *OPC? can be used for command synchronization, *WAI and *OPC are not available.

Block data cannot be transmitted.

Remote Control in a Network (LAN Interface)

Via the LAN interface, the R&S FSUP can be remotely controlled in a local area network.

The LAN interface consists of a connector, a network interface card and protocols (VXI-11 and RSIB). For details on the connector and its use refer to the Quick Start Guide, chapter "Front and Rear Panel".

Instrument access via VXI11 or RSIB is usually achieved from high level programming platforms by using VISA as an intermediate abstraction layer. VISA encapsulates the low level VXI, RSIB or even GPIB function calls and thus makes the transport interface transparent for the user. The necessary VISA library is available as a separate product. For details contact your local R&S sales representative.

Setting the Device Address

For control of the instrument in a network, it must be accessed using the preselected IP address. The IP address of the instrument (device address) is defined in the network configuration.

Setting the IP address:

- > Call *SETUP - GENERAL SETUP – CONFIGURE NETWORK* menu.
- > Select *Protocols* tab.
- > Under *Properties*, set IP address for TCP/IP protocol (for details refer to the Quick Start Guide, chapter LAN Interface).

Return to Manual Operation

Return to manual operation can be made manually via the front panel or remotely via the RSIB interface.

Manually:

- > Press *LOCAL* softkey or *PRESET* key.



Note

Make sure that the execution of commands is completed prior to switch over since otherwise the instrument will switch back to remote control immediately.

Via RSIB interface:

...

```
CALL RSDLLibloc(analyzer%, ibsta%, iberr%, ibcntl&)  
'Set device to manual operation
```

...

Messages

The messages transferred via the data lines of the GPIB (see chapter [“Maintenance and Instrument Interfaces”](#), section [“GPIB Interface” on page 8.3](#)) can be divided into two groups:

- [“GPIB Interface Messages”](#)
- [“Device Messages \(Commands and Device Responses\)”](#)

GPIB Interface Messages

Interface messages are transferred on the data lines of the GPIB, the "ATN" control line being active. They are used for communication between controller and instrument and can only be sent by a controller which has the remote control. Interface commands can be subdivided into

- **universal commands** and
- **addressed commands**.

Universal commands act on all devices connected to the GPIB without previous addressing, addressed commands only act on devices previously addressed as listeners. The interface messages relevant to the instrument are listed in chapter [“Maintenance and Instrument Interfaces”](#), section [“Interface Functions” on page 8.4](#).

Device Messages (Commands and Device Responses)

Device messages are transferred on the data lines of the GPIB, the "ATN" control line not being active. ASCII code is used.

A distinction is made according to the direction in which they are sent on the GPIB:

- **Commands** are messages the controller sends to the instrument. They operate the device functions and request informations.

The commands are subdivided according to two criteria:

- According to the effect they have on the instrument:

Setting commands cause instrument settings such as reset of the instrument or setting the center frequency.

Queries cause data to be provided for output on the GPIB, e.g. for identification of the device or polling the marker.

- According to their definition in standard IEEE 488.2:

Common Commands are exactly defined as to their function and notation in standard IEEE 488.2. They refer to functions such as management of the standardized status registers, reset and selftest.

Device-specific commands refer to functions depending on the features of the instrument such as frequency setting. A majority of these commands has also been standardized by the SCPI committee (cf. section [“SCPI Introduction” on page 5.10](#)).

- **Device responses** are messages the instrument sends to the controller after a query. They can contain measurement results, instrument settings and information on the instrument status (cf. section [“Responses to Queries” on page 5.14](#)).

Structure and syntax of the device messages are described in the following section.

Structure and Syntax of the Device Messages

SCPI Introduction

SCPI (Standard Commands for Programmable Instruments) describes a standard command set for programming instruments, irrespective of the type of instrument or manufacturer. The goal of the SCPI consortium is to standardize the device-specific commands to a large extent. For this purpose, a model was developed which defines the same functions inside a device or for different devices. Command systems were generated which are assigned to these functions. Thus it is possible to address the same functions with identical commands. The command systems are of a hierarchical structure.

Fig. 5-1 illustrates this tree structure using a section of command system SENSE, which controls the device-specific settings, that do not refer to the signal characteristics of the measurement signal. Further examples of structure and syntax are taken from this command system.

SCPI is based on standard IEEE 488.2, i.e. it uses the same syntactic basic elements as well as the common commands defined in this standard. Part of the syntax of the device responses is defined with greater restrictions than in standard IEEE 488.2 (see section ["Responses to Queries" on page 5.14](#)).

Structure of a Command

The commands consist of a so-called header and, in most cases, one or more parameters. Header and parameter are separated by a "white space" (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank). The headers may consist of several key words. Queries are formed by directly appending a question mark to the header.

**Note**

The commands used in the following examples are not in every case implemented in the instrument.

Common commands

Common commands consist of a header preceded by an asterisk "*" and one or several parameters, if any.

Examples:

*RST

RESET, resets the device

*ESE 253

EVENT STATUS ENABLE, sets the bits of the event status enable register

*ESR?

EVENT STATUS QUERY, queries the contents of the event status register.

Device-specific commands

Hierarchy:

Device-specific commands are of hierarchical structure (see Fig. 5-1). The different levels are represented by combined headers. Headers of the highest level (root level) have only one key word. This key word denotes a complete command system.

Example:

```
SENSe
```

This key word denotes the command system `SENSe`.

For commands of lower levels, the complete path has to be specified, starting on the left with the highest level, the individual key words being separated by a colon ":".

Example:

```
SENSe:FREQuency:SPAN 10MHZ
```

This command lies in the third level of the `SENSe` system. It sets the frequency span.




Fig. 5-1 Tree structure the SCPI command systems using the `SENSe` system by way of example

Some key words occur in several levels within one command system. Their effect depends on the structure of the command, that is to say, at which position in the header of a command they are inserted.

Examples:

```
SOURce:FM:POLarity NORMal
```

This command contains key word `POLarity` in the third command level. It defines the polarity between modulator and modulation signal.

```
SOURce:FM:EXTernal:POLarity NORMal
```

This command contains key word `POLarity` in the fourth command level. It defines the polarity between modulation voltage and the resulting direction of the modulation only for the external signal source indicated.

Optional key words

Some command systems permit certain key words to be optionally inserted into the header or omitted. These key words are marked by square brackets in the description. The full command length must be recognized by the instrument for reasons of compatibility with the SCPI standard. Some commands are considerably shortened by these optional key words.

Example:

```
[SENSe]:BANDwidth[:RESolution]:AUTO
```

This command couples the resolution bandwidth of the instrument to other parameters. The following command has the same effect:

```
BANDwidth:AUTO
```



Note

An optional key word must not be omitted if its effect is specified in detail by a numeric suffix.

Long and short form

The key words feature a long form and a short form. Either the short form or the long form can be entered, other abbreviations are not permissible.

Example:

```
STATus:QUEStionable:ENABle 1= STAT:QUES:ENAB 1
```



Note

The short form is marked by upper-case letters, the long form corresponds to the complete word. Upper-case and lower-case notation only serve the above purpose, the instrument itself does not make any difference between upper-case and lower-case letters.

Parameter

The parameter must be separated from the header by a "white space". If several parameters are specified in a command, they are separated by a comma ",". A few queries permit the parameters MINimum, MAXimum and DEFault to be entered. For a description of the types of parameter, refer to section ["Parameters" on page 5.14](#).

Example:

```
SENSe:FREQuency:STOP? MAXimum
```

This query requests the maximal value for the stop frequency. Response: 3.5E9

Numeric suffix

If a device features several functions or features of the same kind, e.g. inputs, the desired function can be selected by a suffix added to the command. Entries without suffix are interpreted like entries with the suffix 1.

Example:

```
SYSTem:COMMunicate:SERial2:BAUD 9600
```

This command sets the baudrate of a second serial interface.

Structure of a Command Line

A command line may consist of one or several commands. It is terminated by a <New Line>, a <New Line> with EOI or an EOI together with the last data byte. The IEC/IEEE driver of the controller usually produces automatically an EOI together with the last data byte.

Several commands in a command line are separated by a semicolon ";". If the next command belongs to a different command system, the semicolon is followed by a colon.

Example:

```
CALL IBWRT(analyzer%, "SENSe:FREQuency:CENTer 100MHz;:INPut:ATTenuation 10")
```

This command line contains two commands. The first one is part of the SENSE command system and is used to determine the center frequency of the instrument. The second one is part of the INPut command system and sets the input signal attenuation.

If the successive commands belong to the same system, having one or several levels in common, the command line can be abbreviated. For that purpose, the second command after the semicolon starts with the level that lies below the common levels (see also [Fig. 5-1](#)). The colon following the semicolon must be omitted in this case.

Example:

```
CALL IBWRT(analyzer%, "SENSe:FREQuency:START 1E6;:SENSe:FREQuency:STOP 1E9")
```

This command line is represented in its full length and contains two commands separated from each other by the semicolon. Both commands are part of the SENSE command system, subsystem FREQuency, i.e. they have two common levels.

When abbreviating the command line, the second command begins with the level below SENSE: FREQuency. The colon after the semicolon is omitted.

The abbreviated form of the command line reads as follows:

```
CALL IBWRT(analyzer%, "SENSe:FREQuency:START 1E6;STOP 1E9")
```

However, a new command line always begins with the complete path.

Example:

```
CALL IBWRT(analyzer, "SENSe:FREQuency:START 1E6")
```

```
CALL IBWRT(analyzer%, "SENSe:FREQuency:STOP 1E9")
```

Responses to Queries

A query is defined for each setting command unless explicitly specified otherwise. It is formed by adding a question mark to the associated setting command. According to SCPI, the responses to queries are partly subject to stricter rules than in standard IEEE 488.2.

1. The requested parameter is transmitted without header.

Example: `INPut:COUPling?`
Response: `DC`

2. Maximum values, minimum values and all further quantities, which are requested via a special text parameter are returned as numerical values.

Example: `SENSe:FREQuency:STOP? MAX`
Response: `3.5E9`

3. Numerical values are output without a unit. Physical quantities are referred to the base units or to the units set using the Unit command.

Example: `SENSe:FREQuency:CENTer?`
Response: `1E6` for 1 MHz

4. Truth values <Boolean values> are returned as 0 (for OFF) and 1 (for ON).

Example: `SENSe:BANDwidth:AUTO?`
Response: `1` for ON

5. Text (character data) is returned in a short form.

Example: `SYSTem:COMMunicate:SERial:CONTrol:RTS?`
Response (for standard): `STAN`

Parameters

Most commands require a parameter to be specified. The parameters must be separated from the header by a "white space". Permissible parameters are numerical values, Boolean parameters, text, character strings and block data. The type of parameter required for the respective command and the permissible range of values are specified in the command description

Numerical values

Numerical values can be entered in any form, i.e. with sign, decimal point and exponent. Values exceeding the resolution of the instrument are rounded up or down. The mantissa may comprise up to 255 characters, the exponent must lie inside the value range -32000 to 32000. The exponent is introduced by an "E" or "e". Entry of the exponent alone is not permissible. In the case of physical quantities, the unit can be entered. Permissible unit prefixes are G (giga), MA (mega), MOHM and MHZ are also permissible), K (kilo), M (milli), U (micro) and N (nano). If the unit is missing, the base unit is used.

Example:

`SENSe:FREQuency:STOP 1.5GHz = SENSe:FREQuency:STOP 1.5E9`

Special numerical

The texts MINimum, MAXimum, DEFault, UP and DOWN are interpreted as values special numerical values.

In the case of a query, the numerical value is provided.

Example:

Setting command: `SENSe:FREQuency:STOP MAXimum`

Query: `SENSe:FREQuency:STOP?`

Response: `3.5E9`

MIN/MAX

MINimum and MAXimum denote the minimum and maximum value.

DEF

DEFault denotes a preset value which has been stored in the EPROM. This value conforms to the default setting, as it is called by the *RST command

UP/DOWN

UP, DOWN increases or reduces the numerical value by one step. The step width can be specified via an allocated step command (see annex C, List of Commands) for each parameter which can be set via UP, DOWN.

INF/NINF

INFINITY, Negative INFINITY (NINF) Negative INFINITY (NINF) represent the numerical values -9.9E37 or 9.9E37, respectively. INF and NINF are only sent as device responses.

NAN

Not A Number (NAN) represents the value 9.91E37. NAN is only sent as device response. This value is not defined. Possible causes are the division of zero by zero, the subtraction of infinite from infinite and the representation of missing values.

Boolean Parameters

Boolean parameters represent two states. The ON state (logically true) is represented by ON or a numerical value unequal to 0. The OFF state (logically untrue) is represented by OFF or the numerical value 0. 0 or 1 is provided in a query.

Example:

Setting command: `DISPlay:WINDow:STATe ON`

Query: `DISPlay:WINDow:STATe?`

Response: `1`

Text

Text parameters observe the syntactic rules for key words, i.e. they can be entered using a short or long form. Like any parameter, they have to be separated from the header by a white space. In the case of a query, the short form of the text is provided.

Example:

Setting command: `INPut:COUPling GROund`

Query: `INPut:COUPling?`

Response: `GRO`

Strings

Strings must always be entered in quotation marks (' or ").

Example:

```
SYSTem:LANGuage "SCPI" or  
SYSTem:LANGuage 'SCPI'
```

Block data

Block data is a transmission format which is suitable for the transmission of large amounts of data. A command using a block data parameter has the following structure.

Example:

```
HEADer:HEADer #45168xxxxxxxx
```

ASCII character # introduces the data block. The next number indicates how many of the following digits describe the length of the data block. In the example, the 4 following digits indicate the length to be 5168 bytes. The data bytes follow. During the transmission of these data bytes, all End or other control signs are ignored until all bytes are transmitted.

This format only supports a byte count up to 9 digits for the number of bytes. For more than 999999999 bytes, following additional format is used.

Example:

```
HEADer:HEADer #(1100000000) xxxxxxxx
```

The byte length count is put into brackets. In the example, the byte counts indicate a length of 1.100.000.000 bytes. The data bytes follow the close bracket.

Overview of Syntax Elements

The following survey offers an overview of the syntax elements.

- : The colon separates the key words of a command.
In a command line the colon after the separating semicolon marks the uppermost command level.
- ; The semicolon separates two commands of a command line. It does not alter the path.
- , The comma separates several parameters of a command.
- ? The question mark forms a query.
- * The asterisk marks a common command.
- " Quotation marks introduce a string and terminate it.
- # The double dagger introduces block data.
A white space (ASCII code 0 to 9, 11 to 32 decimal, e.g. blank) separates header and parameter.

Instrument Model and Command Processing

The instrument model shown in Fig. 5-2 has been made viewed from the standpoint of the servicing of remote commands. The individual components work independently of each other and simultaneously. They communicate by means of so-called "messages".




Fig. 5-2 Instrument model in the case of remote control by means of the GPIB

Input Unit

The input unit receives commands character by character from the GPIB and collects them in the input buffer. The input unit sends a message to the command recognition as soon as the input buffer is full or as soon as it receives a delimiter, <PROGRAM MESSAGE TERMINATOR>, as defined in IEEE 488.2, or the interface message DCL.

If the input buffer is full, the GPIB traffic is stopped and the data received up to then are processed. Subsequently the GPIB traffic is continued. If, however, the buffer is not yet full when receiving the delimiter, the input unit can already receive the next command during command recognition and execution. The receipt of a DCL clears the input buffer and immediately initiates a message to the command recognition.

Command Recognition

The command recognition analyses the data received from the input unit. It proceeds in the order in which it receives the data. Only a DCL is serviced with priority, a GET (Group Execute Trigger), e.g., is only executed after the commands received before as well. Each recognized command is immediately transferred to the instrument data base but without being executed there at once.

Syntactical errors in the command are recognized in the command recognition and supplied to the status reporting system. The rest of a command line after a syntax error is analyzed further if possible and serviced.

If the command recognition recognizes a delimiter (<PROGRAM MESSAGE SEPARATOR> or <PROGRAM MESSAGE TERMINATOR>) or a DCL, it requests the instrument data base to set the commands in the instrument hardware as well now. Subsequently it is immediately prepared to process commands again. This means for the command servicing that further commands can already be serviced while the hardware is still being set ("overlapping execution").

Instrument Data Base and Instrument Hardware

Here the expression "instrument hardware" denotes the part of the instrument fulfilling the actual instrument function - signal generation, measurement etc. The controller is not included.

The instrument data base is a detailed reproduction of the instrument hardware in the software.

GPIB setting commands lead to an alteration in the data set. The data base management enters the new values (e.g. frequency) into the data base, however, only passes them on to the hardware when requested by the command recognition.

The data are only checked for their compatibility among each other and with the instrument hardware immediately before they are transmitted to the instrument hardware. If the detection is made that an execution is not possible, an "execution error" is signalled to the status reporting system. The alteration of the data base are cancelled, the instrument hardware is not reset.

GPIB queries induce the data base management to send the desired data to the output unit.

Status Reporting System

The status reporting system collects information on the instrument state and makes it available to the output unit on request. The exact structure and function are described in section ["Overview of the Status Registers"](#) on page 5.22.

Output Unit

The output unit collects the information requested by the controller, which it receives from the data base management. It processes it according to the SCPI rules and makes it available in the output buffer. If the instrument is addressed as a talker without the output buffer containing data or awaiting data from the data base management, the output unit sends error message "Query UNTERMINATED" to the status reporting system. No data are sent on the GPIB, the controller waits until it has reached its time limit. This behavior is specified by SCPI.

Command Sequence and Command Synchronization

What has been said above makes clear that all commands can potentially be carried out overlapping.

In order to prevent an overlapping execution of commands, one of commands *OPC, *OPC? or *WAI must be used. All three commands cause a certain action only to be carried out after the hardware has been set and has settled. By a suitable programming, the controller can be forced to wait for the respective action to occur (cf. [Table 5-1](#)).

Table 5-1 Synchronization using *OPC, *OPC? and *WAI

Command	Action after the hardware has settled	Programming the controller
*OPC	Setting the operation-complete bit in the ESR	- Setting bit 0 in the ESE - Setting bit 5 in the SRE - Waiting for service request (SRQ)
*OPC?	Writing a "1" into the output buffer	Addressing the instrument as a talker
*WAI	Continuing the GPIB handshake	Sending the next command

An example as to command synchronization can be found in chapter [“Remote Control – Programming Examples”](#).

For a couple of commands the synchronization to the end of command execution is mandatory in order to obtain the desired result. The affected commands require either more than one measurement in order to accomplish the desired instrument setting (e.g. auto range functions), or they require a longer period of time for execution. If a new command is received during execution of the corresponding function this may either lead to either to an aborted measurement or to invalid measurement data.

The following list includes the commands, for which a synchronization via *OPC, *OPC? or *WAI is mandatory:

Table 5-2 Commands with mandatory synchronization (Overlapping Commands)

Command	Purpose
INIT	start measurement
INIT:CONM	continue measurement
CALC:MARK:FUNC:ZOOM	zoom frequency range around marker 1
CALC:STAT:SCAL:AUTO ONCE	optimize level settings for signal statistic measurement functions
[SENS:]POW:ACH:PRES:RLEV	optimize level settings for adjacent channel power measurements

Status Reporting System

The status reporting system (cf. Fig. 5-4) stores all information on the present operating state of the instrument, e.g. that the instrument presently carries out a calibration and on errors which have occurred. This information is stored in the status registers and in the error queue. The status registers and the error queue can be queried via GPIB.

The information is of a hierarchical structure. The register status byte (STB) defined in IEEE 488.2 and its associated mask register service request enable (SRE) form the uppermost level. The STB receives its information from the standard event status register (ESR) which is also defined in IEEE 488.2 with the associated mask register standard event status enable (ESE) and registers STATUS:OPERation and STATUS:QUESTionable which are defined by SCPI and contain detailed information on the instrument.

The IST flag ("Individual STATUS") and the parallel poll enable register (PPE) allocated to it are also part of the status reporting system. The IST flag, like the SRQ, combines the entire instrument status in a single bit. The PPE fulfills the same function for the IST flag as the SRE for the service request.

The output buffer contains the messages the instrument returns to the controller. It is not part of the status reporting system but determines the value of the MAV bit in the STB and thus is represented in Fig. 5-4.

Structure of an SCPI Status Register

Each SCPI register consists of 5 parts which each have a width of 16 bits and have different functions (cf. Fig. 5-3). The individual bits are independent of each other, i.e. each hardware status is assigned a bit number which is valid for all five parts. For example, bit 3 of the STATUS:OPERation register is assigned to the hardware status "wait for trigger" in all five parts. Bit 15 (the most significant bit) is set to zero for all parts. Thus the contents of the register parts can be processed by the controller as positive integer.




Fig. 5-3 The status-register model

CONDition part

The CONDition part is directly written into by the hardware or the sum bit of the next lower register. Its contents reflects the current instrument status. This register part can only be read, but not written into or cleared. Its contents is not affected by reading.

PTRansition part

The Positive-TRansition part acts as an edge detector. When a bit of the CONDition part is changed from 0 to 1, the associated PTR bit decides whether the EVENT bit is set to 1.

PTR bit =1: the EVENT bit is set.

PTR bit =0: the EVENT bit is not set.

This part can be written into and read at will. Its contents is not affected by reading.

NTRansition part

The Negative-TRansition part also acts as an edge detector. When a bit of the CONDition part is changed from 1 to 0, the associated NTR bit decides whether the EVENT bit is set to 1.

NTR-Bit = 1: the EVENT bit is set.

NTR-Bit = 0: the EVENT bit is not set.

This part can be written into and read at will. Its contents is not affected by reading.

With these two edge register parts the user can define which state transition of the condition part (none, 0 to 1, 1 to 0 or both) is stored in the EVENT part.

EVENT part

The EVENT part indicates whether an event has occurred since the last reading, it is the "memory" of the condition part. It only indicates events passed on by the edge filters. It is permanently updated by the instrument. This part can only be read by the user. During reading, its contents is set to zero. In linguistic usage this part is often equated with the entire register.

ENABLE part

The ENABLE part determines whether the associated EVENT bit contributes to the sum bit (cf. below). Each bit of the EVENT part is ANDed with the associated ENABLE bit (symbol '&'). The results of all logical operations of this part are passed on to the sum bit via an OR function (symbol '+').

ENABLE-Bit = 0: the associated EVENT bit does not contribute to the sum bit

ENABLE-Bit = 1: if the associated EVENT bit is "1", the sum bit is set to "1" as well.

This part can be written into and read by the user at will. Its contents is not affected by reading.

Sum bit

As indicated above, the sum bit is obtained from the EVENT and ENABLE part for each register. The result is then entered into a bit of the CONDition part of the higher-order register.

The instrument automatically generates the sum bit for each register. Thus an event, e.g. a PLL that has not locked, can lead to a service request throughout all levels of the hierarchy.



Note

The service request enable register SRE defined in IEEE 488.2 can be taken as ENABLE part of the STB if the STB is structured according to SCPI. By analogy, the ESE can be taken as the ENABLE part of the ESR.

Overview of the Status Registers

The following figure shows the status registers used by the R&S FSUP base unit. The status registers used by the R&S FSUP options are described in the separate software manuals.




Fig. 5-4 Overview of the status registers (base unit)

Description of the Status Registers

Status Byte (STB) and Service Request Enable Register (SRE)

The STB is already defined in IEEE 488.2. It provides a rough overview of the instrument status by collecting the pieces of information of the lower registers. It can thus be compared with the CONDition part of an SCPI register and assumes the highest level within the SCPI hierarchy. A special feature is that bit 6 acts as the sum bit of the remaining bits of the status byte.

The STATUS BYTE is read out using the command "*STB?" or a serial poll.

The STB implies the SRE. It corresponds to the ENABle part of the SCPI registers as to its function. Each bit of the STB is assigned a bit in the SRE. Bit 6 of the SRE is ignored. If a bit is set in the SRE and the associated bit in the STB changes from 0 to 1, a Service Request (SRQ) is generated on the GPIB, which triggers an interrupt in the controller if this is appropriately configured and can be further processed there.

The SRE can be set using command "*SRE" and read using "*SRE?".

Table 5-3 Meaning of the bits in the status byte

Bit No.	Meaning
2	<p>Error Queue not empty</p> <p>The bit is set when an entry is made in the error queue.</p> <p>If this bit is enabled by the SRE, each entry of the error queue generates a Service Request. Thus an error can be recognized and specified in greater detail by polling the error queue. The poll provides an informative error message. This procedure is to be recommended since it considerably reduces the problems involved with GPIB control.</p>
3	<p>QUESTionable status sum bit</p> <p>The bit is set if an EVENT bit is set in the QUESTionable: status register and the associated ENABle bit is set to 1.</p> <p>A set bit indicates a questionable instrument status, which can be specified in greater detail by polling the QUESTionable status register.</p>
4	<p>MAV bit (message available)</p> <p>The bit is set if a message is available in the output buffer which can be read.</p> <p>This bit can be used to enable data to be automatically read from the instrument to the controller (cf. chapter "Remote Control – Programming Examples").</p>
5	<p>ESB bit</p> <p>Sum bit of the event status register. It is set if one of the bits in the event status register is set and enabled in the event status enable register.</p> <p>Setting of this bit implies an error or an event which can be specified in greater detail by polling the event status register.</p>
6	<p>MSS bit (master status summary bit)</p> <p>The bit is set if the instrument triggers a service request. This is the case if one of the other bits of this registers is set together with its mask bit in the service request enable register SRE.</p>
7	<p>OPERation status register sum bit</p> <p>The bit is set if an EVENT bit is set in the OPERation-Status register and the associated ENABle bit is set to 1.</p> <p>A set bit indicates that the instrument is just performing an action. The type of action can be determined by polling the OPERation-status register.</p>

IST Flag and Parallel Poll Enable Register (PPE)

By analogy with the SRQ, the IST flag combines the entire status information in a single bit. It can be queried by means of a parallel poll (cf. section “Parallel Poll” on page 5.33) or using command “*IST?”.

The parallel poll enable register (PPE) determines which bits of the STB contribute to the IST flag. The bits of the STB are ANDed with the corresponding bits of the PPE, with bit 6 being used as well in contrast to the SRE. The Ist flag results from the ORing of all results. The PPE can be set using commands “*PRE” and read using command “*PRE?”.

Event-Status Register (ESR) and Event-Status-Enable Register (ESE)

The ESR is already defined in IEEE 488.2. It can be compared with the EVENT part of an SCPI register. The event status register can be read out using command “*ESR?”.

The ESE is the associated ENABLE part. It can be set using command “*ESE” and read using command “*ESE?”.

Table 5-4 Meaning of the bits in the event status register

Bit No.	Meaning
0	Operation Complete This bit is set on receipt of the command *OPC exactly when all previous commands have been executed.
1	This bit is not used
2	Query Error This bit is set if either the controller wants to read data from the instrument without having send a query, or if it does not fetch requested data and sends new instructions to the instrument instead. The cause is often a query which is faulty and hence cannot be executed.
3	Device-dependent Error This bit is set if a device-dependent error occurs. An error message with a number between -300 and -399 or a positive error number, which denotes the error in greater detail, is entered into the error queue (cf. chapter “Error Messages”).
4	Execution Error This bit is set if a received command is syntactically correct, however, cannot be performed for other reasons. An error message with a number between -200 and -300, which denotes the error in greater detail, is entered into the error queue (cf. chapter “Error Messages”).
5	Command Error This bit is set if a command which is undefined or syntactically incorrect is received. An error message with a number between -100 and -200, which denotes the error in greater detail, is entered into the error queue (cf. chapter “Error Messages”).
6	User Request This bit is set on pressing the LOCAL key.
7	Power On (supply voltage on) This bit is set on switching on the instrument.

STATus:OPERation Register

In the CONDition part, this register contains information on which actions the instrument is being executing or, in the EVENt part, information on which actions the instrument has executed since the last reading. It can be read using commands "STATus:OPERation:CONDition?" or "STATus:OPERation[:EVENT]?".

Table 5-5 Meaning of the bits in the STATus.OPERation register

Bit No.	Meaning
0	CALibrating This bit is set as long as the instrument is performing a calibration.
1 to 3	These bits are not used.
4	MEASuring (phase noise mode only) The value '1' in this bit position indicates that a measurement is in progress.
5 to 7	These bits are not used.
8	HardCOPy in progress This bit is set while the instrument is printing a hardcopy.
9	This bit is not used
10	Sweep Break This bit is set when end of sweep range is reached (spurious measurement, mode analyzer). Command "INIT:CONM" has to be used to proceed.
11 to 14	These bits are not used
15	This bit is always 0

STATus:QUEStionable Register

This register comprises information about indefinite states which may occur if the unit is operated without meeting the specifications. It can be queried by commands STATus:QUEStionable:CONDition? and STATus:QUEStionable[:EVENT]?

Table 5-6 Meaning of bits in STATus:QUEStionable register

Bit No.	Meaning
0 to 2	These bits are not used.
3	POWer This bit is set if a questionable power occurs (cf. also section " STATus:QUEStionable:POWer Register " on page 5.30)
4	TEMPerature This bit is set if a questionable temperature occurs.
5	FREQuency The bit is set if a frequency is questionable (cf. section " STATus:QUEStionable:FREQuency Register " on page 5.27)
6	This bit is not used.
7	LPNoise This bit is set if a questionable information from the low phase noise board (R&S FSUP-B60) occurs (see also " STATus:QUEStionable:LPNoise Register " on page 5.30).

Table 5-6 Meaning of bits in STATus:QUEStionable register (Continued)

Bit No.	Meaning
8	CALibration The bit is set if a measurement is performed uncalibrated (equivalent to label "UNCAL")
9	LIMit (device-specific) This bit is set if a limit value is violated (see also section "STATus:QUEStionable:LIMit<1 2> Register" on page 5.28)
10	LMARgin (analyzer mode only) This bit is set if a margin is violated (see also section "STATus:QUEStionable:LMARgin<1 2> Register" on page 5.29)
11	This bit is not used
12	ACPLimit (analyzer mode only) This bit is set if a limit for the adjacent channel power measurement is violated (see also section "STATus:QUEStionable:ACPLimit Register" on page 5.26)
13	PNOIse (phase noise mode only) This bit is set if a questionable general phase noise failure occurs (see also "STATus:QUEStionable:PNOise Register" on page 5.31).
14	DCPNoise This bit is set if a questionable information from the DC or phase noise board occurs (see also "STATus:QUEStionable:DCPNoise Register" on page 5.32).
15	This bit is always 0.

STATus:QUEStionable:ACPLimit Register

This register comprises information about the observance of limits during adjacent power measurements. It can be queried with commands `STATus:QUEStionable:ACPLimit:CONDition?` and `STATus:QUEStionable:ACPLimit[:EVENT]?`.

This register is only used in analyzer mode.

Table 5-7 Meaning of bits in STATus:QUEStionable:ACPLimit register

Bit No.	Meaning
0	ADJ UPPer FAIL(Screen A) This bit is set if in screen A. the limit is exceeded in the upper adjacent channel
1	ADJ LOWer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in the lower adjacent channel.
2	ALT1 UPPer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in the upper 1st alternate channel.
3	ALT1 LOWer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in the lower 1st alternate channel.
4	ALT2 UPPer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in the upper 2nd alternate channel.
5	ALT2 LOWer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in the lower 2nd alternate channel.
6	ALT3 to 11 LOWer/UPPer FAIL (Screen A) This bit is set if in screen A the limit is exceeded in one of the lower or upper alternate channels 3 to 11.

Table 5-7 Meaning of bits in STATus:QUEStionable:ACPLimit register (Continued)

Bit No.	Meaning
7	not used
8	ADJ UPPer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the upper adjacent channel.
9	ADJ LOWer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the lower adjacent channel.
10	ALT1 UPPer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the upper 1st alternate channel.
11	ALT1 LOWer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the lower 1st alternate channel.
12	ALT2 UPPer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the upper 2nd alternate channel.
13	ALT2 LOWer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in the lower 2nd alternate channel.
14	ALT3 to 11 LOWer/UPPer FAIL (Screen B) This bit is set if in screen B the limit is exceeded in one of the lower or upper alternate channels 3 to 11.
15	This bit is always set to 0.

STATus:QUEStionable:FREQuency Register

This register comprises information about the reference and local oscillator.

It can be queried with commands `STATus:QUEStionable:FREQuency:CONDition?` and `STATus:QUEStionable:FREQuency[:EVENT]?`.

Table 5-8 Meaning of bits in STATus:QUEStionable:FREQuency register

Bit No.	Meaning
0	OVEN COLD This bit is set if the reference oscillator has not yet attained its operating temperature. 'OCXO' will then be displayed.
1	LO UNLocked (Screen A) This bit is set if the local oscillator no longer locks. 'LOUNL' will then be displayed.
2 to 8	not used
9	LO UNLocked (Screen B) This bit is set if the local oscillator no longer locks. 'LOUNL' will then be displayed.
10 to 14	not used
15	This bit is always 0.

STATus:QUEStionable:LIMit<1|2> Register

This register comprises information about the observance of limit lines in the corresponding measurement window (LIMit 1 corresponds to Screen A, LIMit 2 to Screen B). It can be queried with commands `STATus:QUEStionable:LIMit<1|2>:CONDition?` and `STATus:QUEStionable:LIMit<1|2>[:EVENT]?`.

Table 5-9 Meaning of bits in STATus:QUEStionable:LIMit<1|2> register

Bit No.	Meaning
0	LIMit 1 FAIL This bit is set if limit line 1 is violated.
1	LIMit 2 FAIL This bit is set if limit line 2 is violated.
2	LIMit 3 FAIL This bit is set if limit line 3 is violated.
3	LIMit 4 FAIL This bit is set if limit line 4 is violated.
4	LIMit 5 FAIL This bit is set if limit line 5 is violated.
5	LIMit 6 FAIL This bit is set if limit line 6 is violated.
6	LIMit 7 FAIL This bit is set if limit line 7 is violated.
7	LIMit 8 FAIL This bit is set if limit line 8 is violated.
8 to 14	not used
15	This bit is always 0.

STATus:QUEStionable:LMARgin<1|2> Register

This register comprises information about the observance of limit margins in the corresponding measurement window (LMARgin1 corresponds to Screen A, LMARgin2 corresponds to Screen B). It can be queried with commands `STATus:QUEStionable:LMARgin<1|2>:CONDition?` and `"STATus:QUEStionable:LMARgin<1|2>[:EVENT]?"`.

This register is only used in analyzer mode.

Table 5-10 Meaning of bits in STATus:QUEStionable:LMARgin<1|2> register

Bit No.	Meaning
0	LMARgin 1 FAIL This bit is set if limit margin 1 is violated.
1	LMARgin 2 FAIL This bit is set if limit margin 2 is violated.
2	LMARgin 3 FAIL This bit is set if limit margin 3 is violated.
3	LMARgin 4 FAIL This bit is set if limit margin 4 is violated.
4	LMARgin 5 FAIL This bit is set if limit margin 5 is violated.
5	LMARgin 6 FAIL This bit is set if limit margin 1 is violated.
6	LMARgin 7 FAIL This bit is set if limit margin 7 is violated.
7	LMARgin 8 FAIL This bit is set if limit margin 8 is violated.
8 to 14	not used
15	This bit is always 0.

STATUS:QUESTIONABLE:POWER Register

This register comprises all information about possible overloads of the unit.

It can be queried with commands `STATUS:QUESTIONABLE:POWER:CONDITION?` and `STATUS:QUESTIONABLE:POWER[:EVENT]?`.

Table 5-11 Meaning of bits in STATUS:QUESTIONABLE:POWER register

Bit No.	Meaning
0	OVERload (Screen A) This bit is set if the RF input is overloaded. 'OVLD' will then be displayed.
1	UNDERload (Screen A) This bit is set if the RF input is underloaded. 'UNLD' will then be displayed.
2	IF_OVERload (Screen A) This bit is set if the IF path is overloaded. 'IFOVL' will then be displayed.
3 to 7	not used
8	OVERload (Screen B) This bit is set if the RF input is overloaded. 'OVLD' will then be displayed.
9	UNDERload (Screen B) This bit is set if the RF input is underloaded. 'UNLD' will then be displayed.
10	IF_OVERload (Screen B) This bit is set if the IF path is overloaded. 'IFOVL' will then be displayed.
11 to 14	not used
15	This bit is always 0.

STATUS:QUESTIONABLE:LPNoise Register

This register contains information about low phase noise board (R&S FSUP-B60).

The bits can be queried with the `STATUS:QUESTIONABLE:LPNoise:CONDITION?` and `STATUS:QUESTIONABLE:LPNoise[:EVENT]?` commands.

Table 5-12 Meaning of bits in STATUS:QUESTIONABLE:LPNoise register

Bit No.	Meaning
0 to 3	These bits are reserved for future or internal usage.
4	Low phase noise PLL unlock
5 to 14	These bits are reserved for future or internal usage.
15	This bit is always 0.

STATus:QUEStionable:PNOise Register

This register is only used in phase noise mode. It contains information about phase noise measurements.

The bits can be queried with the `STATus:QUEStionable:PNOise:CONDition?` and `STATus:QUEStionable:PNOise[:EVENT]?` commands.

Table 5-13 Meaning of bits in STATus:QUEStionable:PNOise register

Bit No.	Meaning
0	Invalid DC Switching sequence This bit is set if the DC switching sequence is not valid.
1	SIGNAL not found This bit is set if no valid signal is detected.
2	VERify signal failed This bit is set if verification failed to detect a signal within the supplied tolerances.
3	Beat Note not found This bit is set if no beat note is found
4	Beat Note level too low This bit is set if the detected beat note level is too low.
5	Reference frequency out of range This bit is set if the reference frequency is out side of the DUT's tuning range in premeas.
6 to 14	These bits are not used.
15	This bit is always 0.

STATus:QUEStionable:DCPNoise Register

This register contains information about DC and phase noise board.

The bits can be queried with the [STATus:QUEStionable:DCPNoise:CONDition?](#) and [STATus:QUEStionable:DCPNoise\[:EVENT\]?](#) commands.

Table 5-14 Meaning of bits in STATus:QUEStionable:DCPNoise register

Bit No.	Meaning
0	Temperature of DC board too high
1	Current Vcc1 too high
2	Current Vcc2 too high
3	Current Vaux too high
4	Current Vtune1 too high
5	Current Vtune2 too high
6	Vtune1 above Vmax
7	Vtune1 below Vmin
8 to 10	These bits are reserved for future or internal usage.
11	PLL loop unlock
12 to 14	These bits are reserved for future or internal usage.
15	This bit is always 0.

Application of the Status Reporting Systems

In order to be able to effectively use the status reporting system, the information contained there must be transmitted to the controller and further processed there. There are several methods which are represented in the following. Detailed program examples are to be found in chapter [“Remote Control – Programming Examples”](#).

Service Request, Making Use of the Hierarchy Structure

Under certain circumstances, the instrument can send a service request (SRQ) to the controller. Usually this service request initiates an interrupt at the controller, to which the control program can react with corresponding actions. As evident from [Fig. 5-4](#), an SRQ is always initiated if one or several of bits 2, 3, 4, 5 or 7 of the status byte are set and enabled in the SRE. Each of these bits combines the information of a further register, the error queue or the output buffer. The corresponding setting of the ENABLE parts of the status registers can achieve that arbitrary bits in an arbitrary status register initiate an SRQ. In order to make use of the possibilities of the service request, all bits should be set to "1" in enable registers SRE and ESE.

Examples (cf. [Fig. 5-4](#) and chapter [“Remote Control – Programming Examples”](#)):

Use of command `*OPC` to generate an SRQ at the end of a sweep.

- > `CALL IBWRT(analyzer%, "*ESE 1")` Set bit 0 in the ESE (Operation Complete)
- > `CALL IBWRT(analyzer%, "*SRE 32")` Set bit 5 in the SRE (ESB)

After its settings have been completed, the instrument generates an SRQ.

The SRQ is the only possibility for the instrument to become active on its own. Each controller program should set the instrument in a way that a service request is initiated in the case of malfunction. The program should react appropriately to the service request. A detailed example for a service request routine is to be found in chapter [“Remote Control – Programming Examples”](#).

Serial Poll

In a serial poll, just as with command `*STB`, the status byte of an instrument is queried. However, the query is realized via interface messages and is thus clearly faster. The serial-poll method has already been defined in IEEE 488.1 and used to be the only standard possibility for different instruments to poll the status byte. The method also works with instruments which do not adhere to SCPI or IEEE 488.2.

The VISUAL BASIC command for executing a serial poll is `IBRSP()`. Serial poll is mainly used to obtain a fast overview of the state of several instruments connected to the GPIB.

Parallel Poll

In a parallel poll, up to eight instruments are simultaneously requested by the controller by means of a single command to transmit 1 bit of information each on the data lines, i.e., to set the data line allocated to each instrument to logically "0" or "1". By analogy to the SRE register which determines under which conditions an SRQ is generated, there is a parallel poll enable register (PPE) which is ANDed with the STB bit by bit as well considering bit 6. The results are ORed, the result is then sent (possibly inverted) as a response in the parallel poll of the controller. The result can also be queried without parallel poll by means of command `*IST`.

The instrument first has to be set for the parallel poll using quick-BASIC command `IBPPC()`. This command allocates a data line to the instrument and determines whether the response is to be inverted. The parallel poll itself is executed using `IBRPP()`.

The parallel-poll method is mainly used in order to quickly find out after an SRQ which instrument has sent the service request if there are many instruments connected to the GPIB. To this effect, SRE and PPE must be set to the same value. A detailed example as to the parallel poll is to be found in chapter [“Remote Control – Programming Examples”](#).

Query by Means of Commands

Each part of every status register can be read by means of queries. The individual commands are indicated in the detailed description of the registers. What is returned is always a number which represents the bit pattern of the register queried. Evaluating this number is effected by the controller program.

Queries are usually used after an SRQ in order to obtain more detailed information on the cause of the SRQ.

Error Queue Query

Each error state in the instrument leads to an entry in the error queue. The entries of the error queue are detailed plain-text error messages which can be looked at in the ERROR menu via manual operation or queried via the GPIB using `SYSTem:ERRor?` command. Each call of `SYSTem:ERRor?` provides an entry from the error queue. If no error messages are stored there any more, the instrument responds with 0, "No error".

The error queue should be queried after every SRQ in the controller program as the entries describe the cause of an error more precisely than the status registers. Especially in the test phase of a controller program the error queue should be queried regularly since faulty commands from the controller to the instrument are recorded there as well.

Resetting Values of the Status Reporting System

Table 5-15 comprises the different commands and events causing the status reporting system to be reset. None of the commands, except for *RST and `SYSTem:PRESet` influences the functional instrument settings. In particular, DCL does not change the instrument settings.

Table 5-15 Resetting instrument functions

Event	Switching on supply voltage		DCL,SDC (Device Clear, Selected Device Clear)	*RST or SYSTem: PRESet	STATus: PRESet	*CLS
	Power-On-Status-Clear					
Effect	0	1				
Clear STB,ESR	—	yes	—	—	—	yes
Clear SRE,ESE	—	yes	—		—	—
Clear PPE	—	yes	—		—	—
Clear EVENTt parts of the registers	—	yes	—	—		yes
Clear Enable parts of all OPERation and QUEStionable registers, Fill Enable parts of all other registers with "1".	—	yes	—	—	yes	—
Fill PTRansition parts with "1" , Clear NTRansition parts	—	yes	—	—	yes	—
Clear error queue	yes	yes	—	—	—	yes
Clear output buffer	yes	yes	yes	1)	1)	1)
Clear command processing and input buffer	yes	yes	yes	—	—	—

1) Every command being the first in a command line, i.e., immediately following a <PROGRAM MESSAGE TERMINATOR> clears the output buffer.

6 Remote Control – Description of Commands

Introduction	6.3
Notation	6.4
Common Commands	6.7
ABORt Subsystem	6.11
CALCulate Subsystem	6.12
CALCulate:DELtmarker Subsystem	6.12
CALCulate:EVALuation Subsystem	6.22
CALCulate:LIMit Subsystem	6.23
CALCulate:LIMit:ACPower Subsystem	6.28
CALCulate:LIMit:CONTRol Subsystem	6.34
CALCulate:LIMit:LOWer Subsystem	6.36
CALCulate:LIMit:UPPer Subsystem	6.39
CALCulate:MARKer Subsystem	6.42
CALCulate:MARKer:FUNCTion Subsystem	6.52
CALCulate:MARKer:FUNCTion:ADEMod Subsystem	6.62
CALCulate:MARKer:FUNCTion:HARMonics Subsystem	6.64
CALCulate:MARKer:FUNCTion:POWer Subsystem	6.65
CALCulate:MARKer:FUNCTion:STRack Subsystem	6.71
CALCulate:MARKer:FUNCTion:SUMMery Subsystem	6.72
CALCulate:MATH Subsystem	6.84
CALCulate:PEAKsearch PSEarch Subsystem	6.86
CALCulate:SNOise Subsystem	6.87
CALCulate:STATistics Subsystem	6.88
CALCulate:THReshold Subsystem	6.92
CALCulate:UNIT Subsystem	6.94
CALibration Subsystem	6.95
CONFigure Subsystem	6.97
DIAGnostic Subsystem	6.101
DISPlay Subsystem	6.105
FETCh Subsystem	6.117
FORMat Subsystem	6.123
HCOPy Subsystem	6.124
INITiate Subsystem	6.130
INPut Subsystem	6.133
INSTrument Subsystem	6.137

MMEMory Subsystem	6.139
SENSe Subsystem	6.152
SENSe:AVERage Subsystem	6.152
SENSe:BANDwidth Subsystem	6.154
SENSe:CORRection Subsystem	6.158
SENSe:DETEctor Subsystem	6.167
SENSe:FILTer Subsystem	6.168
SENSe:FREQuency Subsystem	6.169
SENSe:LIST Subsystem	6.173
SENSe:MIXer Subsystem	6.184
SENSe:MPOWer Subsystem	6.188
SENSe:POWer Subsystem	6.192
SENSe:ROSCillator Subsystem	6.200
SENSe:SPURs Subsystem	6.202
SENSe:SWEep Subsystem	6.204
SENSe:VCO Subsystem	6.210
SOURce Subsystem	6.217
SOURce:EXTErnal Subsystem	6.223
STATus Subsystem	6.227
SYSTem Subsystem	6.240
TRACe Subsystem	6.251
General Trace Commands	6.251
Number and Format of the Measurement Values for the Different Operating Modes ...	6.254
TRACe:IQ Subsystem	6.256
TRIGger Subsystem	6.265
UNIT Subsystem	6.268
GPIB Commands of HP Models 856xE, 8566A/B, 8568A/B and 8594E	6.269
Introduction	6.269
Command Set of Models 8560E, 8561E, 8562E, 8563E, 8564E, 8565E, 8566A/B, 8568A/B, 8591E, 8594E, 71100C, 71200C, and 71209A	6.270
Special Features of the Syntax Parsing Algorithms for 8566A and 8568A Models	6.287
Special Behavior of Commands	6.288
Model-Dependent Default Settings	6.290
Data Output Formats	6.291
Trace Data Output Formats	6.291
Trace Data Input Formats	6.291
GPIB Status Reporting	6.292
Differences in GPIB Behavior between the FSP and the FSE Families of Instruments ...	6.293

Introduction

This chapter describes all remote control commands of the R&S FSUP in detail. For details on the notation of the remote control commands refer to [“Notation” on page 6.4](#).

Before sending a command sequence consisting of commands described in chapter 6, please make sure that the analyzer mode is active, by one of the following actions:

- Set the preset compatibility to the analyzer mode (`SYST:PRESET:COMP SAN` command).
- Perform a preset (`*RST`).
- Use the `INST:SEL SAN` command.

The remote control commands are sorted according to the subsystem they belong to. The following subsystems are included in this chapter:

- [“Common Commands” on page 6.7](#)
- [“ABORt Subsystem” on page 6.11](#)
- [“CALCulate Subsystem” on page 6.12](#)
- [“CALibration Subsystem” on page 6.95](#)
- [“DIAGnostic Subsystem” on page 6.101](#)
- [“DISPlay Subsystem” on page 6.105](#)
- [“FORMat Subsystem” on page 6.123](#)
- [“HCOPy Subsystem” on page 6.124](#)
- [“INITiate Subsystem” on page 6.130](#)
- [“INPut Subsystem” on page 6.133](#)
- [“INSTrument Subsystem” on page 6.137](#)
- [“MMEMory Subsystem” on page 6.139](#)
- [“SENSe Subsystem” on page 6.152](#)
- [“SOURce Subsystem” on page 6.217](#)
- [“STATus Subsystem” on page 6.227](#)
- [“SYSTem Subsystem” on page 6.240](#)
- [“TRACe Subsystem” on page 6.251](#)
- [“TRIGger Subsystem” on page 6.265](#)
- [“UNIT Subsystem” on page 6.268](#)

An alphabetical list of all remote commands is provided at the end of this chapter in section [“Alphabetical List of Remote Commands” on page 6.340](#). Additionally, a subset of remote commands of HP models is supported. These commands are listed in section [“GPIB Commands of HP Models 856xE, 8566A/B, 8568A/B and 8594E” on page 6.269](#).

For information on differences between the FSP and FSE families refer to section [“Differences in GPIB Behavior between the FSP and the FSE Families of Instruments” on page 6.293](#).

Notation

In the following sections, all commands implemented in the instrument are first listed in tables and then described in detail, arranged according to the command subsystems. The notation is adapted to the SCPI standard. The SCPI conformity information is included in the individual description of the commands.

Table of Commands

Command:	In the command column, the table provides an overview of the commands and their hierarchical arrangement (see indentations).
Parameter:	The parameter column indicates the requested parameters together with their specified range.
Unit:	The unit column indicates the base unit of the physical parameters.
Comment:	In the comment column an indication is made on: <ul style="list-style-type: none"> – whether the command does not have a query form, – whether the command has only one query form – whether the command is implemented only with a certain option of the instrument

Indentations

The different levels of the SCPI command hierarchy are represented in the table by means of indentations to the right. The lower the level, the further the indentation to the right. Please note that the complete notation of the command always includes the higher levels as well.

Example:

`SENSe:FREQuency:CENTer` is represented in the table as follows:

```
SENSe first level
  :FREQuency second level
    :CENTer third level
```

Individual description

The individual description contains the complete notation of the command. An example for each command, the *RST value and the SCPI information are included as well.

The operating modes for which a command can be used are indicated by the following abbreviations:

- A – analyzer
- A-F – analyzer - frequency domain only
- A-T – analyzer - time domain only (zero span)
- PNO – phase noise



Note

The analyzer and phase noise modes are implemented in the base unit. For the other modes, the corresponding options are required.

Upper/lower case notation Upper/lower case letters are used to mark the long or short form of the key words of a command in the description (see chapter [“Remote Control – Basics”](#)). The instrument itself does not distinguish between upper and lower case letters.

Special characters |

A selection of key words with an identical effect exists for several commands. These key words are indicated in the same line; they are separated by a vertical stroke. Only one of these key words needs to be included in the header of the command. The effect of the command is independent of which of the key words is used.

Example:

```
SENSe:FREQuency:CW|:FIXed
```

The two following commands with identical meaning can be created. They set the frequency of the fixed frequency signal to 1 kHz:

```
SENSe:FREQuency:CW 1E3 = SENSe:FREQuency:FIXed 1E3
```

A vertical stroke in parameter indications marks alternative possibilities in the sense of "or". The effect of the command is different, depending on which parameter is used.

Example: Selection of the parameters for the command

```
DISPlay:FORMat FULL | SPLit
```

If parameter FULL is selected, full screen is displayed, in the case of SPLit, split screen is displayed.

[]

Key words in square brackets can be omitted when composing the header (cf. chapter [“Remote Control – Basics”](#), section [“Optional key words” on page 5.12](#)). The full command length must be accepted by the instrument for reasons of compatibility with the SCPI standards.

Parameters in square brackets can be incorporated optionally in the command or omitted as well.

{ }

Parameters in braces can be incorporated optionally in the command, either not at all, once or several times.

Description of parameters

Due to the standardization, the parameter section of SCPI commands consists always of the same syntactical elements. SCPI has therefore specified a series of definitions, which are used in the tables of commands. In the tables, these established definitions are indicated in angled brackets (< to >) and will be briefly explained in the following (see also chapter [“Remote Control – Basics”](#), section [“Parameters” on page 5.14](#)).

<Boolean>

This key word refers to parameters which can adopt two states, "on" and "off". The "off" state may either be indicated by the key word **OFF** or by the numeric value 0, the "on" state is indicated by **ON** or any numeric value other than zero. Parameter queries are always returned the numeric value 0 or 1.

<numeric_value> These key words mark parameters which may be entered as numeric values or be
 <num> set using specific key words (character data).

The following key words given below are permitted:

- MINimum – This key word sets the parameter to the smallest possible value.
- MAXimum – This key word sets the parameter to the largest possible value.
- DEFault – This key word is used to reset the parameter to its default value.
- UP – This key word increments the parameter value.
- DOWN – This key word decrements the parameter value.

The numeric values associated to MAXimum/MINimum/DEFault can be queried by adding the corresponding key words to the command. They must be entered following the quotation mark.

Example:

```
SENSe:FREQuency:CENTer? MAXimum
```

returns the maximum possible numeric value of the center frequency as result.

<arbitrary block This key word is provided for commands the parameters of which consist of a binary
 program data> data block.

Common Commands

The common commands are taken from the IEEE 488.2 (IEC 625-2) standard. A particular command has the same effect on different devices. The headers of these commands consist of an asterisk "*" followed by three letters. Many common commands refer to the status reporting system which is described in detail in chapter "Remote Control – Basics".

Command	Parameter	Function	Comment
*CAL?		Calibration Query	query only
*CLS		Clear Status	no query
*ESE	0 to 255	Event Status Enable	
*ESR?		Standard Event Status Query	query only
*IDN?		Identification Query	query only
*IST?		Individual Status Query	query only
*OPC		Operation Complete	
*OPT?		Option Identification Query	query only
*PCB	0 to 30	Pass Control Back	no query
*PRE	0 to 255	Parallel Poll Register Enable	
*PSC	0 1	Power On Status Clear	
*RST		Reset	no query
*SRE	0 to 255	Service Request Enable	
*STB?		Status Byte Query	query only
*TRG		Trigger	no query
*TST?		Self Test Query	query only
*WAI		Wait to continue	no query

*CAL?

CALIBRATION QUERY initiates a calibration of the instrument and subsequently queries the calibration status. Any responses > 0 indicate errors.

*CLS

CLEAR STATUS sets the status byte (STB), the standard event register (ESR) and the EVENT-part of the QUEStionable and the OPERation register to zero. The command does not alter the mask and transition parts of the registers. It clears the output buffer.

*ESE 0 to 255

EVENT STATUS ENABLE sets the event status enable register to the value indicated. The query form *ESE? returns the contents of the event status enable register in decimal form.

*ESR?

STANDARD EVENT STATUS QUERY returns the contents of the event status register in decimal form (0 to 255) and subsequently sets the register to zero.

***IDN?**

IDENTIFICATION QUERY queries the instrument identification.

Example: " Rohde&Schwarz, R&S FSUP-26, 123456/789, 3.97"

R&S FSUP-26 = Device name

123456/789 = Serial number of the instrument

3.97 = Firmware version number

***IST?**

INDIVIDUAL STATUS QUERY returns the contents of the IST flag in decimal form (0 | 1). The IST flag is the status bit which is sent during a parallel poll (cf. chapter "[Remote Control – Basics](#)").

***OPC**

OPERATION COMPLETE sets bit 0 in the event status register when all preceding commands have been executed. This bit can be used to initiate a service request (cf. chapter "[Remote Control – Basics](#)").

***OPC?**

OPERATION COMPLETE QUERY writes message "1" into the output buffer as soon as all preceding commands have been executed (cf. chapter "[Remote Control – Basics](#)").

***OPT?**

OPTION IDENTIFICATION QUERY checks which options the instrument contains and returns a list of installed options. The individual options are separated by commas.

Position	Option	
1		reserved
2	B4	OCXO
3 to 7		reserved
8	B10	Ext. Generator Control
9 to 13		reserved
14		LAN Interface
15 to 18		reserved
19	B21	Ext. Mixer
20 to 22		reserved
23	B25	Electronic Attenuator
24 to 27		reserved
28	FS-K30	Noise Figure and Gain measurements
29		Phase Noise Tests

***TST?**

SELF TEST QUERY initiates the selftest of the instrument and outputs an error code in decimal form (0 = no error).

***WAI**

WAIT-to-CONTINUE permits servicing of subsequent commands only after all preceding commands have been executed and all signals have settled (cf. section [“*OPC” on page 6.8](#) and chapter [“Remote Control – Basics”](#)).

ABORt Subsystem

The ABORt subsystem contains the commands for aborting triggered actions. An action can be triggered again immediately after being aborted. All commands trigger events, and therefore they have no *RST value.

ABORt

This command aborts a current measurement and resets the trigger system.

Example: "ABOR; INIT: IMM"

Characteristics: *RST value: 0
SCPI: conform

Mode: PNO, A

CALCulate Subsystem

The CALCulate subsystem contains commands for converting instrument data, transforming and carrying out corrections. These functions are carried out subsequent to data acquisition, i.e. following the SENSE subsystem.

The numeric suffix is used in CALCulate to make the distinction between the two measurement windows SCREEN A and SCREEN B:

CALCulate1 = Screen A
CALCulate2 = Screen B.

For commands without suffix, screen A is selected automatically.

Full Screen The settings are valid for the measurement window selected with the numeric suffix. They become effective as soon as the corresponding measurement window has been selected as active measurement window using the command `DISPLay[:WINDow<1|2>]:SElect`. Triggering measurements and querying measured values is possible only in the active measurement window.

Split Screen The settings are valid for the measurement window selected by means of the numeric suffix and become effective immediately.

CALCulate:DELTamarker Subsystem

The CALCulate:DELTamarker subsystem controls the delta-marker functions in the instrument.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

CALCulate<1|2>:DELTamarker<1 to 4>[:STATe] ON | OFF

This command switches on and off the delta marker if delta marker 1 is selected. If marker 2, 3 or 4 is selected and used as a marker, it is switched to delta marker mode. If the corresponding marker is not activated, it will be activated and positioned on the maximum of the measurement curve. If no numeric suffix is indicated, delta marker 1 is selected automatically.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
 "`CALC:DELT3 ON`"
 'Switches marker 3 in screen A to delta marker mode.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:DELTamarker<1 to 4>:MODE ABSolute | RELative

This command switches between relative and absolute frequency input of the delta marker (or time with span = 0). It affects all delta markers independent of the measurement window.

Example: "`CALC:DELT:MODE ABS`"
 'Switches the frequency/time indication for all delta markers to absolute values.
 "`CALC:DELT:MODE REL`"
 'Switches the frequency/time indication for all delta markers to relative to marker 1.

Characteristics: *RST value: REL
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:AOFF

This command switches off all active delta markers.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
"CALC:DELT:AOFF"
'Switches off all delta markers in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:TRACe 1 to 3

This command assigns the selected delta marker to the indicated measurement curve. The selected measurement curve must be active, i.e. its state must be different from "BLANK".

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
"CALC:DELT3:TRAC 2"
'Assigns deltamarker 3 to trace 2 in screen A.

"CALC2:DELT:TRAC 3"
'Assigns delta marker 1 to trace 3 in screen B.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:DELTamarker<1 to 4>:X 0 to MAX (frequency | sweep time)

In analyzer mode, this command positions the selected delta marker in the indicated measurement window to the indicated frequency (span > 0), time (span = 0) or level (APD measurement = ON or CCDF measurement = ON). The input is in absolute values or relative to marker 1 depending on the command CALCulate:DELTamarker:MODE. If the reference fixed measurement (CALCulate:DELTamarker:FUNCTion:FIXed:STATE ON) is active, relative values refer to the reference position are entered. The query always returns absolute values.

In phase noise mode, this command positions the selected delta marker to the indicated frequency or time. The numeric suffix at CALCulate must be 1.

Example: for analyzer mode
 "CALC:DELT:MOD REL"
 'Switches the input for all delta markers to relative to marker 1.
 "CALC:DELT2:X 10.7MHz"
 'Positions delta marker 2 in screen A 10.7 MHz to the right of marker 1.
 "CALC2:DELT:X?"
 'Outputs the absolute frequency/time of delta marker 1 in screen B
 "CALC2:DELT:X:REL?"
 'Outputs the relative frequency/time/level of delta marker 1 in screen B

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:DELTaMarker<1 to 4>:X:RELative?

This command queries the frequency (span > 0) or time (span = 0) of the selected delta marker relative to marker 1 or to the reference position (for CALCulate:DELTaMarker:FUNCTion:FIXed:STATE ON). The command activates the corresponding delta marker, if necessary.

Example: "CALC:DELT3:X:REL?"
 'Outputs the frequency of delta marker 3 in screen B relative to marker 1 or relative to the reference position.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTaMarker<1 to 4>:X:SPUR?

This command queries whether the current delta marker is positioned on a spur.

Return value: 1 if the delta marker is positioned on a spur.
 0 if the delta marker is not positioned on a spur.

Example: "CALC:DELT:X:SPUR?"
 'Queries whether the current delta marker x position is on a spur.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO

This command is a query only and therefore has no *RST value.

CALCulate<1|2>:DELTaMarker<1 to 4>:Y 0 to MAX (frequency | sweep time)

This command positions the selected delta marker to the indicated Y position in the selected measurement window. The units for this command are dBc/Hz. The numeric suffix at CALCulate must be 1.

Example: "CALC:DELT:Y?"
 'Outputs the measured value of marker 1.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:DELTamarker<1 to 4>:Y?

This command queries the measured value of the selected delta marker in the indicated measurement window. The corresponding delta marker will be activated, if necessary. The output is always a relative value referred to marker 1 or to the reference position (reference fixed active).

To obtain a valid query result, a complete sweep with synchronization to the sweep end must be performed between the activation of the delta marker and the query of the y value. This is only possible in single-sweep mode.

Depending on the unit defined with `CALC:UNIT` or on the activated measuring functions, the query result is output in the units below:

- DBM | DBPW | DBUV | DBMV | DBUA: Output unit DB
- WATT | VOLT | AMPere: Output unit W | V | A
- Statistics function (APD or CCDF) on: Dimensionless output
- Result display: FM Hz
- Result display RF POWER: dB
- Result display SPECTRUM: dB

Example: for analyzer mode
`"INIT:CONT OFF"`
 'Switches to single-sweep mode.
`"CALC:DELT2 ON"`
 'Switches on delta marker 2 in screen A.
`"INIT;*WAI"`
 'Starts a sweep and waits for its end.
`"CALC:DELT2:Y?"`
 'Outputs measurement value of delta marker 2 in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum[:PEAK]

This command positions the specified delta marker to the current maximum value of the trace. If necessary, the corresponding delta marker will be activated first.

Example: for analyzer mode
`"CALC2:DELT3:MAX"`
 'Sets delta marker 3 in screen B to the maximum value of the associated trace.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:NEXT

This command positions the specified delta marker to the next smaller maximum value of the trace. The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC1 : DELT2 : MAX : NEXT"
'Sets delta marker 2 in screen A to the next smaller maximum value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:RIGHT

This command positions the specified delta marker to the next smaller maximum value to the right of the current value (i.e. ascending X values). The corresponding delta marker is activated first, if necessary.

Example: for analyzer mode
"CALC2 : DELT : MAX : RIGH"
'Sets delta marker 1 in screen B to the next smaller maximum value to the right of the current value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MAXimum:LEFT

This command positions the specified delta marker to the next smaller maximum value to the left of the current value (i.e. descending X values). The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC : DELT : MAX : LEFT"
'Sets delta marker 1 in screen A to the next smaller maximum value to the left of the current value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum[:PEAK]

This command positions the specified delta marker to the current minimum value of the trace. The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC2 : DELT3 : MIN"
'Sets delta marker 3 in screen B to the minimum value of the associated trace.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:NEXT

This command positions the specified delta marker to the next higher minimum value of the trace. The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC1:DELT2:MIN:NEXT"
'Sets delta marker 2 in screen A to the next higher minimum value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:RIGHT

This command positions the specified delta marker to the next higher minimum value to the right of the current value (i.e. ascending X values). The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC2:DELT:MIN:RIGHT"
'Sets delta marker 1 in screen B to the next higher minimum value to the right of the current value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:MINimum:LEFT

This command positions the specified delta marker to the next higher minimum value to the left of the current value (i.e. descending X values). The corresponding delta marker will be activated first, if necessary.

Example: for analyzer mode
"CALC:DELT:MIN:LEFT"
'Sets delta marker 1 in screen A to the next higher minimum to the left of the current value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:LINK ON | OFF

This command switches on and off a link of delta marker 1 to marker 1. If the link is switched on and the x-axis value of the marker 1 is changed, the delta marker 1 will follow on the same x-position.

The suffix at DELTmarker can only be 1 or not present, because the functionality is only available for marker 1 and delta marker 1.

Example: "CALC1:DELT1:LINK ON"
'Switches the link of marker1/delta marker 1 on.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCTion:FIXed[:STATe] ON | OFF

This command switches the relative measurement to a fixed reference value on or off. Marker 1 will be activated previously and a peak search will be performed, if necessary. If marker 1 is activated, its position becomes the reference point for the measurement. The reference point can then be modified with commands `CALCulate:DELTamarker:FUNCTion:FIXed:RPOint:X` and `to:RPOint:Y` independently of the position of marker 1 and of a trace. It is valid for all delta markers in the selected measurement window as long as the function is active.

Example: "CALC2:DELT:FUNC:FIX ON"
'Switches on the measurement with fixed reference value for all delta markers in screen B.

"CALC2:DELT:FUNC:FIX:RPO:X 128 MHZ"
'Sets the reference frequency in screen B to 128 MHz.

"CALC2:DELT:FUNC:FIX:RPO:Y 30 DBM"
'Sets the reference level in screen B to +30 dBm

Characteristics: *RST value: OFF
SCPI: device-specific.

Mode: A

**CALCulate<1|2>:DELTamarker<1 to 4>:FUNCTion:FIXed:RPOint:MAXimum[:PEAK]
<numeric_value>**

This command sets the reference point level for all delta markers in the selected measurement window for a measurement with fixed reference point (`CALC:DELT:FUNC:FIX:STAT ON`) to the peak of the selected trace.

For phase noise measurements (`CALCulate:DELTamarker:FUNCTion:PNOise:STATe ON`), the command defines a new reference point level for delta marker 2 in the selected measurement window.

Example: "CALC:DELT:FUNC:FIX:RPO:MAX"
'Sets the reference point level for the delta marker in screen A to the peak of the trace.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNction:FIXed:RPOint:Y <numeric_value>

This command defines a new reference point level for all delta markers in the selected measurement window for a measurement with fixed reference point. (CALCulate:DELTamarker:FUNction:FIXed:STATe ON).

For phase noise measurements (CALCulate:DELTamarker:FUNction:PNOise:STATe ON), the command defines a new reference point level for delta marker 2 in the selected measurement window.

Example: "CALC:DELT:FUNC:FIX:RPO:Y -10dBm"
'Sets the reference point level for delta markers in screen A to -10 dBm.

Characteristics: *RST value: - (FUNction:FIXed[:STATe] is set to OFF)
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:FUNction:FIXed:RPOint:Y:OFFSet <numeric_value>

This command defines an additional level offset for the measurement with fixed reference value (CALCulate:DELTamarker:FUNction:FIXed:STATe ON). For this measurement, the offset is included in the display of all delta markers of the selected measurement window.

For phase noise measurements (CALCulate:DELTamarker:FUNction:PNOise:STATe ON), the command defines an additional level offset which is included in the display of delta marker 2 in the selected measurement window.

Example: "CALC:DELT:FUNC:FIX:RPO:Y:OFFS 10dB"
'Sets the level offset for the measurement with fixed reference value or the phase noise measurement in screen A to 10 dB.

Characteristics: *RST value: 0 dB
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:FUNction:FIXed:RPOint:X <numeric_value>

This command defines a new reference frequency (span > 0) or time (span = 0) for all delta markers in the selected measurement window for a measurement with fixed reference value (CALCulate:DELTamarker:FUNction:FIXed:STATe ON).

For phase noise measurements (CALCulate:DELTamarker:FUNction:PNOise:STATe ON), the command defines a new reference frequency or time for delta marker 2 in the selected measurement window.

Example: "CALC2:DELT:FUNC:FIX:RPO:X 128MHz"
'Sets the reference frequency in screen B to 128 MHz.

Characteristics: *RST value: - (FUNction:FIXed[:STATe] is set to OFF)
SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCTion:PNOise:AUTO ON | OFF

This command adds an automatic peak search action for the reference fixed marker 1 at the end of each particular sweep. This function may be used for tracking of a drifting source whilst phase noise measurement. The delta marker 2 which shows the phase noise measurement result keeps the delta frequency value. Therefore the phase noise measurement in a certain offset is valid although the source is drifting. Only when the marker 2 is reaching the border of the span the delta marker value is adjusted to be within the span. Choose a larger span in such situations.

Example: "CALC:DELT:FUNC:PNO 1"
 'Switches the phase noise measurement on.
 "CALC:DELT:FUNC:PNO:AUTO ON"
 'Activates the automatic peak search.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

The suffix at DELTmarker is ignored.

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCTion:PNOise[:STATe] ON | OFF

This command switches on or off the phase noise measurement with all active delta markers in the selected measurement window. The correction values for the bandwidth and the log amplifier are taken into account in the measurement.

Marker 1 will be activated, if necessary, and a peak search will be performed. If marker 1 is activated, its position becomes the reference point for the measurement.

The reference point can then be modified with commands `CALCulate:DELTamarker:FUNCTion:FIXed:RPOint:X` and `...:RPOint:Y` independently of the position of marker 1 and of a trace (the same commands used for the measurement with fixed reference point).

The numeric suffix <1 to 4> with `DELTamarker` is not relevant for this command.

Example: "CALC:DELT:FUNC:PNO ON"
 'Switches on the phase noise measurement with all delta markers in screen A.
 "CALC:DELT:FUNC:FIX:RPO:X 128 MHZ"
 'Sets the reference frequency to 128 MHz.
 "CALC:DELT:FUNC:FIX:RPO:Y 30 DBM"
 'Sets the reference level to +30 dBm

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

CALCulate<1|2>:DELTamarker<1 to 4>:FUNCTion:PNOise:RESult?

This command queries the result of the phase noise measurement in the selected measurement window. The measurement will be switched on, if necessary.

Example: "CALC:DELT:FUNC:PNO:RES?"
 'Outputs the result of phase noise measurement of the selected delta marker in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate:EVALuation Subsystem

CALCulate<1|2>:EVALuation[:STATe] ON | OFF

This command specifies whether residual noise values are calculated over the entire trace or within a specified frequency range.

Parameter: ON: The residual noise values are calculated over the range specified by [CALCulate<1|2>:EVALuation:STARt](#) and [CALCulate<1|2>:EVALuation:STOP](#).
OFF: The results are calculated over the entire trace.

Example: "CALC:EVAL ON"
'Specifies that residual noise is calculated over the entire trace.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:EVALuation:STARt 0 to f_{\max}

This command specifies the start frequency for residual noise calculation if [CALCulate<1|2>:EVALuation\[:STATe\]](#) is switched ON. This command has no effect if [CALCulate<1|2>:EVALuation\[:STATe\]](#) is switched OFF.

Example: "CALC:EVAL:STAR 1KHZ"
'Specifies that residual noise is calculated starting from 1 MHz.

Characteristics: *RST value: 1 KHz
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:EVALuation:STOP 0 to f_{\max}

This command specifies the stop frequency for residual noise calculation if [CALCulate<1|2>:EVALuation\[:STATe\]](#) is switched ON. This command has no effect if [CALCulate<1|2>:EVALuation\[:STATe\]](#) is switched OFF.

Example: "CALC:EVAL:STOP 1MHZ"
'Specifies that residual noise is calculated up to 1 MHz.

Characteristics: *RST value: 1 MHz
SCPI: device-specific

Mode: PNO

CALCulate:LIMit Subsystem

The CALCulate:LIMit subsystem consists of the limit lines and the corresponding limit checks. Limit lines can be defined as upper or lower limit lines. The individual Y values of the limit lines correspond to the values of the x-axis (CONTRol). The number of X and Y values must be identical.

In analyzer mode, 8 limit lines can be active or checked at the same time (marked by LIMIT1 to LIMIT8) in screen A and/or screen B. The measurement windows is selected via CALCulate 1 (screen A) or 2 (screen B). The limit check can be switched on separately for each measurement screen and limit line. WINDow1 corresponds to screen A, WINDow2 to screen B.

In phase noise mode, up to 8 limit lines can be active (CALCulate<1|2>:LIMit<1 to 8>:STATe) or checked (CALCulate<1|2>:LIMit<1 to 8>:FAIL?) at the same time. Up to 100 limit lines can be defined (marked by LIMIT1 to LIMIT100). Only one measurement windows is available (full screen display), the numeric suffixes <1|2> of CALCulate are irrelevant.

Each limit line can be assigned a name (max. 8 letters) under which the line is stored in the instrument. An explanatory comment can also be given for each line (max. 40 characters).

Example (analyzer mode):

Definition and use of a new limit line 5 for trace 2 in screen A and trace 1 in screen B with the following features:

- upper limit line
- absolute x-axis in the frequency domain
- 5 ref. values: 126 MHz/-40 dB, 127 MHz/-40 dB, 128 MHz/-20 dB, 129 MHz/-40 dB, 130 MHz/-40 dB
- relative y-axis with unit dB
- absolute threshold value at -35 dBm
- no safety margin

Definition of the line (example for analyzer mode):

1. Defining the name: `CALC:LIM5:NAME 'TEST1'`
2. Entering the comment: `CALC:LIM5:COMM 'Upper limit line'`
3. Associated trace in screen A: `CALC1:LIM5:TRAC 2`
4. Associated trace in screen B: `CALC2:LIM5:TRAC 1`
5. Defining the x-axis range: `CALC:LIM5:CONT:DOM FREQ`
6. Defining the x-axis scaling: `CALC:LIM5:CONT:MODE ABS`
7. Defining the y-axis unit: `CALC:LIM5:UNIT DB`
8. Defining the y-axis scaling: `CALC:LIM5:UPP:MODE REL`
9. Defining the x-axis values: `CALC:LIM5:CONT 126MHZ, 127MHZ, 128MHZ, 129MHZ, 130MHZ`
10. Defining the y values: `CALC:LIM5:UPP -40, -40, -30, -40, -40`
11. Defining the y threshold value: `CALC:LIM5:UPP:THR -35DBM`

The definition of the safety margin and shifting in X and/or Y direction can take place as from here (see commands below).

Switching on and evaluating the line in screen A (example for analyzer mode):

1. Switching on the line in screen A: `CALC1:LIM5:UPP:STAT ON`
2. Switching on the limit check in screen A: `CALC1:LIM5:STAT ON`
3. Starting a new measurement with synchronization: `INIT;*WAI`
4. Querying the limit check result: `CALC1:LIM5:FAIL?`

Switching on and evaluating the line in screen B is performed in the same way by using `CALC2` instead of `CALC1`.

CALCulate<1|2>:LIMit<1...8>:ACTive?

This commands queries the names of all active limit lines. The numeric suffixes at `CALCulate<1|2>` and `LIMit<1...8>` are ignored.

Return value: The return values are sorted in alphabetic order. If no limit line is active, an empty string is returned.

Example: `"CALC:LIM:ACT?"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is a query only and therefore has no *RST value.

CALCulate<1|2>:LIMit<1 to 8>:CATalog?

This command queries all the names of the limit lines saved on the hard disc.

Up to 8 limit lines can be defined at the same time. The numeric suffixes `<1|2>` of `CALCulate` indicate the measurement window.

Return value: The syntax of the return values is:
<sum of file length of all following files>, <free spaces on hard disc>, <1st file name>, <1st file length>, <2nd file name>, <2 nd file length>,, <n th file name>, <nth file length>

Example: `"CALC:LIM:CAT?"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is a query only and therefore has no *RST value.

CALCulate<1|2>:LIMit<1 to n>:TRACe 1 to 3

This command assigns a limit line to a trace.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix `n = 8`). The numeric suffixes `<1|2>` of `CALCulate` indicate the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix `n = 100`). The numeric suffixes `<1|2>` of `CALCulate` are irrelevant.

Example: for analyzer mode
`"CALC:LIM2:TRAC 3"`
 'Assigns limit line 2 to trace 3 in screen A.
`"CALC2:LIM2:TRAC 1"`
 'Assigns limit line 2 to trace 1 in screen B at the same time.

Characteristics: *RST value: 1
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to 8>:STATe ON | OFF

This command switches on or off the limit check for the selected limit line.

The result of the limit check can be queried with `CALCulate<1|2>:LIMit<1 to 8>:FAIL?`.

In analyzer mode, up to 8 limit lines can be defined and activated at the same time. The numeric suffixes <1|2> of CALCulate indicate the measurement window.

In phase noise mode, up to 100 limit lines can be defined, but only 8 limit lines may be activated or checked at the same time. The numeric suffixes <1|2> of CALCulate are irrelevant.

Example: for analyzer mode
`"CALC:LIM:STAT ON"`
 'Switches on the limit check for limit line 1 in screen A.
`"CALC2:LIM:STAT OFF"`
 'Switches off the limit check for limit line 1 in screen B.

Characteristics: *RST value: OFF
 SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:UNIT DBM | DBCHZ | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | DB | DEG | RAD | S | HZ | PCT | UNITLESS

This command defines the unit for the associated limit line.

The definition is valid regardless of the measurement window.

Specification of the DB unit automatically switches the limit line over to relative mode. Units other than DB cause the limit line to switch over to absolute mode.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). All units except DEG, RAD, S, HZ, PCT, DBCHZ are available.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). Only the units PCT, HZ, DBM, DBCHZ (dBc/Hz), RAD, DBC, DEG are available.

Example: for phase noise mode
`"CALC:LIM4:UNIT DBCHZ"`
 'Sets the unit of limit line 4 to dBc/Hz.

Characteristics: *RST value: DBM (analyzer mode), DBCHZ (phase noise mode)
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to 8>:FAIL?

This command queries the result of the limit check of the limit line. It should be noted that a complete sweep must have been performed for obtaining a valid result. A synchronization with *OPC, *OPC? or *WAI should therefore be provided.

In analyzer mode, up to 8 limit lines can be defined and checked at the same time. The numeric suffixes <1|2> of CALCulate indicate the measurement window. The result of the limit check responds with 0 for PASS, 1 for FAIL, and 2 for MARGIN.

In phase noise mode, up to 100 limit lines can be defined, but only 8 limit lines may be activated or checked at the same time. The numeric suffixes <1|2> of CALCulate are irrelevant. The result of the limit check responds with 0 for PASS and 1 for FAIL.

Example: for analyzer mode
 "INIT;*WAI"
 'Starts a new sweep and waits for its end.
 "CALC2:LIM3:FAIL?"
 'Queries the result of the check for limit line 3 in screen B.

Characteristics: *RST value: -
 SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:CLEar[:IMMediate]

This command deletes the result of the current limit check for all limit lines.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The numeric suffixes <1|2> of CALCulate indicate the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant.

This command is an event and therefore has no *RST value.

Example: for analyzer mode
 "CALC:LIM:CLE"
 'Deletes the result of the limit check in screen A.

Characteristics: *RST value: -
 SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:COMMent <string>

This command defines a comment for the limit line selected (max. 40 characters).

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The comment is independent from the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant.

Example: "CALC:LIM5:COMM 'Upper limit for spectrum'"
 'Defines the comment for limit line 5.

Characteristics: *RST value: blank comment
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:COPY 1 to n | <name>

This command copies one limit line onto another one.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The command is independent from the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). To activate or check a line with suffix > 8, copy it to into a limit line with suffix <1 to 8> using this command. The numeric suffixes <1|2> of CALCulate are irrelevant.

Parameter: 1 to n ::= number of the new limit line or
<name> ::= name of the new limit line given as a string

Example: "CALC:LIM1:COPY 2"
'Copies limit line 1 to line 2.

"CALC:LIM1:COPY 'FM2'"
'Copies limit line 1 to a new line named 'FM2'.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:LIMit<1 to n>:NAME <name of limit line>

This command assigns a name to a limit line. If it does not exist already, a limit line with this name is created.

The name of the limit line may contain a maximum of 8 characters.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The command is independent from the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant.

Example: "CALC:LIM1:NAME 'FM1'"
'Assigns the name 'FM1' to limit line 1.

Characteristics: *RST value: 'REM1' to 'REM8' for lines 1 to 8 (analyzer mode), 'REM1' to 'REM100'
for lines 1 to 100 (phase noise mode)
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:DELeTe

This command deletes the selected limit line.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The command is independent from the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant.

Example: "CALC:LIM1:DEL"
'Deletes limit line 1.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate:LIMit<1 to 100>:COMPAtible?

This command queries the compatibility flag of the indicated limit line. The result of the limit check responds with 0 for not compatible and 1 for compatible.

A limit line is marked as not compatible if the limit line domain/units are not compatible with the current measurement type. In such cases, correct the domain/unit for the limit line or the current measurement type to make the limit line compatible.

Example: "CALC:LIM3:COMP?"
'Queries the compatibility flag for limit line 3.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

This command is a query only and therefore has no *RST value.

CALCulate:LIMit:ACPower Subsystem

The CALCulate:LIMit:ACPower subsystem defines the limit check for adjacent channel power measurement.

CALCulate<1|2>:LIMit<1 to 8>:ACPower[:STATe] ON | OFF

This command switches on and off the limit check for adjacent channel power measurements in the selected measurement window. The commands `CALCulate:LIMit:ACPower:ACHannel:STATe` or `CALCulate:LIMit:ACPower:ALternate:STATe` must be used in addition to specify whether the limit check is to be performed for the upper/lower adjacent channel or for the alternate adjacent channels.

The numeric suffixes <1 to 8> are irrelevant for this command.

Example: "CALC:LIM:ACP ON"
'Switches on the ACP limit check in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPower:ACHannel[:RELative] 0 to 100dB, 0 to 100dB

This command defines the relative limit of the upper/lower adjacent channel for adjacent channel power measurements in the selected measurement window. The reference value for the relative limit value is the measured channel power.

It should be noted that the relative limit value has no effect on the limit check as soon as it is below the absolute limit value defined with `CALCulate:LIMit:ACPower:ACHannel:ABSolute`. This mechanism allows automatic checking of the absolute basic values of adjacent channel power as defined in mobile radio standards.

The numeric suffixes <1 to 8> are irrelevant for this command.

Parameter:	The first numeric value is the limit for the upper (lower) adjacent channel. The second value is ignored but must be indicated for reasons of compatibility with the FSE family.
Example:	"CALC:LIM:ACP:ACH 30DB, 30DB" 'Sets the relative limit value in screen A for the power in the lower and upper adjacent channel to 30 dB below the channel power.
Characteristics:	*RST value: 0 dB SCPI: device-specific
Mode:	A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ACHannel[:RELative]:STATe ON | OFF

This command activates the limit check for the relative limit value of the adjacent channel when adjacent channel power measurement is performed. Before the command, the limit check must be activated using `CALCulate:LIMit:ACPpower:STATe ON`.

The result can be queried with `CALCulate:LIMit:ACPpower:ACHannel:RESult?`. It should be noted that a complete measurement must be performed between switching on the limit check and the result query, since otherwise no valid results are available.

The numeric suffixes <1 to 8> are irrelevant for this command.

Example:	"CALC:LIM:ACP:ACH 30DB, 30DB" 'Sets the relative limit value in screen A for the power in the lower and upper adjacent channel to 30 dB below the channel power.
	"CALC:LIM:ACP:ACH:ABS -35DBM, -35DBM" 'Sets the absolute limit value in screen A for the power in the lower and upper adjacent channel to -35 dBm.
	"CALC:LIM:ACP ON" 'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.
	"CALC:LIM:ACP:ACH:REL:STAT ON" 'Switches on the check of the relative limit values for adjacent channels in screen A.
	"CALC:LIM:ACP:ACH:ABS:STAT ON" 'Switches on the check of absolute limit values for the adjacent channels in screen A.
	"INIT;*WAI" 'Starts a new measurement and waits for the sweep end.
	"CALC:LIM:ACP:ACH:RES?" 'Queries the limit check result in the adjacent channels in screen A.
Characteristics:	*RST value: OFF SCPI: device-specific
Mode:	A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ACHannel:ABSolute -200DBM to 200DBM, -200 to 200DBM

This command defines the absolute limit value for the lower/upper adjacent channel during adjacent channel power measurement (Adjacent Channel Power) in the selected measurement window.

It should be noted that the absolute limit value has no effect on the limit check as soon as it is below the relative limit value defined with `CALCulate:LIMit:ACPpower:ACHannel:RELative`. This mechanism allows automatic checking of the absolute basic values of adjacent channel power as defined in mobile radio standards.

The numeric suffixes <1 to 8> in LIMit are irrelevant for this command.

Parameter: The first value is the limit for the lower and the upper adjacent channel. The second limit value is ignored but must be indicated for reasons of compatibility with the FSE family.

Example: `"CALC:LIM:ACP:ACH:ABS -35DBM, -35DBM"`
'Sets the absolute limit value in screen A for the power in the lower and upper adjacent channel to -35 dBm.

Characteristics: *RST value: -200DBM
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ACHannel:ABSolute:STATe ON | OFF

This command activates the limit check for the adjacent channel when adjacent channel power measurement (Adjacent Channel Power) is performed. Before the command, the limit check for the channel/adjacent channel measurement must be globally switched on using `CALC:LIM:ACP ON`.

The result can be queried with `CALCulate:LIMit:ACPpower:ACHannel:RESult?`. It should be noted that a complete measurement must be performed between switching on the limit check and the result query, since otherwise no valid results are available.

The numeric suffixes <1 to 8> in LIMit are irrelevant for this command.

Example: `"CALC:LIM:ACP:ACH 30DB, 30DB"`
'Sets the relative limit value in screen A for the power in the lower and upper adjacent channel to 30 dB below the channel power.

`"CALC:LIM:ACP:ACH:ABS -35DBM, -35DBM"`
'Sets the absolute limit value in screen A for the power in the lower and upper adjacent channel to -35 dBm.

`"CALC:LIM:ACP ON"`
'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.

`"CALC:LIM:ACP:ACH:REL:STAT ON"`
'Switches on the check of the relative limit values for adjacent channels in screen A.

`"CALC:LIM:ACP:ACH:ABS:STAT ON"`
'Switches on the check of absolute limit values for the adjacent channels in screen A.

`"INIT;*WAI"`
'Starts a new measurement and waits for the sweep end.

`"CALC:LIM:ACP:ACH:RES?"`
'Queries the limit check result in the adjacent channels in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ACHannel:RESult?

This command queries the result of the limit check for the upper/lower adjacent channel in the selected measurement window when adjacent channel power measurement is performed.

If the power measurement of the adjacent channel is switched off, the command produces a query error.

The numeric suffixes <1 to 8> are irrelevant for this command.

Parameter: The result is returned in the form <result>, <result> where <result> = PASSED | FAILED, and where the first returned value denotes the lower, the second denotes the upper adjacent channel.

Example:

```
"CALC:LIM:ACP:ACH 30DB, 30DB"
'Sets the relative limit value in screen A for the power in the lower and upper adjacent channel to 30 dB below the channel power.
```

```
"CALC:LIM:ACP:ACH:ABS -35DBM, -35DBM"
'Sets the absolute limit value in screen A for the power in the lower and upper adjacent channel to -35 dB.
```

```
"CALC:LIM:ACP ON"
'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.
```

```
"CALC:LIM:ACP:ACH:STAT ON"
'Switches on the limit check for the adjacent channels in screen A.
```

```
"INIT;*WAI"
'Starts a new measurement and waits for the sweep end.
```

```
"CALC:LIM:ACP:ACH:RES?"
'Queries the limit check result in the adjacent channels in screen A.
```

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

This command is a query and therefore has no *RST value.

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ALternate<1 to 11>[:RELative] 0 to 100dB, 0 to 100dB.

This command defines the limit for the alternate adjacent channels in the selected measurement window for adjacent channel power measurements. The reference value for the relative limit value is the measured channel power.

The numeric suffix after ALternate<1 to 11> denotes the alternate channel. The numeric suffixes <1 to 8> are irrelevant for this command.

It should be noted that the relative limit value has no effect on the limit check as soon as it is below the absolute limit defined with CALCulate:LIMit:ACPpower:ALternate<1 to 11>:ABSolute. This mechanism allows automatic checking of the absolute basic values of adjacent channel power as defined in mobile radio standards.

Parameter: The first value is the limit for the lower and the upper alternate adjacent channel. The second limit value is ignored but must be indicated for reasons of compatibility with the FSE family.

Example: "CALC:LIM:ACP:ALT2 30DB, 30DB"
 'Sets the relative limit value in screen A for the power in the lower and upper alternate adjacent channel to 30 dB below the channel power.

Characteristics: *RST value: 0DB
 SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ALternate<1 to 11>[:RELative]:STATe ON | OFF

This command activates the limit check for the alternate adjacent channels in the selected measurement window for adjacent channel power measurements. Before the command, the limit check must be activated using CALCulate:LIMit:ACPpower:STATe ON.

The numeric suffix after ALternate<1 to 11> denotes the alternate channel. The numeric suffixes <1 to 8> are irrelevant for this command.

The result can be queried with CALCulate:LIMit:ACPpower:ALternate<1 to 11>:RESult?. It should be noted that a complete measurement must be performed between switching on the limit check and the result query, since otherwise no valid results are obtained.

Example: "CALC:LIM:ACP:ALT2 30DB, 30DB"
 'Sets the relative limit value in screen A for the power in the lower and upper second alternate adjacent channel to 30 dB below the channel power.

"CALC:LIM:ACP:ALT2:ABS -35DBM, -35DBM"
 'Sets the absolute limit value in screen A for the power in the lower and upper second alternate adjacent channel to -35 dBm.

"CALC:LIM:ACP ON"
 'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.

"CALC:LIM:ACP:ACH:REL:STAT ON"
 'Switches on the check of the relative limit values for the alternate adjacent channels in screen A.

"CALC:LIM:ACP:ACH:ABS:STAT ON"
 'Switches on the check of absolute limit values for the alternate adjacent channels in screen A.

"INIT;*WAI"
 'Starts a new measurement and waits for the sweep end.

"CALC:LIM:ACP:ACH:RES?"
 'Queries the limit check result in the second alternate adjacent channels in screen A.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ALternate<1 to 11>:ABSolute -200DBM to 200DBM, -200DBM to 200DBM

This command defines the absolute limit value for the lower/upper alternate adjacent channel power measurement (Adjacent Channel Power) in the selected measurement window.

The numeric suffix after ALternate<1 to 11> denotes the alternate channel. The numeric suffixes <1 to 8> are irrelevant for this command.

It should be noted that the absolute limit value for the limit check has no effect as soon as it is below the relative limit value defined with `CALCulate:LIMit:ACPower:ALternate<1 to 11>:RELative`. This mechanism allows automatic checking of the absolute basic values defined in mobile radio standards for the power in adjacent channels.

Parameter: The first value is the limit for the lower and the upper alternate adjacent channel. The second limit value is ignored but must be indicated for reasons of compatibility with the FSE family.

Example: `"CALC:LIM:ACP:ALT2:ABS -35DBM, -35DBM"`
'Sets the absolute limit value in screen A for the power in the lower and upper second alternate adjacent channel to -35 dBm.

Characteristics: *RST value: -200DBM
SCPI: device-specific

Mode: A

`CALCulate<1|2>:LIMit<1 to 8>:ACPower:ALternate<1 to 11>:ABSolute:STATe` ON | OFF

This command activates the limit check for the alternate adjacent channels in the selected measurement window for adjacent channel power measurement (Adjacent Channel Power).

Before the command, the limit check must be globally switched on for the channel/adjacent channel power with the command `CALCulate:LIMit:ACPower:STATe` ON.

The numeric suffix after `ALternate<1 to 11>` denotes the alternate channel. The numeric suffixes `<1 to 8>` are irrelevant for this command.

The result can be queried with `CALCulate:LIMit:ACPower:ALternate<1 to 11>:RESult?`. It should be noted that a complete measurement must be performed between switching on the limit check and the result query, since otherwise no valid results are available.

Example: `"CALC:LIM:ACP:ALT2 30DB, 30DB"`
'Sets the relative limit value in screen A for the power in the lower and upper second alternate adjacent channel to 30 dB below the channel power.

`"CALC:LIM:ACP:ALT2:ABS -35DBM, -35DBM"`
'Sets the absolute limit value in screen A for the power in the lower and upper second alternate adjacent channel to -35 dBm.

`"CALC:LIM:ACP ON"`
'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.

`"CALC:LIM:ACP:ACH:REL:STAT ON"`
Switches on the check of the relative limit values for the alternative adjacent channels in screen A.

`"CALC:LIM:ACP:ACH:ABS:STAT ON"`
'Switches on the check of absolute limit values for the alternative adjacent channels in screen A.

`"INIT;*WAI"`
'Starts a new measurement and waits for the sweep end.

`"CALC:LIM:ACP:ACH:RES?"`
'Queries the limit check result in the second alternate adjacent channels in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:ACPpower:ALTErnate<1 to 11>:RESult?

This command queries the result of the limit check for the alternate adjacent channels in the selected measurement window for adjacent channel power measurements.

The numeric suffix after ALTErnate<1 to 11> denotes the alternate channel. The numeric suffixes <1 to 8> are irrelevant for this command.

If the power measurement of the adjacent channel is switched off, the command produces a query error.

Parameter: The result is returned in the form <result>, <result> where <result> = PASSED | FAILED and where the first (second) returned value denotes the lower (upper) alternate adjacent channel.

Example:

```
"CALC:LIM:ACP:ALT2 30DB, 30DB"
```

'Sets the relative limit value in screen A for the power in the lower and upper second alternate adjacent channel to 30 dB below the channel power.

```
"CALC:LIM:ACP:ALT2:ABS -35DBM, -35DBM"
```

'Sets the absolute limit value in screen A for the power in the lower and upper second alternate adjacent channel to -35 dBm.

```
"CALC:LIM:ACP ON"
```

'Switches on globally the limit check for the channel/adjacent channel measurement in screen A.

```
"CALC:LIM:ACP:ALT:STAT ON"
```

'Switches on the limit check for the adjacent channels in screen A.

```
"INIT;*WAI"
```

'Starts a new measurement and waits for the sweep end.

```
"CALC:LIM:ACP:ALT:RES?"
```

'Queries the limit check result in the second alternate adjacent channels in screen A.

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

This command is a query and therefore has no *RST value.

CALCulate:LIMit:CONTRol Subsystem

The CALCulate:LIMit:CONTRol subsystem defines the x-axis (CONTRol-axis).

CALCulate<1|2>:LIMit<1 to n>:CONTRol[:DATA] <numeric_value>,<numeric_value>..

This command defines the x-axis values (frequencies or times) of the upper or lower limit lines.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The values are defined independently of the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant. The number of values for the CONTROL axis and for the corresponding UPPER and/or LOWER limit lines have to be identical. Otherwise default values are entered for missing values or not required values are deleted.

Example: "CALC:LIM2:CONT 1MHz,30MHz,100MHz, 300MHz,1GHz"
'Defines 5 reference values for the x-axis of limit line 2

"CALC:LIM2:CONT?"
'Outputs the reference values for the x-axis of limit line 2 separated by a comma.

Characteristics: *RST value: - (LIMIT:STATE is set to OFF)
SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMIT<1 to n>:CONTROL:DOMAIN FREQUENCY | TIME

This command defines the frequency or time domain for the x-axis values.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8).

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant.

Example: "CALC:LIM2:CONT:DOM TIME"
'Defines the time domain for the x-axis of limit line 2.

Characteristics: *RST value: FREQUENCY
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:LIMIT<1 to 8>:CONTROL:OFFSET <numeric_value>

This command defines an offset for the x-axis value of the selected relative limit line in the frequency or time domain.

The unit of values depends on the frequency or time domain of the x-axis, i.e. it is HZ with CALC:LIM:CONT:DOM FREQ and S with CALC:LIM:CONT:DOM TIME.

Example: "CALC:LIM2:CONT:OFFS 100us"
'Sets the X offset for limit line 2 (defined in the time domain) to 100µs.

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMIT<1 to 8>:CONTROL:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the x-axis of the selected limit line. The definition is independent of the measurement window.

Example: "CALC:LIM2:CONT:MODE REL"
'Defines the x-axis of limit line 2 as relatively scaled.

Characteristics: *RST value: ABSolute
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to n>:CONTRol:SHIFt <numeric_value>

This command moves a limit line by the indicated value in x direction. In contrast to `CALC:LIM:CONT:OFFS`, the line is shifted by modifying the individual x values and not by means of an additive offset. The shift is independent of the measurement window.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8).

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of `CALCulate` are irrelevant.

Example: `"CALC:LIM2:CONT:SHIF 50KHZ"`
 'Shifts all reference values of limit line 2 by 50 kHz.

Characteristics: *RST value: --
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:LIMit<1 to 8>:CONTRol:SPACing LINear | LOGarithmic

This command selects linear or logarithmic interpolation for the calculation of limit lines from frequency points.

Example: `"CALC:LIM:CONT:SPAC LIN"`

Characteristics: *RST value: LIN
 SCPI: device-specific

Mode: A

CALCulate:LIMit:LOWer Subsystem

The `CALCulate:LIMit:LOWer` subsystem defines the lower limit line.

If a set command is issued in this subsystem, the specified limit line is automatically converted to a lower limit line.

CALCulate<1|2>:LIMit<1 to n>:LOWer[:DATA] <numeric_value>,<numeric_value>...

This command defines the values for the selected lower limit line.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The units DEG, RAD, S, HZ, PCT are not available. This command is independent of the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of `CALCulate` are irrelevant.

The number of values for the `CONTRol` axis and for the corresponding `LOWer` limit line has to be identical. Otherwise default values are entered for missing values or not necessary values are deleted. If the measured values are smaller than the `LOWer` limit line, the limit check signals errors.

The units HZ, DBM, RAD, PCT, DBC/HZ are available.

The unit must be identical with the unit selected by `CALC:LIM:UNIT`. If no unit is indicated, the unit defined with `CALC:LIM:UNIT` is automatically used.

Example: `"CALC:LIM2:LOW -30,-40,-10,-40,-30"`
 'Defines 5 lower limit values for limit line 2 in the preset unit.

 `"CALC:LIM2:LOW?"`
 'Outputs the lower limit values of limit line 2 separated by a comma.

Characteristics: *RST value: - (LIMit:STATe is set to OFF)
SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:LOWer:STATe ON | OFF

This command switches on or off the indicated limit line. The limit check is activated separately with `CALC:LIM:STAT ON`.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix $n = 8$). The numeric suffixes <1|2> of CALCulate indicate the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix $n = 100$). The numeric suffixes <1|2> of CALCulate are irrelevant. The result of the limit check can be queried with `CALCulate:LIMit<1 to 8>:FAIL?`.

Example: for analyzer mode
`"CALC:LIM4:LOW:STAT ON"`
 'Switches on limit line 4 (lower limit) in screen A.
`"CALC2:LIM4:LOW:STAT ON"`
 'Switches on limit line 4 (lower limit) also in screen B.

Characteristics: *RST value: OFF
SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to 8>:LOWer:OFFSet <numeric_value>

This command defines an offset for the y-axis of the selected relative lower limit line. In contrast to `CALC:LIM:LOW:SHIFT`, the line is not shifted by modifying the individual Y values but by means of an additive offset. The offset is independent of the measurement window.

Example: `"CALC:LIM2:LOW:OFFS 3dB"`
 'Shifts limit line 2 in the corresponding measurement windows by 3 dB upwards.

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:LOWer:MARGin <numeric_value>

This command defines a margin to a lower limit line, at which out-of-limit values are signaled (if the limit check is active), but not handled as a violation of the limit value. The margin is independent of the measurement window.

Example: `"CALC:LIM:LOW:MARG 10dB"`

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:LOWer:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the y-axis of the selected lower limit line. The setting is independent of the measurement window.

Selecting RELative causes the unit to be switched to DB.

Example: "CALC:LIM:LOW:MODE REL"
'Defines the y-axis of limit line 2 as relative scaled.

Characteristics: *RST value: ABSolute
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to n>:LOWer:SHIFt <numeric_value>

This command shifts a limit line by the indicated value in Y direction. In contrast to CALC:LIM:LOW:OFFS, the line is shifted by modifying the individual Y values but not by means of an additive offset.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The units DEG, RAD, S, HZ, PCT are not available. The shift is independent of the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant. The units HZ, DBM, RAD, PCT, DBC/HZ are available.

Example: for analyzer mode
"CALC:LIM3:LOW:SHIF 20DB"
'Shifts all Y values of limit line 3 by 20 dB.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:LIMit<1 to 8>:LOWer:SPACing LINear | LOGarithmic

This command selects linear or logarithmic interpolation for the lower limit line.

Example: "CALC:LIM:LOW:SPAC LIN"

Characteristics: *RST value: LIN
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:LOWer:THReshold <numeric_value>

This command defines an absolute threshold value for limit lines with relative y-axis scaling independently of the measurement window. The absolute threshold value is used in the limit check as soon as it exceeds the relative limit value.

The unit must correspond to the unit selected with CALC:LIM:UNIT (except dB which is not allowed). If no unit is indicated, the unit defined with CALC:LIM:UNIT is automatically used (exception: dBm instead of dB).

In analyzer mode, the units DEG, RAD, S, HZ, PCT are not available.

Example: "CALC:LIM2:LOW:THR -35DBM"
'Defines an absolute threshold value for limit line 2.

Characteristics: *RST value: -200 dBm
SCPI: device-specific

Mode: A

CALCulate:LIMit:UPPer Subsystem

The CALCulate:LIMit:UPPer subsystem defines the upper limit line.

CALCulate<1|2>:LIMit<1 to n>:UPPer[:DATA] <numeric_value>,<numeric_value>...

This command defines the values for the upper limit lines.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The units DEG, RAD, S, HZ, PCT are not available. This command is independent of the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant. The units HZ, DBM, RAD, PCT, DBC/HZ are available.

The number of values for the CONTRol axis and for the corresponding UPPer and/or LOWEr limit line have to be identical. Otherwise default values are entered for missing values or not necessary values are deleted.

The unit must be identical with the unit selected by CALC:LIM:UNIT. If no unit is indicated, the unit defined with CALC:LIM:UNIT is automatically used.

Example: "CALC:LIM2:UPP -10,0,0,-10,-5"
'Defines 5 upper limit values for limit line 2 in the preset unit.
"CALC:LIM2:UPP?"
'Outputs the upper limit values for limit line 2 separated by a comma.

Characteristics: *RST value: - (LIMit:STATe is set to OFF)
SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to n>:UPPer:STATe ON | OFF

This command switches on or off the indicated limit line. The limit check is activated separately with CALC:LIM:STAT ON.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The numeric suffixes <1|2> of CALCulate indicate the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant. The limit check is activated separately with CALC:LIM:STAT ON.

Example: for analyzer mode
"CALC1:LIM4:UPP:STAT ON"
'Switches on limit line 4 (upper limit) in screen A.
"CALC2:LIM4:UPP:STAT ON"
'Switches on limit line 4 (upper limit) in screen B.

Characteristics: *RST value: OFF
SCPI: conform

Mode: PNO, A

CALCulate<1|2>:LIMit<1 to 8>:UPPer:OFFSet <numeric_value>

This command defines an offset for the y-axis of the selected relative upper limit line. In contrast to CALC:LIM:UPP:SHIFt, the line is not shifted by modifying the individual Y values but by means of an additive offset. The offset is independent of the measurement window.

Example: "CALC:LIM2:UPP:OFFS 3dB"
'Shifts limit line 2 by 3 dB upwards in the corresponding measurement windows.

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:UPPer:MARGin <numeric_value>

This command defines a margin to an upper limit line, at which out-of-limit values are signaled (if the limit check is active), but not handled as a violation of the limit value. The margin is independent of the measurement window.

Example: "CALC:LIM2:UPP:MARG 10dB"
'Defines the margin of limit line 2 to 10 dB below the limit value.

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:UPPer:MODE RELative | ABSolute

This command selects the relative or absolute scaling for the y-axis of the selected upper limit line. The setting is independent of the measurement window.

Selecting RELative causes the unit to be switched to DB.

Example: "CALC:LIM2:UPP:MODE REL"
'Defines the y-axis of limit line 2 as relative scaled.

Characteristics: *RST value: ABSolute
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to n>:UPPer:SHIFt <numeric_value>

This command moves a limit line by the indicated value in Y direction. In contrast to CALC:LIM:UPP:OFFS, the line is shifted by modifying the individual Y values and not by means of an additive offset.

In analyzer mode, up to 8 limit lines can be defined at the same time (numeric suffix n = 8). The units DEG, RAD, S, HZ, PCT are not available. The shift is independent of the measurement window.

In phase noise mode, up to 100 limit lines can be defined at the same time (numeric suffix n = 100). The numeric suffixes <1|2> of CALCulate are irrelevant. The units HZ, DBM, RAD, PCT, DBC/HZ are available.

Example: for analyzer mode
"CALC:LIM3:UPP:SHIF 20DB"
'Shifts all Y values of limit line 3 by 20 dB.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:LIMit<1 to 8>:UPPer:SPACing LINear | LOGarithmic

This command selects linear or logarithmic interpolation for the upper limit line.

Example: "CALC:LIM:UPP:SPAC LIN"

Characteristics: *RST value: LIN
SCPI: device-specific

Mode: A

CALCulate<1|2>:LIMit<1 to 8>:UPPer:THReshold <numeric_value>

This command defines an absolute threshold value for limit lines with relative y-axis scaling independently of the measurement window. The absolute threshold value is used in the limit check as soon as it exceeds the relative limit value.

The unit must correspond to the unit selected with `CALC:LIM:UNIT` (except dB which is not possible). If no unit is indicated, the unit defined with `CALC:LIM:UNIT` is automatically used (exception: dBm instead of dB).

In analyzer mode, the units DEG, RAD, S, HZ, PCT are not available.

Example: "CALC:LIM2:UPP:THR -35DBM"
'Defines an absolute threshold value for limit line 2.

Characteristics: *RST value: -200 dBm
SCPI: device-specific

Mode: A

CALCulate:MARKer Subsystem

The CALCulate:MARKer subsystem checks the marker functions in the instrument.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

CALCulate<1|2>:MARKer<1 to 4>[:STATe] ON | OFF

This command switches on or off the selected marker. If no indication is made, marker 1 is selected automatically. If marker 2, 3 or 4 is selected and used as a delta marker, it is switched to marker mode.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
 "CALC:MARK3 ON"
 'Switches marker 3 in screen A on or to marker mode.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:MARKer<1 to 4>:AOFF

In analyzer mode, this command switches off all active markers in the indicated measurement window. In phase noise mode, this command switches off all active markers. The numeric suffix at CALCulate must be 1.

All delta markers and active marker/delta marker measurement functions are also switched off.

Example: for analyzer mode
 "CALC:MARK:AOFF"
 'Switches off all markers in screen A.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:TRACe 1 to 3

This command assigns the selected marker (1 to 4) to the indicated measurement curve. The corresponding trace must be active, i.e. its status must be different from "BLANK".

If necessary, the corresponding marker is switched on prior to the assignment.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
 "CALC:MARK3:TRAC 2"
 'Assigns marker 3 in screen A to trace 2.
 "CALC2:MARK:TRAC 3"
 'Assigns marker 1 in screen B to trace 3.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:MARKer<1 to 4>:X 0 to MAX (frequency | sweep time)

This command positions the selected marker to the indicated :

- frequency (span > 0)
- time (span = 0)
- level (APD/CCDF measurement)

If marker 2, 3 or 4 is selected and used as delta marker, it is switched to marker mode.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
"CALC1:MARK2:X 10.7MHz"
'Positions marker 2 in screen A to frequency 10.7 MHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

CALCulate<1|2>:MARKer<1 to 4>:X:SLIMits[:STATe] ON | OFF

This command switches between a limited (ON) and unlimited (OFF) search range in the selected measurement window. The function is independent of the selection of a marker, i.e. the numeric suffix MARKer<1 to 4> is irrelevant.

If the time domain power measurement is active, this command limits the evaluation range on the trace.

Example: "CALC:MARK:X:SLIM ON"
'Switches on search limitation in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:X:SLIMits:LEFT 0 to MAX (frequency | sweep time)

This command sets the left limit of the search range for markers and delta markers in the selected measurement window. Depending on the x-axis domain, the indicated value defines:

- frequency (span > 0)
- time (span = 0)

The function is independent of the selection of a marker, i.e. the numeric suffix in MARKer<1 to 4> is irrelevant.

If the time domain power measurement is active, this command limits the evaluation range to the trace.

**Note**

The function is only available if the search limit for marker and delta marker is switched on (`CALC:MARK:X:SLIM ON`).

Example: `"CALC:MARK:X:SLIM ON"`
 'Switches the search limit function on for screen A.
`"CALC:MARK:X:SLIM:LEFT 10MHz"`
 'Sets the left limit of the search range in screen A to 10 MHz.

Characteristics: *RST value: - (is set to the left diagram border on switching on search limits)
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:X:SLIMits:RIGHT 0 to MAX (frequency | sweep time)

This command sets the right limit of the search range for markers and delta markers in the selected measurement window. Depending on the x-axis domain the indicated value defines a frequency (span > 0) or time (span = 0). The function is independent of the selection of a marker, i.e. the numeric suffix in MARKer<1 to 4> is irrelevant.

If the time domain power measurement is active, this command limits the evaluation range to the trace.

**Note**

The function is only available if the search limit for marker and delta marker is switched on (`CALC:MARK:X:SLIM ON`).

Example: `"CALC:MARK:X:SLIM ON"`
 'Switches the search limit function on for screen A.
`"CALC:MARK:X:SLIM:RIGH 20MHz"`
 'Sets the right limit of the search range in screen A to 20 MHz.

Characteristics: *RST value: - (is set to the right diagram border on switching on search limits)
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:X:SPUR?

This command queries whether the current marker is positioned on a spur.

Return value: 1 if the marker is positioned on a spur.
 0 if the marker is not positioned on a spur.

Example: `"CALC:MARK:X:SPUR?"`
 'Queries whether the current marker x position is on a spur.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is a query only and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:COUNT ON | OFF

This command switches on or off the frequency counter at the marker position in the selected measurement window. The count result is queried with `CALCulate:MARKer:COUNT:FREQuency?`.

Frequency counting is possible only for one marker at a time for each measurement window. If it is activated for another marker, it is automatically de-activated for the previous marker.

It should be noted that a complete sweep must be performed after switching on the frequency counter to ensure that the frequency to be measured is actually reached. The synchronization to the sweep end required for this is possible only in single-sweep mode.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK ON"
'Switches on marker 1 in screen A.

"CALC:MARK:COUN ON"
'Switches on the frequency counter for marker 1.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:COUN:FREQ?"
'Outputs the measured value in screen A.
```

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:COUNT:RESolution 0.1 | 1 | 10 | 100 | 1000 | 10000 Hz

This command specifies the resolution of the frequency counter in the selected measurement window. The setting is independent of the selected marker, i.e. the numeric suffix in `MARKer<1 to 4>` is irrelevant.

Example:

```
"CALC:MARK:COUN:RES 1kHz"
'Sets the resolution of the frequency counter to 1 kHz.
```

Characteristics: *RST value: 1kHz
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:COUNT:FREQuency?

This command queries the result of the frequency counter for the indicated marker in the selected measurement window. Before the command, the frequency counter should be switched on and a complete measurement performed to obtain a valid count result. Therefore, a single sweep with synchronization must be performed between switching on the frequency counter and querying the count result.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK2 ON"
'Switches marker 2 in screen A.

"CALC:MARK2:COUN ON"
'Switches the frequency counter for marker 2.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK2:COUN:FREQ?"
'Outputs the measured value of marker 2 in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:LOEXclude ON | OFF

This command switches the local oscillator suppression for peak search on or off. This setting is valid for all markers and delta markers in all measurement windows. The numeric suffixes 1|2 and 1 to 4 are irrelevant.

Example: "CALC:MARK:LOEX ON"

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:Y <numeric_value>

This command positions the selected marker to the indicated Y position. The units for this command are dBc/Hz. The numeric suffix at CALCulate must be 1.

Example: "CALC1:MARK:Y?"
'Outputs the measured value of marker 1.

Characteristics: *RST value:--
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:MARKer<1 to 4>:Y?

This command queries the measured value of the selected marker in the indicated measurement window. The corresponding marker is activated before or switched to marker mode, if necessary.

To obtain a valid query result, a complete sweep with synchronization to the sweep end must be performed between the activation of the marker and the query of the y value. This is only possible in single-sweep mode.

The query result is output in the unit determined with the [CALCulate<1|2>:UNIT:POWER](#) command. Only with linear level scaling is the output in %.

If the FM Demodulator is activated, the query result is output in the following units:

- Result display FM: Hz
- Result display RF POWER LOG: dBm
- Result display RF POWER LIN: %
- Result display SPECTRUM LOG: dBm
- Result display SPECTRUM LIN: %

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK2 ON"
'Switches marker 2 in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK2:Y?"
'Outputs the measured value of marker 2 in screen A.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:Y:PERCent 0 to100%

This command positions the selected marker in the selected window to the given probability. If marker 2, 3 or 4 is selected and used as a delta marker, it is switched to marker mode.



Note

The command is only available with the CCDF measurement switched on.
The associated level value can be determined with the CALC:MARK:X? command.

Example:

```
"CALC1:MARK:Y:PERC 95PCT"
'Positions marker 1 in screen A to a 'probability of 95%.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:MAXimum[:PEAK]

This command positions the specified marker to the current maximum value of the corresponding trace. The corresponding marker is activated first or switched to the marker mode.

**Note**

If no maximum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
"CALC:MARK2:MAX"
'Positions marker 2 in screen A to the maximum value of 'the trace.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:NEXT

This command positions the specified marker to the next smaller maximum value of the corresponding trace.

**Note**

If no next smaller maximum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
"CALC:MARK2:MAX:NEXT"
'Positions marker 2 in screen A to the next 'lower maximum value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:RIGHT

This command positions the specified marker to the next smaller maximum value to the right of the current value (i.e. in ascending X values) on the corresponding trace.

**Note**

If no next smaller maximum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
 "CALC:MARK2:MAX:RIGHT"
 'Positions marker 2 in screen A to the next lower maximum value to the right of the current value.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:LEFT

This command positions the specified marker to the next smaller maximum value to the left of the current value (i.e. in descending X values) on the trace.



Note

If no next smaller maximum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
 "CALC:MARK2:MAX:LEFT"
 'Positions marker 2 in screen A to the next lower maximum value to the left of the current value.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MAXimum:AUTO ON | OFF

This command switches an automatic maximum peak search for marker 1 at the end of each particular sweep on and off. The current marker search limit settings (LEFT LIMIT, RIGHT LIMIT, THRESHOLD, EXCLUDE LO) are taken into account. The numeric suffix at MARKer<1 to 4> is irrelevant.

Example: "CALC:MARK:MAX:AUTO ON"
 Activates the auto search function for marker 1.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:MINimum:AUTO ON | OFF

This command switches an automatic minimum peak search for marker 1 at the end of each particular sweep on and off. The current marker search limit settings (LEFT LIMIT, RIGHT LIMIT, THRESHOLD, EXCLUDE LO) are taken into account. The numeric suffix at MARKer<1 to 4> is irrelevant.

Example: "CALC:MARK:MIN:AUTO ON"
 Activates the auto search function for marker 1.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:MINimum[:PEAK]

This command positions the specified marker to the current minimum value of the corresponding trace. The corresponding marker is activated first or switched to marker mode, if necessary.



Note

If no minimum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
"CALC:MARK2:MIN"
'Positions marker 2 in screen A to the minimum value of the trace.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:NEXT

This command positions the specified marker to the next higher minimum value of the corresponding trace.



Note

If no next higher minimum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
"CALC:MARK2:MIN:NEXT"
'Positions marker 2 in screen A to the next higher maximum value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:RIGHT

This command positions the specified marker to the next higher minimum value to the right of the current value (i.e. in ascending X direction) on the corresponding trace.

**Note**

If no next higher minimum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
 "CALC:MARK2:MIN:RIGH"
 'Positions marker 2 in screen A to the next higher minimum value to the right of the current value.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:MINimum:LEFT

This command positions the specified marker to the next higher minimum value to the left of the current value (i.e. in descending X direction) on the corresponding trace.

**Note**

If no next higher minimum value is found on the trace (level spacing to adjacent values < peak excursion), an execution error (error code: -200) is produced.

Example: for analyzer mode
 "CALC:MARK2:MIN:LEFT"
 'Positions marker 2 in screen A to the next higher minimum value to the left of the current value.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:PEXCursion <numeric_value>

This command defines the peak excursion, i.e. the spacing below a trace maximum which must be attained before a new maximum is recognized, or the spacing above a trace minimum which must be attained before a new minimum is recognized. The set value is valid for all markers and delta markers. The unit depends on the selected operating mode.

In phase noise mode, the value range from 0 Hz to 5 MHz

Example: for analyzer mode
 "CALC:MARK:PEXC 10dB"
 'Defines peak excursion 10 dB.

Characteristics: *RST value: 6dB
SCPI: device-specific

Mode: PNO, A

The numeric suffix in MARKer<1 to 4> is irrelevant.

CALCulate:MARKer:FUNCTION Subsystem

The measurement window is selected by CALCulate 1 (screen A) or 2 (screen B).

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:FPEaks[:IMMediate] <numeric_value>

This command searches the selected trace for the indicated number of maxima. The results are entered in a list and can be queried with commands `CALC:MARK:FUNC:FPEaks:X?` and `CALC:MARK:FUNC:FPEaks:Y?`. The number of maxima found can be queried with `CALC:MARK:FUNC:FPEaks:COUNT?`. The trace to be examined is selected with `CALC:MARK:TRACe`. The order of the results in the list can be defined with `CALC:MARK:FUNC:FPEaks:SORT`.



Note

The number of maxima found depends on the waveform and value set for the Peak Excursion parameter (`CALC:MARK:PEXC`), however, a maximum number of 50 maxima are determined. Only the signals which exceed their surrounding values at least by the value indicated by the peak excursion parameter will be recognized as maxima. Therefore, the number of maxima found is not automatically the same as the number of maxima desired.

Example:

```
"INIT:CONT OFF"
'switches to single-sweep mode

"INIT;*WAI"
'starts measurement and synchronizes to end

"CALC:MARK:TRAC 1"
'sets marker 1 in screen A to trace 1

"CALC:MARK:FUNC:FPE:SORT X"
'sets the sort mode to increasing X values

"CALC:MARK:FUNC:FPE 3"
'searches the 3 highest maxima for trace 1

"CALC:MARK:FUNC:COUN?"
'queries the number of maxima found

"CALC:MARK:FUNC:Y?"
'queries the level of maxima found

"CALC:MARK:FUNC:X?"
'queries the frequencies (span <> 0) or time (span = 0) of maxima found.
```

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:FPEaks:COUNT?

This query reads out the number of maxima found during the search. If no search for maxima has been performed, 0 is returned.

Example: "CALC:MARK:FUNC:FPE 3"
 'searches the 3 highest maxima for trace 1

 "CALC:MARK:FUNC:FPE:COUN?"
 'queries the number of maxima found

Characteristics: *RST value: --
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:FPEaks:X?

This query reads out the list of X values of the maxima found. The number of available values can be queried with CALC:MARK:FUNC:FPEaks:COUNT?.

With sort mode X, the X values are in increasing order; with sort mode Y the order corresponds to the decreasing order of the Y values.

Example: "CALC:MARK:FUNC:FPE:SORT Y"
 'sets the sort mode to decreasing y values

 "CALC:MARK:FUNC:FPE 3"
 'searches the 3 highest maxima for trace 1

 "CALC:MARK:FUNC:FPE:COUN?"
 'queries the number of maxima found

 "CALC:MARK:FPE:FUNC:X?"
 'queries the frequencies (span <> 0) or time (span = 0) of the maxima found.

Return value: "107.5E6,153.8E6,187.9E6"
 'frequencies in increasing order

 "2.05E-3,2.37E-3, 3.71e-3"
 'times in increasing order

Characteristics: *RST value: --
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:FPEaks:Y?

This query reads out the list of X values of the maxima found. The number of available values can be queried with CALC:MARK:FUNC:FPEaks:COUNT?.

With sort mode X, the X values are in increasing order; with sort mode Y the order corresponds to the decreasing order of the Y values.

Example: "CALC:MARK:FUNC:FPE:SORT Y"
'sets the sort mode to decreasing y values

"CALC:MARK:FUNC:FPE 3"
'searches the 3 highest maxima for trace 1

"CALC:MARK:FUNC:FPE:COUN?"
'queries the number of maxima found

"CALC:MARK:FUNC:FPE:Y?"
'queries the levels of the maxima found.

Return value: "-37.5,-58.3,-59.6"
'level in decreasing order

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNction:FPEaks:SORT X | Y

This command sets the sort mode for the search for maxima:

Parameter: X: the maxima are sorted in the list of responses according to increasing X values
Y: the maxima are sorted in the list of responses according to decreasing Y values

Example: "CALC:MARK:FUNC:FPE:SORT Y"
'sets the sort mode to decreasing y values

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNction:NDBDown <numeric_value>

This command defines the level spacing of the two delta markers to the right and left of marker 1 in the selected measurement window. Marker 1 is always used as the reference marker. The numeric suffix <1 to 4> is irrelevant for this command.

The temporary markers T1 and T2 are positioned by n dB below the active reference marker. The frequency spacing of these markers can be queried with CALCulate:MARKer:FUNction:NDBDown:RESult?.

If a negative value is entered than the markers are placed n dB above the active reference marker. This is then a n dB up function which can be used for notch filter measurements:

Example: "CALC:MARK:FUNC:NDBD 3dB"
'Sets the level spacing in screen A to 3 dB.

Characteristics: *RST value: 6dB
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNction:NDBDown:STATe ON | OFF

This command switches the "N dB Down" function on or off in the selected measurement window. Marker 1 is activated first, if necessary. The numeric suffix <1 to 4> is irrelevant for this command.

Example: "CALC:MARK:FUNC:NDBD:STAT ON"
'Switches on the N-dB-down function in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:NDBDown:RESult?

This command queries the frequency spacing (bandwidth) of the N-dB-down markers in the selected measurement window. The numeric suffix <1 to 4> is irrelevant for this command.

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value in order to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:NDBD ON"
'Switches on the n-dB-down function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:NDBD:RES?"
'Outputs the measured value of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:NDBDown:FREQuency?

This command queries the two frequencies of the N-dB-down marker in the selected measurement window. The numeric suffix <1 to 4> is irrelevant for this command. The two frequency values are separated by comma and output in ascending order.

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:NDBD ON"
'Switches on the n-dB-down function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:NDBD:FREQ?"
'Outputs the frequencies of the temporary markers in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:NDBDown:TIME?

This command queries the two time values of the "N dB Down" markers in the specified measurement window. The suffix <1 to 4> has no meaning with this command. The two time values are output in ascending order, separated by commas.

To obtain a valid query response, a complete sweep with synchronization to the sweep end must have been performed in between activating the function and querying the measurement results. This is possible only in single-sweep mode.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:NDBD ON"
'Switches on the "N dB Down" function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:NDBD:TIME?"
'Outputs the time values of the temporary markers in screen A.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is a query only and thus has no *RST value

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ZOOM <numeric_value>

In analyzer mode, this command defines the range to be zoomed around marker 1 in the selected measurement window. Marker 1 is activated first, if necessary.

The subsequent frequency sweep is stopped at the marker position and the frequency of the signal is counted. This frequency becomes the new center frequency, and the zoomed span is set. In order to recognize the end of the operation the synchronization to the sweep end should be activated. This is only possible in single-sweep mode.

In phase noise mode, this command zooms the trace by the specified numeric level around marker 1. The numeric suffix at CALCulate must be 1.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode

for analyzer mode
"CALC:MARK:FUNC:ZOOM 1kHz;*WAI"
'Activates zooming in screen A and waits for its end.

for phase noise mode
"CALC1:MARK1:FUNC:ZOOM 10"
'Zooms in around marker 1 by a factor of 10.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNction:NOISe[:STATe] ON | OFF

This command switches the noise measurement on or off for all markers of the indicated measurement window. The noise power density is measured at the position of the markers. The result can be queried with `CALCulate:MARKer:FUNction:NOISe:RESult?`.

Example: `"CALC2:MARK:FUNC:NOIS ON"`
 'Switches on the noise measurement for screen B.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNction:NOISe:RESult?

This command queries the result of the noise measurement.

A complete sweep with synchronization to the sweep end must be performed between switching on the function and querying the measured value in order to obtain a valid query result. This is only possible in single-sweep mode.

Example: `"INIT:CONT OFF"`
 'Switches to single-sweep mode.

 `"CALC:MARK2 ON"`
 'Switches on marker 2 in screen A.

 `"CALC:MARK:FUNC:NOIS ON"`
 'Switches on noise measurement in screen A.

 `"INIT;*WAI"`
 'Starts a sweep and waits for the end.

 `"CALC:MARK2:NOIS:RES?"`
 'Outputs the noise result of marker 2 in screen A.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNction:DEModulation:SElect AM | FM

This command selects the demodulation type for the audio demodulator. The command is independent of the measurement window and of the selected marker, i.e. suffixes 1|2 and 1 to 4 are irrelevant.

Example: `"CALC:MARK:FUNC:DEM:SEL FM"`

Characteristics: *RST value: AM
 SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNction:DEModulation[:STATe] ON | OFF

This command switches on or off the audio demodulator when the indicated marker is reached in the selected measurement window. In the frequency domain (span > 0) the hold time can be defined at the corresponding marker position with `CALCulate:MARKer:FUNction:DEModulation:HOLD`. In the time domain (span = 0) the demodulation is permanently active.

Example: "CALC2:MARK3:FUNC:DEM ON"
'Switches on the demodulation for marker 3 in screen B.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:HOLDoff 10ms to 1000s

This command defines the hold time at the marker position for the demodulation in the frequency domain (span > 0). The setting is independent of the measurement window and the selected marker, i.e. the suffixes <1|2> and <1 to 4> are irrelevant

Example: "CALC:MARK:FUNC:DEM:HOLD 3s"

Characteristics: *RST value: - (DEModulation is set to OFF)
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:CONTinuous ON | OFF

This command switches on or off the continuous demodulation in the frequency domain (span >0) in the selected measurement window. Thus acoustic monitoring of the signals can be performed in the frequency domain. The function does not depend on the selected marker, i.e. the numeric suffix <1 to 4> is irrelevant.

Example: "CALC2:MARK3:FUNC:DEM:CONT ON"
'Switches on the continuous demodulation in screen B.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:SQUelch[:STATe] ON | OFF

This command enables or disables the squelch function for the audio output.

Example: "CALC:MARK:FUNC:DEM:SQU ON"

Characteristics: *RST value: OFF

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:DEModulation:SQUelch:LEVel 0 to 100 PCT

This command sets the trigger level for the squelch function.

Example: "CALC:MARK:FUNC:DEM:SQU ON"
'Switches on the squelch function.

"CALC:MARK:FUNC:DEM:SQU:LEV 80 PCT"
'Sets the squelch to 80%.

Characteristics: *RST value: 50PCT
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:MDEPth[:STATe]

This command switches on the measurement of the AM modulation depth. An AM-modulated carrier is required on the screen for correct operation. If necessary, marker 1 is previously activated and set to the largest signal available.

The level value of marker 1 is regarded as the carrier level. On activating the function, marker 2 and marker 3 are automatically set as delta markers symmetrically to the carrier to the adjacent maxima of the trace.

If the position of delta marker 2 is changed, delta marker 3 is moved symmetrically with respect to the reference marker (marker 1). If the position of delta marker 3 is changed, fine adjustment can be performed independently of delta marker 2.

The R&S FSUP calculates the power at the marker positions from the measured levels.

The AM modulation depth is calculated from the ratio of power values at the reference marker and the delta markers. If the two AM sidebands differ in power, the average value of the two power values is used for calculating the AM modulation depth.

The numeric suffix <1 to 4> of :MARKer is irrelevant with this command.

Example:

```
"CALC:MARK:X 10MHZ"
'Sets the reference marker (marker 1) to the carrier signal at 10 MHz

"CALC:MARK:FUNC:MDEP ON"
'Switches on the modulation depth measurement in screen A.

"CALC:DELT2:X 10KHZ"
'Sets delta markers 2 and 3 to the signals at 10 kHz from the carrier signal

"CALC:DELT3:X 9.999KHZ"
'Corrects the position of delta marker 3 relative to delta marker 2.
```

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:MDEPth:RESult?

This command queries the AM modulation depth in the indicated measurement window.

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

The numeric suffix <1 to 4> of :MARKer is irrelevant for this command.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:X 10MHZ"
'Sets the reference marker (marker 1) to the carrier signal at 10 MHz.

"CALC:MARK:FUNC:MDEP ON"
'Switches on the modulation depth measurement in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:MDEP:RES?"
'Outputs the measured value of screen A.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:TOI[:STATe] ON | OFF

This command initiates the measurement of the third-order intercept point.

A two-tone signal with equal carrier levels is expected at the RF input of the instrument. Marker 1 and marker 2 (both normal markers) are set to the maximum of the two signals. Delta marker 3 and delta marker 4 are positioned to the intermodulation products. The delta markers can be modified separately afterwards with the commands `CALCulate:DELTamarker3:X` and `CALCulate:DELTamarker4:X`.

The third-order intercept is calculated from the level spacing between the normal markers and the delta markers.

The numeric suffix <1 to 4> of :MARKer is irrelevant for this command.

Example: `"CALC:MARK:FUNC:TOI ON"`
'Switches on the measurement of the third-order intercept in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:TOI:RESult?

This command queries the third-order intercept point measurement in the indicated measurement window.

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

The numeric suffix <1 to 4> of :MARKer is irrelevant of this command.

Example: `"INIT:CONT OFF"`
'Switches to single-sweep mode.

`"CALC:MARK:FUNC:TOI ON"`
'Switches the intercept measurement in screen A.

`"INIT;*WAI"`
'Starts a sweep and waits for the end.

`"CALC:MARK:FUNC:TOI:RES?"`
'Outputs the measured value of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CENTer

This command sets the center frequency of the selected measurement window equal to the frequency of the indicated marker.

If marker 2, 3 or 4 is selected and used as delta marker, it is switched to the marker mode.

Example: "`CALC:MARK2:FUNC:CENT`"
 'Sets the center frequency of screen A to the frequency of marker 2.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A-F

This command is an "event" and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:CSTep

This command sets the step width of the center frequency in the selected measurement window to the X value of the current marker.

If marker 2, 3 or 4 is selected and used as delta marker, it is switched to the marker mode.

Example: "`CALC2:MARK3:FUNC:CST`"
 'Sets the center frequency of screen B to the same value as the frequency of marker 3.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A-F

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:REFerence

This command sets the reference level to the power measured by the indicated marker. If the selected marker was used as delta marker, it is switched to marker mode.

In phase noise mode, this command is only available for Transient Power measurements.

Example: for analyzer mode
 "`CALC:MARK2:FUNC:REF`"
 'Sets the reference level of screen A to the level of marker 2.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALCulate:MARKer:FUNCtion:ADEMod Subsystem

The CALCulate:MARKer:FUNCtion:ADEMod subsystem contains the marker functions for the Transient measurements.

The numeric suffix for CALCulate must be 1.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:AM[:RESult<1 to 3>]? PPEak | MPEak | MIDDLE | RMS

This command queries the results of the AM demodulation in Transient measurements.

PPEak	Result of measurement with detector +PK
MPEak	Result of measurement with detector -PK
MIDDLE	Result of averaging \pm PK/2
RMS	Result of measurement with detector RMS

The results are determined from the current measurement data (CLR/WRITE trace). The suffixes for MARKer and RESult are ignored.

Example:

```
"CONF:TRAN:MEAS AMPL"
'Selects the Transient Amplitude measurement type.

"INIT;*WAI"
'Starts the measurement and waits for the end of the 20 sweeps.

"CALC:MARK:FUNC:ADEM:AM? PPE"
'Queries the peak value.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:ADEMod:FM[:RESult<1 to 3>]? PPEak | MPEak | MIDDLE | RMS

This command queries the results of the FM demodulation in Transient measurements.

PPEak	Result of measurement with detector +PK
MPEak	Result of measurement with detector -PK
MIDDLE	Result of averaging \pm PK/2
RMS	Result of measurement with detector RMS

The results are determined from the current measurement data (CLR/WRITE trace). The suffixes for MARKer and RESult are ignored.

Example:

```
"CONF:TRAN:MEAS FREQ"
'Selects the Transient Frequency measurement type.

"INIT;*WAI"
'Starts the measurement and waits for the end of the 20 sweeps.

"CALC:MARK:FUNC:ADEM:FM? PPE"
'Queries the peak value.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:MARKer<1 to 4>:FUNctio:n:ADEMod:PM[:RESult<1 to 3>]? PPEak | MPEak | MIDDLE | RMS

This command queries the results of the PM demodulation in Transient measurements.

PPEak Result of measurement with detector +PK

MPEak Result of measurement with detector -PK

MIDDLE Result of averaging \pm PK/2

RMS Result of measurement with detector RMS

The results are determined from the current measurement data (CLR/WRITE trace). The suffixes for MARKer and RESult are ignored.

Example: "CONF:TRAN:MEAS PHAS"
'Selects the Transient Phase measurement type.

"INIT;*WAI"
'Starts the measurement and waits for the end of the 20 sweeps.

"CALC:MARK:FUNC:ADEM:PM? PPE"
'Queries the peak value.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:MARKer<1 to 4>:FUNctio:n:ADEMod:FERRor[:RESult<1 to 3>]?

This command queries the frequency error with FM and PM demodulation. The results are determined from the current measurement data (CLR/WRITE trace). The suffixes for MARKer and RESult are ignored. This command is only available for traces in the FM and PM result displays. If any other result display is selected, this command is disabled.

Example: "CALC:MARK:FUNC:ADEM:FERR?"
'Queries the frequency error.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:MARKer<1 to 4>:FUNctio:n:ADEMod:CARRier[:RESult<1 to 3>]?

This command queries the carrier power. The results are determined from the current measurement data (CLR/WRITE trace). The suffixes for MARKer and RESult are ignored.

Example: "CALC:MARK:FUNC:ADEM:CARR?"
'Queries the carrier power.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

CALCulate:MARKer:FUNCtion:HARMonics Subsystem

The CALCulate:MARKer:FUNCtion:HARMonics subsystem contains the commands for Harmonic Distortion measurement

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:HARMonics[:STATe] ON | OFF

This command switches on or off the measurement of the harmonics of a carrier signal. The carrier signal is the first harmonic. The function is independent of the marker selection, i.e. the suffix <1|2> or <1 to 4> of CALCulate or MARKer is irrelevant. It is only available in the frequency domain (span > 0).

If the measurement is started in the frequency domain (span > 0), the last span will define the search range for the first harmonic. The level for the first harmonic will also be calculated in the frequency domain. However, the measurement can also be started in the time domain (span = 0), in which case the center frequency and the level used will remain unchanged.

Example: "CALC:MARK:FUNC:HARM ON"
'Switches on the measurement of harmonics.'

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:HARMonics:NHARmonics 1 to 10

This command defines the number of harmonics of a carrier signal to be measured. The function is independent of the marker selection, i.e. the suffix <1|2> or <1 to 4> of CALCulate or MARKer is irrelevant.

Example: "CALC:MARK:FUNC:HARM:NHARM 3"
'Sets the number of harmonics to be measured to 3.'

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-F

CALCulate:MARKer:FUNCTION:POWER Subsystem

The CALCulate:MARKer:FUNCTION:POWER subsystem contains the commands for control of power measurement.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:POWER:SELEct ACPower | CPOWer | MCACpower | OBANdwidth | OBWidth | CN | CN0

This command selects – and switches on – one of the above types of power measurement in the selected measurement window. This function is independent of the selected marker, i.e. the numerical suffix <1 to 4> appended to MARKer has no effect.

The channel spacings and channel bandwidths are configured in the `SENSe:POWer:ACHannel` subsystem.

Please note the following:

If CPOWer is selected, the number of adjacent channels (command: `[SENSe:]POWer:ACHannel:ACPairs`) is set to 0. If ACPower is selected, the number of adjacent channels is set to 1, unless adjacent channel power measurement is switched on already.



Note

The channel/adjacent channel power measurement is performed for the trace selected with `SENSe:POWer:TRACe 1|2|3`.

The occupied bandwidth measurement is performed for the trace on which marker 1 is positioned. To select another trace for the measurement, marker 1 is to be positioned on the desired trace by means of `CALC:MARK:TRAC 1|2|3`.

Parameter:

- ACPower: adjacent channel power measurement with a single carrier signal
- CPOWer: Channel power measurement with a single carrier signal (equivalent to adjacent channel power measurement with *NO. OF ADJ CHAN = 0*)
- MCACpower: Channel/adjacent channel power measurement with several carrier signals
- OBANdwidth | OBWidth: Measurement of occupied bandwidth
- CN: Measurement of carrier-to-noise ratio
- CN0: Measurement of carrier-to-noise ratio referenced to 1 Hz bandwidth

Example: `"CALC:MARK:FUNC:POW:SEL ACP"`
 'Switches on adjacent channel power measurement in window A.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNctIon:POWer:RESult? ACPower | CPOWer | MCACpower | OBANdwidth | OBWidth | CN | CN0

This command queries the result of the power measurement performed in the selected window. If necessary, the measurement is switched on prior to the query.

The channel spacings and channel bandwidths are configured in the `SENSe:POWer:ACHannel` subsystem.

To obtain a valid result, a complete sweep with synchronization to the end of the sweep must be performed before a query is output. Synchronization is possible only in the single-sweep mode.

Parameters:

- ACPower:** adjacent channel power measurement
Results are output in the following sequence, separated by commas:
1. Power of transmission channel
 2. Power of lower adjacent channel
 3. Power of upper adjacent channel
 4. Power of lower alternate channel 1
 5. Power of upper alternate channel 1
 6. Power of lower alternate channel 2
 7. Power of upper alternate channel 2
- The number of measured values returned depends on the number of adjacent/alternate channels selected with `SENSe:POWer:ACHannel:ACPairs`.
With logarithmic scaling (`RANGE LOG`), the power is output in the currently selected level unit; with linear scaling (`RANGE LIN dB` or `LIN %`), the power is output in *W*. If `SENSe:POWer:ACHannel:MODE REL` is selected, the adjacent/alternate-channel power is output in dB.
- CPOWer:** Channel power measurement
With logarithmic scaling (`RANGE LOG`), the channel power is output in the currently selected level unit; with linear scaling (`RANGE LIN dB` or `LIN %`), the channel power is output in *W*.
- MCACpower:** Channel/adjacent channel power measurement with several carrier signals
Results are output in the following sequence, separated by commas:
1. Power of carrier signal 1
 2. Power of carrier signal 2
 3. Power of carrier signal 3
 4. Power of carrier signal 4
 5. Power of carrier signal 5
 6. Power of carrier signal 6
 7. Power of carrier signal 7
 8. Power of carrier signal 8
 9. Power of carrier signal 9
 10. Power of carrier signal 10
 11. Power of carrier signal 11
 12. Power of carrier signal 12
 13. Total power of all carrier signals

- 14. Power of lower adjacent channel
- 15. Power of upper adjacent channel
- 16. Power of lower alternate channel 1
- 17. Power of upper alternate channel 1
- 18. Power of lower alternate channel 2
- 19. Power of upper alternate channel 2

The number of measured values returned depends on the number of carrier signals and adjacent/alternate channels selected with

`SENSe:POWer:ACHannel:TXCHannel:COUNT` and `SENSe:POWer:ACHannel:ACPairs`.

If only one carrier signal is measured, the total value of all carrier signals will not be output.

With logarithmic scaling (`RANGE LOG`), the power is output in dBm; with linear scaling (`RANGE LIN dB` or `LIN %`), the power is output in W. If `SENSe:POWer:ACHannel:MODE REL` is selected, the adjacent/alternate-channel power is output in dB.

OBANdwidth OBWidth:	Measurement of occupied bandwidth The occupied bandwidth in Hz is returned.
CN:	Measurement of carrier-to-noise ratio The carrier-to-noise ratio in dB is returned.
CN0:	Measurement of carrier-to-noise ratio referenced to 1 Hz bandwidth. The carrier-to-noise ratio in dB/Hz is returned.

Example of channel/adjacent channel power measurement:

<code>"SENS2:POW:ACH:ACP 3"</code>	'Sets the number of adjacent/alternate channels in screen B to 3.
<code>"SENS2:POW:ACH:BAND 30KHZ"</code>	'Sets the bandwidth of the transmission channel to 30 kHz.
<code>"SENS2:POW:ACH:BAND:ACH 40KHZ"</code>	'Sets the bandwidth of each adjacent channel to 40 kHz.
<code>"SENS2:POW:ACH:BAND:ALT1 50KHZ"</code>	'Sets the bandwidth of each alternate channel to 50 kHz.
<code>"SENS2:POW:ACH:BAND:ALT2 60KHZ"</code>	'Sets the bandwidth of alternate channel 2 to 60 kHz.
<code>"SENS2:POW:ACH:SPAC 30KHZ"</code>	'Sets the spacing between the transmission channel and the adjacent channel to 30 kHz, the spacing between the transmission channel and alternate channel 1 to 60 kHz, and the spacing between the transmission channel and alternate channel 2 to 90 kHz.
<code>"SENS2:POW:ACH:SPAC:ALT1 100KHZ"</code>	'Sets the spacing between the transmission channel and alternate channel 1 to 100 kHz, and the spacing between the transmission channel and alternate channel 2 to 150 kHz.
<code>"SENS2:POW:ACH:SPAC:ALT2 140KHZ"</code>	'Sets the spacing between the transmission channel and alternate channel 2 to 140 kHz.
<code>"SENS2:POW:ACH:MODE ABS"</code>	'Switches on absolute power measurement.

"CALC2:MARK:FUNC:POW:SEL ACP"	'Switches on the adjacent channel power measurement in screen B.
"INIT:CONT OFF"	'Switches over to single-sweep mode.
"INIT;*WAI"	'Starts a sweep and waits for the end of the sweep.
"CALC2:MARK:FUNC:POW:RES? ACP"	'Queries the result of adjacent channel power measurement in screen B.
"SENS2:POW:ACH:REF:AUTO ONCE"	'Defines the measured channel power as the reference value for relative power measurements.

If the **channel power only** is to be measured, all commands relating to adjacent/alternate channel bandwidth and channel spacings are omitted. The number of adjacent/alternate channels is set to 0 with SENS2:POW:ACH:ACP 0.

Example of occupied bandwidth measurement:

"SENS2:POW:BAND 90PCT"	'Defines 90% as the percentage of the power to be contained in the bandwidth range to be measured.
"INIT:CONT OFF"	'Switches over to single-sweep mode.
"INIT;*WAI"	'Starts a sweep and waits for the end of the sweep.
"CALC2:MARK:FUNC:POW:RES? OBW"	'Queries the occupied bandwidth measured in screen B.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

This command is a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWer:RESult:PHZ ON | OFF

This command switches the query response of the power measurement results in the indicated measurement window between output of absolute values (OFF) and output referred to the measurement bandwidth (ON).

The measurement results are output with CALCulate:MARKer:FUNCtion:POWer:RESult?

Parameter: **ON:** Results output referred to measurement bandwidth.
OFF: Results output in absolute values.

Example of channel/adjacent channel measurement:

"SENS2:POW:ACH:ACP 3"	'Sets the number of adjacent channels in screen B to 3.
"SENS2:POW:ACH:BAND 30KHZ"	'Sets the bandwidth of the main channel to 30 kHz.
"SENS2:POW:ACH:BAND:ACH 40KHZ"	'Sets the bandwidth of all adjacent channels to 40 kHz.
"SENS2:POW:ACH:BAND:ALT1 50KHZ"	'Sets the bandwidth of all alternate adjacent channels to 50 kHz.
"SENS2:POW:ACH:BAND:ALT2 60KHZ"	'Sets the bandwidth of alternate adjacent channel 2 to 60 kHz.

"SENS2:POW:ACH:SPAC 30KHZ"	'Sets the spacing between channel and adjacent channel as well as between all adjacent channels to 30 kHz.
"SENS2:POW:ACH:SPAC:ALT1 40KHZ"	'Sets the spacing between adjacent channel and alternate adjacent channel as well as between all alternate adjacent channels to 40 kHz.
"SENS2:POW:ACH:SPAC:ALT2 50KHZ"	'Sets the spacing between alternate adjacent channel 1 and alternate adjacent channel 2 to 50 kHz.
"SENS2:POW:ACH:MODE ABS"	'Switches on absolute power measurement.
"CALC2:MARK:FUNC:POW:SEL ACP"	'Switches the adjacent channel power measurement in screen B.
"INIT:CONT OFF"	'Switches to single-sweep mode.
"INIT;*WAI"	'Starts a sweep and waits for the end.
"CALC2:MARK:FUNC:POW:RES:PHZ ON"	'Output of results referred to the channel bandwidth.
"CALC2:MARK:FUNC:POW:RES? ACP"	'Queries the result of the adjacent channel power measurement in screen B referred to the channel bandwidth.

If only the **channel power** is to be measured, all commands for defining the bandwidths of adjacent channels as well as the channel spacings are not necessary. The number of adjacent channels is set to 0 with `SENS2:POW:ACH:ACP 0`.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWER[:STATe] OFF

This command switches off the power measurement in the selected measurement window.

Example: `"CALC:MARK:FUNC:POW OFF"`
'Switches off the power measurement in screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an event and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWER:PRESet NADC | TETRA | PDC | PHS | CDPD | FWCDma | RWCDma | F8CDma | R8CDma | F19Cdma | R19Cdma | FW3Gppcdma | RW3Gppcdma | D2CDma | S2CDma | M2CDma | FIS95A | RIS95A | FIS95C0 | RIS95C0 | FJ008 | RJ008 | FIS95C1 | RIS95C1 | TCDMa | NONE | AWLan | BWLan | WIMax | WIBro

This command selects the power measurement setting for a standard in the indicated measurement window and previously switches on the corresponding measurement, if required. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant.

The configuration for a standard comprises of the parameters weighting filter, channel bandwidth and spacing, resolution and video bandwidth, as well as detector and sweep time.

Meaning of the CDMA standard abbreviations:

FIS95A, F8CDma	CDMA IS95A forward
RIS95A, R8CDma	CDMA IS95A reverse
FJ008, F19CDma	CDMA J-STD008 forward
RJ008, R19CDma	CDMA J-STD008 reverse
FIS95C0	CDMA IS95C Class 0 forward
RIS95C0	CDMA IS95C Class 0 reverse
FIS95C1	CDMA IS95C Class 1 forward
RIS95C1	CDMA IS95C Class 1 reverse
FWCDma	W-CDMA 4.096 MHz forward
RWCDma	W-CDMA 4.096 MHz reverse
FW3Gppcdma	W-CDMA 3.84 MHz forward
RW3Gppcdma	W-CDMA 3.84 MHz reverse
D2CDma	CDMA 2000 direct sequence
S2CDma	CDMA 2000 MC1 multi carrier with 1 carrier
M2CDma	CDMA 2000 MC3 multi carrier with 3 carriers
TCDMa	TD-SCDMA
AWLan	WLAN 802.11a
BWLan	WLAN 802.11b
WiMax	WiMAX (Worldwide Interoperability for Microwave Access) IEEE 802.16-2004/Cor1-2005
WiBro	WiMAX WiBro (Wireless Broadband) IEEE 802.16-2004/Cor1-2005



Note

The settings for standards IS95A and C differ as far as the calculation method of channel spacings is concerned. For IS95A and J-STD008 the spacing is calculated from the center of the main channel to the center of the corresponding adjacent channel, for IS95C from the center of the main channel to the nearest border of the adjacent channel.

Example: "CALC2:MARK:FUNC:POW:PRES NADC"
'Selects the standard setting for NADC in screen B

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:POWER:MODE WRITe | MAXHold

This command selects the Clear Write or Maxhold for Channel Power values.

Example: "CALC:MARK:FUNC:POW:MODE MAXH"
'Maxhold for Channel Power values

Characteristics: *RST value: WRITe
SCPI: device-specific

Mode: A-F

CALCulate:MARKer:FUNCTion:STRack Subsystem

The CALCulate:MARKer:FUNCTion:STRack subsystem defines the settings of the signal track.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:STRack[:STATe] ON | OFF

This command switches the signal-track function on or off for the selected measurement window. The function is independent of the selected marker, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant.

With signal track activated, the maximum signal is determined after each frequency sweep and the center frequency is set to the frequency of this signal. Thus with drifting signals the center frequency follows the signal.

Example: "CALC:MARK:FUNC:STR ON"
'Switches on the signal track function for screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:STRack:BANDwidth|BWIDth 10Hz to MAX(SPAN)

These commands have the same function. For the selected measurement window they define the bandwidth around the center frequency within which the largest signal is searched. The function is independent of the selected marker, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant. It is only available in the frequency domain (span > 0).



Note

The entry of the search bandwidth is only possible if the Signal Track function is switched on (CALC:MARK:FUNC:STR ON).

Example: "CALC:MARK:FUNC:STR:BAND 1MHZ"
'Sets the search bandwidth for screen A to 1 MHz.

"CALC:MARK:FUNC:STR:BWID 1MHZ"
'Alternative command for the same function.

Characteristics: *RST value: -- (= span/10 on activating the function)
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:STRack:THReshold -330dBm to +30dBm

This command defines the threshold above which the largest signal is searched for in the selected measurement window. The function is independent of the selected marker, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant. It is only available in the frequency domain (span > 0).

The response unit depends on the settings defined with CALC:UNIT.

**Note**

The entry of the search bandwidth is only possible if the Signal Track function is switched on (`CALC:MARK:FUNC:STR ON`).

Example: `"CALC:MARK:FUNC:STR:THR -50DBM"`
'Sets the threshold for signal tracking in screen A to -50 dBm.

Characteristics: *RST value: -120 dBm
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:MARKer<1 to 4>:FUNction:STRack:TRACe 1 to 3

This command defines the trace on which the largest signal is searched for in the selected measurement window. The function is independent of the selected marker, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant. It is only available in the frequency domain (span > 0).

Example: `"CALC2:MARK:FUNC:STR:TRAC 3"`
'Defines trace 3 in screen B as the trace for signal tracking.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: A-F

CALCulate:MARKer:FUNction:SUMMary Subsystem

This subsystem contains the commands for controlling the time domain power functions. These are provided in the marker subsystem for reasons of compatibility with the FSE family.

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMary[:STATe] ON | OFF

This command switches on or off the previously selected time domain power measurements. Thus one or several measurements can be first selected and then switched on and off together with `CALC:MARK:FUNC:SUMMary:STATe`.

The function is independent of the marker selection, i.e. the suffix of MARKer is irrelevant. It is only available in the time domain (span = 0).

Example: `"CALC:MARK:FUNC:SUMM:STAT ON"`

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMary:PPEak[:STATe] ON | OFF

This command switches on or off the measurement of the positive peak value in the selected measurement window.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant. It is only available in the time domain (span = 0).

Example: "CALC:MARK:FUNC:SUMM:PPE ON"
'Switches on the function in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:PPEak:RESult?

This command is used to query the result of the measurement of the positive peak value in the selected measurement window. The measurement may have to be switched on previously.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:PPE ON"
'Switches on the function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:PPE:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:PPEak:AVERAge:RESult?

This command is used to query the result of the measurement of the averaged positive peak value in the selected measurement window. The query is only possible if averaging has been activated previously using CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:AVERAge.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> in MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:PPE ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:AVER ON"
'Switches on the calculation of average in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:PPE:AVER:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:PPEak:PHOLd:RESult?

This command is used to query the result of the measurement of the positive peak value with active peak hold function. The query is only possible if the peak hold function has been activated previously using CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:PHOLd.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:PPE ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:PHOL ON"
'Switches on the measurement of the peak value in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:PPE:PHOL:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:RMS[:STATe] ON | OFF

This command switches on or off the measurement of the effective (RMS) power in the selected measurement window. If necessary the function is switched on previously.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

Example: "CALC2:MARK:FUNC:SUM:RMS ON"
'Switches on the function in screen B.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:RMS:RESult?

This command queries the result of the measurement of the RMS power value in the selected measurement window.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:RMS ON"
'Switches on the function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:RMS:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:RMS:AVERAge:RESult?

This command queries the result of the measurement of the averaged RMS value in the selected measurement window. The query is only possible if averaging has been activated previously using CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:AVERAge.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:RMS ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:AVER ON"
Switches on the average value calculation in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:RMS:AVER:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:RMS:PHOLd:RESult?

This command queries the result of the measurement of the RMS value with active peak hold in the selected measurement window. The query is only possible only if the peak hold function has been activated previously using CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:PHOLd.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:RMS ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:PHOL ON"
'Switches on the peak value measurement in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:RMS:PHOL:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTion:SUMMary:MEAN[:STATe] ON | OFF

This command switches on or off the measurement of the mean value in the selected measurement window.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

**Note**

The measurement is performed on the trace on which marker 1 is positioned. In order to evaluate another trace, marker 1 must be positioned on another trace with `CALC:MARK:TRAC 1|2|3`.

Example: `"CALC:MARK:FUNC:SUMM:MEAN ON"`
'Switches on the function in screen A.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMery:MEAN:RESult?

This command queries the result of the measurement of the mean value in the selected measurement window.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: `"INIT:CONT OFF"`
'Switches to single-sweep mode.

`"CALC:MARK:FUNC:SUMM:MEAN ON"`
'Switches on the function in screen A.

`"INIT;*WAI"`
'Starts a sweep and waits for the end.

`"CALC:MARK:FUNC:SUMM:MEAN:RES?"`
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMery:MEAN:AVERage:RESult?

This command queries the result of the measurement of the averaged mean value in the selected measurement window. The query is only possible if averaging has been activated previously using `CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMery:AVERage`.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:MEAN ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:AVER ON"
'Switches on the average value calculation in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:MEAN:AVER:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:MEAN:PHOLd:RESult?

This command queries the result of the measurement of the mean value with active peak hold in the selected measurement window. The query is only possible if the peak hold function has been switched on previously using CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd.

The query is possible only if the peak hold function is active. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode

"CALC:MARK:FUNC:SUMM:MEAN ON"
'Switches on the function in screen A

"CALC:MARK:FUNC:SUMM:PHOL ON"
'Switches on the peak value measurement in screen A

"INIT;*WAI"
'Starts a sweep and waits for the end

"CALC:MARK:FUNC:SUMM:MEAN:PHOL:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:SDEVIation[:STATe] ON | OFF

This command switches on or off the measurement of the standard deviation in the selected measurement window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

On switching on the measurement, the mean power measurement is switched on as well.

Example: "CALC2:MARK:FUNC:SUMM:SDEV ON"
'Switches on the measurement of the standard deviation in screen B.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:SDEViation:RESult?

This command queries the results of the standard deviation measurement. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:SDEV ON"
'Switches on the function in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:SDEV:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:SDEViation:AVERage:RESult?

This command queries the result of the averaged standard deviation determined in several sweeps in the selected measurement window. The query is possible only if averaging is active. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:SDEV ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:AVER ON"
'Switches on the calculation of average in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:MEAN:SDEV:RES?"
'Outputs the result of screen A.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:SDEViation:PHOLd:RESult?

This command queries the maximum standard deviation value determined in several sweeps in the selected measurement window. The query is possible only if the peak hold function is active.

The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

A complete sweep with synchronization to sweep end must be performed between switching on the function and querying the measured value to obtain a valid query result. This is only possible in single-sweep mode.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC:MARK:FUNC:SUMM:SDEV ON"
'Switches on the function in screen A.

"CALC:MARK:FUNC:SUMM:PHOL ON"
'Switches on the peak value measurement in screen A.

"INIT;*WAI"
'Starts a sweep and waits for the end.

"CALC:MARK:FUNC:SUMM:SDEV:PHOL:RES?"
'Outputs the result of screen A.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is only a query and therefore has no *RST value.

CALCulate<1|2>:MARKer<1 to 4>:FUNCtion:SUMMary:PHOLd ON | OFF

This command switches on or off the peak-hold function for the active time domain power measurement in the indicated measurement window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

The peak-hold function is reset by switching it off and on again.

Example:

```
"CALC:MARK:FUNC:SUMM:PHOL ON"
'Switches on the function in screen A.
```

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

The peak-hold function is reset by switching off and on, again.

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMary:AVERage ON | OFF

This command switches on or off averaging for the active time domain power measurement in the indicated window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

Averaging is reset by switching it off and on again.

The number of results required for the calculation of average is defined with [SENSe<1|2>:]AVERage:COUNT.

It should be noted that synchronization to the end of averaging is only possible in single-sweep mode.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"CALC2:MARK:FUNC:SUMM:AVER ON"
'Switches on the calculation of average in screen B.

"AVER:COUN 200"
'Sets the measurement counter to 200.

"INIT;*WAI"
'Starts a sweep and waits for the end.
```

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMary:MODE ABSolute | RELative

This command selects absolute or relative time domain power measurement in the indicated measurement window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

The reference power for relative measurement is defined with CALCulate:MARKer:FUNction:SUMMary:REFerence:AUTO ONCE. If the reference power is not defined, the value 0 dBm is used.

Example:

```
"CALC:MARK:FUNC:SUMM:MODE REL"
'Switches the time domain power measurement to relative.
```

Characteristics: *RST value: ABSolute
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MARKer<1 to 4>:FUNction:SUMMary:REFerence:AUTO ONCE

With this command the currently measured average value (...:SUMMary:MEAN) and RMS value (...:SUMMary:RMS) are declared as reference values for relative measurements in the indicated measurement window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

If the measurement of RMS value and average is not activated, the reference value 0 dBm is used.

If the function ...:SUMMary:AVERage or ...:SUMMary:PHOLd is switched on, the current value is the accumulated measurement value at the time considered.

Example:

```
"CALC:MARK:FUNC:SUMM:REF:AUTO ONCE"
'Takes the currently measured power in screen A as reference value for the relative
time domain power measurement.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:SUMMARY:AOFF

This command switches off all time domain measurements in the selected measurement window. The function is independent of the marker selection, i.e. the numeric suffix <1 to 4> of :MARKer is irrelevant. It is only available in the time domain (span = 0).

Example: "CALC2:MARK:FUNC:SUMM:AOFF"
'Switches off the time domain power measurement functions in screen B.

Characteristics: *RST value: _
SCPI: device-specific


Mode: A-T

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:MARKer<1 to 4>:FUNCTION:MSUMmary? <time offset of first pulse>, <measurement time>, <period>, < # of pulses to measure>

The commands of this subsystem are used to determine the power of a sequence of signal pulses having the same interval. The number of pulses to be measured as well as the measurement time and the period can be set. To define the position of the first pulse in the trace, a suitable offset can be entered.

The evaluation is performed on the measurement data of a previously recorded trace. The data recorded during the set measurement time is combined to a measured value for each pulse according to the detector specified and the indicated number of results is output as a list.



TRACE 1 of the selected screen is always used by the function. The suffix of MARKer will be ignored.

Example: "DISP:WIND:TRAC:Y:RLEV -10dBm"
'Sets the reference level to 10 dBm

"INP:ATT 30 dB"
'Sets the input attenuation to 30 dB

"FREQ:CENT 935.2MHz;SPAN 0Hz"
'Sets the receive frequency to 935.2 MHz and the span to 0 Hz

"BAND:RES 1MHz;VID 3MHz"
'Sets the resolution bandwidth to 1 MHz and the video bandwidth to 3 MHz

"DET RMS"
'Sets the RMS detector

"TRIG:SOUR VID;LEV:VID 50 PCT"
'Selects the trigger source VIDEO and sets the level of the video trigger source to 50 PCT

"SWE:TIME 50ms"
'Sets the sweep time to 50 ms

"INIT;*WAI"
'Starts the measurement with synchronization

"CALC:MARK:FUNC:MSUM? 50US,450US,576.9US,8"
'Queries 8 bursts with an offset of 50 μ s, a test time of 450 μ s and a period of 576.9 μ s

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-T

CALCulate:MATH Subsystem

The CALCulate:MATH subsystem allows to process data from the SENSE-subsystem in numeric expressions.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or CALCulate2 (screen B).

In phase noise mode, the numeric suffix at CALCulate must be 1.

CALCulate<1|2>:MATH[:EXpression][:DEFine] (<expr>)

This command defines the mathematical expression for relating traces to trace1.

The CALCulate<1|2>:MATH:STATE command switches the mathematical relation of traces on or off.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B).

In phase noise mode, the numeric suffix at CALCulate must be 1.

Parameter: <expr> ::= 'OP1 - OP2'
 analyzer mode: OP1 ::= TRACE1, OP2 ::= TRACE2 | TRACE3
 phase noise mode: OP1 ::= TRACE1 | TRACE2, OP2 ::= TRACE3

Example: for analyzer mode
 "CALC1:MATH (TRACE1 - TRACE2) "
 'Selects the subtraction of trace 1 from trace 2 in screen A.
 "CALC2:MATH (TRACE1 - TRACE3) "
 'Selects the subtraction of trace 1 from trace 3 in screen B.

Characteristics: *RST value: -
 SCPI: conform

Mode: A-T, PNO

CALCulate<1|2>:MATH:POSition -100PCT to 200PCT

This command defines the position of the result of the trace mathematics in the selected measurement window. The indication is in % of the screen height, with 100% corresponding to the upper diagram border.

Example: "CALC:MATH:POS 50PCT"
 'Sets the position in screen A to the horizontal diagram center.

Characteristics: *RST value: 50 %
 SCPI: device-specific

Mode: A-T

CALCulate<1|2>:MATH:STATe ON | OFF

This command switches the mathematical relation of traces on or off.

In analyzer mode, the measurement windows are selected via CALCulate1 (screen A) or 2 (screen B). In phase noise mode, the numeric suffix at CALCulate must be 1.

Example: for analyzer mode
"CALC:MATH:STAT ON"
'Switches on the trace mathematics in screen A.

Characteristics: *RST value: OFF
SCPI: conform

Mode: A-T, PNO

CALCulate<1|2>:MATH:MODE LINear | LOGarithmic

This command selects linear or logarithmic (= video) calculation of the mathematical functions related to the traces. The calculation of the average is one of the affected functions. The setting is valid for all measurement windows, i.e. the numeric suffix <1 | 2> of CALCulate is irrelevant.

Example: "CALC:MATH:MODE LIN"
'Switches on the linear calculation.

Characteristics: *RST value: LOG
SCPI: device-specific

Mode: A

CALCulate:PEAKsearch | PSEarch Subsystem

CALCulate<1|2>:PEAKsearch|PSEarch:AUTO ON | OFF

By using this command, the peak list in the spurious measurement is calculated automatically after a measurement. For each range, exactly one peak value is calculated.

The SENSE suffix is unused.

Example: "CALC:PEAK:AUTO ON"
'Switches the automatic peak search on.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate:SNOise Subsystem

The CALCulate:SNOise subsystem defines spot noise frequency points and returns the results calculated at their position.

For all spot noise commands, the suffix of CALCulate must be 1. The numeric suffixes of SNOise<1 to 5> indicate the spot noise frequency point.

CALCulate<1|2>:SNOise<1 to 5>:X 1 Hz to 1 GHz

This command defines the spot noise frequency of the selected point. If necessary, this command activates the spot noise calculations.

Example: "CALC:SNO2:X 2MHz"
'Defines 2 MHz as spot noise frequency of point 1.

Characteristics: *RST value: 1 kHz (marker 1), 10 kHz (marker 2), 100 kHz (marker 3), 1 MHz (marker 4), 10 MHz (marker 5)
SCPI: device-specific

Mode: PNO

CALCulate<1|2>:SNOise<1 to 5>:Y?

This command returns the result of the selected spot noise frequency point.

Example: "CALC:SNO:Y?"
'Outputs the measured value of spot noise frequency point 1.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

This command is a query only and therefore has no *RST value.

CALCulate<1|2>:SNOise<1 to 5>:AOFF

This command deactivates the spot noise calculations. The numeric suffixes of SNOise<1 to 5> are irrelevant.

Example: "CALC:SNO:AOFF"
'Deactivates all spot noise calculations.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

This command is an event and therefore has no *RST value and no query.

CALCulate<1|2>:SNOise<1 to 5>:STATE ON | OFF

This command activates or deactivates the spot noise calculations. If set to ON, the spot noise results are calculated as part of the main phase noise measurement.

The numeric suffixes of SNOise<1 to 5> are irrelevant.

Example: "CALC:SNO1:STATE ON"
'Activates the spot noise calculations.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: PNO

CALCulate:STATistics Subsystem

The CALCulate:STATistics subsystem controls the statistical measurement functions in the instrument. The measurement window cannot be selected with these functions. The numeric suffix in CALCulate is therefore ignored.

CALCulate:STATistics:APD[:STATe] ON | OFF

This command switches on or off the measurement of amplitude distribution (APD). On activating this function, the CCDF measurement is switched off.

Example: "CALC:STAT:APD ON"
'Switches on the APD measurement.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate:STATistics:CCDF[:STATe] ON | OFF

This command switches on or off the measurement of the complementary cumulative distribution function (CCDF). On activating this function, the APD measurement is switched off.

Example: "CALC:STAT:CCDF ON"
'Switches on the CCDF measurement.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate:STATistics:CCDF:X<1 to 3>? P0_01 | P0_1 | P1 | P10

This command reads out the level values for the probabilities 0.01%, 0.1%, 1% and 10%. The trace is selected by means of the numeric suffix <1 to 3>.

The desired result is selected by means of the following parameters:

Parameter: P0_01: Level value for 0.01% probability
P0_1: Level value for 0.1% probability
P1: Level value for 1% probability
P10: Level value for 10% probability

Example: "CALC:STAT:CCDF:X? P1"
'Reads out the level values for 1% probability.

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

CALCulate:STATistics:NSAMples 100 to 1E9

This command sets the number of measurement points to be acquired for the statistical measurement functions.

Example: "CALC:STAT:NSAM 500"
 'Sets the number of measurement points to be acquired to 500.

Characteristics: *RST value: 100000
 SCPI: device-specific

Mode: A

CALCulate:STATistics:SCALE:AUTO ONCE

This command optimizes the level setting of the instrument depending on the measured peak power, in order to obtain maximum instrument sensitivity.

To obtain maximum resolution, the level range is set as a function of the measured spacing between peak power and the minimum power for the APD measurement and of the spacing between peak power and mean power for the CCDF measurement. In addition, the probability scale for the number of test points is adapted.

**Note**

Subsequent commands have to be synchronized with *WAI, *OPC or *OPC? to the end of the auto range process which would otherwise be aborted.

Example: "CALC:STAT:SCAL:AUTO ONCE;*WAI"
 'Adapts the level setting for statistical measurements and activates the synchronization.

Characteristics: *RST value: --
 SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

CALCulate:STATistics:SCALE:X:RLEVEL -130dBm to 30dBm

This command defines the reference level for the x-axis of the measurement diagram. The setting is identical to the reference level setting using the command `DISPlay:WINDow:TRACe:Y:RLEVEL`.

With the reference level offset $\neq 0$ the indicated value range of the reference level is modified by the offset.

The unit depends on the setting performed with `CALC:UNIT`.

Example: "CALC:STAT:SCAL:X:RLEV -60dBm"

Characteristics: *RST value: -20dBm
 SCPI: device-specific

Mode: A

CALCulate:STATistics:SCALe:X:RANGe 1dB to 200dB

This command defines the level range for the x-axis of the measurement diagram. The setting is identical to the level range setting defined with the command `DISPlay:WINDow:TRACe:Y:SCALe`.

Example: `"CALC:STAT:SCAL:X:RANG 20dB"`

Characteristics: *RST value: 100dB
SCPI: device-specific

Mode: A

CALCulate:STATistics:SCALe:Y:UNIT PCT | ABS

This command toggles the scaling of y-axis between percentage and absolute.

Example: `"CALC:STAT:SCAL:Y:UNIT PCT"`
'toggle to percentage

Characteristics: *RST value: ABS
SCPI: device-specific

Mode: A

CALCulate:STATistics:SCALe:Y:UPPer 1E-8 to 1.0

This command defines the upper limit for the y-axis of the diagram in statistical measurements. Since probabilities are specified on the y-axis, the entered numerical values are dimensionless.

Example: `"CALC:STAT:Y:UPP 0.01"`

Characteristics: *RST value: 1.0
SCPI: device-specific

Mode: A

CALCulate:STATistics:SCALe:Y:LOWer 1E-9 to 0.1

This command defines the lower limit for the y-axis of the diagram in statistical measurements. Since probabilities are specified on the y-axis, the entered numerical values are dimensionless.

Example: `"CALC:STAT:SCAL:Y:LOW 0.001"`

Characteristics: *RST value: 1E-6
SCPI: device-specific

Mode: A

CALCulate:STATistics:PRESet

This command resets the scaling of the X and Y axes in a statistical measurement. The following values are set:

- x-axis ref level: -20 dBm
- x-axis range APD: 100 dB
- x-axis range CCDF: 20 dB
- y-axis upper limit: 1.0
- y-axis lower limit: 1E-6

Example: "CALC:STAT:PRES"
' Resets the scaling for statistical functions

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

CALCulate:STATistics:RESult<1 to 3>? MEAN | PEAK | CFACtor | ALL

This command reads out the results of statistical measurements of a recorded trace. The trace is selected with the numeric suffix <1 to 3> attached to RESult.

The required result is selected via the following parameters:

Parameter: MEAN: Average (=RMS) power in dBm measured during the measurement time.
PEAK: Peak power in dBm measured during the measurement time.
CFACtor: Determined CREST factor (= ratio of peak power to average power) in dB.
ALL: Results of all three measurements mentioned before, separated by commas:
<mean power>,<peak power>,<crest factor>

Example: "CALC:STAT:RES2? ALL"
'Reads out the three measurement results of trace 2. Example of answer string:
5.56,19.25,13.69 i.e. mean power: 5.56 dBm, peak power 19.25 dBm, CREST
factor 13.69 dB

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

CALCulate:THReshold Subsystem

The CALCulate:THReshold subsystem controls the threshold value for the maximum/minimum search of markers. The measurement windows are selected by CALCulate 1 (screen A) or 2 (screen B).

CALCulate<1|2>:DLINe<1|2> MINimum .. MAXimum (depending on current unit)

This command defines the position of Display Line 1 or 2. These lines enable the user to mark any levels in the diagram. The unit depends on the setting made with `CALC:UNIT`.

Example: `"CALC:DLIN -20dBm"`

Characteristics: *RST value: - (STATe to OFF)
SCPI: device-specific

Mode: A

CALCulate<1|2>:DLINe<1|2>:STATe ON | OFF

This command switches Display Line 1 or 2 (level lines) on or off.

Example: `"CALC:DLIN2:STAT OFF"`

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:THReshold MINimum to MAXimum (depending on current unit)

This command defines the threshold value for the maximum/minimum search of markers with marker search functions MAX PEAK, NEXT PEAK, etc. in the selected measurement window. The associated display line is automatically switched on.

Example: `"CALC:THR -82DBM"`
'Sets the threshold value for screen A to -82 dBm.

Characteristics: *RST value: - (STATe to OFF)
SCPI: device-specific

Mode: A

CALCulate<1|2>:THReshold:STATe ON | OFF

This command switches on or off the threshold line in the selected measurement window. The unit depends on the setting performed with `CALC:UNIT`.

Example: `"CALC2:THR:STAT ON"`
'Switches on the threshold line in screen B.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

CALCulate<1|2>:FLINe<1|2> 0 to f_{\max}

This command defines the position of the frequency lines.

The frequency lines mark the frequencies specified in the measurement window. Frequency lines are only available with SPAN > 0.

Example: "CALC:FLIN2 120MHz"

Characteristics: *RST value: - (STATe to OFF)
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:FLINe<1|2>:STATe ON | OFF

This command switches the frequency line on or off.

Example: "CALC:FLIN2:STAT ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-F

CALCulate<1|2>:TLINe<1|2> 0 to 1000s

This command defines the position of the time lines.

The time lines mark the times specified in the measurement window. Time lines are only available with SPAN = 0.

Example: "CALC:TLIN 10ms"

Characteristics: *RST value: - (STATe auf OFF)
SCPI: device-specific

Mode: A-T

CALCulate<1|2>:TLINe<1|2>:STATe ON | OFF

This command switches the time line on or off.

Example: "CALC:TLIN2:STAT ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-T

CALCulate:UNIT Subsystem

The CALCulate:Unit subsystem defines the units for power measurement settings.

CALCulate<1|2>:UNIT:POWer DBM | V | A | W | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | DBPT | DBUV_M | DBUA_M

This command selects the unit for power in the selected measurement window.

Example: "CALC:UNIT:POW DBM"
'Sets the power unit for screen A to dBm.

Characteristics: *RST value: dBm
SCPI: device-specific

Mode: A

CALibration Subsystem

The commands of the CALibration subsystem determine the data for system error correction in the instrument.

CALibration[:ALL]?

This command initiates the acquisition of system error correction data. A "0" is returned if the acquisition was successful.



Note

During the acquisition of correction data, the instrument does not accept any remote control commands, except

```
*RST
CALibration:ABORt
```

In order to recognize when the acquisition of correction data is completed, the MAV bit in the status byte can be used. If the associated bit is set in the Service Request Enable Register, the instrument generates a service request after the acquisition of correction data has been completed.

Example:

```
"*CLS"
'Resets the status management.

"*SRE 16"
'Enables MAV bit in the Service Request Enable Register.

"*CAL?"
'Starts the correction data recording and then a service request is generated.
```

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

CALibration:ABORt

This command aborts the acquisition of correction data and restores the last complete correction data set.

Example: "CAL:ABOR"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

CALibration:RESult?

This command outputs the results of the correction data acquisition. The lines of the result table (see chapter "Instrument Functions", section "Recording the Correction Data – CAL Key" on page 4.132) are output as string data separated by commas:

Return value: "Total Calibration Status: PASSED", "Date (dd/mm/yyyy): 12/07/2006",
"Time: 16:24:54", "Runtime:00.06"

Example: "CAL:RES?"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

CALibration:STATe ON | OFF

This command determines whether the current calibration data are taken into account by the instrument (ON) or not (OFF).

Example: "CAL:STAT OFF"
'Sets up the instrument to ignore the calibration data.

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

CONFigure Subsystem

The CONFigure subsystem contains commands for configuring complex measurement tasks. The CONFigure subsystem is closely linked to the functions of the FETCH subsystem, where the measurement results of the measurements are queried.

CONFigure:EXTernal:LOWPass ONCE

This command configures and initiates an external lowpass measurement.

This command is for service only.

Example: "CONF:EXT:LOWP ONCE"
'Starts an external lowpass measurement.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is an event and therefore has no *RST value and no query.

CONFigure:PNOise:MEASurement SPECTrum | PLL | CCORrelation | SNTuning

This command configures the measurement type for noise measurements.

Parameter: SPECTrum: Phase Noise Analyzer
PLL: Phase Noise PLL
CCORrelation: Cross Correlation PLL
SNTuning: Spot Noise Tuning



Note

Select PLL or CCORrelation first before selecting the SNTuning parameter,

Example: "CONF:PNO:MEAS SPEC"
'Selects the Phase Noise Analyzer measurement type.

Characteristics: *RST value: PLL
SCPI: device-specific

Mode: PNO

CONFigure:POWER:EXpected:RF -100 dBm to 30 dBm

This command specifies the input power level of the source signal that is supplied to the R&S FSUP RF input.

Example: "CONF:POW:EXP:RF 9"
'The R&S FSUP assumes an input signal strength of 9 dBm.

Characteristics: *RST value: -20 dBm
SCPI: device-specific

Mode: PNO

CONFigure:POWer:AUTO ON | OFF

This command switches on or off the automatic power level detection. If switched on, the power level detection is performed at the start of each measurement sweep.

Example: "CONF:POW:AUTO ON"
'The R&S FSUP automatically detects the input power level.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

CONFigure:REFMeas ONCE

This command configures and initiates a reference measurement.

Example: "CONF:REFM ONCE"
'Starts a reference measurement.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

This command is an event and therefore has no *RST value and no query.

CONFigure:TRANsient:MEASurement FREQuency | PHASe | AMPLitude | POWer

This command configures the measurement type for transient measurements.

Parameter: FREQuency: Transient Frequency
PHASe: Transient Phase
AMPLitude: Transient Amplitude
POWer: Transient Power

Example: "CONF:TRAN:MEAS PHAS"
'Selects the Transient Phase measurement type.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

CONFigure:TSETup INT1 | INT2 | INT3 | EXT1 | EXT2 | DUT1 | DCON1 | DCON2

This command configures the measurements.

Parameter:

Tag	Mode	Generator	Phase Detector	Control	Recom. Freq Range
INT1	PLL mode / int	Internal	Internal	Internal generator	10 MHz ... 8 GHz
INT2	PLL mode / int	Internal	Internal	DUT	10 MHz ... 8 GHz
INT3	PLL mode / int (Cross Correlation)	Internal	Internal	Internal generator	10 MHz ... 8 GHz
EXT1	PLL mode / ext	External	Internal	DUT	10 MHz ... 8 GHz
EXT2	PLL mode / ext	External	Internal	External generator	10 MHz ... 8 GHz
DUT1	PLL mode/ 2 DUTs	DUT2	Internal	DUT1	10 MHz ... 8 GHz

Tag	Mode	Generator	Phase Detector	Control	Recom. Freq Range
DCON1	Down converter (option ext mixer)	Internal	Internal	Internal generator	> 26 GHz
DCON2	Down converter (ext down converter)	Internal	Internal	Internal generator	> 40 GHz

If the external mixer is switched on in the spectrum mode, only DCON1 will be available.
If the external mixer is off, all configurations are selectable except DCON1.

Example: "CONF:TSET INT2"
 'Selects INT2.

Characteristics: *RST value: INT1
 SCPI: device-specific

Mode: PNO, A

CONFigure:VCO:MEASurement TCHar | TSENSitivity | RFPower | HPOWER | DCCHar | SUMMmary

This command configures the measurement type for VCO measurements.

Parameter: TCHar: VCO Tuning Characteristics
 TSENSitivity: VCO Tuning Sensitivity
 RFPower: VCO RF Power Characteristics
 HPOWER: Harmonic Power
 DCCHar: VCO DC Characteristics
 SUMMmary: VCO Summary

Example: "CONF:VCO:MEAS TCH"
 'Selects the VCO Tuning Characteristics measurement type.

Characteristics: *RST value: --
 SCPI: device-specific

Mode: PNO

CONFigure:VCO:PUSHing[:STATe] ON | OFF

This command switches on or off the VCO Pushing measurement. If VCO Pushing is on, VCO Pulling is switched off.

Example: "CONF:VCO:PUSH ON"
 'VCO Pushing measurement is switched on.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: PNO

CONFigure:VCO:PUSHing:SCALe ABSolute | RELative

This command switches the trace scaling for VCO Pushing measurements between ABSolute and RELative.

Example: "CONF:VCO:PUSH:SCAL ABS"
 'Sets VCO Pushing measurement scaling to absolute.

Characteristics: *RST value: REL
SCPI: device-specific

Mode: PNO

CONFigure:VCO:PULLing[:STATe] ON | OFF

This command switches on or off the VCO Pulling measurement. If VCO Pulling is on, VCO Pushing is switched off.

This command is only available with option R&S FSUP-B28.

Example: "CONF:VCO:PULL ON"
'VCO Pulling measurement is switched on.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

CONFigure:VCO:PULLing:SCALE ABSolute | RELative

This command switches the trace scaling for VCO Pulling measurements between ABSolute and RELative.

This command is only available with option R&S FSUP-B28.

Example: "CONF:VCO:PULL:SCAL ABS"
'Sets VCO Pulling measurement scaling to absolute.

Characteristics: *RST value: REL
SCPI: device-specific

Mode: PNO

CONFigure:VCO:TRACe<1 to 4>:HARMonic 0 to 10

This command sets the harmonics to be measured in harmonic measurements. The numeric suffix <1 to 4> indicates the selected trace.

Parameter: 0 = OFF
1 = fundamental
2 to 10 = 2nd harmonic to 10th harmonic

Example: "CONF:VCO:TRAC1:HARM 1"
'Selects fundamental for trace 1.

Characteristics: *RST value:
Trace 1 = Fundamental
Trace 2 = 2nd harmonic
Trace 3 = 3rd harmonic
Trace 4 = 3rd harmnoc
SCPI: device-specific

Mode: PNO

DIAGnostic Subsystem

The DIAGnostic subsystem contains the commands which support instrument diagnostics for maintenance, service and repair. In accordance with the SCPI standard, all of these commands are device-specific.

The measurement windows are selected by DIAGnostic1 (screen A) or DIAGnostic2 (screen B).

DIAGnostic<1|2>:SERVice:INPut[:SELEct] CALibration | RF

This command toggles between the RF input on the front panel and the internal 128 MHz reference signal in the selected measurement window. The level of the 128-MHz signals can be selected by [DIAGnostic<1|2>:SERVice:CSOource\[:POWEr\]](#) command.

Example: "DIAG:SERV:INP CAL"
 ' Selects the internal reference signal.

Characteristics: *RST value: RF
 SCPI: device-specific

Mode: PNO, A

DIAGnostic<1|2>:SERVice:INPut:PULSed[:STATe] ON | OFF

This command toggles the calibration signal in the selected measurement window between pulsed and non-pulsed.

In analyzer mode, the selection takes effect only if the RF input has been set to the internal reference signal using the [DIAGnostic<1|2>:SERVice:INPut\[:SELEct\]](#) command.

In phase noise mode, the internal reference signal is set if it is not already selected.

Example: for analyzer mode:
 "DIAG:SERV:INP CAL"
 "DIAG:SERV:INP:PULS ON"

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: PNO, A

DIAGnostic<1|2>:SERVice:INPut:PULSed:PRATe 10 kHz | 62.5 kHz | 100 kHz | 500 kHz | 1 MHz | 128 MHz | 640 MHz

This command selects the pulse rate for the pulsed calibration signal in the selected measurement window.

In analyzer mode, available frequencies are 10 kHz, 62.5 kHz, 100 kHz, 1 MHz, 128 MHz and 640 MHz.

In phase noise mode, available frequencies are 10 kHz, 62.5 kHz, 100 kHz, 500 KHz, 1 MHz, 128 MHz and 640 MHz.

Example: "DIAG:SERV:INP:PULS:PRAT 62.5 kHz"

Characteristics: *RST value: 128 MHz
 SCPI: device-specific

Mode: PNO, A

DIAGnostic<1|2>:SERVice:INPut:RECTangle[:STATe] ON | OFF

This command switches the rectangle calibration signal on or off in the selected measurement window (suffix <1|2>). The setting takes effect only if the RF input is set to the internal reference signal (`DIAG:SERV:INP CAL` command).

**Note**

If the rectangle calibration signal is switched on, the pulsed calibration signal is switched off.

Example: `"DIAG:SERV:INP CAL"`
 `"DIAG:SERV:INP:RECT ON"`

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

DIAGnostic<1|2>:SERVice:INPut:RECTangle:PRATe <numeric_value>

This command sets the frequency of the rectangle calibration signal in the selected measurement window (suffix <1|2>).

5 kHz | 31.25 kHz | 50 kHz | 250 kHz | 500 kHz can be set.

Example: `"DIAG:SERV:INP:RECT:PRAT 128 MHz"`

Characteristics: *RST value: 5 kHz
 SCPI: device-specific

Mode: A

DIAGnostic<1|2>:SERVice:SFUNction '<string>'

This command activates a service function which can be selected by indicating the five parameters: function group number, board number, function number, parameter 1 and parameter 2 (see service manual). The contents of the parameter string is identical to the code to be entered in the data entry field of manual operation.

The entry of a service function is accepted only if the system password Level 1 or Level 2 has been entered previously (command: `SYSTEM:SECurity`).

The numeric suffix <1|2> is ignored with this command.

**Note**

The service functions of the instrument are not identical to those of the FSE family. That is why the remote command differs in syntax and data format.

Example: "DIAG:SERV:SFUN '2.0.2.12.1'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

DIAGnostic<1|2>:SERVice:NSOource ON | OFF

This command switches the 28 V supply of the noise source at the rear panel on or off.

The numeric suffix <1|2> is ignored with this command.

Example: "DIAG:SERV:NSO ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

DIAGnostic<1|2>:SERVice:CSOource[:POWer] <numeric_value>

This command switches the level of the 128 MHz reference signal source between 0 dBm and -30 dBm in the selected measurement window.

Example: "DIAG:SERV:CSO 0DBM"

Characteristics: *RST value: -30 dBm
SCPI: device-specific

Mode: PNO, A

DIAGnostic<1|2>:SERVice:STES:RESult?

This command reads the results of the selftest out of the instrument. The lines of the result table are output as string data separated by commas:

The numeric suffix <1|2> is ignored with this command.

Parameter: "Total Selftest Status: PASSED", "Date (dd/mm/yyyy): 09/07/
2006
TIME: 16:24:54", "Runtime: 00:06", ...

Example: "DIAG:SERV:STES:RES?"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is only a query and therefore has no *RST value.

DIAGnostic<1|2>:SERVice:HWINfo?

This command queries the contents of the module info table. Table lines are output as string data and are separated by commas.

"<component 1>|<serial #>|<order #>|<model>|<HWC>|<rev>|<sub rev>",
"<component 2>|<serial #>|<order #>|<model>|<HWC>|<rev>|<sub rev>", ...

The individual columns of the table are separated from each other by '|'.
The numeric suffix <1|2> is ignored with this command.

Example: "DIAG:SERV:HWIN?"

Result (shortened):

```
"RF_ATTEN_7|650551/007|1067.7684|02|00|20|04",  
"IF-FILTER|648158/037|1093.5540|03|01|07|05",  
...
```

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

DISPlay Subsystem

The DISPlay subsystem controls the selection and presentation of textual and graphic information as well as of measurement data on the display.

The measurement windows are selected by WINDow1 (screen A) or WINDow2 (screen B).

DISPlay:FORMat SINGLE | SPLit

This command switches the measurement result display between FULL SCREEN and SPLIT SCREEN. The coupling of settings between screen A and screen B can be selected with the command INSTRument:COUPle.

In full-screen display the active measurement window can be selected with DISPlay:WINDow<1|2>:SELEct.

Example: "DISP:FORM SPL"
'Switches the display to 2 measurement windows.

Characteristics: *RST value: SINGLE
SCPI: device-specific

Mode: A

DISPlay:ANNotation:FREQuency ON | OFF

This command switches the x-axis annotation on or off.

Example: "DISP:ANN:FREQ OFF"

Characteristics: *RST value: ON
SCPI: conform

Mode: A

DISPlay:LOGO ON | OFF

This command switches the company logo on the screen on or off.

Example: "DISP:LOGO OFF"

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

DISPlay:PSAVe[:STATe] ON | OFF

This command switches on or off the power-save mode of the display. With the power-save mode activated the display including backlight is completely switched off after the elapse of the response time (see command DISPlay:PSAVe:HOLDoff).



Note

This mode is recommended for preserving the display especially if the instrument is exclusively operated via remote control.

Example: "DISP:PSAVe ON"
'Switches on the power-save mode.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

DISPlay:PSAVe:HOLDoff 1 to 60

This command sets the hold off time for the power-save mode of the display. The available value range is 1 to 60 minutes, the resolution 1 minute. The entry is dimensionless.

Example: "DISP:PSAV:HOLD 30"

Characteristics: *RST value: 15
SCPI: device-specific

Mode: A

DISPlay:CMAP<1 to 26>:DEFault<1|2>

This command resets the screen colors of all display items to their default settings. Two default settings DEFault1 and DEFault2 are available. The numeric suffix of CMAP is irrelevant.

Example: "DISP:CMAP:DEF2"
'Selects default setting 2 for setting the colors.

Characteristics: *RST value: --
SCPI: conform

Mode: A

This command is an event and therefore has no query and no *RST value.

DISPlay:CMAP<1 to 26>:HSL <hue>,<sat>,<lum>

This command defines the color table of the instrument.

Each numeric suffix of CMAP is assigned one or several graphical elements which can be modified by varying the corresponding color setting. The following assignment applies:

CMAP1	Background
CMAP2	Grid
CMAP3	Function field + status field + data entry text
CMAP4	Function field LED on
CMAP5	Function field LED warn
CMAP6	Enhancement label text
CMAP7	Status field background
CMAP8	Trace 1
CMAP9	Trace 2
CMAP10	Trace 3
CMAP11	Marker
CMAP12	Lines
CMAP13	Measurement status + limit check pass
CMAP14	Limit check fail

CMAP15	Table + softkey background
CMAP16	Table + softkey text
CMAP17	Table selected field text
CMAP18	Table selected field background
CMAP19	Table + data entry field opaque title bar
CMAP20	Data entry field opaque text
CMAP21	Data entry field opaque background
CMAP22	3D shade bright part
CMAP23	3D shade dark part
CMAP24	Softkey state on
CMAP25	Softkey state data entry
CMAP26	Logo

Parameter: hue = TINT
 sat = SATURATION
 lum = BRIGHTNESS

The value range is 0 to 1 for all parameters.

Example: "DISP:CMAP2:HSL 0.3,0.8,1.0"
 'Changes the grid color.

Characteristics: *RST value: --
 SCPI: conform

Mode: A

The values set are not changed by *RST.

DISPlay:CMAP<1 to 26>:PDEFined BLACK | BLUE | BROWN | GREEN | CYAN | RED | MAGenta |
 YELLOW | WHITE | DGRAY | LGRAY | LBLUE | LGREEN | LCYan | LRED | LMAGenta

This command defines the color table of the instrument using predefined color values. Each numeric suffix of CMAP is assigned one or several graphical elements which can be modified by varying the corresponding color setting.

The same assignment as for DISPlay:CMAP<1 to 26>:HSL applies.

Example: "DISP:CMAP2:PDEF GRE"

Characteristics: *RST value: --
 SCPI: conform

Mode: A

The values set are not changed by *RST.

DISPlay[:WINDow<1|2>]:ACTive?

This command returns the active measurement window. The numeric response has following meaning:

- 1 Screen A
- 2 Screen B
- 3 Screen C
- 4 Screen D

Example: "DISP:WIND:ACT?"
returns the active window

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

The numeric suffix at WINDow<1|2> is irrelevant.

DISPlay[:WINDow<1|2>]:SElect

This command selects the active measurement window. WINDow1 corresponds to SCREEN A, WINDow2 to SCREEN B.

In full screen mode, the measurements are only performed in the active measurement window. Measurements are therefore initiated in the active window and result queries (marker, trace data and other results) answered also in the active window.

Initiating measurements and querying results in the inactive window yields an error message (execution error).

In split screen mode, the selection of the active window for result queries is irrelevant.



Note

In full screen mode, settings can also be performed in the inactive measurement window. They become effective as soon as the corresponding window becomes active.

Example: "DISP:WIND2:SEL"
'Selects screen B as active measurement window.

Characteristics: *RST value: SCREEN A active
SCPI: device-specific

Mode: A

This command is an event and therefore has no query.

DISPlay[:WINDow<1|2>]:SIZE LARGe | SMALl

This command switches the measurement window for channel and adjacent channel power measurements or for active FM demodulator to full screen or half screen. Only "1" is allowed as a numerical suffix.

Example: "DISP:WIND1:SIZE LARG"
'Switches the measurement window to full screen.

Characteristics: *RST value: SMALl
SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TEXT[:DATA] <string>

This command defines a comment (max. 20 characters) which can be displayed on the screen in the selected measurement window.

Example: "DISP:WIND2:TEXT 'Noise Measurement'"
 'Defines the title for screen B

Characteristics: *RST value: "" (empty)
 SCPI: conform

Mode: A

DISPlay[:WINDow<1|2>]:TEXT:STATe ON | OFF

This command switches on or off the display of the comment (screen title) in the selected measurement window.

Example: "DISP:TEXT:STAT ON"
 'Switches on the title of screen B.

Characteristics: *RST value: OFF
 SCPI: conform

Mode: A

DISPlay[:WINDow<1|2>]:TIME ON | OFF

This command switches on or off the screen display of date and time. The numeric suffix in WINDow<1|2> is irrelevant.

Example: "DISP:TIME ON"

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>:X:SPACing LINear | LOGarithmic

This command toggles between linear and logarithmic display.

Example: "DISP:TRAC:X:SPAC LIN"

Characteristics: *RST value: LOGarithmic
 SCPI: conform

Mode: A

The numeric suffix in TRACe<1 to 3> is irrelevant.

DISPlay[:WINDow<1|2>]:TRACe<1...8>:X:UNIT VOLTage | FREQUency

This command sets the x-axis unit to voltage or frequency for VCO measurements.

The numeric suffix at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:X:UNIT VOLT"
 'X-axis unit is set to VOLT.

Characteristics: *RST value: VOLT
 SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1 to n>:Y[:SCALe] 10dB to 200dB

In analyzer mode, this command defines the display range of the y-axis (level axis) in the selected measurement window with logarithmic scaling ([DISPlay\[:WINDow<1|2>\]:TRACe<1 to 3>:Y:SPACing](#)). For linear scaling, the display range is fixed and cannot be modified. The numeric suffix at TRACe<1 to n> is irrelevant.

In phase noise mode, this command defines the display range of the y-axis (level axis) for the Noise measurements. The automatic scaling must be switched off ([DISPlay\[:WINDow<1|2>\]:TRACe<1...8>:Y\[:SCALe\]:AUTO](#)). The numeric suffix at WINDow<1|2> and TRACe<1 to n> are irrelevant.

Example: "DISP:TRAC:Y 110dB"

Characteristics: *RST value: 100dB
SCPI: device-specific

Mode: PNO, A

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y[:SCALe]:AUTO ON | OFF | ONCE

This command switches automatic scaling for the y-axis on and off. The ONCE setting causes the automatic scaling to be performed immediately, regardless of whether automatic scaling is switched on or not.

The numeric suffix at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:AUTO ON"
'Automatic scaling is switched on.'

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>:Y[:SCALe]:MODE ABSolute | RELative

This command defines the scale type of the y-axis (absolute or relative) in the selected measurement window. `SYSTEM:DISPlay` is set to OFF, this command has no immediate effect on the screen. The numeric suffix in TRACe<1 to 3> is irrelevant.

Example: "DISP:TRAC:Y:MODE REL"

Characteristics: *RST value: ABS
SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to n>:Y[:SCALe]:RLEVel -130 dBm to 30 dBm (analyzer mode)
-200 dBc/Hz to 50 dBc/Hz (phase noise mode)

In analyzer mode, this command defines the reference level in the selected measurement window. Depending on the coupling of the measurement windows, it is valid for both screens or only for the selected measurement window ([INSTrument:COUPlE](#)). The unit depends on the setting defined with the [CALCulate<1|2>:UNIT:POWer](#) command.

The numeric suffix at TRACe<1 to n> is irrelevant.

In phase noise mode, this command specifies the current internal instrument reference level used when performing measurements.

The numeric suffixes at WINDow<1|2> and TRACe<1 to n> are irrelevant.

If the reference level offset is not 0 ([DISPlay\[:WINDow<1|2>\]:TRACe<1 to n>:Y\[:SCALe\]:RLEVel:OFFSet](#)), the indicated value range of the reference level is modified by the offset.

Example: "DISP:TRAC:Y:RLEV -60"

Characteristics: *RST value: -20
SCPI: conform

Mode: PNO, A

DISPlay[:WINDow<1|2>]:TRACe<1 to n>Y[:SCALe]:RLEVel:OFFSet -200dB to 200dB

In analyzer mode, this command defines the offset of the reference level in the selected measurement window. Depending on the coupling of the measurement windows, it is valid for both screens or only for the selected measurement window (*INSTrument:COUPle*).

In phase noise mode, this remote control command specifies the external attenuation/gain applied to measurements.

The numeric suffix at TRACe<1 to n> selects the trace. In analyzer mode, up to 3 traces are available (numeric suffix n = 3). In phase noise mode, up to 8 traces are available (numeric suffix n = 8).

In phase noise mode, also the numeric suffix at WINDow<1|2> is irrelevant.

Example: "DISP:TRAC:Y:RLEV:OFFS -10dB"

Characteristics: *RST value: 0dB
SCPI: conform

Mode: PNO, A

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>Y[:SCALe]:RVALue <numeric_value>

If the external generator control option (R&S FSP-B10) is available and the normalization in the NETWORK mode is activated, this value defines the power value assigned to the reference position in the selected measurement window. This value corresponds to the parameter REFERENCE VALUE in manual operation.

The numeric suffix at TRACe<1 to 3> is irrelevant.

Example: "DISP:TRAC:Y:RVAL 0"
'Sets the power value assigned to the reference position to 0 dB (Ext. Generator Control option) or 0 Hz (FM demodulator mode).

Characteristics: *RST value:
0 dB (NETWORK mode)
0 Hz (FM demodulator mode with FM display)
2.5 MHz (FM demodulator mode with AF spectrum display of FM)
SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>Y[:SCALe]:RPOSition 0 to 100PCT

This command defines the position of the reference value in the selected measurement window. The numeric suffix in TRACe<1 to 3> is irrelevant.

In NETWORK mode (Ext. Generator option R&S FSP-B10) with active normalization, RPOSition defines the reference point for the output of the normalized measurement results.

With the FM demodulator switched on, the reference position for result display RF POWER and SPECTRUM is kept separate from that for result display FM.

Example: "DISP:TRAC:Y:RPOS 50PCT"

Characteristics: *RST value:
 100PCT(analyzer mode)
 50 PCT (NETWORK and FM demodulator mode)
 50 PCT (FM demodulator mode with FM display)
 100 PCT (FM demodulator mode with AF spectrum display of FM)
 SCPI: conform

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>:Y:SPACing LINear | LOGarithmic| LDB

This command toggles between linear and logarithmic display in the selected measurement window. On a linear scale, switch over between the unit % (command `DISP:WIND:TRAC:Y:SPAC LIN`) and the unit dB (command `DISP:WIND:TRAC:Y:SPAC LDB`) is also possible.

If the FM demodulator is active and result display AF spectrum of FM is selected, only the parameters LINear and LOGarithmic are permissible.

The numeric suffix in TRACe<1 to 3> is irrelevant.

Example: "DISP:TRAC:Y:SPAC LIN"

Characteristics: *RST value: LOGarithmic
 SCPI: conform

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:AUTO ON | OFF | ONCE

This command switches automatic scaling of the y-axis on or off for Transient measurements. The ONCE setting causes the automatic scaling to be performed immediately, regardless of whether the automatic scaling is switched on or not. This command will update the selected Transient measurement display.

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:TRAN:AUTO ON"
 'Switches on automatic scaling.

Characteristics: *RST value: ON
 SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:TOP <numeric_value>

This command sets the upper value of the y-axis for Transient measurements. Depending on the configured measurement display, this command takes Hz, dBm, radius or percentage as unit. The automatic scaling must be switched off ([DISPlay\[:WINDow<1|2>\]:TRACe<1...8>:Y:TRANSient\[:SCALE\]:AUTO](#)).

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:TRAN:TOP 1GHZ"
 'Sets the upper value of the y-axis to 1 GHz.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:TRANSient [:SCALe]:RANGe <numeric_value>

This command sets the range of the y-axis for Transient measurements. Depending on the configured measurement display, this command takes Hz, dB, radius or percentage as unit. The automatic scaling must be switched off ([DISPlay\[:WINDow<1|2>\]:TRACe<1...8>:Y:TRANSient\[:SCALe\]:AUTO](#)).

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:TRAN:RANG 1GHZ"
'Sets the range of the y-axis to 1 GHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:TRANSient [:SCALe]:OFFSet <numeric_value>

This command sets the offset of the y-axis for Transient measurements. Depending on the configured measurement display, this command takes Hz, dB, radius or percentage as unit.

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:TRAN:OFFS 3MHZ"
'Sets the frequency offset to 3 MHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>:Y:UNIT?

This command returns the Y unit that has been set.

This command is only a query and has the *RST value from the UNIT:POWER command.

The numeric suffix in TRACe<1 to 3> has no significance.

Example: "DISP:WIND1:TRAC:Y:UNIT?"

Characteristics: *RST value: DBM
SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:VCO[:SCALe]:AUTO ON | OFF | ONCE

This command switches automatic scaling of the y-axis on and off for VCO measurements. The ONCE setting causes the automatic scaling to be performed immediately, regardless of whether the automatic scaling is switched on or not.

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:VCO:AUTO ON"
'Switches on the automatic scaling.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:VCO[:SCALe]:TOP <numeric_value>

This command sets the upper value of the y-axis for VCO measurements. Depending on the configured measurement display, this command takes Hz, dBm or Hz/V units. The automatic scaling must be switched off ([DISPlay\[:WINDow<1|2>\]:TRACe<1...8>:Y:VCO\[:SCALe\]:AUTO](#)).

The numeric suffix at WINDow<1|2> is irrelevant.

For DC Char measurements, the suffix at TRACe is used. TRACe1 is frequency and TRACe2 is level.

For Tuning Char and harmonic measurements, the numeric suffix at TRACe<1 to 8> is irrelevant.

Example: "DISP:TRAC:Y:VCO:TOP 20GHZ"
'Sets the upper value of the y-axis to 20 GHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:VCO[:SCALe]:RANGe <numeric_value>

This command sets the range of the y-axis for VCO measurements. Depending on the configured measurement display, this command takes Hz, dB or Hz/V units. The automatic scaling must be switched off ([DISPlay\[:WINDow<1|2>\]:TRACe<1...8>:Y:VCO\[:SCALe\]:AUTO](#)).

The numeric suffix at WINDow<1|2> is irrelevant.

For DC Char measurements, the suffix at TRACe is used. TRACe1 is frequency and TRACe2 is level.

For Tuning Char and harmonic measurements, the numeric suffix at TRACe<1 to 8> is irrelevant.

Example: "DISP:TRAC:Y:VCO:RANG 10GHZ"
'Sets the range of the y-axis to 10 GHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:Y:VCO[:SCALe]:OFFSet <numeric_value>

This command sets the frequency offset of the y-axis for VCO measurements.

The numeric suffixes at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:Y:VCO:OFFS 3MHZ"
'Sets the frequency offset to 3 MHz.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1 to n>:MODE WRITe | VIEW | AVERAge | MAXHold | MINHold

This command defines the type of display and the evaluation of the traces in the selected measurement window. WRITE corresponds to the Clr/Write mode of manual operation.

The trace is switched off (= BLANK in manual operation) with the [DISPlay\[:WINDow<1|2>\]:TRACe<1 to n>\[:STATe\]](#) command.

In analyzer mode, the number of measurements for AVERAge, MAXHold and MINHold is defined with the [\[SENSe<1|2>:\]AVERAge:COUNT](#) or [\[SENSe<1|2>:\]SWEp:COUNT](#) command.

In phase noise mode, the MINHold trace mode is not available at all. All other trace modes are only available for Noise and Transient measurements. The number of measurements for AVERage is defined with the command [SENSe<1|2>:]SWEep:COUNT. The numeric suffix at WINDow<1|2> is irrelevant.

The numeric suffix at TRACe<1 to n> selects the trace. In analyzer mode, up to 3 traces are available (numeric suffix n = 3). In phase noise mode, up to 8 traces are available (numeric suffix n = 8).

Synchronization to the end of the indicated number of measurements is only possible in single-sweep mode.

If, in analyzer mode, calculation of average values is active, selection between logarithmic and linear averaging is possible. For more detail see command [SENSe<1|2>:]AVERage:TYPE.

Example: for analyzer mode
 "INIT:CONT OFF"
 'Switching to single-sweep mode.

 "SWE:COUN 16"
 'Sets the number of measurements to 16.

 "DISP:WIND1:TRAC3:MODE MAXH"
 'Switches on the calculation of the for trace 3 in screen A.

 "INIT;*WAI"
 'Starts the measurement and waits for the end of the 16 sweeps.

Characteristics: *RST value: WRITe for TRACe1, STATe OFF for TRACe2/3
 SCPI: device-specific

Mode: PNO, A

DISPlay[:WINDow<1|2>]:TRACe<1 to 3>:MODE:HCONTinuous ON | OFF

This command specifies whether or not the traces with peak or minimum value detection are reset after specific parameter changes.

Usually the measurement must be restarted after a parameter change, before an evaluation of the measurement results is performed (e.g. with a marker). In cases in which a change causes a compulsory new measurement, the trace is automatically reset in order to prevent erroneous measurements of previous measurement results (e.g. when the span changes). For applications in which this behavior is not desired, this mechanism can be switched off.

Parameter: OFF: The traces are reset after specific parameter changes.
 ON: The reset mechanism is switched off.

Example: "DISP:WIND1:TRAC3:MODE:HCON ON"
 'The reset mechanism is switched off for measurement window 1.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A

DISPlay[:WINDow<1|2>]:TRACe<1 to n>[:STATe] ON | OFF

This command switches on or off the display of the corresponding trace in the selected measurement window.

The numeric suffix at TRACe<1 to n> selects the trace. In analyzer mode, up to 3 traces are available (numeric suffix n = 3). In phase noise mode, up to 8 traces are available (numeric suffix n = 8); the numeric suffix at WINDow<1|2> is irrelevant.

Example: "DISP:WIND1:TRAC3 ON"

Characteristics: *RST value: ON for TRACe1, OFF for TRACe2 and 3
SCPI: conform

Mode: PNO, A

DISPlay[:WINDow<1|2>]:TRACe<1...8>:SCOPe[:STATe] ON | OFF

This command switches on the Phase Detector scope display if the Phase Noise PLL measurement is selected.

The numeric suffix at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:SCOP OFF"
'Switches on the Phase Detector display.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:SMOothing[:STATe] ON | OFF

This command specifies whether smoothing of a particular trace is performed.

The numeric suffix at WINDow<1|2> is irrelevant

Example: "DISP:TRAC1:SMO OFF"
'Specifies that smoothing of trace 1 is to be performed.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:SMOothing:APERture 1 to 20

This command specifies the aperture of the window to be used when trace smoothing is performed.

An aperture applies to all traces which require smoothing. Therefore the numeric suffix at WINDow<1|2> and TRACe<1 to 8> are irrelevant.

Example: "DISP:TRAC:SMO:APER 10"
'Sets the smoothing window to 10%.

Characteristics: *RST value: 1 PCT
SCPI: device-specific

Mode: PNO

DISPlay[:WINDow<1|2>]:TRACe<1...8>:SMOothing:TYPE LINear | LOGarithmic | MEDian

This command specifies whether linear, logarithmic or median smoothing is to be used when trace smoothing is performed.

Example: "DISP:TRAC1:SMO:TYPE LOG"
'Sets the smoothing type for trace 1 to logarithmic smoothing.

Characteristics: *RST value: LIN
SCPI: device-specific

Mode: PNO

FETCh Subsystem

The FETCh subsystem contains commands for reading out results of complex measurement tasks.

FETCh:EXTernal:LOWPass:FREQuency?

This command returns the measured external lowpass frequency.

This command is for service only.

Example: "FETC:EXT:LOWP:FREQ?"
'Returns the external lowpass frequency result.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:PNOise<1 to 8>:IPN?

This command returns the measured Integrated Phase Noise result.

The numeric suffix at PNOise<1 to 8> selects the trace.

Example: "FETC:PNO1:IPN?"
'Returns the Integrated Phase Noise result.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:PNOise<1 to 8>:RFM?

This command returns the measured residual FM result.

The numeric suffix at PNOise<1 to 8> selects the trace.

Example: "FETC:PNO:RFM?"
'Returns the Residual FM result.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:PNOise<1 to 8>:RPM?

This command returns the measured residual PM result.

The numeric suffix at PNOise<1 to 8> selects the trace.

Example: "FETC:PNO:RPM?"
'Returns the Residual PM result.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:PNOise<1 to 8>:RMS?

This command returns the measured residual RMS result.

The numeric suffix at PNOise<1 to 8> selects the trace.

Example: "FETC:PNO:RMS?"
'Returns the Residual RMS result.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:PNOise<1 to 8>:SPURs?

This command returns the measured spurs results. The data is returned in x,y,x,y,x,y....format:
x value for frequency, y value for power.

The numeric suffix at PNOise<1 to 8> selects the trace.

Example: "FETC:PNO:SPUR?"
'Returns the measured spurs.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:TCHar<1 to 4>:FREQUency?

This command returns a list of measured frequency results at the minimum, current and maximum tuning voltages.

The numeric suffix at TCHar<1 to 4> is irrelevant.

Example: "FETC:VCO:TCH:FREQ?"
'Returns the tuning characteristics frequency results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:TCHar<1 to 4>:POWER?

This command returns a list of measured power results at minimum, current and maximum tuning voltages.

The numeric suffix at TCHar<1 to 4> is irrelevant.

Example: "FETC:VCO:TCH:POW?"
'Returns the tuning characteristics power results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:TCHar<1 to 4>:SENSitivity?

This command returns a list of measured sensitivity results at minimum, current and maximum tuning voltages.

The numeric suffix at TCHar<1 to 4> is irrelevant.

Example: "FETC:VCO:TCH:SENS?"
'Returns the tuning characteristics sensitivity results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:PUSHing:FDEVIation?

This command returns a list of measured frequency deviation results at pushing voltages in the following format:

- frequency deviation at (current tuning voltage + pushing voltage)
- frequency deviation at (current tuning voltage - pushing voltage)

Example: "FETC:VCO:PUSH:FDEV?"
'Returns the pushing characteristics frequency deviation results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:PUSHing:PDEVIation?

This command returns a list of measured power deviation results at pushing voltages in the following format:

- power deviation at (current tuning voltage + pushing voltage)
- power deviation at (current tuning voltage - pushing voltage)

Example: "FETC:VCO:PUSH:PDEV?"
'Returns the pushing characteristics power deviation results.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

FETCh:VCO:PUSHing:SENSitivity?

This command returns a list of measured sensitivity results at pushing voltages in the following format:

- sensitivity at (current tuning voltage + pushing voltage)
- sensitivity at (current tuning voltage - pushing voltage)

Example: "FETC:VCO:PUSH:SENS?"
'Returns the pushing characteristics sensitivity results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:PULLing:FDEVIation?

This command returns a list of measured frequency deviation results at the trigger port in the following format:

- frequency deviation (with termination 1)
- frequency deviation (with termination 2)

This command is only available with option R&S FSUP-B28.

Example: "FETC:VCO:PULL:FDEV?"
'Returns the pulling characteristics frequency deviation results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:PULLing:PDEVIation?

This command returns a list of measured power deviation results at the trigger port in the following format:

- power deviation (with termination 1)
- power deviation (with termination 2)

This command is only available with option R&S FSUP-B28.

Example: "FETC:VCO:PULL:PDEV?"
'Returns the pulling characteristics power deviation results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:PULLing:SENSitivity?

This command returns a list of measured sensitivity deviation results at the trigger port in the following format:

- sensitivity deviation (with termination 1)
- sensitivity deviation (with termination 2)

This command is only available with option R&S FSUP-B28.

Example: "FETC:VCO:PULL:SENS?"
'Returns the pulling characteristics sensitivity deviation results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:HCHar<1 to 8>:FREQUency?

This command returns a list of measured harmonic frequency results at minimum, current and maximum tuning voltages.

The numeric suffix at HCHar<1 to 8> is irrelevant.

Example: "FETC:VCO:HCH1:FREQ?"
'Returns the harmonic measurement frequency results for trace 1.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:HCHar<1 to 8>:POWer:ABSolute?

This command returns a list of measured absolute harmonic power results at minimum, current and maximum tuning voltages.

The numeric suffix at HCHar<1 to 8> is irrelevant.

Example: "FETC:VCO:HCH2:POW:ABS?"
'Returns the harmonic measurement absolute power results for trace 2.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:HCHar<1 to 8>:POWer:RELative?

This command returns a list of measured relative power results at minimum, current and maximum tuning voltages.

The numeric suffix at HCHar<1 to 8> is irrelevant.

Example: "FETC:VCO:HCH2:POW:REL?"
'Returns the harmonic measurement relative power results for trace 2.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:HCHar<1 to 8>:SENSitivity?

This command returns a list of measured harmonic sensitivity results at minimum, current and maximum tuning voltages.

The numeric suffix at HCHar<1 to 8> is irrelevant.

Example: "FETC:VCO:HCH3:SENS?"
'Returns the tuning characteristics sensitivity results for trace 3.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCh:VCO:DCHar<1 to 4>:FREQuency?

This command returns a list of measured frequency results at minimum, current and maximum supply voltages.

The numeric suffix at DCHar<1 to 4> is irrelevant.

Example: "FETC:VCO:DCH:FREQ?"
'Returns the DC characteristics frequency results.

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FETCH:VCO:DCHAr<1 to 4>:POWer?

This command returns a list of measured power results at minimum, current and maximum supply voltages.

The numeric suffix at DCHAr<1 to 4> is irrelevant.

Example: "FETC:VCO:DCH:POW?"
'Returns the DC characteristics power results.'

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

FORMat Subsystem

The FORMat subsystem specifies the data format of the data transmitted from and to the instrument.

FORMat[:DATA] ASCii | REAL| UINt [, 8 | 32]

This command specifies the data format for the data transmitted from the instrument to the control PC.

The format settings are valid for the binary transmission of trace data (see also [TRACe<1|2>\[:DATA\]](#)).

Parameter: SPECTRUM mode: REAL, 32

Example: "FORM REAL, 32"

"FORM ASC"

"FORM UINt, 8"

Characteristics: *RST value: ASCII
SCPI: conform

Mode: PNO, A

The data format is either ASCII or one of the formats REAL. ASCII data are transmitted in plain text, separated by commas. REAL data are transmitted as 32-bit IEEE 754 floating-point numbers in the "definite length block format".

The FORMat command is valid for the transmission of trace data. The data format of trace data received by the instrument is automatically recognized, regardless of the format which is programmed.



Note

Incorrect format setting will result in numerical conversion, which may lead to incorrect results.

FORMat:DEXPort:DSEParator POINt | COMMA

This command defines which decimal separator (decimal point or comma) is to be used for outputting measurement data to the file in ASCII format. Different languages of evaluation programs (e.g. Microsoft Excel) can thus be supported.

Example: "FORM:DEXP:DSEP POIN
'Sets the decimal point as separator.

Characteristics: *RST value: -- (factory setting is POINt; *RST does not affect setting)
SCPI: device-specific

Mode: PNO, A

HCOPy Subsystem

The HCOPy subsystem controls the output of display information for documentation purposes on output devices or files. The instrument allows two independent printer configurations which can be set separately with the numeric suffix <1|2>.

HCOPy:ABORt

This command aborts a running hardcopy output.

Example: "HCOP:ABOR"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

HCOPy:CMAP<1 to 26>:DEFault1|2|3

This command resets the colors for a hardcopy to the selected default settings. DEFault1 (SCREEN COLORS, but background white), DEFault2 (OPTIMIZED COLOR SET) and DEFault3 (USER DEFINED). The numeric suffix in CMAP is not significant.

Example: "HCOP:CMAP:DEF2"
'selects OPTIMIZED COLOR SET for the color settings of a hardcopy.

Characteristics: *RST value: --
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no query and no *RST value.

HCOPy:CMAP<1 to 26>:HSL <hue>,<sat>,<lum>

This command defines the color table in USER DEFINED COLORS mode.

To each numeric suffix of CMAP is assigned one or several picture elements which can be modified by varying the corresponding color setting. The following assignment applies:

CMAP1	Background
CMAP2	Grid
CMAP3	Function field + status field + data entry text
CMAP4	Function field LED on
CMAP5	Function field LED warn
CMAP6	Enhancement label text
CMAP7	Status field background
CMAP8	Trace 1
CMAP9	Trace 2
CMAP10	Trace 3
CMAP11	Marker
CMAP12	Lines
CMAP13	Measurement status + limit check pass

CMAP14	Limit check fail
CMAP15	Table + softkey background
CMAP16	Table + softkey text
CMAP17	Table selected field text
CMAP18	Table selected field background
CMAP19	Table + data entry field opaque title bar
CMAP20	Data entry field opaque text
CMAP21	Data entry field opaque background
CMAP22	3D shade bright part
CMAP23	3D shade dark part
CMAP24	Softkey state on
CMAP25	Softkey state data entry
CMAP26	Logo

Parameter: hue = tint
 sat = saturation
 lum = brightness
 The value range is 0 to 1 for all parameters

Example: "HCOP:CMAP2:HSL 0.3,0.8,1.0"
 'Changes the grid color.

Characteristics: *RST value: --
 SCPI: conform

Mode: PNO, A

The values set are not changed by *RST.

HCOPY:CMAP<1 to 26>:PDEFined BLACK | BLUE | BROWn | GREen | CYAN | RED | MAGenta |
 YELLow | WHITE | DGRAY | LGRAY | LBLUE | LGREEN | LCYan | LRED | LMAGenta

This command defines the color table in USER DEFINED COLORS using predefined color values. To each numeric suffix of CMAP is assigned one or several picture elements which can be modified by varying the corresponding color setting. The same assignment as for :HCOPY:CMAP<1 to 26>:HSL applies

Example: "HCOP:CMAP2:PDEF GRE"

Characteristics: *RST value: --
 SCPI: conform

Mode: PNO, A

The values set are not changed by *RST.

HCOPY:DESTination<1|2> <string>

This command selects the printer output medium (Disk, Printer or Clipboard) associated with configuration 1 or 2.



Note

The type of instrument is selected with `SYSTEM:COMMunicate:PRINter:SElect`, which will automatically select a default output medium. Therefore the command `HCOPY:DESTination` should always be sent after setting the device type.

Parameter: <string>::= 'SYST:COMM:GPIB' | 'SYST:COMM:SER' | 'SYST:COMM:CENT' | 'MMEM' | 'SYST:COMM:PRIN' | 'SYST:COMM:CLIP'

'MMEM': Directs the hardcopy to a file. Command `MMEM:NAME '<file_name>'` defines the file name. All formats can be selected for `HCOPY:DEVIce:LANGuage`.

'SYST:COMM:PRIN': Directs the hardcopy to the printer. The printer is selected with command `SYSTEM:COMMunicate:PRINter:SElect`. `GDI` should be selected for `HCOPY:DEVIce:LANGuage`.

'SYST:COMM:CLIP': Directs the hardcopy to the clipboard. `EWMF` should be selected for `HCOPY:DEVIce:LANGuage`.

Example: `"SYST:COMM:PRIN:SEL2 'LASER on LPT1'"`
 'Selects the printer and output medium for device 2

`"HCOP:DEST2 'SYST:COMM:PRIN'"`
 'Selects the printer interface as device 2.

Characteristics: *RST value: -
 SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

HCOPY:DEVIce:COLor ON|OFF

This command selects between color and monochrome hardcopy of the screen.

Example: `"HCOP:DEV:COL ON"`

Characteristics: *RST value: OFF
 SCPI: conform

Mode: PNO, A

HCOPY:DEVIce:LANGUage<1|2> GDI | WMF | EWMF | BMP

This command determines the data format for the printed output.

Parameter: GDI (Graphics Device Interface): Default format for output to a printer that has been configured under Windows. Must be selected for output to the printer interface (HCOPY:DEVIce 'SYST:COMM:PRIN'). Can be used for output to a file (HCOPY:DEVIce 'SYST:COMM:MMEM'). The printer driver that was configured under Windows is used to generate a file format that is specific to the printer. GDI is available only for HCOPI:MODE SCReen.

WMF (WINDOWS Metafile) and EWMF (Enhanced Metafile Format): Data formats for output to files which can be directly processed at a later point in time for documentation purposes using suitable software. WMF can be used only for output to a file (HCOPY:DEVIce 'SYST:COMM:MMEM'), EWMF can also be used for output to the clipboard (HCOPY:DEVIce 'SYST:COMM:CLIP').

BMP (Bitmap): Data format, exclusively for output to files (HCOPY:DEVIce 'SYST:COMM:MMEM').

BMP is available only for HCOPI:MODE SCReen.

Example: "HCOP:DEV:LANG WMF"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

HCOPY[:IMMEDIATE<1|2>]

This command starts a hardcopy output. The numeric suffix selects which printer configuration (1 or 2) is to be used for the hardcopy output. If there is no suffix, configuration 1 is automatically selected.

Example: "HCOP"
"HCOPY:IMM1"
'Starts the hardcopy output to device 1 (default).'
"HCOPY:IMM2"
'Starts the output to device 2.'

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

HCOPY:ITEM:ALL

This command selects the complete screen to be output.

The hardcopy output is always provided with comments, title, time and date. As an alternative to the whole screen, only traces (commands 'HCOPY:ITEM:WINDow:TRACe:STATe ON') or tables (command 'HCOPY:ITEM:WINDow:TABLE:STATe ON') can be output.

Example: "HCOP:ITEM:ALL"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

HCOPY:ITEM:WINDow<1|2>:TABle:STATe ON | OFF

This command selects the output of the currently displayed tables.

Example: "HCOP:ITEM:WIND:TABL:STAT ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

The command `HCOPY:DEVIce:ITEM:WINDow<1|2>:TABle:STATe OFF` as well as command `HCOPY:DEVIce:ITEM:ALL` enables the output of the whole screen.

HCOPY:ITEM:WINDow<1|2>:TEXT <string>

This command defines the comment text for measurement window 1 or 2 for printout, with a maximum of 100 characters; line feed by means of character @).

Example: "HCOP:ITEM:WIND2:TEXT 'comment'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

HCOPY:ITEM:WINDow<1|2>:TRACe:STATe ON | OFF

This command selects the output of the currently displayed trace.

Example: "HCOP:ITEM:WIND:TRACe:STAT ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

The command `HCOPY:ITEM:WINDow<1|2>:TRACe:STATe OFF` as well as command `HCOPY:ITEM:ALL` enables the output of the whole screen.

HCOPY:PAGE:ORIENTATION<1|2> LANDscape | PORTRait

The command selects the format of the output (portrait and landscape) (hardcopy unit 1 or 2).



Note

The command is only available provided that the output device "printer" (HCOPY:DEST 'SYST:COMM:PRIN') has been selected.

Example: "HCOPY:PAGE:ORI LAND"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

INITiate Subsystem

The INITiate subsystem controls the init-measurement function in the selected measurement window. The measurement windows are assigned to INITiate1 (screen A) and INITiate2 (screen B).

It is basically used to tell the instrument which measurement is to be performed and takes any necessary step to set up the instrument for the measurement.

INITiate<1|2>:CONTinuous ON | OFF

This command determines whether the trigger system is continuously initiated (continuous) or performs single measurements (single).

In analyzer mode, this setting refers to the sweep sequence (switching between continuous/single sweep).

In phase noise mode, the numeric suffix of INITiate is irrelevant.

Example: "INIT:CONT OFF"
'Switches the sequence in screen B to single sweep.
"INIT:CONT ON"
'Switches the sequence to continuous sweep.

Characteristics: *RST value: ON
SCPI: conform

Mode: PNO, A

INITiate<1|2>:CONMeas

This command continues a stopped measurement at the current position in single-sweep mode. The function is useful especially for trace functions MAXHold, MINHold and AVERage if the previous results are not to be cleared with Sweep Count > 0 or Average Count > 0 on restarting the measurement (INIT:IMMEDIATE resets the previous results on restarting the measurement).

The single-sweep mode is automatically switched on. Synchronization to the end of the indicated number of measurements can then be performed with the command *OPC, *OPC? or *WAI. In the continuous-sweep mode, synchronization to the sweep end is not possible since the overall measurement "never" ends.

Example: "INIT:CONT OFF"
'Switches to single-sweep mode.
"DISP:WIND:TRAC:MODE AVER"
'Switches on trace averaging.
"SWE:COUN 20"
Setting the sweep counter to 20 sweeps.
"INIT;*WAI"
'Starts the measurement and waits for the end of the 20 sweeps.
"INIT:CONM;*WAI"
'Continues the measurement (next 20 sequences) and waits for the end.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

INITiate<1|2>[:IMMediate]

In analyzer mode, this command initiates a new sweep in the indicated measurement window.

In phase noise mode, this command initiates a new measurement sequence. The numeric suffix of INITiate is irrelevant. If a measurement sequence is already in progress, the command is ignored.

With Sweep Count > 0 or Average Count > 0, this means a restart of the indicated number of measurements. With trace functions MAXHold, MINHold and AVERage, the previous results are reset on restarting the measurement.

In single-sweep mode, synchronization to the end of the indicated number of measurements can be achieved with the command *OPC, *OPC? or *WAI. In continuous-sweep mode, synchronization to the sweep end is not possible since the overall measurement never ends.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode.

"DISP:WIND:TRAC:MODE AVER
'Switches on trace averaging.

"SWE:COUN 20"
Setting the sweep counter to 20 sweeps.

"INIT;*WAI"
'Starts the measurement and waits for the end of the 20 sweeps.
```

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

INITiate<1|2>:DISPlay ON | OFF

This command configures the behavior of the display during a single sweep.

The numeric suffix of INITiate is irrelevant with this command.

Parameter: OFF: the display is switched off during the measurement,
ON: the display is switched on during the measurement.

Example:

```
"INIT:CONT OFF"
'Switches to single-sweep mode

"INIT:DISP OFF"
'Sets the display behavior to OFF

"INIT;*WAI"
'Starts the measurement with display switched off.
```

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO, A

INITiate<1|2>:SPURious

This command starts a new spurious measurement.

Example: "INIT:CONT OFF"
 'switches to single-sweep mode

 "INIT:SPUR;*WAI"
 'starts the measurement by waiting for the end of the 20 measurements

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

INPut Subsystem

The INPut subsystem controls the input characteristics of the RF inputs of the instrument. The measurement windows are assigned to INPut1 (screen A) and INPut2 (screen B).

INPut<1|2>:ATTenuation 0 to 75dB

This command programs the input attenuator. To protect the input mixer against damage from overloads, the setting 0 dB can be obtained by entering numerals, not by using the command DEC.

The step width is 5 dB, the range is 0 dB to..75 dB.

In analyzer mode, the attenuation set on the step attenuator is coupled to the reference level of the instrument. If the attenuation is programmed directly, the coupling to the reference level is switched off.

In phase noise mode, this command is only available if the automatic setting is switched off (INPut:GAIN:AUTO). The numeric suffix of INPut is irrelevant.

Example: "INP:ATT 40dB"
'Sets the attenuation on the attenuator to 40 dB and switches off the coupling to the reference level.

Characteristics: *RST value: 10 dB (AUTO is set to ON)
SCPI: conform

Mode: PNO, A

INPut<1|2>:ATTenuation:AUTO ON | OFF

This command automatically couples the input attenuation to the reference level (state ON) or switches the input attenuation to manual entry (state OFF). The minimum input attenuation set with the coupling switched on is 10 dB (with electronic attenuator option: 5 dB).

Example: "INP:ATT:AUTO ON"
'Couples the attenuation set on the attenuator to the reference level.

Characteristics: *RST value: ON
SCPI: conform

Mode: A

INPut<1|2>:ATTenuation:PROTection:RESet

The R&S FSUP is equipped with an overload protection mechanism. This mechanism becomes active as soon as the power at the input mixer exceeds a value of 27 dBm. It ensures that the connection between RF input and input mixer is cut off.

The command resets the attenuator into the state that it had before the overload condition was detected. It re-connects the RF input with the input mixer.



Note

This command comes into effect only if the reason for the overload condition has been eliminated. Otherwise the connection between RF input and input mixer is left open.

Example: "INP:ATT:PROT:RES"

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

This command is an event and therefore has no query and no *RST value.

INPut:COUPling AC | DC

This command switches the input coupling of the RF input between AC and DC.

Example: "INP:COUP DC"

Characteristics: *RST value: AC
SCPI: conform

Mode: A

INPut<1|2>:EATT 0 to 30dB

This command programs the attenuation of the electronic input attenuator. The attenuation can be varied in 5 dB steps from 0 to 30 dB. Other entries are rounded to the next lower integer value. If the attenuation is programmed directly, the coupling to the reference level is switched off.

If the defined reference level cannot be set with the given RF attenuation, this level is adapted to the maximum possible value.

The electronic attenuator is switched off in the default state.

Example: "INP:EATT:STAT ON"
'Switches the electronic attenuator into the signal path.

"INP:EATT 15dB"
'Sets the attenuation of the electronic attenuator to 15 dB and switches off the coupling to the reference level.

Characteristics: *RST value: 0 dB (state is set to OFF)
SCPI: device-specific

Mode: A

The command is only available with the electronic attenuator option B25.

INPut<1|2>:EATT:AUTO ON | OFF

This command automatically couples the electronic input attenuation to the reference level and the attenuation of the mechanical attenuator (state ON) or switches the input attenuation to manual entry (state OFF).

Example: "INP:EATT:STAT ON"
'Switches the electronic attenuator into the signal path.

"INP:EATT:AUTO ON"
'Couples the attenuation of the electronic attenuator to the reference level.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

The command is only available with the electronic attenuator option B25.

INPut<1|2>:EATT:STATE ON | OFF

This command switches the electronic input attenuation into the signal path (state ON) or removes it from the signal path (state OFF).

Example: "INP:EATT:STAT ON"
'Switches the electronic attenuator into the signal path.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

The command is only available with the option electronic attenuator B25.

INPut<1|2>:GAIN:STATE ON | OFF

This command switches on the preamplifier for the instrument. The switchable gain is fixed to 20 dB.

In phase noise mode, this command is only available if the automatic setting is switched off ([INPut:GAIN:AUTO](#)). The numeric suffix of INPut is irrelevant.

Example: "INP:GAIN:STAT ON"
'Switches on the 20 dB preamplifier.

Characteristics: *RST value: OFF
SCPI: conform

Mode: PNO, A

The command is only available with the RF preamplifier (B23) or electronic attenuator (B25) option.

INPut:GAIN:AUTO ON | OFF

This command switches preamplifier and the RF attenuator handling into automatic mode. The required preamplifier and attenuation values are set automatically.

Example: "INP:GAIN:AUTO ON"
'Switches the preamplifier and attenuation into auto mode.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

The control of the preamplifier is only available with option R&S FSU-B23 or R&S FSU-B25.

INPut:LNA:GAIN 0 | 20 | 30 | AUTO

This command specifies the amplifier setting of the low noise amplifier in dB.

Example: "INP:LNA:GAIN 20"
'Sets the value of the LNA gain to 20 dB.

Characteristics: *RST value: AUTO
SCPI: device-specific

Mode: PNO

INPut:LNA:GAIN:AUTO ON | OFF

This command activates or deactivates the automatic LNA gain selection.

Example: "INP:LNA:GAIN:AUTO ON"
'Activates the automatic LNA gain selection.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

INPut<1|2>:IMPedance 50 | 75

This command sets the nominal input impedance of the instrument. The set impedance is taken into account in all level indications of results.

The setting 75 Ω should be selected, if the 50 Ω input impedance is transformed to a higher impedance using a 75 Ω adapter of the RAZ type (= 25 Ω in series to the input impedance of the instrument). The correction value in this case is 1.76 dB = 10 log (75 Ω / 50 Ω).

Example: "INP:IMP 75"

Characteristics: *RST value: 50 Ω
SCPI: conform

Mode: A

INPut<1|2>:MIXer[:POWER] <numeric value>

This command defines the desired power at the input mixer of the R&S FSUP. On any change to the reference level the RF attenuation will be adjusted in a way that makes the difference between reference level and RF attenuation come as close to the desired mixer level as possible.

Example: "INP:MIX -30"

Characteristics: *RST value: - 25 dBm
SCPI: device-specific

Mode: A

INPut<1|2>:MIXer:AUTO ON | OFF

This command enables/disables the automatic setup of the mixer level.

Example: "INP:MIX:AUTO ON"

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

INSTrument Subsystem

The INSTrument subsystem selects the operating mode of the unit either via text parameters or fixed numbers. Only operating modes available for the base unit and the models and the options described in this manual (see “[Documentation Overview](#)” on page 0.4) are listed. For details on the other operating modes refer to the corresponding separate manuals.

INSTrument[:SElect] SANalyzer | ADEMod | PNOise

This command enables you to switch between modes by entering the mode designation.

Parameter: SANalyzer: spectrum analyzer
 ADEMod: FM demodulator
 PNOise: phase noise measurement

Example: "INST SAN"
 'Switches the instrument to *SPECTRUM*.

Characteristics: *RST value: PNOise
 SCPI: conform

Mode: PNO, A



Note

A changeover to a mode is only possible if the corresponding option is installed.

INSTrument:NSElect <numeric value>

This command enables you to switch between the modes by using numbers.

Parameter: 1: Analyzer mode
 3: FM demodulator mode
 20: phase noise measurement

Example: "INST:NSEL 1"
 'Switches to the analyzer mode.

Characteristics: *RST value: 20
 SCPI: conform

Mode: PNO, A



Note

A changeover to a mode is only possible if the corresponding option is installed.

INSTrument:COUPle NONE | RLEVel | CF_B | CF_A

In analyzer mode, this command selects the parameter coupling between the two measurement windows screen A and B.

Parameter: NONE: No coupling. The two measurement windows are operated like two independent "virtual" devices.
RLEVel: The reference levels of the two measurement windows are coupled.
CF_B: The center frequency of screen B is coupled to the frequency of marker 1 in screen A.
CF_A: The center frequency of screen A is coupled to the frequency of marker 1 in screen B.

Example: "INST:COUP NONE"
'Switches off the coupling of measurement windows. This leads to two independent "virtual" devices.

Characteristics: *RST value: NONE
SCPI: device-specific

Mode: A

MMEMory Subsystem

The MMEMory (mass memory) subsystem provides commands which allow for access to the storage media of the instrument and for storing and loading various instrument settings.

The various drives can be addressed via the "mass storage unit specifier" <msus> using the conventional DOS syntax. The internal hard disk is addressed by "D:", the floppy disk drive by "A:".



Note

For reasons of compatibility with the FSE instruments, addressing the hard disk by "C:" is also accepted. Since hard disk "C:" is reserved for instrument software, all read and write operations are rerouted to hard disk "D:" in normal operation (service level 0).

The file names <file_name> are indicated as string parameters with the commands being enclosed in quotation marks. They also comply with DOS conventions.

DOS file names consist of max. 8 ASCII characters and an extension of up to three characters separated from the file name by a dot "." Both, the dot and the extension are optional. The dot is not part of the file name. DOS file names do not distinguish between uppercase and lowercase notation. All letters and digits are permitted as well as the special characters "_", "^", "\$", "~", "!", "#", "%", "&", "-", "{", "}", "(, ")", "@", and "'". Reserved file names are CLOCK\$, CON, AUX, COM1 to COM4, LPT1 to LPT3, NUL and PRN.

The two characters "*" and "?" have the function of so-called "wildcards", i.e., they are variables for selection of several files. The question mark "?" replaces exactly one character, the asterisk means any of the remaining characters in the file name. "*. *" thus means all files in a directory.

MMEMory:CATalog? <path>

This command reads the indicated directory. According to DOS convention, wild card characters can be entered in order to query e.g. a list of all files of a certain type.

The path name should be in conformance with DOS conventions and may also include the drive name.

Parameter: <path>::= DOS Path name

Example:

```
"MMEM:CAT? 'D:\USER\DATA'"
'Returns the contents of the D:\USER\DATA directory

"MMEM:CAT? 'D:\USER\DATA\*.LOG'"
'Returns all files in D:\USER\DATA with .LOG extension

"MMEM:CAT? 'D:\USER\DATA\SPOOL?.WMF'"
'Returns all files in D:\USER\DATA whose names start with SPOOL, have 6 letters
and the .WMF extension .
```

Return value: List of file names in the form of strings separated by commas, i.e.
'SPOOL1.WMF', 'SPOOL2.WMF', 'SPOOL3.WMF'

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

MMEMory:CATalog:LONG? <path>

This command queries the directories and files in the given path.

Parameter: <path>::= DOS path

Example: "MMEM:CAT:LONG? 'D:\USER\DATA'"
'queries the contents of directory D:\USER\DATA

Return value: <used_bytes_in_this_directory>,<free_bytes_on_this_disk>,
"<file_name>,<file_type>,<filesize_in_bytes>","
"<file_name>,<file_type>,<filesize_in_bytes>"," ...

with

<file_name>: name of file or directory

<file_type>: DIR (directory), ASCii (ASCII file), BINary (binary file) and STATe (file with device settings)

<filesize_in_bytes>: size of file, 0 for directories

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

MMEMory:CDIRectory <directory_name>

This command changes the current directory.

In addition to the path name, the indication of the directory may contain the drive name. The path name complies with the DOS conventions.

Parameter: <directory_name>::= DOS path name

Example: "MMEM:CDIR 'D:\USER\DATA'"
'Returns the list of files in directory D:\USER\DATA.

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

MMEMory:COPY <file_source>,<file_destination>

This command copies the files indicated in <file_source> to the destination directory indicated with <file_destination> or to the destination file indicated by <file_destination> when <file_source> is just a file.

The indication of the file name may include the path and the drive name. The file names and path information must be in accordance with the DOS conventions.

Parameter: <file_source>,<file_destination> ::= <file_name>
<file_name> ::= DOS file name

Example: "MMEM:COPY 'D:\USER\DATA\SETUP.CFG', 'A:'"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:DATA <file_name>[,<block data>]

This command writes the block data contained in <block> into the file characterized by <file_name>. The GPIB delimiter must be set to EOI to obtain error-free data transfer.

The associated query command reads the indicated file from the mass memory and transfers it to the control computer via the GPIB. It should be noted that the buffer memory of the control computer should be large enough to store the file. The setting of the GPIB delimiter is irrelevant in this case.

The command is useful for reading stored device settings or trace data from the instrument or for transferring them to the instrument.

- `MMEMory:DATA <file_name>,<block data>`
Data transfer from control computer to instrument.
- `MMEMory:DATA? <file_name>`
Data transfer from instrument to control computer.

<file_name> selects the file to be transferred.

The binary data block <block> has the following structure:

- it always begins with the character '#',
- followed by a digit for the length of the length information,
- followed by the indicated number of digits as length information (number of bytes) for the binary data themselves,
- finally the binary data with the indicated number of bytes

Example: `"MMEM:DATA 'TEST01.HCP',#216This is the file"`
 'means:
 '#2: the next 2 characters are the length indication
 '16: number of subsequent binary data bytes
 'This is the file: 16 bytes stored as binary data in the file TEST01.HCP.

 `"MMEM:DATA? 'TEST01.HCP'"`
 'Transfers the file TEST01.HCP from the instrument to the control computer.

Characteristics: *RST value: -
 SCPI: conform

Mode: PNO, A

MMEMory:DELeTe <file_name>

This command deletes the indicated files.

The indication of the file name contains the path and, optionally, the drive name. Indication of the path complies with DOS conventions.

Parameter: <file_name> ::= DOS file name

Example: `"MMEM:DEL 'TEST01.HCP'"`
 'The file TEST01.HCP is deleted.

Characteristics: *RST value: -
 SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:INITialize <msus>

This command formats the disk in drive A. Formatting deletes all data stored on the floppy disk.

Parameter: <msus> ::= 'A.'
Only drive name A: is accepted.

Example: "MMEM:INIT 'A:'"

Characteristics: *RST value: -
SCPI: conform

Mode: A

This command is an event and therefore has no *RST value and no query.

MMEMory:LOAD:STATe 1,<file_name>

This command loads device settings from data set files (*.FSP). The contents of the file is loaded and set as the new device state.

The file name includes indication of the path and may also include the drive name. The path name complies with DOS conventions. The default path for data set files is *D:\USER\CONFIG*.

Parameter: <file_name> ::= DOS file name without extension

Example: "MMEM:LOAD:STAT 1, 'A:TEST'"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:LOAD:AUTO 1,<file_name>

This command defines which device setting is automatically loaded after the device is switched on. The contents of the file are read after switching on the device and used to define the new device state. The file name includes indication of the path and may also include the drive. The path name complies with DOS conventions.

**Note**

The data set defined as auto recall set will also be restored by a *RST-command.

Parameter: <file_name> ::= DOS file name without extension;
FACTORY denotes the data set previously in the instrument

Example: "MMEM:LOAD:AUTO 1, 'D:\USER\DATA\TEST'"

Characteristics: *RST value: FACTORY
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:MDIRectory <directory_name>

This command creates a new directory. The file name includes indication of the path and may also include the drive name. The path name complies with DOS conventions.

Parameter: <directory_name> ::= DOS path name

Example: "MMEM:MDIR 'D:\USER\DATA'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:MOVE <file_source>,<file_destination>

This command renames existing files, if <file_destination> contains no path indication. Otherwise the file is moved to the indicated path and stored under the file name specified there, if any.

The file name includes indication of the path and may also include the drive. The path name complies with DOS conventions.

Parameter: <file_source>,<file_destination> ::= <file_name>
<file_name> ::= DOS file name

Example: "MMEM:MOVE 'D:\TEST01.CFG', 'SETUP.CFG'"
'Renames TEST01.CFG in SETUP.CFG in directory D:\.

"MMEM:MOVE 'D:\TEST01.CFG', 'D:\USER\DATA'"
'Moves TEST01.CFG from D:\ to D:\USER\DATA.

"MMEM:MOVE 'D:\TEST01.CFG', 'D:\USER\DATA\SETUP.CFG'"
'Moves TEST01.CFG from D:\ to D:\USER\DATA and renames the file in SETUP.CFG.

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:MSIS <device>

This command changes to the drive indicated. The drive may be the internal hard disk D: or the floppy disk drive A:.

Example: "MMEM:MSIS 'A:'"

Characteristics: *RST value: "D:"
SCPI: conform

Mode: PNO, A

MMEMory:NAME <file_name>

This command defines a destination file for the printout started with the command `HCOPY:IMMEDIATE`. In this case the printer output must be routed to destination *FILE* using the command `"HCOP:DEST 'MMEM'"`.

The file name includes indication of the path and may also include the drive name. The file name and path information comply with DOS conventions.

Parameter: <file_name> ::= DOS file name

Example: "HCOP:DEV:LANG BMP"
'Selection of data format.

"HCOP:DEST 'MMEM' "
'Selection of the output device

"MMEM:NAME 'PRINT1.BMP' "
'Selection of file name.

"HCOP:IMM"
'Start of the printout.

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:RDIRectory <directory_name>

This command deletes the indicated directory. The directory name includes indication of the path and may also include the drive name. The path name complies with DOS conventions.

Parameter: <directory_name> ::= DOS path name

Example: "MMEM:RDIR 'D:\TEST' "

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:STORE:SPURious <file_name>

This command stores the peak list in an ASCII file to a file on a disk.

The file has a header containing important parameters for scaling, several data sections containing the sweep settings per range and a data section containing the peak list.

The header data is made up of three columns, separated by ';':

parameter name; numeric value; base unit

The data section for the measurement values starts with the key word "TRACE <n>:", where <n> includes the number of the used trace. Next comes the peak list with several columns also separated by ';':

Spreadsheet programs such as MS Excel can read this format. Use ';' as the delimiter for the table cells.



Note

Different language versions of evaluation programs may require different handling of the decimal point. Using the DECIM SEP softkey, you can thus choose between the delimiters '.' (decimal point) and ',' (comma).

Parameter: <file_name> := DOS file name

Example: "MMEM:STOR:SPUR 'D:\TEST.ASC'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value and no query.

MMEMory:STORe<1|2>:STATe 1,<file_name>

This command stores the current device settings in a series of files which have the indicated file name, but different extensions. The file name includes indication of the path and may also include the drive name. The path name complies with DOS conventions. The numeric suffix in STORe<1|2> is irrelevant with this command.

A list of the extensions used is contained under MMEMory:LOAD:STATe.

Parameter: <file_name> := DOS file name without extension

Example: "MMEM:STOR:STAT 1, 'TEST'"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:STORe<1|2>:SPURs <file_name>

This command stores the spurs list in a file with ASCII format. The decimal separator (decimal point or comma) for floating-point numerals contained in the file is defined with the [FORMat:DEXPort:DSEParator](#) command.

The file name includes indication of the path and the drive name. Indication of the path complies with DOS conventions.

Example: "MMEM:STOR:SPUR 'A:\TEST.DAT'"
'Stores spur list in the file 'TEST.DAT' on a disk.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is an event and therefore has no *RST value and no query.

MMEMory:STORe<1|2>:TRACe 1 to n,<file_name>

This command stores the selected trace in a file with ASCII format. The file format is described in chapter "Instrument Functions", section "ASCII FILE EXPORT" on page 4.124.

In analyzer mode, the numeric suffix at STORe<1|2> indicates the measurement window (screen A or B). In phase noise mode, the numeric suffix at STORe<1|2> is irrelevant.

The decimal separator (decimal point or comma) for floating-point numerals contained in the file is defined with the [FORMat:DEXPort:DSEParator](#) command.

Parameter: 1 to n := selected measurement curve (trace); in analyzer mode, up to 3 traces are available (numeric suffix n = 3); in phase noise mode, up to 8 traces are available (numeric suffix n = 8)

<file_name> := file name in compliance to DOS conventions, including indication of the path and the drive name

Example: "MMEM:STOR2:TRAC 3, 'A:\TEST.ASC'"
'Stores trace 3 from screen B in the file TEST.ASC on a disk.'

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

For Spurious Measurement in analyzer mode, an extended file format is used:

	File contents	Explanation
File header	Type;R&S FSUP;	Model
	Version;3.9x;	Firmware version
	Date;02.Feb 2007;	Storage date of data set
	Mode;ANALYZER;SPURIOUS;	Operating mode of the device Format for Spurious Emissions measurement
	Start;9000.000000;Hz Stop;8000000000.000000;Hz	Start/stop of the span Unit: Hz
	x-Axis;LIN;	Linear (LIN) or logarithmic (LOG) (future feature) scaling of the x-axis
	Sweep Count;1;	Selected number of sweeps
	Range 1:	Loop across all defined sweep ranges (1 to 20)
	Start; 9000.000000;Hz	Range start frequency in Hz
	Stop; 150000.000000;Hz	Range stop frequency in Hz
	Filter Type;NORMAL;	Range filter type: NORMAL, RRC or CFILTER
	RBW;10000.000000;Hz	Resolution bandwidth of the measurement filter
	VBW;30000.000000;Hz	Resolution bandwidth of the video filter
	Auto Sweep time;ON	
	Sweep time; 0.145000;s	Selected sweep time in the current range
	Detector;RMS;	Detector: MAX PEAK, MIN PEAK, RAVERAGE
	REF-Level; -10.000000;dBm	Setting of the reference level in the current range
	Auto RF-Attenuator; OFF;	Manual (OFF) or automatic (ON) setting of the RF attenuator
	RF Att;15.000000;dB	Range input attenuation
	Sweep Points;625;	Number of sweep points in the current range
Preamp; 0.000000;dB	Range preamplifier, on (20 dB) or off (0 dB)	
Stop after range;OFF;	Stop after range, switched on (ON) or off (OFF) for the current range	
Transducer;TRD1;	Transducer name (if activated) repeated for all sweep list ranges	
File data section	TRACE 1:	Selected trace
	x-Unit;Hz;	Unit of x values:
	y-Unit;dBm;	Unit of y values:
	Values;2500;	Number of measurement points
	9000.000000;-99.619965; 9225.961538;-105.416908; 9451.923077;-100.938057; 9677.884615;-99.483894; 9903.846154;-106.879539; 10129.807692;-108.772316;	Measurement values: <x value>; <y value>

MMEMory:STORe<1|2>:MARKer <file_name>

This command saves the data of all active markers to a file < file_name >.

Example: "MMEM:STOR:MARK 'C:\marker.txt'"
 'Generates a *MARKER.TXT* file that contains all data of the active markers in screen A.
 If in screen A two markers are active, the generated *MARKER.TXT* file includes the following:
 Marker;1;T1
 -25.87;dBm
 19.920000000;GHz
 Delta;2;T1
 -21.90;dB
 -5.920000000;GHz

Characteristics: *RST value: --
 SCPI: device-specific

Mode: A

The command is an event and therefore has no *RST value and no query.

MMEMory:CLear:STATe 1,<file_name>

This command deletes the instrument setting selected by <file_name>. All associated files on the mass memory storage are cleared. A list of the extensions used is included under `MMEMory:LOAD:STATe`.

The file name includes indication of the path and may also include the drive. The path name complies with DOS conventions.

Parameter: <file_name> ::= DOS file name without extension

Example: "MMEM:CLE:STAT 1, 'TEST'"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:CLear:ALL

This command deletes all device settings in the current directory. The current directory can be selected with `MMEM:CDIR`. The default directory is D:.

Example: "MMEM:CLE:ALL"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value and no query.

MMEMory:SElect[:ITEM]:HWSettings ON | OFF

This command includes the hardware settings in the list of data subsets of a device setting to be stored/loaded. The hardware settings include:

- current configuration of general device parameters (general setup)
- current setting of the measurement hardware including markers
- activated limit lines:
A data set may include 8 limit lines at maximum in each measurement window. This number includes the activated limit lines and, if available, the de-activated limit lines last used. Therefore the combination of the non-activated restored limit lines depends on the sequence of use with the command `MMEM:LOAD`.
- user-defined color setting
- configuration for the hardcopy output
- the activated transducers:
A data set may include 4 transducer factors at maximum. It comprises the activated factors and, if available, the de-activated factors last used. Therefore the combination of non-activated restored transducer factors depends on the sequence of use with the command `MMEM:LOAD`.
- Tracking generator settings
(only in conjunction with option External Generator Control B10)
- Correction data for source calibration
(only in conjunction with option External Generator Control B10)

Example: `"MMEM:SEL:HWS ON"`

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO, A

MMEMory:SElect[:ITEM]:TRACe[:ACTive] ON | OFF

This command adds the active traces to the list of data subsets of a save/recall device setting. Active traces are all traces whose state is not blank.

Example: `"MMEM:SEL:TRAC ON"`

Characteristics: *RST value: OFF, i.e. no traces will be stored
SCPI: device-specific

Mode: PNO, A

MMEMory:SElect[:ITEM]:LINes:ALL ON | OFF

This command adds all limit lines (activated and de-activated) to the list of device settings to be stored/loaded. The selection `MMEM:SEL:LIN:ACT` is thus switched off.

Example: `"MMEM:SEL:LIN:ALL ON"`

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO, A

MMEMory:SElect[:ITEM]:SCData ON | OFF

This command adds the tracking generator calibration data to the list of device settings to be stored/loaded.

Example: "MMEM:SEL:SCD ON"
'Inserts the tracking generator correction data in the list of data subsets

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

This command is only available in conjunction with option external generator control B10.

MMEMory:SElect[:ITEM]:TRANsducer:ALL ON | OFF

This command includes all transducer factors and sets in the list of data subsets of a device setting to be stored/loaded.

Example: "MMEM:SEL:TRAN:ALL ON"

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO, A

MMEMory:SElect[:ITEM]:ALL

This command includes all data subsets in the list device settings to be stored/loaded.

Example: "MMEM:SEL:ALL"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value.

MMEMory:SElect[:ITEM]:NONE

This command deletes all data subsets from the list of device settings to be stored/loaded.

Example: "MMEM:SEL:NONE"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value.

MMEMory:SElect[:ITEM]:DEFault

This command sets the default list of device settings to be stored/loaded. The latter includes:

- current configuration of general device parameters (general setup)
- current setting of the measurement hardware including markers
- activated limit lines
- user-defined color setting
- configuration for the hardcopy output
- Tracking generator settings
(only in conjunction with option External Generator Control B10)
- Correction data for source calibration
(only in conjunction with option External Generator Control B10)

Trace data and non-used limit lines are not included.

Example: "MMEM:SEL:DEF"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

This command is an event and therefore has no *RST value.

MMEMory:COMMent <string>

This command defines a comment (max. 60 characters) for a device setting to be stored.

Example: "MMEM:COMM 'Setup for FM measurement'"

Characteristics: *RST value: blank comment
SCPI: device-specific

Mode: PNO, A

SENSe Subsystem

The SENSe subsystem is organized in several subsystems. The commands of these subsystems directly control device-specific settings, they do not refer to the signal characteristics of the measurement signal.

The SENSe subsystem controls the essential parameters of the R&S FSUP. In accordance with the SCPI standard, the key word "SENSe" is optional for this reason, which means that it is not necessary to include the SENSe node in command sequences.

The measurement windows are selected by SENSe1 and SENSe2:

SENSe1 = Modification of screen A settings

SENSe2 = Modification of screen B settings.

Screen A is automatically selected if 1 or 2 is missing.

SENSe:AVERage Subsystem

The SENSe:AVERage subsystem calculates the average of the acquired data. A new test result is obtained from several successive measurements.

There are two types of average calculation: logarithmic and linear. In case of logarithmic average calculation (denoted with VIDeo), the average value of the measured logarithmic power is calculated and in case of linear average calculation, the linear power is averaged before the logarithm is applied.

The measurement windows are selected by SENSe1 (screen A) and SENSe2 (screen B).

[SENSe<1|2>:]AVERage:COUNT 0 to 32767

This command defines the number of measurements which contribute to the average value.

It should be noted that continuous averaging will be performed after the indicated number has been reached in continuous-sweep mode.

In single-sweep mode, the sweep is stopped as soon as the indicated number of measurements (sweeps) is reached. Synchronization to the end of the indicated number of measurements is only possible in single-sweep mode.

The command [SENSe<1|2>:]AVERage:COUNT is the same as command [SENSe<1|2>:]SWEep:COUNT. In both cases, the number of measurements is defined whether the average calculation is active or not.

The number of measurements is valid for all traces in the indicated measurement window.

Example:

```
"INIT:CONT OFF"
'Switching to single-sweep mode.

"AVER:COUN 16"
'Sets the number of measurements to 16.

"AVER:STAT ON"
'Switches on the calculation of average.

"INIT;*WAI"
'Starts the measurement and waits for the end of the 16 sweeps.
```

Characteristics: *RST value: 0
SCPI: conform

Mode: A

[SENSe<1|2>:]AVERAge[:STATe<1 to 3>] ON | OFF

This command switches on or off the average calculation for the selected trace (STATe<1 to 3>) in the selected measurement window.

Example: "AVER OFF"
 'Switches off the average calculation for trace 1 in screen A.

 "SENS2:AVER:STAT3 ON"
 'Switches on the average calculation for trace 3 in screen B.

Characteristics: *RST value: OFF
 SCPI: conform

Mode: A

[SENSe<1|2>:]AVERAge:TYPE VIDEo | LINear

This command selects the type of average function. If VIDEo is selected, the logarithmic power is averaged and, if LINear is selected, the power values are averaged before they are converted to logarithmic values.

The type of average calculation is equally set for all traces in one measurement window.

Example: "AVER:TYPE LIN"
 'Switches screen A to linear average calculation.

Characteristics: *RST value: VIDEo
 SCPI: device-specific

Mode: A

SENSe:BANDwidth Subsystem

This subsystem controls the setting of the instrument's filter bandwidths. Both groups of commands (BANDwidth and BWIDth) perform the same functions.

In analyzer mode, the measurement windows are selected via SENSe1 (screen A) or SENSe2 (screen B). In phase noise mode, the numeric suffix at SENSe must be 1.

[SENSe]:BANDwidth:DEMod 100 Hz to 30 MHz

This command specifies the demodulation bandwidth. This setting is used during Transient measurements.

Example: "BAND:DEM 15MHZ"
'Sets the demod bandwidth to 15 MHz.

Characteristics: *RST value: 5 MHz
SCPI: device-specific

Mode: PNO

[SENSe<1|2>]:BANDwidth|BWIDth:FFT WIDE | AUTO | NARROW

This command allows to specify between the following three options for FFT filters.

WIDE: The FFT filters with the greater partial span (this is the span which is covered with one FFT analysis) are used always.

AUTO: The firmware decides whether to use wide or narrow filters to achieve the best performance of the measurement.

NARROW: The FFT filters with the smaller partial span are used, this allows measurements near a carrier with reduced reference level, because of a more narrow analog prefilter.

Example: "BWID:FFT WIDE"

Characteristics: *RST value: AUTO
SCPI: device-specific

Mode: A

[SENSe<1|2>]:BANDwidth|BWIDth[:RESolution] 10 Hz to 50 MHz

This command defines the resolution bandwidth. This corresponds to the IF bandwidth of the demodulator in FM demodulator mode.

Analog resolution filters of 10 Hz to 20 MHz in 1, 2, 3, 5, 10 steps are available. Additionally there is a 50 MHz resolution bandwidth. These filters are implemented as 5-circuit LC filters in the range from 300 kHz to 10 MHz and as digital filters with analog characteristic in the range of 10 Hz to 100 kHz.

In addition, the EMI bandwidths 200 Hz, 9 kHz and 120 kHz are available (6 dB bandwidths each). These bandwidths can only be obtained by entering numeric values and not with the commands INCrement and DECrement.

FFT filters from 1 Hz to 30 kHz (3 dB bandwidth each) are also available in the frequency domain (span > 0) for fast measurements on periodic signals. The instrument automatically switches to analog filters above 30 kHz.

A number of especially steep-edged channel filters can be selected provided that parameters CFILter or RRC are selected using the BAND:TYPE command. The possible combinations of filter type and filter bandwidth are listed in the table "List of available channel filters" of chapter "Instrument Functions", section "Setting the Bandwidths and Sweep Time – BW Key" on page 4.97.

If the resolution bandwidth is modified in analyzer mode, the coupling to the span is automatically switched off.

If the resolution bandwidth is modified in FM demodulator mode, the coupling to the demodulation bandwidth is automatically switched off.

Example: "BAND 1MHz"
'Sets the resolution bandwidth to 1 MHz

Characteristics: *RST value: - (AUTO is set to ON)
SCPI: conform

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDTH[:RESolution]:AUTO ON | OFF

In analyzer mode, this command either automatically couples the resolution bandwidth of the instrument to the span or cancels the coupling.

In FM demodulator mode, this command either automatically couples the IF bandwidth of the instrument to the demodulation bandwidth or cancels the coupling ($BW_{RBW} = 10 * BW_{Demod}$).

The automatic coupling adapts the resolution bandwidth to the currently set frequency span according to the relationship between frequency span and resolution bandwidth.

The 6 dB bandwidths 200 Hz, 9 kHz and 120 kHz and the channel filters are not set by the automatic coupling.

The ratio resolution bandwidth/span can be modified with the command [SENSe<1|2>:]BANDwidth[:RESolution]:RATio.

Example: "BAND:AUTO OFF"
'Switches off the coupling of the resolution bandwidth to the span (analyzer mode).
'Switches off the coupling of the IF bandwidth to the demodulation bandwidth (FM demod mode)

Characteristics: *RST value: ON
SCPI: conform

Mode: A-F

[SENSe<1|2>:]BANDwidth|BWIDTH[:RESolution]:RATio 0.0001 to 1

This command defines the ratio resolution bandwidth (Hz) / span (Hz). The ratio to be entered is reciprocal to the ratio span/RBW used in manual operation.

Example: "BAND:RAT 0.1"

Characteristics: *RST value: 0.02 with BAND:TYPE NORMal or RBW > 30 kHz
0.01 with BAND:TYPE FFT for RBW ≤ 30 kHz
SCPI: conform

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDTH[:RESolution]:TYPE NORMal | FFT | CFILter | RRC | P5

This command switches the filter type for the resolution bandwidth between "normal" analog or FIR filters in 1, 3, 10 steps and the FFT filtering for bandwidths <100 kHz.

The advantage of FFT filtering is the higher measurement speed compared to digital filters with analog filter characteristic. However, FFT filters are only suitable for periodic signals, and they are only available for span > 0 Hz.

Steep-edged channel filters and filters with RRC (Root Raised Cosine) characteristic are available. The possible combinations of filter type and filter bandwidth are listed in chapter "Instrument Functions", section "Filter Types" on page 4.103.

Type P5 resonates more quickly.



Notes

When changing the filter type, the next larger filter bandwidth is selected if the same filter bandwidth is not available for the new filter type.

Example: "BAND:TYPE NORM"

Characteristics: *RST value: NORMAL
SCPI: device-specific

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDth:VIDeo 1Hz to 10MHz

This command defines the instrument's video bandwidth. Bandwidths from 10 Hz to 10 MHz in 1, 2, 3, 5, 10 steps are available. The command is not available if FFT filtering is switched on and the set bandwidth is ≤ 30 kHz or if the quasipeak detector is switched on.

Example: "BAND:VID 10kHz"

Characteristics: *RST value: - (AUTO is set to ON)
SCPI: conform

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDth:VIDeo:AUTO ON | OFF

This command either automatically couples the instrument's video bandwidth to the resolution bandwidth or cancels the coupling.

The ratio video bandwidth/resolution bandwidth can be modified with the command [SENSe<1|2>:]BANDwidth:VIDeo:RATio.

Example: "BAND:VID:AUTO OFF"

Characteristics: *RST value: ON
SCPI: conform

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDth:VIDeo:RATio 0.01 to 1000

This command defines the ratio video bandwidth (Hz) / resolution bandwidth (Hz). The ratio to be entered is reciprocal to the ratio RBW/VBW used in manual operation.

Example: "BAND:VID:RAT 3"
'Sets the coupling of video bandwidth to video bandwidth = 3*resolution bandwidth

Characteristics: *RST value: 3
SCPI: conform

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDTH:VIDeo:TYPE LINear | LOGarithmic

This command selects the position of the video filter in the signal path, provided that the resolution bandwidth is ≤ 100 kHz:

- If LINear is selected, the video filter is connected ahead of the logarithmic amplifier (default)
- If LOGarithmic is selected, the video filter follows the logarithmic amplifier

The essential difference between the two modes is the transient response at falling signal edges:

If LINear is selected, the measurement with logarithmic level scaling yields a much "flatter" falling edge than LOGarithmic.

This behavior is due to the conversion of linear power into logarithmic level. If the linear power is halved, the level decreases by only 3 dB.

Example: "BAND:VID:TYPE LIN"
Video filter ahead of the logarithmic amplifier

Characteristics: *RST value: LIN
SCPI: device-specific

Mode: A

[SENSe<1|2>:]BANDwidth|BWIDTH:PLL AUTO | HIGH | MEDium | LOW

This command defines the bandwidth of the main PLL of the instrument synthesizer and thus affects the phase noise of the R&S FSUP. You can set the bandwidth in three stages (high/medium/low); if you select AUTO, it is automatically set.

Example: "BAND:PLL HIGH"

Characteristics: *RST value: AUTO
SCPI: device-specific

Mode: A

SENSe:CORRection Subsystem

This subsystem also controls calibration and normalization during operation with the external generator control option (B10). The measurement windows are selected by SENSE1 (screen A) and SENSE2 (screen B).

[SENSe<1|2>:]CORRection[:STATe] ON | OFF

This command activates/deactivates the normalization of the measurement results in the selected window provided that the tracking generator is active. The command is available only after acquisition of a reference trace for the selected type of measurement (transmission/reflection, see command [SENSe<1|2>:]CORRection:COLLect[:ACQire]).

Example: "CORR ON "
'Activates normalization in screen A.

Characteristics: *RST value: OFF
SCPI: conform

Mode: A

This command is only valid in conjunction with the ext. generator control option (B10).

[SENSe<1|2>:]CORRection:METHod TRANsmission | REFLection

This command selects the type of measurement with active tracking generator (transmission/reflection).

Example: "CORR:METH TRAN "
'Sets the type of measurement in screen A to "transmission".

Characteristics: *RST value: TRANsmission
SCPI: device-specific

Mode: A

This command is only valid in conjunction with the ext. generator control option (B10).

[SENSe<1|2>:]CORRection:COLLect[:ACQire] THRough | OPEN

When the tracking generator is active, this command determines the type of result acquisition for the normalization reference measurement and starts the measurement selected:

Parameter: THRough:
TRANsmission mode: calibration with direct connection between tracking generator and device input.
REFLection mode: calibration with short circuit at the input
OPEN: only valid in REFLection mode: calibration with open input

Example: "INIT:CONT OFF"
'Selects single sweep operation

"CORR:COLL THR;*WAI"
'Starts the measurement of reference data using direct connection between generator and device input and waits for the sweep end.

Characteristics: *RST value: --
SCPI: conform

Mode: A

This command is an "event" and therefore has no *RST value and no query.

This command is only valid in conjunction with the ext. generator control option (B10).

[SENSe<1|2>:]CORRection:RECall

This command restores the instrument setting that was valid for the measurement of the reference data, provided that the tracking generator is active.

Example: "CORR:REC"

Characteristics: *RST value: -
SCPI: conform

Mode: A

This command is an event and therefore has no *RST value and no query.

This command is only valid in conjunction with the ext. generator control option (B10).

[SENSe<1|2>:]CORRection:TRANsducer:ACTive?

This command queries the active transducer factor. If no transducer factor is active, an empty string is returned.

Example: "CORR:TRAN:ACT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is a query and therefore has no *RST value.

[SENSe<1|2>:]CORRection:TRANsducer:CATalog?

This command queries all the names of the transducer files saved on the hard disc.

The syntax of the output is:

<sum of file length of all following files>,<free spaces on hard disc>,<1st file name>,<1st file length>,<2nd file name>,<2nd file length>,...,<nth file name>,<nth file length>

Example: "CORR:TRAN:CAT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:GENerate <name>

This command generates a transducer factor <name> using normalized trace data. The function is only available when normalization is switched on.

Parameter: <name>::= Name of the transducer factors as string data with up to 8 characters.

Example: "CORR:TRAN:GEN 'FACTOR1'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:SElect <name>

This command selects the transducer factor designated by <name>. If <name> does not exist yet, a new transducer factor is created.

**Note**

This command must be sent prior to the subsequent commands for modifying/activating transducer factors.

Parameter: <name>::= Name of the transducer factor in string data form with a maximum of 8 characters.

Example: `":CORR:TRAN:SEL 'FACTOR1' "`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:UNIT <string>

This command specifies the unit for the selected transducer factor.

**Note**

The command `SENS:CORR:TRAN:SEL` must be transmitted prior to this command.

Parameter: <string>::= 'DB' | 'DBM' | 'DBMV' | 'DBUV' | 'DBUV/M' | 'DBUA' | 'DBUA/M' | 'DBPW' | 'DBPT'

Example: `":CORR:TRAN:UNIT 'DBUV' "`

Characteristics: *RST value: 'DB'
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:SCALing LINear | LOGarithmic

This command defines whether the frequency scaling of the transducer factor is linear or logarithmic.

**Note**

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

Example: `":CORR:TRAN:SCAL LOG "`

Characteristics: *RST value: LINear
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:COMMeNt <string>

This command defines the comment for the selected transducer factor.



Note

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

Example: `":CORR:TRAN:COMM 'FACTOR FOR ANTENNA' "`

Characteristics: *RST value: " (empty comment)
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:DATA <freq>,<level>..

This command defines the reference values of the transducer factor selected. These values are entered as a sequence of frequency/level pairs. The frequencies must be sent in ascending order.



Note

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent. The level values are sent as dimensionless numbers; the unit is specified by means of the command `SENS:CORR:TRAN:UNIT`.

Example: `":CORR:TRAN:TRANsducer:DATA 1MHZ,-30,2MHZ,-40"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer[:STATe] ON | OFF

This command switches the selected transducer factor on or off.



Note

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

Example: `":CORR:TRAN ON"`

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:TRANsducer:DELeTe

This command deletes the selected transducer factor.



Note

Prior to this command, the command `SENS:CORR:TRAN:SEL` must be sent.

Example: " :CORR:TRAN:DEL"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is an event and therefore has no *RST value.

[SENSe<1|2>:]CORRection:TRANsducer:ADJust:RLEVel[:STATe] ON | OFF

This command switches the automatic adjustment of the reference level to the selected transducer factor on or off.



Note

The command `SENS:CORR:TRAN:SEL` must have been sent prior to this command.

Example: "CORR:TRAN:ADJ:RLEV ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe<1|2>:]CORRection:CVL:CATalog?

This command queries all the names of the conversion loss tables saved on the hard disc.

The syntax of the output is:

<sum of file length of all following files>,<free spaces on hard disc>,
<1st file name>,<1st file length>,<2nd file name>,<2nd file length>,...,<nth file name>,
<nth file length>,

Example: " :CORR:CVL:CAT?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available if option R&S FSU-B21 is installed.

[SENSe:]CORRection:CVL:SElect <file_name>

This command selects the Conversion Loss Table designated with <file_name>. If <file_name> is not available, a new Conversion Loss Table will be created.



Note

This command must be sent prior to the subsequent commands used to change/activate the Conversion Loss files.

Parameter: <file_name>::= Name of Conversion Loss Table as string data with a maximum of 8 characters

Example: "CORR:CVL:SEL 'LOSS_TAB_4'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option FSU-B21.

[SENSe:]CORRection:CVL:MIXer <string>

This command defines the type designation of the mixer in the Conversion Loss Table.



Note

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Parameter: <string>::= Type designation of mixer with a maximum of 16 characters

Example: "CORR:CVL:MIX 'FS_Z60'"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:SNUMBER <string>

This command defines the serial number of the mixer in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Parameter: <string>:= Serial number of mixer with a maximum of 16 characters

Example: `"CORR:CVL:SNUM '123.4567'"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:BAND A|Q|U|V|E|W|F|D|G|Y|J|USER

This command defines the waveguide band in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: `"CORR:CVL:BAND E"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:HARMonic <numeric_value>

This command defines the used mixer harmonic in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: `"CORR:CVL:SEL 'LOSS_TAB'"`
`"CORR:CVL:HARM 4"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:PORTs 2 | 3

This command defines the type of mixer in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: `"CORR:CVL:SEL 'LOSS_TAB'"`
 `"CORR:CVL:PORT 3"`

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:BIAS <numeric_value>

This command defines the bias current in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: `"CORR:CVL:BIAS 7mA"`

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:COMMeNt <string>

This command defines the comment in the Conversion Loss Table.

**Note**

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Parameter: <string>:= Comment of mixer with a maximum of 60 characters

Example: `"CORR:CVL:COMMENT 'MIXER FOR BAND U'"`

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:DATA <freq>,<level>..

This command defines the reference values of the selected Conversion Loss Tables. The values are entered as a result of frequency/level pairs. The frequencies have to be sent in ascending order. A maximum of 50 pairs of frequency/level may be entered.



Note

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: "CORR:CVL:DATA 1MHZ,-30DB,2MHZ,-40DB"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is only available with the option R&S FSU-B21.

[SENSe:]CORRection:CVL:CLEAr

This command deletes the selected Conversion Loss Table



Note

Command `SENS:CORR:CVL:SEL` must be sent prior to this command.

Example: "CORR:CVL:CLE"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

This command is an event which is why it is not assigned an *RST value.
This command is only available with the option R&S FSU-B21.

SENSe:DETECTOR Subsystem

The SENSe:DETECTOR subsystem controls the acquisition of measurement data via the selection of the detector for the corresponding trace. The measurement windows are selected by SENSe1 (screen A) and SENSe2 (screen B).

Example: "DET POS"
'Sets the detector in screen A to "positive peak".

Characteristics: *RST value: APEak
SCPI: conform

Mode: A

[SENSe<1|2>:]DETECTOR<1 to 3>[:FUNCTION]:AUTO ON | OFF

This command either couples the detector in the selected measurement window to the current trace setting or turns coupling off. The trace is selected by the numeric suffix at DETECTOR.

Example: "DET:AUTO OFF"

Characteristics: *RST value: ON
SCPI: conform

Mode: A

SENSe:FILTer Subsystem

The SENSe:FILTer subsystem selects the filters.

[SENSe]:FILTer:LPASs:FREQuency:RELative 5 | 10 | 25

This command specifies the relative lowpass filter. This setting is used during Transient measurements.

Example: "FILT:LPAS:FREQ:REL 10"
'Sets the relative lowpass filter to 10 %.

Characteristics: *RST value: 5%
SCPI: device-specific

Mode: PNO

SENSe:FREQUENCY Subsystem

The SENSe:FREQUENCY subsystem defines the frequency axis of the active display. The frequency axis can either be defined via the start/stop frequency or via the center frequency and span.

In analyzer mode, the measurement windows are selected via SENSe1 (screen A) or SENSe2 (screen B). In phase noise mode, the numeric suffix at SENSe must be 1.

[SENSe<1|2>:]FREQUENCY:CENTer 0 to f_{\max}

This command defines the center frequency of the R&S FSUP or the measuring frequency for span = 0.

In phase noise mode, the numeric suffix at SENSe must be 1. For Noise measurements, the center frequency is determined automatically, if the DUT parameters are activated for the pre-measurement and the pre-measurement is initiated (see [SENSe]:VCO:PREMeas[:STATe] command). The manual setting of the center frequency takes only effect, if the DUT parameters are deactivated for the pre-measurement.

Example: "FREQ:CENT 100MHz"

Characteristics: *RST value: $f_{\max} / 2$ with f_{\max} = maximum frequency
SCPI: conform

Mode: PNO, A

[SENSe<1|2>:]FREQUENCY:CENTer:STEP 0 to f_{\max}

This command defines the step width of the center frequency.

Example: "FREQ:CENT:STEP 120MHz"

Characteristics: *RST value: - (AUTO 0.1 × SPAN is switched on)
SCPI: conform

Mode: A

[SENSe<1|2>:]FREQUENCY:CENTer:STEP:LINK SPAN | RBW | OFF

This command couples the step width of the center frequency to span (span > 0) or to the resolution bandwidth (span = 0) or cancels the couplings.

Parameter: SPAN = Coupling to frequency display range (for span > 0)
RBW = Coupling to resolution bandwidth (for span = 0)
OFF = manual input, no coupling.

Example: "FREQ:CENT:STEP:LINK SPAN"

Characteristics: *RST value: SPAN
SCPI: device-specific

Mode: A

[SENSe<1|2>:]FREQUENCY:CENTer:STEP:LINK:FACTor 1 to 100 PCT

This command couples the step width of the center frequency with a factor to the span (span > 0) or to the resolution bandwidth (span = 0).

Example: "FREQ:CENT:STEP:LINK:FACT 20PCT"

Characteristics: *RST value: - (AUTO 0.1 × SPAN is switched on)
SCPI: device-specific

Mode: A

[SENSe<1|2>]:FREQUENCY:MULTIPLIER max. 1024

This command specifies a multiplier that is applied to all entered and displayed frequencies. By using this multiplier, the R&S FSUP corrects the measured frequencies to take an external multiplier into account.

This parameter only applies to Noise measurements.

Example: "FREQ:MULT 4"
The R&S FSUP uses the specified value to correct the measured frequencies.

Characteristics: *RST value: 1
SCPI: conform

Mode: PNO

[SENSe<1|2>]:FREQUENCY:SPAN 0 to f_{\max}

In analyzer mode, this command defines the frequency span.

Example: "FREQ:SPAN 10MHz"

Characteristics: *RST value: f_{\max} with f_{\max} = maximum frequency
SCPI: conform

Mode: A

[SENSe<1|2>]:FREQUENCY:SPAN:FULL

In analyzer mode, this command sets the frequency span to its maximum.

Example: "FREQ:SPAN:FULL"

Characteristics: *RST value: -
SCPI: conform

Mode: A

This command is an event and therefore has no *RST value and no query.

[SENSe<1|2>]:FREQUENCY:START 0 to f_{\max}

This command defines the start frequency of the R&S FSUP. This command is only available in the frequency domain (span >0).

In phase noise mode, the numeric suffix at SENSe must be 1. For Noise measurements, only discrete values in 1,3 steps are possible.

Example: "FREQ:STAR 20MHz"

Characteristics: *RST value: analyzer mode: 0; phase noise mode: 1 kHz
SCPI: conform

Mode: A-F, PNO

[SENSe<1|2>:]FREQUENCY:STOP 0 to f_{\max}

This command defines the stop frequency of the R&S FSUP. This command is only available in the frequency domain (span >0).

In phase noise mode, the numeric suffix at SENSe must be 1. For Noise measurements, only discrete values in 1,3 steps are possible.

Example: "FREQ:STOP 20MHz"

Characteristics: *RST value: analyzer mode: f_{\max} ; phase noise mode: 1 MHz
SCPI: conform

Mode: A-F, PNO

[SENSe<1|2>:]FREQUENCY:MODE CW | FIXEd | SWEep

In analyzer mode, this command switches between frequency domain (SWEep) and time domain (CW | FIXEd).

For CW and FIXEd, the frequency setting is via command `FREQUENCY:CENTer`. In the SWEep mode, the setting is via commands `FREQUENCY:START`, `STOP`, `CENTER` and `SPAN`.

Example: "FREQ:MODE SWE"

Characteristics: *RST value: SWEep
SCPI: conform

Mode: A

[SENSe<1|2>:]FREQUENCY:OFFSet <numeric_value>

This command defines the frequency offset of the instrument.

Example: "FREQ:OFFS 1GHZ"

Characteristics: *RST value: 0 Hz
SCPI: conform

Mode: A

[SENSe:]FREQUENCY:TRACk ON | OFF

This command switches the automatic frequency control on and off. This command only applies to Phase Noise Analyzer measurements.

Example: "FREQ:TRAC ON"
'Sets the automatic frequency control to ON.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

[SENSe:]FREQUENCY:VERify[:STATe] ON | OFF

This command specifies whether frequency and level verification are to be performed before a phase noise measurement. This parameter applies only to Phase Noise Analyzer measurements.

This command is synonymous with `[SENSe:]POWER:RLEVel:VERify[:STATe]`.

Example: "FREQ:VER OFF"
'Specifies that frequency and level verification is to be performed.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

[SENSe]:FREQuency:VERify:TOLerance 1 Hz/1 PCT to 1 MHz/100 PCT

This command specifies the frequency tolerance for the verification of the signal. If the signal frequency varies from the specified center frequency by a value greater than the tolerance, the verification fails. This parameter applies only to Phase Noise Analyzer measurements.

The setting for this parameter only has an effect if the [\[SENSe\]:FREQuency:VERify\[:STATe\]](#) or [\[SENSe\]:POWer:RLEVel:VERify\[:STATe\]](#) command is set to ON.

If the [\[SENSe\]:SWEep:FORWard](#) command is set to ON, the tolerance is specified in Hz.

If the [\[SENSe\]:SWEep:FORWard](#) command is set to OFF, the tolerance is specified in %

Example: "SWEEP:FORW ON"
'Sets the sweep direction from start to stop frequency.
"FREQ:VER:TOL 20HZ"
'Sets the frequency tolerance for the verification measurement to 20 Hz.

Characteristics: *RST value: 1 kHz/10 PCT
SCPI: device-specific

Mode: PNO

SENSe:LIST Subsystem

The commands of this subsystem are used for measuring the power at a list of frequency points with different device settings. The measurement is always performed in the time domain (span = 0 Hz).

A new trigger event is required for each test point (exception: Trigger FREE RUN).

The results are output as a list in the order of the entered frequency points. The number of results per test point depends on the number of concurrently active measurements (peak/RMS/average).

Selection of concurrently active measurements and setting of parameters that are constant for the whole measurement is via a configuration command (SENSe:LIST:POWer:SET). This also includes the setting for trigger and gate parameters.

The following setting parameters can be selected independently for each frequency point:

- Analyzer frequency
- Reference level
- RF attenuation of attenuator (only with option B25)
- Resolution filter
- Resolution bandwidth
- Video bandwidth
- Measurement time
- Detector

The number of frequencies is limited to 100 entries.

The commands of this subsystem can be used in two different ways:

1. Instrument setup, measurement and querying of the results in a single command:
With this method, there is the least delay between the measurement and the result output. However, it requires the control computer to wait for the response from the instrument.
2. Instrument setup and querying of the result list at the end of the measurement:
With this method, the control computer may be used for other activities while the measurement is being performed. However, more time is needed for synchronization via service request.



Note

Settings that are not directly included in commands of this subsystem can be configured by sending the corresponding commands prior to the SENSe:LIST commands.

Please note that changes to the trigger level have to be executed in time domain (span = 0 Hz) in order to take effect for the SENSe:LIST commands.

[SENSe]:LIST:BWIDth[:RESolution]:RATio 0.1 PCT to 30 PCT

This command specifies the RBW value of each sub-band as a ratio of the start frequency of the sub-band. A value of 10% specifies that the RBW should be set to 10% of the start frequency value. If the required RBW value is not valid, then the nearest RBW value is set.

Example: "LIST:BWID:RAT 1"
 'Sets the RBW ratio to 1% of the start frequency.

Characteristics: *RST value: 10 PCT
SCPI: device-specific

Mode: PNO

[SENSe]:LIST:BWIDth[:RESolution]:TYPE NORMal | FFT

This command specifies the filter type. The user can control the all sub-band filters with this command.

Example: "LIST:BWID:TYPE FFT"
'Sets the RBW to use FFT filtering.

Characteristics: *RST value: FFT
SCPI: device-specific

Mode: PNO

[SENSe<1|2>:]LIST:POWer:RESult?

This command queries the result of a previous list measurement as configured and initiated with `SENSe:LIST:POWer[:SEQuence]`. The measured results are output in a list of floating point values separated by commas. The unit of the results depends on the setting made with the `CALC:UNIT` command.

This command may be used to obtain measurement results in an asynchronous way, using the service request mechanism for synchronization with the end of the measurement.

If no measurement results are available, the command will return a query error.

Example:

'Configuration of the status reporting system for the generation of an SRQ on operation complete

*ESE 1

*SRE 32

'Configuring and starting the measurement

```
"SENSe:LIST:POWer 935.2MHz,-20dBm,10dB,OFF,NORM,1MHz,3MHz,434us,0,
935.4MHz,-20dBm,10dB,10dB,NORM,30kHz,100kHz,434us,0,
935.6MHz,-20dBm,10dB,20dB,NORM,30kHz,100kHz,434us,0;
*OPC"
```

'Further actions of the control computer during measurement

to

'Response to service request

On SRQ:

```
SENSe:LIST:POWer:RESult?
```

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:LIST:POWer[:SEQUence] <analyzer freq>, <ref level>, <rf att>, <el att>, <filter type>, <rbw>, <vbw>, <meas time>, <trigger level>, to

This command configures the list of settings (max. 100 entries) for the multiple power measurement and starts a measurement sequence. When synchronizing the command with *OPC, a service request is generated as soon as all frequency points are processed and the defined number of individual measurements is reached.

To reduce the setting time, all indicated parameters are set up simultaneously at each test point.

The query form of the command processes the list and immediately returns the list of results. The number of results per test point depends on the setting of the "SENSe:LIST:POWer:SET" command.



Note

The following parameters are the settings for an individual frequency point. They are repeated for every other frequency point.

Parameter:

<analyzer freq>:	Receive frequency for the signal to be measured (= center frequency in manual operation)
	Range of values: 0 Hz to max. frequency, depending on the instrument model.
<ref level>:	Reference level
	Range of values: +30 dBm to -70 dBm in 10 dB steps +30 dBm to -75 dBm in 5 dB steps with EI. Attenuator option B25
<rf att>:	RF input attenuation
	Range of values: 0 dB to 70 dB in 10 dB steps 0 dB to 75 dB in 5 dB steps with EI. Attenuator Option B25
<el att>:	RF input attenuation of electronic attenuator
	Range of values: 0 dB to 30 dB in 10 dB steps
	OFF electronic attenuator not in signal path
	If option B25 is missing, OFF is to be used.
<filter type>:	NORMal: normal resolution filter
	CFILter: channel filter. These are especially steep-edged filters, which are used for example in Fast ACP measurement to ensure the band-limiting of a transmission channel in the time domain.
	RRC: Root Raised Cosine filter. This special filter form is used to determine the channel power for some mobile radio standards.

<rbw>:	Resolution bandwidth	
	Range of values:	10 Hz to 20 MHz in 1, 2, 3, 5, 10 steps, and 50 MHz for <filter type> = NORMal. Type 5 resonates more quickly; the values for NORMAL apply. See filter table for <filter type> = CFILter and <filter type> = RRC. For possible combinations of filter type and filter bandwidth see table "List of available channel filters" in chapter "Instrument Functions", section "Setting the Bandwidths and Sweep Time – BW Key" on page 4.97.
<vbw>:	Video bandwidth	
	Range of values:	1 Hz to 10 MHz(30 MHz if RBW>10 MHz) in 1, 2, 3, 5, 10 steps. The value is ignored for <filter type> = CFILter or RRC
<meas time>:	Measurement time	
	Range of values:	1us to 30s
<trigger level>:	Reserved. Must be set to 0.	

Return value:

The query command returns a list of comma-separated values (CSV) which contains the power measurement results in floating-point format. The unit depends on the setting with `CALC:UNIT`.

Command

```
"SENSe:LIST:POWer? 935.2MHz,-20dBm,10dB,OFF,NORM,1MHz,3MHz,434us,0,
935.4MHz,-20dBm,10dB,10dB,NORM,30kHz,100kHz,434us,0,
935.6MHz,-20dBm,10dB,20dB,NORM,30kHz,100kHz,434us,0"
```

thus returns the following list, for example:

```
-28.3,-30.6,-38.1
```

If the command sequence is extended to

```
"SENSe:LIST:POWer:SET ON,ON,ON,IMM,POS,0,0"
```

```
"SENSe:LIST:POWer? 935.2MHz,-20dBm,10dB,OFF,NORM,1MHz,3MHz,434us,0,
935.4MHz,-20dBm,10dB,10dB,NORM,30kHz,100kHz,434us,0,
935.6MHz,-20dBm,10dB,20dB,NORM,30kHz,100kHz,434us,0"
```

the result list is extended to 3 results per frequency point (peak, RMS and average):

```
-28.3, -29.6, 1.5, -30.6, -31.9, 0.9, -38.1, -40.0, 2.3
```

Example:

```
"SENSe:LIST:POWer 935.2MHz,-20dBm,10dB,OFF,NORM,1MHz,3MHz,434us,0,
935.4MHz,-20dBm,10dB,10dB,CFIL,30kHz,100kHz,434us,0,
935.6MHz,-20dBm,10dB,20dB,CFIL,30kHz,100kHz,434us,0"
```

performs a measurement sequence with the following settings:

Step	Freq. [MHz]	Ref Level	RF Att	el Att	Filter type	RBW	VBW	Meas Time	TRG Level (reserved)
1	935.2	-20 dBm	10 dB	OFF	Normal	1 MHz	3 MHz	434 us	0
2	935.4	-20 dBm	10 dB	10dB	Channel	30 kHz	100 kHz	434 us	0
3	935.6	-20 dBm	10 dB	20dB	Channel	30 kHz	100 kHz	434 us	0

```
"SENSe:LIST:POWer? 935.2MHz,-20dBm,10dB,OFF,NORM,1MHz,3MHz,434us,0,
935.4MHz,-20dBm,10dB,10dB,CFIL,30kHz,100kHz,434us,0,
935.6MHz,-20dBm,10dB,20dB,CFIL,30kHz,100kHz,434us,0"
```

performs the same measurement and returns the result list immediately after the last frequency point.

**Notes**

- The measurement is performed in the time domain and therefore the span is set to 0 Hz. If the time domain is abandoned, the function is automatically switched off.
- The measurement is not compatible with other measurements, especially as far as marker, adjacent channel power measurement or statistics are concerned. The corresponding commands thus automatically deactivate the function.
- The function is only available in remote control. It is deactivated when switching the instrument back to LOCAL.

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:POWer:SET <PEAK meas>,<RMS meas>,<AVG meas>,<trigger mode>,<trigger slope>,<trigger offset>,<gate length>

This command defines the constant settings for the list during multiple power measurement.

Parameters <PEAK meas>, <RMS meas> and <AVG meas> define, which measurements are to be performed at the same time at the frequency point. Correspondingly, one, two or three results per frequency point are returned for the `SENSe:LIST:POWer?` command. If all three parameters are set to OFF, the command generates an execution error.

Parameter: <PEAK meas>: ON activates the measurement of the peak power (peak detector). OFF deactivates the measurement of the peak power.

<RMS meas>: ON activates the measurement of the RMS power (RMS detector). OFF deactivates the measurement of the RMS power.

<AVG meas>: ON activates the measurement of the average power (average detector). OFF deactivates the measurement of the average power.

<trigger mode>: Selection of the trigger source used for the list measurement.
Possible values: IMMEDIATE | VIDEO | EXTERNAL | IFCORRELATION

<trigger slope>: Used trigger slope.
Possible values: POSITIVE | NEGATIVE

<trigger offset>: Offset between the detection of the trigger signal and the start of the measurement at the next frequency point.
Range of values: 0 s, 125 ns to 100s

<gate length>: Gate length with Gated Sweep.
Range of values: 0 s, 125 ns to 100s

**Note**

- The value 0 s deactivates the use of GATED TRIGGER; other values activate the GATED TRIGGER function.
- Values <> 0 s are only possible if <trigger mode> is different from IMMEDIATE. Otherwise, an execution error is triggered.

Return value: The query command returns a list of comma-separated values (CSV) of the settings, i.e.

ON,ON,ON,IMM,POS,0,0

if the configuration has been set with the command

"SENSe:LIST:POWer:SET ON,ON,ON,IMM,POS,0,0"

Example: "SENSe:LIST:POWer:SET ON,OFF,OFF,EXT,POS,10US,434US"

"SENSe:LIST:POWer:SET ON,ON,ON,VID,NEG,10US,0"

Characteristics: *RST values: ON,OFF,OFF,IMM,POS,0S,0S
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:POWer:SET:AVERAge:TYPE LINear | LOGarithmic

With this command the average type of the sense list measurement can be set either to linear (default) or logarithmic. In linear mode voltages are averaged in logarithmic mode levels.

Example: "LIST:POW:SET:AVER LOG"
'sets log averaging for list measurement.

Characteristics: *RST value: LIN
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:POWer:STATe OFF

This command deactivates the list measurement.

Example: "SENSe:LIST:POWer:STATe OFF"

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:BANDwidth[:RESolution] <numeric_value>

This command selects the resolution bandwidth (RBW) of a range in the spurious measurement.

Example: "LIST:RANG2:BAND 10E3"
'Sets the RBW to 10 KHz.

Characteristics: *RST value: 10 kHz
SCPI: device-specific

Mode: A

[SENSe:]LIST:RANGe<1...20>:BWIDth[:RESolution] <numeric_value>

This command selects the resolution bandwidth (RBW) for the specified sub-band. It is only available, if the sweep mode is set to MANual ([\[SENSe<1|2>:\]SWEep:MODE](#)).

Example: "LIST:RANG5:BWID 30"
'Sets the RBW of fifth sub-band to 30 Hz.

Characteristics: *RST value: sub-band dependent
SCPI: device-specific

Mode: PNO

[SENSe<1|2>:]LIST:RANGe<1...20>:BANDwidth:VIDeo <numeric_value>

This command selects the video bandwidth (VBW) of a range in the spurious measurement.

Example: "LIST:RANG2:BAND:VIDeo 40E3"
'Sets the VBW to 40 KHz.

Characteristics: *RST value: 30 kHz
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:BREak ON | OFF

This command determines whether a sweep is stopped in the spurious measurement when a range is changed.

Example: "LIST:RANG2:BRE ON"
'Sweep stops if the range is changed from range 2 to 3.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:COUNT?

This command indicates the number of defined ranges of the spurious measurement.

The numeric suffix <1 to 20> with RANGe is not relevant for this command.

Example: "LIST:RANG:COUN?"
'Indicates the number of ranges

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:DELete

This command deletes a range.

Example: "LIST:RANG2:DEL"
'Deletes range 2

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:DETector APEak | NEGative | POSitive | SAMPlE | RMS | AVERage

This command sets the detector in the spurious measurement.

Example: "LIST:RANG2:DET APE"
'Autopeak detector

Characteristics: *RST value: POS
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:FILTer:TYPE NORMAl | CHANnel | RRC | P5 | NOISe | PULSe

This command sets the filter in the spurious measurement. For details on filter type refer to chapter 4, section "Filter Types" on page 4.103.

Example: "LIST:RANG2:FILT:TYPE RRC"
'RRC filter

Characteristics: *RST value: NORMAL
SCPI: device-specific

Mode: A

[SENSe:]LIST:RANGe<1...20>:FILTer:TYPE NORMAl | FFT

This command selects filter type for the specified sub-band. The FFT filter is only available for RBW values between 1 Hz and 10 kHz. For details on filter type refer to chapter 4, section "Filter Types" on page 4.103.

This command is only available for Noise Analyzer measurements.

Example: "LIST:RANG6:FILT:TYPE FFT"
'Sets the filter to FFT mode.

Characteristics: *RST value: sub-band dependent
SCPI: device-specific

Mode: PNO

[SENSe<1|2>:]LIST:RANGe<1...20>[:FREQUency]:STARt <numeric_value>

This command sets the start frequency of a range in the spurious measurement.

Example: "LIST:RANG2:STAR 1GHZ"
'Start frequency of range 2 to 1 GHz

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>[:FREQUency]:STOP <numeric_value>

This command sets the stop frequency of a range in the spurious measurement.

Example: "LIST:RANG2:STOP 2GHZ"
'Stop frequency of range 2 to 2 GHz

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:INPut:ATTenuation <numeric_value>

This command defines the RF attenuation of a range in the spurious measurement.

Example: "LIST:RANG2:INP:ATT 30db"
'RF attenuation of range 2 to 30 dB

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:INPut:ATTenuation:AUTO ON | OFF

This command switches the autoranging of a range in the spurious measurement on or off.

Example: "LIST:RANG2:INP:ATT:AUTO ON"
'Activates autorange for range 2

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:INPut:GAIN[:STATE] ON | OFF

This command switches the preamplifier of a range in the spurious measurement on or off.

Example: "LIST:RANG2:INP:GAIN:STAT ON"
'Activates the preamplifier for range 2

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:POINTs <numeric_value>

This command defines the number of sweep points of a range in the spurious measurement.

Example: "LIST:RANG2:POIN 300"
'Sets 300 sweep points in range 2

Characteristics: *RST value: 625
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:RLEVel <numeric_value>

This command defines the reference level of a range in the spurious measurement.

Example: "LIST:RANG2:RLEV -30"
'Sets the reference level in range 2 to -30 dBm

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe:]LIST:RANGe<1...20>:SWEep:COUNT <numeric_value>

This command selects the sweep count or, in the Cross Correlation PLL measurement (R&S FSUP-B60), the number of correlations for the specified sub-band. It is only available, if the sweep mode is set to MANual ([SENSe<1|2>:]SWEep:MODE).

Example: "LIST:RANG1:SWE:COUN 5"
'Sets the sweep count to 1.

Characteristics: *RST value: sub-band dependent
SCPI: device-specific

Mode: PNO

[SENSe<1|2>:]LIST:RANGe<1...20>:SWEep:TIME <numeric_value>

This command defines the sweep duration of a range in the spurious measurement.

Example: "LIST:RANG2:SWE:TIME 1MS"
'Sets the sweep time in range 2 to 1 ms

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>:]LIST:RANGe<1...20>:SWEep:TIME:AUTO ON | OFF

This command controls the automatic coupling of the sweep duration on the frequency span and the bandwidth settings in a spurious measurement range.

Example: "LIST:RANG2:SWE:TIME:AUTO ON"
'Activates the coupling of frequency range and bandwidths in range 2

Characteristics: *RST value: ON
SCPI: device-specific

Mode: A

[SENSe<1|2>]:LIST:RANGe<1...20>:TRANsducer <string>

This command sets the transducer factor for a range in the spurious measurement.

Example: "LIST:RANG2:TRAN ON 'fac_1'"
'Sets the transducer factor fac_1 in range 2

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

[SENSe<1|2>]:LIST:RANGe<1...20>:LIMit -200dB to +200dB

This command defines the limit lines for the spurious emission measurement [LIST EVALUATION](#) (for details on this measurement see page 205). For each of the 20 ranges, you can specify a limit line via the numeric suffix at RANGe<1...20>. The numeric suffix at SENSe<1|2> is irrelevant.

Example: "LIST:RANG5:LIM -40"
'Limit line in range 5 is -40 dB.

Characteristics: *RST value: -13dB
SCPI: device-specific

Mode: A

[SENSe<1|2>]:LIST:RANGe<1...20>:LIMit:STATe ON | OFF

This command activates/deactivates the limit checking for the spurious emission measurement [LIST EVALUATION](#) (for details on this measurement see page 205).

The numeric suffix at SENSe<1|2> and the numeric suffix at RANGe1...20> are irrelevant.

Example: "LIST:RANG5:LIM -40"
'Limit line in range 5 is -40 dB.

"LIST:RANG7:LIM -20"
'Limit line in range 7 is -20 dB.

"LIST:RANG:LIM:STAT ON"
'Activates the limit checking in all ranges.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe]:LIST:SWEp:COUNT 1 to 10000

This command specifies the sweep count for all sub-band.

Example: "LIST:SWE:COUN 10"
'Sets the sweep count to 10.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: PNO

SENSe:MIXer Subsystem

The SENSe:MIXer subsystem controls the settings of the external mixer. It is only active if option R&S FSU-B21 is installed.

[SENSe:]MIXer[:STATe] ON | OFF

This command activates or shuts off the external mixer.

Example: "MIX ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:PORTs 2 | 3

This command activates the 2- or 3-port mixer. The command refers to the active band selected with SENSe:MIXer:HARMonic:BAND.

Example: "MIX ON"
"MIX:PORT 3"

Characteristics: *RST value: 2
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:SIGNal ON | OFF | AUTO | ALL

In analyzer mode, this command activates the Signal ID (ON) or Auto ID (AUTO) mode or both (ALL).

Example: "MIX ON"
"MIX:SIGN ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:HARMonic 2 to 64

With band USER, this command sets the nth harmonic. The command may be a query with waveguide bands.

Parameter: <numeric_value> := 2.. 64: (max depending on the LO)

Example: "MIX ON"
"MIX:HARM 5"

Characteristics: *RST value: 2
SCPI: conform

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:HARMonic:TYPE ODD | EVEN | EODD

This command sets the type of harmonic.

Example: "MIX ON"
"MIX:HARM:TYPE EODD"

Characteristics: *RST value: EVEN
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:HARMonic:BAND A|Q|U|V|E|W|F|D|G|Y|J|USER

This command sets the active band.

Example: "MIX ON"
"MIX:HARM:BAND E"

Characteristics: *RST value: U
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:LOSS[:LOW] <numeric_value>

This command sets the conversion loss of the mixer. If two harmonics are used for the band, it is set for the lower harmonic.

Example: "MIX ON"
"MIX:LOSS -12DB"

Characteristics: *RST value: 0 dB
SCPI: conform

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:LOSS:HIGH <numeric_value>

This command sets the conversion loss of the mixer for higher harmonics in bands with two harmonics.

Example: "MIX ON"
"MIX:LOSS:HIGH -14DB"

Characteristics: *RST value: 0 dB
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:LOSS:TABLE[:LOW] <file_name>

This command selects a conversion loss table and sets it for the active band. If two harmonics are used for the band, it is set for the lower harmonic.

Parameter: <file_name> := file name

Example: "MIX ON"
"MIX:LOSS:table mix_1"

Characteristics: *RST value: no table set
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:LOSS:TABLE:HIGH <file_name>

This command sets the conversion loss table for higher harmonics in bands with two harmonics.

Parameter: <file_name> := file name

Example: "MIX ON"
"MIX:LOSS:TABL:HIGH mix_1_6"

Characteristics: *RST value: no table set
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:BIAS[:LOW] <numeric_value>

This command sets the bias current for the active band. If two harmonics are used for the band, it is set for the lower harmonic.

Example: "MIX ON"
"MIX:BIAS 7mA"

Characteristics: *RST value: 0 A
SCPI: conform

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:BIAS:HIGH <numeric_value>

This command sets the bias current of the mixer for higher harmonics in bands with two harmonics.

Example: "MIX ON"
"MIX:BIAS:HIGH 7mA"

Characteristics: *RST value: 0 A
SCPI: conform

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe:]MIXer:THReshold <numeric_value>

This command determines the maximum permissible level difference between measurement and reference sweep in AUTO ID mode.

Parameter: <numeric_value> := 0.1 to 100 dB

Example: "MIX ON"
"MIX:THR 20DB"

Characteristics: *RST value: 10 dB
SCPI: device-specific

Mode: A

This command is only available for option R&S FSU-B21 and external mixer activated.

[SENSe<1|2>:]MIXer:LOPower <numeric_value>

This command changes the LO level of the external mixer LO port from 13.0 dBm to 17.0 dBm in 0.1 dB steps. Default value is 15.5 dB.

Example: "MIX ON"
"MIX ON"
"MIX:LOP 16.0DBM"

Characteristics: *RST value: 15.5 dBm
SCPI: device-specific

Mode: A


This command is only available for option R&S FSU-B21 and external mixer activated.

SENSe:MPOWER Subsystem

The commands of this subsystem are used to determine the mean burst power or peak burst power for a given number of signal bursts, and for outputting the results in a list. Since all the settings required for a measurement are combined in a single command, the measurement speed is considerably higher than when using individual commands.

For measuring the signal bursts, the GATED SWEEP function is used in the time domain. The gate is controlled either by an external trigger signal or by the video signal. An individual trigger event is required for each burst to be measured. If an external trigger signal is used, the threshold is fixed to TTL level, while with a video signal the threshold can be set as desired.

The following graphics shows the relation between trigger time, trigger offset (for delayed gate opening) and measurement time.



Depending on the settings made, the measurements are performed with the RMS detector for RMS power or the PEAK detector for peak power. For all these measurements, TRACE 1 of the selected system is used.

The setting parameters for this measurement are:

- analyzer frequency
- resolution bandwidth
- measurement time used for a single burst
- trigger source
- trigger level
- trigger offset
- type of power measurement (PEAK, MEAN)
- number of bursts to be measured

The commands of this subsystem can be used in two different ways:

1. Setting up the instrument and at the same time querying the result list:
This method ensures the smallest delay between measurement and the output of the measured values, but requires the control computer to wait actively for the response of the instrument.
2. Setting up the instrument and querying the result list after synchronization to the end of measurement:
With this method the control computer can be used for other activities while the instrument is performing the measurement at the cost of additional time needed for synchronization via service request.

[SENSe<1|2>:IMPOWer:SEQuence] <analyzer freq>,<rbw>,<meas time>,<trigger source>, <trigger level>,<trigger offset>,<type of meas>,<# of meas>

This command configures the instrument setup for multiple burst power measurement and starts a measurement sequence. When synchronizing the command with *OPC, a service request is generated as soon as the defined number of individual measurements (# of meas) is reached.

To reduce the setting time, the setup is performed simultaneously for all selected parameters.

The command in the form of a query makes the instrument settings, performs the defined number of measurements and outputs the measurement results list.

Parameter:

- <analyzer freq>: Receive frequency for the burst signals to be measured (= center frequency in manual operation)
Range: 0 Hz to max. frequency, depending on instrument model
- <rbw>: resolution bandwidth for the measurement
Range: 10 Hz to 10 MHz in steps of 1, 3, 10
- <meas time>: Time span during which measurement samples are sampled for RMS / peak measurement The type of measurement is selected by <type of meas>.
Range: 1us to 30s
- <trigger source>: trigger signal source.
Possible settings: EXTERNAL =The trigger signal is fed from the "Ext. Trigger/Gate" input on the rear of the unit. VIDEO =The internal video signal is used as trigger signal.
- <trigger level>: Signal level at which the trigger becomes active. For <trigger source> = VIDEO this is the level of the video signal as a percentage of the diagram height. If <trigger source> = EXTERNAL is selected, the value entered here is ignored, as in this case the trigger input uses TTL levels.
Range: 0 – 100PCT (<trigger source> = VIDEO)
- <trigger offset>: Offset between the detection of the trigger signal and the start of the measurement.
Range: 125 ns to 100s
- <type of meas>: Determines whether mean power (RMS) or peak power (PEAK) is to be measured. The detector is selected accordingly.
Possible values: MEAN, PEAK
- <# of meas>: Number of individual bursts to be measured.
Range: 1 to 625

Return value: The query command returns a list separated by commas (comma separated values = CSV), which contains the power measurement results in floating-point format. The unit used for the return values is always dBm.

The command

"SENSe:MPOWer? 935.2MHz,1MHz,434us,VIDEO,50PCT,5us,MEAN,20" may, for instance, cause the following list to be returned:

18.3,18.6,18.1,18.0,17.9,18.3,18.6,18.1,18.0,17.9,18.3,18.6,18.1,18.0,17.9,18.3,18.6,18.1,18.0,17.9

Example: "SENSe:MPOWer 935.2MHz,1MHz,434us,VIDEO,50PCT,5us,MEAN,20" 'performs a measurement sequence with the following settings:
 'Frequency = 935.2 MHz,
 'Resolution bandwidth = 1 MHz
 'Measurement time = 434 μ s
 'Trigger source = VIDEO
 'Trigger threshold = 50%
 'Trigger offset = 5 μ s
 'Type of measurement = MEAN power
 'No. of measurements = 20

"SENSe:MPOWer? 935.2MHz,1MHz,434us,VIDEO,50PCT,5us,MEAN,20" 'performs the same measurement and in addition returns the results list immediately after completion of the last measurement.



Note

The measurement function always uses trace 1 in the selected screen, and activates the selected screen.

Repeated use of the command without changes to its parameters (i.e. using the same settings again) will speed up the measurement since the previous hardware settings will be cached and therefore additional hardware settling times will be avoided. This also holds true if only part of the parameters (e.g. only the trigger delay) are changed, as in this case the rest of the parameters will be cached.

This measurement is not compatible with other measurements, especially as far as marker functions, adjacent channel measurement or statistics are concerned. The corresponding functions are therefore automatically switched off. In return incompatible commands will automatically deactivate the multi burst power function.

The function is only available in the remote control. It is deactivated on switching back to LOCAL.

Characteristics: *RST value: --
 SCPI: instrument-specific

Mode: A-F, A-T

SENSe:MPOWer:RESult[:LIST]?

This command queries the results of a multiple burst power measurement as configured and initiated with `SENSe:MPOWer[:SEQuence]`. The results are output in a comma-separated list of floating point values. The unit used for the return values is always dBm.

This command may be used to obtain measurement results in an asynchronous way using the service request mechanism for synchronization with the end of the measurement.

If no measurement results are available, the command will return a query error.

Example:

```
*ESE 1
*SRE 32
'Configuration of status reporting systems for the generation of an SRQ on
operation complete

SENSe:MPOWer
935.2MHz,1MHz,434us,VIDEO,50PCT,5us,MEAN,20;*OPC
'Configuring and starting the measurement

...
'Further actions of the control computer during measurement

On SRQ:
'Response to service request

SENSe:MPOWer:RESult?
```

Characteristics: *RST value: --
SCPI: instrument-specific

Mode: A-F, A-T

SENSe:MPOWer:RESult:MIN?

This command queries the minimum power value in a multiple burst power measurement as configured and initiated with `SENSe:MPOWer[:SEQuence]`. The unit used for the return values is always dBm.

If no measurement result is available, the command will return a query error.

Example:

```
*ESE 1
*SRE 32
'Configuration of status reporting systems for the generation of an SRQ on
operation complete

SENSe:MPOWer
935.2MHz,1MHz,434us,VIDEO,50PCT,5us,MEAN,20;*OPC
'Configuring and starting the measurement

...
'Further actions of the control computer during measurement

On SRQ:
'Response to service request

SENSe:MPOWer:RESult:MIN?
```

Characteristics: *RST value: --
SCPI: instrument-specific

Mode: A-F, A-T

SENSe:POWer Subsystem

This subsystem controls the setting of the instrument's channel and adjacent channel power measurements.

In analyzer mode, the measurement windows are selected via SENSe1 (screen A) or SENSe2 (screen B). In phase noise mode, the numeric suffix at SENSe must be 1.

[SENSe<1|2>:]POWer:ACHannel:SPACing:CHANnel<1 to 11> 100 Hz to 2000 MHz

This command defines the channel spacing of the carriers. At the same time the spacing of carriers with higher channel number are set to the same value. If the spacing is equal between all carriers it is sufficient to set the spacing between carrier 1 and 2 with the command `SENS:POW:ACP:SPAC:CHAN1` or `SENS:POW:ACP:SPAC:CHAN`. If the spacing are set in ascending order individual spacing of the carriers can be set.

The command is available only for measurements in the frequency domain (span > 0).

Example: `"POW:ACH:SPAC:CHAN 25kHz"`
 'Sets the spacing between all carriers to 25 kHz

`"POW:ACH:SPAC:CHAN2 4.8MHz"`
 'sets the spacing between TX carrier 2 and 3 to 4.8 MHz.

Characteristics: *RST value: 20 kHz
 SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:SPACing:ACHannel 100 Hz to 2000 MHz

This command defines the channel spacing of the adjacent channel to the TX channel. At the same time, the spacing of alternate adjacent channels 1 to 11 is set to the double or triple etc. of the entered value.

The command is only available in the frequency domain (span > 0).

Example: `"POW:ACH:SPAC:ACH 33kHz"`
 'Sets the spacing between the carrier signal and
 '- the adjacent channel to 33 kHz
 '- the alternate adjacent channel 1 to 66 kHz
 '- the alternate adjacent channel 2 to 99 kHz

Characteristics: *RST value: 14 kHz
 SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:SPACing:ALternate<1 to 11> 100 Hz to 2000 MHz

This command defines the spacing between the alternate adjacent channels and the TX channel. If the spacing to an alternate adjacent channel `ALternate<k>` is modified, the spacing to all the following alternate adjacent channels `ALternate<n>` is set to $(\langle n \rangle + 1) / (\langle k \rangle + 1)$ times the entered value.

This command is only available in the frequency domain (span > 0).

Example: `"POW:ACH:SPAC:ALT1 100kHz"`
 'Sets the spacing between TX channel and alternate adjacent channel 1 to 100 kHz and between TX channel and alternate adjacent channel 2 to 150 kHz.

Characteristics: *RST value:
 40 kHz (ALT1)
 60 kHz (ALT2)
 80 kHz (ALT3)
 100 kHz (ALT4)
 120 kHz (ALT5)
 140 kHz (ALT6)
 160 kHz (ALT7)
 180 kHz (ALT8)
 200 kHz (ALT9)
 220 kHz (ALT10)
 240 kHz (ALT11)
 SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWER:ACHannel:TXChannel:COUNT 1 to 12

This command selects the number of carrier signals.

The command is available only for multi carrier channel and adjacent channel power measurements (CALC:MARK:FUNC:POW:SEL MCAC) in the frequency domain (span > 0).

Example: "POW:ACH:TXCH:COUN 3"

Characteristics: *RST value: 4
 SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWER:ACHannel:ACPairs 0 to 12

This command sets the number of adjacent channels (upper and lower channel in pairs). The figure 0 stands for pure channel power measurement.

The command is only available in the frequency domain (span > 0).

Example: "POW:ACH:ACP 3"
 'Sets the number of adjacent channels to 3, i.e. the adjacent channel and alternate adjacent channels 1 and 2 are switched on.

Characteristics: *RST value: 1
 SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWER:ACHannel:BANDwidth|BWIDth[:CHANnel] 100 Hz to 1000 MHz

This command sets the channel bandwidth of the radio communication system. The bandwidths of adjacent channels are not influenced by this modification (in contrast to the FSE family).

With SENS:POW:HSP ON the steep-edged channel filters from the table "List of available channel filters" in chapter "Instrument Functions", section "Setting the Bandwidths and Sweep Time – BW Key" on page 4.97 are available.

Example: "POW:ACH:BWID 30kHz"
 'Sets the bandwidth of the TX channel to 30 kHz.

Characteristics: *RST value: 14 kHz
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:BANDwidth|BWIDth:ACHannel 100 Hz to 1000 MHz

This command defines the channel bandwidth of the adjacent channel of the radio transmission system. If the bandwidth of the adjacent channel is changed, the bandwidths of all alternate adjacent channels are automatically set to the same value.

With `SENS:POW:HSP ON` the steep-edged channel filters from the table "List of available channel filters" in chapter "Instrument Functions", section "Setting the Bandwidths and Sweep Time – BW Key" on page 4.97 are available.

Example: "POW:ACH:BWID:ACH 30kHz"
'Sets the bandwidth of all adjacent channels to 30 kHz.

Characteristics: *RST value: 14 kHz
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:BANDwidth|BWIDth:ALTErnate<1 to 11> 100 Hz to 1000 MHz

This command defines the channel bandwidth of the alternate adjacent channels of the radio transmission system. If the channel bandwidth of an alternate adjacent channel (e.g. channel no. 1) is changed, the bandwidth of all the following alternate adjacent channels (e.g. channels no. 2 to 11) is automatically set to the same value.

With `SENS:POW:HSP OFF`, the analog and FIR filters are available in the range from 10 Hz to 10 MHz.

With `SENS:POW:HSP ON`, the steep-edged channel filters from the table "List of available channel filters" in chapter "Instrument Functions", section "Setting the Bandwidths and Sweep Time – BW Key" on page 4.97 are available.

Example: "POW:ACH:BWID:ALT2 30kHz"

Characteristics: *RST value: 14 kHz
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:MODE ABSolute | RELative

This command toggles between absolute and relative adjacent channel measurement.

For the relative measurement the reference value is set to the currently measured channel power by command `SENSe:POWer:ACHannel:REFErnance:AUTO ONCE`.

The command is only available in the frequency domain (span > 0).

Example: "POW:ACH:MODE REL"

Characteristics: *RST value: ABSolute
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:REFErnance:AUTO ONCE

This command sets the reference value for the relative measurement to the currently measured channel power.

The command is only available in the frequency domain (span > 0).

Example: "POW:ACH:REF:AUTO ONCE"

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

This command is an event and therefore has no *RST value and no query.

[SENSe<1|2>:]POWer:ACHannel:REFerence:TXCHannel:AUTO MINimum | MAXimum | LHIGhest | OFF

This command activates or deactivates the automatic selection of a transmission channel to be used as a reference channel in relative adjacent channel power measurements.

The transmission channel with the highest power, the transmission channel with the lowest power, or the transmission channel nearest to the adjacent channels can be defined as a reference channel.

The command is available only for multi carrier channel and adjacent channel power measurements (CALC:MARK:FUNC:POW:SEL MCAC) in the frequency domain (span > 0).

Parameter: MINimum: Transmission channel with the lowest power
MAXimum: Transmission channel with the highest power
LHIGhest: Lowermost transmission channel for the lower adjacent channels, uppermost transmission channel for the upper adjacent channels
OFF: Deactivates the automatic transmission channel selection.

Example: "POW:ACH:REF:TXCH:AUTO MAX"
'The transmission channel with the highest power is used as a reference channel.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:REFerence:TXCHannel:MANual 1 to 12

This command selects a transmission channel to be used as a reference channel in relative adjacent channel power measurements.

The command is available only for multi carrier channel and adjacent channel power measurements (CALC:MARK:FUNC:POW:SEL MCAC) in the frequency domain (span > 0).

Example: "POW:ACH:REF:TXCH:MAN 3"
'Transmission channel 3 is used as a reference channel.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:PRESet ACPower | CPOWer | MCACpower | OBANdwidth | OBWidth | CN | CN0

This command adjusts the frequency span, the measurement bandwidths and the detector as required for the number of channels, the channel bandwidths and the channel spacings selected in the active power measurement. If necessary, adjacent channel power measurement is switched on prior to the adjustment.

To obtain valid results, a complete sweep with synchronization to the end of the sweep must be performed after the adjustment. Synchronization is possible only in the single-sweep mode.

The result is queried with the command `CALCulate:MARKer:FUNction:POWer:RESult?`.

The command is available only for measurements in the frequency domain (span > 0).

Example:

```
"POW:ACH:PRES ACP"
'Sets the frequency span, the measurement bandwidths and the detector as
required for the ACP measurement in screen A.

"INIT:CONT OFF"
'Switches over to single-sweep mode.

"INIT;*WAI"
'Starts a sweep and waits for the end of the sweep.

"CALC:MARK:FUNC:POW:RES? ACP"
'Queries the result of the adjacent channel power measurement.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:ACHannel:PRESet:RLEVel

This command adapts the reference level to the measured channel power and – if required - switches on previously the adjacent channel power measurement. This ensures that the signal path of the instrument is not overloaded. Since the measurement bandwidth is significantly smaller than the signal bandwidth in channel power measurements, the signal path can be overloaded although the trace is still significantly below the reference level. If the measured channel power equals the reference level, the signal path is not overloaded.

The command is only available in the frequency domain (span > 0).



Note

Subsequent commands have to be synchronized with *WAI, *OPC or *OPC? to the end of the auto range process which would otherwise be aborted.

Example:

```
"POW:ACH:PRESet:RLEV;*WAI"
'Adapts the reference level to the measured channel power.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A-F

[SENSe<1|2>:]POWer:BANDwidth|BWIDth 10 to 99.9PCT

This command defines the percentage of the power with respect to the total power. This value is the basis for the occupied bandwidth measurement (command: `POWer:ACHannel:PRESet OBW`).

The command is only available in the frequency domain (span > 0).

Example:

```
"POW:BWID 95PCT"
```


Characteristics: *RST value: 99PCT
SCPI: device-specific

Mode: A-F

[SENSe<1|2>]:POWER:HSPeed ON | OFF

This command switches on or off the high-speed channel/adjacent channel power measurement. The measurement itself is performed in the time domain on the center frequencies of the individual channels. The command automatically switches to the time domain and back.

Depending on the selected mobile radio standard, weighting filters with $\sqrt{\cos}$ characteristic or very steep-sided channel filters are used for band limitation.

The command is only available in the frequency domain (span > 0).



Note

If the high-speed power measurement is switched off, the complete channel/adjacent channel power measurement is switched off.

Example: "POW:HSP ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A-F

[SENSe<1|2>]:POWER:NCORrection ON | OFF

This command switches on or off the correction of the instrument inherent noise for channel power measurement. On activating this function, a reference measurement of the instrument inherent noise is performed. The measured noise power is then subtracted from the power in the examined channel.

The instrument inherent noise is then re-determined after any change of the center frequency, resolution bandwidth, sweep time and level setting by repeating the reference measurement in the new instrument setting.

Example: "POW:NCOR ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe]:POWER:RLEVel -100 dB to 30 dB

This command specifies the expected power.

The setting for this parameter only has an effect if the [\[SENSe\]:FREQuency:VERify\[:STATe\]](#) or [\[SENSe\]:POWER:RLEVel:VERify\[:STATe\]](#) command is set to ON.

For Noise measurements, the DUT level is determined automatically, if the DUT parameters are activated for the pre-measurement and the pre-measurement is initiated (see [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command). The manual setting of the DUT level takes only effect, if the DUT parameters are deactivated for the pre-measurement.

Example: "POW:RLEV 1"
'Sets the level tolerance for the pre-measurement to 1 dB.

Characteristics: *RST value: -20 dB
SCPI: device-specific

Mode: PNO

[SENSe]:POWer:RLEVel:VERify[:STATe] ON | OFF

This command specifies whether frequency and level verification are to be performed before a phase noise measurement. This parameter applies only to Phase Noise Analyzer measurements.

This command is synonymous with [\[SENSe\]:FREQuency:VERify\[:STATe\]](#).

Example: "POW:RLEV:VER OFF"
'Specifies that frequency and level verification is to be performed.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

[SENSe]:POWer:RLEVel:VERify:TOLerance 3 dB to 20 dB

This command specifies the power tolerance for the signal verification. If the signal level varies from the specified level by a value greater than the tolerance, the verification fails. This parameter applies only to Phase Noise Analyzer measurements.

The setting for this parameter only has an effect if the [\[SENSe\]:FREQuency:VERify\[:STATe\]](#) or [\[SENSe\]:POWer:RLEVel:VERify\[:STATe\]](#) command is set to ON.

Example: "POW:RLEV:VER:TOL 5DB"
'Sets the level tolerance for the verification measurement to 5dB.

Characteristics: *RST value: 10 dB
SCPI: device-specific

Mode: PNO

[SENSe<1|2>]:POWer:TRACe 1 to 3

This command assigns the channel/adjacent channel power measurement to the indicated trace in the selected measurement window. The corresponding trace must be active, i.e. its state must be different from blank.



Note

The measurement of the occupied bandwidth (OBW) is performed on the trace on which marker 1 is positioned. To evaluate another trace, marker 1 must be positioned to another trace with `CALCulate:MARKer:TRACe`.

Example: "POW:TRAC 2"
'Assigns the measurement in screen A to trace 2.

"SENS2:POW:TRAC 3"
'Assigns the measurement in screen B to trace 3.

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

[SENSe]:POWer:TRACk ON |OFF

This command switches the automatic level control on or off. This command only applies to Phase Noise Analyzer measurements.

Example: "POW:TRAC ON"
'Sets the automatic level control to ON.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

SENSe:ROSCillator Subsystem

This subsystem controls the reference oscillator. The numeric suffix in SENSe is irrelevant for the commands of this subsystem.

[SENSe<1|2>:]ROSCillator:SOURce INTernal | EXTernal

This command controls selection of the reference oscillator.

If the external reference oscillator is selected, the reference signal must be connected to the rear panel of the instrument.

Example: "ROSC:SOUR EXT"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

*RST is not influencing this parameter.

[SENSe<1|2>:]ROSCillator:EXTernal:FREQuency 1MHz to 20MHz

This command informs the instrument on the frequency of the external reference oscillator. This frequency is used as starting point for the synchronization of the internal reference frequencies.

The value of the external reference frequency (1 MHz to 20 MHz) is rounded in steps of 1 Hz.

With option R&S FSUP-B60 (Cross Correlation PLL measurements), the external reference frequency is restricted to 10 MHz and may not be changed.

Example: "ROSC:EXT:FREQ 5MHz"

Characteristics: *RST value: -
SCPI: conform

Mode: A

*RST is not influencing this parameter.

[SENSe<1|2>:]ROSCillator[:INTernal]:TUNe 0 to 4095

This command defines the value for the tuning of the internal reference oscillator.

The reference oscillator should be tuned only if an error has been detected in the frequency accuracy check. After rebooting the instrument, the factory-set reference frequency or the previously saved reference frequency is restored.



Note

This command is only available at service level 1.

Example: "ROSC:TUN 128"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

[SENSe<1|2>:]ROSCillator[:INTernal]:TUNe:SAVe

This command saves the new value for the tuning of the internal reference oscillator. The factory-set value in the EEPROM is overwritten.

**Note**

This command is only available at service level 1.

Example: "ROSC:TUN:SAV"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

SENSe:SPURs Subsystem

Spurs detection is only available for the Phase Noise PLL and Cross Correlation PLL measurements.

[SENSe]:SPURs:HIGHLIGHT:STATE ON | OFF

This command controls the spurs' highlighting.

Example: "SPUR:HIGH:STAT ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

[SENSe]:SPURs:SETup<1|2>:ENABLE ON | OFF

This command enables the selected spurs group to be displayed depending on the [\[SENSe\]:SPURs:SUPPress](#) command setup. The numeric index <1|2> determines the selected group.

Example: "SPUR:SET:ENAB ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

[SENSe]:SPURs:SETup<1|2>:FUNDamental 0 Hz to 1 GHz

This command specifies the fundamental frequency for the selected spurs group.

Example: "SPUR:SET:FUND 100KHZ"

Characteristics: *RST value: 50 Hz
SCPI: device-specific

Mode: PNO

[SENSe]:SPURs:SETup<1|2>:COUNT 1 to 50

This command specifies the max order for the selected spurs group.

Example: "SPUR:SET:COUNT 10"

Characteristics: *RST value: 5
SCPI: device-specific

Mode: PNO

[SENSe]:SPURs:SUPPress NONE | ALL | UNSelected | SELEcted

This command specifies the spurs display mode.

Parameter: The state of this command matches the following softkeys:
NONE: SHOW ALL
ALL: SUPPRESS ALL
UNSelected: SHOW SELECTED
SELEcted: SUPPRESS SELECTED

UNS and SEL states can only be set if **[SENSe]:SPURs:SETup<1|2>:ENABle** command is set to ON.

Example: "SPUR:SUPP ALL"

Characteristics: *RST value: NONE
SCPI: device-specific

Mode: PNO

[SENSe]:SPURs:THReshold 0 to 50

This command specifies the spur threshold. Only spurs above this threshold are displayed.

Example: "SPUR:THR 10"
'Sets the spur threshold to 10 dB.

Characteristics: *RST value: 0 dB
SCPI: device-specific

Mode: PNO

SENSe:SWEep Subsystem

This subsystem controls the sweep parameters.

In analyzer mode, the measurement windows are selected via SENSe1 (screen A) or SENSe2 (screen B). In phase noise mode, the numeric suffix at SENSe must be 1.

[SENSe<1|2>:]SWEep:TIME 2.5ms to 16000s (frequency domain) | 1 μ s to 16000s (time domain)

This command defines the sweep time. The available time values are different in the frequency domain (2.5 ms to 16000s with span > 0) and in the time domain (1 μ s to 16000s with span = 0).

If SWEep:TIME is directly programmed, automatic coupling to resolution bandwidth and video bandwidth is switched off.

Example: "SWE:TIME 10s"

Characteristics: *RST value: - (AUTO is set to ON)
SCPI: conform

Mode: A

[SENSe:]SWEep:TIME 15.63 ns to 1069 s

For Noise measurements, this command is query only. It returns the total measurement time.

For Transient measurements, this command defines the measurement time of the FM demodulator.

For VCO measurements, this command has no effect.

Example: "SWE:TIME?"

Characteristics: *RST value: 62.5 us for Transient measurements
SCPI: conform

Mode: PNO

[SENSe<1|2>:]SWEep:TIME:AUTO ON | OFF

This command controls the automatic coupling of the sweep time to the frequency span and bandwidth settings.

If SWEep:TIME is directly programmed, automatic coupling is switched off.

Example: "SWE:TIME:AUTO ON"
'Switches on the coupling to frequency span and bandwidths.

Characteristics: *RST value: ON
SCPI: conform

Mode: A

[SENSe<1|2>:]SWEep:COUNT 0 to 32767

This command defines the number of sweeps started with single sweep, which are used for calculating the average or maximum value. In average mode, the value 0 defines a continuous averaging of measurement data over 10 sweeps.

Example: "SWE:COUN 64"
'Sets the number of sweeps to 64.

"INIT:CONT OFF"
'Switches to single-sweep mode.

"INIT;*WAI"
'Starts a sweep and waits for its end.

Characteristics: *RST value: 0
SCPI: conform

Mode: PNO, A

[SENSe<1|2>:]SWEep:COUNT:CURRent?

This query command returns the current number of started sweeps. A sweep count value should be set and the device should be in single-sweep mode. This command is a query and therefore has no *RST value.

Example: "SWE:COUNT 64"
'sets sweep count to 64

"INIT:CONT OFF"
'switches to single-sweep mode

"INIT"
'starts a sweep (without waiting for the sweep end!)

"SWE:COUN:CURR?"
'queries the number of started sweeps

Characteristics: *RST value: -
SCPI: conform

Mode: A

[SENSe<1|2>:]SWEep:EGATe ON | OFF

This command switches on/off the sweep control by an external gate signal. If the external gate is selected the trigger source is automatically switched to EXTeRnal as well.

In case of measurement with external gate, the measured values are recorded as long as the gate is opened. There are two possibilities:

- The gate is edge-triggered ("SWEep:EGATe:TYPE EDGE"):
 - After detection of the set gate signal edge, the gate remains open until the gate delay (SWEep:EGATe:HOLDoff) has expired.
- The gate is level-triggered ("SWEep:EGATe:TYPE LEVe1"):
 - After detection of the gate signal, the gate remains open until the gate signal disappears.

A delay between applying the gate signal and the start of recording measured values can be defined with SWEep:EGATe:HOLDoff.

During a sweep the gate can be opened and closed several times. The synchronization mechanisms with *OPC, *OPC? and *WAI remain completely unaffected.

The sweep end is detected when the required number of measurement points (625 in analyzer mode) has been recorded.

Example: "SWE:EGAT ON"
'Switches on the external gate mode.

"SWE:EGAT:TYPE EDGE"
'Switches on the edge-triggered mode.

"SWE:EGAT:HOLD 100US"
'Sets the gate delay to 100 μ s.

"SWE:EGAT:LEN 500US"
'Sets the gate opening time to 500 μ s.

"INIT;*WAI"
'Starts a sweep and waits for its end.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

[SENSe<1|2>:]SWEep:EGATe:TYPE LEVEL | EDGE

This command sets the type of triggering (level or edge) by the external gate signal.

The gate opening time cannot be defined with the parameter EGATe:LENGth in case of level triggering. The gate is closed when the gate signal disappears.

Example: "SWE:EGAT:TYPE EDGE"

Characteristics: *RST value: EDGE
SCPI: device-specific

Mode: A

[SENSe<1|2>:]SWEep:EGATe:POLarity POSitive | NEGative

This command determines the polarity of the external gate signal. The setting is valid both for the edge of an edge-triggered signal and the level of a level-triggered signal.

Example: "SWE:EGAT:POL POS"

Characteristics: *RST value: POSitive
SCPI: device-specific

Mode: A

[SENSe<1|2>:]SWEep:EGATe:HOLDoff 125 ns to 100 s

This command defines the delay time between the external gate signal and the continuation of the sweep.

Example: "SWE:EGAT:HOLD 100us"

Characteristics: *RST value: 0s
SCPI: device-specific

Mode: A

[SENSe<1|2>]:SWEep:EGATe:LENGth 0 to 100 s

In case of edge triggering, this command determines the time interval during which the instrument sweeps.

Example: "SWE:EGAT:LENG 10ms"

Characteristics: *RST value: 0s
SCPI: device-specific

Mode: A

[SENSe<1|2>]:SWEep:EGATe:SOURce EXTernal | IFPower

This command toggles between external gate signal and IF power signal as a signal source for the gate mode. If an IF power signal is used, the gate is opened as soon as a signal at > -20 dBm is detected within the IF path bandwidth (50 MHz).

Example: "SWE:EGAT:SOUR IFP"
'Switches the gate source to IF power.

Characteristics: *RST value: IFPower
SCPI: device-specific

Mode: A

[SENSe]:SWEep:FFTWindow CHEBychev | GAUSSian | RECTangular

This command specifies the FFT window for Phase Noise PLL measurements. For Noise Analyzer measurements the FFT window is always FLATTOP.

Parameter: Available FFT window types: GAUSSian, CHEBychev, RECTangular

Example: "SWE:FFTW GAUS"
'Sets the FFT window to CHEBychev.

Characteristics: *RST value: CHEBychev
SCPI: device-specific

Mode: PNO

[SENSe]:SWEep:FORWard ON | OFF

This command specifies the sweep direction. This parameter applies only to Phase Noise Analyzer measurements, for Phase Noise PLL measurements the sweep direction is always from stop frequency to start frequency.

Parameter: ON: The sweep direction is from the start frequency to the stop frequency.
OFF: The sweep direction is from the stop frequency to the start frequency.

Example: "SWE:FORW ON"
'The sweep direction is set to sweep from start to stop frequency.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

[SENSe<1|2>]:SWEep:IF:SHIFt OFF | A | B

This command activates or deactivates 1st IF shifting. For further details refer to "IF SHIFT" on page 4.256.

In phase noise mode, the numeric suffix at [SENSe<1|2>] is irrelevant.

Parameter: OFF: deactivates the 1st IF shifting
 A: activates the 1st IF shifting for input signals in the frequency range of 2270 MHz to 2310 MHz
 B: activates the 1st IF shifting for input signals in the frequency range of 2310 MHz to 2350 MHz

Example: "SWE:IF:SHIF B"
 'Sets the IF shift to mode B.

Characteristics: *RST value: OFF
 SCPI: device-specific

Mode: A, PNO

[SENSe<1|2>]:SWEep:MODE AUTO | LIST

This command controls the sweep continuation.

AUTO free running sweep

LIST Activates the spurious emissions measurement. The sweep list is defined using the SENS:LIST:RANGE commands.

Example: "SWE:MODE LIST"
 Activates the spurious emissions measurement.

Characteristics: *RST value: AUTO
 SCPI: device-specific

Mode: A

[SENSe]:SWEep:MODE FAST | NORMAl | AVERaged | MANual

This command specifies the general sweep mode for the measurement. For each sub-sweep, the sweep mode provides specific values for RBW, Average and FFT settings. If the sweep mode is set to MANual, the sub-sweep settings can be specified.

Example: "SWE:MODE FAST"
 'Sets the sweep mode so that each sub-sweep is executed as fast as possible.

Characteristics: *RST value: NORM
 SCPI: device-specific

Mode: PNO

[SENSe<1|2>]:SWEep:POINts 155, 313, 625, 1251, 1999, 2501, 5001, 10001, 20001, 30001

This command defines the number of measurement points for one sweep run.

Example: "SWE:POIN 313"

Characteristics: *RST value: 625
 SCPI: conform

Mode: A

[SENSe]:SWEep:POINts?

This command returns the number of sweep points currently held in trace 1.

Example: "SWE:POIN?"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO

This command is only a query and therefore has no *RST value.

[SENSe]:SWEep:XOPTimize ON | OFF

This command specifies whether the number of cross correlations is optimized. If switched off, the number of cross correlations is defined via the [\[SENSe\]:LIST:RANGe<1...20>:SWEep:COUNT](#) command (corresponds to the parameter "Avg / XCorr" on page 4.40). If switched on, the cross correlation is not be pursued further if it does not improve the measurement result (in order to shorten the measurement time). The number of correlations is just used as a maximum value.

Example: "SWE:XOPT ON"
'The R&S FSUP tries to minimize the number of cross correlations.

Characteristics: *RST value: ON
SCPI: conform

Mode: PNO

This command is only available with the R&S FSUP-B60 option (Cross Correlation PLL measurements).

SENSe:VCO Subsystem

This subsystem controls the settings for VCO measurements.

[SENSe]:VCO:CONTRol:DELay 0 s to 10 s

This command sets the settling time for *Tuning Port 1*.

Example: "VCO:CONT:DEL 5MS"
'Sets the *Tuning Port1* settling time to 5 ms.

Characteristics: *RST value: 100 ms
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:CSEarch:SPAN 1 Hz to f_{\max}

This command sets the span for VCO measurements.

Example: "VCO:CSE:SPAN 20GHZ"
'Sets the span to 20 GHz.

Characteristics: *RST value: 40 GHz
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:CSEarch:AUTO ON | OFF

This command activates or deactivates the auto carrier search function. If activated, the value is set automatically, determined via a pre-measurement. If deactivated, the search range is defined using the [\[SENSe\]:VCO:CSEarch:SPAN](#) command.

Example: VCO:CSE:AUTO ON

Characteristics: *RST value: ON

Mode: PNO

[SENSe]:VCO:CSEarch:START 1 Hz to f_{\max}

This command sets the start frequency for VCO measurements.

Example: "VCO:CSE:STAR 1GHZ"
'Sets the start frequency to 1 GHz.

Characteristics: *RST value: 1 Hz
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:CSEarch:STOP <start frequency> to f_{\max}

This command sets the stop frequency for VCO measurements.

Example: "VCO:CSE:STOP 30GHZ"
'Sets the stop frequency to 30 GHz.

Characteristics: *RST value: 40 GHz
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:DRIFT -10 MHz/s to 10 MHz/s

This command sets the DUT drift. The DUT drift is determined automatically, if the DUT parameters are activated for the pre-measurement and the pre-measurement is initiated (see [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command). The manual setting of the DUT drift takes only effect, if the DUT parameters are deactivated for the pre-measurement.

This command is only available for Noise measurements.

Example: "VCO:DRIF 300HZ/s"
'Sets the drift to 300 Hz/s.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:FCOunter:COUPled ON | OFF

This command determines whether the *Frequency Counter Resolution* is coupled or not.

Example: "VCO:FCO:COUP OFF"
'Switches off the coupling.

Characteristics: *RST value: ON
SCPI device-specific

Mode: PNO

[SENSe]:VCO:FCOunter:RESolution 1 Hz to 10 kHz

This command sets the *Frequency Counter Resolution* for VCO measurements.

Example: "VCO:FCO:RES 10HZ"
'Sets the *Frequency Counter* resolution to 10 Hz.

Characteristics: *RST value: 1 kHz
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:LOOP:BWIDth 1 Hz to 30 kHz | ONCE

This command sets the *PLL Loop BW*. With ONCE, the bandwidth is calculated automatically. If a pre-measurement is started via the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command, the loop bandwidth is also calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:LOOP:BWID 20KHZ"
'Sets the bandwidth to 20 kHz.

"VCO:LOOP:BWID ONCE"
'Calculates the loop bandwidth.

Characteristics: *RST value: 10 kHz
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:LOOP:BWIDth:AUTO ON | OFF

This command activates or deactivates the automatic loop bandwidth calculation. If deactivated, the loop bandwidth is specified using the [\[SENSe\]:VCO:LOOP:BWIDth](#) command.

Example: "VCO:LOOP:BWID:AUTO ON"
'Automatically calculates the loop bandwidth.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:LOOP:SLOPe 1 Hz/V to 10 GHz/V

This command sets the *Generator's Slope* (=K_GEN). If a pre-measurement is started via the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command, the slope is calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements, in test setups without controlled DUT (for details refer to "[SELECT CONFIG](#)" on page 4.17).

Example: "VCO:LOOP:SLOP 5MHZ/V"
'Sets the slope to 5 MHz/V.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETEctor:HARMonic 1 to 10

This command specifies which harmonic to be used in the pre-measurement calculations. If a pre-measurement is started via the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command, the harmonic is calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:HARM 2"
'Sets the used harmonic to 2.

Characteristics: *RST value: 1
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETECTOR:HARMONIC:STATE ON | OFF

If switched on, the used harmonic is selected automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:HARM:STAT OFF"
'Sets the harmonic state to OFF.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETECTOR:LEVEL -30 dBm to 20 dBm

This command sets the *Phase Detector Level*. If [SENSe]:VCO:PDETECTOR:PREMEAS[:STATE] is on and a pre-measurement is started via the [SENSe]:VCO:PREMEAS[:STATE] command, the level is calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:LEV 10DBM"
'Sets the level to 10 dBm.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETECTOR:LPNOISE:LEVEL?

This command returns the *Phase Detector Level* measured on the low phase noise board.

This command is only available with the R&S FSUP-B60 option (Cross Correlation PLL measurements).

Example: "VCO:PDET:LPN:LEV?"
'Requests the LPN phase detector level.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is only a query and therefore has no *RST value.

[SENSe]:VCO:PDETECTOR:LPNOISE:OFFSET?

This command returns the *Phase Detector DC Offset* of the low phase noise board.

This command is only available with the R&S FSUP-B60 option (Cross Correlation PLL measurements).

Example: "VCO:PDET:LPN:OFFS?"
'Requests the LPN phase detector DC offset.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is only a query and therefore has no *RST value.

[SENSe]:VCO:PDETECTOR:LPNoise:SLOPe?

This command returns the *Phase Detector Slope* ($=K_{PD}$) of the low phase noise board.

This command is only available with the R&S FSUP-B60 option (Cross Correlation PLL measurements).

Example: "VCO:PDET:LPN:SLOP?"
'Requests the LPN phase detector slope.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

This command is only a query and therefore has no *RST value.

[SENSe]:VCO:PDETECTOR:OFFSet -1 V to 1 V

This command sets the *Phase Detector DC Offset*. If [\[SENSe\]:VCO:PDETECTOR:PREMeas\[:STATe\]](#) is on and a pre-measurement is started via the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command, the offset is calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:OFFS 0.5V"
'Sets the DC Offset to 0.5 V.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETECTOR:PREMeas[:STATe] ON | OFF

If switched on, the *Phase Detector* parameters are calculated as part of the pre-measurement sequence (initiated by the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command). If switched off, the manual setting of the *Phase Detector* parameters takes effect.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:PREM OFF"
'Sets the automatic calculation to OFF.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PDETECTOR:SLOPe 0 V/rad to 1 V/rad

This command sets the *Phase Detector Slope* (K_{PD}). If [\[SENSe\]:VCO:PDETECTOR:PREMeas\[:STATe\]](#) is on and a pre-measurement is started via the [\[SENSe\]:VCO:PREMeas\[:STATe\]](#) command, the slope is calculated automatically.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PDET:SLOP 1V/RAD"
'Sets the slope to 1 V/rad.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:POWer:DELay 0 s to 10 s

This command sets the settling time for DC port 1.

Example: "VCO:POW:DEL 10MS"
'Settling time is set to 10 ms.

Characteristics: *RST value: 100 ms
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PREMeas[:STATe] ON | OFF | ONCE

This command defines whether the DUT parameters are determined automatically in the pre-measurement, and initiates a pre-measurement sequence. For details on the pre-measurement refer to the Quick Start Guide, chapter 5.

Parameter: ONCE: A pre-measurement sequence is initiated.
ON: The DUT parameters are determined automatically in the pre-measurement.
OFF: The DUT parameters are not determined automatically and the manual setting takes effect.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:PREM ON"
'Activates the pre-measurement.
"VCO:PREM ONCE"
'Initiates the pre-measurement sequence.

Characteristics: *RST value: ON
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:PUSHing:POINts 3 to 1000

This command sets the number of points to be measured for VCO DC Characteristics measurements.

Example: "VCO:PUSH:POIN 20"
'Measurement points is set to 20.

Characteristics: *RST value: 10
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:SLOPe -10 GHz/V to 10 GHz/V

This command sets the *DUT slope* ($=K_{VCO}$).

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements, in test setups with controlled DUT (for details refer to ["SELECT CONFIG" on page 4.17](#)).

Example: "VCO:SLOP 5MHZ/V"
'Sets the slope to 5 MHz/V.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:SWEep:TIME 0 s to 10 s

This command sets the sweep time for VCO measurements.

Example: "VCO:SWE:TIME 50MS"
'Sets the tuning range to 50 ms

Characteristics: *RST value: 100 ms
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:TRACking 1 mHz/s to 1 MHz/s

Sets the value of the tracking parameter for internally tuned Phase Noise PLL and Cross Correlation PLL measurements.

Example: "VCO:TRAC 1000"
'The tracking parameter is set to 1 kHz/s.

Characteristics: *RST value: 100 kHz/s
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:TRANge -50 GHz to 50 GHz

This command sets the *DUT Tuning Range*.

This command is only available for Phase Noise PLL and Cross Correlation PLL measurements, in test setups with controlled DUT (for details refer to ["SELECT CONFIG" on page 4.17](#)).

Example: "VCO:TRAN 10MHZ"
'Sets the tuning range to 10 MHz.

Characteristics: *RST value: - (automatic calculation)
SCPI: device-specific

Mode: PNO

[SENSe]:VCO:TUNing:POINts 3 to 1000

This command sets the number of points to be measured for VCO Tuning Characteristics and the Spot Noise Tuning measurements.

Example: "VCO:TUN:POIN 20"
'Measurement points is set to 20.

Characteristics: *RST value: 10
SCPI: device-specific

Mode: PNO

SOURce Subsystem

The SOURce subsystem controls the output signals of the R&S FSUP if the option External Generator Control (R&S FSP-B10) is installed. The measurement window is selected by SOURce1 (screen A) and SOURce2 (screen B).

SOURce:CURRent:POWer<1|2>:LIMit:HIGH 0 to 500 mA

This command specifies the maximum current for the specified DC power supply port.

Example: "SOUR:CURR:POW1:LIM:HIGH 20MA"
'Sets the maximum current of DC power supply port 1 to 20 mA.

Characteristics: *RST value: 50 mA
SCPI: device-specific

Mode: PNO, A

SOURce:CURRent:CONTRol<1|2>:LIMit:HIGH 0 to 20 mA

This command specifies the maximum current for the specified tuning port. In analyzer mode, the numeric suffix of CONTRol is irrelevant.

Example: "SOUR:CURR:CONT1:LIM:HIGH 20MA"
'Sets the maximum current of tuning port 1 to 20 mA.

Characteristics: *RST value: 10 mA
SCPI: device-specific

Mode: PNO, A

SOURce:CURRent:AUX:LIMit:HIGH -500 mA to 0 mA

This command specifies the maximum current for the AUX port, the value has to be negative.

Example: "SOUR:CURR:AUX:LIM:HIGH -20MA"
'Sets the max current of the AUX port to -20 mA.

Characteristics: *RST value: -50 mA
SCPI: device-specific

Mode: PNO, A

SOURce:CURRent:SEQUence:RESult?

This command returns a list of measured currents from ports in the following format:
DC port 1 current, DC port 2 current, Tuning port 1 current, Tuning port 2 current, AUX port current.

Example: "SOUR:CURR:SEQ:RES?"
'Returns the measured current at each port.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

SOURce:POWER:SEQuence:RESult?

This command returns a list of measured powers from ports in the following format:
DC port 1 power, tuning port 1 power, AUX port power.

Example: "SOUR:POW:SEQ:RES?"
'Returns the measured power at each port

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

This command is only a query and therefore has no *RST value.

SOURce:VOLTage[:STATe] ON | OFF

This command enables/disables the DC power.

Example: "SOUR:VOLT ON"
'Enables the DC power.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:AUX:LEVel[:STATe] ON | OFF

This command enables/disables the AUX port.

Example: "SOUR:VOLT:AUX:LEV ON"
'Enables the AUX port.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:AUX:LEVel:AMPLitude -10 V to 0 V

This command specifies the required voltage for the AUX port, the value has to be negative.

Example: "SOUR:VOLT:AUX:LEV:AMPL -1V"
'Sets the voltage of AUX to 1V.

Characteristics: *RST value: -5 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:CONTRol<1|2>:LEVel[:STATe] ON | OFF

This command enables/disables the specified tuning port. In analyzer mode, the numeric suffix of CONTRol is irrelevant.

Example: "SOUR:VOLT:CONT1:LEV OFF"
'Disables tuning port 1.

Characteristics: *RST value: ON for port 1, OFF for port 2
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:CONTRol<1|2>:LEVel:AMPLitude <numeric_value>

This command specifies the required voltage for the specified tuning port. In analyzer mode, the numeric suffix of CONTRol is irrelevant. The specified voltage has to range within the limits set by the [SOURce:VOLTage:CONTRol<1|2>:LEVel:LIMit:LOW](#) and [SOURce:VOLTage:CONTRol<1|2>:LEVel:LIMit:HIGH](#) commands.

Example: "SOUR:VOLT:CONT1:LEV:AMPL 2V"
'Sets the voltage of tuning port 1 to 2V.

Characteristics: *RST value: 2.5 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:CONTRol<1|2>:LEVel:LIMit:HIGH -9.5 V to 28 V

This command specifies the maximum voltage for the specified tuning port. In analyzer mode, the numeric suffix of CONTRol is irrelevant.

Example: "SOUR:VOLT:CONT1:LEV:LIM:HIGH 4V"
'Sets the maximum voltage of tuning port 1 to 4V.

Characteristics: *RST value: 5 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:CONTRol<1|2>:LEVel:LIMit:LOW -10 V to 27.5 V

This command specifies the minimum voltage for the specified tuning port. In analyzer mode, the numeric suffix of CONTRol is irrelevant.

Example: "SOUR:VOLT:CONT1:LEV:LIM:LOW 1V"
'Sets the minimum voltage tuning port 1 to 1V.

Characteristics: *RST value: 0.5 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:CONTRol<1|2>:AFC[:STATe]

This command enables/disables the automatic frequency control (AFC). If AFC is enabled, the R&S FSUP tries to set the target frequency by tuning the DUT in compliance with the AFC settings specified via the following commands: [SOURce:VOLTage:CONTRol<1|2>:AFC:TARGet](#), [SOURce:VOLTage:CONTRol<1|2>:AFC:ITERations](#), [SOURce:VOLTage:CONTRol<1|2>:AFC:TOLerance](#).

The numeric suffix of CONTRol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC ON"
'Enables AFC.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:CONTRol<1|2>:AFC:TARGet

This command specifies the target frequency for automatic frequency control. The numeric suffix of CONTRol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC:TARG 200MHZ"
'Sets the target frequency to 200MHz

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:CONTrol<1|2>:AFC:ITERations

This command specifies the maximum number of iterations for automatic frequency control. The numeric suffix of CONTrol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC:ITER 20"
'Sets the maximum number of iterations to 20

Characteristics: *RST value: 10
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:CONTrol<1|2>:AFC:TOLerance

This command specifies the tolerance on the target frequency for automatic frequency control. The numeric suffix of CONTrol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC:TOL 2KHZ"
'Sets the tolerance to 2KHz

Characteristics: *RST value: 1KHz
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:CONTrol<1|2>:AFC:LIMit:HIGH

This command specifies the maximum voltage for the specified tuning port. The numeric suffix of CONTrol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC:LIMit:HIGH 4V"
'Sets the maximum voltage of tuning port 1 to 4V

Characteristics: *RST value: 5 V
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:CONTrol<1|2>:AFC:LIMit:LOW

This command specifies the minimum voltage for the specified tuning port. The numeric suffix of CONTrol is irrelevant, this command applies only available to tuning port 1.

Example: "SOUR:VOLT:CONT1:AFC:LIMit:LOW 1V"
'Sets the minimum voltage tuning port 1 to 1V

Characteristics: *RST value: 0.5 V
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:SEQuence[:STATe] ON | OFF

This command enables or disables the switching sequence. This command returns an error if no sequence has been defined, or if the sequence is invalid.

Example: "SOUR:VOLT:SEQ ON"
'Enables the switching sequence.'

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:SEQuence:LIST <port>,<delay>,...

This command specifies the switching sequence. The sequence is specified in the following format:
<port>,<delay>,<port>,<delay>, ...

Each enabled port must appear in the specified sequence once and once only, otherwise this command returns an error.

Parameter: port

VCC1	DC port 1
VCC2	DC port 2
VTUNE1	tuning port 1
VTUNE2	tuning port 2
VAUX	AUX port

delay: 0 to 1 s; time to wait after associated port has been switched on.

Example: "SOUR:VOLT:SEQ:LIST VCC1,1,VCC2,1,VTUNE1,1,VTUNE2,1,VAUX,1"
'Sets a switching sequence with a 1 second delay between each port being switched.'

Characteristics: *RST value: VCC1,0.01,VTUNE1,0.01,VAUX,0.01,VCC2,0.01,VTUNE2,0.01
SCPI: device-specific

Mode: PNO

SOURce:VOLTage:SEQuence:RESult?

This command returns a list of measured voltages from ports in the following format:
DC port 1 voltage, DC port 2 voltage, tuning port 1 voltage, tuning port 2 voltage, AUX port voltage.

Example: "SOUR:VOLT:SEQ:RES?"
'Returns the measured voltage at each port.'

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

This command is only a query and therefore has no *RST value.

SOURce:VOLTage:POWer<1|2>:LEVel[:STATe] ON | OFF

This command enables/disables the specified DC power supply port.

Example: "SOUR:VOLT:POW1:LEV OFF"
'Disables DC power supply port 1.'

Characteristics: *RST value: ON for port 1, OFF for port 2
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:POWer<1|2>:LEVel:AMPLitude <numeric_value>

This command specifies the required voltage for the specified DC power supply port. The specified voltage has to range within the limits set by the [SOURce:VOLTage:POWer<1|2>:LEVel:LIMit:LOW](#) and [SOURce:VOLTage:POWer<1|2>:LEVel:LIMit:HIGH](#) commands.

Example: "SOUR:VOLT:POW1:LEV:AMPL 5.2V"
'Sets the voltage of DC power supply port 1 to 5.2 V.

Characteristics: *RST value: 5 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:POWer<1|2>:LEVel:LIMit:HIGH 0 V to 12.25 V

This command specifies the maximum voltage for the specified DC power supply port.

Example: "SOUR:VOLT:POW1:LEV:LIM:HIGH 6V"
'Sets the maximum voltage of DC power supply port 1 to 6V.

Characteristics: *RST value: 5.25 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:POWer<1|2>:LEVel:LIMit:LOW 0 V to 12.25 V

This command specifies the minimum voltage for the specified DC power supply port.

Example: "SOUR:VOLT:POW1:LEV:LIM:LOW 4V"
'Sets the minimum voltage of DC power supply port 1 to 4V.

Characteristics: *RST value: 4.75 V
SCPI: device-specific

Mode: PNO, A

SOURce:VOLTage:POWer<1|2>:PUSHing 0 V to V_{max}

This command specifies the pushing value for the VCO Tuning measurements. The numeric suffix of POWER must be 1 (DC port 1 pushing). The value for the maximum voltage (V_{max}) depends on the specified required voltage, the maximum and minimum voltage.

Example: "SOUR:VOLT:POW1:PUSH 200MV"
'Sets the pushing voltage of DC power supply port 1 to 200 mV.

Characteristics: *RST value: 50 mV
SCPI: device-specific

Mode: PNO

SOURce:EXtErnal Subsystem

The SOURce:EXtErnal subsystem controls the operation of the unit with option Ext. Generator Control (B10). The commands are only valid for the selected window, with SOURce1 changing the setting in screen A and SOURce2 the setting in screen B.

The selection of the external generator 1 or 2 is via EXtErnal<1|2>.



Note

The commands of the SOURce:EXtErnal subsystem assume that the addressed generator was correctly configured with the commands of subsystem SYSTem: COMMunicate: GPIB: RDEVice: GENerator.

If no external generator is selected, if the GPIB address is not correct or the generator is not ready for operation, an execution error will be generated.

SOURce<1|2>:EXtErnal<1|2>[:STATe] ON | OFF

This command activates or deactivates the external generator selected with SOUR:EXT<1|2>:FREQ:SWE ON in the selected window.

The suffix behind EXtErnal is irrelevant for this command.

This command is only available in connection with option Ext. Generator Control B10.

Example:

```
"SYST:COMM:RDEV:GEN1:TYPE 'SMP02'"
'Selects SMP02 as generator 1.

"SYST:COMM:RDEV:GEN1:LINK TTL"
'Selects GPIB + TTL link as interface.

"SYST:COMM:RDEV:GEN1:ADDR 28"
'Sets the generator address to 28.

"SOUR:EXT1:FREQ:SWE ON"
'Activates the frequency sweep for generator 1.

"SOUR:EXT ON"
'Activates the external generator
```

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:FREQUENCY[:FACTor]:DENominator <numeric_value>

This command defines the denominator of the factor with which the analyzer frequency is multiplied in order to obtain the transmit frequency of the selected generator 1 or 2 in the selected window.



Note

Select the multiplication factor in a way that the frequency range of the generator is not exceeded by the following formula:

$$F_{\text{Generator}} = \left| F_{\text{Analyzer}} \cdot \frac{\text{Numerator}}{\text{Denominator}} + F_{\text{Offset}} \right|$$

if applied to the start and stop frequency of the analyzer.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT:FREQ:NUM 4"
 "SOUR:EXT:FREQ:DEN 3"
 'Sets a multiplication factor of 4/3, i.e. the transmit frequency of the generator is 4/3 times the analyzer frequency.

Characteristics: *RST value: 1
 SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:FREQUENCY[:FACTor]:NUMerator <numeric_value>

This command defines the numerator of the factor with which the analyzer frequency is multiplied to obtain the transmit frequency of the selected generator 1 or 2 in the selected window.



Note

Select the multiplication factor in a way that the frequency range of the generator is not exceeded by the following formula:

$$F_{\text{Generator}} = \left| F_{\text{Analyzer}} \cdot \frac{\text{Numerator}}{\text{Denominator}} + F_{\text{Offset}} \right|$$

if applied to the start and stop frequency of the analyzer.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT:FREQ:NUM 4"
 "SOUR:EXT:FREQ:DEN 3"
 'Sets a multiplication factor of 4/3, i.e. the transmit frequency of the generator is 4/3 times the analyzer frequency.

Characteristics: *RST value: 1
 SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:FREQUENCY:OFFSet <numeric_value>

This command defines the frequency offset of the selected generator 1 or 2 with reference to the receive frequency in the selected window.

**Note**

Select the multiplication factor in a way that the frequency range of the generator is not exceeded by the following formula:

$$F_{\text{Generator}} = F_{\text{Analyzer}} * \text{Numerator/Denominator} + F_{\text{Offset}}$$

if applied to the start and stop frequency of the analyzer.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT:FREQ:OFFS 1GHZ"
'Sets a frequency offset of the generator transmit frequency compared to the analyzer receive frequency of 1 GHz.

Characteristics: *RST value: 0 Hz
SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:FREQUENCY:SWEep[:STATe] ON | OFF

This command activates or deactivates the frequency sweep for generator 1 or 2 in the selected window.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT1:FREQ:SWE ON"
'Activates the frequency sweep for ext. generator 1.

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:POWER[:LEVel] <numeric_value>

This command sets the output power of the selected generator 1 or 2 in the selected window.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT:POW -30dBm"
'Sets the generator level to -30 dBm

Characteristics: *RST value: -20 dBm
SCPI: device-specific

Mode: A

SOURce<1|2>:EXTernal<1|2>:ROSCillator[:SOURce] INTernal | EXTernal

This command switches between external and internal reference oscillator for the frequency processing of external generator 1 and 2.

The command always works on both generators. Therefore, the numeric suffix in EXTernal<1|2> is not significant.

This command is only valid in combination with option Ext. Generator Control R&S FSP-B10.

Example: "SOUR:EXT:ROSC EXT"
 'switches to external reference oscillator

Characteristics: *RST value: INT
 SCPI: device-specific

Mode: A

STATus Subsystem

The STATus subsystem contains the commands for the status reporting system (see chapter “Remote Control – Basics”, section “Status Reporting System” on page 5.20). *RST does not influence the status registers.

STATus:OPERation[:EVENT]?

This command queries the contents of the EVENT section of the STATus:OPERation register. The contents of the EVENT section are deleted after readout.

Example: "STAT:OPER?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:OPERation:CONDition?

This command queries the CONDition section of the STATus:OPERation register. Readout does not delete the contents of the CONDition section. The value returned reflects the current hardware status.

Example: "STAT:OPER:COND?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:OPERation:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:OPERation register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit in the status byte.

Example: "STAT:OPER:ENAB 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:OPERation:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:OPER:PTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:OPERation:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:OPERation register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:OPER:NTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:PRESet

This command resets the edge detectors and ENABLE parts of all registers to a defined value. All PTRansition parts are set to FFFFh, i.e. all transitions from 0 to 1 are detected. All NTRansition parts are set to 0, i.e. a transition from 1 to 0 in a CONDition bit is not detected. The ENABLE part of the STATus:OPERation and STATus:QUEStionable registers are set to 0, i.e. all events in these registers are not passed on.

Example: "STAT:PRES"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable register. The contents of the EVENT section are deleted after the readout.

Example: "STAT:QUES?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable:CONDition?

This command queries the CONDition section of the STATus:QUEStionable register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:COND?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus-QUEStionable register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit in the status byte.

Example: "STAT:QUES:ENAB 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:PTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:NTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: A

STATus:QUEStionable:POWer[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:POWer register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:POW?"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

STATus:QUEStionable:POWer:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:POWer register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:POW:COND?"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

STATus:QUEStionable:POWer:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:POWer register. The ENABle register selectively enables the individual events of the associated EVENt section for the summary bit.

Example: "STAT:QUES:POW:ENAB 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

STATus:QUEStionable:POWer:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:POWer register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:POW:PTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

STATus:QUEStionable:POWer:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:POWer register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:POW:NTR 65535"

Characteristics: *RST value: –
SCPI: conform

Mode: PNO, A

STATus:QUEStionable:LIMit<1|2> [:EVENt]?

This command queries the contents of the EVENt section of the STATus:QUEStionable:LIMit register. Readout deletes the contents of the EVENt section.

Example: "STAT:QUES:LIM?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LIMit<1|2>:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:LIMit register.

Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:LIM:COND?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LIMit<1|2>:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:LIMit register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:LIM:ENAB 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LIMit<1|2>:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LIMit register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:LIM:PTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LIMit<1|2>:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LIMit register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:LIM:NTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LMARgin<1|2> [:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:LMARgin register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:LMAR?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:LMARgin<1|2>:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:LMARgin register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:LMAR:COND?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:LMARgin<1|2>:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:LMARgin register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:LMAR:ENAB 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:LMARgin<1|2>:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LMARgin register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:LMAR:PTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:LMARgin<1|2>:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:LMARgin register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:LMAR:NTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:PNOise[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:PNOise register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:PNO?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

STATus:QUEStionable:PNOise:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:PNOise register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:PNO:COND?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

STATus:QUEStionable:PNOise:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:PNOise register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:PNO:ENAB 65535"
'All events bits are represented in the PNOise summary bit.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

STATus:QUEStionable:PNOise:PTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:PNOise Condition register will set the corresponding bit in the STATus:QUEStionable:PNOise Event register when that bit has a positive transition (0 to 1).The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:PNO:PTR 65535"
'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

STATus:QUEStionable:PNOise:NTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:PNOise Condition will set the corresponding bit in the STATus:QUEStionable:PNOise Event register when that bit has a negative transition (1 to 0).The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:PNO:NTR 65535"
'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO

STATus:QUEStionable:DCPNoise[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:DCPNoise register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:DCPN?"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:DCPNoise:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:DCPNoise register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:DCPN:COND?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:DCPNoise:ENABLE 0 to 65535

This command sets the bits of the ENABLE section of the STATus:QUEStionable:DCPNoise register. The ENABLE register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:DCPN:ENAB 65535"
'All events bits are represented in the PNOise summary bit.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:DCPNoise:PTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:DCPNoise Condition register will set the corresponding bit in the STATus:QUEStionable:DCPNoise Event register when that bit has a positive transition (0 to 1).The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:DCPN:PTR 65535"
'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:DCPNoise:NTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:DCPNoise Condition will set the corresponding bit in the STATus:QUEStionable:DCPNoise Event register when that bit has a negative transition (1 to 0).The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:DCPN:NTR 65535"
'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LPNoise[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:LPNoise register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:LPN?"

Characteristics: *RST value: --
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LPNoise:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:LPNoise register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:LPN:COND?"

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LPNoise:ENABLE 0 to 65535

This command sets the bits of the ENABLE section of the STATus:QUEStionable:LPNoise register. The ENABLE register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:LPN:ENAB 65535"
'All events bits are represented in the PNOise summary bit.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LPNoise:PTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:LPNoise Condition register will set the corresponding bit in the STATus:QUEStionable:LPNoise Event register when that bit has a positive transition (0 to 1). The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:LPN:PTR 65535"
'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:LPNoise:NTRansition 0 to 65535

This command determines what bits in the STATus:QUEStionable:LPNoise Condition will set the corresponding bit in the STATus:QUEStionable:LPNoise Event register when that bit has a negative transition (1 to 0). The variable <number> is the sum of the decimal values of the bits that are to be enabled.

Example: "STAT:QUES:LPN:NTR 65535"
 'All condition bits are summarized in the Event register when a positive transition occurs.

Characteristics: *RST value: -
 SCPI: device-specific

Mode: PNO, A

STATus:QUEStionable:SYNC[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:SYNC register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:SYNC?"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

STATus:QUEStionable:SYNC:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:SYNC register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:SYNC:COND?"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

STATus:QUEStionable:SYNC:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:SYNC register. The ENABle register selectively enables the individual events of the associated EVENT section for the sum bit in the status byte.

Example: "STAT:QUES:SYNC:ENAB 65535"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

STATus:QUEStionable:SYNC:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:SYNC register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:SYNC:PTR 65535"

Characteristics: *RST value: -
 SCPI: device-specific

Mode: A

STATus:QUEStionable:SYNC:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:SYNC register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:SYNC:NTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:ACPLimit[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:ACPLimit register. Readout deletes the contents of the EVENT section.

Example: "STAT:QUES:ACPL?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:ACPLimit:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:ACPLimit register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:ACPL:COND?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:ACPLimit:ENABLE 0 to 65535

This command sets the bits of the ENABLE section of the STATus:QUEStionable:ACPLimit register. The ENABLE register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:ACPL:ENAB 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:ACPLimit:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:ACPLimit register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:ACPL:PTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:ACPLimit:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:ACPLimit register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:ACPL:NTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:FREQuency[:EVENT]?

This command queries the contents of the EVENT section of the STATus:QUEStionable:FREQuency register.

Example: "STAT:QUES:FREQ?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

Readout deletes the contents of the EVENT section.

STATus:QUEStionable:FREQuency:CONDition?

This command queries the contents of the CONDition section of the STATus:QUEStionable:FREQuency register. Readout does not delete the contents of the CONDition section.

Example: "STAT:QUES:FREQ:COND?"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:FREQuency:ENABle 0 to 65535

This command sets the bits of the ENABle section of the STATus:QUEStionable:FREQuency register. The ENABle register selectively enables the individual events of the associated EVENT section for the summary bit.

Example: "STAT:QUES:FREQ:ENAB 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:FREQuency:PTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:FREQuency register from 0 to 1 for the transitions of the CONDition bit.

Example: "STAT:QUES:FREQ:PTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEStionable:FREQuency:NTRansition 0 to 65535

This command sets the edge detectors of all bits of the STATus:QUEStionable:FREQuency register from 1 to 0 for the transitions of the CONDition bit.

Example: "STAT:QUES:FREQ:NTR 65535"

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

STATus:QUEue[:NEXT]?

This command returns the earliest entry to the error queue and deletes it.

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI (cf. chapter "Error Messages"). If the error queue is empty, the error number 0, "no error", is returned. This command is identical with the command `SYSTEM:ERROR`.

Example: "STAT:QUE?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

SYSTEM Subsystem

This subsystem contains a series of commands for general functions.

SYSTEM:COMMunicate:GPIB[:SELF]:ADDRESS 0 to 30

This command changes the GPIB address of the unit.

Example: "SYST:COMM:GPIB:ADDR 18"

Characteristics: *RST value: - (no influence on this parameter, factory default 20)
SCPI: conform

Mode: PNO, A

SYSTEM:COMMunicate:GPIB[:SELF]:RTERminator LFEOI | EOI

This command changes the GPIB receive terminator.

According to the standard the terminator in ASCII is <LF> and/or <EOI>. For binary data transfers (e.g. trace data) from the control computer to the instrument, the binary code (0AH) used for <LF> might be included in the binary data block, and therefore should not be interpreted as a terminator in this particular case. This can be avoided by changing the receive terminator to EOI.

Output of binary data from the instrument to the control computer does not require such a terminator change.

Example: "SYST:COMM:GPIB:RTER EOI"

Characteristics: *RST value: -- (no influence on this parameter, factory default LFEOI)
SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:GPIB:RDEvice:GENerator<1|2>:ADDRESS 0 to 30

This command changes the GPIB address of the device selected as external generator 1 or 2.



Note

If two generators are connected at the same time to IECBUS 2 their addresses must be different.

The command is only available with option Ext. Generator Control, R&S FSP-B10.

Example: "SYST:COMM:GPIB:RDEV:GEN1:ADDR 19"
' Changes the GPIB address of generator 1 to 19

Characteristics: *RST value: 28
SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:GPIB:RDEvice:COMMand 0...30,<'command string'>

This command sends a command or query string to the external generator connected via the GPIB interface of the Ext. Generator Control, R&S FSP-B10.

**Note**

Only basic I/O is possible.

The command is only available with option Ext. Generator Control, R&S FSP-B10.

Parameter: 0...30: GPIB address of the external generator connected via the GPIB interface of the Ext. Generator Control, R&S FSP-B10. In the following example, the GPIB address is 18.

Example:

```
"SYST:COMM:GPIB:RDEF:COMM 18, '*RST'"
'Resets generator.
```

```
"SYST:COMM:GPIB:RDEF:COMM 18, 'SOURCE:FREQ:CW 2E9'"
'Sets generator frequency to 2 GHz.
```

```
"SYST:COMM:GPIB:RDEF:COMM 18, 'SOUR:POW 0'"
'Sets generator power to 0dBm.
```

```
"SYST:COMM:GPIB:RDEF:COMM? 18, 'SENS:POW?'"
'Queries the generator power.
```

Characteristics: *RST value: -
SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:RDEvice:GENerator<1|2>:LINK GPIB | TTL

This command selects the interface type of the external generator 1 or 2.
The following types are available

- GPIB alone (= GPIB, for all the generators of other manufacturers and some Rohde & Schwarz units)
- GPIB and TTL interface for synchronization (= TTL, for most of the Rohde & Schwarz generators, see table in command `SYSTEM:COMMunicate:RDEvice:GENerator:TYPE`).

The difference between the two operating modes is the execution speed. While, during GPIB operation, each settable frequency is transmitted separately to the generator, a whole frequency list can be programmed in one go if the TTL interface is also used. Frequency switching can then be performed per TTL handshake which results in considerable speed advantages.

**Note**

Only one of the two generators can be operated via the TTL interface at a time. The other generator must be configured for GPIB.

The command is only available with option Ext. Generator Control, R&S FSP-B10.

Example: "SYST:COMM:RDEV:GEN:LINK TTL"
 'Selects GPIB + TTL interface for generator operation

Characteristics: *RST value: GPIB
 SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:RDEvice:GENerator<1|2>:TYPE <name>

This command selects the type of external generator 1 or 2. For a list of the available generator types including the associated interface, see chapter "External Generator Control – Option R&S FSP-B10", section "List of Generator Types Supported by the R&S FSUP" on page 4.292.



Notes

- Generators with TTL interface can also be operated via GPIB alone.
- With NONE selected, the corresponding generator 1 or 2 is deactivated.
- The command is only available with option Ext. Generator Control, R&S FSP-B10.

Example: "SYST:COMM:RDEV:GEN2:TYPE 'SME02'"
 'Selects SME02 as generator 2.

Characteristics: *RST value: NONE
 SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:SERial:CONTrol:DTR IBFull | OFF

SYSTEM:COMMunicate:SERial:CONTrol:RTS IBFull | OFF

These commands switch the hardware handshake procedure for the serial interface off (OFF) or on (IBFull).

The two commands are equivalent.

Example: "SYST:COMM:SER:CONT:DTR OFF"
 "SYST:COMM:SER:CONT:RTS IBF"

Characteristics: *RST value: -- (no influence on this parameter, factory default OFF)
 SCPI: conform

Mode: A

SYSTEM:COMMunicate:SERial[:RECEive]:BAUD 110 | 300 | 600 | 1200 | 2400 | 9600 | 19200

This command sets the transmission speed for the serial interface (COM).

Example: "SYST:COMM:SER:BAUD 2400"

Characteristics: *RST value: -- (no influence on this parameter, factory default 9600)
 SCPI: conform

Mode: A

SYSTEM:COMMunicate:SERial[:RECeive]:BITS 7 | 8

This command defines the number of data bits per data word for the serial interface (COM).

Example: "SYST:COMM:SER:BITS 7"

Characteristics: *RST value: -- (no influence on this parameter, factory default 8)
SCPI: conform

Mode: A

SYSTEM:COMMunicate:SERial[:RECeive]:PARity[:TYPE] EVEN | ODD | NONE

This command defines the parity check for the serial interface (COM).

Parameter: EVEN: even parity
ODD: odd parity
NONE: no parity check.

Example: "SYST:COMM:SER:PAR EVEN"

Characteristics: *RST value: -- (no influence on this parameter, factory default NONE)
SCPI: conform

Mode: A

SYSTEM:COMMunicate:SERial[:RECeive]:SBITS 1|2

This command defines the number of stop bits per data word for the serial interface (COM).

Example: "SYST:COMM:SER:SBITS 2"

Characteristics: *RST value: -- (no influence on this parameter, factory default 1)
SCPI: conform

Mode: A

SYSTEM:COMMunicate:SERial[:RECeive]:PACE XON | NONE

This command switches on or off the software handshake for the serial interface.

Example: "SYST:COMM:SER:PACE XON"

Characteristics: *RST value: -- (no influence on this parameter, factory default NONE)
SCPI: conform

Mode: A

SYSTEM:COMMunicate:PRINter:ENUMerate:FIRSt?

This command queries the name of the first printer (in the list of printers) available under Windows NT.

The names of other installed printers can be queried with command `SYSTEM:COMMunicate:PRINter:ENUMerate:NEXT?`.

If no printer is configured an empty string is output.

Example: "SYST:COMM:PRIN:ENUM:FIRS?"

Characteristics: *RST value: NONE
SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:PRINter:ENUMerate:NEXT?

This command queries the name of the next printer installed under Windows NT.

The command `SYSTEM:COMMunicate:PRINter:ENUMerate:FIRSt?` should be sent previously to return to the beginning of the printer list and query the name of the first printer.

The names of other printers can then be queried with `NEXT?`. After all available printer names have been output, an empty string enclosed by quotation marks ("") is output for the next query. Further queries are answered by a Query Error.

Example: `"SYST:COMM:PRIN:ENUM:NEXT?"`

Characteristics: *RST value: NONE
 SCPI: device-specific

Mode: A

SYSTEM:COMMunicate:PRINter:SElect <1|2> <printer_name>

This command selects one of the printers configured under Windows NT including the associated output destination.

The specified printer name must be a string as returned by the commands

`SYSTEM:COMMunicate:PRINter:ENUMerate:FIRSt?` or
`SYSTEM:COMMunicate:PRINter:ENUMerate:NEXT?`



Note

Command `HCOPY:DESTination` is used to select an output medium other than the default one.

Example: `"SYST:COMM:PRIN:SEL 'LASER on LPT1'"`

Characteristics: *RST value: NONE
 SCPI: device-specific

Mode: A

SYSTEM:DATE 1980 to 2099, 1 to 12, 1 to 31

This command is used to enter the date for the internal calendar.

The sequence of entry is year, month, day.

Example: `"SYST:DATE 2000,6,1"`

Characteristics: *RST value: –
 SCPI: conform

Mode: A

SYSTEM:DISPlay:FPANel ON | OFF

This command activates or deactivates the display of the front panel keys on the screen.

With the display activated, the instrument can be operated on the screen using the mouse by pressing the corresponding buttons. This may be useful if the instrument is operated in a detached station by means of a remote program such as PCANYWHERE.

**Notes**

With the display of the front panel keys activated, the screen resolution of the unit is set to 1024x768. Thus, only a section of the whole screen is visible on the internal LCD display, which will be moved by mouse moves.

For a full display of the user interface, an external monitor has to be connected to the rear panel.

When the front panel display is deactivated, the original screen resolution is restored.

Example: "SYST:DISP:FPAN ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

SYSTEM:DISPlay:UPDate ON | OFF

This command switches on or off the update of all display elements during remote control.

**Note**

The best performance is obtained when the display output is switched off during remote control.

Example: "SYST:DISP:UPD ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

SYSTEM:ERRor?

This command queries the earliest entry in the error queue, and deletes it after the readout.

Positive error numbers indicate device-specific errors, negative error numbers are error messages defined by SCPI (cf. chapter “Error Messages”). If the error queue is empty, the error number 0, "no error", is returned. This command is identical with the command `STATUS:QUEUE:NEXT?`.

This command is a query and therefore has no *RST value.

Example: `"SYST:ERR?"`

Characteristics: *RST value: –
SCPI: conform

Mode: A

SYSTEM:ERRor:LIST?

This command reads all system messages and returns a list of comma separated strings. Each string corresponds to an entry in the table SYSTEM MESSAGES.

If the error list is empty, an empty string "" will be returned.

This command is a query and therefore has no *RST value.

Example: `"SYST:ERR:LIST?"`

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

SYSTEM:ERRor:CLEar:ALL

This command deletes all entries in the table SYSTEM MESSAGES.

This command is an event and therefore has no query and no *RST value.

Example: `"SYST:ERR:CLE:ALL?"`

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

SYSTEM:FIRMware:UPDate <path>

This command starts a firmware update using the data set in the selected directory. Beforehand, the update files have to be stored in the following subdirectories using command `MMEM:DATA:`

Directory	Contents
DISK1	disk1.bin
DISK2	data3.cab
DISK3	data4.cab
.....
DISK<n>	data<n+1>.cab

Example: "SYST:FIRM:UPD 'D:\USER\FWUPDATE'"
 'Starts the firmware update from directory D:\USER\FWUPDATE using the files of subdirectories DISK1 to DISK11

Characteristics: *RST value: –
 SCPI: device-specific

Mode: A

This command is an 'event' and therefore has no query and no *RST value.

SYSTEM:IFGain:MODE NORMAl | PULSe

This command switches the 10 dB overload reserve on or off.

This command can only be selected in the HP emulation mode.

Parameter: NORM: switches the overload reserve off
 PULSe: switches the overload reserve on

Example: "SYST:LANG '8566B'"
 'Switches the HP emulation on
 "SYST:IFG:MODE PULS"
 'Switches the overload reserve on

Characteristics: *RST value: –
 SCPI: device-specific

Mode: A

SYSTEM:LANGUage 'SCPI' | '71100C' | '71200C' | '71209A' | '8560E' | '8561E' | '8562E' | '8563E' | '8564E' | '8565E' | '8566A' | '8566B' | '8568A' | '8568B' | '8591E' | '8594E'

This command activates the emulation of various analyzers. The analyzer default command set is SCPI.

The following remote-control languages are available:

SCPI, 71100C, 71200C, 71209A, 8560E, 8561E, 8562E, 8563E, 8564E, 8565E, 8566A, 8566B, 8568A, 8568B, 8591E, 8594E



Note

- When SCPI is selected, the 8566B/8568B/8594E command set is available in addition.
- When 8566A, 8566B, 8568A or 8568B is selected, both command sets A and B are available, as far as they are supported.
- The HP model 8591E is compatible to HP model 8594E, the HP models 71100C, 71200C, and 71209A are compatible to HP models 8566A/B.

The settings or changes made on switching between remote-control languages are described in the Quick Start Guide, chapter 2.



Notes regarding switch over to 8566A/B and 8568A/B:

Commands IP and KST, too, will perform the settings for the "# of Trace Points", "Start Freq.", "Stop Freq." and "Input Coupling".

Switch over of the "# of Trace Points" will not take place until the instrument is switched to the remote control mode. For manual operation (selected with LOCAL softkey), the number of sweep points (trace points) will always be set to 1251.

In the remote control mode, the screen area for the measurement will be reduced. The LOCAL softkey (lowermost softkey) will be shifted slightly towards the center of the screen.

Example: "SYST:LANG 'SCPI'"

Characteristics: *RST value: 'SCPI'
SCPI: conform

Mode: A

There is no query for this command.

SYSTem:PASSword[:CENable] 'password'

This command enables access to the service functions by means of the password.

Example: "SYST:PASS 'XXXX'"

Characteristics: *RST value: –
SCPI: conform

Mode: A

This command is an event and therefore has no *RST value and no query.

SYSTem:PRESet

This command initiates an instrument reset.

The effect of this command corresponds to that of the *PRESET* key with manual operation or to the *RST command.

Example: "SYST:PRES"

Characteristics: *RST value: –
SCPI: conform

Mode: A

SYSTem:PRESet:COMPAtible OFF | SANalyzer

This command specifies the preset compatibility.

Parameter: OFF: phase noise mode is set as preset mode.
SANalyzer: Spectrum analyzer mode is set as preset mode.

Example: "SYST:PRES:COMP OFF"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: PNO, A

SYSTem:SPEaker:VOLume 0 to 1

This command sets the volume of the built-in loudspeaker for demodulated signals. Minimum volume is set by 0 and maximum volume by 1.

The value 0 is the lowest volume, the value 1 the highest volume.

Example: "SYST:SPE:VOL 0.5"

Characteristics: *RST value: 0
SCPI: device-specific

Mode: A

SYSTem:TIME 0 to 23, 0 to 59, 0 to 59

This command sets the internal clock. The sequence of entry is hour, minute, second.

Example: "SYST:TIME 12,30,30"

Characteristics: *RST value: –
SCPI: conform

Mode: A

SYSTem:VERSion?

This command queries the number of the SCPI version, which is relevant for the instrument.

Example: "SYST:VERS?"

Characteristics: *RST value: –
SCPI: conform

Mode: A

This command is a query and therefore has no *RST value.

SYSTem:IDENtify:FACTory

This command resets the *IDN string to the factory default.

Return value: "1" for the factory default state
"0" for a changed *IDN string

Example: "SYST:IDEN:FACT"
'Sets the ID string to the factory default.

Characteristics: *RST value: –
SCPI: device-specific

Mode: A

SYSTEM:MSIZE? MBoard

This command outputs the memory size of the mainboard.

Parameter:

MBoard Mainboard

Example:

"`SYST:MSIZ? MBO`"

Outputs the memory size of the mainboard.

Characteristics:

*RST value: --

SCPI: device-specific

Mode:

A

TRACe Subsystem

The TRACe subsystem controls access to the instrument's internal trace memory.

General Trace Commands

TRACe<1|2>[:DATA] TRACE1 | TRACE2 | TRACE3 | TRACE4 | TRACE5 | TRACE6 | TRACE7 | TRACE8 | SPURious | <numeric_value>

This command transfers trace data from the control computer to the instrument, the query reads trace data out of the instrument.

In analyzer mode, the numeric suffix at TRACe<1|2> selects the measurement window. In phase noise mode, the numeric suffix at TRACe<1|2> is irrelevant. In phase noise mode, this command is a query only.



Note

If the FM demodulator is active in the analyzer mode, only the displayed trace data is read out and recalled. A portion of the measurement data that can be called by means of a marker, however, is calculated from the raw measurement data. These results are no longer available after recalling a trace; the associated queries generate a query error.

Parameter:	For information on the LIST parameter, see the TRACe<1 2>:DATA? command. Analyzer mode: TRACE1 TRACE2 TRACE3 SPURious <numeric_value> Phase noise mode: only the TRACE<n> parameters with n = 1 to 8 are used.
Return value:	In analyzer mode: The returned values are scaled in the current level unit. Returned FM-modulated measurement values are scaled in Hz. In phase noise mode: All measured data related to the currently selected measurement type is returned in x,y,x,y,x,y.....format. VCO measurements' trace data are as follows: VCO Tuning Characteristics (pushing off) - 8 traces X-Axis: Volt or Frequency Y-Axis: Trace 1, 3, 5, 7- Frequency or Volt Trace 2, 4, 6, 8 - Sensitivity VCO Tuning Characteristics (pushing on) - 8 traces X-Axis: Volt or Frequency Y-Axis: Frequency or Volt VCO Tuning Sensitivity (pushing off) - 8 traces X-Axis: Volt or Frequency Y-Axis: Trace 1, 3, 5, 7 - Sensitivity Trace 2, 4, 6, 8 - Level

VCO Tuning Sensitivity (pushing on) - 8 traces

X-Axis: Volt or Frequency

Y-Axis: Sensitivity

VCO RF Power Characteristics (pushing off) - 8 traces

X-Axis: Volt or Frequency

Y-Axis: Trace 1, 3, 5, 7 - Level

Trace 2, 4, 6, 8 - Frequency or Volt

VCO RF Power Characteristics (pushing on) - 8 traces

X-Axis: Volt or Frequency

Y-Axis: Level

VCO Harmonic Power - 8 traces

X-Axis: Volt or Frequency

Y-Axis: Level

VCO DC Characteristics - 8 traces

X-Axis: Volt

Y-Axis: Trace 1, 3, 5, 7 - Frequency

Trace 2, 4, 6, 8 - Level

Example:

for analyzer mode

```
"TRAC TRACE1,"+A$ (A$: data list in the current format)
```

for phase noise mode

```
"TRAC: COPY TRACE3, TRACE1"
```

for all modes

```
"TRAC? TRACE1"
```

Characteristics:

*RST value: -

SCPI: device-specific

Mode:

PNO, A

ASCII format (FORMat ASCII):

In ASCII format, a list of values separated by commas is returned (Comma Separated Values = CSV).

The number of measurement points is 625.

Binary format (FORMat REAL,32):

If the transmission takes place using the binary format (REAL,32), the data are transferred in block format (Definite Length Block Data according to IEEE 488.2). General structure of return string:

```
#42500<meas value 1><meas value value2> to <meas value 625>
```

with

- #4: digits of the subsequent number of data bytes (4 in the example)
- 2500: Number of subsequent data bytes (2500 in the example)
- <meas value x>: 4 byte floating point measurement values

Saving and recalling:

Saving and recalling trace data together with the device settings to/from the device-internal hard disk or to/from a floppy is controlled via the commands `MMEMoRY:STORe:STATe` and `MMEMoRY:LOAD:STATe` respectively. Trace data are selected with `"MMEMoRY:SELEct[:ITEM]:ALL"` or `"MMEMoRY:SELEct[:ITEM]:TRACe"`. Trace data in ASCII format (ASCII FILE EXPORT) are exported with the command `"MMEMoRY:STORe:TRACe"`.

Transfer format:

The trace data are transferred in the current format (corresponding to the command `FORMAt ASCIi|REAL`). The device-internal trace memory is addressed using the trace names 'TRACE1' to 'TRACE3'.

The transfer of trace data from the control computer to the instrument takes place by indicating the trace name and then the data to be transferred. In ASCII format, these data are values separated by commas. If the transfer takes place using the format real (REAL,32), the data are transferred in block format.

The parameter of the query is the trace name TRACE1 to TRACE3, it indicates which trace memory will be read out.

TRACe<1|2>:DATA? LIST

This command reads the peak list in the spurious measurement [LIST EVALUATION](#) (for details on this measurement see page 205). The suffix at TRACe<1|2> is irrelevant.

Return value: <result of range 1>,< result of range 2>,...< result of range n>

Every single range has following format:

<No>,<Start>,<Stop>,<rbw>,<freq>,<Levelabs>,<Levelrel>,<Delta>,<Limitcheck>,<unused1>,<unused2>

Where:

No	Range number
Start	Range start frequency
Stop	Range stop frequency
Rbw	Resolution bandwidth
Freq	Frequency of the peak in the range
Levelabs	Absolute peak power of the range in dBm
Levelrel	Reserved (0.0)
Delta	Delta of the peak power to the limit line in dB
Limitcheck	Limit check state (0 = PASSED, 1 = FAILED)
Unused1	Reserved (0.0)
Unused2	Reserved (0.0)

These values are defined via the `[SENSe<1|2>]LIST:RANGe<1...20>` subsystem.

Example:

```
"CALC:PEAK:AUTO ON"
```

'Switches the automatic peak search on.

```
"TRAC:DATA? LIST"
```

'Outputs the values of the automatic peak search.

Characteristics: *RST value: --
SCPI: device-specific

Mode: A

Number and Format of the Measurement Values for the Different Operating Modes

The number of measurement values depends on the instrument setting:

Analyzer mode (span > 0 and zero span):

625 results are output in the unit selected for display.

For spurious emissions measurement the number of results is the sum of all sweep points, specified in the sweep list configuration.



Note

With AUTO PEAK detector, only positive peak values can be read out. Trace data can be written into the instrument with logarithmic display only in dBm, with linear display only in volts.

FORMat REAL,32 is to be used as format for binary transmission, and FORMat ASCii for ASCII transmission.

SPURious reads the peak list in the spurious measurement. As results a list of frequency, level and delta to limit line values is returned. A delta limit of +200dB indicates no limit check is active.

TRACe<1|2>:COPY TRACE1| TRACE2| TRACE3 , TRACE1| TRACE2| TRACE3

This command copies data from one trace to another. The second operand describes the source, the first operand the destination of the data to be copied.

In analyzer mode, the numeric suffix at TRACe<1|2> selects the measurement window.

In phase noise mode, the copy process for measurements with 2 y-axis follows the rule that trace 1 & 2 are copied to traces 3 & 4.

Example: "TRAC:COPY TRACE3,TRACE1"

Characteristics: *RST value: -
SCPI: conform

Mode: PNO, A

This command is an event and therefore has no query and no *RST value.

TRACe<1|2>:IMMEDIATE:LEVEL?

This query returns the current Y results of the sweep. During a sweep the last measured value is read out.

Example: "INIT:CONT OFF"
 'switches to single-sweep mode

 "INIT"
 'starts a sweep (without waiting for the sweep end!)

 "TRAC1:IMM:LEV?"
 'queries the level of the last measured measurement point

Characteristics: *RST value:
 SCPI: conform

Mode: A

TRACe<1|2>:IMMEDIATE:RESULT?

This query returns the current X and Y results of the sweep. During a sweep the last measured values are read out.

Example: "INIT:CONT OFF"
 'switches to single-sweep mode

 "INIT"
 'starts a sweep (without waiting for the sweep end!)

 "TRAC:IMM:RES?"
 'queries the X and Y values of the last measured measurement point

Characteristics: *RST value:
 SCPI: conform

Mode: A

TRACe:IQ Subsystem

The commands of this subsystem are used for collection and output of measured IQ measured data. A special memory is therefore available in the instrument with 16M words for the I and Q data. The measurement is always performed in the time domain (span = 0 Hz) at the selected center frequency. The number of samples to be collected can be set. The sampling rate can be set in the range from 10 kHz to 81.6 MHz; when channel filters are used, the sampling rate depends on the filter involved and can be determined via a special command depending on the setting used. Prior to being stored in memory or output via GPIB, the measured data is corrected by an equalizer filter in terms of frequency response.

Depending on the sample rate, the following maximum bandwidths can be obtained during the measurement.

Sample rate (from)	Sample rate (to)	Max. bandwidth	Notes
81.6 MHz	40.8 MHz	30 MHz	Half-band filter at half the sample rate (81.6 MHz)
40.8 MHz	20.4 MHz	0.68 sample rate	
20.4 MHz	10.2 MHz	0.8 sample rate	
10.2 MHz	5.1 MHz	0.8 sample rate	
5.1 MHz	2.55 MHz	0.8 sample rate	
2.55 MHz	1.275 MHz	0.8 sample rate	
1.275 MHz	0.6375 MHz	0.8 sample rate	
0.6375 MHz	318.75 kHz	0.8 sample rate	
318.75 kHz	159.375 kHz	0.8 sample rate	
159.375 kHz	79.6875 kHz	0.8 sample rate	
79.6875 kHz	39.84375 kHz	0.8 sample rate	
39.84375 kHz	19.921875 kHz	0.8 sample rate	
19.921875 kHz	10 kHz	0.8 sample rate	

Fig. 6-1 shows the analyzer hardware from the IF section to the processor. The IF filter is the resolution filter of the R&S FSUP with bandwidths selectable from 300 kHz to 50 MHz. The A/D converter samples the IF signal (20.4 MHz) at a rate of 81.6 MHz.

The digital signal is down-converted to the complex baseband, lowpass-filtered, and the sampling rate is reduced, i.e. the output sampling rate is set between 10.0 kHz and 81.6 MHz in steps of 0.1 Hz. This avoids unnecessary oversampling at narrower bandwidths, which saves processing time and increases the maximum recording time. Since the sample rate can be programmed quasi-continuously, even sampling rates, which cannot be derived by direct division of the 81.6 MHz, can be set.

The I/Q data are written to a memory of 16M words. The data can then be read out from these areas in blocks that are 512 k words each. The memory is hardware-triggered.




Fig. 6-1 Block diagram illustrating the R&S FSUP signal processing

All trigger sources except for VIDEO can be used for triggering. The number of test points to be recorded prior to the trigger time can be selected for all of the available trigger sources except for FREE RUN, where this parameter is always to be assigned the value 0). Measurement results are output in the form of a list, with the Q values following immediately after the list of I values in the output buffer. The FORMAT command can be used to select between binary output (32 bit IEEE 754 floating-point values) and output in ASCII format.

The commands of this subsystem can be used in two ways:

- Measurement and result query with one command:

This method causes the least delay between measurement and output of the result data, but it requires the control computer to wait actively for the response data.

- Setting up the instrument, start of the measurement via "INIT" and query of the result list at the end of the measurement:

With this method the control computer can be used for other activities during the measurement. In this case the additional time needed for synchronization via service request must be taken into account.

TRACe<1|2>:IQ:DATA?

This command starts a measurement with the settings defined via TRACe: IQ: SET and returns the list of measurement results immediately after they are corrected in terms of frequency response. The number of measurement results depends on the settings defined with TRACe: IQ: SET, the output format depends on the settings of the FORMat – subsystem.



Note

The command requires that all response data are read out completely before the instrument accepts further commands.

Parameter: none

Example:

```
"TRAC:IQ:STAT ON"
'Enables acquisition of I/Q data

"TRAC:IQ:SET NORM,10MHz,32MHz,EXT,POS,0,4096"
'Measurement configuration:
'Filter type: Normal
'RBW: 10 MHz
'Sample Rate: 32 MHz
'Trigger Source: External
'Trigger Slope: Positive
'Pretrigger Samples: 0
'# of Samples: 4096

"FORMat REAL,32"
'Selects format of response data

"TRAC:IQ:DATA?"
'Starts measurement and reads results
```

Return value: The result values are scaled linear in unit *Volt* and correspond to the voltage at the RF input of the instrument.

ASCII Format (FORMat ASCII):

In this case the command returns a comma separated list of the measured voltage values in floating point format (Comma Separated Values = CSV). The number of values returned is 2 * number of samples, the first half being the I-values, the second half the Q-values.



Note

With >512 k \equiv 524288 samples, the data is transmitted in logical blocks of 512k values. See below.

Binary Format (FORMat REAL,32):

In this case, the command returns binary data (Definite Length Block Data according to IEEE 488.2), with the lists of I- and Q-data being arranged one after the other in 32 Bit IEEE 754 floating point data. The scheme of the response string is as follows:

```
#44096<I-value1><I-value2>...<I-value512><Q-value1><Q-value2>...<Q-value512>
```

with

- #4: digits of the subsequent number of data bytes (4 in the example)
- 4096: number of subsequent data bytes (*# of DataBytes*, 4096 in the example)
- <I-value x>: 4-Byte-Floating Point I-value; max. 512k
- <Q-value y>: 4-Byte-Floating Point Q-value; max. 512k

The number of I- and Q-data can be calculated as follows:

```
# of I-data = # of Q-data = (# of DataBytes) / 8
```

The offset of Q-data in the output buffer can be calculated as follows:

```
Q-data offset = (# of DataBytes) / 2 + LengthIndicatorDigit
```

with LengthIndicatorDigits being the number of digits of the length indicator including the '#'. In the example above (#44096...) this results in a value of 6 for LengthIndicatorDigits and the offset for the Q-data will result in 2048 + 6 = 2054.

Blockwise transmission with data volumes exceeding 512k words:

With > 512 k ≡ 524288 samples, the data is transmitted in logical blocks of 512k values. All transmitted blocks, except the block last transmitted, have a data length of exactly 512k words.

The following example shows the data structure for 1058816 I data samples and 1058816 Q data the samples. Since the block length is limited to 512k, 3 blocks are required for data transmission:

- 512k (=524288) Samples of I data of **Block 1**
- 512k (=524288) Samples of Q data of **Block 1**
- 512k (=524288) Samples of I data of **Block 2**
- 512k (=524288) Samples of Q data of **Block 2**
- 10k (=10240) Samples of I data of **Block 3**
- 10k (=10240) Samples of Q data of **Block 3**




Fig. 6-2 Block transfer structure

Characteristics: *RST value: --



Note

Using the command with the *RST values for the TRAC:IQ:SET command, the following minimum buffer sizes for the response data are recommended:
 ASCII format: 10 kBytes
 Binary format: 2 kBytes

SCPI: device-specific

Mode: A-T

TRACe<1|2>:IQ:DATA:FORMat COMPatible | IQBLock | IQPair

This command sets the data output formatting (using the TRAC:IQ:DATA? command).

For further details see [Fig. 6-2](#).

Parameter: COMPatible: 512k I data and 512k Q data is alternately transferred
 IQBLock: First, all I and then all Q data is transferred
 IQPair: I/Q data is transferred in pairs

Example: "TRAC:IQ:DATA:FORM IQP"

Characteristics: *RST value: COMP
SCPI: device-specific

Mode: A

TRACe<1|2>:IQ:DATA:MEMory[:RF]? <offset samples>,<# of samples>

This command permits the readout of previously acquired (and frequency response corrected) I/Q data from the memory, with indication of the offset related to the start of measurement and with indication of the number of measurement values. Therefore a previously acquired data set can be read out in smaller portions. The maximum amount of available data depends on the settings of command TRACe:IQ:SET, the output format on the settings in the FORMat – subsystem.



Note

The command requires that all requested measurement data be completely retrieved before the device accepts any further commands.

If no IQ data is available in the memory because the associated measurement has not yet been started, the command generates a query error.

Parameter: <offset samples>: Offset of the values to be output, referenced to the start of the sampled data.
Value range: 0 ... <# of samples> - 1, where <# of samples> is the value specified with the TRACe:IQ:SET command
<# of samples>: Value range: 1 ... <# of samples> - <offset samples> where <# of samples> is the value specified with the TRACe:IQ:SET command.

Example: "TRAC:IQ:STAT ON"
'activates the I/Q data sampling

"TRAC:IQ:SET NORM,10MHz,32MHz,EXT,POS,100,4096"
'configures the measurement:
'Filter type: Normal
'RBW: 10 MHz
'Sample Rate: 32 MHz
'Trigger Source: External
'Trigger Slope: Positive
'Pretrigger Samples: 100
'# of Samples: 4096

"INIT;*WAI"
'starts the measurement and waits for its end

"FORMat REAL,32"
'specifies the format of the response data

'Reading the results:

"TRAC:IQ:DATA:MEM? 0,2048"
'reads in 2048 I/Q values starting with the beginning of the sampling

"TRAC:IQ:DATA:MEM? 2048,1024"

'reads in 2048 I/Q values starting with the beginning of the sampling

"TRAC:IQ:DATA:MEM? 100,512"

'reads in 512 I/Q values starting with the trigger time (<Pretrigger Samples> was 100)

Return value: Irrespective of the output format selected, the data is scaled linearly with 'V' as the unit and corresponds to the voltage at the RF input of the device.

The return buffer is similarly configured to the return buffer with the TRACe:IQ:DATA? command where all I data has the value 0.

Characteristics: *RST value: --
SCPI: device-specific

Mode: A-T

TRACe<1|2>:IQ:SET <filter type>,<rbw>,<sample rate>,<trigger source>,<trigger slope>,<pretrigger samples>,<# of samples>

This command defines the settings of the analyzer hardware for the measurement of I/Q data. This allows setting the bandwidth of the analog filters in front of the A/D converter as well as setting the sample rate, trigger conditions and the record length.



Note

If this command is omitted, the current analyzer settings will be used for the corresponding parameters.

Parameter: <filter type>: NORMAL
Selects the analog analyzer resolution filters as filter type. This is currently the only available filter type.

<rbw>: Bandwidth of the analog filters in front of the A/D converter.
Value range: 300 kHz – 10 MHz in steps of 1, 2, 3, 5

<sample rate>: Sampling rate for the data acquisition.
Value range: 10 kHz to 81,6 MHz for <filter type> = NORMAL

<trigger mode>: Selection of the trigger source used for the measurement.
Values: IMMEDIATE | EXTERNAL | IFPOWER

**Note**

After selecting IFPower, the trigger threshold can be set with command TRIG:LEV:IFP.

<trigger slope>: Used trigger slope.

Values: POSitive (currently the only value supported)

<pretrigger samples>: Number of measurement values to be recorded before the trigger point.

Range: -16776703 (= -(2²⁴-1-512)) to 65023 (= 2²⁴*1024 – 512 - 1)
(Negative values correspond to a trigger delay.)

**Note**

For <trigger mode> = IMMEDIATE the value must be 0.

<# of samples>: Number of measurement values to record.

Value range: 1 to 16776704 (=16*1024*1024 - 512)

Example:

```
"TRAC:IQ:SET NORM,10MHz,32MHz,EXT,POS,0,2048"
```

'Reads 2048 I/Q-values starting at the trigger point.

'Filtertype: NORMAL (analog)

'RBW: 10 MHz

'Sample Rate: 32 MHz

'Trigger: External

'Slope: Positive

```
"TRAC:IQ:SET NORM,1MHz,4MHz,EXT,POS,1024,512"
```

'Reads 512 I/Q-values from 1024 measurement points before the trigger point.

'Filter type: NORMAL (analog)

'RBW: 1 MHz

'Sample Rate: 4 MHz

'Trigger: External

'Slope: Positive

Characteristics: *RST values: NORM, 3MHz, 32MHz, IMM, POS, 0, 128

**Note**

For using these default settings with command `TRAC:IQ:DATA?` the following minimum buffer sizes for the response data are recommended:

ASCII format: 10 kBytes

Binary format: 2 kBytes

SCPI: device-specific

Mode: A-T

TRACe<1|2>:IQ:SRATE 10.0 kHz to 81.6 MHz

This command sets the sampling rate for the I/Q data acquisition. Thus the sample rate can be modified without affecting the other settings.

Return value: 10.0 kHz to 81.6 MHz
sampling rates require a bandwidth of 50 MHz, set with the `TRAC:IQ:SET` command.

**Note**

If `<filter type> = CFILter`, the sample rate is determined by the selected filter bandwidth. In this case, the currently set sample rate can be determined using the query command. Entering a value causes an execution error if `<filter type> = CFILter`.

Example: `TRAC:IQ:SRAT 4MHZ`

Characteristics: *RST value: 32 MHz
SCPI: device-specific

Mode: A-T

TRACe<1|2>:IQ[:STATe] ON | OFF

This command switches the I/Q data acquisition on or off.

Example:

TRAC:IQ ON

'Switches on I/Q data acquisition

TRAC:IQ:ONL ON

'Switches the online output of the I/Q data on.

INIT:CONT ON

'Selects continuous measurement data output.

Characteristics:

*RST value: OFF

SCPI: device-specific

Mode:

A-T

TRIGger Subsystem

The TRIGger subsystem is used to synchronize instrument actions with events. It is thus possible to control and synchronize the start of a sweep. An external trigger signal can be applied to the connector at the rear panel of the instrument. A distinction is made between TRIGger1 (screen A) and TRIGger2 (screen B).

TRIGger<1|2>[:SEQuence]:SOURce IMMEDIATE | EXTERNAL | VIDEO | IFPOWER | FM | AM | PM

This command selects the trigger source for the start of a sweep.



Note

The trigger source selection has to be done with the command `TRIGger<1|2>[:SEQuence]:SYNChronize:ADJust`.

Parameter:

IMMEDIATE	Automatic triggering of the next measurement at the end of the previous one. The value IMMEDIATE corresponds to the FREE RUN setting.
EXTERNAL	The next measurement is triggered by the signal at the external trigger input.
VIDEO	The next measurement is triggered by the detection of a signal at the video filter output. (not available for FM demodulator mode)
IFPOWER	The next measurement is triggered by the detection of a signal at the instrument IF (10 MHz bandwidth)
AF FM	The next measurement is triggered by the detection of a FM modulated signal (AF is synonymous with FM)
AM	The next measurement is triggered by the detection of a audio signal after AM demodulation
PM	The next measurement is triggered by the detection of a audio signal after PM demodulation



Note

To ensure successful triggering with trigger sources AF, AM, FM, and PM the measurement time should include at least 5 periods of the audio signal.

Example: `"TRIG:SOUR EXT"`
'Selects the external trigger input as source of the trigger signal

Characteristics: *RST value: IMMEDIATE
SCPI: conform

Mode: A

TRIGger[:SEQuence]:MODE IMMEDIATE | EXTERNAL | POWER

This command selects the trigger source for the start of a sweep.

Parameter: Available trigger modes:

IMMEDIATE	No triggering is performed. The value IMMEDIATE corresponds to the FREE RUN setting.
EXTERNAL	The next measurement is triggered by the signal at the external trigger input, e.g. a gated trigger.
POWER	Triggering of the measurement via signals that are outside the measurement channel.

Example: "TRIG:MODE IMM"
'No trigger.

Characteristics: *RST value: IMMEDIATE
SCPI: device-specific

Mode: PNO

TRIGger[:SEQuence]:LEVel:POWer -70 to +30 dBm

This command sets the input signal level at which the measurement will be triggered to start. This command is only available for transient measurements. It is useful for showing the switch on curve of a DUT when the DC power is switched on.

Example: "TRIG:LEV:POW 10DBM"

Characteristics: *RST value: 0 dBm
SCPI: device-specific

Mode: PNO

TRIGger<1|2>[:SEQuence]:LEVel:IFPower -70 to +30DBM

This command sets the level of the IF power trigger source.

Example: "TRIG:LEV:IFP -20DBM"

Characteristics: *RST value: -20 dBm
SCPI: device-specific

Mode: A

TRIGger<1|2>[:SEQuence]:LEVel[:EXTeRnal] 0.5 to +3.5 V

This command sets the level of the external trigger source.

Example: "TRIG:LEV 2V"

Characteristics: *RST value: 1.4 V
SCPI: device-specific

Mode: A

TRIGger<1|2>[:SEQuence]:HOLDoff -100 to 100s

This command defines the length of the trigger delay.

A negative delay time (pretrigger) can be set in the time domain (span = 0 Hz) only.

Example: "TRIG:HOLD 500us"

Characteristics: *RST value: 0 s in analyzer mode, 10 μ s in phase noise mode
SCPI: conform

Mode: PNO, A

TRIGger<1|2>[:SEQuence]:HOLDoff:ADJust:AUTO ON|OFF

This command defines whether the group delay of the bandwidth filters for the external trigger is compensated (ON) or not (OFF). If a burst signal is analyzed in the time domain mode, the rising edge will remain at the same time position if compensation is on and the bandwidth changes.

Example: "TRIG:HOLD:ADJ:AUTO ON"

Characteristics: *RST value: OFF
SCPI: device-specific

Mode: A

TRIGger<1|2>[:SEQuence]:SLOPe POSitive | NEGative

This command selects the slope of the trigger signal. The selected trigger slope applies to all trigger signal sources.

Example: "TRIG:SLOP NEG"

Characteristics: *RST value: POSitive
SCPI: conform

Characteristics: SCPI: device-specific

Mode: A

UNIT Subsystem

The UNIT subsystem is used to switch the base unit of setting parameters.

In analyzer mode, the numeric suffix at UNIT<1|2> selects the measurement window. In phase noise mode, the numeric suffix at UNIT<1|2> is irrelevant.

UNIT<1|2>:POWer DBM | DBPW | WATT | DBUV | DBMV | VOLT | DBUA | AMPere | V | A | W | DB | DBPT | PCT | UNITLESS | DBUV_MHZ | DBMV_MHZ | DBUA_MHZ | DBUV_M | DBUA_M | DBUV_MMHZ | DBUA_MMHZ

This command selects the unit for power for the selected measurement window.

DBxx_MHZ indicates the units dBxx/MHz and DBxx_MMHZ indicates the units dBxx/mMHz (the measured level is referenced to a 1 MHz bandwidth).

Example: "UNIT:POW DBM"
'Sets the power unit for screen A to dBm.

Characteristics: *RST value: DBM
SCPI: conform

Mode: A

UNIT:ANGLE DEG | RAD

This command selects the unit for angles.

Example: "UNIT:ANGL RAD"

Characteristics: *RST value: RAD
SCPI: conform

Mode: PNO

GPIB Commands of HP Models 856xE, 8566A/B, 8568A/B and 8594E

Introduction

The R&S FSP analyzer family supports a subset of the GPIB commands of HP models 8560E, 8561E, 8562E, 8563E, 8564E, 8565E, 8566A, 8566B, 8568A, 8568B and 8594E.

Despite the differences in system architecture and device features, the supported commands have been implemented in a way to ensure a sufficiently high degree of correspondence with the original.

This includes the support of syntax rules for not only newer device families (B and E models) but for the previous A family as well.

In many cases the selection of commands supported by the R&S FSUP is sufficient to run an existing GPIB program without adaptation.

The device model to be emulated is selected manually by means of the key sequence *SETUP - GENERAL SETUP - GPIB - GPIB LANGUAGE* via the GPIB using the *SYSTEM:LANGUage* command.

To make it possible to also emulate device models that are not part of the selection list of the GPIB LANGUAGE softkey, the identification string received in response to the ID command can be modified (key sequence *SETUP - GENERAL SETUP - GPIB - ID STRING USER*). This allows any device model to be emulated whose command set is compatible with one of the supported device models.

Command Set of Models 8560E, 8561E, 8562E, 8563E, 8564E, 8565E, 8566A/B, 8568A/B, 8591E, 8594E, 71100C, 71200C, and 71209A

As with the original units, the R&S FSUP includes the command set of the A models in the command set of the B models.



Note

The HP model 8591E is compatible to HP model 8594E, the HP models 71100C, 71200C, and 71209A are compatible to HP models 8566A/B.

Command	Supported subset	Function	Corresponding HP-Models	Status
A1	A1	Clear/Write A	HP 8566A/ HP 8568A	available
A2	A2	Max Hold A	HP 8566A/ HP 8568A	available
A3	A3	View A	HP 8566A/ HP 8568A	available
A4	A4	Blank A	HP 8566A/ HP 8568A	available
ABORT ¹⁾	ABORT	Stop previous function	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
ADD		Add	HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above
ADJALL	ADJALL	Adjust all	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
ADJCRT ²⁾	ADJCRT	Adjust CRT	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
ADJIF ²⁾	ADJIF	Auto adjust IF	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
AMB	AMB ON OFF AMB 1 0 AMB?	Trace A - B -> Trace A	HP 856xE / HP 8594E	available in V3.3x and above
AMBPL	AMBPL ON OFF AMBPL 1 0 AMBPL?		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
ANNOT	ANNOT ON OFF ANNOT 1 0 ANNOT?	Annotation	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
APB	APB	Trace A + B -> Trace A	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
AT	AT <numeric_value> DB DM AT DN AT UP AT AUTO AT?	Attenuation	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
AUNITS	AUNITS DBM DBMV DBUV AUNITS?	Amplitude Units	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
AUTOCP	AUTOCP	Coupling default	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
AXB	AXB	Exchange trace A and B	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
B1	B1	Clear/Write B	HP 8566A/ HP 8568A	available
B2	B2	Max Hold B	HP 8566A/ HP 8568A	available
B3	B3	View B	HP 8566A/ HP 8568A	available
B4	B4	Blank B	HP 8566A/ HP 8568A	available
BL	BL	Trace B - Display Line -> Trace B	HP 8566A/ HP 8568A	available in V3.3x and above
BML	BML	Trace B - Display Line -> Trace B	HP 856xE/ HP8594E	available in V3.3x and above
BTC	BTC	Transfer Trace B -> C	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
BXC	BXC	Exchange Trace B and C	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
BLANK	BLANK TRA TRB TRC	Blank Trace	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
C1	C1	A-B off	HP 8566A/ HP 8568A	available
C2	C2	A-B -> A	HP 8566A/ HP 8568A	available
CA	CA	Couple Attenuation	HP 8566A/ HP 8568A	available
CAL 1)	CAL ALL CAL ON CAL OFF	Start analyzer self alignment	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
CF	CF <numeric_value> HZ KHZ MHZ GHZ CF UP CF DN CF?	Center Frequency	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
CHANPWR	CHANPWR TRA TRB, <numeric_value>.	Channel Power Measurement	HP 856xE / HP 8594E	available in V3.4x and above
CHPWRBW	CHPWRBW <numeric_value> HZ KHZ MHZ GHZ	Channel Power Bandwidth	HP 856xE / HP 8594E	available in V3.4x and above
CLRW	CLRW TRA TRB TRC	Clear/Write Trace	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
CLS 1)	CLS	Clear all status bits	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
CONTS	CONTS		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
COUPLE	COUPLE AC DC	Input coupling	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
CR	CR	Couple RBW	HP 8566A/ HP 8568A	available
CS	CS	Couple Step Size	HP 8566A/ HP 8568A	available
CT	CT	Couple SWT	HP 8566A/ HP 8568A	available
CTA		Convert to absolute units	HP 8566B/ HP 8568B/ HP 8594E	available in V4.1x and above
CV	CV	Couple VBW	HP 8566A/ HP 8568A	available
D1 2)	D1	Display Size normal	HP 8566A/ HP 8568A	available in V3.3x and above

Command	Supported subset	Function	Corresponding HP-Models	Status
DA 2)	DA	Display address		available in V3.7x and above
DEMODO 1)	DEMODO ON OFF AM FM	AF Demodulator	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
DEMODAGC 2)	DEMODAGC ON OFF 1 0 DEMODAGC?	Demodulation AGC	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
DEMOT	DEMOT <numeric_value> S MS US SC DEMOT UP DN DEMOT?	Demodulation time	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
DET	DET POS SMP NEG DET?	Detector	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
DISPOSE2)	ONEOS TRMATH ONSWP ALL <numeric_value>			
DIV		Divide	HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above
DL	DL <numeric_value> DB DM DL DN DL UP DL ON DL OFF DL?	Display Line	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
DLE	DLE ON OFF	Display Line enable	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
DONE	DONE DONE?	Done query	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
DW 2)	DW	Write to display and increment address		
E1	E1	Peak Search	HP 8566A/ HP 8568A	available
E2	E2	Marker to Center Freq.	HP 8566A/ HP 8568A	available
E3	E3	Deltamarker Step Size	HP 8566A/ HP 8568A	available
E4	E4	Marker to Ref. Level	available	available

Command	Supported subset	Function	Corresponding HP-Models	Status
ERR	ERR 250 cal level error ERR 300 LO unlock ERR 472 cal error digital filter ERR 473 cal error analog filter ERR 552 cal error log amp generator ERR 902 unscale tracking ERR 906 oven cold ERR117 numeric unit error ERR112 Unrecognized Command	Now some FSx errors are mapped to HP errors.	HP8568A HP856xE	Available in V3.7x and above
ERR?	ERR?	Error queue query	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
EX	EX	Exchange trace A and B	HP 8566A / HP 8568A	available in V3.2x and above
FA	FA <numeric_value> HZ KHZ MHZ GHZ FA UP FA DN FA?	Start Frequency	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
FB	FB <numeric_value> HZ KHZ MHZ GHZ FB UP FB DN FB?	Stop Frequency	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
FOFFSET ¹⁾	FOFFSET <numeric_value> HZ KHZ MHZ GHZ FOFFSET?	Frequency Offset	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
FREF	FREF INT EXT	Reference Frequency	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
FS	FS	Full Span	HP 8566A/ HP 8568A	available
FUNCDEF		Define Function Function must be in one line between delimiters @	HP 8594E / HP 856xE / HP 8566B	available in V3.7x and above
GATE ¹⁾	GATE ON OFF GATE 1 0		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
GATECTL ¹⁾	GATECTL EDGE LEVEL GATECTL?		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
GD 1)	GD <numeric_value> US MS SC GD DN GD UP GD?		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
GL 1)	GL <numeric_value> US MS SC GL DN GL UP GL?		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
GP 1)	GP POS NEG GP?		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
GRAT 2)	GRAT ON OFF	Graticule	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
I1	I1		HP 8566A/ HP 8568A	available
I2	I2		HP 8566A/ HP 8568A	available
ID	ID ID?	Identify	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
INZ 1)	INZ 75 INZ 50 INZ?	Input Impedance	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
IP	IP	Instrument preset	HP 8566A/ HP 8568A	available
KEYDEF	KEYDEF	Key definition	HP 8566B/ HP 856xE / HP 859xE	available in V3.7x and above
KEYEXEC	KEYEXEC	Key execute	HP 8566B	available in V3.7x and above
KS=	KS= <numeric_value> HZ KHZ MHZ GHZ KS= DN KS= UP KS=?	Marker Frequency Counter Resolution	HP 8566A/ HP 8568A	available
KS/	KS/	Manual Peaking	HP 8566A/ HP 8568A	available in V3.2x and above
KS(KS(Lock register	HP 8566A/ HP 8568A	available in V3.4x and above
KS)	KS)	Unlock register	HP 8566A/ HP 8568A	available in V3.4x and above
KS91	KS91	Read Amplitude Error	HP 8566A/ HP 8568A	available in V3.4x and above

Command	Supported subset	Function	Corresponding HP-Models	Status
KSA	KSA	Amplitude Units in dBm	HP 8566A/ HP 8568A	available
KSB	KSB	Amplitude Units in dBmV	HP 8566A/ HP 8568A	available
KSC	KSC	Amplitude Units in dBuV	HP 8566A/ HP 8568A	available
KSD	KSD	Amplitude Units in V	HP 8566A/ HP 8568A	available
KSE	KSE <numeric_value> <char data>@	Title mode	HP 8566A/ HP 8568A	available
KSG	KSG KSG ON KSG <numeric_value>	Video Averaging on	HP 8566A/ HP 8568A	available
KSH	KSH	Video Averaging Off	HP 8566A/ HP 8568A	available
KSK		Marker to Next Peak	HP 8566A/ HP 8568A	available
KSL		Marker Noise off	HP 8566A/ HP 8568A	available
KSM		Marker Noise on	HP 8566A/ HP 8568A	available
KSO	KSO	Deltamarker to span	HP 8566A/ HP 8568A	available in V3.2x and above
KSP	KSP <numeric_value>	HPIB address	HP 8566A/ HP 8568A	available
KSQ 2)	KSQ	Band lock off	HP 8566A/ HP 8568A	available in V3.2x and above
KST	KST	Fast Preset	HP 8566A/ HP 8568A	available
KSV	KSV <numeric_value> HZ KHZ MHZ GHZ KSV?	Frequency Offset	HP 8566A/ HP 8568A	available
KSW	KSW	Error Correction Routine	HP 8566A/ HP 8568A	available
KSX	KSX	Correction Values On	HP 8566A/ HP 8568A	available
KSY	KSY	Correction Values Off	HP 8566A/ HP 8568A	available
KSZ	KSZ <numeric_value> DB KSZ?	Reference Value Offset	HP 8566A/ HP 8568A	available
KSa	KSa	Normal Detection	HP 8566A/ HP 8568A	available
KSb	KSb	Pos Peak Detection	HP 8566A/ HP 8568A	available

Command	Supported subset	Function	Corresponding HP-Models	Status
KSd	KSd	Neg Peak Detection	HP 8566A/ HP 8568A	available
KSe	KSe	Sample Detection	HP 8566A/ HP 8568A	available
KSg		CRT beam off		
KSh		CRT beam on		
KSj	KSj	View Trace C	HP 8566A/ HP 8568A	available
KSk	KSk	Blank Trace C	HP 8566A/ HP 8568A	available
KSl	KSl	Transfer B to C	HP 8566A/ HP 8568A	available
KSm	KSm	Graticule off	HP 8566A/ HP 8568A	available
KSn ²⁾	KSn	Grid on	HP 8566A/ HP 8568A	available in V3.2x and above
KSo	KSn	Character display off	HP 8566A/ HP 8568A	available in V3.2x and above
KSp	KSp	Character display on	HP 8566A/ HP 8568A	available in V3.2x and above
KSr	KSr	Create service request	HP 8566A/ HP 8568A	available in V3.2x and above
KSt ²⁾	KSt	Band lock on	HP 8566A/ HP 8568A	available in V3.2x and above
KV ²⁾	KV	Signal ident on	HP 8566A/ HP 8568A	available in V3.2x and above
L0	L0	Display line off	HP 8566A/ HP 8568A	available in V3.2x and above
LB	LB <numeric_value> <char data>@	Label	HP 8566A/ HP 8568A	available in V3.2x and above
LF	LF	Low frequency band preset	HP 8566A/ HP 8568A	available in V3.2x and above
LG	LG <numeric_value> DB DM LG?	Amplitude Scale Log	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
LL ²⁾	LL	Plot command	HP 8566A/ HP 8568A	available in V3.2x and above
LN	LN	Amplitude Scale Lin	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
M1	M1	Marker Off	HP 8566A/ HP 8568A	available

Command	Supported subset	Function	Corresponding HP-Models	Status
M2	M2 M2 <numeric_value> HZ KHZ MHZ GHZ M2 DN M2 UP M2?	Marker Normal	HP 8566A/ HP 8568A	available
M3	M3 M3 <numeric_value> HZ KHZ MHZ GHZ M3 DN M3 UP M3?	Delta Marker	HP 8566A/ HP 8568A	available
M4	M4 <numeric_value> HZ KHZ MHZ GHZ	Marker Zoom	HP 8566A/ HP 8568A	available
MA	MA	Marker Amplitude	HP 8566A/ HP 8568A	available
MC0	MC0	Marker Count off	HP 8566A/ HP 8568A	available
MC1	MC1	Marker Count on	HP 8566A/ HP 8568A	available
MDS	MDS	Measurement data size	HP 8566B	available in V3.7x and above
MF	MF MF?	Marker Frequency	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MINH ¹⁾	MINH TRC	Minimum Hold	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKA	MKA <numeric_value> MKA?	Marker Amplitude	HP 856xE / HP 8566B / HP 8568B / HP 8594E	MKA <numeric_value> available in V3.4x and above query always available
MKACT	MKACT 1 MKACT?	Select the active marker	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKBW ¹⁾	MKBW <numeric_value> MKBW ON MKBW OFF	N dB Down	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKD	MKD MKD <numeric_value> HZ KHZ MHZ GHZ MKD DN MKD UP MKD ON MKD OFF MKD?	Delta Marker	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
MKDR	MKDR <numeric_value> HZ KHZ MHZ GHZ S SC MS MSEC USM KDR?	Delta Marker reverse	HP 856xE / HP 8566B / HP 8568B / HP 8594E	query available in V3.2x and above, completely available in V3.3x and above
MKDR?		Delta Marker reverse query		
MKF	MKF <numeric_value> HZ KHZ MHZ GHZ MKF?	Set Marker Frequency	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
		Marker On		hidden
MKFC	MKFC ON OFF	Frequency Counter on/off	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
MKFCR 1)	MKFCR <numeric_value> HZ KHZ MHZ GHZ MKFCR DN MKFCR UP MKFCR?	Frequency Counter Resolution	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKMIN	MKMIN	Marker -> Min	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKN	MKN MKN <numeric_value> HZ KHZ MHZ GHZ MKN DN MKN UP MKN ON MKN OFF MKN?	Normal Marker	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKNOISE	MKNOISE ON OFF MKNOISE 1 0 MKNOISE?	Noise Measurement	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKOFF	MKOFF MKOFF ALL	Marker off	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKP	MKP <numeric_value> MKP?	Marker position	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.4x and above
MKPK	MKPK MKPK HI MKPK NH MKPK NR MKPK NL	Marker Search	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKPT	MKPT MKPT HI MKPT NH MKPT NR MKPT NL	Marker Peak Threshold	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
MKPX	MKPX <numeric_value> DB MKPX DN MKPX UP MKPX?	Peak Excursion	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKRL	MKRL	Ref Level = Marker Level	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKSP	MKSP	Deltamarker to span	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
MKSS	MKSS	CF Stepsize = Marker Freq	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKT	MKT <numeric_value> S MS US SC MKT?	MKF = fstart + MKT/ SWT*Span	HP 856xE / HP 8594E	available in V3.3x and above
MKTRACE	MKTRACE TRA TRB TRC	Marker to Trace	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKTRACK	MKTRACK ON OFF MKTRACK 1 0 MKTRACK?	Signal Track	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MKTYPE	MKTYPE AMP MKTYPE?	Marker type	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.4x and above
MOV	MOV TRA TRB TRC, TRA TRB TRC	Move Trace Contents	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
MPY		Multiply	HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above
MT0	MT0	Marker Track Off	HP 8566A/ HP 8568A	available
MT1	MT1	Marker Track On	HP 8566A/ HP 8568A	available
MXMH	MXMH TRA TRB	Maximum Hold	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
NORMALIZE	NORMALIZE	Normalize trace	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above available in V3.2x and above

Command	Supported subset	Function	Corresponding HP-Models	Status
NRL ¹⁾	NRL <numeric_value> DB DM NRL?	Normalized Reference Level	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
NRPOS	NRPOS <numeric_value> NRL?	Normalize position	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
O1	O1	Format ASCII, Values 0 to 4095	HP 8566A/ HP 8568A	available
O2	O2	Format Binary, Values 0 to 4095	HP 8566A/ HP 8568A	available in V3.3x and above
O3	O3	Format ASCII	HP 8566A/ HP 8568A	available
OA	OA	Output All	HP 8566A/ HP 8568A	available
OL	OL <80 characters> OL?	Output Learn String	HP 8566A/ HP 8568A	available
OT	OT	Output Trace Annotations	HP 8566A/ HP 8568A	available
PA ²⁾	PA <numeric_value>, <numeric_value	Plot command	HP 8566A/ HP 8568A	available in V3.2x and above
PD ²⁾	PD <numeric_value>, <numeric_value	Plot command	HP 8566A/ HP 8568A	available in V3.2x and above
PLOTORG ²⁾	PLOTORG DSP GRT	Plot command	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
PLOTSRC ²⁾	PLOTSRC ANNT GRT TRB TRA ALLDSP GRT	Plot command	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
PP	PP	Preselector Peaking	HP 8566A/ HP 8568A	available
PRINT ¹⁾	PRINT PRINT 1 0	Hardcopy	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
PSDAC ²⁾	PSDAC <numeric_value> PSDAC UP DN	Preselector DAC value	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
PSTATE ²⁾	PSTATE ON OFF 1 0	Protect State	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
PU ²⁾	PU	Pen Up	HP 8566A/ HP 8568A	available in V3.3x and above

Command	Supported subset	Function	Corresponding HP-Models	Status
PWRBW	PWRBW	Power Bandwidth	HP 8566B/ HP 859x/ HP 856xE	available in V3.7x and above
R1	R1	Set Status Bit Enable	HP 8566A/ HP 8568A	available
R2	R2	Set Status Bit Enable	HP 8566A/ HP 8568A	available
R3	R3	Set Status Bit Enable	HP 8566A/ HP 8568A	available
R4	R4	Set Status Bit Enable	HP 8566A/ HP 8568A	available
RB	RB <numeric_value> HZ KHZ MHZ GHZ RB DN RB UP RB AUTO RB?	Resolution Bandwidth	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
RBR	RBR <numeric_value> RBR DN RBR UP RBR?	Resolution Bandwidth Ratio	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
RC1...6	RC1...6	Recall Last State	HP 8566A/ HP 8568A	available
RCLS	RCLS <numeric_value>	Recall State Register	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
RCLT	RCLT TRA TRB,<number>	Recall Trace	HP856xE / HP8594E	available in V3.3x and above
RESET	RESET	Instrument preset	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
REV	REV REV?	Firmware revision	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
RL	RL <numeric_value> DB DM RL DN RL UP RL?	Reference Level	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
RLCAL	RLCAL <numeric_value> RL?	Reference Level Calibration	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
RCLOSCAL	RCLOSCAL	Recall Open/ Short Average	HP 856xE / HP 8594E	available in V3.3x and above
RCLTHRU	RCLTHRU	Recall Thru	HP 856xE / HP 8594E	available in V3.3x and above

Command	Supported subset	Function	Corresponding HP-Models	Status
RLPOS ¹⁾	RLPOS <numeric_value> RLPOS DN RLPOS UP RLPOS?	Reference Level Position	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
ROFFSET	ROFFSET <numeric_value> DB DM ROFFSET?	Reference Level Offset	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
RQS	RQS	Service Request Bit mask	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
S1	S1	Continuous Sweep	HP 8566A/ HP 8568A	available
S2	S2	Single Sweep	HP 8566A/ HP 8568A	available
SAVES	SAVES <numeric_value>	Save State Register	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
SAVET	SAVET TRA TRB,<number>	Save Trace	HP856xE / HP8594E	available in V3.3x and above
SMOOTH	SMOOTH TRA TRB TRC, <number of points>	Smooth Trace	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.4x and above
SNGLS	SNGLS	Single Sweep	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
SQUELCH ²⁾	SQUELCH <numeric_value> DM DB SQUELCH UP DN SQUELCH ON OFF	Squelch	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
SP	SP <numeric_value> HZ KHZ MHZ GHZ SP DN SP UP SP?	Span	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
SRCNORM ¹⁾	SRCNORM ON OFF SRCNORM 1 0	Source Normalization	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
SRCPOFS ¹⁾	SRCPOFS <numeric_value> DB DM SRCPOFS DN SRCPOFS UP SRCPOFS?	Source Power Offset	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
SRCPWR 1)	SRCPWR <numeric_value> DB DM SRCPWR DN SRCPWR UP SRCPWR ON SRCPWR OFF SRCPWR?	Source Power	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
SS	SS <numeric_value> HZ KHZ MHZ GHZ SS DN SS UP SS AUTO SS?	CF Step Size	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
ST	ST <numeric_value> US MS SC ST DN ST UP ST AUTO ST?	Sweep Time	HP 8566A/ HP 8568A/ HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
STB	STB	Status byte query	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
STOREOPEN	STOREOPEN	Store Open	HP 856xE / HP 8594E	available in V3.3x and above
STORESHORT	STORESHORT	Store Short	HP 856xE / HP 8594E	available in V3.3x and above
STORETHRU	STORETHRU	Store Thru	HP 856xE / HP 8594E	available in V3.3x and above
SUB		Subtract	HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above
SV1...6	SV1...6	Save State	HP 8566A/ HP 8568A	available
SWPCPL 2)	SWPCPL SA SR SWPCPL?	Sweep Couple	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
SWPOUT 2)	SWPOUT FAV FAVA RAMP SWPOUT?	Sweep Output	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.2x and above
T0	T0	Threshold off	HP 8566A/ HP 8568A	available
T1	T1	Free Run Trigger	HP 8566A/ HP 8568A	available
T2 2)	T2	Line Trigger	HP 8566A/ HP 8568A	available
T3	T3	External Trigger	HP 8566A/ HP 8568A	available

Command	Supported subset	Function	Corresponding HP-Models	Status
T4	T4	Video Trigger	HP 8566A/ HP 8568A	available
TA	TA	Transfer A	HP 8566A/ HP 8568A	available
TACL	TACL?	Returns instantaneous measurement results. See TRACE<trace #>:IMMediate:LEVel? for full description.		available in V3.7x and above
TBCL	TBCL?			
TCCL	TCCL?			
TACR	TACR?	Returns instantaneous measurement results. See TRACE<trace #>:IMMediate:LEVel? for full description.		available in V3.7x and above
TBCR	TBCR?			
TCCR	TCCR?			
TB	TB	Transfer B	HP 8566A/ HP 8568A	available
TDF	TDF P TDF M TDF B TDF A TDF I	Trace Data Format	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
TH	TH <numeric_value> DB DM TH DN TH UP TH ON TH OFF TH AUTO TH?	Threshold	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
THE	THE ON OFF	Threshold Line enable	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
TIMEDSP ¹⁾	TIMEDSP ON OFF TIMEDSP 1 0 TIMEDSP?	Time Display	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
TM	TM FREE VID EXT LINE ²⁾ TM?	Trigger Mode	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
TM LINE ²⁾	TM LINE	Trigger Line	HP 8566B	available in V3.7x and above
TRA	TRA B TRA A TRA I	Transfer A	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available

Command	Supported subset	Function	Corresponding HP-Models	Status
TRB	TRB B TRB A TRB I	Transfer B	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
TRSTAT	TRSTAT?	Trace State Query	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available in V3.3x and above
TS	TS	Take Sweep	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
UR 2)	UR	Plot Command	HP 8566A/ HP 8568A	available in V3.2x and above
VARDEF	VARDEF	Variable definition, arrays are not supported	HP 8566B / HP 8568B / HP 8594E	available in V4.1x and above, ignored in earlier versions
VAVG	VAVG VAVG TRA TRB TRC	Video Averaging	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
VB	VB <numeric_value> HZ KHZ MHZ GHZ VB DN VB UP VB AUTO VB?	Video Bandwidth	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
VBR 1)	VBR <numeric_value> VBR DN VBR UP VBR?	Video Bandwidth Ratio	HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
VIEW	VIEW TRA TRB TRC		HP 856xE / HP 8566B / HP 8568B / HP 8594E	available
VTL	VTL <numeric_value> DB DM VTL DN VTL UP VTL?	Video Trigger Level	HP 856xE / HP 8594E	available in V3.3x and above

1) HP 8594E only

2) Command will be accepted without error message, but will be ignored

Special Features of the Syntax Parsing Algorithms for 8566A and 8568A Models

The command syntax is very different for models A and B. Different names are assigned to identical instrument functions, and the command structure likewise differs considerably between models A and models B.

The command structure for models A is as follows:

```
<command> ::=
<command code>[<SPC>][<data>|<step>][<SPC>][<delimiter>][<command code>]...<delimiter>
```

```
<data> ::= <value>[<SPC>][<units code>][<SPC>][<delimiter>][<SPC>][<data>]...
```

```
<step> ::= UP|DN
```

where

```
<command code> = see Table "Supported Commands"
```

```
<value> = integer or floating-point numerical value
```

```
<units code> = DM | -DM | DB | HZ | KZ | MZ | GZ | MV | UV | SC | MS | US
```

```
<delimiter> = <CR> | <LF> | <,> | <;> | <ETX>
```

```
<SPC> = 3210
```

```
<ETX> = 310
```


Command sections given in [] are optional.

The R&S FSUP GPIB hardware differs from that used in the HP analyzers. Therefore, the following constraint exists:

<LF>| <EOI> are still used as delimiters since the GPIB hardware is able to identify them. The other delimiters are identified and evaluated during syntax analysis.

Special Behavior of Commands

Command	Known Differences
ABORT	Does not automatically set the command complete bit (bit 4) in the status byte. An additional DONE is required for that purpose.
ANNOT	Only frequency axis annotation is affected.
AT	AT DN/UP: Step size
CAL	The CAL commands do not automatically set the command complete bit (bit 4) in the status byte. An additional DONE command is required for that purpose.
CF	Default value, range, step size
CR	Default ratio Span / RBW
CT	Formula for coupled sweeptime
CV	Default ratio RBW / VBW
DET	DET? returns SAMP instead of SMP on the R&S FSUP. DET not automatically set the command complete bit (bit 4) in the status byte. An additional DONE is required for that purpose.
ERR?	Deletes the error bit in the status register but always returns a '0' in response.
FA	Default value, range, step size
FB	Default value, range, step size
ID	Query of instrument type. The instrument type entered with <i>SETUP - GENERAL SETUP - GPIB - ID STRING USER</i> will be returned.
M2	Default value, range, step size
M3	Default value, range, step size
MKACTION	Only marker 1 is supported as the active marker.
MKBW	Default value
MKPT	Step size
MKPX	Step size
OL?	Storage of instrument settings: 80 characters are returned as information on the instrument settings. The contents of the 80 characters returned does not correspond to the original data contents of the 8566A / 8568A family.
OL	Readout of instrument settings: The 80 characters read by means of OL? are accepted as information on the corresponding instrument settings. The contents of the 80 characters read does not correspond to the original data contents of the 8566A / 8568A family.
RB	Default value, range, step size
RL	Default value, step size
RLPOS	Adapts the position of the reference level even if the tracking generator normalization is not active.

Command	Known Differences
RQS	Supported bits: 1 (Units key pressed) 2 (End of Sweep) 3 (Device error) 4 (Command complete) 5 (Illegal command)
SRCNORM	
SRCPWR	
SP	Default value, range, step size
SS	Default value, range, step size
ST	Default value, range, step size
STB	<p>The status bits are mapped as described with command RQS.</p> <hr/> <div style="display: flex; align-items: center;">  <div> <p>Note</p> <p>Bit 2 and 4 are always set in parallel if "Command Complete" or "End of Sweep" are recognized. The R&S FSUP cannot distinguish between these conditions. Additionally these bits are not suitable for synchronization on the end of sweep in continuous sweep operation.</p> </div> </div> <hr/>
TA	Output of 1001 trace points of trace A in O1 or O3 format.
TB	Output of 1001 trace points of trace B in O1 or O3 format.
TH	Default value
VB	Range
VBR	Default value

Model-Dependent Default Settings

If the GPIB language is switched over to an 85xx model, the GPIB address will automatically be switched over to 18 provided that the default address of the R&S FSUP (20) is still set. If a different value is set, this value will be maintained. Upon return to SCPI, this address will remain unchanged.

The following table shows the default settings obtained after a change of the GPIB language and for the commands IP, KST and RESET:

Model	# of Trace Points	Start Freq.	Stop Freq.	Ref Level	Input Coupling
8566A/B	1001	2 GHz	22 GHz	0 dBm	
8568A/B	1001	0 Hz	1.5 GHz	0 dBm	AC
8560E	601	0 Hz	2.9 GHz	0 dBm	AC
8561E	601	0 Hz	6.5 GHz	0 dBm	AC
8562E	601	0 Hz	13.2 GHz	0 dBm	AC
8563E	601	0 Hz	26.5 GHz	0 dBm	AC
8564E	601	0 Hz	40 GHz	0 dBm	AC
8565E	601	0 Hz	50 GHz	0 dBm	AC
8594E	401	0 Hz	3 GHz	0 dBm	AC



Notes regarding the set stop frequency:

The stop frequency given in the table may be limited to the corresponding frequency range of the R&S FSUP.

Command LF sets the stop frequency for 8566A/B to a maximum value of 2 GHz.



Note regarding the number of test points (trace points):

The number of trace points is switched over only upon transition to the REMOTE state.

Data Output Formats

In the case of the SCPI and IEEE488.2 standards, the output formats for numerical data are flexible to a large extent. The output format for the HP units, by contrast, is accurately defined with respect to the number of digits. The memory areas for reading instrument data have therefore been adapted accordingly in the remote-control programs for instruments of this series.

Therefore, in response to a query, the R&S FSUP returns data of the same structure as that used by the original instruments; this applies in particular to the number of characters returned.

Two formats are currently supported when trace data is output: Display Units (command O1) and physical values (command O2, O3 or TDF P). As to the "Display Units" format, the level data of the R&S FSUP is converted to match the value range and the resolution of the 8566/8568 series. Upon transition to the *REMOTE* state, the R&S FSUP is reconfigured such that the number of test points (trace points) corresponds to that of the 85xx families (1001 for 8566A/B and 8568A/B, 601 for 8560E to 8565E, 401 for 8594E).

Trace Data Output Formats

All formats are supported for trace data output: display units (command O1), display units in two byte binary data (command O2 or TDF B and MDS W), display units in one byte binary data (command O4 or TDF B and MDS B) and physical values (commands O3 or TDF P). With format "display units" the level data will be converted into value range and resolution of the 8566/8568 models. On transition to *REMOTE* state the number of trace points will be reconfigured in order to be conform to the selected instrument model (1001 for 8566A/B and 8568 A/B, 601 for 8560E to 8565E, 401 for 8594E).

Trace Data Input Formats

Trace data input is only supported for binary date (TDF B, TDF A, TDF I, MDS W, MDS B).

GPIB Status Reporting

The STB command and the serial poll respond with an 8-bit value having the following assignment:

Bit enabled by RQS	
0	not used (value 0)
1	Units key pressed
2	End of Sweep
3	Device Error
4	Command Complete
5	Illegal Command
6	Service Request
7	not used (value 0)

Bits 0 and 7 are not used and always have the value 0.

Please note that the R&S FSUP reports any key pressed on the front panel rather than only the unit keys if bit 1 was enabled.

Another difference is the behavior of bit 6 when using the STB? query. On the HP analyzers this bit monitors the state of the SRQ line on the bus. On the R&S FSUP this is not possible. Therefore this bit is set, as soon as one of the bits 1 to 5 is set. It won't be reset by performing a serial poll.

Differences in GPIB Behavior between the FSP and the FSE Families of Instruments

The following list of commands contains the differences in syntax and behavior between the GPIB command set of the FSP and the FSE families of instruments. Firmware options are not described in this operating manual as the related commands are not available in the basic instrument. FSE alone in column "Devices" denotes the instrument families FSE, FSIQ, FSET and ESIB, unless otherwise noted in column "Notes".

Devices		Command (<i>Sheet 1 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	*CAL?		R&S FSUP: executes total calibration FSE: executes short calibration
R&S FSUP	FSE	*CLS		
R&S FSUP	FSE	*ESE		
R&S FSUP	FSE	*ESR?		
R&S FSUP	FSE	*IDN?		model indicator and version index is different for R&S FSUP and FSE
R&S FSUP	FSE	*IST?		
R&S FSUP	FSE	*OPC?		
R&S FSUP	FSE	*OPT?		list of available options is slightly different for R&S FSUP and FSE, but equally available options have equal names
R&S FSUP	FSE	*PCB		
R&S FSUP	FSE	*PRE		
R&S FSUP	FSE	*PSC		
R&S FSUP	FSE	*RST		instrument settings are slightly different for R&S FSUP and FSE due to different instrument specs
R&S FSUP	FSE	*SRE		
R&S FSUP	FSE	*STB?		

Devices		Command (Sheet 2 of 47)	Parameter	Notes
R&S FSUP	FSE	*TRG		R&S FSUP starts measurement in active screen FSE: starts measurement in both screens (split screen mode)
R&S FSUP	FSE	*TST?		
R&S FSUP	FSE	*WAI		
R&S FSUP	FSE	ABORT		
R&S FSUP		CALCulate:STATistics:APD[:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:CCDF[:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:NSAMples	100 to 1E9	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:PRESet		new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:Result<1...3>?	MEAN PEAK CFACTOR ALL	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:SCALE:AUTO	ONCE	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:X:RANGE	-10dB to 200dB	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:X:RLEVel	-130dBm to 30dBm	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:Y:LOWer	-1E-9 to 0.1	new function for R&S FSUP
R&S FSUP		CALCulate:STATistics:Y:UPPer	-1E-8 to 1.0	new function for R&S FSUP
	FSE	CALCulate<1 2>:CTHReshold	MIN to MAX	not available in R&S FSUP
	FSE	CALCulate<1 2>:CTHReshold:STATe	ON OFF	not available in R&S FSUP
R&S FSUP		CALCulate<1 2>:DELTAmarker<1...4>:AOFF		markers 2...4 are either normal or delta markers; marker 1 always serves as the reference marker for all deltamarkers
	FSE	CALCulate<1 2>:DELTAmarker<1...4>:AOFF		there are 4 markers and 4 deltamarkers; the most recently used marker serves as the reference marker for all deltamarkers

Devices		Command (Sheet 3 of 47)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:FIXed:RPOint:X	<numeric_value>	R&S FSUP: marker 1 can be moved independently from the reference point FSE: the marker and the reference point are linked to each other
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:FIXed:RPOint:Y	<numeric_value>	R&S FSUP: marker 1 can be moved independently from the reference point; FSE: the marker and the reference point are linked to each other
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:FIXed:RPOint:Y: OFFSet	<numeric_value>	
R&S FSUP		CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:FIXed:RPOint:MAX: PEAK		new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:FIXed[:STATe]	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:PNOise:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:FUNcTion:PNOise[:STATe]	ON OFF	
	FSE	CALCulate<1 2>:DELTamarker<1...4>:MAXimum:APEak		not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MAXimum:LEFT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MAXimum:NEXT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MAXimum:RIGHT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MAXimum[:PEAK]		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MINimum:LEFT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MINimum:NEXT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MINimum:RIGHT		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MINimum[:PEAK]		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:MODE	ABSolute RELative	
	FSE	CALCulate<1 2>:DELTamarker<1...4>:STEP:AUTO	ON OFF	not available for R&S FSUP
	FSE	CALCulate<1 2>:DELTamarker<1...4>:STEP[:INCRement]	<numeric_value>	not available for R&S FSUP

Devices		Command (<i>Sheet 4 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:TRACe	1 to 3	R&S FSUP: 3 traces are available per screen; FSE: 4 traces are available in full screen mode and 2 traces per screen in split screen mode
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:X	0 to MAX (frequency sweep time)	unit 'SYM' is not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:X:RELative		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>:Y?		
R&S FSUP	FSE	CALCulate<1 2>:DELTamarker<1...4>[:STATe]	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:DLINe<1 2>	MIN to MAX	
R&S FSUP	FSE	CALCulate<1 2>:DLINe<1 2>:STATe	ON OFF	
	FSE	CALCulate<1 2>:FEED	'XTIM:DDEM:MEAS' 'XTIM:DDEM:REF' 'XTIM:DDEM:ERR:MPH' 'XTIM:DDEM:ERR:VECT' 'XTIM:DDEM:SYMB' 'XTIM:AM' 'XTIM:FM' 'XTIM:PM' 'XTIM:AMSummary' 'XTIM:FMSummary' 'XTIM:PMSummary' 'TCAP'	not available for R&S FSUP
	FSET	CALCulate<1 2>:FEED	'XTIM:DDEM:MEAS' 'XTIM:DDEM:REF' 'XTIM:DDEM:ERR:MPH' 'XTIM:DDEM:ERR:VECT' 'XTIM:DDEM:SYMB' 'TCAP'	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:FLINe<1 2>	0 to f_{max}	
R&S FSUP	FSE	CALCulate<1 2>:FLINe<1 2>:STATe	ON OFF	
	FSE	CALCulate<1 2>:FORMat	MAGNitude PHASe UPHase RIMag FREQuency IEYE QEYE TEYE FEYE COMP CONS	not available for R&S FSUP
	FSE	CALCulate<1 2>:FSK:DEVIation:REFerence	<numeric value>	not available for R&S FSUP
	FSE	CALCulate<1 2>:LIMit<1...8>:ACPoweR:ACHannel	0 to 100 DB, 0 to 100 DB	compatible to CALCulate<1 2>:LIMit<1...8>:ACPoweR:ACHannel[:RELative] of R&S FSUP not available for FSET

Devices		Command (Sheet 5 of 47)	Parameter	Notes
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel:ABSolute	-200 to 200 DBM, -200 to 200 DBM	new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel:ABSolute:STATe	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel:RESult?		
	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel:STATe	ON OFF	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ACHannel[:RELative]: STATe of R&S FSUP not available for FSET
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel[:RELative]	0 to 100 DB, 0 to 100 DB	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ACHannel of FSE
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ACHannel[:RELative]:STATe	ON OFF	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ACHannel:STATe of FSE
	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>	0 to 100 DB, 0 to 100 DB	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ALternate<1 2> [:RELative] of R&S FSUP not available for FSET
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>:ABSolute	-200 to 200 DBM, -200 to 200 DBM	new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>:ABSolute:STATe	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>:RESult?		
	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>:STATe	ON OFF	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ALternate<1 2> [:RELative]:STATe of R&S FSUP not available for FSET
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>[:RELative]	0 to 100 DB, 0 to 100 DB	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ALternate<1 2> of FSE
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:ACPowEr: ALternate<1 2>[:RELative]:STATe	ON OFF	compatible to CALCulate<1 2>: LIMit<1...8>:ACPowEr: ALternate<1 2>: STATe of FSE
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:ACPowEr[:STATe]	ON OFF	

Devices		Command (Sheet 6 of 47)	Parameter	Notes
	FSE	CALCulate<1 2>:LIMit<1...8>:BURSt:POWer?		not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:BURSt:PTEMplate?		not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate:LIMit:CATalog?		not available in R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CLEar[:IMMediate]		
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:COMMeNt	<string>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:DOMain	FREQUency TIME	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:MODE	RELative ABSolute	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:OFFset	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:SHIFt	<numeric_value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:SPACing	LINear LOGarithmic	
	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol:UNIT[:TIME]	S SYM	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:CONTRol[:DATA]	<numeric value>, <numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:COPY	1 to 8 <name>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:DELeTe		
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:FAIL?		
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:MARGIn	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:MODE	RELative ABSolute	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:OFFset	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:SHIFt	<numeric_value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:SPACing	LINear LOGarithmic	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer:STATe	ON OFF	
		CALCulate<1 2>:LIMit<1...8>:LOWer:THReshold	<numeric value>	new function for R&S FSUP

Devices		Command (Sheet 7 of 47)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:LOWer[:DATA]	<numeric value>	
	FSE	CALCulate<1 2>:LIMit<1...8>:MARGin	0 to 100DB	not available for R&S FSUP, FSET and ESIB
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:NAME	1 to 8 <string>	
	FSE	CALCulate<1 2>:LIMit<1...8>:SPECTrum: MODulation:EXCEPTIONs?	ARFCn TXBand RXBand COMBined DCSRx1800	not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPECTrum: MODulation:FAILs?	ARFCn TXBand RXBand COMBined DCSRx1800	not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPECTrum: MODulation?	ARFCn TXBand RXBand COMBined DCSRx1800	not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPECTrum: SWITChing:FAILs?		not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPECTrum: SWITChing?		not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPURious:FAILs?	TXBand OTXBand RXBand IDLeband	not available for R&S FSUP, FSET and ESIB
	FSE	CALCulate<1 2>:LIMit<1...8>:SPURious?	TXBand OTXBand RXBand IDLeband	not available for R&S FSUP, FSET and ESIB
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:STATE	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:TRACe	1 to 3	R&S FSUP: 3 traces are available per screen FSE: 4 traces are available in full screen mode and 2 traces per screen in split screen mode
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:UNIT	DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DBUV_M DBUA_M DEG RAD S HZ PCT UNITLESS	Available units are compatible to the FSE
	FSE/FSIQ	CALCulate<1 2>:LIMit<1...8>:UNIT	DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBUA_M DBUV_MHZ DBUA_MHZ DEG RAD S HZ PCT UNITLESS	only the following units are available for the R&S FSUP:DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DBUV_M DBUA_M DEG RAD S HZ PCT UNITLESS

Devices		Command (Sheet 8 of 47)	Parameter	Notes
	FSET/ ESIB	CALCulate<1 2>:LIMit<1...8>:UNIT	DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBUA_M DBUV_MHZ DBUA_MHZ DEG RAD S HZ PCT UNITLESS	only the following units are available for the R&S FSUP:DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DBUV_M DBUA_M DEG RAD S HZ PCT UNITLESS
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:MARGin	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:MODE	RELative ABSolute	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:OFFset	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:SHIFt	<numeric_value>	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:SPACing	LINear LOGarithmic	
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer:STATe	ON OFF	
R&S FSUP		CALCulate<1 2>:LIMit<1...8>:UPPer:THReshold	<numeric value>	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:LIMit<1...8>:UPPer[:DATA]	<numeric value>	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:AOFF		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:COUNT	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:COUNT: FREQUency?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:COUNT: RESolution	0.1 1 10 100 1000 10000 Hz	
	FSE	CALCulate<1 2>:MARKer<1...4>: COUPLed[STATe]	ON OFF	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:AFREQUency[:RESult]?		not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:AM[:RESult]?	PPEak MPEak MIDDLE RMS	not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:CARRier[:RESult]?		not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:FERRor[:RESult]?		not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:FM[:RESult]?	PPEak MPEak MIDDLE RMS RDEV	not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNCTION: ADEMod:PM[:RESult]?	PPEak MPEak MIDDLE RMS	not available for R&S FSUP and FSET

Devices		Command (Sheet 9 of 47)	Parameter	Notes
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: ADEMod:SINad:RESult?		not available for R&S FSUP and FSET
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: ADEMod:SINad[:STATe]	ON OFF	not available for R&S FSUP and FSET
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: CENTer		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: CSTep		
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: DDEMod:RESult?	MERM MEPK MEPS PERM PEPK PEPS EVRM EVPK EVPS IQOF IQIM ADR FERR FEPK RHO DEV FSRM R&S FSUPK R&S FSUPS DTTS	not available for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: DEModulation: CONTinuous		new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: DEModulation:HOLDoff	10ms to 1000s	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: DEModulation:SElect	AM FM	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: DEModulation[:STATe]	ON OFF	
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: FPEaks[:IMMediate]	<numeric value>	new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: FPEaks:COUNT?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: FPEaks:X?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: FPEaks:Y?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: FPEaks:SORT	X Y	new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: MDEPth:RESult?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: MDEPth[:STATe]		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctIon: MSUMmary?	<numeric_value>, <numeric_value>, <numeric_value>, <numeric_value>	new function for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: MSTep		not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: NDBDown	<numeric_value>	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctIon: NDBDown:FREQuency?		

Devices		Command (Sheet 10 of 47)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:NDBDown:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:NDBDown:STATe	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:NOISe:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:NOISe:STATe	ON OFF	
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer:CFILter	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer:PRESet	NADC TETRA PDC PHS CDPD FWCDma RWCDma F8CDma R8CDma F19Cdma R19Cdma FW3Gppcdma RW3Gppcdma D2CDma S2CDma M2CDma NONE	available standards are compatible to the FSE
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer:RESult:PHZ	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer:RESult?	ACPower CPOWer OBANdwidth OBWidth MCACpower	MCACpower is not available on the FSE MCACpower, ACPower and CPOWer are not available on the FSET
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer:SElect?	ACPower CPOWer OBANdwidth OBWidth CN CN0 MCACpower	MCACpower is not available on the FSE MCACpower, ACPower and CPOWer are not available on the FSET
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:POWer[:STATe]	OFF	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:REFerence		
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:SFACtor	(60dB/3dB) (60dB/6dB)	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:SFACtor:FREQuency?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:SFACtor:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:SFACtor:STATe	ON OFF	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:STARt		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNctio:n:STOP		not available for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNctio:n:STRack: BANDwidth BWIDth	10 Hz to MAX(span)	new function for R&S FSUP. Replaces DISP:FLINE of the FSE.

Devices		Command (Sheet 11 of 47)	Parameter	Notes
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNction:STRack:THReshold	-330 to +30 dBm	new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNction:STRack:TRACe	1 to 3	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:STRack[:STATe]	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:AOff		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:AVERAge	ON OFF	
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MAXimum: AVERAge:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MAXimum: PHOLd:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MAXimum: RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MAXimum [:STATe]	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MEAN: AVERAge:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MEAN:PHOLd:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MEAN:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MEAN[:STATe]	ON OFF	
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MIDdle: AVERAge:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MIDdle: PHOLd:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MIDdle: RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MIDdle [:STATe]	ON OFF	not available for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MODE	ABSolute RELative	new function for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MPEak: AVERAge:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MPEak: PHOLd:RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MPEak: RESult?		not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:MPEak [:STATe]	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNction:SUMMary:PHOLd	ON OFF	

Devices		Command (<i>Sheet 12 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:PPEak: AVERAge:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:PPEak:PHOLd:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:PPEak:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:PPEak[:STATe]	ON OFF	
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:REFEreNce: AUTO	ONCE	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:RMS:AVERAge:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:RMS:PHOLd: RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:RMS:RESult?		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:RMS[:STATe]	ON OFF	
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:SDEVIation: RESult?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMarySDEVIation: AVERAge:RESult?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:SDEVIation: PHOLd:RESult?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary:SDEVIation [:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:SUMMary[:STATe]	ON OFF	
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:TOI:RESult?		new function for R&S FSUP
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:FUNcTion:TOI[:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:FUNcTion:ZOOM	<numeric_value>	R&S FSUP: function uses always marker 1 as its reference marker; FSE: all available markers can be used as a reference marker
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:LOEXclude	ON OFF	
	FSE	CALCulate<1 2>:MARKer<1...4>:MAXimum:APEak		not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MAXimum:LEFT		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MAXimum:NEXT		

Devices		Command (<i>Sheet 13 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MAXimum:RIGHT		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MAXimum[:PEAK]		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MINimum:LEFT		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MINimum:NEXT		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MINimum:RIGHT		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:MINimum[:PEAK]		
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:PEXCursion	<numeric_value>	
	FSE	CALCulate<1 2>:MARKer<1...4>:READout	MPHase RIMaginary	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:SCOupled[STATE]	ON OFF	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:STEP:AUTO	ON OFF	not available for R&S FSUP
	FSE	CALCulate<1 2>:MARKer<1...4>:STEP[:INCREMENT]	<numeric_value>	not available for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:TRACe	1 to 3	R&S FSUP: 3 traces are available per screen FSE: 4 traces are available in full screen mode and 2 traces per screen in split screen mode
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:X	0 to MAX (frequency sweep time)	additional unit SYM is available for FSE
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:X:SLIMits:LEFT	0 to MAX (frequency sweep time)	new function for R&S FSUP. Replaces DISP:FLIN and DISP:TLIN commands of the FSE
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:X:SLIMits:RIGHT	0 to MAX (frequency sweep time)	new function forR&S FSUP. Replaces DISP:FLIN and DISP:TLIN commands of the FSE
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:X:SLIMits[:STATE]	ON OFF	
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>:Y?		
R&S FSUP		CALCulate<1 2>:MARKer<1...4>:Y:PERCent	<numeric_value>	new function for R&S FSUP
R&S FSUP	FSE	CALCulate<1 2>:MARKer<1...4>[:STATE]	ON OFF	

Devices		Command (Sheet 14 of 47)	Parameter	Notes
R&S FSUP		CALCulate<1 2>:MATH:MODE	LINear LOGarithmic	affects all traces on the R&S FSUP; therefore the numeric suffix : MATH<1...4> is not allowed for the R&S FSUP
	FSE	CALCulate<1 2>:MATH<1...4>:MODE	LINear LOGarithmic	for FSE, only the trace indicated by a numeric suffix is affected
R&S FSUP		CALCulate<1 2>:MATH:POS	-100PCT to 200PCT	new function for R&S FSUP; replacement for CALC:RLINe of the FSE
R&S FSUP	FSE	CALCulate<1 2>:MATH:STATe	ON OFF	for R&S FSUP, traces can only be subtracted from trace 1; therefore there is no numeric suffix behind :MATH
R&S FSUP	FSE	CALCulate<1 2>:MATH[:EXPRession][:DEFine]	<expr>	for R&S FSUP, traces can only be subtracted from trace 1; therefore there is no numeric suffix behind :MATH and <expr> may only consist of (TRACE1-TRACE2) or (TRACE1-TRACE3)
	FSE	CALCulate<1 2>:RLINe	MIN to MAX	not available for R&S FSUP (replaced by CALC:MATH:POS)
	FSE	CALCulate<1 2>:RLINe:STATe	ON OFF	not available for R&S FSUP (replaced by CALC:MATH:POS)
R&S FSUP	FSE	CALCulate<1 2>:THReshold	MIN to MAX	
R&S FSUP	FSE	CALCulate<1 2>:THReshold:STATe	ON OFF	
	FSE	CALCulate<1 2>:TLINe<1 2>	0 to 1000s	not available on the R&S FSUP; replaced by CALC:SLIMits:LEFT and CALC:SLIMits:RIGHT
	FSE	CALCulate<1 2>:TLINe<1 2>:STATe	ON OFF	not available on the R&S FSUP; replaced by CALC:SLIMits:LEFT and CALC:SLIMits:RIGHT
	FSE	CALCulate<1 2>:UNIT:ANGLe	DEG RAD	not available for R&S FSUP
R&S FSUP		CALCulate<1 2>:UNIT:POWER	DBM V A W DBPW WATT DBUV DBMV VOLT DBUA AMPere	available units are compatible to the FSE

Devices		Command (Sheet 15 of 47)	Parameter	Notes
	FSET/ ESIB	CALCulate<1 2>:UNIT:POWer	DBM V W DB PCT UNITLESS DBPW WATT DBUV DBMV VOLT DBUA AMPere DBPT DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBUA_M DBUV_MMHZ DBUA_MMHZ	the R&S FSUP supports the following units:DBM V A W DBPW WATT DBUV DBMV VOLT DBUA AMPere
	FSE/ FSIQ	CALCulate<1 2>:UNIT:POWer	DBM V W DB PCT UNITLESS DBPW WATT DBUV DBMV VOLT DBUA AMPere DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBUA_M DBUV_MMHZ DBUA_MMHZ	the R&S FSUP supports the following units:DBM V A W DBPW WATT DBUV DBMV VOLT DBUA AMPere
	FSE	CALCulate<1 2>:X:UNIT:TIME	S SYM	not available for R&S FSUP
R&S FSUP		CALibration:ABORt		new function for R&S FSUP
	FSE	CALibration:BANDwidth BWIDTH[:RESolution]?		not available for R&S FSUP
	FSE	CALibration:IQ?		not available for R&S FSUP
	FSE	CALibration:LDEtector?		not available for R&S FSUP
	FSE	CALibration:LOSuppression?		not available for R&S FSUP
	FSE	CALibration:PPEak?		not available for R&S FSUP
	ESIB	CALibration:PRESelector?		not available for R&S FSUP
		CALibration:RESult?		new function for R&S FSUP
	FSE	CALibration:SHORT?		not available for R&S FSUP
R&S FSUP	FSE	CALibration:STATE	ON OFF	
R&S FSUP	FSE	CALibration[:ALL]?		
	FSE	CONFigure:BURSt:PFERror:COUNT	1 to 1000	not available for R&S FSUP and FSET
	FSE	CONFigure:BURSt:PFERror[IMMediate]		not available for R&S FSUP and FSET
	FSE	CONFigure:BURSt:POWer:CONDition	NORMal EXTRemE	not available for R&S FSUP and FSET

Devices	Command (Sheet 16 of 47)	Parameter	Notes
FSE	CONFigure:BURSt:POWer:COUNT	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:BURSt:POWer[IMMediate]		not available for R&S FSUP and FSET
FSE	CONFigure:BURSt:PTEMplate:[IMMediate]		not available for R&S FSUP and FSET
FSE	CONFigure:BURSt:PTEMplate:COUNT	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:BURSt:PTEMplate:SElect	FULL TOP RISing FALLing	not available for R&S FSUP and FSET
FSE	CONFigure:BURSt:REFerence:AUTO	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:MODulation:COUNT	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:MODulation:RANGe	ARFCn TXBand RXBand COMBined DCSRx1800	not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:MODulation:TGATe	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:MODulation:[IMMediate]		not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:SWITChing:COUNT	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:SPECtrum:SWITChing:[IMMediate]		not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:ANTenna	CONDUCTed RADiated	not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:COUN:RXBandt	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:COUNT	1 to 1000	not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:RANGe	TXBand OTXBand RXBand IDLeband COMBined	not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:STEP:COUNT?		not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:STEP<1..26>	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure:SPURious:[IMMediate]		not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:ARFCn	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:ARFCn:AUTO	ONCE	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:CHANnel:SFH	ON OFF	not available for R&S FSUP and FSET

Devices	Command (<i>Sheet 17 of 47</i>)	Parameter	Notes
FSE	CONFigure[:BTS]:CHANnel:SLOT	0 to 7	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:CHANnel:SLOT:AUTO	ONCE	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:CHANnel:TSC	0 to 7	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:CHANnel:TSC:AUTO	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:COSiting	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:LIMit:FREQency	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:LIMit:PPEak	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:LIMit:PRMS	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:LIMit:STANdard	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:NETWork:PHASe	1 2[,PLUS]	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:NETWork[:TYPE]	PGSM PGSM900 EGSM EGSM900 DCS GSM1800 PCS GSM1900 RGSM RGSM900	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:CLASs	1 to 8 1 to 4 M1 M2 M3	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:COUPled	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:DYNamic	0 to 15	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:EXPEcted	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:LIMit	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:SINGle:CLEar		not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:SINGle[:STATE]	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:POWer:STATic	0 to 6	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:PRESet		not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:SWEeptime	STANdard AUTO	not available for R&S FSUP and FSET
FSE	CONFigure[:BTS]:TXSupp	ON OFF	not available for R&S FSUP and FSET

Devices	Command (Sheet 18 of 47)	Parameter	Notes
FSE	CONFigure[:BTS]MEASurement?		not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:ARFCn	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:ARFCn:AUTO	ONCE	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:CHANnel:SFH	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:CHANnel:TSC	0 to 7	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:LIMit:FREQuency	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:LIMit:PPEak	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:LIMit:PRMS	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:LIMit:STANdard	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:NETWork:PHASe	1 2[,PLUS]	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:NETWork[:TYPE]	PGSM PGSM900 EGSM EGSM900 DCS GSM1800 PCS GSM1900 RGSM RGSM900	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:CLASs	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:COUPled	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:EXPEcted	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:LEVel	0 to 31	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:LIMit	<numeric_value>	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:SINGLE:CLEar		not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:SINGLE[:STATE]	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:POWer:SMALI	ON OFF	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:PRESet		not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:SWEeptime	STANdard AUTO	not available for R&S FSUP and FSET
FSE	CONFigure[:MS]:TXSupp	ON OFF	not available for R&S FSUP and FSET

Devices		Command (Sheet 19 of 47)	Parameter	Notes
	FSE	CONFigure[:MS]MEASurement?		not available for R&S FSUP and FSET
	FSET	DIAGnostic:INFO:CCOunt:ATTenuation?		not available for R&S FSUP
	FSE	DIAGnostic:INFO:CCOunt:ATTenuation<1 10>?		not available for R&S FSUP
	FSIQ	DIAGnostic:INFO:CCOunt:ATTenuation<1 2 3>?		not available for R&S FSUP
	ESIB	DIAGnostic:INFO:CCOunt:ATTenuation<1 2 4>?		not available for R&S FSUP
	FSE	DIAGnostic:INFO:CCOunt:PRESelector<1..6>?		not available for R&S FSUP
R&S FSUP		DIAGnostic:SERvice:CSOource[:POWer]	<numeric_value>	new function for R&S FSUP
	FSE	DIAGnostic:SERvice:FUNCTion	<numeric_value>, <numeric_value> to	not available for R&S FSUP. Replaced by DIAG:SERV:SFUNCTion
	FSET	DIAGnostic:SERvice:HGENerator	OFF 10 kHz 100 kHz BALanced	not available for R&S FSUP
R&S FSUP		DIAGnostic:SERvice:HWINfo?		new function for R&S FSUP
R&S FSUP	FSE	DIAGnostic:SERvice:INPut[:SElect]	CALibration RF	
R&S FSUP		DIAGnostic:SERvice:INPut:PULSed[:STATe]	ON OFF	new command for R&S FSUP
R&S FSUP		DIAGnostic:SERvice:INPut:PULSed:PRATe	<numeric_value>	new command for R&S FSUP
R&S FSUP	FSE	DIAGnostic:SERvice:NSOource	ON OFF	
R&S FSUP		DIAGnostic:SERvice:SFUNCTion	<string> to	replacement for DIAG:SERV:FUNC of R&S FSUP; necessary due to different parameter formats needed on the R&S FSUP
R&S FSUP		DIAGnostic:SERvice:STEST:RESult?		new function for R&S FSUP
R&S FSUP	FSE	DISPlay:ANNotation:FREQUency	ON OFF	
		DISPlay:BARGraph:LEVel:LOWer		not available for R&S FSUP
		DISPlay:BARGraph:LEVel:UPPer		not available for R&S FSUP
R&S FSUP	FSE	DISPlay:CMAP<1...26>:DEFault<1 2>		larger selection of independently configurable items (1 to 26)

Devices		Command (Sheet 20 of 47)	Parameter	Notes
R&S FSUP	FSE	DISPlay:CMAP<1...26>:HSL	0 to 1,0 to 1,0 to 1	larger selection of independently configurable items (1 to 26)
R&S FSUP	FSE	DISPlay:CMAP<1...26>:PDEFined	<color>	larger selection of independently configurable items (1 to 26)
R&S FSUP	FSE	DISPlay:FORmat	SINGle SPLit	
R&S FSUP	FSE	DISPlay:LOGO	ON OFF	
	FSE	DISPlay:PROGram[:MODE]	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	DISPlay:PSAVe:HOLDoff	0 to 60	
R&S FSUP	FSE	DISPlay:PSAVe[:STATe]	ON OFF	
	FSE	DISPlay[:WINDow<1 2>]:FEED	'AF' 'VIDeo'	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:MINFo	ON OFF	not available for R&S FSUP
R&S FSUP		DISPlay[:WINDow<1 2>]:SElect		new function for R&S FSUP
R&S FSUP		DISPlay[:WINDow<1 2>]:SIZE	LARGE SMALI	new function for R&S FSUP
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TEXT:STATe	ON OFF	
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TEXT[:DATA]	<string>	
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TIME	ON OFF	
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:MODE	WRITe VIEW AVERAge MAXHold MINHold	R&S FSUP: 3 traces are available per screen FSE: 4 traces are available in full screen mode and 2 traces per screen in split screen mode
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:EYE: COUNT	1 to Result Length	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:MODE: ANALog	ON OFF	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:MODE: CWRite	ON OFF	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:MODE: HCONTinuous	ON OFF	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:SYMBOL	DOTS BARS OFF	not available for R&S FSUP

Devices		Command (Sheet 21 of 47)	Parameter	Notes
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X:SPACing	LINear LOGarithmic	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X[:SCALe]:RVALue	<numeric_value>	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X[:SCALe]:ZOOM	ON OFF	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:CENTer	<numeric_value>	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:START	<numeric_value>	not available for R&S FSUP
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:X[:SCALe]:ZOOM[:FREQuency]:STOP	<numeric_value>	not available for R&S FSUP
R&S FSUP		DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y:SPACing	LINear LOGarithmic LDB	R&S FSUP: TRACe<1...3> LDB is not available for FSE
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:Y:SPACing	LINear LOGarithmic PERCent	PERCent is not available for R&S FSUP FSE: TRACE<1...4>
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]	10dB to 200dB	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
	FSET/ESIB	DISPlay[:WINDow<1 2>]:TRACe<1...4>:Y[:SCALe]:BOTTom	<numeric_value>	not available for R&S FSUP
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]:MODE	ABSolute RELative	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:Y[:SCALe]:PDIVision		not available for R&S FSUP
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]:RLEVEL	-130dBm to 30dBm	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]:RLEVEL:OFFSet	-200dB to 200dB	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]:RPOSITION	0 to 100 PCT	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
R&S FSUP	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...3>:Y[:SCALe]:RVALue	<numeric_value>	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
	FSE	DISPlay[:WINDow<1 2>]:TRACe<1...4>:Y[:SCALe]:RVALue:AUTO	ON OFF	not available for R&S FSUP
	FSET/ESIB	DISPlay[:WINDow<1 2>]:TRACe<1...4>:Y[:SCALe]:TOP	<numeric_value>	not available for R&S FSUP

Devices		Command (Sheet 22 of 47)	Parameter	Notes
R&S FSUP		DISPlay[:WINDow<1 2>]:TRACe<1...3>[:STATe]	ON OFF	R&S FSUP: TRACe<1...3> FSE: TRACE<1...4>
	FSE	FETCh:BURSt:FERRor:AVERAge?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:FERRor:MAXimum?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:FERRor:STATus?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:PEAK:AVERAge?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:PEAK:MAXimum?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:PEAK:STATus?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:RMS:AVERAge?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:RMS:MAXimum?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:PERRor:RMS:STATus?		not available for R&S FSUP and FSET
	FSE	FETCh:BURSt:POWER[:IMMEdiate]?		not available for R&S FSUP and FSET
	FSE	FETCh:MODulation[:ALL]?	ARFCn TXBand RXBand COMBined DCSRx1800	not available for R&S FSUP and FSET
	FSE	FETCh:PTEMplate:REFerence?	TXBand	not available for R&S FSUP and FSET
	FSE	FETCh:SPECTrum:MODulation:REFerence?	TXBand	not available for R&S FSUP and FSET
	FSE	FETCh:SPECTrum:SWITChing:REFerence?	TXBand	not available for R&S FSUP and FSET
	FSE	FETCh:SPECTrum:SWITChing[:ALL]?		not available for R&S FSUP and FSET
	FSE	FETCh:SPURious:STEP?		not available for R&S FSUP and FSET
	FSE	FETCh:SPURious[:ALL]?	TXBand OTXBand RXBand IDLeband	not available for R&S FSUP and FSET
	FSE	FORMat:DEXPort:APPend[:STATe] ON OFF[,32]		not available for R&S FSUP
R&S FSUP	FSE	FORMat:DEXPort:DSEParator	POINT COMMa	
	FSE	FORMat:DEXPort:HEADer[:STATe] ON OFF[,32]		not available for R&S FSUP
R&S FSUP		FORMat[:DATA]	ASCIi REAL[,32]	

Devices		Command (<i>Sheet 23 of 47</i>)	Parameter	Notes
	FSE	FORMat[:DATA]	ASCIi REAL UINt [,32]	UINt is not available for R&S FSUP
R&S FSUP	FSE	HCOPy:ABORt		
R&S FSUP		HCOPy:CMAP:DEFault		new function for R&S FSUP
R&S FSUP		HCOPy:CMAP:HSL	<numeric_value>, <numeric_value>, <numeric_value>	new function for R&S FSUP
R&S FSUP		HCOPy:CMAP:PDEFined	<char data>	new function for R&S FSUP
R&S FSUP		HCOPy:DESTination<1 2>	'MMEM' 'SYST:COMM:PRIN' 'SYST:COMM:CLIP'	
	FSE/ FSET	HCOPy:DESTination<1 2>	'SYST:COMM:GPIB' 'SYST:COMM:SER1' 'SYST:COMM:SER2' 'SYST:COMM:CENt' 'MMEM' 'SYST:COMM:PRIN' 'SYST:COMM:CLIP'	SYST:COMM:GPIB/SER1/SER2 is not available for R&S FSUP
	FSIQ/ ESIB	HCOPy:DESTination<1 2>	'MMEM' 'SYST:COMM:PRIN' 'SYST:COMM:CLIP'	
R&S FSUP	FSE	HCOPy:DEVice:COLor	ON OFF	
R&S FSUP		HCOPy:DEVice:LANGUage<1 2>	GDI WMF EWMF BMP	
	FSE/ FSET	HCOPy:DEVice:LANGUage<1 2>	HPGL PCL4 PCL5 POSTscript ESCP WMF PCX HP7470 to	
	FSIQ/ ESIB	HCOPy:DEVice:LANGUage<1 2>	WMF GDI EWMF BMP to	
	FSE/ FSET	HCOPy:DEVice:PRESet<1 2>	ON OFF	not available for R&S FSUP
	FSE/ FSET	HCOPy:DEVice:RESolution<1 2>	150 300	not available for R&S FSUP
R&S FSUP	FSE	HCOPy:ITEM:ALL		
	FSE	HCOPy:ITEM:FFEed<1 2>:STATe	ON OFF	not available for R&S FSUP
	FSE	HCOPy:ITEM:LABel:TEXT	<string>	not available for R&S FSUP
	FSE	HCOPy:ITEM:PFEed<1 2>:STATe	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	HCOPy:ITEM:WINDow<1 2>:TABLe:STATe	ON OFF	
R&S FSUP	FSE	HCOPy:ITEM:WINDow<1 2>:TEXT	<string>	

Devices		Command (Sheet 24 of 47)	Parameter	Notes
	FSE	HCOPY:ITEM:WINDow<1 2>:TRACe:CAINcrement	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	HCOPY:ITEM:WINDow<1 2>:TRACe:STATe	ON OFF	
	FSE	HCOPY:PAGE:DIMensions:FULL		not available for R&S FSUP
	FSE	HCOPY:PAGE:DIMensions:QUADrant<1...4>		not available for R&S FSUP
R&S FSUP	FSE	HCOPY:PAGE:ORientation<1 2>	LANDscape PORTrait	
R&S FSUP	FSE	HCOPY[:IMMediate]		
	FSET/ESIB	HOLD		not available for R&S FSUP
R&S FSUP	FSE	INITiate<1 2>:CONMeas	ON OFF	
R&S FSUP	FSE	INITiate<1 2>:CONTInuous	ON OFF	
R&S FSUP	FSE	INITiate<1 2>:DISPlay	ON OFF	
R&S FSUP	FSE	INITiate<1 2>[:IMMediate]		
	FSET	INPut:PRESelection:CATalog?		not available for R&S FSUP
	FSET	INPut:PRESelection:USET:NAME	'name of user defined preselector set (to edit existing set or to create new set)'	not available for R&S FSUP
	FSET	INPut:PRESelection:USET:CLEar		not available for R&S FSUP
	FSET	INPut:PRESelection:USET:COMMeNT	'comment for preselector-set'	not available for R&S FSUP
	FSET	INPut:PRESelection:USET:LRANge[:DATA]	<numeric_value>, <numeric_value>, <numeric_value>	not available for R&S FSUP
	FSET	INPut:PRESelection:USET:MRANge[:DATA]	<numeric_value>, <numeric_value>, <numeric_value>	not available for R&S FSUP
R&S FSUP	FSE	INPut<1 2>:ATTenuation	0 to 70dB	
	FSET	INPut<1 2>:ATTenuation	0 to 70 80dB	80 dB not available for R&S FSUP
R&S FSUP	FSE	INPut<1 2>:ATTenuation:AUTO	ON OFF	

Devices		Command (Sheet 25 of 47)	Parameter	Notes
R&S FSUP	FSE	INPut<1 2>:ATTenuation:AUTO:MODE	NORMal LNOise LDISTorsion	not available for models 3 and 7; not available for R&S FSUP
	FSET/ESIB	INPut<1 2>:ATTenuation:PROTection	ON OFF	not available for R&S FSUP
R&S FSUP		INPut<1 2>:ATTenuation:PROTection:PRESet		new function for R&S FSUP
	FSET	INPut<1 2>:ATTenuation:STEPsize	1dB 10dB	not available for R&S FSUP
	FSET	INPut<1 2>:BIMPedance	150OHM 600OHM 10kOHM	not available for R&S FSUP
	FSET	INPut<1 2>:COUPling	AC DC	only available for R&S FSUP models 3, 8, 26
		INPut<1 2>:EATT	0 to 30dB	new function for R&S FSUP
		INPut<1 2>:EATT:AUTO	ON OFF	new function for R&S FSUP
		INPut<1 2>:EATT:STATe	ON OFF	new function for R&S FSUP
	FSET	INPut<1 2>:GAIN	0 to 30dB	not available for R&S FSUP
	FSET/ESIB	INPut<1 2>:GAIN:AUTO	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	INPut<1 2>:GAIN:STATe	ON OFF	
R&S FSUP	FSE	INPut<1 2>:IMPedance	50 75	
	FSE	INPut<1 2>:IMPedance:CORRection	RAM RAZ	not available for R&S FSUP
	FSET	INPut<1 2>:LISN:PEARth	GROunded FLOating	not available for R&S FSUP
	FSET	INPut<1 2>:LISN:PHASe	L1 L2 L3 N	not available for R&S FSUP
	FSET	INPut<1 2>:LISN[:TYPE]	TWOphase FOURphase OFF	not available for R&S FSUP
R&S FSUP	FSE	INPut<1 2>:MIXer	<numeric_value>	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:COUPling	ON OFF	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:COUPling:HIGH:FREQuency	5MHz to 500MHz	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:COUPling:HIGH:SET	'name of preselector set for high RBW'	not available for R&S FSUP

Devices		Command (Sheet 26 of 47)	Parameter	Notes
	FSET	INPut<1 2>:PRESelection:COUPling:LOW:FREQUency	10Hz to 5MHz	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:COUPling:LOW:SET	'name of preselector set for low RBW'	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:COUPling:MID:SET	'name of preselector set for medium RBW'	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:FILTer:HPASS[:FREQUency]	100Hz to 5MHz	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:FILTer:LPASS[:FREQUency]	20KHz to 40MHz	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:FILTer[:STATe]	ON OFF	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:SET	NARROW NORMAl WIDE	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection:USET[:SElect]	'name of user defined preselector set'	not available for R&S FSUP
	FSET	INPut<1 2>:PRESelection[:STATe]	ON OFF	not available for R&S FSUP
	FSET	INPut<1 2>:TYPE	RF BALanced	not available for R&S FSUP
	ESIB	INPut<1 2>:TYPE	INPUT1 INPUT2	not available for R&S FSUP
	FSE	INPut<1 2>:UPORt<1 2>:STATe	ON OFF	not available for R&S FSUP
	FSE	INPut<1 2>:UPORt<1 2>[:VALue]?		not available for R&S FSUP
	ESIB	INPut2:COUPling	AC DC	not available for R&S FSUP
		INSTRument:COUPlE	NONE RLeVel CF_B CF_A	available coupling modes between Screen A and Screen B have been changed between FSE and R&S FSUP
	FSE	INSTRument:COUPlE	NONE MODE X Y CONTrol XY XCONTrol YCONTrol ALL	Available coupling modes between screen A and screen B have been changed between FSE and R&S FSUP
		INSTRument<1 2>:NSElect	1	currently only parameter value 1 available
	ESIB	INSTRument<1 2>:NSElect	1 to 3 6	4 parameter values are available
	FSE/ FSIQ	INSTRument<1 2>:NSElect	1 to 5	5 parameter values are available
	FSET	INSTRument<1 2>:NSElect	1 2 6	3 parameter values are available
		INSTRument<1 2>[:SElect]	SANalyzer	Currently only SANalyzer available

Devices		Command (<i>Sheet 27 of 47</i>)	Parameter	Notes
	FSE/ FSIQ	INSTRument<1 2>[:SElect]	SANalyzer DDEMod ADEMod BGSM MGSM	5 parameters are available.
	ESIB	INSTRument<1 2>[:SElect]	RECeiver SANalyzer DDEMod ADEMod	4 parameters are available.
	FSET	INSTRument<1 2>[:SElect]	ANalyzer DDEMod RECeiver	3 parameters are available.
R&S FSUP	FSE	MMEMory:CATalog?	string	
R&S FSUP	FSE	MMEMory:CDIRectory	directory name	
R&S FSUP	FSE	MMEMory:CLear:ALL		
R&S FSUP	FSE	MMEMory:CLear:STATe	1,path	
R&S FSUP	FSE	MMEMory:COMMent	<string>	
R&S FSUP	FSE	MMEMory:COPIY	path\file, path\file	
R&S FSUP	FSE	MMEMory:DATA	filename[, <block data>]	
R&S FSUP	FSE	MMEMory:DELeTe	path\filename	
R&S FSUP	FSE	MMEMory:LOAD:AUTO	1,path	
R&S FSUP	FSE	MMEMory:LOAD:STATe	1,path	
R&S FSUP	FSE	MMEMory:MDIRectory	path	
R&S FSUP	FSE	MMEMory:MOVE	path	
R&S FSUP	FSE	MMEMory:MSIS	'A:' 'D:'	R&S FSUP: valid drives are A: and D: FSE: valid drives are A: and C:
R&S FSUP	FSE	MMEMory:NAME	path\filename	
R&S FSUP	FSE	MMEMory:RDIRectory	directory	
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:ALL		
	FSE	MMEMory:SElect[:ITEM]:CSETup	ON OFF	not available for R&S FSUP (default setting on the R&S FSUP)
	FSE	MMEMory:SElect[:ITEM]:CVL:ALL	ON OFF	not available for R&S FSUP and FSET

Devices		Command (Sheet 28 of 47)	Parameter	Notes
	FSE	MMEMory:SElect[:ITEM]:CVL[:ACTIve]	ON OFF	not available for R&S FSUP and FSET
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:DEFault		
	FSE	MMEMory:SElect[:ITEM]:GSEtUp	ON OFF	not available for R&S FSUP (default setting on the R&S FSUP)
	FSE	MMEMory:SElect[:ITEM]:HCOPy	ON OFF	not available for R&S FSUP (default setting on the R&S FSUP)
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:HWSettings	ON OFF	
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:LINes:ALL	ON OFF	
	FSE	MMEMory:SElect[:ITEM]:LINes:ALL	ON OFF	
	FSE	MMEMory:SElect[:ITEM]:LINes[:ACTIve]	ON OFF	not available for R&S FSUP (default setting on the R&S FSUP)
	FSE	MMEMory:SElect[:ITEM]:MACROs	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:NONE		
R&S FSUP	FSE	MMEMory:SElect[:ITEM]:SCData	ON OFF	
R&S FSUP		MMEMory:SElect[:ITEM]:TRACe[:ACTIve]	ON OFF	no numeric suffixes behind TRACe
	FSE	MMEMory:SElect[:ITEM]:TRACe<1...4>	ON OFF	numeric suffixes behind TRACe
	FSE	MMEMory:SElect[:ITEM]:TRANsducer:ALL	ON OFF	not available for R&S FSUP
	FSE	MMEMory:SElect[:ITEM]:TRANsducer[:ACTIve]	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	MMEMory:STORe:STATe	1,path	
R&S FSUP	FSE	MMEMory:STORe:TRACe	1 to 3,path	
	FSE	OUTPut:AF:SENSitivity	<numeric_value>	not available for R&S FSUP and FSET
	FSE	OUTPut:UPORt<1 2>:STATe	ON OFF	not available for R&S FSUP
	FSE	OUTPut:UPORt<1 2>[:VALue]	#B00000000 to #B11111111	not available for R&S FSUP
R&S FSUP	FSE	OUTPut<1 2>[:STATe]	ON OFF	

Devices		Command (<i>Sheet 29 of 47</i>)	Parameter	Notes
	FSE	READ:BURSt:FERRor:AVERAge?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:FERRor:MAXimum?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:FERRor:STATus?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:PEAK:AVERAge?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:PEAK:MAXimum?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:PEAK:STATus?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:RMS:AVERAge?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:RMS:MAXimum?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:PERRor:RMS:STATus?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:POWer:DYNamic?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:POWer:LEVel?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:POWer:STATic?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:POWer?		not available for R&S FSUP and FSET
	FSE	READ:BURSt:REFerence[:IMMediate?]		not available for R&S FSUP and FSET
	FSE	READ:SPECTrum:MODulation[:ALL]?		not available for R&S FSUP and FSET
	FSE	READ:SPECTrum:SWITching[:ALL]?		not available for R&S FSUP and FSET
	FSE	READ:SPURious:STEP?		not available for R&S FSUP and FSET
	FSE	READ:SPURious[:ALL]?		not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]ADEMod:AF:COUPling	AC DC	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]ADEMod:RTIME	ON OFF	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]ADEMod:SBANd	NORMal INVerse	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]ADEMod:SQUelch:LEVel	30 to 150 dBm	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]ADEMod:SQUelch[:STATE]	ON OFF	not available for R&S FSUP and FSET

Devices		Command (<i>Sheet 30 of 47</i>)	Parameter	Notes
	FSET	[SENSe<1 2>:JAM:RANGe[:UPPer]	3PCT 10 PCT 100PCT	not available for R&S FSUP
	FSE	[SENSe<1 2>:]AVERAge:AUTO	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]AVERAge:COUnT	0 to 32767	
	FSE	[SENSe<1 2>:]AVERAge:COUnT	0 to 32767	
R&S FSUP		[SENSe<1 2>:]AVERAge:TYPE	VIDeo LINear	command is used to select logarithmic or linear averaging on the R&S FSUP; therefore parameters are incompatible to the FSE
	FSE	[SENSe<1 2>:]AVERAge:TYPE	MAXimum MINimum SCALar	command is used to select logarithmic or linear averaging on the R&S FSUP; therefore parameters are incompatible to the FSE
R&S FSUP	FSE	[SENSe<1 2>:]AVERAge[:STATe<1...3>]	ON OFF	
	FSE	[SENSe<1 2>:]BANDwidth BWIDth:DEMod	<numeric_value>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]BANDwidth BWIDth:PLL	AUTO HIGH MEDium LOW	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth:VIDeo	1Hz to 10MHz	
	FSET	[SENSe<1 2>:]BANDwidth BWIDth:VIDeo	1Hz to 500MHz	
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth:VIDeo:AUTO	ON OFF	
	FSET	[SENSe<1 2>:]BANDwidth BWIDth:VIDeo:EXTernal[:STATe]	ON OFF	not available for R&S FSUP
R&S FSUP		[SENSe<1 2>:]BANDwidth BWIDth:VIDeo:RATio	0.0001 to 1	only numeric values available. Parameter ranges differ between R&S FSUP and FSE
	FSE	[SENSe<1 2>:]BANDwidth BWIDth:VIDeo:RATio	0.001 to 1000 SINE PULSE NOISE	also text parameters are available. Parameter ranges differ between R&S FSUP and FSE not available for FSET
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]	10Hz to 10MHz (anal. filter) 1Hz to 10MHz (FFT filter)	FSE: 10Hz to 10MHz (models 20) 1Hz to 10MHz (models 30)
	FSET	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]	10 Hz to 500MHz	
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]:AUTO	ON OFF	
	FSE	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]:MODE	ANALog DIGital	not available for R&S FSUP and FSET

Devices		Command (<i>Sheet 31 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]: MODE:FFT	ON OFF	old command that is still supported, but has been replaced on the R&S FSUP by [SENSe<1 2>:]BANDwidth BWIDth[:RESolution]:TYPE
R&S FSUP	FSE	[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]: RATio	0.0001 to 1	
R&S FSUP		[SENSe<1 2>:]BANDwidth BWIDth[:RESolution]: TYPE	NORMal FFT CFILter RRC	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]BANDwidth BWIDth:VIDeo:TYPE	LINear LOGarithmic	new function for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:COLLect[:ACQuire]	THROUGH OPEN	
	FSE	[SENSe<1 2>:]CORRection:CVL:Band	A Q U V E W F D G Y J	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:BIAS	<numeric_value>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:CATalog?		not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:CLear		not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:COMMent	<string>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:DATA	<freq>, <level> to	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:MIXer	<string>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:PORTs	2 3	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:SElect	<file_name>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:SNUMber	<string>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]CORRection:CVL:TYPE	ODD EVEN EODD	not available for R&S FSUP and FSET
	FSE/ FSIQ	[SENSe<1 2>:]CORRection:LOSS:INPut[: MAGNitude]	<numeric_value>	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:METhod	TRANsmission REFLexion	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:RECall		
	FSE	[SENSe<1 2>:]CORRection:RXGain:INPut[: MAGNitude]	<numeric_value>	not available for R&S FSUP, FSET and ESIB
R&S FSUP	FSE	[SENSe<1 2>:]CORRection[:STATe]	ON OFF	

Devices		Command (Sheet 32 of 47)	Parameter	Notes
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:ACTive?		
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:CATalog?		
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:COMMeNt	<string>	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:DATA	<freq>, <level> to	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:DELeTe		
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:SCALing	LINear LOGarithmic	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:SELeCt	<name>	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer:UNIT	<string>	
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:TRANsducer[::STATe]	ON OFF	
	FSE	[SENSe<1 2>:]CORRection:TSET:ACTive?		not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:BReAk	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:CATalog?		not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:COMMeNt	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:DELeTe		not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:RANGe<1...10>	<freq>, <freq>, <name> to	not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:SELeCt	<name>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET:UNIT	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]CORRection:TSET[::STATe]	ON OFF	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]CORRection:YIG:TEMPeRature:AUTO	ON OFF	new function for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:FiLTeR:ALPHa	0.2 to 1	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:FiLTeR:MEASurement	OFF RCOSine RRCosine GAUSSian B22 B25 B44 QFM QFR QRM QRR A25Fm EMES EREF	not available for R&S FSUP

Devices		Command (<i>Sheet 33 of 47</i>)	Parameter	Notes
	FSE	[SENSe<1 2>:]DDEMod:FILTer:REFEreNce	RCOSine RRCosine GAUSSian B22 B25 B44 QFM QFR QRM QRR A25Fm EMES EREF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:FORMat	QPSK PSK MSK QAM FSK	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:FSK:NSTate	2 4	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:MSK:FORMat	TYPE1 TYPE2 NORMal DIFFerential	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:NORMalize	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:PRATe	1 2 4 8 16	not available for R&S FSUP
	FSE/ ESIB	[SENSe<1 2>:]DDEMod:PRESet	GSM EDGe NADC TETRa DCS1800 PCS1900 PHS PDCup PDCDown APCO25CQPSK APCO25C4FM CDPD DECT CT2 ERMes MODacom PWT TFTS F16 F322 F324 F64 FQCDma RQCDma FNADc RNADc BPSK18 GMSK18 QPSK18 GMSK36	not available for R&S FSUP
	FSIQ	[SENSe<1 2>:]DDEMod:PRESet	GSM EDGe NADC TETRa PHS PDCup PDCDown APCO25CQPSK APCO25C4FM CDPD DECT CT2 ERMes MODacom PWT TFTS F16 F322 F324 F64 FWCDma RWCDma FW3Gppcdma RW3Gppcdma BPSK18 GMSK18 QPSK18 GMSK36	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DDEMod:PRESet	GSM EDGe NADC TETRa DCS1800 PCS1900 PHS PDCup PDCDown APCO25CQPSK APCO25C4FM CDPD DECT CT2 ERMes MODacom PWT TFTS F16 F322 F324 F64 FQCDma RQCDma FNADc RNADc BPSK18 GMSK18 QPSK18 GMSK36	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:PSK:FORMat	NORMal DIFFerential N3Pi8	not available for R&S FSUP

Devices		Command (Sheet 34 of 47)	Parameter	Notes
	FSE	[SENSe<1 2>:]DDEMod:PSK:NSTate	2 8	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:QAM:NSTate	16	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:QPSK:FORMat	NORMal DIFFerential OFFSet DPI4	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SBANd	NORMal INVerse	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:PULSe:STATe	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:CATalog?		not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:COMMeNt	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:DATA	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:NAME	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:OFFSet	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:PATteRn	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:SElect	<string>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:SYNC:STATe	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SEARch:TIME	100 to 1600	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DDEMod:SRATe	160 Hz to 1,6 MHz	not available for R&S FSUP
	FSIQ	[SENSe<1 2>:]DDEMod:SRATe	160 Hz to 7 MHz	not available for R&S FSUP
		[SENSe<1 2>:]DDEMod:TIME	1 to Frame Length	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DEMod	OFF AM AMVideo FM PM	not available for R&S FSUP
	ESIB	[SENSe<1 2>:]DEMod	OFF AM FM	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DEMod:FiLTeR:HPASs:FREQuency	0 Hz 10 Hz 100 Hz 1 kHz	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DEMod:FiLTeR[:LPASs]:AUTO	ON OFF	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DEMod:FiLTeR[:LPASs]:FREQuency	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]DETeCtor<1...4>:CMEM[:STATe]	ON OFF	not available for R&S FSUP

Devices		Command (Sheet 35 of 47)	Parameter	Notes
R&S FSUP		[SENSe<1 2>:]DETEctor<1...3>[:FUNction]	APEak NEGative POSitive SAMPlE RMS AVERAge QPEak	R&S FSUP: number of traces restricted to 3; detector settings correspond to selected screen FSE: Qpeak not available
	ESIB	[SENSe<1 2>:]DETEctor<1...4>[:FUNction]	APEak NEGative POSitive SAMPlE RMS AVERAge QPEak	
R&S FSUP	FSE	[SENSe<1 2>:]DETEctor<1...3>[:FUNction]:AUTO	ON OFF	number of traces restricted to 3
	FSET	[SENSe<1 2>:]DETEctor<1...4>:PSTRetch:AUTO	ON OFF	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DETEcto<1...4>r:PSTRetch[:STATe]	ON OFF	not available for R&S FSUP
	ESIB	[SENSe<1 2>:]DETEctor<1...4>:RECEiver[:FUNction]	POSitive NEGative RMS AVERAge QPEak	not available for R&S FSUP
	FSET	[SENSe<1 2>:]DETEctor<1...4>:RECEiver[:FUNction]	POSitive NEGative RMS AVERAge	not available for R&S FSUP
	FSE	[SENSe<1 2>:]FILTEr:CCITt[:STATe]	ON OFF	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:CMESsage[:STATe]	ON OFF	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:DEMPHasis:LINK	DISPlay AUDio	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:DEMPHasis:TCONstant	<numeric_value>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:DEMPHasis[:STATe]	ON OFF	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:HPASs:FREQUency	30 Hz 300 HZ	not available for R&S FSUP and FSET
	FSET	[SENSe<1 2>:]FILTEr:HPASs:FREQUency	10 kHz 1 kHz 100 Hz	not available for R&S FSUP
	FSE	[SENSe<1 2>:]FILTEr:HPASs[:STATe]	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]FILTEr:LPASs:FREQUency	3 kHz 15 kHz	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]FILTEr:LPASs[:STATe]	ON OFF	not available for R&S FSUP and FSET
	FSET	[SENSe<1 2>:]FILTEr:NOTCh[:STATe]	ON OFF	not available for R&S FSUP
	FSET	[SENSe<1 2>:]FM[:DEViation]:RANGe:UPPer	ON OFF	not available for R&S FSUP
	FSET	[SENSe<1 2>:]FM[:DEViation]:RANGe[:UPPer]	<numeric_value>	not available for R&S FSUP

Devices		Command (Sheet 36 of 47)	Parameter	Notes
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:CENTer	0 to f_{max}	frequency ranges are different for R&S FSUP and FSE
	FSE	[SENSe<1 2>:]FREQuency:CENTer:LINK	START STOP SPAN	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:CENTer:STEP	0 to f_{max}	frequency ranges are different for R&S FSUP and FSE
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:CENTer:STEP:LINK	SPAN RBW OFF	
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:CENTer:STEP:LINK:FACTor	1 to 100 PCT	
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:MODE	CW FIXed SWEep	
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:OFFSet	<numeric_value>	
	FSET	[SENSe<1 2>:]FREQuency:RANGe	2 GHz 22 GHz	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:SPAN	0 to f_{max}	frequency ranges are different for R&S FSUP and FSE
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:SPAN:FULL		
	FSE	[SENSe<1 2>:]FREQuency:SPAN:LINK	CENTer STOP SPAN	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:STARt	0 to f_{max}	frequency ranges are different for R&S FSUP and FSE
	FSET	[SENSe<1 2>:]FREQuency:STARt:FLINe[:STATe]	ON OFF	not available for R&S FSUP. Replaced by CALC:MARK:FUNC:SLIMits
	FSE	[SENSe<1 2>:]FREQuency:STARt:LINK	CENTer STOP SPAN	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]FREQuency:STOP	0 to f_{max}	frequency ranges are different for R&S FSUP and FSE
	FSET	[SENSe<1 2>:]FREQuency:STOP:FLINe[:STATe]	ON OFF	not available for R&S FSUP; replaced by CALC:MARK:FUNC:SLIMits.
	FSE	[SENSe<1 2>:]FREQuency:STOP:LINK	CENTer STARt SPAN	not available for R&S FSUP
	FSET/ESIB	[SENSe<1 2>:]FREQuency[:CW]:FIXed]	f_{min} to f_{max}	not available for R&S FSUP
	FSET/ESIB	[SENSe<1 2>:]FREQuency[:CW]:FIXed]:STEP	f_{min} to f_{max}	not available for R&S FSUP
R&S FSUP		[SENSe<1 2>:]LIST:POWer:RESult?		new function for R&S FSUP

Devices		Command (<i>Sheet 37 of 47</i>)	Parameter	Notes
R&S FSUP		[SENSe<1 2>:]LIST:POWer[:SEQuence]	<analyzer freq>, <ref level>, <rf att>, <el att>, <filter type>, <rbw>, <vbw>, <meas time>, <trigger level>,...	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]LIST:POWer:SET	<PEAK meas>, <RMS meas>, <AVG meas>, <trigger mode>, <trigger slope>, <trigger offset>, <gate length>	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]LIST:POWer:STATe	ON OFF	new function for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:BIAS	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:BIAS:LIMit:MIN	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:BIAS:LIMit[:MAX]	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:BLOCK	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:HARMonic	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:HARMonic:BAND	A Q U V E W F D G Y J	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:HARMonic:TYPE	ODD EVEN EODD	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:LOSS:HIGH	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:LOSS:TABLE	<file_name>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:LOSS[:LOW]	<numeric_value>	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:PORTs	2 3	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:SIGNal	2 3	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer:THReshold	0.1 to 100 dB	not available for R&S FSUP
	FSE	[SENSe<1 2>:]MIXer[:STATe]	ON OFF	not available for R&S FSUP

Devices		Command (Sheet 38 of 47)	Parameter	Notes
R&S FSUP		[SENSe<1 2>:]MPOWer[:SEQuence]	<analyzer freq>, <rbw>, <meas time>, <trigger source>, <trigger level>, <trigger offset>, <type of meas>, <# of meas>	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]MPOWer:RESult[:LIST]?		new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]MPOWer:RESult:MIN?		new function for R&S FSUP
	FSE	[SENSe<1 2>:]MSUMmary:AHOLd[:STATE]	ON OFF	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]MSUMmary:MODE	ABSolute RELative	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]MSUMmary:MTIME	0.1S 1S	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]MSUMmary:REFerence	<numeric_value>	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]MSUMmary:REFerence:AUTO	ONCE	not available for R&S FSUP and FSET
	FSE	[SENSe<1 2>:]MSUMmary:RUNit	PCT DB	not available for R&S FSUP and FSET
	FSET	[SENSe<1 2>:]PM[:DEViation]:RANGe[:UPPer]	<numeric_value>	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:ACPairs	0 to 3	R&S FSUP: new parameter value 0 for channel power measurement
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel: BANDwidth BWIDTH:ACHannel	100 to 1000MHz	R&S FSUP: parameter range starts at 100Hz FSE: parameter range starts at 0 Hz
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel: BANDwidth BWIDTH:ALternate<1 2>	100 to 1000MHz	R&S FSUP: parameter range starts at 100Hz FSE: parameter range starts at 0 Hz
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel: BANDwidth BWIDTH[:CHANnel]	100 to 1000MHz	R&S FSUP: parameter range starts at 100Hz FSE: parameter range starts at 0 Hz
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:MODE	ABSolute RELative	
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:PRESet	ACPower CPower OBANDwidth OBWidth CN CN0 MCACpower	MCACpower not available for FSE
R&S FSUP		[SENSe<1 2>:]POWer:ACHannel:PRESet:RLEVel		new function for R&S FSUP

Devices		Command (<i>Sheet 39 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:REfERENCE: AUTO	ONCE	
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:SPACing[: ACHannel]	100Hz to 2000MHz	different parameter range
R&S FSUP		[SENSe<1 2>:]POWer:CHannel:SPACing: CHANnel	100Hz to 2000MHz	new function for R&S FSUP
	FSE	[SENSe<1 2>:]POWer:ACHannel:SPACing[: UPPer]	0 to 1000MHz	not available for R&S FSUP and FSET
R&S FSUP	FSE	[SENSe<1 2>:]POWer:ACHannel:SPACing: ALTErnate<1 2>	100Hz to 2000MHz	different parameter range
R&S FSUP		[SENSe<1 2>:]POWer:ACHannel:TXCHannel: COUNT	1 2 3 4	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]POWer:ACHannel:REfERENCE: TXCHannel:AUTO	MINimum MAXimum LHIGHest	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]POWer:ACHannel:REfERENCE: TXCHannel:MANual	1 to 12	new function for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]POWer:BANDwidth BWIDth	10 to 99.9PCT	different parameter range
R&S FSUP		[SENSe<1 2>:]POWer:HSPeed	ON OFF	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]POWer:NCORrection	ON OFF	new function for R&S FSUP
R&S FSUP		[SENSe<1 2>:]POWer:TRACe	1 to 3	new function for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]ROSCillator:[INTErnal:]TUNe	0 to 4095	
R&S FSUP	FSE	[SENSe<1 2>:]ROSCillator:[INTErnal:]TUNe:SAVe		
	FSE	[SENSe<1 2>:]ROSCillator:EXTErnal:FREQUency	1MHz to 16MHz	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]ROSCillator:SOURce	INTErnal EXTErnal	
	FSET/ ESIB	[SENSe<1 2>:]SCAN<:RANGes[COUNT]	1 to 10	not available for R&S FSUP
	FSE/ ESIB	[SENSe<1 2>:]SCAN<1...10>:BANDwidth: RESolution	f_{min} to f_{max}	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:INPut:ATTenuation	dB_{min} to dB_{max}	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:INPut:ATTenuation: AUTO	ON OFF	not available for R&S FSUP
	FSET	[SENSe<1 2>:]SCAN<1...10>:INPut:BIMPedance	150OHM 600OHM 10kOHM	not available for R&S FSUP
	FSET	[SENSe<1 2>:]SCAN<1...10>:INPut:GAIN	0dB to 30dB	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:INPut:GAIN:AUTO	ON OFF	not available for R&S FSUP

Devices		Command (<i>Sheet 40 of 47</i>)	Parameter	Notes
	ESIB	[SENSe<1 2>:]SCAN<1...10>:INPut:GAIN[:STATE]	ON OFF	not available for R&S FSUP
	ESIB	[SENSe<1 2>:]SCAN<1...10>:INPut:TYPE	INPUT1 INPUT2	not available for R&S FSUP
	FSET	[SENSe<1 2>:]SCAN<1...10>:INPut:TYPE	RF BALanced	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:START	f _{min} to f _{max}	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:STEP	f _{min} to f _{max}	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:STOP	f _{min} to f _{max}	not available for R&S FSUP
	FSET/ ESIB	[SENSe<1 2>:]SCAN<1...10>:TIME	100 μs to 100 s	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:COUNT	0 to 32767	
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe	ON OFF	
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe:HOLDoff	0 to 100s	
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe:LENGth	0 to 100s	
	FSE	[SENSe<1 2>:]SWEep:EGATe:LENGth	0 to 100s	
	FSE	[SENSe<1 2>:]SWEep:EGATe:LEVel	-5V to +5V	not available for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe:POLarity	POSitive NEGative	
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe:SOURce	EXTernal IFPower RFPower	
R&S FSUP	FSE	[SENSe<1 2>:]SWEep:EGATe:TYPE	LEVel EDGE	
	FSE	[SENSe<1 2>:]SWEep:GAP	ON OFF	not available for R&S FSUP
	FSE	[SENSe<1 2>:]SWEep:GAP:LENGth	0 to 100s	not available for R&S FSUP
	FSE	[SENSe<1 2>:]SWEep:GAP:PRETrigger	0 to 100s	not available for R&S FSUP
	FSE	[SENSe<1 2>:]SWEep:GAP:TRGTogap	0 to 100s	not available for R&S FSUP
R&S FSUP		[SENSe<1 2>:]SWEep:POINts	<numeric_value>	not available for FSE
	FSET/ ESIB	[SENSe<1 2>:]SWEep:SPACing	LINear LOGarithmic AUTO	not available for R&S FSUP
	FSE/ FSIQ	[SENSe<1 2>:]SWEep:SPACing	LINear LOGarithmic	not available for R&S FSUP

Devices		Command (<i>Sheet 41 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	[SENSe<1 2>:]SWEp:TIME	2.5ms to 1000s 1µs to 16000s	different parameter ranges for R&S FSUP and FSE
R&S FSUP	FSE	[SENSe<1 2>:]SWEp:TIME:AUTO	ON OFF	
	FSE	[SENSe<1 2>:]TCAPture:LENGth	1024 2048 4096 8192 16384	not available for R&S FSUP
	FSE	[SENSe<1 2>:]TV:PSOFfset	0 to 6.5 MHz	not available for R&S FSUP and FSET
R&S FSUP		[SENSe<1 2>:]TV:CCVS	INternal EXternal	new function for R&S FSUP
R&S FSUP	FSE	[SENSe<1 2>:]TV[::STATe]	ON OFF	
R&S FSUP	FSE	SOURce:AM:STATe	ON OFF	
R&S FSUP	FSE	SOURce:DM:STATe	ON OFF	
R&S FSUP		SOURce:EXternal[::STATe]	ON OFF	new command for R&S FSUP
R&S FSUP		SOURce:EXternal:FREQuency:OFFset	<numeric_value>	new command for R&S FSUP
R&S FSUP		SOURce:EXternal:FREQuency[::FACTor]:NUMerator	<numeric_value>	new command for R&S FSUP
R&S FSUP		SOURce:EXternal:FREQuency[::FACTor]:DENominator	<numeric_value>	new command for R&S FSUP
R&S FSUP		SOURce:EXternal:FREQuency:SWEp[::STATe]	ON OFF	new command for R&S FSUP
R&S FSUP		SOURce:EXternal:POWER[::LEVel]	<numeric_value>	new command for R&S FSUP
R&S FSUP	FSE	SOURce:FM:STATe	ON OFF	
R&S FSUP	FSE	SOURce:FREQuency:OFFSet	-150Hz to 150MHz	different value ranges for R&S FSUP and FSE
	FSE	SOURce:POWER:ALC:SOURce	INternal EXternal	not available for R&S FSUP and FSET
R&S FSUP	FSE	SOURce:POWER[::LEVel][::IMMEDIATE]:OFFSet	-200dB to +200dB	
R&S FSUP	FSE	SOURce:POWER[::LEVel][::IMMEDIATE][::AMPLitude]	-30dBm to 0dBm	different value ranges for R&S FSUP and FSE
R&S FSUP	FSE	STATus:OPERation:CONDition?		
	FSE	STATus:OPERation:CONDition?		
R&S FSUP	FSE	STATus:OPERation:ENABLE	0 to 65535	
R&S FSUP	FSE	STATus:OPERation:NTRansition	0 to 65535	

Devices		Command (Sheet 42 of 47)	Parameter	Notes
R&S FSUP	FSE	STATus:OPERation:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:OPERation[:EVENT?]		
R&S FSUP	FSE	STATus:PRESet		
R&S FSUP	FSE	STATus:QUEStionable:ACPLimit:CONDition?		
R&S FSUP	FSE	STATus:QUEStionable:ACPLimit:ENABle	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:ACPLimit:NTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:ACPLimit:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:ACPLimit[:EVENT]?		
R&S FSUP	FSE	STATus:QUEStionable:CONDition?		
R&S FSUP	FSE	STATus:QUEStionable:ENABle	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:FREQUency:CONDition?		
R&S FSUP	FSE	STATus:QUEStionable:FREQUency:ENABle	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:FREQUency:NTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:FREQUency:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUEStionable:FREQUency[:EVENT]?		
R&S FSUP	FSE	STATus:QUEStionable:LIMit<1 2>:CONDition?		R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUEStionable:LIMit<1 2>:ENABle	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUEStionable:LIMit<1 2>:NTRansition	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUEStionable:LIMit<1 2>:PTRansition	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUEStionable:LIMit<1 2>[:EVENT]?		R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUEStionable:LMARgin<1 2>:CONDition?		R&S FSUP: individual registers for screen A and B

Devices		Command (<i>Sheet 43 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	STATus:QUESTionable:LMARgin<1 2>:ENABLE	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUESTionable:LMARgin<1 2>:NTRansition	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUESTionable:LMARgin<1 2>:PTRansition	0 to 65535	R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUESTionable:LMARgin<1 2>[:EVENT]?		R&S FSUP: individual registers for screen A and B
R&S FSUP	FSE	STATus:QUESTionable:NTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:POWer:CONDition?		
R&S FSUP	FSE	STATus:QUESTionable:POWer:ENABLE	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:POWer:NTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:POWer:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:POWer[:EVENT]?		
R&S FSUP	FSE	STATus:QUESTionable:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:SYNC:CONDition?		
R&S FSUP	FSE	STATus:QUESTionable:SYNC:ENABLE	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:SYNC:NTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:SYNC:PTRansition	0 to 65535	
R&S FSUP	FSE	STATus:QUESTionable:SYNC[:EVENT]?		
	FSE	STATus:QUESTionable:TRANsdncer:CONDition?		not available for R&S FSUP
	FSE	STATus:QUESTionable:TRANsdncer:ENABLE	0 to 65535	not available for R&S FSUP
	FSE	STATus:QUESTionable:TRANsdncer:NTRansition	0 to 65535	not available for R&S FSUP
	FSE	STATus:QUESTionable:TRANsdncer:PTRansition	0 to 65535	not available for R&S FSUP
	FSE	STATus:QUESTionable:TRANsdncer[:EVENT]?		not available for R&S FSUP
R&S FSUP	FSE	STATus:QUESTionable[:EVENT]?		

Devices		Command (Sheet 44 of 47)	Parameter	Notes
R&S FSUP	FSE	STATus:QUEue[:NEXT?]		
	FSE	SYSTem:BINFo?		not available for R&S FSUP
R&S FSUP		SYSTem:COMMunicate:GPIB:RDEvice:GENerator<1 2>:ADDRess	0 to 30	new command for R&S FSUP
	FSE	SYSTem:COMMunicate:GPIB:RDEvice<1 2>:ADDRess	0 to 30	not available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	0 to 30	
R&S FSUP	FSE	SYSTem:COMMunicate:GPIB[:SELF]:RTERminator	LFEOI EOI	
R&S FSUP	FSE	SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt?		
R&S FSUP	FSE	SYSTem:COMMunicate:PRINter:ENUMerate:NEXT?		
R&S FSUP		SYSTem:COMMunicate:PRINter:SElect<1 2>	<printer_name>	numeric suffix behind SElect
	FSIQ/ESIB	SYSTem:COMMunicate:PRINter<1 2>:SElect	<printer_name>	numeric suffix behind PRINters
R&S FSUP		SYSTem:COMMunicate:RDEvice:GENerator<1 2>:LINK	GPIB TTL	new function for R&S FSUP
R&S FSUP		SYSTem:COMMunicate:RDEvice:GENerator<1 2>:TYPE	<name>	new function for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial:CONTRol:DTR	IBFull OFF	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial:CONTRol:RTS	IBFull OFF	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial[:RECeive]:BAUD	110 300 600 1200 2400 9600 19200	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial[:RECeive]:BITS	7 8	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial[:RECeive]:PACE	XON NONE	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial[:RECeive]:PARity[:TYPE]	EVEN ODD NONE	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:COMMunicate:SERial[:RECeive]:SBITs	1 2	only SERial1 available for R&S FSUP
R&S FSUP	FSE	SYSTem:DATE	1980 to 2099, 1 to 12, 1 to 31	
R&S FSUP		SYSTem:DISPlay:FPANel	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	SYSTem:DISPlay:UPDate	ON OFF	

Devices		Command (<i>Sheet 45 of 47</i>)	Parameter	Notes
R&S FSUP	FSE	SYSTem:ERRor[:NEXT]?		new function for R&S FSUP, but compatible to SYSTem:ERRor? on the FSE
R&S FSUP		SYSTem:ERRor:LIST?		new function for R&S FSUP
R&S FSUP		SYSTem:ERRor:CLEar:ALL		new command for R&S FSUP
R&S FSUP	FSE	SYSTem:FIRMware:UPDate	<path>	
R&S FSUP		SYSTem:LANGuage	'SCPI' '8560E' '8561E' '8562E' '8563E' '8564E' '8565E' '8566A' '8566B' '8568A' '8568B' '8594E'	new command for R&S FSUP
R&S FSUP	FSE	SYSTem:PASSword[:CENable]	'pass word'	
R&S FSUP	FSE	SYSTem:PRESet		
	ESIB/FSIQ	SYSTem:PRESet:COMPAtible	FSE OFF	not available for R&S FSUP
R&S FSUP	FSE	SYSTem:SET		
R&S FSUP	FSE	SYSTem:SPEaker:VOLume	0 to 1	
R&S FSUP	FSE	SYSTem:TIME	0 to 23, 0 to 59, 0 to 59	
R&S FSUP	FSE	SYSTem:VERSion?		
R&S FSUP	FSE	TRACe:COPI	TRACE1 TRACE2 TRACE3 , TRACE1 TRACE2 TRACE3	only TRACE1...TRACE3 available for R&S FSUP
	FSET/ESIB	TRACe:FEED:CONTRol<1...4>	ALWays NEVer	not available for R&S FSUP
R&S FSUP	FSE	TRACe[:DATA]	TRACE1 TRACE2 TRACE3 , <block> <numeric_value>	only TRACE1...TRACE3 available for R&S FSUP
	FSET/ESIB	TRACe[:DATA]	TRACE1 TRACE2 TRACE3 TRACE4 SINGle SCAN STATus, <block> <numeric_value>	
R&S FSUP		TRACe:IQ:DATA?		new function for R&S FSUP

Devices		Command (Sheet 46 of 47)	Parameter	Notes
R&S FSUP		TRACe:IQ:SET	<filter type>, <rbw>, <sample rate>, <trigger source>, <trigger slope>, <pretrigger samples>, <# of samples>	new function for R&S FSUP
R&S FSUP		TRACe:IQ:AVERAge[:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP		TRACe:IQ:AVERAge:COUnT	<numeric_value>	new function for R&S FSUP
R&S FSUP		TRACe:IQ:SRATe	16kHz to 32MHz	new function for R&S FSUP
R&S FSUP		TRACe:IQ[:STATe]	ON OFF	new function for R&S FSUP
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:HOLDoff	0 to 100s	
	FSE	TRIGger<1 2>[:SEQuence]:LEVel:AF	-120 to +120PCT	not available for R&S FSUP
	FSE	TRIGger<1 2>[:SEQuence]:LEVel:VIDeo	0 to 100PCT	not available for R&S FSUP; replaced by TRIGger:SEQuence:SOURce:VIDeo
	FSE	TRIGger<1 2>[:SEQuence]:LEVel[:EXTeRnal]	-5.0 to +5.0V	not available for R&S FSUP
R&S FSUP		TRIGger<1 2>[:SEQuence]:LEVel:IFPower	<numeric_value>	new command for R&S FSUP
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:SLOPe	POSitive NEGative	
R&S FSUP		TRIGger<1 2>[:SEQuence]:SOURce	IMMediate LINE EXTeRnal VIDeo IFPower	
	FSE/ESIB	TRIGger<1 2>[:SEQuence]:SOURce	IMMediate LINE EXTeRnal VIDeo RFPower TV AF	
	FSIQ	TRIGger<1 2>[:SEQuence]:SOURce	IMMediate LINE EXTeRnal VIDeo RFPower AF	
	FSET	TRIGger<1 2>[:SEQuence]:SOURce	IMMediate LINE EXTeRnal VIDeo	
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:SOURce:VIDeo:FORMat:LPFrame	525 625	requires option B6 on FSP
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:SOURce:VIDeo:FIELD:SElect	ALL ODD EVEN	requires option B6 on FSP
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:SOURce:VIDeo:LINE:NUMBer	<numeric_value>	requires option B6 on FSP
R&S FSUP	FSE	TRIGger<1 2>[:SEQuence]:SOURce:VIDeo:SSIGnal:POLarity	NEGative POSitive	requires option B6 on FSP

Devices		Command (Sheet 47 of 47)	Parameter	Notes
	FSE/ ESIB	TRIGger<1 2>[:SEQuence]:SYNChronize:ADJust: FRAMe	0 to 100s	not available for R&S FSUP
	FSE	TRIGger<1 2>[:SEQuence]:SYNChronize:ADJust: FRAMe:AUTO	ONCE	not available for R&S FSUP and FSET
	FSE	TRIGger<1 2>[:SEQuence]:SYNChronize:ADJust: SLOT	0 to 100s	not available for R&S FSUP and FSET
	FSE	TRIGger<1 2>[:SEQuence]:SYNChronize:ADJust: SLOT:AUTO	ONCE	not available for R&S FSUP and FSET
	FSE	TRIGger<1 2>[:SEQuence]:SYNChronize: SOURce	FRAMe TSC	not available for R&S FSUP and FSET
R&S FSUP		UNIT<1 2>:POWer	DBM DBPW WATT DBUV DBMV VOLT DBUA AMP V A W	available units are compatible to the FSE.
	FSE/ FSIQ	UNIT<1 2>:POWer	DBM DBPW WATT DBUV DBMV VOLT DBUA AMP DB PCT UNITLESS DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBIA_M DBUV_MMHZ DBUA_MMHZ	for R&S FSUP, the following units apply: DBM DBPW WATT DBUV DBMV VOLT DBUA AMP V A W
	FSET/ ESIB	UNIT<1 2>:POWer	DBM DBPW DBPT WATT DBUV DBMV VOLT DBUA AMPere V W DB PCT UNITLESS DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBIA_M DBUV_MMHZ DBUA_MMHZ	for R&S FSUP, the following units apply: DBM DBPW WATT DBUV DBMV VOLT DBUA AMP V A W
	FSE	UNIT<1 2>:PROBe	ON OFF	not available for R&S FSUP

Alphabetical List of Remote Commands

Command	Parameter	Page
[SENSe<1 2>:]POWer:ACHannel:BANDwidth BWIDTH[:CHANnel]	100 Hz to 1000 MHz	6.193
[SENSe<1 2>:]POWer:ACHannel:REFerence:TXCHannel:MANual	1 to 12	6.195
*CAL?		6.7
*CLS		6.7
*ESE 0 to 255		6.7
*ESR?		6.7
*IDN?		6.8
*IST?		6.8
*OPC		6.8
*OPC?		6.8
*OPT?		6.8
*PCB 0 to 30		6.9
*PRE 0 to 255		6.9
*PSC 0 1		6.9
*RST		6.9
*SRE 0 to 255		6.9
*STB?		6.9
*TRG		6.9
*TST?		6.10
*WAI		6.10
ABORT		6.11
CALCulate:LIMit<1 to 100>:COMPAtible?		6.28
CALCulate:STATistics:APD[:STATe]	ON OFF	6.88
CALCulate:STATistics:CCDF[:STATe]	ON OFF	6.88
CALCulate:STATistics:CCDF:X<1 to 3>?	P0_01 P0_1 P1 P10	6.88
CALCulate:STATistics:NSAMPles	100 to 1E9	6.89
CALCulate:STATistics:PRESet		6.90
CALCulate:STATistics:RESult<1 to 3>?	MEAN PEAK CFACtor ALL	6.91
CALCulate:STATistics:SCALE:AUTO	ONCE	6.89
CALCulate:STATistics:SCALE:X:RANGE	1dB to 200dB	6.90
CALCulate:STATistics:SCALE:X:RLEVEL	-130dBm to 30dBm	6.89
CALCulate:STATistics:SCALE:Y:LOWer	1E-9 to 0.1	6.90
CALCulate:STATistics:SCALE:Y:UNIT	PCT ABS	6.90
CALCulate:STATistics:SCALE:Y:UPPer	1E-8 to 1.0	6.90
CALCulate<1 2>:DELTamarker<1 to 4>:AOFF		6.13
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:FIXed:RPOint:MAXimum[:PEAK]	<numeric_value>	6.18
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:FIXed:RPOint:X	<numeric_value>	6.19
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:FIXed:RPOint:Y	<numeric_value>	6.19
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:FIXed:RPOint:Y:OFFSet	<numeric_value>	6.19
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:FIXed[:STATe]	ON OFF	6.18
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:PNOise:AUTO	ON OFF	6.20
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:PNOise:RESult?		6.20
CALCulate<1 2>:DELTamarker<1 to 4>:FUNctioN:PNOise[:STATe]	ON OFF	6.20
CALCulate<1 2>:DELTamarker<1 to 4>:LINK	ON OFF	6.18
CALCulate<1 2>:DELTamarker<1 to 4>:MAXimum:LEFT		6.16
CALCulate<1 2>:DELTamarker<1 to 4>:MAXimum:NEXT		6.16
CALCulate<1 2>:DELTamarker<1 to 4>:MAXimum[:PEAK]		6.15
CALCulate<1 2>:DELTamarker<1 to 4>:MAXimum:RIGHT		6.16
CALCulate<1 2>:DELTamarker<1 to 4>:MINimum:LEFT		6.17
CALCulate<1 2>:DELTamarker<1 to 4>:MINimum:NEXT		6.17

Command	Parameter	Page
CALCulate<1 2>:DELTamarker<1 to 4>:MINimum[:PEAK]		6.16
CALCulate<1 2>:DELTamarker<1 to 4>:MINimum:RIGHt		6.17
CALCulate<1 2>:DELTamarker<1 to 4>:MODE	ABSolute RELative	6.12
CALCulate<1 2>:DELTamarker<1 to 4>[:STATe]	ON OFF	6.12
CALCulate<1 2>:DELTamarker<1 to 4>:TRACe	1 to 3	6.13
CALCulate<1 2>:DELTamarker<1 to 4>:X	0 to MAX (frequency sweep time)	6.13
CALCulate<1 2>:DELTamarker<1 to 4>:X:RELative?		6.14
CALCulate<1 2>:DELTamarker<1 to 4>:X:SPUR?		6.14
CALCulate<1 2>:DELTamarker<1 to 4>:Y	0 to MAX (frequency sweep time)	6.14
CALCulate<1 2>:DELTamarker<1 to 4>:Y?		6.15
CALCulate<1 2>:DLINe<1 2>	MINimum .. MAXimum (depending on current unit)	6.92
CALCulate<1 2>:DLINe<1 2>:STATe	ON OFF	6.92
CALCulate<1 2>:EVALuation:STARt	0 to fmax	6.22
CALCulate<1 2>:EVALuation[:STATe]	ON OFF	6.22
CALCulate<1 2>:EVALuation:STOP	0 to fmax	6.22
CALCulate<1 2>:FLINe<1 2>	0 to fmax	6.93
CALCulate<1 2>:FLINe<1 2>:STATe	ON OFF	6.93
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ACHannel:ABSolute	-200DBM to 200DBM, -200 to 200DBM	6.30
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ACHannel:ABSolute:STATe	ON OFF	6.30
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ACHannel[:RELative]	0 to 100dB, 0 to 100dB	6.28
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ACHannel[:RELative]:STATe	ON OFF	6.29
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ACHannel:RESult?		6.31
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ALTernate<1 to 11>:ABSolute	-200DBM to 200DBM, -200DBM to 200DBM	6.32
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ALTernate<1 to 11>:ABSolute:STATe	ON OFF	6.33
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ALTernate<1 to 11>[:RELative]	0 to 100dB, 0 to 100dB.	6.31
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ALTernate<1 to 11>[:RELative]:STATe	ON OFF	6.32
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR:ALTernate<1 to 11>:RESult?		6.34
CALCulate<1 2>:LIMit<1 to 8>:ACPoweR[:STATe]	ON OFF	6.28
CALCulate<1 2>:LIMit<1 to 8>:CATalog?		6.24
CALCulate<1 2>:LIMit<1 to 8>:CONTRol:MODE	RELative ABSolute	6.35
CALCulate<1 2>:LIMit<1 to 8>:CONTRol:OFFSet	<numeric_value>	6.35
CALCulate<1 2>:LIMit<1 to 8>:CONTRol:SPACing	LINear LOGarithmic	6.36
CALCulate<1 2>:LIMit<1 to 8>:FAIL?		6.26
CALCulate<1 2>:LIMit<1 to 8>:LOWer:MARGin	<numeric_value>	6.37
CALCulate<1 2>:LIMit<1 to 8>:LOWer:MODE	RELative ABSolute	6.37
CALCulate<1 2>:LIMit<1 to 8>:LOWer:OFFSet	<numeric_value>	6.37
CALCulate<1 2>:LIMit<1 to 8>:LOWer:SPACing	LINear LOGarithmic	6.38
CALCulate<1 2>:LIMit<1 to 8>:LOWer:THReshold	<numeric_value>	6.38
CALCulate<1 2>:LIMit<1 to 8>:STATe	ON OFF	6.25
CALCulate<1 2>:LIMit<1 to 8>:UPPer:MARGin	<numeric_value>	6.40
CALCulate<1 2>:LIMit<1 to 8>:UPPer:MODE	RELative ABSolute	6.40
CALCulate<1 2>:LIMit<1 to 8>:UPPer:OFFSet	<numeric_value>	6.39
CALCulate<1 2>:LIMit<1 to 8>:UPPer:SPACing	LINear LOGarithmic	6.41
CALCulate<1 2>:LIMit<1 to 8>:UPPer:THReshold	<numeric_value>	6.41
CALCulate<1 2>:LIMit<1 to n>:CLEar[:IMMediate]		6.26
CALCulate<1 2>:LIMit<1 to n>:COMMeNt	<string>	6.26
CALCulate<1 2>:LIMit<1 to n>:CONTRol[:DATA]	<numeric_value>, <numeric_value>..	6.34
CALCulate<1 2>:LIMit<1 to n>:CONTRol:DOMain	FREQuency TIME	6.35
CALCulate<1 2>:LIMit<1 to n>:CONTRol:SHIFt	<numeric_value>	6.36
CALCulate<1 2>:LIMit<1 to n>:COPY	1 to n <name>	6.27
CALCulate<1 2>:LIMit<1 to n>:DELeTe		6.27

Command	Parameter	Page
CALCulate<1 2>:LIMit<1 to n>:LOWer[:DATA]	<numeric_value>,<numeric_value>...	6.36
CALCulate<1 2>:LIMit<1 to n>:LOWer:SHIFt	<numeric_value>	6.38
CALCulate<1 2>:LIMit<1 to n>:LOWer:STATe	ON OFF	6.37
CALCulate<1 2>:LIMit<1 to n>:NAME	<name of limit line>	6.27
CALCulate<1 2>:LIMit<1 to n>:TRACe	1 to 3	6.24
CALCulate<1 2>:LIMit<1 to n>:UNIT	DBM DBCHZ DBPW WATT DBUV DBMV VOLT DBUA AMPere DB DEG RAD S HZ PCT UNITLESS	6.25
CALCulate<1 2>:LIMit<1 to n>:UPPer[:DATA]	<numeric_value>,<numeric_value>...	6.39
CALCulate<1 2>:LIMit<1 to n>:UPPer:SHIFt	<numeric_value>	6.40
CALCulate<1 2>:LIMit<1 to n>:UPPer:STATe	ON OFF	6.39
CALCulate<1 2>:LIMit<1...8>:ACTive?		6.24
CALCulate<1 2>:MARKEr<1 to 4>:AOFF		6.42
CALCulate<1 2>:MARKEr<1 to 4>:COUNT	ON OFF	6.45
CALCulate<1 2>:MARKEr<1 to 4>:COUNT:FREQuency?		6.45
CALCulate<1 2>:MARKEr<1 to 4>:COUNT:RESolution	0.1 1 10 100 1000 10000 Hz	6.45
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:ADEMod:AM[:RESult<1 to 3>]?	PPEak MPEak MIDDLE RMS	6.62
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:ADEMod:CARRier[:RESult<1 to 3>]?		6.63
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:ADEMod:FERRor[:RESult<1 to 3>]?		6.63
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:ADEMod:FM[:RESult<1 to 3>]?	PPEak MPEak MIDDLE RMS	6.62
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:ADEMod:PM[:RESult<1 to 3>]?	PPEak MPEak MIDDLE RMS	6.63
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:CENTer		6.61
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:CSTep		6.61
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation:CONTinuous	ON OFF	6.58
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation:HOLDoff	10ms to 1000s	6.58
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation:SELect	AM FM	6.57
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation:SQUelch:LEVel	0 to 100 PCT	6.58
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation:SQUelch[:STATe]	ON OFF	6.58
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:DEModulation[:STATe]	ON OFF	6.57
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:FPEaks:COUNT?		6.53
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:FPEaks[:IMMediate]	<numeric_value>	6.52
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:FPEaks:SORT	X Y	6.54
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:FPEaks:X?		6.53
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:FPEaks:Y?		6.53
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:HARMonics:NHARmonics	1 to 10	6.64
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:HARMonics[:STATe]	ON OFF	6.64
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:MDEPth:RESult?		6.59
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:MDEPth[:STATe]		6.59
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:MSUMmary?	<time offset of first pulse>, <measurement time>, <period>, <# of pulses to measure>	6.82
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NDBDown	<numeric_value>	6.54
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NDBDown:FREQuency?		6.55
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NDBDown:RESult?		6.55
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NDBDown:STATe	ON OFF	6.54
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NDBDown:TIME?		6.56
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NOISe:RESult?		6.57
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:NOISe[:STATe]	ON OFF	6.57
CALCulate<1 2>:MARKEr<1 to 4>:FUNCTion:POWER:MODE	WRITe MAXHold	6.70

Command	Parameter	Page
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:POWer:PRESet	NADC TETRA PDC PHS CDPD FWCDma RWCDma F8CDma R8CDma F19Cdma R19Cdma FW3Gppcdma RW3Gppcdma D2CDma S2CDma M2CDma FIS95A RIS95A FIS95C0 RIS95C0 FJ008 RJ008 FIS95C1 RIS95C1 TCDMA NONE AWLan BWLan WIMax WIBro	6.69
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:POWer:RESult:PHZ	ON OFF	6.68
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:POWer:RESult?	ACPower CPower MCACpower OBANdwidth OBWidth CN CN0	6.66
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:POWer:SElect	ACPower CPower MCACpower OBANdwidth OBWidth CN CN0	6.65
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:POWer[:STATe]	OFF	6.69
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:REFerence		6.61
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:STRack:BANdwidth BWIDTh	10Hz to MAX(SPAN)	6.71
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:STRack[:STATe]	ON OFF	6.71
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:STRack:THReshold	-330dBm to +30dBm	6.71
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:STRack:TRACe	1 to 3	6.72
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:AOff		6.82
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:AVERage	ON OFF	6.81
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:MEAN:AVERage:RESult?		6.77
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:MEAN:PHOLd:RESult?		6.78
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:MEAN:RESult?		6.77
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:MEAN[:STATe]	ON OFF	6.76
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:MODE	ABSolute RELative	6.81
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:PHOLd	ON OFF	6.80
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:PPEak:AVERage:RESult?		6.73
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:PPEak:PHOLd:RESult?		6.74
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:PPEak:RESult?		6.73
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:PPEak[:STATe]	ON OFF	6.72
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:REFerence:AUTO	ONCE	6.81
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:RMS:AVERage:RESult?		6.75
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:RMS:PHOLd:RESult?		6.76
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:RMS:RESult?		6.75
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:RMS[:STATe]	ON OFF	6.74
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:SDEVIation:AVERage:RESult?		6.79
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:SDEVIation:PHOLd:RESult?		6.80
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:SDEVIation:RESult?		6.79
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery:SDEVIation[:STATe]	ON OFF	6.78
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:SUMMery[:STATe]	ON OFF	6.72
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:TOI:RESult?		6.60
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:TOI[:STATe]	ON OFF	6.60
CALCulate<1 2>:MARKer<1 to 4>:FUNctioN:ZOOM	<numeric_value>	6.56
CALCulate<1 2>:MARKer<1 to 4>:LOEXclude	ON OFF	6.46
CALCulate<1 2>:MARKer<1 to 4>:MAXimum:AUTO	ON OFF	6.49
CALCulate<1 2>:MARKer<1 to 4>:MAXimum:LEFT		6.49
CALCulate<1 2>:MARKer<1 to 4>:MAXimum:NEXT		6.48

Command	Parameter	Page
CALCulate<1 2>:MARKer<1 to 4>:MAXimum[:PEAK]		6.47
CALCulate<1 2>:MARKer<1 to 4>:MAXimum:RIGHT		6.48
CALCulate<1 2>:MARKer<1 to 4>:MINimum:AUTO	ON OFF	6.49
CALCulate<1 2>:MARKer<1 to 4>:MINimum:LEFT		6.51
CALCulate<1 2>:MARKer<1 to 4>:MINimum:NEXT		6.50
CALCulate<1 2>:MARKer<1 to 4>:MINimum[:PEAK]		6.50
CALCulate<1 2>:MARKer<1 to 4>:MINimum:RIGHT		6.50
CALCulate<1 2>:MARKer<1 to 4>:PEXCursion	<numeric_value>	6.51
CALCulate<1 2>:MARKer<1 to 4>[:STATe]	ON OFF	6.42
CALCulate<1 2>:MARKer<1 to 4>:TRACe	1 to 3	6.42
CALCulate<1 2>:MARKer<1 to 4>:X	0 to MAX (frequency sweep time)	6.43
CALCulate<1 2>:MARKer<1 to 4>:X:SLIMits:LEFT	0 to MAX (frequency sweep time)	6.43
CALCulate<1 2>:MARKer<1 to 4>:X:SLIMits:RIGHT	0 to MAX (frequency sweep time)	6.44
CALCulate<1 2>:MARKer<1 to 4>:X:SLIMits[:STATe]	ON OFF	6.43
CALCulate<1 2>:MARKer<1 to 4>:X:SPUR?		6.44
CALCulate<1 2>:MARKer<1 to 4>:Y	<numeric_value>	6.46
CALCulate<1 2>:MARKer<1 to 4>:Y:PERCent	0 to 100%	6.47
CALCulate<1 2>:MARKer<1 to 4>:Y?		6.46
CALCulate<1 2>:MATH[:EXPRession][:DEFine]	(<expr>)	6.84
CALCulate<1 2>:MATH:MODE	LINear LOGarithmic	6.85
CALCulate<1 2>:MATH:POSition	-100PCT to 200PCT	6.84
CALCulate<1 2>:MATH:STATe	ON OFF	6.85
CALCulate<1 2>:PEAKsearch PSEarch:AUTO	ON OFF	6.86
CALCulate<1 2>:SNOise<1 to 5>:AOFF		6.87
CALCulate<1 2>:SNOise<1 to 5>:STATe	ON OFF	6.87
CALCulate<1 2>:SNOise<1 to 5>:X	1 Hz to 1 GHz	6.87
CALCulate<1 2>:SNOise<1 to 5>:Y?		6.87
CALCulate<1 2>:THReshold	MINimum to MAXimum (depending on current unit)	6.92
CALCulate<1 2>:THReshold:STATe	ON OFF	6.92
CALCulate<1 2>:TLINe<1 2>	0 to 1000s	6.93
CALCulate<1 2>:TLINe<1 2>:STATe	ON OFF	6.93
CALCulate<1 2>:UNIT:POWER	DBM V A W DBPW WATT DBUV DBMV VOLT DBUA AMPere DBPT DBUV_M DBUA_M	6.94
CALibration:ABORT		6.95
CALibration[:ALL]?		6.95
CALibration:RESult?		6.96
CALibration:STATe	ON OFF	6.96
CONFigure:EXTernal:LOWPass	ONCE	6.97
CONFigure:PNOise:MEASurement	SPECTrum PLL CCORrelation SNTuning	6.97
CONFigure:POWER:AUTO	ON OFF	6.98
CONFigure:POWER:EXPected:RF	-100 dBm to 30 dBm	6.97
CONFigure:REFMeas	ONCE	6.98
CONFigure:TRANSient:MEASurement	FREQuency PHASe AMPLitude POWER	6.98
CONFigure:TSETup	INT1 INT2 INT3 EXT1 EXT2 DUT1 DCON1 DCON2	6.98
CONFigure:VCO:MEASurement	TCHar TSENSitivity RFPower HPOWER DCCHar SUMMary	6.99
CONFigure:VCO:PULLing:SCALE	ABSolute RELative	6.100
CONFigure:VCO:PULLing[:STATe]	ON OFF	6.100
CONFigure:VCO:PUSHing:SCALE	ABSolute RELative	6.99
CONFigure:VCO:PUSHing[:STATe]	ON OFF	6.99
CONFigure:VCO:TRACe<1 to 4>:HARMonic	0 to 10	6.100

Command	Parameter	Page
DIAGnostic<1 2>:SERVice:CSOource[:POWer]	<numeric_value>	6.103
DIAGnostic<1 2>:SERVice:HWInfo?		6.103
DIAGnostic<1 2>:SERVice:INPut:PULSed:PRATe	10 kHz 62.5 kHz 100 kHz 500 kHz 1 MHz 128 MHz 640 MHz	6.101
DIAGnostic<1 2>:SERVice:INPut:PULSed[:STATe]	ON OFF	6.101
DIAGnostic<1 2>:SERVice:INPut:RECTangle:PRATe	<numeric_value>	6.102
DIAGnostic<1 2>:SERVice:INPut:RECTangle[:STATe]	ON OFF	6.102
DIAGnostic<1 2>:SERVice:INPut[:SElect]	CALibration RF	6.101
DIAGnostic<1 2>:SERVice:NSOource	ON OFF	6.103
DIAGnostic<1 2>:SERVice:SFUNction	'<string>'	6.102
DIAGnostic<1 2>:SERVice:STESt:RESult?		6.103
DISPlay:ANNotation:FREQuency	ON OFF	6.105
DISPlay:CMAP<1 to 26>:DEFault<1 2>		6.106
DISPlay:CMAP<1 to 26>:HSL	<hue>, <sat>, <lum>	6.106
DISPlay:CMAP<1 to 26>:PDEFined	BLACK BLUE BROWn GREen CYAN RED MAGenta YELLOW WHITE DGRAY LGRAY LBLUe LGREen LCYan LRED LMAGenta	6.107
DISPlay:FORMat	SINGLE SPLit	6.105
DISPlay:LOGO	ON OFF	6.105
DISPlay:PSAVe:HOLDoff	1 to 60	6.106
DISPlay:PSAVe[:STATe]	ON OFF	6.105
DISPlay[:WINDow<1 2>]:ACTive?		6.107
DISPlay[:WINDow<1 2>]:SElect		6.108
DISPlay[:WINDow<1 2>]:SIZE	LARGE SMALL	6.108
DISPlay[:WINDow<1 2>]:TEXT[:DATA]	<string>	6.108
DISPlay[:WINDow<1 2>]:TEXT:STATe	ON OFF	6.109
DISPlay[:WINDow<1 2>]:TIME	ON OFF	6.109
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:MODE:HCONtinuous	ON OFF	6.115
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:X:SPACing	LINear LOGarithmic	6.109
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:Y[:SCALE]:MODE	ABSolute RELative	6.110
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:Y[:SCALE]:RPOSition	0 to 100PCT	6.111
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:Y[:SCALE]:RVALue	<numeric_value>	6.111
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:Y:SPACing	LINear LOGarithmic LDB	6.112
DISPlay[:WINDow<1 2>]:TRACe<1 to 3>:Y:UNIT?		6.113
DISPlay[:WINDow<1 2>]:TRACe<1 to n>:MODE	WRITE VIEW AVERage MAXHold MINHold	6.114
DISPlay[:WINDow<1 2>]:TRACe<1 to n>[:STATe]	ON OFF	6.115
DISPlay[:WINDow<1 2>]:TRACe<1 to n>:Y[:SCALE]	10dB to 200dB	6.110
DISPlay[:WINDow<1 2>]:TRACe<1 to n>:Y[:SCALE]:RLEVel	-130 dBm to 30 dBm (analyzer mode)-200 dBc/Hz to 50 dBc/Hz (phase noise mode)	6.110
DISPlay[:WINDow<1 2>]:TRACe<1 to n>:Y[:SCALE]:RLEVel:OFFSet	-200dB to 200dB	6.111
DISPlay[:WINDow<1 2>]:TRACe<1...8>:SCOPE[:STATe]	ON OFF	6.116
DISPlay[:WINDow<1 2>]:TRACe<1...8>:SMOothing:APERture	1 to 20	6.116
DISPlay[:WINDow<1 2>]:TRACe<1...8>:SMOothing[:STATe]	ON OFF	6.116
DISPlay[:WINDow<1 2>]:TRACe<1...8>:SMOothing:TYPE	LINear LOGarithmic MEDian	6.116
DISPlay[:WINDow<1 2>]:TRACe<1...8>:X:UNIT	VOLTage FREQuency	6.109
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y[:SCALE]:AUTO	ON OFF ONCE	6.110
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:OFFSet	<numeric_value>	6.113
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:RANGe	<numeric_value>	6.113
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:TOP	<numeric_value>	6.112
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:TRANSient[:SCALE]:AUTO	ON OFF ONCE	6.112
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:VCO[:SCALE]:AUTO	ON OFF ONCE	6.113
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:VCO[:SCALE]:OFFSet	<numeric_value>	6.114
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:VCO[:SCALE]:RANGe	<numeric_value>	6.114
DISPlay[:WINDow<1 2>]:TRACe<1...8>:Y:VCO[:SCALE]:TOP	<numeric_value>	6.114

Command	Parameter	Page
FETCh:EXternal:LOWPass:FREQuency?		6.117
FETCh:PNOise<1 to 8>:IPN?		6.117
FETCh:PNOise<1 to 8>:RFM?		6.117
FETCh:PNOise<1 to 8>:RMS?		6.118
FETCh:PNOise<1 to 8>:RPM?		6.117
FETCh:PNOise<1 to 8>:SPURs?		6.118
FETCh:VCO:DCHAr<1 to 4>:FREQuency?		6.121
FETCh:VCO:DCHAr<1 to 4>:POWer?		6.122
FETCh:VCO:HCHAr<1 to 8>:FREQuency?		6.120
FETCh:VCO:HCHAr<1 to 8>:POWer:ABSolute?		6.121
FETCh:VCO:HCHAr<1 to 8>:POWer:RELative?		6.121
FETCh:VCO:HCHAr<1 to 8>:SENSitivity?		6.121
FETCh:VCO:PULLing:FDEViation?		6.120
FETCh:VCO:PULLing:PDEViation?		6.120
FETCh:VCO:PULLing:SENSitivity?		6.120
FETCh:VCO:PUSHing:FDEViation?		6.119
FETCh:VCO:PUSHing:PDEViation?		6.119
FETCh:VCO:PUSHing:SENSitivity?		6.119
FETCh:VCO:TCHAr<1 to 4>:FREQuency?		6.118
FETCh:VCO:TCHAr<1 to 4>:POWer?		6.118
FETCh:VCO:TCHAr<1 to 4>:SENSitivity?		6.119
FORMat[:DATA]	ASCIi REAL UINt [, 8 32]	6.123
FORMat:DEXPort:DSEParator	POINt COMMA	6.123
HCOPy:ABORt		6.124
HCOPy:CMAP<1 to 26>:DEFault1 2 3		6.124
HCOPy:CMAP<1 to 26>:HSL	<hue>, <sat>, <lum>	6.124
HCOPy:CMAP<1 to 26>:PDEFined	BLACK BLUE BROWn GREen CYAN RED MAGenta YELLow WHITe DGRAY LGRAY LBLUe LGREen LCYan LRED LMAGenta	6.125
HCOPy:DESTination<1 2>	<string>	6.126
HCOPy:DEVice:COLor	ON OFF	6.126
HCOPy:DEVice:LANGUage<1 2>	GDI WMF EWMF BMP	6.127
HCOPy[:IMMEDIATE<1 2>]		6.127
HCOPy:ITEM:ALL		6.127
HCOPy:ITEM:WINDow<1 2>:TABLe:STATe	ON OFF	6.128
HCOPy:ITEM:WINDow<1 2>:TEXT	<string>	6.128
HCOPy:ITEM:WINDow<1 2>:TRACe:STATe	ON OFF	6.128
HCOPy:PAGE:ORientation<1 2>	LANDscape PORTRait	6.129
INITiate<1 2>:CONMeas		6.130
INITiate<1 2>:CONTinuous	ON OFF	6.130
INITiate<1 2>:DISPlay	ON OFF	6.131
INITiate<1 2>[:IMMEDIATE]		6.131
INITiate<1 2>:SPURious		6.132
INPut:COUPling	AC DC	6.134
INPut:GAIN:AUTO	ON OFF	6.135
INPut:LNA:GAIN	0 20 30 AUTO	6.136
INPut:LNA:GAIN:AUTO	ON OFF	6.136
INPut<1 2>:ATTenuation	0 to 75dB	6.133
INPut<1 2>:ATTenuation:AUTO	ON OFF	6.133
INPut<1 2>:ATTenuation:PROTection:RESet		6.133
INPut<1 2>:EATT	0 to 30dB	6.134
INPut<1 2>:EATT:AUTO	ON OFF	6.134
INPut<1 2>:EATT:STATe	ON OFF	6.135
INPut<1 2>:GAIN:STATe	ON OFF	6.135

Command	Parameter	Page
INPut<1 2>:IMPedance	50 75	6.136
INPut<1 2>:MIXer:AUTO	ON OFF	6.136
INPut<1 2>:MIXer[:POWER]	<numeric value>	6.136
INSTrument:COUPle	NONE RLeVel CF_B CF_A	6.138
INSTrument:NSElect	<numeric value>	6.137
INSTrument[:SElect]	SANalyzer ADEMod PNOise	6.137
MMEMy:CATalog:LONG?	<path>	6.140
MMEMy:CATalog?	<path>	6.139
MMEMy:CDIRectory	<directory_name>	6.140
MMEMy:CLEar:ALL		6.148
MMEMy:CLEar:STATe	1,<file_name>	6.148
MMEMy:COMMeNt	<string>	6.151
MMEMy:COpy	<file_source>,<file_destination>	6.140
MMEMy:DATA	<file_name>[,<block data>]	6.141
MMEMy:DELeTe	<file_name>	6.141
MMEMy:INItialize	<msus>	6.142
MMEMy:LOAD:AUTO	1,<file_name>	6.142
MMEMy:LOAD:STATe	1,<file_name>	6.142
MMEMy:MDIRectory	<directory_name>	6.143
MMEMy:MOVE	<file_source>,<file_destination>	6.143
MMEMy:MSIS	<device>	6.143
MMEMy:NAME	<file_name>	6.143
MMEMy:RDIRectory	<directory_name>	6.144
MMEMy:SElect[:ITEM]:ALL		6.150
MMEMy:SElect[:ITEM]:DEFault		6.151
MMEMy:SElect[:ITEM]:HWSettings	ON OFF	6.149
MMEMy:SElect[:ITEM]:LINES:ALL	ON OFF	6.149
MMEMy:SElect[:ITEM]:NONE		6.150
MMEMy:SElect[:ITEM]:SCData	ON OFF	6.150
MMEMy:SElect[:ITEM]:TRACe[:ACTive]	ON OFF	6.149
MMEMy:SElect[:ITEM]:TRANsducer:ALL	ON OFF	6.150
MMEMy:STORe:SPURious	<file_name>	6.144
MMEMy:STORe<1 2>:MARKer	<file_name>	6.148
MMEMy:STORe<1 2>:SPURs	<file_name>	6.145
MMEMy:STORe<1 2>:STATe	1,<file_name>	6.145
MMEMy:STORe<1 2>:TRACe	1 to n,<file_name>	6.145
[SENSe]:BANDwidth:DEMod	100 Hz to 30 MHz	6.154
[SENSe:]CORRection:CVL: BAND	A Q U V E W F D G Y J USER	6.164
[SENSe:]CORRection:CVL:BIAS	<numeric_value>	6.165
[SENSe:]CORRection:CVL:CLEar		6.166
[SENSe:]CORRection:CVL:COMMeNt	<string>	6.165
[SENSe:]CORRection:CVL:DATA	<freq>,<level>..	6.166
[SENSe:]CORRection:CVL:HARMonic	<numeric_value>	6.164
[SENSe:]CORRection:CVL:MIXer	<string>	6.163
[SENSe:]CORRection:CVL:PORTs	2 3	6.165
[SENSe:]CORRection:CVL:SElect	<file_name>	6.163
[SENSe:]CORRection:CVL:SNUMber	<string>	6.163
[SENSe]:FILTer:LPASs:FREQuency:RELative	5 10 25	6.168
[SENSe]:FREQuency:MULTIplier	max. 1024	6.170
[SENSe]:FREQuency:TRACk	ON OFF	6.171
[SENSe]:FREQuency:VERify[:STATe]	ON OFF	6.171
[SENSe]:FREQuency:VERify:TOLerance	1 Hz/1 PCT to 1 MHz/100 PCT	6.172
[SENSe]:LIST:BWIDTh[:RESolution]:RATio	0.1 PCT to 30 PCT	6.173
[SENSe]:LIST:BWIDTh[:RESolution]:TYPE	NORMal FFT	6.174
[SENSe]:LIST:RANGe<1...20>:BWIDTh[:RESolution]	<numeric_value>	6.179

Command	Parameter	Page
[SENSe]:LIST:RANGe<1...20>:FILTer:TYPE	NORMal FFT	6.180
[SENSe]:LIST:RANGe<1...20>:SWEep:COUNT	<numeric_value>	6.182
[SENSe]:LIST:SWEep:COUNT	1 to 10000	6.183
[SENSe:]MIXer:BIAS:HIGH	<numeric_value>	6.186
[SENSe:]MIXer:BIAS[:LOW]	<numeric_value>	6.186
[SENSe:]MIXer:HARMonic	2 to 64	6.184
[SENSe:]MIXer:HARMonic:BAND	A Q U V E W F D G Y J USER	6.185
[SENSe:]MIXer:HARMonic:TYPE	ODD EVEN EODD	6.185
[SENSe:]MIXer:LOSS:HIGH	<numeric_value>	6.185
[SENSe:]MIXer:LOSS[:LOW]	<numeric_value>	6.185
[SENSe:]MIXer:LOSS:TABLE:HIGH	<file_name>	6.186
[SENSe:]MIXer:LOSS:TABLE[:LOW]	<file_name>	6.186
[SENSe:]MIXer:PORTs	2 3	6.184
[SENSe:]MIXer:SIGNAL	ON OFF AUTO ALL	6.184
[SENSe:]MIXer[:STATe]	ON OFF	6.184
[SENSe:]MIXer:THReshold	<numeric_value>	6.187
SENSe:MPOWer:RESult[:LIST]?		6.191
SENSe:MPOWer:RESult:MIN?		6.191
[SENSe]:POWer:RLEVel	-100 dB to 30 dB	6.197
[SENSe]:POWer:RLEVel:VERify[:STATe]	ON OFF	6.198
[SENSe]:POWer:RLEVel:VERify:TOLerance	3 dB to 20 dB	6.198
[SENSe]:POWer:TRACk	ON OFF	6.199
[SENSe]:SPURs:HIGHlight:STATe	ON OFF	6.202
[SENSe]:SPURs:SETup<1 2>:COUNT	1 to 50	6.202
[SENSe]:SPURs:SETup<1 2>:ENABLE	ON OFF	6.202
[SENSe]:SPURs:SETup<1 2>:FUNDamental	0 Hz to 1 GHz	6.202
[SENSe]:SPURs:SUPPRes	NONE ALL UNSelected SElected	6.203
[SENSe]:SPURs:THReshold	0 to 50	6.203
[SENSe]:SWEep:FFTWindow	CHEBychev GAUSSian RECTangular	6.207
[SENSe]:SWEep:FORWard	ON OFF	6.207
[SENSe]:SWEep:MODE	FAST NORMal AVERaged MANual	6.208
[SENSe]:SWEep:POINts?		6.209
[SENSe]:SWEep:TIME	15.63 ns to 1069 s	6.204
[SENSe]:SWEep:XOPTimize	ON OFF	6.209
[SENSe]:VCO:CONTRol:DELay	0 s to 10 s	6.210
[SENSe]:VCO:CSEarch:AUTO	ON OFF	6.210
[SENSe]:VCO:CSEarch:SPAN	1 Hz to fmax	6.210
[SENSe]:VCO:CSEarch:START	1 Hz to fmax	6.210
[SENSe]:VCO:CSEarch:STOP	<start frequency> to fmax	6.211
[SENSe]:VCO:DRIFT	-10 MHz/s to 10 MHz/s	6.211
[SENSe]:VCO:FCOunter:COUPled	ON OFF	6.211
[SENSe]:VCO:FCOunter:RESolution	1 Hz to 10 kHz	6.211
[SENSe]:VCO:LOOP:BWIDth	1 Hz to 30 kHz ONCE	6.211
[SENSe]:VCO:LOOP:BWIDth:AUTO	ON OFF	6.212
[SENSe]:VCO:LOOP:SLOPe	1 Hz/V to 10 GHz/V	6.212
[SENSe]:VCO:PDETector:HARMonic	1 to 10	6.212
[SENSe]:VCO:PDETector:HARMonic:STATe	ON OFF	6.213
[SENSe]:VCO:PDETector:LEVel	-30 dBm to 20 dBm	6.213
[SENSe]:VCO:PDETector:LPNoise:LEVel?		6.213
[SENSe]:VCO:PDETector:LPNoise:OFFSet?		6.213
[SENSe]:VCO:PDETector:LPNoise:SLOPe?		6.214
[SENSe]:VCO:PDETector:OFFSet	-1 V to 1 V	6.214
[SENSe]:VCO:PDETector:PREMeas[:STATe]	ON OFF	6.214
[SENSe]:VCO:PDETector:SLOPe	0 V/rad to 1 V/rad	6.214
[SENSe]:VCO:POWer:DELay	0 s to 10 s	6.215

Command	Parameter	Page
[SENSe]:VCO:PREMeas[:STATe]	ON OFF ONCE	6.215
[SENSe]:VCO:PUSHing:POINts	3 to 1000	6.215
[SENSe]:VCO:SLOPe	-10 GHz/V to 10 GHz/V	6.215
[SENSe]:VCO:SWEp:TIME	0 s to 10 s	6.216
[SENSe]:VCO:TRACking	1 mHz/s to 1 MHz/s	6.216
[SENSe]:VCO:TRANge	-50 GHz to 50 GHz	6.216
[SENSe]:VCO:TUNing:POINts	3 to 1000	6.216
[SENSe<1 2>]:AVERAge:COUNT	0 to 32767	6.152
[SENSe<1 2>]:AVERAge[:STATe<1 to 3>]	ON OFF	6.153
[SENSe<1 2>]:AVERAge:TYPE	VIDeo LINear	6.153
[SENSe<1 2>]:BANDwidth BWIDTH:FFT	WIDE AUTO NARROW	6.154
[SENSe<1 2>]:BANDwidth BWIDTH:PLL	AUTO HIGH MEDium LOW	6.157
[SENSe<1 2>]:BANDwidth BWIDTH[:RESolution]	10 Hz to 50 MHz	6.154
[SENSe<1 2>]:BANDwidth BWIDTH[:RESolution]:AUTO	ON OFF	6.155
[SENSe<1 2>]:BANDwidth BWIDTH[:RESolution]:RATio	0.0001 to 1	6.155
[SENSe<1 2>]:BANDwidth BWIDTH[:RESolution]:TYPE	NORMal FFT CFILter RRC P5	6.155
[SENSe<1 2>]:BANDwidth BWIDTH:VIDeo	1Hz to 10MHz	6.156
[SENSe<1 2>]:BANDwidth BWIDTH:VIDeo:AUTO	ON OFF	6.156
[SENSe<1 2>]:BANDwidth BWIDTH:VIDeo:RATio	0.01 to 1000	6.156
[SENSe<1 2>]:BANDwidth BWIDTH:VIDeo:TYPE	LINear LOGarithmic	6.157
[SENSe<1 2>]:CORRection:COLLect[:ACQuire]	THRough OPEN	6.158
[SENSe<1 2>]:CORRection:CVL:CATalog?		6.162
[SENSe<1 2>]:CORRection:METHod	TRANsmission REFLection	6.158
[SENSe<1 2>]:CORRection:RECall		6.159
[SENSe<1 2>]:CORRection[:STATe]	ON OFF	6.158
[SENSe<1 2>]:CORRection:TRANsducer:ACTive?		6.159
[SENSe<1 2>]:CORRection:TRANsducer:ADJust:RLEVel[:STATe]	ON OFF	6.162
[SENSe<1 2>]:CORRection:TRANsducer:CATalog?		6.159
[SENSe<1 2>]:CORRection:TRANsducer:COMMeNT	<string>	6.161
[SENSe<1 2>]:CORRection:TRANsducer:DATA	<freq>,<level>..	6.161
[SENSe<1 2>]:CORRection:TRANsducer:DELete		6.162
[SENSe<1 2>]:CORRection:TRANsducer:GENerate	<name>	6.159
[SENSe<1 2>]:CORRection:TRANsducer:SCALing	LINear LOGarithmic	6.160
[SENSe<1 2>]:CORRection:TRANsducer:SELect	<name>	6.160
[SENSe<1 2>]:CORRection:TRANsducer[:STATe]	ON OFF	6.161
[SENSe<1 2>]:CORRection:TRANsducer:UNIT	<string>	6.160
[SENSe<1 2>]:DETEctor<1 to 3>[:FUNction]:AUTO	ON OFF	6.167
[SENSe<1 2>]:FREQuency:CENTer	0 to fmax	6.169
[SENSe<1 2>]:FREQuency:CENTer:STEP	0 to fmax	6.169
[SENSe<1 2>]:FREQuency:CENTer:STEP:LINK	SPAN RBW OFF	6.169
[SENSe<1 2>]:FREQuency:CENTer:STEP:LINK:FACTor	1 to 100 PCT	6.169
[SENSe<1 2>]:FREQuency:MODE	CW FIXed SWEp	6.171
[SENSe<1 2>]:FREQuency:OFFSet	<numeric_value>	6.171
[SENSe<1 2>]:FREQuency:SPAN	0 to fmax	6.170
[SENSe<1 2>]:FREQuency:SPAN:FULL		6.170
[SENSe<1 2>]:FREQuency:START	0 to fmax	6.170
[SENSe<1 2>]:FREQuency:STOP	0 to fmax	6.171
[SENSe<1 2>]:LIST:POWer:RESult?		6.174
[SENSe<1 2>]:LIST:POWer[:SEQuence]	<analyzer freq>,<ref level>,<rf att>,<el att>,<filter type>,<rbw>,<vbw>,<meas time>,<trigger level>,<to	6.175
[SENSe<1 2>]:LIST:POWer:SET	<PEAK meas>,<RMS meas>,<AVG meas>,<trigger mode>,<trigger slope>,<trigger offset>,<gate length>	6.177
[SENSe<1 2>]:LIST:POWer:SET:AVERAge:TYPE	LINear LOGarithmic	6.178

Command	Parameter	Page
[SENSe<1 2>:]LIST:POWer:STATe	OFF	6.179
[SENSe<1 2>:]LIST:RANGe<1...20>:LIMit	-200dB to +200dB	6.183
[SENSe<1 2>:]LIST:RANGe<1...20>:LIMit:STATe	ON OFF	6.183
[SENSe<1 2>:]LIST:RANGe<1...20>:BANDwidth[:RESolution]	<numeric_value>	6.179
[SENSe<1 2>:]LIST:RANGe<1...20>:BANDwidth:VIDeo	<numeric_value>	6.179
[SENSe<1 2>:]LIST:RANGe<1...20>:BREAk	ON OFF	6.179
[SENSe<1 2>:]LIST:RANGe<1...20>:COUNT?		6.180
[SENSe<1 2>:]LIST:RANGe<1...20>:DELeTe		6.180
[SENSe<1 2>:]LIST:RANGe<1...20>:DETEctor	APEak NEGative POSitive SAMPlE RMS AVERAge	6.180
[SENSe<1 2>:]LIST:RANGe<1...20>:FILTer:TYPE	NORMal CHANnel RRC P5 NOISe PULSe	6.180
[SENSe<1 2>:]LIST:RANGe<1...20>[:FREQUency]:STARt	<numeric_value>	6.181
[SENSe<1 2>:]LIST:RANGe<1...20>[:FREQUency]:STOP	<numeric_value>	6.181
[SENSe<1 2>:]LIST:RANGe<1...20>:INPut:ATTenuation	<numeric_value>	6.181
[SENSe<1 2>:]LIST:RANGe<1...20>:INPut:ATTenuation:AUTO	ON OFF	6.181
[SENSe<1 2>:]LIST:RANGe<1...20>:INPut:GAIN[:STATE]	ON OFF	6.181
[SENSe<1 2>:]LIST:RANGe<1...20>:POINts	<numeric_value>	6.182
[SENSe<1 2>:]LIST:RANGe<1...20>:RLEVel	<numeric_value>	6.182
[SENSe<1 2>:]LIST:RANGe<1...20>:SWEp:TIME	<numeric_value>	6.182
[SENSe<1 2>:]LIST:RANGe<1...20>:SWEp:TIME:AUTO	ON OFF	6.182
[SENSe<1 2>:]LIST:RANGe<1...20>:TRANsducer	<string>	6.183
[SENSe<1 2>:]MIXer:LOPower	<numeric_value>	6.187
[SENSe<1 2>:]MPOWER[:SEQUence]	<analyzer freq>, <rbw>, <meas time>, <trigger source>, <trigger level>, <trigger offset>, <type of meas>, <# of meas>	6.189
[SENSe<1 2>:]POWER:ACHannel:ACPairs	0 to 12	6.193
[SENSe<1 2>:]POWER:ACHannel:BANDwidth BWIDth:ACHannel	100 Hz to 1000 MHz	6.194
[SENSe<1 2>:]POWER:ACHannel:BANDwidth BWIDth:ALTErnate<1 to 11>	100 Hz to 1000 MHz	6.194
[SENSe<1 2>:]POWER:ACHannel:MODE	ABSolute RELative	6.194
[SENSe<1 2>:]POWER:ACHannel:PRESet	ACPowEr CPowEr MCACpowEr OBANDwidth OBWidth CN CNO	6.195
[SENSe<1 2>:]POWER:ACHannel:PRESet:RLEVel		6.196
[SENSe<1 2>:]POWER:ACHannel:REFerence:AUTO	ONCE	6.194
[SENSe<1 2>:]POWER:ACHannel:REFerence:TXCHannel:AUTO	MINimum MAXimum LHIGHest OFF	6.195
[SENSe<1 2>:]POWER:ACHannel:SPACing:ACHannel	100 Hz to 2000 MHz	6.192
[SENSe<1 2>:]POWER:ACHannel:SPACing:ALTErnate<1 to 11>	100 Hz to 2000 MHz	6.192
[SENSe<1 2>:]POWER:ACHannel:SPACing:CHANnel<1 to 11>	100 Hz to 2000 MHz	6.192
[SENSe<1 2>:]POWER:ACHannel:TXCHannel:COUNT	1 to 12	6.193
[SENSe<1 2>:]POWER:BANDwidth BWIDth	10 to 99.9PCT	6.196
[SENSe<1 2>:]POWER:HSPEed	ON OFF	6.197
[SENSe<1 2>:]POWER:NCORrection	ON OFF	6.197
[SENSe<1 2>:]POWER:TRACe	1 to 3	6.198
[SENSe<1 2>:]ROSCillator:EXTernal:FREQUency	1MHz to 20MHz	6.200
[SENSe<1 2>:]ROSCillator[:INTernal]:TUNe	0 to 4095	6.200
[SENSe<1 2>:]ROSCillator[:INTernal]:TUNe:SAVE		6.201
[SENSe<1 2>:]ROSCillator:SOURce	INTernal EXTernal	6.200
[SENSe<1 2>:]SWEp:COUNT	0 to 32767	6.204
[SENSe<1 2>:]SWEp:COUNT:CURRent?		6.205
[SENSe<1 2>:]SWEp:EGATe	ON OFF	6.205
[SENSe<1 2>:]SWEp:EGATe:HOLDoff	125 ns to 100 s	6.206
[SENSe<1 2>:]SWEp:EGATe:LENGth	0 to 100 s	6.207
[SENSe<1 2>:]SWEp:EGATe:POLarity	POSitive NEGative	6.206
[SENSe<1 2>:]SWEp:EGATe:SOURce	EXTernal IFPower	6.207
[SENSe<1 2>:]SWEp:EGATe:TYPE	LEVel EDGE	6.206

Command	Parameter	Page
[SENSe<1 2>].SWEep:IF:SHIFt	OFF A B	6.208
[SENSe<1 2>].SWEep:MODE	AUTO LIST	6.208
[SENSe<1 2>].SWEep:POINts	155, 313, 625, 1251, 1999, 2501, 5001, 10001, 20001, 30001	6.208
[SENSe<1 2>].SWEep:TIME	2.5ms to 16000s (frequency domain) 1µs to 16000s (time domain)	6.204
[SENSe<1 2>].SWEep:TIME:AUTO	ON OFF	6.204
SOURce:CURRent:AUX:LIMit:HIGH	-500 mA to 0 mA	6.217
SOURce:CURRent:CONTRol<1 2>:LIMit:HIGH	0 to 20 mA	6.217
SOURce:CURRent:POWer<1 2>:LIMit:HIGH	0 to 500 mA	6.217
SOURce:CURRent:SEQuence:RESult?		6.217
SOURce:POWer:SEQuence:RESult?		6.218
SOURce:VOLTagE:AUX:LEVel:AMPLitude	-10 V to 0 V	6.218
SOURce:VOLTagE:AUX:LEVel[:STATe]	ON OFF	6.218
SOURce:VOLTagE:CONTRol<1 2>:AFC:ITERations		6.220
SOURce:VOLTagE:CONTRol<1 2>:AFC:LIMit:HIGH		6.220
SOURce:VOLTagE:CONTRol<1 2>:AFC:LIMit:LOW		6.220
SOURce:VOLTagE:CONTRol<1 2>:AFC[:STATe]		6.219
SOURce:VOLTagE:CONTRol<1 2>:AFC:TARGet		6.219
SOURce:VOLTagE:CONTRol<1 2>:AFC:TOLerance		6.220
SOURce:VOLTagE:CONTRol<1 2>:LEVel:AMPLitude	<numeric_value>	6.219
SOURce:VOLTagE:CONTRol<1 2>:LEVel:LIMit:HIGH	-9.5 V to 28 V	6.219
SOURce:VOLTagE:CONTRol<1 2>:LEVel:LIMit:LOW	-10 V to 27.5 V	6.219
SOURce:VOLTagE:CONTRol<1 2>:LEVel[:STATe]	ON OFF	6.218
SOURce:VOLTagE:POWer<1 2>:LEVel:AMPLitude	<numeric_value>	6.222
SOURce:VOLTagE:POWer<1 2>:LEVel:LIMit:HIGH	0 V to 12.25 V	6.222
SOURce:VOLTagE:POWer<1 2>:LEVel:LIMit:LOW	0 V to 12.25 V	6.222
SOURce:VOLTagE:POWer<1 2>:LEVel[:STATe]	ON OFF	6.221
SOURce:VOLTagE:POWer<1 2>:PUSHing	0 V to Vmax	6.222
SOURce:VOLTagE:SEQuence:LIST	<port>,<delay>,...	6.221
SOURce:VOLTagE:SEQuence:RESult?		6.221
SOURce:VOLTagE:SEQuence[:STATe]	ON OFF	6.221
SOURce:VOLTagE[:STATe]	ON OFF	6.218
SOURce<1 2>:EXTErnal<1 2>:FREQUency[:FACTor]:DENominator	<numeric_value>	6.224
SOURce<1 2>:EXTErnal<1 2>:FREQUency[:FACTor]:NUMerator	<numeric_value>	6.224
SOURce<1 2>:EXTErnal<1 2>:FREQUency:OFFSet	<numeric_value>	6.225
SOURce<1 2>:EXTErnal<1 2>:FREQUency:SWEep[:STATe]	ON OFF	6.225
SOURce<1 2>:EXTErnal<1 2>:POWer[:LEVel]	<numeric_value>	6.225
SOURce<1 2>:EXTErnal<1 2>:ROSCillator[:SOURce]	INTernAl EXTErnAl	6.226
SOURce<1 2>:EXTErnal<1 2>[:STATe]	ON OFF	6.223
STATus:OPERation:CONDition?		6.227
STATus:OPERation:ENABle	0 to 65535	6.227
STATus:OPERation[:EVENT]?		6.227
STATus:OPERation:NTRansition	0 to 65535	6.228
STATus:OPERation:PTRansition	0 to 65535	6.227
STATus:PRESet		6.228
STATus:QUESTionable:ACPLimit:CONDition?		6.237
STATus:QUESTionable:ACPLimit:ENABle	0 to 65535	6.237
STATus:QUESTionable:ACPLimit[:EVENT]?		6.237
STATus:QUESTionable:ACPLimit:NTRansition	0 to 65535	6.238
STATus:QUESTionable:ACPLimit:PTRansition	0 to 65535	6.237
STATus:QUESTionable:CONDition?		6.228
STATus:QUESTionable:DCPNoise:CONDition?		6.234
STATus:QUESTionable:DCPNoise:ENABle	0 to 65535	6.234
STATus:QUESTionable:DCPNoise[:EVENT]?		6.233

Command	Parameter	Page
STATus:QUESTionable:DCPNoise:NTRansition	0 to 65535	6.234
STATus:QUESTionable:DCPNoise:PTRansition	0 to 65535	6.234
STATus:QUESTionable:ENABle	0 to 65535	6.229
STATus:QUESTionable[:EVENT]?		6.228
STATus:QUESTionable:FREQuency:CONDition?		6.238
STATus:QUESTionable:FREQuency:ENABle	0 to 65535	6.238
STATus:QUESTionable:FREQuency[:EVENT]?		6.238
STATus:QUESTionable:FREQuency:NTRansition	0 to 65535	6.239
STATus:QUESTionable:FREQuency:PTRansition	0 to 65535	6.238
STATus:QUESTionable:LIMit<1 2> [:EVENT]?		6.230
STATus:QUESTionable:LIMit<1 2>:CONDition?		6.230
STATus:QUESTionable:LIMit<1 2>:ENABle	0 to 65535	6.231
STATus:QUESTionable:LIMit<1 2>:NTRansition	0 to 65535	6.231
STATus:QUESTionable:LIMit<1 2>:PTRansition	0 to 65535	6.231
STATus:QUESTionable:LMARgin<1 2> [:EVENT]?		6.231
STATus:QUESTionable:LMARgin<1 2>:CONDition?		6.231
STATus:QUESTionable:LMARgin<1 2>:ENABle	0 to 65535	6.232
STATus:QUESTionable:LMARgin<1 2>:NTRansition	0 to 65535	6.232
STATus:QUESTionable:LMARgin<1 2>:PTRansition	0 to 65535	6.232
STATus:QUESTionable:LPNoise:CONDition?		6.235
STATus:QUESTionable:LPNoise:ENABle	0 to 65535	6.235
STATus:QUESTionable:LPNoise[:EVENT]?		6.235
STATus:QUESTionable:LPNoise:NTRansition	0 to 65535	6.235
STATus:QUESTionable:LPNoise:PTRansition	0 to 65535	6.235
STATus:QUESTionable:NTRansition	0 to 65535	6.229
STATus:QUESTionable:PNOise:CONDition?		6.232
STATus:QUESTionable:PNOise:ENABle	0 to 65535	6.233
STATus:QUESTionable:PNOise[:EVENT]?		6.232
STATus:QUESTionable:PNOise:NTRansition	0 to 65535	6.233
STATus:QUESTionable:PNOise:PTRansition	0 to 65535	6.233
STATus:QUESTionable:POWER:CONDition?		6.229
STATus:QUESTionable:POWER:ENABle	0 to 65535	6.230
STATus:QUESTionable:POWER[:EVENT]?		6.229
STATus:QUESTionable:POWER:NTRansition	0 to 65535	6.230
STATus:QUESTionable:POWER:PTRansition	0 to 65535	6.230
STATus:QUESTionable:PTRansition	0 to 65535	6.229
STATus:QUESTionable:SYNC:CONDition?		6.236
STATus:QUESTionable:SYNC:ENABle	0 to 65535	6.236
STATus:QUESTionable:SYNC[:EVENT]?		6.236
STATus:QUESTionable:SYNC:NTRansition	0 to 65535	6.237
STATus:QUESTionable:SYNC:PTRansition	0 to 65535	6.236
STATus:QUEue[:NEXT]?		6.239
SYSTem:COMMunicate:GPIB:RDEvice:COMMand	0...30,<command string>	6.241
SYSTem:COMMunicate:GPIB:RDEvice:GENerator<1 2>:ADDRess	0 to 30	6.240
SYSTem:COMMunicate:GPIB[:SELF]:ADDRess	0 to 30	6.240
SYSTem:COMMunicate:GPIB[:SELF]:RTERminator	LFEOI EOI	6.240
SYSTem:COMMunicate:PRINter:ENUMerate:FIRSt?		6.243
SYSTem:COMMunicate:PRINter:ENUMerate:NEXt?		6.244
SYSTem:COMMunicate:PRINter:SELect <1 2>	<printer_name>	6.244
SYSTem:COMMunicate:RDEvice:GENerator<1 2>:LINK	GPIB TTL	6.241
SYSTem:COMMunicate:RDEvice:GENerator<1 2>:TYPE	<name>	6.242
SYSTem:COMMunicate:SERial:CONTRol:DTR	IBFull OFF	6.242
SYSTem:COMMunicate:SERial:CONTRol:RTS	IBFull OFF	6.242
SYSTem:COMMunicate:SERial[:RECeive]:BAUD	110 300 600 1200 2400 9600 19200	6.242
SYSTem:COMMunicate:SERial[:RECeive]:BITS	7 8	6.243

Command	Parameter	Page
SYSTem:COMMunicate:SERial[:RECeive]:PACE	XON NONE	6.243
SYSTem:COMMunicate:SERial[:RECeive]:PARity[:TYPE]	EVEN ODD NONE	6.243
SYSTem:COMMunicate:SERial[:RECeive]:SBITs	1 2	6.243
SYSTem:DATE	1980 to 2099, 1 to 12, 1 to 31	6.244
SYSTem:DISPlay:FPANel	ON OFF	6.245
SYSTem:DISPlay:UPDate	ON OFF	6.245
SYSTem:ERRor:CLear:ALL		6.246
SYSTem:ERRor:LIST?		6.246
SYSTem:ERRor?		6.246
SYSTem:FIRMware:UPDate	<path>	6.246
SYSTem:IDENtify:FACTory		6.249
SYSTem:IFGain:MODE	NORMal PULSe	6.247
SYSTem:LANGUage	'SCPI' '71100C' '71200C' '71209A' '8560E' '8561E' '8562E' '8563E' '8564E' '8565E' '8566A' '8566B' '8568A' '8568B' '8591E' '8594E'	6.247
SYSTem:MSIZe?	MBOard	6.250
SYSTem:PASSword[:CENable]	'password'	6.248
SYSTem:PRESet		6.248
SYSTem:PRESet:COMPAtible	OFF SANalyzer	6.248
SYSTem:SPEaker:VOLume	0 to 1	6.249
SYSTem:TIME	0 to 23, 0 to 59, 0 to 59	6.249
SYSTem:VERSion?		6.249
TRACe<1 2>:COPY	TRACE1 TRACE2 TRACE3 , TRACE1 TRACE2 TRACE3	6.254
TRACe<1 2>[:DATA]	TRACE1 TRACE2 TRACE3 TRACE4 TRACE5 TRACE6 TRACE7 TRACE8 SPURious <numeric_value>	6.251
TRACe<1 2>:DATA?	LIST	6.253
TRACe<1 2>:IMMEdiate:LEVel?		6.255
TRACe<1 2>:IMMEdiate:RESult?		6.255
TRACe<1 2>:IQ:DATA:FORMat	COMPAtible IQBLock IQPair	6.259
TRACe<1 2>:IQ:DATA:MEMory[:RF]?	<offset samples>, <# of samples>	6.260
TRACe<1 2>:IQ:DATA?		6.257
TRACe<1 2>:IQ:SET	<filter type>, <rbw>, <sample rate>, <trigger source>, <trigger slope>, <pretrigger samples>, <# of samples>	6.261
TRACe<1 2>:IQ:SRATe	10.0 kHz to 81.6 MHz	6.263
TRACe<1 2>:IQ[:STATe]	ON OFF	6.264
TRIGger[:SEQuence]:LEVel:POWER	-70 to +30 dBm	6.266
TRIGger[:SEQuence]:MODE	IMMEdiate EXTernal POWER	6.266
TRIGger<1 2>[:SEQuence]:HOLDoff	-100 to 100s	6.267
TRIGger<1 2>[:SEQuence]:HOLDoff:ADJust:AUTO	ON OFF	6.267
TRIGger<1 2>[:SEQuence]:LEVel[:EXTernal]	0.5 to +3.5 V	6.266
TRIGger<1 2>[:SEQuence]:LEVel:IFPower	-70 to +30DBM	6.266
TRIGger<1 2>[:SEQuence]:SLOPe	POSitive NEGative	6.267
TRIGger<1 2>[:SEQuence]:SOURce	IMMEdiate EXTernal VIDeo IFPower FM AM PM	6.265
UNIT:ANGLE	DEG RAD	6.268
UNIT<1 2>:POWER	DBM DBPW WATT DBUV DBMV VOLT DBUA AMPere V A W DB DBPT PCT UNITLESS DBUV_MHZ DBMV_MHZ DBUA_MHZ DBUV_M DBUA_M DBUV_MMHZ DBUA_MMHZ	6.268

7 Remote Control – Programming Examples

Introduction	7.2
Basic Programming Steps for the VISA Interface	7.2
Service Request	7.3
Initiate Service Request	7.3
Waiting for the Arrival of a Service Request	7.3
Waiting Without Blocking the Keyboard and Mouse	7.5
Service Request Routine	7.5
Evaluation of SCPI Status Registers	7.6
Evaluation of Event Status Register	7.6
More Complex Programming Examples	7.7
Using Marker and Delta Marker	7.7
Measuring Spurious Emissions	7.7
Shape Factor Measurement (Using n dB Down)	7.9
Measuring the Third Order Intercept Point	7.10
Measuring the AM Modulation Depth	7.11
Limit Lines and Limit Test	7.12
Time Domain Power Measurement	7.14
Fast Power Measurement on Power Ramps	7.15
Power Measurement with Multi-Summary Marker	7.15
Multi-Burst Power Measurement	7.17
Fast Level Measurement Using Frequency Lists	7.19
Level Correction of Transducers (Definition of Transducer Factors)	7.21
Measuring the Magnitude and Phase of a Signal (I/Q Data Acquisition)	7.22
Reading and Writing Files	7.25
Reading a File from the Instrument	7.25
Creating a File on the Instrument	7.26

Introduction

The following programming examples have a hierarchical structure, i.e. subsequent examples are based on previous ones. It is thus possible to compile very easily an operational program from the modules of the given examples. VISUAL BASIC has been used as programming language. However, the programs can be translated into other languages.



Note

In programming languages as C, C++ or programmes as MATLAB, NI Interactive Control, a backslash starts an escape sequence (e.g. “\n” is used to start a new line). In these programming languages and programmes, two backslashes instead of one must be used in remote commands (for an example refer to the Quick Start Guide, chapter “Brief Introduction to Remote Control“.)

In this chapter, more complex programming examples are given. In the Quick Start Guide, chapter 6, basic steps in remote control programming are provided.

Basic Programming Steps for the VISA Interface

In this section, all basic programming examples about the topic service request are included:

- [“Initiate Service Request” on page 7.3](#)
- [“Waiting for the Arrival of a Service Request” on page 7.3](#)
- [“Waiting Without Blocking the Keyboard and Mouse” on page 7.5](#)
- [“Service Request Routine” on page 7.5](#)
- [“Evaluation of SCPI Status Registers” on page 7.6](#)
- [“Evaluation of Event Status Register” on page 7.6](#)

Basic examples that explain the programming of the instrument and can serve as a basis to solve more complex programming tasks are provided in the Quick Start Guide, chapter 6.

Service Request

The service request routine requires an extended initialization of the instrument in which the relevant bits of the transition and enable registers are set. In order to use the service request function in conjunction with a National Instruments GPIB driver, the setting "Disable Auto Serial Poll" must be changed to "yes" by means of IBCONF.

Initiate Service Request

```

REM ---- Example of initialization of the SRQ in the case of errors -----
PUBLIC SUB SetupSRQ()
status = viWrite(analyzer, "*CLS", 4, retCnt)
                'Reset status reporting system
status = viWrite(analyzer, "*SRE 168", 8, retCnt)
                'Permit service request for STAT:OPER,STAT:QUES
                'and ESR register
status = viWrite(analyzer, "*ESE 60", 7, retCnt)
                'Set event enable bit for command, execution,
                'device-dependent and query error
status = viWrite(analyzer, "STAT:OPER:ENAB 32767", 20, retCnt)
                'Set OPERation enable bit for all events
status = viWrite(analyzer, "STAT:OPER:PTR 32767", 19, retCnt)
                'Set appropriate OPERation Ptransition bits
status = viWrite(analyzer, "STAT:QUES:ENAB 32767", 20, retCnt)
                'Set questionable enable bits for all events
status = viWrite(analyzer, "STAT:QUES:PTR 32767", 19, retCnt)
                'Set appropriate questionable Ptransition bits

END SUB
REM *****

```

Waiting for the Arrival of a Service Request

There are basically two methods of waiting for the arrival of a service request:

Blocking (user inputs not possible)

This method is appropriate if the waiting time until the event to be signalled by an SRQ is short (shorter than the selected time-out), if no response to user inputs is required during the waiting time, and if – as the main criterion – the event is absolutely certain to occur.

Reason:

From the time the WaitSRQ() function is called until the occurrence of the expected event, it does not allow the program to respond to mouse clicks or key entries during the waiting time. Moreover, it causes program abort if the SRQ event does not occur within the predefined time-out period.

The method is, therefore, in many cases not suitable for waiting for measurement results, especially with triggered measurements.

The following function calls are required:

```
status = viEnableEvent(analyzer, VI_EVENT_SERVICE_REQ, VI_QUEUE, VI_NULL)
status = viWaitOnEvent(analyzer, VI_EVENT_SERVICE_REQ, 10000, etype, eevent)
                                'Wait for service request
IF (result% = 1) THEN CALL Srq   'If SRQ is recognized =>
                                'subroutine for evaluation
```

Non-blocking (user inputs possible)

This method is recommended if the waiting time until the event to be signalled by an SRQ is long (longer than the selected time-out), and user inputs should be possible during the waiting time, or if the event is not certain to occur. This method is, therefore, the preferable choice for waiting for the end of measurements, i.e. the output of results, especially in the case of triggered measurements.

The method necessitates a waiting loop that checks the status of the SRQ line at regular intervals and returns control to the operating system during the time the expected event has not yet occurred. In this way, the system can respond to user inputs (mouse clicks, key entries) during the waiting time.

A query of the VI_ATTR_GPIB_SRQ_STATE attribute can only be sent from the controller, not from the instrument. Therefore, the handle of the controller board is used for this calling of the viGetAttribute attribute.

It is advisable to employ the Hold() auxiliary function, which returns control to the operating system for a selectable waiting time (see section [“Waiting Without Blocking the Keyboard and Mouse” on page 7.5](#)), so enabling user inputs during the waiting time.

```
result% = 0
For i = 1 To 10                                'Abort after max. 10 loop iterations
  Call viGetAttribute(board, VI_ATTR_GPIB_SRQ_STATE, result%)
                                          'Check service request line
  If (result% <> 0) Then
    CALL Srq                                'If SRQ is recognized =>
                                          'subroutine for evaluation
  Else
    CALL Hold(20)                           'Call hold function with
                                          '20 ms waiting time.
                                          'User inputs are possible.
  Endif
Next i
If result% = 0 Then
  PRINT "Timeout Error; Program aborted"    'Output error message
  STOP                                       'Stop software
Endif
```

Waiting Without Blocking the Keyboard and Mouse

A frequent problem with remote control programs using Visual Basic is to insert waiting times without blocking the keyboard and the mouse.

If the program is to respond to user inputs also during a waiting time, control over the program events during this time must be returned to the operating system. In Visual Basic, this is done by calling the *DoEvents* function. This function causes keyboard- or mouse-triggered events to be executed by the associated elements. For example, it allows the operation of buttons and input fields while the user waits for an instrument setting to be completed.

The following programming example describes the *Hold()* function, which returns control to the operating system for the period of the waiting time selectable in milliseconds.

```

Rem *****
Rem The waiting function below expects the transfer of the desired
Rem waiting time in milliseconds. The keyboard and the mouse remain
Rem operative during the waiting period, thus allowing desired elements
Rem to be controlled
REM *****
Public SUB Hold(delayTime As Single)
Start = Timer          'Save timer count on calling the function
DO While Timer < Start + delayTime / 1000  'Check timer count
  DoEvents            'Return control to operating system
                    'to enable control of desired elements as long as
                    'timer has not elapsed

LOOP
END SUB
REM *****
The waiting procedure is activated simply by calling Hold(<Waiting time in milliseconds>).

```

Service Request Routine

A service request is processed in the service request routine.

```

REM ----- Service request routine -----
Public SUB Srq()
ON ERROR GOTO noDevice          'No user existing
Call viReadSTB(analyzer, STB%)  'Serial poll, read status byte
IF STB% > 0 THEN                'This instrument has bits set in the STB
  SRQFOUND% = 1
  IF (STB% AND 16) > 0 THEN CALL Outputqueue
  IF (STB% AND 4) > 0 THEN CALL ErrorQueueHandler
  IF (STB% AND 8) > 0 THEN CALL Questionablestatus
  IF (STB% AND 128) > 0 THEN CALL Operationstatus
  IF (STB% AND 32) > 0 THEN CALL Esrread
END IF
noDevice:
END SUB
REM *****

```

Reading out the status event registers, the output buffer and the error/event queue is effected in subroutines.

Evaluation of SCPI Status Registers

```

REM ----- Subroutine for evaluating Questionable Status Register -----
Public SUB Questionablestatus ()
Ques$ = SPACE$(20)                'Preallocate blanks to text variable
status = viWrite(analyzer, "STATUS:QUEStionable:EVENT?", 26, retCnt)
status = viRead(analyzer, Ques$, 20, retCnt)
PRINT "Questionable Status: "; Ques$
END SUB
REM *****
REM ----- Subroutine for evaluating Operation Status Register -----
Public SUB Operationstatus ()
Oper$ = SPACE$(20)                'Preallocate blanks to text variable
status = viWrite(analyzer, "STATUS:OPERation:EVENT?", 23, retCnt)
status = viRead(analyzer, Oper$, 20, retCnt)
PRINT "Operation Status: "; Oper$
END SUB
REM *****

```

Evaluation of Event Status Register

```

REM ----- Subroutine for evaluating the Event Status Register -----
Public SUB Esrread ()
Esr$ = SPACE$(20)                'Preallocate blanks to text variable
status = viWrite(analyzer, "*ESR?", 5, retCnt)  'Read ESR
status = viRead(analyzer, Esr$, 20, retCnt)
IF (VAL(Esr$) AND 1) > 0 THEN PRINT "Operation complete"
IF (VAL(Esr$) AND 2) > 0 THEN PRINT "Request Control"
IF (VAL(Esr$) AND 4) > 0 THEN PRINT "Query Error"
IF (VAL(Esr$) AND 8) > 0 THEN PRINT "Device dependent error"
IF (VAL(Esr$) AND 16) > 0 THEN
    PRINT "Execution Error; Program aborted"      'Output error message
    STOP                                           'Stop software
END IF
IF (VAL(Esr$) AND 32) > 0 THEN
    PRINT "Command Error; Program aborted"        'Output error message
    STOP                                           'Stop software
END IF
IF (VAL(Esr$) AND 64) > 0 THEN PRINT "User request"
IF (VAL(Esr$) AND 128) > 0 THEN PRINT "Power on"
END SUB
REM *****

```

More Complex Programming Examples

In this section, the more advanced programming examples are included:

- [“Using Marker and Delta Marker” on page 7.7](#)
- [“Limit Lines and Limit Test” on page 7.12](#)
- [“Time Domain Power Measurement” on page 7.14](#)
- [“Fast Power Measurement on Power Ramps” on page 7.15](#)
- [“Fast Level Measurement Using Frequency Lists” on page 7.19](#)
- [“Level Correction of Transducers \(Definition of Transducer Factors\)” on page 7.21](#)
- [“Measuring the Magnitude and Phase of a Signal \(I/Q Data Acquisition\)” on page 7.22](#)
- [“Reading and Writing Files” on page 7.25](#)

For basic programming examples, refer to section [“Basic Programming Steps for the VISA Interface” on page 7.2](#) and the Quick Start Guide, chapter 6.

Using Marker and Delta Marker

Measuring Spurious Emissions

In transmission measurements, it is often necessary to search a large frequency range for unwanted spurious emissions.

This can be done by means of the R&S FSUP's LIST PEAKS function, which finds up to 50 peaks in a preselected frequency range and outputs them as a list. The search range can be defined both in terms of frequency and level, and the number of peaks to be found is selectable as well.

In the following example, the 10 highest peaks are to be found in a preselected frequency range. Only signals >-60 dBm in a range ± 400 kHz about the center frequency are of interest, so the search range is limited accordingly. The signals found are output in the order of ascending frequency.

```

REM *****
Public Sub SpuriousSearch()
powerlist$ = Space$(1000)
freqlist$ = Space$(1000)
countstr$ = Space$(30)
'----- R&S FSUP default setting -----
CALL SetupInstrument                'Default setting
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)  'Single sweep
'----- Definition of search range -----
status = viWrite(analyzer, "CALC:MARK:X:SLIM:STAT ON", 24, retCnt)
status = viWrite(analyzer, "CALC:MARK:X:SLIM:LEFT 99.6MHz;RIGHT 100.4MHz", 44,
retCnt)
                                'Activate search limit and set to
                                '+400 kHz about center frequency
status = viWrite(analyzer, "CALC:THR:STAT ON", 16, retCnt)
status = viWrite(analyzer, "CALC:THR -60DBM", 15, retCnt)
                                'Activate threshold and set to -60 dBm
'----- Activate search for spurious -----
status = viWrite(analyzer, "CALC:MARK:FUNC:FPE:SORT X", 25, retCnt)
                                'Sort according to frequency
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)
                                'Perform sweep with sync
status = viWrite(analyzer, "CALC:MARK:FUNC:FPE 10", 21, retCnt)
                                'Search for 10 highest peaks
status = viWrite(analyzer, "CALC:MARK:FUNC:FPE:COUN?", 24, retCnt)
                                'Call number of peaks, check it,
status = viRead(analyzer, countstr$, 30, retCnt)
                                'and read it in
status = viWrite(analyzer, "CALC:MARK:FUNC:FPE:X?", 21, retCnt)
                                'Query and read
status = viRead(analyzer, freqlist$, 1000, retCnt)
                                'frequency list
status = viWrite(analyzer, "CALC:MARK:FUNC:FPE:Y?", 21, retCnt)
                                'Query and read
status = viRead(analyzer, powerlist$, 1000, retCnt)
                                'level list
Print "# of spurious: ";countstr$    'Output number of results
Print "Frequencies: ";freqlist$      'Output frequency list
Print "Power: ";powerlist$           'Output level list
END SUB
REM *****

```

Shape Factor Measurement (Using n dB Down)

The n-dB-down function of the R&S FSUP is used twice to determine the shape factor of a filter (ratio of bandwidths at 60 dB and 3 dB below the filter maximum).

The following example is again based on a signal with a level of -30 dBm at 100 MHz. The shape factor is determined for the 30 kHz resolution bandwidth. The default setting of the R&S FSUP is used for measurements (SetupInstrument).

```

REM *****
Public Sub ShapeFactor()
result$ = Space$(100)
'----- R&S FSUP default setting -----
CALL SetupInstrument           'Default setting
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)  'Single sweep
'----- Set frequency -----
status = viWrite(analyzer, "FREQ:SPAN 1MHz", 14, retCnt)  'Span
status = viWrite(analyzer, "BAND:RES 30kHz", 14, retCnt) 'Resolution bandwidth
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)       'Perform sweep with sync
'----- Measure 60 dB value -----
status = viWrite(analyzer, "CALC:MARK:PEXC 6DB", 18, retCnt)
                                'Peak excursion
status = viWrite(analyzer, "CALC:MARK:STAT ON", 17, retCnt)
                                'Marker1 on
status = viWrite(analyzer, "CALC:MARK:TRAC 1", 16, retCnt)
                                'Assign marker1 to trace1
status = viWrite(analyzer, "CALC:MARK:MAX", 13, retCnt)
                                'Set marker1 to 100 MHz
status = viWrite(analyzer, "CALC:MARK:FUNC:NDBD 60dB", 24, retCnt)
                                'Read out bandwidth measured
status = viWrite(analyzer, "CALC:MARK:FUNC:NDBD:RES?", 24, retCnt)
                                'at 60 dB

status = viRead(analyzer, result$, 100, retCnt)
result60 = Val(result$)
'----- Measure 3 dB Down value -----
status = viWrite(analyzer, "CALC:MARK:FUNC:NDBD 3dB", 23, retCnt)
                                'Read out bandwidth measured
status = viWrite(analyzer, "CALC:MARK:FUNC:NDBD:RES?", 24, retCnt)
                                'at 60 dB

status = viRead(analyzer, result$, 100, retCnt)
result3 = Val(result$)
'----- Read out shape factor-----
Print "Shapefaktor 60dB/3dB: ";result60/result3
END SUB
REM *****

```

Measuring the Third Order Intercept Point

The third order intercept point (TOI) is the (virtual) level of two adjacent useful signals at which the intermodulation products of third order have the same level as the useful signals.

The intermodulation product at f_{S2} is obtained by mixing the first harmonic of the useful signal P_{N2} with signal P_{N1} , the intermodulation product at f_{S1} by mixing the first harmonic of the useful signal P_{N1} with signal P_{N2} .

$$f_{S1} = 2 \times f_{n1} - f_{n2} \quad (1)$$

$$f_{S2} = 2 \times f_{n2} - f_{n1} \quad (2)$$

The following example is based on two adjacent signals with a level of -30 dBm at 100 MHz and 110 MHz. The intermodulation products lie at 90 MHz and 120 MHz according to the above formula. The frequency is set so that the examined mixture products are displayed in the diagram. Otherwise, the default setting of the R&S FSUP is used for measurements (SetupInstrument).

```

REM *****
Public Sub TOI()
result$ = Space$(100)
'----- R&S FSUP default setting -----
CALL SetupStatusReg           'Set status registers
status = viWrite(analyzer, "*RST", 4, retCnt)      'Reset instrument
status = viWrite(analyzer, "INST:SEL SAN", 12, retCnt)
                                           'Change into analyzer mode
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)  'Single sweep
status = viWrite(analyzer, "SYST:DISP:UPD ON", 16, retCnt) 'ON: display on
                                           'OFF: off
'----- Set frequency -----
status = viWrite(analyzer, "FREQ:START 85MHz;STOP 125 MHz", 29, retCnt) 'Span
'----- Set level -----
status = viWrite(analyzer, "DISP:WIND:TRAC:Y:RLEV -20dBm", 28, retCnt)
                                           'Reference level
status = viWrite(analyzer, "INIT;*WAI", 4, retCnt)      'Perform sweep with sync
'----- TOI measurement -----
status = viWrite(analyzer, "CALC:MARK:PEXC 6DB", 18, retCnt)
                                           'Peak excursion
status = viWrite(analyzer, "CALC:MARK:FUNC:TOI ON", 21, retCnt)
                                           'Switch on TOI measurement
status = viWrite(analyzer, "CALC:MARK:FUNC:TOI:RES?", 23, retCnt)
                                           'and read out results
status = viRead(analyzer, result$, 100, retCnt)
'----- Read out result -----
Print "TOI [dBm]: "; result$
END SUB
REM *****

```


Measuring the AM Modulation Depth

The example below is based on an AM-modulated signal at 100 MHz with the following characteristics:

- Carrier signal level: -30 dBm
- AF frequency: 100 kHz
- Modulation depth: 50%

The default setting of the R&S FSUP can be used for the measurements described below (SetupInstrument).

```

REM *****
Public Sub AMMod()
result$ = Space$(100)
CALL SetupInstrument           'Default setting
'----- Peak search -----
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)      'Single sweep
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)           'Perform sweep with sync
status = viWrite(analyzer, "CALC:MARK:PEXC 6DB", 18, retCnt) 'Peak excursion
status = viWrite(analyzer, "CALC:MARK:STAT ON", 17, retCnt)  'Marker 1 on
status = viWrite(analyzer, "CALC:MARK:TRAC 1", 16, retCnt)
                                           'Assign marker1 to trace1
'----- Measure modulation depth-----
status = viWrite(analyzer, "CALC:MARK:MAX;FUNC:MDEP ON", 26, retCnt)
                                           'Marker to Peak;
status = viWrite(analyzer, "CALC:MARK:FUNC:MDEP:RES?", 24, retCnt)
                                           'Measure mod. depth
status = viRead(analyzer, result$, 100, retCnt)              'Read out result
'----- Read out result -----
Print "AM Mod Depth [%]: "; result$
END SUB
REM *****

```

Limit Lines and Limit Test

The example below shows the definition and use of a new limit line 5 for trace 1 on screen A and trace 2 on screen B with the following characteristics:

- Upper limit line
- Absolute x-axis in the frequency range
- 5 reference values: 120 MHz/-70 dB, 126 MHz/-40 dB, 127 MHz/-40 dB, 128 MHz/-10 dB, 129 MHz/-40 dB, 130 MHz/-40 dB, 136 MHz/-70 dB
- Relative y-axis with unit dB
- Absolute threshold at -75 dBm
- No margin

The signal of the integrated calibration source (128 MHz, -30 dBm) is used to check the limit test.

```

REM *****
Public Sub LimitLine()
result$ = Space$(100)
'----- R&S FSUP default setting -----
CALL SetupInstrument                'Default setting
status = viWrite(analyzer, "FREQUENCY:CENTER 128MHz;Span 10MHz", 34, retCnt)
                                     'Span
status = viWrite(analyzer, "Diag:Serv:Inp Cal;CSO -30dBm", 28, retCnt)
                                     'Cal signal on
'----- Definition of limit lines -----
status = viWrite(analyzer, "CALC:LIM5:NAME 'TEST1'", 22, retCnt)
                                     'Define name
status = viWrite(analyzer, "CALC:LIM5:COMM 'Upper limit'", 28, retCnt)
                                     'Define comment
status = viWrite(analyzer, "CALC1:LIM5:TRAC 1", 17, retCnt)
                                     'Assign trace in screen A
status = viWrite(analyzer, "CALC2:LIM5:TRAC 2", 17, retCnt)
                                     'Assign trace in screen B
status = viWrite(analyzer, "CALC:LIM5:CONT:DOM FREQ", 23, retCnt)
                                     'Define x-axis range
status = viWrite(analyzer, "CALC:LIM5:CONT:MODE ABS", 23, retCnt)
                                     'Define x-axis scaling
status = viWrite(analyzer, "CALC:LIM5:UNIT DB", 17, retCnt)
                                     'Define y-axis unit
status = viWrite(analyzer, "CALC:LIM5:UPP:MODE REL", 22, retCnt)
                                     'Define y-axis scaling

```

```

'----- Definition of data points and threshold -----
xlimit$ = "CALC:LIM5:CONT 120MHZ,126MHZ,127MHZ,128MHZ,129MHZ,130MHZ,136MHZ"
status = viWrite(analyzer, xlimit$, 63, retCnt) 'Set values for x-axis
status = viWrite(analyzer, "CALC:LIM5:UPP -70,-40,-40,-20,-40,-40,-70", 41,
retCnt) 'Set values for y-axis
status = viWrite(analyzer, "CALC:LIM5:UPP:THR -75DBM", 24, retCnt)
'Set y threshold
'(only possible for relative y-axis)
'-----
'A margin or an x /y offset can be defined here.
'----- Activate and evaluate the limit line in screen A -----
status = viWrite(analyzer, "CALC1:LIM5:UPP:STAT ON", 22, retCnt)
'Activate line 5 in screen A
status = viWrite(analyzer, "CALC1:LIM5:STAT ON", 18, retCnt)
'Activate limit check in screen A
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)
'Perform sweep with sync
status = viWrite(analyzer, "CALC1:LIM5:FAIL?", 16, retCnt)
'Query result of limit check
status = viRead(analyzer, result$, 100, retCnt)
'Result: 1 (= FAIL)
'----- Read out result -----
Print "Limit Result Line 5: "; result$
'----- Evaluate limit line in screen A by means of status register -----
status = viWrite(analyzer, "*CLS", 4, retCnt) 'Reset status register
'----- Measure -----
status = viWrite(analyzer, "INIT;*OPC?", 4, retCnt)
'Perform sweep with sync
status = viRead(analyzer, result$, 100, retCnt) 'Wait for service request
status = Val(result$)
'----- Read out result -----
IF (status% = 1) THEN
  status = viWrite(analyzer, "STAT:QUES:LIM1:COND?", 20, retCnt)
'Read out STAT:QUES:LIMit register
  status = viRead(analyzer, result$, 100, retCnt)
'Read out result

  IF ((Val(result$) And 16) <> 0) THEN
    Print "Limit5 failed"
  ELSE
    Print "Limit5 passed"
  END IF
END IF
END SUB
REM *****

```

Time Domain Power Measurement

In the following example, the mean carrier power of a signal with 300 kHz bandwidth at 100 MHz is to be determined. In addition, the peak power, the rms value and the standard deviation are measured. To do this, the time-domain-power measurement functions are used.

```

REM *****
Public Sub TimeDomainPower()
result$ = Space$(100)
'----- R&S FSUP default setting -----
CALL SetupStatusReg                                'Set status register
status = viWrite(analyzer, "*RST", 4, retCnt)      'Reset instrument
status = viWrite(analyzer, "INST:SEL SAN", 12, retCnt)
                                                    'Change into analyzer mode
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)  'Single sweep
status = viWrite(analyzer, "SYST:DISP:UPD ON", 16, retCnt) 'ON: display on
                                                    'OFF: off

'----- Configure R&S FSUP for time domain power measurement -----
status = viWrite(analyzer, "FREQ:CENT 100MHz;SPAN 0Hz", 25, retCnt)
                                                    'Set frequency
status = viWrite(analyzer, "BAND:RES 300kHz", 15, retCnt)
                                                    'Resolution bandwidth
status = viWrite(analyzer, "SWE:TIME 200US", 14, retCnt)
                                                    'Sweep time
status = viWrite(analyzer, "CALC:MARK:FUNC:SUMM:PPE ON", 26, retCnt)
                                                    'Peak measurement on
status = viWrite(analyzer, "CALC:MARK:FUNC:SUMM:MEAN ON", 27, retCnt)
                                                    'Mean measurement on
status = viWrite(analyzer, "CALC:MARK:FUNC:SUMM:RMS ON", 26, retCnt)
                                                    'RMS measurement on
status = viWrite(analyzer, "CALC:MARK:FUNC:SUMM:SDEV ON", 27, retCnt)
                                                    'Standard deviation on

'----- Perform measurement and query results -----
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)
                                                    'Perform sweep with sync
                                                    'Query results:
query$ = " CALC:MARK:FUNC:SUMM:PPE:RES?;"          'Peak measurement
query$ = query$ + ":CALC:MARK:FUNC:SUMM:MEAN:RES?;" 'Mean measurement
query$ = query$ + ":CALC:MARK:FUNC:SUMM:RMS:RES?;"  'RMS measurement
query$ = query$ + ":CALC:MARK:FUNC:SUMM:SDEV:RES?"  'Standard deviation
status = viWrite(analyzer, query$, 120, retCnt)
status = viRead(analyzer, result$, 100, retCnt)
Print result$
END SUB
REM *****

```

Fast Power Measurement on Power Ramps

A frequent task in mobile radio tests is measurement of a DUT at various power control levels at the highest possible speed. The R&S FSUP offers two test functions for this task, which can be used depending on the signal characteristics.

In the following, the two methods are presented by means of two examples.

Power Measurement with Multi-Summary Marker

The multi-summary marker function is suitable for measuring the power of a sequence of pulses with the following characteristics:

- The pulses occur at identical time intervals, which is typical of GSM transmission in slots, for example.
- The level of the first signal is reliably above threshold.
- The subsequent pulses may have any levels.

The function uses the first pulse as a trigger signal. The power of the subsequent pulses is determined exclusively via the timing pattern selected for the pulse sequence. The function is, therefore, suitable for adjustments where the DUT output power varies considerably and is not reliably above the trigger threshold.

The measurement accuracy is determined by the ratio of pulse duration to total measurement time; this should not be below 1:50.

The function always uses TRACE 1 of the selected screen.




Fig. 7-1 Block diagram illustrating signal processing by the R&S FSUP

In the example below, a sequence of 8 pulses is measured with an offset of 50 μs of the first pulse, 450 μs measurement time/pulse and 576.9 μs pulse period.

```

REM *****
Public Sub MultiSumMarker()
result$ = Space$(200)
'----- R&S FSUP default setting-----
CALL SetupStatusReg           'Configure status register
status = viWrite(analyzer, "*RST", 4, retCnt)      'Reset instrument
status = viWrite(analyzer, "INST:SEL SAN", 12, retCnt)
                                           'Change into analyzer mode
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)
                                           'Single sweep mode
status = viWrite(analyzer, "SYST:DISP:UPD ON", 16, retCnt)
                                           'ON:  switch display on
                                           'OFF: switch display off
'----- Configure R&S FSUP for power measurement in time domain -----
status = viWrite(analyzer, "FREQ:CENT 935.2MHz;SPAN 0Hz", 27, retCnt)
                                           'Frequency setting
status = viWrite(analyzer, "DISP:WIND:TRAC:Y:RLEV 10dBm", 27, retCnt)
                                           'Set reference level to 10 dB
status = viWrite(analyzer, "INP:ATT 30 dB", 13, retCnt)
                                           'Set input attenuation to 30 dB
status = viWrite(analyzer, "BAND:RES 1MHz;VID 3MHz", 22, retCnt)
                                           'Bandwidth setting
status = viWrite(analyzer, "DET RMS", 7, retCnt)
                                           'Select RMS detector
status = viWrite(analyzer, "TRIG:SOUR VID", 13, retCnt)
                                           'Trigger source: video
status = viWrite(analyzer, "TRIG:LEV:VID 50 PCT", 19, retCnt)
                                           'Trigger threshold: 50%
status = viWrite(analyzer, "SWE:TIME 50ms", 13, retCnt)
                                           'Sweep time ≥ 1 frame
'----- Perform measurement and query results -----
status = viWrite(analyzer, "INIT;*WAI", 9, retCnt)
                                           'Perform sweep with sync
                                           'Query results:
cmd$ = "CALC:MARK:FUNC:MSUM? "
cmd$ = cmd$ + "50US,"           'Offset of first pulse
cmd$ = cmd$ + "450US,"         'Measurement time
cmd$ = cmd$ + "576.9US,"       'Pulse period
cmd$ = cmd$ + "8"              'Number of bursts
status = viWrite(analyzer, cmd$, 41, retCnt)
status = viRead(analyzer, result$, 100, retCnt)  'Read results
Print result$
END SUB
REM *****

```

Multi-Burst Power Measurement

The multi-burst power measurement function is suitable for measuring the power of a sequence of pulses with the following characteristics:

- The pulses occur at variable time intervals.
- The levels of all pulses of the sequence are reliably above the trigger threshold, or an external trigger signal is used.

The function requires one trigger event per pulse. This means that if the video trigger or the IF power trigger is used, the levels of all pulses must be above the trigger threshold.

The function is, therefore, particularly suitable for re-measuring DUTs already adjusted and whose output power is within the specified range. The measurement is optimized for minimum overhead relative to the actual measurement time.




Fig. 7-2 Block diagram illustrating signal processing by the R&S FSUP

Either the root-mean-square power or the peak power is measured, depending on whether the RMS detector or the PEAK detector is selected. The function always uses TRACE 1 of the selected screen.

The following parameters are to be set for this measurement:

- Analyzer frequency
- Resolution bandwidth
- Measurement time per single pulse
- Trigger source
- Trigger threshold
- Trigger offset
- Type of power measurement (PEAK, MEAN)
- Number of pulses to be measured

During the measurement, each pulse is mapped into a pixel of the screen, i.e. any change of the trace can be detected only at the left-hand edge of the screen. Maximum measurement speed is as usual achieved with the display switched off.

In the example below, a GSM pulse sequence of 8 pulses is measured with 5 μ s trigger offset, 434 μ s measurement time/pulse, video trigger with 50% trigger threshold, and peak detection:

```
REM *****  
Public Sub MultiBurstPower()  
result$ = Space$(200)  
'----- R&S FSUP default setting -----  
CALL SetupStatusReg 'Configure status register  
status = viWrite(analyzer, "*RST", 4, retCnt) 'Reset instrument  
status = viWrite(analyzer, "INST:SEL SAN", 12, retCnt)  
'Change into analyzer mode  
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)  
'Single sweep mode  
status = viWrite(analyzer, "SYST:DISP:UPD OFF", 17, retCnt)  
'OFF: display off  
'----- Perform measurement and query results -----  
cmd$ = "MPOW? "  
cmd$ = cmd$ + "935.2 MHZ," 'Center frequency  
cmd$ = cmd$ + "1MHZ," 'Resolution bandwidth  
cmd$ = cmd$ + "434US," 'Measurement time  
cmd$ = cmd$ + "VID," 'Trigger source  
cmd$ = cmd$ + "50PCT," 'Trigger threshold  
cmd$ = cmd$ + "1US," 'Trigger offset, must be > 125 ns  
cmd$ = cmd$ + "PEAK," 'Peak detector  
cmd$ = cmd$ + "8" 'Number of bursts  
status = viWrite(analyzer, cmd$, 47, retCnt)  
status = viRead(analyzer, result$, 100, retCnt) 'Read results  
Print result$  
END SUB  
REM *****
```


Fast Level Measurement Using Frequency Lists

A typical task for the R&S FSUP is power measurement at a number of frequency points, e.g. at multiples of the fundamental (harmonics measurement), or at frequencies defined by a mobile radio standard (e.g. spectrum due to transients at ± 200 kHz, ± 400 kHz, etc. about the carrier frequency of a GSM signal). In many cases, different level and/or bandwidth settings are required for the different frequency points to match the channel spacing and meet the requirements of dynamic range.

Especially for this application, the R&S FSUP offers a number of remote-control functions (commands available in SENSE:LIST subsystem) that allow level measurement based on a frequency list with different instrument settings assigned to different frequencies. Not only the frequency list can be programmed, but also the measurement types (PEAK, RMS, AVG) to be performed simultaneously can be selected.

The example below describes a harmonics measurement on a dual-band amplifier. The harmonics level in general decreases as the frequency increases. To boost measurement sensitivity, therefore, the reference level is lowered by 10 dB from the third harmonic.

The following settings are used:

- Reference level: 10.00 dBm up to 2nd harmonic, 0 dBm from 3rd harmonic
- RF attenuation: 20 dB
- Electronic attenuation: 0 dB
- RBW: 1 MHz
- VBW: 3 MHz
- Filter type: NORMal
- Measurement time: 300 μ s
- Trigger delay: 100 μ s
- Trigger: video, 45%

Frequency	Type
935.2 MHz	GSM 900 fundamental
1805.2 MHz	GSM 1800 fundamental
1870.4 MHz	GSM 900 2nd harmonic
2805.6 MHz	GSM 900 3rd harmonic
3610.4 MHz	GSM 1800 2nd harmonic
3740.8 MHz	GSM 900 4th harmonic
5815.6 MHz	GSM 1800 3rd Harmonic

The frequencies are selected in ascending order to minimize system-inherent waiting times resulting from frequency changes.

At each frequency point the peak power and the rms power are measured. The peak power and the rms power values are stored alternately in the results memory.

```

REM *****
Public Sub FrequencyList()
result$ = Space$(500)
'----- R&S FSUP default setting -----
CALL SetupStatusReg                                'Configure status register
status = viWrite(analyzer, "*RST", 4, retCnt)      'Reset instrument
status = viWrite(analyzer, "INST:SEL SAN", 12, retCnt)
                                                    'Change into analyzer mode
status = viWrite(analyzer, "INIT:CONT OFF", 13, retCnt)
                                                    'Single sweep mode
status = viWrite(analyzer, "SYST:DISP:UPD OFF", 17, retCnt)
                                                    'Display off
'-----Configure R&S FSUP for power measurement based on frequency list -
status = viWrite(analyzer, "TRIG:LEV:VID 45PCT", 18, retCnt)
                                                    'Video trigger threshold
status = viWrite(analyzer, "LIST:Power:SET ON,ON,OFF,VID,POS,100us,0", 40,
retCnt)
'----- Perform measurement and query results -----
cmd$ = "LIST:Power? "
cmd$ = cmd$ + "935.2MHZ,10dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "1805.2MHZ,10dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "1870.4MHZ,10dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "2805.6MHZ,0dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "3610.4MHZ,10dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "3740.8MHZ,0dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0,"
cmd$ = cmd$ + "5815.6MHZ,0dBm,20dB,OFF,NORM,1MHz,3MHz,300us,0"
status = viWrite(analyzer, cmd$, 343, retCnt)
status = viRead(analyzer, result$, 100, retCnt)
Print result$
END SUB
REM *****

```

Level Correction of Transducers (Definition of Transducer Factors)

In more complex test systems, the frequency response of the test setup must be taken into account in all power measurements to avoid any measurement errors being introduced from sources other than the DUT.

The R&S FSUP offers the possibility of defining a frequency-dependent attenuation correction factor (transducer factor).

In the example below, a factor with the following characteristics is defined:

Name: Transtest
 Unit: dB
 Scaling: lin
 Comment: simulated cable correction

Frequency	Level
10 MHz	0 dB
100 MHz	3 dB
1 GHz	7 dB
3 GHz	10 dB

The factor is defined and can be activated as required.

```

REM *****
Public Sub TransducerFactor()
'----- Define transducer factor -----
status = viWrite(analyzer, "CORR:TRAN:SEL 'TRANSTEST'", 25, retCnt)
                                'Define "Transtest" transducer factor
status = viWrite(analyzer, "CORR:TRAN:UNIT 'DB'", 19, retCnt)
                                'Unit 'dB'
status = viWrite(analyzer, "CORR:TRAN:SCAL LIN", 18, retCnt)
                                'Linear frequency axis
status = viWrite(analyzer, "CORR:TRAN:COMM 'Simulated cable correction'", 43,
retCnt)
cmd$ = "CORR:TRAN:DATA "          'Enter frequency and level
cmd$ = cmd$ + "10MHz, 0,"         'values. Level values without unit!
cmd$ = cmd$ + "100MHz, 3,"
cmd$ = cmd$ + "1GHz, 7,"
cmd$ = cmd$ + "3GHz, 10"
status = viWrite(analyzer, cmd$, 50, retCnt)
                                'Enter frequency and level values
'----- Activate transducer -----
status = viWrite(analyzer, "CORR:TRAN:STAT ON", 17, retCnt)
                                'Activate transducer factor
END SUB
REM *****

```

Measuring the Magnitude and Phase of a Signal (I/Q Data Acquisition)

Due to the R&S FSUP's internal architecture, it is capable of measuring and outputting the magnitude and phase of a signal in addition to its power values. This opens up a variety of possibilities for more in-depth analysis (FFT, demodulation, etc.).

For details on signal processing and the relation between sampling rate and maximum bandwidth refer to chapter 6, section "TRACe:IQ Subsystem" on page 6.256.

The following maximum bandwidths are possible in this measurement depending on the selected sampling rate:

The following example shows the steps necessary to collect data at a predefined sampling rate and read it from the I/Q memory.

Data is output in the form of voltage values referring to the analyzer input.

In binary format, the length information carried in the message header is evaluated and used for calculating the x-axis values.

Binary data is read in three steps:

1. The number of digits carrying the length information is read.
2. The length information itself is read.
3. The trace data is read.

This procedure is necessary with programming languages like Visual Basic which support only structures of identical data types (arrays), whereas the binary data format uses different data types in the header and the data section.



Note

The arrays for measured data are dynamically dimensioned to allow the example to be easily adapted to individual requirements.

```

Rem *****
Public Sub ReadIQData()
'----- Create variables -----
Dim IData() As Single 'I values as single floats
Dim QData() As Single 'Q values as single floats
Dim digits As Byte    'No. of digits as length information
Dim IQBytes As Long   'Length of trace data in bytes
Dim IQSamples As Long 'No. of trace data in Samples
Dim LastSize As Long  'Length of last block in bytes
Const BlockSize = 524288 'Block size in R&S FSUP, as per manual
result$ = Space$(100)    'Buffer for simple results
'----- R&S FSUP default setting -----
Call SetupInstrument     'Default setting
'Activate I/Q data acquisition mode; must be done before TRAC:IQ:SET!
status = viWrite(analyzer, "TRAC:IQ:STAT ON", 15, retCnt)

```

```

' Number of test points (800 000)
' (max. test points allowed (= 16 * 1024 * 1024 - 512))
' at RBW 50 MHz,
' sample rate 80 MHz, trigger free run, pos. trigger edge
' and 0 s trigger delay.
status = viWrite(analyzer, "TRAC:IQ:SET NORM,50MHz,80MHz,IMM,POS,0,800000",
45, retCnt)
'----- Read-out in binary format -----
status = viWrite(analyzer, "FORMAT REAL,32", 14, retCnt) 'Set binary format
status = viWrite(analyzer, "TRAC:IQ:DATA?", 13, retCnt)
'-----
' Meas. + read out I/Q data
' The data must be retrieved from device
' They have the following format:
' Example:
' "#42000"
' |||||_____ Length of data in bytes
' |_____ No. of digits as length
status = viRead(analyzer, result$, 2, retCnt) 'Read and store length for
digits = Val(Mid$(result$, 2, 1)) 'number of digits
result$ = Space$(100) 'Re-initialize buffer
status = viRead(analyzer, result$, digits, retCnt) 'Read length
' Total number of bytes that are read
IQBytes = Val(Left$(result$, digits)) 'and store
' Total number of samples (I and Q) that are read
IQSamples = IQBytes / 8 '4 bytes each for I and Q samples
If IQBytes > 0 Then
' Dynamically create buffer for I/Q data
ReDim IData(0 To IQSamples - 1)
ReDim QData(0 To IQSamples - 1)
' "Blocks" with 512 k I/Q data each are read
Blocks = (IQSamples - 1) \ BlockSize
' 0 or 1 block, each with "LastSize" I/Q data, is read
LastSize = IQSamples - (Blocks * BlockSize)
' Entire blocks with 512 k samples each
For Index = 0 To Blocks - 1
' Read I and Q data in buffer; index for I data counts samples
' Size of data for ibrd32 in bytes
status = viRead32(analyzer, IData(Index * BlockSize), BlockSize * 4,
retCnt)
status = viRead32(analyzer, QData(Index * BlockSize), BlockSize * 4,
retCnt)
Next Index
' The last block (if any) with < 512 k data)
If LastSize > 0 Then
' Read I/Q data; see above
status = viRead32(analyzer, IData(Blocks * BlockSize), LastSize * 4,
retCnt)

```

```
    status = viRead32(analyzer, QData(Blocks * BlockSize), LastSize * 4,
retCnt)
    End If
End If
status = viRead(analyzer, result$, 1, retCnt)      'Read in end character <NL>
status = viWrite(analyzer, "TRAC:IQ:STAT OFF", 16, retCnt)
                                                'I/Q data acquisition mode
status = viWrite(analyzer, "DISP:WIND:Trac:Stat on", 22, retCnt)
                                                'Re-start screen
status = viWrite(analyzer, "INIT:CONT ON", 13, retCnt) 'continuous sweep on
'----- Output of binary data as frequency/level pair -----
Open ".\traceiq.dat" For Output As #1           'Store in current directory
For i = 0 To IQSamples - 1
    Print #1, i; " ; "; Str(IData(i)); " ; "; Str(QData(i))
Next i
Close #1
END SUB
REM *****
```

Reading and Writing Files

Reading a File from the Instrument

In the following example, file TEST1.SET stored under D:\USER\DATA is read from the instrument and stored in the controller.

```

REM *****
Public Sub ReadFile()
'----- Generate variables -----
Dim digits As Byte      'Number of digits of length information
Dim fileBytes As Long   'Length of file with trace data in bytes
result$ = Space$(100)   'Buffer for simple results
'----- Default setting of status register -----
Call SetupStatusReg     'Configure status register
'----- Read out file -----
status = viWrite(analyzer, "MMEM:DATA? 'D:\USER\DATA\TEST1.SET'", 35, retCnt)
                                     'Select file
status = viRead(analyzer, result$, 2, retCnt) 'Read and store number of
digits = Val(Mid$(result$, 2, 1))           'digits of length information
status = viRead(analyzer, result$, digits, retCnt) 'Read and store length
fileBytes = Val(Left$(result$, digits))      'information
FileBuffer$ = Space$(fileBytes)             'Buffer for file
status = viRead(analyzer, FileBuffer, fileBytes, retCnt)
                                     'Read file into buffer
status = viRead(analyzer, result$, 1, retCnt) 'Read terminator <NL>
'----- Store file to controller -----
Open "TEST1.SET" For Output As #1
Print #1, FileBuffer;                    ' ; to avoid linefeed at end of file
Close #1
END SUB
REM *****

```

Creating a File on the Instrument

In the following example, the TEST1.SET file available on the controller is stored in the instrument under D:\USER\DATA\DUPLICAT.SET.

```

REM *****
Public Sub WriteFile()
'----- Generate variables -----
FileBuffer$ = Space$(100000) 'Buffer for file
Dim digits As Long           'Number of digits of length information
Dim fileBytes As Long        'Length of file in bytes
fileSize$ = Space$(100)      'Length of file as a string
result$ = Space$(100)        'Buffer for simple results
'----- Default setting of status register -----
Call SetupStatusReg          'Configure status register
'----- Prepare the definite length block data -----
fileBytes = FileLen("test1.set") 'Determine length of file
fileSize$ = Str$(fileBytes)
digits = Len(fileSize$) - 1     'Determine number of digits of
fileSize$ = Right$(fileSize$, digits) 'length information
FileBuffer$ = "#" + Right$(Str$(digits), 1) + fileSize$
                                'Store length information in
                                'file buffer
'----- Read file from controller -----
Open "TEST1.SET" For Binary As #1
FileBuffer$ = FileBuffer$ + Left$(Input(fileBytes, #1), fileBytes)
Close #1
'----- Write file -----
status = viWrite(analyzer, "SYST:COMM:GPIB:RTER EOI", 23, retCnt)
                                'Set receive terminator on the instrument
status = viWrite(analyzer, "MMEM:DATA 'D:\USER\DATA\DUPLICAT.SET'," +
FileBuffer$, 36 + Len(FileBuffer$), retCnt)
                                'Select file
END SUB
REM *****

```


8 Maintenance and Instrument Interfaces

Introduction	8.2
Maintenance	8.2
Storing and Packing	8.2
List of Power Cables Available	8.2
Instrument Interfaces	8.3
GPIB Interface	8.3
Interface Characteristics	8.3
Bus Lines	8.4
Interface Functions	8.4
GPIB Messages	8.5
Printer Interface (LPT)	8.7
RS-232-C Interface (COM)	8.8
Interface Characteristics	8.8
Signal Lines	8.8
Transmission Parameters	8.9
Control Characters	8.10
Handshake	8.10

Introduction

The following chapter contains information on the maintenance of the R&S FSUP and on the instrument interfaces:

- [“Maintenance” on page 8.2](#)
- [“Instrument Interfaces” on page 8.3](#)

Please follow the instructions in the service manual when exchanging modules or ordering spares. The order no. for spare parts can be found in the service manual.

The address of our support center and a list of all Rohde & Schwarz service centers can be found at the beginning of this manual.

The service manual includes further information particularly on troubleshooting, repair, exchange of modules (including battery exchange, adjustment of the OCXO oscillator) and calibration.

Maintenance

Storing and Packing

For the storage temperature range of the R&S FSUP, see the instrument specifications. When stored for an extended period of time the instrument should be protected against dust.

The original packing should be used, particularly the protective covers at the front and rear, when the instrument is to be transported or dispatched. If the original packing is no longer available, use a sturdy cardboard box of suitable size and carefully wrap the instrument to protect it against mechanical damage.

List of Power Cables Available

Table 8-1 List of power cables available

Stock No.	Earthed-contact connector	Preferably used in
DS 006.7013	BS1363: 1967' complying with IEC 83: 1975 standard B2	Great Britain
DS 006.7020	Type 12 complying with SEV-regulation 1011.1059, standard sheet S 24 507	Switzerland
DS 006.7036	Type 498/13 complying with US-regulation UL 498, or with IEC 83	USA/Canada
DS 006.7107	Type SAA3 10 A, 250 V, complying with AS C112-1964 Ap.	Australia
DS 0025.2365	DIN 49 441, 10 A, 250 V, angular	Europe (except Switzerland)
DS 0099.1456	DIN 49 441, 10 A, 250 V, straight	

Instrument Interfaces

In this section, only a selection of connectors is described:

- “[GPIB Interface](#)” on page 8.3
- “[Printer Interface \(LPT\)](#)” on page 8.7
- “[RS-232-C Interface \(COM\)](#)” on page 8.8

For further information on the front and back panel connectors refer to the Quick Start Guide, chapter 1.

GPIB Interface

The standard instrument is equipped with an GPIB connector. An IEEE 488 interface connector is located on the rear panel of the R&S FSUP. An external controller for remote control of the instrument can be connected via the IEEE 488 interface connector using a shielded cable.

Interface Characteristics

- 8-bit parallel data transfer
- bi-directional data transfer
- three-line handshake
- high data transfer rate
- up to 15 instruments can be connected
- maximal length of the interconnecting cables 15 m (single connection, 2m)
- wired-OR connection if several instruments are connected in parallel.




Fig. 8-1 Pin assignment of GPIB interface

Bus Lines

Data bus with 8 lines DIO 1 to DIO 8.

The transmission is bit-parallel and byte-serial in the ASCII/ISO code. DIO1 is the least significant, DIO8 the most significant bit.

Control bus with 5 lines.

IFC (Interface Clear),
active low resets the interfaces of the devices connected to the default setting.

ATN (Attention),
active low signals the transmission of interface messages
inactive high signals the transmission of device messages.

SRQ (Service Request),
active low enables a device connected to send a service request to the controller.

REN (Remote Enable),
active low permits the switch over to remote control.

EOI (End or Identify),
has two functions in connection with ATN:
active low marks the end of data transmission when ATN=high
active low triggers a parallel poll when ATN=low.

Handshake bus with three lines.

DAV (Data Valid),
active low signals a valid data byte on the data bus.

NRFD (Not Ready For Data),
active low signals that one of the devices connected is not ready for data transfer.

NDAC (Not Data Accepted),
active low as long as the device connected is accepting the data present on the data bus.

Interface Functions

Instruments which can be remote controlled via the GPIB can be equipped with different interface functions. [Table 8-2](#) lists the interface functions appropriate for the instrument.

Table 8-2 Interface functions

Control character	Interface function
SH1	Handshake source function (source handshake), full capability
AH1	Handshake sink function (acceptor handshake), full capability
L4	Listener function, full capability, unaddress if MTA.
T6	Talker function, full capability, ability to respond to serial poll, unaddress if MLA
SR1	Service request function (Service Request), full capability
PP1	Parallel poll function, full capability
RL1	Remote/Local switch over function, full capability
DC1	Reset function (Device Clear), full capability

Table 8-2 Interface functions

Control character	Interface function
DT1	Trigger function (Device Trigger), full capability
C0	No controller function

GPIB Messages

The messages transferred via the data lines of the GPIB can be divided into two groups:

- “Interface Messages” on page 8.5
- “Instrument Messages” on page 8.6

Interface Messages

Interface messages are transferred on the data lines of the GPIB when the "ATN" control line is active (LOW). They are used for communication between controller and instruments and can only be sent by the controller which currently has control of the GPIB.

Universal Commands

The universal commands are encoded 10 - 1F hex. They affect all instruments connected to the bus without addressing.

Table 8-3 Universal Commands

Command	QuickBASIC command	Effect on the instrument
DCL (Device Clear)	IBCMD (controller%, CHR\$(20))	Aborts the processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument settings.
IFC (Interface Clear)	IBSIC (controller%)	Resets the interfaces to the default setting.
LLO (Local Lockout)	IBCMD (controller%, CHR\$(17))	The LOC/IEC ADDR key is disabled.
SPE (Serial Poll Enable)	IBCMD (controller%, CHR\$(24))	Ready for serial poll.
SPD (Serial Poll Disable)	IBCMD (controller%, CHR\$(25))	End of serial poll.
PPU (Parallel Poll Unconfigure)	IBCMD (controller%, CHR\$(21))	End of the parallel-poll state.

Addressed Commands

The addressed commands are encoded 00 - 0F hex. They are only effective for instruments addressed as listeners.

Table 8-4 Addressed Commands

Command	QuickBASIC command	Effect on the instrument
SDC (Selected Device Clear)	IBCLR (device%)	Aborts the processing of the commands just received and sets the command processing software to a defined initial state. Does not change the instrument setting.
GTL (Go to Local)	IBLOC (device%)	Transition to the "Local" state (manual operation).
PPC (Parallel Poll Configure)	IBPPC (device%, data%)	Configure instrument for parallel poll. Additionally, the QuickBASIC command executes PPE/PPD.

Instrument Messages

Instrument messages are transferred on the data lines of the GPIB if the "ATN" control line is not active. ASCII code is used.

Structure and syntax of the instrument messages are described in chapter ["Remote Control – Basics"](#). The commands are listed and explained in detail in chapter ["Remote Control – Description of Commands"](#).

Printer Interface (LPT)

The instrument is equipped with a 25-pin LPT connector on the rear panel for connecting a printer. In Fig. 8-2 the pin assignment is described. The LPT interface is compatible with the CENTRONICS printer interface.




Fig. 8-2 LPT connector pin assignment

Pin	Signal	Input (I) Output (O)	Description
1	STROBE	O	Pulse for transmitting a data byte, min. 1µs pulse width (active LOW)
2	D0	O	Data Line 0
3	D1	O	Data Line 1
4	D2	O	Data Line 2
5	D3	O	Data Line 3
6	D4	O	Data Line 4
7	D5	O	Data Line 5
8	D6	O	Data Line 6
9	D7	O	Data Line 7
10	ACK	I	Indicates that the printer is ready to receive the next byte. (active LOW)
11	BUSY	I	Signal is active when the printer cannot accept data. (active HIGH)
12	PE	I	Signal is active when the paper tray is empty. (active HIGH)
13	SELECT	I	Signal is active when the printer is selected. (active HIGH)
14	AUTOFEED	O	When signal is active, the printer automatically performs a line feed after each line. (active LOW)
15	ERROR	I	This signal is high when the printer has no paper, is not selected or has an error status. (active LOW)
16	INIT	O	Initialize the printer. (active LOW)
17	SELECT IN	O	If signal is active, the codes DC1/DC3 are ignored by the printer. (active LOW).
18 - 25	GND		Ground connection.

Fig. 8-3 Pin assignments for the LPT connector.

RS-232-C Interface (COM)

The standard R&S FSUP is equipped with a RS-232-C serial interface. The interface can be set up and activated manually in the *SETUP-GENERAL SETUP* menu in the *COM INTERFACE* table (selection *OWNER = INSTRUMENT*) for remote control. For details on the connector refer to the Quick Start Guide, chapter 1.

Interface Characteristics

- Serial data transmission in asynchronous mode
- Bi-directional data transfer via two separate lines
- Transmission rate selectable from 110 to 19200 baud
- Logic '0' signal from +3 V to +15 V
- Logic '1' signal from -15 V to -3 V
- External instrument (controller) can be connected




Fig. 8-4 Pin assignment of the RS-232-C interface

Signal Lines

- **DCD** (Data Carrier Detect)

Not used in R&S FSUP.

Input; active LOW.

Using this signal, the local terminal recognizes that the modem of the remote station receives valid signals with sufficient level. DCD is used to disable the receiver in the local terminal and prevent reading of false data if the modem cannot interpret the signals of the remote station.

- **RxD** (Receive Data)

Input, LOW = logic '1', HIGH = logic '0'.

Data line, local terminal receives data from remote station.

- **TxD** (Transmit Data)

Output, LOW = logic '1', HIGH = logic '0'.

Data line, local terminal transmits data to remote station.

- **DTR** (Data Terminal Ready)
Output, active LOW,
Indicates that the local terminal is ready to receive data.
- **GND**
Interface ground, connected to instrument ground
- **DSR** (Data Set Ready)
Input, active LOW,
Indicates that the remote station is ready to receive data.
- **RTS** (Request To Send)
Output, active LOW.
Indicates that the local terminal wants to transmit data.
- **CTS** (Clear To Send)
Input, active LOW.
Used to tell the local terminal that the remote station is ready to receive data.
- **RI** (Ring Indicator)
Not used in R&S FSUP.
Input, active LOW.
Used by a modem to indicate that a remote station wants to establish a connection.


Transmission Parameters

To ensure error-free data transmission, the parameters of the instrument and the controller must have the same settings. The parameters are defined in the SETUP-GENERAL SETUP menu.

Transmission rate (baud rate)	The following transmission rates can be set in the instrument: 110, 300, 600, 1200, 2400, 4800, 9600, 19200.
Data bits	Data transmission is in 7- or 8-bit ASCII code. The first bit transmitted is the LSB (least significant bit).
Start bit	Each data byte starts with a start bit. The falling edge of the start bit indicates the beginning of the data byte.
Parity bit	In order to detect errors, a parity bit may be transmitted. No parity, even parity or odd parity may be selected. In addition, the parity bit can be set to logic '0' or to logic '1'.
Stop bits	The transmission of a data byte is terminated by 1, 1,5 or 2 stop bits.

Example

Transmission of character 'A' (41 hex) in 7-bit ASCII code, with even parity and 2 stop bits:



Control Characters

For interface control, several strings are defined and control characters are reserved which are based upon GPIB control.

Table 8-5 Control strings or control characters of the RS-232 interface

Control string or character	Function
'@REM'	Switch over to remote
'@LOC'	Switch over to local
'@SRQ'	Service Request SRQ (SRQ is sent by the instrument)
'@GET'	Group Execute Trigger (GET)
'@DCL'	Reset instrument (Device Clear DCL)
<Ctrl Q> 11 Hex	Enables character output / XON
<Ctrl S> 13 Hex	Inhibits character output / XOFF
0D Hex, 0A Hex	Terminator <CR>, <LF>

Handshake

Software handshake

In the software handshake mode of operation, the data transfer is controlled using the two control characters XON / XOFF.

The instrument uses the control character XON to indicate that it is ready to receive data. If the receive buffer is full, it sends the XOFF character via the interface to the controller. The controller then interrupts the data output until it receives another XON from the instrument. The controller indicates to the instrument that it is ready to receive data in the same way.

Cable required for software handshake

The connection of the instrument with a controller for software handshake is made by crossing the data lines. The following wiring diagram applies to a controller with a 9-pin or 25-pin configuration.




Fig. 8-5 Wiring of the data lines for software handshake

Hardware handshake

For hardware handshake, the instrument indicates that it is ready to receive data via the lines DTR and RTS. A logic '0' on both lines means 'ready' and a logic '1' means 'not ready'. The RTS line is always active (logic '0') as long as the serial interface is switched on. The DTR line thus controls the readiness of the instrument to receive data.

The readiness of the remote station to receive data is reported to the instrument via the CTS and DSR line. A logic '0' on both lines activates the data output and a logic '1' on both lines stops the data output of the instrument. The data output takes place via the TxD line.

Cable for hardware handshake

The connection of the instrument to a controller is made with a so-called zero modem cable. Here, the data, control and acknowledge lines must be crossed. The following wiring diagram applies to a controller with a 9-pin or 25-pin configuration.




Fig. 8-6 Wiring of the data, control and acknowledge lines for hardware handshake

9 Error Messages

Introduction	9.2
SCPI-Specific Error Messages	9.3
Device-Specific Messages	9.9

Introduction

Error messages are entered in the error/event queue of the status reporting system in the remote control mode and can be queried with the command `SYSTem:ERRor?`. The answer format of R&S FSUP to the command is as follows:

```
<error code>, "<error text with queue query>;  
<remote control command concerned>"
```

The indication of the remote control command with prefixed semicolon is optional.

Example:

The command `"TEST:COMMAND"` generates the following answer to the query `SYSTem:ERRor?`:

```
-113,"Undefined header;TEST:COMMAND"
```

The subsequent list contains the description of error texts displayed on the instrument.

Distinction is made between error messages defined by SCPI, which are marked by negative error codes, and the device-specific error messages for which positive error codes are used:

- ["SCPI-Specific Error Messages" on page 9.3](#)
- ["Device-Specific Messages" on page 9.9](#)

The right-hand column in the following tables contains the error text in bold which is entered in the error/event queue and can be read out by means of query `SYSTem:ERRor?`. A short explanation of the error cause is given below. The left-hand column contains the associated error code.

SCPI-Specific Error Messages

Table 9-1 No Error

Error code	Error text in the case of queue poll Error explanation
0	No error This message is output if the error queue does not contain any entries.

Table 9-2 Command Error - Faulty command; sets bit 5 in the ESR register

Error code	Error text in the case of queue poll Error explanation
-100	Command Error The command is faulty or invalid.
-101	Invalid Character The command contains an invalid sign. Example: A header contains an ampersand, "SENSE&".
-102	Syntax error The command is invalid. Example: The command contains block data the instrument does not accept.
-103	Invalid separator The command contains an invalid sign instead of a separator. Example: A semicolon is missing after the command.
-104	Data type error The command contains an invalid value indication. Example: ON is indicated instead of a numeric value for frequency setting.
-105	GET not allowed A Group Execute Trigger (GET) is within a command line.
-108	Parameter not allowed The command contains too many parameters. Example: Command SENSE:FREQUENCY:CENTer permits only one frequency indication.
-109	Missing parameter The command contains too few parameters. Example: The command SENSE:FREQUENCY:CENTer requires a frequency indication.
-110	Command header error The header of the command is faulty.
-111	Header separator error The header contains an invalid separator. Example: the header is not followed by a "White Space", "*ESE255"
-112	Program mnemonic too long The header contains more than 12 characters.

Table 9-2 Command Error - Faulty command; sets bit 5 in the ESR register (Continued)

Error code	Error text in the case of queue poll Error explanation
-113	Undefined header The header is not defined for the instrument. Example: *XYZ is undefined for every instrument.
-114	Header suffix out of range The header contains an invalid numeric suffix. Example: SENSE3 does not exist in the instrument.
-120	Numeric data error The command contains a faulty numeric parameter.
-121	Invalid character in number A number contains an invalid character. Example: An "A" in a decimal number or a "9" in an octal number.
-123	Exponent too large The absolute value of the exponent is greater than 32000.
-124	Too many digits The number includes too many digits.
-128	Numeric data not allowed The command includes a number which is not allowed at this position. Example: The command INPut:COUPling requires indication of a text parameter.
-130	Suffix error The command contains a faulty suffix.
-131	Invalid suffix The suffix is invalid for this instrument. Example: nHz is not defined.
-134	Suffix too long The suffix contains more than 12 characters.
-138	Suffix not allowed A suffix is not allowed for this command or at this position of the command. Example: The command *RCL does not permit a suffix to be indicated.
-140	Character data error The command contains a faulty text parameter
-141	Invalid character data The text parameter either contains an invalid character or it is invalid for this command. Example: Write error with parameter indication;INPut:COUPling XC.
-144	Character data too long The text parameter contains more than 12 characters.
-148	Character data not allowed The text parameter is not allowed for this command or at this position of the command. Example: The command *RCL requires a number to be indicated.
-150	String data error The command contains a faulty string.

Table 9-2 Command Error - Faulty command; sets bit 5 in the ESR register (Continued)

Error code	Error text in the case of queue poll Error explanation
-151	Invalid string data The command contains a faulty string. Example: An END message has been received prior to the terminating apostrophe.
-158	String data not allowed The command contains a valid string at a position which is not allowed. Example: A text parameter is set in quotation marks, <code>INPut:COUPling "DC"</code>
-160	Block data error The command contains faulty block data.
-161	Invalid block data The command contains faulty block data. Example: An END message was received prior to reception of the expected number of data.
-168	Block data not allowed The command contains valid block data at an invalid position. Example: The command <code>*RCL</code> requires a number to be indicated.
-170	Expression error The command contains an invalid mathematical expression.
-171	Invalid expression The command contains an invalid mathematical expression. Example: The expression contains mismatching parentheses.
-178	Expression data not allowed The command contains a mathematical expression at an invalid position.

Table 9-3 Execution Error - Error on execution of a command; sets bit 4 in the ESR register

Error code	Error text in the case of queue poll Error explanation
-200	Execution error Error on execution of the command.
-201	Invalid while in local The command is not executable while the device is in local due to a hard local control. Example: The device receives a command which would change the rotary knob state, but the device is in local so the command can not be executed.
-202	Settings lost due to rtl A setting associated with hard local control was lost when the device changed to LOCS from REMS or to LWLS from RWLS.
-210	Trigger error Error on triggering the device.
-211	Trigger ignored The trigger (GET, *TRG or trigger signal) was ignored because of device timing considerations. Example: The device was not ready to respond.

Table 9-3 Execution Error - Error on execution of a command; sets bit 4 in the ESR register (Continued)

Error code	Error text in the case of queue poll Error explanation
-212	Arm ignored An arming signal was ignored by the device.
-213	Init ignored Measurement initialization was ignored as another measurement was already in progress.
-214	Trigger deadlock The trigger source for the initiation of measurement is set to GET and subsequent measurement is received. The measurement cannot be started until a GET is received, but the GET would cause an interrupted-error)
-215	Arm deadlock The trigger source for the initiation of measurement is set to GET and subsequent measurement is received. The measurement cannot be started until a GET is received, but the GET would cause an interrupted-error.
-220	Parameter error The command contains a faulty or invalid parameter.
-221	Settings conflict There is a conflict between setting of parameter value and instrument state.
-222	Data out of range The parameter value lies out of the allowed range of the instrument.
-223	Too much data The command contains too many data. Example: The instrument does not have sufficient storage space.
-224	Illegal parameter value The parameter value is invalid. Example: The text parameter is invalid, TRIGger:SWEEp:SOURce TASTe
-230	Data corrupt or stale The data are incomplete or invalid. Example: The instrument has aborted a measurement.
-231	Data questionable The measurement accuracy is suspect.
-240	Hardware error The command cannot be executed due to problems with the instrument hardware.
-241	Hardware missing Hardware is missing. Example: An option is not fitted.
-250	Mass storage error A mass storage error occurred.
-251	Missing mass storage The mass storage is missing. Example: An option is not installed.
-252	Missing media The media is missing. Example: There is no floppy in the floppy disk drive.

Table 9-3 Execution Error - Error on execution of a command; sets bit 4 in the ESR register (Continued)

Error code	Error text in the case of queue poll Error explanation
-253	Corrupt media The media is corrupt. Example: The floppy is bad or has the wrong format.
-254	Media full The media is full. Example: There is no space on the floppy.
-255	Directory full The media directory is full.
-256	File name not found The file name cannot be found on the media.
-257	File name error The file name is wrong. Example: An attempt is made to copy to a duplicate file name.
-258	Media protected The media is protected. Example: The write-protect tab on the floppy is activated.
-260	Expression error The expression contains an error.

Table 9-4 Device Specific Error; sets bit 3 in the ESR register

Error code	Error text in the case of queue poll Error explanation
-300	Device-specific error R&S FSUP-specific error not defined in greater detail.
-310	System error This error message suggests an error within the instrument. Please inform the R&S Service.
-313	Calibration memory lost Loss of the non-volatile data stored using the *CAL? command. This error occurs when the correction data recording has failed.
-330	Selftest failed The selftest could not be executed.
-350	Queue overflow This error code is entered in the queue instead of the actual error code if the queue is full. It indicates that an error has occurred but not been accepted. The queue can accept 5 entries.

Table 9-5 Query Error - Error in data request; sets bit 2 in the ESR register

Error code	Error text in the case of queue poll Error explanation
-400	<p>Query error General error occurring when data are requested by a query.</p>
-410	<p>Query INTERRUPTED The query has been interrupted. Example: After a query, the instrument receives new data before the response has been sent completely.</p>
-420	<p>Query UNTERMINATED The query is incomplete. Example: The instrument is addressed as a talker and receives incomplete data.</p>
-430	<p>Query DEADLOCKED The query cannot be processed. Example: The input and output buffers are full, the instrument cannot continue operation.</p>
-440	<p>Query UNTERMINATED after indefinite response A query is in the same command line after a query which requests an indefinite response.</p>

Device-Specific Messages

Table 9-6 Device-specific messages

Error code	Error text in the case of queue poll Error explanation
1036	MS: The correction table based amplifier gain exceeds the amplifier range for CALAMP1 and CALAMP2 on IF board This message is output when the setting range of the calibration amplifier is not sufficient for the required correction. The error occurs only with modules which are not correctly adjusted or defective.
1052	Frontend LO is Unlocked This message is output when the phase regulation of the local oscillator fails in the RF frontend.
1060	Trigger-Block Gate Delay Error- gate length < Gate Delay This message is output when the gate signal length is not sufficient for the pull-in delay with a predefined gate delay.
2022	OPTIONS.INI invalid This message is output when an error has been recognized in the file OPTIONS.INI which contains the clearing codes for retrofittable firmware applications. If this file is not correctly recognized, all firmware applications are blocked for this instrument.
2028	Hardcopy not possible during measurement sequence This message is output when a printout is started during scan sequences that cannot be interrupted. Such sequences are for example: <ul style="list-style-type: none"> • Recording the system error correction data (calibration) • Instrument selftest In such cases a synchronization to the end of the scan sequence should be performed prior to starting the printout.
2033	Printer Not Available This message is output when the selected printer is not included in the list of available output devices. A possible cause is that the required printer driver is missing or incorrectly installed.
2034	CPU Temperature is too high This message is output when the temperature of the processor exceeds 70 °C.

Table 9-7 Status bar messages (in alphabetical order)

Status bar message	Description
AFC error: below granularity of tuning voltage	If the AFC tolerance is smaller than the minimum change in frequency that can be produced by changing the VTune1 voltage, this message is output. Increasing the AFC frequency tolerance may fix this error.
AFC error: maximum number of iterations reached	If the AFC algorithm fails to find the target frequency within the number of iterations specified, this error message is displayed. Increasing the number of iterations or the AFC frequency tolerance may fix this error.
AFC error: turning curve flat at 0V	If the sensitivity of the DUT is 0 Hz/V near the AFC target frequency, this message may be output as it is not possible to tune the DUT.
AFC error: tuning voltage limit reached	If the AFC target frequency is outside the frequency range of the DUT, this message is output. Selecting a target frequency within the operating range of the DUT may fix this error.
AFC not available	If it is not possible to run a measurement with AFC, for example when the DC power is off, this message is generated.

Status bar message	Description
AFC not available, Vtune is off	If you try to run a measurement with AFC enabled but VTune1 is disabled, this error message will be generated. Ensure VTune1 is enabled with the correct V_{min} and V_{max} settings.
Cannot run measurement - Power is not on.	If a measurement requires control of the DUT and the DC power is not enabled, this message is displayed .
Cannot run measurement - Vtune1 is not enabled.	If a measurement requires control of the DUT and VTune1 is not enabled, this message is displayed .
Cannot tune frequency difference to zero.	This error message is displayed during the pre-measurements (PLL Modes C & D). It indicates that the Reference Frequency is outside of the DUT's frequency range.
Carrier not found.	If the pre-measurement fails to find a carrier and the DC power is switched off, this message is displayed.
Cross Corr. Channels are mismatched.	If a difference greater than 10 dB is detected between beat note levels measured by the Phase Noise Board and the LPN board, this message is displayed. If this occurs when in cross correlation mode (PLL mode INT3), the message is displayed as an error. When in PLL mode INT1, the message is a warning and is removed after 5 seconds.
Cross Correlation disabled, frequency too high.	If a frequency greater than 8 GHz is set or detected during a pre-measurement and cross correlation mode is selected, this message is displayed as a warning that the instrument has been temporarily switched to PLL mode INT1. This message is removed after 5 seconds.
Cross Corr. No beat note found.	This error message is displayed during the pre-measurements in PLL/XCORR mode. (Only if a LPN board is present and switched on). It indicates that a valid beat note was not detected from the LPN Board.
Cross Correlation re-enabled.	If cross correlation was previously disabled because a frequency greater than 8 GHz was set, this message is displayed when the frequency is reduced below 8 GHz and cross correlation mode will be re-enabled. This message is removed after 5 seconds.
External reference frequency reset.	This message is displayed on changing to phase noise mode if the EXT REF frequency has been modified from 10 MHz in the analyzer mode. If the R&S FSUP-B60 option (Cross Correlation PLL measurements) is installed, the EXT REF frequency must be 10 MHz for phase noise measurements. This message is removed after 5 seconds.
Frequency too low (frequency, level values).	This error message is displayed during the pre-measurements. It indicates that a signal frequency below 5 MHz was being attempted to be measured.
Invalid DC settings.	This error message is displayed during the VCO Tuning Characteristics measurements. It indicates that DC Settings specified by the user are not valid for the current measurement.
Is tuning port connected ?	This warning message is displayed during the pre-measurements in Modes B, C & D. It indicates that the tuning slope is less than 100Hz, which could mean that the Tuning port is not connected to the DUT. This message is removed after 5 seconds.
Level too low (frequency, level values).	This error message is displayed during the pre-measurements. It indicates that a signal level less than -20dBm was being attempted to be measured.
No signal found.	No valid signal was found.
No beat note found.	This error message is displayed during the pre-measurements. It indicates that a valid beat note was not detected.

Status bar message	Description
No signals found within tolerance range.	This message is only displayed when the <i>Verify Frequency & Level</i> parameter is set in the General Settings dialog box. It indicates that no input signal could be identified within the supplied tolerances of the specified frequency and level. Check that the <i>Frequency and Level</i> parameters are set correctly. If further measurement executions give this message, try increasing the frequency and/or level tolerance ranges.
Preamplifier switched off.	This warning message is displayed during measurements. It indicates that the Pre-Amplifier (B25) has been switched off as the frequency range is not within the range required for the preamplifier. This message is removed after 3 seconds.
Signal not within the subsweep tolerance.	This message is similar to the above, but is displayed after the initial verification has been successfully performed and indicates that the current subsweep is outside tolerance.

Index

Symbols

* (enhancement label) 4.121

A

Abort

recording of correction data 4.132

Absolute/relative channel power 4.178

ACP measurement 4.164

Addressed command 8.5

Adjacent-channel power

number of channels 4.174

Alphabetical list of remote commands 6.340

AM modulation

depth 4.195

Amplitude 4.92

probability distribution function 4.189

statistics 4.187

Analyzer mode 4.82

Annotation 4.224

APD function 4.189

Attenuation 4.94

AUTO ID

remarks concerning signal identification 4.332

with large spans 4.334

Autopoint detector 4.129

Average detector 4.128, 4.130

Averaging 4.120, 4.162

continuous sweep 4.121

lin/log 4.123

single sweep 4.121

sweep count 4.120

B

Band filter

digital 4.103

Bandwidth

occupied 4.183

resolution 4.99

video 4.99

Baud rate 4.240

Block data 5.16

Boolean parameter 5.15

Brightness 4.225

screen 4.273

C

Calibration

functioning 4.285

reflection measurement 4.284

results 4.133

transmission measurement 4.278

CCDF function 4.189

Center frequency 4.85

step size 4.86

Channel

bandwidth 4.174, 4.184, 4.194

number 4.173, 4.174

power 4.178

spacing 4.175

Channel filters 4.104

Channel power measurement 4.168

Characteristic curve measurement results

DC characteristic 2.9

pulling 2.8

pushing 2.5

Characters

special 6.5

Clear/Write mode 4.119

Colon 5.16

Color 4.226, 4.271

Color printout 4.271

COM interface 4.240, 8.8

Comma 5.16

Command

. 5.16

addressed 8.5

colon 5.16

comma 5.16

common 6.7

description 6.4

errors 9.3

header 5.11

line 5.13

long form 5.12

overlapping execution 5.19

programming examples 7.2

query 5.14

question mark 5.14, 5.16

quotation mark 5.16

recognition 5.18

sequence 5.19

short form 5.12

structure 5.10

suffix 5.13

syntax elements 5.16

universal 8.5

white space 5.16

CONDition part status register 5.20

Configuration 4.227

save 4.257

Continue single sweep 4.108

Continuous sweep 4.107

Control

characters 8.10

Conversion loss 4.324

frequency-dependent 4.324

Copy

file 4.264

limit line 4.212

trace 4.63, 4.126

Correction

inherent noise 4.170

Correction data 4.132

Correction values

normalization 4.275

Counter resolution 4.138

Coupling

bandwidths 4.97

default settings 4.101, 4.102

frequency of diagrams 4.223

reference level of diagrams 4.223

resolution bandwidth 4.100

sweep time 4.100

video bandwidth	4.100	Example of operation	4.338
Create directory	4.263	Execution errors	9.5
Cross Correlation measurement (R&S FSUP-B60 option)	4.345	External Generator (R&S FSP-B10 option)	4.275
Cumulative distribution function	4.189	External mixer	4.318
		External noise source	4.230
		External trigger/gate input	4.111
D		F	
Date	4.224	Fast power measurement	4.170
input	4.243	FFT filter	4.103
DC settings (analyzer mode)	4.83	File	
DC SETTINGS dialog box	4.46	copy	4.264
DCL	5.18	delete	4.265
Default		rename	4.264
coupling ratios	4.101	sort	4.265
display settings	4.224	Filter	
scalings of x- and y-axis	4.192	band filter	4.103
Delay		FFT	4.103
gate signal	4.115	Firmware update	4.255
Delete		Firmware version	4.251
file	4.265	Fixed filter	4.103
limit line	4.212	Free-run sweep	4.110
Detector		Frequency	4.85
autopeak	4.127	center	4.85
average	4.128	counter	4.137
max peak	4.127	coupling of diagrams	4.223
min peak	4.127	display window	4.85, 4.90
quasipeak	4.128	line	4.220
RMS	4.128	offset	4.88
sample	4.127	offset (ext. generator)	4.287
Device reset (overall)	4.5	span	4.90
Device-specific messages		start	4.87
error messages	9.9	stop	4.88
status bar messages	9.9	switching off display	4.224
Diskette		Frequency range	4.319
format	4.267	Frequency-converting measurements	4.287
Display		Front panel keys	
brightness	4.225	enable	4.10
color	4.226	Full screen	4.222
date	4.224	level	4.320
deactivation during single sweep	4.58, 4.109	Full span	4.90
power-save mode	4.224		
saturation	4.226	G	
time	4.224	Gate	
tint	4.225	delay	4.115
title	4.223	external/internal	4.113
Display line	4.218	length	4.115
Display mode		General Settings (Transient) dialog box	4.33
split screen	4.222	General Settings dialog box	
Display range		Autoscale Once	4.24
frequency	4.85	Noise	4.19
level	4.93	Smoothing	4.25
span	4.90	Smoothing Type	4.25
Distribution function	4.189	Trace Offset	4.25
Double dagger	5.16	Transient	4.33
		VCO	4.28
		VCO Tuning	4.28
E		X Axis Start	4.24
ENABle part status register	5.21	X Axis Stop	4.24
Error messages	4.251, 9.2	Y Axis Range	4.24
device-specific	9.9	Y Axis Top	4.24
SPCI-specific	9.3	GET (Group Execute Trigger)	5.18
Error queue query	5.34	GPIB	
Error variable - <i>iberr</i>	4.302	address	4.237
ESE (event status enable register)	5.24	command description	6.4
ESR (event status register)	5.24		
EVENT part status register	5.21		

- interface 8.3
 - interface functions 8.4
 - programming examples 7.2
- H**
- Hardcopy
 - screen 4.269
 - Hardware adjustment 4.254
 - Harmonic. 4.321
 - measurement 4.199
 - Header 5.11
 - Hotkey
 - DC POWER 4.8
 - MORE 4.276
 - PREMEAS 2.13, 4.9
 - QUICKSET 4.8
 - QUICKSET (analyzer mode) 4.83
 - QUICKSET (phase noise mode) 4.12
 - RUN 4.8
 - SCREEN A/B 4.9, 6.108
 - SETTINGS 4.9, 4.17
 - SPECTRUM 4.8, 4.82, 6.137
 - SSA 4.8, 4.11
 - SSA HOME 4.11
- I**
- Impedance of input 4.96
 - Inherent noise
 - correction 4.170
 - Input
 - external trigger/gate 4.111
 - impedance 4.96
 - Instrument functions 4.1
 - Interfaces 8.3
 - GPIOB 8.4
 - Intermodulation product 4.196
 - Interrupt 5.32
 - IST flag 5.24
- K**
- Key
 - AMPT 4.11, 4.92
 - BW 4.11, 4.98
 - CAL 4.132
 - DISP 4.11, 4.221
 - ESC 6.26
 - FILE 4.257
 - FREQ 4.11, 4.85
 - LINES 4.76, 4.209, 4.218
 - MEAS 4.69, 4.157
 - MKR 4.64, 4.134
 - MKR FCTN 4.11, 4.141
 - MKR-> 4.66, 4.150
 - PRESET 4.5, 6.9, 6.248
 - SETUP 4.80, 4.227
 - SPAN 4.11, 4.90
 - SWEEP 4.58, 4.107
 - TRACE 4.59, 4.118
 - TRIG 4.11, 4.110
- L**
- Level 4.92
 - display range 4.93
 - line 4.219
 - offset (ext. generator) 4.277
 - offset (phase noise) 4.145
 - range 4.93
 - reference 4.93
 - Level correction 4.339
 - frequency dependent 4.339
 - with average value 4.340
 - Limit
 - ACP measurement 4.180
 - evaluation range 4.161
 - probability range 4.191
 - Limit check 4.211
 - ACP measurement 4.180
 - Limit line
 - copy 4.212
 - delete 4.212
 - domain 4.215
 - edit 4.213
 - limit check 4.211
 - offset 4.212
 - scaling 4.216
 - select 4.211
 - shift 4.218
 - unit 4.216
 - value 4.217
 - Line
 - frequency (Frequency Line 1, 2) 4.220
 - level (Display Line 1,2) 4.219
 - limit 4.211
 - reference (tracking generator) 4.280
 - threshold 4.153
 - time (Time Line 1, 2) 4.220
 - LO exclude 4.154
 - Logo 4.224
 - Lower case 6.5
 - LPT interface 8.7
- M**
- Maintenance 8.2
 - Manual operation
 - return to 5.6, 5.8
 - switch to 4.10
 - Marker 4.134
 - center frequency to 4.151
 - CF stepsize to 4.153
 - MKR to 4.150
 - N dB Down 4.146
 - normal 4.134
 - peak 4.66, 4.142, 4.151
 - reference level to 4.67, 4.151
 - repeated sweep 4.240
 - search limit 4.152
 - signal track 4.88
 - to trace 4.136, 4.149
 - zoom 4.140
 - Max hold 4.120
 - Max peak detector 4.130
 - Maximum
 - peak value 4.162
 - search 4.66, 4.151
 - value 4.160
 - Mean power (GSM burst) 4.160
 - Mean value 4.160
 - Measurement
 - carrier/noise ratio C/N and C/No 4.193
 - frequency-converting 4.287

reflection	4.284
storing data (ASCII format)	4.206
transmission	4.278
MEASUREMENT CONFIGURATION dialog box	4.17
Measurement example	
ACP with user-specific channel configuration	4.181
adjacent-channel power for a specific standard	4.181
available PLL test setups	2.15
CCDF of a IS95 BTS signal	4.192
characteristic curve measurement results	2.4
occupied bandwidth of a PDC signal	4.186
phase noise measurement (Phase Noise Analyzer)	2.11
signal/noise power density (C/No) of an IS95 CDMA signal	4.183
troubleshooting	2.20
Measurement results	
save	4.257
Measurement Settings dialog box	
Noise	4.37
Transient	4.44
VCO	4.42
Messages	4.251
Min hold	4.122
Min peak detector	4.130
Minimum search	4.153
Mixer	
connecting external mixer	4.318
external	4.318
Mixer products	
at the same frequency	4.336
unwanted with small span	4.334
with low S/N ratio	4.333
Mobile radio standard	4.168
Mode	
analyzer	4.82
phase noise	4.11
spectrum analysis	4.82
Modulation	
depth	4.195
N	
Noise	
correction	4.170
measurement	4.142
source, external	4.230
Normalization	4.280
NTRansition register part	5.21
Numerical values (command)	5.14
O	
Occupied bandwidth	4.183
Offset	
frequency	4.88
frequency (ext. generator)	4.287
gate signal	4.115
limit line	4.212
phase noise	4.145
reference level	4.95
trigger	4.111
Operating time	4.251
Order number	4.250
Overwrite mode	4.119
OVL D	4.286

P

Packing	8.2
Parallel poll	5.33
enable register (PPE)	5.24
Parameter	
block data	5.16
boolean	5.15
numerical values	5.14
string	5.16
text	5.15
Password	
service functions	4.253
Path	4.263
Peak	
search	4.66, 4.142, 4.151
Phase Noise Analyzer	
center frequency	2.13
level	2.13
measurement example	2.11
settings	2.13
Phase noise measurement (spectrum analysis mode)	4.144
Phase noise mode	4.11
PLL test setups	2.15
basic configuration	2.16
double DUT measurement	2.18
external down conversion	2.19
using an external reference oscillator	2.17
Polarity	
external trigger/gate	4.114
trigger edge	4.111
Power	
bandwidth percentage	4.184
cables	8.2
mean	4.160
Power measurement	4.157
CP/ACP	4.164
occupied bandwidth	4.183
signal amplitude statistics	4.187
time domain	4.158
trace	4.180
PPE (parallel poll enable register)	5.24
Preamplifier	4.230
Preset instrument	4.5
Pretrigger	4.111
Print	
start	4.269
Printer	
configuration	4.268
connection	8.7
interface	8.7
PTRansition part status register	5.21
Q	
Quasipeak detector	4.128
Query	5.14, 5.33
errors	9.8
Question mark	5.14, 5.16
Quotation mark	5.16
R	
Recording	
correction data	4.132
Reference	
data set (tracking generator)	4.285
external	4.229

- fixed 4.138
 - frequency 4.139
 - level to marker level 4.67, 4.151
 - line (tracking generator) 4.280
 - position for normalization 4.280
 - Reference level 4.93
 - channel power 4.171
 - coupling of diagrams 4.223
 - offset. 4.95
 - position 4.95
 - to marker level 4.67, 4.151
 - Reference point
 - frequency 4.139
 - frequency (phase noise) 4.145
 - level 4.139
 - level (phase noise) 4.145
 - offset. 4.139, 4.145
 - time. 4.139
 - Reference value 4.329
 - channel power 4.170
 - time domain power 4.161
 - Reflection measurement. 4.284
 - Remote commands
 - alphabetical list. 6.340
 - Remote control
 - basics 5.1
 - GPIO 5.5
 - RS-232-C 5.6
 - RSIB 4.299
 - switch to 5.4
 - Rename
 - directory 4.264
 - file 4.264
 - Reset
 - device 4.5
 - status reporting system 5.34
 - Resolution bandwidth 4.99
 - Resolution counter 4.138
 - RF attenuation 4.94
 - RMS detector 4.128, 4.130
 - RMS value 4.160
 - RS-232-C
 - configuration 4.240
 - interface 8.8
- S**
- Sample detector 4.130
 - Sample number 4.190
 - Saturation 4.226
 - screen. 4.273
 - Save
 - configuration 4.257
 - limit line. 4.218
 - measurement 4.257
 - Scalar reflection measurement 4.284
 - Scaling 4.93
 - level axis. 4.95
 - limit line. 4.216
 - x- and y-axis (signal statistic) 4.190
 - SCPI
 - conformity information 6.4
 - introduction 5.10
 - version 5.3
 - SCPI specific error messages. 9.3
 - command error 9.3
 - device specific error 9.7
 - execution error 9.5
 - no error 9.3
 - query error 9.8
 - Screen
 - brightness 4.273
 - colors 4.274
 - full screen 4.222
 - hue 4.273
 - saturation 4.273
 - split screen 4.222
 - Search
 - bandwidth 4.88
 - minimum 4.153
 - peak 4.66, 4.142, 4.151
 - range. 4.152
 - Selftest 4.254
 - Sensitivity
 - APD measurement 4.191
 - CCDF measurement. 4.191
 - Serial interface 8.8
 - configuration 4.240
 - Serial number 4.250
 - Serial poll 5.33
 - Service functions. 4.252
 - Service request (SRQ) 5.23, 5.32
 - Service request enable register (SRE) 5.23
 - Setup 4.227
 - general 4.236
 - Signal
 - amplitude statistics 4.187
 - count 4.137
 - identification 4.331
 - search bandwidth 4.88
 - tracking 4.88
 - type 4.332
 - Single sweep 4.107
 - deactivating repeated sweep 4.240
 - Softkey
 - % POWER BANDWIDTH 4.184, 6.196
 - = CENTER 4.86, 4.87
 - = MARKER 4.86, 4.87
 - 0.1 * RBW 4.87, 6.169
 - 0.1 * SPAN 4.86, 6.169
 - 0.5 * RBW 4.87, 6.169
 - 0.5 * SPAN 4.86, 6.169
 - 2 FILE LISTS 4.266
 - ABSOLUTE PEAK/MIN 6.16, 6.17
 - ACCEPT BIAS 4.323
 - ACP LIMIT CHECK. 4.180, 6.28
 - ACP REF SETTINGS 4.177, 6.195
 - ADJ CHAN BANDWIDTH 6.194
 - ADJ CHAN SPACING 6.192
 - ADJUST AXIS. 4.204
 - ADJUST REF LVL 4.171, 4.185, 6.196
 - ADJUST SETTINGS. 4.191, 4.195, 4.200, 6.89, 6.195
 - ADJUST SETTINGS (occupied bandwidth) 4.185
 - ADJUST SETTINGS (power measurements) 4.179
 - AFC. 4.16
 - AFC SETTINGS 4.22, 6.219
 - ALL MARKER OFF. 4.65, 4.140, 6.13, 6.42
 - AM 6.57, 6.265
 - AMPERE 4.93, 6.268
 - ANNOTATION ON/OFF 4.224, 6.105
 - APD ON/OFF 4.189, 6.88, 6.91
 - ASCII FILE EXPORT 4.57, 4.63, 4.124, 4.206, 4.266, 6.123, 6.144, 6.145
 - AUTO ID 4.323, 4.331, 4.332

AUTO ID THRESHOLD	4.323, 4.332	DATA ENTRY OPAQUE	4.224
AUTO MAX PEAK	4.152	DATA SET CLEAR	4.260, 6.148
AUTO MIN PEAK	4.152	DATA SET CLEAR ALL	4.267, 6.148
AUTO PEAK SEARCH	4.146, 6.20	DATA SET LIST	4.260
AUTO SELECT	4.129, 6.167	DATE	4.265
AUTOSCALE Y-AXIS	4.14	dBm	4.93, 6.268
AUX DUT	4.83	dBmA	4.93, 6.268
AUX ENABLE	4.84	dBmV	4.93, 6.268
AUX I MAX	4.84	dBpT	6.94
AUX PORT	4.50, 6.217, 6.218, 6.221	dBpW	4.93, 6.268
AVERAGE	4.41, 4.60, 4.120, 6.114, 6.153, 6.183	DC PORT 1/2	4.83
AVERAGE ON/OFF	4.162, 6.73, 6.75, 6.77, 6.79, 6.81	DC PORT1	4.48, 6.217, 6.221, 6.222
AVG MODE LOG/LIN	4.123, 6.85, 6.153	DC PORT2	4.48, 6.217, 6.221, 6.222
BLANK	4.60, 4.121, 6.115	DC SETTINGS	4.46, 6.220
BRIGHTNESS	4.225, 4.273, 6.106, 6.124	DECIM SEP	4.63, 4.126, 4.207, 4.267, 6.123
C/N	4.194	DEFAULT COLORS	4.224, 6.106, 6.124
C/NO	4.194	DEFAULT CONFIG	4.18, 4.260, 6.151
CAL ABORT	4.132, 6.95	DEFAULT COUPLING	4.102
CAL CORR ON/OFF	4.133, 6.96	DEFAULT SETTINGS	4.192, 6.90
CAL GEN 128 MHZ	4.81, 4.253, 6.101, 6.102	DELAY COMP ON/OFF	4.117, 6.267
CAL GEN COMB	4.81, 6.101	DELETE	4.77, 4.79, 4.265, 6.27, 6.141, 6.144, 6.162
CAL GEN COMB PULSE	4.253	DELETE FACTOR	4.232
CAL GEN COMB RECT	4.253	DELETE LIMIT LINE	4.212, 6.27
CAL REFL OPEN	4.284, 6.158	DELETE LINE	4.236, 4.330
CAL REFL SHORT	4.284, 6.158	DELETE RANGE	4.203
CAL RESULTS	4.133, 6.96	DELETE TABLE	4.327
CAL TOTAL	4.132, 6.95	DELETE VALUE	4.217
CAL TRANS	4.278, 6.158	DEMOD BW	4.75
CCDF ON/OFF	4.189, 6.88, 6.91	DETECTOR	4.129
CENTER	4.85, 6.169	DETECTOR AUTOPEAK	4.129
CENTER = MKR FREQ	4.151, 6.61	DETECTOR AVERAGE	4.130
CENTER A = MARKER B	4.223, 6.138	DETECTOR MAX PEAK	4.130
CENTER B = MARKER A	4.223, 6.138	DETECTOR MIN PEAK	4.130
CF STEPSIZE	4.86, 6.169	DETECTOR QPK	4.130
CHAN POWER ACP	6.65	DETECTOR RMS	4.130
CHAN PWR / HZ	4.178, 6.68	DETECTOR SAMPLE	4.130
CHAN PWR ACP	4.167	DEVICE 1/2	4.270, 6.126, 6.127, 6.129, 6.143, 6.243
CHANNEL BANDWIDTH	4.174, 4.184, 4.194, 6.193	DEVICE SETUP	4.270
CHANNEL SPACING	4.175, 6.192	DIAGRAM FULL SIZE	4.171
CLEAR ALL MESSAGES	4.251, 6.246	DISABLE ALL ITEMS	4.260
CLEAR/WRITE	4.60, 4.119, 4.179, 6.114	DISPLAY LINE 1/2	4.219
CNT RESOL	4.138, 6.45	DISPLAY ON/OFF	4.248
COLOR ON/OFF	4.272, 6.126	DISPLAY PWR SAVE	4.224, 6.105, 6.106
COLORS	4.270, 4.271	DISPLAY SETTINGS	4.24, 6.110, 6.170, 6.171
COM INTERFACE	4.240, 6.242	DUT SETTINGS	4.52, 6.169, 6.197, 6.211, 6.215, 6.216
COMMAND TRACKING	4.253	EDIT	4.77, 6.24, 6.26, 6.160
COMMENT	4.270	EDIT ACP LIMITS	4.180, 6.28, 6.29, 6.30, 6.31, 6.32, 6.33
COMMENT SCREEN A/B	6.128	EDIT COMMENT	4.259, 6.151
CONFIG DISPLAY	4.223	EDIT LIMIT LINE	4.214, 6.25, 6.35, 6.36, 6.37, 6.39, 6.40, 6.41
CONFIGURE NETWORK	4.81, 4.244	EDIT PATH	4.259, 4.263, 6.140, 6.143
CONT DEMOD	6.58	EDIT SWEEP LIST	4.202, 6.183
CONT MEAS	4.192, 6.130, 6.131	EDIT TABLE	4.325, 4.327
CONTINUE SGL SWEEP	4.108, 6.130, 6.131	EDIT TRD FACTOR	4.232, 4.233
CONTINUOUS SWEEP	4.58, 4.107, 6.130, 6.131	EL ATTEN AUTO	4.96
CONV LOSS TABLE	4.322, 4.324	EL ATTEN MANUAL	4.96
COPY	4.264, 6.140	EL ATTEN OFF	4.96
COPY LIMIT LINE	4.212, 6.27	ENABLE ALL ITEMS	4.260, 6.150
COPY T1->T3	6.254	ENTER PASSWORD	4.253, 6.248
COPY TABLE	4.327	EXCLUDE LO	4.154, 6.46
COPY TRACE	4.14, 4.63, 4.126, 6.254	EXT MIXER ON/OFF	4.320
COUPLING DEFAULT	6.155, 6.204	EXT SOURCE	4.288
COUPLING RATIO	4.101, 6.155	EXT SRC ON/OFF	4.289, 6.223
CP/ACP ABS/REL	4.178, 6.194	EXTENSION	4.265
CP/ACP CONFIG	4.173, 6.28, 6.192	EXTERN	4.111, 6.207, 6.265
CP/ACP ON/OFF	4.168, 6.65, 6.66, 6.69	EXTERNAL MIXER	4.320
CP/ACP STANDARD	4.168, 6.69		
CUT	4.264		

FAST ACP ON/OFF	4.170, 6.197	LO LEVEL	4.323
FFT FILTER MODE	4.105	LOAD TABLE	4.325
FILE MANAGER	4.262, 6.140	LOCAL	4.10, 5.8
FILTER TYPE	4.103, 6.156	LOGO ON/OFF	4.224, 6.105
FIRMWARE UPDATE	4.81, 4.255, 6.246	LOOP BW	4.15, 6.211
FM	6.57, 6.265	LOOP BW AUTO	4.15, 6.211, 6.212
FORMAT DISK	4.267, 6.142	LOOP SETTINGS	4.54, 6.211, 6.212
FREE RUN	4.110, 6.265	LXI	4.248
FREQ AXIS LIN/LOG	4.91, 6.109	MAIN PLL BANDWIDTH	4.105
FREQUENCY LINE 1/2	4.220	MAKE DIRECTORY	6.143
FREQUENCY OFFSET	4.88, 4.287, 6.171	MANUAL	4.86, 4.87
FREQUENCY SWEEP	4.294, 6.224, 6.225	MARGIN	4.205
FULL SCREEN	4.222, 6.105	MARKER 1	4.64, 4.135, 6.13, 6.15, 6.42, 6.43, 6.46
FULL SPAN	4.90, 6.170	MARKER 2	4.64, 4.135, 6.13, 6.15, 6.42, 6.43, 6.46
GATE DELAY	4.115, 6.206	MARKER 3	4.64, 4.135, 6.13, 6.15, 6.42, 6.43, 6.46
GATE LENGTH	4.115, 6.207	MARKER 4	4.64, 4.135, 6.13, 6.15, 6.42, 6.43, 6.46
GATE MODE LEVEL/EDGE	4.114, 6.206	MARKER DEMOD	6.57
GATE SETTINGS	4.114, 6.205	MARKER NORM/DELTA	4.64, 4.135, 6.12, 6.13, 6.14, 6.18
GATED TRIGGER	4.113, 6.205, 6.207	MARKER ZOOM	4.65, 4.140, 6.56
GEN REF INT/EXT	4.296	MAX HOLD	4.60, 4.120, 4.179, 6.114
GENERAL SETTINGS	4.19, 6.100, 6.112, 6.113, 6.114, 6.133, 6.135, 6.170, 6.171, 6.199, 6.210, 6.211, 6.215, 6.219, 6.220	MAX HOLD ON/OFF	4.162, 6.74, 6.76, 6.78, 6.80
GENERAL SETUP	4.81, 4.236	MEAN	4.160, 6.76, 6.77
GPIB	4.237	MEAS SETTINGS	4.37, 6.154, 6.168, 6.180, 6.182, 6.204, 6.207, 6.210, 6.211, 6.215, 6.216, 6.266, 6.267
GPIB ADDRESS	4.81, 4.237, 6.240	MEAS TIME	4.13, 4.75
GPIB LANGUAGE	4.238	MIN	4.67, 4.153, 6.16, 6.50
GRID ABS/REL	4.95, 6.110	MIN HOLD	4.63, 4.122, 6.114
GRID MIN LEVEL	6.112	MIXER	4.95
HARDCOPY ABORT	6.124	MIXER LVL AUTO	4.95
HARDWARE INFO	4.250, 6.103	MIXER LVL MANUAL	4.95
HARMONIC DISTOR	4.199	MKR DEMOD ON/OFF	6.57
HARMONIC ON/OFF	4.199	MKR STOP TIME	6.58
HARMONIC PWR	4.73, 6.99, 6.120, 6.121	MKR->CF STEPSIZE	4.153, 6.61
HARMONIC RBW AUTO	4.200	MKR->TRACE	4.65, 4.67, 4.136, 4.149, 4.153, 6.13, 6.42
HARMONIC SWEEP TIME	4.200	MODULATION DEPTH	4.195, 6.59
HIGHLIGHT SPURS	4.14, 4.56, 6.202	MULT CARR ACP	4.167
HOLD CONT ON/OFF	4.122	N DB DOWN	4.146, 6.54, 6.55, 6.56
ID STRING FACTORY	4.237, 6.249	NAME	4.77, 4.215, 4.265, 6.25, 6.27, 6.35, 6.38, 6.39
ID STRING USER	4.237	NETWORK	4.276, 4.277
IF GAIN NORM PULS	6.247	NETWORK LOGIN	4.81, 4.245
IF GAIN NORM/PULS	4.240	NEW	4.76, 6.24, 6.26
IF POWER	4.111, 6.207, 6.265, 6.266	NEW FACTOR	4.232, 4.233
IF SHIFT	4.81, 4.256, 6.208	NEW FOLDER	4.263
IF SHIFT A	4.256, 6.208	NEW LIMIT LINE	4.214, 6.25, 6.26, 6.27, 6.35, 6.37
IF SHIFT B	4.256, 6.208	NEW SEARCH	4.148
IF SHIFT OFF	4.256	NEW TABLE	4.325, 4.327
INPUT CAL	4.81, 4.252, 6.101, 6.103	NEXT MIN	4.67, 4.154, 6.17, 6.50, 6.51
INPUT RF	4.81, 4.252, 6.101	NEXT MIN LEFT	4.68, 4.154, 6.17, 6.51
INS AFTER RANGE	4.203	NEXT MIN RIGHT	4.68, 4.154, 6.17, 6.51
INS BEFORE RANGE	4.203	NEXT PEAK	4.67, 4.152, 6.14, 6.16, 6.17, 6.44, 6.48, 6.49
INSERT	4.78	NEXT PEAK LEFT	4.67, 4.152, 6.14, 6.16, 6.44, 6.49
INSERT LINE	4.236, 4.330	NEXT PEAK RIGHT	4.67, 4.152, 6.14, 6.16, 6.44, 6.49
INSERT VALUE	4.217	NEXT RANGES	4.203
INSTALL OPTION	4.246	NO OF SAMPLES	4.190, 6.89
INSTALL PRINTER	4.271	NO. OF ADJ CHAN	4.173, 6.193
ITEMS TO SAVE/RCL	4.259	NO. OF HARMONICS	4.199
ITEMS TO SAVE/RECALL	6.149	NO. OF TX CHAN	4.174, 6.193
LAST SPAN	4.91	NOISE CORR ON/OFF	4.170, 6.197
LCI	4.248	NOISE MEAS	4.70, 4.142, 6.57, 6.117, 6.118, 6.251
LEFT LIMIT	4.148, 4.152, 6.43, 6.44	NOISE SRC ON/OFF	4.81, 4.230, 6.103
LIMIT ON/OFF	4.161, 6.43	NORMALIZE	4.280, 6.158
LINK MKR1 AND DELTA1	4.65, 4.136, 6.18	NUMBER OF SWEEPS	4.162, 6.204
LIST EVALUATION	4.205	OCCUP BW ON/OFF	4.184, 6.65, 6.66, 6.69
LIST SPURS	4.56	OCCUPIED BANDWIDTH	4.184, 6.65
LNA GAIN	4.15, 6.136	OPTIMIZED COLOR SET	4.272
LNA GAIN AUTO	4.15, 6.136	OPTIONS	4.246

PAGE DOWN	4.81, 4.133, 4.233, 4.254, 4.330
PAGE UP	4.81, 4.133, 4.232, 4.254, 4.330
PASTE	4.264
PEAK	4.66, 4.142, 4.151, 4.160, 6.14, 6.15, 6.44, 6.47, 6.72, 6.73
PEAK EXCURSION	4.68, 4.148, 4.154, 6.51
PEAK LIST	4.147, 6.52
PEAK LIST OFF	4.149, 6.52
PEAK SEARCH	4.139, 4.146, 4.205, 6.19
PEAKS PER PEAKS	4.205
PERCENT MARKER	4.190, 6.47
PH NOISE ANALYZER	4.70, 6.97
PH NOISE ON/OFF	4.145, 6.20
PH NOISE PLL	4.70, 6.97
PHASE DETECTOR	4.53, 6.212, 6.213, 6.214
PHASE NOISE	4.144, 6.20
POLARITY POS/NEG	4.111, 4.114, 6.206, 6.267
PORT LIMITS	4.84
POWER ABS/REL	4.162, 6.81
POWER METER	4.256
POWER MODE	4.179, 6.70
POWER OFFSET	4.277
POWER ON/OFF	4.159, 6.72, 6.74, 6.76, 6.78, 6.82
PREAMP	4.230
PREDEFINED COLORS	4.226, 4.274, 6.107, 6.125
PREMEAS	6.215
PRESET ANALYZER	4.81, 4.255
PRESET SETTINGS	4.50, 4.54, 4.57
PRESET SSA	4.81, 4.255
PREVIOUS RANGES	4.204
PRINT SCREEN	4.269, 6.127, 6.143
PRINT TABLE	4.269, 6.127, 6.128, 6.143
PRINT TRACE	4.269, 6.127, 6.128, 6.143
PUSH DUT	4.13
PUSH/PULL REL/ABS	4.74, 6.99, 6.100
RANGE	4.75
RANGE LIN % dB	6.112
RANGE LINEAR	4.93, 6.112
RANGE LINEAR %	4.93
RANGE LINEAR dB	4.93
RANGE LOG 100 dB	4.93, 6.112
RANGE LOG MANUAL	4.93, 6.112
RBW%	4.41, 6.173
RBW/VBW MANUAL	4.102, 6.156
RBW/VBW NOISE	4.102, 6.156
RBW/VBW PULSE	4.101, 6.156
RBW/VBW SINE	4.101, 6.156
RECALL	4.258, 4.283, 6.142, 6.159
REF FXD ON/OFF	4.138, 6.18
REF LEVEL	4.93, 6.110
REF LEVEL = MKR LVL	4.67, 4.151, 6.61
REF LEVEL COUPLED	4.223, 6.138
REF LEVEL OFFSET	4.95, 6.111
REF LEVEL POSITION	4.95, 6.111
REF MEAS	4.71, 6.98
REF POINT FREQUENCY	4.139, 4.145, 6.19
REF POINT LEVEL	4.139, 4.145, 6.18, 6.19
REF POINT LVL OFFSET	4.139, 4.145, 6.19
REF POINT TIME	4.139, 6.19
REF VALUE	4.281, 6.111
REF VALUE POSITION	4.280, 6.111
REFERENCE FIXED	4.138, 6.18
REFERENCE INT/EXT	4.80, 4.229, 6.200
REFLVL ADJ AUTO MAN	4.232
REMOVE OPTION	4.246
RENAME	4.264, 6.143
RES BW	4.190, 6.154
RES BW AUTO	4.100, 6.155
RES BW MANUAL	4.99, 6.154, 6.155
RESIDUAL CALC	4.25, 6.22
RESTORE FIRMWARE	4.255
RF ATTEN AUTO	4.94, 6.133
RF ATTEN MANUAL	4.94, 4.96
RF INPUT 50 Ohm/75 Ohm	4.96, 6.136
RF INPUT AC/DC	4.94
RF POWER	6.265
RIGHT LIMIT	4.148, 4.152, 6.43, 6.44
RMS	4.160, 6.74, 6.75
SATURATION	4.226, 4.273, 6.106, 6.124
SAVE	4.79, 4.258, 6.145
SAVE AS TRD FACTOR	4.283
SAVE LIMIT LINE	4.218
SAVE SETTINGS	4.50
SAVE TABLE	4.330
SAVE TRD FACTOR	4.236
SCALING	4.190, 6.89
SCOPE	4.13, 6.116
SCREEN COLORS	4.272
SCREEN TITLE	4.223, 6.108, 6.109
SEARCH LIMIT OFF	4.153, 6.43
SEARCH LIMITS	4.152, 6.43
SEARCH NEXT LEFT	6.16, 6.17, 6.49, 6.51
SEARCH NEXT RIGHT	6.16, 6.17, 6.48, 6.50
SELECT BAND	4.320
SELECT CONFIG	4.17, 6.98
SELECT GENERATOR	4.290, 6.240, 6.241, 6.242
SELECT ITEMS	4.260, 6.149
SELECT LIMIT LINE	4.211, 6.24, 6.25, 6.26, 6.37
SELECT MARKER	4.66, 4.142, 4.150, 4.199, 6.42, 6.43, 6.46
SELECT OBJECT	4.225, 4.273
SELECT SPURS	4.56, 6.202
SELECT TRACE	4.60, 4.89, 4.119, 4.180, 6.72, 6.198
SELFTEST	4.81, 4.254, 6.10
SELFTEST RESULTS	4.81, 4.254, 6.103
SERVICE	4.81, 4.252, 6.101
SERVICE SETTINGS	4.84, 6.97, 6.117
SET CP REFERENCE	4.170, 6.194
SET REFERENCE	4.161, 6.81
SET TO DEFAULT	4.274
SETTLE TIME	4.13
SGL SWEEP DISP OFF	4.58, 4.109, 6.131
SHIFT X LIMIT LINE	4.218, 6.36
SHIFT Y LIMIT LINE	4.218, 6.40
SHOW ALL	4.55, 6.118, 6.203
SHOW CONFIG	4.18
SHOW SELECTED	4.55, 6.203
SIGNAL COUNT	4.137, 6.45
SIGNAL ID	4.323, 4.331
SIGNAL SETTINGS	4.21, 6.97, 6.98, 6.169, 6.171, 6.172, 6.197, 6.198, 6.207
SIGNAL STATISTIC	4.189
SIGNAL TRACK	4.88, 6.71
SINGLE MEAS	4.192, 6.130, 6.131
SINGLE SWEEP	4.58, 4.107, 6.130, 6.131
SIZE	4.266
SMOOTHING	4.61, 6.116
SOFT FRONT PANEL	4.247
SORT BY DELTA LIM	4.206
SORT BY FREQUENCY	4.206
SORT MODE	4.265
SORT MODE FREQ/LEVEL	4.148
SOURCE CAL	4.278
SOURCE POWER	4.277, 6.225

SPAN MANUAL	4.90, 6.170
SPAN START	4.39, 6.170
SPAN STOP	4.39, 6.171
SPAN/RBW AUTO	4.102, 6.155
SPAN/RBW MANUAL	4.102, 6.155
SPLIT SCREEN	4.222, 6.105
SPOT LIST	4.14, 6.87
SPOT NOISE	4.27, 6.87
SPOT NOISE VS TUNING	4.70
SPUR LIST	4.14
SPUR THRESHOLD	4.56, 6.203
SPURIOUS EMISSIONS	4.201
SPURIOUS ON/OFF	4.202
SPURS SETTINGS	4.55
SQUELCH	6.58
STANDARD DEVIATION	4.161, 6.78, 6.79
START	4.87
START LIMIT	4.161, 6.43, 6.44
START MEAS	4.204
STARTUP RECALL	4.260, 6.142
STATISTICS	4.251, 6.8
STOP	4.88
STOP LIMIT	4.161, 6.44
STOP MEAS	4.204, 6.11
SUBSPAN RBW	4.40, 6.179
SUPPLY DUT	4.83
SUPPLY DUT1	4.13
SUPPLY ENABLE	4.83
SUPPLY I MAX	4.84
SUPPLY U MAX	4.84
SUPPLY U MIN	4.84
SUPPRESS ALL	4.55, 6.203
SUPPRESS SELECTED	4.55, 6.203
SUPPRESS SPURS	4.14
SWEEP COUNT	4.58, 4.61, 4.108, 4.122, 6.182, 6.183, 6.204
SWEEP LIST	4.202, 6.179, 6.180, 6.181, 6.182, 6.183
SWEEP MODE	4.38, 6.208
SWEEP POINTS	4.109, 6.208
SWEEP REP ON/OFF	4.240
SWEEP TIME	4.170
SWEPTIME	4.115
SWEPTIME AUTO	4.100, 4.108, 6.204
SWEPTIME MANUAL	4.90, 4.99, 4.108, 6.204
SWITCHING SEQUENCE	4.50, 4.84, 6.218, 6.221
SYSTEM INFO	4.250
SYSTEM MESSAGES	4.251, 6.246
T1-T2->T1	4.131, 6.84
T1-T3->T1	4.62, 4.131, 6.84
T2-T3->T2	4.63, 6.84
TEST SETUP	4.17
THRESHOLD	4.148, 4.153, 6.92
TIME DOM POWER	4.159, 6.72, 6.74, 6.76, 6.78
TIME LINE 1/2	4.220
TIME+DATE	4.243, 6.244, 6.249
TIME+DATE ON/OFF	4.224, 6.109
TINT	4.225, 4.273, 6.106, 6.124
TOI	4.198, 6.60
TRACE MATH	4.62, 4.131, 6.84
TRACE MATH OFF	4.63, 4.131, 6.84, 6.85
TRACE POSITION	4.131, 6.84
TRACE SETTINGS	4.25, 6.111, 6.116
TRACK BW	4.88, 6.71
TRACK FREQ ON/OFF	4.14
TRACK LEVEL ON/OFF	4.14
TRACK ON/OFF	4.88, 6.71
TRACK THRESHOLD	4.88, 6.71
TRACKING	4.15
TRANSDUCER	4.231, 6.160
TRANSDUCER FACTOR	4.232, 6.160, 6.161
TRANSIENT AMPT	4.75, 6.62, 6.98
TRANSIENT FREQ	4.75, 6.62, 6.63, 6.98
TRANSIENT MEAS	4.75, 6.63, 6.251
TRANSIENT PHASE	4.75, 6.63, 6.98
TRANSIENT PWR	4.75, 6.98
TRD FACTOR NAME	4.234
TRD FACTOR UNIT	4.235
TRD FACTOR VALUES	4.235
TRIGGER OFFSET	4.111, 6.267
TUNE DUT	4.83
TUNE DUT1	4.13
TUNE ENABLE	4.83
TUNE I MAX	4.84
TUNE U MAX	4.84
TUNE U MIN	4.84
TUNING PORT1	4.49, 6.217, 6.218, 6.219, 6.221
TUNING PORT2	4.49, 6.217, 6.218, 6.219, 6.221
TUNING SETTINGS	4.40, 6.210, 6.215, 6.216
UNIT	4.93, 6.268
UPDATE PATH	4.255
USE FFT ON OFF	4.41, 6.174
USE HARMONIC	4.16
USER DEFINED	4.272
VALUE	4.78, 6.25, 6.34, 6.35, 6.36, 6.38, 6.39, 6.40
VALUES	4.217, 6.34, 6.36, 6.39
VBW LIN LOG	6.157
VBW MODE LIN/LOG	4.106
VCO DC CHAR	4.73, 6.99, 6.121, 6.122
VCO LOOP SETTINGS	4.51
VCO MEAS	4.72, 6.251
VCO PULLING ON/OFF	4.73, 6.99
VCO PUSHING ON/OFF	4.72
VCO RF PWR CHAR	4.72, 6.99, 6.118, 6.119, 6.120
VCO SUMMARY	4.74, 6.99, 6.218
VCO TUNING CHAR	4.72, 6.99, 6.118, 6.119, 6.120
VCO TUNING SENSITIVITY	4.72, 6.99, 6.119, 6.120
VIDEO	4.110, 6.265
VIDEO BW AUTO	4.100, 6.156
VIDEO BW MANUAL	4.99, 6.156
VIEW	4.60, 4.121, 6.114
VIEW PEAK LIST	4.206
VOLT	4.93, 6.268
WATT	4.93, 6.268
X * RBW	4.87, 6.169
X * SPAN	4.86, 6.169
X OFFSET	4.212, 6.35
X-AXIS RANGE	4.191, 6.90
X-AXIS REF LEVEL	4.190, 6.89
X-AXIS VOLT/FREQ	4.74, 6.109
XCORR	4.41
XCORR OPT ON/OFF	4.41
Y OFFSET	4.213, 6.37, 6.39
Y-AXIS MAX VALUE	4.191, 6.90
Y-AXIS MIN VALUE	4.191, 6.90
Y-UNIT %/ABS	4.191
ZERO SPAN	4.90, 6.170
Span	4.90
Special characters	6.5
Spectrum analysis mode	4.82
Split screen	4.222
Squelch function	4.149
SRE (service request enable register)	5.23
SRQ (service request)	5.23, 5.32
Standard	

mobile radio	4.168
Standard deviation	4.161
Start frequency	4.87
Statistics	4.187
Status bar messages	
device-specific	9.9
Status byte (STB)	5.23
STATus OPERation register	5.25
STATus QUEStionable register	5.25
ACPLimit register	5.26
FREQUency register	5.27
LIMit register	5.28
LMARgin register	5.29
POWer register	5.30
Status register	
CONDition part	5.20
ENABLE part	5.21
ESE	5.24
ESR	5.24
EVENT part	5.21
NTRansition part	5.21
overview	5.22
PPE	5.24
PTRansition part	5.21
SRE	5.23
STATus OPERation	5.25
STATus QUEStionable ACPLimit	5.26
STATus QUEStionable FREQUency	5.27
STATus QUEStionable LIMit	5.28
STATus QUEStionable LMARgin	5.29
STATus QUEStionable POWer	5.30
STB	5.23
structure	5.20
sum bit	5.21
Status reporting system	5.20
resetting values	5.34
STB (status byte)	5.23
Stepsize	4.87
center frequency	4.86
coupling	4.87
Stop frequency	4.88
Storing	8.2
trace	4.206
String	5.16
Suffix	5.13
Sum bit	5.21
Supply voltage	
external noise source	4.230
Sweep	
continue single sweep	4.108
continuous	4.107
count	4.108
coupling	4.97
free run	4.110
gated	4.112, 4.113
range	4.202
settings	4.58, 4.107
single	4.107
time	4.90, 4.108
time coupling	4.100
Switching cycles	4.251
Syntax elements	5.16
of commands	5.16
System messages	4.251

T

Test	
selftest	4.254
Text parameter	5.15
Third order intercept	4.196
Threshold	
line	4.153
signal tracking	4.88
Time	4.224
axis	4.90
input	4.243
line	4.220
Tint	4.225
Title for the active diagram	4.223
TOI	4.196
Tolerance	
comparison of test sweep and reference	4.332
Trace	4.118, 4.119
averaging	4.120, 4.123
blank	4.121
clear/write	4.119
copy	4.63, 4.126
freeze	4.121
info	4.62, 4.131
math	4.131
max hold	4.120
min hold	4.122
position for 0 difference	4.131
power measurement	4.180
select	4.118
signal tracking	4.89
storing (ASCII format)	4.206
Trace info	4.62, 4.63, 4.131
Trace mode	
average	4.120
blank	4.121
clear/write	4.119
max hold	4.120
view	4.121
Transducer	
activating	4.231
entry	4.233
Transmission measurement	4.278
Trigger	
external	4.111
external gate	4.113
free run	4.110
gated sweep	4.114
IF power	4.111
offset	4.111
slope	4.111
sweep	4.110
video	4.110
Troubleshooting	2.20

U

Unit	
level axis	4.93
limit line	4.216
Universal command	8.5
Upper case	6.5

V

VCO & LOOP SETTINGS dialog box	4.51
R&S FSUP-B60	4.345

Video bandwidth 4.99
Video triggering 4.110
View trace 4.121

W

White space 5.16

Z

Zero span 4.90
Zoom 4.140
 amplitude 4.121
 x axis (gate signal) 4.115