



FOR YOUR PROTECTION...

To aid in reporting this compact copier in case of loss or theft, please record below the model number and serial number located on the back of the unit. We also suggest you record all the information listed and retain for future reference.

MODEL NUMBER _____ SERIAL NUMBER _____

DATE OF PURCHASE _____

Dealer _____

Address _____ City _____

State _____ Zip _____ Telephone _____

Service Station _____

Address _____ City _____

State _____ Zip _____ Telephone _____

For location of the nearest Sharp Authorized Service, or to obtain product literature, accessories, or supplies,

please call **1 - 800 - BE-SHARP**

For customer assistance, please visit <http://www.sharp-usa.com> on the World Wide Web or call **1-(630)378-3590**.



CONTENTS

1 GETTING STARTED

- INTRODUCTION 3
- CAUTIONS 3
- MAIN FEATURES 4
- PART NAMES 6
- OPERATION PANEL 7

2 INSTALLATION

- COPIER INSTALLATION 8
- CAUTIONS ON HANDLING 9
- CHECKING PACKED COMPONENTS AND ACCESSORIES 10
- UNPACKING 10
- REMOVING PROTECTIVE PACKING MATERIALS 11
- INSTALLING THE TD CARTRIDGE 12
- LOADING COPY PAPER (installing the paper tray) 13
- POWER TO COPIER 15
- POWER ON 16
 - Initial settings of operation panel 16

3 MAKING COPIES

- PAPER 17
- NORMAL COPYING 18
 - Stream feeding mode 20
- EXPOSURE ADJUSTMENT/PHOTO COPYING 20
- REDUCTION/ENLARGEMENT/ZOOM 21
- BYPASS FEED (including special paper) 22
- TWO-SIDED COPYING 23

4 SPECIAL FUNCTIONS

- DESCRIPTION OF SPECIAL FUNCTIONS 25
- TONER SAVE MODE 25
- USER PROGRAMS (power save modes, auto clear time, stream feeding mode) 26
 - Setting the power save modes, auto clear time, and stream feeding mode 26
- DISPLAYING TOTAL NUMBER OF COPIES 27

5 SUPPLIES AND USER MAINTENANCE

- TD CARTRIDGE REPLACEMENT 28
- DRUM CARTRIDGE REPLACEMENT 29
- USER MAINTENANCE 31
 - Cabinet 31
 - Original table and original cover 31
 - Transfer charger 32
 - When copier is not in use 33

6 COPIER TROUBLE?

- MISFEED REMOVAL 34
 - A Misfeed in the paper feed area 35
 - B Misfeed in the fusing area 35
 - C Misfeed in the transport area 36
 - D Misfeed in the lower paper feed area
(AL-1250 and AL-1521 only) 37
 - E Misfeed in the SPF 38
- TROUBLESHOOTING 39
- STATUS INDICATORS 40
- AUTOMATIC EXPOSURE ADJUSTMENT 41

7 APPENDIX

- SPECIFICATIONS 42
- OPTION AND SUPPLY PART NUMBERS AND STORAGE 44
- MOVING INSTRUCTIONS 45

INDEX

1

GETTING STARTED

This chapter provides basic information for using the copier.

INTRODUCTION

This copier has been designed to provide intuitive operating ease while requiring a minimum amount of space. To get full use of all copier features, be sure to familiarize yourself with this manual and the copier.

For quick reference during copier use, keep this manual in a handy location.



Note

- The AL-1250 can be used as a laser printer. The AL-1020/AL-1220 /AL-1521 can also be used as a laser printer if an optional printer upgrade kit is installed. This manual describes only the copier features. For description of the printer features, see the printer manual.
- The AL-1020 and AL-1220 are equipped with one paper tray while the AL-1250 and AL-1521 are equipped with two paper trays. The illustrations in this manual are mainly for the AL-1020 and AL-1220.

Conventions used in this manual

In this manual, the following icons are used to provide the user with information pertinent to the use of the copier.



Warning

Warns the user that injury to the user or damage to the copier may result if the contents of the warning are not properly followed.



Caution

Cautions the user that damage to the copier or one of its components may result if the contents of the caution are not properly followed.



Note

Notes provide information relevant to the copier regarding specifications, functions, performance, operation and such, that may be useful to the user.



Indicates a letter displayed in the display.

CAUTIONS

Follow the cautions below when using this copier.



Warning

- The fusing area is hot. Exercise care in this area when removing misfed paper.
- Do not look directly at the light source. Doing so may damage your eyes.
- Do not switch the copier rapidly on and off. After turning the copier off, wait 10 to 15 seconds before turning it back on.
- Copier power must be turned off before installing any supplies.

CAUTIONS



Caution

- Place the copier on a firm, level surface.
- Do not install the copier in a humid or dusty location.
- When the copier is not used for long time, for example for consecutive holidays, turn the power switch off and remove the power cord from the outlet.
- When moving the copier, be sure to turn the power switch off and remove the power cord from the outlet.
- Do not cover the copier with a dust cover, cloth or plastic film while the power is on. Doing so may prevent heat radiation, damaging the copier.

SAFETY PRECAUTIONS

This Digital Copier is rated Class 1 and complies with 21 CFR 1040.10 and 1040.11 of the CDRH standards. This means that the copier does not produce hazardous laser radiation. For your safety, observe the precautions below.

- Do not remove the cabinet, operation panel or any other covers.
- The copier's exterior covers contain several safety interlock switches. Do not bypass any safety interlock by inserting wedges or other items into switch slots.



Caution

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

MAIN FEATURES

① High-speed laser copying

- Since warm-up time is zero, copying can be started immediately after the power switch is turned on.
- First-copy time is only 9.6 seconds (normal mode).
- Copying speed is 10 copies/min. (AL-1020), 12 copies/min. (AL-1220/AL-1250) or 15 copies/min. (AL-1521), which adapts to business use, allowing improvement of working efficiency.

② High-quality digital image

- High-quality image copying at 600 dpi can be performed.
- In addition to the automatic exposure mode, the manual exposure can be adjusted in five steps.
- The photo mode copying function allows clear copying of delicate halftone original images such as monochrome photos and color photos.

③ Substantial copying functions

- Zoom copying from 50% to 200% in 1% increments can be performed.
- Continuous copying of maximum 99 sheets can also be performed.
- Automatic document feeding through the single pass feeder (SPF) can be performed.
- Toner save mode reduces toner consumption by approximately 10%.
- User programs allow setting/modification of functions for customer's needs.

④ Scan once/ Print many

- This copier is equipped with a 1-page memory buffer. This Memory allows the copier to scan an original 1 time only and make up to 99 copies. This feature allows for improved workflow, reduced operating noise from the copier and reduced wear and tear on the scanning mechanism. This feature provides for a higher reliability.

⑤ Printer feature

- The AL-1250 copier can be used as a laser printer. The AL-1020, AL-1220 and AL-1521 copiers can be used as a laser printer by installing an optional printer upgrade kit. If you would like to upgrade your AL-1020, AL-1220 or AL-1521 to printer capability, see your local reseller or visit the SHARP web site at www.sharp-usa.com.

⑥ Environmentally friendly design

- Paper output tray is housed in the copier for space saving.
- Preheat mode and auto power shut-off mode are provided to reduce power consumption in standby mode.




Note


This copier does not have an internal calendar or clock.
This copier will not be affected by the year 2000.

PART NAMES

1
Getting started



OPERATION PANEL



1 Exposure mode selector key and indicators

Use to sequentially select the exposure modes: AUTO, MANUAL or PHOTO. Selected mode is shown by a lit indicator. (p. 20)

2 Light and dark keys and exposure indicators

Use to adjust the MANUAL or PHOTO exposure level. Selected exposure level is shown by a lit indicator. (p.20)
Use to start and terminate user program setting. (p. 26)

3 Alarm indicators

: Drum replacement required indicator (p. 29)
 : Misfeed indicator (p. 34)
 : TD cartridge replacement required indicator (p. 28)

4 SPF indicator (p.18)

5 SPF misfeed indicator (p.34)

6 Copy ratio selector key and copy ratio indicators

Use to sequentially select preset reduction/enlargement copy ratios. Selected copy ratio is shown by a lit indicator. (p. 21)

7 Zoom indicator (p. 21)

8 Copy ratio display (%) key (p. 21)

9 Display

Displays the specified copy quantity, zoom copy ratio, user program code, and error code.

10 ON LINE indicator

Lights up when the machine is used as a printer. To use the AL-1020, AL-1220 and AL-1521 as a printer, an optional printer upgrade kit is needed.

11 Power save indicator

Lights up when the copier is in a power save mode. (p. 25, 26)

12 Tray select key

Use to select a paper feed station (paper tray or bypass tray). (p. 22)

13 Paper feed location indicators

Light up to show the selected paper feed station.
* AL-1250/1521 only.

14 Zoom keys

Use to select any reduction or enlargement copy ratio from 50% to 200% in 1% increments. (p. 21)

15 Copy quantity keys

- Use to select the desired copy quantity (1 to 99). (p. 18)
- Use to make user program entries. (p. 26)

16 Clear key

- Press to clear the display, or press during a copy run to terminate copying. (p. 18)
- Press and hold down during standby to display the total number of copies made to date. (p. 27)

17 Print key and ready indicator

- Copying is possible when the indicator is on.
- Use to set a user program.

2

INSTALLATION

Follow the installation procedure below to use the copier properly.

COPIER INSTALLATION

Improper installation may damage the copier. Please note the following during initial installation and whenever the copier is moved.



Caution


If the copier is moved from a cool place to a warm place, condensation may form inside the copier. Operation in this condition will cause poor copy quality and malfunctions. Leave the copier at room temperature for at least 2 hours before use.

Do not install your copier in areas that are:


- damp, humid, or very dusty




- exposed to direct sunlight




- poorly ventilated



- subject to extreme temperature or humidity changes, e.g., near an air conditioner or heater.



Be sure to allow the required space around the machine for servicing and proper ventilation.



A small amount of ozone is produced within the copier during operation. The emission level is insufficient to cause any health hazard.

NOTE:


The present recommended long term exposure limit for ozone is 0.1 ppm (0.2 mg/m³) calculated as an 8 hr. time-weighted average concentration.

However, since the small amount that is emitted may have an objectionable odor, it is advisable to place the copier in a ventilated area.

CAUTIONS ON HANDLING


Be careful in handling the copier as follows to maintain the performance of this copier.

Do not drop the copier, subject it to shock or strike it against any object.



Do not expose the drum cartridge to direct sunlight.

Doing so will damage the surface (green portion) of the drum cartridge, causing smudges on copies.



Store spare supplies such as drum cartridges and TD cartridges in a dark place without removing from the package before use.


If they are exposed to direct sunlight, smudges on copies may result.

Do not touch the surface (green portion) of the drum cartridge.

Doing so will damage the surface of the cartridge, causing smudges on copies.

CHECKING PACKED COMPONENTS AND ACCESSORIES

Open the carton and check if the following components and accessories are included.




Note

- If anything is not included or is damaged, contact our Technical Assistance Department at 1-(630)378-3590.
- Save the carton and packing materials. These can be re-used for transporting the machine, should it be necessary.


UNPACKING

Be sure to hold the handles on both sides of the copier to unpack the copier and carry it to the installation location.



REMOVING PROTECTIVE PACKING MATERIALS

- 1** Remove all pieces of tape shown in the illustration below. Then open the original cover and remove protective materials (a), (b) and (c).




- 2** Use a coin (or suitable object) to remove the screw.




Caution

Store the screw in the paper tray because it will be used if the copier has to be moved. (p. 14)





INSTALLING THE TD CARTRIDGE


- 1 Open the bypass tray and then open the side cover while pressing the side cover open button.





- 2 Remove the CAUTION tape from the front cover and remove the two protective pins from the fusing unit by pulling the strings upward one at a time.




- 3 Push gently on both sides of the front cover to open the cover.



- 4 Remove the TD cartridge from the bag. Remove the protective paper. Hold the cartridge on both sides and shake it horizontally four or five times. Hold the tab of the protective cover and pull the tab to your side to remove the cover.



- 5** Gently insert the TD cartridge until it locks in place.





- 6** Close the front cover and then the side cover by pressing the round projections near the side cover open button.



Caution

When closing the covers, be sure to close the front cover securely and then close the side cover. If the covers are closed in the wrong order, the covers may be damaged.




LOADING COPY PAPER (installing the paper tray)



Note


While the AL-1020 and AL-1220 are equipped with one paper tray, the AL-1250 and AL-1521 are equipped with two paper trays. For the AL-1250/AL-1521, load copy paper into the two paper trays.

- 1** Raise the handle of the paper tray and pull the paper tray out until it stops.




LOADING COPY PAPER

- 2** Remove the pressure plate lock. Rotate the pressure plate lock in the direction of the arrow to remove it while pressing down the pressure plate of the paper tray.




- 3** Store the pressure plate lock which has been removed in step 2 and the screw which has been removed when unpacking (see page 11, step 2 of **REMOVING PROTECTIVE PACKING MATERIALS**) in the front of the paper tray. To store the pressure plate lock, rotate the lock to fix it on the relevant location.


Pressure plate lock



Screw



- 4** Adjust the paper guides on the paper tray to the copy paper width and length. Squeeze the lever of paper guide (A) and slide the guide to match with the width of the paper. Move paper guide (B) to the appropriate slot as marked on the tray.




Paper guide (B)


Paper guide (A)

- 5** Fan the copy paper and insert it into the tray. Make sure the edges go under the corner hooks.



Note

Do not load paper above the maximum height line (). Exceeding the line will cause a paper misfeed.




- 6** Gently push the paper tray back into the copier.



Note

After loading copy paper, to cancel the blinking "P" without restarting copying, press the clear (C) key. The "P" in the display will go out and the ready (R) indicator will light up.




POWER TO COPIER

- 1** Ensure that the power switch of the copier is in the OFF position. Insert the attached power cord into the power cord socket at the rear of the copier.



Warning

If you use the copier in a country other than the country where the copier was purchased, you will need to make sure that your local power supply is compatible with your model. If you plug the copier into an incompatible power supply, irreparable damage to the copier will result.



- 2** Plug the other end of the power cord into the nearest outlet.



Caution

Only insert the power cord into a properly grounded wall socket. Do not use extension cords or power strips.


POWER ON

Turn the power switch on the left side of the copier to the "ON" position. The ready (Ⓞ) indicator will light up and other indicators which show the initial settings of the operation panel will also light up to indicate the ready condition. For the initial settings, see the "Initial settings of operation panel" described below.




Note

- The copier will enter a power save mode once the set time has elapsed without any copier operation after the last copy of a run is made or power is turned on.
The settings of the power save modes can be modified. See page 26, **USER PROGRAMS**.
- The copier will return to the initial settings a preset amount of time after the last copy is made. The preset amount of time (auto clear time) can be changed.
See page 26, **USER PROGRAMS**.



Initial settings of operation panel

The copier assumes the initial settings when the copier is turned on or a preset time (auto clear time) elapses after the last copy is made. The initial settings of the operation panel are shown below.



"0" is displayed in the display.

3

MAKING COPIES

This chapter describes basic copying functions and some other copying functions using the bypass tray.

PAPER

For best results, use only paper recommended by SHARP.

Type of paper feeding	Type of media		Size	Weight
Paper tray	Standard paper		Letter (8-1/2" x 11") Legal (8-1/2" x 14") Invoice (5-1/2" x 8-1/2") A4 (210mm x 297mm) B5 (182mm x 257mm)	15 lbs. to 21 lbs.
Bypass tray	Standard paper and thick paper		Letter (8-1/2" x 11") Legal (8-1/2" x 14") Invoice (5-1/2" x 8-1/2") A4 (210mm x 297mm) B5 (182mm x 257mm)	14 lbs. to 34.5 lbs.**
	Special media	Transparency film	Letter (8-1/2" x 11") A4 (210mm x 297mm)	
		Envelope*	Commercial 10 (4-1/8" x 9-1/2") Monarch (3-7/8" x 7-1/2") International DL (110mm x 220mm) International C5 (162mm x 229mm)	

* Do not use envelopes that have metal clasps, plastic snappers, string closures, windows, linings, self-adhesive, patches or synthetic materials. These will cause physical damage to the copier.


** For paper weighing from 28 to 34.5 lbs., 8-1/2" x 11" is the maximum size that can be fed through the bypass tray.

- Special papers such as transparency film and labels must be fed one sheet at a time through the bypass tray.

NORMAL COPYING

This copier has two document input stations - a single pass feeder (SPF) for automatic document feeding and an original table for manual handling of documents. The SPF is designed to hold up to 30 originals measuring from 5-1/2" x 8-1/2" to 8-1/2" x 14" and weighing from 14 to 23 lbs.

- 1 Ensure that paper of the desired size is set in the paper tray. See page 13, **LOADING COPY PAPER**. When copying onto paper larger than 8-1/2" x 11" size, pull out the paper output tray extension. When using the AL-1250 and AL-1521, use the tray select (☰) key to select the desired paper tray.



- 2 Turn the power switch on.

- 3 Place the original(s) face up in the document feeder tray or face down on the original table.



A. When using the SPF:

- (1) Make sure that no original is left on the original table.
- (2) Adjust the original guides to the size of originals.
- (3) Set the originals face up in the document feeder tray.




Note

- Before feeding originals in the document feeder tray, be sure to remove any staples or paper clips from them.
- Before placing curled or wavy originals into the document feeding tray, be sure to flatten them. If not, original misfeeds may result.
- The SPF (☰) indicator on the operation panel will light up. If this indicator does not light up, the originals are not properly set or the SPF is not properly closed.
- Badly damaged originals may misfeed in the SPF. It is recommended that such originals be copied from the original table.
- Special originals such as transparency film should not be fed through the SPF, but should be placed directly on the original table.



B. When using the original table:


- (1) Open the original cover.
- (2) Place an original face down on the original table. Align it with the original scale and the centering (▶) mark. Close the original cover.



Note

When copying a book or an original which has been folded or a crumpled original, press down the original cover lightly. If the original cover is not securely closed, the copies may be striped or blurred.

A book, an original which has been folded, or a crumpled original




4

Set the number of copies using the two copy quantity (▲, ▲) keys.




Note

- Press the clear (C) key to clear an entry if a mistake is made.
- A single copy can be made with the initial setting, i.e., when "0" is displayed.




- Press the right copy quantity key to set the unit digit from 0 to 9. This key will not change the tens digit.
- Press the left copy quantity key to set the tens digit from 1 to 9.


NORMAL COPYING

- 5 Press the print () key.





Note

- To display the number of copies made in a continuous run, press the left copy quantity key.
- To stop copying in the middle of a run, press the clear () key. Copying will stop and the number in the display will be reset to “0”.





Stream feeding mode


The stream feeding mode allows easy operation of continuous copying from the SPF.

If the stream feeding mode has been enabled using user program No.4, the SPF () indicator will blink approximately 5 seconds after printing of all copies from the SPF is complete. While this indicator is blinking, any new originals placed in the document feeder tray will be fed and copied automatically. If the stream feeding mode has been disabled, the print () key must be pressed each time the originals are set even immediately after completion of a copy run from the SPF. The default setting of the stream feeding mode is “ON”. See page 26, **USER PROGRAMS**.


EXPOSURE ADJUSTMENT/PHOTO COPYING

Copy density adjustment is not required for most originals in the automatic exposure mode. To adjust the copy density manually or to copy photographs, the exposure level can be adjusted in five steps manually.

- 1 Set the original and check the copy paper size.
- 2 Press the exposure mode selector key to select the manual () mode or photo () mode.



- 3** Use the light (☐) and dark (●) keys to adjust the exposure level. If exposure level 2 is selected, the two left-handmost indicators for that level will light up simultaneously. Also, if level 4 is selected, the two right-handmost indicators for that level will light up simultaneously.



- 4** Set the number of copies using the copy quantity (▲, ▲) keys and press the print (Ⓜ) key.

REDUCTION/ENLARGEMENT/ZOOM

Three preset reduction ratios and two enlargement ratios can be selected. The zoom function enables copy ratio selection from 50% to 200% in 1% increments.

- 1** Set the original and check the copy paper size.
- 2** Use the copy ratio selector key and/or zoom (⊖, ⊕) keys to select the desired copy ratio.



Note

- To verify a zoom setting without changing the zoom ratio, press and hold down the copy ratio display (%) key. When the key is released, the display will return to the copy quantity display.
- To reset the ratio to 100%, press the copy ratio selector key repeatedly until the 100% indicator lights up.

To select a preset copy ratio:

Preset reduction and enlargement ratios are: 50%, 64%, 78%, 129%, and 200%



To select a zoom ratio:

When a zoom (⊖ or ⊕) key is pressed, the ZOOM indicator will light up and the zoom ratio will be displayed in the display.



Note

To decrease or increase the zoom ratio rapidly, press and hold down the ⊖ or ⊕ key. However the value will stop at the preset reduction or enlargement ratios. To move beyond these ratios, release the key and then press and hold it down again.



3

Set the number of copies using the copy quantity (▲, ▲) keys and press the print (Ⓢ) key.

BYPASS FEED (including special paper)

The bypass tray automatically feeds up to 50 sheets of standard copy paper and also feeds special papers such as transparency film and labels one sheet at a time. Copy paper measuring from 3-1/2" x 5-1/2" to 8-1/2" x 14" and in the weight range of 14 to 34.5 lbs. can be used in this tray. (For paper weighing from 28 to 34.5 lbs., 8-1/2" x 11" is the maximum size.)

1

Place the original(s) face up in the document feeder tray or face down on the original table.




Note

The original image must be smaller than the paper or media for copying. If the original image is bigger than the paper or media, this may cause smudges on the edges of the copies.


2

Open the bypass tray and extend the tray.




Note

To close the bypass tray, perform step 1 and then step 2 in the illustration and push the round projections at the right of the tray until they click.





- 3 Set the paper guides to the copy paper width. Insert the copy paper (print face down) all the way into the bypass tray.



Note

- Paper must be fed narrow side into the feed slot.
- Transparency film, labels, and other special purpose papers must be fed individually.
- When copying onto transparency film, remove each copy promptly. Do not let copies stack up.
- When loading an envelopes, make sure that it is straight and flat.




- 4 Press the tray select (☰) key to select the bypass tray. Set the number of copies if using standard copy paper. Press the print (⏻) key.


TWO-SIDED COPYING

Two-sided copying can be made on this copier using the bypass tray.


Example: The following two originals will be copied onto two sides of copy paper.




First original



Second original



- 1 Place the first original on the original table and make a copy. The first copy can be made using either the paper tray or the bypass tray.



TWO-SIDED COPYING

- 2 Replace the first original with the second original on the original table and close the original cover. Make sure that the first and second originals are oriented in the same way on the original table.



Note

Both the first and second originals can be set in the SPF but they must be set separately. If the stream feeding mode for the SPF has been enabled, set the second original after the SPF (⇨) indicator goes out. See page 20.


- 3 For tablet binding, turn the first copy over left to right as shown below. For booklet binding, turn the first copy over top to bottom (not shown). Feed the first copy into the bypass tray.

- 4 Press the tray select (☰) key to select the bypass tray and press the print (⏏) key.



Note

Be sure to feed the copy paper one sheet at a time.



DESCRIPTION OF SPECIAL FUNCTIONS

This chapter describes the special functions of this copier. Use these functions as needed.

Toner save mode (page 25)

Reduces toner consumption by approximately 10%.

Power save modes (page 26)

The copier has two power save modes of operation: preheat mode and auto power shut-off mode.

- **Preheat mode**

When the copier enters the preheat mode, the power save (⏻) indicator will light up and other indicators will remain on or off as before. In this condition, the fuser in the copier is maintained at a lower heat level, thereby saving power. To copy from the preheat mode, make desired copier selections and press the print (⏻) key using the normal copying procedure.

- **Auto power shut-off mode**

When the copier enters the auto power shut-off mode, the power save (⏻) indicator will light up and other indicators will go out. The auto power shut-off mode saves more power than the preheat mode but requires a longer time before starting copying. To copy from the auto power shut-off mode, press the print (⏻) key. Then make desired copier selections and press the print (⏻) key using the normal copying procedure.

Auto clear (page 26)

The copier returns to the initial settings a preset amount of time after the last copy is made. This preset amount of time (auto clear time) can be changed.


Stream feeding mode (page 26)

For description of the stream feeding mode, see page 20.


TONER SAVE MODE

1


Press the exposure mode selector key to select the manual (⏻) mode.



- 2 Press and hold down the exposure mode selector key for approximately 5 seconds. The manual (☐⋯▶) indicator will go out and the photo (📷) indicator will begin to blink. The exposure indicator marked “5” will light up, indicating the standard toner mode is active.



- 3 To enter the toner save mode, press the light (Ⓛ) key. The exposure indicator marked “1” will light up, indicating the toner save mode is selected.



- 4 Press the exposure mode selector key twice. The photo (📷) indicator will stop blinking and the AUTO indicator will light up steadily. The toner save mode is now active.



Note

To return to the standard mode, repeat the procedure but use the dark (Ⓧ) key to select exposure level “5” in step 3.

USER PROGRAMS (power save modes, auto clear time, stream feeding mode)

The user programs allow the parameters of certain functions to be set, changed, or canceled as desired.

Setting the power save modes, auto clear time, and stream feeding mode

- 1 Press and hold down the light (Ⓛ) and dark (Ⓧ) keys simultaneously for more than 5 seconds until all the alarm indicators (🔊, ⚡, ⚠) blink and “— —” appears in the display.
- 2 Use the left copy quantity (Ⓜ) key to select a user program number (1: auto clear time, 2: preheat mode, 3: auto power shut-off timer, 4: stream feeding mode, 5: auto power shut-off mode). The selected number will blink in the left side of the display.

- 3 Press the print (Ⓞ) key. The entered program number will be steadily lit and the currently selected parameter number for the program will blink on the right side of the display.
- 4 Select the desired parameter using the right copy quantity (Ⓜ) key. The entered parameter number will blink on the right of the display.

Program No.	Mode	Parameters					
1	Auto clear time	0 ⇨ OFF	1 ⇨ 30 sec.	* 2 ⇨ 60 sec.	3 ⇨ 90 sec.	4 ⇨ 120 sec.	5 ⇨ 10 sec.
2	Preheat mode	0 ⇨ 30 sec.	1 ⇨ 60 sec.	* 2 ⇨ 90 sec.			
3	Auto power shut-off timer	0 ⇨ 2 min.	* 1 ⇨ 5 min.	2 ⇨ 15 min.	3 ⇨ 30 min.	4 ⇨ 60 min.	5 ⇨ 120 min.
4	Stream feeding mode	0 ⇨ OFF	* 1 ⇨ ON				
5	Auto power shut-off mode	0 ⇨ OFF	* 1 ⇨ ON				

Factory default settings are indicated with an asterisk (*).

- 5 Press the print (Ⓞ) key. The right-hand number in the display will be steadily lit and the entered value will be stored.



To change the setting or to set another mode, press the clear (Ⓢ) key. The copier will return to step 2.

- 6 Press the light (Ⓛ) or dark (Ⓧ) key to return to the normal copy mode.

DISPLAYING TOTAL NUMBER OF COPIES

Use the following procedure to display the total number of copies.

- 1 Press the clear (Ⓢ) key to reset the display to zero.
- 2 Press and hold down the clear (Ⓢ) key for approximately 5 seconds. The total number of copies will appear in two steps, each with three digits.
Example: Total number of copies is 1,234.

001 ⇨ 234

5

SUPPLIES AND USER MAINTENANCE

This chapter describes how to replace the TD cartridge and the drum cartridge.



Caution

Be sure to use only genuine SHARP parts and supplies.

TD CARTRIDGE REPLACEMENT

The TD cartridge replacement required (∴) indicator will light up when toner is needed. For more information on purchasing the TD cartridge, see **OPTION AND SUPPLY PART NUMBERS AND STORAGE** on page 44. If copying is continued while the ∴ indicator is lit, copies will gradually become lighter until the copier stops and the indicator begins blinking. Replace the old TD cartridge by following the procedure given below.




Note

- After the copier stops, it may be possible to make a few more copies by taking the TD cartridge out of the copier, shaking it horizontally, then reinstalling it. If copying is not possible after this operation, replace the TD cartridge.
- During long copy run of a dark original, the ready (⊕) indicator may blink, the ∴ indicator light up, and the copier stop, even though toner is left. The copier will feed toner up to 2 minutes and then the ready (⊕) indicator will light up. Press the print (⊕) key to restart copying.


1

Ensure that the bypass tray is open and then open the side cover while pressing the side cover open button. Then, push gently on both sides of the front cover to open the cover.





2

Gently pull the TD cartridge out while pressing the lock release button. Dispose of the old TD cartridge in accordance with local regulations.



3 Install a new TD cartridge. To install the new cartridge, see page 12, **INSTALLING THE TD CARTRIDGE**.


4 Close the front cover and then the side cover by pressing the round projections near the side cover open button. The  indicator will go out and the ready () indicator will light up.



Caution

When closing the covers, be sure to close the front cover securely and then close the side cover. If the covers are closed in the wrong order, the covers may be damaged.

DRUM CARTRIDGE REPLACEMENT


The useful life of the drum cartridge is approximately 18,000 copies. When the internal counter reaches approximately 17,000 copies, the drum replacement required () indicator will light up indicating that replacement of the drum cartridge will be needed soon. For more information on purchasing the drum cartridge, see **OPTION AND SUPPLY PART NUMBERS AND STORAGE** on page 44. When the indicator begins to blink, the copier will stop operating until the cartridge is replaced. Replace the drum cartridge at this time.



Caution


Do not remove the protective cover on the drum portion (black paper) of a new drum cartridge before use. The cover protects the drum against external light.

1 Ensure that the bypass tray is open and then open the side cover while pressing the side cover open button. Then, push gently on both sides of the front cover to open the cover.



2 Gently pull the TD cartridge out while pressing the lock release button. To remove the TD cartridge, see page 28, step 2.

3 Hold the handle of the drum cartridge and gently pull the cartridge out. Dispose of the old drum cartridge in accordance with local regulations.





DRUM CARTRIDGE REPLACEMENT

- 4 Remove the new drum cartridge from the protective bag and remove the protective cover from the cartridge. Then gently install the new drum cartridge.



Note

Do not touch the surface of the drum (green portion) of the cartridge. Doing so may cause smudges on the copies.



- 5 Gently install the TD cartridge. To install the TD cartridge, see page 12, **INSTALLING THE TD CARTRIDGE**.

- 6 Close the front cover and then the side cover by pressing the round projections near the side cover open button. The drum replacement required (⊖) indicator will go out and the ready (⊕) indicator will light up.



Caution

When closing the covers, be sure to close the front cover securely and then close the side cover. If the covers are closed in the wrong order, the covers may be damaged.

USER MAINTENANCE

Proper care is essential in order to get clean, sharp copies. Be sure to take a few minutes to regularly clean the copier.



Warning

Before cleaning, be sure to turn the power switch off and remove the power cord from the outlet.



Caution


Do not use thinner, benzene or other volatile cleaning agents. Doing so may cause deformation, discoloration, deterioration or malfunction.

Cabinet

Wipe the cabinet with a soft, clean cloth.

Original table and original cover

Stains on the glass, cover or SPF roller will also be copied. Wipe the glass, cover and SPF roller with a soft, clean cloth. If necessary, dampen the cloth with a glass cleaner.





Transfer charger

If copies start becoming streaky or blotchy, the transfer charger may be dirty. Clean the charger using the following procedure.


- 1 Turn the power switch off.
- 2 Ensure that the bypass tray is open and then open the side cover while pressing the side cover open button.
- 3 Take the charger cleaner out by holding the tab. Set the charger cleaner onto the right end of the transfer charger, gently slide the cleaner to the left end, and then remove it. Repeat this operation two or three times.



Slide the charger cleaner from the right end to the left end along the groove of the transfer charger. If the cleaner is stopped on the way, smudges on copies may occur.



- 4 Return the charger cleaner to its original position. Close the side cover by pressing the round projections near the side cover open button.





- 5 Turn the power switch on.

When copier is not in use

To prevent entry of dust and foreign matter, store the copier as follows.

1

Remove the power cord and secure the copier using tape (four locations).



6

COPIER TROUBLE?

This chapter describes misfeed removal and troubleshooting.

MISFEED REMOVAL

When the misfeed (⌘) indicator blinks or **P** blinks in the display, the copier will stop because of a misfeed.

If a misfeed occurs when using the SPF, a number may appear in the display after a minus sign. This indicates the number of the originals that must be returned to the document feeder tray after a misfeed. Return the required number of originals. Then this number will disappear when copying is resumed or the clear (Ⓢ) key is pressed.

When the SPF misfeeds an original sheet, the copier will stop and the SPF misfeed (◀) indicator will blink, while the misfeed (⌘) indicator will remain off. For a misfeed of originals in the SPF, see **"E Misfeed in the SPF"** on page 38.




Note

If the AL-1250 and AL-1521 are turned on with the lower side cover open, the misfeed (⌘) indicator will blink. In this case, close the lower side cover. The misfeed (⌘) indicator will go out.

1


Ensure that the bypass tray is open and then open the side cover while pressing the side cover open button.



2

Check the misfeed location. Remove the misfed paper following the instructions for each location in the illustration below.

If **P** blinks in the display, proceed to **"A Misfeed in the paper feed area"**. (p. 35)




If paper is misfed here, proceed to **"B Misfeed in the fusing area"**. (p. 35)

If the misfed paper is seen from this side, proceed to **"C Misfeed in the transport area"**. (p. 36)

If paper is misfed here, proceed to **"A Misfeed in the paper feed area"**. (p. 35)

If paper is misfed here, proceed to **"D Misfeed in the lower paper feed area"**. (p. 37) (AL-1250/AL-1521 only)

A Misfeed in the paper feed area

- 1 Gently remove the misfed paper from the paper feed area as shown in the illustration. When  blinks in the display and the misfed paper is not seen from the paper feed area, pull out the paper tray and remove the misfed paper. If the paper cannot be removed, proceed to “**B Misfeed in the fusing area**”.




Warning

The fusing unit is hot. Do not touch the fusing unit when removing misfed paper. Doing so may cause a burn or other injury.



Caution


- Do not touch the surface of the drum (green portion) of the drum cartridge when removing the misfed paper. Doing so may damage the drum and cause smudges on copies.
- If the paper has been fed through the bypass tray, do not remove the misfed paper through the bypass tray. Toner on the paper may stain the paper transport area, resulting in smudges on copies.



- 2 Close the side cover by pressing the round projections near the side cover open button. The misfeed (⚠) indicator will go out and the ready (Ⓢ) indicator will light up.

B Misfeed in the fusing area

- 1 Lower the fusing unit release lever.



- 2 Gently remove the misfed paper from under the fusing unit as shown in the illustration. If the paper cannot be removed, proceed to “**C Misfeed in the transport area**”.




Warning

The fusing unit is hot. Do not touch the fusing unit when removing misfed paper. Doing so may cause a burn or other injury.



Caution

- Do not touch the surface of the drum (green portion) of the drum cartridge when removing the misfed paper. Doing so may cause smudges on copies.
- Do not remove the misfed paper from above the fusing unit. Unfixed toner on the paper may stain the paper transport area, resulting in smudges on copies.




3

Raise the fusing unit release lever and then close the side cover by pressing the round projections near the side cover open button. The misfeed (⊗) indicator will go out and the ready (⊕) indicator will light up.

C Misfeed in the transport area


1

Lower the fusing unit release lever.




2

Push gently on both sides of the front cover to open the cover.



- 3 Rotate the feeding roller in the direction of the arrow and gently remove the misfed paper from the exit area.



- 4 Raise the fusing unit release lever, close the front cover and then close the side cover by pressing the round projections near the side cover open button. The misfeed (Ⓜ) indicator will go out and the ready (Ⓡ) indicator will light up.




Caution

When closing the covers, be sure to close the front cover securely and then close the side cover. If the covers are closed in the wrong order, the covers may be damaged.

D Misfeed in the lower paper feed area (AL-1250 and AL-1521 only)

- 1 Open the lower side cover (under the bypass tray) and remove the misfed paper. If **P** blinks and the misfed paper is not seen from the area of the lower side cover, pull out the lower paper tray and remove the misfed paper. Then close the lower paper tray.




- 2 Close the lower side cover.
- 3 Close the side cover by pressing the round projections near the side cover open button. The misfeed (Ⓜ) indicator will go out and the ready (Ⓡ) indicator will light up.


E Misfeed in the SPF

An original misfeed may occur at one of three locations: if the misfed original is seen from the document feeder tray, (A) in the document feeder tray; if the misfed original is not seen from the document feeder tray, (B) in the exit area or (C) under the feeding roller. Remove the misfed original following the instructions for each location.


- (A) Open the feeding roller cover and pull the original gently to the left and out from the document feeder tray. Close the feeding roller cover. Open and close the original cover to clear the SPF misfeed (◀) indicator.
If the misfed original cannot be easily removed, proceed to **(C) under the feeding roller** without pulling the original forcibly from the document feeder tray.



- (B) Open the original cover and rotate the roller rotating knob to remove the misfed original from the exit area.
If the misfed original cannot be easily removed, proceed to **(C) under the feeding roller** without pulling the original forcibly.



- (C) Open the original cover and rotate the roller rotating knob to remove the misfed original from the document feeder tray or exit area. If it is difficult, remove the misfed original from under the feeding roller.



Note

A number may appear in the display after a minus sign, indicating the number of the originals that must be returned to the document feeder tray. Clear the misfeed and return the required number of originals. Then press the print (Ⓞ) key to resume copying.

TROUBLESHOOTING

If any problem occurs, check the list below before contacting our Technical Assistance Department at 1-(630)378-3590.

Problem	Possible cause	Solution	See page:
Copier does not operate.	Copier plugged in?	Plug the copier into a grounded outlet.	15
	Power switch on?	Turn the power switch on.	16
	Side cover closed securely?	Gently close the side cover.	—
	Front cover closed?	Gently close the front cover and then close the side cover.	—
Blank copies	Is the original placed face down on the original table or face up in the SPF?	Place the original face down on the original table or face up in the SPF.	18
Power save (⏻) indicator on.	Is the copier in the preheat mode?	Press any key to cancel the preheat mode.	25
	Is the copier in the auto power shut-off mode?	Press the print (Ⓞ) key to cancel the auto power shut-off mode.	25
Copies are too dark or too light.	Is original image too dark or too light?	Adjust the exposure manually.	20
	Is the copier in the automatic exposure mode?	Adjust the automatic exposure level.	41
	Is the copier in the photo exposure mode?	Cancel the photo exposure mode.	20
Dust, dirt, smudges appear on copies.	Original table or original cover dirty?	Clean regularly.	31
	Original smudged or blotchy?	Use a clean original.	—
Striped copies	Is transfer charger clean?	Clean the transfer charger.	32
Paper misfeeds frequently.	Non-standard paper used?	Use standard paper. If using special papers, feed the paper through the bypass tray.	17
	Paper curled or damp?	Store copy paper flat in the wrapper in a dry location.	—
	Pieces of paper inside copier?	Remove all pieces of misfed paper.	34
	Paper guides in the paper tray not set properly?	Set the guides properly depending on the paper size.	13
	Too much paper in the paper tray or bypass tray?	Remove excessive paper from the tray.	14
Images rub off the copy easily.	Is the copy paper too heavy?	Use copy paper within the specified range.	17
	Paper damp?	Replace with dry copy paper. If the copier is not used for long time, remove the paper from the paper tray and store it in its wrapper in a dry location.	44









STATUS INDICATORS

When the following indicators light up or blink on the operation panel or the following alphanumeric codes appear in the display, solve the problem immediately referring to both the table below and the relevant page.



Be sure to use only genuine SHARP parts and supplies.

Caution


Indication		Cause and remedy		See page:
	Drum replacement required indicator	Steadily lit	Replacement of drum cartridge will be needed soon. Prepare a new cartridge.	44
		Blinking	Drum cartridge must be replaced. Replace it with a new one.	29
	TD cartridge replacement required indicator	Steadily lit	Replacement of TD cartridge will be needed soon. Prepare a new cartridge.	44
		Blinking	TD cartridge must be replaced. Replace it with a new one.	28
	Misfeed indicator	Blinking	A misfeed has occurred. Remove the misfed paper referring to the description of "Misfeed removal."	34
			In the AL-1250/AL-1521, the lower side cover may be open. If so, close it.	—
	SPF misfeed indicator	Blinking	An original misfeed has occurred in the SPF. Remove the misfed originals referring to the description of "Misfeed in the SPF".	38
	The paper tray indicator is blinking.		The paper tray is not installed properly. Push the tray into the copier securely.	—
	"CH" is blinking in the display.		The TD cartridge is not installed. Check if the cartridge is installed.	28
	"CH" is steadily lit in the display.		Side cover is open. Close the side cover securely by pressing the round projections near the side cover open button.	—
	"P" is blinking in the display.		Paper tray or bypass tray is empty. Load copy paper.	13
			A misfeed has occurred in the paper tray or bypass tray. Remove the misfed paper.	34
			Paper tray is not securely installed. Push the tray in securely.	—
	A letter and a number appear alternately.		The copier will not function. Turn the power switch off, remove the power cord from the outlet, and contact our Technical Assistance Department at 1-(630)378-3590.	—

AUTOMATIC EXPOSURE ADJUSTMENT


The automatic exposure level can be adjusted to suit your copying needs. This level is set for copying from the original table and copying from the SPF respectively.

- 1** When adjusting the automatic exposure level for copying from the SPF, place an original in the document feeder tray and make sure that the SPF (☞) indicator lights up.
When adjusting the level for copying from the original table, make sure that no original is left in the document feeder tray.


- 2** Press the exposure mode selector key to select the photo (📷) mode.



- 3** Press and hold down the exposure mode selector key for approximately 5 seconds. The photo (📷) indicator will go out and the AUTO indicator will begin to blink. One or two exposure indicators corresponding to the automatic exposure level which has been selected will light up.



- 4** Press the light (☞) or dark (☹) key to lighten or darken the automatic exposure level as desired.
If exposure level 2 is selected, the two left-handmost indicators for that level will light up simultaneously. Also, if level 4 is selected, the two right-handmost indicators for that level will light up simultaneously.



- 5** Press the exposure selector key. The AUTO indicator will stop blinking and light up steadily.



Note

This automatic exposure level will remain in effect until you change it again by this procedure.

7

APPENDIX

SPECIFICATIONS

Type	Digital copying machine, desk-top type
Copy system	Dry, electrostatic transfer
Originals	Sheets, bound documents
Original size	Max. 10" x 14" (Max. 8-1/2" x 14" for SPF)
Copy sizes	8-1/2" x 14" to 3-1/2" x 5-1/2" (Feed copy paper lengthwise only.) Image loss: Max. 5/32" (4 mm) (leading and trailing edges) Max. 5/32" (4 mm) (along the other edges in totals)
Copy speed	AL-1020: 10 copies/min. AL-1220/AL-1250: 12 copies/min. AL-1521: 15 copies/min.
Continuous copying	Max. 99 copies; subtractive counter
First-copy time (Approximately)	9.6 sec. (normal copying mode)
Copy ratio	Variable: 50% to 200% in 1% increments (total 151 steps) Fixed: 50%, 64%, 78%, 100%, 129%, 200%
Exposure system	Original table: Moving optical source, slit exposure (stationary platen) with automatic exposure SPF: Moving original
Copy paper feed	One (AL-1020/AL-1220) or two (AL-1250/AL-1521) paper trays with automatic feed (250 sheets); one bypass tray with 50-sheet automatic feed capability
Fusing system	Heat rollers
Development system	Magnetic brush development
Light source	Xenon lamp
Resolution	Scan: 400 dpi Output: 600 dpi
Gradation	Scan: 256 levels Output: 2 levels

Memory	6 MB
Power supply	AC 120V (±10%), 60 Hz (±2%)
Power consumption	1,000 W
Overall dimensions	31.9" (W) x 18.8" (D) (809 mm (W) x 477 mm (D))
Weight (Approximately)	AL-1020/AL-1220: 47.4 lbs. (21.5 kg) AL-1250/AL-1521: 54.3 lbs. (24.6 kg) TD and drum cartridges included
Copier dimensions	AL-1020/AL-1220: 20.4" (W) x 18.8" (D) x 15.0" (H) (518 mm (W) x 477 mm (D) x 379 mm (H)) AL-1250/AL-1521: 20.4" (W) x 18.8" (D) x 18.3" (H) (518 mm (W) x 477 mm (D) x 464 mm (H))
Operating conditions	Temperature: 50°F to 86°F (10°C to 30°C) Humidity: 20% to 85%
Noise level	Sound Power Level L_{WA} (1B=10dB) Copying: 7.1 [B (A)], Standby: Background noise level Sound Pressure Level L_{PA} (bystander positions) Copying: 40 [dB (A)], Standby: Background noise level Noise emission measurement in accordance with ISO 7779.

First-copy time may differ depending on operating conditions, such as power-supply voltage and room temperature.



Note

As a part of our policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.

OPTION AND SUPPLY PART NUMBERS AND STORAGE

When ordering supplies and option, please use the correct part numbers as listed below.



Be sure to use only genuine SHARP parts and supplies.



For best copying results, be sure to use only SHARP Genuine Supplies which are designed, engineered, and tested to maximize the life and performance of SHARP copiers. Look for the Genuine Supplies label on the toner package.

Supply list

Supply	Part number	Usable life
TD cartridge	AL-100TD	Approx. 6,000 sheets*
Drum cartridge	AL-100DR	Approx. 18,000 sheets

* Based on copying onto letter-type paper at 5% toned area
(The life of the TD cartridge which has been included in the copier at the factory is approximately 2,000 sheets.)

Option list (AL-1020/AL-1220/AL-1521 only)

When purchasing an optional printer upgrade kit, be sure to select the kit which is compatible to your copier. If the printer upgrade kit is not proper, your copier cannot be used as a printer.

Copier model	Part name	Part number	Contents
AL-1020 AL-1220 AL-1521	Printer upgrade kit	AL-10PK	Printer board, printer driver (CD-ROM), interface cable (for IBM PC/AT or compatible computers)

Proper storage

1. Store the supplies in a location that is:
 - clean and dry,
 - at a stable temperature,
 - not exposed to direct sunlight.
2. Store copy paper in the wrapper and lying flat.
 - Paper stored out of the wrapper or in packages standing on end may curl or get damp, resulting in paper misfeeds.

MOVING INSTRUCTIONS

When moving this copier, follow the procedure below.



Note

When moving this copier, be sure to remove the TD cartridge in advance.

1

Turn the power switch off and disconnect the power cord.

2

① Ensure that the bypass tray is open and then open the side cover while pressing the side cover open button. ② Push gently on both sides of the front cover to open the cover.

3

Gently pull the TD cartridge out while pressing the lock release button. See page 28, **TD CARTRIDGE REPLACEMENT**.

4

Close the front cover and then the side cover by pressing the round projections near the side cover open button.



Caution

When closing the covers, be sure to close the front cover securely and then close the side cover. If the covers are closed in the wrong order, the covers may be damaged.

5

Raise the handle of the paper tray and pull the paper tray out until it stops.

6

Push the center of the pressure plate down until it locks in place and lock the plate using the pressure plate lock which has been stored in the front of the paper tray.

7

Use a coin (or suitable object) to attach to the left side of the copier the screw that has been stored in the front of the paper tray.



Caution

When shipping the copier, the screw must be reinstalled to prevent shipping damage.

8

Push the paper tray back into the copier.

9

Close the bypass tray and the paper output tray extension, and attach the packing materials and tape which were removed during installation of the copier. See page 11, **REMOVING PROTECTIVE PACKING MATERIALS**.

10

Pack the copier into the carton. See page 10, **CHECKING PACKED COMPONENTS AND ACCESSORIES**.

INDEX

A

- Auto clear 25, 26
- Automatic exposure adjustment 41
- Auto power shut-off mode 25, 26

B

- Bypass tray 22

C

- Cautions 3
- Cautions on handling 9
- Charger cleaner 32
- Copier trouble? 34
- Copying
 - normal 18
 - reduction/enlargement 21
 - through bypass tray 22
 - two-sided 23
- Copy paper 17
- Copy quantity 18
- Copy ratio 21

D

- Dark key 20
- Document feeder tray 18
- Drum cartridge
 - indicator 7, 40
 - replacement 29

E

- Enlargement 21
- Exposure adjustment 20

F

- Features 4
- Fixed copy ratio 21
- Fusing unit release lever 6, 35

I

- Initial settings 16
- Installation
 - location 8
 - TD cartridge 12

L

- Light key 20
- Loading copy paper 13

M

- Maintenance 31
- Manual exposure 20
- Manual feeding 22
- Misfeed removal
 - fusing area 35
 - lower paper feed area 37
 - paper feed area 35
 - SPF 38
 - transport area 36
- Moving instructions 45

N

- Names
 - operation panel 7
 - part 6

O

- ON LINE indicator 7
- Operation panel
 - initial settings 16
 - part names 7
- Options 44
- Original cover 6
- Original guides 18
- Original table 6

P

- Packed components 10
- Paper
 - loading 13
 - special 17
 - specifications 17
- Paper feed area 35
- Paper output tray 6
- Paper output tray extension 6, 18
- Paper size 17
- Paper transport area 36
- Paper tray 6
- Part names 6
- Photo mode 7, 20
- Power cord 10, 15
- Power on 16
- Power save modes 25, 26
- Power switch 6, 16
- Preheat mode 25, 26
- Print key 18
- Protective packing materials 11

R		T	
Ready indicator	7	TD cartridge	
Reduction	21	- indicator	7, 40
Replacement		- installation	12
- drum cartridge	29	- replacement	28
- TD cartridge	28	Toner save mode	25
S		Total number of copies	27
Screw	11, 14	Transfer charger	6, 32
Single pass feeder (SPF)	18	Troubleshooting	39
Special paper	17	Two-sided copying	23
Specifications		U	
- copier	42	User maintenance	
- paper	17	- cabinet	31
SPF	18	- original cover	31
Status indicators	40	- original table	31
Supply		- transfer charger	32
- life	44	Z	
- part number	44	Zoom	21
- storage	44		

WARNING:
 FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment.

Note:
 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SERVICE INFORMATION

If a Problem Occurs

Most operational questions can be answered by referring to the Operation Manual. Also, for your convenience, you will find answers to most frequently asked questions on our website at www.sharp-usa.com. You can also email your service questions to www.digitalcopiersupport@sharpsec.com. Should you require further assistance, call Sharp at 1-630-378-3590. A Customer Relations Specialist will assist you. Before your call, please be ready to provide the model number of your Product, Serial Number, Date of Purchase, description of the problem, and a valid Credit Card Number (should it be required).

How Exchange is Obtained

A replacement unit in exchange for your copier is provided directly by Sharp to any U.S. location. You will be required to provide consent for acceptance of an exchange unit and provide credit card authorization. At that time, Sharp will ship to you, at no cost, an exchange for your defective Product. The exchange unit we ship to you will be new or remanufactured. Upon your receipt of the exchange unit, packing and shipping instructions will be enclosed for you to return the defective unit. Upon Sharp's receipt of the defective unit, your credit card hold will be released.

How Warranty Repair Service is Obtained

If you prefer that we repair your unit instead of replacing it, our Customer Relations Specialists at 1-630-378-3590 will explain how to obtain warranty repair service. **Please be sure to retain the original packaging materials in order to facilitate shipment.** The shipment of the defective unit will be at your expense; please be sure it is insured and packaged securely. Upon repair of your unit, Sharp will promptly return it at no cost to you at any U.S. location.

What You Must Do

Your Product is designed to perform with a minimum amount of user maintenance. However, you are responsible for the required user maintenance described in the Operation Manual. This requires user maintenance including replacement of the TD cartridge and drum cartridge, cleaning of the unit and transfer charger, removal of dust and foreign matter, clearing of paper misfeeds, and proper routine and preventive maintenance.

Service After Expiration of Warranty Coverage

Should you require service repair after warranty coverage has expired, contact Sharp at 1-630-378-3590 for information.

END-USER LIMITED WARRANTY

SHARP ELECTRONICS CORPORATION warrants to the first end-user purchaser that this Sharp brand product (the "Product"), when shipped in its original container, will be free from defective workmanship and materials, and agrees that it will, at its option, either repair the defect or replace the defective Product or part thereof with a new or remanufactured equivalent at no charge to the purchaser for parts or labor for the period(s) set forth below.

This warranty does not apply to any appearance items of the Product nor to the additional excluded item(s) set forth below nor to any Product the exterior of which has been damaged or defaced, which has been subjected to improper voltage or other misuse, abnormal service or handling, or which has been altered or modified in design or construction.

In order to enforce the rights under this limited warranty, the purchaser should follow the steps set forth below and provide proof of purchase to the servicer.

To the extent permitted by applicable state law, the warranties set forth herein are in lieu of, and exclusive of, all other warranties, express or implied. Specifically, ALL OTHER WARRANTIES OTHER THAN THOSE SET FORTH ABOVE ARE EXCLUDED. ALL EXPRESS AND IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR USE, AND FITNESS FOR A PARTICULAR PURPOSE ARE SPECIFICALLY EXCLUDED. If, under applicable state law, implied warranties may not validly be disclaimed or excluded, the duration of such implied warranties is limited to the period(s) from the date of purchase set forth below.

Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein, or to extend the duration of any warranties beyond the time period described herein on behalf of Sharp.

The warranties described herein shall be the sole and exclusive warranties granted by Sharp and shall be the sole and exclusive remedy available to the purchaser. Correction of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of Sharp to the purchaser with respect to the Product, and shall constitute full satisfaction of all claims, whether based on contract, negligence, strict liability or otherwise. In no event shall Sharp be liable, or in any way responsible, for any damages or defects in the Product which were caused by repairs or attempted repairs performed by anyone other than an authorized servicer. Nor shall Sharp be liable or in any way responsible for any incidental or consequential economic or property damage. Some states do not allow limits on warranties or on remedies for breach in certain transactions; in such states, the limits herein may not apply.

Model Specific Section

Your Product Model Number & Description:

AL-1020/1220/1250/1521 Digital Laser Copier
(Be sure to have this information available when you need service for your Product.)

Warranty Period for this Product:

Three (3) years from date of purchase except for the toner and developer cartridge and the drum cartridge supplied with the Product, which are warranted for fifteen (15) days from date of purchase.
Any Disk media supplied with the Product is warranted for replacement only and limited to ninety (90) days from date of purchase (Model AL-1250 only).

Additional Item(s) Excluded from Warranty Coverage (if any):

The warranty does not apply to defects or damage resulting from improper or inadequate maintenance by the purchaser (see Operation Manual) or the use of non-genuine Sharp Toner & Developer and Drum Cartridges.

Printer Interface Cable (Model AL-1250 only).

Software (Model AL-1250 only, see Software License Sheet)

Where to Obtain Service:

Service is available in the United States from Sharp. You may ship in your Product for repair or replacement. Replacement units may be remanufactured, rather than new, but your original limited warranty will continue for the remainder of your original warranty period or ninety (90) days from the date we send the replacement unit to you, whichever is longer.

What to do to Obtain Service:

Call Sharp at 1-630-378-3590 to obtain a Return Authorization Number and shipping instructions. A technician will work with you on the phone and if it is determined that your Product needs service, you will have your choice of having your unit repaired or replaced to any U.S. location. Be sure to have **Proof of Purchase** available.

TO OBTAIN PRODUCT INFORMATION, CALL 1-800-BE-SHARP.

SHARP[®]

SHARP ELECTRONICS CORPORATION

Sharp Plaza, Mahwah, New Jersey 07430-2135.

www.sharp-usa.com

SHARP CORPORATION