


User's manual

Advanced Electronic/Air Column PC-2200



CONTENTS

| | | |
|-----------|--------------------------------|-----------|
| 1. | INTRODUCTION | 4 |
| 1.1 | GENERAL INFORMATIONS | 4 |
| 1.2 | TECHNICAL SPECIFICATIONS | 5 |
| 1.3 | COLUMN DESCRIPTION | 6 |
| 1.4 | KEYPAD CONFIGURATION | 7 |
| 1.5 | STATUS PANEL | 8 |
| | | |
| 2. | INSTALLATION | 9 |
| 2.1 | MECANICAL INSTALLATION | 9 |
| 2.2 | ELECTRICAL INSTALLATION | 10 |
| | | |
| 3. | HOW TO USE IT | 11 |
| 3.1 | SWITCHING ON THE COLUMN | 11 |
| 3.2 | PROGRAMMING A SIMPLE MEASURE | 12 |
| 3.3 | PROGRAMMING A PART (EXAMPLE 1) | 13 |
| 3.4 | PROGRAMMING A DIAMETER | 14 |
| 3.5 | PROGRAMMING A PART (EXAMPLE 2) | 15-16 |
| 3.6 | THE CLASSIFICATION MENU | 17 |
| 3.7 | THE RS232 INTERFACE | 18 |
| 3.8 | LAYOUT OF IN/OUTPUT | 19 |
| | | |
| 4. | FUNCTIONS | 20 |
| 4.1 | THE MEASURING MODE FUNCTIONS | 20 |
| 4.2 | THE PROGRAMMING MODE FUNCTIONS | 21-22 |
| 4.3 | CH-BUS APPLICATIONS | 23 |
| 4.4 | CH-BUS MECANICAL INSTALLATION | 23 |
| 4.5 | PROGRAMMING THE CH-BUS | 24 |
| | | |
| 5. | PNEUMATIC INSTALLATION | 25 |
| 5.1 | THE A/D CONVERTER | 26 |
| 5.2 | HOW TO ADJUST THE CONVERTER | |
| | | |
| 6. | GENERAL INITIALIZATION | 27 |
| 6.1 | TABLE OF DEFAULT VALUES | 27 |
| 6.2 | APPLICATION EXAMPLES | 28 |
| 6.3 | DIAMETER/THICKNESS | 28 |
| 6.4 | BLANK SETTING SHEET | 29 |
| | | |
| 7. | GENERAL | 30 |
| 7.1 | TROUBLESHOOTING | 30 |
| 7.2 | MAINTENANCE | 31 |
| | | |
| 8. | MAP | 32 |

CHAPTER 1. INTRODUCTION

1.1 GENERAL INFORMATION'S

- The column PC-2200 is an instrument system that measures and displays (ID, OD, Length related measurements such as misalignment, and others) in automotives, machines, electrical and electronic parts, and determines whether the measured results are acceptable or not.
- The user can identify the measurement values correctly and easily as the display is made on a 3-Color LED Bar (green, orange, red) and a DOT MATRIX LED (8 characters) mounted in the front side.
- The Status panel, positioned on the front bottom side, shows the current operating status in regards to the unit system (mm/inch) and operating sets (M1, M2, M3, M4) using 12 LED's (green).
- The Keypad being consisted as 9 membrane switches mounted below the Status panel, performs the user program such as the system setup. The user can build the program environment that can satisfy the user's requirements to the maximum in easy and free way through the Keypad such as selecting the menu and setting up the required variables.
- The rear upper side is configured as the AC power switch, Fuse holder, AC power inlet and Aux. power supply, and therefore, it can use several units of PC-2200 through connecting with only one unit of power supply. The AC power of AC 110/230 V and 50/60 Hz is applied. You can select the power source of 110V/230V (default : 230V) by inserting the connector on the DC power PC board that is fixed on the upper side of the system inside.
- With the 5 external interfaces on the rear center side, the column can be connected to an other column, or to PC, or Printer, or CNC.
- You can use the HBT, LVDT and CAPACITIVE probes as electronic system or AIR probes through the analog board on the rear bottom side. You should install the analog board (PCB) dedicated by the type of probe.
- The PC-2200 is an integrated high quality measurement system that performs various measurements and display functions such as inter-channel operations up to 4 channels and dynamic mode in addition to the simple displays of measurement values.

1.2 TECHNICAL SPECIFICATIONS

General :

| | |
|----------------------------------|----------------------------------|
| Storage temperature | : -40° à +60°C / - 40°F to 140°F |
| Operational temperature | : 0° à +50°C / 32°F to 122°F |
| Power supply | : 110/230V (AC) 50/60Hz |
| Max. consumption | : 40VA |
| Fuse | : 2A delayed |
| MTBF (Mean Time between Failure) | : >100'000 heures |
| Average life of display | : > 50'000 heures |

Performance :

| | |
|---|---------------------------|
| Time for stabilization after switching ON | : 5 minutes |
| Measurement thermal drift | : 100PPM/°C |
| Measuring thermal drift between channels | : 30PPM/°C |
| PC-2200 equipped with HBT-LVDT-CAP probes | : +/- 0.5% +/- Resolution |
| Measuring accuracy at 20°C / 68°F | |
| Resolution = 0.1 µm / .00001" | |
| PC-2200 equipped with Air System in the nominal conditions | |
| Working range | : +/- 50µm / .002" |

Interfaces :

Analog **OUTPUT**

| | |
|----------------------|--------------------|
| Range | : ± 5.0V F.S. |
| Full scale accuracy: | : 2% of full scale |

Serial **OUTPUT (RS 232)**

| | |
|--------------------------------|---------------------|
| Type | : RS 232 C |
| Transmission speed (Baud rate) | : 4800, 9600, 19200 |
| Word length | : 7 ou 8 |
| Parity control | : NONE, EVEN, ODD |

DC-OUT Photo couplers


| | |
|-----------------|--------|
| Maximal Voltage | : 30V |
| Maximal Tension | : 60mA |

Weight and Dimensions :


Column

| | |
|-------------------------------------|--|
| Dimensions (height * width * depth) | : 450 * 57 * 215mm / 17.7"*2.16"*8.66" |
| Weight | : 4.12 kg |


1.3 COLUMN DESCRIPTION



1.4 KEYPAD CONFIGURATION



1.5 STATUS PANEL



Chapter 2 : Installation

2.1 MECHANICAL INSTALLATION


Fix the column on the aluminum base and lock it with the 2 screws (M6 x16)
Connect the power supply cable (A) .
Connect the probe cable to the analog board (B)
Switch (ON) I.



2.2 ELECTRICAL INSTALLATION

Switching the Voltage from 230V to 110V.

Remove the cover by unscrewing the 8 screws.
Move the connector A on 110V.



Chapter 3 : HOW TO USE IT

3.1 SWITCHING ON THE COLUMN

To start the first time, we advise to make a general **RESET** .

Press  + **ON** simultaneously,


| | | | | | | | |
|---|---|---|---|---|---|---|---|
| T | S | M | - | C | O | R | P |
|---|---|---|---|---|---|---|---|

 ⇒

| | | | | | | | |
|---|---|---|---|---|--|--|--|
| R | E | S | E | T | | | |
|---|---|---|---|---|--|--|--|

 ⇒

| | | | | | | | |
|---|--|---|---|---|---|---|---|
| - | | 1 | . | 0 | 4 | 0 | 0 |
|---|--|---|---|---|---|---|---|

Do not release your pressure on  before the message **RESET** appears on the display, then a test program will start.

The default parameters are :

CHANNEL : Source : **Ext. - CH-A** Ratio :**1.000** Direc. **+**
 MEASURE : **M1** – Bar :**Bottom** B.fact. **1.00** – Range : \pm **1.0mm** Sens : **1.000** Resol.:**0.001mm** – Func: **A** –
 Mode: **STATIC**
 SPEC. : M1 – NOMI. **000.0000** - -TOLER **-0.8000** - +TOLER **+0.8000** –APPROCH **-0.8000**
 + APPROCH : **+0.8000**
 MASTER : M1 - -MASTER **+00.0000** +MASTER **+00.0000**
 CLASS : **OFF**
 RS232 : SPEED **9600**, DATA **8**, PARITY **N**, TERM **CRLF**, RTS **ON**, PRINT **BRIEF**, RSMODE **PRINT**
 ID NO. **000**
 ETC : GENERAL UNIT **METRIC**, DISPLAY **mm**, INPUT **HBT**, P/W PROGRAM **0000**, CALIBR **OFF**
 AVERAGE BAR **003**, DIGIT **003**, A/D **10**
 VERSION **V2.00**

The above parameters are the default values so , it is necessary to modify the values according to your application.

Description of functions per menu.

CHANNEL : Select the source and the probes used with ratio and measuring direction.

MEASURE : Select the starting position of the bar, Bar factor, Range of the Bar, Resolution of the digital display. Combination of probes, Static or Dynamic measuring mode.

SPEC. : Store the nominal size, the upper tolerance, the lower tolerance, the upper warning limit, the lower warning limit of the component to be measured.

MASTER : Store the lower master value and the upper master value used.

CLASS : Active the classification mode, class number, starting value, class range.

RS232 : Select the transmission speed, word length, parity control, end of characters, request to send signal, printing mode, simplex or duplex mode, identity number.

ETC

GENERAL : Select the unit (mm or inch), type of display (mm or um), type of probes used, program and calibration password.



AVERAGE : Select the bar sensitivity , the display sensitivity, the analog board sensitivity.

VERSION : Show the software version.

3.2 PROGRAMMING A SIMPLE MEASURE

Example N°1

Measure a component with a HBT probe connected to channel A.



USING a HBT probe, we do not use the calibration, this mode will be explained in a subsequent chapter.

Step n°1 is to place the probe into a correct position to be able to get the maximum range and the minimum deviation.

Place the master 20.0000 mm on the stand, place the probe into position.

Press simultaneously **A D J U S T** **C H - A** **- 1 . 0 5 0 0**

Move the probe down to the electro-mechanical zero, **- 0 . 0 0 1 0** then,

approximately stop around zero, lock the probe . Press to escape to the measuring mode.

Parameters to be changed for exemple number 1

MEASURE : **M1** –Range : $\pm 0.01mm$ Resol.:**0.0002mm** –

SPEC. : M1 – NOMI. **020.0000** - -TOLER **-0.0050** - +TOLER **+0.0050** –APPROCH **-0.0040**
+ APPROCH : **+0.0040**

3.3 PROGRAMMING A PART (EXAMPLE 1)

Press **Prog** (2 sec) **P/W** 0000 **Enter** **CHANNEL** **MEASURE** **Enter**

M1 **Enter** **SELECT** **BAR** **B.FACT**

RANGE **Enter** \pm 1.0 ∇ \pm 0.5 ∇ \pm 0.1 ∇

\pm 0.05 ∇ \pm 0.01 ∇ \pm 0.005 **Enter** **RANGE**

SENS. **RESOL.** **Enter** 0.001 ∇ 0.0005 ∇

0.0002 **Enter** **RESOL.** **Esc** **M1** **Esc** **MEASURE**

SPEC. **Enter** **M1** **Enter** **NOMI.** **Enter** 000.0000

S **M** 020.0000 **Enter** **NOMI.** **-TOLER** **Enter**

- 0.8000 **S** **M** **-** 0.0050 **Enter** **-TOLER**

+TOLER **Enter** **+** 0.8000 **S** **M** **+** 0.0050 **Enter**


+TOLER **-APPRO** **Enter** **-** 0.8000 **S** **M**

- 0.0040 **Enter** **-APPRO** **+** APPRO **Enter** **+** 0.8000

S **M** **+** 0.0040 **Enter** **Esc** **M1** **Esc** **SPEC.**

Esc **SAVE?** **Enter**


Place the master 20.0000mm in contact with the probe then press **Preset** **PRESET** **Enter**



The warning limit should be smaller than the tolerance.

3.4 PROGRAMMING A DIAMETER

Measurement of a diameter with a HBT probe connected to channel **A**.



Step n°1 is to place the probe into its location to be able to get the maximum range and the minimum deviation.

Place the measuring head of 15.0000 mm in the master,

Press simultaneously



Move the probe down to the electro-mechanical zero. then,

approximately stop around zero, lock the probe. Press **Esc** to escape to the measuring mode.

Parameters to be changed for exemple number 2

CHANNEL : Direc. -

MEASURE : **M1** -Range : ± 0.005 mm Resol.: 0.0001 mm -

SPEC. : M1 - NOMI. **015.0000** - -TOLER **-0.0020** - +TOLER **+0.0020** -APPROCH **-0.0016**
+ APPROCH : **+0.0016**

MASTER : **M1** - -Master : **14.9988**mm - +Master : **15.0026**mm

3.5 PROGRAMMING A PART (EXAMPLE 2)

Press **Prog** (2 sec) **P/W 0000** **Enter** **CHANNEL** **Enter** **SOURCE** **▶**

CH-A **▶** **Enter** **RATIO** **▶** **DIREC** **▶** **Enter** **+** **▶** **▼**

---- **▶** **Enter** **DIREC** **▶** **Esc** **CH-A** **▶** **Esc** **CHANNEL** **▶**

MEASURE **▶** **Enter** **M1** **▶** **Enter** **SELECT** **▶** **BAR** **▶** **▶**

B.FACT **▶** **RANGE** **▶** **Enter** **±** **1.0** **▼** **±** **0.5** **▶** **▼**

± **0.1** **▶** **▼** **±** **0.05** **▶** **▼** **±** **0.01** **▶** **▼** **±** **0.005** **▶** **Enter**

RANGE **▶** **SENS.** **▶** **RESOL.** **▶** **Enter** **0.001** **▶** **▼**

0.0005 **▶** **▼** **0.0002** **▶** **▼** **0.0001** **▶** **Enter** **RESOL.** **▶** **Esc**

M1 **▶** **Esc** **MEASURE** **▶**

SPEC. **▶** **Enter** **M1** **▶** **Enter** **NOMI.** **▶** **Enter** **000.0000**

◀ **M** **▶** **▼** **015.0000** **Enter** **NOMI.** **▶** **-TOLER** **▶** **Enter**

- **0.8000** **◀** **M** **▶** **▼** **-** **0.0020** **Enter** **-TOLER** **▶**

+TOLER **▶** **Enter** **+** **0.8000** **◀** **M** **▶** **▼** **+** **0.0020** **Enter**

+TOLER **▶** **-APPRO** **▶** **Enter** **-** **0.8000** **◀** **M** **▶** **▼**

- **0.0016** **Enter** **-APPRO** **▶** **+** **APPRO** **▶** **Enter** **+** **0.8000**

◀ **M** **▶** **▼** **+** **0.0016** **Enter** **Esc** **M1** **▶** **Esc** **SPEC.** **▶**

MASTER **▶** **Enter** **M1** **▶** **Enter** **-MASTER** **▶** **Enter** **015.0000**

◀ **M** **▶** **▼** **014.9988** **Enter** **-MASTER** **▶** **+** **MASTER** **▶** **Enter**

015.0000 **◀** **M** **▶** **▼** **015.0026** **Enter** **+** **MASTER** **▶** **Esc**

M1 **▶** **Esc** **MASTER** **▶** **Esc** **SAVE?** **▶** **Enter**

The Calibration

Example N°2

The parameters are now stored. The automatic calibration can be started.



Cal CAL.M1 Enter CAL. _ _ _ _ place the measuring head in the lower master. Enter

CAL. _ _ _ _ place the measuring head in the upper master. Enter _ _ _ 0 . 9 8 1

The sensitivity is calculated automatically.

If the message MIN OVER appears, that means that the value between the two masters is bigger than the calculated value.

Cal CAL.M1 ▶ MODULE ◀▶ Enter M1 _ _ _ _ _ ▶ Enter CAL% _ _ _ _ ▶

VALUE _ _ _ _ Enter _ _ _ _ 0 0 0 %

NONE : All sensitivity values are allowed.

000% : The sensitivity value will not be accepted if the calculated value during the calibration is different of the stored value.

XXX% : The sensitivity value will not be accepted if the calculated value during the calibration is different of XXX% of the stored value.

After the calibration the measurement can start.

3.6 THE CLASSIFICATION MENU

CLASS


The class menu is use separately.

Example : Pin dia. 10mm - 0 +0.100mm to be classify by steps of 0.005mm , in 20 classes, starting from 10.0000 mm.

Prog (2 sec) **P/W** **Enter** **CHANNEL** **MEASURE**
SPEC. **MASTER** **CLASS** **Enter** **SELECT** **Enter**
OFF **M** **ON** **Enter** **SELECT** **NUMBER** **Enter**
010 **S** **M** **020** **Enter** **NUMBER**
START **Enter** **000.0000** **S** **M** **010.0000** **Enter**
START **STEP** **Enter** **000.0100** **S** **M**
000.0050 **Enter** **STEP** **Esc** **CLASS** **Esc** **SAVE?** **Enter**
OK **C** **---** measure the first pin **C** **5**

The first pin will be classify into class 5, the printed value will be between 10.025 and 10.030 mm

To escape from the Class menu, SELECT. **OFF**



3.7 THE RS232 INTERFACE

The RS 232 Interface allow to send the data to a printer, as well to a PC, also allow to modify the stored parameters in the column with the help of the communicator software.

How to connect a PC-2200 to a **serial** printer.





The most important to connect a column to a printer or a computer are the adjustment of parameters.
The first values to be known are the serial printer parameters.
e.g. : **4800** bauds, **7** bits, parity **even**.


How to setup the column ?

Prog (2 sec.) P/W 0000 Enter CHANNEL ▶ MEASURE ▶
SPEC. ▶ MASTER ▶ CLASS ▶ RS232 ▶ Enter
SPEED ▶ Enter 9600 ▶ M 4800 ▶ Enter SPEED ▶
DATA ▶ Enter 8 ▶ M 7 ▶ Enter DATA ▶
PARITY ▶ Enter NONE ▶ M EVEN ▶ Enter PARITY ▶
TERM ▶ Enter CR ▶ M CRLF ▶ Enter TERM ▶
RTS ▶ Enter ON ▶ ▼ OFF ▶ Enter RTS ▶
PRINT ▶ Enter BRIEF ▶ ▼ FULL ▶ Enter PRINT ▶
RSMODE ▶ Enter PRINT ▶ Enter RSMODE ▶
ID NO. ▶ Enter 000 ▶ Enter ID NO. ▶ Esc RS232 ▶ Esc
SAVE? ▶ Enter 2.0000

Press ◀ SEND



3.8 LAYOUT OF IN/OUTPUT



| Pin# | Functions |
|------|-------------------|
| 1 | * (not connected) |
| 2 | Rxd |
| 3 | Txd |
| 4 | Vcc |
| 5 | Gnd |
| 6 | * (not connected) |
| 7 | Rts |
| 8 | Cts |
| 9 | Gnd |

(Connection of a serial printer or a PC)

In the case of RS232-RS mode is set as "PRINT", the display value is printed via the RS232 by connecting the pins #1,9 of external control..

If the RS 232-RS mode is set as « HOST », the communication become (duplex) and allow to use the communicator software.

| Pin# | Functions |
|------|--------------------------|
| 1 | RS 232 sortie (0.5 sec.) |
| 2 | Current value display |
| 3 | Dynamic/Static |
| 4 | M1->M2->M3->M4 |
| 5 | Hold measure |
| 6 | * (not connected) |
| 7 | * (not connected) |
| 8 | * (not connected) |
| 9 | Gnd |

The external control functions can be activate by connecting the pins les pôles #1 à 5 to the pin #9(GND) according to the required function.

The following functions can be activated by connecting the pin #9 to pin # (foot pedal, box)
 #1)Print the display value. #2) Change dynamic mode to static mode
 #3) reset the dynamic mode (min.,max.) #4) Move the measurement mode (M1) to M2,.....
 M2,M3,M4 should be active. (ON)
 #5) Freeze the displayed value.

Active the preset mode by connecting the pin #3 and #4 simultaneously

| Pin# | Functions |
|------|---------------------|
| 1 | O.K (Green) |
| 2 | * (not connected) |
| 3 | Approach + (Orange) |
| 4 | +N.G (Red) |
| 5 | * (not connected) |
| 6 | Approach - (Orange) |
| 7 | -N.G (Red) |
| 8 | Drive Voltage |
| 9 | Gnd |

Active the contact with GND pin#9 when the value of the bar is positioned in the corresponding range pins #1, 3, 4, 6, 7) .

This application show if the product is acceptable or not with an external unit such as lamps, relays, by powering the pins #8,9.

The power supply stops when the class menu is OFF.

| Pin# | Functions |
|------|-------------------|
| 1 | D/A sortie |
| 2 | * (not connected) |
| 3 | * (not connected) |
| 4 | * (not connected) |
| 5 | * (not connected) |
| 6 | * (not connected) |
| 7 | * (not connected) |
| 8 | * (not connected) |
| 9 | Gnd |

Analog output of the display (Signal Voltage (pin #1 and #9).

The voltage range is : $\pm 4.3V$ with ± 1 mm, or ± 0.05 inch


| Pin# | Functions |
|------|-------------------|
| 1 | Ex-A |
| 2 | Ex-B |
| 3 | Ex-C |
| 4 | Ex-D |
| 5 | Gnd |
| 6 | * (not connected) |
| 7 | * (not connected) |
| 8 | * (not connected) |
| 9 | Gnd |

This function is used when the signal of a probe should we shifted to a second column.

Application : Example : Display a maximum value on 1 column and a minimum value to the other column with only one probe..


The analog board of the importing value column should be disconnected,

Circuit connection diagram (OUTPUT)



E= External voltage










CH-Bus diagram




Chapter 4 Functions

Definition of keypad functions per menu

4.1 THE MEASURING MODE FUNCTIONS

| | | | Functions | Functions |
|--|---|---|-------------|------------------------|
|  | | Access to programming mode | | |
|  | | « M » Change the measure number (M1-M2) only if M2,M3,M4 (ON) | M1-M2-M3-M4 | |
|  | | | | |
|  | | « S » send the displayed value to RS232 | | |
|  | | No function in measuring mode | | |
|  | | No function in measuring mode | | |
|  | | Simultaneously when switching (ON) | RESET | |
|  | Preset Value M1 00.0000 | Access to preset mode | PRESET | Maximum +/- 0.999mm |
|  | Calibration Module M1, M2, M3,M4 CAL% | Cal. Min__ et Max__ Cal. by measure M1, M2, M3, M4 NONE, Value 000% | | |

4.2 THE PROGRAMMING MODE FUNCTIONS

| | Menu | Sub-menu | Functions | Functions | Functions | Functions |
|---|----------------|----------|------------------------------|--------------|-----------|-----------|
|  | CHANNEL | SOURCE | EXT. CH-BUS | | | |
| | | CH-A | RATIO | 1.000 | DIRECT | + / - |
| | | CH-B | RATIO | 1.000 | DIRECT | + / - |
| | | CH-C | RATIO | 1.000 | DIRECT | + / - |
| | | CH-D | RATIO | 1.000 | DIRECT | + / - |

SOURCE : **EXT.** Select the source of the probe on the analog board on this column.

CH-BUS. Select the source of the probe from another column thru the CH-BUS.

CH-A : Select the ration value and measuring direction for the channel A.

CH-B : Select the ration value and measuring direction for the channel B.

CH-C : Select the ration value and measuring direction for the channel C.

CH-D : Select the ration value and measuring direction for the channel D.

| | Menu | Sub-menu | Functions | Functions | Functions |
|------|----------------|------------|-----------|--|---|
| Prog | MEASURE | M1 | ON | BAR B. FACT RANGE SENS. RESOL. FUNC MODE | BOTTOM,CENTER,-10->0 1.00 $\pm 1.0, \pm 0.5, \pm 0.1, \pm 0.05, \pm 0.01,$ ± 0.005 1.000 0.01,0.005,0.001,0.0005,0.0002,0.0001 A,B,C,D,A+B,C+D,(A+B)-C,(A+B+C)/3 (A+B+C+D)/4,(A+B)-(C+D) STATIC,MAXIMUM,MINIMUM, (M+m)/2,(M-m)/2,M-m. |
| | | M2, M3, M4 | ON/OFF | | |

M1,M... : Select the characteristics of the measuring result M1, it is possible to store 4 different measuring results (M1,M2,M3,M4). M2,M3,M4 should be (ON)

BAR : Select the starting position of the LED-bar, (BOTTOM) start from bottom, (CENTER) start from center, (-10->0) start from an excentred position in case of being out of range with the LED – bar.

B.FACT : Bar multiplication factor, giving the possibility of adjusting several column at the same level.

RANGE : Select the measuring range.

SENS : Calculated sensitivity value after calibration.

RESOL : Select the measuring resolution..

FUNC : Select the setting of measurement.

MODE : Select the dynamic or static mode

| | Menu | Sub-menu | Functions | Functions | Functions |
|------|--------------|----------|-----------|---|--|
| Prog | SPEC. | M1 | | NOMI. -TOLER +TOLER -APPRO +APPRO | 000.000 -0.8000 +0.8000 -0.8000 +0.8000 |
| | | M2 | | | |

M1,M.. : Store in measurement number 1, 2, 3, 4.

NOMI. : Store the nominal size

-TOLER : Store the lower tolerance.

+TOLER : Store the upper tolerance.

-APPRO : Store the lower warning limit.

+APPRO :Store the upper warning limit.

| | Menu | Sub-menu | Functions | Functions | Functions |
|------|---------------|----------|--------------------|-----------|--------------------------------------|
| Prog | MASTER | M1 | -MASTER +MASTER | | +000.0000 +000.0000 |
| | | M2 | | | |

M1,M... : Store in measurement number 1, 2, 3, 4.

-MASTER : Store the lower master value.

+MASTER :Store the upper master value.

| | Menu | Sub-menu | Functions | Functions | Functions |
|------|--------------|----------|-----------|-------------------------|--|
| Prog | CLASS | Select | ON/OFF | NUMBER START STEP | 000 +00.0000 0.0000 |

CLASS : Switch ON or OFF the class menu.
NUMBER : Store the number of classes to be used.
START : Store the starting nominal value
STEP : Store the step value of the class.

| | Menu | Sub-menu | Functions | Functions | Functions |
|------|--------------|---|-----------|-----------|--|
| Prog | RS232 | SPEED DATA PARITY TERM RTS PRINT RSMODE ID NO. | | | 4800,9600,19200 BAUDS 7,8 Bits NONE, ODD,EVEN CRLF / CR ON / OFF BRIEF / FULL PRINT /HOST 000 |

SPEED : Select the transmission speed .
DATA :Select the word length.
PARITY : Select the parity control : none, even, odd
TERM : Select the end characters : CR, CRLF
RTS : (Request to Send) request to send a signal
PRINT : Select the printing mode (BRIEF) send the minimum data, (FULL) send a complete protocol.
RS232 : Select the RS232 Interface in mode PRINT(Simplex) or HOST (Duplex)
ID NO : Store an identity number.



| | Menu | Sub-menu | Functions | Functions | Functions |
|------|------------|---------------------------------------|--|--------------------|--|
| Prog | ETC | GENERAL AVERAGE VERSION | UNIT DISPLAY INPUT P/W BAR DIGIT A/D | PROGRAM CALIBR. | METRIC, INCH mm ou um HBT,LVDT,CAP,AIR 0000 ON/OFF 0000 003 005 10 V 2.00 TMI |

GENERAL : Select the measuring unit, select the display (mm or um), select the analog board used, store a PROGRAM password and a CALIBRATION password.
AVERAGE : BAR, Store a filter for the bar.
 DIGIT, Store a filter for the digital display.
 A/D, Store a filter for analog/digital converter.
VERSION : Show the software version.

4.3 CH-BUS APPLICATIONS

The CH-BUS channel transfer a signal to another column.


Application.



We need to see 2 values simultaneously.

1. Diameter 15.0000mm
2. max T.I.R 0.002mm

4.4 CH-BUS MECHANICAL INSTALLATION



The receptive column should have the analog board removed.

4.5 PROGRAMMING THE CH-BUS

The column n°1 should be programmed like example n°2 to page n°15

Programming column n°2

Prog P / W 0 0 0 0 Enter CHANNEL Enter SOURCE Enter
 EXT. CH-BUS Enter SOURCE Esc CHANNEL
 MEASURE Enter M1 Enter SELECT BAR
 B. FACT RANGE Enter ± 1.0 ± 0.5
 ± 0.1 ± 0.05 ± 0.01 ± 0.005 Enter
 RANGE SENS. RESOL. Enter 0.001
 0.0005 0.0002 0.0001 Enter RESOL.
 FUNC. MODE Enter STATIC
 M-m Enter MODE Esc M1 Esc MEASURE
 SPEC. Enter M1 Enter NOMI. Enter 000.0000
 S M 000.0000 Enter NOMI. -TOLER Enter
 - 0.0000 S M - 0.0000 Enter -TOLER
 +TOLER Enter + 0.0000 S M + 0.0020 Enter
 +TOLER -APPRO Enter - 0.8000 S M
 - 0.0016 Enter -APPRO +APPRO Enter + 0.8000
 S M + 0.0016 Enter Esc M1 Esc SPEC. Esc
 SAVE? Enter 000.0000

Column n°1

15.0000


Diameter
15.0000 mm

Column n°2

0.0020

T.I.R
0.0020 mm

Chapter 5 PNEUMATIC INSTALLATION



Hose nipple for the air probe.

1. Fix the column and the converter on the aluminum base
2. Fix the hose of the air probe to nipple of converter.



Connection cable PC-2332.

3. Connect the cable PC-2332 between the converter and the analog board.
4. Connect the air supply to the hose nipple on the converter.

Open the air pressure up to minimum 3 bars.


5.1 THE A/D CONVERTER




< Front View >





<Rear View >






<Internal View >



(View)




(Diagram)

-  Pressure source
-  Filter
-  Connection

- ② Pressure regulator
- ③ Preliminary nozzles
- ⑥ Measuring adjustment nozzles (Measuring zero setting)
- ⑦ Pressure transducer
- ⑨ Measuring head.
- ⑩ Connector (9-pin)
- ⑪ Pressure setting hole

The programming procedure is similar to an electronic probe.

5.2 How to adjust the converter



It is necessary to adjust the converter for an optimal use

1) Pressure adjustment (STANDARD : 2 +/- 0.1 bar)

- Connect the gauge « C »
- Connect the air input « D » (Min. 3 bar)
- Adjust the pressure by turning the screw « B ».

The pressure by default is 2 bars (Factory setting)


- Connect the converter and the column with the cable (904-2332)
- Connect the gauge « C »
- Disconnect the pressure « D ».
- Press the PRESET key « 0.0000 ».
- Place the plug gauge into the min master
- Connect again the air input « D » (3 bars min.)
- Adjust the screw A

Example : Master value Min : -0.020mm

Displayed value : -0.020 mm

In the case of a bad adjustment, the measuring range can be smaller.

Chapter 6 GENERAL INITIALIZATION


- (1) Function: Initialize all stored data to the default values. **CAUTION** : All your stored data will be erased. Press  + **ON**

6.1 TABLE OF DEFAULT VALUES

| Menu | Sub-menu | Selection | Functions | Choice | Default value | |
|---------|----------|-----------|-------------------|---|-----------------|--|
| CHANNEL | SOURCE | EXT. | | | EXT. | |
| | | CH-BUS | | | | |
| | | CH-A | RATIO | 0 - 5.000 | 1.000 | |
| | | | DIREC. | + / - | + | |
| | | CH-B | RATIO | 0 - 5.000 | 1.000 | |
| | | | DIREC. | + / - | + | |
| | | CH-C | RATIO | 0 - 5.000 | 1.000 | |
| | | | DIREC. | + / - | + | |
| MEASURE | M1 | SELECT | ON | | ON | |
| | | | BAR | BOTTOM CENTER -10->0 | BOTTOM | |
| | | | B.FACT | -5.00 / +5.00 | 1.00 | |
| | | | RANGE | ± 1.0mm ± 0.5mm ± 0.1mm ± 0.05mm ± 0.01mm ± 0.005mm | ± 1.0mm | |
| | | | SENS. | Valeur calculée après étalonnage | 1.000 | |
| | | | RESOL. | 0.01, 0.005, 0.001, 0.0005, 0.0002, 0.0001 | 0.001 | |
| | | | FUNC | A, B, C, D, A+B, C+D, (A+B)-C, (A+B+C)/3, (A+B+C+D)/4 (A+B)-(C+D) | A | |
| | | | MODE | STATIC, MAXIMUM, MINIMUM,(M+m)/2, (M-m)/2, M-m | STATIC | |
| SPEC. | M1 | NOMI. | 000.0000 | | 000.000 | |
| | | -TOLER. | -0.8000 | | -0.8000 | |
| | | +TOLER | +0.0000 | | +0.8000 | |
| | | -APPRO | -0.0000 | | -0.8000 | |
| | | +APPRO | +0.0000 | | +0.8000 | |
| MASTER | M1 | -MASTER | +00.0000 | | +00.0000 | |
| | | +MASTER | +00.0000 | | +00.0000 | |
| CLASS | SELECT | OFF / ON | | | OFF | |
| | | NUMBER | 1 - 100 | | 010 | |
| | | START | +00.0000 | | +00.0000 | |
| | | STEP | 0.0000 | | 0.0100 | |
| | | | | | | |
| RS232 | | SPEED | 19200, 9600, 4800 | | 9600 | |
| | | DATA | 7, 8 | | 8 | |
| | | PARITY | None,even,Odd | | None | |
| | | TERM | CR,CRLF | | CRLF | |
| | | RTS | ON / OFF | | ON | |
| | | PRINT | BRIEF, FULL | | BRIEF | |
| | | RSMODE | PRINT,HOST | | PRINT | |
| | | ID NO. | 000 | | 000 | |
| | | | | | | |
| | | | | | | |
| ETC | GENERAL | UNIT | METRIC,INCH | | METRIC | |
| | | DISPLAY | mm, um | | mm | |
| | | INPUT | HBT,LVDT,CAP,AIR | | HBT | |
| | | PW | PROGRAM | | 0000 | |
| | | | CALIBR. | ON/OFF | OFF | |
| | | AVERAGE | BAR | 000 | 003 | |
| | | | DIGIT | 000 | 003 | |
| | | | A/D | 00 | 10 | |
| | | | VERSION | | V2.00 | |

6.2 APPLICATION EXAMPLES

6.3 DIAMETER/THICKNESS



<Specification of the measure>

| |
|-------------------------------|
| External diameter : 10.000 mm |
| Lower tolerance : - 20µm |
| Upper tolerance: +20µm |
| Lower warning limit: - 15µm |
| Upper warning limit: +15µm |
| Lower master : 9.980 mm |
| Upper master : 10.020 mm |
| Unit : mm |

| Menu | Sub-menu | Selection | Function | Choice | Values | | |
|---------|----------|-----------|---------------|---|------------------|------|---------|
| CHANNEL | SOURCE | EXT. | | | EXT. | | |
| | | CH-BUS | | | | | |
| | | CH-A | RATIO | 0 - 5.000 | 1.000 | | |
| | | | DIREC. | + / - | + | | |
| | | CH-B | RATIO | 0 - 5.000 | 1.000 | | |
| | | | DIREC. | + / - | + | | |
| | | CH-C | RATIO | 0 - 5.000 | 1.000 | | |
| | | | DIREC. | + / - | + | | |
| | | CH-D | RATIO | 0 - 5.000 | 1.000 | | |
| | | | DIREC. | + / - | + | | |
| MEASURE | M1 | SELECT | ON | | ON | | |
| | | | BAR | BOTTOM CENTER -10->0 | CENTER | | |
| | | | B.FACT | -5.00 / +5.00 | 1.00 | | |
| | | | RANGE | ± 1.0mm ± 0.5mm ± 0.1mm ± 0.05mm ± 0.01mm ± 0.005mm | ± 0.05mm | | |
| | | | SENS. | Valeur calculée après étalonnage | 1.000 | | |
| | | | RESOL. | 0.01, 0.005, 0.001, 0.0005, 0.0002, 0.0001 | 0.001 | | |
| | | | FUNC | A, B, C, D, A+B, C+D, (A+B)-C, (A+B+C)/3, (A+B+C+D)/4 (A+B)-(C+D) | A+B | | |
| | | | MODE | STATIC, MAXIMUM, MINIMUM,(M+m)/2, (M-m)/2, M-m | STATIC | | |
| | | SPEC. | M1 | NOMI. | 000.0000 | | 010.000 |
| | | | | -TOLER. | -0.8000 | | -0.0200 |
| +TOLER. | +0.0000 | | | | +0.0200 | | |
| -APPRO | -0.0000 | | | | -0.0150 | | |
| +APPRO | +0.0000 | | | | +0.0150 | | |
| MASTER | M1 | -MASTER | +00.0000 | | +9.9800 | | |
| | | +MASTER | +00.0000 | | +10.0200 | | |
| CLASS | SELECT | OFF / ON | | | OFF | | |
| | | NUMBER | 1 - 100 | | 010 | | |
| | | START | +00.0000 | | +00.0000 | | |
| | | STEP | 0.0000 | | 0,0100 | | |
| | | RS232 | SPEED | 19200, 9600, 4800 | | 9600 | |
| | | | DATA | 7, 8 | | 8 | |
| RS232 | | PARITY | None,even,Odd | | None | | |
| | | TERM | CR,CRLF | | CRLF | | |
| | | RTS | ON / OFF | | ON | | |
| | | PRINT | BRIEF, FULL | | BRIEF | | |
| | | RSMODE | PRINT,HOST | | PRINT | | |
| | | ID NO. | 000 | | 000 | | |
| | | ETC | GENERAL | UNIT | METRIC,INCH | | METRIC |
| | | | | DISPLAY | mm, um | | mm |
| | | | | INPUT | HBT,LVDT,CAP,AIR | | HBT |
| | | | | P/W | PROGRAM | | 0000 |
| | CALIBR. | | | ON/OFF | OFF | | |
| AVERAGE | BAR | | | 000 | 003 | | |
| | DIGIT | | | 000 | 003 | | |
| | A/D | | | 00 | 10 | | |
| VERSION | | | | | V2.00 | | |

6.4 BLANK SETTING SHEET

<Specification of the measure>

| | |
|--------------------|---|
| <p>Application</p> | <p>Nominal size : Lower tolerance: Upper tolerance: Lower warning limit: Upper warning limit: Lower master : Upper master: Unit : mm</p> |
|--------------------|---|

<Initialisation>

| Menu | Sub-menu | Selection | Function | Choice | Values | | |
|---------|----------|------------|------------------|---|-------------------|--|--|
| CHANNEL | SOURCE | EXT. | | | | | |
| | | CH-BUS | | | | | |
| | | CH-A | RATIO | 0 - 5.000 | | | |
| | | | DIREC. | + / - | | | |
| | | CH-B | RATIO | 0 - 5.000 | | | |
| | | | DIREC. | + / - | | | |
| | | CH-C | RATIO | 0 - 5.000 | | | |
| | | | DIREC. | + / - | | | |
| | | CH-D | RATIO | 0 - 5.000 | | | |
| | | | DIREC. | + / - | | | |
| MEASURE | M1 | SELECT | ON | | | | |
| | | | BAR | BOTTOM CENTER -10->0 | | | |
| | | | B.FACT | -5.00 / +5.00 | | | |
| | | | RANGE | ± 1.0mm ± 0.5mm ± 0.1mm ± 0.05mm ± 0.01mm ± 0.005mm | | | |
| | | | SENS. | Valeur calculée après étalonnage | | | |
| | | | RESOL. | 0.01, 0.005, 0.001, 0.0005, 0.0002, 0.0001 | | | |
| | | | FUNC | A, B, C, D, A+B, C+D, (A+B)-C, (A+B+C)/3, (A+B+C+D)/4 (A+B)-(C+D) | | | |
| | | | MODE | STATIC, MAXIMUM, MINIMUM,(M+m)/2, (M-m)/2, M-m | | | |
| | | SPEC. | M1 | NOMI. | 000.0000 | | |
| | | | | -TOLER. | -0.8000 | | |
| +TOLER | +0.0000 | | | | | | |
| -APPRO | -0.0000 | | | | | | |
| +APPRO | +0.0000 | | | | | | |
| MASTER | M1 | -MASTER | +00.0000 | | | | |
| | | +MASTER | +00.0000 | | | | |
| CLASS | SELECT | OFF / ON | | | | | |
| | | NUMBER | 1 - 100 | | | | |
| | | START | +00.0000 | | | | |
| | | STEP | 0.0000 | | | | |
| | | RS232 | | SPEED | 19200, 9600, 4800 | | |
| | | | | DATA | 7, 8 | | |
| | | | | PARITY | None,even,Odd | | |
| | | | | TERM | CR,CRLF | | |
| | | | | RTS | ON / OFF | | |
| | | | PRINT | BRIEF, FULL | | | |
| | RSMODE | PRINT,HOST | | | | | |
| | ID NO. | 000 | | | | | |
| ETC | GENERAL | UNIT | METRIC,INCH | | | | |
| | | DISPLAY | mm, um | | | | |
| | | INPUT | HBT,LVDT,CAP,AIR | | | | |
| | | P/W | PROGRAM | | | | |
| | | | CALIBR. | ON/OFF | | | |
| | | AVERAGE | BAR | 000 | | | |
| | | | DIGIT | 000 | | | |
| | | | A/D | 00 | | | |
| | | | VERSION | | | | |

Chapter 7 General

7.1 TROUBLESHOOTING

| Default | Actions |
|---|--|
| The digital display is off. | Le fuse is out of order, (2A) |
| The bar is off. | Le fuse is out of order, (2A) |
| The digital display is not counting or show wrong values. | Check if the probe connected is compatible with the analog board. |
| The function M2 , M3, M4 do not work | Les fonctions M2, M3, M4 must be turned ON MEASURE menu. |
| La calibration is refused « OVER MINIMUM » | One or few data are not compatible between the specification values and the master values. |

7.2 MAINTENANCE

Remember that it is a measuring instrument
Take care of it.

Take notice that this user's manual is in relation with the software version V.2.00

