



**Model 560-197-1  
56000 Data Rate Clock and Distribution System Chassis  
(Single AC Power Supplies)  
Manual**

**SECTION ONE**

- 1. FUNCTIONAL DESCRIPTION
  - 1.1. PURPOSE OF EQUIPMENT
    - 1.1.1. PHYSICAL SPECIFICATIONS
    - 1.1.2. ENVIRONMENTAL SPECIFICATIONS
    - 1.1.3. POWER SPECIFICATIONS
    - 1.1.4. CONNECTOR SPECIFICATIONS
    - 1.1.5. CARD LOCATION/COMPATIBILITY CONSTRAINTS
    - 1.1.6. CARD SLOT ALLOCATION TABLE
  - 1.2. CERTIFICATIONS
    - 1.2.1. CE COMPLIANT
    - 1.2.2. UR AND C-UR RECOGNIZED

**SECTION TWO**

- 2. INSTALLATION AND OPERATION
  - 2.1. REMOVAL AND INSTALLATION
  - 2.2. OPERATION
  - 2.3. SETUP
  - 2.4. PREVENTIVE MAINTENANCE
    - 2.4.1. INSPECTION
    - 2.4.2. CLEANING
  - 2.5. CORRECTIVE MAINTENANCE
    - 2.5.1. FRONT/REAR CARDS and POWER SUPPLIES
    - 2.5.2. POWER ENTRY MODULE

**SECTION THREE**

- 3. THEORY OF OPERATION
  - 3.1. GENERAL INFORMATION
  - 3.2. HARDWARE DESCRIPTION
    - 3.2.1. POWER DISTRIBUTION
    - 3.2.2. SIGNAL DISTRIBUTION

**SECTION FOUR**

- 4. DETAILED DRAWINGS
  - 4.1. 560-197-1 DETAILED DRAWINGS / BILL OF MATERIALS

# SECTION ONE

## 1. FUNCTIONAL DESCRIPTION

### 1.1 PURPOSE OF EQUIPMENT

The TrueTime Model 560-197-1 Data Rate Clock and Distribution System (DRC) Chassis supports DRC-compatible cards. It provides 17 front slots for function cards, 17 rear slots for input/output cards, and one front slot for a power supply. The chassis contains a backplane for inter-card communication, common-signal bussing, and power distribution. These signals are discussed in detail in SECTION THREE below.

This version of the chassis is supplied with one AC input Power Supply. For future reference, it is useful to record card locations in the Card Slot Allocation Table. See specific manual for detailed information on any particular card.

#### 1.1.1 PHYSICAL SPECIFICATIONS

Dimensions: 19" w X 5.22" h X 14" d (48 cm X 13 cm X 36 cm)  
Weight: Approximately 13 pounds (6 kg)

#### 1.1.2 ENVIRONMENTAL SPECIFICATIONS

Operating Temp: 0° to +50°C  
Storage Temp: -40° to +85°C  
Humidity: Up to 95% max., relative, non-condensing  
Cooling Mode: Convection  
Altitude: Sea level to 10,000 ft

#### 1.1.3 POWER SPECIFICATIONS

See specific Power Supply manual.

#### 1.1.4 CONNECTOR SPECIFICATIONS

Location: Power Entry Module  
Mating Connector: IEC320 Connector

#### 1.1.5 CARD LOCATION/COMPATIBILITY CONSTRAINTS

See specific manual and/or Card Compatibility Matrix.

1.1.6 CARD SLOT ALLOCATION TABLE

SLOT	FRONT	REAR
1 <sup>1</sup>		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18 (19)	Blank Panel Blank Panel	
20 (21)	Power Supply, AC -48 VDC	Power Entry, AC Input

NOTES:

1. Slot 1 is left-most when viewed from front of chassis.

## 1.2 CERTIFICATIONS

### 1.2.1 CE COMPLIANT

This unit is CE compliant. See the Declaration of Conformity at the front of this manual. Note the conditions for acceptability listed on the Declaration.

### 1.2.2 UR AND C-UR RECOGNIZED

This unit is UR and C-UR recognized. The conditions for acceptability include the requirement that the unit be installed in a rack or other device which provides adequate bottom containment. Other conditions for acceptability may be established by the power supplies used in the unit. See the manual sections regarding the power supplies.

# SECTION TWO

## 2. INSTALLATION AND OPERATION

### 2.1 REMOVAL AND INSTALLATION

At initial installation, mount chassis to allow for vertical air-flow for convection cooling.

If it becomes necessary to replace any card in the chassis, follow this procedure:

**CAUTION:** Individual components and assemblies within the chassis are sensitive to static discharge. Whenever installing or removing cards, the person performing the replacement should use proper static discharge procedures, including a standard personnel ESD grounding device (e.g. grounded wrist-strap) and ESD protective packaging.

All cards are hot-swappable. It is not necessary to turn off chassis power during removal or insertion of cards. Refer to specific card manual for the effect of input-signal and/or adjacent card hot-swapping.

Refer to specific manual section for card location constraints and card setup information. (Except for power supply slots 18 through 21, there are few restrictions on card location.)

To remove card, loosen the captive retaining hardware at the top and bottom of the assembly, then firmly pull on the handle (or on any connector on rear panel adapter cards) at the bottom of the card. Slide the card free of the frame. Refer to the SETUP section for any required switch settings; or, set them identically to the card being replaced. Reinstall the card in the frame by fitting it into the card guides at the top and bottom of the frame and sliding it in slowly, avoiding contact between bottom side of card and adjacent card front panel, until it mates with the connector. Seat card firmly to avoid contact bounce. Secure the retaining screws at the top and bottom of the card assembly.

### 2.2 OPERATION

Connect system power via rear Power Entry Modules (see Power Supply manual section for connector pinout). The chassis is intended to be continuously powered; there are no power switches. See individual manuals for operation of specific cards.

## 2.3 SETUP

If the chassis is configured with an interface card using INPUT 1 through 8, **SETUP IS REQUIRED**. The termination impedance for INPUT 1 through 8 **MUST** be set to match the characteristics of the signal source. If the timing signal is sourced by a 50 ohm driver, the 50 ohm terminator **MUST** be enabled. If the signal is sourced by a high impedance driver (e.g. 600 ohm), the 50 ohm terminator **MUST** be disabled. This is done by enabling or disabling a 50 ohm terminator using a DIP switch located on the backplane at rear Slot 16.

To enable or disable the 50 ohm terminator, **DISCONNECT EXTERNAL POWER** to avoid personal injury and equipment damage, then remove the cards in rear Slots 16 and 17. Using a small-bladed 4-inch screwdriver or similar tool, set each DIP switch position ON/OFF according to the following chart:

INPUT	SW1	ON	OFF
1	1	50Ω	>1kΩ
2	2	50Ω	>1kΩ
3	3	50Ω	>1kΩ
4	4	50Ω	>1kΩ
5	5	50Ω	>1kΩ
6	6	50Ω	>1kΩ
7	7	50Ω	>1kΩ
8	8	50Ω	>1kΩ

## 2.4 PREVENTIVE MAINTENANCE

A systematic preventative maintenance routine can reduce the possibility of a malfunction. This routine should include inspection and cleaning of the instrument.

### 2.4.1 INSPECTION

Exercise care when handling this equipment. It contains sensitive parts that can be damaged by improper handling. Do not touch connector pin surfaces because of the danger of static discharge, also deposits on contact surfaces can cause corrosion, resulting in equipment damage or failure. Inspect the unit for damaged components, loose or frayed connections, and corrosion on metal surfaces. If damage is found, correct it immediately.

### 2.4.2 CLEANING

Accumulations of dust and dirt can impair cooling and cause performance degradation. The equipment may be cleaned by the use of a vacuum cleaner or compressed air, and if the problem is bad enough, with a cloth dampened with clean water and a mild detergent. Thoroughly rinse cloth

with clean water after washing and wipe off washed areas to remove any residue. Be careful not to get water into switches or potentiometers. Thoroughly dry the equipment with compressed air, and/or time permitting, by air drying.

## 2.5 CORRECTIVE MAINTENANCE

### 2.5.1 FRONT/REAR CARDS AND POWER SUPPLY

Refer to specific manual for information regarding suspect card.

### 2.5.2 POWER ENTRY MODULE

Power Entry Module trouble-shooting is covered in the specific Power Supply manual. However, should it be required, the Power Entry Module schematic is part of the chassis drawing included in section Four of this manual.

# SECTION THREE

## 3. THEORY OF OPERATION

### 3.1 GENERAL INFORMATION

This section contains a detailed description of the chassis implementation. Refer to the schematics in SECTION FOUR.

### 3.2 HARDWARE DESCRIPTION

The chassis incorporates a backplane for signal/power distribution and a Power Entry Module for delivering input power to the power supply. Front Slots 1 through 17 support various function cards. Rear Slots 1 through 17 support various I/O cards. Front Slots 18/19 can hold another (redundant) power supply as an option. They are covered by blank panels when the option is not selected. Slots 20/21 hold a power supply, which receives input power from the Power Entry Module.

#### 3.2.1 POWER DISTRIBUTION

Input power is delivered to the power supply via the Power Entry Module. The Power Entry Module incorporates an input connector and fuse appropriate to the associated Power Supply.

The Power Supply applies filtering and transient protection to the input power. Power is input at a specific voltage level, depending on the type of Power Supply installed; however, it is always delivered to the chassis backplane at -48 VDC. The -48 VDC power on the backplane is floating with respect to ground (GND). Each card installed in the chassis contains a local, internally-isolated, DC-to-DC converter. The output of each local power supply is referenced to signal GND on each card. Signal GND is distributed throughout the chassis via a ground plane on the backplane. Signal GND and Chassis GND are connected together via a connector on the backplane and also at the I/O card output connectors.

Hot swapping is supported by various features incorporated into the chassis. Of primary concern is the possibility of static-discharge into backplane signal lines during card insertion. This is minimized by extended ground pins located at each end of the backplane connector on front cards, forcing any static build-up to discharge into GND. These also assure that the card has a solid ground reference prior to signal pins contacting the backplane. Static is controlled on rear cards by a partial ground plane that extends to the extreme edge of the card, allowing static to discharge into the chassis during card insertion.

The effects of power supply transients are minimized by the isolation provided by local DC-to-DC converters. Another aspect of hot-swapping concerns CPU bus activity. This is discussed in paragraph 3.2.2.3.



## 3.2.2 SIGNAL DISTRIBUTION

There are three categories of signals on the backplane. These are bussed frequency distribution signals, bussed timing distribution signals, and bussed inter-card communication signals.

### 3.2.2.1 FREQUENCY DISTRIBUTION SIGNALS

The bussed frequency distribution signals are delivered on the backplane via 50 ohm matched-impedance traces, each terminated with a 50 ohm resistor. These are always driven by cards located at or near Slot 1, since the terminator is located at Slot 17. These three signals, REF A, REF B, and REF C (labeled FREQ A, B, and C on the schematic), are used to deliver reference frequencies to each slot. All cards that drive REF A, B, or C are AC-coupled to the backplane. The signals on REF A, B, and C are 1-5 Vpp, squarewave or sinewave.

### 3.2.2.2 TIMING DISTRIBUTION SIGNALS

The bussed timing signals, INPUTS 1 through 8, are delivered on the backplane via 50 ohm matched-impedance traces. Each can be terminated with a 50 ohm resistor by enabling sections of SW1. These are always driven via cards located at or near Slot 1, since the terminator is located at Slot 17.

The characteristics of the signal on INPUT 1 though 8 vary according to the requirements of installed card(s) using that particular signal.

### 3.2.2.3 INTER-CARD COMMUNICATION SIGNALS

The bussed inter-card communication signals include Fault, Data, Address, and Control signals used by the Fault Monitor CPU. These signals are bussed to every slot. There are 19 Fault lines. These are outputs from function-cards and inputs to the CPU. Pin C25 at each slot is used for the Fault output. Pin C25 is connected to the appropriate Fault line at each slot, such that each function-card automatically drives the proper bussed Fault signal, which in turn is available to the CPU at any slot. Data, Address, and Control data-bus signals are used by the CPU to communicate with various function cards. The Control signals include STROBE, DIRECTION, and ENABLE. STROBE is used to gate read/write cycles. DIRECTION, which has a pull-down resistor on the backplane, must driven high by the CPU to generate a write cycle to a function card. ENABLE, which has a pull-down resistor and capacitor on the backplane, must charge up to a Logic 1 level from local CPU +5V before any function card will recognize a write-cycle. All signals are TTL-level. The Fault

lines have pull-ups on the Fault Monitor CPU, which forces unused Fault lines to the inactive state.

Hot-swapping of the CPU is supported for insertion by the RC time-constant built into ENABLE. It is supported during removal by the direct pull-down on DIRECTION. Note that data-bus hot-swapping effects are important only for write-cycles. Hot-swapping of the function cards is supported by the bus architecture: the Data lines are never driven by the function cards. This eliminates the possibility of function card output buffers interfering with bus traffic during power-up. Also, all bussed input lines are isolated with series resistors to minimize bus-loading during power-up. For read-cycles the Data lines become additional address bits. All read-data is transferred to the CPU, 1 bit at a time, via the private Fault line. When there is no bus activity, the Fault line represents the composite fault status of each function card.

# SECTION FOUR

## 4. DETAILED DRAWINGS


4.1 560-197-1 DETAILED DRAWINGS / BILL OF MATERIALS

© Truetime, Inc. 1999 All Rights Reserved


PROPRIETARY NOTICE  
 THIS DOCUMENT, WHETHER PATENTABLE OR NON-PATENTABLE, SUBJECT MATTER, EMBODIES, PROPRIETARY AND CONFIDENTIAL INFORMATION AND IS THE EXCLUSIVE PROPERTY OF TRUETIME, INC. IT MAY NOT BE REPRODUCED, USED OR DISCLOSED TO OTHERS FOR ANY PURPOSE EXCEPT THAT FOR WHICH IT IS LOANED, AND IT SHALL BE RETURNED UPON DEMAND.

REVISIONS

REV	DESCRIPTION	DATE	APPROVED
A	CAR 1200	01/26/99	




FRONT VIEW




REAR VIEW

DETAIL-A



4-PIN MOLEX  
 (INSTALL ON 124)



USE 18 AWG WIRES

INSTALL SURROUNDS  
 ORIENTATED AS SHOWN  
 ALIGN WITH HOLE #2

2 THE FOLLOWING ARE ADDITIONAL ASSEMBLY INSTRUCTIONS:

- A. INSTALL THE BACK PLANE AND CONNECTOR SHELLS TO RAILS WITH SIX SCREWS, DO NOT TIGHTEN YET.
- B. INSTALL A PAIR OF SIDE PANELS SO THE BACK PLANE ASSEMBLY IS AT THE END OF THE SIDE PANEL, AND THE SCREW HEADS ARE FACING YOU. TIGHTEN THE FOUR SIDE SCREWS. THIS WILL SET THE SPACING BETWEEN THE RAILS HOLDING THE BACK PLANE. THE SIDE PANELS WILL PUSH THE RAILS TO THE OUTER TOLERANCE OF THE BACK PLANE CONNECTOR SCREW TOLERANCE.
- C. TIGHTEN THE SIX BACK PLANE SCREWS. INSTALL AND TIGHTEN THE REMAINING BACK PLANE SCREWS.
- D. REMOVE THE SIDE PANELS, AND REINSTALL IN THE PROPER LOCATION.

1 CHASSIS ASSEMBLY REFERENCE DWG 560-197-10 SHEETS 3 & 4.

CHASSIS (ITEM 1) TO BE ASSEMBLED USING SCHROFF (MANUFACTURER'S) ASSEMBLY INSTRUCTIONS. SUB:BACK.EMC.(#60845-001) PROVIDED WITH EACH KIT WITH THIS EXCEPTION:  
 MFR'S ITEM 9 OF KIT TO BE REAR MOUNTED  
 (SEE PANEL C & D ON 560-197-10 SHEET 3).  
 MFR'S ITEMS 11 & 12 OF KIT TO BE FRONT MOUNTED  
 (SEE PANEL C & D ON 560-197-10 SHEET 3).  
 NOTES: UNLESS OTHERWISE SPECIFIED

CONTRACT NO.

APPROVALS

DRAWN BY RNR

CHECKED BY

APPROVED BY

NEXT ASSY

DATE

2/98

1/97

**TrueTime**  
 Where Customer Satisfaction is our Highest Priority  
 2315 Duane Ct. Santa Rosa, CA 95407

TOP ASSEMBLY  
 DISTRIBUTION CHAS

SIZE CODE IDENT NO. DRAWING NO.

B 560-197-1

REV A

SCALE NONE


SHEET 1 OF 2

FILENAME: \560\197-1A  
 DATE: 01-26-99



POSITION SCREWS IN MOUNTING HOLES OFF CENTER, TOWARDS REAR.

### DETAIL B



**Truelime**  
 Where Customer Satisfaction is our highest priority.  
 2835 Duane Ct. Santa Rosa, CA 95407

SIZE CODE IDENT NO. DRAWING NO. REV

B 560-197-1 A

SCALE NONE SHEET 2 OF 2

FILENAME: \560\197-1B  
 DATE: 01-26-99

MAX \* BILL OF MATERIALS \* SINGLE-LEVEL EXPLOSION BY PART IDENTIFIER W/REFERENCE

PART IDENTIFIER	DESCRIPTION 1	DESCRIPTION 2	EFF DATE	ECN #	QTY/ASSY	REV UOM LVL	REFERENCE DESCRIPTION
560-197-1	SIGNAL DISTRIB CHASSIS	SINGLE AC PWR SUPPLY				EA	
0000-APPROVAL	PARTS LIST APPROVAL		000000		1.0000	EA	<i>DE 1/99</i>
0000-PL	PARTS LIST REV LEVEL		000000		1.0000	EA	REV A (01-29-99)
0000-PRINT	REFERENCE PRINT		000000		1.0000	EA	560-197-1 REV A
0001-PRINT	REFERENCE PRINT		000000		1.0000	EA	SEE BOM NOTE 1
0002-PRINT	REFERENCE PRINT		000000		1.0000	EA	
	SEE 560-197-10 SHEET 3 & 4						
201-088	RAIL HORIZONTAL REAR	SCHROFF 30819-088	000000		2.0000	EA	07
211-005	HANDLE SUBRACK 3U	SCHROFF 10501-005	000000		2.0000	EA	02
212-016	GUIDE RAIL	SCHROFF 60817-016	000000		34.0000	EA	18
223-010	CHASSIS KIT (HF)	SCHROFF 20845-284	000000		1.0000	EA	01 SEE BOM NOTE 1
223-144	NUT M2.5	SCHROFF #21100-144	000000		4.0000	EA	13
240-002-003	SCREW PH PN SS 2-56X3/8	AROW 0206MPP	000000		2.0000	EA	05
241-006-003	SCREW PH FH SS 6-32X 3/8	BUY/USE ONLY 100 DEGREE	000000		2.0000	EA	21
249-007	SCREW SH CH ZN M2.5X12	SCHROFF 21100-148	000000		38.0000	EA	19
249-234	SCREW PH FH M5X12	SCHROFF 21100-234	000000		4.0000	EA	16
249-M5X12	SCREW SK ZP M5X12	SCHROFF 21100-457	000000		12.0000	EA	17
251-006	NUT KEP SS 6-32 .250 HEX	KEPNUT SMALL PATTERN	000000		2.0000	EA	22
254-.312	WSHR SPLIT #4 SS	STAINLESS	000000		4.0000	EA	15
254-002	WSHR SPLIT #2	#2 LOCKWASHER	000000		2.0000	EA	06
269-004	WSHR FLAT NYL 4 1/16	1/4INCH OD	000000		4.0000	EA	14
315-018-010UL	WIRE 18 AWG BLACK UL1015	BELDEN 8918-10	000000		0.6000	FT	SEE WIRING
332-002	CORD POWER	BELDEN 17250	000000		2.0000	EA	SHIPPING KIT
363-2.0	FUSE 2A 250V 3AG SB	LITTELFUSE 313002	000000		2.0000	EA	SHIPPING KIT
385-096	CONN SHROUD FOR 96-P CONN	AMP 535074-1	000000		17.0000	EA	24
400-033	LABEL,DRC SLOT NUMBERS	MADE FROM 400-038	000000		0.0200	EA	26
400-034	LABEL,POWER SUP SLOTS	AC INPUT	000000		1.0000	EA	27
400-048	LABEL,UR/CUR SYMBOLS	MADE FROM 400-031	000000		1.0000	EA	31
400-051	LABEL,CE SYMBOL	MADE FROM 400-031	000000		1.0000	EA	30
402-007T	PIN 18-24 AWG	MOLEX 08-52-0113	000000		4.0000	EA	SEE WIRING
403-004T	CONN 4-P	MOLEX 26-03-4041	000000		1.0000	EA	SEE WIRING
560-1107	ASSY FRT PNL BLANK .8 IN.	SEE BOM NAV PART NOTES	000000		2.0000	EA	12
560-1181-6	ASSY,REAR PANEL	560-1181/HARDWARE ONLY	000000		2.0000	EA	11
560-1222-2	ASSY AC PWR ENTRY MODULE	PANEL/HARDWARE/WIRING	000000		1.0000	EA	28
560-1223	GUIDE RAIL FOR DRC P/S	FAB	000000		1.0000	EA	20
560-1225	CHASSIS KEY DRC P/S	FAB	000000		1.0000	EA	04
560-2188	PCB SHIELD (UL)	FAB	000000		2.0000	EA	25
560-5149-1	ASSY PWR SUP AC -48VDC	MADE FROM 560-2149	000000		1.0000	EA	29
560-5165	ASSY BACKPLANE (DISTRB)	MADE FROM 560-2165	000000		1.0000	EA	23
LA	LABOR ASSEMBLY COST HRS		000000		0	EA	
LT	LABOR TEST COST HOURS		000000		0	EA	
NOTE 1			000000		1.0000	EA	

THIS NOTE IS FOR REF ONLY. THE ITEMS TO BE MODIFIED WILL BE DONE BEFORE THE KIT GOES TO MANUFACTURING. 223-010 CHASSIS IS A BUYOUT KIT FROM SCHROFF. THE SIDE PANELS (ITEM 8, QTY 2, ON THE TRUETIME DRAWING) AND THE

MAX \* BILL OF MATERIALS \* SINGLE-LEVEL EXPLOSION BY PART IDENTIFIER W/REFERENCE

PART IDENTIFIER	DESCRIPTION 1	DESCRIPTION 2	EFF DATE	ECN #	QTY/ASSY	REV UOM LVL	REFERENCE	DESCRIPTION
-----------------	---------------	---------------	-------------	-------	----------	----------------	-----------	-------------

BRACKETS (ITEM 3, QTY 2, ON THE TRUETIME DRAWING) BOTH REQUIRE HOLES ADDED  
(FAB MODIFICATION). REF.PRINTS: 223-010-S(SIDE PNL) & 223-010-B(BRACKETS).