

**SerialXpress® SDX100**  
**Advanced Jitter Generation Tool**  
**For AWG5000/B & AWG7000/B Series**  
**Waveform Generators**  
**Programmer Manual**



077-0144-02

**Tektronix**



**SerialXpress® SDX100**  
**Advanced Jitter Generation Tool**  
**For AWG5000/B & AWG7000/B Series**  
**Waveform Generators**  
**Programmer Manual**

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

SerialXpress® SDX100 is a registered trademark of Tektronix, Inc.

MATLAB®. Copyright 1984 - 2008 The MathWorks, Inc.

SerialXpress Programmer Online Help, part number 076-0166-02.

### **Contacting Tektronix**

Tektronix, Inc.  
14200 SW Karl Braun Drive  
P.O. Box 500  
Beaverton, OR 97077  
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit [www.tektronix.com](http://www.tektronix.com) to find contacts in your area.

---

# Table of Contents

## Getting Started

Introduction .....	1-1
Documentation .....	1-2
Sample Program .....	1-3

## Syntax and Commands

Command Syntax .....	2-1
Command Groups .....	2-3
Batch Compile Group Commands .....	2-3
Base Data and Base Parameter Settings Group Commands .....	2-3
Compile Settings Group Commands .....	2-4
ISI and S-Parameter Group Commands .....	2-5
Licensing Group Commands .....	2-7
Periodic Jitter Group Commands .....	2-7
Pre-Emphasis Group Commands .....	2-7
Random Jitter Group Commands .....	2-8
Random Noise Group Commands .....	2-8
Save and Restore Setup Group Commands .....	2-8
Sequence Group Commands .....	2-9
SSC Group Commands .....	2-9
Waveform List Group Commands .....	2-10
Command Descriptions .....	2-11



---

# Getting Started





---

# Introduction

This online programmer manual provides information on how to use commands for remotely controlling your instrument. With this information, you can write computer programs that will perform functions such as setting the random jitter magnitude or SSC parameters.

The programmer manual is divided into sections. Each section describes a closely related group of commands. For example, all the random jitter commands are in one section and all the compilation options are grouped in another section.

SerialXpress programmatic interface works seamlessly with the AWG5000B and AWG7000B series instruments programmatic interface. It supports all the interfaces of the AWG5000B/AWG7000B series instruments. Using a single VISA or raw socket session, it is possible to communicate with both SerialXpress and AWG.

For information on the Remote Control, GPIB Parameters, LAN Parameters, Connecting to the Instrument using GPIB, and Setting up GPIB Communication, refer to the *AWG5000B and AWG7000B Series Arbitrary Waveform Generators Programmer Manual*.

## Documentation

In addition to this SerialXpress Programmer Online Guide, the following documentation is included with this application:

- SerialXpress Quick Start User Manual. The Quick Start User Manual has information about installing and operating your instrument.
- SerialXpress User Online Help. The online help provides in-depth operation and user interface help.

## Sample Program

The sample program illustrates methods you can use to control the arbitrary waveform generator. This program sends waveform data and then starts waveform generation. You can access the sample program from Windows Start menu. Select **All Programs > Tektronix > SerialXpress > PI Examples**.

This program is also included on the Document CD.



---

# Syntax and Commands



---

# Command Syntax

For information on the Syntax Overview, Command and Query Structure, Clearing the Instrument, Command Entry, Parameter Types, and SCPI Commands and Queries, refer to the *AWG5000B and AWG7000B Series Arbitrary Waveform Generators Programmer Manual*.





# Command Groups

## Batch Compile Group Commands

You can use the following commands to set the batch compile parameters.

**Table 2-1: Batch compile group commands**

<b>Command</b>	<b>Description</b>
<a href="#">SXPress:BCOMpile:PJ:ENABLE</a>	Enables or disables the batch compile setup for periodic jitter (Pj)
<a href="#">SXPress:BCOMpile:PJ:END</a>	Sets or returns the end value of Pj for batch compile
<a href="#">SXPress:BCOMpile:PJ:FREQuency&lt;n&gt;</a>	Sets or returns the value of Pj frequency for batch compile
<a href="#">SXPress:BCOMpile:PJ:INCRement</a>	Sets or returns the increment value of Pj for batch compile
<a href="#">SXPress:BCOMpile:PJ:STARt</a>	Sets or returns the start value of Pj for batch compile
<a href="#">SXPress:BCOMpile:RJ:ENABLE</a>	Enables or disables the batch compile setup for random jitter (Rj)
<a href="#">SXPress:BCOMpile:RJ:END</a>	Sets or returns the end value of Rj for batch compile
<a href="#">SXPress:BCOMpile:RJ:INCRement</a>	Sets or returns the increment value of Rj for batch compile
<a href="#">SXPress:BCOMpile:RJ:STARt</a>	Sets or returns the start value of Rj for batch compile

## Base Data and Base Parameter Settings Group Commands

You can use the following commands to set the base data and base parameters.

**Table 2-2: Base data and base parameter settings group commands**

<b>Command</b>	<b>Description</b>
<a href="#">SXPress:AMPLitude</a>	Sets or returns the amplitude of the waveform
<a href="#">SXPress:BDATa:FILE</a>	Sets or returns the user-defined pattern file to generate the waveform
<a href="#">SXPress:BDATa:PATtern</a>	Sets or returns the pattern to generate the waveform
<a href="#">SXPress:BDATa:STANdard</a>	Sets or returns the standard and pattern to generate the waveform
<a href="#">SXPress:BDATa:TYPE</a>	Sets or returns the base data type
<a href="#">SXPress:DCD:ENABLE</a>	Enables or disables the DCD parameter

**Table 2-2: Base data and base parameter settings group commands (cont.)**

<b>Command</b>	<b>Description</b>
<a href="#">SXPRess:DCD:VALue</a>	Sets or returns the DCD value of the pulse
<a href="#">SXPRess:DRATe</a>	Sets or returns the data rate
<a href="#">SXPRess:ENCode:ENCo8b10b:DISParity</a>	Sets or returns the disparity set for encoding
<a href="#">SXPRess:ENCode:ENCo8b10b:ENABle</a>	Enables or disables the 8B10B encoding on the base data pattern
<a href="#">SXPRess:ENCode:SCHeme</a>	Sets or returns the encoding scheme used on the base data pattern
<a href="#">SXPRess:FTIME</a>	Sets or returns the fall time of the pulse
<a href="#">SXPRess:IState:OFFSet</a>	Sets or returns the offset of the idle state waveform
<a href="#">SXPRess:IState:VALue</a>	Sets or returns the idle state value
<a href="#">SXPRess:MARKer&lt;n&gt;:CLOCK:FREQUency</a>	Sets or returns the frequency of marker data
<a href="#">SXPRess:MARKer&lt;n&gt;:TRIGger:LENGth</a>	Sets the beginning 'n' samples of the marker output to high
<a href="#">SXPRess:MARKer&lt;n&gt;:TYPE</a>	Sets or returns the type of the marker data
<a href="#">SXPRess:RFTYpe</a>	Sets or returns the step height of the rise or fall time
<a href="#">SXPRess:RTIME</a>	Sets or returns the rise time of the pulse
<a href="#">SXPRess:SCRamble:ENABle</a>	Enables or disables base pattern scrambling
<a href="#">SXPRess:SCRamble:RINit</a>	Sets or returns the scrambling seed value
<a href="#">SXPRess:SCRamble:POLYnomial</a>	Sets or returns the scrambling polynomial

## Compile Settings Group Commands

You can use the following commands to set the compile settings parameters.

**Table 2-3: Compile settings group commands**

<b>Command</b>	<b>Description</b>
<a href="#">SXPRess:COMPIle</a>	Compiles a waveform and adds it to the waveform list
<a href="#">SXPRess:COMPIle:BCOMpile:ENABle</a>	Enables or disables the batch compile state
<a href="#">SXPRess:COMPIle:BWEXpansion:ENABle</a>	Enables or disables the bandwidth expansion filter state
<a href="#">SXPRess:COMPIle:BWEXpansion:INTerleave</a>	Sets or returns the interleave state
<a href="#">SXPRess:COMPIle:BWEXpansion:ZERoing</a>	Sets or returns the zeroing state
<a href="#">SXPRess:COMPIle:SRATe</a>	Sets or returns the sampling rate
<a href="#">SXPRess:COMPIle:SRATe:AUTomatic</a>	Sets or returns the automatic option for sampling rate

Table 2-3: Compile settings group commands (cont.)

Command	Description
<a href="#">SXPress:COMPIle:TRANsfer:CHANnel</a>	Sets or returns the channel to which a compiled waveform is transferred
<a href="#">SXPress:COMPIle:TRANsfer:ENABle</a>	Enables or disables the automatic waveform transfer state

## ISI and S-Parameter Group Commands

You can use the following commands to set the ISI and S-Parameter parameters.

Table 2-4: ISI and S-Parameter group commands

Command	Description
<a href="#">SXPress:ISI:ENABle</a>	Enables or disables the ISI parameter state
<a href="#">SXPress:ISI:VALue</a>	Sets or returns the ISI magnitude
<a href="#">SXPress:SPARam:AGGRessor:CLOCK:FREQUency</a>	Sets or returns the clock frequency of the aggressor signal
<a href="#">SXPress:SPARam:AGGRessor:DIRectioN</a>	Sets or returns the aggressor direction relative to the direction of the victim
<a href="#">SXPress:SPARam:AGGRessor:PATtern:DRATe</a>	Sets or returns the data rate of the aggressor signal
<a href="#">SXPress:SPARam:AGGRessor:PATtern:NAME</a>	Sets or returns the name of the aggressor pattern file
<a href="#">SXPress:SPARam:AGGRessor:RTIME</a>	Sets or returns the rise time of the aggressor signal
<a href="#">SXPress:SPARam:AGGRessor:RXMinus:SElect</a>	Sets or returns the negative receiver port of the aggressor signal
<a href="#">SXPress:SPARam:AGGRessor:RXPLus:SElect</a>	Sets or returns the positive receiver port selection of the aggressor for the single-ended s8p file
<a href="#">SXPress:SPARam:AGGRessor:TXMinus:SElect</a>	Sets or returns the negative transmitter port of the aggressor signal
<a href="#">SXPress:SPARam:AGGRessor:TXPLus:SElect</a>	Sets or returns the positive transmitter port selection of the aggressor for the single-ended s8p file
<a href="#">SXPress:SPARam:AGGRessor:TYPE</a>	Sets or returns the type of the aggressor signal of the s8p file

**Table 2-4: ISI and S-Parameter group commands (cont.)**

<b>Command</b>	<b>Description</b>
SXPRESS:SPARAM:CASCADE:ENABLE	Enables or disables S-Parameter cascading
SXPRESS:SPARAM:CASCADE:FILE[n]:ENABLE	Enables or disables cascading for the specified cascading unit
SXPRESS:SPARAM:CASCADE:FILE[n]:NAME	Sets or returns the S-Parameter file for cascading
SXPRESS:SPARAM:ENABLE	Enables or disables the S-Parameter filter state
SXPRESS:SPARAM:EIGHTP:SELECTION	Sets or returns the 8-port selection of the S-Parameter filter
SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXMINUS	Sets or returns the S-Parameter port assignment of the RxMinus port
SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXPLUS	Sets or returns the S-Parameter port assignment of the RxPlus port
SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXMINUS	Sets or returns the S-Parameter port assignment of the TxMinus port
SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXPLUS	Sets or returns the S-Parameter port assignment of the TxPlus port
SXPRESS:SPARAM:FOURPORT:LAYOUT	Sets or returns the four port layout of the S-Parameter filter
SXPRESS:SPARAM:FOURPORT:TYPE	Sets or returns the four port type of the S-Parameter filter
SXPRESS:SPARAM:IFILTER:ENABLE	Enables or disables the inverse filter state of the S-Parameter
SXPRESS:SPARAM:IFILTER:FFILE	Sets the inverse filter file of the user S-Parameter filter
SXPRESS:SPARAM:SCALING	Sets or returns the ISI scaling of the S-Parameter filter
SXPRESS:SPARAM:TFILE	Sets the touchstone file of the S-Parameter filter
SXPRESS:SPARAM:TWOPORT:SELECTION	Sets or returns the two port channel location of the S-Parameter filter
SXPRESS:SPARAM:VICTIM:RXMINUS:SELECT	Sets or returns the negative receiver port of the victim signal
SXPRESS:SPARAM:VICTIM:RXPLUS:SELECT	Sets or returns the positive receiver port of the victim signal

Table 2-4: ISI and S-Parameter group commands (cont.)

Command	Description
<a href="#">SXPress:SPARam:VICTim:TXMinus:SElect</a>	Sets or returns the negative transmitter port of the victim signal
<a href="#">SXPress:SPARam:VICTim:TXPLus:SElect</a>	Sets or returns the positive transmitter port of the victim signal

## Licensing Group Commands

You can use the following commands to set the licensing options.

Table 2-5: Licensing group command

Command	Description
<a href="#">SXPress:OPTions?</a>	Returns the activated options

## Periodic Jitter Group Commands

You can use the following commands to set the periodic jitter parameters.

Table 2-6: Periodic jitter group commands

Command	Description
<a href="#">SXPress:PJ&lt;n&gt;:ENABle</a>	Enables or disables the periodic jitter parameter state
<a href="#">SXPress:PJ&lt;n&gt;:FREQuency</a>	Sets or returns the frequency of the periodic jitter
<a href="#">SXPress:PJ&lt;n&gt;:MAGNitude</a>	Sets or returns the magnitude of the periodic jitter
<a href="#">SXPress:PJ&lt;n&gt;:PHASe</a>	Sets or returns the phase of the periodic jitter

## Pre-Emphasis Group Commands

You can use the following commands to set the pre-emphasis parameters.

Table 2-7: Pre-emphasis group commands

Command	Description
<a href="#">SXPress:PREemphasis:ENABle</a>	Enables or disables the pre-emphasis parameter state
<a href="#">SXPress:PREemphasis:VALue</a>	Sets or returns the pre-emphasis value

## Random Jitter Group Commands

You can use the following commands to set the random jitter parameters.

**Table 2-8: Random jitter group commands**

Command	Description
<a href="#">SXPRess:RJ&lt;n&gt;:ENABle</a>	Enables or disables the random jitter parameter state
<a href="#">SXPRess:RJ&lt;n&gt;:FREQuency:END</a>	Sets or returns the end frequency of the random jitter frequency band
<a href="#">SXPRess:RJ&lt;n&gt;:FREQuency:STARt</a>	Sets or returns the start frequency of the random jitter frequency band
<a href="#">SXPRess:RJ&lt;n&gt;:MAGNitude</a>	Sets or returns the magnitude of the random jitter
<a href="#">SXPRess:RSEed:ENABle</a>	Enables or disables random seed state
<a href="#">SXPRess:RSEed:VALue</a>	Sets or returns the value of the random seed

## Random Noise Group Commands

You can use the following commands to set the random noise parameters.

**Table 2-9: Random noise group commands**

Command	Description
<a href="#">SXPRess:NOISe:ENABle</a>	Enables or disables the noise parameter state
<a href="#">SXPRess:NOISe:LOCation</a>	Sets or returns the location where the noise will be applied
<a href="#">SXPRess:NOISe:VALue</a>	Sets or returns the noise magnitude

## Save and Restore Setup Group Commands

You can use the following commands to set the save and restore parameters.

**Table 2-10: Save and restore setup group commands**

Command	Description
<a href="#">SXPRess:SDEFault</a>	Restores all the application parameters to their default values
<a href="#">SXPRess:SREStore</a>	Restores the parameter settings as in the setup file
<a href="#">SXPRess:SSAVe</a>	Saves the current application setup in a file

## Sequence Group Commands

Table 2-11: Sequence group commands

Command	Description
<a href="#">SXPress:MODE</a>	Sets or returns the current mode in which SerialXpress is running
<a href="#">SXPress:SEquence:ELEment:ADD</a>	Adds a new sequence element to the sequence table
<a href="#">SXPress:SEquence:ELEment:BCOMpile</a>	Enables or disables the batch compile state of the selected sequence element
<a href="#">SXPress:SEquence:ELEment:DELeTe</a>	Deletes the selected sequence element in the table
<a href="#">SXPress:SEquence:ELEment:GOTO:INDex</a>	Sets or returns the Go To target for the sequence element
<a href="#">SXPress:SEquence:ELEment:REPeat:COUnt</a>	Sets or returns the repeat count of the selected sequence element
<a href="#">SXPress:SEquence:ELEment:REPeat:MODE</a>	Sets or returns the repeat mode state of the selected sequence element
<a href="#">SXPress:SEquence:ELEment:WSTate</a>	Sets or returns the wait state of the selected sequence element
<a href="#">SXPress:SEquence:INDex</a>	Sets or returns the current sequence index
<a href="#">SXPress:SEquence:LENGth?</a>	Returns the current sequence length
<a href="#">SXPress:SEquence:WRAP:STATE</a>	Enables or disables the wrap between sequence elements state in the application

## SSC Group Commands

You can use the following commands to set the SSC parameters.

Table 2-12: SSC group commands

Command	Description
<a href="#">SXPress:SSC:CUStom:FILE</a>	Sets the SSC custom file
<a href="#">SXPress:SSC:DFDT</a>	Sets or returns the df/dt value of the SSC
<a href="#">SXPress:SSC:DFDT:DURation</a>	Sets or returns the df/dt duration value of the SSC
<a href="#">SXPress:SSC:DFDT:LOCation</a>	Sets or returns the df/dt location value of the SSC
<a href="#">SXPress:SSC:ENABle</a>	Enables or disables the SSC state
<a href="#">SXPress:SSC:FREQuency:DEViation</a>	Sets or returns the SSC frequency deviation
<a href="#">SXPress:SSC:FREQuency:MODulation</a>	Sets or returns the SSC frequency modulation
<a href="#">SXPress:SSC:SHAPE</a>	Sets or returns the SSC shape

**Table 2-12: SSC group commands (cont.)**

<b>Command</b>	<b>Description</b>
<a href="#">SXPRess:SSC:SPRead</a>	Sets or returns the SSC spread
<a href="#">SXPRess:SSC:USPRead:PERcentage</a>	Sets or returns the unequal spread percentage

## Waveform List Group Commands

You can use the following commands to set the waveform list parameters.

**Table 2-13: Waveform list group commands**

<b>Command</b>	<b>Description</b>
<a href="#">SXPRess:WFMName</a>	Sets the waveform name that is generated with next compile command
<a href="#">SXPRess:WAVEform:DELeTe</a>	Deletes the waveform from the waveform list
<a href="#">SXPRess:WAVEform:REName</a>	Renames the existing waveform
<a href="#">SXPRess:WAVEform:SAVE</a>	Saves the existing waveform
<a href="#">SXPRess:WAVEform:TRANsfer</a>	Transfers the waveform data from the application to the AWG



# Command Descriptions

## SXPRESS:AMPLITUDE

This command sets or returns the amplitude of the waveform. This value indicates the maximum and minimum values of the waveform samples. You can use this command to create a waveform whose amplitude is less than the minimum value that can be set on the AWG.

---

**NOTE.** *The amplitude set on the application is not same as the amplitude set on the instrument.*

---

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:AMPLITUDE <NR3> SXPRESS:AMPLITUDE?
<b>Arguments</b>	<NR3>  At SXPRESS:SDEFAULT, this returns 1.0 V.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:AMPLITUDE 1 sets the amplitude of the waveform to 1 volt.  SXPRESS:AMPLITUDE? returns 1.00000000E+000, indicating that the waveform amplitude is 1 volt.

## SXPRESS:BCOMPPILE:PJ:ENABLE

This command enables or disables the batch compile setup for periodic jitter.

Batch compile generates waveforms with the Pj values varying from start value to end value with specified increment. Each waveform will be generated with one of the four frequencies.

<b>Group</b>	Batch compile
<b>Syntax</b>	SXPRESS:BCOMPPILE:PJ:ENABLE <state> SXPRESS:BCOMPPILE:PJ:ENABLE?

**Related Commands** [SXPRess:BCOMpile:PJ:START](#), [SXPRess:BCOMpile:PJ:END](#),  
[SXPRess:BCOMpile:PJ:FREQuency<n>](#), [SXPRess:BCOMpile:PJ:INCRement](#)

**Arguments** <state>::=<Boolean>  
0 indicates False.  
1 indicates True.  
At SXPRess:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPRESS:BCOMPILE:PJ:ENABLE 1 enables the batch compile for Pj.  
SXPRESS:BCOMPILE:PJ:ENABLE? returns whether Pj will be batch compiled.

## SXPRess:BCOMpile:PJ:END

This command sets or returns the end value of the periodic jitter for batch compile.

**Group** Batch compile

**Syntax** SXPRess:BCOMpile:PJ:END <NR3>  
SXPRess:BCOMpile:PJ:END?

**Related Commands** [SXPRess:BCOMpile:PJ:ENABLE](#), [SXPRess:BCOMpile:PJ:START](#),  
[SXPRess:BCOMpile:PJ:INCRement](#), [SXPRess:BCOMpile:PJ:FREQuency<n>](#)

**Arguments** <NR3>  
At SXPRess:SDEFault, this returns 0.

**Returns** <NR3>

**Examples** SXPRESS:BCOMPILE:PJ:END 0.25 sets the end value of Pj to 0.15 UI for batch compile.  
SXPRESS:BCOMPILE:PJ:END? returns the end value of Pj for batch compile.

## SXPRESS:BCOMPILE:PJ:FREQUENCY<n>

This command sets or returns the value of the periodic jitter frequency for batch compile.

**Group** Batch compile

**Syntax** SXPRESS:BCOMPILE:PJ:FREQUENCY<n> <NR3>  
SXPRESS:BCOMPILE:PJ:FREQUENCY<n>?

**Related Commands** [SXPRESS:BCOMPILE:PJ:ENABLE](#), [SXPRESS:BCOMPILE:PJ:START](#),  
[SXPRESS:BCOMPILE:PJ:END](#), [SXPRESS:BCOMPILE:PJ:INCREMENT](#)

**Arguments** <NR3>  
At SXPRESS:SDEFAULT, this returns 0.  
The value of <n> ranges from 1 to 4.

**Returns** <NR3>

**Examples** SXPRESS:BCOMPILE:PJ:FREQUENCY1 100000 sets the Pj frequency1 to 100 KHz for batch compile.  
SXPRESS:BCOMPILE:PJ:FREQUENCY1? returns the frequency1 value of Pj for batch compile.

## SXPRESS:BCOMPILE:PJ:INCREMENT

This command sets or returns the increment value of the periodic jitter for batch compile.

**Group** Batch compile

**Syntax** SXPRESS:BCOMPILE:PJ:INCREMENT <NR3>  
SXPRESS:BCOMPILE:PJ:INCREMENT?

**Related Commands** [SXPRESS:BCOMPILE:PJ:ENABLE](#), [SXPRESS:BCOMPILE:PJ:START](#),  
[SXPRESS:BCOMPILE:PJ:END](#), [SXPRESS:BCOMPILE:PJ:FREQUENCY<n>](#)

<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 0.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:BCOMPILE:PJ:INCREMENT 0.01 sets the increment value of Pj to 0.01 UI for batch compile. SXPRESS:BCOMPILE:PJ:INCREMENT? returns the increment value of Pj for batch compile.

## SXPRESS:BCOMpile:PJ:START

This command sets or returns the start value of the periodic jitter for batch compile.

<b>Group</b>	Batch compile
<b>Syntax</b>	SXPRESS:BCOMpile:PJ:START <NR3> SXPRESS:BCOMpile:PJ:START?
<b>Related Commands</b>	<a href="#">SXPRESS:BCOMpile:PJ:ENABLE</a> , <a href="#">SXPRESS:BCOMpile:PJ:END</a> , <a href="#">SXPRESS:BCOMpile:PJ:INCREMENT</a> , <a href="#">SXPRESS:BCOMpile:PJ:FREQuency&lt;n&gt;</a>
<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 0.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:BCOMPILE:PJ:START 0.15 sets the start value of Pj to 0.15 UI for batch compile. SXPRESS:BCOMPILE:PJ:START? returns the start value of Pj for batch compile.

## SXPRESS:BCOMpile:RJ:ENABLE

This command enables or disables the batch compile setup for random jitter.

Batch compile generates waveform with Rj values varying from the start value to the end value with specified increment.

**Group** Batch compile

**Syntax** `SXPRESS:BCOMPILE:RJ:ENABLE <state>`  
`SXPRESS:BCOMPILE:RJ:ENABLE?`

**Related Commands** [SXPRESS:BCOMPILE:RJ:START](#), [SXPRESS:BCOMPILE:PJ:INCREMENT](#),  
[SXPRESS:BCOMPILE:PJ:FREQUENCY<n>](#)

**Arguments** `<state>::=<Boolean>`  
 0 indicates False.  
 1 indicates True.  
 At `SXPRESS:SDEFAULT`, this returns 0.

**Returns** `<state>`

**Examples** `SXPRESS:BCOMPILE:RJ:ENABLE 1` enables the batch compile for Rj.  
`SXPRESS:BCOMPILE:RJ:ENABLE?` returns whether Rj will be batch compiled.

## SXPRESS:BCOMPILE:RJ:END

This command sets or returns the end value of Rj for batch compile.

**Group** Batch compile

**Syntax** `SXPRESS:BCOMPILE:RJ:END <NR3>`  
`SXPRESS:BCOMPILE:RJ:END?`

**Related Commands** [SXPRESS:BCOMPILE:RJ:ENABLE](#), [SXPRESS:BCOMPILE:RJ:START](#),  
[SXPRESS:BCOMPILE:PJ:FREQUENCY<n>](#)

**Arguments** `<NR3>`  
 At `SXPRESS:SDEFAULT`, this returns 0.

**Returns** <NR3>

**Examples** `SXPRESS:BCOMPILE:RJ:END 0.25` sets the end value of Rj to 0.25 UI for batch compile.

`SXPRESS:BCOMPILE:RJ:END?` returns the end value of Rj for batch compile.

## SXPRESS:BCOMpile:RJ:INCRement

This command sets or returns the increment value of Rj for batch compile.

**Group** Batch compile

**Syntax** `SXPRESS:BCOMpile:RJ:INCRement <NR3>`  
`SXPRESS:BCOMpile:RJ:INCRement?`

**Related Commands** [SXPRESS:BCOMpile:RJ:ENABle](#), [SXPRESS:BCOMpile:RJ:STARt](#),  
[SXPRESS:BCOMpile:PJ:INCRement](#)

**Arguments** <NR3>

At `SXPRESS:SDEFault`, this returns 0.

**Returns** <NR3>

**Examples** `SXPRESS:BCOMPILE:RJ:INCREMENT 0.01` sets the increment value of Rj to 0.01 UI for batch compile.

`SXPRESS:BCOMPILE:RJ:INCREMENT?` returns the increment value of Rj for batch compile.

## SXPRESS:BCOMpile:RJ:STARt

This command sets or returns the start value of Rj for batch compile.

**Group** Batch compile

**Syntax** `SXPRESS:BCOMpile:RJ:STARt <NR3>`  
`SXPRESS:BCOMpile:RJ:STARt?`

<b>Related Commands</b>	<a href="#">SXPress:BCOMpile:RJ:ENABLE</a> , <a href="#">SXPress:BCOMpile:PJ:INCREMENT</a> , <a href="#">SXPress:BCOMpile:PJ:FREQUENCY&lt;n&gt;</a>
<b>Arguments</b>	<NR3> At SXPress:SDEFault, this returns 0.
<b>Returns</b>	<NR3>
<b>Examples</b>	<code>SXPRESS:BCOMPILE:RJ:START 0.15</code> sets the start value of Rj to 0.15 UI for batch compile. <code>SXPRESS:BCOMPILE:RJ:START?</code> returns start value of Rj for batch compile.

## SXPress:BDATA:FILE

This command sets or returns the user-defined pattern file used to generate the waveform.

- The file name should be according to the Windows file naming conventions.
- The file should have a pre-defined format.
- The file name should contain the full path of the file. If the path is not specified, the application executable path is assumed.
- If the file format is wrong or not available, the error flags are set.

**Group** Base data and base parameter settings

**Syntax** `SXPress:BDATA:FILE <file_name>`

**Related Commands** [SXPress:BDATA:FILE](#)

**Arguments** `<file_name>::=<string>`

**Examples** `SXPRESS:BDATA:FILE "C:\Samples\Pattern.txt"` sets the file path in the application. When waveform generation begins, the application opens the pattern from that location.

`SXPRESS:BDATA:FILE?` returns the file path.

## SXPRESS:BDATA:PATTERN

This command sets and returns the pattern for waveform generation.

Pre-defined patterns are different for each standard. Individual patterns may be different even if their names are same. For example, CJTPAT is available for both Display Port and SAS standards with different patterns of zeroes and ones.

**Group** Base data and base parameter settings

**Syntax** SXPRESS:BDATA:PATTERN <pattern\_name>

**Related Commands** [SXPRESS:BDATA:STANDARD](#), [SXPRESS:BDATA:TYPE](#)

**Arguments** <pattern\_name>::=<string>

It is the name of the pre-defined patterns supported by the application.

At SXPRESS:SDEFAULT, this returns the pattern based on the standard selected.

**Examples** SXPRESS:BDATA:STANDARD "DISPLAYPORT"

SXPRESS:BDATA:PATTERN "PRBS7"

The commands sets the standard to DisplayPort and then sets the pattern to PRBS7.

If the pattern is not available for the standard, an error message is displayed.

SXPRESS:BDATA:PATTERN? returns the selected pattern.

## SXPRESS:BDATA:STANDARD

This command sets or returns the name of the standard whose pattern is used for creating waveforms.



When the standard is set, a group of corresponding patterns are available for the settings. The default patterns for each standard are listed below:

- SATA – MFTP
- SAS – JTPAT\_RD+
- DisplayPort – PRBS7
- Fibre Channel – CJTPAT
- PCI-Express – CompliancePat
- General – Clock
- USB – CP0

When the standards are set, the data rate is changed automatically. For more information on the signal standards and their default data rates, refer to the *SerialXpress online help*.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:BDATA:STANDARD <name>`

**Related Commands** [SXPRESS:BDATA:STANDARD](#), [SXPRESS:BDATA:TYPE](#)

**Arguments** `<name>::=<string>`

“SATA” – SATA standard is used (common for all generations)

“USB” – USB 3.0 standard is used

“PCI-Express”

“Fibre Channel”

“SAS”

“DisplayPort” – DisplayPort is used (high bit rate is assumed)

“General” – Other pattern such as PRBS and clock are used

At `SXPRESS:SDEFault`, this returns “General”.

**Examples** `SXPRESS:BDATA:STANDARD "SATA"` sets the Standard to SATA. This will also set the Pattern to MFTP to generate the waveform unless the other patterns are specified.

`SXPRESS:BDATA:STANDARD?` returns the selected standard.

## SXPRESS:BDATA:TYPE

This command sets or returns the base data type. Base data type determines if you can assign the pattern input in the same file or use pre-defined files.

This command can be used to resolve the pattern name conflicts when the created file has the same file name as that of the pre-defined pattern files.

**Group** Base data and base parameter settings

**Syntax** SXPRESS:BDATA:TYPE <input\_type>  
SXPRESS:BDATA:TYPE?

**Related Commands** [SXPRESS:BDATA:STANDARD](#), [SXPRESS:BDATA:FILE](#), [SXPRESS:COMPILE](#)

**Arguments** <input\_type>::={FILE | STANDARD | USER}

FILE indicates that the input pattern set with the SXPRESS:BDATA:FILE command is used for waveform generation.

STANDARD indicates that the input pattern set with the SXPRESS:BDATA:PATTERN command is used for waveform generation.

USER indicates that the input pattern set with the SXPRESS:BDATA:TYPE USER command is used for waveform generation.

At SXPRESS:SDEFAULT, this returns STANDARD.

**Returns** <input\_type>

**Examples** SXPRESS:BDATA:TYPE STANDARD selects Standard as the base data type.

SXPRESS:BDATA:TYPE FILE selects the user-defined file as the base data type.

## SXPRESS:COMPILE (No Query Form)

This command compiles a waveform and adds it to the waveform list.

It adds the distortion as necessary and names the waveform depending on the settings, using the [SXPRESS:WFMNAME](#) command. If no waveform name is set, the base data file name is used. Base data file name is set using the [SXPRESS:BDATA:FILE](#) or [SXPRESS:BDATA:STANDARD](#) command.

**Group** Compile settings

<b>Syntax</b>	SXPRESS:COMPILE
<b>Related Commands</b>	<a href="#">SXPress:BDATA:STANDARD</a> , <a href="#">SXPress:BDATA:FILE</a> , <a href="#">SXPress:COMPILE:BCOMPILE:ENABLE</a>
<b>Examples</b>	<p>SXPRESS:BDATA:STANDARD "SATA"</p> <p>SXPRESS:BDATA:PATTERN "HFTP"</p> <p>SXPRESS:COMPILE</p> <p>These commands sets the Standard to SATA, Pattern to HFTP, and compiles a waveform with the waveform name "HFTP".</p>

## SXPress:COMPILE:BCOMPILE:ENABLE

This command enables or disables the batch compile state in the **Compile Settings** dialog box. If batch compile is enabled, the [SXPress:COMPILE](#) command triggers a batch compile instead of a normal compile.

Batch compile creates multiple waveforms with a combination of random jitter and periodic jitter. It is used to create more than one waveform with incremental increase in Rj or Pj values. Depending on the number of parameters chosen and the amount of increment for each parameter, the number of waveforms created by a single COMPILE command varies from one to several hundreds. For more description on the Batch Compile, refer to the *SerialXpress online help*.

---

**NOTE.** Check the value of this command before using the [SXPress:COMPILE](#) command to ensure that batch compile is not started unintentionally. Once the compile operation is started, it cannot be stopped.

---

<b>Group</b>	Compile settings
<b>Syntax</b>	<p>SXPRESS:COMPILE:BCOMPILE:ENABLE &lt;state&gt;</p> <p>SXPRESS:COMPILE:BCOMPILE:ENABLE?</p>
<b>Related Commands</b>	<a href="#">SXPress:COMPILE</a> , <a href="#">SXPress:BCOMPILE:PJ:ENABLE</a> , <a href="#">SXPress:BCOMPILE:RJ:ENABLE</a>
<b>Arguments</b>	<p>&lt;state&gt;::=&lt;Boolean&gt;</p> <p>0 indicates False.</p> <p>1 indicates True.</p>

At SXPRESS:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPRESS:COMPILE:BCOMPILE:ENABLE 1 enables the batch compile option.  
 SXPRESS:COMPILE:BCOMPILE:ENABLE 0 disables the batch compile option.  
 SXPRESS:COMPILE:BOMPILE:ENABLE? returns 0.

## SXPRESS:COMPILE:BWEXPANSION:ENABLE

This command enables or disables the bandwidth expansion filter state.

The bandwidth expansion filter is used to increase the spectral flatness of the AWG at higher data rates (> 4 Gbps).

**Group** Compile settings

**Syntax** SXPRESS:COMPILE:BWEXPANSION:ENABLE <state>  
 SXPRESS:COMPILE:BWEXPANSION:ENABLE?

**Related Commands** [SXPRESS:COMPILE](#), [SXPRESS:DRATE](#)

**Arguments** <state>::=<Boolean>  
 0 indicates False.  
 1 indicates True.  
 At SXPRESS:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPRESS:COMPILE:BWEXPANSION:ENABLE 1 enables the bandwidth expansion filter option.  
 SXPRESS:COMPILE:BWEXPANSION:ENABLE? returns 1, indicating that the bandwidth expansion filter is enabled.

## SXPRESS:COMPile:BWEXpansion:INTerleave

This command sets or returns the interleave state.

Interleave is used to either suppress or activate the interleave option when the bandwidth expansion filter is used. The interleave option is available only when the value of [SXPRESS:COMPile:SRATe](#) is set to a value greater than or equal to 12 GS/s. It is useful only when the resultant waveform is loaded on an AWG with option 2 installed.

**Group** Compile settings

**Syntax** SXPRESS:COMPile:BWEXpansion:INTerleave <state>  
SXPRESS:COMPile:BWEXpansion:INTerleave?

**Related Commands** [SXPRESS:COMPile:BWEXpansion:ENABle](#), [SXPRESS:COMPile:SRATe](#), [SXPRESS:COMPile](#)

**Arguments** <state>::=<Boolean>  
0 indicates False.  
1 indicates True.  
At SXPRESS:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPRESS:COMPile:BWEXpansion:INTerleave 1 sets the bandwidth expansion filter interleave option.  
SXPRESS:COMPile:BWEXpansion:INTerleave? returns 1.

## SXPRESS:COMPile:BWEXpansion:ZERoing

This command sets or returns the zeroing state.

Zeroing option is used during bandwidth expansion operation and can be set only when the interleave flag is set to 1.

**Group** Compile settings

<b>Syntax</b>	<code>SXPRESS:COMPile:BWExpansion:ZEROing &lt;state&gt;</code> <code>SXPRESS:COMPile:BWExpansion:ZEROing?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:COMPile:BCOMPile:ENABLE</a> , <a href="#">SXPRESS:COMPile:BWExpansion:INTerleave</a> , <a href="#">SXPRESS:COMPile</a>
<b>Arguments</b>	<code>&lt;state&gt;::=&lt;Boolean&gt;</code> 0 indicates False. 1 indicates True. At <code>SXPRESS:SDEFault</code> , this returns 0.
<b>Returns</b>	<code>&lt;state&gt;</code>
<b>Examples</b>	<code>SXPRESS:COMPILE:BWEXPANSION:ZEROING 1</code> sets the zeroing option when interleave is 1. <code>SXPRESS:COMPILE:BWEXPANSION:ZEROING?</code> returns 1, indicating that the zeroing flag is set.

## SXPRESS:COMPile:SRATe

This command sets or returns the sampling rate set in the application. This value is not the same as the sampling rate set on the AWG.

The maximum or minimum value of the sampling rate is automatically adjusted based on the AWG on which the application is running.

When the waveforms are created in the application, the sampling rate specified in this command is used. When waveforms are transferred to the instrument, the same sampling rate is set on the AWG.

<b>Group</b>	Compile settings
<b>Syntax</b>	<code>SXPRESS:COMPile:SRATe &lt;NR3&gt;</code> <code>SXPRESS:COMPile:SRATe?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:COMPile</a> , <a href="#">SXPRESS:COMPile:SRATe:AUTomatic</a>
<b>Arguments</b>	<code>&lt;NR3&gt;</code> At <code>SXPRESS:SDEFault</code> , this returns 6 GS/s.

**Returns** <NR3>

**Examples** `SXPRESS:COMPILE:SRATE 7E+9` sets the sampling rate to 7 GS/s.  
`SXPRESS:COMPILE:SRATE?` returns the currently selected sampling rate.

## SXPRESS:COMPILE:SRATE:AUTOMATIC

The command sets or returns the automatic option for sampling rate. This means that the application sets the sampling rate depending on the data rate and the AWG instrument capability.

The default setting of the sampling rate in the automatic mode is six times the data rate.

To change the sampling rate manually, the automatic option should be disabled.

**Group** Compile settings

**Syntax** `SXPRESS:COMPILE:SRATE:AUTOMATIC <state>`  
`SXPRESS:COMPILE:SRATE:AUTOMATIC?`

**Related Commands** [SXPRESS:COMPILE](#),  
[SXPRESS:COMPILE:SRATE](#)

**Arguments** <state>::=<Boolean>  
0 indicates False.  
1 indicates True.  
At `SXPRESS:SDEFault`, this returns 0.

**Returns** <state>

**Examples** `SXPRESS:COMPILE:SRATE:AUTOMATIC 1` sets the sampling rate to six times the data rate.  
`SXPRESS:COMPILE:SRATE:AUTOMATIC?` returns the status of the automatic option.

## SXPRESS:COMPILE:TRANSFER:CHANNEL

This command sets or returns the channel to which a compiled waveform is transferred.

To transfer a waveform to the AWG, use the [SXPRESS:COMPILE:TRANSFER:ENABLE](#) command.

---

**NOTE.** *You cannot transfer the waveforms when the application is started without the AWG software running (offline mode).*

---

**Group**      Compile settings

**Syntax**      SXPRESS:COMPILE:TRANSFER:CHANNEL <NR3>  
 SXPRESS:COMPILE:TRANSFER:CHANNEL?

**Related Commands**      [SXPRESS:COMPILE:TRANSFER:ENABLE](#), [SXPRESS:COMPILE](#)

**Arguments**      <NR3>  
 At SXPRESS:SDEFAULT, this returns 1.

**Returns**      <NR3>

**Examples**      SXPRESS:COMPILE:TRANSFER:CHANNEL 1 transfers the waveform to Channel 1 (Ch 1) of the AWG.  
 SXPRESS:COMPILE:TRANSFER:CHANNEL? returns 1.

---

**NOTE.** *When the value of the sampling rate set in the application is greater than the maximum sampling rate of the AWG for the non-interleave mode, the application automatically enables the Interleave option on the AWG. In such cases, trying to transfer the waveform to Ch 2 on the instrument will result in an error.*

---

## SXPRESS:COMPILE:TRANSFER:ENABLE

This commands enables or disables the automatic waveform transfer state (**Compiles and Sends To** option in the **Compile Settings** dialog box). When this option is enabled, the waveforms are automatically transferred to the AWG after compilation.



---

**NOTE.** This command fails and sets an error when the free trial expires and you do not have the license to transfer the waveforms. You can check the status of the license using the [SXPress:OPTions?](#) command.

---

<b>Group</b>	Compile settings
<b>Syntax</b>	<code>SXPress:COMpile:TRANSfer:ENABle &lt;state&gt;</code> <code>SXPress:COMpile:TRANSfer:ENABle?</code>
<b>Related Commands</b>	<a href="#">SXPress:COMpile:TRANsfer:CHANnel</a> , <a href="#">SXPress:COMpile</a> , <a href="#">SXPress:OPTions?</a>
<b>Arguments</b>	<code>&lt;state&gt;::=&lt;Boolean&gt;</code> 0 indicates False. 1 indicates True. At <code>SXPress:SDEFault</code> , this returns 0.
<b>Returns</b>	<code>&lt;state&gt;</code>
<b>Examples</b>	<code>SXPress:COMPILE:TRANSFER:ENABLE 1</code> enables the automatic waveform transfer option. <code>SXPress:COMPILE:TRANSFER:ENABLE?</code> returns 1.

## SXPress:DCD:ENABLE

This command enables or disables the DCD parameter. When disabled, the value of the DCD is ignored.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	<code>SXPress:DCD:ENABle &lt;state&gt;</code> <code>SXPress:DCD:ENABle?</code>
<b>Related Commands</b>	<a href="#">SXPress:DCD:VALue</a>

<b>Arguments</b>	<p>&lt;state&gt;::=&lt;Boolean&gt;</p> <p>0 indicates False.</p> <p>1 indicates True.</p> <p>At SXPRESS:SDEFault, this returns 0.</p>
<b>Returns</b>	<state>
<b>Examples</b>	<p>SXPRESS:DCD:ENABLE 1 enables the DCD parameter.</p> <p>SXPRESS:DCD:ENABLE? returns 0 if DCD is disabled.</p>

## SXPRESS:DCD:VALue

This command sets or returns the DCD value of the pulse.

DCD is the difference in the rise time and fall time. Changing the DCD value changes the fall time but the rise time remains constant.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	<p>SXPRESS:DCD:VALue &lt;NR3&gt;</p> <p>SXPRESS:DCD:VALue?</p>
<b>Related Commands</b>	<a href="#">SXPRESS:FTIME</a> , <a href="#">SXPRESS:RTIME</a>
<b>Arguments</b>	<p>&lt;NR3&gt;</p> <p>At SXPRESS:SDEFault, this returns 0 ps.</p>
<b>Returns</b>	<NR3>
<b>Examples</b>	<p>SXPRESS:DCD:VALUE 0.5 sets the DCD value to 0.5 UI.</p> <p>SXPRESS:DCD:VALUE? returns the DCD value.</p>

## SXPRESS:DRATe

This command sets or returns the data rate. Changing the data rate may affect the sampling rate, sample per UI (SPUI), rise time, fall time, and range of Rj bandwidth. These values are automatically reset to the nearest values if required.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:DRATE <NR3>`  
`SXPRESS:DRATE?`

**Related Commands** [SXPress:COMPile:SRATe](#), [SXPress:COMPile](#)

**Arguments** `<NR3>`  
 At `SXPRESS:SDEFault`, this returns 1E9.

**Returns** `<NR3>`

**Examples** `SXPRESS:DRATE 4E9` sets the data rate to 4 Gbps.  
`SXPRESS:DRATE?` returns 4e9.

## SXPress:ENCode:ENCo8b10b:DISParity

This command sets or returns the disparity set for encoding.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:ENCode:ENCo8b10b:DISParity <disparity>`  
`SXPRESS:ENCode:ENCo8b10b:DISParity?`

**Related Commands** [SXPress:COMPile:SRATe](#), [SXPress:COMPile](#)

**Arguments** `<disparity> ::= {RDPLus | RDMinus}`

**Returns** `<disparity>`

**Examples** `SXPRESS:ENCODE:ENCO8B10B:DISPARITY RDPLUS` sets the disparity to RDPLus.  
`SXPRESS:ENCODE:ENCO8B10B:DISPARITY?` returns the disparity.

## SXPRESS:ENCODE:ENCo8b10b:ENABLE

This command enables or disables the 8B10B encoding state on the base data pattern. This option can be enabled with or without other encoding types.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:ENCODE:ENCo8b10b:ENABLE <state> SXPRESS:ENCODE:ENCo8b10b:ENABLE?
<b>Arguments</b>	<state>::=<Boolean>  0 indicates False. 1 indicates True.  At SXPRESS:SDEFAULT, this returns 0.
<b>Returns</b>	<state>
<b>Examples</b>	SXPRESS:ENCODE:ENCo8b10b:ENABLE 1 enables the 8B10B encoding option.  SXPRESS:ENCODE:ENCo8b10b:ENABLE? returns 0 if the 8B10B encoding is disabled.

## SXPRESS:ENCODE:SCHEME

This command sets or returns the encoding scheme on the base data pattern.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:ENCODE:SCHEME <scheme> SXPRESS:ENCODE:SCHEME?
<b>Arguments</b>	<scheme>::={NRZ   NRZI}  At SXPRESS:SDEFAULT, this returns NRZ.
<b>Returns</b>	<scheme>

**Examples**    `SXPRESS:ENCODE:SCHEME NRZI` sets the encoding scheme to NRZI.  
`SXPRESS:ENCODE:SCHEME?` returns the encoding scheme.

## SXPRESS:FTIME

This command sets or returns the fall time of the pulse.

If the fall time is same as the rise time, the DCD will be zero. If the fall time is different from the rise time, the difference appears as a DCD. The fall time set depends on the definition of the step height using the [SXPRESS:RFTYPE](#) command.

---

**NOTE.** *You can change the fall time only when DCD is disabled.*

---

**Group**    Base data and base parameter settings

**Syntax**    `SXPRESS:FTIME <NR3>`  
`SXPRESS:FTIME?`

**Related Commands**    [SXPRESS:RTIME](#), [SXPRESS:DRATE](#), [SXPRESS:DCD:VALUE](#)

**Arguments**    `<NR3>`  
 At `SXPRESS:SDEFAULT`, this returns 200 ps.

**Returns**    `<NR3>`

**Examples**    `SXPRESS:FTIME 180e-12` sets the fall time to 180 ps. If the rise time is 200 ps, the DCD value returns 20 ps.  
`SXPRESS:FTIME?` returns the fall time.

## SXPRESS:ISI:ENABLE

This command enables or disables the ISI parameter state.

When disabled, ISI will not be considered for waveform compilation.

**Group**    ISI and S-Parameter

**Syntax**      `SXPRESS:ISI:ENABLE <state>`  
`SXPRESS:ISI:ENABLE?`

**Related Commands**      [SXPRESS:ISI:VALue](#)

**Arguments**      `<state>::=<Boolean>`  
 0 indicates False.  
 1 indicates True.  
 At `SXPRESS:SDEFault`, this returns 0.

**Returns**      `<state>`

**Examples**      `SXPRESS:ISI:ENABLE 1` enables ISI.  
`SXPRESS:ISI:ENABLE?` returns 0 if ISI is disabled.

## SXPRESS:ISI:VALue

This command sets or returns the ISI magnitude.

**Group**      ISI and S-Parameter

**Syntax**      `SXPRESS:ISI:VALue <NR3>`  
`SXPRESS:ISI:VALue?`

**Related Commands**      [SXPRESS:ISI:ENABLE](#)

**Arguments**      `<NR3>`  
 At `SXPRESS:SDEFault`, this returns 0 ps.

**Returns**      `<NR3>`

**Examples**      `SXPRESS:ISI:VALUE 0.5` sets the ISI value to 0.5 UI.  
`SXPRESS:ISI:VALUE?` returns the ISI magnitude.

## SXPRESS:ISTate:OFFSet

This command sets or returns the offset of the idle state waveform.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:ISTate:OFFSet <NR3> SXPRESS:ISTate:OFFSet
<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 0 volts.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:ISTATE:OFFSET 0.15 sets the idle state offset to 0.15 volts. SXPRESS:ISTATE:OFFSET? returns the current idle state offset.

## SXPRESS:ISTate:VALue

This command sets or returns the idle state value to generate an idle state waveform for that duration. You can use this command to create an idle state waveform by setting the pattern to Idle State.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:ISTate:VALue <NR3> SXPRESS:ISTate:VALue?
<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 320 ns.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:ISTATE:VALUE 240e-7 sets the idle state value to 24 $\mu$ s. SXPRESS:ISTATE:VALUE? returns the current value of the idle state.

## SXPRESS:MARKer<n>:CLOCK:FREQUency

This command sets or returns the frequency of marker data when the marker type is set to clock.

The value of <n> is either 1 or 2.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:MARKer<n>:CLOCK:FREQUency <NR3> SXPRESS:MARKer<n>:CLOCK:FREQUency?
<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 10 MHz.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:MARKER1:CLOCK:FREQUENCY 10000000 sets the frequency of the marker1 data to 10 MHz.  SXPRESS:MARKER1:CLOCK:FREQUENCY? returns the frequency of the marker1 data.

## SXPRESS:MARKer<n>:TRIGger:LENGth

This command sets the beginning 'n' samples of the marker output to high. It returns the length of the marker output that is set to high.

The value of <n> is either 1 or 2.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:MARKer<n>:TRIGger:LENGth <NR1>
<b>Arguments</b>	<NR1> At SXPRESS:SDEFault, this returns 50.
<b>Returns</b>	<NR1>



- Examples** `SXPRESS:MARKER1:TRIGGER:LENGTH 10` sets the beginning 10 samples of the marker output to high.
- `SXPRESS:MARKER1:TRIGGER:LENGTH?` returns the length of the marker1 output that is set to high.

## SXPRESS:MARKER<n>:TYPE

This command sets or returns the type of the marker data.

The value of <n> is either 1 or 2.

If the marker is set to 1, the marker output of the pattern will be a digital output from the marker channel.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:MARKER<n>:TYPE <type>`  
`SXPRESS:MARKER<n>:TYPE?`

**Arguments** `<type>::=<numeric>`

1 indicates that the marker is the same as the base data bits.

2 indicates that the marker has clock pattern.

3 indicates that the marker type is set to trigger.

4 indicates that all markers are set to high.

5 indicates that all markers are set to low.

At `SXPRESS:SDEFault`, this returns 1.

**Returns** `<type>`

- Examples** `SXPRESS:MARKER1:TYPE 4` sets all the marker1 output to high.
- `SXPRESS:MARKER1:TYPE?` returns the marker1 type.

## SXPRESS:MODE

This command sets or returns the current mode in which SerialXpress is running.

This command must be sent first to run SerialXpress in the sequence mode.

<b>Group</b>	Sequence
<b>Syntax</b>	SXPRESS:MODE <state> SXPRESS:MODE?
<b>Arguments</b>	<state>::=<Boolean>  0 indicates that the application is running in the single mode.  1 indicates that the application is running in the sequence mode.  At SXPRESS:SDEFault, this returns 0.
<b>Returns</b>	<mode>
<b>Examples</b>	SXPRESS:MODE 0 sets the application to the single mode. SXPRESS:MODE? returns the current mode of the application.

## SXPRESS:NOISE:ENABLE

This command enables or disables the noise parameter state.

<b>Group</b>	Random noise
<b>Syntax</b>	SXPRESS:NOISE:ENABLE <state> SXPRESS:NOISE:ENABLE?
<b>Related Commands</b>	<a href="#">SXPRESS:NOISE:VALue</a>
<b>Arguments</b>	<state>::=<Boolean>  0 indicates False.  1 indicates True.  At SXPRESS:SDEFault, this returns 0.
<b>Returns</b>	<state>

**Examples**    `SXPRESS:NOISE:ENABLE 1` enables the noise parameter.  
`SXPRESS:NOISE:ENABLE?` returns 0 if noise is disabled.

## SXPRESS:NOISE:LOCATION

This command sets or returns the location where the noise will be applied.

**Group**    Random noise

**Syntax**    `SXPRESS:NOISE:LOCATION <location>`  
`SXPRESS:NOISE:LOCATION?`

**Related Commands**    [SXPRESS:NOISE:VALue](#)

**Arguments**    `<location> ::= {NEAR | FAR}`  
At `SXPRESS:SDEFault`, this returns NEAR.

**Returns**    `<location>`

**Examples**    `SXPRESS:NOISE:LOCATION NEAR` applies the noise at the near end just after the transmitter simulation.  
`SXPRESS:NOISE:LOCATION?` returns the location of the noise applied.

## SXPRESS:NOISE:VALue

This command sets or returns the noise magnitude.

**Group**    Random noise

**Syntax**    `SXPRESS:NOISE:VALue <NR3>`  
`SXPRESS:NOISE:VALue?`

**Related Commands**    [SXPRESS:NOISE:ENABle](#)

**Arguments**    `<NR3>`  
At `SXPRESS:SDEFault`, this returns 0 volts.

**Returns** <NR3>

**Examples** SXPRESS:NOISE:VALUE 0.4 sets the noise magnitude to 0.4 V.  
 SXPRESS:NOISE:VALUE? returns the noise magnitude.

## SXPRESS:OPTions? (Query Only)

The command returns the activated options.

**Group** Licensing

**Syntax** SXPRESS:OPTions?

**Returns** <string>

**Examples** SXPRESS:OPTIONS?

This command returns the option(s) as follows:

- If no options are activated, it returns BASE.
- If the SSC option is activated, it returns BASE and SSC.
- If ISI/SPARAM is activated, it returns BASE and ISI.
- If all the options are activated, it returns BASE, ISI, and SSC.

## SXPRESS:PJ<n>:ENABLE

This command enables or disables the periodic jitter parameter state.

When disabled, the value of corresponding periodic jitter is ignored. It retains the previous settings of magnitude, frequency, and phase but is not considered for waveform compilation.

The value of <n> ranges from 1 to 4.

**Group** Periodic jitter

**Syntax** SXPRESS:PJ<n>:ENABLE <state>  
 SXPRESS:PJ<n>:ENABLE?

**Related Commands** [SXPress:PJ<n>:MAGNitude](#)

**Arguments** <state>::=<Boolean>  
 0 indicates False.  
 1 indicates True.  
 At SXPress:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPress:PJ1:ENABLE 1 enables Pj1.  
 SXPress:PJ2:ENABLE? returns 0 if Pj2 is disabled.

## SXPress:PJ<n>:FREQUency

This command sets or returns the frequency (in Hz) of the periodic jitter.  
 The value of <n> ranges from 1 to 4.

**Group** Periodic jitter

**Syntax** SXPress:PJ<n>:FREQUency <NR3>  
 SXPress:PJ<n>:FREQUency?

**Related Commands** [SXPress:PJ<n>:MAGNitude](#), [SXPress:PJ<n>:ENABLE](#), [SXPress:PJ<n>:FREQUency](#)

**Arguments** <NR3>  
 At SXPress:SDEFault, this returns 100 KHz.

**Returns** <NR3>

**Examples** SXPress:PJ1:FREQUency 100000 sets the Pj1 frequency to 100 KHz.  
 SXPress:PJ2:FREQUency? returns the Pj2 frequency.

## SXPRESS:PJ<n>:MAGNitude

This command sets or returns the periodic jitter magnitude (in ps). If Pj is enabled, it will be applied in the next compilation.

The value of <n> ranges from 1 to 4.

**Group** Periodic jitter

**Syntax** SXPRESS:PJ<n>:MAGNitude <NR3>  
SXPRESS:PJ<n>:MAGNitude?

**Related Commands** [SXPRESS:PJ<n>:ENABLE](#), [SXPRESS:PJ<n>:FREQUENCY](#), [SXPRESS:PJ<n>:PHASE](#)

**Arguments** <NR3>

At SXPRESS:SDEFAULT, this returns 0 ps.

**Returns** <NR3>

**Examples** SXPRESS:PJ1:MAGNITUDE 50 sets the Pj1 magnitude to 50 UI.  
SXPRESS:PJ1:MAGNITUDE? returns the Pj1 magnitude.

## SXPRESS:PJ<n>:PHASe

This command sets or returns the phase of the periodic jitter.

The value of <n> ranges from 1 to 4.

**Group** Periodic jitter

**Syntax** SXPRESS:PJ<n>:PHASe <NR3>  
SXPRESS:PJ<n>:PHASe?

**Related Commands** [SXPRESS:PJ<n>:ENABLE](#), [SXPRESS:PJ<n>:MAGNITUDE](#), [SXPRESS:PJ<n>:FREQUENCY](#)

**Arguments** <NR3>

At SXPRESS:SDEFAULT, this returns 0 degrees.

**Returns** <NR3>

**Examples** `SXPRESS:PJ1:PHASE 30` sets the Pj1 phase to 30 degrees.  
`SXPRESS:PJ2:PHASE?` returns the Pj2 phase.

## SXPRESS:PREEmphasis:ENABLE

This command enables or disables the pre-emphasis parameter state. When disabled, the value of pre-emphasis is ignored.

**Group** Pre-emphasis

**Syntax** `SXPRESS:PREEmphasis:ENABLE <state>`  
`SXPRESS:PREEmphasis:ENABLE?`

**Related Commands** [SXPRESS:PREEmphasis:VALue](#)

**Arguments** <state>::=<Boolean>  
 0 indicates False.  
 1 indicates True.  
 At `SXPRESS:SDEFault`, it returns 0.

**Returns** <state>

**Examples** `SXPRESS:PREEMPHASIS:ENABLE 1` enables the pre-emphasis parameter.  
`SXPRESS:PREEMPHASIS:ENABLE?` returns 0 if pre-emphasis is disabled.

## SXPRESS:PREEmphasis:VALue

This command sets or returns the pre-emphasis value.

**Group** Pre-emphasis

**Syntax** `SXPRESS:PREEmphasis:VALue <NR3>`  
`SXPRESS:PREEmphasis:VALue?`

**Related Commands**    [SXPress:PREemphasis:ENABLE](#)

**Arguments**    <NR3>  
 At SXPress:SDEFault, this returns 0 dB.

**Returns**    <NR3>

**Examples**    SXPress:PREEMPHASIS:VALUE 0.4 sets the pre-emphasis value to 0.4 dB.  
 SXPress:PREEMPHASIS:VALUE? returns the pre-emphasis magnitude.

## SXPress:RFTYPE

This command sets or returns the step height of the rise and fall time.

**Group**    Base data and base parameter settings

**Syntax**    SXPress:RFTYPE <rftype>  
 SXPress:RFTYPE

**Arguments**    <rftype>::={TWENTyeighty | TENNinety}  
 At SXPress:SDEFault, this returns TWENTyeighty.

**Returns**    <rftype>

**Examples**    SXPress:RFTYPE TWENTYEIGHTY sets the rise/fall time type to 20/80.  
 SXPress:RFTYPE? returns the rise/fall time type.

## SXPress:RJ<n>:ENABLE

This command enables or disables the random jitter parameter state. When disabled, the value of the corresponding random jitter is ignored. It retains the previous settings of magnitude and low/high frequencies but is not considered for waveform compilation.

The value of <n> is 1, 2, and/or 3.

**Group**    Random jitter



**Syntax**    `SXPRESS:RJ<n>:ENABLE <state>`  
`SXPRESS:RJ<n>:ENABLE?`

**Related Commands**    [SXPRESS:RJ<n>:MAGNitude](#)

**Arguments**    `<state>::=<Boolean>`  
 0 indicates False.  
 1 indicates True.  
 At SXPRESS:SDEFault, this returns 0.

**Returns**    `<state>`

**Examples**    `SXPRESS:RJ1:ENABLE 1` enables Rj1.  
`SXPRESS:RJ2:ENABLE?` returns 0 if Rj2 is disabled.

## SXPRESS:RJ<n>:FREQUENCY:END

This command sets or returns the end frequency of the random jitter frequency band. The random jitter start and end frequencies will define a band over which the Rj will be applied.

The value of <n> is 1 to 3.

**Group**    Random jitter

**Syntax**    `SXPRESS:RJ<n>:FREQUENCY:END <NR3>`  
`SXPRESS:RJ<n>:FREQUENCY:END?`

**Related Commands**    [SXPRESS:RJ<n>:ENABLE](#), [SXPRESS:RJ<n>:MAGNitude](#), [SXPRESS:RJ<n>:FREQUENCY:START](#)

**Arguments**    `<NR3>`  
 At SXPRESS:SDEFault, this returns data rate/2.

**Returns**    `<NR3>`

**Examples**    `SXPRESS:RJ1:FREQUENCY:END 100000` sets the Rj1 end frequency to 100 KHz.  
`SXPRESS:RJ1:FREQUENCY:END?` returns the Rj1 end frequency.

## **SXPRESS:RJ<n>:FREQUENCY:START**

This command sets or returns the start frequency of the random jitter frequency band.

The value of <n> is 1 to 3.

**Group**    Random jitter

**Syntax**    `SXPRESS:RJ<n>:FREQUENCY:START <NR3>`  
`SXPRESS:RJ<n>:FREQUENCY:START?`

**Related Commands**    [SXPRESS:RJ<n>:ENABLE](#), [SXPRESS:RJ<n>:MAGNITUDE](#), [SXPRESS:RJ<n>:FREQUENCY:END](#)

**Arguments**    <NR3>  
At `SXPRESS:SDEFAULT`, this returns 100.000 KHz.

**Returns**    <NR3>

**Examples**    `SXPRESS:RJ1:FREQUENCY:START 100000` sets the Rj1 start frequency to 100 KHz.  
`SXPRESS:RJ1:FREQUENCY:START?` returns the Rj1 start frequency.

## **SXPRESS:RJ<n>:MAGNITUDE**

This command sets or returns the magnitude of the random jitter. If Rj<n> is enabled, the values set will be applied to the data in the next compile.

The value of <n> is 1 to 3.

**Group**    Random jitter

**Syntax**    `SXPRESS:RJ<n>:MAGNITUDE <NR3>`  
`SXPRESS:RJ<n>:MAGNITUDE?`

<b>Related Commands</b>	<a href="#">SXPress:RJ&lt;n&gt;:ENABLE</a> , <a href="#">SXPress:RJ&lt;n&gt;:FREQuency:START</a> , <a href="#">SXPress:RJ&lt;n&gt;:FREQuency:END</a>
<b>Arguments</b>	<NR3> At SXPress:SDEFault, this returns 0 ps.
<b>Returns</b>	<NR3>
<b>Examples</b>	<code>SXPRESS:RJ1:MAGNITUDE 0.5</code> sets the Rj1 magnitude to 0.5 UI. <code>SXPRESS:RJ1:MAGNITUDE?</code> returns the Rj1 magnitude in ps.

## SXPress:RSEed:ENABLE

This command enables or disables the random seed state.

<b>Group</b>	Random jitter
<b>Syntax</b>	<code>SXPress:RSEed:ENABle &lt;state&gt;</code> <code>SXPress:RSEed:ENABle</code>
<b>Related Commands</b>	<a href="#">SXPress:RJ&lt;n&gt;:MAGNitude</a> , <a href="#">SXPress:RSEed:VALue</a>
<b>Arguments</b>	<state>::=<Boolean> 0 indicates False. 1 indicates True. At SXPress:SDEFault, this returns 0.
<b>Returns</b>	<state>
<b>Examples</b>	<code>SXPRESS:RSEED:ENABLE 1</code> enables random seed. <code>SXPRESS:RSEED:ENABLE?</code> returns 1 if random seed is enabled.

## SXPress:RSEed:VALue

This command sets or returns the value of the random seed.

<b>Group</b>	Random jitter
<b>Syntax</b>	<code>SXPRESS:RSEED:VALUE &lt;NR1&gt;</code> <code>SXPRESS:RSEED:VALUE</code>
<b>Related Commands</b>	<a href="#">SXPRESS:RJ&lt;n&gt;:MAGNitude</a> , <a href="#">SXPRESS:RSEED:ENABLE</a>
<b>Arguments</b>	<NR1>::=Any number between 1 to 99999. At <code>SXPRESS:SDEFAULT</code> , this returns 12345.
<b>Returns</b>	<NR1>
<b>Examples</b>	<code>SXPRESS:RSEED:VALUE 123</code> sets the random seed value to 123. <code>SXPRESS:RSEED:VALUE?</code> returns the random seed value.

## SXPRESS:RTIME

This command sets or returns the rise time of the pulse.

When rise and fall time are different, the difference appears as a DCD. The rise time set depends on the definition of the step height set using the [SXPRESS:RFTYPE](#) command. Maximum value of rise time is 1/data rate.

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	<code>SXPRESS:RTIME &lt;NR3&gt;</code> <code>SXPRESS:RTIME?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:FTIME</a> , <a href="#">SXPRESS:DRATE</a> , <a href="#">SXPRESS:DCD:VALUE</a>
<b>Arguments</b>	<NR3> At <code>SXPRESS:SDEFAULT</code> , this returns 200 ps.
<b>Returns</b>	<NR3>
<b>Examples</b>	<code>SXPRESS:RTIME 220E-12</code> sets the rise time to 220 ps. If the fall time is 200 ps, the difference appears as a DCD.

`SXPRESS:RTIME?` returns the rise time.

## SXPRESS:SCRAMBLE:ENABLE

This command enables or disables base pattern scrambling.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:SCRAMBLE:ENABLE <state>`  
`SXPRESS:SCRAMBLE:ENABLE?`

**Related Commands** [SXPRESS:SCRAMBLE:RINIT](#), [SXPRESS:SCRAMBLE:POLYNOMIAL](#)

**Arguments** `<state>::=<Boolean>`  
 0 indicates False.  
 1 indicates True.  
 At `SXPRESS:SDEFAULT`, this returns 0.

**Returns** `<state>`

**Examples** `SXPRESS:SCRAMBLE:ENABLE 1` enables base pattern scrambling.  
`SXPRESS:SCRAMBLE:ENABLE?` returns 0 if base pattern scrambling is not enabled.

## SXPRESS:SCRAMBLE:POLYNOMIAL

This command sets or returns the scrambling polynomial.

**Group** Base data and base parameter settings

**Syntax** `SXPRESS:SCRAMBLE:POLYNOMIAL <polynomial>`  
`SXPRESS:SCRAMBLE:POLYNOMIAL?`

**Related Commands** [SXPRESS:SCRAMBLE:ENABLE](#), [SXPRESS:SCRAMBLE:RINIT](#)

<b>Arguments</b>	<polynomial>::=<string> At SXPRESS:SDEFault, this returns X16+X5+X4+X3+1.
<b>Returns</b>	<string>
<b>Examples</b>	SXPRESS:SCRAMBLE:POLYNOMIAL "X7+X5+X4+1" sets the scrambling polynomial to X7+X5+X4+1. SXPRESS:SCRAMBLE:POLYNOMIAL? returns the scrambling polynomial value.

## SXPRESS:SCRAMBLE:RINIT

This command sets or returns the scrambling seed value. It contains a binary number like 11001101.

---

**NOTE.** *The length of the register must be equal to the degree of the polynomial.*

---

<b>Group</b>	Base data and base parameter settings
<b>Syntax</b>	SXPRESS:SCRAMBLE:RINIT <seed> SXPRESS:SCRAMBLE:RINIT?
<b>Related Commands</b>	<a href="#">SXPRESS:SCRAMBLE:ENABLE</a> , <a href="#">SXPRESS:SCRAMBLE:POLYNOMIAL</a>
<b>Arguments</b>	<seed>::=<string> At SXPRESS:SDEFault, this returns 1111111111111111.
<b>Returns</b>	<string>
<b>Examples</b>	SXPRESS:SCRAMBLE:RINIT "11101011" sets the scrambling seed to 11101011. SXPRESS:SCRAMBLE:RINIT? returns the scrambling seed value.

## SXPRESS:SDEFault (No Query Form)

This command restores all the application parameters to their default values.

<b>Group</b>	Save and restore setup
<b>Syntax</b>	<code>SXPRESS:SDEFAULT</code>
<b>Related Commands</b>	<a href="#">SXPress:SDEFAULT</a> , <a href="#">SXPress:SSAVE</a>
<b>Examples</b>	<code>SXPRESS:SDEFAULT</code> sets all the parameters to their default values.

## SXPress:SEQUENCE:ELEMENT:ADD (No Query Form)

This command adds a new sequence element to the end of the sequence table and increments the sequence length.

You cannot insert an element using this command. The newly added element will have all the parameters set in the Base pattern tab. The selected pattern is added to the Base pattern column in the sequence table. If this is the first sequence element, all the other sequence element parameters in the table are set to the default value. Else, the values will be same as the currently selected index. When you add a sequence element, the index points to the newly added element. This command does not work in the Standard mode and returns an error.

<b>Group</b>	Sequence
<b>Syntax</b>	<code>SXPRESS:SEQUENCE:ELEMENT:ADD</code>
<b>Related Commands</b>	<a href="#">SXPress:MODE</a> , <a href="#">SXPress:BDATA:FILE</a> , <a href="#">SXPress:BDATA:PATTERN</a> , <a href="#">SXPress:BDATA:STANDARD</a> , <a href="#">SXPress:BDATA:TYPE</a> , <a href="#">SXPress:SEQUENCE:LENGTH?</a>
<b>Examples</b>	<pre>SXPRESS:BDATA:STANDARD "DISPLAYPORT" SXPRESS:BDATA:PATTERN "PRBS7" SXPRESS:SEQUENCE:ELEMENT:ADD</pre> <p>These commands adds the standard DisplayPort and pattern PRBS7 to the sequence table.</p>

## SXPress:SEQUENCE:ELEMENT:BCOMPile

This command sets or returns the sequence element number to which the batch compile is applied. Use the [SXPress:COMPile:BCOMPile:ENABLE](#) command to enable or disable batch setup.

<b>Group</b>	Sequence
<b>Syntax</b>	<code>SXPRESS:SEQUENCE:ELEMENT:BCOMPILE &lt;state&gt;</code> <code>SXPRESS:SEQUENCE:ELEMENT:BCOMPILE?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:MODE</a> , <a href="#">SXPRESS:COMPILER:BCOMPILER:ENABLE</a>
<b>Arguments</b>	<code>&lt;state&gt;::=&lt;Boolean&gt;</code>  0 disables batch compile.  1 enables batch compile.  At <code>SXPRESS:SDEFAULT</code> , this returns 0.
<b>Returns</b>	<code>&lt;state&gt;</code>
<b>Examples</b>	<code>SXPRESS:SEQUENCE:ELEMENT:BCOMPILER 1</code> enables the batch compile option for the selected sequence element.  <code>SXPRESS:SEQUENCE:ELEMENT:BCOMPILER?</code> returns the state of the batch compile for the selected sequence element.

## SXPRESS:SEQUENCE:ELEMENT:DELETE (No Query Form)

This command deletes the selected sequence element or all the sequence elements in the table.

This command is applicable only in the Sequence mode. In the Standard mode, an error message is displayed.

<b>Group</b>	Sequence
<b>Syntax</b>	<code>SXPRESS:SEQUENCE:ELEMENT:DELETE</code>
<b>Related Commands</b>	<a href="#">SXPRESS:MODE</a> , <a href="#">SXPRESS:SEQUENCE:LENGTH?</a> , <a href="#">SXPRESS:SEQUENCE:ELEMENT:ADD</a>
<b>Examples</b>	<code>SXPRESS:SEQUENCE:INDEX 4</code>  <code>SXPRESS:SEQUENCE:ELEMENT:DELETE</code> deletes the fourth element in the sequence table.



## SXPRESS:SEQUENCE:ELEMENT:GOTO:INDEX

This command sets or returns the Go To target for the sequence element.

The Go To index should be less than or equal to the sequence length and cannot be same as the selected sequence index.

**Group** Sequence

**Syntax** SXPRESS:SEQUENCE:ELEMENT:GOTO:INDEX <index>  
SXPRESS:SEQUENCE:ELEMENT:GOTO:INDEX?

**Related Commands** [SXPRESS:SEQUENCE:INDEX](#), [SXPRESS:SEQUENCE:LENGTH?](#)

**Arguments** <index>::=<NR1>

At SXPRESS:SDEFAULT, this returns 1.

**Returns** <index>

**Examples** SXPRESS:SEQUENCE:ELEMENT:GOTO:INDEX 4 will cause the sequencer to jump to the fourth element.

SXPRESS:SEQUENCE:ELEMENT:GOTO:INDEX? returns 4.

## SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT

This command sets or returns the repeat count of the selected sequence element.

You can set the repeat count only when the repeat mode is set to manual count.

**Group** Sequence

**Syntax** SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT <value>  
SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT?

**Related Commands** [SXPRESS:SEQUENCE:INDEX](#), [SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE](#)

**Arguments** <value>::=<NR1>

At SXPRESS:SDEFAULT, this returns 1.

**Returns** <value>

**Examples** `SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT 1000` sets the repeat count of the selected sequence element to 1000.

`SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT?` returns the repeat count of the selected sequence element.

## SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE

This command sets or returns the repeat mode state of the selected sequence element.

**Group** Sequence

**Syntax** `SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE <state>`  
`SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE?`

**Related Commands** [SXPRESS:SEQUENCE:INDEX](#), [SXPRESS:SEQUENCE:ELEMENT:REPEAT:COUNT](#)

**Arguments** <state> ::= {COUNT | TIME | AUTO | INFINITE}

At `SXPRESS:SDEFAULT`, this returns AUTO.

**Returns** <state>

**Examples** `SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE AUTO` sets the repeat mode of the selected sequence element to auto.

`SXPRESS:SEQUENCE:ELEMENT:REPEAT:MODE?` returns the repeat mode state of the selected sequence element.

## SXPRESS:SEQUENCE:ELEMENT:WSTATE

This command sets or returns the wait state of the selected sequence element.

**Group** Sequence

**Syntax** `SXPRESS:SEQUENCE:ELEMENT:WSTATE <state>`  
`SXPRESS:SEQUENCE:ELEMENT:WSTATE?`

**Related Commands**    [SXPress:SEquence:INdex](#)

**Arguments**    `<state>::=<Boolean>`  
 0 sets the wait state to OFF.  
 1 sets the wait state to ON.  
 At SXPress:SDEFault, this returns the following:  
 0 if AWG7000 or AWG7000B (with Option 8) is available.  
 1 if AWG7000 is not available or AWG7000B does not have Option 8.

**Returns**    `<state>`

**Examples**    `SXPRESS:SEQUENCE:ELEMENT:WSTATE 1` sets the wait state to ON.  
`SXPRESS:SEQUENCE:ELEMENT:WSTATE?` returns 1, if wait state is set to ON.

## SXPress:SEquence:INdex

This command sets or returns the current sequence index. The sequence index number starts from zero.

The current sequence index indicates the selected sequence element.

The sequence index should be within the current sequence length and cannot be less than 1.

**Group**    Sequence

**Syntax**    `SXPress:SEquence:INdex <NR1>`  
`SXPress:SEquence:INdex?`

**Related Commands**    [SXPress:MODE](#), [SXPress:SEquence:LENGth?](#)

**Arguments**    `<NR1>`  
 At SXPress:SDEFault, this returns 0.

**Returns**    `<NR1>`

**Examples**    `SXPRESS:SEQUENCE:INDEX 3` sets the sequence index to the third sequence element.

## SXPRESS:SEQUENCE:LENGTH? (Query Only)

This command returns the current sequence length.

Sequence length indicates the number of sequence elements in the SerialXpress sequence.

This command works even in the Standard mode. It returns 0 if no sequence element is present.

**Group**        Sequence

**Syntax**       `SXPRESS:SEQUENCE:LENGTH?`

**Related Commands**    [SXPRESS:MODE](#), [SXPRESS:SEQUENCE:ELEMENT:ADD](#)

**Returns**       <NR1>

**Examples**       `SXPRESS:SEQUENCE:LENGTH?` returns the sequence length value.

## SXPRESS:SEQUENCE:WRAP:STATE

This command enables or disables the wrap between sequence elements state in the application.

When enabled, the continuity of the waveform sample is ensured when the sequence execution moves from one sequence element to another.

When disabled, the continuity of the waveforms is not ensured. However, the sequence elements are created and may be sent to the AWG.

This command will not have any effect in standard mode. However, you can set or return the command without any error.

**Group**        Sequence

**Syntax**       `SXPRESS:SEQUENCE:WRAP:STATE <state>`  
`SXPRESS:SEQUENCE:WRAP:STATE?`

**Related Commands**    [SXPress:MODE](#)

**Arguments**    <state>::=<Boolean>  
 0 indicates that wrap between sequence elements is disabled.  
 1 indicates that wrap between sequence elements is enabled.  
 At SXPress:SDEFault, this returns 0.

**Returns**    <state>

**Examples**    SXPress:SEQUENCE:WRAP:STATE 0 sets the wrap between sequence elements option.  
 SXPress:SEQUENCE:WRAP:STATE? returns 0, indicating that the wrap between sequence elements option is enabled.

## SXPress:SPARam:AGGRessor:CLOCK:FREQUENCY

This command sets or returns the clock frequency of the aggressor signal. This is applicable only when [SXPress:SPARam:AGGRessor:TYPE](#) is set to Clock.

**Group**    ISI and S-Parameter

**Syntax**    SXPress:SPARam:AGGRessor:CLOCK:FREQUENCY <NR3>  
 SXPress:SPARam:AGGRessor:CLOCK:FREQUENCY?

**Related Commands**    [SXPress:SPARam:AGGRessor:TYPE](#)

**Arguments**    <NR3>::=<numeric>

**Returns**    <NR3>

**Examples**    SXPress:SPARAM:AGGRESSOR:CLOCK:FREQUENCY 100E6 sets the clock frequency of the aggressor signal to 100 MHz.  
 SXPress:SPARAM:AGGRESSOR:CLOCK:FREQUENCY? returns the clock frequency of the aggressor signal.

## SXPress:SPARam:AGGRessor:DIRection

This command sets or returns the aggressor direction relative to the direction of the victim.

**Group** ISI and S-Parameter

**Syntax** SXPress:SPARam:AGGRessor:DIRection <direction>  
SXPress:SPARam:AGGRessor:DIRection?

**Related Commands** [SXPress:SPARam:AGGRessor:TYPE](#)

**Arguments** <direction>::={FORWARD | REVERSE}  
FORWARD indicates that the signal flow of the aggressor is same as the victim.  
REVERSE indicates that the signal flow of the aggressor is opposite to the victim.

**Returns** <type>

**Examples** SXPress:SPARam:AGGRessor:DIRection FORWARD sets the direction of the aggressor signal to be same as the victim signal.  
SXPress:SPARam:AGGRessor:DIRection? returns the direction of the aggressor signal.

## SXPress:SPARam:AGGRessor:PATtern:DRATE

This command sets or returns the data rate of the aggressor signal. This is applicable only when [SXPress:SPARam:AGGRessor:TYPE](#) is set to Pattern.

**Group** ISI and S-Parameter

**Syntax** SXPress:SPARam:AGGRessor:PATtern:DRATE <NR3>  
SXPress:SPARam:AGGRessor:PATtern:DRATE?

**Related Commands** [SXPress:SPARam:AGGRessor:TYPE](#), [SXPress:SPARam:AGGRessor:PATtern:NAME](#)

**Arguments** <NR3>::=<numeric>

**Returns** <NR3>

**Examples** `SXPRESS:SPARAM:AGGRESSOR:PATTERN:DRATE 3E9` sets the data rate of the aggressor signal to 3 Gbps.

`SXPRESS:SPARAM:AGGRESSOR:PATTERN:DRATE?` returns the data rate of the aggressor signal.

## SXPress:SPARAm:AGGRessor:PATTErn:NAME

This command sets or returns the name of the aggressor pattern file.

**Group** ISI and S-Parameter

**Syntax** `SXPress:SPARAm:AGGRessor:PATTErn:NAME <name>`  
`SXPress:SPARAm:AGGRessor:PATTErn:NAME?`

**Related Commands** [SXPress:SPARAm:AGGRessor:TYPE](#)

**Arguments** <name>:=Name of the pattern file

**Returns** <type>

**Examples** `SXPRESS:SPARAM:AGGRESSOR:PATTERN:NAME "PRBS7.txt"` selects PRBS7.txt as the aggressor pattern file.

`SXPRESS:SPARAM:AGGRESSOR:PATTERN:NAME?` returns the aggressor pattern file.

## SXPress:SPARAm:AGGRessor:RTIME

This command sets or returns the rise time of the aggressor signal. This is applicable only when [SXPress:SPARAm:AGGRessor:TYPE](#) is set to Pattern or Clock.

**Group** ISI and S-Parameter

**Syntax** `SXPress:SPARAm:AGGRessor:RTIME <NR3>`  
`SXPress:SPARAm:AGGRessor:RTIME?`

<b>Related Commands</b>	<a href="#">SXPress:SPARam:AGGRessor:TYPE</a>
<b>Arguments</b>	<NR3>::=<numeric>
<b>Returns</b>	<NR3>
<b>Examples</b>	<p>SXPRESS:SPARAM:AGGRESSOR:RTIME 75E-12 sets the rise time of the aggressor signal to 75 ps.</p> <p>SXPRESS:SPARAM:AGGRESSOR:RTIME? returns the rise time of the aggressor signal.</p>

## SXPRESS:SPARam:AGGRessor:RXMinus:SElect

This command sets or returns the negative receiver port of the aggressor signal.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<p>SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect &lt;NR1&gt;</p> <p>SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect?</p>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARam:AGGRessor:RXPLus:SElect</a> , <a href="#">SXPRESS:SPARam:AGGRessor:TXMinus:SElect</a>
<b>Arguments</b>	<NR1>::={ONE   TWO   THRee   FOUR   FIVE   SIX   SEVen   EIGHt}
<b>Returns</b>	<NR1>
<b>Examples</b>	<p>SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect FOUR selects the fourth negative receiver port of the aggressor signal.</p> <p>SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect? returns the selected negative receiver port of the aggressor signal.</p>

## SXPRESS:SPARam:AGGRessor:RXPLus:SElect

This command sets or returns the positive receiver port selection of the aggressor for the single-ended s8p file.



<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:AGGRESSOR:RXPLUS:SElect &lt;NR1&gt;</code> <code>SXPRESS:SPARAM:AGGRESSOR:RXPLUS:SElect?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect</a> , <a href="#">SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SElect</a>
<b>Arguments</b>	<code>&lt;NR1&gt; ::= {ONE   TWO   THRee   FOUR   FIVE   SIX   SEVen   EIGHt}</code>
<b>Returns</b>	<code>&lt;NR1&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:AGGRESSOR:RXPLUS:SELECT FIVE</code> selects the fifth positive receiver port of the aggressor signal. <code>SXPRESS:SPARAM:AGGRESSOR:RXPLUS:SELECT?</code> returns the selected positive receiver port of the aggressor signal.

## SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SElect

This command sets or returns the negative transmitter port of the aggressor signal.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SElect &lt;NR1&gt;</code> <code>SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SElect?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SElect</a> , <a href="#">SXPRESS:SPARAM:AGGRESSOR:RXMINUS:SElect</a>
<b>Arguments</b>	<code>&lt;NR1&gt; ::= {ONE   TWO   THRee   FOUR   FIVE   SIX   SEVen   EIGHt}</code>
<b>Returns</b>	<code>&lt;NR1&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SELECT FOUR</code> selects the fourth negative transmitter port of the aggressor signal. <code>SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SELECT?</code> returns the selected negative transmitter port of the aggressor signal.

## SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SELEct

This command sets or returns the positive transmitter port selection of the aggressor for the single-ended s8p file.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SELEct &lt;NR1&gt;</code> <code>SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SELEct?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:AGGRESSOR:RXPLUS:SELEct</a> , <a href="#">SXPRESS:SPARAM:AGGRESSOR:TXMINUS:SELEct</a>
<b>Arguments</b>	<code>&lt;NR1&gt; ::= {ONE   TWO   THREe   FOUR   FIVE   SIX   SEVen   EIGHt}</code>
<b>Returns</b>	<code>&lt;NR1&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SELEct THREE</code> selects the third positive transmitter port of the aggressor signal. <code>SXPRESS:SPARAM:AGGRESSOR:TXPLUS:SELEct?</code> returns the selected positive transmitter port of the aggressor signal.

## SXPRESS:SPARAM:AGGRESSOR:TYPE

This command sets or returns the type of the aggressor signal of the s8p file.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:AGGRESSOR:TYPE &lt;type&gt;</code> <code>SXPRESS:SPARAM:AGGRESSOR:TYPE?</code>
<b>Arguments</b>	<code>&lt;type&gt; ::= {PATTErn   CLOCk   VICTIm}</code> <p>PATTErn indicates that the aggressor signal is another pattern file.</p> <p>CLOCk indicates that the aggressor signal is a clock pattern.</p> <p>VICTIm indicates that the aggressor signal is same as the victim signal and has all the characteristics of the victim signal.</p>

**Returns** <type>

**Examples** `SXPRESS:SPARAM:AGGRESSOR:TYPE CLOCK` sets the clock signal as the aggressor signal.  
`SXPRESS:SPARAM:AGGRESSOR:TYPE?` returns the type of the aggressor signal.

## SXPRESS:SPARAM:CASCADE:ENABLE

This command enables or disables S-Parameter cascading.

**Group** ISI and S-Parameter

**Syntax** `SXPRESS:SPARAM:CASCADE:ENABLE <state>`  
`SXPRESS:SPARAM:CASCADE:ENABLE?`

**Related Commands** [SXPRESS:SPARAM:CASCADE:FILE\[n\]:ENABLE](#), [SXPRESS:SPARAM:CASCADE:FILE\[n\]:NAME](#)

**Arguments** <state>::=<Boolean>  
 0 indicates False.  
 1 indicates True.  
 At SXPRESS:SDEFault, this returns 0.

**Returns** <state>

**Examples** `SXPRESS:SPARAM:CASCADE:ENABLE 1` enables S-Parameter file cascading.  
`SXPRESS:SPARAM:CASCADE:ENABLE?` returns 0 if S-Parameter file cascading is not enabled.

## SXPRESS:SPARAM:CASCADE:FILE[n]:ENABLE

This command enables or disables cascading for the specified cascading unit.  
 The value of n is 1 | 2 | 3 | 4 | 5 | 6.

**Group** ISI and S-Parameter

<b>Syntax</b>	<code>SXPRESS:SPARAM:CASCADE:FILE[n]:ENABLE &lt;state&gt;</code> <code>SXPRESS:SPARAM:CASCADE:FILE[n]:ENABLE?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:CASCADE:ENABLE</a> , <a href="#">SXPRESS:SPARAM:CASCADE:FILE[n]:NAME</a>
<b>Arguments</b>	<code>&lt;state&gt;::=&lt;Boolean&gt;</code>  0 indicates False. 1 indicates True.  At <code>SXPRESS:SDEFAULT</code> , this returns 0 for <code>n = 2   3   4   5   6</code> and 1 for <code>n = 1</code> .
<b>Returns</b>	<code>&lt;state&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:CASCADE:FILE1:ENABLE 1</code> enables S-Parameter file cascading for the first cascading unit.  <code>SXPRESS:SPARAM:CASCADE:FILE1:ENABLE?</code> returns 0 if S-Parameter file cascading is not enabled for the first cascading unit.

## SXPRESS:SPARAM:CASCADE:FILE[n]:NAME

This command sets or returns the S-Parameter file for cascading. The drive may be a local or a network drive. If the full path is not specified, the command sets the file in the current path.

The value of `n = 1 | 2 | 3 | 4 | 5 | 6`.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:CASCADE:FILE[n]:NAME &lt;file name&gt;</code> <code>SXPRESS:SPARAM:CASCADE:FILE[n]:NAME?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:CASCADE:ENABLE</a> , <a href="#">SXPRESS:SPARAM:CASCADE:FILE[n]:ENABLE</a>
<b>Arguments</b>	<code>&lt;file name&gt;::=&lt;string&gt;</code>  At <code>SXPRESS:SDEFAULT</code> , this returns null or “ ” for <code>n = 2   3   4   5   6</code> and <code>...\Samples\Touchstone\40inISITrace.s4p</code> for <code>n = 1</code> .

**Returns** <string>

**Examples** `SXPRESS:SPARAM:CASCADE:FILE1:NAME "C:\SPARAM\Cable.s4p"` sets the S-Parameter file of the first cascading unit as **Cable.s4p** in the C:\SPARAM directory.

`SXPRESS:SPARAM:CASCADE:FILE2:NAME?` returns the S-Parameter file of the second cascading unit.

## SXPRESS:SPARAM:EIGHTP:SELECTION

This command sets or returns the 8-port selection (s8p) of the S-Parameter filter.

**Group** ISI and S-Parameter

**Syntax** `SXPRESS:SPARAM:EIGHTP:SELECTION <type>`  
`SXPRESS:SPARAM:EIGHTP:SELECTION?`

**Arguments** <type> ::= {SING | DIFFERENTIAL}

**Returns** <type>

**Examples** `SXPRESS:SPARAM:EIGHTP:SELECTION SING` sets the 8-port type of the S-Parameter filter to Single-ended.

`SXPRESS:SPARAM:EIGHTP:SELECTION?` returns the 8-port type of the S-Parameter filter.

## SXPRESS:SPARAM:ENABLE

This command enables or disables the S-Parameter filter state.

**Group** ISI and S-Parameter

**Syntax** `SXPRESS:SPARAM:ENABLE <state>`  
`SXPRESS:SPARAM:ENABLE?`

**Related Commands** [SXPRESS:SPARAM:TFILE](#)

**Arguments** <state>::=<Boolean>  
 0 indicates False.  
 1 indicates True.  
 At SXPRESS:SDEFault, this returns 0.

**Returns** <state>

**Examples** SXPRESS:SPARAM:ENABLE 1 enables the S-Parameter filter.  
 SXPRESS:SPARAM:ENABLE? returns 0 if the S-Parameter filter is disabled.

## SXPRESS:SPARAM:FOURport:ASSignment:RXMinus

This command sets or returns the S-Parameter port assignment for the RxMinus port.

**Group** ISI and S-Parameter

**Syntax** SXPRESS:SPARAM:FOURport:ASSignment:RXMinus <port>  
 SXPRESS:SPARAM:FOURport:ASSignment:RXMinus?

**Related Commands** [SXPRESS:SPARAM:FOURport:TYPE](#), [SXPRESS:SPARAM:FOURport:ASSignment:TXMinus](#), [SXPRESS:SPARAM:FOURport:ASSignment:TXPlus](#), [SXPRESS:SPARAM:FOURport:ASSignment:RXPlus](#)

**Arguments** <port>::={ONE | TWO | THRee | FOUR}  
 At SXPRESS:SDEFault, this returns ONE.

**Returns** <port>

**Examples** SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXMINUS TWO sets the port assignment of the RxMinus to port two.  
 SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXMINUS? returns the port assignment of the RxMinus port.

## SXPRESS:SPARAM:FOURport:ASSignment:RXPLus

This command sets or returns the S-Parameter port assignment for the RxPlus port.

**Group** ISI and S-Parameter

**Syntax** SXPRESS:SPARAM:FOURport:ASSignment:RXPLus <port>  
SXPRESS:SPARAM:FOURport:ASSignment:RXPLus?

**Related Commands** [SXPRESS:SPARAM:FOURport:TYPE](#), [SXPRESS:SPARAM:FOURport:ASSignment:TXMinus](#), [SXPRESS:SPARAM:FOURport:ASSignment:TXPLus](#), [SXPRESS:SPARAM:FOURport:ASSignment:RXMinus](#)

**Arguments** <port>::={ONE | TWO | THREE | FOUR}  
At SXPRESS:SDEFault, this returns ONE.

**Returns** <port>

**Examples** SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXPLUS TWO sets the port assignment of the RxPlus to port two.  
SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:RXPLUS? returns the port assignment of the RxPlus port.

## SXPRESS:SPARAM:FOURport:ASSignment:TXMinus

This command sets or returns the S-Parameter port assignment for the TxMinus port.

**Group** ISI and S-Parameter

**Syntax** SXPRESS:SPARAM:FOURport:ASSignment:TXMinus <port>  
SXPRESS:SPARAM:FOURport:ASSignment:TXMinus?

**Related Commands** [SXPRESS:SPARAM:FOURport:TYPE](#), [SXPRESS:SPARAM:FOURport:ASSignment:TXPLus](#), [SXPRESS:SPARAM:FOURport:ASSignment:RXPLus](#), [SXPRESS:SPARAM:FOURport:ASSignment:RXMinus](#)

<b>Arguments</b>	<code>&lt;port&gt;::={ONE   TWO   THRee   FOUR}</code> At <code>SXPRESS:SDEFault</code> , this returns ONE.
<b>Returns</b>	<code>&lt;port&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXMINUS TWO</code> sets the port assignment of the TxMinus to port two. <code>SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXMINUS?</code> returns the port assignment of the TxMinus port.

## SXPRESS:SPARAM:FOURport:ASSignment:TXPLus

This command sets or returns the S-Parameter port assignment for TxMinus port.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:FOURport:ASSignment:TXPLus &lt;port&gt;</code> <code>SXPRESS:SPARAM:FOURport:ASSignment:TXPLus?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:FOURport:TYPE</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSignment:TXMinus</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSignment:RXPLus</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSignment:RXMinus</a>
<b>Arguments</b>	<code>&lt;port&gt;::={ONE   TWO   THRee   FOUR}</code> At <code>SXPRESS:SDEFault</code> , this returns ONE.
<b>Returns</b>	<code>&lt;port&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXPLUS TWO</code> sets the port assignment of TxPlus to port two. <code>SXPRESS:SPARAM:FOURPORT:ASSIGNMENT:TXPLUS?</code> returns the port assignment of the TxPlus port.

## SXPRESS:SPARAM:FOURport:LAYout

This command sets or returns the 4-port layout of the S-Parameter filter.



<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:FOURport:LAYOUT &lt;layout&gt;</code> <code>SXPRESS:SPARAM:FOURport:LAYOUT?</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:FOURport:TYPE</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:TXMINUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:TXPLUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:RXPLUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:RXMINUS</a>
<b>Arguments</b>	<code>&lt;layout&gt;::={TYPICAL   ALTERNATE}</code> At <code>SXPRESS:SDEFAULT</code> , this returns <code>TYPICAL</code> .
<b>Returns</b>	<code>&lt;layout&gt;</code>
<b>Examples</b>	<code>SXPRESS:SPARAM:FOURPORT:LAYOUT TYPICAL</code> sets the 4-port layout of the S-Parameter filter to typical. <code>SXPRESS:SPARAM:FOURPORT:LAYOUT?</code> returns the 4-port layout of the S-Parameter filter.

## SXPRESS:SPARAM:FOURport:TYPE

This command sets or returns the 4-port type of the S-Parameter filter.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<code>SXPRESS:SPARAM:FOURport:TYPE &lt;port type&gt;</code> <code>SXPRESS:SPARAM:FOURport:TYPE</code>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:FOURport:LAYOUT</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:TXMINUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:TXPLUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:RXPLUS</a> , <a href="#">SXPRESS:SPARAM:FOURport:ASSIGNMENT:RXMINUS</a>
<b>Arguments</b>	<code>&lt;port type&gt;::={SINGLED   DIFFERENTIAL}</code> At <code>SXPRESS:SDEFAULT</code> , this returns <code>DIFFERENTIAL</code> .
<b>Returns</b>	<code>&lt;port type&gt;</code>

- Examples**    `SXPRESS:SPARAM:FOURPORT:TYPE SINGLEENDED` sets the 4-port type of the S-Parameter filter to Single-ended.
- `SXPRESS:SPARAM:FOURPORT:TYPE?` returns the 4-port type of the S-Parameter filter.

## SXPRESS:SPARAM:IFILTER:ENABLE

This command enables or disables the inverse filter state of the S-Parameter.

**Group**    ISI and S-Parameter

**Syntax**    `SXPRESS:SPARAM:IFILTER:ENABLE <state>`  
`SXPRESS:SPARAM:IFILTER:ENABLE?`

**Related Commands**    [SXPRESS:SPARAM:TFILE](#), [SXPRESS:SPARAM:IFILTER:FFILE](#)

**Arguments**    `<state>::=<Boolean>`

0 indicates False.

1 indicates True.

At `SXPRESS:SDEFAULT`, this returns 0.

**Returns**    `<state>`

**Examples**    `SXPRESS:SPARAM:IFILTER:ENABLE 1` enables the S-Parameter inverse filter.

`SXPRESS:SPARAM:IFILTER:ENABLE?` returns 0 if the S-Parameter inverse filter is disabled.

## SXPRESS:SPARAM:IFILTER:FFILE (No Query Form)

This command sets the user-defined S-Parameter inverse filter file.

**Group**    ISI and S-Parameter

**Syntax**    `SXPRESS:SPARAM:IFILTER:FFILE <file name>`

**Related Commands**    [SXPRESS:SCRAMBLE:ENABLE](#), [SXPRESS:SPARAM:IFILTER:ENABLE](#)

<b>Arguments</b>	<file name>::=<string> At SXPress:SDEFault, this returns null or “ ”.
<b>Examples</b>	SXPRESS:SPARAM:IFILTER:FFILE “C:\Samples\InverseFilter.flr” sets the S-Parameter inverse filter file as <b>Inversefilter.flr</b> in the C:\Samples directory.

## SXPRESS:SPARAM:SCALING

This command sets or returns the ISI scaling of the S-Parameter filter.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	SXPRESS:SPARAM:SCALING <NR3> SXPRESS:SPARAM:SCALING?
<b>Related Commands</b>	<a href="#">SXPRESS:SCRAMBLE:ENABLE</a>
<b>Arguments</b>	<NR3> At SXPress:SDEFault, this returns 1.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:SPARAM:SCALING 1.5 sets the ISI scaling factor to 1.5. SXPRESS:SPARAM:SCALING? returns the ISI scaling factor.

## SXPRESS:SPARAM:TFILE (No Query Form)

This command sets the touchstone file of the S-Parameter.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	SXPRESS:SPARAM:TFILE <file name>
<b>Related Commands</b>	<a href="#">SXPRESS:SCRAMBLE:ENABLE</a>

**Arguments** <file name>::=<string>

**Examples** SXPRESS:SPARAM:TFILE "C:\Samples\Pattern.s4p" will set the S-Parameter filter file as **Patterns.s4p** in the C:\Samples directory.

## SXPRESS:SPARAM:TWOPort:SELECTION

This command sets or returns the 2-port channel location of the S-Parameter.

**Group** ISI and S-Parameter

**Syntax** SXPRESS:SPARAM:TWOPort:SELECTION <selectport>  
SXPRESS:SPARAM:TWOPort:SELECTION?

**Related Commands** [SXPRESS:SCRamble:ENABLE](#)

**Arguments** <selectport>::={S2ONe | S1TWo}  
At SXPRESS:SDEFault, this returns S2ONe.

**Returns** <selectport>

**Examples** SXPRESS:SPARAM:TWOPort:SELECTION S2ONe sets the channel location of the 2-port parameter.  
SXPRESS:SPARAM:TWOPort:SELECTION? returns the selected port.

## SXPRESS:SPARAM:VICTim:RXMinus:SElect

This command sets or returns the negative receiver port of the victim signal.

**Group** ISI and S-Parameter

**Syntax** SXPRESS:SPARAM:VICTim:RXMinus:SElect <NR1>  
SXPRESS:SPARAM:VICTim:RXMinus:SElect?

**Related Commands** [SXPRESS:SPARAM:VICTim:RXPLus:SElect](#), [SXPRESS:SPARAM:VICTim:TXMinus:SElect](#)

<b>Arguments</b>	<NR1> ::= {ONE   TWO   THREe   FOUR   FIVE   SIX   SEVen   EIGHt}
<b>Returns</b>	<NR1>
<b>Examples</b>	<p>SXPRESS:SPARAM:VICTIM:RXMINUS:SELECT THREE selects the third negative receiver port of the victim signal.</p> <p>SXPRESS:SPARAM:VICTIM:RXMINUS:SELECT? returns the selected negative receiver port of the victim signal.</p>

## SXPRESS:SPARAM:VICTIM:RXPLUS:SELEct

This command sets or returns the positive receiver port of the victim signal.

<b>Group</b>	ISI and S-Parameter
<b>Syntax</b>	<p>SXPRESS:SPARAM:VICTIM:RXPLUS:SELEct &lt;NR1&gt;</p> <p>SXPRESS:SPARAM:VICTIM:RXPLUS:SELEct?</p>
<b>Related Commands</b>	<a href="#">SXPRESS:SPARAM:VICTIM:RXMINUS:SELEct</a> , <a href="#">SXPRESS:SPARAM:VICTIM:TXPLUS:SELEct</a>
<b>Arguments</b>	<NR1> ::= {ONE   TWO   THREe   FOUR   FIVE   SIX   SEVen   EIGHt}
<b>Returns</b>	<NR1>
<b>Examples</b>	<p>SXPRESS:SPARAM:VICTIM:RXPLUS:SELECT TWO selects the second positive receiver port of the victim signal.</p> <p>SXPRESS:SPARAM:VICTIM:RXPLUS:SELECT? returns the selected positive receiver port of the victim signal.</p>

## SXPRESS:SPARAM:VICTIM:TXMINUS:SELEct

This command sets or returns the negative transmitter port of the victim signal.

<b>Group</b>	ISI and S-Parameter
--------------	---------------------

**Syntax**      `SXPRESS:SPARAM:VICTIM:TXMINUS:SELECT <NR1>`  
`SXPRESS:SPARAM:VICTIM:TXMINUS:SELECT?`

**Related Commands**      [SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT](#), [SXPRESS:SPARAM:VICTIM:RXMINUS:SELECT](#)

**Arguments**      `<NR1> ::= {ONE | TWO | THREE | FOUR | FIVE | SIX | SEVEN | EIGHT}`

**Returns**      `<NR1>`

**Examples**      `SXPRESS:SPARAM:VICTIM:TXMINUS:SELECT THREE` selects the third negative transmitter port of the victim signal.

`SXPRESS:SPARAM:VICTIM:TXMINUS:SELECT?` returns the selected negative transmitter port of the victim signal.

## SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT

This command sets or returns the positive transmitter port of the victim signal.

**Group**      ISI and S-Parameter

**Syntax**      `SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT <NR1>`  
`SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT?`

**Related Commands**      [SXPRESS:SPARAM:VICTIM:TXMINUS:SELECT](#), [SXPRESS:SPARAM:VICTIM:RXPLUS:SELECT](#)

**Arguments**      `<NR1> ::= {ONE | TWO | THREE | FOUR | FIVE | SIX | SEVEN | EIGHT}`

**Returns**      `<NR1>`

**Examples**      `SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT ONE` selects the first positive transmitter port of the victim signal.

`SXPRESS:SPARAM:VICTIM:TXPLUS:SELECT?` returns the selected positive transmitter port of the victim signal.

## SXPRESS:SREStore (No Query Form)

This command loads the application setup values from the file and restores the parameter settings.

**Group** Save and restore setup

**Syntax** SXPRESS:SREStore <setupfile path>[,<drive letter>]

**Arguments** <setupfile path>::=<string>  
<drive letter>::=<string>

**Examples** SXPRESS:SRESTORE "\bin\Setup1.sxs", "c:" restores the setup **Setup1.sxs** from the C:\bin directory on to the application.

## SXPRESS:SSAVE (No Query Form)

This command saves the current application setup in a file which can be reloaded later to restore the current settings.

**Group** Save and restore setup

**Syntax** SXPRESS:SSAVE <setupfile path>[,<drive letter>]

**Arguments** setupfile path::=<string>  
drive letter::=<string>

**Examples** SXPRESS:SSAVE "\bin\Setup1.sxs", "c:" saves the current setup of the application as **Setup1.sxs** in the C:\bin directory.

## SXPRESS:SSC:CUSTOM:FILE (No Query Form)

This command sets the SSC custom file.

**Group** SSC

**Syntax** SXPRESS:SSC:CUSTOM:FILE <file\_name>

**Related Commands**    [SXPress:SSC:ENABLE](#), [SXPress:SSC:SHAPE](#)

**Arguments**    <file\_name>::=<string>  
 At SXPress:SDEfault, this returns null (“”).

**Examples**    SXPress:SSC:CUSTOM:FILE “test.xls” sets the SSC custom shape definition file as **test.xls**.

## SXPress:SSC:DFDT

This command sets or returns the df/dt value of SSC.

**Group**    SSC

**Syntax**    SXPress:SSC:DFDT <NR3>  
 SXPress:SSC:DFDT?

**Related Commands**    [SXPress:SSC:ENABLE](#), [SXPress:SSC:SHAPE](#), [SXPress:SSC:SPRead](#)

**Arguments**    <NR3>  
 At SXPress:SDEfault, this returns 0 ppm.

**Returns**    <NR3>

**Examples**    SXPress:SSC:DFDT 100 sets the df/dt value to 100.  
 SXPress:SSC:DFDT? returns the df/dt value.

## SXPress:SSC:DFDT:DURATION

This command sets or returns the df/dt duration value of SSC.

**Group**    SSC

**Syntax**    SXPress:SSC:DFDT:DURATION <NR3>  
 SXPress:SSC:DFDT:DURATION?



**Related Commands** [SXPress:SSC:ENABLE](#), [SXPress:SSC:DFDT](#), [SXPress:SSC:DFDT:LOCation](#)

**Arguments** <NR3>  
At SXPress:SDEFault, this returns 1.50  $\mu$ s.

**Returns** <NR3>

**Examples** `SXPRESS:SSC:DFDT:DURATION 2.40` sets the df/dt duration value to 2.40  $\mu$ s.  
`SXPRESS:SSC:DFDT:DURATION?` returns the df/dt duration value.

## SXPress:SSC:DFDT:LOCation

This command sets or returns the df/dt location value of SSC.

**Group** SSC

**Syntax** `SXPress:SSC:DFDT:LOCation <NR3>`  
`SXPress:SSC:DFDT:LOCation?`

**Related Commands** [SXPress:SSC:ENABLE](#), [SXPress:SSC:DFDT](#), [SXPress:SSC:DFDT:DURation](#)

**Arguments** <NR3>  
At SXPress:SDEFault, this returns 50%.

**Returns** <NR3>

**Examples** `SXPRESS:SSC:DFDT:LOCATION 60` sets the df/dt location value to 60%.  
`SXPRESS:SSC:DFDT:LOCATION?` returns the df/dt location value.

## SXPress:SSC:ENABLE

This command enables or disables the SSC state. When disabled, the SSC is not applied to the base data.

**Group** SSC

**Syntax**      `SXPRESS:SSC:ENABLE <state>`  
`SXPRESS:SSC:ENABLE?`

**Related Commands**      This command is related to all other SSC commands.

**Arguments**      `<state>::=<Boolean>`  
 0 indicates False.  
 1 indicates True.  
 At `SXPRESS:SDEFAULT`, this returns 0.

**Returns**      `<state>`

**Examples**      `SXPRESS:SSC:ENABLE 1` enables SSC.  
`SXPRESS:SSC:ENABLE?` returns 0 if SSC is disabled.

## SXPRESS:SSC:FREQUENCY:DEVIATION

This command sets or returns the SSC frequency deviation.

**Group**      SSC

**Syntax**      `SXPRESS:SSC:FREQUENCY:DEVIATION <NR3>`  
`SXPRESS:SSC:FREQUENCY:DEVIATION?`

**Related Commands**      [SXPRESS:SSC:ENABLE](#), [SXPRESS:SSC:SHAPE](#), [SXPRESS:SSC:SPREAD](#),  
[SXPRESS:SSC:DFDT](#)

**Arguments**      `<NR3>`  
 At `SXPRESS:SDEFAULT`, this returns 0 ppm.

**Returns**      `<NR3>`

**Examples**      `SXPRESS:SSC:FREQUENCY:DEVIATION 4000` sets the SSC frequency deviation to 4000 ppm.  
`SXPRESS:SSC:FREQUENCY:DEVIATION?` returns the SSC frequency deviation.

## SXPRESS:SSC:FREQUENCY:MODULATION

This command sets or returns the SSC frequency modulation.

<b>Group</b>	SSC
<b>Syntax</b>	SXPRESS:SSC:FREQUENCY:MODULATION <NR3> SXPRESS:SSC:FREQUENCY:MODULATION?
<b>Related Commands</b>	<a href="#">SXPRESS:SSC:ENABLE</a> , <a href="#">SXPRESS:SSC:SHAPE</a> , <a href="#">SXPRESS:SSC:SPREAD</a> , <a href="#">SXPRESS:SSC:DFDT</a> , <a href="#">SXPRESS:SSC:FREQUENCY:DEVIATION</a>
<b>Arguments</b>	<NR3> At SXPRESS:SDEFAULT, this returns 33 Hz.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:SSC:FREQUENCY:MODULATION 33000 sets the SSC frequency modulation to 33 KHz. SXPRESS:SSC:FREQUENCY:MODULATION? returns the SSC frequency modulation.

## SXPRESS:SSC:SHAPE

This command sets or returns the shape of the SSC profile.

<b>Group</b>	SSC
<b>Syntax</b>	SXPRESS:SSC:SHAPE <shape> SXPRESS:SSC:SHAPE?
<b>Related Commands</b>	<a href="#">SXPRESS:SSC:SPREAD</a>
<b>Arguments</b>	<shape> ::= {SINE   TRIANGLE   CUSTOM} At SXPRESS:SDEFAULT, this returns SINE.
<b>Returns</b>	<shape>

**Examples**    `SXPRESS:SSC:SHAPE SINE` sets the shape of the SSC profile to sinusoidal.  
`SXPRESS:SSC:SHAPE?` returns the shape of the SSC profile.

## SXPRESS:SSC:SPREAD

This command sets or returns the spread of the SSC profile.

**Group**    `SSC`

**Syntax**    `SXPRESS:SSC:SPREAD <spread>`  
`SXPRESS:SSC:SPREAD?`

**Related Commands**    [SXPRESS:SSC:SHAPE](#)

**Arguments**    `<spread> ::= {UP | DOWN | CENTRE | UNEQUAL}`  
At `SXPRESS:SDEFAULT`, this returns `DOWN`.

**Returns**    `<spread>`

**Examples**    `SXPRESS:SSC:SPREAD UNEQUAL` sets the spread of the SSC profile to unequal.  
`SXPRESS:SSC:SPREAD?` returns the spread of the SSC profile.

## SXPRESS:SSC:USPREAD:PERCENTAGE

This command sets or returns the percentage of the unequal spread if the selected spread type is **Unequal**. If some other spread type is selected, this value is not considered.

**Group**    `SSC`

**Syntax**    `SXPRESS:SSC:USPREAD:PERCENTAGE <NR3>`  
`SXPRESS:SSC:USPREAD:PERCENTAGE?`

**Related Commands**    [SXPRESS:SSC:SPREAD](#)

---

<b>Arguments</b>	<NR3> At SXPRESS:SDEFault, this returns 0.
<b>Returns</b>	<NR3>
<b>Examples</b>	SXPRESS:SSC:USPREAD:PERCENTAGE 50 sets the unequal spread percentage to 50%. SXPRESS:SSC:USPREAD:PERCENTAGE? returns the unequal spread percentage.

## SXPRESS:WAVEform:DELEte (No Query Form)

This command deletes the waveform from the waveform list.

**Group** Waveform list

**Syntax** SXPRESS:WAVEform:DELEte <waveform>

**Related Commands** [SXPRESS:WFMName](#)

**Arguments** <waveform>::=<string>

**Examples** SXPRESS:WAVEFORM:DELETE "CLOCK" deletes the waveform **Clock**.

## SXPRESS:WAVEform:REName (No Query Form)

This command renames the existing waveform.

The waveform name should be according to Microsoft Windows file naming conventions.

**Group** Waveform list

**Syntax** SXPRESS:WAVEform:REName <cur name>,<new name>

**Related Commands** [SXPRESS:WFMName](#)

**Arguments**     <cur name>::=<string>  
                   <new name>::=<string>

**Examples**     SXPRESS:WAVEFORM:RENAME "CLOCK", "TESTCLOCK" renames the waveform from Clock to TestClock.

## SXPRESS:WAVEform:SAVE (No Query Form)

This command saves the existing waveform as a .wfm file.

**Group**         Waveform list

**Syntax**        SXPRESS:WAVEform:SAVE <waveform name>,[,<file path>[,<drive letter>]]

**Related Commands**    [SXPRESS:WFMName](#)

**Arguments**     <waveform name>::=<string>. This is the name of an existing waveform.  
                   <file path>::=<string>. The file path where the waveform is saved.

---

**NOTE.** *The file name should follow the Microsoft Windows file naming conventions.*

---

**drive letter**::=<string>. This is a two character string specifying the disk drive name. If the optional parameter file path and drive letter are not specified, the waveform is saved as waveformname.wfm in the directory containing the software executables of the application.

**Examples**     SXPRESS:WAVEFORM:SAVE "Clock", "\bin\ClockTest.wfm" , "c:" saves the waveform as ClockTest.wfm in the C:\bin directory.

SXPRESS:WAVEFORM:SAVE CJTPAT saves the waveform CJTPAT as a CJTPAT.wfm in the directory containing the software executables of the application.

## SXPRESS:WAVEform:TRANSfer (No Query Form)

This command transfers the waveform data from the application to the AWG. The channel to which the waveform data is transferred is specified in the application.

Once the waveform is transferred, the corresponding channel output is set to the ON state in the AWG.

**Group** Waveform list

**Syntax** `SXPRESS:WAVEFORM:TRANSFER <waveform name>,<channel no>`

**Related Commands** [SXPRESS:WFMName](#), [SXPRESS:COMPile:TRANsfer:CHANnel](#)

**Arguments** `<waveform name>::=<string>`. This is the name of an existing waveform.  
`<channel no>::=<numeric>`. The AWG channel number to which the waveform is transferred.

**Examples** `SXPRESS:WAVEFORM:TRANSFER "CLOCK",2` transfers the waveform Clock to the Channel 2 (Ch 2) of the AWG.

## SXPRESS:WFMName (No Query Form)

This command sets the waveform name that is generated with the next compile command.

Waveform naming convention should be according to the Microsoft Windows file naming conventions. If the waveform name already exists, no error is generated. However, compilation fails in such cases since the waveforms cannot be overwritten from the Programmatic Interface.

**Group** Waveform list

**Syntax** `SXPRESS:WFMName <name>`

**Related Commands** [SXPRESS:COMPile](#)

**Arguments** `<name>::=<string>`  
 At `SXPRESS:SDEFault`, this returns null or "".

**Examples** `SXPRESS:WFNAME "TESTSIGNAL"` sets the waveform name as TestSignal.





# Index

## C

Command Groups, 2-3

## S

SXPress:BCOMpile:PJ:ENABLE, 2-11  
SXPress:BCOMpile:PJ:END, 2-12  
SXPress:BCOMpile:PJ:FREQUENCY<n>, 2-13  
SXPress:BCOMpile:PJ:INCREMENT, 2-13  
SXPress:BCOMpile:PJ:START, 2-14  
SXPress:BCOMpile:RJ:ENABLE, 2-14  
SXPress:BCOMpile:RJ:END, 2-15  
SXPress:BCOMpile:RJ:INCREMENT, 2-16  
SXPress:BCOMpile:RJ:START, 2-16  
SXPress:BDATA:PATTErn, 2-18  
SXPress:BDATA:STANDARD, 2-18  
SXPress:COMpile:BCOMpile:ENABLE, 2-21  
SXPress:COMpile:BWEXpansion:ENABLE, 2-22  
SXPress:COMpile:BWEXpansion:INTERleave, 2-23  
SXPress:COMpile:BWEXpansion:ZERoing, 2-23  
SXPress:COMpile:SRATE, 2-24  
SXPress:COMpile:SRATE:AUTomatic, 2-25  
SXPress:COMpile:TRANsfer:CHANnel, 2-26  
SXPress:COMpile:TRANsfer:ENABLE, 2-26  
SXPress:ENCode:ENCo8b10b:DISParity, 2-29  
SXPress:ENCode:ENCo8b10b:ENABLE, 2-30  
SXPress:ENCode:SCHEme, 2-30  
SXPress:ISTate:OFFSet, 2-33  
SXPress:ISTate:VALue, 2-33  
SXPress:MARKer<n>:CLOCK:FREQUENCY, 2-34  
SXPress:MARKer<n>:TRIGger:LENGth, 2-34  
SXPress:MARKer<n>:TYPE, 2-35  
SXPress:NOISe:ENABLE, 2-36  
SXPress:NOISe:LOCation, 2-37  
SXPress:PJ<n>:ENABLE, 2-38  
SXPress:PJ<n>:FREQUENCY, 2-39  
SXPress:PJ<n>:MAGNitude, 2-40  
SXPress:PJ<n>:PHASe, 2-40  
SXPress:PREEmphasis:ENABLE, 2-41  
SXPress:PREEmphasis:VALue, 2-41  
SXPress:RJ<n>:ENABLE, 2-42  
SXPress:RJ<n>:FREQUENCY:END, 2-43  
SXPress:RJ<n>:FREQUENCY:START, 2-44  
SXPress:RJ<n>:MAGNitude, 2-44  
SXPress:RSEed:ENABLE, 2-45  
SXPress:SCRamble:ENABLE, 2-47  
SXPress:SCRamble:POLYNomial, 2-47  
SXPress:SCRamble:RINit, 2-48  
SXPress:SEQuence:ELEMent:ADD, 2-49  
SXPress:SEQuence:ELEMent:BCOMpile, 2-49  
SXPress:SEQuence:ELEMent:DELEte, 2-50  
SXPress:SEQuence:ELEMent:GOTO:INDEX, 2-51  
SXPress:SEQuence:ELEMent:REPeat:COUnT, 2-51  
SXPress:SEQuence:ELEMent:REPeat:MODE, 2-52  
SXPress:SEQuence:ELEMent:WSTATe, 2-52  
SXPress:SEQuence:INDEX, 2-53  
SXPress:SEQuence:LENGth?, 2-54  
SXPress:SEQuence:WRAP:STATe, 2-54  
SXPress:SPARAm:AGGRessor:CLOCK:  
FREQUENCY, 2-55  
SXPress:SPARAm:AGGRessor:DIRection, 2-56  
SXPress:SPARAm:AGGRessor:PATTErn:DRATE, 2-56  
SXPress:SPARAm:AGGRessor:PATTErn:NAME, 2-57  
SXPress:SPARAm:AGGRessor:RTIME, 2-57  
SXPress:SPARAm:AGGRessor:RXMinus:  
SELEct, 2-58  
SXPress:SPARAm:AGGRessor:RXPLus:  
SELEct, 2-58  
SXPress:SPARAm:AGGRessor:TXMinus:  
SELEct, 2-59  
SXPress:SPARAm:AGGRessor:TXPLus:  
SELEct, 2-60  
SXPress:SPARAm:AGGRessor:TYPE, 2-60  
SXPress:SPARAm:CASCade:ENABLE, 2-61  
SXPress:SPARAm:CASCade:FILE[n]:ENABLE, 2-61  
SXPress:SPARAm:CASCade:FILE[n]:NAME, 2-62  
SXPress:SPARAm:EIGHtp:SELECTION, 2-63  
SXPress:SPARAm:ENABLE, 2-63  
SXPress:SPARAm:FOURport:ASSignment:  
RXMinus, 2-64  
SXPress:SPARAm:FOURport:ASSignment:  
RXPLus, 2-65  
SXPress:SPARAm:FOURport:ASSignment:  
TXMinus, 2-65  
SXPress:SPARAm:FOURport:ASSignment:  
TXPLus, 2-66  
SXPress:SPARAm:FOURport:LAYout, 2-66  
SXPress:SPARAm:FOURport:TYPE, 2-67

SXPRess:SPARam:IFILter:ENABLE, 2-68  
SXPRess:SPARam:IFILter:FFILE, 2-68  
SXPRess:SPARam:SCALing, 2-69  
SXPRess:SPARam:TFILE, 2-69  
SXPRess:SPARam:TWOPort:SELection, 2-70  
SXPRess:SPARam:VICTim:RXMinus:SElect, 2-70  
SXPRess:SPARam:VICTim:RXPLus:SElect, 2-71  
SXPRess:SPARam:VICTim:TXMinus:SElect, 2-71  
SXPRess:SPARam:VICTim:TXPLus:SElect, 2-72  
SXPRess:SSC:CUSTom:FILE, 2-73  
SXPRess:SSC:DFDT:DURation, 2-74  
SXPRess:SSC:DFDT:LOCation, 2-75  
SXPRess:SSC:FREQuency:DEVIation, 2-76  
SXPRess:SSC:FREQuency:MODulation, 2-77  
SXPRess:SSC:USPRead:PERCentage, 2-78  
SXPRess:WAVEform:DELeTe, 2-79  
SXPRess:WAVEform:REName, 2-79  
SXPRess:WAVEform:SAVE, 2-80  
SXPRess:WAVEform:TRANsfer, 2-80  
SXPRess:AMPLitude, 2-11  
SXPRess:BDATa:FILE, 2-17  
SXPRess:BDATa:TYPE, 2-20  
SXPRess:COMPIle, 2-20  
SXPRess:DCD:ENABLE, 2-27  
SXPRess:DCD:VALue, 2-28  
SXPRess:DRATe, 2-28  
SXPRess:FTIME, 2-31  
SXPRess:ISI:ENABle, 2-31  
SXPRess:ISI:VALue, 2-32  
SXPRess:MODE, 2-35  
SXPRess:NOISe:VALue, 2-37  
SXPRess:OPTions?, 2-38  
SXPRess:RFTYpe, 2-42  
SXPRess:RSEed:VALue, 2-45  
SXPRess:RTIME, 2-46  
SXPRess:SDEFault, 2-48  
SXPRess:SREStore, 2-73  
SXPRess:SSAVE, 2-73  
SXPRess:SSC:DFDT, 2-74  
SXPRess:SSC:ENABle, 2-75  
SXPRess:SSC:SHAPE, 2-77  
SXPRess:SSC:SPRead, 2-78  
SXPRess:WFMName, 2-81