

Tektronix[®]
COMMITTED TO EXCELLENCE

**7104
OSCILLOSCOPE
WITH OPTIONS**

INSTRUCTION MANUAL

**Tektronix, Inc.
P.O. Box 500
Beaverton, Oregon 97077**

Serial Number _____



WARRANTY

This Tektronix product is warranted against defective materials and workmanship, under normal use, for a period of one year from date of initial shipment. Tektronix will repair or replace, at its option, those products determined to be defective within the warranty period and returned, freight prepaid, to a Tektronix Service Center. There is no implied warranty for fitness of purpose.

Please direct all requests for service or replacement parts to the nearest Tektronix Service Center or Field Office; include the type or part number of the product and its serial number.

Copyright © 1978 by Tektronix, Inc. All rights reserved.
Content of this publication may not be reproduced in any form without the permission of Tektronix, Inc.

Products of Tektronix, Inc. and its subsidiaries are covered by U.S. and foreign patents and/or pending patents.

TEKTRONIX, TEK, SCOPE-MOBILE, TELEQUIPMENT, and  are registered trademarks of Tektronix, Inc.

Printed in U.S.A. Specification and price change privileges are reserved.

TABLE OF CONTENTS (CONT.)

	PAGE		PAGE
TRUBLESHOOTING THE CRT AND ASSOCIATED CIRCUITRY	4-12	PART I—PERFORMANCE CHECK	5-15
CRT DISPLAY SYMPTOM CHECKOUT PROCEDURE.....	4-13	INDEX TO PERFORMANCE CHECK PROCEDURE.....	5-15
CRT CIRCUIT TROUBLESHOOTING PROCEDURE.....	4-13	PERFORMANCE CHECK POWER-UP SEQUENCE.....	5-15
CORRECTIVE MAINTENANCE	4-22	A. Z-AXIS AND DISPLAY.....	5-16
OBTAINING REPLACEMENT PARTS	4-22	B. CALIBRATOR AND OUTPUT SIGNALS.....	5-18
SOLDERING TECHNIQUES.....	4-22	C. TRIGGER SYSTEM	5-22
COMPONENT REMOVAL AND REPLACEMENT	4-23	D. HORIZONTAL SYSTEM	5-24
DISPLAY UNIT KICKSTAND.....	4-23	E. VERTICAL SYSTEM.....	5-27
POWER-SUPPLY UNIT REMOVAL.....	4-23	F. READOUT SYSTEM.....	5-31
CATHODE-RAY TUBE REMOVAL.....	4-24	G. PHOTOGRAPHIC WRITING RATE	5-33
CATHODE-RAY TUBE REPLACEMENT	4-25	PART II—ADJUSTMENT AND PERFORMANCE CHECK	5-35
CIRCUIT BOARDS.....	4-25	INDEX TO ADJUSTMENT AND PERFORMANCE CHECK	5-35
PLUG-IN INTERFACE CONNECTORS	4-30	ADJUSTMENT AND PERFORMANCE CHECK POWER-UP SEQUENCE	5-35
DELAY LINE REMOVAL	4-30	A. POWER SUPPLY	5-36
SEMICONDUCTORS	4-30	B. Z-AXIS AND DISPLAY	5-38
INTERCONNECTING PINS.....	4-34	C. CALIBRATOR AND OUTPUT SIGNALS.....	5-46
PUSHBUTTON SWITCHES	4-35	D. TRIGGER SYSTEM	5-50
GRATICULE LIGHT BULBS	4-35	E. HORIZONTAL SYSTEM	5-54
POWER TRANSFORMER	4-35	F. VERTICAL SYSTEM.....	5-61
LINE FUSE	4-37	G. READOUT SYSTEM	5-68
ADJUSTMENT AFTER REPAIR	4-37	H. PHOTOGRAPHIC WRITING RATE.....	5-71
SECTION 5 CALIBRATION		SECTION 6 INSTRUMENT OPTIONS	
USING THESE PROCEDURES.....	5-2		
PERFORMANCE CHECK SUMMARY.....	5-2	SECTION 7 REPLACEABLE ELECTRICAL PARTS	
ADJUSTMENT INTERVAL	5-2		
TEKTRONIX FIELD SERVICE	5-2	SECTION 8 DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS	
TEST EQUIPMENT REQUIRED	5-12		
SPECIAL FIXTURES	5-12	SECTION 9 REPLACEABLE MECHANICAL PARTS	
TEST EQUIPMENT ALTERNATIVES	5-12		
		CHANGE INFORMATION	

LIST OF ILLUSTRATIONS

FIGURE NO.	PAGE	FIGURE NO.	PAGE
Frontis-piece	7104 Features	3-18	Readout word relating 10 possible character locations to the decimal point instructions that can be encoded; and the resultant crt display
1-1	7104 dimensional drawing	3-19	Flow chart for character generation by the Readout System
2-1	Front-panel controls, connectors and indicators	3-20	Theoretical timing diagrams for the Intensity Limiting stage
2-2	Rear-panel controls and connectors	3-21	(A) Representation of Inverter stage. Idealized waveforms of (B) total inverter current, I , (C) voltage of CR1234 and CR1241, and (D) voltage across primary
2-3	Definition of graticule measurement lines	4-1	Color code for resistors and capacitors
2-4	Location of readout on the crt identifying the originating plug-in and channel	4-2	Semiconductor lead configurations
3-1	Basic block diagram of the 7104 Oscilloscope	4-3	Orientation of multi-pin connectors
3-2	Breakdown of separate stages within Horizontal Logic IC (4428)	4-4	Current sensing waveform at R1284 showing: A. Power supplies not in current limit operation B. Power supplies in current limit operation
3-3	(A) Diagram of clock generator stage; (B) Idealized waveform for clock generator stage	4-5	Location of line shortage capacitor screws used for manually discharging C1216 and C1217
3-4	Idealized waveforms for the Vertical Chopped Blanking IC (U4320)	4-6	Typical waveforms on C1216 and C1217 with the line voltage set to about 20 volts
3-5	(A) Input and output pins for Chop Counter IC, U4340; (B) Idealized waveforms for Chop Counter stage	4-7	Current waveforms of T1230 showing burst operation at line voltage of about 60 volts
3-6	Logic diagram of Vertical Mode Logic stage	4-8	Current waveform at T1230 for normal inverter operation at line voltage of 115 volts
3-7	(A) Logic diagram of Trace Separation stage; (B) Table of input/output combinations	4-9	Waveform at TP1234 on the power-supply Inverter board with the line voltage at about 20 volts
3-8	Location of readout display on the crt identifying the originating plug-in and channel	4-10	Typical waveform at junction of R1811 and CR1747 on the High Voltage circuit board
3-9	Character selection matrix for 7104 Readout System	4-11	Typical waveform at junction of R1814 and CR1816 on the High Voltage circuit board
3-10	Typical readout display where only channel 2 of the Right Vertical and B Horizontal units is displayed	4-12	Power supply unit securing screws
3-11	Output waveforms of the Timer stage	4-13	Location of securing screws for the A6-Main Interface board
3-12	Detail of output at pins 12, 13, 14 and 16 of U2126	4-14	Correct placement of power transistor and mounting hardware on rear heat sink
3-13	Timer stage operation when display-skip condition occurs	4-15	HYPCON assembly removal and replacement
3-14	Timer relationship of the time-slot (TS) pulses produced by Q2159	4-16	Coaxial end-lead connector assembly
3-15	Typical encoding scheme for voltage-sensing plug-in unit. Coding shown for deflection factor of 100 microvolts	4-17	Exploded view of circuit-board pin and ferrule
3-16	Idealized current waveforms of (A) Row analog data and (B) Column analog data	4-18	Removal procedure for push-button switches
3-17	Typical output waveforms for Zeros Logic and Memory stage operation (at pin 7 of U2232)	5-1	Typical 7104 Photographic Writing Rate
		5-2	Readout display with Q2225 removed
		5-3	Typical 7104 Photographic Writing Rate

LIST OF ILLUSTRATIONS (CONT.)

FIGURE NO.

The illustrations in section 8 are located near their associated diagrams on the foldout page.

8-1	Location of circuit boards in the 7104.
8-2	Semiconductor lead configurations.
8-3	A1-Front Panel circuit board assembly.
8-4	A5-Mode Switch circuit board assembly.
8-5	A6-Main Interface circuit board assembly.
8-6	A13-Logic circuit board assembly.
8-7	A14-Trigger Selector circuit board assembly.
8-8	A15-Readout System circuit board assembly.
8-9	A27-Protection Circuit circuit board assembly.
8-10	A1-Front Panel circuit board assembly.
8-11	A16-Vertical Channel Switch circuit board assembly.
8-12A	A17-Vertical Amplifier circuit board assembly.
8-12B	A18-Termination circuit board assembly.
8-13	A19-Horizontal Amplifier circuit board assembly.
8-14	A19-Horizontal Amplifier circuit board assembly.

FIGURE NO.

8-15	A1-Front Panel circuit board assembly.
8-16	A21-Z-Axis circuit board assembly.
8-17	A22-High Voltage circuit board assembly.
8-18	A2-Display Control circuit board assembly.
8-19	A23-Inverter circuit board assembly.
8-20	A24-Rectifier circuit board assembly.
8-21	A25-Low-Voltage Regulator circuit board assembly.
8-22	A26-Fan Motor circuit board assembly.
8-23	A28-X-Y Delay Compensation circuit board assembly.
8-24	7104 Troubleshooting Chart.
8-25	Test Point and Adjustment Locations A.
8-26	Test Point and Adjustment Locations B.
8-27	Test Point and Adjustment Locations C.
8-28	Test Point and Adjustment Locations D.
8-29	Test Point and Adjustment Locations E.
8-30	Test Point and Adjustment Locations F.
8-31	Test Point and Adjustment Locations G.
8-32	Test Point and Adjustment Locations H.

LIST OF TABLES

TABLE NO.		PAGE	TABLE NO.		PAGE
1-1	Power-Cord Conductor Identification	1-2	3-8	Input/Output Combinations for the Vertical Binary stage	3-16
1-2	Power-Cord Plug Configuration	1-2	3-9	Input/Output Combinations for the Plug-In Binary stage	3-17
1-3	Shipping Carton Test Strength	1-3	3-10	Input/Output Combinations for the Vertical Chopped Blanking stage	3-19
1-4	Electrical Characteristics	1-3	3-11	Standard Readout Format	3-27
1-5	Environmental Characteristics	1-10	3-12	Channel Address Code	3-32
1-6	Physical Characteristics	1-11	4-1	Recommended Power Supply Troubleshooting Sequence	4-8
1-7	7104 Oscilloscope Vertical System Specification	1-13	4-2	Typical Power-Supply Resistance	4-9
1-8	7104 Oscilloscope System Horizontal Specification	1-14	4-3	Burst Voltage Test Points	4-10
1-9	Special Purpose Plug-In Units	1-14	4-4	Recommended CRT Circuitry Troubleshooting Sequence	4-14
2-1	Display Combinations	2-11	5-1	Calibration Procedure Electives	5-1
3-1	Basic Logic Reference	3-5	5-2	Performance Check Summary	5-3
3-2	Mode Switching Inputs/Outputs	3-9	5-3	Test Equipment	5-13
3-3	Input/Output Combinations for A Lockout (U4428 pin 14)	3-11	5-4	Power Supply Tolerance	5-37
3-4	Input/Output Combinations for B Lockout (U4428 pin 15)	3-11	5-5	Vertical Compensation Adjustments	5-63
3-5	Input/Output Combinations for Alternate Pulse (U4428 pin 8)	3-12	5-6A	Low-Frequency Compensation	5-64
3-6	Input/Output Combinations for Z-Axis Logic stage	3-14	5-6B	Low-Frequency Compensation	5-64
3-7	Input/Output Combinations of the Horizontal Binary stage	3-14	6-1	Option Information Locator	6-1

OPERATORS SAFETY SUMMARY

The following general safety information applies to all operators and service personnel. Specific warnings and cautions will be found throughout the manual where they apply and should be followed in each instance.

TERMS

In This Manual

CAUTION statements identify conditions or practices that could result in damage to the equipment or other property.

WARNING statements identify conditions or practices that could result in personal injury or loss of life.

As Marked on Equipment

CAUTION indicates a personal injury hazard not immediately accessible as one reads the marking, or a hazard to property including the equipment itself.

DANGER indicates a personal injury hazard immediately accessible as one reads the marking.

SYMBOLS

In This Manual



This symbol indicates where applicable cautionary or other information is to be found.

As Marked on Equipment



DANGER—High voltage.



Protective ground (earth) terminal.



ATTENTION—Refer to manual.

WARNINGS

Power Source

This product is intended to operate from a power source that will not apply more than 250 volts rms between the supply conductors or between either supply conductors and ground. A protective ground connection, by way of the grounding conductor in the power cord, is essential for safe operation.

Grounding the Instrument

This instrument is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the input or output terminals of the instrument. A protective ground connection, by way of the grounding conductor in the power cord, is essential for safe operation.

Use the Proper Power Cord

Use only the power cord and connector specified for your instrument. Use only a power cord that is in good condition. For detailed information on power cords and connectors, see page 1-2 of this manual.

Refer cord and connector changes to qualified service personnel.

Use the Proper Fuse

To avoid fire hazard, use only the fuse specified in the parts list for this instrument, and which is identical in type, voltage rating, and current rating.

Refer fuse replacement to qualified service personnel.

Do Not Operate in Explosive Atmosphere

To avoid explosion, do not operate this instrument in an atmosphere of explosive gasses until it has been specifically certified for such operation.

Do Not Remove Panels or Covers

To avoid personal injury, do not remove the protective cabinet panels or covers. Do not operate this instrument without the panels or covers properly installed.

Do Not Remove CRT Implosion Shield

Do not remove the clear plastic implosion shield covering the crt faceplate. This shield provides protection to the operator from crt implosion.

SERVICING SAFETY SUMMARY

FOR QUALIFIED SERVICE PERSONNEL ONLY

Refer also to the preceding Operators Safety Summary

Do Not Service Alone

Do not perform internal service or adjustment of this product unless another person capable of rendering first aid and resuscitation is present.

Use Care When Servicing With Power On

Dangerous voltages exist at several points in this product. To avoid personal injury, do not touch exposed connections and components while power is on.

Disconnect power before removing protective panels, soldering, or replacing components.

Power Source


This product is intended to operate from a power source that will not apply more than 250 volts rms between the supply conductors or between either supply conductor and ground. A protective ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Crt Handling

Use care when handling a crt. Breakage of the crt causes a high-velocity scattering of glass fragments (implosion). Protective clothing and safety glasses should be worn. Avoid striking the crt on any object which might cause it to crack or implode. When storing a crt, place it in a protective carton or set it face down in a protected location on a smooth surface with a soft mat under the faceplate.

Silicone Grease Handling

Handle silicone grease with care. Avoid getting the silicone grease in your eyes. Wash hands thoroughly after use.



7104 Features

The TEKTRONIX 7104 Oscilloscope is a solid-state, wide-bandwidth instrument designed for general-purpose applications. The 7104 can also be used to observe or photograph very fast repetitive or single shot waveforms.

The 7104 accepts Tektronix 7000-series plug-in units; the flexibility of the plug-in feature and variety of plug-in units available allows the system to be used for many measurement applications. The left pair of plug-in compartments are for vertical deflection and the right pair are for horizontal deflection. Electronic switching between each pair will produce multitrace vertical and/or horizontal displays.