


Using the TAS Two Channel Oscilloscopes



Front-panel menu buttons display menu choices on the CRT.

Select instrument functions with the corresponding menu button below the CRT.

Select the operation for a selected function using the corresponding menu button to the right of the CRT.

Selections are underscored.

Channel select buttons assign instrument control to the selected channel, indicated with a lighted LED.

ALT/CHOP, ADD displays the menu choices for the display mode and math operations.

POSITION moves the vertical position of the sweep.

VERTICAL MENU displays the menu choices or the vertical operating system.

VOLTS/DIV adjusts the vertical deflection factor.

WAVEFORM OFF clears the selected channel's waveform from the display until only one waveform remains.

Using the Horizontal System

POSITION moves the sweeps horizontally.

HORIZONTAL MENU displays the menu choices for the horizontal operating system.

SEC/DIV adjusts the horizontal deflection factor.

MAG horizontally magnifies the sweeps by a factor of ten.

Menu Map

