

Service Manual



ASG 100 Audio Signal Generator

070-8546-03

Warning

The servicing instructions are for use by qualified personnel only. To avoid personal injury, do not perform any servicing unless you are qualified to do so. Refer to all safety summaries prior to performing service.



Copyright © Tektronix, Inc. All rights reserved. Printed in U.S.A.
Tektronix products are covered by U.S. and foreign patents, issued and pending.

Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved. The following are registered trademarks: TEKTRONIX and TEK.

For further information, contact: Tektronix, Inc., Corporate Offices, P.O. Box 1000, Wilsonville, OR 97070-1000, U.S.A. Phone: (503) 627-7111; TLX: 192825; TWX: (910) 467-8708; Cable: TEKWSGT.

Tektronix' Television Division participates in the Broadcast Professionals Forum (BPFORUM) on the CompuServe® Information Service. Press releases on new products, product-specific newsletters, application information and technical papers are among the types of information uploaded.

Additionally, product specialists from Tektronix will be "on line" to answer questions regarding product applications, operation and maintenance.

Instructions for accessing the information on CompuServe can be found in the current Tektronix Television Products Catalog.

CompuServe access is currently available in the U.S.A., Canada, Europe, Japan, Australia, New Zealand, Argentina, Venezuela, Korea, and Taiwan.

WARRANTY

Tektronix warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If any such product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; or c) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX WITH RESPECT TO THIS PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

TABLE OF CONTENTS

Table of Contents

List of Illustrations	vi
List of Tables	vii

Safety Summary

Section 1 Introduction and Specifications

Introduction	1-1
Automatic Audio Channel Testing	1-1
Manual Signal Testing	1-2
Line Up	1-2
Manual	1-2
Remote Control	1-2
Specifications	1-3
Electrical Characteristics	1-3
Environmental Characteristics	1-6
Mechanical Characteristics	1-6
Power Cord Options	1-7

Section 2 Operation and Setup

Mains Voltage	2-2
Freedom of Operation	2-2
Front Panel Controls	2-2
Functions	2-2
ON LINE	2-3
SILENCE	2-3
VOICE	2-3
RECORD (PRESS SILENCE + VOICE)	2-3
AUTO	2-4
Auto Test Level	2-4
Sweep Test Level	2-4
LINE-UP	2-5
Alternating VOICE and LINE-UP	2-5
MANUAL	2-5
Tone Tests	2-6
Polarity Tests	2-6
Multitone Tests	2-7
Manual Test Level	2-7
Manual Test Frequency	2-7
VOLUME	2-7
MIC	2-7
IDENTIFICATION	2-7
FREQUENCY	2-8
AMPLITUDE	2-8

Arrow Buttons	2-8
↑ (Up Arrow), ↓ (Down Arrow)	2-9
← (Left Arrow), → (Right Arrow)	2-9
PAUSE AUTO	2-9
SAVE	2-10
Status Feedback	2-10
POWER	2-10
Power-On Diagnostics	2-10
OUTPUT ≥775mV(rms)	2-11
Display Window	2-11
Headphones	2-11
REAR PANEL POWER SWITCH AND SIGNAL CONNECTORS	2-12
Power Switch	2-12
Audio Signal Connectors	2-12
Remote Connector	2-12
Internal Settings and Setup Editing	2-13
Enabling and Disabling Signal Editing	2-13
Editing Signal Parameters	2-15
Saving Signal Parameters	2-15
External Edit Enable	2-16
Front Panel and Remote Control Enabling	2-17
Setting the Output Impedance	2-17

Section 3 Maintenance

Lithium Battery	3-1
Battery Disposal	3-1
Battery Emergency and First Aid Information	3-1
Fuse	3-2
Preventive Maintenance	3-2
Cleaning	3-2
Visual Inspection	3-3
Static-Sensitive Components	3-4
Troubleshooting	3-5
Troubleshooting Aids	3-5
Foldout Pages	3-5
Parts Lists	3-5
Major Assembly Interconnection	3-6
General Troubleshooting Techniques	3-6
Power-On Diagnostics	3-7
Corrective Maintenance	3-7
Obtaining Replacement Parts	3-7
Removal and Replacement Procedures	3-8
Cabinet Removal and Replacement	3-8
Front Panel Removal and Replacement	3-8
Main Board Removal and Replacement	3-8
Power Supply Removal and Replacement	3-9
Serial Connector EMI Board Removal and Replacement	3-10

Section 4 Verification and Adjustment

Verification Procedure	4-2
Preparation	4-2
Procedures	4-2
1. Power Up Check	4-2
2. Check Frequency Accuracy ($\pm 0.1\%$)	4-2
3. Check Amplitude Accuracy (± 0.2 dB at 1000 Hz)	4-3
4. Check Amplitude Flatness (+0.05/0.2 dB, 10 Hz to 20 kHz)	4-3
5. Check Channel-to-Channel Level Difference (≤ 0.2 dB at +14 dBu)	4-4
6. Check Total Harmonic Distortion + Noise ($< 0.015\%$, 20 Hz to 19 kHz $< 0.056\%$ > 19 kHz to 20 kHz)	4-5
7. Check Signal-to-Noise Ratio (> 80 dB at 0 dBu at 1 kHz)	4-6
8. Check Channel-to-Channel Phase Difference ($\leq 1^\circ$, 10 Hz to 20 kHz)	4-6
9. Check Loop-Through	4-7
10. Check SAVE Operation	4-7
11. Check RECORD and Headphones Operation	4-7
12. Check Audio/Video Timing Control	4-8
13. Check AUTO Test 0.33 and Tek Sequences and AUTO TEST LVL Operation	4-8
14. Check AUTO Test Sweep and SweepLev Operation	4-8
15. Check Remote Operation	4-9
Adjustment Procedure	4-10
Preparation	4-10
Procedures	4-10
1. Check Supply Voltages	4-10
2. Adjust Gain	4-11
3. Adjust Distortion	4-11

Section 5 Theory of Operation

Control Processor (Diagram 1)	5-1
Front Panel Processor	5-1
Reset Circuit U54 and Inverting Buffer	5-1
Address Latch (Address/Data Demultiplexer)	5-1
RAM	5-2
EPROM	5-2
Battery Backup	5-2
Address Decoder	5-2
Front Panel Interface	5-2
DIP Switch	5-3
Remote Connector	5-3
Digital Signal Processor (Diagram 2)	5-3
Digital Signal Processor (DSP)	5-3
Address Decoder	5-4
Control Register Latches	5-4
EPROM	5-4
DSP RAM	5-4
Battery Backup	5-5
CODEC	5-5

Digital-to-Analog Converter (Diagrams 3 and 3a)	5-5
Digital Formatter/Synchronizer	5-5
Digital-to-Analog Converters	5-5
Low-Pass Filters	5-6
Filter Voltage Reference Regulators	5-6
Channel 1 and Channel 2 Attenuator (Diagram 4)	5-6
Step Attenuators	5-6
Attenuation Range Steps	5-6
Switching Control Signals	5-6
Output Buffers	5-7
Gain Switching	5-7
Output Impedance Resistor Arrays	5-7
Relay Driver	5-7
Output Switching Relays	5-7
EMI Filters	5-8
Control Signals (CTRL0–CTRL3)	5-8
PREVIEW (CTRL12)	5-8
Headphone Amplifier (Diagram 5)	5-8
Input Differential to Single-Ended Amplifiers	5-8
Signal/Preview Multiplexer	5-8
Channel 1 and Channel 2 Voltage Controlled Amplifiers	5-8
Audio Level Control Buffer	5-9
Current-to-Voltage Amplifiers	5-9
Preview Termination Transistors	5-9
Microphone Preamplifier (Diagram 6)	5-9
Microphone Input Amplifier	5-9
AGC and Output Amplifier	5-9
Power Distribution (Diagram 6)	5-10
Front Panel (diagram 7)	5-10
Serial Filter Board (Diagram 8)	5-10
Power Supply (No diagram provided)	5-10

Section 6 Replaceable Electrical Parts List

Section 7 Diagrams

Section 8 Replaceable Mechanical Parts List

Appendix A Remote Operation

Remote Control From a Terminal	A-1
Limited Local Remote Control	A-1
Installation	A-1
Connect a Properly Configured Communications Cable	A-1
Set DIP Switch	A-4
Set Serial Communication Parameters	A-4
Setting Baud Rate	A-4

Remote Operation	A-6
Remote Commands	A-7
Command Description	A-10
Help Commands	A-10
Queries	A-11
Unit Identification	A-11
Special Queries	A-12
Restoring Defaults	A-12
Flow Control	A-12
Remote Command Syntax	A-12
auto [l:level][test_name]	A-13
Aborting an Auto Sequence	A-13
[r l][tone [f:frequency] [l:level]]	A-14
[r l]polr [l:level]	A-15
[r l]mtone<1 2 3 4> [l:level]	A-15

List of Illustrations

Figure		Page
1-1	Typical 1 kHz THD + Noise versus Output Level	1-4
2-1	ASG 100 Menu Map	2-1
2-2	ASG 100 Front Panel controls.	2-2
2-3	Manual test signal selection using arrow keys	2-6
2-4	ASG 100 Rear Panel connectors	2-12
2-5	Remove side panel door to access DIP switch	2-13
2-6	DIP switch settings for editing	2-14
2-7	Output impedance resistor network	2-18
2-8	Effects of a changing load resistance on the dBm output of the ASG 100	2-19
2-9	Effects of matching load and source impedances in the ASG 100	2-20
A-1	Cabling to IBM PC/XT or Compatibles and the VM700A.	A-3
A-2	Cabling to IBM AT/386 and Compatibles	A-3
A-3	Setting baud rate during power on	A-5
A-4	Help screen of remote commands.	A-11

List of Tables

Table		Page
1-1	Electrical Characteristics	1-3
1-2	ASG 100 Multitones	1-5
1-3	Environmental Characteristics	1-6
1-4	Physical Characteristics	1-6
1-5	Voltage, Fuse, and Power Cord Data	1-7
2-1	Dip Switch Functions	2-16
3-1	Emergency Procedures for Contact with Lithium Battery Contents	3-2
3-2	Static Susceptibility	3-4
3-3	Self Diagnostic Tests	3-7
4-1	Test Equipment Required for Verification and Adjustment	4-1
4-2	Amplitude Accuracy Check Points	4-3
4-3	Test Frequencies for Amplitude Flatness	4-4
4-4	Test Frequencies for THD + Noise	4-5
A-1	Pin Connections for Remote Connector	A-2
A-2	Serial Communication Parameters	A-4
A-3	List of ASG 100 Commands, Arguments, and Queries	A-7
A-4	Special Queries	A-10
A-5	Control Signals	A-10
A-6	Test Name Arguments to Remote "AUTO" Command	A-14

OPERATOR'S SAFETY SUMMARY

The general safety information in this part of the summary is for both operating and servicing personnel. Specific warnings and cautions will be found throughout the manual where they apply, but may not appear in this summary.

Terms In This Manual



statements identify conditions or practices that could result in damage to the equipment or other property.



statements identify conditions or practices that could result in personal injury or loss of life.

Terms As Marked on Equipment



CAUTION indicates a personal injury hazard not immediately accessible as one reads the marking, or a hazard to property, including the equipment itself. Refer to the manual for information.



DANGER indicates a personal injury hazard immediately accessible as one reads the marking.



Protective ground (earth) terminal.

SAFETY INFORMATION

Use the Proper Power Source. This product is intended to operate from a power source that will not apply more than 250 V rms between the supply conductors or between either supply conductor and ground. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Ground the Product. This product is grounded through the grounding conductor of the power cord. To avoid electrical shock, plug the power cord into a properly wired receptacle before connecting to the product input or output terminals. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.

Danger May Arise From Loss of Ground. Upon loss of the protective-ground connection, all accessible conductive parts (including knobs and controls that may appear to be insulating) can render an electric shock.

Use the Proper Fuse. To avoid fire hazard, use only the fuse of correct type, voltage rating, and current rating as specified in the parts list for your product. Refer fuse replacement to qualified service personnel.

Do Not Operate in Explosive Atmospheres. To avoid explosion, do not operate this product in an explosive atmosphere.

Do Not Remove Covers. To avoid personal injury, do not remove the product covers or panels. Do not operate the product without the covers and panels properly installed.


SERVICING SAFETY SUMMARY

For Qualified Service Personnel only. Refer also to the preceding Operators Safety Summary.

Do Not Service Alone. Do not perform internal service or adjustment of this product unless another person capable of rendering first aid and resuscitation is present.

Use Care When Servicing With Power On. Dangerous voltages exist at several points in this product. To avoid personal injury, do not touch exposed connections or components while power is on. Disconnect power before removing protective panels, soldering, or replacing components.

Use the Proper Power Source. This product is intended to operate from a power source that will not apply more than 250 V rms between the supply conductors or between either supply conductor and ground. A protective-ground connection by way of the grounding conductor in the power cord is essential for safe operation.



The ASG 100 Audio Signal Generator.

Section 1

INTRODUCTION AND SPECIFICATIONS

INTRODUCTION

The ASG 100 Audio Signal Generator was developed by Tektronix to meet the audio testing requirements of commercial broadcasting. The ASG 100 reduces testing time by transmitting short, predefined audio test sequences that produce precise and easily reproduced results in its AUTO mode. It can also transmit source identification, a voice segment (either continually or as part of the AUTO test) and user defined tones. The user defined tones of LINE UP and MANUAL test signal operation provide the continuous signals needed for adjusting audio levels and manual checking of the left/right audio channels.

AUTOMATIC AUDIO CHANNEL TESTING

Test equipment for sound programming and the sound channels of television programming must be capable of quickly checking the audio signal path to make sure of the circuit's quality. Automatic equipment must be able to rapidly measure the test signal in ways that give repeatable and meaningful test results.

To assist in the repeatability area, standard test signal sequences have been defined. These sequences begin with the necessary components to start the measurement, identify the source of the test signals, and identify the stored automatic test that is to be done. Then the test signal portion of the sequence runs in predefined frequency, level, and timing patterns that permit automated testing of the signal path characteristics.

Each of the test signals in the automatic test sequence are used to check on the different parameters that are important to signal quality. The tests have defined sequences for both monaural and stereo audio testing, and are based on Recommendation O.33 of the *CCITT Specification For Measuring Equipment, Volume IV, Series O Recommendations-1988*.

When used with a CCITT O.33 compliant receiver, such as the Tektronix VM700A Option 40 or Option 41, the results of the AUTO testing sequence can be documented automatically without the need for human intervention (unless of course, an out-of-tolerance condition is found by the test).

The Tektronix VM700A Option 40 and Option 41 receiving and measuring equipment uses the test signals sent by the companion ASG 100 audio signal generator to measure the following parameters as defined in Recommendation O.33 for monophonic audio paths.

- Insertion Gain

- Frequency Response

- Distortion

- Signal-to-Noise Ratio

- Compandor Linearity

- Expanded Noise

For stereophonic audio paths, additional measurements are done to assure the A/B (left/right) channel parameters of the signal paths are sufficiently matched for proper transmission of the program audio.

The added measurements are:

Interchannel difference in gain and phase

Interchannel crosstalk and circuit transposition

MANUAL SIGNAL TESTING

Line Up

The Line Up test signal is selectable in both frequency and amplitude for use in providing a known line up signal for adjusting levels from various audio sources. This signal may be set for a house standard and then fixed (editing disabled) or it may remain controllable from the front panel. The frequency range is from 10 Hz to 20 kHz and the amplitude range is from -90 dBu to +24 dBu. As shipped from the factory (and the default if factory defaults are reloaded), the Line Up signal is 400 Hz at 0.0 dBu.

Manual

Tone

The Tone test signal comes as stereo, left tone, and right tone. The frequency and amplitude are selectable over the same range as the Line Up signal. The factory default for the Tone signals is 440 Hz at 0.0 dBu.

Polarity

Polarity also comes as stereo, left polarity, and right polarity. The polarity test signal is the sum of a fundamental sine wave of 440 Hz and its equal amplitude second harmonic sine wave of 880 Hz. The amplitude of the polarity signal is selectable from -90 dBu to +24 dBu with a fixed fundamental frequency of 440 Hz. The factory default for the amplitude is 0.0 dBu.

Multitone

The Multitone signals also come as stereo, and left and right channels. Multitone signals are composed of a selected set of sine wave frequencies. The amplitude of the multitone signal is selectable from -90 dBu to +24 dBu. The output signal amplitude for the Multitone signals is the rms value of signal set, not the amplitude of any single frequency component in the set. There are presently four sets of multitone signals covering different bandwidths and providing different sine wave components. The multitone signals are used to check for response and harmonic distortion of audio circuits and devices (amplifiers, tape recorders, cables, etc.). The factory default for the amplitude is 0.0 dBu.

REMOTE CONTROL

There are two types of remote control possible with the ASG 100. The remote control connector on the rear panel of the instrument may be used as contact closure connections for minimal remote operation. Using contact closure remote, an AUTO sequence may be started and front panel editing may be enabled (if it is internally disabled). The second type of remote control uses the remote control connector as an RS-232C serial port, and the front panel operation may be controlled via a PC or terminal if serial communications is enabled in the ASG 100. The Audio/Video Timing signal synchronization feature is also controlled through the remote port. See *Appendix D* of the Operator's manual for information on the Audio/Video Timing feature.

SPECIFICATIONS

Electrical Characteristics

Table 1-1
Electrical Characteristics

Characteristic	Performance Requirement	Comment
External Power Voltage (Nom.) Input Freq Range Power Consumption	100 to 240 Vac. 47 Hz to 440 Hz. 20 W Typical.	Full range, no selector.
RS-232C Interface Baud Rates Maximum Applied Voltage Signals Levels Connector	1200, 2400, 4800, and 9600 (factory default). 25 V (dc + peak ac). RXD (received data), TXD (transmitted data), and GND are used for serial remote control of the ASG 100. Compatible with RS-232C. DB-9 DTE (terminal communications device).	Front panel selection only, no switch settings for baud rate except the factory default of 9600. RTS and CTS are not used in the ASG 100. Pins 4, 6, and 9 of the connector are not to be connected to the terminal interconnection cable. Those pins are used for contact closure remote control. Requires a null modem for connection to a another DTE device.
Output Signal Frequency Range Multitone Resolution Accuracy	10 Hz to 20 kHz. See Table 1-2 1 Hz. $\pm 0.1\%$.	
Output Signal Amplitude Range Accuracy Resolution Flatness	-90 dBu to $+24$ dBu ($24.5 \mu\text{V}$ to $12.2 V_{\text{rms}}$) balanced into a load resistance of $10 \text{ k}\Omega$ or greater with 12Ω source resistance. ± 0.2 dB at 1 kHz from $+24$ dBu to -80 dBu into a load resistance of $10 \text{ k}\Omega$ or greater. ± 0.1 dB. ± 0.2 dB, 10 Hz to 20 kHz* $+0.05/-0.2$ dB, 10 Hz to 20 kHz (relative to 1 kHz)**	Output is approximately 0.17 dB lower with a 600Ω load and is 6 dB lower with internal 600Ω source resistance and a 600Ω load. Multitone signal components are not sent at the specified amplitude; the amplitude specification is for the combined Multitone signal rms value. Typ. ± 0.1 dB, 10 Hz to 19 kHz* Typ. $+0.05/-0.1$ dB, 10 Hz to 15 kHz**

* B039999 and below
** B040000 and above

Table 1-1 (cont.)

Characteristic	Performance Requirement	Comment
Total Harmonic Distortion + Noise for outputs ≥ -10 dBu (245 mV _{rms}) (measured over an 80 kHz bandwidth)	< 0.01% (-80 dB), 20 Hz to 18 kHz*; < 0.025% (-72 dB), 18 kHz to 20 kHz*; < 0.015% (-76.5 dB), 10 Hz to 19 kHz**; < 0.056% (-65 dB), >19 kHz to 20 kHz**	< 0.005% at 1 kHz at full output, measured over a 22 KHz bandwidth (see typical curve in Figure 1-1). This typical specification will also hold at +14 dBu and +4 dBu.
Signal-to-Noise, measured over a 22 kHz bandwidth.	> 90 dB at 1 kHz at 0 dBu output level.	$S/N = 20 \log \frac{V_{Manual}}{V_{Silence}}$ S/N improves as the output signal increases and decreases as output reduces, proportionally.
XLR Inputs	Balanced.	EMI capacitive load of 0.002 μ F. Looped through to output if ASG 100 is not ON LINE.
XLR Outputs	Balanced.	
Output Impedance	12 Ω , 600 Ω or User-defined; balanced.	
Level Difference Between Channels	≤ 0.2 dB at +14 dBu.	
Phase Difference Between Channels	$\leq 1^\circ$, 10 Hz to 20 kHz.	
Typical Crosstalk + Noise measured over 80 kHz band-width at +24 dBu Generator to Output	≤ -90 dB at 1 kHz and 20 kHz.	Left tone into Right output or Right tone into Left output; generator source resistance 12 Ω and load termination either open or 600 Ω .
Input to Output (loop through; ASG 100 off line)	≤ -110 dB at 1 kHz and 20 kHz with both outputs unterminated. ≤ -115 dB at 1 kHz and ≤ -110 dB at 20 kHz with driven channel terminated into 600 Ω and the inactive channel unterminated. ≤ -120 dB at 1 kHz and 20 kHz with the driven channel unterminated and the inactive channel terminated in 600 Ω . ≤ -120 dB at 1 kHz and 20 kHz with both outputs terminated in 600 Ω .	Left channel input into Right channel output or Right channel input into Left channel output; source resistance 50 Ω . Typ. ≤ -130 dB measured over a 22 kHz bandwidth at 1 kHz.

* B039999 and below

** B040000 and above




Figure 1-1. Typical 1 kHz THD + Noise versus Output Level.

Table 1-2
ASG 100 Multitones

Multitone 1	Multitone 2	Multitone 3	Multitone 4
59	23	47	23
117	94	141	117
187	141	281	234
246	223	656	750
293	270	1031	867
375	352	2016	1758
422	562	4031	3492
949	879	8019	6984
1184	1113	15000	13992
1512	1395		20015
1887	1758		
2391	2227		
3000	2789		
3785	3516		
4758	4430		
6012	5590		
7570	7043		
9539	8871		
12012	11180		
15000	14074		
	17742		
	19992		

NOTE

The Multitone signals are combined in repetitive blocks. At the end of the block time, all the signals are in phase again for a seamless transition into the next signal block.

ENVIRONMENTAL CHARACTERISTICS

Table 1-3
Environmental Characteristics

Characteristic	Limits
Operating Temp.	0° C to +50° C.
Non-Operating Temp.	-40° C to +65° C.

MECHANICAL CHARACTERISTICS

Table 1-4
Physical Characteristics

Characteristic	Value
Length	180 in. (458 mm).
Width	8.1 in. (206 mm).
Height	1.7 in. (43 mm).
Weight	3.25 lb. (1.48 kg).

Table : Certifications and compliances







Category	Standards or description
EC Declaration of Conformity – EMC	<p>Meets intent of Directive 89/336/EEC for Electromagnetic Compatibility. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Union:</p> <p>EN 50081-1 Emissions: EN 55022 Class B Radiated and Conducted Emissions</p> <p>EN 50082-1 Immunity: IEC 801-2 Electrostatic Discharge Immunity IEC 801-3 RF Electromagnetic Field Immunity IEC 801-4 Electrical Fast Transient/Burst Immunity</p> <p>Must use high quality shielded cables to ensure conformance with EMC regulations.</p>
Australia/New Zealand Declaration of Conformity – EMC	<p>Complies with EMC provision of Radiocommunications Act per the following standard(s):</p> <p>AN/NZS 2064.1/2 Industrial, Scientific, and Medical Equipment: 1992 AN/NZS 3548 Information Technology Equipment: 1995</p>
EMC Compliance	<p>Meets the intent of Directive 89/336/EEC for Electromagnetic Compatibility when it is used with the product(s) stated in the specifications table. Refer to the EMC specification published for the stated products. May not meet the intent of the directive if used with other products.</p>
FCC Compliance	<p>Emissions comply with FCC Code of Federal Regulations 47, Part 15, Subpart B, Class A Limits.</p>
EC Declaration of Conformity – Low Voltage	<p>Compliance was demonstrated to the following specification as listed in the Official Journal of the European Union:</p> <p>Low Voltage Directive 73/23/EEC, amended by 93/69/EEC</p> <p>EN 61010-1:1993 Safety requirements for electrical equipment for measurement control and laboratory use.</p>
U.S. Nationally Recognized Testing Laboratory Listing	<p>UL3111-1 Standard for electrical measuring and test equipment. UL1244 Standard for electrical and electronic measuring and testing equipment.</p>
Canadian Certification	<p>CAN/CSA C22.2 No. 231 CSA safety requirements for electrical and electronic measuring and test equipment.</p>
Additional Compliance	<p>IEC61010-1 Safety requirements for electrical equipment for measurement, control, and laboratory use.</p>
Installation (Overvoltage) Category	<p>Terminals on this product may have different installation (overvoltage) category designations. The installation categories are:</p> <p>CAT III Distribution-level mains (usually permanently connected). Equipment at this level is typically in a fixed industrial location. CAT II Local-level mains (wall sockets). Equipment at this level includes appliances, portable tools, and similar products. Equipment is usually cord-connected. CAT I Secondary (signal level) or battery operated circuits of electronic equipment.</p>
Pollution Degree	<p>A measure of the contaminants that could occur in the environment around and within a product. Typically the internal environment inside a product is considered to be the same as the external. Products should be used only in the environment for which they are rated.</p>

Table : Certifications and compliances (cont.)

Category	Standards or description	
	Pollution Degree 1	No pollution or only dry, nonconductive pollution occurs. Products in this category are generally encapsulated, hermetically sealed, or located in clean rooms.
	Pollution Degree 2	Normally only dry, nonconductive pollution occurs. Occasionally a temporary conductivity that is caused by condensation must be expected. This location is a typical office/home environment. Temporary condensation occurs only when the product is out of service.
	Pollution Degree 3	Conductive pollution, or dry, nonconductive pollution that becomes conductive due to condensation. These are sheltered locations where neither temperature nor humidity is controlled. The area is protected from direct sunshine, rain, or direct wind.
	Pollution Degree 4	Pollution that generates persistent conductivity through conductive dust, rain, or snow. Typical outdoor locations.

POWER CORD OPTIONS

Table 1-5
Voltage, Fuse,^a and Power Cord Data

Plug Configuration	Category	Power Cord and Plug Type	Voltage Range	Reference Standards ^b
	U.S. Domestic Standard	U.S. 120 V 15 A	115 V Nominal 90 V to 132 V	ANSI C73.11 NEMA 5-15-P IEC 83 UL 198.6
	Option A1	EURO 240 V 10-16 A	230 V Nominal 180 V to 250 V	CEE(7), II, IV, VII IEC 83 IEC 127
	Option A2	UK ^c 240 V 6 A	230 V Nominal 180 V to 250 V	BS 1363 IEC 83 IEC 127
	Option A3	Australian 240 V 10 A	230 V Nominal 180 V to 250 V	AS C112 IEC 127
	Option A4	North American 240 V 15 A	230 V Nominal 180 V to 250 V	ANSI C73.20 NEMA 6-15-P IEC 83 UL 198.6
	Option A5	Switzerland 220 V 6 A	230 V Nominal 180 V to 250 V	SEV IEC 127

^a All options listed come with a factory-installed fuse for the selected operating voltage range.

^b Reference Standards Abbreviations:

ANSI—American National Standards Institute

AS—Standards Association of Australia

BS—British Standards Institution

CEE—International Commission on Rules for the Approval of Electrical Equipment

IEC—International Electrotechnical Commission

NEMA—National Electrical Manufacturer's Association

SEV—Schweizerischer Elektrotechnischer Verein

UP—Underwriters Laboratories Inc.

^c A 6 Ampere, type C fuse is also installed inside the plug of the Option A2 power cord.

Section 2 OPERATION AND SETUP




Figure 2-1. ASG 100 Menu Map.

MAINS VOLTAGE

Plug the power cord into the outlet for any voltage source between 100 and 240 volts. You do not need to make any adjustments on the ASG 100 to accommodate different source voltages in the rated operating range. Various power cord options are available to match the ac various international AC mains. The power cord supplied with the ASG 100 is as ordered from the factory. See Section 1, *Introduction and Specification*, for the power cord options.

FREEDOM OF OPERATION

The user definable states of the ASG 100 may be totally accessible or set to preselected setups that can not be accidentally altered in normal use. As shipped from the factory, the total range of user definable features are available. Once the application needs are determined and programmed, the editing feature may be selectively disabled to prevent accidental changes the frequency and output levels of the test signal. Refer to *Internal Settings and Setup Editing* for information on enabling and disabling the editing function.

FRONT PANEL CONTROLS

The following text details the operation of the front-panel controls and indicators. A front-panel illustration is shown in Figure 2-2 for reference.




Figure 2-2. ASG 100 Front Panel controls.

FUNCTIONS

The ASG 100 is powered on and off with the power switch to the right of the power receptacle on the back panel.

The ASG 100 functions are enabled from the front panel through the six larger buttons. These “main selection” buttons have LED in the center that indicates the choice is selected. The ON LINE LED is red; the remaining five are green. The smaller buttons are controls that let you display and adjust the values associated with the various test functions.

The test signal functions initiated by the five main selection buttons to the right of the ON-LINE button are mutually exclusive in most cases; enabling one of these five signal functions automatically disables the previously selected function. There are two exceptions to this:

- To initiate a continuously alternating voice ID and line-up tone, press the VOICE and LINE UP buttons simultaneously. (Both LEDs will be on and the display is **Voi + Lnup.**)

- To record four seconds of voice for identification purposes, press the VOICE and SILENCE buttons simultaneously. The recording process is cued with **Record:, Ready . . .**, and **Begin**; then a four-second countdown is displayed to time the recording. After that time, the selected function returns.

The ASG 100 outputs the selected signal only when the ON-LINE function is enabled. The lighted ON-LINE button indicates that the ASG 100 has interrupted the source signal and connected its own output circuit to the downstream audio path.

The ASG 100 sends all signals it generates to the signal ports on the back panel and to the headphones jack on the front panel. When the ASG 100 is not on line, the incoming program audio (if any is applied to the loop-through connectors) may be monitored at the headphone jack.

ON LINE

When the ON LINE function is enabled (indicated by the red LED in the center of the button), the ASG 100 interrupts any source audio signal before it in the audio path, and sends the currently selected test tone or pattern to the audio equipment after it. Selecting any signal choice while on line is permitted. However, when AUTO is selected, that test must be completed before any other choice (except off line) is permitted. Off line is selected from the front panel by pressing the ON LINE button a second time.

When one of the AUTO mode automatic test sequences is selected, the ASG 100 reverts to off-line status (the red LED turns off) when the selected test sequence is finished and sends a message to that effect over the serial port. Off line reconnects the incoming source audio signal (if any) to the equipment following the ASG 100 in the audio path.

NOTE

The ASG 100 will not go on line when the front panel ON LINE is pressed when the AUTO ID, TESTLev, or SweepLev is being displayed. You must return to the AUTO Test Selection display or select another test signal.

SILENCE

The SILENCE function makes the ASG 100 generate *no* signal. With SILENCE enabled, any signal shown on the VM700A Option 40 and Option 41 or other monitoring equipment is the noise picked up along the audio path following the ASG 100. The ASG 100 must be ON LINE to send silence, just as for the other functions.

VOICE

The VOICE function continuously replays the 4-second voice identifier the ASG 100 is currently programmed to send. The voice signal level follows the setting of the LINE UP signal amplitude setting.

RECORD (PRESS SILENCE + VOICE)

The RECORD function records 4 seconds of voice input through the built in microphone.

You enable this function by pressing the SILENCE and VOICE buttons simultaneously; there is no remote RECORD command. While the two buttons are held in, the display window shows the prompt **Record:**. When the buttons are released, the display changes to **Ready. . .**, then **Begin**, and a countdown from **4. 0** to **0. 0**. During the four second countdown, the ASG 100 records any

sounds made within several feet of the microphone, but for best recording results speak directly into the microphone recording a VOICE identification. When RECORD is started, the front panel controls are disabled until the recording has finished. Upon finishing, the front panel state returns to the state in effect when the recording session was started except ON LINE.

NOTE

If the ASG 100 is ON LINE when a recording session is started, it is switched off line; it remains off line until ON LINE is again selected, either locally or remotely.

AUTO

The AUTO function generates the currently selected automatic predefined test signal sequence, such as CCITT O. 33 and TEK or one of the Sweep signals, when ON LINE.

Auto Test Level

During off line, you may display the test level to which the amplitudes of the tones of the CCITT O. 33 and Tek AUTO test sequences are referenced.

For the O. 33 and TEK test sequences, the actual output levels in dBm0 of the ASG 100 test signals equals the sum of the test level and the step levels specified in Appendix B, *Test Sequences*. For example, the first step of the O.33 test sequence is specified at -12 dBm0. However, if the test level is set to be +4.0 dBu, the actual output level of this signal will be $(-12 + 4) = -8.0$ dBm0. The test level can be set from a minimum of -6 dBu to a maximum of +14 dBu. The factory default test level is 0 dBu. This level is one that is usually made uneditable from the front panel so that the known reference for the automatic testing sequences is not easily changed.

Typically, if a TEST Lev change is needed, editing is enabled by a technician to allow an adjustment, then editing is disabled again to lock in the new values for use by operators in the field. For more information on enabling editing, refer to *Internal Settings and Setup Editing*.

NOTE

When monitoring the test signals with test equipment, such as a VM700A Option 40 or Option 41, to get correct readings of insertion gains, be sure the Test Level setting on the VM700A matches the Test Level setting on the ASG 100.

To display the current TEST Lev value, from AUTO with an O. 33 or TEK AUTO Test selected, press the AMPLITUDE button. The TEST Lev label is displayed while the button is held in, and the test level setting is displayed when the AMPLITUDE button is released. When editing is enabled and you want to change the TEST Lev setting, move the blinking cursor to the digit you want to change by pressing the \leftarrow or \rightarrow buttons. Then change the value of the digit by pressing the \downarrow button or \uparrow button. If you wish to make the new setting your default value, you must also press the SAVE button after making the edit. You can not go ON LINE from the TEST Lev display; you can either press the AMPLITUDE button again or make another selection to clear the TEST Lev display.

Sweep Test Level

The Sweep sequence test level reference is settable to a different level than the reference level for the CCITT O. 33 and TEK tests. When setting the **SweepLev** value, one of the sweep signals (Sweep, R Sweep, or L Sweep) must be the selected AUTO test. Editing is done as above for TEST

Lev when editing is enabled. As with TEST Lev, you cannot go ON LINE with the SweepLev displayed.

LINE-UP

The LINE-UP function generates a single tone at a standard frequency and amplitude. The factory default setting is 400 Hz at 0 dBu.

Once you have pressed the LINE-UP button, you can display the frequency or amplitude of the tone by pressing the FREQUENCY or AMPLITUDE button. For information on adjusting their values (when editing is enabled to allow this), refer to the *FREQUENCY* and *AMPLITUDE* descriptions.

The frequency and amplitude of the LINE-UP tone may be programmable from the front panel. If you change the Line-up parameters and want to lock in the new values so they cannot subsequently be changed from the front panel, the editing function can be disabled. For more information, refer to *Internal Settings and Setup Editing*.

Alternating VOICE and LINE-UP

This feature is not indicated on the front panel of the ASG 100. Pressing the VOICE and LINE UP buttons together makes the ASG 100 continuously send the recorded voice pattern alternated with the specified line-up tone when ON LINE. The voice amplitude level follows the level setting of the Line Up signal.

MANUAL

The MANUAL function offers Tone, Polarity, and Multitone signals. Each of these has right and left channel only choices. The factory default option is **Tone**. To choose one of the other options, press either the up-arrow button or down-arrow button until the desired test name appears in the display window. Left and right channel signals are selected using the left-right arrow buttons. The first press of a left or right arrow button selects the left or right channel test signal. If a left or right channel test signal is selected, pressing the opposite arrow returns to stereo test signal. A second press then selects the opposite channel test signal (see Figure 2-3).




Figure 2-3. Manual test signal selection using arrow keys.

Tone Tests

The Tone functions (**Tone**, **L Tone**, and **R Tone**), generates a single, continuous sine wave tone at a specified frequency and level. If a tone choice, is displayed, you can display the frequency or amplitude of the tone by pressing the **FREQUENCY** or **AMPLITUDE** button. If editing is enabled, you can then edit the value using the arrow buttons. For information on enabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting frequency and amplitude values, refer to the *FREQUENCY* and *AMPLITUDE* descriptions.

Polarity Tests

Most audio systems require signal polarity to be preserved through the distribution system. In stereo systems, polarity is especially important for stereo imaging and for monaural compatibility. If polarity is reversed in one channel of the stereo pair, monaural signals cancel.

The MANUAL Polarity functions (**Polarity**, **L Polar**, and **R Polar**) generate special polarity signals that make it easy to test polarity in the audio path and assure correct wire connections for balanced audio output. This is the same polarity signal included in the TEK automatic test sequence.

Multitone Tests

The Multitone functions (**MTone1**, **MTone2**, **MTone3**, and **MTone4** and their right and left channel choices, **R MTonen** and **L MTonen**) provide signals that are composed of selected sets of sine wave frequencies. These signals are used to check audio circuit frequency response and total harmonic distortion and noise levels in audio circuits.

Manual Test Level

You can display the amplitude of the manual signals by pressing the **AMPLITUDE** button when a manual test name is displayed. You can edit the amplitude of any of the manual tests using the arrow buttons when manual test editing is enabled. In normal use, editing of the Manual Test may most often be enabled simply because of the nature of the testing being done when using one of the Manual Test signals. For information on enabling or disabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting amplitude values, refer to the **AMPLITUDE** control description.

Manual Test Frequency

You can display the frequency of the manual signals by pressing the **FREQUENCY** button when a manual test name is displayed. The frequency of the polarity signal is preset at the factory to at 440 Hz and cannot be changed, and there is no frequency indication for Multitone signals. You can edit the frequency of the Tone tests (Tone, R Tone and L Tone) using the arrow buttons when editing is enabled. For information on enabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting the signal frequency, refer to the **FREQUENCY** control description.

VOLUME

The **VOLUME** knob controls the level of the audio output through the headphones. It does *not* affect the level of the signal output through the other signal ports. To increase the volume, turn the knob clockwise.

MIC. (Microphone)

When you enable the **RECORD** function, the microphone picks up 4 seconds of sound made in the vicinity of the ASG 100. Automatic gain control is built into the microphone circuit.

You can then make the ASG 100 replay the recorded sound pattern, either repeatedly with the **VOICE** function, or at the beginning of one of the standard test signal sequences with the **AUTO** function.

The **AUTO** test sequences that include a voice segment in the preamble are identified by a “V” suffix on the sequence name. For example the **TEK** mono test sequence that includes a voice segment is displayed as **TEK:90V**.

IDENTIFICATION

The identification code, consisting of 4 alphanumeric characters and various punctuation characters, provides a way to identify the test signals generated. For example, you could use it to designate the location from which the signal is being generated. This feature is very useful when there may be multiple signal sources arriving at a central control point for testing audio signal paths.

The **IDENTIFICATION** control is active only when the **AUTO** function the selected, but off line. It lets you see what the current four-character code that is transmitted as part of the *preamble* is. The

preamble is a set of initializing data the ASG 100 prefixes to some of the standard test signal sequences it generates.

To see the current identification code, press the AUTO button, then the IDENTIFICATION button.

If editing is enabled, you can change the identification code using the Arrow Buttons. For information on enabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting values using the arrow buttons, refer to *Arrow Buttons*.

FREQUENCY

The FREQUENCY control displays either the frequency of the LINE-UP signal or the frequency of the MANUAL function signals of Tone and Polarity (there is no single frequency associated with Multitones). To display the signal frequency, press either the LINE-UP button to view the LINE-UP signal frequency, or the MANUAL button to view the Tone or Polarity signal frequency. When viewing a MANUAL signal, use the \uparrow or \downarrow buttons to display the Tone or Polarity functions, then press the FREQUENCY button. All the Tone signals (Tone, R Tone, and L Tone) are set to the same frequency, but the LINE UP signal and the Tone signals are separately settable.

NOTE

The Polarity signal is the sum two equal-amplitude sine waves. One has a fundamental frequency of 440 Hz (the displayed frequency for Polarity) and the other is the second harmonic of that frequency, 880 Hz. The Polarity signal frequency is not editable.

If the DIP switches are set to allow editing, you can change the signal frequency of the LINE UP or MANUAL Tone signals using the Arrow Buttons. The frequency of the tone signal may also be changed remotely as an argument to asking for the Tone signal via the serial interface. For information on enabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting values using the arrow buttons, refer to *Arrow Buttons*.

AMPLITUDE

The AMPLITUDE control displays the amplitude of the tone generated by the LINE UP function, the MANUAL Tone function, the MANUAL Polarity function. To display these amplitudes, press the LINE UP button, or the MANUAL button and the \uparrow or \downarrow buttons to display the Tone or Polarity function, then press the AMPLITUDE button.

As with FREQUENCY (discussed in the preceding subsection), once you display the LINE UP, MANUAL Tone or Polarity amplitude, if editing is enabled, you can change the amplitude using the Arrow Buttons. For information on enabling editing, refer to *Internal Settings and Setup Editing*. For more information on adjusting values using the arrow buttons, refer to *Arrow Buttons*.

When the ASG 100 is ON LINE, and you press the \uparrow button to increase the amplitude, if the displayed value is greater than or equal to 0 dBu, the cursor automatically locks onto the least significant digit and increases the level by that increment only. This protects against sudden, unintended jumps in volume.

Arrow Buttons

The Arrow Buttons let you select options and specify values for the AUTO, LINE UP, and MANUAL functions.

For example, the AUTO function offers many standard test signal sequences you can choose. Similarly, the MANUAL function lets you choose a test signal or specify a number of parameters for you can make the ASG 100 generate. The Arrow Buttons let you cycle through the available choices and specify characters or numbers.

↑(Up Arrow), ↓ (Down Arrow)

When the currently selected function offers a set of choices, pressing the ↑ or ↓ button cycles up or down through those choices, displaying them in the display window.

If the currently selected function displays a value that may be edited, such as frequency, test level, or the identification code, a blinking cursor indicates the currently editable character. Pressing the ↑ or ↓ button cycles up or down through the available characters or numerals.

When editing numbers or alpha characters, pressing and immediately releasing the button increments or decrements the value by one number or alpha character. Pressing and holding the button for 1 second initiates automatic incrementing or decrementing, which continues until you release the button. The frequency and level settings have upper and lower limits and cease changing when those limits are reached. The list the character selections for ID are circular and return to the starting point when continuing a change in the same direction.

When making test name selections, the buttons must be pressed and released for each new choice. The list of test names is also circular and returns to the starting point when continuing a change in the same direction.

←(Left Arrow), ⇒(Right Arrow)

The ← and ⇒ buttons are used to select the left or right manual test signal and allow you to select a digit for editing when editing is enabled

If a value you can edit is displayed, pressing the ← or ⇒ buttons moves a blinking cursor one character to the left or the right. When the cursor is on a character, the character blinks off and on, indicating you can edit it. When editing the alphanumeric encoded IDENTIFICATION, the character to edit must be explicitly selected to be controlled by the ↑ and ↓ buttons. When editing a number value, the selected digit to edit will increment and decrement the total value of the displayed value, not just the digit column selected.

If editing is not enabled, there will be no flashing digit or space in the display.

PAUSE AUTO

During an AUTO test signal sequence, pressing the ⇒ button pauses the sequence at the signal step the ASG 100 is generating at that moment.

For example, suppose you press the ⇒ (PAUSE AUTO) button during the step of the O. 33 sequence when the ASG 100 is generating a tone of 80 Hz at -12 dB. The ASG 100 will continue generating that tone, rather than progressing to the next step in the sequence.

Once you have paused the test sequence, you can increment it one step at a time by pressing the ↑ button. You can decrement the sequence by pressing the ↓ button. You can increment to the last test in the sequence or decrement to the first test in a sequence, but you cannot step the test sequence offline.

To resume automatic generation of the rest of the test sequence, press the (PAUSE AUTO) button a second time.

SAVE

If SAVE is pressed when saving is not enabled, the word **Disabled** will be displayed.

If the SAVE function is enabled, pressing the SAVE button stores the function value currently displayed as the default and **Saved** will appear in the display. Once you save a function value, powering on the unit restores that value if user-defined settings are enabled. If user-defined settings are not enabled, the new value saved will be in effect for the time the power is on only. When the power is turned off and back on, the factory defaults will be returned. The normal setting is for user-defined settings to be enabled and recalled on power on.

NOTE

When the factory defaults are restored, all user selected values are written over in the NVRAM, and the user defaults become the same as the factory defaults.

Saving can be done either from the main selection level or at the level of the individual parameter. For example, if the LINE UP function is currently displayed and you press the SAVE button, the frequency and the amplitude parameters currently specified for the line up tone are stored. If the frequency value itself is displayed and you press the SAVE button, only the frequency value is stored.

A selected auto test sequence may be saved as the power-on choice as well as a selected manual test signal. Just select the one you want the start-up setting to be and press SAVE. The ASG 100 powers up each time with the AUTO choice selected, and the selected test will be the one that you saved. When MANUAL is selected, the test name you selected and saved will be the one that appears.

For more information on the enabling edits and saves refer to *Internal Settings and Setup Editing*.

STATUS FEEDBACK

POWER

When the ASG 100 is powered on, the POWER LED lights up.

Power-On Diagnostics

When you power on the ASG 100, it performs a numbered series of tests of its memories and their interconnections, and then tests the backup battery.

The display window shows the number of each test as the ASG 100 performs it, in the format shown below:

DSP 1/4 . . . 2/4 . . . 3/4 . . . 4/4

The sequence of messages above indicates the ASG 100 is performing the self tests, but only the first and last will be evident in the display for normal power-ons. When it completes the numbered tests, the ASG 100 tests its backup battery. A status message is displayed if the battery is not good.

If the ASG 100 fails one of the numbered self tests, it keeps trying to perform that test and displaying its number. When the ASG 100 indicates a failed selftest, you cannot make it perform its other functions. Contact your Tektronix representative for service information.

After repeated iterations, the unit may pass a test it failed initially, and proceed to the next test in the sequence. However, you should still stop using the unit and have it serviced.

OUTPUT $\geq 775\text{mV(rms)}$

The LED above this label blinks when the amplitude of the selected signal is greater than or equal to 0 dBu, as required by the CCITT 0. 33 Standard. This is to alert you to the possibility of levels that could overload or damage equipment. Whenever this LED is blinking, the signal level is increased in tenth dBu steps only when you raise the level using the front panel controls. It may be decreased normally.

Display Window

The ASG 100 lets you set a number of parameters affecting the signal it generates. Using the panel controls you can specify the parameter you want to check or modify. The display window shows the current signal pattern for whatever signal parameter you last chose. When you select the RECORD function, the window also displays instructions for inputting a four-second voice pattern.

When you power up the ASG 100, the display window shows the name of the default automatic test sequence, (either the factory default of O. 33:01 or a user selected automatic test sequence).

Headphones

The HEADPHONES port outputs whatever signal is currently being output through the external output ports. If the ASG 100 is ON LINE, this is the signal pattern currently selected on the ASG 100. If it is off line, it is the program signal being looped through the ASG 100. The VOLUME knob controls the level of the signal through this port. It has no effect on the signal level through the ASG 100.



It is possible to set levels and adjust the volume so the output through the headphones is excessively loud. For safety, use minimum volume level setting when making level adjustments.

REAR PANEL POWER SWITCH AND SIGNAL CONNECTORS




Figure 2-4. ASG 100 Rear Panel connectors.

Power Switch

The ASG 100 power switch is immediately to the right of the power plug receptacle on the back panel (see Figure 2-4). In the off position, the top of the switch, which has a red “O” engraved in it, is out. When the ASG 100 is connected to a power source, power it up by pressing the top of the switch. Power it off by pressing the bottom of the switch.

NOTE

When power is turned on, the selections for the settings will be determined by the stored defaults that are recalled. However, the ASG 100 will be off line, and any signal applied will be automatically connected to the output via the loop-through circuitry.

Audio Signal Connectors

The input and output connectors for the AUDIO IN and AUDIO OUT connectors for the left and right channels are loop-through connectors. When the ASG 100 is off line, the signals applied to the input connectors are connected directly to the output connectors via the internal loop-through circuitry of the ASG 100. A small sample of the incoming program signal is fed to the headphones output connector (on the front panel) so the program audio may be monitored.

Remote Connector

This DB-9 connector is used to access two types of remote control. It may be used to connect switching contacts that are used to start the AUTO Test or to override the editing locked feature so new setups may be saved without removing the ASG 140 from a rack installation to reset the internal DIP switches. Its second purpose is to provide an RS-232C interface for remote control of all the instruments functions. See Appendix A, *Remote Control*, for using the RS-232C interface to control the operation of the ASG 140 remotely. An additional feature controlled via the remote connector is the Audio/Video Timing measurement signal synchronization. See Appendix D, *Audio/Video Timing*, in the Operator’s manual for information on how this feature is used.

INTERNAL SETTINGS AND SETUP EDITING

The ASG 100 allows you to enable and disable editing of various signal features, such as amplitude, frequency and signal identification. Front panel control or remote control or both may also be either enabled or disabled. You can also change the output impedance of the ASG 100. This section describes how to make these changes.

You control signal editing and output impedance through two components found on the circuit board inside the ASG 100:

- The 10-pole DIP switch labeled “S1” on the circuit board. The settings of the first four switches control editability of the user definable test variables and the default values used when the ASG 100 is powered on.
- The DIP resistor package that sets the output impedance of the ASG 100, located in the socket labeled “R167.” Information on setting the output impedance is found in this section of the manual.

Enabling and Disabling Signal Editing

On the ASG 100 circuit board is a DIP switch you can set to enable or disable editing of ASG 100 functions, and to select the type of values used as the defaults for user-definable functions.

As you face the ASG 100, on the left side, near the front is a small screw-on door. Removing the side panel reveals the DIP switch, as shown in Figure 2-5. The individual switches that affect editing and what each does are shown in Figure 2-6.




Figure 2-5 Remove side panel door to access DIP switch.




Figure 2-6. DIP switch settings for editing.

Editing Signal Parameters

After you enable editing of a signal parameter, you can adjust that parameter value from the front panel. To edit a signal parameter, press the front panel buttons required to display the current value. For example, to edit the frequency of the line-up tone, press the **LINE UP** button and then the **FREQUENCY** button.

The digit currently active for editing is indicated by a blinking character, numeral or underscore. To change the active digit, use the \Leftarrow and \Rightarrow buttons. To change the value of the active digit, press either the \Uparrow or \Downarrow button to increment or decrement the value until you get the desired character or number.

Saving Signal Parameters

When you have changed the parameter to the value you want, save it as the default by pressing the **SAVE** button.

If a top-level function (**Line Up** or one of the **Manual** test signals) is displayed, pressing the button saves as defaults the values of all parameter settings beneath that function (both frequency and amplitude in the case of **Line Up**).

If it is a test signal parameter, such as the frequency, that is displayed, pressing the **SAVE** button saves only that parameter value as a default; the default values of any other parameters under the function (such as the amplitude) are not updated.

To leave a signal parameter you have been editing, press any of the main-level function buttons: **SILENCE**, **VOICE**, **AUTO**, **LINE UP**, or **MANUAL**.

When you finish editing signal parameters and saving the desired default values, ensure the DIP switches are set as follows:

- PROG 0** **Down.** This preserves the saved values as defaults that will be restored whenever the operator powers up the instrument. (Placing DIP switch S-1 in the up position erases all user-defined settings and returns factory settings when the operator powers up the instrument.)
- PROG 1**
- PROG 3** **Down.** This prevents further editing of signal parameters.

NOTE

*You may choose to leave all, any, or none of the user-definable frequency and level choices of a testing option editable from the front panel by the technician or engineer using the ASG 100. A normal choice may be to fix the **AUTO** and **LINE UP** test to known settings and leave the **MANUAL** test editable for setting levels and frequencies that may be needed for manual testing. Your application will determine how you decide to customize the test signals and the freedom of operation for the user.*

Table 2-1 shows the present assignment of all the switches of the DIP switch package, and the factory setting of each switch.

**Table 2-1
Dip Switch Functions**

Switch Name	Switch Action		Factory Setting
	Up	Down	
Prog 0	At power up, ASG 100 recalls factory settings for all functions.	At power up, ASG 100 recalls values last saved (with the SAVE button) for user-definable functions. ^a	Down
Prog 1	MANUAL functions can be edited.	MANUAL functions can NOT be edited.	Up
Prog 2	LINE UP function can be edited.	LINE UP function can NOT be edited.	Up
Prog 3	AUTO TEST Level and SOURCE ID can be edited.	AUTO TEST Level and SOURCE ID can NOT be edited.	Up
Prog 4	Normal operating state.	Reserved.	Up
Prog 5	Reserved.	Normal operating state.	Down
Prog 6	Front Panel Controls Enabled.	Front Panel Controls Disabled.	Up
Prog 7	Remote Control Enabled.	Remote Control Disabled.	Up
MOD B	Factory setting required for correct performance. DO NOT CHANGE.		Up
MOD A	Factory setting required for correct performance. DO NOT CHANGE.		Up

^a As shipped from the factory, the factory default settings are stored in the memory reserved for custom settings. This means that when you use the ASG 100 for the first time, the factory defaults will be used, even if DIP switch 1 is in the DOWN (user-defined settings enabled) position.

External Edit Enable

When the editing features are disabled internally, they may be enabled via the rear-panel REMOTE connector. This method of operation permits editing from the front panel when needed without having to remove the installed equipment to access the side panel and internal switches. Editing is enabled by connecting pins 4 and 6 of the Remote connector together. This connection may be made via a jumper, switch, or remote-controlled relay contact.

If activation of the AUTO test sequence using external contact closures is a part of your normal operation, you may also want to add the Remote Edit enable capability. If the need to change a programmed frequency, amplitude, or ID, etc., arises, the feature can be enabled, the edit made by the on-site operator, and then disabled again. When the connection between pin 4 and pin 6 is removed, the settings of internal dip switches again control the state of the editing and saving function for the AUTO, LINE UP, and MANUAL test settings. Note however, that the settings that were edited will now be in effect for the remainder of the test session. If those edits were also SAVED, they will be in effect when the ASG 100 is again turned on.

Front-panel editing may not be enabled via the RS-232C serial commands. However, even with front-panel editing disabled, the remote command arguments for editing still function.

NOTE

There is no remote command for saving an edit to make it a new default, so at the next power on of the ASG 100, the previously "saved" defaults are restored.

Front Panel and Remote Control Enabling

Depending on the mode of operation needed, you may choose to disable the control capabilities of the ASG 100. If remote control alone is needed, and you want no local front panel access, you may disable the front panel controls by setting PROG6, section 7, of S1 to the down position. This effectively prevents any changes from the front panel of the instrument; the front panel is locked out.

The remote control capability of the ASG 100 may be locked out by setting PROG7, section 8, of S1 to the down position. If access is attempted when the RS-232C serial port is shut off, a message is sent to that effect. The ASG 100 still responds to the control signals it recognizes (control C, control Q, and control S) and sends out the sign on messages, but it will not respond to any commands.

Even if both the front panel and the remote access are disabled, the contact closure operation via the remote connector for sending an auto test sequence and enabling the editing features still work. This state of the controls provides minimal access to making any signal level or auto test type changes, and may be used when those sort of changes to operation are to be restricted.

Setting the Output Impedance

The factory setting for output impedance is 12 Ω . If your audio system's configuration requires some other impedance level, you can change the resistor network on the ASG 100 circuit board to create the required impedance.

The output impedance of the ASG 100 is controlled by a resistor network located in the socket marked "R167" and labeled "ACTIVE" on the circuit board. This socket is centered in front of the XLR connectors labeled "J11" and "J14" on the circuit board. You can change the factory output impedance of the ASG 100 by changing the resistor package in the ACTIVE socket.

Tektronix manufactures the ASG 100 with a 10 Ω DIP resistor package in the R167 socket. That resistance is added in series with the resistance of the EMI filters creating a default output impedance of 12 Ω (5 Ω per side of each balanced output plus the 0.8 Ω each of the two filters). The resistor package is marked "100G" (meaning 10.0 Ω , $\pm 2\%$).

For your convenience, an alternate resistor package for producing an output impedance 600 Ω is provided. This resistor package comes installed in socket "R168," which is also labeled "SPARE" on the circuit board. The spare resistor package itself is marked "601G" (meaning 600 Ω $\pm 2\%$). To create a 600 Ω output impedance, remove this resistor package from the "SPARE" socket and insert it in the "ACTIVE" socket in place of the 10 Ω resistor package.

In addition, in case you want to create a custom output impedance, the ASG 100 also provides a blank 16 pin header in the socket marked "R173" and labeled "USER" on the circuit board. This socket is adjacent to the "SPARE" socket. To create a custom output impedance, solder your own resistors to this header and insert it in the "ACTIVE" socket in place of the factory-supplied resistor package.

Figure 2-7 below shows the resistor network and how the socket is wired.




Figure 2-7. Output impedance resistor network.

If you make your own resistor network, it must consist of resistors of equal value. As shown in Figure 2-3, for each output in the XLR connectors, a pair of resistors are wired together in parallel for power handling purposes.


Use parallel resistors with values equal to the output impedance you want to achieve. The resistor pairs are wired in parallel, so the impedance produced on each output pin is one-half the resistance value of each resistor. However, each output port sums the signals on each of its two signal lines to produce a differential signal. This results in an output impedance equal to the resistance value of the resistors used in the resistor package.

NOTE

The output levels indicated by ASG 100 display are in dBu, not dBm, and do not compensate for changing source or load impedances. The levels displayed by the ASG 100 are correct when used with the 12 Ω source impedance and a high impedance load (>1200 Ω). With a 600 Ω load, the output will be reduced by 0.17 dB (see Figure 2-8).

If you change the source impedance to 600 Ω and use the unit in a power-matched system (with 600 Ω loads), the actual output delivered to the load will be 6 dB less than the displayed value.

If you use a custom resistor network to implement some other source impedance, the output levels will be reduced by a different factor, which you must calculate and take into account when reading the displayed values (see Figure 2-9)



The general formula for calculating the dBu difference when the source resistance is held at 12 Ω and the load resistance varies is:


$$dBu_{diff} = 20 \log \left(1 - \frac{12 \Omega}{R_{Load} + 12 \Omega} \right)$$

Using the above formula it can be seen that the front panel ASG 100 dBu reading approximately corresponds to dBm when driving a 600 Ω load. The difference between actual dBm and the ASG 100 readout is -0.17 dB with a 600 Ω load.

The output amplifiers of the ASG 100 are current limited. The load resistance should not be less than 150 Ω.

Figure 2-8. Effects of a changing load resistance on the dBu output of the ASG 100.

Load R = Source R



Difference between displayed dBu and output dBm as a function of source resistance and load resistance changes when matching source and load.

NOTE: Points of interest. At 150 Ω, dBu and dBm match. At 300 Ω, subtract 3 dB from the reading, and at 600 Ω subtract 6 dB.

The source resistance should never be made greater than the load resistance.

Figure 2-9. Effects of matching load and source impedances in the ASG 100.

Section 3

MAINTENANCE

This section contains instructions for preventive maintenance, general troubleshooting, and corrective maintenance. If the instrument does not function properly, troubleshooting and corrective measures should be taken immediately to circumvent additional problems.

LITHIUM BATTERY

Battery Disposal

The ASG100 stores default values when powered off by means of its lithium battery, located on the circuit board, immediately behind the headphones jack. If you need to replace the battery, observe the warnings and instructions in this section.

WARNING

Improper handling may cause fire, explosion or severe burns. To avoid personal injury, observe proper procedures for the handling of lithium batteries. Do not recharge, crush, disassemble, heat the battery above 212°F (100°C), incinerate, or expose the contents to water.

If you replace the ASG 100 lithium battery, dispose of the old battery as required by local, state and federal agencies.

NOTE

Typically, small quantities of the battery (less than 20) can be safely disposed of with ordinary garbage in a sanitary landfill.

Larger quantities must be sent by surface transport to a hazardous waste disposal facility. The batteries should be individually packaged to prevent shorting. Then, pack them into a sturdy container that is clearly labeled as follows:

Lithium Batteries - DO NOT OPEN

Battery Emergency and First Aid Information

Manufacturer: Eagle Picher

Battery Type: Lithium

In case of emergency, follow the instructions in Table 3-1 below.

Table 3-1
Emergency Procedures for Contact with Lithium Battery Contents

Contact	Procedure
Skin	Wash promptly with plenty of water.
Eyes	Flush immediately with plenty of water and use an emergency eye wash, if available. Report to a medical professional for treatment.
Inhalation	Leave the area and get fresh air. Report to a medical professional for treatment.
Ingestion	Non-toxic according to laboratory testing. However, report to a medical professional for advice.

In case of venting, clear the immediate area. Venting will usually last only a few seconds.

FUSE

The power supply for the ASG 140 is internally fused. Refer all internal servicing to a qualified service person.

Use only the specified fuse or equivalent if replacing the fuse. Physically, the fuse is a DIN metric size fuse; but electrically, it is UL and CSA rated for correct protection of the fused circuitry.

Specified Replacement Fuse

Tektronix part number 159-0296-00

Replacement Fuse Description

Fuse, Cartridge: MT4, 2A, 5.2 X 20 mm, NORMAL blow.

Electrical Characteristics:

Rating: 250 V maximum, 2A.

Blow Time at 25°C Ambient:

110% of rated current	4 hour minimum
135% of rated current	60 minutes maximum
200% of rated current	5 seconds

Interrupting Capacity (short circuit current)

10,000 A at 125 V; 100 A at 250 V.

PREVENTIVE MAINTENANCE

Preventive maintenance consists of cleaning, visual inspection, performance checking, and, if needed, readjustment. The preventive maintenance schedule established for the instrument should be based on the environment in which it is operated and the amount of use. Under average conditions, scheduled preventive maintenance should be performed every 2000 hours of operation.

Cleaning

The instrument should be cleaned often enough to prevent dust or dirt from accumulating. Dirt acts as a thermal insulating blanket that prevents effective heat dissipation, and can provide high-resistance electrical leakage paths between conductors or components in a humid environment.

- Exterior** Clean the dust from the outside of the instrument by wiping with a soft cloth or small brush. A brush is especially useful to remove dust from around the selector buttons, knobs, and connectors. Hardened dirt may be removed with a cloth dampened in water that contains a mild detergent. Abrasive cleaners should not be used.
- Interior** Clean the interior of the instrument by loosening the accumulated dust with a dry, soft brush. Once the dirt is loosened remove it with low-pressure air (high-velocity air can damage some parts). Hardened dirt or grease may be removed with a cotton-tipped applicator dampened with a solution of mild detergent and water. Abrasive cleaners should not be used. If the circuit board assemblies must be removed for cleaning, follow the instructions for removal/replacement under the heading of Corrective Maintenance.

After cleaning, allow the interior to thoroughly dry before applying power to the instrument.



Do not allow water to get inside any enclosed assembly or component. Do not clean any plastic materials with organic cleaning solvents, such as benzene, toluene, xylene, acetone, or similar compounds, because they may damage the plastic.

Visual Inspection

After cleaning, carefully check the instrument for defective connections, damaged parts, and improperly seated transistors or integrated circuits. The remedy for most visible defects is obvious; however, if heat-damaged parts are discovered, determine the cause of overheating before replacing the damaged part, to prevent additional damage.

Periodic checks of the transistors and integrated circuits are not recommended. The best measure of performance is the actual operation of the component in the circuit.

STATIC-SENSITIVE COMPONENTS

This instrument contains electrical components that are susceptible to damage from static discharge. Static voltages 1 kV to 30 kV are common in unprotected environments. Table 3-2 shows the relative static discharge susceptibility of various semiconductor classes.

Table 3-2
Static Susceptibility

Relative Susceptibility Levels ^a	Voltage
MOS and CMOS	100 - 500 V
ECL	200 - 500 V
Schottky Signal Diodes	250 V
Schottky TTL	500 V
HF Bipolar Transistors	400 - 600 V
JFETs	600 - 800 V
Linear microcircuits	400 - 1,000 V (est.)
Low-Power Schottky TTL	900 V
TTL	1,200 V

^aVoltage equivalent for levels (voltage discharged from a 100 pF capacitor through a 100Ω resistance).

Observe the following precautions to avoid damage:

1. Minimize handling of static-sensitive components.
2. Transport and store static-sensitive components or assemblies in their original containers, on a metal rail, or on conductive foam. Label any package that contains static-sensitive components or assemblies.
3. Discharge the static voltage from your body, by wearing a wrist grounding strap, while handling these components. Servicing static-sensitive assemblies or components should be done only at a static-free work station by qualified personnel.
4. Nothing capable of generating or holding a static charge should be allowed on the work station surface.
5. Keep the component leads shorted together whenever possible.
6. Pick up the components by the body, never by the leads.
7. Do not slide the components over any surface.
8. Avoid handling components in areas that have a floor or work surface covering capable of generating a static charge.
9. Use a soldering iron that is connected to earth ground.
10. Use only special antistatic, suction, or wick-type desoldering tools.

TROUBLESHOOTING

The material contained here is general and is not intended to cover specific cases. Note that the manual itself is considered a troubleshooting aid, and as such a brief discussion of its contents is in order.

Troubleshooting Aids

Foldout Pages

The foldout pages at the back of the manual contain information that is useful in troubleshooting the instrument. Schematic diagrams, circuit board illustrations, and parts locating charts are found there.

Diagrams - Schematic diagrams are the most often used troubleshooting aids. The circuit number and electrical value of each component is shown on the diagram. The first page has definitions of the symbology used on the schematic diagrams. Refer to the Replaceable Electrical Parts list for a complete description of each component. Circuits that are mounted on circuit boards or assemblies are enclosed in a border, with the name and assembly number shown on the border.

NOTE

Check the Change Information section in the rear of the manual for corrections and modifications to the instrument and the manual.

Board Illustrations - Electrical components, connectors, and test points are identified on circuit board illustrations, which are located on the back of a preceding schematic diagram. Circuit boards are grid numbered, with the lowest number in the upper left corner; highest number in the lower right.

Parts Locating Charts - Generally, components mounted on etched circuit boards are assigned circuit numbers according to their geographic location within the assembly, beginning with the lowest numbers at the upper left corner (as pictured in the illustration). The schematic diagrams are assigned location grids, and a parts locating chart (for each schematic diagram) gives grid locations of components on that schematic.

Parts Lists

There are two separate parts lists in this manual. The List of Replaceable Electrical Parts precedes the schematic diagrams and circuit board illustrations. The List of Replaceable Mechanical Parts accompanied by exploded view drawings, follows the schematic diagrams and circuit board illustrations.

Replaceable Electrical Parts - This list is arranged by assembly as designated in ANSI Standard Y32.16-1975. The list begins with the part numbers for the major assemblies (etched circuit boards). Each circuit board is identified by an A# (Assembly Number).

The circuit numbers of the individual components in the parts list is made up by combining the assembly number with the individual circuit number.

EXAMPLE: R117 on Assembly (circuit board) A3 would be listed in the Replaceable Electrical Parts list as A3R117.

NOTE

Always consult the parts list for part numbers and descriptions when ordering replacement parts. Some parts may have been replaced or have a different part number in an individual instrument. Also check the "Change Information" at the back of the manual for the most recent changes.

Replaceable Mechanical Parts - This list is arranged so that it corresponds to the exploded view drawing for major instrument components. Standard Accessories, which are included in the parts list, are also included in the exploded view drawing.

Major Assembly Interconnection

Signals and power supply voltages are passed through the instrument by a system of interconnecting cables. The connector holders on these cables have numbers that identify terminal connectors; numerals used are from 2 up. A triangular key symbol is used to identify pin 1 on the circuit board to assist in aligning connectors with correct square pins.

General Troubleshooting Techniques

The following procedure is designed to assist in isolating problems, which in turn expedites repairs and minimizes down time.

1. Ensure that the malfunction actually exists. This is done by making sure that the instrument is operating as intended by Tektronix.
2. Determine and evaluate all trouble symptoms. This is accomplished by isolating the problem to a general area such as an assembly. The block diagram is a valuable aid in signal tracing and circuit isolation.



Use extreme care when probing with meter leads or probes, because of the high component density and limited access within the instrument. The inadvertent movement of leads or a probe could cause a short circuit or transient voltage capable of destroying components.

3. Determine the nature of the problem. Attempt to make the determination of whether the instrument is out of calibration or if there has been a component failure. Once the type of failure has been determined, proceed on to identify the functional area most likely at fault.
4. Visually inspect the suspect assembly for obvious defects. Most commonly these will be broken or loose components, improperly seated components, overheated or burned components, chafed insulation, etc. Repair or replace all obvious defects. In the case of overheated components, determine the cause of overheating and correct the cause before re-applying power.
5. Use successive electrical checks to locate the source of the problem. At times it may be necessary to change a calibration adjustment to determine if a circuit is operational, but since this can destroy instrument calibration, care should be exercised. Before changing an adjustment, note its position so that it can be returned to its original setting.
6. Determine the extent of the repair. If the necessary repair is complex, it may be advisable to contact your local Tektronix field office or representative before continuing. If the repair is minor, see the parts list for replacement information.

Power-On Diagnostics

When you power on the ASG 100, it performs a numbered series of tests of its memories and their interconnections, and then tests the backup battery.

The display window shows the number of each test as the ASG 100 performs it, in the format shown below:

DSP 1/4 . . . 2/4 . . . 3/4 . . . 4/4

The sequence of messages above indicates the ASG 100 is performing the self tests. The 2/4 and 3/4 test normally occur too quickly to be seen in the display. The tests performed are described in Table 3-3.

Table 3-3
Self Diagnostic Tests

Test Number	Description
DSP 1/4	Read-only memory
DSP 2/4	Data Bus
DSP 3/4	Address Bus
DSP 4/4	Non-volatile memory

When it completes the numbered tests, the ASG 100 tests its backup battery. A status message is displayed if the battery is not good.

If the ASG 100 fails one of the numbered self tests, it keeps trying to perform that test and displaying its number. When the ASG 100 indicates a failed test, you cannot make it perform its other functions. Contact your Tektronix representative for service information.

After repeated iterations, the unit may pass a test it failed initially, and proceed to the next test in the sequence. However, you should still stop using the unit and have it serviced.

CORRECTIVE MAINTENANCE

NOTE

Repair should not be attempted by the customer during the warranty period.

Obtaining Replacement Parts

Replacement parts are available through the local Tektronix, Inc. field office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components, as they become available, and to improve circuit performance. Therefore, it is important to include the following information when ordering parts:

1. Part Number
2. Instrument Type or Number
3. Serial Number
4. Modification or Option Number (if applicable)

If a part has been replaced with a new or improved part, the new part will be shipped (if it is a direct replacement). If the part is not directly replaceable, the local Tektronix field office or representative will contact the customer concerning any changes. After any repair, circuit readjustment may be required.

Removal and Replacement Procedures

Tools required:

1/2 inch open-end wrench

1/16 inch hexagonal wrench

3/32 inch flat-bit screwdriver

1P POZIDRIV screwdriver

3/16 inch nutdriver

Cabinet Removal and Replacement

1. Disconnect the power cord from the rear of the instrument.
2. Remove the six POZIDRIV screws holding the top cover to the chassis. Do not remove the two screws that hold the small access plate on the left side. Lift the top cover off the instrument.

Front Panel Removal and Replacement

1. Disconnect J20 (headphone connector) from the main board, and disconnect J2 (microphone cable) from the front panel board.
2. Use a small, flat-bit screwdriver to pry gently on both ends of connector J8 (the large ribbon cable to the front panel) to disengage the connector from the main board mating pins.
3. Turn the instrument over and remove the two POZIDRIV screws that hold the front panel assembly to the chassis.
4. If you wish to further disassemble the front panel board assembly, remove the four POZIDRIV screws holding the circuit board to the front panel ring. The circuit board may then be separated from the ring.
5. Remove the 1/2 inch retaining nut and washer on the headphone jack and the volume control knob to separate the front panel from the front panel circuit board. A 1/16 inch Allen wrench is needed to loosen the retaining screw in the volume control knob.

To reinstall the front panel assembly use the following procedure.

1. Reassemble the front panel to the front panel circuit board. Reinstall the retainer nut on the headphone connector and the volume control knob.
2. Insert the assembled front panel and front panel circuit board into the front panel ring and reinstall the four holding screws. Make sure that the headphone connector ground lug is connected to the front panel ring by the holding screw near that connector.
3. Position the front panel assembly on the front of the chassis and reinstall the two holding screws on the bottom side of the chassis. Start both screws then tighten firmly. Do not over tighten.

Main Board Removal and Replacement

1. Remove the front panel assembly (see the Front Panel Removal and Replacement procedure).
2. Disconnect connectors J23 (to the power supply) and J25 (to the rear panel) from the main board.

3. Remove the eight POZIDRIV screws holding the main board to the chassis.
4. Use a 3/32 inch flat-bit screwdriver to release the four XLR connectors from their housings on the rear panel. Insert the screwdriver into the small slot in the center of the XLR connectors and turn counterclockwise (less than 1/4 turn required) to release the latch.
5. Lift up the front of the main board slightly to clear the mounting studs and press on the connectors while sliding the board toward the front to remove the connectors from their housing on the rear panel. A slight wiggle of the front of the board helps to release the connectors from the housings.

To reinstall the main board use the following procedure.

1. Slide the main board XLR connectors straight into the connector housing on the rear panel.
2. Align the screw holes in the main board with the mounting studs, and start all eight retaining screws. After all the screws are started, tighten all eight screws. Do not over tighten.
3. Use the 3/32 inch small bit screwdriver to reengage the XLR connector release by inserting the bit into the small slot in the center of the connectors and turning clockwise until the latch is engaged (less than 1/4 turn).
4. Reconnect J23 and J25 to the main board.
5. Reinstall the front panel assembly.

Power Supply Removal and Replacement

1. Disconnect connector J23 from the main board.
2. Remove the three POZIDRIVE screws holding the power supply to the chassis.
3. Slide the plastic shield forward and off the power supply.
4. Disconnect connector J1 (ON/OFF switch) from the power supply board and remove the power supply from the instrument.

To reinstall the power supply use the following procedure.

1. Position the power supply board over the mounting studs and reconnect J1 to the board.
2. Slide the plastic shield back in place, aligning the holes in the bottom of the shield to the mounting stud holes.
3. Reinstall the three retaining screws in the power supply board. Start all three, then tighten firmly. Do not over tighten.

Serial Connector EMI Board Removal and Replacement

1. Disconnect connector J25 (1/2 inch wide ribbon cable) from the main board.
2. Use a 3/16 inch nutdriver to remove the connector retaining screws.
3. Remove the serial connector, EMI board, and attached ribbon cable from the instrument.

To reinstall the serial connector EMI board assembly use the following procedure.

1. Place the serial connector through the hole in the rear panel and reinstall the two connector retaining screws. Tighten the two screws firmly, but do not over tighten.
2. Reconnect J25 to the main board.

Section 4

VERIFICATION AND ADJUSTMENT

This section is divided into two sets of procedures. The first set is used to verify the operation of the ASG 100. The second and shorter procedure that follows verification is used to return the ASG 100 to specification if adjustment is needed. The test equipment shown in Table 4-1 or an equivalent substitute is that required for both verification and adjustment. If the example test equipment is not available, check the minimum specifications to determine if another piece of test equipment might be used. If other test equipment is used, controls and connectors for that equipment may be different than called out for the example test equipment. Refer to the appropriate operator's manuals for operation of the test equipment.

Table 4-1
Test Equipment Required for Verification and Adjustment

Equipment	Minimum Specification	Purpose	Example
Low Distortion Oscillator	Balanced output, sine wave output, 20 Hz to 20 kHz.	Check loop-through.	Tektronix SG5010 ^a or SG 505. ^a
Distortion Analyzer	Balanced input, THD accuracy > 0.001%, 22 Hz to 22 kHz audio bandpass.	Check/Adjust signal.	Tektronix AA5001 ^a or AA501A.
Digital Multimeter with test leads	Accuracy 0.05%, 4-1/2 digit display.	Check power supply.	Tektronix DM504A. ^a
Frequency Counter	Accuracy 0.01%, 8-digit display.	Check frequency accuracy.	Tektronix DC 503A ^a or equivalent.
RMS Meter	Accuracy 1%, resolution 5 digits; balanced input.	Check amplitude accuracy and flatness.	Fluke 8506A or 8505A-09 or equivalent.
Test Oscilloscope	Dual Channel: 60 MHz bandwidth.	Check channel phase difference.	Tektronix 2465B or 2246A.
Stereo Headphones	10 Hz to 20 kHz response standard stereo phono plug connector.	Check headphone output and auto test sequences.	
Serial Communications Terminal with RS-232C interconnection cable.	RS-232C serial ASCII communications.	Check RS-232C serial port and remote operation.	IBM or compatible with terminal software program.
Audio Signal Cable (2 required)	XLR-male-to-triple-banana adapter cable.	Signal connections for frequency and loop-through checks.	E-Z-Hook 5023-24.
Audio Signal Cable (2 required)	XLR-female-to-triple-banana adapter cable.	Signal connections for frequency and loop-through checks.	E-Z-Hook 5023F-24.
Adapter	BNC-male-to-dual-binding-post-banana adapter.	Signal interconnection for channel phase check.	Tektronix Part Number 103-0035-00.

^a A Tektronix TM500 power supply is required to power the plug in test equipment.

VERIFICATION PROCEDURE

These verification procedures are designed to be done with the cover of the ASG 100 installed, using the normal operating controls only. If a verification check fails, it may mean that the instrument needs repair and/or adjustment. Refer any repairs or adjustments to a qualified service person.

Preparation

Remove the small access plate on the left side of the ASG 100 to set the internal dip switch for performing the verification procedure.

Set the switch sections of S1 as follows to enable the editing and save features of the ASG 100 so they can be checked. Note the switch positions prior to setting them if it is necessary to restore the setup.

PROG0 (section 1)	up
PROG1 through PROG3 (sections 2, 3, 4)	up
PROG4 (section 5)	up
PROG5 (section 6)	down
PROG6 (section 7)	up
PROG7 (section 8)	up
MODA and MODB (sections 9, 10)	up

Procedures

1. Power Up Check

- a. Connect the power cord to the ASG 100 and turn on the ASG 100.
- b. Check that the ASG 100 initializes normally and finishes with the AUTO LED lit.
- c. Set PROG0 (section 1) of the internal dip switch to the down position. This enables user's front panel settings to be restored on power up. With PROG0 in the up position, factory defaults for front panel settings are stored in the NVRAM at each power up.

2. Check Frequency Accuracy ($\pm 0.1\%$)

- a. Connect the Audio Out Left connector to the frequency counter BNC input via the XLR-female-to-triple-banana-connector adapter and the BNC male-to-dual-binding-post banana adapter. Connect pin 1 of the XLR connector (green) to ground of the BNC dual-binding-post adapter. Connect pin 2 of the XLR connector (black) to the red post of the BNC dual-binding-post adapter. Do not connect pin 3 of the XLR connector; leave it open.

NOTE

The color of the conductors for the pins in the XLR connector apply to the example cable. If a substitute XLR to triple banana connector adapter is used, the correct pin-to-conductor color must be verified.

- b. Select the LINE UP signal from the ASG 100 and check the current frequency setting (factory default is 400 Hz).
- c. Press the ON LINE button and check that the frequency counter is triggered correctly.
- d. Check that the output frequency is as noted in part b within $\pm 0.1\%$. Example: 400 Hz \pm 0.4 Hz (399.6 to 400.4 Hz).
- e. Disconnect the test signal from the frequency counter.

3. CHECK AMPLITUDE ACCURACY (± 0.2 DB AT 1000 HZ)

- a. Connect the Audio Out Left connector to the balanced input connectors of the rms voltmeter via the XLR-female-to-triple-banana-connector adapter cable. Pin 1 of the XLR adapter cable (green) is ground, pin 2 (black) is + and pin 3 (red) is -.
- b. Set the ASG 100 for a MANUAL L Tone output of 1 kHz at 0 dBu and press the ON LINE button (LED indicator in the button should light).
- c. Set the rms meter appropriately to measure 0 dBu (0.7746 V rms) unterminated. (If a 600 Ω termination is used, the amplitude will be 0.17 dB lower, 0.7594 V rms.)
- d. Check that the amplitude is 0 dBu ± 0.2 dBu (0.75697 to 0.79264 V rms).
- e. Set the ASG 100 to the other dBu values given in Table 4-2, and check that the rms meter reads within the amplitude tolerance shown. Use either Auto Range or an appropriate voltage range setting of the rms meter to make the measurement.
- f. Move the XLR connector to the Audio Out Right connector, set the ASG 100 for a MANUAL R Tone output signal of 1 kHz at 0 dBu, and repeat parts c through e to check the right channel signal amplitude accuracy.

**Table 4-2
Amplitude Accuracy Check Points**

dBu	Volts RMS	Tolerance (± 0.2 dB)
-40 dBu	0.00775 V	0.00757 to 0.00793 V
-30 dBu	0.02450 V	0.02394 to 0.02507 V
-20 dBu	0.07746 V	0.07570 to 0.07926 V
-10 dBu	0.24495 V	0.23937 to 0.25066 V
0 dBu	0.7746 V	0.75697 to 0.79264 V
+10 dBu	2.4495 V	2.39374 to 2.50656 V
+20 dBu	7.7460 V	7.5696 to 7.92643 V

4. CHECK AMPLITUDE FLATNESS (+0.05/-0.2 DB, 10 HZ TO 20 KHZ)

- a. Move the XLR connector to the Audio Out Left connector. Set the ASG 100 for a MANUAL L Tone output of 1 kHz at +14 dBu.
- b. Note the amplitude of the test signal as indicated by the rms meter (+14 dBu is 3.8822 V).
- c. Set the ASG 100 frequency to the values given in Table 4-3 and note the output amplitude as indicated on the rms meter for each frequency.

**Table 4-3
Test Frequencies for Amplitude Flatness**

ASG 100 Frequency	Left Tone Amplitude	Right Tone Amplitude
20 Hz		
100 Hz		
400 Hz		
1000 Hz (reference)		
5000 Hz		
10000 Hz		
15000 Hz		
20000 Hz		

- d. Check that the amplitude is flat within +0.05/-0.2 dB at each test frequency with respect to the 1000 Hz 14 dBu amplitude noted in part a. The amplitude accuracy specification permits the 14 dBu amplitude at 1000 Hz to be 3.7938 to 3.9726 V, and the flatness has to be calculated using the measured voltage to check the actual flatness over frequency. (More or other frequencies may be checked as considered necessary. The empty columns of Table 4-3 are provided to enter the amplitude for each frequency if you wish.)

The voltage-to-dB conversion is done using the following formula:

$$dB = 20 \log \frac{\text{Measured voltage}}{\text{Reference voltage}}$$

The reference voltage value is that noted for the 1 kHz +14 dBu MANUAL Tone signal. The Measured voltage is the signal amplitude at each of the other frequencies checked.

For example:

Assume the reference voltage (1 kHz, +14 dBu) is 3.87 V and that the measured voltage for a different frequency signal is found to be 3.854 V. Substituting these values into the equation gives:

$$dB = 20 \log \frac{3.854}{3.87} = -0.036 \text{ dB}$$

- e. Move the XLR connector to the Audio Out Right connector. Set the ASG 100 for a MANUAL R Tone of 1 kHz at +14 dBu.
- f. Repeat parts b through d to check the right channel amplitude flatness.

5. Check Channel-to-Channel Level Difference (≤ 0.2 dB at +14 dBu)

- a. With the XLR connector on the Audio Output Right signal, set the ASG 100 for a MANUAL Tone output signal of 1 kHz at +14 dBu. Using the Tone test signal places the same signal on the left and right channel output amplifiers.
- b. Note the output amplitude of the right channel Tone signal on the rms meter.
- c. Move the XLR connector from the Audio Out Right connector to the Audio Out Left connector.
- d. Note the output amplitude of the left channel Tone signal on the rms meter.

- e. Check that the amplitude of the Tone signal is the same for both channels within ± 0.2 dB. The calculation for dB is as given in step 4.
 - f. Set the ASG 100 for a MANUAL L Tone signal and note the output amplitude of the L TONE signal on the rms meter. Using the L Tone test signal verifies the left channel signal-generating circuitry.
 - g. Check that the amplitude of the L Tone signal is within ± 0.2 dB of the Tone signal amplitude noted in part d. The calculation for dB is as given in step 4.
 - h. Take the ASG 100 off line and disconnect the test signal connector from the rms meter.
6. Check Total Harmonic Distortion + Noise (< 0.015%, 20 Hz to 19 kHz; < 0.056%, > 19 kHz to 20 kHz)
- a. Connect the Audio Out Left connector to the balanced input connectors of the audio distortion analyzer (AA5501 or AA501) via an XLR female-to-triple-banana connector adapter cable. Pin 1 of the XLR adapter cable (green) is ground, pin 2 (black) is + and pin 3 (red) is -.
 - b. SET Distortion Analyzer

Input Range	AUTO RANGE
Function	THD + N
Response	RMS
Filters	AUDIO BAND PASS or 30 kHz LOW PASS *
Attenuation	None
 - c. SET ASG 100

MANUAL	L TONE
AMPLITUDE	+14.0 dBu
FREQUENCY	Table 4-4
ON LINE	On line (LED lit and OUTPUT ≥ 775 mV(rms) LED flashes)
 - d. Check for a THD + N of less than 0.015% for each of the frequencies listed in Table 4-4. (Other frequencies may be used if considered necessary. The empty columns of Table 4-4 are provided to enter the THD + N reading for each frequency if you wish.)

Table 4-4
Test Frequencies for THD + Noise

Frequency	Left Channel THD + N Reading	Right Channel THD + N Reading
20 Hz		
100 Hz		
400 Hz		
1000 Hz		
5000 Hz		
10000 Hz*		
15000 Hz*		
18000 Hz*		
19000 Hz*		

* Measurements above 7 kHz should be made using the 80 kHz Low Pass Filter.

- e. Set the ASG 100 for a frequency of 20000 Hz and check for a THD + N of less than 0.056%.
- f. Move the XLR connector to the Audio Out Right connector. Set the ASG 100 for a MANUAL R Tone signal and repeat the measurements of parts d and e.

7. Check Signal-to-Noise Ratio (>80 dB at 0 dBu at 1 kHz)

- a. Move the XLR connector to the Audio Out Left connector.
- b. Set the ASG 100 for a MANUAL L Tone output of 1000 Hz at 0 dBu.
- c. Set the distortion analyzer for dB RATIO and LEVEL. Select the AUDIO BAND PASS filter.
- d. Press SET REF on the distortion analyzer. The reading should now be 0.0.
- e. Select SILENCE from the ASG 100.
- f. Check that the noise floor is more than 80 dB down from the signal level.
- g. Move the XLR connector to the Audio Out Right connector.
- h. Set the ASG 100 for a MANUAL R Tone output of 1000 Hz at 0 dBu and repeat parts c through f to check the right channel Signal-to-Noise ratio.
- i. Set the ASG 100 to off line and disconnect the signal from the distortion analyzer.

8. Check Channel-to-Channel Phase Difference ($\leq 1^\circ$, 10 Hz to 20 kHz)

- a. Connect the Audio Out Left connector to the CH1 input of the test oscilloscope via an XLR-to-banana adapter cable and BNC-male-to-dual-binding-post-banana-connector adapter. Connect pin 1 of the XLR adapter cable (green) to ground, and connect pin 2 (black) to the + input binding post.
- b. Connect the Audio Out Right connector to the CH2 input of the test oscilloscope via an XLR-to-banana adapter cable and BNC-male-to-dual-binding-post-banana-connector adapter. Connect pin 1 of the XLR adapter cable (green) to ground, and connect pin 2 (black) to the + input binding post.
- c. Set the test oscilloscope

Input Coupling	GND
CH 1 and CH 2 VOLTS/DIV	1 V
Trigger SOURCE	CH 2
Trigger MODE	AUTO
Vertical MODE	CH 1 and CH 2
Horizontal MODE	A
SEC/DIV	5 μ s
- d. SET ASG 100

MANUAL	Tone
AMPLITUDE	+14.0 dBu
FREQUENCY	20000 Hz
ON LINE	On line (LED lit and OUTPUT ≥ 775 mV(rms) LED flashes)
- e. Adjust the Horizontal POSITION to place the beginning of the sweep on the leftmost vertical graticule line.
- f. Adjust the Vertical POSITION of both channels to align the baseline traces with the center horizontal graticule line.
- g. Set the Input Coupling to DC (both channels).
- h. Set the Trigger MODE to NORM and adjust the Trigger LEVEL so that the zero crossing point of the signal is at the beginning of the trace on the center horizontal graticule line.
- i. Press the X10 MAG control of the oscilloscope.

- j. Check that the difference between the two channel traces is less than 0.28 horizontal division. $(0.28 \text{ div} \times \frac{36 \text{ deg per div}}{10} = 1.00 \text{ degree})$
- k. Set the ASG 100 frequency to 10 Hz and set the oscilloscope to 10 ms (with X10 MAG on). Make sure the trigger point and trace still start at the beginning of the trace on the center horizontal graticule line.
- l. Check that the difference between the two channel traces is less than 0.28 horizontal division.
- m. Disconnect the test oscilloscope setup.

9. Check Loop-Through

- a. Provide a test signal of known amplitude (check or set with the rms meter).
- b. Apply the test signal to the Audio In Left XLR loop-through input and connect the Audio Out Left connector to an rms voltage meter.
- c. Check the test signal for the signal level set in part a.
- d. Move the test signal input to the Audio In Right XLR connector and connect the Audio Out Right signal to the rms voltage meter.
- e. Check the test signal for the signal level set in part a.

NOTE

An additional check of the loop through may be done if considered necessary. Perform a THD + N check of the signal before and after the loop through to verify no additional distortion of the signal occurs and no additional noise is added to the signal.

10. Check SAVE Operation

NOTE

If the SAVE feature is enabled, the word "Saved" appears when the SAVE button is pressed. If SAVE is disabled internally, the word "Disabled" appears when the SAVE button is pressed. The SAVE feature must be enabled to perform this check.

- a. Select the MANUAL L Tone signal. Set the Frequency for 2 kHz and the Amplitude for -12 dBu.
- b. Press SAVE (the word Saved should appear), then turn off the ASG 100 (off switch on the rear panel).
- c. Turn on the ASG 100. When the initialization has completed, press MANUAL.
- d. Check that the L Tone signal is selected, the frequency is 2000 Hz, and the amplitude is -12 dBu.

11. Check RECORD and Headphones Operation

- a. Connect a set of stereo headphones to the front panel HEADPHONES connector and turn the VOLUME control to minimum.
- b. Press and release the SILENCE and VOICE buttons at the same time.

- c. Check that the recording sequence begins and record a voice test signal for the 4 second recording session. Speak normally about two or three feet from the front of the ASG 100 to record a test message during the recording period.
- d. Press VOICE , then ON LINE. Slowly increase the Volume control to a comfortable listening level.
- e. Check that the recorded test message is continually repeated while the ASG 100 is on line.
- f. Press ON LINE again to turn off the voice test signal.

12. Check Audio/Video Timing Control

- a. Set the ASG 100 for a MANUAL Tone of 400 Hz.
- b. Listen to the signal in the headphones and ground pin 1 of the rear panel remote connector.
- c. Check that the output signal turns off when pin 1 is grounded.
- d. Unground pin 1 of the remote connector and check that the signal turns on again.

13. Check AUTO Test O.33 and Tek Sequences and AUTO TEST LVL Operation

- a. Set the ASG 100 for the O.33:01 Auto Test.

NOTE

If the editing is disabled, you will not be able to make edits to the frequency or test levels, and the word "Disabled" appears when the SAVE button is pressed. The SAVE feature must be enabled to perform this check.

- b. Press IDENTIFICATION and edit the displayed text to a new ID.
- c. Press AUTO again to return to the O.33:01 display and press and hold the Amplitude button. The message TEST Lev should be displayed. Release the button.
- d. Check that the TEST Lev maximum value is +14.0 dBu and its minimum value is -6.0 dBu. Edit the TEST Lev to +1 dBu.
- e. Press the AUTO button to return to the top of the menu, then press the SAVE button (Saved message should appear).
- f. Reset the ASG 100 by pressing the left and right arrow buttons at the same time.
- g. Check that the ASG 100 initializes with the O.33:01 test displayed in the readout window, that the TEST Lev is +1 dBu, and that the Identification is as set in part b.
- h. Press the ON LINE button and listen in the headphones for the test sequence to occur and that at the end of the test sequence, the ASG 100 goes off line.

14. Check AUTO Test Sweep and SweepLev Operation

- a. Set the ASG 100 for the Sweep Auto Test.
- b. Press and hold the AMPLITUDE button. The message SweepLev should be displayed. Release the button.
- c. Check that the SweepLev maximum value is +24.0 dBu and its minimum value is -90.0 dBu. Edit the SweepLev to +1 dBu.

- d. Press the AUTO button to return to the top of the menu, then press the Save button (Saved message should appear).
- e. Reset the ASG 100 by pressing the left and right arrow buttons at the same time.
- f. Check that the ASG 100 initializes with the Sweep test displayed in the readout window, and that the SweepLev is +1 dBu.
- g. Press the ON LINE button and listen in the headphones for the Sweep test sequence to occur and that at the end of the test sequence, the ASG 100 goes off line.

15. Check Remote Operation

- a. Connect the ASG 100 to an ASCII terminal or PC running terminal communications software. See Appendix A for serial communications setup and remote operation if necessary.
- b. Turn the power off and back on again to check the power up messages.
- c. Type ? to obtain the ASG 100 Remote Command Menu.
- d. Type `tone 1:-4 f:2000 (cr)`. Check that the ASG 100 goes on line with the word Tone displayed.
- e. Type `offline (cr)`. Check that the ASG 100 goes off line.
- f. Type `tone?`. Check that the returned Tone frequency is 2000 Hz and that the Tone level is -4.0 dBu.
- g. Turn off the ASG 100 and disconnect the serial communications cable.
- h. Restore any settings and dipswitch positions needed to return the ASG 100 to its needed state for operation and replace the access plate over the dipswitch.

ADJUSTMENT PROCEDURE

Preparation

- a. Disconnect the power cord from the ASG 100 and remove the top cover of the instrument.
- b. Set the switch sections of S1 as follows:

PROG0 (section 1)	up (stores factory defaults on power up)
PROG1 through PROG3 (sections 2, 3, 4)	up (enables editing and saving)
PROG4 (section 5)	up (factory setting)
PROG5 (section 6)	down (factory setting)
PROG6 (section 7)	up (enables remote control)
PROG7 (section 8)	up (enables front panel)
MODA and MODB (sections 9, 10)	up (factory settings)
- c. Connect the power cord to the ASG 100 and turn on the power switch. Check that DS1, near the power supply connector, comes on.
- d. Set PROG0 of S1 to the down position. This enable the user-settable defaults. With the PROG0 up, the factory defaults are restored at each power on.

Procedures

1. Check Supply Voltages

Test Equipment Required	
Power Supply (TM500)	Digital Multimeter (DM504A)

- a. Use the digital multimeter to check the power supply voltages at J23.

+15 V	Pin 1	14.55 V to 16.5 V (-3%, +10%)
-15 V	Pin 6	-14.25 V to -15.75 V (±5%)
+5 V	Pins 2 and 3	4.90 V to 5.10 V (±2%)

- b. Check the following supplemental regulated voltages at the points indicated.

+12 V	Out Pin of U68	+12 V ± 0.6 V
+12 V	Out Pin of U69	+12 V ± 0.6 V
+5 V _A	Out Pin of U7	+5 V ± 0.25 V
-5 V _A	Out Pin of U8	-5 V ± 0.25 V
-12 V	Out Pin of U70	-12 V ± 0.6 V

2. Adjust Gain

Test Equipment Required	
Distortion Analyzer (AA5001)	RMS Meter
Power Supply (TM500)	Audio Signal Cables (XLR-Male-to-banana-connector)

- a. Connect the ASG 100 Audio Out Right XLR connector to the rms meter via an XLR-to-banana-connector adapter cable. Pin 1 is ground, pin 2 is the +output and pin 3 is the -output of the ASG 100.
- b. Set the rms meter to measure rms voltage (unterminated). Use either Auto Range or an appropriate range setting to measure the expected rms voltage.
- c. SET ASG 100:

MANUAL	R Tone
AMPLITUDE	+14.0 dBu
FREQUENCY	1000 Hz
ON LINE	On line (LED lit and OUTPUT ≥775 mV(rms) LED flashes)
- d. Adjust the Right Channel Gain potentiometer, R24, for an amplitude of 3.89 volts.
- e. Press ON LINE to turn off the test signal (ON LINE LED off).
- f. Disconnect the XLR connector from the Audio Out Right connector and move it to the Audio Out Left connector.
- g. Set the ASG 100 MANUAL test signal to L Tone and press ON LINE to turn on the test signal.
- h. Adjust the Left Channel Gain potentiometer, R26, for an amplitude of 3.89 volts.
- i. Press ON LINE to turn off the test signal (ON LINE LED off).
- j. Disconnect the test cable from the rms meter.

3. Adjust Distortion

- a. Connect the XLR-to-banana-connector test cable from the Audio Out Left connector to the distortion analyzer balanced inputs. In the adapter cable, pin 1 (green) is ground, pin 2 (black) is the +output and pin 3 (red) is the -output of the ASG 100.
- b. SET Distortion Analyzer:

Input Range	AUTO RANGE
Function	THD+N
Response	RMS
Filters	30 kHz LOW PASS or AUDIO BAND PASS
- c. Set the ASG 100 MANUAL test signal to L Tone and press ON LINE to turn on the test signal.
- d. Adjust the Left Channel MSB potentiometer, R28, for minimum THD reading (<0.01 %).
- e. Press ON LINE to turn off the test signal (ON LINE LED off).

- f. Disconnect the XLR connector from the Audio Out Left connector and move it to the Audio Out Right connector.
- g. Set the ASG 100 MANUAL test signal to R Tone and press ON LINE to turn on the test signal.
- h. Adjust the Right Channel MSB potentiometer, R27, for minimum THD reading (<0.01 %).
- i. Press ON LINE to turn off the test signal (ON LINE LED off) and disconnect the test equipment from the ASG 100.

Section 5

THEORY OF OPERATION

CONTROL PROCESSOR (Diagram 1)

Front Panel Processor

The front panel processor monitors the front panel buttons, lights the LED indicators as appropriate, produces the character displays in the display window, handles the serial interface processing, and commands the DSP processor to generate the requested signal or sequence.

The processor is a special purpose microprocessor with built in RAM and bit manipulation registers. The built in RAM can be programmed to operate the processor without the need to have further bus accessed to fetch instructions from external RAM. The bit manipulation registers are addressable, 8-bit registers, and the individual bits can be checked, compared, complemented, zeroed, etc., as needed by the task being performed.

The processor also has built in timers. One of these is used to generate the interrupts needed for the front panel scanning that checks for switch presses.

There are three main buses to and from the processor. These are the 16-bit address bus (AD0-AD7 and A8-A15), the 8-bit data bus (AD0-AD7), and the 8-bit control bus (PROG0-PROG5, /DCR and /DSR).

Notice that the lower 8 bits of the address are multiplexed with the data on the AD0-AD7 pins. The data is separated from the address information by address latch U47 when the ALE (address latch enable) bit is high. When the ALE bit is low (/PROG) the data on the bus is valid. The /PSEN control line dictates when the EPROM, U63 is enabled to output data to the data bus. It is also one of the input signals to the address decoder, U49, that are decoded to produce the various enable strobes for the digital devices on the processor buses.

Another bus to the processor is the one that handles the serial communications (/RDX, /TDX, /INT0, /RTS, /CTS, and /RI) and provides the /RD and /WR (read and write) control signals to the devices on the data bus of the processor.

Subsets of the various bus signals are used to communicate with the DSP processor and the front panel character display device.

Crystal Y2 generates the 11.059 MHz operating frequency for the front panel processor.

Reset Circuit U54 and Inverting Buffer

The Reset circuit delays processor operation until the voltage stabilizes. When the operating voltage reaches a stable level, the reset is removed from the front panel processor allowing it to access its memory for initialization commands. The output of U54 is true low, so an inverter, U40C, provides the necessary logic level to the processor's Reset input.

Address Latch (Address/Data Demultiplexer)

The eight bits of the data bus, DATA0 through DATA7, are multiplexed with the lower eight bits of the 16 address bits. Multiplexer U47 is enabled by ALE (address latch enable) when the bus has valid address data, and those eight bits are latched. The latched bits plus the remaining eight bits from the unmultiplexed address bus combine to produce the 16-bit addresses on the address bus, ADDR0 through ADDR15.

RAM

RAM U64 is a static RAM device with a 15-bit Address Bus and an 8-bit Data Bus. The RAM device is connected to a backup battery to hold the stored data in memory during power off. The backup battery makes this RAM a non-volatile device, and it is used to store the user-selectable operating states for the ASG 100. When user selectable defaults are enabled, the state of the instrument on power up is restored from the saved data in this device.

EPROM

EPROM U63 stores the program memory. The processor gets its operating instructions from this memory device. The EPROM has a 16-bit address bus and an 8-bit data bus. When factory defaults are selected, the state of the instrument on power up is restored from data stored in this device.

Battery Backup

Level Monitor U62 checks the +5 V line. If the voltage on this line is more than 0.3 V above battery voltage (BATT), the power for operating the static RAM is supplied from the +5 V line. If the +5 V line voltage drops low enough, U62 disables the chip select to the RAM and supplies the holding power for memory from the battery.

When data is to be accessed by the processor, the NVRCE chip select is generated via address decoder U49. Until power comes up to the correct operating level the chip select is disabled through U62.

Address Decoder

The PAL address decoder, U49, decodes ADDR8 through ADDR15 plus (RESETA), (PSEN), (RD), and (WR) to generate the control signals that address the individual devices on the processor's bus.

Decoded Signals:

(SW0EN) and (SW1EN) enable switch buffers U51 and U52 when the processor scans the front panel for switch activity

(HPCHEN) and (HPFLEN) are used to control the LED alphanumeric display device (U1 on the front panel)

LEDCLK controls clocking the data about which LED is to be lit into the LED buffer (U50)

(DSPEN), (DSPRST), and (DSPWR) are used to control communication between the front panel processor and the digital signal processor (U1 on the main board).

(ROMCE) selects the EPROM, U63, for access by the processor.

(NVRCE) selects the RAM, U64, for access by the processor.

Front Panel Interface

LED driver U50 is an octal D flip-flop register. The processor loads U50 with the LED(s) that are to be lit. There is no physical connection between the front panel button switches and the LED associated with the button. The switches are scanned for presses, and the processor determines the LED that must be turned on and off via its software instructions. Data on the input is transferred to the output on the rising edge of the LEDCLK. A reset signal (RESETA) clears the register at power on and when the front-panel reset button is pressed.

Switch buffers U51 and U52 are read at regular intervals to determine if a front panel button has been pressed. The two, 8-bit buffers share the data bus and are read at different times by the processor. Each buffer has its own enable — SW0EN for U52 and SW1EN for U51. Eight switches on U52 and six on U51 provide the 14 front panel buttons. The remaining two positions on U51 are PROG6 and PROG7, which come from DIP switch S1.

The main board signals are connected to the front panel via a 50-pin connector (J8 on the main board to J1 on the front panel board).

DIP Switch

DIP switch S1 sets some instrument operating states. This switch may be accessed by removing an instrument side panel. After setting normal operating frequencies and levels, S1 may be set to disable editing and maintain a known operational state. Editing may also be enabled via the remote connector using contact closures to connect pins 6 and 9. While these pins are connected, the normally editable signals may be changed as needed. When the contact is opened to disconnect pins 6 and 9, editing is again controlled by internal switch settings. See Section 2, *Operation and Setup*, for more information on DIP switch settings.

Remote Connector

Serial interface U67 is a level translator between the serial port and the rear panel remote connector.

When contact closure remote operation is used, just two serial lines are used for remote control: pins 4 and 6. Connecting pin 4 to pin 9 (ground) starts an auto test sequence; connecting pin 6 to pin 9 overrides the internal editing disable if it was set. Overriding the internal editing disable lets you change frequencies, levels, or ID numbers without having to access the internal DIP switch. This remote override is not necessary when editing is enabled, but in normal operation, the ability to edit parameters will usually be disabled after initial setup.

Serial Filter board A8 provides individual EMI filters on each of the remote control lines. These filters keep the ASG 100 from radiating digital noise and also keep external noise from entering via the remote connector.

DIGITAL SIGNAL PROCESSOR (Diagram 2)

Digital Signal Processor (DSP)

Address and Data Buses. The address and data buses of U1 are not multiplexed. The DSP has a 16-bit address bus (A0 - A15) and a 24-bit data bus (D0 - D23). Three 8-bit EPROM devices are stacked to provide the 24-bit firmware to the DSP. A set of three pull-up resistor packs (R1, R2, R3) are connected to the data bus to pull the data lines high when the lines are not being driven.

Host Port PB0 - PB14. The data handled by this port on PB0 - PB7 is 8 bits wide and 8 bytes deep. It allows communication between the DSP and the control processor without the need to do bus request/bus grant data handling. This port is mainly used to handshake control signals between the front panel processor and the DSP. Addressing of the 8 bytes of DSP to write is done by ADDR (0 - 2) from the control processor. The DSP uses the interrupt INT0 to generate an interrupt to the control processor.

Serial Ports PC0 - PC8. There are two serial ports. Pins PC0 (RXD), PC1 (TXD), and PC2 (SCLK) are unused, but are available on J310 for testing and future expansion. Serial communications via the remote connector is handled by the front panel processor. The remaining pins (PC3 - PC8) are a synchronous serial port. Output bits from this port are used to drive the data

formatter/synchronizer that shifts digital data to align it properly for the digital-to-analog converters.

Bits SC0, SC1, and SC2 are called flag bits and are used by the address decoder (U12) to determine which device on the serial bus is being addressed. One of the bits, SCK, is the serial bit clock. This bit clocks the serial data in the data formatter/synchronizer and the CODEC, U9. The serial digital data from the CODEC (SRD) is applied to the DSP via pin 42 (PC7). The serial output data line from the DSP is STD (PC8). This data stream is applied to the data formatter/synchronizer to be formatted for application to the digital-to-analog converters.

Oscillator. A crystal oscillator device, Y3, produces an 18.432 MHz clock signal that is applied to the EXTAL (external clock input) pin of U1.

Address Decoder

Address decoder U12 is a programmable array logic device. It has inputs from the DSP and the control register latch. The various chip selects to the devices on the DSP bus are decoded by depending on the state of all the input signals. These control signals are:

1. CODEC: Enables the CODEC device, U9, when an audio signal is being recorded for the audio ID.
2. (CTRL): Clocks the control registers, U10 and U11, to latch new control data for the CH 1 and CH 2 gain, attenuation, and relay states.
3. (PCMLE): Enables the data latches for the left and right digital-to-analog converters, U15 and U14.
4. (CEEXT0), (CEEXT1), and (CEEXT2): Unused signals to J310.
5. (CEROM): Chip enable to the EPROM devices, U2, U3, and U4.
6. (CERAM): Chip enable to the RAM. This signal is applied to the battery backup level monitor, U5. The level monitor acts to prevent the RAM from being enabled and switches to the backup battery when power to the ASG 100 is switched off.

Control Register Latches

Control signals that select the gain, attenuation, and relay states for the CH 1 and CH 2 signal paths (diagram 4, A2) are latched from the data bus into latches U10 and U11. When control data states must be updated, the DSP places the data on the lower 16 bits of the data bus and generates a (CTRL) clock output from the PAL address decoder, U12. At power up, the (DSPRST) signal from the control processor circuitry goes low to clear the latches to a known state before the DSP writes the correct control data.

EPROM

The three 64-Kbyte EPROM memory devices, U2, U3, and U4, store the DSP's operating firmware. They are addressed in parallel on the 16-bit address bus, and their 8-bit data bus outputs are stacked to yield the 24-bit word used by the DSP.

DSP RAM

The DSP RAM, U6, is a 32-Kbyte memory chip. A 15-bit address selects the RAM memory space to be written to or read from. The (DWR) and (DRD) (write and read) signals from the DSP select the direction; the (CEO), also from the DSP via the level monitor, U5, enables the RAM to output or input data on the lower 8 bits of the data bus.

Battery Backup

The DSP RAM, U6, has its stored memory maintained during power off by a backup battery BT1. A level monitor, U5, controls the CE (chip enable) input to the RAM. When normal power is applied to the monitor, the chip enable signal from the DSP (CERAM) and the +5 V VCCI source are applied to the DSP RAM. When the +5 V power is removed, the level monitor disables the chip select into to the RAM to prevent random writing or reading and applies the backup battery to the RAM to hold the stored data in memory. The RAM is held disabled until power rises to the correct operating level.

CODEC

During a record session, the 4-second audio signal from the front panel microphone is amplified and level controlled in the Mic Preamp and AGC circuitry (diagram 6, A2). That analog signal is applied to the CODEC device, U9, where it is digitized and output in a serial data stream. The digitized audio signal is processed by the DSP, U1, for storage into RAM U6, a battery-backed memory device. On command from the control processor, the stored digital audio data is retrieved and applied to the digital-to-analog converter (DAC) circuitry where it is converted to an analog signal for output to the CH 1 and CH 2 output connectors.

The clock signal for the digitizing rate of the CODEC is provided by the SCK clock signal developed by the DSP. The CODEC and the DACs run at different rates, but the firmware is programmed to perform sample rate conversion of the sampled audio data.

DIGITAL-TO-ANALOG CONVERTER (Diagrams 3 and 3a)

Digital Formatter/Synchronizer

The serial data from the DSP section comes into U66A, pin 2, a D flip-flop used as a data synchronizer. The incoming serial data is synchronized to the PCM clock (PCMCLK) and sent to a shift register consisting of U16, 17, 18, and 19.

The first shift register (U16) takes the 24-bit DSP serial data with trailing zeros and shifts it six places. This gives the data string leading zeros for input to the 18-bit DAC. This six-place shift moves the 24-bit input data to the 18-bit data positions used by the DACs. Data exiting U16 may be jumper configured for either 18-bit or 20-bit data format (18-bit is used).

The U16 18-bit serial data goes two places: to U14 as the input data to the right channel, and; to three more stages of 8-bit shift registers, U17, 18 and 19. These registers shift the data another 24 bits before it goes to the left-channel DAC. The output of the DSP is interleaved right- and left-channel data. The time needed to shift the left-channel data an extra 24 bits allows the left- and right-channel data to arrive at the same time for conversion. Since both DACs (U15, left and U14, right) have their data registers filled at the same time, they both use the same latch enable signal (PCMLE) to latch the data.

Digital-to-Analog Converters

This section discusses the right channel DAC, U14, and its associated circuitry. The left-channel circuitry (U15, U21) is identical. DAC U14 is an 18-bit digital-to-analog converter. The output is a current signal from pin 13 that has nominal values of ± 1 mA peak. That current is input to the summing node of U20 where it is converted to a voltage signal at the output of U20, pin 10.

The feedback circuit that sets the loop gain of the DAC and the current-to-voltage converter is formed by resistors R24 (an adjustable potentiometer) and R23.

With input data bits equal to 10000, the MSB is one, and the output should be 0 mA. The DAC has a most significant bit adjust potentiometer, R27, called Distortion Adjust. An audio distortion analyzer must be used to set the signal distortion to its minimum value.

Low-Pass Filters

The signal voltage from U20 is applied to FL3, an 11-pole, low-pass filter with a 23 kHz cutoff. The upper output signal frequency is 20 kHz, but a 23 kHz low-pass filter is used to move the ripple effect of the filter above 20 kHz.

The DAC sends a new output every $1/(48 \text{ kHz})$, which approximates a sine wave. The filter smooths the steps to a sine wave.

The signal then enters buffer amplifier U13A. The buffer has a gain of four to compensate for a 6 dB loss in the filter and to provide the proper operating amplitude. At TP7 the signal is twice the amplitude as it is at U20 pin 10.

Filter Voltage Reference Regulators

The filters are powered by +12 and -12 volts. The power source is derived from the + and -15 volt supplies by three-terminal regulators U69 and U70.

CHANNEL 1 AND CHANNEL 2 ATTENUATOR (Diagram 4)

Step Attenuators

From the output of U13, the signal is applied to a stepped attenuator, U22 (left) and U28 (right). The right channel circuitry is discussed; the left channel is identical.

The signal enters at CH2. It is AC coupled through C99 to remove any DC offset that might be present in the buffer amplifier. The time constant of the AC coupling is very long, and the capacitor does not affect the lower audio frequencies.

Attenuation Range Steps

The attenuation is done by a string of resistors to ground. Each step or tap of the attenuator is 10 dB lower than the previous step, and there are five steps, making the lowest step of the attenuator at -50 dB. Multiplexer U28 selects the various taps of the attenuator under software control. Operator selection of a dBu range causes the software to locate the appropriate attenuator tap and switch the multiplexer to that tap.

There are two additional taps on the step attenuators. On U22, the left-channel step attenuator (pin 9) has a signal line that sends the output of the right channel step attenuator to the left channel. In effect, the left channel of U22 has the same signal as the right channel, and everything works off of the right-channel DAC. When a stereo signal is required for a stereo test sequence, separate channel signals are generated. The multiplexer selects between S1 and S8 for output, depending on the address sent in the control lines.

Switching Control Signals

In response to request from the front panel or through the remote control port for a new signal level, the DSP generates the needed switching signals on its data bus. These control signals (CTRL4-CRTL11) are latched into U10 and U11 (diagram 2) where they are held until a different

signal level is called for. The control signals switch the left and right attenuators (U22 and U28) for the needed attenuation step, and set the gain of the left and right channel output buffers. The gain of the buffer stages is controlled by switching in the feedback loop of the amplifiers to produce either 0 dB or +10 dB gain.

Output Buffers

The output of the multiplexers, U22 left and U28 right, is a step-attenuated sine wave of operator-selected amplitude. The multiplexer output signal goes to the output buffers (U23A and Q2–Q5, left; U29A and Q10–Q13 right).

On the right channel, the first stage of the output buffer is U29A, an op-amp driving a push-pull output stage that is current limited to 50 mA peak (current limit is set by R80 and R79). A 50 mA current through R80 and R79 develops 0.6 V, causing Q10 or Q11 to switch on and divert drive current away from the output transistors (Q12 and Q13). This protects the output transistors from load short circuits. Normal maximum output at unity gain is +14 dBu, which is 1.9457 volts RMS per side. This buffer's output is the plus polarity side of the CH2 differential output.

Inverting amplifiers U23B and Q6–Q9 (left negative) and U29B and Q14–Q17 (right negative) provide the negative side of the differential audio signal to the CH1 and CH2 output connectors. Again on the right channel, at the output of the first buffer, R85 applies the plus polarity output signal to U29B pin 6, the inverting input pin, where it is inverted with unity gain. For example, a 1 V peak, positive-going sine wave out of the first buffer produces a 1 V peak, negative-going sine wave at the output of the second buffer. Together, the two buffers produce the differential audio signal outputs.

Gain Switching

The feedback for the output buffer goes through either of two FET switches, U25B or C. When U25C is closed (U25B open), unity feedback goes from pin 10 to pin 11 of the multiplexer. The output of the buffer is connected to the summing node, making it a unity gain buffer.

When U25C is open (U25B closed), the feedback is divided by R108 and R107, causing the gain to increase by 10 dB (because it is a non-inverting amplifier, the gain increases by 2.162 plus 1, or 10 dB). This gain is switched in for outputs above +14 dBu.

Output Impedance Resistor Arrays

The differential output signal from the right output buffer is sent through a resistor array, R167 G and H for the plus and E and F for the minus polarity. These resistors provide the output impedance for the ASG 100. The ASG 100 is shipped from the factory with 10 Ω resistors in these circuits (5 Ω in each half because they are paralleled). That resistance is in series with $\approx 0.8 \Omega$ in the EMI filters on each differential output line, so the overall output impedance is $\approx 12 \Omega$.

Resistor arrays R168 and R173 are sets of 600 Ω resistors. If the application needs 600 Ω output impedance instead of 12 Ω , the 600 Ω resistor arrays are used to configure the ASG 100 for 600 Ω output impedance. Custom output impedances may be made for other applications, see Section 2, *Operation and Setup*, for more information on output impedance.

Relay Driver

Output Switching Relays

After passing through the output load resistors, the differential signal goes to a set of relays (K2 on the right channel, K5 on the left). With the relay enabled, the generated signal is connected to the output jacks (J14 on the right channel). With the relay disabled, the audio on J13 is routed directly to the output at J14.

In broadcasting, much of the time the program signal is routed straight through the ASG 100 (the signal generated by the ASG 100 is not used). To perform a test, the user touches the ON-LINE button. Relays energize and re-route the output to the signal generator circuitry rather than to the incoming program signal. The test or tones the ASG 100 has been configured to send are then sent on the audio signal line.

If the tone being sent is one of the AUTO TEST sequences, when the sequence is complete, the ASG 100 automatically switches off line and program audio is switched on line. When the output switching relay is not energized, the user's input signal is passed through. This prevents interruptions to the user's signal if the ASG 100 loses power or is switched off.

EMI Filters

A choke and a capacitor in series with the relay coils help reduce high frequency interference. Other filter devices consist of ferrite beads and bypass capacitors to ground in series with the outputs and inputs. These devices also reduce radiated EMI from the remote connector on the ASG 100 rear panel.

Control Signals (CTRL0–CTRL3)

A relay driver IC, U27, converts logic signals from the DSP to voltages that actuate output switching relays. The control signals that run the relays and step the multiplexers enter through the CTRL (0-15) bus from latches U10 and U11, diagram 2.

PREVIEW (CTRL12)

The PREVIEW signal is used to switch the headphone output off during recording of the VOICE identification.

HEADPHONE AMPLIFIER (Diagram 5)

Input Differential to Single-Ended Amplifiers

Two buffers receive the CH1PHO and CH2PHO differential signals and convert them to single-ended outputs. The left-channel buffer is U35A (channel 1) and the right-channel buffer is U38A (channel 2). The single-ended output is routed to the headphone jack, where it allows the user to monitor the feed-through audio instead of the ASG 100 output tones.

Signal/Preview Multiplexer

The buffer outputs (on pin 1) are routed to a multiplexer, U41, for signal selection between Norm and Preview. At this time the Preview signal is used only to send Silence to the headphones when making a VOICE identification recording.

Channel 1 and Channel 2 Voltage Controlled Amplifiers

Multiplexer outputs are passed to DBX voltage-controlled amplifiers U33 and U36. The DC control level (AUD_LEVEL) enters at the lower left-hand corner of the schematic. The front panel volume control potentiometer, R5 (diagram 7), swings the voltage between ± 15 V. The voltage is buffered and filtered by U39.

The AUD_LEVEL voltage is by series resistor R132 and capacitor C51. This circuit produces a large time constant filtering action that keeps digital signals and high frequency noise from entering the DC control line.

Audio Level Control Buffer

At the output of U39, the DC control range is +0.48 V to -0.12 V. The +0.48 V corresponds to an attenuation of 80 dB when the volume control is rotated fully counterclockwise. When the DC voltage is -0.12 volts, the voltage-controlled amplifier, U36, has a gain of 20 dB that sets the headphone volume range.

Current-to-Voltage Amplifiers

The signal output of the U36 is a current that is sent to U38B and converted to a voltage. The voltage passes through series resistor R118 to drive the right side of the headphones.

The purpose of R118 is to equalize the gain difference between low- and high-impedance headphones.

Preview Termination Transistors

In Normal, the PREV1 and PREV2 signals are terminated by Q18 and Q19. The low PREVIEW control signal is inverted by U40A, and the high NORM signal forward biases Q18 and Q19. With these transistors on, the PREV1 and PREV2 signals are shunted to ground through the transistors. In Preview, Q18 and Q19 are biased off, and the PREV1 and PREV2 signals are switched to the input of the headphone amplifiers, U33 and U36. The current use for this Preview circuit is to send Silence to the headphones during VOICE recording. In Normal, either the ASG 100 output signal or the program signal is applied to the headphones.

MICROPHONE PREAMPLIFIER (Diagram 6)

Microphone Input Amplifier

In the preamp and AGC part of the microphone circuitry, the front-panel microphone connects to the main board via J7. Input amplifier U42B provides relatively low-level amplification for the microphone input signal (about 12.4 dB). The gain of this stage is low to reduce extra background noise, so the user must speak directly into the microphone to record the VOICE identification signal with good amplitude.

A 5.1 V Zener diode (VR3 through resistor R137) connected to the microphone input supplies voltage to power the FET amplifier inside the condenser microphone.

AGC and Output Amplifier

The output of the microphone preamp (U42B pin 7) is applied to U46A, an AGC (automatic gain control) circuit. The AGC circuit operates with op-amp U42A to convert the signal current to a voltage.

The feedback loop of U42A has two series resistors a 10 μ F capacitor to ground from the center of the two series resistors. The feedback network gives the AGC circuit unity gain at DC for its bias. The 10- μ F capacitor bypasses any audio AC to ground. This forces the audio signal to pass through the AGC circuit for gain control while allowing DC to pass through the RC network to bias the op-amp. The audio output of U42A to the CODEC, U9 diagram 2, is 1 V rms and is capacitively coupled via C70.

The AGC circuit uses a pair of back-to-back clamps, (VR4 and VR5) in the feedback path to prevent a large voltage overshoot that can be generated by abrupt volume changes. Without the clamps, the voltage overshoot can overdrive the CODEC.

POWER DISTRIBUTION (Diagram 6)

The power supply module, A3, provides + and -15 V and +5 V to the main board via J23. From the +15 V supply, three-terminal regulator U68 develops +12 V for the RS-232 serial port device, U67 in diagram 1. The +15 V supply provides power to a three-terminal regulator, U7, that develops the analog +5 V supply, and the -15 V supply provides power to three-terminal regulator U8. That device develops the analog -5 V. These analog voltages run the DACs (U14 and U15) and the high-speed op-amp of the CODEC, U9 in diagram 2. The +5 V digital supply is filtered and decoupled by C108 and C69. An indicator LED, DS1, on the +5 V supply line is lit to show at a glance that the +5 V supply is active. The decoupling capacitors for the supplies are indicated.

FRONT PANEL (Diagram 7)

Volume Control R5 adjusts the headphone volume, but has no affect on test signal output.

The front panel processor loads display data and addresses display device U1, on the processor data and address bus. A subset of addresses, (ADDR0 — ADDR4) are used to address the display. The eight data bus lines are used to transfer display data to U1.

Microphone MK1 provides the audio test signal that is digitized for transmission later either when VOICE ID is selected ON LINE or during an auto test when VOICE ID is part of the selected automatic test sequence.

The LEDs associated with the front panel buttons are not directly connected. The data to control LED lighting is provided from the front panel processor via a buffer (U50, schematic page 1).

The 14 front panel buttons are buffered to the front-panel processor by U51 and U52 (diagram 1). These buffers are read at intervals to check for button presses. Each button press is interpreted by programing instructions.

The main board interconnect (J1) provides 50 pins that interconnect the front panel to the main board.

SERIAL FILTER BOARD (Diagram 8)

The serial filter board provides an EMI filter on each of the 8 lines of the remote control serial interface lines. These filters reduce the conducted radiation (through the serial interface) of high-frequency components.

POWER SUPPLY (No diagram provided)

The power supply is a high-efficiency switching supply. It produces regulated outputs of +15V, -15V and +5V. A protection fuse is located at the input of the power supply board. The power distribution and decoupling circuits shown on schematic page 6 provide further filtering and regulated +12V and +5V from the power supply's +15V supply line. A -5V supply is developed by a regulator on the power supply's -15 V line.

Section 6

Replaceable Electrical Parts

This section contains a list of the components that are replaceable for the ASG 100. Use this list to identify and order replacement parts. There is a separate Replaceable Electrical Parts list for each instrument.

Parts Ordering Information

Replacement parts are available from or through your local Tektronix, Inc., Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available and to give you the benefit of the latest circuit improvements. Therefore, when ordering parts, it is important to include the following information in your order.

- Part number
- Instrument type or model number
- Instrument serial number
- Instrument modification number, if applicable

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc., Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

Using the Replaceable Electrical Parts List

The tabular information in the Replaceable Electrical Parts list is arranged for quick retrieval. Understanding the structure and features of the list will help you find all of the information you need for ordering replaceable parts.

Cross Index—Mfr. Code Number to Manufacturer

The Mfg. Code Number to Manufacturer Cross Index for the electrical parts list is located immediately after this page. The cross index provides codes, names, and addresses of manufacturers of components listed in the electrical parts list.

Abbreviations

Abbreviations conform to American National Standards Institute (ANSI) standard Y1.1.



List of Assemblies

A list of assemblies can be found at the beginning of the electrical parts list. The assemblies are listed in numerical order. When the complete component number of a part is known, this list will identify the assembly in which the part is located.

Column Descriptions

**Component No.
(Column 1)**

The component circuit number appears on the diagrams and circuit board illustrations, located in the diagrams section. Assembly numbers are also marked on each diagram and circuit board illustration, in the Diagram section and on the mechanical exploded views, in the mechanical parts list. The component number is obtained by adding the assembly number prefix to the circuit number.



The electrical parts list is arranged by assemblies in numerical sequence (A1, with its subassemblies and parts, precedes A2, with its subassemblies and parts).

Mechanical subparts to the circuit boards are listed in the electrical parts list. These mechanical subparts are listed with their associated electrical part (for example, fuse holder follows fuse).

Chassis-mounted parts and cable assemblies have no assembly number prefix and are located at the end of the electrical parts list.

**Tektronix Part No.
(Column 2)**

Indicates part number to be used when ordering replacement part from Tektronix.

**Serial/Assembly No.
(Column 3 and 4)**

Column three (3) indicates the serial or assembly number at which the part was first used. Column four (4) indicates the serial or assembly number at which the part was removed. No serial or assembly number entered indicates part is good for all serial numbers.

**Name and Description
(Column 5)**

An item name is separated from the description by a colon (:). Because of space limitations, an item name may sometimes appear as incomplete. Use the U.S. Federal Catalog handbook H6-1 for further item name identification.

The mechanical subparts are shown as *ATTACHED PARTS* / *END ATTACHED PARTS* or *MOUNTING PARTS* / *END MOUNTING PARTS* in column five (5).

**Mfr. Code
(Column 6)**

Indicates the code number of the actual manufacturer of the part. (Code to name and address cross reference can be found immediately after this page.)

Mfr. Part No. (Column 7)

Indicates actual manufacturer's part number.

CROSS INDEX – MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code.	Manufacturer	Address	City, State, Zip Code
00853	SANGAMO WESTON INC COMPONENTS DIV	SANGAMO RD PO BOX 128	PICKENS SC 29671-9716
01121	ALLEN-BRADLEY CO INDUSTRIAL CONTROL PRODUCTS	1201 S 2ND ST	MILWAUKEE WI 53204-2410
04222	AVX CERAMICS DIV OF AVX CORP	19TH AVE SOUTH P O BOX 867	MYRTLE BEACH SC 29577
05397	UNION CARBIDE CORP MATERIALS SYSTEMS DIV	11901 MADISON AVE	CLEVELAND OH 44101
05828	GENERAL INSTRUMENT CORP GOVERNMENT SYSTEMS DIV	600 W JOHN ST	HICKSVILLE NY 11802
07716	TRW INC TRW IRC FIXED RESISTORS/BURLINGTON	2850 MT PLEASANT AVE	BURLINGTON IA 52601
09922	BURNDY CORP	RICHARDS AVE	NORWALK CT 06852
0B0A9	DALLAS SEMICONDUCTOR CORP	4350 BELTWOOD PKWY SOUTH	DALLAS TX 75244
22526	BERG ELECTRONICS INC (DUPONT)	857 OLD TRAIL RD	ETTERS PA 17319
24165	SPRAGUE ELECTRIC CO	267 LOWELL ROAD	HUDSON NH 03051
24546	DALE ELECTRONICS A VISHAY INTERTECHNOLOGY INC CO	550 HIGH ST	BRADFORD PA 16701-3737
26364	COMPONENTS CORP	6 KINSEY PLACE	DENVILLE NJ 07834-2611
27014	NATIONAL SEMICONDUCTOR CORP	2900 SEMICONDUCTOR DR	SANTA CLARA CA 95051-0606
32997	BOURNS INC TRIMPOT DIV	1200 COLUMBIA AVE	RIVERSIDE CA 92507-2114
34361	OMRON ELECTRONICS INC.		SUNNYVALE CA
51406	MURATA ERIE NORTH AMERICA INC HEADQUARTERS AND GEORGIA OPERATIONS	2200 LAKE PARK DR	SMYRNA GA 30080
53387	MINNESOTA MINING MFG CO	PO BOX 2963	AUSTIN TX 78769-2963
54473	MATSUSHITA ELECTRIC CORP OF AMERICA	ONE PANASONIC WAY PO BOX 1501	SECAUCUS NJ 07094-2917
54583	TDK ELECTRONICS CORP	12 HARBOR PARK DR	PORT WASHINGTON NY 11550
55680	NICHICON /AMERICA/ CORP	927 E STATE PKY	SCHAUMBURG IL 60195-4526
57027	INTERNATIONAL RESISTIVE PRODUCTS INC	4222 S STAPLES	CORPUS CHRISTI TX 78411-2702
57668	ROHM CORP	8 WHATNEY PO BOX 19515	IRVINE CA 92713
78488	STACKPOLE CORP THE	201 STACKPOLE ST	ST MARYS PA 15857-1401
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
81855	EAGLE-PICHER INDUSTRIES INC ELECTRONICS DIV	COUPLES DEPT C AND PORTER STS PO BOX 47	JOPLIN MO 64801
82389	SWITCHCRAFT INC SUB OF RAYTHEON CO	5555 N ELSTRON AVE	CHICAGO IL 60630-1314
86928	SEASTROM MFG CO INC	701 SONORA AVE	GLENDALE CA 91201-2431
91506	AUGAT IPD	452 JOHN DIETSCH BLVD PO BOX 2510	ATTLEBORO FALLS MA 02763
91637	DALE ELECTRONICS INC	2064 12TH AVE PO BOX 609	COLUMBUS NE 68601-3632
93907	TEXTRON INC CAMCAR DIV	600 18TH AVE	ROCKFORD IL 61108-5181
98159	RUBBER TECK INC	19115 HAMILTON AVE PO BOX 389	GARDENA CA 90247
TK0768	SUPERTEX INC	1225 BORDEAUX DRIVE	SUNNYVALE CA 94086
TK1345	ZMAN & ASSOCIATES		
TK1450	TOKYO COSMOS ELECTRIC CO LTD	2-268 SOBUDAI ZAWA	KANAGAWA 228 JAPAN
TK2058	TDK CORPORATION OF AMERICA	2055 GATEWAY PLACE SUITE 200	SAN JOSE CA 95110

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number Effective	Serial / Assembly Number Discontinued	Name & Description	Mfr. Code	Mfr. Part Number
A1	671-1763-00			CIRCUIT BD ASSY:FRONT PANEL	80009	671-1763-00
A2	671-1758-00	B010100	B010107	CIRCUIT BD ASSY:MAIN	80009	671-1758-00
A2	671-1758-01	B010108	B010123	CIRCUIT BD ASSY:MAIN	80009	671-1758-01
A2	671-1758-02	B010124	B010231	CIRCUIT BD ASSY:MAIN	80009	671-1758-02
A2	671-1758-03	B010232	B010409	CIRCUIT BD ASSY:MAIN	80009	671-1758-03
A2	671-1758-04	B010410	B020649	CIRCUIT BD ASSY:MAIN	80009	671-1758-04
A2	671-1758-05	B020650	B031031	CIRCUIT BD ASSY:MAIN	80009	671-1758-05
A2	671-1758-06	B031032	B031126	CIRCUIT BD ASSY:MAIN	80009	671-1758-06
A2	671-1758-07	B031127	B031760	CIRCUIT BD ASSY:MAIN	80009	671-1758-07
A2	671-1758-08	B031761	B039999	CIRCUIT BD ASSY:MAIN	80009	671-1758-08
A2	671-1758-09	B040000		CIRCUIT BD ASSY:MAIN	80009	671-1758-09
A3	119-4112-00			POWER SUPPLY:SWING,AUTO IN 85-264VAC, 47-440HZ,OUT 5VDC 5A,+15V 2A, -15V 0.5A	80009	119-4112-00
A4	671-2106-00			CIRCUIT BD ASSY:SERIAL FILTER	80009	671-2106-00
A1	671-1763-00			CIRCUIT BD ASSY:FRONT PANEL	80009	671-1763-00
A1C1	281-0775-01			CAP,FXD,CER:MCL;0.1UF,20%,50V,Z5U,0.170 X 0.100;AXIAL	04222	SA105E104MAA
A1C2	281-0775-01			CAP,FXD,CER:MCL;0.1UF,20%,50V,Z5U,0.170 X 0.100;AXIAL	04222	SA105E104MAA
A1C3	290-1271-00			CAP,FXD ALUM:3300UF,20%,10V,0.492 X 1.575;AXIAL,BULK	80009	290-1271-00
A1DS1	150-1259-00			DIO,OPTO:LED;YEL,585NM,3.0VF @ 10MA;HLMP-1819	80009	150-1259-00
A1DS2	150-1258-00			DIO,OPTO:LED;GRN,569NM,3.0VF @ 10MA;HLMP-1840	80009	150-1258-00
A1J1	174-2266-00			CA ASSY,SP,ELEC:RBN;IDC,50,28 AWG,3.0 L,2X25 PCB X 2X25 RCPT 0.1 CTR,ACCOM 0.025 SQ PIN	80009	174-2266-00
A1J2	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 2)	80009	131-0608-00
A1MK1	119-4087-00			MICROPHONE:	80009	119-4087-00
A1R1	307-0542-00			RES NTWK,FXD,FI:(5)10K OHM,5%,0.125W	01121	106A103OR706A103
A1R2	307-0542-00			RES NTWK,FXD,FI:(5)10K OHM,5%,0.125W	01121	106A103OR706A103
A1R3	307-0594-00			RES NTWK,FXD,FI:(8)220 OHM,2%,0.125W	80009	307-0594-00
A1R4	307-0542-00			RES NTWK,FXD,FI:(5)10K OHM,5%,0.125W	01121	106A103OR706A103
A1R5	311-2482-00			RES,VAR,NONWW:100K OHM,20%,0.25 W,LIN	80009	311-2482-00
A1R6	315-0221-00			RES,FXD,FILM:220 OHM,5%,0.25W	80009	315-0221-00
A1R7	307-0793-00	671-1763-00	671-1763-00	RES,FXD,CMPSPN:0.5 OHM,5%,0.5W	57668	TR50J-E0E5E
A1R7	308-0793-00	671-1763-00		RES,FXD:0.51 OHM,5%,1WTC=150PPM/DEG C,MI T&R	80009	308-0793-00
A1S1	260-2384-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,RED LED,W/KEYCAP;HL20-LSR	80009	260-2384-00
	366-0671-00			*ATTACHED PARTS* PUSH BTN:W/LENS,HL20-1101	80009	366-0671-00
				END ATTACHED PARTS		
A1S2	260-2442-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,GRN LED,W/KEYCAP;HL20-LSG	80009	260-2442-00
	366-0671-00			*ATTACHED PARTS* PUSH BTN:W/LENS,HL20-1101	80009	366-0671-00
				END ATTACHED PARTS		
A1S3	260-2442-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,GRN LED,W/KEYCAP;HL20-LSG	80009	260-2442-00
	366-0671-00			*ATTACHED PARTS* PUSH BTN:W/LENS,HL20-1101	80009	366-0671-00
				END ATTACHED PARTS		
A1S4	260-2442-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,GRN LED,W/KEYCAP;HL20-LSG	80009	260-2442-00
	366-0671-00			*ATTACHED PARTS* PUSH BTN:W/LENS,HL20-1101	80009	366-0671-00
				END ATTACHED PARTS		

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A1S5	260-2442-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,GRN LED,W/KEYCAP;HL20-LSG *ATTACHED PARTS*	80009	260-2442-00
	366-0671-00			PUSH BTN:W/LENS,HL20-1101 *END ATTACHED PARTS*	80009	366-0671-00
A1S6	260-2442-00			SW,PUSH:SPST;MOM,NO,100 GRM FRC,COND RBR CONT,GRN LED,W/KEYCAP;HL20-LSG *ATTACHED PARTS*	80009	260-2442-00
	366-0671-00			PUSH BTN:W/LENS,HL20-1101 *END ATTACHED PARTS*	80009	366-0671-00
A1S7	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S8	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S9	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S10	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S11	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S12	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S13	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1S14	260-2300-00			SW,PUSH:SPST,25MA,15VAC *ATTACHED PARTS*	34361	B3F1152
	366-0716-00			PUSH BTN: *END ATTACHED PARTS*	80009	366-0716-00
A1U1	150-1253-00			DIQ,OPTO:DSPL;GRN,5BY7,8 DIG-IT,CMOS,RAM,ASCII DCDR;HDSP-2113	80009	150-1253-00
A2	671-1758-00	B010100	B010107	CIRCUIT BD ASSY:MAIN	80009	671-1758-00
A2	671-1758-01	B010108	B010123	CIRCUIT BD ASSY:MAIN	80009	671-1758-01
A2	671-1758-02	B010124	B010231	CIRCUIT BD ASSY:MAIN	80009	671-1758-02
A2	671-1758-03	B010232	B010409	CIRCUIT BD ASSY:MAIN	80009	671-1758-03
A2	671-1758-04	B010410	B020649	CIRCUIT BD ASSY:MAIN	80009	671-1758-04
A2	671-1758-05	B020650	B031031	CIRCUIT BD ASSY:MAIN	80009	671-1758-05
A2	671-1758-06	B031032	B031126	CIRCUIT BD ASSY:MAIN	80009	671-1758-06
A2	671-1758-07	B031127	B031760	CIRCUIT BD ASSY:MAIN	80009	671-1758-07
A2	671-1758-08	B031761	B039999	CIRCUIT BD ASSY:MAIN	80009	671-1758-08
A2	671-1758-09	B040000		CIRCUIT BD ASSY:MAIN	80009	671-1758-09
A2BT1	146-0049-00			BTRY,STORAGE:3.5V,750MAH	81855	LIC-7P
A2C3	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C4	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X	04222	SA205C104MAA

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2C5	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C6	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C7	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C8	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C9	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C11	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C12	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C13	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C14	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C15	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C16	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C21	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C22	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C23	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C24	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C25	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C26	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C27	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C28	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C29	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C30	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C31	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C32	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C34	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C35	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C36	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C37	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C38	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C39	283-0599-00			CAP,FXD,MICA DI:98PF,5%,500V	80009	283-0599-00
A2C40	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C41	283-0642-00			CAP,FXD,MICA DI:33PF,2%,500V,0.370 X 0.340;RDL	00853	D105E330G0
A2C42	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2C43	290-0848-00			CAP,FXD,ALUM:47UF,+100%-20%,16V,0.681 X 0.414;RDL	80009	290-0848-00
A2C45	283-0599-00			CAP,FXD,MICA DI:98PF,5%,500V	80009	283-0599-00
A2C46	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C47	283-0642-00			CAP,FXD,MICA DI:33PF,2%,500V,0.370 X 0.340;RDL	00853	D105E330G0
A2C48	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C49	290-0848-00			CAP,FXD,ALUM:47UF,+100%-20%,16V,0.681 X 0.414;RDL	80009	290-0848-00
A2C51	290-0990-00			CAP,FXD,ELCTLT:10UF,20%,50V	80009	290-0990-00
A2C52	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C53	290-0848-00			CAP,FXD,ALUM:47UF,+100%-20%,16V,0.681 X 0.414;RDL	80009	290-0848-00
A2C54	290-0973-00			CAP,FXD,ELCTLT:100UF,20%,25VDC	24165	513D107M025BB4D
A2C55	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C56	290-0778-00			CAP,FXD,ALUM:1UF,20%,50V,5 X 11 MM;RDL	54473	ECE-A50N1
A2C57	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C59	290-0891-00			CAP,FXD,ELCTLT:1UF,+75 -10%,50V	24165	513D105M063JA4D
A2C60	290-0891-00			CAP,FXD,ELCTLT:1UF,+75 -10%,50V	24165	513D105M063JA4D
A2C61	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C62	290-0891-00			CAP,FXD,ELCTLT:1UF,+75 -10%,50V	24165	513D105M063JA4D
A2C63	290-0891-00			CAP,FXD,ELCTLT:1UF,+75 -10%,50V	24165	513D105M063JA4D
A2C64	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C65	283-0167-00			CAP,FXD,CER DI:0.1UF,10%,100V	80009	283-0167-00
A2C66	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C67	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C68	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C69	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C70	290-0891-00			CAP,FXD,ELCTLT:1UF,+75 -10%,50V	24165	513D105M063JA4D
A2C71	281-0819-00			CAP,FXD,CER:MLC;33 PF,5%,50V,0.100 X 0.170;AXIAL,MI	04222	SA102A330JAA
A2C72	281-0819-00			CAP,FXD,CER:MLC;33 PF,5%,50V,0.100 X 0.170;AXIAL,MI	04222	SA102A330JAA
A2C77	290-0950-00	671-1758-00	671-1758-03	CAP,FXD,ELCTLT:100UF,+50-20%,50WVDC	80009	290-0950-00
A2C78	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C79	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C80	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C81	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C82	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C83	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C84	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C85	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C86	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C87	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2C88	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C89	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C93	283-0359-00			CAP,FXD,CER DI:1000PF,10%,200V	04222	SR212A102KAA
A2C94	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C95	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C96	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C97	290-0990-00			CAP,FXD,ELCTLT:10UF,20%,50V	80009	290-0990-00
A2C98	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C99	290-0990-00			CAP,FXD,ELCTLT:10UF,20%,50V	80009	290-0990-00
A2C100	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C101	281-0765-00			CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C102	283-0642-00			CAP,FXD,MICA DI:33PF,2%,500V,0.370 X 0.340;RDL	00853	D105E330G0
A2C103	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C105	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C106	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C108	290-0944-01			CAP,FXD,ELCTLT:220UF,20%,10V	55680	UVX1C221MPA1TA
A2C109	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C110	290-0974-00			CAP,FXD,ELCTLT:10UF,20%,50VDC	55680	UVX1H100MAA
A2C111	290-0782-00			CAP,FXD,ELCTLT:4.7UF,+75-20%,35VDC	55680	UVX1V4R7MAA
A2C112	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C113	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C114	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C115	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C116	281-0819-00			CAP,FXD,CER:MLC;33 PF,5%,50V,0.100 X 0.170;AXIAL,MI	04222	SA102A330JAA
A2C117	281-0819-00			CAP,FXD,CER:MLC;33 PF,5%,50V,0.100 X 0.170;AXIAL,MI	04222	SA102A330JAA
A2C118	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C119	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C120	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C121	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C124	283-0067-00			CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C125	283-0067-00			CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C126	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C127	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C128	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C129	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C130	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C131	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C132	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C133	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C134	283-0067-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
A2C137	281-0775-02			CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C138	281-0775-02	671-1758-04		CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2C139	281-0775-02	671-1758-04		CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C140	281-0775-02	671-1758-04		CAP,FXD,CER:MLC;0.1UF,20%,50V,X7R,0.265 X 0.100;AXIAL,T&R	04222	SA205C104MAA
A2C141	283-0047-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:270PF,5%,500V	80009	283-0047-00
A2C141	281-0765-00	671-1758-04		CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2C142	290-0973-00	671-1758-04		CAP,FXD,ELCTL:100UF,20%,25VDC	24165	513D107M025BB4D
A2C143	283-0047-00	671-1758-00	671-1758-03	CAP,FXD,CER DI:270PF,5%,500V	80009	283-0047-00
A2C143	281-0765-00	671-1758-04		CAP,FXD,CER DI:100PF,5%,100V	04222	SA102A101JAA
A2CR4	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR5	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR6	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR7	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR8	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR9	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR10	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR11	152-0141-02			DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2CR14	152-0066-00	671-1758-00	671-1758-03	DIO,RECT:400V,1A,IFSM=30A,1.2VF,2US;GP10G/1 N5060,T&R,SAF CONT	05828	GP10G-020
A2CR15	152-0141-02	671-1758-00	671-1758-03	DIO,SIG:ULTRA FAST;40V,150MA,4NS,2PF;1N4152,DO-35,T&R	80009	152-0141-02
A2DS1	150-1033-00			DIO,OPTO:LED;AMBER,585NM,2MCD AT 10MA;HLMP-1401,T-1,T&R	80009	150-1033-00
A2FL2	119-4080-00	671-1758-00	671-1758-08	FILTER,LOWPASS	80009	119-4080-00
A2FL2	671-4081-00	671-1758-09		FILTER,LOWPASS	80009	671-4081-00
A2FL3	119-4080-00	671-1758-00	671-1758-08	FILTER,LOWPASS	80009	119-4080-00
A2FL3	671-4081-00	671-1758-09		FILTER,LOWPASS	80009	671-4081-00
A2FL4	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL5	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL6	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL7	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL8	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL9	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL10	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL11	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL12	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2FL13	119-4225-00	671-1758-04		FILTER,EMI:	80009	119-4225-00
A2J2	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 3)	80009	131-0608-00
A2J7	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 3)	80009	131-0608-00
A2J8	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 50)	80009	131-0608-00
A2J11	131-5230-00			CONN,CIRC: *MOUNTING PARTS*	80009	131-5230-00
	213-0055-00			SCR,TPG,TF:2-32 X 0.188,TYPE B,PNH,STL *END MOUNTING PARTS*	93907	ORDER BY DESCR
A2J12	131-3987-00			CONN,CIRC:PCB,AUDIO,MALE,RTANG,3 POS,1.22 H X 1.024 W,CTR PLZ,LATCHING *MOUNTING PARTS*	82389	E3MRA
	213-0055-00			SCR,TPG,TF:2-32 X 0.188,TYPE B,PNH,STL	93907	ORDER BY DESCR

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number Effective	Discontinued	Name & Description	Mfr. Code	Mfr. Part Number
A2J13	131-5230-00			*END MOUNTING PARTS* CONN,CIRC:	80009	131-5230-00
	213-0055-00			*MOUNTING PARTS* SCR,TPG,TF:2-32 X 0.188,TYPE B,PNH,STL	93907	ORDER BY DESCR
A2J14	131-3987-00			*END MOUNTING PARTS* CONN,CIRC:PCB,AUDIO;MALE,RTANG,3 POS,1.22 H X 1.024 W,CTR PLZ,LATCHING	82389	E3MRA
	213-0055-00			*MOUNTING PARTS* SCR,TPG,TF:2-32 X 0.188,TYPE B,PNH,STL	93907	ORDER BY DESCR
A2J20	131-0608-00			*END MOUNTING PARTS* TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 3)	80009	131-0608-00
A2J23	131-5227-00			CONN,HDR PWR:	80009	131-5227-00
A2J25	131-3520-00			CONN,HDR:	53387	2510-6002UB
A2J26	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 2)	80009	131-0608-00
A2J28	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 12)	80009	131-0608-00
A2J29	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 2)	80009	131-0608-00
A2J30	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 18)	80009	131-0608-00
A2J31	131-5228-00	671-1758-00	671-1758-05	CONN,DIN:PCB;MALE,STR,2 X 32,0.1 CTR,0.457 H X 0.114 TAIL,ROWS A & C LOADED	80009	131-5228-00
A2J32	131-0608-00			TERM,PIN:0.365 L X 0.025 BRZ GLD PL (QUANTITY 12)	80009	131-0608-00
A2K2	148-0235-00			RELAY,ARM:	80009	148-0235-00
A2K5	148-0235-00			RELAY,ARM:	80009	148-0235-00
A2L1	108-0543-00	671-1758-04		COIL,RF:FIXED,1.1UH	TK1345	108-0543-00
A2L2	108-0543-00	671-1758-04		COIL,RF:FIXED,1.1UH	TK1345	108-0543-00
A2L3	108-0543-00	671-1758-04		COIL,RF:FIXED,1.1UH	TK1345	108-0543-00
A2P2	131-0993-00			CONN,BOX:SHUNT/SHORTING;FEM,STR,1 X 2,0.1 CTR,0.385 H,30 GLD,BLK,JUMPER	22526	65474-006
A2Q2	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ, AMPL;2N3904,TO-92 EBC	80009	151-0190-00
A2Q3	151-0188-00			XSTR,SIG:BIPOLAR,PNP;40V,200MA,250MHZ, AMPL;2N3906,TO-92 EBC	80009	151-0188-00
A2Q4	151-0136-00			XSTR,SIG:BIPOLAR,NPN;40V,700MA,100MHZ, AMPL;2N3053,TO-39	80009	151-0136-00
A2Q5	151-0235-00			XSTR,SIG:BIPOLAR,PNP;80V,1.0A,150MHZ, AMPL;2N4033,TO-39	80009	151-0235-00
A2Q6	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ, AMPL;2N3904,TO-92 EBC	80009	151-0190-00
A2Q7	151-0188-00			XSTR,SIG:BIPOLAR,PNP;40V,200MA,250MHZ, AMPL;2N3906,TO-92 EBC	80009	151-0188-00
A2Q8	151-0136-00			XSTR,SIG:BIPOLAR,NPN;40V,700MA,100MHZ, AMPL;2N3053,TO-39	80009	151-0136-00
A2Q9	151-0235-00			XSTR,SIG:BIPOLAR,PNP;80V,1.0A,150MHZ, AMPL;2N4033,TO-39	80009	151-0235-00
A2Q10	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ, AMPL;2N3904,TO-92 EBC	80009	151-0190-00
A2Q11	151-0188-00			XSTR,SIG:BIPOLAR,PNP;40V,200MA,250MHZ, AMPL;2N3906,TO-92 EBC	80009	151-0188-00
A2Q12	151-0136-00			XSTR,SIG:BIPOLAR,NPN;40V,700MA,100MHZ, AMPL;2N3053,TO-39	80009	151-0136-00
A2Q13	151-0235-00			XSTR,SIG:BIPOLAR,PNP;80V,1.0A,150MHZ, AMPL;2N4033,TO-39	80009	151-0235-00
A2Q14	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ, AMPL;2N3904,TO-92 EBC	80009	151-0190-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2Q15	151-0188-00			XSTR,SIG:BIPOLAR,PNP;40V,200MA,250MHZ,AMPL;2N3906,TO-92 EBC	80009	151-0188-00
A2Q16	151-0136-00			XSTR,SIG:BIPOLAR,NPN;40V,700MA,100MHZ,AMPL;2N3053,TO-39	80009	151-0136-00
A2Q17	151-0235-00			XSTR,SIG:BIPOLAR,PNP;80V,1.0A,150MHZ,AMPL;2N4033,TO-39	80009	151-0235-00
A2Q18	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ,AMPL;2N3904,TO-92 EBC	80009	151-0190-00
A2Q19	151-0190-00			XSTR,SIG:BIPOLAR,NPN;40V,200MA,300MHZ,AMPL;2N3904,TO-92 EBC	80009	151-0190-00
A2Q20	151-1121-00	671-1758-04		XSTR,PWR:MOS,N-CH;60V,0.5A,3.0 OHM;VN0106N3/VN0606L,TO-92 SGD	TK0768	VN0106N3
A2R1	307-0445-00			RES,NTWK:THICK FILM;(9) 4.7K OHM,2%,0.2W EACH,TC=100 PPM;SIP10,PIN 1 COM	91637	MSP10A01472GD03
A2R2	307-0445-00			RES,NTWK:THICK FILM;(9) 4.7K OHM,2%,0.2W EACH,TC=100 PPM;SIP10,PIN 1 COM	91637	MSP10A01472GD03
A2R3	307-0445-00			RES,NTWK:THICK FILM;(9) 4.7K OHM,2%,0.2W EACH,TC=100 PPM;SIP10,PIN 1 COM	91637	MSP10A01472GD03
A2R5	322-3258-00			RES,FXD:MET FILM;4.75K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3258-00
A2R6	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R7	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R13	322-3318-00	671-1758-00	671-1758-08	RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R14	322-3450-00			RES,FXD,FILM:475K OHM,1%,0.2W,TC=T0	80009	322-3450-00
A2R15	322-3450-00			RES,FXD,FILM:475K OHM,1%,0.2W,TC=T0	80009	322-3450-00
A2R16	322-3414-00			RES,FXD:MET FILM;200K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF501G20002F
A2R17	322-3414-00			RES,FXD:MET FILM;200K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF501G20002F
A2R18	322-3318-00	671-1758-00	671-1758-08	RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R19	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R20	322-3222-07	671-1758-00	671-1758-08	RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R20	322-3176-00	671-1758-09		RES,FXD,FILM:665 OHM,0.1%,0.2W TC=T0MI	80009	322-3176-00
A2R21	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R22	322-3222-07	671-1758-00	671-1758-08	RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R22	322-3176-00	671-1758-09		RES,FXD,FILM:665 OHM,0.1%,0.2W TC=T0MI	80009	322-3176-00
A2R23	322-3001-00	671-1758-00	671-1758-08	RES,FXD,META FILM:10 OHM,0.1%,0.2W TC=100	80009	322-3001-00
A2R23	322-3201-00	671-1758-09		RES,FXD,META FILM:1.21K OHM,0.1%,0.2W TC=T9	80009	322-3201-00
A2R24	311-1895-00			RES,VAR,NONWWW:TRMR2K OHM,10%,0.5,LIN	32997	3299W-1-202
A2R25	322-3001-00	671-1758-00	671-1758-08	RES,FXD,META FILM:10 OHM,0.1%,0.2W TC=100	80009	322-3001-00
A2R25	322-3201-00	671-1758-09		RES,FXD,META FILM:1.21K OHM,0.1%,0.2W TC=T9	80009	322-3201-00
A2R26	311-1895-00			RES,VAR,NONWWW:TRMR,2K OHM,10%,0.5,LIN	32997	3299W-1-202
A2R27	311-2239-00			RES,VAR,TRMR:CERMET;100K OHM,20%,0.5W,0.197 SQ,SIDE ADJUST;T&R	TK1450	GF06UT 100K
A2R28	311-2239-00			RES,VAR,TRMR:CERMET;100K OHM,20%,0.5W,0.197 SQ,SIDE ADJUST;T&R	TK1450	GF06UT 100K
A2R29	322-3112-00			RES,FXD,FILM:143 OHM,1%,0.2W,TC=T0	80009	322-3112-00
A2R30	321-1762-07			RES,FXD,FILM:6.695K OHM,0.1%,0.125W,TC=T9	57027	RC55-D-6K695-B-R
A2R31	322-3509-07			RES,FXD,FILM:2.162K OHM,0.1%,0.2W,TC=T9 TAPED & REELED,SM BODY	91637	2.162K OHM
A2R32	321-1611-07			RES,FXD,FILM:550 OHM,0.1%,0.125W,TC=T9	80009	321-1611-07
A2R33	321-1708-01			RES,FXD,FILM:133.3 OHM,0.5%,0.125W,TC=T0	80009	321-1708-01
A2R34	322-3126-07			RES,FXD,FILM:200 OHM,0.1%,0.2W,TC=T9	91637	CCF50-2-C200ROBT
A2R35	321-0021-00			RES,FXD,FILM:16.2 OHM,1%,0.125W,TC=T0	80009	321-0021-00
A2R36	321-0811-07			RES,FXD,FILM:56.3 OHM,0.1%,0.125W,TC=T9	80009	321-0811-07
A2R37	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R38	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2R39	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R40	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R41	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R42	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R43	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R44	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R45	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R46	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R66	322-3226-00			RES,FXD:MET FILM;2.21K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 2K21
A2R67	322-3193-07			RES,FXD,FILM:1K OHM,0.1%,0.2W,TC=T9	80009	322-3193-07
A2R68	322-3509-07			RES,FXD,FILM:2.162K OHM,0.1%,0.2W,TC=T9 TAPED & REELED,SM BODY	91637	2.162K OHM
A2R69	322-3112-00			RES,FXD,FILM:143 OHM,1%,0.2W,TC=T0	80009	322-3112-00
A2R70	321-1762-07			RES,FXD,FILM:6.695K OHM,0.1%,0.125W,TC=T9	57027	RC55-D-6K695-B-R
A2R71	322-3509-07			RES,FXD,FILM:2.162K OHM,0.1%,0.2W,TC=T9 TAPED & REELED,SM BODY	91637	2.162K OHM
A2R72	321-1611-07			RES,FXD,FILM:550 OHM,0.1%,0.125W,TC=T9	80009	321-1611-07
A2R73	321-1708-01			RES,FXD,FILM:133.3 OHM,0.5%,0.125W,TC=T0	80009	321-1708-01
A2R74	322-3126-07			RES,FXD,FILM:200 OHM,0.1%,0.2W,TC=T9	91637	CCF50-2-C200ROBT
A2R75	321-0021-00			RES,FXD,FILM:16.2 OHM,1%,0.125W,TC=T0	80009	321-0021-00
A2R76	321-0811-07			RES,FXD,FILM:56.3 OHM,0.1%,0.125W,TC=T9	80009	321-0811-07
A2R77	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R78	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R79	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R80	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R81	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R82	322-3239-00			RES,FXD,FILM:3.01K OHM,1%,0.2W,TC=T0	57668	CRB20 FXE 3K01
A2R83	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R84	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R85	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R86	322-3222-07			RES,FXD,FILM:2K OHM,0.1%,0.2W TC=T9	80009	322-3222-07
A2R107	322-3193-07			RES,FXD,FILM:1K OHM,0.1%,0.2W,TC=T9	80009	322-3193-07
A2R108	322-3509-07			RES,FXD,FILM:2.162K OHM,0.1%,0.2W,TC=T9 TAPED & REELED,SM BODY	91637	2.162K OHM
A2R109	322-3114-00			RES,FXD:MET FILM;150 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2-G1500F
A2R110	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R111	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R112	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R113	322-3097-00			RES,FXD:MET FILM;100 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100E
A2R114	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R115	322-3265-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;5.62K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3265-00
A2R115	322-3361-00	671-1758-02		RES,FXD:MET FILM;56.2K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2F56201F

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2R117	322-3289-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R117	322-3385-00	671-1758-02		RES,FXD:MET FILM;100K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100K
A2R118	322-3114-00			RES,FXD:MET FILM;150 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2-G1500F
A2R119	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R120	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R121	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R122	322-3097-00			RES,FXD:MET FILM;100 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100E
A2R123	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R124	322-3265-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;5.62K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3265-00
A2R124	322-3361-00	671-1758-02		RES,FXD:MET FILM;56.2K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2F56201F
A2R126	322-3289-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R126	322-3385-00	671-1758-02		RES,FXD:MET FILM;100K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100K
A2R127	322-3248-00			RES,FXD,FILM;3.74K OHM,1%,0.2W,TC=T0	80009	322-3248-00
A2R128	322-3289-00			RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R129	322-3289-00			RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R130	322-3248-00			RES,FXD,FILM;3.74K OHM,1%,0.2W,TC=T0	80009	322-3248-00
A2R132	322-3385-00			RES,FXD:MET FILM;100K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100K
A2R133	322-3243-00			RES,FXD:MET FILM;3.32K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-1-G33200F
A2R134	322-3193-00			RES,FXD:MET FILM;1K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 1K00
A2R135	322-3145-00			RES,FXD,FILM;316 OHM,1%,0.2W,TC=T0	80009	322-3145-00
A2R136	322-3226-00			RES,FXD:MET FILM;2.21K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 2K21
A2R137	322-3226-00			RES,FXD:MET FILM;2.21K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 2K21
A2R138	322-3289-00			RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R140	321-0307-00			RES,FXD,FILM;15.4K OHM,1%,0.125W,TC=T0	80009	321-0307-00
A2R141	322-3193-00			RES,FXD:MET FILM;1K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 1K00
A2R142	322-3285-00			RES,FXD,FILM;9.09K OHM,1%,0.2W,TC=T0	80009	322-3285-00
A2R143	322-3285-00			RES,FXD,FILM;9.09K OHM,1%,0.2W,TC=T0	80009	322-3285-00
A2R144	322-3289-00			RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R145	322-3301-00			RES,FXD,FILM;13.3K OHM,1%,0.2W,TC=T0	80009	322-3301-00
A2R148	307-0446-00			RES NTWK,FXD,FI:10K OHM,20%,(9)RES	80009	307-0446-00
A2R149	322-3481-00			RES,FXD,FILM:1M OHM.1%,0.2W,TC=T0	80009	322-3481-00
A2R153	321-0140-00	671-1758-00	671-1758-03	RES,FXD,FILM:280 OHM,1%,0.125W,TC=T0	07716	CEAD280R0F
A2R154	322-3179-00	671-1758-00	671-1758-03	RES,FXD,FILM:715 OHM,1%,0.2W,TC=T0	80009	322-3179-00
A2R158	322-3193-00			RES,FXD:MET FILM;1K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 1K00
A2R159	322-3258-00			RES,FXD:MET FILM;4.75K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3258-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number Effective	Serial / Assembly Number Discontinued	Name & Description	Mfr. Code	Mfr. Part Number
A2R160	322-3097-00			RES,FXD:MET FILM;100 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100E
A2R161	322-3097-00			RES,FXD:MET FILM;100 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100E
A2R162	322-3356-00			RES,FXD,FILM:49.9K OHM,1%,0.2W,TC=T0	80009	322-3356-00
A2R163	322-3289-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R163	322-3385-00	671-1758-02		RES,FXD:MET FILM;100K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100K
A2R164	322-3265-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;5.62K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3265-00
A2R164	322-3361-00	671-1758-02		RES,FXD:MET FILM;56.2K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2F56201F
A2R165	322-3289-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R165	322-3385-00	671-1758-02		RES,FXD:MET FILM;100K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 100K
A2R166	322-3265-00	671-1758-00	671-1758-01	RES,FXD:MET FILM;5.62K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3265-00
A2R166	322-3361-00	671-1758-02		RES,FXD:MET FILM;56.2K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2F56201F
A2R167	307-1223-00			RES NTWK,FXD,FI:8,10 OHM,2%,0.3W,16 DIP	91637	MDP1603-100G
	136-0971-00			*MOUNTING PARTS*		
				SKT,PL-IN ELEK:DIP,16 PIN,2 X 8,0.3 X 0.1 SP,T/G,0.095 H X 0.1 TAIL	80009	136-0971-00
				END MOUNTING PARTS		
A2R174	322-3193-00			RES,FXD:MET FILM;1K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 1K00
A2R175	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R176	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R177	307-0542-00			RES NTWK,FXD,FI:(5)10K OHM,5%,0.125W	01121	106A103OR706A103
A2R178	307-0542-00			RES NTWK,FXD,FI:(5)10K OHM,5%,0.125W	01121	106A103OR706A103
A2R179	322-3289-00			RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R180	321-0793-07			RES,FXD,FILM:37.5 OHM 0.1%,0.125W TC=T9	24546	NE55E37R5B
A2R181	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R182	322-3126-07			RES,FXD,FILM:200 OHM,0.1%,0.2W,TC=T9	91637	CCF50-2-C200ROBT
A2R183	322-3009-00			RES,FXD:MET FILM;12.1 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20FXE475E
A2R184	322-3126-07			RES,FXD,FILM:200 OHM,0.1%,0.2W,TC=T9	91637	CCF50-2-C200ROBT
A2R185	321-0793-07			RES,FXD,FILM:37.5 OHM 0.1%,0.125W TC=T9	24546	NE55E37R5B
A2R186	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R187	322-3318-00			RES,FXD:MET FILM;20K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	57668	CRB20 FXE 20K0
A2R188	322-3147-00			RES,FXD:MET FILM;332 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3147-00
A2R189	322-3258-00			RES,FXD:MET FILM;4.75K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3258-00
A2R190	322-3289-00	671-1758-00	671-1758-03	RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R191	322-3289-00	671-1758-04		RES,FXD:MET FILM;10K OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	80009	322-3289-00
A2R192	322-3114-00	671-1758-01		RES,FXD:MET FILM;150 OHM,1%,0.2W,TC=100 PPM;AXIAL,T&R,SM BODY	91637	CCF50-2-G1500F
A2S1	260-2544-00			SW,RKR:SPST,10 PIN,PIANO DIP	80009	260-2544-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2TP1	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP2	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP3	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP4	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP5	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP6	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP7	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2TP8	214-4085-00			TERM, TEST PT:0.070 ID,0.220 H,0.063 DIA PCB,0.015 X 0.032 BRS,W/ RED NYL CLR	26364	104-01-02
A2U1	156-6157-00	671-1758-00	671-1758-07	IC, PROCESSOR:CMOS,DSP:24-BITS,20MHZ,512 X 24 RAM;DSP56001,CQFP132	80009	156-6157-00
A2U1	156-6157-01	671-1758-08		DSP56001 ON ADAPTER		
A2U2	160-7395-00	671-1758-00	671-1758-00	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7395-00
A2U2	160-7395-01	671-1758-01	671-1758-01	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7395-01
A2U2	160-7395-02	671-1758-02	671-1758-04	MICROCKT,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7395-02
A2U2	160-7395-03	671-1758-05	671-1758-05	IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7395-03
A2U2	160-7395-04	671-1758-06		IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7395-04
	136-0755-00			*MOUNTING PARTS*		
				SKT,DIP:	09922	DILB28P-108
				END MOUNTING PARTS		
A2U3	160-7396-00	671-1758-00	671-1758-00	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7396-00
A2U3	160-7396-01	671-1758-01	671-1758-01	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7396-01
A2U3	160-7396-02	671-1758-02	671-1758-04	MICROCKT,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7396-02
A2U3	160-7396-03	671-1758-05	671-1758-05	IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7396-03
A2U3	160-7396-04	671-1758-06		IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7396-04
	136-0755-00			*MOUNTING PARTS*		
				SKT,DIP:	09922	DILB28P-108
				END MOUNTING PARTS		
A2U4	160-7397-00	671-1758-00	671-1758-00	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7397-00
A2U4	160-7397-01	671-1758-01	671-1758-01	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7397-01
A2U4	160-7397-02	671-1758-02	671-1758-04	MICROCKT,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7397-02
A2U4	160-7397-03	671-1758-05	671-1758-05	IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7397-03
A2U4	160-7397-04	671-1758-06		IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7397-04
	136-0755-00			*MOUNTING PARTS*		
				SKT,DIP:	09922	DILB28P-108
				END MOUNTING PARTS		
A2U5	156-2760-00			IC,MISC:	0B0A9	DS1210
A2U6	156-3850-00			IC, MEM:CMOS,SRAM;32K X 8,120NS,3UA,OE:,DIP28.6	80009	156-3850-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2U7	156-0991-00			IC,LIN:BIPO-LAR,VR;POS,5.0V,100MA,5%;MC78L05ACP,TO-92	80009	156-0991-00
A2U8	156-1150-00			IC,LIN:BIPO-LAR,VR;NEG,-5.0V,100MA,4%;MC79L05ACP,TO-92	80009	156-1150-00
A2U9	156-4044-00			IC,MISC:CMOS,TELECOM;ULAW PCM CODEC AND FILTER;TCM29C18N,DIP16.3	80009	156-4044-00
A2U10	156-0865-02			IC,DGTL:LSSTL,FLIP FLOP;74LS273,DIP20.3,TUBE	80009	156-0865-02
A2U11	156-0865-02			IC,DGTL:LSSTL,FLIP FLOP;74LS273,DIP20.3,TUBE	80009	156-0865-02
A2U12	160-7393-00			MICROCKT,DGTL:STTL,PLD;10NS,180MA;22V10	80009	160-7393-00
	136-0925-00			*MOUNTING PARTS*		
				SKT,DIP:	91506	224-AG30D
				END MOUNTING PARTS		
A2U13	156-1191-00			IC,LIN:BIFET,OP-AMP;DUAL;TL072CN/LF353N,DIP08.3	80009	156-1191-00
A2U14	156-4040-00			IC,CONV:	80009	156-4040-00
	136-0729-00			*MOUNTING PARTS*		
				SKT,DIP:PCB;FEM,STR,2 X 8,16 POS,0.1 X 0.3 CTR,0.175 H X 0.130 TAIL,BECU,TIN	09922	DILB16P-108T
				END MOUNTING PARTS		
A2U15	156-4040-00			IC,CONV:	80009	156-4040-00
	136-0729-00			*MOUNTING PARTS*		
				SKT,DIP:PCB;FEM,STR,2 X 8,16 POS,0.1 X 0.3 CTR,0.175 H X 0.130 TAIL,BECU,TIN	09922	DILB16P-108T
				END MOUNTING PARTS		
A2U16	156-0651-02			IC,DGTL:LSSTL,SHIFT RGSTR;74LS164,DIP14.3,TUBE	80009	156-0651-02
A2U17	156-0651-02			IC,DGTL:LSSTL,SHIFT RGSTR;74LS164,DIP14.3,TUBE	80009	156-0651-02
A2U18	156-0651-02			IC,DGTL:LSSTL,SHIFT RGSTR;74LS164,DIP14.3,TUBE	80009	156-0651-02
A2U19	156-0651-02			IC,DGTL:LSSTL,SHIFT RGSTR;74LS164,DIP14.3,TUBE	80009	156-0651-02
A2U20	156-4043-00			IC,LIN:BIPOLAR,OP-AMP;40MHZ,UNITY GAIN STABLE,LOW OFFSET;AD841KN,DIP14.3	80009	156-4043-00
A2U21	156-4043-00			IC,LIN:BIPOLAR,OP-AMP;40MHZ,UNITY GAIN STABLE,LOW OFFSET;AD841KN,DIP14.3	80009	156-4043-00
A2U22	156-1270-00			IC,MISC:BIFET,ANALOG MUX;8 CHANNEL, 850 OHM, 1.6US;LF13508,DIP16.3	80009	156-1270-00
A2U23	156-1272-00			IC,LIN:BIPOLAR,OP-AMP;DUAL,HI OUT DRV,LOW NOISE;NE5532N,DIP08.3	80009	156-1272-00
A2U25	156-1211-00			IC,MISC:BIFET,ANALOG SW;QUAD;LF13333,DIP16.3	80009	156-1211-00
A2U27	156-1245-00			IC,LIN:	80009	156-1245-00
A2U28	156-1270-00			IC,MISC:BIFET,ANALOG MUX;8 CHANNEL, 850 OHM, 1.6US;LF13508,DIP16.3	80009	156-1270-00
A2U29	156-1272-00			IC,LIN:BIPOLAR,OP-AMP;DUAL,HI OUT DRV,LOW NOISE;NE5532N,DIP08.3	80009	156-1272-00
A2U33	156-3098-00			IC,MISC:BIPOLAR,MISC;DBX NOISE REDUCTION SYS V CONT AMP;UPC1252HA2,SIP8	80009	156-3098-00
A2U35	156-1272-00			IC,LIN:BIPOLAR,OP-AMP;DUAL,HI OUT DRV,LOW NOISE;NE5532N,DIP08.3	80009	156-1272-00
A2U36	156-3098-00			IC,MISC:BIPOLAR,MISC;DBX NOISE REDUCTION SYS V CONT AMP;UPC1252HA2,SIP8	80009	156-3098-00
A2U38	156-1272-00			IC,LIN:BIPOLAR,OP-AMP;DUAL,HI OUT DRV,LOW NOISE;NE5532N,DIP08.3	80009	156-1272-00
A2U39	156-1149-00			IC,LIN:BIFET,OP-AMP;LF351N,DIP08.3	27014	LF351N/GLEA134
A2U40	156-0385-02	671-1758-00	671-1758-03	IC,DGTL:LSSTL,GATES;74LS04,DIP14.3,TUBE	80009	156-0385-02
A2U40	156-0645-02	671-1758-04		IC,DGTL:LSSTL,GATES;74LS14,DIP14.3,TUBE	80009	156-0645-02
A2U41	156-3166-00			IC,MISC:CMOS,ANALOG SW;DUAL DPST,55 OHM,+/-15V;DG405,DIP16.3	80009	156-3166-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2U42	156-1272-00			IC,LIN:BIPOLAR,OP-AMP;DUAL,HI OUT DRV,LOW NOISE;NE5532N,DIP08.3	80009	156-1272-00
A2U46	156-2815-00			IC,MISC:BIPOLAR,MISC;ANALOG COMPAN-DOR;NE572N,DIP16.3	80009	156-2815-00
A2U47	156-1065-00			IC,DGTL:LSTTL,LATCH;OCTAL D TRANS,3-STATE;74LS373,DIP20.3,TUBE	80009	156-1065-00
A2U48	156-4046-00			IC,PROCESSOR:CMOS,MICROCOMPTR;8-BIT,16MHZ,256 X 8,ROMLESS;80C32,DIP40.6,TUBE	80009	156-4046-00
	136-0757-00			*MOUNTING PARTS* SKT,DIP: *END MOUNTING PARTS*	09922	DILB40P-108
A2U49	160-7392-00	671-1758-00	671-1758-01	IC,DGTL:CMOS,PLD;EEPLD,22V10,25NS,33.3MHZ,90MA;22V10-25,DIP24.3	80009	160-7392-00
A2U49	160-7392-01	671-1758-02	671-1758-03	IC,DGTL:CMOS,PLD;EEPLD,22V10,25NS,33.3MHZ,90MA;22V10-25,DIP24.3	80009	160-7392-01
A2U49	160-7392-02	671-1758-04	671-1758-04	IC,DGTL:CMOS,PLD;EEPLD,22V10,25NS,33.3MHZ,90MA;22V10-25,DIP24.3	80009	160-7392-02
A2U49	160-7392-03	671-1758-05	671-1758-06	IC,DGTL:CMOS,PLD;EEPLD,22V10,25NS,33.3MHZ,90MA;22V10-25,DIP24.3	80009	160-7392-03
A2U49	160-7392-04	671-1758-07		IC,DGTL:CMOS,PLD;EEPLD,22V10,25NS,33.3MHZ,90MA;22V10-25,DIP24.3	80009	160-7392-04
	136-0925-00			*MOUNTING PARTS* SKT,DIP: *END MOUNTING PARTS*	91506	224-AG30D
A2U50	156-0865-02			IC,DGTL:LSTTL,FLIP FLOP;74LS273,DIP20.3,TUBE	80009	156-0865-02
A2U51	156-0956-02			IC,DGTL:LSTTL,BFR/DRV;74LS244,DIP20.3,TUBE	80009	156-0956-02
A2U52	156-0956-02			IC,DGTL:LSTTL,BFR/DRV;74LS244,DIP20.3,TUBE	80009	156-0956-02
A2U54	156-3547-00			IC,MISC:	80009	156-3547-00
A2U55	156-0991-00	671-1758-00	671-1758-00	IC,LIN:BIPO-LAR,VR;POS,5.0V,100MA,5%;MC78L05ACP,TO-92	80009	156-0991-00
A2U62	156-2760-00			IC,MISC:	0B0A9	DS1210
A2U63	160-7394-00	671-1758-00	671-1758-01	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7394-00
A2U63	160-7394-01	671-1758-02	671-1758-02	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512,DIP28.6	80009	160-7394-01
A2U63	160-7394-02	671-1758-03	671-1758-04	MICROCKT,DGTL:CMOS,EPROM;64K X 8,250NS;27C512	80009	160-7394-02
A2U63	160-7394-03	671-1758-05	671-1758-05	IC,DGTL:CMOS,EPROM;64K X 8,25NS;27C512,DIP28.6	80009	160-7394-03
A2U63	160-7394-04	671-1758-06		IC,DGTL:CMOS,EPROM;64K X 8,PRGM,25NS;27C512,DIP28.6	80009	160-7394-04
	136-0755-00			*MOUNTING PARTS* SKT,DIP: *END MOUNTING PARTS*	09922	DILB28P-108
A2U64	156-3850-00			IC,MEM:CMOS,SRAM;32K X 8,120NS,3UA,OE;,DIP28.6	80009	156-3850-00
A2U66	156-2009-00			IC,DGTL:HCMOS,FLIP FLOP;DUAL D-TYPE;74HC74,DIP14.3,TUBE	80009	156-2009-00
A2U67	156-4048-00			IC,MISC:	80009	156-4048-00
	136-0925-00			*MOUNTING PARTS* SKT,DIP: *END MOUNTING PARTS*	91506	224-AG30D
A2U68	156-2735-00			IC,LIN:BIPO-LAR,VR;POS,12V,100MA,5%;MC78L12ACP,TO-92	80009	156-2735-00
A2U69	156-1160-00			IC,LIN:BIPO-LAR,VR;POS,12V,100MA,4%;LM78L12ACH,TO-39	80009	156-1160-00
A2U70	156-1207-00			IC,LIN:BIPO-LAR,VR;NEG,-12V,500MA,3%;LM320H-12,TO-39	80009	156-1207-00
A2VR3	152-0195-00			DIO,ZENER:5.1V,5%,0.4W;1N751A FMLY,DO-35 OR 7	80009	152-0195-00

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
A2VR4	152-0395-00			DIO,ZENER:4.3V,5%,0.4W;1N749A,DO-35 OR 7,TR	80009	152-0395-00
A2VR5	152-0395-00			DIO,ZENER:4.3V,5%,0.4W;1N749A,DO-35 OR 7,TR	80009	152-0395-00
A2W1	131-0566-00			BUS,CNDCT:DUM RES,0.094 OD X 0.225 L	80009	131-0566-00
A2W5	131-4566-00	671-1758-01	671-1758-03	BUS,CNDCT:0 OHM,300 SPACING,SM BODY	80009	131-4566-00
A2W123	131-0566-00			BUS,CNDCT:DUM RES,0.094 OD X 0.225 L	80009	131-0566-00
A2Y2	158-0393-00			XTAL UNIT,QTZ:11.0592 MHZ,+/- 0.005,SER,ESR MAX 30 OHMS,HC-49/U PKG	80009	158-0393-00
	346-0032-00			*ATTACHED PARTS* STRAP,RETAINING:0.075 DIA X 4.0 L,MLD RBR	98159	2829-75-4
				END ATTACHED PARTS		
A2Y3	119-4072-00			OSC,XTAL,CLK:18.432MHZ,+/- 0.01%,HCMOS,0 TO 70 DEG C,4 PIN 14 PIN DIP COMPATIBLE	80009	119-4072-00
A3	119-4112-00			POWER SUPPLY:SWING,AUTO IN 85-264VAC, 47-440HZ,OUT 5VDC 5A,+15V 2A, -15V 0.5A	80009	119-4112-00
A4	671-2106-00			CIRCUIT BD ASSY:SERIAL FILTER	80009	671-2106-00
A4C1	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C2	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C3	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C4	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C5	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C6	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C7	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C8	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C9	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C10	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C11	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C12	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C13	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C14	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C15	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C16	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C17	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4C18	283-0197-00			CAP,FXD,CER DI:470PF,5%,50V	05397	C320C471J5G5CA
A4FL1	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL2	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL3	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL4	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL5	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL6	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL7	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL8	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4FL9	119-3580-00			FILTER,EMI:	TK2058	ZJSR-5101-102TA
A4J1	174-2353-00			CA ASSY,SP,ELEC:10,28 AWG,9.25 L (CONNECTED TO A1J25)	80009	174-2353-00
A4J2	131-3926-00			CONN,DSUB:	80009	131-3926-00
C135	283-0067-00	B010100	B010409	CAP,FXD,CER DI:0.001UF,10%,200V	51406	
C135	283-0067-00	B040000		CAP,FXD,CER DI:0.001UF,10%,200V	51046	283-0067-00
C136	283-0067-00	B010100	B010409	CAP,FXD,CER DI:0.001UF,10%,200V	51046	283-0067-00
C136	283-0067-00	B040000		CAP,FXD,CER DI:0.001UF,10%,200V	51046	283-0067-00
C200	283-0067-00	B010410		CAP,FXD,CER DI:0.001UF,10%,200V	51046	283-0067-00
E200	276-0647-00	B010410	B039999	CORE,EM-TOROID,FERRITE	78488	57-0126

Replaceable Electrical Parts

Component Number	Tektronix Part Number	Serial / Assembly Number		Name & Description	Mfr. Code	Mfr. Part Number
		Effective	Discontinued			
FL100	119-1536-00			FILTER,RFI:3A,250VAC,50/60HZ	54583	ZUB2203-00
J200	131-5233-00			CONN,JACK,PHONE: *ATTACHED PARTS*	80009	131-5233-00
	210-0201-00			TERM,LUG:0.12 ID,LOCKING,BRZ TIN PL *END ATTACHED PARTS*	86928	A373-157-2
J230	174-2338-00			CA ASSY,SP,ELEC: (CONNECTED FROM A1J23 TO A3J2)	80009	174-2338-00
S100	260-2553-00			SW,RKR:DPDT,6A,125VAC,POWER,W/QUICK CON- NECT TERMS	80009	260-2553-00
W1	174-2497-00			CA ASSY,SP,ELEC:2,18 AWG,3.25 L (CONNECTED FROM A3J1 TO S100)	80009	174-2497-00
W7	174-2451-00			CA ASSY,RF:COAXIAL;RFD,50 OHM,0.083 DIA,11.0 L,1X3,0.1 CTR,RCPT BOTH ENDS (CONNECTED FROM A1J7 TO A2J2)	80009	174-2451-00
W200	174-2494-00	B010100	B010409	CA ASSY,SP,ELEC:PHONE JACK CABLE	80009	174-2494-00
W200	174-2552-00	B010410		CA ASSY,SP,ELEC:3,26 AWG,3.1 L,RBN	80009	174-2552-00

DIAGRAMS/CIRCUIT BOARD ILLUSTRATIONS

Symbols

Graphic symbols and class designation letters are based on ANSI Standard Y32.2-1975.

Logic symbology is based on ANSI Y32.14-1973 in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

Both overline and parenthesis indicate a low asserting state.

Example: $\overline{\text{ID,CONTROL}}$ or (ID CONTROL)

Abbreviations are based on ANSI Y1.1-1972.

Other ANSI standards that are used in the preparation of diagrams by Tektronix, Inc. are:

- Y14.15, 1966 — Drafting Practices.
- Y14.2, 1973 — Line Conventions and Lettering.
- Y10.5, 1968 — Letter Symbols for Quantities Used in Electrical Science and Electrical Engineering.

American National Standard Institute
1430 Broadway, New York, New York 10018

Component Values

Electrical components shown on the diagrams are in the following units unless noted otherwise:


- Capacitors:
 - Values one or greater are in picofarads (pF).
 - Values less than one are in microfarads (μF).
- Resistors = Ohms (Ω).

The following information and special symbols may appear in this manual.

Assembly Numbers

Each assembly in the instrument is assigned an assembly number (e.g., A20). The assembly number appears on the diagram (in circuit board outline), circuit board illustration title, and lookup table for the schematic diagram.


The Replaceable Electrical Parts List is arranged by assembly number in numerical sequence; the components are listed by component number. Example:




Grid Coordinates


The schematic diagram and circuit board component location illustration have grids. A lookup table with the grid coordinates is provided for ease of locating the component. Only the components illustrated on the facing diagram are listed in the lookup table.

When more than one schematic diagram is used to illustrate the circuitry on a circuit board, the circuit board illustration may only appear opposite the first diagram; the lookup table will list the diagram number of other diagrams that the other circuitry appears on.





ASG 100 Block Diagram



Static Sensitive Devices
See Maintenance Section

**A2 MAIN BOARD
671-1758-04 & UP**

Schematic Diagram <1> Component Locator Chart

Main Board, Assembly A2. Partial Assembly A2 also shown on Diagrams 2, 3, 4, 5, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C71	B3	K7	C115	B3	L6	R148	C1	L6	R177	B1	J7	U40E	D3	G4	U54	C4	K6
C72	B3	L7				R149	B3	L7	R178	B1	J7	U40F	D3	G4	U55 *	B4	K6
C77 *	B4	L6	CR14 *	B4	K6	R153 *	B4	L5	R179	A3	K7	U47	D2	L6	U62	E4	M2
C78	B4	K5				R154 *	B4	L5	R189	B3	L6				U63	F4	M5
C103	G2	N5	J8	H1	N5	R158	A2	K7	S1	A1	J8	U48	B2	J7	U64	F3	M4
C109	F4	M3	J25	C5	J4							U49	E2	L6	U67	B5	K5
C110	B5	L5	J26	A3	K7				U40B	D3	G4	U50	G3	L7			
C111	B5	M5	J28	A1	J7	R162	G2	N6	U40C	B3	G4	U51	G5	L8			
			J29	B3	L5	R174	H1	N5				U52	G4	L7	Y2	B2	K8

The schematic diagram has an alphanumeric grid to assist in locating parts within that diagram.

*See parts list for earlier values and serial number ranges.

FRONT PANEL PROCESSOR

FRONT PANEL INTERFACE


BATTERY BACKUP

RAM


EPROM

RS232 PORT

DIP SWITCH



↓ = ANALOG GROUND
 ↓ = DIGITAL GROUND
 * SEE PARTS LIST FOR EARLIER VALUES AND SERIAL NUMBER RANGES.



Static Sensitive Devices
See Maintenance Section

+ Back of board.


A2 MAIN BOARD
671-1758-00 - 03

Schematic Diagram <2> Component Locator Chart
Assembly A2. Partial Assembly A2 also shown on Diagrams 1, 3, 4, 5, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
BT1	E5	L2	J31B	H1	L1	R159	E5	J4	U9	E5	I5
C93	E5	I4	J32	B5	L1	R190 *	A3	M1	U10	E2	J6
C114	G5	L1	R1	D1	J3	U1	B1	L4	U11	E2	J6
CR15 *	F5	M1	R2	D1	J3	U2	G2	K1	U12	D3	M3
			R3	D1	J3	U3	G3	J1	U40D	C5	G4
			R5	B2	L4	U4	G3	I1	W5 *	A3	I4
J30	B1	K8	R6	E5	I4	U5	F5	M2			
J31A	H2	L1	R7	D5	I5	U6	G5	L1	Y3	A3	I3

The schematic diagram has an alphanumeric grid to assist in locating parts within that diagram.

*See parts list for earlier values and serial number ranges.



P/O A2 MAIN BOARD

Schematic Diagram <3>

Component Locator Chart


The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.

Main Board, Assembly A2.

Partial Assembly A2 also shown on Diagrams 1, 2, 4, 5, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C21	F3	G7			
C22	F3	G6	R23	E3	H6
C23	H4	G6	R24	E4	H6
C24	E3	I5	R25	E2	H5
C31	F4	G7	R26	E2	H5
			R27	C4	H6
C32	F4	G6			
C34	E4	I6	R28	C3	H5
C94	E4	I6	R66 *	B1	
C95	E3	I5	R160	E4	H6
C116	E4	I6	R161	E3	H5
C117	E2	H4	TP7	H4	F7
C118	E5	H7	TP8	H3	G6
C119	E5	G4			
C120	F5	G5	U13A	H4	F7
C121	F5	H7	U13B	H3	F7
			U14	C4	I6
FL2	F3	G5	U15	C2	I5
FL3	F4	G5	U16	B1	I7
J2	C1	I7	U17	B1	H7
			U18	B2	I6
R14	C3	H5	U19	B2	I5
R15	C4	H6	U20	E4	I6
R16	C3	H6	U21	E3	I4
R17	C4	H7			
			U66A	B1	I4
R19	H2	F6	U66B	A1	I4
R20	G2	F6	U69	E5	G5
R21	H4	F7	U70	E5	H7
R22	G4	F7			

*See parts list for earlier values and serial number ranges.



Schematic Diagram <3a>

Component Locator Chart


The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.

Main Board, Assembly A2.

Partial Assembly A2 also shown on Diagrams 1, 2, 4, 5, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C21	F3	G7	R22	G4	F7
C22	F3	G6			
C23	H4	G6	R23	E3	H6
C24	E3	I5	R24	E4	H6
C31	F4	G7	R25	E2	H5
			R26	E2	H5
C32	F4	G6	R27	C4	H6
C34	E4	I6			
C94	E4	I6	R28	C3	H5
C95	E3	I5	R66 *	B1	
C116	E4	I6	R160	E4	H6
			R161	E3	H5
C117	E2	H4			
C118	E5	H7	TP7	H4	F7
C119	E5	G4	TP8	H3	G6
C120	F5	G5			
C121	F5	H7	U13A	H4	F7
			U13B	H3	F7
FL2	F3	G5	U14	C4	I6
FL3	F4	G5	U15	C2	I5
			U16	B1	I7
J2	C1	I7			
			U17	B1	H7
R13	G3	G6	U18	B2	I6
R14	C3	H5	U19	B2	I5
R15	C4	H6	U20	E4	I6
R16	C3	H6	U21	E3	I4
R17	C4	H7			
			U66A	B1	I4
R18	G4	F7	U66B	A1	I4
R19	H2	F6	U69	E5	G5
R20	G2	F6	U70	E5	H7
R21	H4	F7			

*See parts list for earlier values and serial number ranges.



DATA FORMATTER/SYNCHRONIZER

LEFT D/A CONVERTER

LEFT LOW PASS FILTER

RIGHT D/A CONVERTER

RIGHT LOW PASS FILTER

↓ = ANALOG GROUND
 ↓ = DIGITAL GROUND

NOTE: ** SEE PARTS LIST FOR EARLIER VALUES AND SERIAL NUMBER RANGES.

P/O A2 MAIN BOARD

Schematic Diagram <4> Component Locator Chart


The schematic diagram has an alphanumeric grid to assist in locating parts within that diagram.

Main Board, Assembly A2.

Partial Assembly A2 also shown on Diagrams 1, 2, 3, 5, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C35	D1	D5	FL11 *	H4	A5	R33	B2	D6	R167A	F1	B6
C36	D2	D5							R167B	F2	B6
C37	D4	D7	J11	H1	A6	R34	B2	D6	R167C	F2	B6
C38	D4	D8	J12	H2	A4	R35	B2	E6	R167D	F2	B6
C96	D1	D5	J13	H3	A7	R36	B3	E6	R167E	F5	B6
			J14	H4	A5	R37	D1	C4			
C97	B1	D6	J33	H5	D5	R38	D2	C5	R167F	F5	B6
C98	D3	D7							R167G	F4	B6
C99	B4	D7	K2A	G5	B5	R39	E2	B5	R167H	F4	B6
C126 *	H1	A6	K2B	G5	B5	R40	E1	B4	R168	F1	B4
C127 *	H1	A6	K2C	G4	B5	R41	E2	C5	R173	E3	C4
						R42	E3	C6			
C128 *	H1	A4	K5A	G3	B4	R43	F2	B6	R180	B3	E7
C129 *	H1	A4	K5B	G2	B4				R181	B3	D6
C130 *	H3	A8	K5C	G1	B4	R44	F2	B5	R182	B3	D7
C131 *	H4	A8				R45	E2	C5	R183	B5	D8
C132 *	H4	A5	L1 *	C3	H4	R46	E2	C5	R184	B5	D8
			L2 *	C5	B7	R67	B1	D6			
C133 *	H4	A5	L3 *	G3	B7	R68	B1	D6	R185	B5	E8
C137	F4	H4							R191 *	G4	N1
C138 *	G5	B5	Q2	D1	C5	R69	B4	D7			
C139 *	G3	B4	Q3	D2	C5	R70	B4	D7	U22	C1	E5
C140 *	G3	B4	Q4	D1	C4	R71	B4	D7	U23A	D2	C5
			Q5	D2	C5	R72	B4	D7	U23B	E2	C5
C141 *	C2	D5	Q6	F2	C5	R73	B4	D8	U25A	C1	C6
C143 *	C4	D6							U25B	C3	C6
			Q7	F2	C6	R74	B5	D8			
CR4	D1	C5	Q8	F2	B5	R75	B5	E8	U25C	D3	C6
CR5	D2	C5	Q9	F3	B6	R76	B5	E8	U25D	D1	C6
CR6	E2	C6	Q10	D4	C6	R77	D4	C6	U27	E1	G8
CR7	E2	C6	Q11	D4	C7	R78	D4	C7	U28	C4	E7
									U29A	D4	C7
CR8	D4	C7	Q12	D4	B6	R79	E4	B7	U29B	E5	C7
CR9	D4	C7	Q13	D4	B7	R80	E4	B6			
CR10	E4	C8	Q14	F4	C7	R81	E4	C7			
CR11	E5	C8	Q15	F5	C8	R82	E5	C8			
			Q16	F4	B7	R83	F5	B7			
FL4 *	H1	A6							CHASSIS		
FL5 *	H1	B6	Q17	F5	B7	R84	F5	B7	C135 *	H3	—
FL6 *	H2	A5	Q20 *	G4	N1	R85	E4	C7	C136 *	H3	—
FL7 *	H2	A5				R86	E4	C7	C200 *	H3	—
			R29	B2	D6	R107	B3	D7			
FL8 *	H3	A7	R30	B2	D6	R108	B3	D7	E200 *	H3	—
FL9 *	H3	B7	R31	B2	D6						
FL10 *	H4	A6	R32	B2	D6						

*See parts list for earlier values and serial number ranges.



Schematic Diagram <5>

Component Locator Chart


The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.

Main Board, Assembly A2.




Partial Assembly A2 also shown on Diagrams 1, 2, 3, 4, and 6.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C39	D3	F4	R119	F4	F5
C40	E3	G4			
C41	F3	G4	R120	D4	E5
C42	C1	G5	R121	C2	E5
C43	C1	E4	R122	F4	F5
			R123	F4	G5
C45	D4	F5	R124	B2	F6
C46	E4	F5			
C47	F4	F5	R126	B2	F6
C48	C2	G6	R127	E4	F5
C49	C2	E6	R128	E4	F5
			R129	E3	F4
			R130	E3	F4
C51	C5	E4			
C100	B2	F6			
C101	B1	F5	R132	B5	E4
C135	BH		R133	B5	E4
C136	BH		R163	B1	F5
C200	CH		R164	B1	F5
			R165	B2	F6
E200	BH				
			R166	B2	F6
J20	H3	L1	R175	B3	E5
J200	BH		R176	B3	D5
			R186	C3	D4
Q18	C3	D5	R187	C3	D5
Q19	C3	C4			
			U33	E3	F4
R109	G3	G4	U35A	B1	F5
R110	F3	F4	U35B	F3	F5
R111	D3	F4	U36	E4	E5
R112	C1	F4	U38A	B2	F6
R113	F3	G4			
			U38B	F4	F6
R114	F3	G4	U39	C5	E4
R115	B1	F5	U40A	B3	G4
R117	B1	F5	U41	D3	D5
R118	G4	G5			

*See parts list for earlier values and serial number ranges.



HEADPHONE AMPLIFIER



NOTE: PIN 3 OF J200 NOT INSERTED ON ECB.

** SEE ELECTRICAL PARTS LIST FOR EARLIER VALUES AND SERIAL NUMBER RANGES.

⏏ = ANALOG GROUND
⏏ = DIGITAL GROUND

P/O A2 MAIN BOARD

Schematic Diagram <6>

Component Locator Chart

The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.



Main Board, Assembly A2.

Partial Assembly A2 also shown on Diagrams 1, 2, 3, 4, and 5.

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C3	D3	H4	C102	G1	E7
C4	D5	I4	C105	F4	M2
C5	D3	H4			
C6	D5	I4	C106	F4	M4
C7	D3	I1	C108	C3	H1
			C112	C3	M5
C8	D3	K1	C113	C3	M5
C9	E3	J1	C124	D4	H1
C11	E3	M2			
C12	E3	L3	C125	D4	K5
C13	E3	I5	C134	D4	N8
			C137	F4	H4
C14	F3	M3	C142 *	B3	F7
C15	F3	J6			
C16	F3	J5	DS1	C4	H1
C25	E5	H7			
C26	E3	H7	J7	B2	F6
			J23	B4	H2
C27	E5	H6			
C28	E3	H6	R134	C2	F7
C29	E5	H7	R135	C2	F7
C30	E3	H5	R136	B2	F6
C52	G2	F7	R137	B2	F6
			R138	C2	F7
C53	C2	E7			
C54	B2	E6	R140	F1	F8
C55	G2	F7	R141	F2	G7
C56	C2	F7	R142	F1	F8
C57	C2	F7	R143	G1	F8
			R144	D2	G8
C59	F1	F8			
C60	F2	G7	R145	E2	G8
C61	F1	E8	R188	C3	I1
C62	D2	G8			
C63	D2	G8	TP1	C4	B6
			TP2	C4	E7
C64	E2	G7	TP3	C4	G4
C65	D2	G8			
C66	E2	G7	TP4	E4	L2
C67	B3	I2	TP5	E4	L8
C68	B5	I3	TP6	C4	H7
C69	B3	I2	U7	D3	H4
C70	G2	F8	U8	D5	H4
C79	D4	J6	U42A	F2	F7
C80	D4	L6			
C81	D4	L7	U42B	C2	F7
			U46A	E2	G7
C82	E4	L7	U68	C3	M5
C83	E4	L6			
C84	E4	L5	VR3	B2	F6
C85	E4	K5	VR4	G1	G7
C86	F4	I6	VR5	G2	G7
C87	F3	K3	W1	E4	B8
C88	G3	K4	W123 *	D4	B4
C89	G3	L3			


*See parts list for earlier values and serial number ranges.

MIC PREAMP AND AGC



POWER DISTRIBUTION AND DECOUPLING

A3 POWER SUPPLY




NOTE: ∇ and ∇ tie together only at this one point (star ground).

∇ = ANALOG GROUND

∇ = DIGITAL GROUND

* * * SEE ELECTRICAL PARTS LIST FOR EARLIER VALUES AND SERIAL NUMBER RANGES.

P/O A2 MAIN BOARD



1

2

 **Static Sensitive Devices**
See Maintenance Section

A1 FRONT PANEL BOARD

Schematic Diagram <7>

Component Locator Chart

The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.


Front Panel Board, Assembly A1

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C1	C1	D1	S1A	C4	A1
C2	C1	G1	S1B	C3	A1
C3	B1	D1	S2A	D4	B1
			S2B	D3	B1
DS1	G3	A2	S3A	E4	B1
DS2	C1	G2			
			S3B	D3	B1
J1	A1	D1	S4A	E4	C1
J2	D2	A1	S4B	E3	C1
			S5A	F4	C1
R1	B3	C2	S5B	F3	C1
R2	C4	C2			
R3A	G3	B2	S6A	G4	D1
R3B	G3	B2	S6B	F3	D1
R3C	F3	B2	S7	C5	E2
			S8	D5	E2
R3D	E3	B2	S9	E5	F2
R3E	E3	B2			
R3F	D3	B2	S10	E5	F2
R3G	C3	B2	S11	F5	D2
R4	B3	E1	S12	G5	D2
			S13	G5	G2
			S14	H5	C2
R5	B1	G1			
R6	C1	H2			
R7	B1	D1	U1	B2	E2

*See parts list for earlier values and serial number ranges.

A B C D E F G H

1
2
3
4
5




NOTE: ** SEE PARTS LIST FOR EARLIER VALUES AND SERIAL NUMBER RANGES.

671-1763-00 & ABOVE
A1 FRONT PANEL BOARD

ASG 100

FRONT PANEL

7



A4 SERIAL FILTER BOARD

Schematic Diagram <8>

Component Locator Chart

The schematic diagram has an alpha-numeric grid to assist in locating parts within that diagram.

Serial Filter Board, Assembly A2A1

Comp No	Diag Loc	Bd Loc	Comp No	Diag Loc	Bd Loc
C1	D2	A2	C16	D4	A1
C2	E2	A1	C17	D4	A2
C3	D2	B2	C18	E4	A1
C4	E2	B1	FL1	D2	A1
C5	D2	A2	FLS	D2	B1
C6	E2	A1	FL3	D2	A1
C7	D3	B2	FL4	D3	B1
C8	E3	B1	FL5	D3	A1
C9	D3	A2	FL6	D3	A1
C10	E3	A1	FL7	D4	A1
C11	D3	A2	FL8	D4	A1
C12	E3	A1	FL9	D4	A1
C13	D4	A2	J1	B2	A2
C14	E4	A1	J2	F2	A1
C15	D4	A2			

*See parts list for earlier values and serial number ranges.

A

B

C

D

E

F

G

H



1

2

3


4

5



671-2106-00

A4 SERIAL FILTER BOARD



Section 8

Replaceable Mechanical Parts

This section contains a list of the components that are replaceable for the ASG 100. Use this list to identify and order replacement parts. There is a separate Replaceable Mechanical Parts list for each instrument.

Parts Ordering Information

Replacement parts are available from or through your local Tektronix, Inc., Field Office or representative.

Changes to Tektronix instruments are sometimes made to accommodate improved components as they become available and to give you the benefit of the latest circuit improvements. Therefore, when ordering parts, it is important to include the following information in your order.

- Part number
- Instrument type or model number
- Instrument serial number
- Instrument modification number, if applicable

If a part you have ordered has been replaced with a new or improved part, your local Tektronix, Inc., Field Office or representative will contact you concerning any change in part number.

Change information, if any, is located at the rear of this manual.

Using the Replaceable Mechanical Parts List

The tabular information in the Replaceable Mechanical Parts list is arranged for quick retrieval. Understanding the structure and features of the list will help you find all of the information you need for ordering replaceable parts.

Cross Index—Mfr. Code Number to Manufacturer

The Mfg. Code Number to Manufacturer Cross Index for the mechanical parts list is located immediately after this page. The cross index provides codes, names, and addresses of manufacturers of components listed in the mechanical-parts list.

Abbreviations

Abbreviations conform to American National Standards Institute (ANSI) standard Y1.1.

Chassis Parts

Chassis-mounted parts and cable assemblies are located at the end of the Replaceable Electrical Parts list.

Column Descriptions

Figure & Index No. (Column 1)	Items in this section are referenced by figure and index numbers to the illustrations.
Tektronix Part No. (Column 2)	Indicates part number to be used when ordering replacement part from Tektronix.
Serial No. (Column 3 and 4)	Column three (3) indicates the serial number at which the part was first used. Column four (4) indicates the serial number at which the part was removed. No serial number entered indicates part is good for all serial numbers.
Qty (Column 5)	This indicates the quantity of mechanical parts used.
Name and Description (Column 6)	<p>An item name is separated from the description by a colon (:). Because of space limitations, an item name may sometimes appear as incomplete. Use the U.S. Federal Catalog handbook H6-1 for further item name identification.</p> <p>Following is an example of the indentation system used to indicate relationship.</p> <pre> 1 2 3 4 5 Name & Description Assembly and/or Component Mounting parts for Assembly and/or Component *MOUNTING PARTS*/*END MOUNTING PARTS* Detail Part of Assembly and/or Component Mounting parts for Detail Part *MOUNTING PARTS*/*END MOUNTING PARTS* Parts of Detail Part Mounting parts for Parts of Detail Part *MOUNTING PARTS*/*END MOUNTING PARTS*</pre> <p>Mounting Parts always appear in the same indentation as the Item it mounts, while the detail parts are indented to the right. Indented items are part of and included with, the next higher indentation. Mounting parts must be purchased separately, unless otherwise specified.</p>
Mfr. Code (Column 7)	Indicates the code number of the actual manufacturer of the part. (Code to name and address cross reference can be found immediately after this page.)
Mfr. Part Number (Column 8)	Indicates actual manufacturer's part number.

CROSS INDEX – MFR. CODE NUMBER TO MANUFACTURER

Mfr. Code.	Manufacturer	Address	City, State, Zip Code
52152	MINNESOTA MINING AND MFG CO INDUSTRIAL SPECIALTIES DIV	3M CENTER	ST PAUL MN 55144-0001
54583	TDK ELECTRONICS CORP	12 HARBOR PARK DR	PORT WASHINGTON NY 11550
71468	ITT CANNON DIV OF ITT CORP	666 E DYER RD	SANTA ANA CA 92702
78189	ILLINOIS TOOL WORKS INC SHAKEPROOF DIV	ST CHARLES ROAD	ELGIN IL 60120
80009	TEKTRONIX INC	14150 SW KARL BRAUN DR PO BOX 500	BEAVERTON OR 97077-0001
93907	TEXTRON INC CAMCAR DIV	600 18TH AVE	ROCKFORD IL 61108-5181
TK0858 TK1373	STAUFFER SUPPLY CO (DIST) PATELEC-CEM (ITALY)	10156 TORINO	VAICENTALLO 62/45S ITALY

Replaceable Mechanical Parts

Fig. & Index No.	Tektronix Part No.	Serial Number		Qty	12345	Name & Description	Mfr. Code	Mfr. Part No.
		Effective	Dscont					
1-1	200-3870-00			1		COVER, TOP: ALUMINUM, ASG100 *MOUNTING PARTS*	80009	200-3870-00
-2	211-0119-00			8		SCREW, MACHINE: 4-40 X 0.25, FLH, 100 DEG, STL *END MOUNTING PARTS*	93907	ORDER BY DESCR
-3	426-2420-00			1		FRAME, FRONT: ALUMINUM, ASG100 *MOUNTING PARTS*	80009	426-2420-00
-4	211-0119-00			2		SCREW, MACHINE: 4-40 X 0.25, FLH, 100 DEG, STL *END MOUNTING PARTS*	93907	ORDER BY DESCR
-5	366-2167-00			1		KNOB: GRAY, 0.125 ID X 0.392 OD X	80009	366-2167-00
-6	-----			1		CIRCUIT BD ASSY: FRONT PANEL (SEE A1 REPL) *MOUNTING PARTS*		
-7	211-0244-00			4		SCR, ASSEM WSHR: 4-40 X 0.312, PNH STL *END MOUNTING PARTS*	TK0858	211-0244-00
-8	333-3881-00			1		PANEL, FRONT: ASG100	80009	333-3881-00
-9	337-3749-00			1		PROTECTOR, SW: TV GRAY, POLYCARBONATE	80009	337-3749-00
-10	-----			1		CIRCUIT BD ASSY: MAIN (SEE A2 REPL) *MOUNTING PARTS*		
-11	211-0101-00			8		SCREW, MACHINE: 4-40 X 0.25, FLH, 100 DEG, STL	93907	ORDER BY DESCR
-12	211-0244-00			8		SCR, ASSEM WSHR: 4-40 X 0.312, PNH STL *END MOUNTING PARTS*	TK0858	211-0244-00
-13	-----			1		POWER SUPPLY: SWITCHING, AUTO IN 85-264VAC, 47-440HZ, OUT 5VDC 5A, +15V 2A, -15V 0.5A (SEE A3 REPL) *MOUNTING PARTS*		
-14	211-0244-00			3		SCR, ASSEM WSHR: 4-40 X 0.312, PNH STL *END MOUNTING PARTS*	TK0858	211-0244-00
-15	337-3738-00			1		SHIELD, ELEC: POWER SUPPLY	80009	337-3738-00
-16	348-0844-00			1		PAD, CUSHIONING: 0.05 SQ X 0.23 H, POLYURETHANE W/ PRESSURE SENS ADHESIVE	52152	SJ-5018-GRAY
-17	-----			1		FILTER, RFI: 3A, 250VAC, 50/60HZ (SEE FL100 REPL) *MOUNTING PARTS*		
-18	211-0012-00			2		SCREW, MACHINE: 4-40 X 0.375, PNH, STL	93907	ORDER BY DESCR
-19	210-0586-00			2		NUT, PL, ASSEM WA: 4-40 X 0.25, STL CD PL *END MOUNTING PARTS*	78189	211-041800-00
-20	174-2495-00			1		CA ASSY, SP, ELEC: 18 AWG, 3.3 L, 8-0	80009	174-2495-00
-21	174-2496-00			1		CA ASSY, SP, ELEC: 18 AWG, 3.3 L, 8-9	80009	174-2496-00
-22	196-1213-00			1		LEAD, ELECTRICAL: 18 AWG, 2.5 L, 5-4 *MOUNTING PARTS*	80009	196-1213-00
-23	211-0244-00	B010100	B032105	1		SCR, ASSEM WSHR: 4-40 X 0.312, PNH STL	TK0858	211-0244-00
-23	211-0722-00	B032106		1		SCREW, MACHINE: 6-32 X 0.250, PNH, STL, CDPL *END MOUNTING PARTS*		
-24	-----			1		CA ASSY, SP, ELEC: 10, 28 AWG, 9.25 L (SEE A4J1 REPL) *MOUNTING PARTS*		
-25	214-3903-01			2		SCREW, JACK: 4-40 X 0.312 EXT THD, 4-40 INT THD, 0.188 HEX, STEEL, CAD PLATE		
-26	348-0844-00			5		PAD, CUSHIONING: 0.05 SQ X 0.23 H, POLYURETHANE W/ PRESSURE SENS ADHESIVE	52152	SJ-5018-GRAY
-27	200-3869-00	B010100	B031903	1		COVER, BOTTOM: ALUMINUM, ASG100	80009	200-3869-00
-27	200-3869-01	B031904	B032105	1		COVER, BOTTOM, ALUMINUM, ASG100	80009	200-3869-01
-27	200-3869-02	B032106		1		COVER, BOTTOM, ALUMINUM, ASG100	80009	200-3869-02

Replaceable Mechanical Parts

Fig. & Index No.	Tektronix Part No.	Serial Number		Qty	12345	Name & Description	Mfr. Code	Mfr. Part No.
		Effective	Dscont					
						STANDARD ACCESSORIES		
-28	161-0066-00			1		CA ASSY,PWR:3,18AWG,98 L,SVT,GREY/BLK,60 DEG C,IEC BME X STR,IEC RCPT,10A/125V (STANDARD ONLY)	80009	161-0066-00
	070-8152-0X			1		MANUAL,TECH:INSTR,ASG100	80009	070-8152-0X
	070-8546-0X			1		MANUAL,TECH:SERVICE,ASG100	80009	070-8546-0X
						OPTIONAL ACCESSORIES		
-29	161-0066-09			1		CA ASSY,PWR:3,0.75MM SQ,220V,99.0 L (EUROPEAN OPTION A1 ONLY)	80009	161-0066-09
-30	161-0066-10			1		CA ASSY,PWR: (UNITED KINGDOM OPTION A2 ONLY)	TK1373	24230
-31	161-0066-11			1		CA ASSY,PWR:3,0.75MM,240V,96.0 L (AUSTRALIAN OPTION A3 ONLY)	80009	161-0066-11

Replaceable Mechanical Parts

Appendix A

REMOTE OPERATION

REMOTE CONTROL FROM A TERMINAL

You can control the ASG 100 from a terminal, a computer running terminal emulation software, or a VM700A Video Measurement Set via the RS-232C serial interface. Remote control via a modem is also possible using the RS-232C serial port of the ASG 100. These operations are:

- AUTO test selection and level setting
- LINE UP test tone
- MANUAL test tone in left, right or both channels plus level and frequency setting
- MANUAL polarity test tone in left, right, or both channels plus level setting
- MANUAL multi-tone test in left, right, or both channels plus level setting
- SILENCE function
- VOICE playback
- VOICE plus LINE UP test tone, alternating
- ID setting and queries
- Queries of test signal settings
- OFFLINE

LIMITED LOCAL REMOTE CONTROL

Limited remote control of the ASG 100 is possible using contact closures on the remote connector. One closure activates the auto sequence, and the other enables front panel editing of a setting when editing is internally disabled. Remote connections for these functions are explained in the following text.

INSTALLATION FOR REMOTE CONTROL

Connect a Properly Configured Communications Cable

On the back panel of the ASG 100, to the right of the power switch, is a 9-pin male connector labeled "REMOTE." This DB-9 connector is used to access two types of remote control. It may be used to connect switching contacts that are used to start the AUTO Test or to override the editing locked feature so new setups may be saved without removing the ASG 100 from a rack installation to reset the internal DIP switches. Its second, and most versatile, purpose is to provide an RS-232C interface for remote control the instrument's signal generation functions.

When used for RS-232C serial data transfer, the remote port is configured as a 9-pin (DB-9) DTE (Data Terminal Equipment) connector. You can set up remote control by connecting this serial port to the serial port of a terminal (or terminal-emulating computer) through a properly configured communications cable.

The functions of the pins on the remote connector are shown in Table A-1. On the ASG 100 end, the DTE cable you use must be connected to a 9-pin female connector conforming to this configuration.

Table A-1
Pin Connections for Remote Connector

Pin Number	Signal Name	Signal Description
1	DCD	Data Carrier Detect (not connected)
2	RXD	Received Data (connected)
3	TXD	Transmitted Data (connected)
4	DTR	Contact closure with pin 6 enables editing of function settings. Contact closure with pin 9 starts AUTO test. Do not connect this pin with the remote terminal via the RS-232C interconnection cable.
5	GND	Signal Ground/Common Return (connected)
6	DSR	Contact closure with pin 4 enables editing of function settings. Do not connect this pin to the remote terminal via the RS-232C interconnection cable.
7	RTS	Request to Send (not used in the ASG 100)
8	CTS	Clear to Send (not used in the ASG 100)
9	RI	Contact closure with pin 4 starts AUTO test. Do not connect this pin to the remote terminal via the RS-232C interconnection cable.

On the remote terminal end, the configuration of the cable connector should match that of the terminal's serial port. The cable configurations for communication between the ASG 100 and IBM PCs and compatibles operating as data terminal equipment are shown in Figure A-1 and Figure A-2.




Figure A-1. Cabling to IBM PC/XT or Compatibles and the VM700A.




Figure A-2. Cabling to IBM AT/386 and Compatibles.

NOTE

In all configurations pins 4, 6 and 9 on the ASG 100 serial port must not be connected to the serial port on the remote terminal or computer; they are reserved for remotely enabling function editing and initiating the AUTO test. Typically, if you establish remote control through a terminal or computer, you will perform these operations through remote commands, rather than through shorting these pins.

Set DIP Switch to Enable Remote Control

As explained in Section 2, *Operation and Setup*, certain functions are enabled and disabled by the positions of the switches on the 10-switch DIP labeled "S1" on the circuit board. You access this switch through the cover on the left panel of the ASG 100. As with all servicing, refer the internal adjustments to a qualified service person.

Remote operation of the ASG 100 through its remote port is enabled when switch S1, position 8 (labeled "PROG7" on the circuit board) is in the up position.

Set Serial Communication Parameters on the Terminal

Using the commands appropriate for your terminal or terminal emulator, set the communication parameters to the values shown below in Table A-2.

Table A-2
Serial Communication Parameters

Parameter	Value
Baud Rate	9600 ^a
Data Bits	8
Parity	None
Stop Bits	1

^aBaud rate for the ASG 100 is selectable for 1200, 2400, 4800, or 9600 baud. The factory setting is 9600 baud.

Setting Baud Rate of the ASG 100

The baud rate of the ASG 100 is user settable from the front panel so that lower baud rate modems not capable of the factory default of 9600 baud may be used for remote control. Four choices are available: 1200, 2400, 4800, and 9600 baud. The data bits, parity, and stop bits parameters for the ASG 100 are fixed.

NOTE

If you need to operate the ASG 100 on a baud rate setting other than 9600, PROG0 of S1 must be set to the user defaults position (down) to make the needed baud rate setting. Leave the switch set to user defaults to prevents the baud rate (and the other user selectable front panel settings as well) from being changed to factory defaults in the event of a loss of power to the ASG 100. The factory default baud rate setting of 9600 is restored at power on if PROG0 of S1 is set to the factory default (up) position




Figure A-3. Setting baud rate during power on.

The baud rate may be set during power up only if PROG0 of S1, the default settings switch (factory defaults up and user defaults down), is set to the user default position (down). At power up, the current baud rate setting (for example, Baud9600) appears in the display window for about 3 seconds. A front panel button that selects baud rate must be pressed to change the setting (see Figure A-3, A) before that message is removed from the display. Setting a new baud rate automatically saves it as the user selectable power-on setting.

When a baud rate selection button is pressed, the message "Set:nnnn" (where nnnn is the new baud rate) will be displayed. Holding a button in keeps the setting associated with that button displayed until it is released. When released, the new baud rate is displayed. If that is not the required setting, immediately pressing another baud rate choice selects the baud rate associated with that front panel button (see Figure A-3, B).

If a another baud rate selection button is not pressed within the 3-second time period after a baud rate setting has been made, the ASG 100 continues with the power-on routine and initialization of the front panel settings.

It is not necessary to turn off the ASG 100 at the rear panel ON/OFF switch to get a power up restart for resetting the baud rate. Pressing the left and right arrow buttons at the same time resets the ASG 100 and restores the enabled defaults (factory or user). This is the same action that occurs when a control C is sent to the ASG 100 via the RS-232C serial port.

Once the ASG 100 baud rate has been set to a different choice, the device communicating with the ASG 100 must also be set to that same baud rate (or be able to auto baud) to communicate with the ASG 100. If the baud rate selected matches the baud rate expected by the device that the ASG 100 is sending to, the remote display will print out the DSP Firmware version number, the DSP diagnostics version number, and the the FP Controller version number. If nothing is seen, either the serial communication path is not connected, or the baud rate is incorrect. If only garbled ascii characters are seen, try another baud rate.

REMOTE OPERATION

Once installation is complete, when you power on the ASG 100 the screen of the remote terminal transcripts the self-test the ASG 100 performs, then displays the following prompt:

```
ASG100\fp>
```

When this prompt is displayed, you can enter the remote commands. Any command that is not understood will cause the error line "Unrecognized command." to appear. Other error messages appear when arguments to the command are not within limits or errors in the syntax of the arguments are found.

The RS-232C interface of the ASG 100 permits only one command per line, and a command line is terminated by a carriage return. If the command sent requires a reply from the ASG 100 or starts an AUTO test sequence (i.e., Sweep which needs about 32 seconds to finish), an appropriate time delay must be permitted before another command is sent. Attempting to batch load a set of commands to the ASG 100 may cause command data to be lost while the ASG 100 is sending its reply. Also, *any* command sent the ASG 100 while an AUTO test is being executed will terminate the AUTO test.

Remote Commands

There are commands that take arguments to permit the parameters of the command to be altered. The commands also have associated queries to determine the parameters of a test signal. Several of the commands are queries only. There are also three control characters that the ASG 100 recognizes to assist in remote operation of the instrument. A concise list of the commands, arguments, queries, and special control characters is given in Tables A-3, A-4, and A-5 for quick reference. The text following the tables explains the commands in more detail.

Table A-3
List of ASG 100 Commands, Arguments, and Queries

Commands	Argument	Argument	Queries	Responses
auto	l:[level]	[test name]	auto? auto help	<p>Auto with no arguments starts the selected auto test at the current level setting. The level argument sets a new TEST Lev for the O.33 and Tek tests from -6 dBu to +14 dBu. The test name argument selects the test sequence.</p> <p>If the test signal for auto is a Sweep signal, the level argument sets a new SweepLev from -90 dBu to +24 dBu.</p> <p>When help is on, the ASG 100 sends a reply of "Auto sequence done." when the auto sequence has completed.</p> <p>auto? returns the selected test sequence, the current ID, and the level settings for Test Level and Sweep Level.</p> <p>auto help returns a list of valid arguments for the auto command.</p>
help			help? ?	All forms of this command return a list of ASG 100 commands.
helpoff				Turns off the help replies, error messages, and prompts. Test signal queries are answered.
helpon				Turns the help replies, error messages, and prompts back on.
id *****			id?	<p>Sets a new 4-character ID. All printable ASCII characters are valid and all four characters must be used. Spaces are valid.</p> <p>The query returns the 4-character ID.</p>

Table A-3 (cont)

Commands	Argument	Argument	Queries	Responses
lineup			lineup?	<p>Sends the line up signal to both channels. The frequency and level cannot be changed remotely. If a variable tone signal is needed for a special line up, use the tone test signal.</p> <p>The query returns the present level and frequency for the lineup signal.</p>
lmtone<1 2 3 4>	l:[<i>level</i>]		lmtone[n]?	<p>Sends the selected multi-tone (1, 2, 3, or 4) to the left channel at the current level. The level argument sets the new signal level from -90 dBu to +24 dBu.</p> <p>The query returns the present level for the multi-tone test signals.</p>
lpolr	l:[<i>level</i>]		lpolr?	<p>Sends the polarity signal to the left channel. The level argument sets the new signal level from -90 dBu to +24 dBu.</p> <p>The query returns the present level for the polarity test signals.</p>
ltone	l:[<i>level</i>]	f:[<i>frequency</i>]	ltone?	<p>Sends the tone signal to the left channel. The level argument sets the new signal level from -90 dBu to +24 dBu. The frequency argument sets a new frequency from 10 Hz to 20 kHz.</p> <p>The query returns the present level for the tone test signals.</p>
mtone<1 2 3 4>	l:[<i>level</i>]		mtone[n]?	<p>Sends the selected multi-tone (1, 2, 3, or 4) to both channel (channels A and B). The level argument sets the new signal level from -90 dBu to +24 dBu.</p> <p>The query returns the present level for the multi-tone test signals.</p>
offline			offline?	<p>Takes the ASG 100 offline and restores the input program (if any) to the downstream equipment.</p> <p>The query replies that there are no variables for offline.</p>

Table A-3 (cont)

Commands	Argument	Argument	Queries	Responses
rmtone<1 2 3 4>	l:[level]		rmtone[n]?	Sends the selected multi-tone signal (1, 2, 3, or 4) to the right channel. The level argument sets the new signal level from -90 dBu to +24 dBu. The query returns the present level for the multi-tone test signals.
rpolr	l:[level]		rpolr?	Sends the polarity signal to the right channel. The level argument sets the new signal level from -90 dBu to +24 dBu. The query returns the present level for the polarity test signals.
rtone	l:[level]	f:[frequency]	rtone?	Sends the tone signal to the right channel. The level argument sets the new signal level from -90 dBu to +24 dBu. The frequency argument sets a new frequency from 10 Hz to 20 kHz. The query returns the present level for the tone test signals.
silence			silence?	Sends silence on the output signal lines. The query replies that there are no variables for the silence command.
tone	l:[level]	f:[frequency]	tone?	Sends the tone signal to both channels. The level argument sets the new signal level from -90 dBu to +24 dBu. The frequency argument sets a new frequency from 10 Hz to 20 kHz. The query returns the present level for the tone test signals.
voi+lu			voi+lu?	Sends the recorded voice id alternately with the line up signal. The query returns the present line up level which is also the voice level.
voice			voice?	Sends the recorded voice id. The query returns the present line up level which is also the voice level.

Table A-4
Special Queries

Query	Response
display?	Returns the present display text.
leds?	Returns the LED or LEDs that are on. NOTE: If an auto sequence is on, it is aborted.
version?	Returns the front panel controller firmware version number and date the version was created.

Table A-5
Control Signals

Control Signal	Response
control C	Restarts the ASG 100 and restores the default front panel settings (either factory or user selected as determined by the setting PROG0 of DIP switch S1).
control S	Halts serial port communication from the ASG 100. Normally used by a terminal or host computer to prevent an input buffer overflow.
control Q	Restores serial port communications that have been stopped by a control S.

Command Description

Help Commands

To display a list of the remote test signal commands on the terminal screen, enter:

```
help[cr] or ?
```

Figure A-4 shows the resulting menu.

Sending help with the auto command in the following form:

```
auto help
```

returns a list of the legal arguments that may be used with the auto command (see Table A-5 for test names).

Help mode can be disabled to eliminate the output of the help menu and the normal prompts. The command to disable the help menu is:

```
helpoff[cr]
```

All error messages and prompts are disabled. The ASG 100 still responds to the direct queries for information on frequency or levels when given as shown below, but it will not respond to help, ?, or auto help and does not return error messages on incorrect commands with help turned off.

Help is turned on again using the command:

```
helpon[cr]
```


ASG 100 REMOTE COMMAND MENU

```

offline .....Takes unit offline.
silence .....Sends silence.
voice .....Sends the stored voice sequence.
auto [l:level] [test_name] .....Starts auto sequence.
id "****" .....Assigns identification code.
lineup .....Sends the preset line up tone.
voi+lu .....Alternately sends voice and line up.
[r | l]tone [f:freq] [l:level] .....Sends a tone to respective channel(s).
[r | l]polr [l:level] .....Sends polarity to respective channel(s).
[r | l]mtone<1|2|3|4> [l:level] ....Sends multi-tone to respective channel(s).
Where:
test_name   is an auto sequence argument. Type "auto help" for list.
             Example:      "auto tek:91"    will generate the tek:91 sequence.
freq       is the frequency in Hz.
             Example:      "tone f:440"    sends a tone at 440Hz, default level.
level      is the level in dBu. The level must be entered to the nearest tenth
             of a dBu.
             Example:      "lmtone l:+2.3"  sends left channel multi-tone at +2.3dBu.
*          is any ASCII character from " " to "-".

```

Figure A-4. Help screen of remote commands.

Queries

There are several remote queries available. They are associated with the test signal commands. The form of the query is:

```
tone?
```

and the return is the present setting for the Manual Tone frequency and the Manual Tone Level. Similar information is returned when the question mark is used to make a query of one of the other test signal commands. The query associated with the commands of voice, voi+lu, and lineup that have no arguments return the current line-up signal level and frequency.

A query of **Auto?** returns the currently selected test sequence, the 4-character id of the ASG 100 queried, and the Test Level and Sweep Level settings associated with the auto test sequences.

Unit Identification

There is an id command and an id query. The id command sends a four-character identification code to the ASG 100. That identification code will be used in the preamble of the auto tests that make use of the unit identifier. Note: The new id sent via remote control is not saved; if the ASG 100 is reset, the identifier will default to the previously saved id.

The form of the command is:

```
id "****"
```

Any 4-character combination of ASCII figures, letters, or punctuation is permitted. All four characters are needed, but they may be spaces. Note: if you use a space for all four characters, the the display will be blank. An error message is generated when an argument syntax error is found if help is on.

The query **id?** returns the 4-character identification code of the ASG 100.

Special Queries

There are two queries that let the remote operator determine the display state of the ASG 100. They are :

`display?` and `leds?`

The `display?` query returns the present display seen on the front panel, and the `leds?` query returns all the front panel indicators that are on.

NOTE

The power-on LED is not firmware controlled, so it is not reported in the return.

Either of these commands may prove useful for determining the state of the ASG 100 without sending a command to cause the state to change. Coupled with the queries regarding the present signal parameters (`tone?`, `lineup?`, `etc?`), it is possible to determine the state of the ASG 100 front panel and the signal parameters without sending a command that will put it on line or change its state if it is on line.

NOTE

If an auto sequence is in progress, the auto sequence is aborted if any communication is received during the test sequence. This includes asking the ASG 100 what its present state is.

A third special query, `version?`, returns the front panel controller firmware version and the date it was generated. This query is provided because any version related firmware questions that arise may be more easily addressed when the installed version is known.

Restoring Defaults

The remote commands with arguments change the setup from the power-on setup. To restore the power-on state, either the factory defaults or the user selected settings, whichever is enabled, type control C. This restarts the ASG 100 and restores the power-on control settings.

Flow Control

The ASG 100 responds to X ON/X OFF software flow control. When a control S is received for X OFF, the ASG 100 stops sending on its serial port. When a control Q is received for X ON, serial communications is resumed. If there is a message pending from the ASG 100, it is sent. Only the first message is queued for output. During the time communication is off, incoming commands are processed, but not echoed.

REMOTE COMMAND SYNTAX

The commands **offline**, **silence**, **voice**, **lineup**, and **voi+lu** take no arguments and perform the requested operation just as from the front panel.

The remote **auto** and remote **tone**, **polarity**, and **mtone** commands allow you to specify optional arguments, as indicated by the bracketed text in Figure A-4 (shown previously). The following text describe the syntax for these remote commands. Type in the commands exactly, one command to a line; do not add extra spaces or other punctuation in front of a command. After the command, use one space before an argument and as a separator when two arguments are used, as in the case of setting both amplitude and frequency for tone. For example:

```
tone f:1000 l:-2.5
```

The order of the arguments does not matter, and the arguments are not case sensitive. The command may be all upper case, all lower case, or mixed. The command line terminator is the carriage return [cr]. The special control characters, control C, control S, and control Q, are received immediately without waiting for a carriage return.

auto [*l:level*][*test_name*]

Level is an optional argument. The test level reference for the auto test sequence is specified. If the argument is not used, the auto test level reference remains at the last selected value. The valid arguments are +14 dBu to -6 dBu in whole integer values. For example, 1:5, 1:0, 1:-3, etc.). Error messages are generated if a limit violation is detected in the argument if help is on.

Test_name is also an optional argument. The argument is a text string specifying which automatic test sequence you want to send. If you do not specify a test name, the auto command initiates the test last selected. The level and test name arguments for auto are not order sensitive, and either may be used first.

The text strings to use for the test sequences supplied by Tektronix are listed below in Table A-6. Enter the arguments with punctuation exactly as shown. The command to send the TEK:90 test at 0.0 dBu will look like this: **auto tek:90 l:0** or **AUTO TEK:90 L:0**. A help query of the auto command in the form of **auto help** returns a list of the legal arguments available with the auto command. An error in the test name argument also results in a display of the legal arguments if help is on.

When the sequence is done, the ASG 100 sends the below message followed by the ASCII bell character:

```
*Auto sequence done.
```

A programmer may choose to watch for the * so that all other commands are held off until the test sequence is done. Another option is to put in a wait state long enough for the test sequence to finish. A wait state would be required if the helpoff command is in effect as the ASG 100 will not return any messages or prompts in this state.

Aborting an Auto Sequence

An auto test sequence is aborted if ANY communication is received after the command is given until the auto test sequence is done. The message "Aborting time sequence, executing new command" is generated. Sending a carriage return only halts the AUTO sequence, and the ASG 100 waits for a second carriage return or a new command to execute before returning the prompt.

Aborting the auto test sequence is a precaution, because the processor of the ASG 100 is also sending the commands needed to generate the test signals in the proper time sequence. Any interruption to handle communications may corrupt the timing of the test sequence.

Table A-6
Test Name Arguments to Remote "AUTO" Command

O.33:00 Test Type	Argument	Tek Test Type	Argument
Mono	o.33:00	Mono	Tek:90
Mono with Voice ID	o.33:00v	Mono with Voice ID	Tek:90v
Stereo	o.33:01	Stereo	Tek:91
Stereo with Voice ID	o.33:01v	Stereo with Voice ID	Tek:91v
Medium Band Sound Program	o.33:02	Microphone	Tek:92
Medium Band Sound Program with Voice ID	o.33:02v	Microphone with Voice ID	Tek:92v
Narrow Band	o.33:03	Line Level	Tek:93
Narrow Band with Voice ID	o.33:03v	Line Level with Voice ID	Tek:93v
Narrow Band Sound Program with Compandor	o.33:04	Transmitter	Tek:94
Narrow Band Sound Program with Compandor with Voice ID	o.33:04v	Transmitter with Voice ID	Tek:94v
3-Level Alignment Signal for International Sound Program without Station Identifier	o.33:05	Stereo with Crosstalk	Tek:95
		Stereo with Crosstalk and Voice ID	Tek:95v
		Sweep	Sweep Sweepr Sweep1

[rll][tone [f:frequency] [l:level]

The **tone** remote command with no arguments makes the ASG 100 send the currently selected MANUAL test tone through the right and left channels at the same time. The **rtone** and **ltone** versions of this command send the MANUAL test tone through the right and left channels, respectively. A query of any of the tone commands in the form of **tone?** returns the current frequency and level setting of the manual tone signals.

The frequency argument specifies a desired frequency for the manual test tone. Enter the initial characters of this argument, **f**, literally, as shown. Specify *frequency* as a positive integer number representing the desired frequency in Hertz. An error in the frequency argument, a number outside the legal range or bad syntax, will result in an error message being generated if help is on.

The level argument specifies a desired amplitude for the manual test tone. Enter the initial characters of this argument, **l**, literally, as shown. Specify *level* as a number representing the amplitude in dBu. You can specify values to tenths of a decibel, for example **5.3**. Do not add extra numbers after the tenths. An error in the argument, specifying a number outside the legal range or incorrect syntax, will result in an error message being generated if help is on.

If you want to specify a negative amplitude, you must prefix the value with a - (minus sign), for example, **-4**. Otherwise the value is assumed to be positive. You can also explicitly specify a positive amplitude with a + (plus sign) prefix, for example, **+6**. A change in the level applies to all the tone signals.

[rll]polr [l:level]

The **polr** remote command with no argument makes the ASG 100 send the polarity tone at the currently selected level through both channels. The **rpolr** and **lpolr** versions of this command send the polarity tone through the right and left channels, respectively. A query of any of the polarity commands in the form of **polr?** returns the fixed frequency of 440 Hz and the current level setting of the manual polarity signals.

The level argument specifies a desired amplitude for the polarity test tone. Enter the initial characters of this argument, **l**, literally, as shown. Specify *level* as a number representing the amplitude in dBu. You can specify values to tenths of a decibel, for example **5.3**. Do not add extra numbers after the tenths. An error in the level argument, specifying a level outside the legal range or incorrect syntax, will result in an error message being generated if help is on.

If you want to specify a negative amplitude, you must prefix the value with a **-** (minus sign), for example, **-4**. Otherwise the value is assumed to be positive. You can also explicitly specify a positive amplitude with a **+** (plus sign) prefix, for example, **+6**. A change in the level applies to all the polarity signals.

There is no frequency argument for polarity. The polarity testing signal is composed of two equal-amplitude sine waves of 440 Hz and 880 Hz, and frequency changes are not permitted. Attempting to send a frequency argument to polarity will result in an error message being generated if help is on.

[rll]mtone<1|2|3|4> [l:level]

The **mtone<1|2|3|4>** remote commands makes the ASG 100 send the selected multi-tone signal at the currently selected amplitude through both channels. The **rmtone <1..4>** and **lmtone <1..4>** versions of this command send the selected test multi-tone through the right and left channels, respectively. The multi-tone signal wanted must be designated. Sending **mtone** alone does not cause a default multi-tone to be sent. A query of any of the multi-tone commands in the form of **mtone1?** returns the current level setting of the manual multi-tone signals.

The level argument specifies a desired amplitude for the multi-tone test signal. Enter the initial characters of this argument, **l**, literally, as shown. Specify *level* as a number representing the amplitude in dBu. A change in the level applies to all the multi-tone signals. An error in the level argument, specifying a level outside the legal range or bad syntax, will result in an error message being generated if help is on.

If you want to specify a negative amplitude, you must prefix the value with a **-** (minus sign), for example, **-4**. Otherwise the value is assumed to be positive. You can also explicitly specify a positive amplitude with a **+** (plus sign) prefix, for example, **+6**.

There is no frequency argument for multi-tone. The test signals are composed of sets of equal-amplitude sine waves at predetermined frequencies, and there is no specific frequency associated with multi-tones. Attempting to send a frequency argument to multi-tone will result in an error message being generated if help is on.

