

**RF Scout®
Interference Hunter
Quick Start User Manual**

www.tektronix.com
071-1901-03

Tektronix

Copyright © Tektronix. All rights reserved. Licensed software products are owned by Tektronix or its subsidiaries or suppliers, and are protected by national copyright laws and international treaty provisions.

Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TEKTRONIX and TEK are registered trademarks of Tektronix, Inc.

NetTek and RF Scout are registered trademarks of Tektronix, Inc.

Contacting Tektronix

Tektronix, Inc.
14200 SW Karl Braun Drive
P.O. Box 500
Beaverton, OR 97077
USA

For product information, sales, service, and technical support:

- In North America, call 1-800-833-9200.
- Worldwide, visit www.tektronix.com to find contacts in your area.

Warranty 2

Tektronix warrants that this product will be free from defects in materials and workmanship for a period of one (1) year from the date of shipment. If any such product proves defective during this warranty period, Tektronix, at its option, either will repair the defective product without charge for parts and labor, or will provide a replacement in exchange for the defective product. Parts, modules and replacement products used by Tektronix for warranty work may be new or reconditioned to like new performance. All replaced parts, modules and products become the property of Tektronix.

In order to obtain service under this warranty, Customer must notify Tektronix of the defect before the expiration of the warranty period and make suitable arrangements for the performance of service. Customer shall be responsible for packaging and shipping the defective product to the service center designated by Tektronix, with shipping charges prepaid. Tektronix shall pay for the return of the product to Customer if the shipment is to a location within the country in which the Tektronix service center is located. Customer shall be responsible for paying all shipping charges, duties, taxes, and any other charges for products returned to any other locations.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. Tektronix shall not be obligated to furnish service under this warranty a) to repair damage resulting from attempts by personnel other than Tektronix representatives to install, repair or service the product; b) to repair damage resulting from improper use or connection to incompatible equipment; c) to repair any damage or malfunction caused by the use of non-Tektronix supplies; or d) to service a product that has been modified or integrated with other products when the effect of such modification or integration increases the time or difficulty of servicing the product.

THIS WARRANTY IS GIVEN BY TEKTRONIX WITH RESPECT TO THE PRODUCT IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED. TEKTRONIX AND ITS VENDORS DISCLAIM ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TEKTRONIX' RESPONSIBILITY TO REPAIR OR REPLACE DEFECTIVE PRODUCTS IS THE SOLE AND EXCLUSIVE REMEDY PROVIDED TO THE CUSTOMER FOR BREACH OF THIS WARRANTY. TEKTRONIX AND ITS VENDORS WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IRRESPECTIVE OF WHETHER TEKTRONIX OR THE VENDOR HAS ADVANCE NOTICE OF THE POSSIBILITY OF SUCH DAMAGES.

Table of Contents

General Safety Summary	iii
Environmental Considerations	vi
Preface.....	viii
Key Features	viii
Documentation	ix
Software Upgrades	x
Conventions Used in This Manual.....	x
Preventing Personal Injury from Lightning	xi
Installation	1
RF Scout Standard Accessories.....	1
Operating Considerations	2
Connecting the AC Adapter	4
Charging the Batteries	5
Powering On and Off the Instrument, and Functional Verification	6
Touch Screen Concepts	7
Calibrate the Touch Screen.....	8
Starting the RF Scout Application	10
Setting Display Colors	11
Enabling Signal Standards	12

Getting Acquainted with Your Instrument	15
Instrument Elements	15
Power On/Standby and Status Panel	16
Input/Output Connectors (NetTek Y400 Platform)	17
NetTek YBT250 Module Signal Connectors.....	18
Microsoft WindowsCE Elements	18
The User Interface	19
The Command Bar.....	20
The Tuning Controls	21
The External Signal Status Buttons	22
The Measurement Mode Buttons.....	23
The Parameter Entry Controls.....	24
Getting Help.....	25
Operating Basics	26
Setting Up to Take a Measurement	26
Spectrum Measurements	31
Channel Measurements Mode	49
iMap Measurement Mapping Mode	53
Signal Measurements.....	73
Specifications	75
Certifications and Compliances	102
Index	

General Safety Summary

Review the following safety precautions to avoid injury and prevent damage to this product or any products connected to it.

To avoid potential hazards, use this product only as specified.

Only qualified personnel should perform service procedures.

While using this product, you may need to access other parts of a larger system. Read the safety sections of the other component manuals for warnings and cautions related to operating the system.

To Avoid Fire or Personal Injury

Use Proper Power Cord. Use only the power cord specified for this product and certified for the country of use.

Observe All Terminal Ratings. To avoid fire or shock hazard, observe all ratings and markings on the product. Consult the product manual for further ratings information before making connections to the product.

The inputs are not rated for connection to mains or Category II, III, or IV circuits.

Power Disconnect. The power cord disconnects the product from the power source. Do not block the power cord; it must remain accessible to the user at all times.

Do Not Operate Without Covers. Do not operate this product with covers or panels removed.

Do Not Operate With Suspected Failures. If you suspect that there is damage to this product, have it inspected by qualified service personnel.

Avoid Exposed Circuitry. Do not touch exposed connections and components when power is present.

Replace Batteries Properly. Replace batteries only with the specified type and rating.

Recharge Batteries Properly. Recharge batteries for the recommended charge cycle only.

Use Proper AC Adapter. Use only the AC adapter specified for this product.

Do Not Operate in an Explosive Atmosphere.

Terms in this Manual

These terms may appear in this manual:



WARNING. *Warning statements identify conditions or practices that could result in injury or loss of life.*



CAUTION. *Caution statements identify conditions or practices that could result in damage to this product or other property.*

Symbols and Terms on the Product

These terms may appear on the product:

- DANGER indicates an injury hazard immediately accessible as you read the marking.
- WARNING indicates an injury hazard not immediately accessible as you read the marking.
- CAUTION indicates a hazard to property including the product.

The following symbol(s) may appear on the product:



Environmental Considerations

This section provides information about the environmental impact of the product.

Product End-of-Life Handling

Observe the following guidelines when recycling an instrument or component:

Equipment Recycling. Production of this equipment required the extraction and use of natural resources. The equipment may contain substances that could be harmful to the environment or human health if improperly handled at the product's end of life. In order to avoid release of such substances into the environment and to reduce the use of natural resources, we encourage you to recycle this product in an appropriate system that will ensure that most of the materials are reused or recycled appropriately.



This symbol indicates that this product complies with the European Union's requirements according to Directive 2002/96/EC on waste electrical and electronic equipment (WEEE). For information about recycling options, check the Support/Service section of the Tektronix Web site (www.tektronix.com).

Battery Recycling. This product may contain a lithium ion (Li-ion) rechargeable battery, which must be recycled or disposed of properly. Please properly dispose of or recycle the battery according to local government regulations.

Mercury Notification. This product uses an LCD backlight lamp that contains mercury. Disposal may be regulated due to environmental considerations. Please contact your local authorities or, within the United States, the Electronics Industries Alliance (www.eiae.org) for disposal or recycling information.

Perchlorate Materials. This product contains one or more type CR lithium coin cell batteries. According to the state of California, CR lithium coin cells are classified as perchlorate materials and require special handling. See www.dtsc.ca.gov/hazardouswaste/perchlorate for additional information.

Transporting Batteries

The lithium ion rechargeable battery pack in this product contains less than 8 grams of equivalent lithium content, with individual cells containing less than 1.5 grams of equivalent lithium, as measured by International Civil Aviation Organization (ICAO) standards. Consult your air carrier for applicability and determination of any special lithium ion battery transportation requirements.

Restriction of Hazardous Substances

This product has been classified as Monitoring and Control equipment, and is outside the scope of the 2002/95/EC RoHS Directive.

Preface

This manual describes the installation and basic operation of the RF Scout Interference Hunter. For more detailed information on individual measurements, tap the underlined link text on measurement screens to open the Online help for those topics.

Key Features

The RF Scout Interference Hunter is a rugged, multi-standard spectrum analyzer and interference mapping tool optimized for field use. Key features include:

- Interference hunting functions that help find interference quickly
- Spectrogram display for detection and logging of intermittent signals
- Signal strength, AM/FM demodulation, and noise floor measurements
- Scanners for GSM/GMSK/EDGE, UMTS/W-CDMA/HSDPA, cdmaOne, cdma2000, 1xEV-DO, TD-SCDMA, and iDEN signals
- User-defined channels for taking general measurements and channel scans
- iMap Integrated measurement mapping for on-site analysis of interference and coverage problems
- Macro editor for creating collections of measurements to take in the iMap window
- PN Sync function for displaying 1xEV-DO and cdma2000 PN offsets in areas that do not have GPS signal availability

Documentation

To read about

Use these documents

Installation and operation (overviews)

RF Scout Interference Hunter Quick Start User Manual. The quick start user manual contains general information about how to put your instrument into service, guides to user interface controls, and application examples.

Help using the application

Online Help. The online help is context sensitive, displaying information appropriate for the active screen or the selected help text. (See page 25, *Getting Help*.)

Software Upgrades

Periodic software upgrades may become available. The software is only operational if you have a valid option key for the specific application module and serial number.

To check for upgrades:

1. Go to the Tektronix Web site (www.tektronix.com).
2. Click **Software Downloads** on left side of the screen to link to the Software Downloads Web page.
3. Enter the product name or model number in the **Search by keyword** field and click **Go**.
4. Scroll through the list and select the appropriate link for your instrument to show more information or to download the software.

The instructions to perform the software upgrade are in the readme.txt file that is part of the software download.

Conventions Used in This Manual

The following icons are used in this manual:


Sequence
Step



Front panel
power



Connect
power



Preventing Personal Injury from Lightning



WARNING. To prevent personal injury from the effects of lightning, exercise the following precautions when using this product:

Before connecting this product to any source

- Check your local weather forecast for the possibility of thunderstorms or lightning.
- If weather conditions could allow thunderstorms or lightning to develop, be sure to visually check the sky and weather conditions in your area frequently.
- If you can hear thunder or if you see lightning, do not connect this product to any source which may be exposed to the effects of lightning.
- Use your own good judgement and common sense. You must protect yourself from the effects of lightning.
- You must assume that hazardous voltages will be present on exposed surfaces of this product if it is connected to a source exposed to lightning. The insulation of this product will not protect you from these hazardous voltages.

Do not connect this product to any source which might be subject to the effects of lightning

If thunderstorms or lightning are in your vicinity:

- When weather conditions that could lead to lightning activity exist in your area, ***you could be at risk of a lightning strike*** before the cloud is close enough for you to hear thunder or see lightning.
- When lightning strikes a structure or facility, current travels through rebar, concrete, pipes, cables, vent stacks, and electrical system.
- Lightning can induce electric and magnetic fields into structures and portions of wiring. The length of a conductor affected by the magnetic field of a lightning strike may exceed two miles.

Be alert and aware of the effects of lightning

- When lightning strikes a conductor, which in turn introduces the current into an area some distance from the ground strike point, equipment can be damaged and personnel injured if they become an indirect path in the completion of the ground circuit.
- Conductors such as the braided shields of cables or unshielded wires will have significant transient currents flowing in them in regions exposed to the electric field effect of lightning.
- Induced voltages may cause breakdown of insulation in wiring at connectors and in electrical components or breakdown of air.

Installation

Carefully unpack your instrument and verify that it includes the standard accessories.

RF Scout Standard Accessories

Accessory	Tektronix part number
NetTek Y400 Analyzer Platform	Y400
NetTek YBT250 Field Transmitter & Interference Tester Application Module	YBT250
AC Power Adapter	119-6984-xx
Lithium-Ion Battery	146-0151-xx
<i>NetTek Y400 Analyzer Setup Reference</i>	071-1430-xx
<i>RF Scout Interference Hunter Quick Start User Manual</i>	071-1901-xx
<i>NetTek YBT250 Field Transmitter Tester/RF Scout Interference Hunter installation software</i> CD-ROM	063-3476-xx

Your instrument may also include optional accessories. Verify that the optional accessories you ordered are included with your instrument. For a current list of accessories, upgrades, and options, including service options, available for your instrument, visit the Tektronix Web site, www.tektronix.com.

Operating Considerations

AC Adapter	Input voltage and current: 100 V - 240 V AC, 1.8 A Input frequency: 47 Hz to 63 Hz Output voltage and current: 24 V DC, 3 A
Dimensions	Height: 25 cm. (9.75 in) Width: 33 cm. (13 in) Depth: 9 cm. (3.5 in)
Weight	5.52 kg (12.125 lbs) (with one battery)
Temperature Range	Operating: 0 °C to +50 °C specified performance, -10 °C to +50 °C typical Nonoperating: -40 °C to +60 °C
Humidity	Operating: 5% to 95% Relative Humidity (RH), noncondensing: up to +30 °C Nonoperating: 5% to 45% Relative Humidity (RH), noncondensing: +30 °C up to +50 °C
Altitude	Operating: Up to 4,600 m (15,092 ft.) Nonoperating: Up to 15,240 m (50,000 ft.)
RF Signal Input	Input frequency range: 30 MHz to 2500 MHz Coupling: AC Input impedance: 50 Ω (nominal) Maximum input power without damaging instrument: 50 W CW or peak envelope power

Cleaning

- Clean the exterior surfaces of the instrument with a dry lint-free cloth or a soft-bristle brush.
- Use a cloth or swab moistened with deionized or distilled water, or a 75% isopropyl alcohol solution for more stubborn stains, to clean the instrument or touch screen; use just enough moisture to dampen the cloth or swab.
- Use a gentle amount of force when cleaning the touch screen.



CAUTION. *Do not get moisture inside the instrument during exterior cleaning.*

Do not wash the front-panel On/Standby switch. Cover the switch while washing the instrument.


Do not spray liquids directly on the instrument or touch screen.

Do not use abrasive cleaners, or chemical cleaning agents that contain benzene, toluene, xylene, acetone, or similar solvents; they can damage the instrument or touch screen. Do not use commercial glass cleaners to clean the touch screen.


Do not scrub the touch screen with excessive force while cleaning.

Connecting the AC Adapter


1. Lift the instrument strap to expose the power adapter connector.
2. Connect the AC power adapter to the instrument.



3. Connect the AC adapter to a properly-grounded AC power source using the provided power cord.



4. Charge the batteries before using the instrument on battery power for the first time. (See page 5, *Charging the Batteries.*)



Charging the Batteries

Charge the batteries before using the instrument on battery power for the first time. Batteries are partially charged and calibrated at the factory. A calibrated battery allows the instrument to more accurately estimate how long the application modules can operate before the instrument automatically powers off. The front-panel BATTERIES charge status indicator turns off when charging is complete.

Approximate charge time

Number of batteries	Instrument powered on	Instrument powered off
1	8 hours	3 hours
2	16 hours	6 hours

NOTE. *These are typical numbers for batteries that are low but not completely discharged. Newer-model instruments can contain higher-capacity batteries, resulting in increased run time and longer charge time.*

For more information on battery charging, battery calibration, and instrument power management, see the instrument Online help: **Start > Help > Tektronix Basics > Power Management.**

Powering On and Off the Instrument, and Functional Verification


1. Tap the **On/Standby** button to power on the instrument.

The instrument WindowsCE Status bar shows the Battery icon when the instrument is operating on battery power and the External Power Connected icon when the instrument is operating with an external adapter.

To power off the instrument, tap the **On/Standby** button again.

For information on the instrument on/standby power modes, see the Online help: **Start > Help > Tektronix Basics > Shutting Down the Instrument.**

2. For functional verification, watch the screen. Verify that the instrument does not display any power-on diagnostic error messages.



Touch Screen Concepts

The instrument user interface is based on touch-screen technology. Instead of using physical button and knob controls to select functions, set values, and take measurements, you tap (touch) virtual controls on the instrument screen. Virtual controls behave the same way as physical controls.


The following are touch screen terms used in this manual:

Term	Description	Equivalent mouse operation
Stylus	The physical object you use to touch the screen. A stylus is either your finger or an appropriate plastic-tipped stylus. Do not use any metal-tipped objects or pens for a stylus, as they can damage the touch screen.	The mouse pointer.
Tap	Touch the screen briefly with the stylus. Selects the item on the screen.	The left mouse button.
Drag	Press gently on the screen with the stylus, drag the stylus to a new position, and then raise the stylus from the screen. Moves an item or selects an area.	Drag (hold down the left mouse button, move the mouse, and then release the button).

Calibrate the Touch Screen

Before using the instrument for the first time, calibrate the touch screen display to respond correctly to your taps.


1. Tap **Start > Settings > Control Panel** to open the Control Panel screen.




2. Double-tap the **Stylus** icon on the Control Panel screen.




3. In the Double-Tap tab, double-tap the checkerboard grid at a comfortable speed with your stylus or finger to set the tap rate.
4. Double-tap the test icon to verify your settings.




5. Tap the **Calibration** tab and read the instructions.
6. Tap the **Recalibrate** button to open the Cursor Position target screen.



7. Follow the target screen instructions. When the position target disappears, touch anywhere on the screen to return to the Calibration tab.



8. Tap **OK** to save calibration settings.




Starting the RF Scout Application

If purchased with preloaded software, RF Scout starts automatically when you power on the instrument. If RF Scout does not start automatically, or you have stopped the application, use either of the following methods to start the application:

- Double-tap the **RF Scout** icon on the instrument screen
- Select **Start > Programs > NetTek > RF Scout**

The instrument opens the RF Scout application. The Microsoft WindowsCE taskbar displays a button for each running application. To bring the RF Scout to the front of the screen, tap the **RF Scout** button in the taskbar.




NOTE. You cannot run RF Scout application at the same time as the YBT250 application. However, you can run RF Scout and the YBA250 application module measurements at the same time as long as you are not measuring Insertion Gain/Loss.


Setting Display Colors

You can change the color scheme used in the instrument display. The color schemes optimize the display colors for use in different environments (outdoors or indoors) and for better printing quality on black and white (monochrome) printers.

1. Select **Tools > Options**.




2. Tap the **Preferences** tab.
3. Tap the **Color Scheme** list field and select a display color scheme.
4. Tap **OK**.
5. Select **File > Exit** to close the application.
6. Restart the application to enable the changed color scheme.




Enabling Signal Standards

Before you begin using the instrument, you must enable (select) the signal standards that you want to measure. You can only take measurements on enabled standards.

1. Select **Tools > Options**.




2. Tap the **Signal Standards** tab.



3. Tap the name of the standard in the **Signal Standards supported** list that you want to enable. Drag the stylus to select two or more contiguous standards.

4. Tap the **Add >>** button to add the selected standard(s) to the **Signal Standards selected** list.
5. Tap **OK**. The enabled standards are now selectable from the main window Signal Standards drop-down list.




NOTE. Limiting the number of enabled standards to just those that you regularly test makes it easier and faster to select a standard from the Signal Standard drop-down list.

Getting Acquainted with Your Instrument


Instrument Elements

1. NetTek Y400 Analyzer Platform.
2. Battery compartment.
3. NetTek YBT250 Application Module.
4. Input/Output ports. (See page 17, *Input/Output Connectors (NetTek Y400 Platform)*.)
5. PCMCIA card ports.
6. Power and Status panel. (See page 16, *Power On/Standby and Status Panel*.)
7. External adapter power connector. (See page 4, *Connecting the AC Adapter*.)
8. Touch screen.




Power On/Standby and Status Panel

1. Power On/Standby button. Push to power on or off the instrument. For more information, access the online help: **Start > Help > Tektronix Basics > Shutting Down the Instrument.**
2. Reset button. Performs a hardware reset; all programs and data loaded into volatile memory are erased. Generally only used to recover from a system lock-up. Use a thin probe to push the reset button.
3. Power/Display status. Green indicates that the instrument is powered on. Amber indicates that the instrument is powered on but the display is turned off (to conserve power).
4. Battery status. Green indicates that the instrument is connected to an external power source and is charging installed batteries. Red indicates a low battery. No color indicates that the batteries are charged.



Input/Output Connectors (NetTek Y400 Platform)


1. Microphone input
2. Headphone jack
3. Ethernet connector (RJ-45)
4. Serial RS-232 connector
5. PS/2 keyboard connector
6. USB Host connector
7. USB Slave connector



See the *Y400 NetTek Analyzer Setup Reference* document (Tektronix part number 071-1430-XX) for more information on the NetTek Y400 Analyzer Platform.

NetTek YBT250 Module Signal Connectors

1. Timing Input. Connects to an external timing reference signal, such as a BTS Even Second Clock signal, or the timing signal from a Tektronix YBGPS1 GPS Timing Reference.
2. Frequency Reference Input. Use an external frequency reference signal to improve measurement accuracy.
3. RF Input. The RF Input connects the RF input signal source or measurement antenna to the instrument.




Microsoft WindowsCE Elements

The Microsoft WindowsCE user interface is similar to other Microsoft Windows operating systems. You use standard Microsoft Windows operations to start (run) applications, select and move objects, and open folders or files. For more Microsoft WindowsCE information, access the online help: **Start > Help > WindowsCE Basics**.

The Status area, located at the bottom right of the screen, contains icons that display important information about the instrument power status. For an explanation of all status area icons, access the online help: **Start > Help > WindowsCE Basics > Understanding Taskbar Icons**.








The User Interface

- 1. Command bar.** (See page 20, *The Command Bar*.)
- 2. Tuning controls.** (See page 21, *The Tuning Controls*.)
- 3. Measurement results.** Shows the waveform displays and measurement results. The appearance of this area changes depending on the selected measurement mode and measurement type.
- 4. External signal status buttons.** (See page 22, *The External Signal Status Buttons*.)
- 5. Measurement mode buttons.** (See page 23, *The Measurement Mode Buttons*.)
- 6. Parameter entry controls.** (See page 24, *The Parameter Entry Controls*.)







The Command Bar

Contains the application menus, as well as buttons for saving measurement results, opening the application setup dialog box, and running/pausing the application.

Element	Description
	Menus. See the Online help topic <i>Menus</i> for information about the menu functions.
	Save Results button. Saves the current measurement acquisition to a file. See the Online help topic <i>The Save & Export Tab</i> for how to set file save parameters.
	Log Measurements button. Enables automatically taking and saving a measurement at specified time intervals. See the Online help topic <i>The Logging Dialog Box</i> for how to set the time interval between measurement acquisitions.
 	Edit button. Opens the Setup dialog box that contains instrument settings tabs. See the Online help topic <i>Setup Tabs</i> for information on the setup dialog tabs. Open button. Shows the Open dialog box that lists saved instrument setup files to load and configure instrument settings. See the Online help topic <i>The Setup Menu Tab</i> for directions on how to switch the button between the Edit and Open modes.
	Run/Pause button. Runs or Pauses the current measurement acquisition.
	Help button. Opens the online help. Online help is context-sensitive and normally displays a help topic related to the current measurement mode or screen. If the current screen is not context-sensitive, the instrument opens the Online help at the main help menu. Use the index, or do a word search, to locate specific information.









The Tuning Controls

Selects the signal standard, signal direction (uplink or downlink), measurement channel, and measurement frequency.

Element	Description
	<p>The Signal Standard drop-down list displays the enabled signal standards from which you select a standard to measure. (See page 12, <i>Enabling Signal Standards</i>.)</p>
	<p>The Downlink and Uplink buttons change the Freq (MHz) setting to the forward link (downlink) or reverse link (uplink) frequency of the current signal standard and channel. For W-CDMA signals, these buttons set the corresponding forward or reverse channel number.</p>
	<p>The Channel button sets the channel number. The field next to the button shows the current channel number. Tapping the button opens the numeric keypad, with which you enter a channel number.</p> <p>The current signal standard defines the available channel numbers. Setting the channel number sets the instrument measurement frequency to the appropriate value for the selected signal standard and up or downlink mode setting.</p>
	<p>The Freq (MHz) button sets the Measurement Frequency. The field next to the button shows the frequency. Tapping the button opens the numeric keypad, with which you enter a frequency value.</p>





The External Signal Status Buttons

Indicates status and sets GPS, measurement reference frequency source, input signal attenuation or amplification values, and PN Sync parameters.

Element	Description
	The GPS status button indicates the GPS signal lock status of an attached GPS receiver. The color indicates the GPS receiver signal lock status. Tap this button to open the GPS setup tab. See the Online topic <i>The GPS Tab</i> for more information.
	The Measurement Reference Frequency status button indicates the measurement frequency reference source. Tap this button to open the Inputs tab. Use this button if you connect an external measurement reference frequency source to the instrument.
	The available measurement reference frequency sources are the internal instrument frequency reference (F INT), an external reference (F EXT), or a GPS-derived timing reference from the Tektronix YBGPS1 GPS Timing Reference (F GPS). See the Online topic <i>The Inputs Tab</i> for more information.
	
	The RF Input Signal Gain/Loss status button shows the external attenuator or amplifier status. Tap this button to open the Inputs tab where you can set the input signal amplification or attenuation values. Use this button if you connect an attenuator or amplifier to the input signal. See the Online topic <i>The Inputs Tab</i> for more information.
	When PN Sync is enabled, the RF Input Signal Gain/Loss status button is replaced with the PN Sync status button. The color indicates the PN Sync availability status. Tap this button to open the PN Sync Settings dialog box. See the Online topic <i>PN Sync</i> for more information.
	
	

The Measurement Mode Buttons

The Measurement Mode buttons select the type of measurement or operation to perform.

Element	Description
	Select the Spectrum Measurements button to take spectrum, spectrogram, signal strength, audio demodulation, and noise floor signal measurements.
	Select the Channel Measurements button to take code power, codogram, EMF, and channel scanner/analyzer measurements.
	Select the iMap Mapping button to open the Map tool and link instrument measurements to a location on a map. Use for graphically recording measurements to help analyze signal characteristics, locate interference, and save measurement/location information.
	Select the Signal Measurements button to take signal measurements including RF power, signal quality, occupied bandwidth, carrier frequency, power vs. time, and others.

The Parameter Entry Controls

The Parameter Entry controls (keypad and knob) let you enter or change numeric values in selected fields. You can use either tool to enter or change a value.

Element


Description



The input control field shows the label for the field and the current value of the selected field or object.



Tap the keypad button to display a keypad in which to enter a value in the selected field. The keypad content changes to show the available entry functions for the selected item.






The knob control lets you scroll through and select from all available values.

1. Drag the knob circle left or right to quickly scroll through all available values and select a value.
2. Tap the arrows on the top half of the knob icon to step the value in large increments. The increment value depends on the value type (channel or frequency).
3. Tap the arrows on the bottom half of the knob icon to step the value in single unit increments.

Getting Help

The application includes a comprehensive Online help system. You access Online help using the following methods:


Online help element	Description
	<p>Help button. Located at the top right of the screen, this button is available all the time. Tap this button to display a help topic that is relevant to the current measurement screen.</p> <p>If the current screen is not context-sensitive, the application opens the Online help at the main help menu. Use the index link, or do a word search, to locate specific information.</p>
	<p>Help link text. On measurement screens, underlined blue text is help link text. Bold help link text at the top of a measurement screen opens a topic describing how to take that measurement. Help link text that is located next to a measurement or setting opens a topic relevant to that particular measurement or setting.</p>
<p>Contents Index</p>	<p>Online help Content and Index links. Every Online help topic includes a Contents and Index link. If the topic does not contain the information you were seeking, use these links to locate specific information.</p>
	<p>Tab or dialog box help button. This button is displayed at the bottom of many setup tabs or dialog boxes, and opens an Online help topic relevant to that tab or dialog box.</p>

Operating Basics


Setting Up to Take a Measurement

Perform the following steps to set up the instrument to take a measurement. These steps apply for most types of measurements.

1. Connect a signal to the instrument.
2. Tap the **Signal Standard List** arrow button to open the signal standard list.
3. Tap a signal standard to select it. This signal standard is used for measurements until you change to a different signal standard. (See page 12, *Enabling Signal Standards*.)




4. Tap the appropriate signal **Uplink** or **Downlink** button for the measurement that you are taking.




Entering a Channel:

NOTE. You only need to enter a channel or a frequency; you do not need to enter both values.

5. Tap the **Channel** button to open the keypad.




6. Enter a channel number.
7. You can also tap the **List** button to display a list of available channels from which to select a value. Channel numbers are defined by the current signal standard.
If there is a corresponding frequency for the entered channel number, the instrument displays that frequency in the Freq (MHz) field.
If you enter a channel number outside the valid range, the instrument sets the channel number to the closest valid number.
8. Tap **OK** to close the keypad or channel list and set the channel value.



Entering a Frequency:

NOTE. You only need to enter a channel or a frequency; you do not need to enter both values.


9. Tap the **Freq (MHz)** button to open the keypad.



10. Use the keypad to enter a frequency value. This sets the center frequency of the measurement.


If there is a corresponding channel number for the entered frequency, the instrument displays that channel number in the Channel field.

11. Tap a frequency unit button (such as GHz or MHz) to close the keypad and set the frequency value.




Selecting a Measurement Mode:

- 12. Tap a measurement mode button. (See page 23, *The Measurement Mode Buttons*.)
- 13. For Spectrum and Channel measurements, select the tab of the measurement that you want to take.



2409-036


- 14. For Signal measurements, tap the **Select Measurement** button, then tap the measurement that you want to take.



2408-038

Setting Additional Measurement Parameters:


15. Tap the **Edit** button to open the **Setup** dialog box.
16. Tap the tab of the measurement parameters that you want to set.
17. Select or enter the measurement parameter values.
18. Tap **OK** to close the Setup dialog box and enable the measurement parameter settings.




Spectrum Measurements

Displaying a Spectrum Waveform


1. Set the instrument to measure a signal of interest. (See page 26, *Setting Up to Take a Measurement.*)



2. Tap the **Spectrum Measurement** button.




3. Tap the **Spectrum** tab.




4. Tap the **AutoLevel** button.



- Set spectrum display parameters. Available spectrum parameters include the frequency span, resolution bandwidth (RBW), signal attenuation value, graph reference and division values, start and stop frequencies, and marker positions.



6. For example, to change the graph reference and division values, tap the **Ref Lvl** field or the **Vertical Scale** field to select it.
7. Use the Parameter Entry controls to enter or change the scale setting.
8. Use Markers to take measurements on a waveform. (See page 34, *Spectrum Waveform Markers*.)



NOTE. Tap the **Edit** button to open the **Setup** dialog box and set additional measurement parameters. Available parameters depend on the current signal standard and measurement type. Not all measurements have setup parameters.

Spectrum Waveform Markers


Markers are visual icons that you position on a spectrum waveform to measure signal frequency and level values. You use the markers to measure the value at a particular point on a waveform (Absolute Marker Values), or measure the difference between two markers (Delta Marker Values). The markers follow the waveform level changes.

Each marker icon has an associated marker readout, displayed at the bottom of the Spectrum display. The marker readout shows the marker icon symbol, the marker name, and the frequency and level values for the marker.

There are a maximum of seven markers available; the Trace marker (Tra), and M1 through M6. The Tra marker changes the measurement frequency to the location you select on the waveform. The M1 through M6 markers read the waveform frequency and level at the location they are placed. Tra, M1, and M2 markers are shown by default.

Turning Markers On and Off.

1. Tap **View**.
2. Tap **Markers** to turn marker display on or off.



1901-018



Selecting Which Marker Readouts to Display.

1. Select **View > Marker Setup...** to display the **Markers** dialog box.
2. Tap to enable or disable individual markers and set the marker mode:



On enables or disables the selected marker.

Front Trace places the marker on the front trace.


Trace 1 and **Trace 2** keep the marker on the specified trace regardless of which trace is in front. Use this mode to compare two waveform traces.



3. Tap **OK**. The instrument shows the center frequency readout plus three marker readouts at a time (in Absolute Marker Readouts mode) or the center frequency readout plus two marker readouts at a time (in Delta Marker Readouts mode).




4. Tap the marker readout scroll buttons to scroll through the enabled marker readouts.




Setting the Marker Measurement Mode.

1. Tap **View**.
2. Tap **Delta Marker Readouts** to enable marker readouts to display the difference (delta) between the frequency and level values at marker M1 and the other markers. While in Delta Marker Readouts mode, all marker readouts are relative to marker M1.
3. Tap **Absolute Marker Readouts** to enable marker readouts to display the actual frequency and level values of the signal at the marker position on the waveform.




Add or Move a Marker on a Waveform.

1. Tap **View**.
2. Tap **Measurement Frequency Cursor**.



3. Tap the marker readout of the marker that you want to add or move on the spectrum waveform. The marker readout border darkens to indicate that it is selected.
4. Tap the waveform where you want to add or move the marker. The marker is placed on the waveform and the readout shows the signal values at the new location.
5. Use the Parameter Entry controls to fine-tune the position of the marker on the waveform.




Comparing Spectrum Waveforms (Traces)

You can compare two live waveforms (derived from the single RF input signal), the RF input waveform and a saved waveform, or two saved waveforms.


Selecting Waveform Traces.

1. Tap the **Traces** button to toggle between **Trace 1** and **Trace 2**.




Comparing Live and Saved Waveform Traces.

1. Set the instrument Spectrum parameters to display the waveform of interest. (See page 31, *Spectrum Measurements*.)
2. Tap the **Traces** button to select **Trace 1**.
3. Tap the **Trace 1** list button and then tap a trace type to select it. The instrument applies the selected operation to the input signal and displays the results as the trace 1 waveform.
4. Tap the **Traces** button to select **Trace 2**.



5. Tap the **Trace 2** list button and then tap a trace type to select it. The instrument applies the selected operation to the input signal and displays the results as the trace 2 waveform.

The figure shows Trace 1 as an **Normal** waveform and Trace 2 as a **Min Hold** waveform. You can use markers to make measurements between the waveforms.




6. To compare a saved waveform to a live waveform, tap the **Trace 2** list button and then **Saved**. The instrument opens the **Trace 2 & Mask** setup tab.

7. Tap **Saved Trace**.

8. Tap the **Browse** button to navigate to and select the saved waveform to open.

9. Tap **OK**. The instrument displays the saved waveform as the Trace 2 waveform.




NOTE. The current instrument measurement settings must match the instrument settings used to capture the saved waveform in order to compare both waveforms.


Comparing Two Saved Waveform Traces.

NOTE. Waveform traces are saved with the settings in effect at the time the trace is saved. When a saved trace is displayed, the stored settings values are shown for reference, though no actual instrument settings change. As soon as you tap the **Run** button to return to making new acquisitions, the display settings are restored to what they were before the saved trace was opened.

1. Select **File > Compare Saved**.
2. Navigate to and select the first waveform file to load.
3. Tap **OK** to open the **Select second result file to compare** dialog box (it looks exactly the same as the first dialog box).




4. Navigate to and select the second waveform file to load.
5. Tap **OK** to enter the second file and close the dialog box. The instrument displays both waveforms.
6. After viewing the waveforms, tap the **Run** button to return the instrument to taking measurements.




Display a Spectrogram

A spectrogram shows how the signal level changes over time. It can be very useful in identifying intermittent signals.

1. Set the instrument to display the spectrum waveform of interest. (See page 31, *Displaying a Spectrum Waveform*.)
2. Tap the **Spectrogram** tab.
3. Tap the **Updates** button to display a dialog box where you can change the spectrogram measurement update rate, and enable automatic saving of data when a screen is full (80 data record acquisitions).
4. The Data Record readout shows the time and date stamp of the spectrogram record located at the record cursor (white horizontal line). To change the record cursor position, tap the Data Record field and use the keypad or knob to move the record cursor.





5. Tap the Split Screen button to switch between a full-screen spectrogram display and a split spectrum and spectrogram display.




Locating a Signal

1. Connect a directional antenna to the instrument.
2. Set the instrument to display the spectrum waveform of interest. (See page 31, *Displaying a Spectrum Waveform*.)
3. Tap the **Strength** tab.
4. Tap the trace of the interfering signal to set the measurement frequency. You can use the keypad or knob to adjust the measurement frequency.
5. Point the directional antenna in different directions. As you change the direction of the antenna, the audible tone and beep (if selected), and the Strength bar graph change to indicate signal strength. The signal of interest is located in the direction that results in the strongest signal.
6. Tap **Fast Update** to improve audio tone response, at the expense of a reduced screen update rate.



Listening to a Signal



1. Set the instrument to display the spectrum waveform of interest. (See page 31, *Displaying a Spectrum Waveform*.)
2. Tap the **Audio** tab.
3. Tap the trace of the interfering signal to set the measurement frequency. You can use the keypad or knob to adjust the measurement frequency.
4. Tap the different **Demodulation** types and listen to the resultant audio (if any). A station ID can be particularly helpful when the interfering signal is a radio or broadcast television station. You may also be able to discriminate between possible sources by listening to the characteristic sounds of paging, video, control signals or the harmonics of other common signals.



Taking a Noise Floor Measurement

Noise floor measures all the RF Power coming into the receive antenna within the frequency band of the selected channel. The noise floor is the power integrated across the selected channel. To make an accurate measurement, you must measure the noise floor on a disabled channel (a channel that is not carrying live traffic).

1. Connect a signal from a BTS receiver test port to the instrument.
2. Set the instrument to display the spectrum waveform of interest. (See page 31, *Displaying a Spectrum Waveform*.)
3. Tap the **Reverse** (up) link button.
4. Tap the **Noise** tab.
5. Tap the trace of the interfering signal to set the measurement frequency. You can use the keypad or knob to adjust the measurement frequency.



Channel Measurements Mode

Channel measurements mode includes measurements for Code Power, Codograms, EMF, Channel scanners, and Scrambling Code Analyzers. Code Power and Codogram are also available in the Signal measurements.


Taking a Channel Measurement

The following procedure assumes that you have already set up the measurement. (See page 26, *Setting Up to Take a Measurement.*)


1. Tap the **Channel Measurement** button.




2. Tap the tab of the measurement that you want to take. The active signal standard determines the available measurements.



3. Tap available measurement parameters and use the Parameter Entry controls to set measurement parameter values.




4. Tap the **Edit** button to open the **Setup** dialog box and set additional measurement parameters in the dialog box tabs. Available parameters depend on the current signal standard and measurement type. Not all measurements have setup parameters.




Scanner Tadd/Tdrop Markers

Tadd and Tdrop are horizontal markers that you can set on 1xEV-DO and cdma2000 PN Scanner measurements to visually indicate add or drop signal power levels. Using these markers lets you quickly identify PN codes that are within defined add or drop ranges. The Tadd/Tdrop horizontal markers are visual aids only, and do not cause the instrument to display warnings when signals are above or below the set levels.

1. Select **View > PN Scanner Tadd/Trop Markers** to display the markers on the scanner measurement graph.



2. Tap the Tadd or Tdrop readout and use the keypad or knob control to change the marker level value.




See the Online help topic *Take a Scan Measurement* for information on scanner measurements.

Custom Scanner Code Labels

The Scanner Code Label Editor lets you add unique labels to the graphs of 1xEV-DO/cdma2000 PN offset and W-CDMA scrambling code scanners. Once you have created labels, tapping a bar graph of a PN offset or scrambling code displays the label assigned to that PN offset or scrambling code, directly below the graph. Using labels lets you quickly identify the source of a particular code.

1. Select **View > PN Offset Labels** or **View > Scrambling Code Labels** to enable viewing scanner labels on the scanner measurement graph.
2. Tap a bar graph plot to display the custom label assigned to that PN offset or scrambling code.



See the Online help topic *Scanner Code Labels Overview* for information on creating, saving and using custom scanner code labels.

iMap Measurement Mapping Mode


iMap integrates interference mapping, coverage mapping, in-building mapping, outdoor mapping, and provides an integrated solution for field interference and coverage problems in one instrument.

Using iMap is as easy as selecting a measurement and touching the displayed map where you want the measurement to be placed. Measurement icons are color coded to indicate if the measurements have passed or failed limit tests. You can also add a direction arrow to a measurement to indicate the direction the antenna was pointing when you took a measurement.

You can load scanned bitmap files as maps for in-building mapping, or use GSF and MIF map file formats for outdoor maps. Using GSF or MIF map files lets you use a connected GPS receiver (such as the Tektronix YBGPS1 GPS Timing Reference) to automatically place measurements at your current location.

You can save maps and associated measurement results data to common file formats such as CSV or MapInfo. Saving maps and measurement results lets you analyze measurement data (position, value, and direction) and prepare reports to help resolve interference problems.

1. To start the iMap tool, tap the **iMap** button. When you open the iMap tool for the first time, the screen displays the message **No map loaded**. Otherwise, iMap displays the last-loaded map.



Map File Concepts

The iMap tool uses two types of maps; Grid and Image.

Grid Maps. Grid maps have geophysical latitude and longitude coordinate references embedded in the map file. RF Scout uses grid maps, along with an active GPS receiver, to place measurements on a map at your current geophysical position. Grid maps require specialized PC software to create or can be purchased from map-creating companies. RF Scout can load both GSF- and MIF-format grid map files. You need to convert non-GSF or MIF grid maps to GSF format before you can load them into the iMap tool. (See page 69, *Converting Map File Formats to GSF.*)

Grid maps require an active GPS receiver to correctly link measurements to geophysical map locations. An active GPS receiver is a receiver that is locked to four or more satellite signals and is providing the RF Scout with accurate GPS location data. If you load a grid map and a GPS receiver is either not connected or does not have a good satellite signal lock, the instrument considers the grid map as an image map.

Image Maps. Image maps do not have any geophysical latitude and longitude references embedded in the map file. An image map is a bitmap picture, such as a scanned building floor plan or aerial photograph, to which you can attach measurements. Save the file to 256-color bitmap format. The iMap Converter, a program that is included with the PC version of the RF Scout application, lets you convert image maps to GSF format map files, as well as convert image maps to grid maps.(See page 71, *Adding Coordinates to an Image (Bitmap) File.*)

NOTE. *Image (bitmap) files that you convert to GSF-format load faster on the RF Scout because the instrument does not have to convert the bitmap to GSF before loading. However, it is then possible to confuse image GSF maps with grid (coordinate) GSF files. Use a file-naming convention to differentiate between GSF maps that were created from coordinate maps and GSF maps that were created from bitmap files but do not contain coordinate information.*

Loading a Map into RF Scout

You need to load a map before you can use the RF Scout iMap tool.


1. With iMap open, select **File > Load Map**.
2. Navigate to and select the map file to load (Bitmap, GSF or MIF format).
3. Tap **Open**. The iMap application loads the map on the screen.




Mapping a Measurement

The following procedure requires that you have already set up the measurement. (See page 26, *Setting Up to Take a Measurement.*) You must have also loaded a map file. (See page 55, *Loading a Map into RF Scout.*)

1. Tap the **Single Measurement** button.




2. Tap an iMap measurement button. Available measurements depend on the current signal standard. The selected measurement is displayed in the Measurement Thumbnail area.



3. Tap the map:

- If a connected GPS receiver is active, and you are using a grid map, a single measurement is placed at the current GPS latitude and longitude coordinates.
- If a GPS receiver is not active, or if you are using an image map (such as a building floor plan), a single measurement is placed where you tapped the map.

- ### 4. You can select a different measurement button, and then tap the map to add a new measurement to the map. Multiple measurement icons at the same location stack on top of each other.



5. To move an icon, tap the **Select** button and then touch and drag the icon to a new position. If the measurement was part of a stack of measurements (such as measurements created by a macro), then iMap moves the topmost icon in the stack. If the icon is moved to a new stack of measurements, then the icon is placed in the stack in time-of-measurement order.



NOTE. To add measurements at a new location on a grid map with an active GPS receiver, you must physically move to the new location.

NOTE. You can move measurement icons on an image map, or on a grid map with the GPS receiver inactive. Attempting to move an icon on a grid map with an active GPS receiver causes iMap to drag the map and its measurement icons to a new position on the screen; the measurement icons are not moved.

When a GPS receiver is not active, you can move any measurement icon. This includes moving measurement icons that were placed on the map while in GPS mode. iMap does not reposition moved GPS-related measurement icons back to their original geographical position on a map when the GPS receiver is active.

iMap Measurement Icons

The iMap application uses icons on the map to represent a measurement taken at that location. There are three types of measurement icons: large, small, and flag. The large and small icons have individual icon graphics for each measurement type that they represent. The flag icon is a simple small flag, and is used for all measurement types. See the RF Scout Online help topic *iMap Measurement Map Icon Types* for more information.

To select which type of measurement icon to display on a map, tap the **View** menu item and select the icon type to use. All current icons on the map are changed to the selected icon type.


You can set the measurement icons to color their border to indicate the signal or measurement range value (from Best to Unacceptable). Setting the icon border color lets you quickly evaluate the relative value of a measurement. To set icon color ranges, tap **Tools > iMap Measurement Settings**. See the RF Scout Online help topic *Setting The iMap Measurement Icon Colors* for more information.

You can perform various actions on measurement icons, including view the measurement results of an icon, move the icon, delete the icon, and attach a measurement direction arrow to an icon. See the following sections, and the RF Scout Online help topic *View Map Measurements*, for more information.

Viewing and Deleting Icon Measurements

To view or delete the measurement results associated with an iMap measurement icon:

1. Tap the iMap **Select** mode button.
2. Tap a measurement icon to open the **Map Measurements** dialog box.
3. Tap the measurement of interest in the list.
4. Tap **Open** to open the measurement screen for the selected measurement. Then tap the iMap button to return to the iMap screen.
5. To delete the selected measurement, tap the **Delete** button. If there are multiple measurements that you want to delete, repeatedly tap **Delete**.
6. Tap **OK** to close the dialog box.



NOTE. You can also double-tap on a measurement icon to open the measurement window for that measurement. If there are multiple measurements at a location, double-tapping an icon displays the results for the measurement icon that is at the top of the list.


To delete all the measurement icons from a map, select **File > Clear All Measurements**.

Measurement Direction Arrows


The iMap direction arrow function lets you draw an arrow on a mapped measurement icon. You can use the arrow to indicate the direction your antenna was pointing when you took a measurement.

Draw a Measurement Direction Arrow.


1. Tap the **Measurement Direction** button.



2. Tap and drag from the center of a measurement icon in the direction the antenna was pointing when the measurement was made. iMap draws an arrow from the measurement icon.




3. To change the arrow direction, draw a new line. iMap replaces the existing arrow with the new direction arrow.




Delete a Direction Arrow.


1. Tap the iMap **Select** mode button.



2. Single-tap the measurement icon with the direction arrow to delete. iMap opens the **Map Measurements** dialog box.



3. Tap the measurement name that has the direction arrow to delete.
4. Tap the **Remove Arrow** button.
5. Tap **OK**. iMap closes the dialog box and deletes the direction arrow.




Logging iMap Measurements (Automatic Measurements)

Logging measurements lets you automatically map a single measurement at a set time interval or change in GPS position (with active GPS receiver and a grid map).

NOTE. The iMap tool only maps completed measurement results. If the specified time interval is less than that required to take a measurement, iMap ignores the specified time interval and maps results as soon as the measurement acquisition is done. For example, if the instrument requires 20 seconds to take a measurement, but the time interval is set to 10 seconds, then the instrument maps results every 20 seconds.


1. Tap a measurement button. Available measurements depend on the current signal standard.



2. Tap the **Log Measurements** button.




3. Select the type of repeat measurement to take (time interval or distance between measurement positions).
4. Tap **OK** to return to the mapping screen.




5. Tap the map to start logging measurements:

- For grid maps with an active GPS receiver, tap the map at any point. The instrument begins adding measurement flags to the map at the current GPS position.
- For image maps or for grid maps without an active GPS receiver, tap the map at the measurement starting location. The instrument begins taking measurements, but does not display them on the map until measurement logging is done.



6. Tap the map to stop measurements:

- For grid maps with an active GPS receiver, tap the map at any position.
- For image maps or grid maps without an active GPS receiver, tap the map at the position the last measurement was taken. Measurements are then evenly spaced on a straight line between the start and stop map points.



7. Tap the **Single Measurement** or the **Select** button to exit the logging measurements mode.



NOTE. The iMap Log measurements function automatically sets the map view measurements mode to **Measurement Flags** during logging measurement acquisition. When iMap measurement logging is done, the instrument restores the map view measurements mode to the mode it was at before the iMap measurement logging was initiated.

If you tap the **Select**, **Measurement Direction**, or **Single Measurement** button while logging measurements in non-GPS mode, iMap cancels the log measurements mode and does not draw any measurement icons on the map.

Grid maps with an active GPS receiver support logging measurements by time interval or distance change interval. Image maps, or grid maps with an inactive GPS receiver, support logging measurements by time intervals.

You cannot place a measurement icon on any area of the map that is covered by a message banner or by the zoom and pan controls.

iMap Measurement Macros

iMap has the capability to use a macro file to take a set of sequential measurements with one operation, instead of selecting and running individual measurements one at a time. Each macro file measurement can be unique, including measurements for different channels, measurement settings, and signal standards. You create a macro file by using the iMap Macro Editor tool. You then load the macro file into the instrument, and enable the macro to run with the **Macro** button on the iMap tool bar.

To open the iMap Macro Editor, select **Tools > iMap Macro Editor**. See the RF Scout Online help topic *Mapping Measurements Using Macros* for complete information on creating, saving, loading, and running iMap measurement macros.

The iMap Map Converter Program

RF Scout includes a map file conversion program that is installed at the same time as the RF Scout PC Simulator. The iMap Converter program:

- Converts industry-standard MapInfo Interchange Format (.mif), ArcInfo Shape (.shp), USGS Digital Line Graph (.opt) geographic coordinate maps, and 256-color bitmap images (.bmp), into GSF-format files for use with RF Scout.
- Combines multiple coordinate map files into a single map.
- Lets you add geographic coordinate information to bitmap image files, effectively converting image maps to grid maps.
- Recognizes world files associated with an image file, and automatically creates a grid map with coordinates when you load an image map file that has an associated world file.


See the RF Scout Online help topic *Map File Concepts* for more information on converting map files.

NOTE. *Bitmap files that are converted to GSF-format load faster on the RF Scout because the instrument does not have to do the bitmap-to-GSF conversion in the instrument. However, it is then possible to confuse image GSF maps with grid (coordinate) GSF files. Use a file naming convention to differentiate between GSF maps created from coordinate maps and GSF maps created from bitmap files that do not have coordinate information.*


The MIF-format files take significantly longer to load than the GSF-format files. Tektronix recommends that you use iMap Converter to convert MIF map files to GSF map files, rather than loading MIF files directly on the instrument.

Converting Map File Formats to GSF.


1. On the PC, select **Start > Programs > NetTek > iMap Converter**.




2. Click the **Open Map(s)** button to load grid (coordinate) or Bitmap (image) map files.



3. Use the dialog box to navigate to and select one or more grid map files or a single bitmap file.
4. Click **Open**. The iMap Converter loads the file, converts the data, and displays the resulting map.





5. Click the **Save for NetTek** button.
6. Use the dialog box to enter a map name and navigate to the location to save the GSF-format map file.
7. Click **Save** to save the file.



NOTE. The iMap Converter program saves all files as GSF-format. This includes bitmap files that you convert to GSF-format to reduce the map file size and loading time. Therefore it is possible to have GSF-format maps that are not grid (coordinate) maps. Use a file naming convention to differentiate between GSF maps created from coordinate maps and GSF maps created from bitmap files to which you have not added coordinates.

Adding Coordinates to an Image (Bitmap) File. The iMap Converter lets you add geographic coordinate information to an image (bitmap) map file, effectively converting it to a grid map. This feature lets you convert building or floor plan diagrams, saved images from road map programs, or photographs (such as aerial photographs) to grid (coordinate) maps for use with RF Scout GPS measurement mapping.


There are two ways to manually add coordinates to an image file:

Element	Description
 <p data-bbox="261 644 417 668">Set Coordinates</p>	<p data-bbox="448 554 1498 639">Set Coordinates (two points) lets you enter the latitude and longitude of two points that you select on the image file. The iMap Converter uses those two points to add coordinate information for the entire image map, extrapolating the coordinates for any map area that is outside of the defined two points.</p>
 <p data-bbox="261 785 417 808">Set Coordinates</p>	<p data-bbox="448 694 1498 747">Set Coordinates (image edges) lets you enter the latitude and longitude of the edges of the image file. iMap Converter uses these points to add coordinate information to the entire image map.</p>

NOTE. Image maps to which you plan to add coordinate information must have true North as the top edge of the image.

To Add Coordinates to an Image Map.

1. Load an image (bitmap) map file into the iMap Converter program.
2. Click on the two point or edges **Set Coordinates** button, depending on how you want to enter the coordinate information. This example uses the Set Coordinates (image edges) button.
3. Set the coordinate system to either Degrees or Decimal.
4. Enter the map edge coordinates in the dialog box.
5. Click **OK**.
6. Click **Save for NetTek** to save the converted map file.





Signal Measurements


Taking a Signal Measurement

Signal measurements include RF channel power, peak/average, carrier frequency, occupied bandwidth, signal quality, code power, codograms, and pilot power. Available measurements depend on the current signal standard.


- 1. Set the instrument to measure a signal of interest. (See page 26, *Setting Up to Take a Measurement.*)
- 2. Tap the **Signal Measurement** button.
- 3. Tap the **Select Measurement** button to open the **Select Signal Standard and Measurement** dialog box.
- 4. Tap the measurement button for which you want to take measurements. The instrument opens the selected measurement screen.



- Make any necessary setting changes on the measurement screen (if available). For example, the cdma2000 Signal Quality measurement lets you select the signal type to use for measuring Signal Quality (Pilot only or Auto detect active codes).



- Tap the **Edit** button to open the **Setup** dialog box and set additional measurement parameters in the dialog box tabs. Available parameters depend on the current signal standard and measurement type. Not all measurements have setup parameters.



Specifications

This section lists the electrical, environmental, and physical specifications of the RF Scout Interference Hunter. All specifications are guaranteed unless labeled “typical”. Typical specifications are provided for your convenience and are not guaranteed.

Table 1: General characteristics

Characteristic	Description
RF Input	
Input Frequency Range	30 MHz – 2500 MHz
Input Impedance	50 ohms (nominal)
Signal Amplitude for Modulation Measurements	–50 dBm to +30 dBm for CW-like or peak envelope power Measurements may be outside this range but accuracy is not guaranteed
Signal Amplitude for Spectral Display, typical	CW or peak envelope power: –144 dBm to +30 dBm, 200 MHz to 2.0 GHz –142 dBm to +30 dBm, 2.0 GHz to 2.2 GHz –139 dBm to +30 dBm, 2.2 GHz to 2.5 GHz Levels apply when using 100 Hz resolution bandwidth
Input Overload Detect	>1 W (+30 dBm) CW or peak envelope power
Maximum Input Power without Damaging Instrument	50 W CW or peak envelope power
Coupling	AC for all measurements and spectral display modes

Table 1: General characteristics (cont.)

Characteristic	Description
Maximum Working Voltage	15 V (DC + peak AC)
Spurious Input Signals	To meet modulation measurement specifications: (Total power of interest - Total power in spurious) > 35 dB or Center frequency of signal of interest - center frequency of spurious signal > 1.4 MHz and (Total power of interest - Total power in all spurious) \geq -3 dB
Frequency Reference Input	
Impedance	50 ohms (nominal)
Frequency Range	Any multiple of 1 MHz up to 15 MHz inclusive, \pm 1 ppm Any multiple of 1.2288 MHz up to 19.6608 MHz inclusive, \pm 1 ppm 2.048 MHz \pm 1 ppm 4.8 MHz \pm 1 ppm
Level Range	-15 dBm to +15 dBm
Maximum Input Level without Damage	\pm 3 V peak continuous
Coupling	AC
Working Voltage	3 V (DC + peak AC)

Table 1: General characteristics (cont.)

Characteristic	Description
Lock Time	< 15 seconds
Timing Input	
Impedance	10 k Ω
Minimum High Threshold	2.0 V
Maximum Low Threshold	0.8 V
Minimum High Time	10 ns
Minimum Low Time	10 ns
Maximum Input Level without Damage	\pm 5 V peak continuous
Coupling	DC
Timing Error	\pm 10 ppm
Internal Time Base Characteristics	

Table 1: General characteristics (cont.)

Characteristic	Description
Error	<p>± 0.5 ppm drift from 0 °C to 50 °C</p> <p>± 1.0 ppm aging/year</p> <p>Ten minute warm-up period required to meet accuracy specification.</p> <p>Users can connect the External Reference input to a frequency source and obtain a user correction value. This value will be used to correct time base errors in measurements to the accuracy of the external reference. The internal time base will continue to drift with temperature and age as specified above.</p>
Signal Path Characteristics	
Phase Noise	≤ -75 dBc/Hz @ 20 kHz carrier offset
Noise Figure	<p>1 kHz resolution bandwidth:</p> <p>≤ 10 dB, 200 MHz to 2000 MHz</p> <p>≤ 12 dB typical, 2000 MHz to 2200 MHz</p> <p>≤ 15 dB typical, 2200 MHz to 2500 MHz</p>
Displayed Average Noise Level (DANL), typical	<p>10 Hz RBW: -152 dBm, 200 MHz to 2000 MHz</p> <p>100 Hz RBW: -145 dBm, 200 MHz to 2000 MHz</p> <p>1 kHz RBW: -135 dBm, 200 MHz to 2000 MHz</p>

Table 2: Measurement characteristics

Measurement	Description
External Attenuation	User Selectable ON/OFF Attenuation = -30 dB to +80 dB
Code Domain Power (cdmaOne, cdma2000, W-CDMA)	Measures the power in each of the Walsh codes (64 in cdmaOne, 128 in cdma2000) used in a CDMA signal. Measures the power in each of (up to 512) OVSF codes used in a W-CDMA signal.
Units	dB relative to Pilot Power or Total Power
Resolution	0.1 dB
Accuracy	cdmaOne and cdma2000: ± 1 dB code domain power level > -20 dB relative to total power, using the recommended TIA/EIA-IS-97-D pilot level of -7.0 dB (20%) relative to total power. W-CDMA: ± 1 dB Code domain power level > -20 dB relative to total power, using W-CDMA 3GPP Test Model 3. Reference information: ± 2.5 dB for -27 dB $< \text{CDP} < -20$ dB relative to total power in band classes 0-6 (cdmaOne, cdma2000). ± 2.5 dB for -27 dB $< \text{CDP} < -20$ dB relative to total power (W-CDMA).

Table 3: Spectral analysis

Characteristic	Description
Measurement Frequency	Sets the measurement frequency of the display. The measurement frequency can be set by either entering a specific frequency or by selecting a channel number.
Units	MegaHertz (MHz) or Channel Number
Resolution	1 kHz 1 channel
Range	30 MHz to 2500 MHz
Frequency Span	Sets the frequency range covered by the spectral display.
Units	kiloHertz (kHz), MegaHertz (MHz)
Resolution	1 kHz
Range	10 kHz to 2470 MHz, continuously variable or 1-2-5 steps
Resolution Bandwidth (RBW)	Width of the resolution bandwidth filter
Units	Hertz (Hz), kiloHertz (kHz), MegaHertz (MHz)
Resolution	Uses 1-3 steps to cover the range
Range	10 Hz to 6 MHz
	When in Auto mode, the instrument automatically sets the RBW. The RBW is set as a combination of 1-3 steps at the 1, 2, 5 span settings, and a linear range between 1, 2, 5 span settings, for a nominal value of approximately Span/125.
Reference Level	The power level indicated by the top line of the spectral display
Units	dBm

Table 3: Spectral analysis (cont.)

Characteristic	Description
Resolution	1 dBm
Range	-100 dBm to +30 dBm
Spectral Display Amplitude	
Units	dB relative to Reference Level
Resolution	0.1 dB
Accuracy	± 1.25 dB, -20 dBm to +30 dBm ± 2.0 dB, -80 dBm to -20 dBm ± 2.75 dB, -120 dBm to -80 dBm ± 5 dB -134 dBm < Input < -120 dBm, typical
Accuracy specifications apply only for spans less than 1000 MHz and to CW-like signals.	
Vertical Scale Factor	
Units	1 dB to 10 dB in 1 dB increments

Table 3: Spectral analysis (cont.)

Characteristic	Description
Display Modes	<p>Normal: updates display with each new result</p> <p>Max Hold: updates displayed point only if new point > old point</p> <p>Min Hold: updates displayed point only if new point < old point</p> <p>Max/Min Hold: displays a bar between Max Hold and Min Hold</p> <p>Average: displays average of N (specified by user) results</p> <p>Reference information: Average is calculated as follows: The last N values are saved in memory; when a new result is available, the earliest result of the N stored values is discarded, the new average is calculated from the stored values. If the number of results is less than N, then all of the results are averaged together.</p>
Number of Averages	$1 \leq N \leq 99$
Spurious Free Dynamic Range (external signal related)	<p>IM3 better than -70 dBc typical, 100 MHz to 2500 MHz</p> <p>2nd Harmonic better than -60 dBc, typical</p>
Residual Spurious Signals	<p>-125 dBm at BTS Rx frequencies (776-794, 806-849, 872-940, 1453-1465, 1525-1549, 1710-1785, 1840-1910, 1920-1980) MHz and GPS frequencies (L1 1570.3-1580.5, L2 1222.5-1232.8, L5 1171.4-1181.6) MHz</p> <p>-115 dBm at BTS Tx frequencies (746-764, 832-834, 840-960, 1477-1513, 1805-1880, 1930-1990, 2110-2170) MHz</p> <p>-95 dBm at frequencies not listed above, except from 1155-1168 MHz: -20 dBm in spans above 10 MHz, 1155 MHz-1175 MHz</p>

Table 4: Interference analysis characteristics

Characteristic	Description
Noise Floor Measurement	Measures the interference power that is coming into the receiver antenna for any standard. Measurement defaults to uplink channel when specified by channel number.
Units	dBm
Resolution	0.1 dB
Accuracy	± 3 dB typical
AM Demodulation	Provides an audio output signal after AM demodulation of the user-selected signal to use for identifying a signal.
Measurement Frequency	30 MHz to 2500 MHz with 1 kHz resolution
Input Signal Level	-100 dBm minimum
Measurement Bandwidth	8 kHz
Audio Output Bandwidth	4 kHz
Run Time	4 seconds per activation
FM Demodulation	Provides an audio output signal after FM demodulation of the user-selected signal to use for identifying a signal.
Measurement Frequency	30 MHz to 2500 MHz with 1 kHz resolution

Table 4: Interference analysis characteristics (cont.)

Characteristic	Description
Input Signal Level	-100 dBm minimum
Maximum Signal Deviation	Up to 100 kHz
Measurement Bandwidth	8 kHz, 15 kHz, 75 kHz, 200 kHz; selected by user
Audio Output Bandwidth	4 kHz for Measurement BW = 8 kHz, 15 kHz 15 kHz for Measurement BW = 75 kHz, 200 kHz
Run Time	4 seconds per activation
Signal Strength Indicator	Provides an audio tone and a visual display that vary with the strength of the selected signal.
Measurement Frequency	30 MHz to 2500 MHz with 1 kHz resolution
Input Signal Level	-110 dBm minimum

Table 4: Interference analysis characteristics (cont.)

Characteristic	Description
Measurement Bandwidth	Up to 10 MHz, dependent on span setting
Tone Type	Variable beep rate, based on signal strength Variable frequency tone, based on signal strength

Table 5: Scanner characteristics

Characteristic	Description
W-CDMA Scrambling Code Analyzer	Detects scrambling codes and pilot channel power levels of received co-channel W-CDMA downlink signals.
Input Signal Range	-117 to +30 dBm, typical
Units and Resolution	Io, Ec: dBm. Ec/Io: dB. 0.1 dB
Accuracy	Ec: ±2 dB for $E_c \geq -102$ dBm and $E_c/I_o \geq -12$ dB, typical ±3 dB for $E_c \geq -112$ dBm and $E_c/I_o \geq -14$ dB, typical
Display Controls	Sort by Power (descending Ec value) Sort by Scrambling Code (ascending SC index) Lock (set) current Scrambling Code set

Table 5: Scanner characteristics (cont.)

Characteristic	Description
cdma2000 PN Scanner	Detects PN Offset, Tau (Timing Error) and Pilot Channel power levels of multiple co-channel cdmaOne and/or cdma2000 forward link signals.
Input Signal Range	-120 to +30 dBm, typical
Units	Io, Ec: dBm Ec/Io: dB PN Offset: PN index (0 to 511) Tau: chips
Resolution	Ec, Io, Ec/Io: 0.1 dB PN Offset: 1 PN Tau: 0.1 chip
Accuracy	Ec: ±2 dB for $E_c \geq -95$ dBm and $E_c/I_o \geq -8$ dB, typical ±3 dB for $E_c \geq -110$ dBm and $E_c/I_o \geq -12$ dB, typical Tau: 0.5 chip, of highest power multipath component of each detected PNOS, relative to input timing reference (ESC or YBGPS1), typical.
Display Controls	Sort by Power (descending Ec value) Sort by PN offset (ascending offset values) Lock (set) current PN Offset values

Table 5: Scanner characteristics (cont.)

Characteristic	Description
1xEV-DO PN Scanner	<p>Detects PN Offset, Tau (Timing Error) and Pilot Channel power levels of multiple co-channel 1xEV-DO forward link signals. Up to 10 PN offsets are displayed.</p> <p>Io: The total received power in the pilot intervals of the signal, within the signal bandwidth (1.23 MHz).</p> <p>Ec: The absolute power level of the detected pilot at the indicated PN Offset, in dBm.</p>
Input Signal Range	-120 to +30 dBm, typical
Units	<p>Io, Ec: dBm</p> <p>Ec/Io: dB</p> <p>PN Offset: PN index (0 to 511)</p> <p>Tau: chips</p>
Resolution	<p>Ec, Io, Ec/Io: 0.1 dB</p> <p>PN Offset: 1 PN</p> <p>Tau: 0.1 chip</p>
Accuracy, typical	<p>Ec:</p> <p>± 2.5 dB for $E_c \geq -95$ dBm and $E_c/I_o \geq -8$ dB</p> <p>± 3.5 dB for $E_c \geq -110$ dBm and $E_c/I_o \geq -12$ dB</p> <p>Tau:</p> <p>±0.5 chip, of highest power multipath component of each detected PNOS, relative to input timing reference (ESC or YBGPS1)</p>

Table 5: Scanner characteristics (cont.)

Characteristic	Description
Display Controls	Sort by Power (descending Ec value) Sort by PN offset (ascending offset values) Lock (set) current PN Offset values
GSM Channel Scanner	The GSM channel scanner displays channel power and related information on a maximum of 128 GSM forward link signals. Displays Channel, Frequency, Peak Power, Traffic Type, C/I, and BSIC The scanner is intended for off-air reception using an antenna, and measures only forward (down) link signals. This measurement requires that YBT250 option GS1 is installed.
Input Signal Range	-120 to +30 dBm, typical
Units	Frequency: MHz Peak Power: dBm C/I: dB
Resolution	Frequency: 0.001 MHz Peak Power: 0.1 dBm C/I: 0.1 dB
Accuracy, typical	± 1 dB, -20 dBm to +30 dBm, ± 0.75 dB for identified GSM channels The center frequency is derived from the channel number. C/I is derived from EVM using the following equation: $C/I = -20 * \log_{10}(EVM/100)$

Table 5: Scanner characteristics (cont.)

Characteristic	Description
Display Controls	AutoLevel (graph) Sort table by power or frequency Start and stop channel select Peak hold
TD-SCDMA Scanner	Detects Sync code index, and DwPts Channel power levels of multiple co-channel TD-SCDMA forward link signals. Up to 10 Sync codes are displayed. Io: The total received power in the DwPts of the signal, within the signal bandwidth (1.6 MHz), in dBm. Ec: The absolute power level of the detected DwPts at the indicated Sync Code, in dBm.
Input Signal Range	-120 to +30 dBm, typical
Units	Io, Ec: dBm Ec/Io: dB Sync Code: Sync Code index (0 to 31)
Resolution	Ec, Io, Ec/Io: 0.1 dB Sync Code index: 1 code index offset

Table 5: Scanner characteristics (cont.)

Characteristic	Description
Accuracy, typical	Ec: ± 2.0 dB for $E_c \geq -85$ dBm and $E_c/I_0 \geq -8$ dB ± 3.5 dB for $E_c \geq -105$ dBm and $E_c/I_0 \geq -12$ dB
Display Controls	Sort by Power (descending Ec value) Sort by Sync Code (ascending offset values) Lock (set) current Sync Code values

Table 6: Signal Measurement characteristics

Characteristic	Description
RF Channel Power	Measures the average RF power in a user-defined channel. The default value of channel bandwidth is taken from the selected standard. The acceptable values for channel numbers are taken from the selected standard. The user can input the channel center frequency instead of the channel number.
Units and Resolution	Watts (W), dBm 3 significant digits for W; 0.1 dB for dBm units
Accuracy	± 0.75 dB: -20 dBm to $+30$ dBm, ± 0.5 dB typical ± 1.25 dB: -80 dBm to -20 dBm, ± 1.0 dB typical Reference information: Accuracy is guaranteed for input signals between -80 and $+30$ dBm total power (CW or peak envelope). Accuracy specification is typical down to -120 dBm total power.

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
RF Power (GSM/EDGE)	Measures the average RF power of the useful part of a GSM or EDGE burst (GMSK or 8-PSK modulation), as determined by the location of the burst Training Sequence.
Units and Resolution	dBm: 0.01 dB for dBm units
Accuracy	For GSM or EDGE (GMSK or 8-PSK modulation) burst signals, the RF power measurement accuracy is: ± 1.0 dB: -20 dBm to $+30$ dBm, ± 0.75 dB typical ± 1.5 dB: -80 dBm to -20 dBm, ± 1.25 dB typical Reference information: Burst timing is determined from the location of the burst Training Sequence. If Burst timing cannot be found, the power measurement will be done on an arbitrarily selected segment of the signal equal to the useful part of a slot.
RF Power (1xEV-DO)	Measures the RF power in the Pilot, MAC, and Data intervals of a 1xEV-DO timeslot.
Units and Resolution	dBm: 0.01 dB for dBm units
Accuracy	For burst signals, the RF power measurement accuracy is: ± 1.0 dB: -20 dBm to $+30$ dBm, ± 0.75 dB typical ± 1.5 dB: -80 dBm to -20 dBm, ± 1.25 dB typical
RF Power (TD-SCDMA)	Measures the average RF power on individual timeslots (excluding the guard period) as determined by the location of the downlink pilot timeslot (DwPTS).
Units and Resolution	dBm: 0.01 dB for dBm units

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Accuracy	<p>For burst signals, the RF power measurement accuracy is:</p> <p>± 1.0 dB: -20 dBm to $+30$ dBm, ± 0.75 dB typical</p> <p>± 1.5 dB: -80 dBm to -20 dBm, ± 1.25 dB typical</p> <p>Reference information: Burst timing is determined from the power envelope profile of the DwPTS. If the DwPTS cannot be found, an error message is displayed.</p>
RF Channel Carrier Frequency	Measures the frequency of the carrier in the user selected channel. The user can enter a channel number or frequency.
Units and Resolution	MegaHertz (MHz): 1 Hz
Accuracy	<p>$\pm (10 \text{ Hz} + \text{Time Base Error})$, 99% confidence interval</p> <p>W-CDMA: $\pm (12 \text{ Hz} + \text{Time Base Error})$, 99% confidence interval</p> <p>Note: The carrier frequency must be within 10 kHz of the expected value, except:</p> <p>W-CDMA, 1xEV-DO, and GSM/EDGE: within 5 kHz</p> <p>IS-136: within 1.5 kHz</p> <p>W-CDMA 3GPP Test Model 4</p>
Accuracy using YBGPS1 GPS Timing Reference	<p>$\pm (10 \text{ Hz} + 0.015 \text{ ppm})$, typical</p> <p>Note: The carrier frequency must be within 10 kHz of the expected value, except:</p> <p>W-CDMA, 1xEV-DO, and GSM/EDGE: within 5 kHz</p> <p>IS-136: within 1.5 kHz</p> <p>The GPS antenna and the instrument antenna should be stationary for specified accuracy. Doppler shift of BST frequency is ± 0.09 ppm when the instrument antenna is moving at 60 mph (100 km/hr).</p>

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
FM Deviation	Measures the maximum one-side frequency deviation of the analog FM cellular carrier selected by the user after demodulation. The user can enter a channel number or frequency.
Units and Resolution	kiloHertz (kHz): 0.1 kHz
Accuracy	± 10% for $2 \text{ kHz} \leq \text{Deviation} \leq 10 \text{ kHz}$ Maximum measurable deviation is 15 kHz peak. Maximum modulation frequency is 3 kHz.
PN Offset	Measures the PN Offset of the cdmaOne or cdma2000-1x signal. The user can select the CDMA signal of interest by a channel number or frequency.
Units and Resolution	PN Index: 1 PN Index, where each PN Index is 64 chips
Accuracy	Displayed PN Index must match the PN Offset of the CDMA signal.
Pilot Time Alignment Error (Tau)	Measures the time offset between the PN sequence of the input signal and the External Even Second Clock (on Timing Input connector).
Units and Resolution	Microsecond (μs), Chips: 0.1 μs (1 chip)
Accuracy	± 250 ns typical
Waveform Quality (Rho, ρ)	Measures the waveform quality as defined by IS-97-D using a pilot-only CDMA (or cdma2000-1x) signal.
Units and Resolution	None: 0.0001

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Accuracy	<p>± 0.005, $0.9 \leq \rho \leq 1.0$; Usable range $0.5 \leq \rho \leq 1.0$</p> <p>Degradation due to adjacent channel CDMA carriers (having equivalent power): add ± 0.015.</p> <p>Reference information: The Rho measurement is only specified for a pilot-only CDMA signal. The accuracy specification given here applies only to measurements made on a pilot-only CDMA signal, with the instrument set to use the pilot-only method. For measurements on signals that are not pilot-only, see the Estimated Waveform Quality measurement.</p>
Waveform Quality (Rho Pilot, Rho MAC, Rho Data) (1xEV-DO)	<p>Rho (ρ) for 1xEV-DO signals provides an indication of the signal to distortion ratio for the transmitted signal. This quality measure is an indication of how similar the transmitted signal is to a perfect signal. Rho can vary between 0.0 and 1.0, where 1.0 represents a perfect signal.</p> <p>Rho Pilot is only computed on chips in the Pilot intervals. Pilot Rho is measured on the pilot interval of 20 half slots.</p> <p>Rho MAC is only computed on chips in the MAC interval. Rho MAC is measured on the MAC interval of 20 half slots.</p> <p>Rho Data is only computed on chips in the Data interval. Rho Data is measured on the Data interval of 20 half slots.</p>
Units and Resolution	None: 0.0001
Accuracy	<p>± 0.005, $0.9 \leq \rho \leq 1.0$; Usable range $0.5 \leq \rho \leq 1.0$</p> <p>Degradation due to adjacent channel CDMA carriers (having equivalent power): add ± 0.015.</p>
Estimated Waveform Quality	Measures waveform quality as defined by IS-97-D using any CDMA signal.

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Units and Resolution	None: 0.0001
Accuracy	± 0.01 for rho ≥ 0.9, typical Reference information: The Rho measurement as given in IS-97-D is only specified for a pilot-only CDMA signal. This measurement makes an estimate of the Rho value on any CDMA signal.
Error Vector Magnitude (EVM) (cdmaOne and cdma2000)	The normalized RMS of all of the vectors that extend from the intended constellation points to the actual symbol points in a record of symbols.
Units and Resolution	Percent: 0.01%
Accuracy	±1%; EVM ≤ 31% Degradation due to adjacent channel CDMA carriers (having equivalent power): add 10% Residual error: 5% < 1000 MHz; 7% < 2000 MHz Reference information: These measurements are accurate for both pilot-only and in-service CDMA signals.
Error Vector Magnitude (EVM) (W-CDMA)	The normalized RMS of all of the vectors that extend from the intended constellation points to the actual symbol points in a record of symbols.
Units and Resolution	Percent: 0.01%

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Accuracy (W-CDMA composite)	<p>$\pm 2.5\%$; $12.5\% \leq \text{EVM} \leq 22.5\%$</p> <p>Residual error: $6\% < 1000 \text{ MHz}$; $8\% < 2500 \text{ MHz}$</p> <p>Reference information: The W-CDMA composite refers to a signal with one or more channels using QPSK modulation, or a combination of QPSK and 16QAM modulation. The EVM measurement readout displays the EVM for the composite signal. W-CDMA 3GPP Test Model 4.</p>
(W-CDMA EVM16QAM)	<p>$\pm 1.5\%$; $6.5\% \leq \text{EVM}_{16\text{QAM}} \leq 22.5\%$, typical</p> <p>Residual error: 4%</p> <p>Reference information: The EVM16QAM measurement readout displays the symbol EVM for the code channels using 16QAM modulation.</p>
Synchronization Channel Power (W-CDMA)	Measures the Primary Synchronization Channel (P-SCH) and Secondary Synchronization Channel (S-SCH) power.
Units and Resolution	dBm, W: 0.1 dBm
Carrier Feedthrough	Measures the offset of the constellation from zero power.
Units and Resolution	dB relative to full carrier power: 0.1 dB
Accuracy	<p>cdmaOne and cdma2000: $\pm 2 \text{ dB}$</p> <p>Residual floor: -50 dBc</p> <p>Reference information: For cdmaOne and cdma2000, the carrier feedthrough measurement is valid only for a pilot-only signal.</p>

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Pilot Power	Measures the absolute power of the pilot, without regard to whether other codes are present. (P-CPICH for W-CDMA.)
Units and Resolution	dBm, Watts (W): 0.1 dB
Accuracy	± 1 dB, -20 dBm to +30 dBm ± 1.5 dB, -50 dBm to -20 dBm Reference information: W-CDMA 3GPP Test Model 2.
Sync Power	Measures the absolute power of the W-CDMA sync channel (SCH), without regard to whether other codes are present.
Units and Resolution	dBm, Watts (W): 0.1 dB
Occupied Bandwidth	The Occupied Bandwidth measurement displays the frequency bandwidth within which 99% of the power transmitted on a single channel lies. This measurement can be properly made only if the channel being measured has no channels adjacent to it.
Units and Resolution	Hertz (Hz): Three significant digits
Accuracy	5% of the reading, typical Reference information: For TD-SCDMA signals, OBW is measured for each timeslot.
Adjacent Channel Leakage power Ratio (ACLR) (W-CDMA)	Measures the ratios of the mean RRC filtered power in the 5 MHz BW assigned channel to the mean RRC filtered power in each of the nearest 5 MHz BW 1st and 2nd adjacent upper and lower channels. Adjacent channel centers are offset in multiples of 5 MHz from the assigned channel center. The user can enter the channel center frequency instead of the channel number.

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Units and Resolution	dB: 0.01 dB
Accuracy	± 1.5 dB, $20 \leq \text{ACLR} < 48$ dB, typical ± 2.5 dB, $48 \leq \text{ACLR} < 53$ dB, typical -30 dBm to +20 dBm (power in assigned channel) Reference information: WCDMA Test Model 1 signal (3G PP TS25.141). The filter response is Root-Raised Cosine (RRC), alpha = 0.22, and 3.84 MHz noise BW (3GPP TS25.104).
Error Vector Magnitude (EVM) (GSM/EDGE)	Error Vector Magnitude is the normalized RMS value of all of the vectors that extend from the intended constellation points to the actual symbol points in a record of symbols. The EVM measurement is made over one GSM or EDGE burst.
Units and Resolution	Percent: 0.01%
Accuracy	$\pm 1.5\%$, $4\% \leq \text{EVM} < 10\%$. Residual error: 4.0%
Phase Error (GSM/EDGE)	Phase Error is the RMS value of the differences between the phase angles of the received signal and those of an ideal reconstructed signal. The Phase Error measurement is made over one GSM or EDGE burst.
Units and Resolution	Degrees: 0.01°
Accuracy	± 1.0 , $2 \leq \text{Phase Error} < 12$. Residual error: 2.0
Origin Offset (GSM/EDGE)	Origin Offset is the ratio of unmodulated signal power to modulated signal power. The unmodulated signal component causes the signal constellation center to be offset from the ideal location. The Origin Offset measurement is made over one GSM or EDGE burst.

Table 6: Signal Measurement characteristics (cont.)

Characteristic	Description
Units and Resolution	dB: 0.01 dB
Range	-15 dB to -60 dB
Carrier to Interference (C/I) (GSM/EDGE)	Carrier to Interference (C/I) is the ratio of desired signal (carrier) to undesired signal (interference). The C/I measurement is derived from the EVM result and gives an estimate of the power-based C/I value. The C/I measurement is made over one GSM or EDGE burst.
Units and Resolution	dB: 0.01 dB
Range	0 dB to 50 dB Reference information: C/I is derived from EVM using the following equation: $C/I = -20 * \log_{10}(EVM/100)$
RF Power vs Time (GSM/EDGE)	RF Power vs Time displays the normalized signal envelope power over one GSM or EDGE burst.
Units and Resolution	Symbols: 1 symbol. Microseconds: 1 microsecond.
Time Uncertainty	± 0.2 symbol ± 0.8 microsecond Reference information: Burst to mask alignment is derived from the location of the Training Sequence in the useful part of the burst.

Table 7: Environmental characteristics

Characteristic	Description
Temperature Range	Operating: 0 °C to +50 °C specified performance, -10 °C to +50 °C typical Nonoperating: -40 °C to +60 °C
Humidity	Operating: 5% to 95% Relative Humidity (RH), noncondensing: up to +30 °C Nonoperating: 5% to 45% Relative Humidity (RH), noncondensing: +30 °C up to +50 °C
Altitude	Operating: Up to 4,600 m (15,092 ft.) Nonoperating: Up to 15,240 m (50,000 ft.)

Table 8: Physical characteristics

Characteristic	Description
Dimensions	Height: 25 cm. (9.75 in) Width: 33 cm. (13 in) Depth: 9 cm. (3.5 in)
Weight	5.5 kg (12.125 lbs): Y400, YBT250, and 1 battery

Table 9: Miscellaneous characteristics

Characteristic	Description
Battery Life	One battery installed: 2 hours with measurements active, 4 hours in suspend mode Two batteries installed: 4 hours with measurements active, 8 hours in suspend mode
Recommended Instrument Calibration Interval	2 years

Table 10: Safety compliance

Category	Description
Safety Compliance	ANSI/UL61010-1:2004 Electrical Equipment for Measurement, Control, and Laboratory Use. CSA C22.2 No. 61010.1:2004 Electrical Equipment for Measurement, Control, and Laboratory Use. EN 61010-1:2001 Electrical Equipment for Measurement, Control, and Laboratory Use. IEC61010-1:2001 Electrical Equipment for Measurement, Control, and Laboratory Use. ISA 82.02.01 Electrical Equipment for Measurement, Control, and Laboratory Use.

Certifications and Compliances

EC Declaration of Conformity – EMC

Meets intent of Directive 2004/108/EEC for Electromagnetic Compatibility. Compliance was demonstrated to the following specifications as listed in the Official Journal of the European Communities:

EN 61326:1997. EMC requirements for Class A electrical equipment for measurement, control, and laboratory use. ^{1, 2, 3, 4}

- IEC 61000-4-2:1999. Electrostatic discharge immunity (Performance criterion C)
- IEC 61000-4-3:2002. RF electromagnetic field immunity (Performance criterion A) ⁵
- IEC 61000-4-4:2004. Electrical fast transient / burst immunity (Performance criterion B)
- IEC 61000-4-5:2005. Power line surge immunity (Performance criterion B)
- IEC 61000-4-6:2003. Conducted RF immunity (Performance criterion A) ⁵
- IEC 61000-4-11:2004. Voltage dips and interruptions immunity (Performance criterion B)

EN 61000-3-2:2000. AC power line harmonic emissions

EN 61000-3-3:1995. Voltage changes, fluctuations, and flicker

European Contact.

Tektronix UK, Ltd.
Western Peninsula
Western Road
Bracknell, RG12 1RF
United Kingdom

- 1 **This product is intended for use in nonresidential areas only. Use in residential areas may cause electromagnetic interference.**
- 2 **Emissions which exceed the levels required by this standard may occur when this equipment is connected to a test object.**
- 3 **To ensure compliance with the EMC standards listed here, high quality shielded interface cables should be used.**
- 4 **Minimum Immunity test requirement.**
- 5 **Performance Criteria: Residual spurious signals can increase to -70 dBm with exposure to the disturbance levels of this test.**

Australia / New Zealand Declaration of Conformity – EMC

Complies with the EMC provision of the Radiocommunications Act per the following standard, in accordance with ACMA:

- EN 61326:1997. EMC requirements for electrical equipment for measurement, control, and laboratory use.

Index

Symbols and Numbers

?, 25

A

- AC adapter, 2
- AC adapter, connecting, 4
- Accessories, standard, 1
- Active GPS receiver and maps, 54
- Active GPS, definition, 54
- Adapter, AC, connecting, 4
- Add a marker to a waveform, 38
- Add map coordinates to bitmap file (iMap Converter), 71
- Add signal standards to select list, 12
- Altitude specifications, 2
- Amplifier, RF input signal, 22
- ArcInfo Shape (.shp) map file, 68
- Attenuator, RF input signal, 22
- Audio tab, 47
- Automatic iMap measurements, 64

B

Battery

- charge status, 16
- charge times, 5
- charging, 5
- Bitmap file (iMap), 54
- BMP, 54
- Button
 - Channel measurement mode, 23
 - channel select, 21
 - downlink, 21, 26
 - Edit, 20
 - F EXT, 22
 - F GPS, 22
 - F INT, 22
 - forward link, 21
 - frequency select, 21
 - GPS status, 22
 - help, 25
 - Help, 20
 - iMap log measurements, 64
 - iMap mapping mode, 23
 - log measurements (not iMap), 20
 - log measurements, iMap, 64
 - measurement mode, 23

- measurement reference
 - frequency status, 22
- Open, 20
- Pause, 20
- PN Sync status, 22
- power on/standby, 16
- reset, 16
- reverse link, 21
- RF input signal gain/loss, 22
- Run, 20
- save results, 20
- signal measurement mode, 23
- spectrum measurement
 - mode, 23
- traces, 39
- uplink, 21, 26

C

- Calibrate the touch screen, 8
- Change the spectrum graph reference level, 33
- Change the spectrum graph vertical scale, 33
- Changing

- application screen colors for
 - printing, 11
 - numbers in fields, 24
- Channel measurement mode
 - button, 23
- Channel select button, 21
- Charging the batteries, 5
- Cleaning the instrument, 3
- Clock, Even Second, 18
- Color, iMap measurement icons, 59
- Command bar, 19, 20
- Comparing live and saved waveforms, 40
- Comparing two live waveforms, 40
- Comparing two saved waveforms (spectrum), 42
- Concepts, touch screen, 7
- Connecting the AC adapter, 4
- Connectors
 - input & output (Y400), 17
 - Reference Frequency Input, 18
 - RF Input, 18
 - Timing Input, 18
 - YBT250 module, 18
- Conventions used in this manual, x
- Converting maps to GSF, 68

D

- Definition
 - active GPS receiver, 54
 - grid map, 54
 - image map, 54
- DeleteMap measurement icons, iMap, 60
- Dimensions, 2
- Direction arrow, iMap, 61
- Display a Spectrogram, 44
- Display a spectrum waveform, 31
- Displaying
 - power on/off status, 16
- Displaying markers, 34
- Documentation, ix
- Downlink button, 21, 26
- Drag, 7
- Drawing a map measurement direction arrow, 61

E

- Edit button, 20
- Enabling signal standards, 12
- Entering numbers in fields, 24
- ESC, 18

- Ethernet connector (RJ-45), 17
- Even Second Clock, 18
- External Reference status button, 19
- External RF input signal amplifier, 22
- External RF input signal attenuator, 22
- External timing reference signal input, 18

F

- Forward link button, 21
- Frequency reference input specification, YBT250, 76
- Frequency select button, 21
- Front Trace (marker), 35
- Functional verification, 6

G

- Getting help on measurements, 25
- GPS status button, 19, 22
- GPS, active, definition, 54
- Grid map, 54
- .gsf, 54
- GSF, 54
- GSF, converting maps to, 68

H

Headphone jack, 17

Help

- accessing online help, 25
- button, 20
- link text, 25

Humidity operation specifications, 2

I

Image map, 54

iMap

- automatic map measurements, 64
- delete measurement icons, 60
- direction arrow, drawing, 61
- draw a direction arrow, 61
- icon color, 59
- icon types, 59
- loading a map file, 55
- log measurements button, 64
- logging measurements, 64
- map file concepts, 54
- mapping a measurement, 56
- mapping mode button, 23
- measurement icon color, 59

- measurement icon types, 59
- measurement icons, delete, 60
- measurement icons, viewing, 60
- measurement mapping, 56
- move a measurement icon, 56
- tool overview, 53
- viewing mapped measurement icons, 60

iMap Converter, 68

- add coordinates to an image file, 71
- Set coordinates, 71

Improve measurement accuracy, 18

Indoor color scheme, 11

Input field entry controls, 24

Input signal characteristics, 2

Input/Output connectors, 17

Installation, 1

Instrument cleaning, 3

Instrument elements, 15

Interference measurements

- Audio, 47

- Noise, 48

- Strength, 46

Interfering signal audio

- demodulation, 47

K

Key features, viii

Keypad button, 24

Knob control, 24

L

Lightning, preventing personal injury, xi

Listening to an interfering signal, 47

Live and saved waveforms, comparing, 40

Loading a map file, 55

Locating an interfering signal, 46

Log measurements button (not iMap), 20

Log measurements button, iMap, 64

Logging iMap measurements, 64

M

Map file concepts, 54

Map file conversion program, 68

MapInfo Interchange Format (.mif) map file, 68

Mapping a measurement, 56

Markers

- absolute marker readouts, 37
- add a marker to a waveform, 38
- delta marker readouts, 37
- displaying, 34
- Front Trace, 35
- marker readout scroll buttons, 36
- measurement mode, 37
- overview, 34
- selecting which markers to display, 35
- setup, 35
- Trace 1, 35
- Trace 2, 35
- turning on or off, 34
- View > Marker Setup, 35

Measurement

- mode buttons, 19, 23
- reference frequency status button, 22
- results screen, 19

Measurement icon colors, iMap, 59

Measurement icon direction arrow, iMap, 61

Measurement icon types, iMap, 59

Measurement icons, iMap, deleting, 60

Measurement icons, iMap, viewing, 60

Measurement mapping, iMap, 56

Measuring noise floor (interference), 48

Menus, 20

Microphone input, 17

Microsoft WindowsCE user interface, 18

.mif, 54

MIF, 54

Move a measurement icon, iMap, 56

N

Noise floor measurement, 48

Noise tab, 48

O

Online help, 25

Open button, 20

Opening RF Scout, 10

Operating considerations, 2

Outdoor color scheme, 11

Overview, iMap, 53

P

Parameter entry controls, 19, 24

Parts of the instrument, 15

Pause button, 20

PN Sync status button, 22

Power adapter, 2

Power On/Standby button, 16

Power/Display status, 16

Powering on and off the instrument, 6

Preventing personal injury from lightning, xi

PS/2 keyboard connector, 17

R

Readout scroll buttons, marker, 36

Ref Lvl, 33

Reset button, 16

Reverse link button, 21

RF input

- characteristics, 2
- signal connector, 18
- signal gain/loss button, 22
- YBT250, 75

RF Signal Gain/Loss status button, 19

Run button, 20

Running RF Scout, 10

S

- Safety Summary, iii
- Save results button, 20
- Saved waveforms, comparing (spectrum), 42
- Screen display colors, 11
- Select which markers to display, 35
- Selecting signal standard to measure, 21
- Selecting waveforms (traces), 39
- Serial RS-232 connector, 17
- Set Coordinates (iMap Converter), 71
- Set which markers to display, 35
- Setting
 - display colors, 11
 - signal standards, 12
 - the channel number, 21
 - the measurement frequency, 21
 - to take a measurement, 26
- Setup dialog box, 31
- Signal audio demodulation, 47
- Signal input characteristics, 2
- Signal input connectors
 - Reference Frequency Input, 18
 - RF Input, 18
 - Timing Input, 18
- Signal locating (interference), 46

- Signal measurement mode button, 23
- Signal standard selection list, 21
- Software upgrades, x
- Specifications, 75
- Spectrogram, displaying, 44
- Spectrum
 - absolute marker readouts, 37
 - add a marker to a waveform, 38
 - change graph reference level, 33
 - change graph vertical scale, 33
 - comparing live and saved waveforms, 40
 - comparing two live waveforms, 40
 - comparing two saved waveforms, 42
 - delta marker readouts, 37
 - display a spectrogram, 44
 - displaying markers, 34
 - Front Trace marker mode, 35
 - marker readout scroll buttons, 36
 - markers overview, 34
 - measurement mode, 37
 - saved waveforms, comparing, 42
 - selecting waveforms (traces), 39
 - selecting which markers to display, 35

- setup markers, 35
- take a measurement, 31
- Trace 1 marker mode, 35
- Trace 2 marker mode, 35
- traces button, 39
- turning on or off markers, 34
- View > Marker Setup, 35
- waveforms (traces), selecting, 39
- Spectrum measurement mode
 - button, 23
- Standard accessories, 1
- Starting RF Scout, 10
- Status panel, 16
- Strength tab, 46
- Stylus, 7

T

- Tab
 - Audio (Interference mode), 47
 - Noise (Interference mode), 48
 - Strength (Interference mode), 46
- Taking a channel measurement, 49, 73
- Taking a spectrum measurement, 31
- Tap, 7

Temperature range operation
 specifications, 2
Timing input specification, YBT250, 77
Touch screen
 calibrate, 8
 concepts, 7
 on/off status, 16
Trace 1 (marker), 35
Trace 2 (marker), 35
Traces button, 39
Tuning controls, 19, 21
Turning on or off markers, 34

U

Underlined blue text, 25
Unpack the instrument, 1
Updates button (spectrogram), 44
Upgrades, software, x
Uplink button, 21, 26
USB Host connector, 17
USB Slave connector, 17
User interface
 command bar, 19, 20

External Reference status
 button, 19
GPS status button, 19
Measurement mode buttons, 19
measurement results screen, 19
menus, 20
overview, 19
Parameter entry controls, 19
RF Signal Gain/Loss status
 button, 19
 tuning controls, 19
USGS Digital Line Graph (.opt) map
 file, 68

V

Verifying instrument functionality, 6
Vertical Scale, 33
Viewing measurement icons, iMap, 60

W

Waveforms
 add a measurement marker, 38

 change graph reference level, 33
 change graph vertical scale, 33
 comparing, 39
 comparing live and saved
 waveforms, 40
 comparing two live
 waveforms, 40
 comparing two saved
 waveforms, 42
Waveforms (traces), selecting, 39
Weight, 2

Y

Y400 user interface elements, 18
YBT250 module connectors
 FREQUENCY REFERENCE
 input specification, 76
 Reference Frequency Input, 18
 RF Input, 18
 RF input specification, 75
 Timing Input, 18
 TIMING input specification, 77